



Now a part of Seagate Technology

CDC® STORAGE MODULE DRIVE

BK4XX

BK5XX

**INSTALLATION AND CHECKOUT
MAINTENANCE
PARTS DATA**

Volume 1 of 2

HARDWARE MAINTENANCE MANUAL

REVISION RECORD

REVISION	DESCRIPTION
01 (9-29-76)	Preliminary manual released
02 (10-26-76)	Added electronic package repair and replacement information, additional parts data information, and corrections.
03 (12-1-76)	Added corrections, test and adjustment information, and checkout information.
A (12-15-76)	Manual released including ECOs 48092, 48113C, 48151, 48155, 48196A, 48200, 48210, 48211, 48240B, 48242, 48256, 48351.
B (1-18-77)	Manual updated to include technical and editorial changes.
C (3-22-77)	Manual updated to include Engineering Change Orders 48322, 48365A, 48436. Technical and editorial changes.
D (5-10-77)	Manual updated to include Engineering Change Orders 48519, 48437; Field Change Order 48518. Technical and editorial changes.
E (8-1-77)	Manual updated to include Engineering Change Orders 48477, 48478, 48576; Field Change Order 48477. Technical and editorial changes.
F (10-10-77)	Manual updated to include Engineering Change Orders 48574, 48604, 48630, 48635, 48716. Technical and editorial changes.
G (11-30-77)	Manual updated to include Engineering Change Orders 48744A and 48746. Technical and editorial changes.
H (2-28-78)	Manual updated to include Engineering Change Orders 48499, 48863, 48896, 48941, 48966. Editorial changes.

REVISION LETTERS I, O, Q
AND X ARE NOT USED.

©1976, 77, 78, 79, 80, 81, 82, 83,
84, 85
By Control Data Corporation
Printed in the United States
of America

Address comments concerning this
manual to:

Control Data Corporation
Twin Cities Disk Division
Customer Documentation Dept.
5950 Clearwater Drive
Minnetonka MN. 55343
or use Comment Sheet in the back
of this manual.

REVISION RECORD (Contd)

REVISION	DESCRIPTION
J (4-12-78)	Manual updated to include Engineering Change Orders 48953, 48798A; Field Change Order 55044. Technical and editorial changes.
K (4-21-78)	Manual updated to include ECOs 55087 (Release BK4A1D & BK5A1D), 55112, 55157, and 55162. Update also includes other technical and editorial changes.
L (10-10-78)	Manual updated to include ECOs 55116A and 55155B. Update includes technical and editorial changes. Update also includes addition of Appendixes A and B.
M (1-16-79)	Manual updated to include ECOs 55392, 55315, 55448, 55450, 55310, 55280, 55438, 55549, 55393, 55350, 55492A, 55522, FCO 55492 plus additional technical changes. This revision obsoletes all previous editions.
N (4-2-79)	Manual updated with ECOs 55630, 55520, 55534, 55687, 55631, plus additional technical and editorial changes.
P (6-15-79)	Manual updated with ECOs 55742A, 55633A, 55728, 55658, 55663A, 55273, 55248A, 55682, 55476A, 55697A, 55523B, 55743, plus additional technical and editorial changes. This revision obsoletes all previous editions.
R (9-4-79)	Manual updated with ECOs 55785, 55804, 55821, 55835, 55810, plus additional technical and editorial changes.
S (11-5-79)	Manual updated with ECOs 55812, 55912, 55854, 55923, 55909, 55925, 55839, 55924, 55883, 55914, 55886, plus additional technical and editorial changes.
T (11-15-79)	Manual updated with ECOs 55887B, 55898, 55980, 55982, plus additional technical and editorial changes.
U (4-25-80)	Manual updated with ECOs 55992, 55966, 55956, 55980, 60000, 55844, 60031, 60032, 60001, 60015, 60028, 60043, 55981, plus additional technical and editorial changes.

REVISION RECORD (Contd)

REVISION	DESCRIPTION
V (5-29-80)	Manual updated with ECOs 60136, 60115A, 60137, 60114, 60003A, 60044B, FCO 60044 plus additional technical and editorial changes.
W (9-25-80)	Manual updated with ECOs 60171, 60169, 60204, 60154, 55952A, 60140 and 60156. This revision obsoletes all previous editions.
Y (12-8-80)	Manual updated with ECOs 60155, 60288, 60246, 60240, plus additional technical and editorial changes.
Z (4-1-81)	Manual updated with ECOs 60381, 60324, 60337, 60253A, FCO 60378, plus additional technical and editorial changes.
AA (5-12-81)	Manual updated with ECO's 60392, 60453, 60450, 60467, FCO 60392, plus additional technical and editorial changes.
AB (9-28-81)	Manual updated with ECO's 60448, 60462, 60463, FCO 60448, plus additional technical and editorial changes.
AC (12-22-81)	Manual updated with ECO's DJ00007, DJ00015, DJ00022, DJ00023, DJ00026, DJ00043, PE 60499, plus additional technical and editorial changes. This revision obsoletes all previous editions.
AD (3-22-82)	Manual updated with ECO's DJ00021, DJ00030, DJ00046, DJ00075, DJ00085, DJ00099, DJ00180, DJ00207, DJ00219, plus additional technical and editorial changes.
AE (4-27-82)	Manual updated with ECO's DJ00143, DJ00169, DJ00198, DJ00199 plus additional technical and editorial changes.
AF (5-13-82)	Manual updated with ECO's DJ00240, DJ00275 plus additional technical and editorial changes.
AG (6-2-82)	Manual updated with ECO DJ00282, FCO DJ00282 plus additional technical and editorial changes.
AH (7-30-82)	Manual updated with ECO DJ00309, plus editorial changes.
AJ (1-17-83)	Manual updated with ECO's DJ00363, DJ00366, DJ00367, DJ00380 plus additional technical and editorial changes.
AK (2-19-83)	Manual updated with ECO DJ00443, plus editorial changes.
AL (6-8-83)	Manual updated with ECO's DJ00228E, DJ00393, DJ00436, DJ00485 plus additional technical and editorial changes.

REVISION RECORD (Contd)

REVISION	DESCRIPTION
AM (10-31-83)	Manual updated with ECOS DJ00463A, DJ00464A, DJ00477A, DJ00483A, DJ00490, DJ00491A, DJ00492A, DJ00517 plus additional technical and editorial changes. This revision obsoletes all previous editions.
AN (02-16-84)	Manual updated with ECO's DJ00533A, DJ00535, DJ00564A plus additional technical and editorial changes.
AP (09-04-84)	Manual updated with ECOS DJ00603, DJ00399A plus additional technical and editorial changes.
AR (01-31-85)	Manual updated with ECOS DJ00660, DJ00661, DJ00645, DJ00771 plus FCO DJ00590 (class II ECOS DJ00368, 356, 433, 654, 774, 812). Technical and editorial changes.

MANUAL TO EQUIPMENT LEVEL CORRELATION

This manual reflects the equipment configurations listed below.

EXPLANATION: Locate the equipment type and series code number, as shown on the equipment FCO log, in the list below. Immediately to the right of the series code number is an FCO number. If that number and all of the numbers underneath it match all of the numbers on the equipment FCO log, then this manual accurately reflects the equipment.

This correlation sheet also applies to the following related manuals:

Pub No. 83322240 Rev. Y
 Pub No. 83322250 Rev. T

EQUIPMENT TYPE	SERIES CODE	WITH FCOs	COMMENTS
BK4XX/BK5XX	10	None	Optional
	11	None	
	12	None	
	13	None	
	14	None	
	15	None	
	16	48477 48518A	
	17	None	
	18	None	
	19	55172	
	20	55044	
	21	None	
	22	55112 55157 55422	
	23	None	
24	55492	S/C 24 only	
25	None		
26	None		
27	None		

MANUAL TO EQUIPMENT LEVEL CORRELATION (Contd)

EQUIPMENT TYPE	SERIES CODE	WITH FCOs	COMMENTS
	28	None	
	29	60378	S/C 29-36 only
	30	None	
	31	None	
	32	60044	S/C 24-32 BK4B7A/B only
	33	None	
	34	None	
	35	None	
	36	None	
	37	60392	
	38	60448	S/C 20-38 BK4B7A/B, BK5C1E/F/J/K only
	39	None	
	40	None	
	41	DJ00201	
	42	None	
	43	DJ00282	
	44	None	
	45	None	
	46	None	
	47	None	
	48	None	
	49	None	
	50	None	
	51	None	
	52	DJ00590	BK5A5V/W S/C 01-52

LIST OF EFFECTIVE PAGES

Sheet 1 of 8

New features, as well as changes, deletions, and additions to information in this manual are indicated by bars in the margins or by a dot near the page number if the entire page is affected. A bar by the page number indicates pagination rather than content has changed.

<u>PAGE</u>	<u>REV</u>	<u>PAGE</u>	<u>REV</u>
Cover	-	Blank	-
Blank	-	xxxiii	AR
Title P	-	xxxiv	AR
ii	AR	xxxv	AR
iii	AD	Blank	-
iv	AL	xxxvii	AR
iv.i	AR	xxxviii	AR
Blank	-	xxxix	AR
v	AP	xL	AR
vi	AR	xLi	AR
vii	AR	xLii	AR
viii	AR	xLiii	AR
ix	AR	Blank	-
x	AR	xLv	AR
xi	AR	xLvi	AR
xii	AR	S-1 Div	-
xiii	AR	Blank	-
xiv	AP	1-1	AP
xv	AJ	1-2	AP
xvi	AL	1-3	AP
xvii	AR	1-4	AP
xviii	AR	1-5	AP
xix	AR	1-6	AP
xx	AR	1-7	AP
xxi	AR	1-8	AP
xxii	AR	1-9	AP
xxiii	AR	1-10	AP
xxiv	AR	1-11	AP
xxv	AR	1-12	AP
xxvi	AR	1-13	AP
xxvii	AR	1-14	AP
xxviii	AR	1-15	AP
xxix	AR	1-16	AP
Blank	-	1-17	AP
xxxi	AR	1-18	AP

LIST OF EFFECTIVE PAGES (Contd)

Sheet 2 of 8

<u>PAGE</u>	<u>REV</u>	<u>PAGE</u>	<u>REV</u>
1-19	AP	2-7	AR
1-20	AR	2-8	AR
1-21	AR	2-9	AR
1-22	AR	2-10	AL
1-23	AR	2-11	AL
1-24	AP	2-12	AL
1-25	AP	2-13	AL
1-26	AP	2-14	AL
1-27	AP	2-14.1	AL
1-28	AP	2-14.2	AL
1-29	AP	2-14.3	AL
1-30	AP	2-14.4	AN
1-31	AP	2-15	AR
1-32	AP	2-16	AR
1-33	AP	2-17	AR
1-34	AP	2-18	AL
1-35	AP	2-19	AL
1-36	AP	2-20	AL
1-37	AP	2-21	AL
1-38	AP	2-22	AL
1-39	AP	2-23	AL
1-40	AP	2-24	AL
1-41	AP	2-25	AL
1-42	AP	2-26	AL
1-43	AP	2-27	AL
1-44	AP	2-28	AL
1-45	AP	2-29	AL
1-46	AP	2-30	AL
1-47	AP	2-31	AL
1-48	AP	2-32	AL
1-49	AP	2-33	AL
Blank	-	2-34	AL
S-2 Div	-	2-35	AL
Blank	-	2-36	AL
2-1	AC	2-37	AL
Blank	-	2-38	AL
S-2A Div	-	2-39	AL
Blank	-	2-40	AL
2-3	AL	2-41	AL
2-4	AR	2-42	AL
2-5	AR	2-43	AL
2-6	AR	2-44	AR

LIST OF EFFECTIVE PAGES (Contd)

Sheet 3 of 8

<u>PAGE</u>	<u>REV</u>	<u>PAGE</u>	<u>REV</u>
2-45	AR	2-83	AB
2-46	AR	2-84	AC
2-47	AR	2-84.1	AR
2-48	AR	Blank	-
2-49	AR	S-2D Div	-
Blank	-	Blank	-
S-2B Div	-	2-85	AR
Blank	-	2-86	AR
2-51	AL	2-87	AR
2-52	AL	2-88	AC
2-53	AL	2-89	AC
2-54	AL	2-90	AC
2-55	AL	2-91	AC
2-56	AL	2-92	W
2-57	AL	2-93	AC
2-58	AL	2-94	W
2-59	AL	2-95	AR
Blank	-	2-96	AR
S-2C Div	-	2-97	AR
Blank	-	2-98	W
2-61	AP	2-99	AC
2-62	AC	2-100	AC
2-63	AC	2-101	AC
2-64	AC	2-102	AC
2-65	AJ	2-103	AC
2-66	Y	2-104	AC
2-67	AP	2-105	AC
2-68	AP	2-106	AC
2-69	W	2-107	AR
2-70	W	2-108	AR
2-71	AB	2-109	AR
2-72	Y	2-110	AR
2-73	Y	2-111	AR
2-74	AM	2-112	AC
2-75	AC	2-113	Z
2-76	W	2-114	AC
2-77	AC	2-115	AC
2-78	W	2-116	AJ
2-79	AC	2-117	AJ
2-80	AC	2-118	AD
2-81	W	2-119	AC
2-82	W	2-120	AC

LIST OF EFFECTIVE PAGES (Contd)

Sheet 4 of 8

<u>PAGE</u>	<u>REV</u>	<u>PAGE</u>	<u>REV</u>
2-121	AP	3-15	AM
2-122	AP	3-16	AR
2-123	AP	3-16.1	AR
2-124	AA	3-16.2	AR
2-125	AP	3-17	AR
2-126	AP	3-18	AM
2-127	AP	3-19	AM
2-128	W	3-20	AR
2-129	W	3-21	AM
2-130	AP	3-22	AR
2-131	AP	3-22.1	AR
2-132	AP	3-22.2	AR
2-133	AP	3-23	AR
2-134	AR	3-24	AR
2-135	AR	3-25	AM
2-136	AR	3-26	AR
2-137	AR	3-27	AR
2-138	AR	3-28	AR
2-139	AP	3-29	AM
2-140	AP	3-30	AR
2-141	AP	3-31	AM
2-142	AP	3-32	AR
S-3 Div	-	3-33	AR
Blank	-	Blank	-
3-1	AC	3-35	AR
Blank	-	3-36	AR
S-3A Div	-	3-37	AM
Blank	-	3-38	AR
3-3	AC	3-38.1	AR
3-4	AC	Blank	-
3-5	AR	3-38.3	AR
3-6	AM	3-38.4	AR
3-7	AR	3-39	AR
3-8	AR	Blank	-
3-8.1	AN	3-41	AM
Blank	-	3-42	AR
3-9	AR	3-43	AR
3-10	AM	Blank	-
3-11	AR	3-45	AR
3-12	AR	3-46	AN
3-13	W	3-47	AR
3-14	AR	Blank	-

LIST OF EFFECTIVE PAGES (Contd)

Sheet 5 of 8

<u>PAGE</u>	<u>REV</u>	<u>PAGE</u>	<u>REV</u>
3-49	AR	3-89	AR
3-50	AN	3-90	AR
3-51	AR	3-91	AR
3-52	AR	3-92	AR
3-53	AN	3-93	AR
3-54	AN	3-94	AR
3-55	AM	3-95	AM
Blank	-	3-96	AM
3-57	AN	3-97	AP
3-58	AN	3-98	AR
3-59	AN	3-99	AR
3-60	W	3-100	AR
3-61	AM	3-101	AP
3-62	AR	3-102	AP
3-62.1	AR	3-102.1	AR
Blank	-	3-102.2	AR
3-63	AR	3-103	AP
3-64	AP	3-104	AR
3-65	AP	3-105	AR
3-66	AR	Blank	-
3-67	AR	3-107	AR
3-68	AR	3-108	AR
3-69	AR	3-109	AR
3-70	AN	Blank	-
3-71	AM	3-111	AR
3-72	AR	3-112	AR
3-73	AP	3-113	AR
Blank	-	Blank	-
3-75	AR	3-115	AR
3-76	W	3-116	AR
3-77	AR	3-117	AR
3-78	AR	Blank	-
3-79	AR	3-119	AR
3-80	AR	3-120	AR
3-81	AR	3-121	AM
3-82	AR	3-122	AR
3-83	AP	3-123	AN
3-84	AR	3-124	AJ
3-85	AR	3-125	AM
3-86	AP	3-126	AR
3-87	AP	3-127	AM
3-88	AR	3-128	AR

LIST OF EFFECTIVE PAGES (Contd)

Sheet 6 of 8

<u>PAGE</u>	<u>REV</u>	<u>PAGE</u>	<u>REV</u>
3-129	AR	3-169	AR
3-130	AR	3-170	AR
3-131	AR	3-171	AR
3-132	AR	3-172	AR
3-133	AM	3-173	AR
3-134	AR	Blank	-
3-135	AP	3-175	AM
3-136	AR	3-176	AR
3-137	AP	3-177	AR
3-138	AR	3-178	W
3-139	AM	3-178.1	AR
Blank	-	Blank	-
3-141	AR	3-179	AR
3-142	AM	3-180	AR
3-143	AM	3-181	AR
Blank	-	Blank	-
3-145	AR	S-3B Div	-
3-146	AR	Blank	-
3-146.1	AR	3-183	AM
Blank	-	3-184	AM
3-147	AR	3-185	AP
3-148	AR	3-186	AP
3-149	AM	3-187	AP
3-150	AR	3-188	AR
3-151	AR	3-189	Y
Blank	-	3-190	Y
3-153	AR	3-191	AP
3-154	AR	3-192	AP
3-155	AM	3-193	AP
Blank	-	3-194	AP
3-157	AM	3-195	AP
3-158	AN	3-196	AP
3-159	AM	3-197	AP
Blank	-	3-198	AP
3-161	AM	3-199	AP
3-162	AM	3-200	AP
3-163	AN	3-201	AP
Blank	-	3-202	AP
3-165	AR	3-203	AP
3-166	AR	3-204	AP
3-167	AM	3-205	AP
3-168	AR	Blank	-

LIST OF EFFECTIVE PAGES (Contd)

Sheet 7 of 8

<u>PAGE</u>	<u>REV</u>	<u>PAGE</u>	<u>REV</u>
App A Div	-	A-31	AC
Blank	-	Blank	-
A-i	W	App B Div	-
Blank	-	Blank	-
A-1	AC	B-i	W
A-2	AC	Blank	-
A-3	AC	B-1	AC
A-4	W	B-2	AC
A-5	W	B-3	AC
Blank	-	B-4	AC
DLT Div	-	B-5	W
Blank	-	B-6	W
A-7	AP	DLT Div	-
A-8	L	Blank	-
A-9	L	B-7	L
A-10	L	B-8	L
A-11	L	B-9	L
A-12	L	B-10	L
A-13	L	B-11	L
A-14	L	B-12	L
A-15	L	B-13	L
A-16	L	B-14	L
A-17	L	B-15	L
A-18	L	B-16	L
A-19	L	B-17	L
A-20	L	B-18	L
Procedures	-	B-19	L
Blank	-	B-20	L
A-21	AC	B-21	L
A-22	AC	B-22	L
A-23	AC	B-23	L
A-24	AC	Blank	-
A-25	AC	Procedures	-
A-26	AC	Blank	-
A-27	AC	B-25	AC
A-28	AC	B-26	W
A-29	AC	B-27	AC
A-30	AC	B-28	AC

LIST OF EFFECTIVE PAGES (Contd)

Sheet 8 of 8

<u>PAGE</u>	<u>REV</u>	<u>PAGE</u>	<u>REV</u>
B-29	AC		
B-30	W		
B-31	AC		
B-32	AC		
B-33	AC		
B-34	AC		
B-35	AC		
Blank	-		
Cmt Sht	-		
Rtn Env	-		
Blank	-		
Cover	-		

PREFACE

This manual contains maintenance information applicable to all the Storage Module Drives (SMDs) listed in the configuration charts (found following the table of contents). The configuration charts define each of the equipments covered by this manual in terms of cabinet mounting styles, cabinet colors, and the various electronic features provided. Since this manual covers all of the various configurations available on the SMD; it is necessary to understand exactly which configuration you have, in order to know which procedures in this manual are applicable to your drive.

This manual provides information relating to the field level maintenance of the SMDs; that is, maintenance which can be performed on the SMD at the installation site. The manual assumes that the reader is already trained in the use of normal mechanical and electronic repair equipment; and is familiar with the basic maintenance procedures, such as soldering, wirewrapping, etc. Also, the procedures contained in this manual are written assuming that the reader knows where all the various parts of the drive are located, what they are called, and how to open the drive to get at them. Anyone not familiar with this type of information is referred to the General Maintenance Information in Section 2.

Information in this manual is divided into three sections:

- Section 1 - Installation and Checkout
- Section 2 - Maintenance
- Section 3 - Parts Data

Other manuals, also applicable to the SMDs covered in this manual, are as follows, and are available from Control Data Literature Distribution Services, 308 North Dale Street, St. Paul MN 55103.

Publication No.	Title
83322250	Hardware Maintenance Manual Volume 2, Diagrams and Wire Lists. Applicable to BK4XX
83322240	Hardware Maintenance Manual, Volume 2, Diagrams and Wire Lists. Applicable to BK5XX

PREFACE (Contd)

Publication No.	Title
83322200	Hardware Reference Manual, General Description, Operation, Theory of Operation, Discrete Component Circuits
83322440	CDC Microcircuits Manual Volume 1, Functional Descriptions of Integrated Circuits.
83324440	CDC Microcircuits Manual Volume 2, Functional Descriptions of Integrated Circuits.
83323770	A Guide for the Disk Drive Operator

WARNING

To ensure the integrity of safety features built into these drives, installation and maintenance must be performed only by qualified service personnel using designated CDC/MPI parts. Also, in case of fire or other emergency, isolate the drives from main power by disconnecting the drive power plugs from their site power receptacles. In situations where pulling the plugs is not possible or practical (such as in a rack mount installation), use the system main power disconnect to isolate the drives from main power.

WARNUNG

Um das einwandfreie Funktionieren der eingebauten Schutzvorrichtungen zu gewährleisten, darf die Installation und Wartung nur von qualifiziertem Service-Personal unter Verwendung von Original CDC/MPI Teilen durchgeführt werden. Beim Ausbrechen von Feuer oder in anderen Notfällen ist die Verbindung zum Hauptstromnetz dadurch zu unterbrechen, dass die Stecker der Antriebe aus den Steckdosen gezogen werden. Sollte dies nicht möglich oder unpraktisch sein (z. B. dann, wenn die Stationen übereinander installiert sind), ist der Hauptstromunterbrecher des Systems zu bedienen, um die Antriebe vom Hauptstromnetz zu trennen.

CONTENTS

Important Safety Information and Precautions	xxxix
Configuration Charts	xxxiii
Abbreviations	xLv
1. INSTALLATION AND CHECKOUT	
Introduction	1-1
Site Preparation	1-1
General	1-1
Space and Clearance	1-2
Environment	1-2
Power Requirements	1-6
Normal Requirements	1-6
Special Requirements for 3 Phase, 4 Wire, Wye Site Power	1-10
General	1-10
Specifications for Neutral Conductor	1-10
Limiting Branch and Feeder Circuit Load Currents	1-10
Grounding	1-10
Safety Ground	1-11
System Ground	1-11
I/O Cables and Terminators	1-12
Packaging	1-15
Installation Procedures	1-18
General	1-18
Preinstallation Inspection	1-19
Cabinet Modification	1-20
Slide Installation	1-22
Latch Installation	1-22
Cabinet Leveling	1-22
System Grounding	1-23

General	1-23
Floor Grid Grounding	1-23
Star Grounding	1-27
Daisy Chain Grounding	1-28
Transformer Wiring	1-28
AC Power Cords	1-29
System I/O Cabling	1-29
Cabling Connections	1-29
Securing Flat I/O Cables	1-33
Securing Round I/O Cables	1-33
Pedestal and Acoustic I/O Units	1-34
Acoustic Drawer and Rack Mount Units	1-35
Routing Sector and Index Signals	1-39
Routing Signals To A Cable	1-39
Routing Signals To B Cable	1-39
Setting Sector Select Switches	1-40
Checkout	1-48
2. MAINTENANCE	
Introduction	2-1
2A. GENERAL MAINTENANCE INFORMATION	
General	2-3
Warnings and Precautions	2-4
Head/Disk Special Precautions and Procedures	2-5
General	2-5
Precautions	2-6
Detection and Recovery	2-9
General	2-9
Head Crash Detection	2-10
Guide for Determining the Cause of Head Crashes	2-11
Recovery from a Head Crash	2-14
Electrostatic Discharge Protection	2-14.1
Maintenance Tools and Materials	2-14.2
General	2-14.2

Disk Packs	2-14.3
Field Test Unit	2-14.3
Head Alignment Kit	2-19
System Software	2-22
Maintenance Controls and Test Points	2-22
General	2-22
Maintenance Controls	2-22
Test Points	2-26
Standard Test Conditions	2-27
General	2-27
Power On/Power Off	2-27
Online/Offline	2-33
Single Channel	2-33
Dual Channel	2-33
Disconnecting I/O Cables	2-34
Manual Carriage Positioning	2-34
Accessing Drive For Maintenance	2-35
General	2-35
Pack Access Cover Opening and Closing	2-36
Case Assembly Opening And Closing	2-37
Acoustic Top Case Opening	2-37
Acoustic Top Case Closing	2-42
Pedestal Case Opening	2-42
Pedestal Case Closing	2-43
Normal Case Opening	2-43
Normal Case Closing	2-44
Raising and Lowering Deck	2-44
Raising and Lowering Logic Chassis - S/C 16 & Below	2-48
Raising and Lowering Logic Chassis - S/C 17 & Above	2-49
2B. PREVENTIVE MAINTENANCE	
General	2-51
Preventive Maintenance Procedures	2-52
General	2-52

General Cleaning	2-53
Clean Primary Filter	2-53
Replace Absolute Filter	2-54
Testing Absolute Filter	2-55
Replacing Absolute Filter	2-56
Clean Shroud and Spindle	2-57
Clean and Lubricate Lockshaft	2-57
Inspect and Clean Rails and Bearings	2-57
Check Power Supply Output	2-59
Check Head Alignment	2-59
2C. TESTS AND ADJUSTMENTS	
General	2-61
Plus and Minus 5 Volt Adjustment (3 Card Power Supply)	2-62
Plus and Minus 5 Volt Adjustment (2 Card Power Supply)	2-63
Head Alignment	2-65
General	2-65
Initial Setup	2-67
Servo Head Offset Check	2-68
Read/Write Heads Check and Adjustment	2-72
Velocity Gain Adjustment (40 MB)	2-75
Procedure A. With BLQV Or LLQV	2-75
Procedure B. With MLQV Or Later	2-80
Velocity Gain Adjustment (80 MB)	2-80
Speed Transducer Electrical Check	2-84.1
2D. REPAIR AND REPLACEMENT	
General	2-85
Cabinet Repair	2-85
General	2-85
Case Assemblies	2-86
Adjustment	2-86
Removal-Replacement	2-87
Repair	2-87
Drive Seals/Gaskets	2-88

Adjustment	2-88
Removal - Replacement	2-88
Repair	2-88
Pack Access Cover Assemblies	2-89
Adjustment	2-89
Removal-Replacement	2-89
Repair	2-90
Door Assemblies	2-90
Adjustment	2-90
Removal-Replacement	2-90
Repair	2-90
Side Panel Assemblies	2-91
Adjustment	2-91
Repair	2-93
Slide Assemblies	2-93
Adjustment	2-93
Removal-Replacement	2-95
Repair	2-97
Electronic Package Repair	2-97
General	2-97
42 Volt Supply/Emergency Retract Assembly	2-98
Adjustment	2-98
Removal-Replacement	2-98
Repair	2-99
Power Supply Assembly (A1A01) (2 Card Power Supply)	2-99
Adjustment	2-99
Removal - Replacement	2-99
Repair	2-99
12 And 20 Volt Supply (A1A02) (3 Card Power Supply)	2-99
Adjustment	2-100
Removal-Replacement	2-100
Repair	2-100
5 Volt Supply (A1A03) (3 Card Power Supply)	2-100

Adjustment	2-100
Removal-Replacement	2-100
Repair	2-100
Blower Motor Assembly (A1BM1)	2-101
Adjustment	2-101
Removal-Replacement	2-101
Repair	2-101
Run Triac (A1K1)	2-102
Adjustment	2-102
Removal-Replacement	2-102
Repair	2-102
Deck Interlock Switch (A1S4)	2-102
Adjustment	2-102
Removal-Replacement	2-103
Repair	2-104
Logic Chassis Assembly (A2)	2-104
Adjustment	2-104
Removal-Replacement	2-104
Repair	2-105
Control Panel Assembly (A3A01)	2-107
Adjustment	2-107
Removal-Replacement	2-107
Repair	2-107
Power Amplifier Assembly (A3A04)	2-108
Adjustment	2-108
Removal-Replacement	2-108
Repair	2-108
Track Servo Preamplifier (A3A05)	2-109
Adjustment	2-109
Removal-Replacement	2-109
Repair	2-109
Drive Belt	2-110
Adjustment	2-110

Removal-Replacement	2-111
Repair	2-112
Drive Motor and Brake Assemblies (A3DM1, A3HB1)	2-112
Adjustment	2-112
Removal-Replacement	2-112
Repair	2-115
Spindle Assembly	2-116
Adjustment	2-116
Removal-Replacement	2-117
Repair	2-119
Static Ground Spring	2-120
Adjustment	2-120
Removal-Replacement	2-121
Repair	2-121
Speed Transducer (A3L1)	2-121
Adjustment	2-121
Removal-Replacement	2-122
Repair	2-122
Velocity Transducer (A3L2)	2-123
Adjustment	2-123
Removal-Replacement	2-123
Repair	2-126
Pack Cover Solenoid (A3L3)	2-126
Adjustment - S/C 16 & Below	2-126
Removal-Replacement (All units except BK5C6D)	2-127
Adjustment S/C 17 & Above (All units except BK5C6D)	2-127
Removal - Replacement (BK5C6D Only)	2-127
Repair	2-130
Rail Bracket Assembly	2-130
Adjustment	2-130
Removal-Replacement	2-130
Repair	2-131
Carriage and Coil Assembly	2-131
Heads Loaded Switch (A3S2)	2-131

Adjustment	2-131
Removal-Replacement	2-133
Repair	2-133
Flex Lead Assembly	2-133
Adjustment	2-133
Removal-Replacement	2-133
Repair	2-133
Magnet Assembly	2-134
Adjustment	2-134
Removal-Replacement	2-134
Repair	2-134
Head Arm Assemblies	2-135
Adjustment	2-135
Removal-Replacement	2-136
Repair	2-137
Cable Assemblies (W1 Through W4, W6, W11, W12)	2-142
Adjustment	2-142
Removal-Replacement	2-142
Repair	2-142
3. PARTS DATA	
Introduction	3-1
3A. ILLUSTRATED PARTS BREAKDOWN	
General	3-3
Color Code Chart	3-5
Final Assembly	3-11
Final Assembly, Pedestal	3-15
Final Assembly, Acoustic Cabinet	3-19
Final Assembly, Acoustic Drawer	3-27
Final Assembly, 30 Inch Rack Mount	3-31
Final Assembly, 36 Inch Rack Mount	3-33
Final Assembly, Nude	3-37
Case Assembly, Pedestal	3-38.1
Case Assembly, Acoustic Cabinet	3-43

Case Assembly, Acoustic Drawer	3-47
Case Assembly, 30 Inch Rack Mount	3-51
Case Assembly, 36 Inch Rack Mount	3-55
Case Assembly, Universal	3-59
Pack Access Cover Assembly, Nonacoustic/Universal	3-62.1
Pack Access Cover Assembly, Acoustic	3-65
Front and Rear Door, Nonacoustic	3-67
Front Door Assembly - Acoustic Cabinet	3-69
Rear Door Assembly - Acoustic Cabinet	3-71
Rear Door Assembly, Acoustic Drawer	3-73
Side Panel, Nonacoustic	3-77
Side Panel Assembly, Acoustic	3-79
Drive Electronics Assembly	3-81
Control Panel Assembly (A3A01)	3-93
Logic Chassis Assembly	3-95
Deck Assembly (A3)	3-99
Spindle Assembly	3-121
Rail Bracket Assembly	3-123
Carriage and Coil Assembly (A3VC1)	3-125
Magnet Assembly	3-127
Drive Motor and Brake Assemblies	3-129
Power Amplifier, Component Assembly (Type _VTN) (A3A04)	3-133
Base Assembly (A1)	3-135
Base Assembly (A1)	3-151
3 Card Power Supply Assembly	3-167
Component Assembly, Type _SJV (+42V Power Supply and Emergency Retract) (A1A01)	3-169
Component Assembly, Type _SKV (+20 V, +12 V Power Supplies) (A1A02)	3-171
Component Assembly, Type _SHV (+5 V Power Supply) (A1A03)	3-173
2 Card Power Supply Assembly	3-177
Component Assembly, Type _XKV (Power Supply)	3-178.1
3B. SPARE PARTS LIST	
General	3-183

FIGURES

1-1	Clearances (Pedestal Cabinet)	1-2
1-2	Clearances (Acoustic Cabinet)	1-3
1-3	Clearances (Acoustic Drawer)	1-4
1-4	Clearances (30-Inch Rack Mount)	1-5
1-5	Clearances (36-Inch Rack Mount)	1-5
1-6	60 Hz AC Power Connector	1-7
1-7	Start-up Current	1-8
1-8	I/O Cable Configurations	1-13
1-9	A Cable (60 Pin I/O)	1-16
1-10	A Cable (50 Pin I/O)	1-17
1-11	B Cable	1-18
1-12	Leveling Pad Installation	1-23
1-13	System Grounding	1-24
1-14	Power Cord Installation and System Ground	1-26
1-15	AC Power Wiring	1-30
1-16	I/O Cable Attachment	1-31
1-17	Terminator Assembly	1-33
1-18	Securing Flat I/O Cables	1-34
1-19	Securing Round I/O Cables (Pedestal & Acoustic 1X)	1-35
1-20	Securing Round I/O Cables (Pedestal)	1-36
1-21	Securing Round I/O Cables (Acoustic 1X)	1-37
1-22	Securing Round I/O Cables (Acoustic Drawer and Rack Mount)	1-38
1-23	Sector Select Switches	1-41
2-1	Head Alignment Kit	2-21
2-2	Maintenance Switches and Indicators	2-23
2-3	Physical Location Codes	2-38
2-4	Deck Maintenance Position	2-46
2-5	Drilling of Absolute Filter	2-55
	Figures 2-6 thru 2-10 deleted	

2-11	Power Supply Adjustment Locations (3 Card P.S.)	2-63
2-11	Power Supply Adjustment Locations (2 Card P.S.)	2-64
2-12	Basic Head Alignment Check & Adjustment Procedure	2-66
2-13	Head Alignment Setup	2-69
2-14	Head Alignment Waveform	2-70
2-15	Head Arm Alignment	2-76
2-16	40 MB Velocity Transducer Gain Waveforms	2-78
2-17	40 MB Velocity Gain Adjustment Locations	2-79
2-18	40 MB Coarse Velocity Waveform	2-81
2-19	40 MB Fine Velocity Waveforms	2-82
2-20	Procedure B and All 80 MB Velocity Gain Waveform	2-83
2-21	80 MB Velocity Gain Adjustment Location	2-84
2-21.1	Speed Transducer Electrical Check	2-84.1
2-22	Side Panel Adjustment	2-92
2-23	Slide Assembly Parts Location	2-94
2-24	Wirewrap Pin Replacement	2-107
2-25	Drive Belt Adjustment	2-110
2-26	Drive Motor Pulley Adjustment	2-114
2-27	Spindle/Carriage Alignment	2-116
2-28	Speed Transducer Adjustment	2-123
2-29	Velocity Transducer Replacement	2-124
2-30	Pack Cover Solenoid Adjustment	2-128
2-31	Heads Loaded Switch Replacement	2-132
2-32	Head Replacement - Left Side View	2-135
2-33	Head Replacement - Right Side View	2-136
2-34	Typical Head/Arm Components	2-139
2-35	Head Cleaning Motion	2-140
3-1	Final Assembly	3-10
3-2	Final Assembly - Pedestal	3-14
3-3	Final Assembly - Acoustic Cabinet	3-18
3-4	Final Assembly - Acoustic Drawer	3-26
3-5	Final Assembly - 30 Inch Rack Mount	3-30

3-6	Final Assembly - 36 Inch Rack Mount	3-32
3-7	Final Assembly - Nude	3-36
3-8	Case Assembly - Pedestal	3-38
3-9	Case Assembly - Acoustic Cabinet	3-42
3-10	Case Assembly - Acoustic Drawer	3-46
3-11	Case Assembly - 30 Inch Rack Mount	3-50
3-12	Case Assembly - 36 Inch Rack Mount	3-54
3-13	Case Assembly - Universal	3-58
3-14	Pack Access Cover Assembly - Nonacoustic/Universal	3-62
3-15	Pack Access Cover Assembly - Acoustic	3-64
3-16	Front and Rear Door - Nonacoustic	3-66
3-17	Front Door Assembly - Acoustic Cabinet	3-68
3-18	Rear Door Assembly - Acoustic Cabinet	3-70
3-19	Rear Door Assembly - Acoustic Drawer	3-72
3-20	Side Panel - Nonacoustic	3-76
3-21	Side Panel Assembly - Acoustic	3-78
3-22	Drive Electronics Assembly	3-80
3-23	Control Panel Assembly	3-92
3-24	Logic Chassis Assembly	3-94
3-25	Deck Assembly	3-98
3-26	Spindle Assembly	3-120
3-27	Rail Bracket Assembly	3-122
3-28	Carriage and Coil Assembly	3-124
3-29	Magnet Assembly	3-126
3-30	Drive Motor and Brake Assemblies	3-128
3-31	Power Amplifier	3-132
3-32	Base Assembly (471718XX)	3-134
3-33	Base Assembly (832619XX)	3-150
3-34	3 Card Power Supply Assembly	3-166
3-35	Component Assembly, Type _SJV	3-168
3-36	Component Assembly, Type _SKV	3-170
3-37	Component Assembly, Type _SHV	3-172
3-38	2 Card Power Supply Assembly	3-176
3-39	Component Assembly, Type _XKV	3-178

TABLES

1-1	Environmental Specifications	1-6
1-2	Source Power Requirements	1-9
1-3	Maximum Current Source Requirements	1-9
1-4	Conductor Load Current Limitations	1-11
1-5	Installation Accessories	1-14
1-6	Installation Procedures	1-20
1-7	Grounding Accessories	1-25
1-8	Sector Select Switch Settings	1-43
2-1	Maintenance Tools and Materials	2-14.4
2-2	Maintenance Switches and Indicators	2-24
2-3	Test Points	2-28
2-4	Physical Location Codes	2-39
2-5	Preventive Maintenance Index	2-52
2-6	40 MB Velocity Voltage Vs Null Time	2-77
3-1	Color Code Chart	3-5

APPENDIXES

A.	Decision Logic Tables (S/C 20 and above)	A-i
B.	Decision Logic Tables (S/C 19 and below)	B-i

IMPORTANT SAFETY INFORMATION AND PRECAUTIONS

Proper safety and repair is important to the safe, reliable operation of this unit. Service should be done by qualified personnel only. This maintenance manual describes procedures recommended by the manufacturer as effective methods of servicing the unit. Some of these procedures require the use of specially designed tools. For proper maintenance and safety, these specially designed tools should be used as recommended.

The procedures in this maintenance manual and labels on the unit contain warnings and cautions which must be carefully read and observed in order to minimize or eliminate the risk of personal injury. The warnings point out conditions or practices that are potentially hazardous to maintenance personnel. The cautions point out practices which, if disregarded, could damage the unit and make it unsafe for use.

For the safety of maintenance and operating personnel, the following precautions must be observed:

- Perform all maintenance in accordance with the procedures given in this manual.
- Read and observe all cautions and warnings provided in the procedures and labeled on the unit.
- Use the special tools called out in the maintenance procedure.
- Observe sound safety practices when performing maintenance.
- Use caution when troubleshooting a unit that has voltages present. Remove power from unit before servicing or replacing components.
- Wear safety glasses when servicing units.
- Wear safety shoes when removing or replacing heavy components.

It is also important to understand that these warnings and cautions are not exhaustive. The manufacturer could not possibly know, evaluate and advise maintenance personnel of all conceivable ways in which maintenance might be performed or the possible risk of each maintenance technique. Consequently, the manufacturer has not completed any such broad evaluation. Thus, any persons who use any non-approved maintenance procedure or tool must first satisfy themselves that neither their safety nor the unit performance will be jeopardized by the maintenance techniques they select.

CONFIGURATION CHART

EQUIP	TLA	POWER		DATA CAP (MB)	CH	A CABLE CONFIG	CLR ⁴ CODE	CAB MTG STYLE
		V	HZ					
BK4A1A	47173102	120	60	40	S	60-pin	A	30-in rk
BK4A1B	47173103	220/ 240	50	40	S	60-pin	A	30-in rk
BK4A1D	47173147	220/ 240	50	40	S	60-pin	AH	30-in rk
BK4A2A	47173104	120	60	40	D	60-pin	A	30-in rk
BK4A2B	47173105	220/ 240	50	40	D	60-pin	A	30-in rk
BK4A3A	47173106	120	60	40	S	60-pin	B	36-in rk
BK4A3B	47173107	220/ 240	50	40	S	60-pin	B	36-in rk
BK4A4A	47173108	120	60	40	D	60-pin	B	36-in rk
BK4A4B	47173109	220/ 240	50	40	D	60-pin	B	36-in rk
BK4A5A	47173116	120	60	40	S	60-pin	C	ped cab
BK4A5B	47173117	220/ 240	50	40	S	60-pin	C	ped cab
BK4A5C	47173150	120	60	40	S	S&IOBC	AK	ped cab
BK4A5D	47173151	220/ 240	50	40	S	S&IOBC	AK	ped cab
BK4A5E	47173152	120	60	40	S	60-pin	AY	ped cab
BK4A5F	47173153	220	50	40	S	60-pin	AY	ped cab
BK4A5G	47173157	100	60	40	S	S&IOBC	AK	ped cab
BK4A5H	47173156	100	50	40	S	S&IOBC	AK	ped cab
BK4A6A	47173118	120	60	40	D	60-pin	C	ped cab
BK4A6B	47173119	220/ 240	50	40	D	60-pin	C	ped cab
BK4A7A	47173120	120	60	40	S	60-pin	D	acst drw
BK4A7B	47173121	220/ 240	50	40	S	60-pin	E	acst drw
BK4A8A	47173122	120	60	40	D	60-pin	D	acst drw

Table Continued on Next Page

CONFIGURATION CHART (Contd)

EQUIP	TLA	POWER		DATA CAP (MB)	CH	A CABLE CONFIG	CLR ⁴ CODE	CAB MTG STYLE
		V	HZ					
BK4A8B	47173123	220/ 240	50	40	D	60-pin	E	acst drw
BK4A9A	47173124	120	60	40	S	60-pin	F	acst cab
BK4A9B	47173125	220/ 240	50	40	S	60-pin	G	acst cab
BK4A9C	47173146	220	50	40	S	60-pin	3	acst cab
BK4A9E	47173154	120	60	40	S	60-pin	BM	acst cab
BK4A9F	47173155	220	50	40	S	60-pin	BN	acst cab
BK4A9G	47173162	120	60	40	S	S&IOBC	BZ	acst cab
BK4B1A	47173126	120	60	40	D	60-pin	F	acst cab
BK4B1B	47173127	220/ 240	50	40	D	60-pin	G	acst cab
BK4B5A	47173134	120	60	40	D	50-pin	C	ped cab
BK4B5B	47173135	220/ 240	50	40	D	50-pin	C	ped cab
BK4B5C	47173136	120	60	40	S	50-pin	C	ped cab
BK4B5D	47173137	220/ 240	50	40	S	50-pin	C	ped cab
BK4B6C	47173140	120	60	40	S	60-pin	K	ped cab
BK4B6D	47173141	220/ 240	50	40	S	60-pin	K	ped cab
BK4B7A	47173148	120	60	40	S	60-pin	-	basic
BK4B7B	47173149	220/ 240	50	40	S	60-pin	-	basic
BK4B9A	47173110	120	60	40	S	60-pin	L	ped cab
BK4B9B	47173111	220/ 240	50	40	S	60-pin	L	ped cab
BK4B9C	47173112	120	60	40	S	60-pin	M	acst cab
BK4B9D	47173113	220/ 240	50	40	S	60-pin	M	acst cab
BK4B9E	47173114	120	60	40	S	60-pin	N	acst drw
BK4B9F	47173115	220/ 240	50	40	S	60-pin	R	acst drw

Table Continued on Next Page

CONFIGURATION CHART (Contd)

EQUIP	TLA	POWER		DATA CAP (MB)	CH	A CABLE CONFIG	CLR ⁴ CODE	CAB MTG STYLE
		V	HZ					
BK4B9G	47173142	120	60	40	S	60-pin	S	acst cab
BK4B9H	47173143	220/ 240	50	40	S	60-pin	Z	acst cab
BK4B9J	47173144	120	60	40	S	60-pin	T	acst drw
BK4B9K	47173145	220/ 240	50	40	S	60-pin	U	acst drw

CONFIGURATION CHART (Contd)

EQUIP	TLA	POWER		DATA CAP (MB)	CH	A CABLE CONFIG	CLR ⁴ CODE	CAB MTG STYLE
		V	HZ					
BK5A1A	47173002	120	60	80	S	60-pin ¹	A	30-in rk
BK5A1B	47173003	220/ 240	50	80	S	60-pin ¹	A	30-in rk
BK5A1D	47173085	220/ 240	50	80	S	60-pin	AH	30-in rk
BK5A1E	47292521	120	60	80	S	S&IOBC	AX	30-in rk
BK5A1F	47292522	220/ 240	50	80	S	S&IOBC	AX	30-in rk
BK5A1G	47292542	120	60	80	S	60-pin ¹	BG	uni cab
BK5A1H	47292543	220	50	80	S	60-pin ¹	BG	uni cab
BK5A1J	47292597	120	60	80	S	S&IOBC	CE	30-in rk
BK5A1K	47292551	240	50	80	S	60-pin	BB	30-in rk
BK5A1L	47292598	220	50	80	S	S&IOBC	CE	30-in rk
BK5A1M	47292573	220	50	80	S	60-pin ¹	A	30-in rk
BK5A1N	82398035	220	50	80	S	S&IOABC	CY	30-in rk
BK5A1P	82398041	220	50	80	S	S&IOABC	DG	30-in rk
BK5A2A	47173004	120	60	80	D	60-pin ¹	A	30-in rk
BK5A2B	47173005	220/ 240	50	80	D	60-pin ¹	A	30-in rk
BK5A3A	47173006	120	60	80	S	60-pin ¹	B	30-in rk
BK5A3B	47173007	220/ 240	50	80	S	60-pin ¹	B	30-in rk
BK5A3C	47292519	120	60	80	S	60-pin	AR	36-in rk
BK5A3D	47292520	220/ 240	50	80	S	60-pin	AR	36-in rk
BK5A3E	82398023	120	60	80	S	S&IOABC	CT	36-in rk
BK5A3F	48292544	220	50	80	S	60-pin	B	36-in rk
BK5A3G	82398026	220	50	80	S	S&IOABC	CT	36-in rk
BK5A3H	47292561	220	50	80	S	60-pin ¹	B	36-in rk
BK5A3J	82398042	220	50	80	S	S&IOABC	DH	36-in rk
BK5A3K	47292579	220	50	80	S	60-pin	BP	36-in rk
BK5A3M	47292593	220	50	80	S	S&IOABC	CA	36-in rk
BK5A3N	82398045	120	60	80	S	S&IOABC	DL	36-in rk
BK5A3P	82398046	220	50	80	S	S&IOABC	DL	36-in rk
BK5A4A	47173008	120	60	80	D	60-pin ¹	B	36-in rk
BK5A4B	47173009	220/ 240	50	80	D	60-pin ¹	B	36-in rk

Table Continued on Next Page

CONFIGURATION CHART (Contd)

EQUIP	TLA	POWER		DATA CAP (MB)	CH	A CABLE CONFIG	CLR ⁴ CODE	CAB MTG STYLE
		V	HZ					
BK5A5A	47173016	120	60	80	S	60-pin ¹	C	ped cab
BK5A5B	47173017	220/ 240	50	80	S	60-pin ¹	C	ped cab
BK5A5C	47173048	120	60	80	S	60-pin	J	ped cab
BK5A5D	47173049	220	50	80	S	60-pin	J	ped cab
BK5A5E	47173068	120	60	80	S	60-pin	AE	ped cab
BK5A5F	47173074	120	60	80	S	60-pin	V	ped cab
BK5A5G	47173075	220/ 240	50	80	S	60-pin	V	ped cab
BK5A5H	47173076	120	60	80	S	S&IOBC	W	ped cab
BK5A5J	47173088	120	60	80	S	60-pin	AJ	ped cab
BK5A5K	47173089	220/ 240	50	80	S	60-pin	AJ	ped cab
BK5A5L	47173090	120	60	80	S	75-pin	DA ³	ped cab
BK5A5M	47173091	220/ 240	50	80	S	75-pin	DA ³	ped cab
BK5A5N	47292504	120	60	80	S	S&IOBC	AK	ped cab
BK5A5P	47292505	220/ 240	50	80	S	S&IOBC	AK	ped cab
BK5A5R	47292536	120	60	80	S	60-pin	AW	ped cab
BK5A5S	47292537	220/ 240	50	80	S	60-pin	AW	ped cab
BK5A5T	47292538	120	60	80	S	60-pin	DA ³	ped cab
BK5A5U	47292539	220	50	80	S	60-pin	DA ³	ped cab
BK5A5V	47292540	120	60	80	S	60-pin	AY	ped cab
BK5A5W	47292541	220	50	80	S	60-pin	AY	ped cab
BK5A5Y	47292545	120	60	80	S	60-pin	AZ	ped cab
BK5A5Z	47292552	220	50	80	S	60-pin	BC	ped cab
BK5A6A	47173018	120	60	80	D	60-pin ¹	C	ped cab
BK5A6B	47173019	220/ 240	50	80	D	60-pin ¹	C	ped cab
BK5A6E	47292547	120	60	80	D	S&IOBC	BA	ped cab
BK5A6F	47292548	220	50	80	D	S&IOBC	BA	ped cab

Table Continued on Next Page

CONFIGURATION CHART (Contd)

EQUIP	TLA	POWER		DATA CAP (MB)	CH	A CABLE CONFIG	CLR ⁴ CODE	CAB MTG STYLE
		V	HZ					
BK5A6G	47292555	120	60	80	D	S&IOABC	CV ³	ped cab
BK5A6H	47292556	220	50	80	D	S&IOABC	CV ³	ped cab
BK5A7A	47173020	120	60	80	S	60-pin ¹	D	acst drw
BK5A7B	47173021	220/ 240	50	80	S	60-pin ¹	E	acst drw
BK5A7G	47173080	120	60	80	S	60-pin	AC	acst drw
BK5A7H	47173078	220/ 240	50	80	S	60-pin	AA	acst drw
BK5A7J	47292513	120	60	80	S	60-pin	BS ³	acst drw
BK5A7K	47292514	220/ 240	50	80	S	60-pin	BS ³	acst drw
BK5A7L	47292525	120	60	80	S	60-pin	AU	acst drw
BK5A7M	47292526	220/ 240	50	80	S	60-pin	AV	acst drw
BK5A7N	47292529	120	60	80	S	60-pin	BS ³	acst drw
BK5A7P	47292530	220/ 240	50	80	S	60-pin	BS ³	acst drw
BK5A7R	47292557	120	60	80	S	S&IOBC	BD	acst drw
BK5A7S	47292558	220	50	80	S	S&IOBC	BD	acst drw
BK5A7T	47292594	220	50	80	S	S&IOABC	CB	acst drw
BK5A7U	47292562	220	50	80	S	60-pin ¹	E	acst drw
BK5A7V	47292565	120	60	80	S	S&IOABC	BK	acst drw
BK5A7W	47292566	240	50	80	S	S&IOABC	BL	acst drw
BK5A7Y	47292574	120	60	80	S	60-pin	BK ³	acst drw
BK5A7Z	47292575	220	50	80	S	60-pin	BL ³	acst drw
BK5A8A	47173022	120	60	80	D	60-pin ¹	D	acst drw
BK5A8B	47173023	220/ 240	50	80	D	60-pin ¹	E	acst drw
BK5A8H	82398005	220	50	80	D	S&IOABC	CJ ³	acst drw
BK5A9A	47173024	120	60	80	S	60-pin ¹	F	acst cab
BK5A9B	47173025	220/ 240	50	80	S	60-pin ¹	G	acst cab

Table Continued on Next Page

CONFIGURATION CHART (Contd)

EQUIP	TLA	POWER		DATA CAP (MB)	CH	A CABLE CONFIG	CLR ⁴ CODE	CAB MTG STYLE
		V	HZ					
BK5A9G	47173066	120	60	80	S	60-pin	X	acst cab
BK5A9H	47173067	220/ 240	50	80	S	60-pin	Y	acst cab
BK5A9J	47173069	220/ 240	50	80	S	60-pin	³	acst cab
BK5A9K	47173077	220/ 240	50	80	S	60-pin	AB	acst cab
BK5A9L	47173081	120	60	80	S	60-pin	AD	acst cab
BK5A9M	47292516	220/ 240	50	80	S	60-pin	BU ³	acst cab
BK5A9N	47292510	120	60	80	S	60-pin	AL	acst cab
BK5A9P	47292515	120	60	80	S	60-pin	BT ³	acst cab
BK5A9R	47292517	120	60	80	S	60-pin	AN	acst cab
BK5A9S	47292518	220/ 240	50	80	S	60-pin	AP	acst cab
BK5A9T	47292523	120	60	80	S	60-pin	AS	acst cab
BK5A9U	47292524	220/ 240	50	80	S	60-pin	AT	acst cab
BK5A9V	47292527	120	60	80	A	60-pin	BT ³	acst cab
BK5A9W	47292528	220/ 240	50	80	S	60-pin	BU ³	acst cab
BK5A9Z	47292564	220	50	80	S	60-pin ¹	G	acst cab
BK5B1A	47173026	120	60	80	D	60-pin ¹	F	acst cab
BK5B1B	47173027	220/ 240	50	80	D	60-pin ¹	G	acst cab
BK5B1G	82398027	220	50	80	D	S&IOABC	CW	acst cab
BK5B1H	82398004	220	50	80	D	S&IOBC	CK ³	acst cab
BK5B5J	47173082	120	60	80	S	60-pin	AF	acst cab
BK5B5K	47173083	220/ 240	50	80	S	60-pin	AG	acst cab
BK5B5L	47292549	120	60	80	S	S&IOBC	BA	ped cab
BK5B5M	47292550	220	50	80	S	S&IOBC	BA	ped cab
BK5B5N	47292553	120	60	80	S	S&IOABC	CV ³	ped cab
BK5B5P	47292554	220	50	80	S	S&IOABC	CV ³	ped cab
BK5B5R	82398034	220	50	80	S	S&IOABC	CZ	ped cab
BK5B5S	47292563	220	50	80	S	60-pin ¹	C	ped cab

Table Continued on Next Page

CONFIGURATION CHART (Contd)

EQUIP	TLA	POWER		DATA CAP (MB)	CH	A CABLE CONFIG	CLR ⁴ CODE	CAB MTG STYLE
		V	HZ					
BK5B5T	47292572	100	60	80	S	S&IOBC	AK	ped cab
BK5B5U	47292571	100	50	80	S	S&IOBC	AK	ped cab
BK5B5W	47292581	220	50	80	S	60-pin	C	ped cab
BK5B5Y	47292591	120	60	80	S	60-pin ¹	CD	ped cab
BK5B5Z	47292592	220/ 240	50	80	S	60-pin ¹	CD	ped cab
BK5B6A	47173036	120	60	80	D	S&IOBC	H	ped cab
BK5B6B	47173037	220/ 240	50	80	D	S&IOBC	H	ped cab
BK5B6C	47173038	120	60	80	S	S&IOBC	H	ped cab
BK5B6D	47173039	220/ 240	50	80	S	S&IOBC	H	ped cab
BK5B7A	47173040	120	60	80	D	50-pin	C	ped cab
BK5B7B	47173041	220/ 240	50	80	D	50-pin	C	ped cab
BK5B7C	47173042	120	60	80	S	50-pin	C	ped cab
BK5B7D	47173043	220/ 240	50	80	S	50-pin	C	ped cab
BK5B8C	47173046	120	60	80	S	S&IOBC	K	ped cab
BK5B8D	47173047	220/ 240	50	80	S	S&IOBC	K	ped cab
BK5B9A	47173010	120	60	80	S	60-pin	L	ped cab
BK5B9B	47173011	220/ 240	50	80	S	60-pin	L	ped cab
BK5B9C	47173012	120	60	80	S	60-pin	M	acst cab
BK5B9D	47173013	220/ 240	50	80	S	60-pin	M	acst cab
BK5B9E	47173014	120	60	80	S	60-pin	N	acst drw
BK5B9F	47173015	220/ 240	50	80	S	60-pin	R	acst drw
BK5B9G	82398008	100	60	80	S	60-pin	C	ped cab
BK5B9H	82398009	100	50	80	S	60-pin	C	ped cab
BK5B9J	47173070	120	60	80	S	60-pin	S	acst cab
BK5B9K	47173071	220/ 240	50	80	S	60-pin	Z	acst cab
BK5B9L	47173072	120	60	80	S	60-pin	T	acst drw
BK5B9M	47173073	220/ 240	50	80	S	60-pin	U	acst drw

Table Continued on Next Page

CONFIGURATION CHART (Contd)

EQUIP	TLA	POWER		DATA CAP (MB)	CH	A CABLE CONFIG	CLR ⁴ CODE	CAB MTG STYLE
		V	HZ					
BK5B9N	82398006	120	60	80	S	60-pin	CG	ped cab
BK5B9P	82398036	120	60	80	S	S&IOAC	DF	ped cab
BK5B9R	82398019	120	60	80	S	S&IOABC	CL	ped cab
BK5B9S	82398020	220	50	80	S	S&IOABC	CL	ped cab
BK5B9T	82398017	120	60	80	S	S&IOABC	CM	ped cab
BK5B9U	82398018	220	50	80	S	S&IOABC	CM	ped cab
BK5B9V	82398021	120	60	80	S	S&IOABC	CS	ped cab
BK5B9W	82398022	220	50	80	S	S&IOABC	CS	ped cab
BK5B9Y	82398024	120	60	80	S	S&IOABC	CU	ped cab
BK5B9Z	82398025	220	50	80	S	S&IOABC	CU	ped cab
BK5C1E	47173092	120	60	80	S	60-pin	-	basic
BK5C1F	47173093	220/ 240	50	80	S	60-pin	-	basic
BK5C1G	47292535	120	60	80	S	60-pin	-	basic
BK5C1H	47292599	220	50	80	S	60-pin	CF	Nude
BK5C1J	47292585	100	50	80	S	60-pin	-	basic
BK5C1K	47292586	100	60	80	S	60-pin	-	basic
BK5C2A	47173050	120	60	80	S	60-pin	P	nude
BK5C2B	47173051	220/ 240	50	80	S	60-pin	P	nude
BK5C3A	47292511	120	60	80	S	60-pin ¹	AM	desk
BK5C3B	47292512	220/ 240	50	80	S	60-pin ¹	AM	desk
BK5C4A	47292559	120	60	80	S	S&IOBC	BE	acst cab
BK5C4B	47292560	220	50	80	S	S&IOBC	BF	acst cab
BK5C4C	47292567	120	60	80	S	S&IOABC	BH	acst cab
BK5C4D	47292568	220	50	80	S	S&IOABC	BJ	acst cab
BK5C4E	47292569	120	60	80	S	60-pin	BM	acst cab
BK5C4F	47292570	220	50	80	S	60-pin	BN	acst cab
BK5C4G	47292576	120	60	80	S	60-pin	BH ³	acst cab
BK5C4H	47292577	220	50	80	S	60-pin	BJ ³	acst cab
BK5C4K	47292578	220	50	80	S	60-pin	BR	acst cab
BK5C4M	47292580	220	50	80	S	60-pin	BV	acst cab
BK5C4N	82398037	220	50	80	S	S&IOABC	DC	acst cab
BK5C4P	47292582	220	50	80	S	60-pin	BW	acst cab
BK5C4R	47292583	120	60	80	S	S&IOBC	BX	acst cab
BK5C4S	47292584	220	50	80	S	S&IOABC	BY	acst cab

Table Continued on Next Page

CONFIGURATION CHART (Contd)

EQUIP	TLA	POWER		DATA CAP (MB)	CH	A CABLE CONFIG	CLR ⁴ CODE	CAB MTG STYLE
		V	HZ					
BK5C4T	82398044	220	50	80	S	S&IOABC	DJ	acst cab
BK5C4U	82398002	220	50	80	S	S&IOABC	CK ³	acst cab
BK5C4W	82398007	120	60	80	S	60-pin	CH	acst cab
BK5C4Y	82398010	100	60	80	S	60-pin	F	acst cab
BK5C4Z	82398011	100	50	80	S	60-pin	G	acst cab
BK5C5A	47292595	120	60	80	S	60-pin ¹	CC	acst drw
BK5C5B	47292596	220	50	80	S	60-pin	CC	acst drw
BK5C5D	82398003	220	50	80	S	S&IOABC	CJ ³	acst drw
BK5C5F	82398043	220	50	80	S	S&IOABC	DK	acst drw
BK5C6A	82398012	120	60	80	S	S&IOABC	CN	acst cab
BK5C6B	82398013	220	50	80	S	S&IOABC	CP	acst cab
BK5C6C	82398016	120	60	80	S	S&IOABC	CR	acst cab
⁵ BK5C6D	81528302	220	50	80	S	S&IOABC	DN	acst cab
BK5C6E	82398038	220	50	80	S	S&IOABC	DD	acst drw
BK5C7A	82398039	120	60	80	S	S&IOAC	DE	ped cab
BK5C7B	82398040	220	50	80	S	S&IOAC	DB	ped cab
BK5C7C	82398047	120	60	80	S	S&IOAC	DM	acst cab
BK5C7D	82398048	220	50	80	S	S&IOAC	DM	acst cab

¹ Units built after S/C 34 have Index and Sector on A and B Cables.

² Units built after S/C 24 have Pack Interlocks.

³ Units have Special Supplement.

⁴ SEE TABLE 3-1 COLOR CODE CHART.

⁵ VDE Unit

ABBREVIATIONS

30-IN RK	30-Inch Rack	FIG	Figure
36-IN RK	36-Inch Rack	FLT	Fault
ABR	Absolute Reserve	FREQ	Frequency
ABV	Above	FTU	Field Test Unit
ACST CAB	Acoustic Cabinet	FWD	Forward
ACST DRW	Acoustic Drawer	GND	Ground
ADDR	Address	HD	Head
AGC	Automatic Gain Control	I/O	Input-Output
AM	Address Mark	INTLK	Interlock
AMPL	Amplifier	LAP	Logical Address Plug
BLK	Black	LD	Load
BLW	Below	MAINT	Maintenance
CAR	Cylinder Address Register	MAX	Maximum
CH	Channel	MB	Megabyte
CHAN	Channel	MFM	Modified Frequency Modulation
CNTLGL	Centrifugal		
CNTR	Counter	MK	Mark
COMP	Compensation	MUTL	Multiple
COMPTR	Comparator	NC	No Condition
CONFIG	Configuration	NEG	Negative
CONT	Continued	NFR	Not Field Replaceable
CR REF	Cross Reference	NO	Number
CYL	Cylinder	NOM	Nominal
D/A	Digital To Analog	NORM	Normal
DCCR	Decoder	NRM	Normal
DIFF	Difference	NRZ	Nonreturn To Zero
DLY	Delay	PC PT	Piece Part
DRVR	Driver	PLO	Phase Lock Oscillator
DSBL	Disable	PED CAB	Pedestal Cabinet
ECL	Emitter Coupled Logic	PN	Part Number
ECO	Engineering Change Order	POS	Positive
EMER	Emergency	PWR	Power
EN	Enable	RCVRS	Receivers
EOT	End Of Travel	RD	Read
EQUIP	Equipment	RDY	Ready
EQUIV	Equivalent	REC	Receiver
FCO	Field Change Order	REF	Reference
FF	Flip Flop	REG	Register

ABBREVIATIONS (Contd)

REV	Reverse	TBS	To Be Supplied
RGTR	Register	TLA	Top Level Assembly
RTM	Reserve Timer	TP	Test Point
RTZ	Return To Zero	TRK	Track
S&IOABC	Sector and Index On A & B Cable	TTL	Transistor Transistor Logic
S&IOBC	Sector and Index On B Cable	UNI CAB	Universal Cabinet
S/C	Series Code	UNREG	Unregulated
SEC	Second	VCO	Voltage Controlled Oscillataor
SEL	Select	W+R	Write Or Read
SEQ	Sequence	W·R	Write and Read
SER	Servo	W/	With
SH	Sheet	W/O	Without
SOL	Solenoid	WRT	Write
SR	Servo	WT	White
SW	Switch	XDUCER	Transducer
T	Track	XMTR	Transmitter

SECTION 1

INSTALLATION AND CHECKOUT

INTRODUCTION

This section provides information pertaining to the installation and checkout of the storage module drive. Prior to performing any of the procedures contained in this section, become thoroughly familiar with the information contained in Section 2A, General Maintenance Information.

The information in this section is divided into the following major areas:

- Site Preparation - Describes requirements that must be met in preparing a site for installation of a drive.
- Packaging - Provides information regarding shipment of the drive.
- Installation - Provides instructions on the installation and interconnection of the drives.
- Checkout - Provides instructions to ensure that the drive is functional.

SITE PREPARATION

GENERAL

Site preparation information is provided to enable a user to layout an installation site. Consideration is given to:

- Space and Clearance
- Environment
- Power Requirements
- Grounding
- I/O Cables and Terminators


The Installation instructions, provided later in this section, are based on the assumption that all site preparation requirements have been met.

SPACE AND CLEARANCE

Position the drive either by itself or in line with other drives. In either case, there must be enough clearance around the drive to permit access for maintenance. Space requirements are shown on figures 1-1 through 1-5.

ENVIRONMENT


In laying out the site, consideration must be given to providing the proper environmental conditions. All environmental specifications for the drive are listed in table 1-1.



9H1B


Figure 1-1. Clearances (Pedestal Cabinet)

Figure 1-2. Clearances (Acoustic Cabinet)




9H2C

Figure 1-3. Clearances (Acoustic Drawer)




9H3B



9H4B

Figure 1-4. Clearances (30-Inch Rack Mount)



9H5B

Figure 1-5. Clearances (36-Inch Rack Mount)

TABLE 1-1. ENVIRONMENTAL SPECIFICATIONS

Characteristic	Condition	Specifications
Temperature	Operating	15° to 40° C (59° to 104° F) with a maximum change of 6.7° C (12° F) per hour
	Transit*	-40.4° to +70° C (-40° to +158° F)
	Storage	-10° to +50° C (14° to 122° F) with a maximum change of 15.0° C (27° F) per hour
Relative Humidity (No condensation)	Operating	20% to 80%
	Transit*	5% to 95%
Altitude	Operating	-305 to +2000 Meters (-1000 to +6500 Feet)
	Transit*	-305 to +4572 Meters (-1000 to +15,000 Feet)
*Unit packed for shipment.		

POWER REQUIREMENTS

Normal Requirements

Site layout includes providing an ac power source for each drive. Drives connect to this power source via a factory-supplied 4 m (13-ft) long power cord.

Power cords used on 60 Hz units have their own prewired power connectors (see figure 1-6). Power cords used on 50 Hz units are not supplied with connectors and must be wired at the site according to the following formula:

- Green wire to ground
and

- All additional wires either phase to phase or phase to neutral

For information concerning power requirements, frequency, and current, refer to:

- Source Power Requirements - Table 1-2
- Maximum Current Source Requirements - Table 1-3
- Maximum Start-Up Time (Seconds) - Figure 1-7

NOTE

Drives cannot be converted from one frequency to another (50 Hz to 60 Hz for example) or from one voltage to another (100 V ac to 120 V ac) without making major mechanical changes. If such a conversion is necessary, contact your factory representative.





Figure 1-6. 60 Hz AC Power Connector



9H238 B

Figure 1-7. Start-up Current

TABLE 1-2. SOURCE POWER REQUIREMENTS

Voltage AC		Frequency Hz		Phase
Nominal	Range	Nominal	Range	
100	90 to 110	60	58.8 to 60.6	1
120	102 to 128	60	59.0 to 60.6	1
220	195 to 235	50	49.0 to 50.5	1
240	213 to 257	50	49.0 to 50.5	1

TABLE 1-3. MAXIMUM CURRENT SOURCE REQUIREMENTS

Power Source	Requirements					
	VAC/Hz	Line Current In Amps		Power Factor		Consumption In KW (BTU/HR)
	Operat- ing	Stand- by	Operat- ing	Stand- by	Operat- ing	Stand- by
100/60	8.2	1.5	0.77	0.90	0.631	0.135
120/60	8.2	1.5	0.77	0.90	0.757	0.162
220/50	4.2	1.4	0.85	0.90	0.758	0.277
240/50	5.0	1.5	0.75	0.90	0.900	0.324

Operating - Carriage and disks in motion.
Standby - Disks not turning.

WARNING

Any 3 phase, 4 wire, wye circuit where over one half of the total load consists of electric discharge lighting, data processing (such as this unit), or similar equipment must meet the requirements given in the following topic. These requirements must be met in the United States, in order to comply with the National Electrical Code, and are recommended for installations in other countries. Failure to meet these requirements may result in hazardous conditions due to high currents (and heating) in the neutral conductors and transformers supplying the system.

SPECIAL REQUIREMENTS FOR 3 PHASE, 4 WIRE, WYE SITE POWER

General .

This unit uses single phase power. If the power originates from a 3 phase, wye branch or feeder circuit with a load as defined in the above warning, ensure that the circuit meets following specifications.

Specifications for Neutral Conductor

Always consider the neutral in the 3-phase, wye circuit as a current carrying conductor and ensure that it is no smaller than the line conductors.

Limiting Branch and Feeder Circuit Load Currents

Limit the maximum load current in each 3-phase, wye conductor (lines and neutral) to the values shown in table 1-4.

GROUNDING

Consideration must be given to providing an adequate grounding system when laying out the site. Failure to provide proper grounding may cause a safety hazard or may cause excessive data errors. To be properly grounded, the drive must have two ground connections; a safety ground, and a system ground. Grounding materials and procedures are provided in the Installation section of this manual.

TABLE 1-4. CONDUCTOR LOAD CURRENT LIMITATIONS

Number of Conductors in Conduit, Cable, or Raceway	Limit to this Percentage of Value Specified by NEC* or Local or National Regulations
4 through 6	80%
7 through 24	70%
25 through 42	60%
43 and above	50%
* United States National Electrical Code.	

Safety Ground

A safety ground must be provided by the site ac power system. The green (or green and yellow striped) wire in the drives cord provides the safety ground connection between the drive and the power system. In turn, the site ac power system must tie this connection (safety ground) to earth ground. All site ac power connection points must be maintained at the same safety ground potential.

System Ground

In addition to the safety ground, a system ground connection is also required. There are three alternative system ground connection schemes.

- Grounded Floor Grid - This scheme ties each equipment to a grid located beneath a false floor. The grid consists of horizontal and vertical members which are mechanically secure and have ground straps (or their equivalent) joining the individual members. The ground straps ensure a constant ground potential at all points on the grid. The grid is then tied directly to earth ground. This is the preferred scheme.
- Ungrounded Floor Grid - This scheme also ties each equipment to a grid beneath a false floor. This grid is mechanically secure and tied together with ground straps as described in the grounded floor grid discussion. However, in this case the floor grid is tied to earth ground through a controller or some other piece of equipment.

- Star - This scheme has a separate ground cable going from the controller to each drive, and each drive has a terminator installed on it.

NOTE

The daisy chain scheme of grounding is not recommended for strings of more than ten equipments.

- Daisy Chain - This scheme connects each drive to the next in a string. The string is not to exceed ten drives. The string is terminated by connecting one of the drives to the controller which then connects to earth ground.

I/O CABLES AND TERMINATORS


In laying out the site, consideration must be given to the routing of I/O cables. The drive connects to the controller via two I/O cables that are designated as the A cable and the B cable.

I/O cables connect to the controller in either a star or daisy chain configuration depending on the requirements of the specific installation. Both configurations are shown in figure 1-8.

The star system requires that the A and B cables go directly from each drive to the controller. It also requires an A cable terminator assembly at each drive.


The daisy chain configuration also requires that the B cable go directly from each drive to the controller. However, only the first drive in the chain requires an A cable directly to the controller. The others are connected via the daisy chain. In the daisy chain configuration, only the last drive in the chain has an A cable terminator assembly.

Both the I/O cables and terminators are considered accessories and must be obtained separately from the drive. The part numbers of the terminators and the various available lengths of I/O cables are listed in table 1-5. The pin assignments and signal names may be found in the diagrams section of this manual.



NOTES:

1. MAXIMUM INDIVIDUAL A CABLE LENGTHS = 100 FEET
2. MAXIMUM INDIVIDUAL B CABLE LENGTHS = 50 FEET



9X16

Figure 1-8. I/O Cable Configurations

TABLE 1-5. INSTALLATION ACCESSORIES

	CABLE LENGTH IN FEET/METRES											
	4	5	6	8	10	15	20	25	30	40	50	100
	1.2	1.5	1.8	2.4	3.0	4.5	6.1	7.6	9.1	12.2	15.3	30.5
A CABLE (60-Pin)												
775642XX (Unshielded Flat *)	10	00	01	02	03	04	05	06	07	08	09	
815374XX (Shielded Round)	NA	00	NA	NA	01	02	03	04	05	06	07	08
A CABLE (50-Pin)												
774594XX (Unshielded Flat)	NA	00	01	02	03	04	05	06	07	08	09	
B CABLE												
775643XX (Unshielded Flat *)	NA	00	01	02	03	04	05	06	07	08	09	
927089XX (Shielded Round)	NA	00	NA	NA	01	02	03	04	05	06	07	
OTHER ACCESSORIES												
A Cable Terminator (60-pin): 75841300												
A Cable Terminator (50-pin): 75841301												
Logic Plug: 943724XX												
NOTE: NA = Not Available												
* = See warning in discussion on I/O Cables and Terminators												

Pin assignments and signal names for the 60 pin A cable are shown in figure 1-9. Pin assignments and signal names for the 50 pin A cable are shown in figure 1-10. Figure 1-11 shows pin assignments and signal names for the B cable.

WARNING

When installing or replacing cables on a 60 Hz unit, S/C 49 and above, observe the following warning. To meet F.C.C. requirements for electromagnetic interference, it is mandatory that the round I/O cabling listed in table 1-5, is used for drive installation. If flat cabling listed in table 1-5 is used, it is the users responsibility to provide additional shielding, and obtain F.C.C. approval. Also, see warning in Preface of Hardware Reference manual.

In estimating the I/O cables needed for an installation, decide which configuration will be used and allow sufficient length to permit extension of rack-mounted drives. Limitations on I/O cable lengths may influence system layout. The maximum length for each B cable is 15.3 m (50 ft). Each star system A cable or the cumulative A cabling in a daisy chain system cannot exceed 30.6 m (100 ft) in length.


PACKAGING

Packaging of the drive consists of an outer container (made up of corrugated cardboard and wood) and internal blocking and holddown bolts. Carefully remove the outer container. Set aside the packing material for use during reshipment of the drive. Refer to the unpackaging instruction slip, which is inside the pack shroud area, for instructions on removal of the internal blocking and holddown bolts. When the drive is to be shipped, it must be packaged as it was originally received from the factory.

If it is necessary to reship the drive, obtain packaging instructions from:

Packaging Engineer
Material Services Dept.
Normandale Division, MPI
7801 Computer Ave.
Minneapolis, Mn. 55435

When ordering packaging instructions, specify the exact equipment number and series code of the drive as shown on the equipment identification label.




NOTES:

- \triangle_1 DUAL CHANNEL UNITS ONLY.
- \triangle_2 GATED BY UNIT SELECTED.
- \triangle_3 INDEX AND SECTOR MAY BE IN "A" CABLE AND/OR "B" CABLE.

9P5C

Figure 1-9. A Cable (60 Pin I/O)



NOTES:


\triangle_1 DUAL CHANNEL UNITS ONLY

\triangle_2 GATED BY UNIT SELECTED

\triangle_3 INDEX AND SECTOR MAY BE IN "A" CABLE AND/OR "B" CABLE

9X27

Figure 1-10. A Cable (50 Pin I/O)



NOTES:

1. 26 CONDUCTOR FLAT CABLE. MAXIMUM LENGTH - 50 FT.
2. NO SIGNALS GATED BY UNIT SELECTED.

9P4B


 INDEX AND SECTOR MAY BE IN "A" CABLE AND/OR "B" CABLE.

Figure 1-11. B Cable

INSTALLATION PROCEDURES

GENERAL

The procedures in this discussion describe the actual installation of the drive. These procedures are based on the assumption that the site meets all requirements discussed under Site Preparation.

Generally, the procedures listed below, are listed in the order in which they should be performed. However, this order may vary depending on mounting configurations and specific site installation requirements. Specific procedures for each type of mounting configuration are listed in table 1-6.

- Preinstallation Inspection
- Cabinet Modification
- Slide Installation
- Latch Installation
- Cabinet Leveling
- System Grounding
- Transformer Wiring
- AC Power Cord
- System I/O Cabling
- Routing Sector and Index Signals
- Setting Sector Switches

NOTE

Make sure temperature gradients are not exceeded during installation. Refer to table 1-1 for specifications.

PREINSTALLATION INSPECTION

Perform the following inspection prior to installing the drive.

1. Inspect drive for possible shipping damage. Any claim for this type of damage should be filed promptly with the transporter involved. If a claim is filed, save the original shipping materials.
2. Ensure that all logic cards are firmly seated in logic chassis and power supply.
3. Ensure that the control panel is firmly seated in shroud.
4. Ensure that all connectors are firmly seated, and check for loose hardware.
5. Raise deck and ensure that all cabling is intact and that there are no broken or damaged wires.
6. Check entire drive for presence of foreign material which could cause an electrical short.
7. Check actuator and pack area for presence of material which could obstruct movement of carriage and heads.
8. Ensure that carriage locking pin and ring assembly is moved from SHIPPING LOCK hole to PIN STORAGE hole.

TABLE 1-6. INSTALLATION PROCEDURES

Procedure	Mounting Configuration				
	Ped Cab	Acoustic Cab	Acoustic Drawer	30" Rack	36" Rack
Preinstallation Inspection	X	X	X	X	X
Cabinet Modification			X		
Slide Installation				X	X
Latch Installation				X	X
Cabinet Leveling	X	X			
System Grounding	X	X	X	X	X
Transformer Wiring	X	X	X	X	X
AC Power Cord	X	X	X	X	X
System I/O Cabling	X	X	X	X	X
Routing Sector and Index Signals	X	X	X	X	X
Setting Sector Switches	X	X	X	X	X

CABINET MODIFICATION

Cabinet modification applies only to acoustic cabinet units. This procedure provides the information necessary to install an acoustic drawer in an existing acoustic cabinet. It is assumed that all power, ground and signal cables have been removed from the top mounted drive; and that the drive has been moved to a work area where it can be approached from all sides.

1. Remove left and right side panels and set aside for future installation.
2. Disconnect fan connector P400.
3. Remove and discard rear door assembly.
4. Remove and discard front door assembly, upper and lower hinges, and keeper latch.

NOTE

A convenient support for ballast installation is made by laying two 2 x 4s flat on floor and covering them with a piece of 1/2 inch plywood.

WARNING

Due to weight of ballast, use caution to prevent personal injury.

5. Position ballast beneath frame (see figure 3-4). Using four screws, lockwashers, and flat washer, secure ballast to frame.
6. Install upper and lower front panels using attaching hardware as shown in figure 3-4. Ensure that ground cable is attached to lower front panel.
7. Loosely install keeper latch using attaching hardware as shown in figure 3-4.

WARNING

Due to weight of drive, use caution to prevent personal injury.

8. Perform Slide Installation procedure (see Section 2D, Repair and Replacement) with the following exceptions: Before installing side panels, install case assembly and then slide drive to its closed position. Tighten hardware securing keeper latches. This ensures that latches are properly aligned to case. When keeper latches are tightened, install side panels.
9. Roll drive back to permanent location and perform Cabinet Leveling procedure (this section).
10. Perform System I/O Cabling procedure and Setting Sector Switches procedure (both in this section).

SLIDE INSTALLATION

When installing drives in an equipment rack, it is first necessary to install the slide assemblies in the rack. Refer to the Slide Installation procedure in Section 2D, Repair and Replacement, for all necessary instructions.

LATCH INSTALLATION


A set of keeper latches are required with each slide mounted drive. Install the keeper latches to the rack as illustrated in figure 3-5 or 3-6. Latch orientation, as well as attaching hardware, are shown in the illustration. No latch adjustment is required.

CABINET LEVELING

Cabinet leveling should not be performed until drive is in final location and there is no further necessity to move it. It may be advantageous to install leveling pads prior to installation of other equipment in the cabinet or the connection of cabling.

Cabinet leveling consists of installing leveling pads (leveling pads are shipped in a plastic bag taped to inside of cabinet), placing drive in final location, screwing down leveling pads until drive is aligned with other equipments, and ensuring weight is off casters.

1. Install jam nut on each leveling pad and install a leveling pad at each corner of cabinet frame (see figure 1-12) by raising corner of cabinet and threading leveler into weld nut on frame.
2. Locate drive in final position.
3. Turn leveling pads down until they support drive's weight.
4. Adjust leveling pads until drive is aligned with adjacent equipment.
5. Place spirit level on drive case assembly and adjust leveling pads until drive is level within three angular degrees both front to back and side to side.
6. When drive is level in both directions, tighten jam nut against bottom of frame.



9H375

Figure 1-12. Leveling Pad Installation

SYSTEM GROUNDING

General


This section contains instructions for system grounding connections. It is assumed that the site has been prepared in accordance with the site requirements information provided earlier in this section. Refer to that discussion if there is any doubt about which grounding scheme to use. System grounding procedures are presented as follows:

- Floor Grid Grounding
- Star Grounding
- Daisy Chain Grounding


Floor Grid Grounding

This procedure describes how to ground the system to a floor grid as shown in figure 1-13. In this configuration, ground straps connect the controller and drives to the floor grid. In addition, if the floor grid is isolated from earth ground, then the controller is connected to earth ground. See table 1-7 for grounding accessory part numbers.


FLOOR GRID AVAILABLE



FLOOR GRID UNAVAILABLE - STAR CONFIGURATION





FLOOR GRID UNAVAILABLE - DAISY CHAIN CONFIGURATION



NOTES:

1 REQUIRED IF FLOOR GRID IS NOT GROUNDED.

2 COMMON GROUND STRAP 
EARTH GROUND 

3 CONNECTION AT DRIVE


9X28

Figure 1-13. System Grounding

TABLE 1-7. GROUNDING ACCESSORIES

Description	Part Number	Use
Flat Braided Shielding 15 m (50 ft)	93267009	Construct ground cable
Terminal Lug	40125601	Terminates ground cable to drive and floor grid.
Lockwasher, external tooth, No. 10	10126402	Attaching ground cable to floor grid.
Screw, Pan head, Cross Recessed, self tapping 10-32 x 1/2	17901524	Attaching ground cable to floor grid.

1. Open drive case assembly to gain access to power panel.
2. Prepare ground straps as follows:
 - a. Allowing sufficient length for drive extension, cut ground straps to length needed for the following connections:
 - Controller to floor grid
 - Controller to earth ground (if necessary)
 - Each drive to floor grid
 - b. Crimp and solder terminal lugs to both ends of each ground strap.
3. Connect ground strap between controller ground terminal and floor grid (see step 5 for floor grid connection). If necessary, connect another ground strap between controller ground and earth ground.
4. Attach ground strap to system ground stud on each drive as follows (see figure 1-14):
 - a. Remove nut and lockwashers from system ground stud at rear of drive.
 - b. Place ground strap terminal lug between lockwashers and secure with nut.



9X4B

Figure 1-14. Power Cord Installation and System Ground

5. Connect each ground strap to floor grid as follows:
 - a. Route free end of ground strap through floor cutout.
 - b. Drill a 0.9 mm (11/32 in) hole in floor grid.
 - c. Secure terminal lug to floor grid using screw and lockwasher. Lockwasher goes between terminal lug and floor grid.
6. Close drive case assembly.

Star Grounding

This procedure describes how to ground the system in a star configuration as shown in figure 1-13. In this configuration, ground straps connect the controller to earth ground and to each drive in the system. See table 1-7 for grounding accessory part numbers.

1. Open drive case assembly to gain access to power panel.
2. Prepare ground straps as follows:
 - a. Allowing sufficient length for drive extension, cut ground straps to length needed for the following connections:
 - Controller to earth ground
 - Controller to each drive
 - b. Crimp and solder terminal lugs to both ends of each ground strap.
3. Connect one end of all ground straps to controller ground terminal. Connect one strap to earth ground and route other straps to each drive in system.
4. Attach ground strap to system ground stud on each drive as follows (see figure 1-14):
 - a. Remove nut and lockwashers from system ground stud at rear of drive.
 - b. Place ground strap terminal lug between lockwashers and secure with nut.
5. Close drive case assembly.

Daisy Chain Grounding

This procedure describes how to ground the system in a daisy chain configuration as shown in figure 1-13. In this configuration, ground straps connect the controller to earth ground and to the first drive in the daisy chain. The remainder of the drives are connected by ground straps going from the first drive to the second, the second to the third and so on. See table 1-7 for grounding accessory part numbers.

1. Open drive case assembly to gain access to power panel.
2. Prepare ground straps as follows:
 - a. Allowing sufficient length for drive extension, cut ground straps to length needed for the following connections:
 - Controller to earth ground
 - Controller to nearest drive
 - Each drive to next drive in daisy chain
 - b. Crimp and solder terminal lugs to both ends of each ground strap
3. Connect two straps to controller ground terminal. Connect one strap to earth ground and route other strap to first drive in daisy chain.
4. Route ground straps between drives and referring to figure 1-14 attach ground straps to system ground stud on each drive as follows:
 - a. Remove nut and lockwashers from system ground stud at rear of drive.
 - b. Place ground strap terminal lug between lockwashers and secure with nut.
5. Close drive case assembly.

TRANSFORMER WIRING

The power supply transformer is designed to accept various ac input voltages. The input voltage is applied to the proper transformer primary windings by jumper wires on terminal TB1. A drive is shipped ready to accept the input voltage and frequency listed in the configuration chart that appears in the front matter of this manual.

NOTE

Drives cannot be converted from one frequency to another (50 Hz to 60 Hz) or from one voltage to another (100 Vac to 120 Vac) without making major changes. If such a conversion is necessary, contact your sales representative.

Check ac input power wiring on TBl as follows:

1. Raise deck assembly as shown in section 2A, maintenance.
2. Ensure that input power wiring to TBl conforms to site ac power requirements as shown on figure 1-15.
3. Lower deck assembly by reversing procedure in step 1.

AC POWER CORDS

There are two types of power cords supplied with 50 and 60 Hz drives. One type is permanently attached to the drive and the other type is removable (see figure 1-14).

Ensure that the removable ac power cord (if used) is connected to the drive and secured into place as shown in figure 1-14 prior to connecting power cord to the site ac power source.

SYSTEM I/O CABLING


The following procedures describe how to install and secure I/O cables and terminators to the drive. It is assumed that the site has been prepared in accordance with site preparation information provided earlier in this section. System cabling procedures are presented in the following order:

- Cabling Connections
- Securing Flat I/O Cables
- Securing Round I/O Cables


Cabling Connections

This procedure describes how to connect the I/O cables in either a star or daisy chain configuration (see figure 1-8). Figure 1-16 shows where the I/O cables are connected to the logic chassis.

Figure 1-15. AC Power Wiring



9H9B



9X3A

Figure 1-16. I/O Cable Attachment

1. Connect B cable from channel I controller to drive connector IJ2. For dual channel drives, connect a second B cable from channel II controller to drive connector IIJ2.

NOTE

Steps 2 and 3 apply only to systems using star I/O configuration.

2. Connect A cable from channel I controller to drive connector IJ3. For dual channel drives, connect a second A cable from channel II controller to drive connector IIJ3.
3. Install terminator on drive connector IJ4 and make terminal ground connection (see figure 1-17). For dual channel drives, install a second terminator on drive connector IIJ4.

NOTE

Steps 4 through 6 apply only to drives using the daisy chain I/O cabling configuration. In these steps, upstream and downstream define drives adjacent to a particular drive in daisy chain with upstream drive closer to the controller.

4. Connect A cable to drive connector IJ3 either from channel I controller or from IJ4 of upstream drive. For dual channel drives, connect a second A cable to drive connector IIJ3 either from channel II controller or from IIJ4 of upstream drive.

NOTE

If drive is not last in daisy chain, perform step 5. If drive is last in daisy chain, perform step 6.

5. Connect another A cable from drive connector IJ4 to downstream drive's connector IJ3. For dual channel drives, connect a second A cable from drive connector IIJ4 to downstream drive's connector IIJ3.
6. Install terminator on drive connector IJ4 and make terminal ground connection (see figure 1-17). For dual channel drives install a second terminator on drive connector IIJ4.




Figure 1-17. Terminator Assembly

Securing Flat I/O Cables

The following procedure provides instructions on securing flat I/O cables to the drive.

1. Remove I/O clamp from spacer on logic chassis (see figure 1-18).
2. Arrange I/O cables so they lay flat over spacer.
3. Position I/O clamp over cables and spacer. Ensure that cables are clear of spacer screw holes.
4. Secure I/O clamp into place with screws.

Securing Round I/O Cables

The following procedures provide instructions on securing round I/O cables to various drive configurations. The procedures are presented as follows:

- Pedestal and Acoustic 1X Units
- Acoustic Drawer and Rack Mount Units




Figure 1-18. Securing Flat I/O Cables

Pedestal and Acoustic 1X Units


This procedure describes how to ground and secure I/O cables to pedestal and acoustic 1X units.

1. Remove two strain relief clamps from bracket on logic chassis as shown in figure 1-19.
2. Position I/O cables on strain relief bracket. Install strain relief clamps and secure into place with screws.
3. Remove two grounding clamps and strain relief clamps from rear of pedestal or acoustic frame. See figures 1-20 (pedestal) and 1-21 (acoustic 1X).

NOTE

In the next step, prior to stripping heat shrink, allow sufficient cable length so that logic chassis can be raised for maintenance after cables are secured.

4. Determine where the heat shrink tubing must be removed from all cables, so that bare shielding will be in contact with grooved grounding plate on I/O mounting bracket.



9X31

Figure 1-19. Securing Round I/O Cables (Pedestal & Acoustic 1X)

NOTE

In next step ensure that bare shielding is in contact with grounding plate.

5. Install ground clamps and strain relief clamps and secure with screws.

Acoustic Drawer and Rack Mount Units

This procedure describes how to ground and secure round I/O cables to acoustic drawer and rack mount units.

1. Loosen screw securing I/O cover to housing (located next to time meter) and lift cover off (see figure 1-22).





Figure 1-20. Securing Round I/O Cables (Pedestal)

2. Remove two grounding clamps and strain relief clamps from grounding plate.
3. Determine where the heat shrink tubing must be removed from all cables, so that bare shielding will be in contact with grooved grounding plate on I/O mounting bracket.

NOTE


In next step, ensure that bare shielding is in contact with grounding plate.

4. Install ground clamps and strain relief clamps and secure with screws.
5. Install I/O cover removed in step 1.



9X33

Figure 1-21. Securing Round I/O Cables (Acoustic 1X)



9X34

Figure 1-22. Securing Round I/O Cables (Acoustic Drawer & Rack Mount)

NOTE

If the acoustic drawer unit is to be used as the lower unit in a 2X configuration, perform steps 3 and 5 of procedure for pedestal and acoustic 1X units while observing figure 1-21.

NOTE

If it becomes necessary to raise the deck or logic chassis for maintenance after the I/O cables are secured, perform steps 6 and 7.

6. Remove I/O cover as described in step 1.
7. Remove two screws securing strain relief and grounding bracket to I/O housing (see figure 1-22) and lift bracket (with I/O cables and clamps attached to bracket) from housing.

ROUTING SECTOR AND INDEX SIGNALS

Some drives can be wired to send the Index and Sector signals to the controller via either the A or the B cable. Other drives are able to carry these signals only on one cable or the other and cannot be changed.

Units that cannot be changed are those having Sector and Index only on the A cable (S&IOAC) or only on the B cable (S&IOBC).

Units that can be changed are all those having Sector and Index on both the A and B cables (S&IOABC), except BK5A6-G/H, BK5B5-N/P, and BK5C4-C/D. The following paragraphs describe the wiring of applicable S&IOABC units.

Routing Signals To A Cable

Units will automatically send Sector & Index on the A cable. No change is necessary.

Routing Signals To B Cable

With the main site ac power turned off and with drive's AC POWER and POWER SUPPLY circuit breakers set to OFF, proceed as follows:

1. Gain access to logic chassis and raise it to its maintenance position. (Refer to Accessing Drive For Maintenance in the General Maintenance section of this manual.)
2. Remove jumper plug from B07 on back panel.
3. Return logic chassis to normal operating position.

SETTING SECTOR SELECT SWITCHES

The number of sectors per revolution generated by the drive logic must be matched to that required by the controller. Therefore, sector select switches are provided in the drive logic to allow selection of different sector counts. These switches are located on logic card A2B08 and appear as shown in figure 1-23.

Refer to the subsystem reference manual to determine the number of sectors required by the controller; and then locate that number in table 1-8. Across from the number of sectors listed in the table is a row of Cs and Os. C represents the Closed or On position of the sector switch. O represents the Open or Off position of the sector switch. Set the switches to the positions designated in the table while referring to figure 1-23 for an illustration of the switch positions.

The switch settings listed in table 1-8 have been determined from a formula. Use of this formula is demonstrated below to provide the user with an additional tool for determining sector switch settings.

Each sector will contain a certain number of dibits (received from the servo tracks). The number of dibits in each sector is the result of the number of sectors required by the controller. Thus:


$$\text{Total Dibits per Sector} = \frac{13\,440}{\text{Number of Sectors}} - 1$$

NOTE

Ignore any remainder in the calculation. However, the existence of a remainder adds a "short" sector before index.

Each sector switch represents a binary and decimal value of dibits (as counted in the logic). The values related to each switch are as follows:

ROCKER-TYPE SWITCHES




ROCKER-TYPE SWITCHES:

TO ACTUATE A SWITCH TO ITS CLOSED POSITION,
PRESS ON END OF SWITCH FARTHEST FROM "OPEN" LETTERING.

* SWITCHES 6 AND 7 SHOWN IN CLOSED POSITION.

SLIDE-TYPE SWITCHES



SLIDE-TYPE SWITCHES:

TO ACTUATE A SWITCH TO ITS ON POSITION,
SLIDE SWITCH IN DIRECTION OF ARROW SHOWN ON SWITCH.

* SWITCHES 6 AND 7 SHOWN IN ON POSITION.

9X19

Figure 1-23. Sector Select Switches

<u>Switch No.</u>	<u>Binary Value</u>	<u>Decimal Value</u>
0	2^0	1
1	2^1	2
2	2^2	4
3	2^3	8
4	2^4	16
5	2^5	32
6	2^6	64
7	2^7	128
8	2^8	256
9	2^9	512
10	2^{10}	1024
11	2^{11}	2048

Here is an example of determining the switch settings for selecting 63 sectors:

$$\text{Total Dibits per Sector} = \frac{13\ 440}{63} - 1 = 212$$

NOTE

Remainder is ignored.

Determine which switches to place in the Closed or On position as follows:

Total Dibits per sector	212
Dibits selected by switch 7	<u>128</u>
(Difference)	84
Dibits selected by switch 6	<u>64</u>
(Difference)	20
Dibits selected by switch 4	<u>16</u>
(Difference)	4
Dibits selected by switch 2	<u>4</u>
(Difference)	0

TABLE 1-8. SECTOR SELECT SWITCH SETTINGS

Number of Sectors	Switch Number											
	0	1	2	3	4	5	6	7	8	9	10	11
4	C	C	C	C	C	O	O	O	C	O	C	C
5	C	C	C	C	C	C	C	O	O	C	O	C
6	C	C	C	C	C	C	O	C	O	O	O	C
7	C	C	C	C	C	C	C	O	C	C	C	O
8	C	C	C	C	O	O	O	C	O	C	C	O
9	O	O	C	O	C	O	C	C	C	O	C	O
10	C	C	C	C	C	C	O	O	C	O	C	O
11	O	O	C	O	O	O	C	C	O	O	C	O
12	C	C	C	C	C	O	C	O	O	O	C	O
13	O	O	O	C	O	O	O	O	O	O	C	O
14	C	C	C	C	C	C	O	C	C	C	O	O
15	C	C	C	C	C	C	C	O	C	C	O	O
16	C	C	C	O	O	O	C	O	C	C	O	O
17	C	O	C	O	C	O	O	O	C	C	O	O
18	C	O	O	C	O	C	C	C	O	C	O	O
19	O	C	O	O	O	O	C	C	O	C	O	O
20	C	C	C	C	C	O	O	C	O	C	O	O
21	C	C	C	C	C	C	C	O	O	C	O	O
22	C	O	O	O	O	C	C	O	O	C	O	O
23	C	C	C	O	O	O	C	O	O	C	O	O
24	C	C	C	C	O	C	O	O	O	C	O	O
25	O	O	O	C	C	O	O	O	O	C	O	O
26	C	C	O	O	O	O	O	O	O	C	O	O
27	O	O	O	O	C	C	C	C	C	O	O	O

Table Continued on Next Page

TABLE 1-8. SECTOR SELECT SWITCH SETTINGS (Contd)

Number of Sectors	Switch Number											
	0	1	2	3	4	5	6	7	8	9	10	11
28	C	C	C	C	C	O	C	C	C	O	O	O
29	O	C	C	C	O	O	C	C	C	O	O	O
30	C	C	C	C	C	C	O	C	C	O	O	O
31	O	O	O	O	C	C	O	C	C	O	O	O
32	C	C	O	O	O	C	O	C	C	O	O	O
33	O	C	C	O	C	O	O	C	C	O	O	O
34	O	C	O	C	O	O	O	C	C	O	O	O
35	C	C	C	C	C	C	C	O	C	O	O	O
36	O	O	C	O	C	C	C	O	C	O	O	O
37	O	C	O	C	O	C	C	O	C	O	O	O
38	O	O	O	O	O	C	C	O	C	O	O	O
39	C	C	C	O	C	O	C	O	C	O	O	O
40	C	C	C	C	O	O	C	O	C	O	O	O
41	O	C	C	O	O	O	C	O	C	O	O	O
42	C	C	C	C	C	C	O	O	C	O	O	O
43	C	C	C	O	C	C	O	O	C	O	O	O
44	O	O	O	O	C	C	O	O	C	O	O	O
45	C	O	O	C	O	C	O	O	C	O	O	O
46	C	C	O	O	O	C	O	O	C	O	O	O
47	O	O	C	C	C	O	O	O	C	O	O	O
48	C	C	C	O	C	O	O	O	C	O	O	O
49	C	O	O	O	C	O	O	O	C	O	O	O
50	C	C	O	C	O	O	O	O	C	O	O	O
51	O	C	C	O	O	O	O	O	C	O	O	O

Table Continued on Next Page

TABLE 1-8. SECTOR SELECT SWITCH SETTINGS (Contd)

Number of Sectors	Switch Number											
	0	1	2	3	4	5	6	7	8	9	10	11
52	C	O	O	O	O	O	O	O	C	O	O	O
53	O	O	C	C	C	C	C	C	O	O	O	O
54	C	C	C	O	C	C	C	C	O	O	O	O
55	C	C	O	O	C	C	C	C	O	O	O	O
56	C	C	C	C	O	C	C	C	O	O	O	O
57	O	C	O	C	O	C	C	C	O	O	O	O
58	O	C	C	O	O	C	C	C	O	O	O	O
59	O	C	O	O	O	C	C	C	O	O	O	O
60	C	C	C	C	C	O	C	C	O	O	O	O
61	C	C	O	C	C	O	C	C	O	O	O	O
62	C	C	C	O	C	O	C	C	O	O	O	O
63	O	O	C	O	C	O	C	C	O	O	O	O
64	C	O	O	O	C	O	C	C	O	O	O	O
65	C	O	C	C	O	O	C	C	O	O	O	O
66	O	C	O	C	O	O	C	C	O	O	O	O
67	C	C	C	O	O	O	C	C	O	O	O	O
68	O	O	C	O	O	O	C	C	O	O	O	O
69	C	O	O	O	O	O	C	C	O	O	O	O
70	C	C	C	C	C	C	O	C	O	O	O	O
71	O	O	C	C	C	C	O	C	O	O	O	O
72	C	O	O	C	C	C	O	C	O	O	O	O
73	C	C	C	O	C	C	O	C	O	O	O	O
74	O	O	C	O	C	C	O	C	O	O	O	O
75	O	C	O	O	C	C	O	C	O	O	O	O

Table Continued on Next Page

TABLE 1-8. SECTOR SELECT SWITCH SETTINGS (Contd)

Number of Sectors	Switch Number											
	0	1	2	3	4	5	6	7	8	9	10	11
76	C	C	C	C	O	C	O	C	O	O	O	O
77	C	O	C	C	O	C	O	C	O	O	O	O
78	C	C	O	C	O	C	O	C	O	O	O	O
79	C	O	O	C	O	C	O	C	O	O	O	O
80	C	C	C	O	O	C	O	C	O	O	O	O
81	O	O	C	O	O	C	O	C	O	O	O	O
82	O	C	O	O	O	C	O	C	O	O	O	O
83	O	O	O	O	O	C	O	C	O	O	O	O
84	C	C	C	C	C	O	O	C	O	O	O	O
85	C	O	C	C	C	O	O	C	O	O	O	O
86	C	C	O	C	C	O	O	C	O	O	O	O
87	C	O	O	C	C	O	O	C	O	O	O	O
88	C	C	C	O	C	O	O	C	O	O	O	O
89	O	C	C	O	C	O	O	C	O	O	O	O
90	O	O	C	O	C	O	O	C	O	O	O	O
91	O	C	O	O	C	O	O	C	O	O	O	O
92	C	O	O	O	C	O	O	C	O	O	O	O
93	C	C	C	C	O	O	O	C	O	O	O	O
94	C	O	C	C	O	O	O	C	O	O	O	O
95	O	O	C	C	O	O	O	C	O	O	O	O
96	C	C	O	C	O	O	O	C	O	O	O	O
97	C	O	O	C	O	O	O	C	O	O	O	O
98	O	O	O	C	O	O	O	C	O	O	O	O
99	O	C	C	O	O	O	O	C	O	O	O	O

Table Continued on Next Page

TABLE 1-8. SECTOR SELECT SWITCH SETTINGS (Contd)

Number of Sectors	Switch Number											
	0	1	2	3	4	5	6	7	8	9	10	11
100	C	O	C	O	O	O	O	C	O	O	O	O
101	O	O	C	O	O	O	O	C	O	O	O	O
102	O	C	O	O	O	O	O	C	O	O	O	O
103	C	O	O	O	O	O	O	C	O	O	O	O
104	O	O	O	O	O	O	O	C	O	O	O	O
105	C	C	C	C	C	C	C	O	O	O	O	O
106	C	O	C	C	C	C	C	O	O	O	O	O
107	O	O	C	C	C	C	C	O	O	O	O	O
108	C	C	O	C	C	C	C	O	O	O	O	O
109	O	C	O	C	C	C	C	O	O	O	O	O
110	C	O	O	C	C	C	C	O	O	O	O	O
111	O	O	O	C	C	C	C	O	O	O	O	O
112	C	C	C	O	C	C	C	O	O	O	O	O
113	C	O	C	O	C	C	C	O	O	O	O	O
114	O	O	C	O	C	C	C	O	O	O	O	O
115	C	C	O	O	C	C	C	O	O	O	O	O
116	O	C	O	O	C	C	C	O	O	O	O	O
117	C	O	O	O	C	C	C	O	O	O	O	O
118	O	O	O	O	C	C	C	O	O	O	O	O
119	C	C	C	C	O	C	C	O	O	O	O	O
120	C	C	C	C	O	C	C	O	O	O	O	O
121	O	C	C	C	O	C	C	O	O	O	O	O
122	C	O	C	C	O	C	C	O	O	O	O	O
123	O	O	C	C	O	C	C	O	O	O	O	O

Table Continued on Next Page

TABLE 1-8. SECTOR SELECT SWITCH SETTINGS (Contd)

Number of Sectors	Switch Number											
	0	1	2	3	4	5	6	7	8	9	10	11
124	C	C	O	C	O	C	C	O	O	O	O	O
125	O	C	O	C	O	C	C	O	O	O	O	O
126	C	O	O	C	O	C	C	O	O	O	O	O
127	O	O	O	C	O	C	C	O	O	O	O	O
128	O	O	O	C	O	C	C	O	O	O	O	O

Note: C = Closed or On position; O = Open or Off position.

Thus, placing switches 2, 4, 6, and 7 in the Closed or On position selects 63 sectors of 212 dibits per sector. Since a remainder existed in the calculation formula, an additional "short" sector of 21 Sector Clock pulses (806 kHz) will be present just before index.

CHECKOUT

This procedure describes checks that must be performed on the drive prior to putting it online. Before starting, make sure that the drive has been unpacked and installed in its normal operating position; all grounding, power and I/O connections have been made and sector switches have been set.

1. Set all circuit breakers to off.

NOTE

For all units except BK5C6D, to gain access to the pack area while the drive is powered down, pull down on the solenoid latch and up on the pack access cover latch release.

For the BK5C6D, to gain access to the pack area it is necessary to have the main circuit breaker on for at least 30 seconds.

2. Perform the General Cleaning and the Clean Shroud and Spindle procedures found in the preventive maintenance section 2B.
3. Ensure that all logic cards are firmly seated in their connectors in logic chassis.
4. Swing logic chassis up to maintenance position. Ensure that all connectors are firmly seated on the logic chassis back panel pins, and check for loose or broken wires. Then return logic chassis to normal operating position.
5. Install logic plug in operator control panel.
6. Set all circuit breakers to on, verify that blower starts, and allow it to operate for at least 10 minutes before proceeding to step 7.
7. Install scratch disk pack.
8. Press START switch and verify that the following occurs:
 - a. START indicator lights.
 - b. Drive motor starts and pack comes up to speed in approximately 30 seconds.
 - c. Heads load when pack comes up to speed.
 - d. READY indicator on front panel lights.
9. Perform Servo System Test and Adjustment and Head Alignment procedures in section 2C.

SECTION 2

MAINTENANCE

INTRODUCTION

This section provides all the information necessary to maintain all models and all configurations of the drive. The maintenance discussed in this section is limited to that which can be performed in the field. Unless otherwise specified the information presented here applies to all equipments listed in the front of this manual.

The maintenance procedures defined in this section are to be performed only by qualified maintenance personnel. Maintenance is performed in accordance with the time schedules provided at the beginning of each subsection, or as needed in the case of corrective maintenance.

Information in this section is divided into the following major areas:

- General Maintenance Information - Provides information on safety precautions, maintenance tools and materials, controls and test points, standard test conditions, and accessing the drive for maintenance, be thoroughly familiar with the information in this section.
- Preventive Maintenance - Provides procedures for performing a regularly scheduled maintenance routine.
- Tests and Adjustments - Provides procedures for all the major drive level tests and adjustments which can be performed in the field.
- Repair and Replacement - Provides procedures and information on the replacement and adjustment of drive assemblies. This section assumes that the assembly was previously identified as malfunctioning.

SECTION 2A

GENERAL MAINTENANCE INFORMATION

GENERAL

This section contains general information relating to maintenance of the drive. A person performing maintenance on the drive should be familiar with this information in addition to the operating principles and procedures described in the hardware reference manual.

The information in this section is divided into the following areas:

- Warnings and Precautions - Lists warnings and precautions that must be observed when working on the drive.
- Head/Disk Special Precautions and Procedures - Describes precautions and procedures pertaining specifically to handling and maintenance of the heads and disk pack.
- Electrostatic Discharge Protection - Provides instructions for proper handling of electrostatically sensitive devices.
- Maintenance Tools and Materials - Lists the tools and materials required to perform maintenance on the drive. This includes discussions on the type and handling of disk packs, the field test unit, the head alignment kit, and the use of system software, all of which are used for performing drive tests and adjustments.
- Standard Test Conditions - Describes and defines the basic conditions from which all the test procedures start. This includes defining the power on/off condition, online/offline condition, disconnecting the I/O, and manually positioning the carriage.
- Accessing Drive for Maintenance - Identifies the various parts of the drive electronics assembly and provides the procedures which describe opening and closing the various parts of the machine in order to gain access for maintenance purposes.

WARNINGS AND PRECAUTIONS

WARNING

The following topic provides warnings and precautions that must be observed during maintenance. Refer also to Important Safety Information and Precautions located in the front of this manual following the table of contents. Failure to observe the warnings, precautions, and other safety information provided in this manual could result in personal injury.

Observe the following warnings and precautions at all times. Failure to do so may cause equipment damage and/or personal injury.

- Use care while working with power supply. Line voltages are present inside the base (A1) in the area of the ac power supply.
- Keep hands away from actuator during seek operations and when reconnecting leads to voice coil. Under certain conditions, emergency retract voltage may be present, causing sudden reverse motion and head unloading.
- Use caution while working near heads. If heads are touched, fingerprints can damage them. Clean heads immediately if they are touched.
- Keep pack access cover closed unless it must be open for maintenance. This prevents entrance of dust into pack area. Do not open pack access cover while disk is spinning or attempt to slow disks by hand.
- Keep all watches, disk packs, meters, and other test equipment at least two feet away from voice coil magnet.
- Do not remove or install circuit cards while power is on. Circuit cards are easily damaged by transient voltage spikes which may be generated by removing or installing cards when power is on.
- Ensure that logic chassis is in normal operating position before raising deck. On rail mounted configurations, the logic chassis will be damaged by collision with the cabinet or frame. Also, since logic chassis cannot be secured in maintenance position, it may fall and be damaged as deck is raised.

- If maintenance procedures require opening the acoustic top cover, be sure that the cover's support rod is securely in place. An improperly secured rod can cause the cover to fall and may result in personal injury.
- Do not open acoustic top case when drawer mounted drive has logic chassis in maintenance position. The top case and drawer unit's logic chassis will collide and damage will occur.
- Do not use customer disk pack for testing purposes, (see paragraph on disk packs).
- Do not use CE alignment disk pack unless specifically directed to do so. These packs contain prerecorded alignment data that can be destroyed if test procedure requires drive to write. This alignment data cannot be generated in the field.
- If drive fails to power down when START switch is pressed (to turn off indicator) disconnect voice coil leadwire (see paragraph on manual carriage positioning and manually retract heads before troubleshooting malfunction).
- Make certain that heads are retracted before turning off power.
- If power to drive motor is lost while heads are loaded and not under servo control (during manual carriage positioning), immediately retract carriage. Otherwise heads will crash when disk speed is insufficient to enable heads to fly.
- Keep all metal tools away from flex leads while power is applied in order to prevent damage to the power amplifier.
- Observe all precautions listed under Electrostatic Discharge Protection and Head/Disk Special Precautions and Procedures.

HEAD/DISK SPECIAL PRECAUTIONS AND PROCEDURES

GENERAL

To maintain the high data integrity of the drive, it is necessary to follow certain special precautions and procedures pertaining to the disk pack and heads. These precautions and procedures will minimize the possibility of destructive head to disk contact (head crash) and subsequent loss of data. In addition to preventive measures, these discussions also describe methods of detecting and recovering from a head crash should one occur.

PRECAUTIONS

There are five primary variables that cause the great majority of head crashes. These are 1) the disk drive, 2) the disk pack, 3) the environment, 4) the maintenance and 5) the operator of the disk drive. A list of precautions that can be taken to prevent head crashes will be given for each variable.

1. Disk Drive

- Check the action of the pack access cover latch as it is closed. Latching should occur only after the cover seal has been compressed slightly. The pumping action of the spinning disk pack can cause dirt and dust particles to be drawn in to the shroud if the cover is not sealed at all points. Using a strip of paper (dollar bill size), check the pack access cover-shroud seal by opening the pack access cover and laying the slip of paper on the shroud, then closing the cover (latched). Resistance should be felt while trying to withdraw the paper. Check at multiple places on each side of the shroud.
- Check for adequate positive pressure air flow of 0.5 inches of water (see Replace Absolute Filter procedure).
- Make certain the wood shipping block is removed and the coarse filter is installed in its place. Make certain the coarse filter is not plugged.
- Make certain the shroud area is clean. Look for possible foreign materials and if present find the source and eliminate it.
- If the unit has had a carriage slam, examine the heads for damage and the disk pack for divots where oxide has been removed.
- Ensure that the heads loaded switch is correctly positioned (see Heads Loaded Switch Adjustment procedure). A switch that is too far forward or back may result in the heads projecting slightly into the shroud area so that head 0 may be damaged by the plastic cover during pack load/unload.

2. Disk Pack

- Do not use damaged disk packs. If disk packs arrive in damaged cartons or are suspected of having been dropped, have them inspected before use as the disks may have been bent.

- Keep hands, pencils, or other objects off the disk pack surfaces. The disk pack surfaces not only can be contaminated this way, but also can be distorted or damaged through impact, excessive pressure or abrasion.
- Never lift or hold a disk pack by any of the recording disks, as permanent damage will result.
- Clean the outside (interiors should also be cleaned if contaminated), surfaces of the protective covers periodically to remove any build-up of dust that may occur. Use a lint free gauze pad dampened with head cleaning solution. If possible, use a vacuum cleaner to remove dust that accumulates on the cover lip.
- If the disk drives are not in use and the blower is shut off, take the disk packs out of the drives and store them in their protective canisters.
- Do not allow the pack to rest on or strike any other object when its bottom protective cover is removed.
- Reassemble the disk pack bottom and top protective covers after the pack is mounted in the drive. This should be done even when no disk pack is contained in the cover to prevent dust and dirt from accumulating inside the covers.
- Replace cracked, distorted, or otherwise physically damaged pack covers.
- Do not place disk pack identifying labels anywhere except outside the top protective cover assembly. The pack serial number may be used to maintain correct pack to canister identification.
- The temperature of the disk pack must be stabilized to the temperature of the room in which the drive is operating.

3. Environment

- Install the drive in a room which is kept carefully dusted with particular attention given to keeping a smooth floor mopped and a carpeted floor vacuumed. Carpeted floors can be particularly troublesome because of the dirt and dust they trap and the amount of lint they generate. Traffic in the room housing the disk drive should be kept to a minimum.

- Maintain as much separation as possible between the disk drive and printers and tape and card punch equipment. These machines can generate a lot of paper, carbon, and ink particles. Do not store packs near this type of equipment.
- Eliminate eating, drinking, or smoking in the disk drive area if at all possible. Particles of food and drink can be ingested into the shroud area when the pack access cover is opened and closed. Smoke particles have a sticky characteristic. The absolute filter on the disk drive will clog more rapidly in such an environment.
- If at all possible, maintain the relative humidity in the disk drive operating room at 40% to 50%. Low relative humidity levels can lead to particle attraction and accumulation by static electricity.
- Disk packs and disk drives must be stabilized to the same temperature.
- Avoid building construction in the area of the drive or area used for pack storage. If construction is absolutely necessary make certain that protective steps are taken to avoid contamination in the area of the packs and drives.
- One of the sources of head/disk contamination is the ambient air in the room in which the drive operates. Although the drive is designed to operate successfully over a wide range of ambient air conditions, it follows that the cleaner the room air can be maintained, the better and longer the drive air filtering and handling system can do its job of keeping potentially destructive particles out of the head/disk gap.

4. Maintenance

- Do not, under any circumstances, clean the heads while they are in the unit. If head cleaning is required, remove the heads from the unit and clean per the manual procedure given in this manual. This must only be performed by trained personnel.
- Control Data does not recommend periodic field cleaning of disk packs. If field cleaning is employed, it is done at the risk of the user. Packs that are suspected for any reason should be returned to the vendor for disposition.

- Do not over lubricate the spindle lockshaft.
- Do not use any type of oil or lubricant on the drive except for the very small amount used on the lockshaft.

5. Operator

- Keep the disk pack access cover closed and latched and if possible, keep the shroud blower energized at all times. This will help keep contaminants out of the shroud cavity and away from the heads. Remove pack and store in its protective canister if blower motor is not energized.
- Do not store pack on drives - vibration will shake them off.
- Never lift or hold a disk pack by any of the recording disks, as permanent damage and or contamination will result.
- Keep disk packs out of the drives and locked in their protective covers when not in use.
- Do not allow the pack to rest on or strike any other object when its bottom protective cover is removed for installation in the drive.
- Reassemble the disk pack bottom and top protective covers. This should be done even when no disk pack is contained in the cover, to prevent dust and dirt from accumulating inside the covers.
- Do not place disk pack identifying labels anywhere except outside the top protective cover assembly. The pack serial number may be used to maintain correct pack to canister identification.
- Do not eat, smoke, or allow beverages near the drive or pack.

DETECTION AND RECOVERY

General

Previous sections have been concerned with precautions to be observed and preventive maintenance steps to be taken to minimize the occurrence of head crashes. But suppose all of those things have been done and the drive is in operation. Will the

drive even issue any warning of an impending head crash? If a head does crash is there any danger that the crash can be propagated to other disk packs and other drives? If so what should be done? Answers to these questions will be covered in this section.

Head Crash Detection

It is important that the drive operator be aware of a number of head crash signals and warnings provided by the drive itself. These are described in the following paragraphs.

CAUTION

Should the conditions under 1, 2, or 3, below, be detected, shut down the drive at once. Under these conditions the pack should not be installed on another drive without first ensuring that the pack has not been damaged or contaminated. (See "Evaluate the Disk Pack" and "Disk Pack Inspection and Cleaning" in this section.) Also, do not attempt to operate the drive with another disk pack until full assurance is made that no damage or contamination has occurred to the drive heads or to the shroud area.

1. Head to disk contact may have occurred if the following conditions are noted when the heads are over the disk.
 - An audible "ping" or a scratching noise is heard.
 - A burning odor is detected.
2. Head to disk contact will have occurred if:
 - Concentric rings, nicks or areas where oxide has been removed are observed on the disk surface.
 - Small deposits of very fine black dust are observed on the shroud walls. Test by running fingertip along shroud wall and inspecting.

3. Warnings of impending head crashes are very often provided by the data signals picked up by the heads. Under conditions of increasing contamination in the air cushion on which the head flies, variations in flying height can become a significant proportion of the nominal height. Since both the magnetic intensity of the data pulse as recorded on the disk and the pulse as read from the disk are greatly influenced by head gap to disk distance, variations in flying height can result in the generation of data errors. Continuous monitoring of data error rate is strongly recommended. A pack may have been damaged yet have no marks visible to the naked eye. A significant increase in data error rate of the order of five to ten times normal should be heeded as a definite warning signal.

Guide For Determining The Cause Of Head Crashes

If the drive has been shut down because head crash detection signals have been observed, the following steps should be taken:

1. Reconstruct the operating history of the disk pack. The purpose of this history is to determine the actual source of the crash (first drive and pack).
 - a. Evaluate drive failures that may possibly have occurred prior to head crash.
 - b. If available, make the previous drive on which the crashed pack was used, and the previous pack used on the crashed drive, part of the investigation. The crash may have been propagated.
 - c. Try to reconstruct the mode of operation when the failure occurred. Had anything unusual happened prior to the failure?
 - d. How long had the pack been on the drive before the crash? Was it a new pack? New drive? Had there been any shipping damage when the drive or pack arrived on the site?
2. Reconstruct the conditions of drive, pack and heads as they existed prior to the crash.

- a. Drop the circuit breakers and disconnect the power cord.
- b. Remove the top cover.
- c. Reinstall the crashed disk pack.
- d. Manually position the head arm assemblies toward the spindle to the point just before the head arms slide off the head cam towers.
- e. Looking through the shroud observation window with a hi-intensity light, look to see if the heads appear to be equidistant with respect to the disks. (Under no circumstances should any part of the head be in contact with a disk prior to sliding off the cam surface.
- f. With the heads still in the "over the disk condition," manually turn the pack (by rotating with the top trim shield) and verify that the head to disk spacing remains constant.
- g. Look at the recording surfaces and make note of which disk pack surfaces (and heads) have had contact.
- h. Slide the head arms off the cam towers onto the disks. Do not rotate the disk pack or traverse the heads across disks. Look at the head assemblies (particularly those which have not crashed). Note any head load springs that are relatively close to or touching the disk.
- i. Retract the carriage and remove the pack. (Evaluate the heads) and further inspect those head assemblies during step 4 of this procedure.

3. Evaluate the Drive

- a. With the disk pack removed, manually position the carriage so that the heads are in a loaded position. Traverse the carriage repeatedly between the carriage front stops and the unload cams. If resistance is found, check for the following possible causes: bound velocity transducer; flex lead retainer mispositioned and is striking the rail bracket; worn rail; bad carriage bearing; obstruction caught on the magnet; foreign material on the rails. Retract the carriage to the full retract position.

- b. Connect the power cord and turn on the AC breaker. Check for adequate air flow entering the shroud area. If questionable, either compare with another drive in the area or remove the positive air filter and replace with another filter. Drop the AC breaker and disconnect the power cord.
- c. Using a strip of paper (dollar bill size), check the pack access cover seal as follows. Open the pack access cover, lay the slip of paper on the shroud, close cover (latched), and try to withdraw the paper. Resistance should be felt while trying to withdraw the paper. Check several places on each side of the shroud.
- d. When cleaning the shroud area, look for possible foreign material (paper, plastic, etc.). If contamination exists, try to determine the type and its possible source.
- e. Note head positions then remove all heads for evaluation and cleaning.

4. Evaluate the Heads

- a. While making head-pack observations in the drive, if it was noted that any part of a head load spring appeared to be close to a disk, the possibility exists that the fixed arm (part attached to the carriage) is bent. Look at the subject head for evidence of a burnish mark on the cam arm where it might possibly have struck the disk on a head cam.
- b. Compare crashed heads to non-crashed heads and look for possible mechanical failure differences such as bent gimbal springs, etc.
- c. Return non-recoverable heads to the manufacturer for further analysis.

5. Evaluate the Disk Pack

- a. Install crashed pack on drive (use a pack inspector if available) and try to determine if pack has been damaged in any way. Using observation window in shroud and high intensity light, rotate pack and note any disk fluctuation (up and down). None should be in evident (including upper and lower cover disks).

- b. Look on pack trim shield (top of pack) for any evidence of adhesive. A pack identification label might have been applied.
- c. Look for an unusually high amount of "dings" or chips at the outer area of the data disks. If found, these may be due to carriage slams - a drive malfunction.

Recovery From A Head Crash

The following procedure should be used to ensure all contamination is removed from a unit after a head crash. This is essential to eliminate propagation to both packs and drives. Consult the repair and replacement section of the manual for details on these steps.

1. Remove all power to the drive.
2. Remove the case assembly.
3. Remove all heads, keeping them in order.
4. Clean the inside of the shroud and the inside of the pack access cover using lint free cloths and head cleaning solution. Do not let any solution contact the rubber gasket in the pack access cover.
5. Clean the rails and carriage (if crash debris was coarse). Remove the magnet and the carriage and coil assembly if necessary.
6. Clean the air system duct surfaces with head cleaning solution.
7. Replace the carriage and coil assembly and magnet if removed. Ensure that the carriage motion is smooth and unobstructed.

8. Consult the paragraph on head-arm replacement criteria in the repair and replacement section of this manual before installing the heads. Replace any heads that are defective per these criteria. Replacement heads should be new or those that have been cleaned by properly trained personnel. Ensure before replacing any undamaged heads that their spoiler holes are free of the characteristic fine dust which they collect when a crash occurs. Install the heads and tighten their clamping screws to 1.4 N·M (12 lb in).
9. Reinstall the case assembly.
10. Disable the voice coil drive. Apply power and purge for five minutes with a good pack rotating.
11. Perform a manual heads load. Be aware of any burning odor behind the drive, an indication that the heads are still not flying correctly. If this odor is detected repeat the head crash recovery procedure starting from step 1.
12. Enable the voice coil drive. Load a scratch pack. Using a field test unit perform a sequence forward write operation, covering the entire pack. Read back for ten minutes, first sequencing forward over the entire pack then performing random seeks. Look for error free performance. This will give confidence that all heads are flying correctly.
13. Perform a head alignment per the procedure called out in the tests and adjustments section in the manual.

ELECTROSTATIC DISCHARGE PROTECTION

All drive electronic assemblies are sensitive to static electricity, due to the electrostatically sensitive devices used within the drive circuitry. Although some of these devices such as metal-oxide semiconductors are extremely sensitive, all semiconductors as well as some resistors and capacitors may be damaged or degraded by exposure to static electricity.

Electrostatic damage to electronic devices may be caused by a direct discharge of a charged conductor, or by exposure to the static fields which surround charged objects. To avoid damage to drive electronic assemblies, service personnel must observe the following precautions when servicing the drive:

- Ground yourself to the drive - whenever the drive electronics are or will be exposed, connect yourself to ground with a wrist strap (see table 2-1 for part number). Connection may be made to any metal assembly or to the ground jack at the rear of the drive. As a general rule, remember that you, the drive, and the circuit cards must all be at ground potential to avoid potentially damaging static discharges.
- Keep cards in conductive bags - when circuit cards are not installed in the drive, keep them in conductive static shielding bags (see table 2-1 for part number). These bags provide absolute protection from direct static discharge and from static fields surrounding charged objects. Remember that these bags are conductive and should not be placed where they might cause an electrical short circuit.
- Remove cards from bags only when you are grounded - all cards received from the factory are in static shielding bags, and should not be removed unless you are grounded.
- Turn off power to drive before removing or installing any circuit cards.

MAINTENANCE TOOLS AND MATERIALS

GENERAL

The maintenance procedures described in this manual require the use of certain special tools, test equipment, and materials. These tools, and test equipment are listed in table 2-1 along with the appropriate source part number. Note that the list only includes special tools. It is assumed that the user has at his disposal all the common hand tools such as wrenches, screw drivers, and the like.

Most of the items listed in the table require no explanation. The items listed in the table are called out in the specific procedures in which they are required. However, some of the items included in the list require further explanation.

Throughout this manual the procedures assume that the reader has a disk pack and some means of exercising the drive at his disposal. The procedures are written assuming the field test unit is available. However, if there is suitable system software available it may be used in place of the field test unit. Likewise, the head alignment kit is available either by itself or as a part of the field test unit. The following paragraphs discuss the disk packs, field test unit, head alignment kit, and system software.

DISK PACKS

The maintenance procedures refer to three types of disk packs: (1) customer (2) scratch and (3) CE. All three are physically identical, but are used for different purposes.

A customer disk pack refers to a pack used by the customer for data storage during normal online operations.

The CE pack contains special prerecorded information used during maintenance. Use care to ensure that this data is not destroyed or altered.

A scratch pack is simply a disk pack that does not contain customer or other information that must not be destroyed. Therefore, a scratch pack can be used in maintenance procedures where a danger exists that the pack could be damaged or its information altered.

FIELD TEST UNIT

The Field Test Unit (FTU) is basically an offline tester. This means that the drive cannot be selected or used by the controller while the FTU is in use. The one exception to this is that the FTU can be used to monitor head off-set while a test software routine is performing the head alignment check.

TABLE 2-1. MAINTENANCE TOOLS AND MATERIALS

Description	CDC ¹ Part Number
Adapter (3/16 Hex to 1/4 Sq)	CDC 12262582
Adhesive, (4 oz) Magnet Carriage Stop - S/C 26 & BLW only	CDC 95050802
Adhesive (Drive Seals) (1 oz)	CDC 64303300
Blank Tab Card (Computer Punch Card) ²	CDC 70631686
Bonding Agent, Fast Set	CDC 95033900
Card Extender	CDC 54109701
Card Extraction Tool	CDC 87399200
Carriage Alignment Arm	CDC 75018400
Chip Extender (Chipclip)	CDC 12212196
Cloth, Lint Free	CDC 94211400
Deck Support Bracket (S/C 16 & BLW)	CDC 87073000
Disk Pack, CE (40 MB) (876-51)	CDC 70439001
Table Continued on Next Page	

TABLE 2-1. MAINTENANCE TOOLS AND MATERIALS (Contd)

Description	CDC Part Number
Disk Pack, CE (80 MB) (877-51)	CDC 70438700
Disk Pack, Data (40 MB) (876)	CDC 70439500
Disk Pack, Data (80 MB) (877)	CDC 70438000
Dust Remover, Spray Dry ² (12 oz)	CDC 95047800
Field Test Unit (TB216A) (with Head Alignment)	CDC 82338800
Gauze, Lint Free	CDC 12209713
Grease, Dielectric (4 oz)	CDC 95533600
Head Adjustment Tool	CDC 75018803
Head Alignment Kit ⁵	CDC 77440503
Head Cleaning Solution (8 oz)	CDC 82365800
High Intensity Light ⁴	CDC 12212038
Hose Assembly	CDC 82346500
I/O Pin Removal Tool	CDC 12212759
Loctite, Grade C	Loctite Corp.
Loctite Primer, Grade T	Loctite Corp.
Lubricant Paste (2.8 oz)	CDC 95016101

Table Continued on Next Page

TABLE 2-1. MAINTENANCE TOOLS AND MATERIALS (Contd)

Description	CDC Part Number
Mirror	Commercially Available
Non-Metallic Feeler Gauge, 0.005 inch	CDC 12205633
Oscilloscope, Dual Trace	Tektronix 454A or equivalent
Oscilloscope Hood	Tektronix 016-0083-00
Pin Straightener	CDC 87369400
Pressure Gauge Kit, Differential (optional)	CDC 73040100
Push-Pull Gauge	CDC 12210797
Wirewrap Removal Tool, 20-30 Gage	CDC 12259183
Scope Probe Tip (Hatchet Type)	CDC 12212885
Speed Sensor Adjustment Tool (Go NoGo Tool)	CDC 87052601
Sprayable Adhesive	CDC 95018602
Static Ground Wrist Strap	CDC 12263496
Large (6 1/2 to 8 in. wrist)	CDC 12263623
Small (up to 6 1/2 in. wrist)	CDC 12263627
Static Shielding Bag	CDC 12263627
Table Continued on Next Page	

TABLE 2-1. MAINTENANCE TOOLS AND MATERIALS (Contd)

Description	CDC Part Number
Torque Screwdriver ³	CDC 92016400
Torque Screwdriver Bit ³	CDC 87016701
Torque Wrench, 1/4 inch	CDC 12263205
Volt/ohmmeter	Ballantine 345 or equivalent digital voltmeter
Wire Wrap Bit, 30 Gauge	CDC 12218402
Wire Wrap Gun, Electric	CDC 12259111
Wire Wrap Sleeve, 30 Gauge	CDC 12218403
<p>¹ CDC is a registered trademark of Control Data Corporation.</p> <p>² Used for head cleaning.</p> <p>³ Torque screwdriver and bit are used for torquing head clamping hardware.</p> <p>⁴ Works only with 120 V, 60 Hz. For other voltages and frequencies, use commercially available 100 or 150 watt outdoor floodlight with suitable receptacle and extension cord. Note: Light must have hard safety glass bulb and all items must be rated for use with applicable source power.</p> <p>⁵ Only at sites where FTU not available and alignment performed through host computer.</p>	

The FTU is connected to the drive in one of two ways: (1) through the standard I/O connectors on the I/O card(s) (On dual channel units the FTU may be connected to either channel I or channel II, depending on which I/O is to be checked.) or (2) through the I/O bypass connection.

The standard I/O connection requires that the system I/O cables be disconnected and that the FTU I/O cables be connected in their place. This also requires that the FTU flat cable adapter cables be used. When the FTU is connected to a drive through the standard I/O connections, the drive (on channel) to which the FTU is connected, must have an I/O terminator card installed. When the FTU is connected through the I/O the drive must be set to Online operation. However, the Local/Remote switch A10S1 may be set to either position depending on whether or not the drive is to be powered on from the FTU.

The I/O bypass connection leaves the system I/O cables in place and connects an I/O bypass cable between the FTU and connector A2J2 on the logic chassis backpanel. When the FTU is connected through the I/O bypass connection, the drive must be set to Offset operation.

Specific instructions for interconnecting the drive and the FTU are contained in the preliminary set-up instructions in the FTU manual. Likewise, the procedures for causing the drive to perform various operations (access, read, write, head selection) required for testing are contained in the FTU manual. When performing the preliminary set-up procedure the drive oriented switches located on the FTU panel shall be set as follows:

- RPM to 3600 (HI)
- TPI to 200 (LO) for BK4XX and to 400 (HI) for BK5XX
- HEADS to 5 (LO)
- BPI to 6000

The FTU also contains the head alignment card. The head alignment card, used in conjunction with the meter on the FTU, performs the same function as the head alignment kit. Refer to the following paragraph for details on the head alignment kit.

HEAD ALIGNMENT KIT

The head alignment kit contains the head alignment card, the head alignment cable, and the associated null meter (refer to figure 2-1). The head alignment card develops an output voltage which is derived from the output of the servo and read/write preamplifiers. When a CE disk pack is installed in the drive, this output voltage will be proportional to the distance a selected head is offset from the track centerline. The head alignment card plugs into card location A02 in the logic chassis.

The head alignment card included in the kit is either the _FSV card or the AZPV card. The only difference between the cards is that the AZPV card does not have the four indicators found on the _FSV card (see figure 2-1).

The following toggle switches, located on the card edge, control the cards operation:

- S1 - Changes the polarity of the alignment signal and is used in aligning both servo and read/write heads. Refer to paragraph on calculating offset in Head Alignment procedure. (See Tests and Adjustments Section.)
- S2 - When switch is in S position, the card selects the servo head as an input to the card. When switch is in R/W position it selects a data head input to the card.
- S3 - Changes sensitivity of card. When in X.1 position, the cards sensitivity is reduced by a factor of 10. When in X1 position, the cards sensitivity is not reduced. This switch must be in X1 position when making measurements for use in calculating head alignment error.

Four indicators are provided on the _FSV card (but not on the AZPV card) as monitors to ensure the card is operating properly and is receiving the proper data. These indicators are as follows:

Power - When lighted it indicates power is applied to card.

Input - When lighted, it indicates the input signals are too low for the alignment card circuits to operate.

Bad Track - When lighted, it indicates a short duration loss of input. A one shot maintains the lighted condition for at least four seconds. Note that this indicator lights when the position of switch S1 is changed.


Mode - When lighted it indicates that either S2 is in the S (servo) position or S3 is in the X.1 position. When either of these conditions exists, read/write head alignment error cannot be measured.

The card receives its inputs through the connector in logic chassis card position A02. The Servo Dibits signal is wire-wrapped to this connector. The ground and Head Alignment Output signals are provided through the head alignment cable which is part of the head alignment kit. This cable connects between card slot A2 (pins 08 through 11) on the wirewrap side of the logic chassis, and connector J104 located on the head select/read amplifier card A3A02.

The output voltage of the card is measured by a null meter which connects through test leads to test points X and Z on the card. This meter is either part of the head alignment kit or is located on the FTU panel.

The switch on the meter's front panel changes the sensitivity of the meter. When in the 50 position, the meter reads 50mV full scale. When the switch is in the 500 position, the meter reads 500mV full scale. The switch must be in the 50 position when making measurements for use in calculating head alignment errors.

Figure 2-1. Head Alignment Kit



- 1 METER IS PART OF FTU OR HEAD ALIGNMENT KIT. METER READINGS TO LEFT OF ZERO ARE NEGATIVE AND READINGS TO RIGHT OF ZERO ARE POSITIVE.
- 2 NEWER KITS HAVE AZPV CARD
- 3 INDICATORS DO NOT APPEAR ON AZPV CARD

SYSTEM SOFTWARE

The drive may also be tested by use of microdiagnostic test routines (system software). This requires use of the controller and the appropriate software. In this type of testing the drive communicates with the controller as during normal online operations. No special I/O connections are necessary.

When system software is used to test the drive; it must be set to online operation, have power applied, have the correct disk pack installed, and have the appropriate logical address plug installed.

Refer to manuals or other documentation applicable to the specific system or subsystem for information concerning the system software routines.


MAINTENANCE CONTROLS AND TEST POINTS

GENERAL

Throughout this manual references are made to switches, indicators, and test points. The material contained in the following two paragraphs identify and define these controls. Since much of the information is based on the physical location code of the control or test point, refer to the General paragraph under Accessing Drive For Maintenance for a discussion of the codes.

MAINTENANCE CONTROLS

In addition to the operator panel and power panel switches and indicators described in the Operation section of the Hardware Reference Manual, the drive has a number of controls used primarily for maintenance. All these controls are located on the edges of cards in the logic chassis. Figure 2-2 illustrates these controls and indicates the switch positions. Table 2-2 describes the function of each control. For single channel drives disregard all references to logic card B05.



NOTE: DUAL CHANNEL CARD COMPLEMENT SHOWN.

9X20

Figure 2-2. Maintenance Switches and Indicators

TABLE 2-2. MAINTENANCE SWITCHES AND INDICATORS

Physical Location Code	Name	Description
A04CR1	Voltage	Lights to indicate a below normal voltage existed.
A04CR2	Write	Lights to indicate a write fault existed.
A04CR3	HD SEL	Lights to indicate a multiple head select occurred.
A04CR4	R W	Lights to indicate that both write and read were selected simultaneously.
A04CR5	OC (W + R)	Lights to indicate that a write or read was selected during a seek operation (not on cylinder).
A04S1	Maint Fault Clear	<p>CLEAR position clears out Fault latch and five Fault Status latches. When switch is actuated fault indicators on edge of Fault card go out and remain out unless condition causing fault still exists.</p> <p>NORM is normal operating position for switch and position to which it returns when released (spring loaded).</p>
A04S2	Maint Unit Disable	<p>Although switch exits on both single and dual channel drives, or is only used on single channel units. Dual channel units use switches B05S1 and S2 for same purpose. DISABLE position prevents Unit Selected from being sent to controller and disables transmitters and receivers.</p>
Table Continued on Next Page		

TABLE 2-2. MAINTENANCE SWITCHES AND INDICATORS (Contd)

Physical Location Code	Name	Description
A04S2	Maint Unit Disable	NORM is normal operating position and position switch must always be in for all dual channel drives.
A10S1	Local/Remote	<p>LOCAL position prevents control of power sequencing by controller. Drive is powered on and off by START switch assuming circuit breakers are set to On.</p> <p>REMOTE position allows controller to command power sequencing. Drive cannot be started until a ground is applied via subsystem Power Sequence Pick and Hold lines.</p>
B05CR1	CH I Select	Lights to indicate Channel I has selected drive.
B05CR2	CH I Res	Lights to indicate Channel I has drive reserved.
B05CR3	CH II Select	Lights to indicate Channel II has selected drive.
B05CR4	CH II res	Lights to indicate Channel II has drive reserved.
B05S1/S2	Channel I/II Maint Unit Disable	Switches apply only to dual channel units. They perform same function as switch A04S2. In DI position switch S1 disables Unit Selected signal, transmitters, and receivers to channel I controller. Switch S2 disables Unit Selected signal, transmitters, and receivers to channel II controller when set fo DII position.

Table Continued on Next Page

TABLE 2-2. MAINTENANCE SWITCHES AND INDICATORS (Contd)

Physical Location Code	Name	Description
B05S3	Release Timer Select	<p>NORM is normal operating position for switches.</p> <p>When performing maintenance on drive both switches should be set to their disable position.</p> <p>Switch applies only to dual channel drives. Used to select between an absolute reserve and reserve time condition to control selection of drive by controller. In ABR (absolute reserve) position, controller selecting drive has control until it issues a release command. During this time opposite channel controller is unable to select drive except by using disable command (see reference manual). In RTM (Reserve Timer) position, first controller to select drive, holds it reserved for nominally 500 ms following time Unit Select Tag is dropped. During this time, opposite channel controller cannot select drive except by using disable command (see reference manual).</p>

TEST POINTS

Throughout the drive there are a number of test points which are used in the various stages of maintenance. Table 2-3 lists these test points. The table is arranged in alpha-numeric order by physical location codes of the cards. Refer to the General paragraph under Accessing Drive For Maintenance for a description of the physical location codes.

Table 2-3 also lists the card type(s) that may be in any given physical location. If the test point information is true for a number of card types, then all the types are listed. If the information changes between different card types in a given physical location, then there are individual listings for each card type.

Test points "A" and "Z" on all cards are always ground and are therefore not listed in the table. The test points are listed alphabetically for each card type. The alphabetical identification for the test point also appears next to the test point on the card. The table identifies those test points which are on the card edge and can be reached while the card is in the logic chassis. The remainder of the test points can only be accessed with the card on a card extender.

The last column in the table provides the cross reference number for the logic page in the logic diagrams that show the test point.

STANDARD TEST CONDITIONS

GENERAL

Unless otherwise specified all drive tests start with power removed from the drive and the drive set to offline operation. Some tests require that the FTU be installed which may require that the I/O cable be disconnected. Also some special tests require that the carriage be manually positioned. The following paragraphs define these standard test conditions. All procedures throughout this manual assume the reader is familiar with these conditions.

POWER ON/POWER OFF

The drive may be either online or offline when it is powered on or off. In order to apply power the following interlocks must be closed:

- Deck Interlock Switch - Deck in normal operating position
- Pack Cover Switch - Pack access cover closed.

In addition to the interlocks, the LOCAL/REMOTE switch A10S1 and the Power Sequence pick and Hold lines must also be considered in the power on sequence. During normal maintenance the LOCAL/REMOTE switch is set to LOCAL, and therefore when all

TABLE 2-3. TEST POINTS

Physical Location Code/Card Type	Test Point	Title	Cross Ref	Comments	
A2A01/CLSV	T	+ 9.67 MHz Clock	012		
	U	- Dibit Strobe Pulse	012		
	V	- Dibit OSC Window	012		
	W	+ Write Clock Strobe	013		
	X	+ Write Clock Window	013		
	Y	+ 19.34 MHz Clock	013		
A2A03/HFRV GFRV	E	+ Sensing Dibits	032		
	F	+ CYL Detect A	034		
	G	+ CYL Detect B	034		
	H	+ Track Servo Signal	034		
	J	- Analog Servo Detect	033		
	K	- Attenuator Output	032		
	L	+ Analog Servo Detect	034		
	M	+ Attenuator Output	032		
	N	+ 14 V 031			
	P	- 14 V 031			
	Q	+ AGC 034			
	R	- Peak Detector	033		
	S	+ Peak Detector	033		
	T	+ AGCed Servo Signal	033		
	U	- AGCed Servo Signal	033		
	V	- Trigger	034		
	W	+ 50% Detector	034		
	X	- 50% Detector	034		
Y	+ Timer	034			
A2A04/DKfV RkFV	B *	+ Up To Speed	044		
	C *	Not Used	-		
	D *	Not Used	-		
A2A05/HLRV KLRV	B *	+ Strobe Pulse	052	KLRV used	
	C *	+ Missing Address (ECL)	053	only on	
	D *	+ Data Window	052	BK5B6A-D;	
	E *	- AM Disable	053	S/C 21 &	
	F *	+ Missing Address (TTL)	053	Abv. HLRV	
	G *	- Lock to Data + AM Pulse	053	used on	
	H *	- Missing Address Pulse	053	all other	
	J *	+ Read Gate	053	units	

Table Continued on Next Page

TABLE 2-3. TEST POINTS (Contd)

Physical Location Code/Card Type	Test Point	Title	Cross Ref Comments
A2A06/BLZV	X	+ Low Frequency Filter Output	052
	Y	- Low Frequency Filter Output	
	W	+ VCO Input	063
	X	+ Data Window Divide By 2	064
	Y	+ Data Strobe	062
A2A07/BLQV LLQV	B *	+ INTEG Velocity	072
	C *	+ Summing AMP Output	072
	D *	+ Desired Velocity	072
	E *	+ Coarse Position Error	073
	F *	+ Velocity	072
	W	- Coarse Position Error	073
	X	- D/A Bits 0 - 6	073
	Y	+ Summing Amp Notch Amplifier	072
A2A07/JLQV NLQV	B *	+ INTEG Velocity	072
	C *	+ Coarse Position Error	073
	D *	+ Desired Velocity	072
	E *	+ Summing AMP Output	072
	F *	+ Velocity	072
	T	+ Buffered Velocity	072
	U	- D/A Bits 0 - 5	073
	V	+ D/A Bits 0 - 7	073
	W	- Coarse Position Error	073
	X	- D/A Bits 6, 7	073
Y	+ Summing Amp Notch Amplifier	072	

Table Continued on Next Page

TABLE 2-3. TEST POINTS (Contd)

Physical Location Code/Card Type	Test Point	Title	Cross Ref	Comments
A2A08/ELUV FLUV	B *	- EOT Integrator Clamp	082	
	C *	+ EOT Integrated Velocity	082	
	D *	Offset Analog	084	
	E *	+ Fine Position Notch Amplifier	085	ELUV only
	E *	FWD + REV Offset Analog	084	FLUV only
	F *	+ Fine Position Analog	084	
A2A09/FLPV	W	- Fine Position Analog	092	
	X	- Summing Amplifier	092	
	Y	+ Power AMP Driver	093	
A2A10/6SGV	B *	Speed Analog	103	
	C *	+ Remote Start	102	
	D *	- Speed Pulses	104	
	E *	+ Up To Speed Enable	104	
	F *	+ Delayed Up To Speed Enable	104	
A2B01/FTVV GTVV	B *	+ CH I Unit SEL Bit 2	113	
	C *	+ CH I Unit SEL Bit 3	113	
A2B02/JRVV	B *	+ Control select	124	
	C *	- CH I Open Cable Detect	124	
	D *	+ Tie High	124	
A2B03/FTVV GTVV	B *	+ CH II Unit SEL Bit 2	133	
	C *	+ CH II Unit SEL Bit 3	133	
A2B04/JRVV	B *	+ Control Select	144	
	C *	- CH II Open Cable Detect	144	
	D *	+ Tie High	144	

Table Continued on Next Page

TABLE 2-3. TEST POINTS (Contd)

Physical Location Code/Card Type	Test Point	Title	Cross Ref	Comments
A2B05/EKHV	B *	+ Reserve Timer	153	
	C *	+ Selected Clock	152	
	D *	+ CH II Select Compare	154	
A2B06/FLWV	B *	- Carry Interrupt	163	
A2B07/DLXV ELXV	B *	+ Strobe Data	172	
	C *	- Uncompensated MFM Data	173	
	D *	+ Write Gate	172	
	E *	+ Data Buffer	172	
A2B08/FLTV	B *	+ Reverse EOT Pulse	183	
	C *	+ Index	182	
A2B09/MLVV NLVV	B *	- Seek Pulse	193	
	C *	- Start Seek	193	
	D *	- Power Up Delay	194	
A2B10/6SMV	B *	- Disable CH II	202	
	C *	- Disable CH I	202	
	D *	DIFF Output	202	
	E *	DIFF Output	202	
	F *	- Seek Interrupt	202	
	A3A02/NZJN PZJN	A *	Read Preamplifier	263
B *		Read Preamplifier	263	
E *		+ AGC REF Voltage	263	
F *		AGC Output	263	
G *		AGC Output	263	
H		- 6 Volts	261	
HO		Head Select 0	262	
H1		Head Select 1	262	
H2		Head Select 2	262	
H3		Head Select 3	262	
H4		Head Select 4	262	

Table Continued on Next Page

TABLE 2-3. TEST POINTS (Contd)

Physical Location Code/Card Type	Test Point	Title	Cross Ref	Comments	
A3A03/CZKN EZKN	J	+ Read Enable	262		
	K	+ 6 Volts	261		
	L	Rectifier Output	263		
	M	+ Missing Address	263		
	N	+ Read Address Mark Enable	263		
	P	+ Address Mark Detect	263		
	Q *	+ Multiple Head Select Fault	262		
	R	- Analog Data	263		
	S	+ Analog Data	263		
	A *	- MFM Data Pulses	272		
	B	Write Voltage Sense Reference	273		
	C	Write Data Voltage Translator Output	272		
	D	Write Data Voltage Translator Output	272		
	E *	- Write Data	272		
	F *	- AC Write Fault	273		
	G *	+ Write Protect Clamp	272		
	H *	Write Current	272		
	J	Write Current Fault Reference	272		
	K	- Writer Turn Off Fault	273		
	L *	- Write Current Fault	272		
	M *	- Turn On Fault Inhibit Delay	273		
	N *	- Turn Off Fault Inhibit Delay	273		
	P	+ Write Gate	272		
	Q	Write Current D/A Output	272		
	R *	Write Voltage Regulator Output	271		
	A1A03/ASHV	- 5V	- 5 Volt (Unregulated)	332	
		+ 5V	+ 5 Volt (Unregulated)	333	

*Test point on edge of card.

other conditions are satisfied the drive starts. The following is the definition of the power on condition. Power off is the reverse of these conditions:

- AC POWER circuit breaker set to ON.
- POWER SUPPLY circuit breaker set to ON.
- START switch pressed such that it is lighted.

It should be noted that for operations such as changing packs, it is not necessary to turn off the circuit breakers. It is only necessary to stop the drive motor by pressing the START switch (indicator not lighted).

When it is necessary to turn off power for one particular drive in a daisy chain string, it is recommended that the entire string be powered off (at least by pressing the START switch). This is necessary in order to prevent error conditions.

ONLINE/OFFLINE

The drive may be set offline (with respect to the system) as necessary to accomplish maintenance procedures. If it is required that the interface cables be disconnected for any reason refer to the paragraph on Disconnecting I/O Cables. While it is not necessary to remove power from the drive in order to set it offline, it is necessary to remove power in order to connect an FTU or similar test equipment (refer to paragraph on Power On/Power Off). Whenever the drive is taken offline for any reason, inform the system operator beforehand. The following two procedures (single and dual channel) describe setting the drive offline. Setting the drive online is simply the opposite condition.

Single Channel

1. Set Local/Remote switch A10S1 to LOCAL.
2. Set Maintenance Unit Disable switch A04S2 to DISABLE.

Dual Channel

1. Set Local/Remote switch A10S1 to LOCAL.
2. Set Channel I Maintenance Unit Disable switch B05S1 to DI.
3. Set Channel II Maintenance Unit Disable switch B05S2 to DII.

DISCONNECTING I/O CABLES

There are two I/O cable configurations: (1) star, (2) daisy chain. Refer to the Interconnect Cables and Terminators paragraph in Section 1 for further information. If the system uses a star cable configuration, it may or may not need to have power removed prior to disconnecting the I/O cables. Refer to system manual for details. If the system uses the daisy chain cable configuration, it must have power removed before the I/O cables are disconnected. The following procedure defines disconnecting I/O cables. Reconnecting the I/O is performed in the reverse order.

NOTE

Inform system operator that drive(s) are being taken offline.

1. Remove power from drive (from all drives if in a daisy chain string).
2. Referring to figure 3-22, remove I/O clamp securing I/O cables.
3. Remove A cables from connectors J3 and J4. Remove B cable from connector J2.
4. If system operation is required during time drive is removed from daisy chain, patch I/O cables around drive under test.
5. Perform required maintenance on drive.

MANUAL CARRIAGE POSITIONING

Certain tests require manual positioning of the carriage and coil assembly. This procedure should only be performed as required by specific tests later in this manual, or as a trouble shooting procedure when the drive does not respond under normal logic control. It should be noted that improper carriage positioning causes servo fault conditions. Typical examples of improper carriage positioning are such things as: loading heads too slowly, hitting forward stop with carriage, or positioning carriage in loading zone. If a servo fault does occur, unload heads, clear the fault, and repeat the operation being performed.

1. Press START switch to stop drive motor and unload heads. Set POWER SUPPLY circuit breaker to OFF.
2. Disconnect yellow voice coil leadwire from faston on edge of power amplifier assembly.

3. Set POWER SUPPLY circuit breaker to ON and press START switch to start drive motor.
4. Remove magnet cover by snapping it out of place.

CAUTION

Wait 30 seconds for drive motor to come up to speed then load heads. Avoid having heads in partially loaded condition.

5. Carefully grasp voice coil and load heads. Use care not to apply a downward force. Move carriage at approximately same speed it moves under logic control
6. Position carriage as required to accomplish test being performed.
7. When tests are completed, manually unload heads to fully retracted position.
8. Press START switch to stop drive motor and set POWER SUPPLY circuit breaker to OFF.

WARNING

Be certain fingers are clear of positioner before connecting voice coil leadwire.

9. Reconnect yellow leadwire to faston on power amplifier assembly.

ACCESSING DRIVE FOR MAINTENANCE

GENERAL

The material in this section deals with gaining access to the drive electronics assembly to perform routine maintenance procedures. Figure 2-3 shows all of the functional electronics in the drive and indicates the physical location codes assigned to each. Alongside some of the location codes there is another identifier in parenthesis. This indicates the mating connectors identifier.

Table 2-4 is an alpha-numeric listing of all the physical location codes. The table also provides the title for each entry, and cross references to the parts data illustration and the sheet in the logic diagram set.

The number listed in the parts column of the table is the figure number which shows the listed item. In some cases there is a third part to the number (3-30-3), this third part (-3) indicates the sheet number of a multi-sheet illustration.

The number in the diagrams column of the table is the cross reference number of the diagram sheet which shows the listed item. In some cases an "X" appears as the third digit of the cross reference number. This indicates that the listed item is scattered over a number of sheets within the specified cross reference set (see introduction to logic diagrams for explanation of cross reference numbering system).

The procedures which follow in this section deal with opening and closing the various parts of the drive and cabinet. Many operations, such as opening and closing doors, are obvious and require no explanation. Other operations, such as sliding out the rail-mounted drive, only require the location of parts. Determine these things by looking at the appropriate illustration in the Parts data section. Should it be necessary to remove any of the components of the drive, refer to Section 2D, Repair and Replacement for the appropriate procedure.

The following procedures are included to explain details which are not obvious in themselves or by looking at the associated illustrations. Procedures contained throughout this manual assume that the reader is familiar with the information presented here.

PACK ACCESS COVER OPENING AND CLOSING

The pack access cover should only be opened to change packs or perform a maintenance procedure. Do not allow the cover to stand open more than necessary. The open cover allows dust to enter the pack area, and the dust is potentially damaging to the disk pack and heads. Never open the pack access cover while the disks are turning.

Some drives have a pack cover interlock feature installed. On these machines the pack access cover can only be opened when the ac and dc circuit breakers are set to ON and the disks are not turning. If power is applied to the machine and the READY light on the control panel is lighted or blinking, the pack access cover cannot be opened.

CASE ASSEMBLY OPENING AND CLOSING

Although there are several types of case assemblies, for the purpose of opening and closing procedures, there are three types.

1. acoustic top case
2. pedestal case
3. normal case

The acoustic top case can have one of two methods of latching:

- a. two 1/4-turn fasteners
- b. a slide-bolt latch

The pedestal case is latched with two top cover release catches. These catches may or may not be secured with socket head screws.

The normal case uses one method of latching (a pivot-type release latch), but there are two different configurations for using these latches:

- a. using the same kind of pivot release latch at each rear corner of the case
- b. using a different kind of pivot release latch at each rear corner of the case

Acoustic Top Case Opening



WARNING

The support rod will only hold the weight of the top cover if it is locked in the stop groove. An improperly secured rod will allow the top cover to fall and result in personal injury.

1. Open rear door and look inside drive to determine how case is secured.
2. Release top case as follows:
 - a. If case is secured by 1/4-turn fasteners, use a screwdriver to release the two 1/4-turn fasteners. Then lift up on rear of case.
 - b. If case is secured by a slide-bolt latch, use a 6 mm hex wrench to actuate the latch while lifting upward on rear of case.




Figure 2-3. Physical Location Codes

TABLE 2-4. PHYSICAL LOCATION CODES

Physical Location Code		Title	Parts	Diagrams
A1		Base Assembly (AC Power System)	3-32 3-33	302
A1A01	*	Plus and Minus 42V Supply and Emergency Retract	3-35	31X
A1A02	*	Plus and Minus 20V, Plus and Minus 12V Supplies	3-36	32X
A1A03	*	Plus and Minus 5V Supply	3-37	33X
A1BM1		Blower Motor	3-32-2 3-33-2	302
A1C1		Servo Capacitor (+)	3-32-2 3-33-2	312
A1C2		Servo Capacitor (-)	3-32-2 3-33-2	312
A1C3		Emergency Retract Capacitor	3-32-2 3-33-2	312
A1C5		Blower Motor Start Capacitor	3-32-2 3-33-2	302
A1C8		Transformer Tuning Capacitor	3-32-2 3-33-2	302
A1CB1		AC Power Circuit Breaker	3-32-3 3-33-3	302
A1CB2		Power Supply Circuit Breaker	3-32-3 3-33-3	302
A1FL1		Line Filter	3-32-3 3-33-3	302
Table Continued on Next Page				

TABLE 2-4. PHYSICAL LOCATION CODES (Contd)

Physical Location Code	Title	Parts	Diagrams
AlK1	Run Triac	3-32-1 3-33-1	302
AlK2	Emergency Retract Relay	3-34	312
AlM1	Elapsed Time Meter	3-32-3 3-33-3	302
AlS4	Deck Interlock Switch	3-32-1 3-33-1	302
AlT1	AC Power Transformer	3-32-1 3-33-1	302
AlTB1	Terminal Board	3-32-1 3-33-1	302
AlTB2	Terminal Block (50 Hz S/C 31 & Abv) (60 Hz s/C 34 & Abv)	3-32-3 3-33-3	302
AlJ1A **	Power Supply Connector	3-34	31X
AlJ1B **	Power Supply Connector	3-34	32X
AlJ100 **	Power Supply Connector	3-34	33X
AlJ400	Fan Connector (Acoustic Top Mount Only)	3-18 3-19	302
AlP1	AC Power Connector	3-32-3 3-33-3	302
A2XXX	Logic Chassis - Logic chassis and associated cards are shown on figure 3-21, sheet 1. Part number information for each card is presented in Spare Parts List in section 3. Logic diagrams for each card are found in Hardware Maintenance, Volume II, see preface for publication number.		
Table Continued on Next Page			

TABLE 2-4. PHYSICAL LOCATION CODES (Contd)

Physical Location Code	Title	Parts	Diagrams
A3	Deck Assembly	3-25	- -
A3A01	Control Panel	3-23	25XX
A3A02	Head Select and Read Amplifier	3-25-5	26X
A3A03	Writer	3-25-5	27X
A3A04	Power amplifier	3-25-1	28X
A3A05	Track Servo Preamplifier	3-25-1	29X
A3C6	Drive Motor Capacitor	3-25-6	302
A3DM1	Drive Motor	3-25-6	302
A3HB1	Hysteresis Brake	3-25-6	302
A3K5	Start Triac	3-25-6	302
A3L1	Speed Transducer	3-25-4	103
A3L2	Velocity Transducer	3-29	072
A3L3	Pack Cover Solenoid (optional)	3-25-2	102
A3S2	Heads Loaded Switch	3-27	302
A3S3	Pack Cover Switch	3-25-1	252
A3VC1	Voice Coil	3-28	312
NOTES	<p>* 3 Card Power Supply uses all three physical location codes separately; 2 Card Power Supply combines all three into one location code A1A01</p> <p>** 3 Card Power Supply connectors are separate from cards. 2 Card Power Supply connectors are located on card.</p>		

3. Continue to lift case upward until support rod reaches its end of travel.
4. Then lower case until support rod bottoms securely in stop groove of support rod slide.

Acoustic Top Case Closing

1. Push case assembly forward until it reaches its end of travel.
2. Lift up on support rod.
3. Lower case while continuing to lift up on support rod just long enough for it to clear stop groove in guide; then continue to lower case to its closed position.
4. Secure case as required by:
 - a. Using a screwdriver to turn the two 1/4-turn fasteners to their locked positions, or
 - b. Confirming that the slide-bolt is fully extended below the latch catch.

Pedestal Case Opening

1. Look at the rear of case assembly to determine how case is secured. If the latches are secured by socket head screws, loosen them.

CAUTION

Lift up case only about one inch during next step.

2. Release case as follows:
 - a. Depress the release catches and lift up case slightly, or
 - b. Depress the socket head screws and lift up case slightly.
3. After case has been released and raised about an inch, swing hinged rear panel of case outward to clear the rear of the actuator assembly.

4. Pivot case upward and toward the front until it rests on case support arms.

Pedestal Case Closing

CAUTION

To avoid damage to latches and actuator assembly, carefully follow instructions pertaining to the case rear panel as the case is lowered.

1. Pivot case toward rear and downward, and, as it is being lowered, swing hinged rear panel of case outwards so it clears actuator. Do not completely close case.
2. When case is about one inch from touching frame, swing hinged rear panel inward until it reaches its end of travel.
3. While holding in hinged rear panel, lower case assembly to its fully closed position.
4. Ensure that the latches catch. If socket head screws are used, tighten them.

Normal Case Opening

1. Pull out drawer-mounted drive to its fully extended position.

CAUTION

Lift up case only about one inch-during the next step.

2. Release case as follows:
 - a. If case has similar latch tabs protruding through the rear corners of the case, push down on both tabs while lifting up on rear of case.
 - b. If case has a different kind of latch in each corner:
 - (1) Push down on latch tab protruding through a slot in the left side (rear) of the case.
 - (2) Insert a 6 mm hex wrench into the socket inset in the right side (rear) of the case and turn wrench to release the latch.
3. After case has been released and raised about an inch, swing hinged rear panel of case outward to clear the rear of the actuator assembly.

4. Pivot case upward and toward the front until it rests on case support arms.

Normal Case Closing

CAUTION

To avoid damage to latches and actuator assembly, carefully follow instructions pertaining to the position of the case rear panel as the case is lowered.

1. Pivot case toward rear and downward, and, as it is being lowered, swing hinged rear panel outward so it clears actuator. Do not completely close case.
2. When case is about one inch from touching frame, swing hinged rear panel inward until it reaches its end of travel.
3. While holding in hinged panel, lower case assembly to its fully closed position.
4. Ensure that latches catch.

RAISING AND LOWERING DECK



WARNING

Due to weight of deck, use caution to prevent personal injury.

There are two positions the deck can be in: (1) normal operating (2) maintenance. In the normal operating position the deck is secured to the shock mounts on the base by two holddown screws inside the shroud and next to the spindle. While in this position, the rear deck holddown screw (center of three screws at rear of deck casting) and associated spacer are stored in the keeper hole at the rear of the deck casting. The following procedure assumes that power is removed from the drive and that the disk pack is removed from the spindle. This procedure describes raising the deck to the maintenance position.

NOTE

On newer 60 Hz acoustical drawer or rack mount units using round I/O cables, remove I/O bracket from its mounting prior to raising deck. This will allow strain relief when deck is raised.

Raise the deck as follows:

1. Remove (and set aside for future use) deck holddown screws from inside shroud (refer to figure 2-4).
2. Remove rear deck holddown screw and spacer from keeper hole on back of deck casting.
3. Insert spacer between deck and base hinge (refer to inset on figure 2-4). Insert rear deck holddown screw through deck and spacer and secure to base hinge.
4. Perform step 4a for units in S/C 16 and below, perform step 4b for units in S/C 17-19, and perform step 4c for units S/C 20 and above. (Optional FCO 55172 can be installed to bring units built before S/C 20 up to the latest configuration).
 - a. Lift up deck from front of drive and install deck support bracket. Bracket is inserted into shock mounts on base and into holddown screw holes in bottom of deck casting.
 - b. Lift up deck from front of drive until deck support bracket is completely extended. Carefully lower deck until support bracket slides into locking position (hinge in center of bracket should point slightly towards rear of drive).
 - c. Lift deck from front of drive until deck support bracket is completely extended. Carefully lower deck until support bracket slides into locking position (hinge in center of bracket should point slightly towards rear of drive). Remove thumb screw from storage hole and secure in the locking hole located on the face of the deck support bracket. The thumb screw must be in the locking hole when deck is in raised position.

Lower the deck as follows:

1. Perform step 1a for units in S/C 16 and below, perform step 1b for units in S/C 17 through 19 and perform step 1c for units in S/C 20 and above.




Figure 2-4. Deck Maintenance Position (Sheet 1 of 2)
S/C 16 & Below




Figure 2-4. Deck Maintenance Position (Sheet 2)
S/C 17 & Above

- a. Lift deck and remove deck support bracket.
 - b. Lift deck until the deck support bracket disengages from locked position and push back of bracket slightly forward, then lower deck slowly.
 - c. Remove thumb screw from locking hole and secure in storage hole. Lift deck until the deck support bracket disengages from locked position and push back of bracket slightly forward, then lower deck slowly.
2. Inspect underside of deck and base assembly for any particles of dust or foreign material. If material is present, vacuum area and with a dampened cloth, remove any residue.
 3. Lower deck to normal operating position (and secure I/O cable bracket if removed).
 4. Secure deck to front shock mounts using two deck front holddown screws.
 5. Remove rear deck holddown screw and spacer. Store in keeper hole.

RAISING AND LOWERING LOGIC CHASSIS - S/C 16 & BELOW

There are two positions for the logic chassis; (1) normal operating (2) maintenance. In the normal operating position the logic chassis sits alongside the actuator and the 1/4-turn fastener at the rear is secured to the deck casting. The following procedure describes raising the logic chassis to the maintenance position. It also describes removal of the logic chassis protective panel. Returning the logic chassis to the normal operating position is performed in the reverse order. This procedure assumes that power is removed from the drive.

1. Release 1/4-turn fastener securing logic chassis to rear of deck casting. Ensure that ring on 1/4-turn fastener does not interfere with logic chassis bracket when chassis is raised.
2. Slide logic chassis toward rear of drive to disengage chassis ears from logic chassis support rod.
3. Lift up on chassis until flat spring pops into place.
4. Pivot chassis 90 degrees and slide it over top of magnet assembly.
5. Remove attaching hardware securing logic chassis protective panel.

CAUTION

Use care not to damage cables or connectors when removing logic chassis cover.

6. Carefully slide logic chassis protective panel toward front of drive enough to disengage rear of panel from slot. Carefully slide panel along cables far enough to access back panel.

RAISING & LOWERING LOGIC CHASSIS - S/C 17 & ABOVE

There are two positions for the logic chassis: (1) normal operation (2) maintenance. In the normal operating position the logic chassis sits alongside the actuator and the 1/4-turn fastener at the rear is secured to the deck casting. The following procedure describes raising the logic chassis to the maintenance position. Returning the logic chassis to the normal operating position is performed in the reverse order. This procedure assumes that power is removed from the drive.

1. Release 1/4-turn fastener securing logic chassis to rear of deck casting. Ensure that ring on 1/4-turn fastener does not interfere with logic chassis bracket when chassis is raised.
2. Loosen the two front clamping screws securing the front of the logic chassis.
3. Lift the rear of the logic chassis enough to clear the 1/4-turn fastener hole and slide the chassis back until it stops. This distance is approximately 19 mm (3/4 in).
4. Raise the logic chassis from the slide, up and over the voice coil until it comes to rest on the coil.

SECTION 2B

PREVENTIVE MAINTENANCE

GENERAL

This section provides all information necessary to perform the required preventive maintenance on a drive in the field. Proper performance of the drive is dependent on adequate and timely execution of preventive maintenance routines. Many potential drive problems can be caught and corrected by strict adherence to the preventive maintenance schedule.

Procedures in this section assume the reader is familiar with the information provided in Section 2A General Maintenance Information. Refer to section 2A for information on safety precautions, maintenance tools and materials, test point locations, and accessing information (the opening and closing procedures for the various components of the drive).

Table 2-5 provides the preventive maintenance index. The index consists of six levels of maintenance based on a calendar period or hours of operation, whichever comes first.

The index assumes that the drives are installed in a computer room environment, and as such has scheduled maintenance consistent with that assumption. If the installation site is something other than a computer room environment, the maintenance schedule needs to be adjusted accordingly. The main factor in setting maintenance intervals is the cleanliness of the installation site. Under no circumstances should the maintenance intervals exceed those specified in table 2-5.

The following are the definitions of the six preventive maintenance levels:

- Level 1 - Weekly or 150 hours
- Level 2 - Bimonthly or 1000 hours
- Level 3 - Quarterly or 1500 hours
- Level 4 - Semiannually or 3000 hours

TABLE 2-5. PREVENTIVE MAINTENANCE INDEX

Level	Est Time (Minutes)	Procedure
4	10	General Cleaning
4	5	Clean Primary Filter
6	20	Replace Absolute Filter
4	1	Clean Shroud and Spindle
4	2	Clean and Lubricate Lockshaft
4	5	Inspect and Clean Rails and Bearings
4	2	Check Power Supply Output
5	120	Check Head Alignment

Level 5 - Annually or 6000 hours

Level 6 - Biennially or 9000 hours

PREVENTIVE MAINTENANCE PROCEDURES

GENERAL

Perform preventive maintenance in accordance with the time or calendar schedule as specified in table 2-5. The following procedures are contained in this section in the order specified.

- General Cleaning
- Clean Primary Filter
- Replace Absolute Filter
- Clean Shroud and Spindle
- Clean and Lubricate Lockshaft

- Inspect and Clean Rails and Bearings
- Check Power Supply Output
- Check Head Alignment

GENERAL CLEANING

Since the drive is a precision machine and built to close tolerances, good housekeeping is essential to proper operation. A thorough cleaning on a regular basis prevents many problems. This procedure assumes the power is removed from the drive.

1. Carefully vacuum interior of cabinet and case, paying particular attention to flat surfaces where dust accumulates.
2. With deck in normal operating position, vacuum exterior surfaces of electronic assembly. Use a soft cloth dampened in a mild detergent solution to remove any greasy residue.
3. Raise deck to maintenance position and vacuum underside of deck and base assembly. Again, use a dampened cloth to remove any residue.
4. Inspect cables and connections for any sign of damage and correct as necessary.
5. Inspect drive belt for signs of fraying or cracking. Replace belt as necessary.
6. Return deck to normal operating position and close case and door assemblies.
7. Using a soft cloth dampened in a mild detergent solution, carefully wipe all cabinet surfaces. Use care not to allow moisture to run into drive.

CLEAN PRIMARY FILTER

The primary filter must be kept clean in order to allow sufficient passage of air to keep the drive cool. If the filter cannot be cleaned by the following procedure, it must be

replaced. This procedure assumes that power has been removed from the drive.

1. Remove primary filter from drive:
 - For non-acoustic drives see figure 3-7, 3-10, 3-13, or figure 3-11, depending on drives mounting configuration.
 - For acoustic drives see figure 3-3, sheet 3
2. Clean filter by agitating in mild detergent solution.
3. Rinse thoroughly in clean running water. Shake vigorously to remove excess water and allow to dry.
4. Replace filter in drive.

REPLACE ABSOLUTE FILTER

An adequate supply of clean air to the pack area is essential to proper operation of the drive. The absolute filter traps all dirt particles too small to be stopped by the primary filter. Eventually the filter becomes too clogged to yield a sufficient airflow, and it must be replaced. Its useful life depends on the drives operating environment.

The user has two options: (1) replace the absolute filter at fixed intervals dependent on site environment or (2) obtain a pressure gauge (see table 2-1) and replace the absolute filter when it fails the testing procedure given below.

With the first option, replacement of the absolute filter is required once every two years when the drive is operated in a computer room environment. If the drive is operated in something other than a computer room environment, absolute filter replacement is required more often. In a non-computer room environment, it is suggested that the absolute filter be replaced every year or whenever there is doubt about the ability of the filter to pass air into the shroud area.

With the second option, maintenance personnel can periodically check the airflow through the absolute filter to determine the proper time for filter replacement. Regardless of a planned testing schedule, testing should be performed whenever there is doubt about the ability of the filter to pass air into the shroud area.

The following describes testing and replacement of the absolute filter.

Testing Absolute Filter

1. Remove power from the drive.
2. Gain access to absolute filter and determine whether filter has a hole and plastic plug for test purposes. If not,
 - a. Remove filter from drive.
 - b. Drill a 6.35 mm 0.25 in hole in the location shown in Figure 2-5.
 - c. Thoroughly clean shavings from filter before reinstalling it in drive.




Figure 2-5. Drilling of Absolute Filter

3. Remove plastic plug and insert tubing attached to the differential pressure gauge (refer to list of Maintenance Tools and Materials).
4. Apply power to drive and load heads.
5. If pressure is 0.5 inch-water or less, filter should be replaced. If pressure is above 0.5 inch-water, filter need not be replaced at this time.
6. Remove tubing and insert plug. (Spare plastic plugs are included in the gauge test kit.) The plastic plug must be inserted at all times except when making pressure measurements.
7. Return drive to normal operation.

REPLACING ABSOLUTE FILTER

1. Remove power from drive and raise deck to maintenance position.
2. Remove screw and lockwasher securing filter retaining bracket (see Figure 3-32 Sheet 1).
3. Remove bracket by pivoting it toward front of drive and disengaging flange on bracket from slot in base pan.
4. Remove absolute filter by pulling it toward front of drive. It may be necessary to jiggle filter to disengage it from blower motor outlet.
5. Wipe base pan clean in area under absolute filter and around blower motor outlet.
6. Install new filter by sliding it in from front of drive and engaging it in blower motor outlet.
7. Install filter retaining bracket and secure with screw and lockwasher.
8. Return deck to normal operating position.
9. Set circuit breakers to ON and allow blowers to purge unit for at least five minutes.

NOTE

If a pressure gauge is not available, skip step 10 and return drive to normal operation.

10. Perform testing absolute filter procedure.

CLEAN SHROUD AND SPINDLE

In order to prevent head-to-disk contact, it is imperative that the pack area be kept clean. The following procedure assumes that power is removed from the drive and that the disk pack is removed from the spindle.

1. Carefully vacuum entire pack area.
2. Using a wad of adhesive type tape, remove any particles not removed during vacuuming.
3. Using a piece of lint free gauze dampened in head cleaning solution, wipe all surfaces of the shroud. Remove all smudges and dirt. Carefully clean all surfaces of spindle.
4. Close pack access cover immediately after cleaning to ensure that dust does not enter pack area.

CLEAN AND LUBRICATE LOCKSHAFT

In order to prevent damage to the lockshaft and the disk pack it is necessary to keep the threads in the top of the lockshaft clean. This procedure assumes that power is removed from the drive and that the disk pack is removed from the spindle.

1. Using a stiff brush or a sharp pointed instrument, remove old lubricant paste from threads in lockshaft.
2. Using a piece of lint free gauze dampened in head cleaning solution, wipe all surfaces of spindle to remove traces of lubricant paste.
3. Apply a thin coat of new lubricant paste to threads of lockshaft.

CAUTION

Inspecting and cleaning the rails and bearings is a delicate procedure that should be performed only by qualified service personnel.

INSPECT AND CLEAN RAILS AND BEARINGS

In order to ensure that the carriage is able to move freely along the rails, it is essential that the rail and bearing surfaces be kept clean. Any obstruction to free movement of the carriage may cause cylinder address errors. This procedure as-

sumes that power is removed from the drive and that the disk pack is removed from the spindle.

1. Remove magnet cover (see figure 3-29) by grasping edge of cover and snapping it out of place.
2. Grasp coil through opening in top of magnet assembly. Carefully and slowly push coil forward to extend heads.
3. Once head arms have cleared cams, gently slide carriage and coil assembly back and forth along full length of rails. While moving coil, be aware of any possible irregularity (bumps or jerks) in movement. A sudden irregularity indicates dirt on rails or bearings. Do not confuse pressure of flex leads and head leads with a sudden irregularity in motion. Pressure from leads is a smooth change.
4. If a sudden irregularity in motion was noted in previous step proceed to next step. If no sudden irregularity in motion was noted, cleaning is not required. Terminate procedure by returning carriage to heads unloaded position (fully retracted) and replace magnet cover.

CAUTION

If, when performing step 5, it is necessary to use head cleaning solution, use extreme caution not to get any solution into the bearings.

5. Using a clean, dry cotton swab or Q tip, clean all rail and bearing surfaces. In some cases, it may be necessary to dampen (not soak) the swab or Q tip with head cleaning solution. Access front portion of lower rail from interior of pack area. Access rear position of lower rail and all of top rail from sides of actuator. Raise logic chassis as required to gain access from left side of actuator. Move carriage back and forth while cleaning in order to ensure all surfaces are reached.
6. When rail and bearing cleaning is completed, repeat step 3 to ensure that carriage moves freely without sudden irregularities in its motion. If carriage now moves smoothly throughout its travel, proceed to step 7. If sudden irregularities persist, visually inspect rails and bearings using a strong light. Look for deterioration of rail or bearing surfaces. Surface deterioration requires replacement of defective parts. Since neither carriage nor rails are field replaceable, contact factory maintenance representative.
7. Return carriage to heads unloaded position (fully retracted) and replace magnet cover.

CHECK POWER SUPPLY OUTPUT.

Perform the Plus and Minus 5 Volt Adjustment procedure contained in Section 2C Tests and Adjustments.

CHECK HEAD ALIGNMENT

Perform the Head Alignment procedure contained in Section 2C, Tests and Adjustments.

SECTION 2C

TEST AND ADJUSTMENTS

GENERAL

This section provides information on all the electrical test and adjustments which can be performed in the field. The adjustments contained here are limited to those which can be performed at the drive level. These tests should only be performed as required elsewhere in this manual, or when there is suspicion that the drive is not functioning properly. A drive that passes all the requirements in this section may be considered operationally acceptable. If any of the adjustments, contained in this section, cannot be completed satisfactorily, terminate the procedure and perform trouble analysis.

Mechanical adjustments are contained in the Repair and Replacement section. A person performing these tests and adjustments should already be familiar with the information contained in the General Maintenance Information section. Refer to that section for information on safety precautions, maintenance tools and materials, test point locations, and information on opening and closing of the various components of the drive.

These procedures assume that an FTU is connected to the drive (or that suitable software is available), that a scratch pack is installed (or CE pack where noted), and that the drive is powered on. All the following tests are written, providing first a check procedure, and then the adjustment. If the drive meets the criteria of the check, there is no need of the adjustment.

The following procedures are contained in this section, in the order specified:

- Plus and Minus 5 Volt Adjustment
- Head Arm Alignment
- Velocity Gain Adjustment (40 MB)
- Velocity Gain Adjustment (80 MB)
- Speed Transducer Electrical Check

PLUS AND MINUS 5 VOLT ADJUSTMENT (3 CARD POWER SUPPLY)

This procedure checks the output of the plus and minus 5-volt power supplies while the drive is doing repeat seeks. Power supply outputs are checked at the logic chassis backpanel. Therefore, the supplies are being checked in a manner to account for both line loss and loading.

This procedure assumes that the FTU is connected to the drive, a scratch pack is installed, and power is applied.

CAUTION

Drive should not be operated for extended period with logic chassis in maintenance position. Loss of cooling air (when logic chassis is raised) could cause drive to overheat.

1. Raise logic chassis to maintenance position.
2. Connect digital volt/ohmmeter between GND AND +5 V fastons on logic chassis backpanel.
3. Command drive to do repeat seeks between cylinders 0 and 32.
4. Plus 5-volt output should be from +5.05 to +5.15 volts. If not, adjust +5 V potentiometer on card AlA03 (see figure 2-11) until output is within specification.
5. Move volt/ohmmeter leads to -5 V faston.
6. Minus 5-volt output should be from -5.05 to -5.15 volts. If not, adjust -5 V potentiometer on card AlA03 (see figure 2-11) until output is within specification.
7. If any adjustment was necessary in preceeding steps, recheck both outputs.
8. When both power supply outputs are within specification, restore drive to normal operation.




Figure 2-11. Power Supply Adjustment Locations
(3 Card Power Supply)

PLUS AND MINUS 5 VOLT ADJUSTMENT (2 CARD POWER SUPPLY)

This procedure checks the output of the plus and minus 5-volt power supplies while the drive is doing repeat seeks. Power supply outputs are checked at the logic chassis backpanel. Therefore, the supplies are being checked in a manner to account for both line loss and loading.

This procedure assumes that the FTU is connected to the drive, a scratch pack is installed, and power is applied.

CAUTION

Drive should not be operated for extended period with logic chassis in maintenance position. Loss of cooling air (when logic chassis is raised) could cause drive to overheat.

1. Raise logic chassis to maintenance position.

2. Connect digital volt/ohmmeter between GND and +5 V fastons on logic chassis backpanel.
3. Command drive to do repeat seeks between cylinders 0 and 32.
4. Plus 5-volt output should be from +5.05 to +5.15 volts. If not, adjust +5 V potentiometer on card ALA01 (see figure 2-11) until output is within specification.
5. Move volt/ohmmeter leads to -5 V faston.
6. Minus 5-volt output should be from -5.05 to -5.15 volts. If not, adjust -5 V potentiometer on card ALA01 (see figure 2-11) until output is within specification.
7. If any adjustment was necessary in preceding steps, recheck both outputs.
8. When both power supply outputs are within specification, restore drive to normal operation.




Figure 2-11. Power Supply Adjustment Locations
(2 Card Power Supply)

HEAD ALIGNMENT

GENERAL

Alignment of the heads is checked under the following conditions:

- During initial installation of the drive.
- After replacing one or more head arm assemblies.
- When misalignment of one or more heads is suspected. (For example, inability to read a pack written on another drive).


If it is determined that a head is misaligned, the head arm is adjusted to bring the alignment of the head within specifications. Figure 2-12 is a flowchart summarizing the basic functions of the head alignment check and adjustment procedure.

Head alignment is performed by using a Field Test Unit (FTU) or by using the controller, microprogram diagnostics, head alignment card and meter. This procedure applies only to the method using an FTU. Refer to the FTU maintenance manual for switch settings and functions called for in this procedure.

When performing head alignment, give special consideration to the following:

Thermal Stabilization - In order to ensure accuracy during head alignment, it is important that the drive, CE pack, and FTU be at their normal operating temperature. This requires that all three be connected and allowed to operate (pack turning and heads loaded to cylinder zero) for a minimum of 60 minutes. If head alignment is being performed on more than one drive, and provided that the pack was taken immediately from a previous drive, and provided that the drive under test has been operating with heads loaded for a minimum of 60 minutes preceding tests; then the CE pack only requires a 14-minute stabilization time.

Alignment Tool - Use only the head alignment tool specified in the maintenance tools and materials table. Use of a different tool may cause damage to head arm or carriage. Always inspect the adjustment end of tool prior to use. Tool must be free of nicks and scratches and must have a polished surface where it enters the carriage alignment hole. If any aluminum deposits are present, polish tool surface with crocus cloth. Any other



1 ACCEPTABLE RANGE DEPENDS ON CE USED:
 • IF PACK IS SAME ONE USED FOR LAST ALIGNMENT, RANGE IS $0 \pm 150 \text{ mV}$
 • IF PACK IS NOT SAME ONE USED FOR LAST ALIGNMENT, RANGE IS $0 \pm 225 \text{ mV}$

907 E

Figure 2-12. Basic Head Alignment Check & Adjustment Procedure

polishing medium will damage the tool. Do not use a defective tool; repair or replace tool if damage exists. When using tool, position it so that pin in end of tool engages alignment slot in head arm. The tool should slip easily through the alignment hole in the carriage and into the alignment slot in the head arm. If anything more than a small amount of force is required to adjust the head, the tool is probably binding in the hole of the carriage. Ensure that alignment tool is kept perpendicular to hole in carriage at all times.

Carriage Locking - During the alignment procedure (when the heads are over the alignment track) the carriage locking pin and ring assembly must be installed in the ALIGN TRACK LOCK hole in the rail bracket assembly. This locks the carriage in one head alignment position. Failure to install the pin and ring assembly would allow the carriage to retract if any emergency retract signal were generated. Since your hands are in the actuator during the head alignment procedure, the retract could be dangerous.

CAUTION

Should an emergency retract condition be generated when the locking pin is in the ALIGN TRACK LOCK hole, the following results may occur:

- Blown fuses,
- Tripped dc circuit breaker
- Blown power amplifier transistors, and
- Unretracted heads on a stationary CE pack.

Carefully observe the instructions regarding the installation and removal of the carriage locking pin and ring assembly.

INITIAL SETUP

1. Install CE disk pack and perform thermal stabilization.
2. Set AC POWER and POWER SUPPLY circuit breakers to OFF.
3. Raise case assembly to maintenance position.
4. Install head alignment card into location A2A02.
5. Raise logic chassis.
6. Remove connector support bracket (see figure 2-32).

7. Connect FTU to drive. Refer to FTU maintenance manual for installation instructions.
8. Install terminator on I/O connector. If unit is dual channel, install terminator on I/O connector of channel being used by FTU.
9. Connect meter cables between head alignment card and FTU null meter. (Refer to figure 2-13).
10. Connect oscilloscope to test point Z (ground) and test point Y (dibits) on head alignment card.
11. Install head alignment cable between A2A02 pins 8-11 A and B and A3A02 J104.
12. Set AC POWER and POWER SUPPLY circuit breakers to ON.
13. Press START switch to start drive motor and load heads.


CAUTION

The CE disk pack has odd-even dibits on tracks 000 through 330 only. Do not attempt to access beyond cylinder 330.

SERVO HEAD OFFSET CHECK

1. Set head alignment card S/RW switch to S and X.1X1 switch to X.1.
2. Command continuous seeks between cylinders 240 and 245 for a minimum of 30 seconds.
3. Command direct seek either to cylinder 000 (for 40 MB drive) or 004 (for 80 MB drive).
4. Observe dibit pattern on oscilloscope. It should be similar to that shown on figure 2-14.
5. Toggle P/N switch to both P and N positions and record null meter readings. If both P and N readings are less than 50 mV, the X.1X1 switch can be set to X1 position for more accurate readings.

Figure 2-13. Head Alignment Setup



- 1 METER IS PART OF FTU OR HEAD ALIGNMENT KIT. METER READINGS TO LEFT OF ZERO ARE NEGATIVE AND READINGS TO RIGHT OF ZERO ARE POSITIVE.
- 2 NEWER KITS HAVE AZPV CARD
- 3 INDICATORS DO NOT APPEAR ON AZVP CARD

Figure 2-14. Head Alignment Waveform

OSCILLOSCOPE SETTINGS

LOGIC GND TO SCOPE GND

VOLTS / DIV

CH 1 - 20MV/CM

CH 2 - NOT USED

TIME / DIV

A - 1 μ S/CM

B - NOT USED

TRIGGERING


A - +INTERNAL

B - NOT USED

PROBE CONNECTIONS

CH 1 TO TPY (RD SIGNAL) ON HD ALIGNMENT CARD

CH 2 TO NOT USED



6. Calculate head offset by using the following formula:

$$(P) - (N) = \text{OFFSET}$$

Where P is meter reading with P/N switch in P position and N is meter reading with switch in N position. Meter readings to right of zero are positive and meter readings to left of zero are negative.

Example: P = +20 N = +15

$$(P) - (N) = (+20) - (+15) = +5$$

Example: P = +20 N = -15

$$(P) - (N) = (+20) - (-15) = +35$$

Example: P = -20 N = +15

$$(P) - (N) = (-20) - (+15) = -35$$

7. Record offset calculated in step 6.

8. Evaluate servo head offset as follows:

- If offset ranges between +60 mV and -60 mV, it is acceptable to proceed with head alignment.
- If offset is outside ±60 mV range, it is unacceptable. In this case, trouble shoot servo system before proceeding with head alignment.

NOTE

If performing head alignment on a 40 MB drive, skip steps 9 and 10.

9. Command direct seek to cylinder 005 and repeat steps 4 through 8.

10. Add offset readings from cylinders 004 and 005. This sum should range between +75 mV and -75 mV. If it does not, troubleshoot servo system.

Example 1:

$$P_4 = -25$$

$$N_4 = -15$$

$$(P) - (N) = (-25) - (-15) = -10 \text{ mV}$$

$$P_5 = +10$$

$$N_5 = -10$$

$$(P) - (N) = (+10) - (-10) = +20 \text{ mV} \quad (-10) + (20) = +10 \text{ mV}$$

Sum is within ± 75 mV range and is therefore acceptable.

Example 2:

$$P_4 = +30$$

$$N_4 = -10$$

$$(P) - (N) = (+30) - (-10) = +40 \text{ mV}$$

$$P_5 = +15$$

$$N_5 = -30$$

$$(P) - (N) = (+15) - (-30) = +45 \text{ mV} \quad (+40) + (+45) = +85 \text{ mV}$$

Sum is outside ± 75 mV range and is therefore unacceptable. Servo system troubleshooting is required.

11. Command direct seek to cylinder 245, install carriage locking pin into alignment hole (refer to figure 2-15) and repeat steps 4 through 8.

READ/WRITE HEADS CHECK AND ADJUSTMENT

1. Set R/RW switch to RW. Observe that dibit pattern is similar to that shown on figure 2-14.
2. Calculate offset of all read/write heads by using same method given in steps 5 and 6 of Servo Head Check.
3. Remove carriage locking pin.

CAUTION

If any offset exceeds a 0 ± 300 mV range, those heads are excessively misaligned. Therefore, to avoid possible loss of data, transfer data from packs written with those heads to other storage before proceeding with alignment.

- 4 Evaluate read/write head offset as follows.

- a. When using same CE pack as used for last alignment, offsets must range between +150 mV and -150 mV. If all offsets are within this range, alignment is satisfactory so proceed to step 16.
 - b. When using a different CE pack than the one used for last alignment, offsets must range between +225mV and -225 mV. If all offsets are within this range, alignment is satisfactory so proceed to step 16.
 - c. If any offsets are outside acceptable range, as defined in steps a or b (whichever applies), these heads are misaligned. Proceed to step 5.
5. Press START switch to stop drive motor and unload heads.
 6. Remove connector support bracket (see figure 2-32).
 7. Loosen head-arm mounting screws securing heads requiring alignment and torque these screws to $0.5 \pm 0.1 \text{ N}\cdot\text{m}$ ($4 \pm 1/2 \text{ lbf}\cdot\text{in}$).
 8. Press START switch to start drive motor and load heads.
 9. Command direct seek to cylinder 245.

CAUTION

Use extreme care to avoid short circuit contact with write driver board when installing or removing head alignment tool and torque wrench.

NOTE

When performing alignment on an 80 MB drive, the force exerted during adjustment can move the heads from the alignment cylinder to an adjacent cylinder. This will result in an improper alignment. Prevent this by connecting a jumper from A2B09-11A (Seek Error) to ground. However, be sure to remove the jumper before commanding the drive to perform another seek.

10. Align heads as follows:
 - a. Select head to be aligned.

WARNING

To prevent personal injury in case of an emergency retract, install carriage locking pin in head alignment hole prior to positioning head alignment tool. Be sure to remove pin before next seek is performed.

- b. Install head alignment tool so that tool pin engages head-arm alignment slot (refer to figure 2-15).
 - c. Observe oscilloscope and adjust head to obtain balanced dibit pattern. Pattern is balanced when point A amplitude equals point B and point C equals point D (see figure 2-14).
 - d. Observe null meter and adjust head until offset ranges between +75 mV and -75 mV. Calculate offset as described in steps 5 and 6 of Servo Head Check. Occasionally, a head cannot be aligned because its adjustment slot is at its end of travel. If this occurs, check position of servo head-arm adjustment slot and, if necessary, recenter it. However, it should be noted that any slight adjustment of the servo head required realignment of all read/write heads. Torque servo head to $1.4 \pm 0.1 \text{ N}\cdot\text{m}$ ($12 \pm 1/2 \text{ lbf}\cdot\text{in}$).
 - e. Repeat steps a through d for all heads to be aligned.
11. Remove carriage locking pin and also remove jumper from A2B09-11A (if it was installed).
 12. Press START switch to stop drive motor and unload heads.
 13. Torque head-arm clamp screws of each head adjusted to $1.4 \pm 0.1 \text{ N}\cdot\text{m}$ ($12 \pm 1/2 \text{ lbf}\cdot\text{in}$). While torquing screws, use only straight arm allen wrench and keep it as perfectly aligned as possible with screws. If care is not taken during this operation, head may be pushed out of alignment.
 14. Check each head adjustment to see if torquing screws affected alignment. If any heads are outside $\pm 150 \text{ mV}$ range, readjust them as directed in steps 7 through 13.
 15. Perform the following to ensure that heads will remain aligned under normal operating conditions.
 - a. Command continuous seeks between cylinders 240 and 245 for a minimum of 30 seconds.
 - b. Unload and load heads at least twice.

- c. Command direct seek to cylinder 245.
 - d. Check alignment of each head adjusted. If any heads are outside acceptable range (as defined in step 4), repeat this procedure starting with step 10.
16. Press START switch to stop drive motor.
 17. Set AC POWER and POWER SUPPLY circuit breakers to OFF.
 18. Disconnect test setup and remove alignment card and terminator (if installed).
 19. Replace connector support bracket (see figure 2-32).
 20. Lower logic chassis to normal operating position.
 21. Lower case assembly.
 22. Remove CE pack.
 23. Restore drive to on-line operation.

VELOCITY GAIN ADJUSTMENT (40 MB)

The following procedures provide information on checking and, if necessary, adjusting the servo system velocity gain. If the procedures cannot be completed satisfactorily, terminate, and begin performing trouble analysis.

The Velocity Gain procedure will vary depending on the card type found in location A12. For units using the BLQV or LLQV, perform procedure A. For units using the MLQV (or any later generation card, NLQV for example), perform Procedure B.

Both procedures assume that the FTU is connected, and that a scratch pack is installed on the drive.

PROCEDURE A. WITH BLQV OR LLQV

1. With the drive case closed, command random seeks for 10 minutes minimum in order to thermally stabilize drive.
2. Stop random seeks and set up oscilloscope per figure 2-16. Oscilloscope ground references must be as shown.
3. Command 410 (hex 19A) cylinder continuous seeks and adjust oscilloscope trigger level to obtain waveform shown in figure 2-8.




Figure 2-15. Head Arm Alignment

4. Measure amplitude of Velocity signal (displayed on channel 2) and null-to-null time of Fine Position Analog signal (displayed on channel 1). Amplitude of Velocity signal and null-to-null time of Fine Position Analog signal must correspond as shown in table 2-6.

TABLE 2-6. 40 MB VELOCITY VOLTAGE VS NULL TIME

NOTE			
Voltage readings in column A are ± 1 volt. Null-to-null readings in column B are ± 4 μ sec.			
A (volts)	B (μ sec)	A (volts)	B (μ sec)
5.2	100	6.7	77
5.3	98	6.8	76
5.4	96	6.9	75
5.5	94	7.0	74
5.6	93	7.1	73
5.7	91	7.2	72
5.8	89	7.3	71
5.9	88	7.4	70
6.0	86	7.5	69
6.1	85	7.6	68
6.2	84	7.7	67
6.3	82	7.8	67
6.4	81	7.9	66
6.5	80	8.0	65
6.6	79		

NOTE

Velocity amplitude changes as null-to-null time of Fine Position Analog signal is adjusted. Be sure to check both measurements while performing adjustment.


5. If time versus voltage relationship, measured in previous step, was not as specified in table, perform velocity transducer gain adjustment. On card A2A07, adjust potentiometer E2R6 (see figure 2-17 until relationship between time and voltage is as specified in table 2-6.
6. When velocity transducer gain adjustment is correct, change oscilloscope setup to that shown in figure 2-18.

Figure 2-16. 40 MB Velocity Transducer Gain Waveforms


OSCILLOSCOPE SETUP

	VOLTS / DIV	TEST POINT	SIGNAL NAME
CH 1 - (USE X 10 PROBE)	0.2 V	A2A08 TPF	+ FINE POSITION ANALOG
CH 2 - (USE X 10 PROBE)	0.1 V	A2A07 TPF	+ VELOCITY
	SLOPE / SOURCE	TEST POINT	SIGNAL NAME
TRIGGER A - (USE X 10 PROBE)	+ / EXT	A2B09 14B	-T ≥ 128
TRIGGER B - (USE X PROBE)	NOT USED		
TIME / DIV: 20 μs	MODE TRIGGER: CHOP		

ADDITIONAL SETTINGS: NONE



9H30



9H31A

Figure 2-17. 40 MB Velocity Gain Adjustment Locations

7. Measure full length seek time. Time between On Cylinder Sense pulses (displayed on channel 2) should be 50 to 52 milliseconds.
8. If full length seek time is not as specified, perform coarse velocity adjustment. On card A2A07, adjust coarse velocity potentiometer B3R2 (see figure 2-17) until time between On Cylinder Sense pulses is 50 to 52 milliseconds.

NOTE

Position of oscilloscope probe connections does not change between coarse and fine velocity adjustments.

9. When coarse velocity adjustment is correct, change oscilloscope setup to that shown in figure 2-19.
10. Command random seeks.
11. Fine Position Analog signal (displayed on channel 1) should show a slight ripple just as it is nulling out. Also, there could be a slight overshoot of the forward and reverse signals. On Cylinder Sense signal should be

relatively stable. Referring to figure 2-11, note difference between Velocity Too Fast, Velocity Too Slow, and Correct Velocity.

12. If overshoot of Fine Position Analog signal and jitter of On Cylinder Sense signal are not approximately as shown in figure 2-19, (correct velocity) perform fine velocity adjustment. On card A2A07, adjust fine velocity potentiometer B3R6 (see figure 2-17 until velocity is as fast as possible without excessive overshoot or breakup of On Cylinder Sense waveform.
13. If fine velocity adjustment was required in previous step, repeat coarse velocity adjustment. Continue to perform adjustments until both coarse and fine velocity adjustments meet specifications.
14. Return drive to normal operation

PROCEDURE B. WITH MLQV OR LATER

1. With the drive case closed, command random seeks for 10 minutes minimum in order to thermally stabilize drive.
2. Stop random seeks and set up oscilloscope per figure 2-20. Oscilloscope ground references must be as shown.
3. Command 410 (HEX 19A) cylinder continuous seeks and adjust oscilloscope trigger level to obtain waveform shown in figure 2-20.
4. Measure full length seek time. Time between On Cylinder pulses should be 52 ± 2 milliseconds.
5. If full length seek time is not as specified, perform velocity gain adjustment. On card A2A07, adjust velocity gain potentiometer E2R6 (see figure 2-21) until time between leading edges of On Cylinder pulses is 52 ± 2 milliseconds.
6. Return drive to normal operation.


VELOCITY GAIN ADJUSTMENT (80 MB)

This procedure provides information on the checking and, if necessary, adjusting of the 80 megabyte servo system velocity signal. If the adjustment cannot be completed satisfactorily, the procedure must be terminated. If this happens, perform trouble analysis. The following procedure assumes that the FTU is connected, and that a scratch pack is installed on the drive.

Figure 2-18. 40 MB Coarse Velocity Waveform

OSCILLOSCOPE SETUP

	VOLTS / DIV	TEST POINT	SIGNAL NAME
CH 1 - (USE X 10 PROBE)	0.5 V	A2A08 TPF	+ FINE POSITION ANALOG
CH 2 - (USE X 10 PROBE)	0.5 V	A2B09 15A	+ ON CYLINDER SENSE
	SLOPE / SOURCE	TEST POINT	SIGNAL NAME
TRIGGER A - (USE X 10 PROBE)	+ / EXT	A2B09 16B	- COURSE
TRIGGER B - (USE X PROBE)	NOT USED		
TIME / DIV: 10 ms		MODE TRIGGER: CHOP	
ADDITIONAL SETTINGS: NONE			



OSCILLOSCOPE SETUP

	VOLTS / DIV	TEST POINT	SIGNAL NAME
CH 1 - (USE X 10 PROBE)	0.5 V	A2A08 TPF	+ FINE POSITION ANALOG
CH 2 - (USE X 10 PROBE)	0.5 V	A2B09 15A	+ ON CYLINDER SENSE
	SLOPE / SOURCE	TEST POINT	SIGNAL NAME
TRIGGER A - (USE X 10 PROBE)	+ / EXT	A2B09 16B	- COARSE
TRIGGER B - (USE X PROBE)	NOT USED		
TIME / DIV: 0.5 ms		MODE TRIGGER: CHOP	

ADDITIONAL SETTINGS: NONE







Figure 2-19. 40 MB Fine Velocity Waveforms

Figure 2-20. Procedure B and All 80 MB Velocity Gain Waveform

OSCILLOSCOPE SETUP

	VOLTS / DIV	TEST POINT	SIGNAL NAME
CH 1 - (USE X 10 PROBE)	0.2 V	A2B09 03A	+ ON CYLINDER
CH 2 - (USE X PROBE)	NOT USED		
	SLOPE / SOURCE	TEST POINT	SIGNAL NAME
TRIGGER A - (USE X 10 PROBE)	+ / EXT	A2B09 07A	- FORWARD SEEK
TRIGGER B - (USE X PROBE)	NOT USED		
TIME / DIV: 10 ms		MODE TRIGGER: CH 1	

ADDITIONAL SETTINGS: NONE



△ MEASUREMENT IS FROM TRAILING
EDGE OF PULSE A TO LEADING EDGE
OF PULSE B

9H34C

1. With the drive case closed, command random seeks for 10 minutes minimum in order to thermally stabilize drive.
2. Stop random seeks and set up oscilloscope per figure 2-20. Oscilloscope ground references must be as shown.
3. Command 822 (hex 336) cylinder continuous seeks and adjust oscilloscope trigger level to obtain waveform shown in figure 2-20.
4. Measure full length seek time. Time between On Cylinder pulses should be 52 to 54 milliseconds.
5. If full length seek time is not as specified, perform velocity gain adjustment. On card A2A07, adjust velocity gain potentiometer E2R6 (see figure 2-21) until time between leading edges of On Cylinder pulses is 52 to 54 milliseconds.
6. Return drive to normal operation




Figure 2-21. 80 MB Velocity Gain Adjustment Location

SPEED TRANSDUCER ELECTRICAL CHECK

This procedure checks the output of the speed transducer. Perform the following steps when you suspect that the spindle is not reaching normal operating speed.

1. Install a scratch pack.
2. Connect oscilloscope as shown in figure 2-21.1 and start drive motor.
3. Observe that the speed transducer output is between -0.60 and -1.28 volts on the negative swing and between +0.9 and +2.1 volts on the positive swing.
4. If oscilloscope reading is not within tolerance, power down drive, remove pack and perform Speed Transducer Adjustment procedure (shown in section 2D). If the speed transducer is within mechanical tolerance as described in section 2D and oscilloscope reading is still incorrect, replace speed transducer.

OSCILLOSCOPE SETUP

INPUT:

CHANNEL	VOLTS/DIV	CONNECTION	SIGNAL NAME
CH 1 1	0.5 V/CM	A10-27A	
CH 2			

TRIGGERING:


SLOPE/SOURCE	CONNECTION	SIGNAL NAME
-INT CH 1		

SCOPE GND TO GND ON LOGIC CARD.
USE X10 PROBES UNLESS OTHERWISE NOTED.

TIME/DIV: 0.2 MS/CM MODE:

NOTES: 1 USE X1 PROBE.

2. CALIBRATE SCOPE TO GROUND.



9X35

Figure 2-21.1 Speed Transducer Electrical Check

SECTION 2D

REPAIR AND REPLACEMENT

GENERAL

This section assumes that the particular assembly has previously been identified as malfunctioning. It then provides all necessary procedures pertaining to the adjustment, replacement, and repair of field replaceable parts of the drive. In addition, it identifies what to do when a particular part of the drive cannot be replaced in the field.

Information contained in this section assumes that the reader is thoroughly familiar with the information presented in the General Maintenance Information section of this manual. Also, this section relies heavily on the illustrations contained in the Parts Data section of this manual. These illustrations show the assembly and disassembly relationship of all the parts in the various assemblies. Individual procedures make specific references to the parts data illustrations.

Throughout the section, procedures for the various components or assemblies provide information on adjustment, removal-replacement, and repair in that order. If an adjustment procedure is included, and if there is some doubt as to the need for replacement, the adjustment procedure should be attempted before the final decision to replace the part is made.

Unless otherwise specified, all procedures in this section assume that the drive is powered down and that the customer disk pack is removed. Also, unless otherwise specified, all procedures can be performed with the drive installed in its normal operating position (in line with other drives, or in an equipment rack). Procedures for opening and closing the various cabinet components, and for raising and lowering the deck and logic chassis are included in the General Maintenance section under Access Drive For Maintenance.

CABINET REPAIR

GENERAL

Cabinet repair is limited to the removal and replacement of the various assemblies and their subcomponents, and to the adjustment of those assemblies for proper seating. Information is presented for all of the various mounting configurations of the drive. For this reason, ensure that the procedure is applicable to your drive (acoustic, non-acoustic, cabinet mounted, slide rail mounted, etc.).

Information is presented in the following order:

- Case Assemblies
- Drive Seals/Gaskets
- Pack Access Cover Assemblies
- Door Assemblies
- Side Panel Assemblies
- Slide Assemblies

CASE ASSEMBLIES

The case assemblies applicable to the various mounting configurations of the drive are illustrated in figures 3-8 and 3-13.

Adjustment

There are three adjustments applicable to the case assemblies: (1) Alignment to pack access cover (applicable to all mounted configurations), (2) Alignment to 1/4-turn fasteners (applicable only to acoustic top mount drives with these fasteners) and (3) Alignment of slide bolt latch (applicable only to acoustic top mount drives with slide bolt installed on frame).

Alignment To Pack Access Cover - The case assembly must be parallel to, and centered around, the pack access cover. Before making this adjustment, ensure that the pack access cover is properly adjusted. Adjust the case assembly by carefully bending the pivot pin tabs on the base assembly (A1). The case assembly is properly adjusted when the gap between the case and pack access cover (with cover installed and closed) is approximately equal on all sides and the edges are approximately parallel.

Alignment To 1/4-Turn Fasteners - When the case assembly is closed, the case must align with the 1/4-turn fasteners such that the fasteners can engage and secure the case to the frame. Before making this adjustment, ensure that the pack access cover is properly adjusted and that the case is properly aligned to the pack access cover. Adjust the case by loosening all four sets of attaching hardware (see figure 3-3, Sheet 1) which secure the drive electronics assembly to the frame. Move the drive electronics assembly in relation to the frame, until the case can be secured by the 1/4-turn fasteners. When adjustment is complete and case can be secured, tighten the attaching hardware securing the drive electronics assembly to the frame.

Alignment of Slide-Bolt Latch

The slide-bolt latch and the bracket it is attached to are slotted to permit vertical and lateral positioning. Both adjustments should be made to achieve latching that is reliable with a minimum amount of play.

Removal-Replacement



WARNING

Due to weight of cases use caution to prevent personal injury.

Although the various case assemblies are distinctive, the following procedure (with differences noted) applies to all case assemblies. Replacement is simply performed in the reverse order of removal.

1. Open case assembly from rear and pivot it forward on case pivot pin until it rests on case support arm (or support rod).
2. Remove ground cable by pulling it from quick disconnect terminal.
3. Disengage two halves of case support arm (or disengage support rod from slot in frame) while supporting case.
4. While still supporting case, slide case pivot pins (both sides) towards center of drive to disengage pivot pins from brackets.
5. Lift off case assembly.

Repair

Case assembly repair consists of removing and replacing broken or damaged parts. Section 3 lists all parts of the case assemblies which are field replaceable. There are no special tools required for case repair. The following items require the use of special materials:

- When replacing the support arm on all except the acoustic top case, put a light coat of Loctite grade C on threads of attaching screw.

CAUTION

Spray adhesive may get into drive if sprayed into air in computer room.

- When replacing acoustical foam panels on acoustic case assemblies, use a light coat of sprayable adhesive. First remove paper backing from foam. Then spray the adhesive around all edges of panel approximately one inch from edge. Also apply adhesive in an "X" pattern across center of panel. Place panel in position on case and press firmly into position.

DRIVE SEALS/GASKETS

Drive seals and gaskets serve as a noise buffer and reduce contamination in the pack area. Drive seals and gaskets are illustrated in figures 3-3, (Sheet 3), 3-9, and 3-24 (sheet 6).

Adjustment

There is no adjustment applicable to the drive seals and gaskets.

Removal-Replacement

Removal and replacement of gaskets is accomplished in accordance with parts data section information. The following procedure covers drive seal removal and replacement.

1. Apply pressure and pull to break adhesive seal.
2. Carefully remove adhesive residue by scraping or by using alcohol based solution.
3. Apply adhesive in track of seal and replace. Ensure seals are properly oriented (rounded side up on shroud, rounded side out on frame, deck, and case).

Repair

No repair is possible for drive seals and gaskets. Damaged parts should be replaced.

PACK ACCESS COVER ASSEMBLIES

The non-acoustic and acoustic pack access cover assemblies are illustrated in figures 3-14 and 3-15 respectively.

Adjustment

Pack access cover adjustment is required if the gasket on the bottom of the cover does not seal on the shroud. Check the sealing by placing a piece of paper on the shroud and closing the cover. If the paper can be easily pulled out, the cover needs adjustment. Check the sealing at a minimum of four points around the shroud.

There are three points of adjustment on the pack access cover: (1) left hinge bracket (2) right hinge bracket (3) cover catch. The hinge brackets provide enough play to allow an up and down adjustment which controls the sealing of the gasket at the rear of the pack access cover. The cover catch also provides up and down adjustment. The cover catch controls the sealing of the gasket at the front of the cover.

In addition to pack access cover sealing adjustment, the cover must also be aligned parallel to and centered between the edges of the case assembly. Center cover on shroud by using pack cover spacers (as required) between bracket and bearing as shown on final assembly figure (3-2 and 3-6). Spacers may go on either side of cover as necessary to center cover. It may be necessary to readjust cover centering in order to complete case assembly centering adjustment.

Removal-Replacement

The following procedure applies to both the non-acoustic and acoustic pack access cover. Cover replacement is simply the reverse order of removal.

1. Open pack access cover and remove ground strap by pulling loose quick disconnect on left side under shroud.
2. Remove retaining ring from pin securing gas spring to pack access cover.
3. While supporting pack access cover, pull out pin securing gas spring to cover.
4. Carefully loosen screws securing rightside hinge bracket. When screws have been loosened sufficiently, disengage hinge bracket and remove pack access cover.

Repair

Pack access cover repair consists of replacing broken and damaged parts. Section 3 lists all field replaceable parts of the covers. There are no special tools or materials required for pack access cover repair.

DOOR ASSEMBLIES

The door assemblies for the various mounting configurations of the drive are illustrated in figures 3-16 and 3-19.

Adjustment

The only adjustment required for the door assemblies is that they be aligned to the rest of the cabinet, and that they not rub on other cabinet members through the arc of their swing. All adjustment is accomplished by positioning the hinge members. Once the door is properly aligned, some adjustment of the keeper latch may be required to ensure proper latching.

Removal-Replacement

Removal and replacement procedures for the door assemblies depend on the style of the cabinet: non-acoustic or acoustic. The following procedures describe door removal; replacement is accomplished in the reverse order or removal.

Non-Acoustic Door - Door removal is accomplished by first opening the door and pulling the ground strap from the quick-disconnect terminal. The door is then removed by removing the lower hinge bracket and disengaging the door from the top hinge.

Acoustic door - Door removal is accomplished by first opening the door and removing the attaching hardware securing the ground strap (and unplugging connector P400 on rear doors). The door is then removed by pulling out the hinge pin in the lower hinge and lifting the door from the upper hinge.

Repair

Door repair is limited to replacing broken or damaged parts. Section 3 lists all field replaceable parts of the doors. There are no special tools required for door repair. The only special material required is sprayable adhesive. This is used in attaching the acoustical foam panels to acoustic door assemblies. Procedure for using the adhesive is the same as that listed under case assembly repair.

SIDE PANEL ASSEMBLIES

The non-acoustic and acoustic side panels are illustrated in figures 3-20 and 3-21 respectively. All work on the side panels requires that the drive be accessible on all sides.

Adjustment

Side panel adjustment is required only on acoustic cabinets. Adjustment is required in three directions (see figure 2-22). The four brackets on the side panel (A in figure 2-22) control the up-down adjustment for the side panel. The four brackets on the frame (B in figure 2-22) control the front-back and in-out adjustment of the side panel.

Perform the up-down adjustment to cause the top of the side panel to be parallel and flush with the top of the cabinet frame. Perform the front-back adjustment to cause the front edge of the side panel to be parallel to, and approximately 40 mm (1-1/2 in) in front of the front cabinet frame member (see figure 2-22). For this adjustment also ensure that front edge of side panel is flush with the front door when it is installed. Perform the in-out adjustment to cause the acoustic seals on the side panel to be in contact with the cabinet frame. This adjustment should be snug enough to cause a slight squashing of the seals when the side panel is secured in place.

A complete side panel adjustment is performed in the following order:

1. Adjust lower two brackets on side panel until panel meets up-down adjustment requirements.
2. Adjust lower two brackets on frame until panel meets front-back and in-out adjustment requirements. Lower rear bracket on frame governs exact front-back placement, while lower front bracket needs only an approximate placement.
3. Adjust top two brackets on frame so that 1/4-turn fasteners line up with side panel in front-back direction and that side panel meets in-out requirements.
4. Adjust top two brackets on side panel so that they line up with 1/4-turn fasteners.

Removal-Replacement

Removal and replacement procedures for the side panel assemblies depend on the style of the cabinet: non-acoustic or




Figure 2-22. Side Panel Adjustment

acoustic. The following procedures describe side panel removal. Replacement is accomplished in the reverse order of removal.

Non-Acoustic Side Panel - Remove side panel as follows:

1. Open front door and remove ground cable(s) from side panel(s) by pulling cable from quick-disconnect.
2. Remove front attaching hardware from side panel(s).
3. Open rear door and remove rear attaching hardware while supporting side panel(s).
4. Lift side panel up to clear side panel brackets.

Acoustic Side Panel - Remove side panel as follows:

1. Open rear door and remove ground cable from side panel(s) by removing screw and lock washer.
2. Release rear 1/4-turn fastener(s).
3. Open front door (or fully extend lower drive on its slides) and release front 1/4-turn fastener(s) while supporting side panel.
4. Lift side panel up to clear side panel brackets.

Repair

Side panel repair is limited to replacing broken or damaged parts. Section 3 lists all field replaceable parts of the side panels. There are no special tools required for side panel repair.


The only special material required is sprayable adhesive. This is used in attaching the acoustical foam panels to acoustic side panels. Procedure for using the adhesive is the same as that listed under case assembly repair.

SLIDE ASSEMBLIES

The slide assembly relationship to the drive and frame is illustrated in figures 3-4 through 3-6. Identification of the various slide parts is shown in figure 2-23.

Adjustment

Adjustment of the slide assemblies is covered in the replacement procedure.



NOTES:

- ① ALLOW REAR RECESS BRACKET ADJUSTMENT.
- ② LOCKS IN EXTENDED POSITION WHEN OUTER SLIDE IS FULLY EXTENDED.
- ③ EXTENDED BY PRESSING FULL EXTENSION RELEASE. FULL EXTENSION LOCK SNAPS OUT WHEN THIS SLIDE IS FULLY EXTENDED.
- ④ LOOSENING NUTS ALLOWS CATCH TO MOVE IN DIRECTION OF ARROW THUS ALLOWING QUICK DISCONNECT TO BE REMOVED.
- 5 ASSEMBLY SHOWN IS FOR RIGHT SIDE OF DRIVE.
- ⑥ NUT PLATES, WHICH ARE FURNISHED WITH SLIDE, ARE SUPPLIED WITH EITHER HOLES CENTERED IN THE NUT PLATE OR HOLES OFFSET FROM THE CENTER OF THE NUT PLATE. ON NUT PLATES WITH OFFSET HOLES, INSTALL NUT PLATES SO HOLES ARE CLOSE TO THE BRACKETS.

9X11

Figure 2-23. Slide Assembly Parts Location

Removal-Replacement

WARNING

Due to weight of slide mounted drive, use caution to prevent personal injury.

The following procedures (with differences noted) apply to all drive configurations which use slide assemblies.

Removal - Remove slide assembly as follows:

1. Pull drive out to its fully extended position by pressing full extension releases.
2. Disconnect I/O cables, power cable, and system ground.
3. Loosen nuts securing quick-disconnect catches and slide catches toward front of drive.

CAUTION

Two people are required to lift drive off slide assemblies.

4. Carefully lift drive (with quick disconnects attached to drives base assembly) from slide assemblies and set on a solid support.
5. Remove quick disconnects from drives base assembly by removing attaching screws and washers.
6. Push slide assemblies to fully closed position by pressing in full extension releases and pushing in slide assemblies.
7. Loosen mounting hardware securing slide assemblies to frame.
8. Disengage slide assemblies from frame by pulling slotted ends of slides out from between nut plate and frame.

Replacement - Install slide assemblies as follows:

1. Loosen adjusting screws and adjusting nuts on slide assemblies such that rear recess bracket can slide back and forth.
2. Push slide assemblies into fully closed position.

3. Loosely attach screws, lock washers, and nut plates to frame. Leave hardware loose enough so that slotted ends of slide assembly can be inserted between nut plate and frame.
4. Adjust position of rear recess bracket such that slide assemblies can be positioned in frame. Position slide assemblies in frame with quick disconnect flanges at bottom and facing one another.
5. Tighten mounting hardware securing slide assemblies to frame. Tighten adjusting screws and adjusting nuts securing rear recess bracket to main bracket.
6. Ensure that slide assemblies are aligned both horizontally and vertically by pressing full extension releases.
7. Pull both slide assemblies to their fully extended position by pressing full extension releases.
8. Separate quick disconnects from slide assemblies by loosening nuts securing quick disconnect catch and sliding catch forward.
9. Remove rubber mounting pads from bottom of drive (some units may not have mounting pads).

NOTE

For ease of assembly and to prevent damage to case assembly, remove case before installing drive on slide assemblies.

10. Using four countersunk flat-head screws and countersunk washers on each side, attach quick disconnects to drives base assembly.

CAUTION

Before mounting drive ensure that all slide assembly mounting hardware is secure. Use two people to lift drive on to slides. When installing drawer mounted drive, use care not to exert undue downward pressure or frame may tip forward.

11. Carefully lift drive over fully extended slide assemblies. Engage mounting tooth on quick disconnects with mounting slot on outer slide. Ensure that mounting block is properly seated in mounting notch.

12. Slide quick disconnect catch into position under outer slide and tighten nuts.
13. Press in to release full extension locks and then slide drive in and out several times to ensure that it slides freely and that binding does not occur. If binding occurs, slide assemblies are not properly aligned.
14. Connect I/O cables, power cable, and system ground.
15. When slide installation is complete, install side panels (drawer mounted drives only) and then install case assembly.

Repair

No repair of the slide assemblies is possible at the field level. If a slide assembly is damaged, the entire assembly must be replaced.

ELECTRONIC PACKAGE REPAIR

GENERAL

Electronic package repair is limited to the removal and replacement of the various assemblies and parts of the drive, and to the adjustment of those components. The illustrations in section 3 show all the field replaceable parts of the drive and their interrelationship to one another. Most parts of the drive can be replaced simply by studying the parts list illustrations. However, there are some procedures which are not obvious or which require the use of special tools or materials. These procedures are arranged in alpha-numeric order according to their physical location codes. The mechanical assemblies, which do not have physical location codes (drive belt), are located next to a part with which they logically associate (drive motor). The following procedures are included in the order stated:

- 42 Volt Supply/Emergency Retract Assembly (A1A01) (3 Card Power Supply)
- Power Supply Assembly (A1A01) (2 Card Power Supply)
- 12 And 20 Volt Supply (A1A02) (3 Card Power Supply)
- 5 Volt Supply (A1A03) (3 Card Power Supply)
- Blower Motor (A1BM1)
- Run Triac (A1K1)
- Deck Interlock Switch (A1S4)
- Logic Chassis (A2)

- Control Panel Assembly (A3A01)
- Power Amplifier Assembly (A3A04)
- Track Servo Preamplifier (A3A05)
- Drive Belt
- Drive Motor and Brake Assemblies (A3DM1, A3HB1)
- Spindle Assembly
- Static Ground Spring
- Speed Transducer (A3L1)
- Velocity Transducer (A3L2)
- Pack Cover Solenoid (A3L3)
- Rail Bracket Assembly
- Carriage and Coil Assembly
- Heads Loaded Switch (A3S2)
- Flex Lead Assembly
- Magnet Assembly
- Head Arm Assemblies
- Cable Assemblies (W1 through W4, W6, W11, W12)

42 VOLT SUPPLY/EMERGENCY RETRACT ASSEMBLY (A1A01) (3 CARD POWER SUPPLY)

The plus and minus 42 volt power supply, emergency retract assembly is illustrated in figure 3-35.

Adjustment:

There are no adjustments applicable to the 42 volt power supply. If the output does not meet specification, repair or replace the card.

Removal-Replacement

There are no special procedures for removing the card. Simply remove the power supply cover and lift the card straight out of the power supply chassis.

Repair

Repair of the 42 volt power supply card consist of removing and replacing the electrical components in accordance with the parts data information. In replacing resistors R1 and R2, use RTV adhesive sealant, or a suitable substitute, to cement the resistor body to the board blank.

POWER SUPPLY ASSEMBLY (A1A01) (2 CARD POWER SUPPLY)

The plus and minus 42, 20, and 12 volt power supply is illustrated in figure 3-39.

Adjustment

There are no adjustments applicable to the 42, 20, and 12 volt power supply. The outputs should be 42 ± 2 V, 20 ± 2 V, and 12 ± 2 V. If any voltages are out of tolerance, replace the card.

Removal-Replacement

1. Remove protective cover assembly.
2. Unplug connectors from J1, J2, and J3.
3. Remove four screws securing the power supply assembly to the base.
4. Lift the power supply assembly out of the drive

Repair

Repair of the power supply card consists of removing and replacing the electrical components in accordance with the parts data information. When replacing the large capacitors be sure to secure them with a tie wrap. Use dielectric grease between the base of the transistor and the heat sink.

12 & 20 VOLT SUPPLY (A1A02) (3 CARD POWER SUPPLY)

The plus and minus 12 volt and plus and minus 20 volt power supply is illustrated in figure 3-36.

Adjustment

There are no adjustments applicable to the 12 and 20 volt power supply. If the output does not meet specification, repair or replace the card.

Removal-Replacement

There are no special procedures for removing the card. Simply remove the power supply cover and lift the card straight out of the power supply chassis.

Repair

Repair of the 12 and 20 volt power supply consists of removing and replacing the electrical components in accordance with the parts data information. In replacing voltage regulator diodes VR1 and VR2, apply a thin coat of dielectric grease between the base of the diode and the heatsink.

5 VOLT SUPPLY (A1A03) (3 CARD POWER SUPPLY)

The plus and minus 5 volt power supply is illustrated in figure 3-37.

Adjustment

Adjustment of the 5 volt power supply is covered in Section 2C, Test and Adjustment.

Removal-Replacement

There are no special procedures for removing the card. Simply remove the power supply cover and lift the card straight out of the power supply chassis.

Repair

Repair of the 5 volt power supply consists of removing and replacing the electrical components in accordance with the parts data information. In replacing resistor R20, use RTV adhesive sealant (or a suitable substitute) to cement the resistor body to the board blank. In replacing transistors Q4, Q9, and Q10, apply a thin coat of dielectric grease between the base of the transistor and the heatsink.

BLOWER MOTOR ASSEMBLY (A1BM1)

The blower motor is illustrated in figures 3-32, and 3-33 (sheet 2).

Adjustment

There is no adjustment applicable to the blower motor.

Removal-Replacement

Removal and replacement of the blower motor assembly is accomplished in accordance with the information in the parts data section. Before removing the blower motor, first remove the absolute filter and the logic chassis air plenum. If the square shoulder grommets between the base and the blower motor are removed or need to be replaced, ensure that the wide shoulder on the grommet is installed toward the blower. The foam tape gasket between the blower and the logic chassis air plenum is not part of the blower motor assembly. Refer to Repair for the replacement of the gasket.

Repair

Repair of the blower motor assembly is limited to the replacement of connectors, pins, quick connect terminals, insulating pods, and the foam gasket next to the logic chassis air plenum. Refer to the paragraph on cable assembly removal-replacement and repair for information concerning the electrical terminals.

Gasket replacement requires approximately 305 to 330 mm (12 to 13 in) of foam tape. Proceed as follows:

NOTE

Use care not to damage gasket when installing logic chassis air plenum.

1. Cut two lengths of foam tape, each 140 mm (5-1/2 in) long.
2. Place logic chassis air plenum on base next to blower motor and align holddown holes. Mark position of each end of plenum on blower motor with a pencil.
3. Remove backing from one 140 mm (5-1/2 in) length of tape to expose adhesive. Position edge of tape against base (to seal space under blower) and center around two

marks made on blower motor. Press tape firmly into position against blower and base.

4. Remove backing from second length of foam tape to expose adhesive. Position tape above upper edge of cutout in blower, edge of tape must be even with edge of cutout. Align ends of tape with first piece of tape and press into place on blower.
5. Cut two lengths of foam tape to length required to fill space between two lengths of tape already installed. Remove backing from tape and position with outer edges of tape even with ends of installed tape. Press into position.

RUN TRIAC (AIK1)

The run triac is illustrated in figures 3-32 and 3-33 (sheet 1).

Adjustment

There is no adjustment applicable to the run triac.

Removal-Replacement.

Removal and replacement of the run triac is performed in accordance with the information in the parts data section. When replacing the run triac, apply a light coat of dielectric grease to the base of the triac.

Repair

No repair of the run triac is possible. If the triac fails it must be replaced.

DECK INTERLOCK SWITCH (A1S4)

The deck interlock switch is illustrated in figures 3-32 and 3-33 (Sheet 1).

Adjustment

Adjustment of the deck interlock switch is not a critical adjustment. Should it be necessary to adjust the deck interlock switch, use the adjusting screw in the end of the plunger to increase or decrease the travel of the plunger.

Removal-Replacement

1. Remove power from the unit.
2. Remove the case assembly (top cover), raise the deck, and install a deck support bracket. (Refer to figure 2-4.)

NOTE

A 6 inch long hex driver is recommended for easier removal of the front and rear deck mounting screws.

3. Remove the two front deck hold down screws located in the shroud area.
4. Remove the two wires from the deck interlock switch, located directly behind the transformer.
5. Remove the deck support bracket and return the deck to its original condition.
6. Unplug the velocity transducer and remove its mounting bracket, located at the rear of the magnet. This is necessary to allow removal of the two rear deck mounting screws.
7. Remove the velocity transducer cable clamp and lay the cable aside.
8. Remove the two rear deck mounting screws. The rear deck hold down screw and spacer should be in the keeper hole. All screws are located directly above the running time meter.
9. Unplug connector P200 from power amp card and remove the tie wrap closest to this connector to allow more harness movement.

WARNING

Use care when reaching under the raised deck to avoid any accidents.

10. Raise the rear of the deck about 100 mm (4 in). Lift the hinged, shock-mount bracket containing the interlock switch away from the magnet until it stops. Slowly lower the rear deck assembly until it rests on the mounting bracket.

11. Remove the two mounting screws from the underside of the interlock switch, and remove the switch.

Repair

No repair of the deck interlock switch is possible.

LOGIC CHASSIS ASSEMBLY (A2)

The logic chassis assembly is illustrated in figure 3-24.

Adjustment

There is no adjustment applicable to the logic chassis assembly.

Removal-Replacement

The following procedure covers removal of the entire logic chassis from the drive and removal of the wirewrap assembly from the logic chassis. However, the most common repair of the logic chassis is the changing of pins on the wirewrap panel. For these procedures it is not necessary to remove the entire logic chassis assembly. Replacement of the logic chassis is performed in reverse order of removal.

1. Disconnect I/O cables in accordance with procedure listed under Standard Test Conditions.
2. Remove I/O card(s) from location D1 (and D2).
3. If terminators are installed, remove them from locations C1 (and C2).
4. Remove all cards from logic chassis.
5. Raise logic chassis to maintenance position and remove all connectors, power and ground leads, and logic chassis cover from back of wirewrap panel (refer to figure 3-22, sheet 2).
6. To remove logic chassis:
 - a. S/C 16 and below - With logic chassis in maintenance position, press in on flat spring and slide logic chassis off hinge.
 - b. S/C 17 and above - Lower logic chassis to operating position and remove hardware securing logic chassis hinge to magnet. Lift chassis up and out of base.

7. Remove parts of logic chassis as necessary, in accordance with illustration in parts data section.
8. If it is necessary to remove wirewrap assembly from logic chassis proceed as follows:
 - a. Use a pliers to open crimp on end of each guide rail. When all crimps have been opened and each guide rail member is sufficiently straight, guide rails can be pulled out of wirewrap assembly.
 - b. Remove hardware securing wirewrap assembly to logic chassis and remove wirewrap assembly. When replacing apply Loctite, grade C, to first few threads of studs on logic chassis.

Repair

Logic chassis repair is limited to the removal and replacement of broken or damaged parts in accordance with the parts data section, and to the repair of wires and replacement of wirewrap panels pins. The following procedures provide information on wirewrap replacement and pin straightening/replacement.

Wirewrap Replacement - This procedure describes removal and replacement of backpanel wirewrap connections.

1. Using end of wirewrap tool with notch opposing direction of wires wrap, slide tool over pin and carefully turn tool to unwrap wire.

CAUTION

Do not attempt to rewrap a previously wrapped wire. Cut off old wrap and restrip wire, or replace with new wire.

2. If wire is being replaced, cut new wire to proper length and strip approximately 30 mm (1-1/8 in) of insulation from each end of wire.
3. Insert one end of wire into wirewrap tool until insulation rests against stop.
4. Slide tool over backpanel pin, leaving a small gap between bottom of post or lower wrap level and new wire.
5. Hold wire securely (allow small amount of slack to assure one turn of insulation) and twist tool to wrap wire around pin. As tool is twisted, wire wrapping around pin forces tool up and off wire.

6. When wire is completely wrapped, remove tool and inspect connection. Each connection must have one turn of insulation and six to seven turns of bare wire around pin.

Pin Straightening/Replacement - Wirewrap panel pin straightening is accomplished using the pin straightener listed in maintenance tools and materials. This procedure describes removing a damaged pin from the wirewrap panel and replacing it with a new one.

1. Remove card from logic chassis position associated with pin removal.

NOTE

Remove wires from pin, noting levels from which removed. When reinstalling wires, follow procedures in wirewrap replacement paragraph.

2. Remove all wires from subject pin.
3. Slide I/O pin removal tool over pin from wirewrap side of panel and apply pressure toward panel and apply pressure toward panel until bond breaks and pin starts to slide out.
4. Grasp shank of pin (with long nose pliers or similar tool) from card side of panel and pull it out. If collar (see figure 2-21.) comes out with pin, proceed to step 5. If collar remains secure in panel, proceed to step 6.
5. Coat collar of replacement pin (not hole) with fast cure epoxy and insert pin and collar into panel from wirewrap side. Proceed to step 7.
6. Insert replacement pin (with collar removed) into panel from wirewrap side until it is same length as adjacent pins.

CAUTION

Any epoxy on shaft of pin will prevent an electrical connection.

7. Carefully apply a fast cure epoxy (obtain commercially) around pin on wirewrap side of panel.
8. Following epoxy cure, reconnect wires and replace logic card in card slot.




Figure 2-24. Wirewrap Pin Replacement

CONTROL PANEL ASSEMBLY (A3A01)

The control panel assembly is illustrated in figures 3-22 and 3-23.

Adjustment

There is no adjustment applicable to the control panel assembly.

Removal-Replacement

Remove the control panel from the shroud by reaching behind the shroud and carefully pressing on the back of the panel. Lift the panel out the front of the shroud and disconnect connector P201. Replacement is performed in reverse order.

Repair

Repair of the control panel is limited to the removal and replacement of broken or damaged parts in accordance with the parts data information. When replacing any of the switches or lens diffused LEDs, ensure that they are properly aligned to

clear the bezel before they are soldered in place. It is especially important that the switches not bind on the bezel after assembly.

POWER AMPLIFIER ASSEMBLY (A3A04)

The power amplifier is illustrated in figure 3-25, sheet 1 and in figure 3-31.

Adjustment

There is no adjustment applicable to the power amplifier assembly.

Removal-Replacement

The following procedure removes the power amplifier from the drive. Replacement is performed in reverse order.

1. Remove quick connect terminal (yellow leadwire) from faston on upper left hand corner of assembly.
2. Loosen attaching hardware securing upper left hand corner such that assembly can later be removed.
3. Raise deck to maintenance position.
4. Remove connector J200. It may be necessary to use a tool to pry apart two halves of connector.
5. Remove two sets of attaching hardware securing assembly to deck casting. It may be necessary to raise deck higher in order to gain adequate access to attaching hardware.
6. Carefully lift assembly from behind attaching hardware loosened in step 2.

Repair

Repair of the power amplifier assembly consists of removing and replacing broken or damaged parts in accordance with the parts data section. When replacing any of the resistors on the board, use RTV adhesive sealant, or a suitable substitute, to cement the resistor body to the board blank. When replacing transistors Q1 through Q4, apply a thin coat of dielectric grease between the base of the transistor and the heat sink. Transistor Q5 uses the insulating wafer and does not need the dielectric grease.

TRACK SERVO PREAMPLIFIER (A3A05)

The track servo preamplifier assembly is illustrated in figure 3-25, sheet 1.

Adjustment

There is no adjustment applicable to the servo preamplifier assembly.

Removal-Replacement

The following procedure covers removal of the servo preamplifier assembly from the mounting plate and leaves the mounting plate secured to the deck. Replacement is performed in the reverse order of removal.

1. Raise deck to maintenance position.
2. Reach behind servo preamplifier from under deck and disconnect connector J8. It may be necessary to cut and remove cable tie strap.
3. Loosen attaching hardware on upper left hand corner of assembly. Carefully slide servo preamplifier shield from behind attaching hardware and leave it hanging on servo head cable.
4. Remove attaching hardware securing servo preamplifier housing to mounting plate. It may be necessary to remove deck support bracket and move deck up or down in order to have clear access to attaching hardware. Especially on cabinet mounted drives, it is easier to have one person manipulate deck into position and have a second person remove attaching hardware.
5. Unplug servo head connector from servo preamplifier board. Carefully remove preamplifier housing (containing board) from between deck and power supply. It may be easier to remove preamplifier housing if deck is lowered to normal operating position.
6. Remove attaching hardware securing servo amplifier board to housing.

Repair

There is no repair of the servo preamplifier possible at the field level. If the board is malfunctioning it must be replaced.

DRIVE BELT

The drive belt and associated adjusting hardware are shown in figure 3-25, sheet 5.

Adjustment

The drive belt adjustment may be performed any time there is suspicion that the belt may be slipping or as required by other procedures in this manual. Before performing the adjustment, check the belt for any signs of damage: fraying, cracking, or checking of belt surface. If any of these signs exist, replace the belt before performing adjustment.

1. Raise deck to maintenance position.
2. Referring to figure 2-25, measure distance between spring guide and stop nut. Distance must be as follows:
 - Between 8.9 and 11.4 mm (0.35 to 0.45 in) for 50 Hz drives.




Figure 2-25. Drive Belt Adjustment

- Between 5.1 and 7.6 mm (0.20 to 0.30 in) for 60 Hz drives.
3. If dimension is not correct, turn motor adjusting rod until it meets specification.
 4. Open pack access cover and rotate spindle while checking drive belt tracking. Belt must run true on both motor pulley and spindle pulley. Belt not tracking properly indicates pulley misalignment.
 5. When belt is tracking properly, close pack access cover and return deck to normal operating position.

Apply power to drive and press START switch to start drive motor. Again watch drive belt and see that it is tracking properly.

Removal-Replacement

The following procedure covers both the removal and replacement of the drive belt and applies to all drives.

1. Raise deck to maintenance position.

WARNING

Spring is under compression. Wear safety glasses.

CAUTION

Failure to relieve pressure on compression spring may cause the motor shaft to be bent.

2. Turn motor adjusting rod out until pressure on compression spring is fully relieved.

3. Remove drive belt from motor by rolling belt off motor pulley while rotating pulley. Disengage belt from spindle pulley and slip it out from around brake.
4. To install drive belt, slip belt up over brake and then engage other end of belt in groove on spindle pulley. Apply tension to belt and guide it on to motor pulley while manually rotating drive belt and drive motor pulley.
5. Manually rotate drive motor pulley several times to make certain that drive belt is tracking properly.
6. Perform Adjustment procedure.

Repair

There is not repair of the belt possible.

DRIVE MOTOR AND BRAKE ASSEMBLIES (A3DM1, A3HB1)

The drive motor and brake assemblies are illustrated in figure 3-30.

Adjustment

There are two adjustments pertaining to the drive motor and brake assemblies 1) drive belt adjustment 2) brake adjustment. The drive belt adjustment procedure is provided in the Drive Belt paragraph. The brake adjustment is performed during the replacement and is provided in the Removal-Replacement paragraph under brake replacement.

Removal-Replacement

The brake assembly may be removed and replaced separately, or the drive motor and brake assemblies may be removed and replaced as a unit. When removing the drive motor, the brake must also be removed. Removal and replacement of either the brake or drive motor and brake is self evident when using the illustration in the parts data section. Before beginning any work on the drive motor and brake assemblies, perform the drive belt removal procedure. The following information presents details of the reassembly procedures which are not obvious. Be thoroughly familiar with this information before attempting replacement.

Brake Replacement - The following procedure is to be used when ever a brake is installed on the drive motor shaft.

CAUTION

In order to prevent damage to drive motor shaft, brake replacement must be performed in the order specified.

1. Loosely install brake mounting bracket on motor mounting plate (see figure 3-30).
2. Install brake shaft collar (with ridge of collar facing away from drive motor) and then brake on drive motor shaft.
3. Install brake on motor shaft as follows:
 - a. For floating type brake. Slide brake on motor shaft so collar slides on split shaft of brake armature and brake stud (with sleeving and ground standoff installed) strikes end of slot in brake mounting bracket. Attach ground wire to ground standoff.
 - b. For non-floating type brake. Slide brake on motor shaft so that collar slides on split shaft of brake armature and so that stud on brake strikes end of slot in brake mounting bracket. Tighten nut securing brake to brake mounting bracket.

CAUTION

In following step, be certain that brake is centered around drive motor shaft. If brake is miscentered it could cause damage to, or breaking of, drive motor shaft.

4. Support brake to maintain centering on motor shaft while tightening screw securing brake mounting bracket to motor mounting plate.
5. While holding motor pulley to prevent shaft from turning, rotate hysteresis brake armature several turns to eliminate any binding between drive motor shaft and brake armature.

NOTE

To minimize motor and brake vibration, ensure that the socket head screw in the brake shaft collar is positioned opposite the set screw in the pulley shaft collar.

6. With brake shaft collar resting on brake, tighten hex head socket screw in collar as follows:
 - On newer units (use a 9/64-in hex wrench) tighten screw to a torque between 3.2 and 3.6 N·M (28 and 32 Lbf·in).
 - On older units (use a 7/64-in hex wrench) tighten screw to a torque between 2.1 and 2.5 N·M (18 and 22 Lbf·in).




Figure 2-26. Drive Motor Pulley Adjustment

NOTE

Replacement brakes are supplied with extension cabling (required on older units.) If extension cable is not required, discard it.

7. Connect brake leadwires.
8. Replace cable ties, being certain that all wires are secured so they will not be rubbed by drive belt.

Drive Motor Replacement - Observe the following when reassembling the drive motor assembly:

NOTE

If it is necessary to replace drive motor assembly because of an electrical failure of the motor, also replace capacitor A3C6. It is likely that this capacitor is associated with failure.

1. Tighten plate mounting screws to a torque between 0.9 and 1.3 N·M (8 and 12 Lbf·in).
2. With motor mounted on motor mounting plate, position pulley on drive motor shaft so that alignment dimension shown in figure 2-26 is 20.7 ± 0.8 mm ($13/16 \pm 1/32$ in).
3. Ensure that motor pulley flange protrudes slightly through shaft collar.
4. Tighten set screw in shaft collar to a torque between 6.8 and 7.9 N·M (60 and 70 Lbf·in).

Repair

Repair of the drive motor and brake assemblies is limited to removing and replacing broken or damaged parts in accordance with information in the parts data section.




Figure 2-27. Spindle/Carriage Alignment

SPINDLE ASSEMBLY

The spindle assembly is illustrated in figure 3-26.

Adjustment

Spindle adjustment must be performed any time the attaching hardware securing the spindle to the deck has been loosened.

1. Remove belt from spindle pulley.
2. Remove head arm assembly number 3 (second from bottom).
3. Install carriage alignment arm in slot on carriage just vacated by head arm assembly number 3. Secure alignment arm to carriage and tighten attaching hardware until torque is between 0.40 and 0.51 N·M (3.5 and 4.5 Lbf·in).

4. Extend carriage until alignment arm is aligned as shown in figure 2-27.
5. Using non-metallic feeler gauge, check that distance between alignment arm and spindle is as specified in figure 2-27. If adjustment is required, go to step 6. If specification is met go to step 12.
6. Retract carriage and rotate spindle until holes in top of spindle align with mounting hardware.
7. Remove screws and washers securing spindle to deck. Install screws (without washers) and just snug screws tight.
8. Extend carriage until alignment arm is positioned as shown in figure 2-27.
9. Using a plastic faced hammer, gently tap spindle until dimension between alignment arm and spindle is as specified in figure 2-27.
10. Tighten one screw at a time and check dimension after tightening each screw.
11. When last screw is tightened in step 10, remove first screw tightened and install washer on it. Then reinstall screw, tighten it, and recheck dimensional requirement. Repeat this procedure for the second and third screws.
12. Remove alignment arm and install head arm assembly in slot number 3 in carriage.
13. Install belt onto spindle pulley.
14. Perform static ground spring adjustment and head arm alignment procedures.

Removal-Replacement

The following procedure covers removing and replacing the entire spindle assembly. It is not necessary to remove the spindle to perform lockshaft replacement. Refer to Repair for information concerning lockshaft replacement.

CAUTION

When spindle assembly is removed from drive or shipping container do not allow it to rest on pulley end of assembly. When it must set down, lay it on its side or on spindle face plate. Improper handling of spindle assembly may cause damage to spindle bearings which could result in premature failure of spindle or even damage to disks and heads.

1. Raise deck to maintenance position.
2. Referring to figure 3-25, sheet 6, remove attaching hardware securing ground cable to static ground spring block.
3. Remove drive belt and set it aside.
4. Lower deck to normal operating position.
5. Rotate spindle until holes in top of spindle align with mounting hardware.
6. Remove attaching hardware securing spindle assembly to deck.
7. Lift spindle assembly from deck, being careful to avoid damage to static ground spring.
8. Remove attaching hardware securing static ground spring mounting block to spindle assembly. Remove static ground spring assembly and install it on replacement spindle assembly.
9. Carefully lower replacement spindle assembly through deck opening in shroud. Orient spindle assembly so that ground spring mounting block faces drive motor.
10. Secure spindle assembly to deck using screws only. Lock washers are installed during Adjustment procedure.
11. Raise deck to maintenance position.

12. Install ground cable to static ground spring mounting block and install drive belt.
13. Perform Drive Belt Adjustment procedure and then the Spindle Assembly Adjustment procedure. Following spindle assembly adjustment, check speed sensor adjustment.

Repair

Repair of the spindle assembly is limited to removal and replacement of the lockshaft and associated hardware as indicated in the parts data section. The following procedure covers removal and replacement of the lockshaft.

1. Raise deck to maintenance position.
2. Referring to figure 3-25, sheet 6, remove attaching hardware securing ground cable to static ground spring block.
3. Remove static ground spring from mounting block.
4. Remove shaft end seal by prying down with a pair of opposing screw drivers.
5. Reaching in from bottom of spindle, remove shoulder screw and associated washers and spring. Spindle may be locked in position during shoulder screw removal, by pressing down on end of brake plate.
6. Lift lockshaft out from top of spindle.
7. Install replacement lockshaft, sliding it in from top of spindle. If smaller compression spring came out with old lockshaft, assemble it on new lockshaft before assembly.
8. Assemble two washers and compression spring on shoulder screw as shown in figure 3-25. Apply a thin coat of Loctite primer, grade T, to last four threads of shoulder screw, being careful not to get any primer on spring or washers.
9. Allow Loctite primer to air dry for approximately 5 minutes.
10. When Loctite primer is dry apply a thin coat of Loctite, grade C, to last four threads of shoulder screw. Parts must be assembled within three minutes of Loctite application.

11. Assemble shoulder screw and hardware into bottom of lockshaft. Tighten shoulder screw to a torque between 4.0 and 5.0 N·M (35 and 45 Lbf·in)
12. Press shaft end seal into position on bottom of spindle assembly. Lower deck to normal operating position and allow Loctite to air dry for approximately three hours.
13. Following Loctite cure, raise deck to maintenance position and assemble static ground spring and associated ground cable.
14. Perform Clean and Lubricate Lockshaft procedure (see preventive maintenance).
15. Perform Static Ground Spring Adjustment procedure.

STATIC GROUND SPRING

The static ground spring (located on the bottom of the spindle assembly) is illustrated in figure 3-25, sheet 6.

Adjustment

The ground spring adjustment procedure must be performed any time the screws securing the spring or mounting block have been loosened, or as required by other procedures in this manual.

1. Raise deck to maintenance position.
2. Connect push-pull gauge to outer end of ground spring.
3. Using a force in-line with lockshaft, pull down on push-pull gauge. Force required to pull ground spring free of spindle end seal must be 90 ± 25 grams.
4. If force is within specification, go to step 7. If force is not within specification, loosen attaching hardware securing ground spring mounting block to side of spindle assembly.
5. Adjust spring tension by sliding mounting block toward deck (to increase tension) or away from deck (to decrease tension) and retightening attaching hardware.
6. Repeat force measurement and adjustment steps until specifications are met. If specifications cannot be met, replace ground spring.

7. Remove attaching hardware securing ground cable to ground spring mounting block and disconnect ground cable.
8. Connect multimeter (set to RX1) between ground cable and ground spring. Meter should indicate zero ohms. If specification is met go to step 10, if it is not met, go to step 9.
9. Clean bottom of shaft end seal (on bottom of spindle) using a piece of gauze slightly dampened with media cleaning solution. Repeat step 8. If specification is not met, replace ground spring.
10. Disconnect multimeter and connect ground cable to ground spring mounting block.
11. Lower deck to normal operating position.

Removal-Replacement

There are no special procedures for the removal and replacement of the static ground spring. Perform the removal-replacement in accordance with the information in the parts data section.

Repair

No repair of the static ground spring is possible. If any of the parts fail, they must be replaced.

SPEED TRANSDUCER (A3L1)

The speed transducer assembly is illustrated in figure 3-25, sheet 4.

Adjustment

Speed transducer adjustment is required whenever the relative position of the spindle and the speed transducer has been changed, or as specified by other procedures in this manual.

1. Inside the pack area, place Go-NoGo tool across top of spindle face plate so that gauge extends out over top of speed transducer.
2. Check dimension from top of speed transducer to top of spindle face plate as shown in figure 2-28. If adjustment is required, proceed to step 3.

NOTE

On newer 60 Hz acoustical drawer or rack mount units using round I/O cables, remove I/O bracket from its mounting, prior to raising deck. This will allow strain relief when deck is raised.

3. Raise deck to maintenance position.
4. Loosen locknut on bottom of speed transducer. Disconnect connector J202 so that leads are free to turn during adjustment.
5. Rotate speed transducer until top of transducer makes contact with the Go surface of the Go-NoGo tool. Tighten locknut until torque is between 0.45 and 0.67 N·m (4 and 6 lbf·in). Recheck dimension with Go-NoGo tool.
6. When dimension is correct and locknut is tightened, install connector J202.
7. Lower deck to normal operating position (and secure I/O cable bracket if removed in step 3).
8. Install scratch pack and apply power to drive spindle. Ensure that the drive spindle gets up to speed and the heads load.
9. If the heads fail to load, perform the Speed Transducer Electrical Check in Tests and Adjustments, section 2C.

Removal-Replacement

There are no special procedures for the removal or replacement of the speed transducer. The speed transducer is removed and replaced from the bottom side of the deck assembly. When replacement is completed, perform the adjustment procedure.

Repair

Repair of the speed transducer is limited to the replacement of the connector and pins in accordance with the parts data section. Refer to Cable Assembly repair procedures for information on connector and pin replacement.




Figure 2-28. Speed Transducer Adjustment

VELOCITY TRANSDUCER (A3L2)

The velocity transducer is illustrated in figure 3-29 and shown in parts data illustration 3-17.

Adjustment

Velocity transducer adjustment is covered in the removal and replacement procedure.

Removal-Replacement

The velocity transducer assembly consists of a transducer coil (complete with housing and connector), a transducer core, and an extension rod. Whenever it is necessary to change any part of the transducer assembly, all parts of the assembly must be changed.




Figure 2-29. Velocity Transducer Replacement

9H20C

NOTE

When ordering the velocity transducer assembly, be certain to also order the extension rod.

The following procedure first covers replacement of the transducer coil, aligning it to the old transducer core. It then covers replacement of the core.

1. Remove attaching hardware, securing transducer coil to rear of magnet assembly. Unplug connector P22.
2. Carefully remove transducer coil, sliding it straight out rear of magnet assembly.
3. Slowly and carefully slide replacement transducer coil into rear of magnet assembly.
4. Align one of the three slots on back of transducer coil with mounting hole in magnet. Manually extend heads and slide carriage back and forth. Be aware of any drag or of any rubbing sound. Rotate coil and move carriage again for each of remaining two slots on back of transducer coil.
5. Select mounting slot which produced minimum drag and minimum rubbing. Orient this slot to mounting hole and install and tighten attaching hardware.
6. Connect connector P22. Extend heads and move carriage back and forth to verify alignment of transducer coil.
7. Reach in from logic chassis side of drive and disconnect extension rod from rear of carriage assembly using a 1/8-inch open end wrench.
8. Push extension rod and transducer core through coil and out rear of magnet assembly.
9. Apply light coat of Loctite grade C to threads of new extension rod and screw rod into end of replacement transducer core. Wipe off excessive Loctite.

NOTE

Do not apply Loctite to remaining end of extension rod until completing next step.

10. Slowly and carefully slide replacement transducer core and extension rod through coil from rear.

CAUTION

Use extreme care not to allow Loctite to get on carriage rails or bearings.

11. Very carefully apply a light coat of Loctite grade C to threads on end of extension rod. Thread extension rod into rear of carriage and lightly tighten. Wipe away excessive Loctite.
12. Manually extend heads and move carriage back and forth to verify that carriage moves freely and there is no excessive drag.

Repair

Repair of the velocity transducer assembly is limited to removing and replacing the connector and pins in accordance with the parts data section. Refer to Cable Assembly repair procedures for information on connector and pin replacement.

PACK COVER SOLENOID (A3L3)

The pack cover solenoid (optional) is illustrated in sheet 2B of figure 3-25 for the BK5C6D and sheet 2A of figure 3-25 for other units.

Adjustment - S/C 16 & Below

The pack cover solenoid adjustment is required whenever the solenoid is changed or if the pack cover does not lock when power is removed from the drive. There are two adjustments pertaining to the solenoid: 1) clearance, 2) spring tension.

The clearance adjustment is made to obtain minimum clearance between the interlock latch (see figure 2-30) and the interlock keeper on the pack access cover. When the pack access cover is latched (solenoid deenergized, and latch in up position) the keeper must strike the latch and not allow the pack cover catch to be released. Loosen the attaching hardware securing the solenoid assembly to the shroud, and slide the assembly backwards or forwards to achieve this adjustment.

The spring tension adjustment is made to fully extend the solenoid plunger when the solenoid is deenergized. The tension should not be so great as to prevent the plunger from fully retracting when the solenoid is energized. Perform the adjustment by loosening the spring mounting hardware and sliding it up or down in the mounting slot.

Removal-Replacement (All Units Except BK5C6D)

There are no special procedures for removal and replacement of the pack cover solenoid. Perform the removal and replacement in accordance with the information in the parts data section.

Adjustment S/C 17 & Above (All Units Except BK5C6D)

The pack cover solenoid adjustment is required whenever the solenoid is changed or if the pack cover does not lock when power is removed from the drive. There are two adjustments pertaining to the solenoid: (1) horizontal, (2) vertical.

1. Adjust horizontal position of the interlock using adjustment slots to obtain a gap of 0.635 to 1.397 mm (0.025 to 0.055 in) between the interlock latch and pack cover latch. Refer to figure 2-30.
2. Adjust vertical position of solenoid using the adjustment slots to obtain clearance between interlock latch and the pack cover latch when the plunger of the solenoid is bottomed. The travel of the plunger cannot be so great as to prevent retracting the plunger when the solenoid is energized.

Removal - Replacement (BK5C6D Only)

There are no special procedures for removal and replacement of the pack cover solenoid. Perform the removal and replacement in accordance with the information in the parts data section. Perform the following steps to check for proper interlock operation:




Figure 2-30. Pack Cover Solenoid Adjustment (Sheet 1 of 2)
S/C 16 & Below




Figure 2-30. Pack Solenoid Adjustment (Sheet 2)
S/C 17 and Above

1. Install disk pack and close pack access cover.
2. Ensure that pack access cover will not open when AC circuit breaker is off.
3. Turn on AC circuit breaker. Ensure that pack access cover will not open until AC power has been on for more than 30 seconds.

NOTE

The interlock hook on the pack access cover must actuate the interlock switch when the cover is closed. If this does not occur, the drive motor will fail to start when the START switch is pressed.

4. Close pack access cover and start drive motor. Ensure that the pack access cover does not open when the disk pack is rotating.

Repair

No repair of the pack cover solenoid is possible. If any part fails, it must be replaced.

RAIL BRACKET ASSEMBLY

The rail bracket assembly is illustrated in figure 3-27.

Adjustment

The rail bracket assembly is not adjustable in the field. Refer to Removal-Replacement for additional information.

Removal-Replacement

Because of the precision alignment, and the special tools and training required to accomplish the alignment, it is not possible to perform adjustment or replacement of the rails or the rail bracket assembly in the field. Under no circumstances should the screws securing the rails or the rail bracket to the deck be loosened. If either the rails or the rail bracket assembly are damaged or misaligned, contact the factory maintenance representative for service.

Repair

Repair of the rail bracket assembly is limited to the replacement of those items mounted on the bracket, as specified in the parts data section. In addition to the following information, refer to the Heads Loaded Switch and the Flex Lead Assembly procedures.

When replacing the cam towers, tighten attaching screws to torque between 0.57 and 0.79 N·M (5 and 7 Lbf·in). When replacing the upper stop block, the rubber stop bumper must also be replaced. Attach the stop bumper to the stop block using a small amount of rubber silicone sealant.

CARRIAGE AND COIL ASSEMBLY

The carriage and coil assembly is illustrated in figure 3-28. Because of the precision alignment of the carriage bearings, and the special tools and training required to accomplish the alignment, the carriage and coil assembly cannot be replaced in the field. If either the carriage or coil is damaged or misaligned, call the factory maintenance representative for service.

The flex lead assembly, also illustrated in figure 3-28, can be replaced in the field.

Refer to that procedure for service information.

HEADS LOADED SWITCH (A3S2)

The heads loaded switch is illustrated in figure 3-27.

Adjustment

Perform the heads loaded switch adjustment under any of the following conditions:

- Heads do not fully retract when drive is powered down.
 - Unknown cause of a power amplifier or power amplifier fuse failure.
 - Heads loaded switch is changed or in any way moved.
 - Instructed to do so by another procedure.
1. Disconnect leadwires from heads loaded switch, taking note of leadwire placement.

2. Connect multimeter (set to RX1 scale) between ground contact and normally open contact as shown in figure 2-31. With carriage fully retracted, multimeter should indicate zero ohms.

NOTE

Measure carriage travel between rear edge of voice coil and inside back edge of magnet assembly.

3. Note measurement from rear of voice coil to inside back edge of magnet assembly with carriage retracted. Manually extend head very slowly, while observing multimeter. Measure carriage travel at point that multimeter switches from zero ohms to infinity. Difference between fully retracted measurement and heads extended measurement should be from 2.29 to 4.06 mm (0.090 to 0.160 in).




Figure 2-31. Heads Loaded Switch Replacement

4. If switch does not transfer within specified measurement, loosen hardware securing switch mounting bracket to rail bracket assembly and adjust switch position.
5. When adjustment is complete recheck carriage travel per step 3. Assuming adjustment is correct, reconnect lead-wires to heads loaded switch.

Removal-Replacement

No special procedures are required for replacement of the heads loaded switch.

Repair

No repair of the heads loaded switch is possible. If the switch fails, it must be replaced.

FLEX LEAD ASSEMBLY

The flex lead assembly is shown in relation to the carriage and coil assembly in figure 3-28.

Adjustment

Adjust the flex lead assembly any time the assembly is changed, or any time work is done in the area which could cause the flex lead assembly to become misaligned.

Adjustment of the flex lead assembly is a matter of positioning the assembly so that it is parallel with the travel of the carriage and coil. When the flex lead assembly is properly aligned, there is no buckling of the leads during extension and retraction of the carriage and coil assembly. Likewise, there is a parallel motion with the carriage, without evidence of the leads either riding up or down.

Removal-Replacement

There are no special procedures for the removal and replacement of the flex lead assembly. Perform the removal and replacement in accordance with the information in the parts data section.

Repair

No repair of the flex lead assembly is possible. If any of the parts are damaged or frail, the assembly must be replaced.

MAGNET ASSEMBLY

The magnet assembly and associated hardware is shown in figure 3-29.

Adjustment

The magnet assembly must be adjusted any time the mounting hardware securing the magnet to the deck is loosened.

The magnet assembly is properly adjusted when the coil slides through its complete travel without contacting the magnet assembly. Ensure that when the magnet assembly is secured to the deck, a 0.005 inch non-metallic feeler gauge passes between the coil and the magnet. The 0.005 inch clearance must be maintained at all points around the coil in the front opening of the magnet assembly. After securing the magnet to the deck, and before installing the velocity transducer, manually extend the heads and move the carriage and coil assembly back and forth through its full travel. There should be no rubbing or scraping sound and there should be no drag felt during this movement.

Removal-Replacement



WARNING

Due to weight of magnet assembly, use caution to prevent personal injury.

There are no special procedures for the removal and replacement of the magnet assembly. Perform the removal and replacement in accordance with the information in the parts data section.

Repair

Repair of the magnet assembly is limited to the removal and replacement of the velocity transducer assembly and for older units, the magnet rear carriage stop. For velocity transducer service information refer to the velocity transducer procedures. If the rear carriage stop should be damaged it must be replaced. See table 2-1 for adhesive used to secure the magnet stop.

HEAD ARM ASSEMBLIES

The head arm assemblies are shown in figure 3-25, sheet 1. In addition, the various parts involved in the removal and replacement of the head arms are identified in figures 2-32 and 2-33. Repair of the head arm assemblies is limited to inspection and cleaning, refer to the Repair paragraph for details and limits.

Adjustment

Adjustment of the head arm assemblies is covered in Section 2C, Test and Adjustment.




Figure 2-32. Head Replacement - Left Side View




Figure 2-33. Head Replacement - Right Side View

Removal-Replacement

The following procedure covers removal and replacement of either the servo head or the read/write heads. Remove heads from the carriage only to perform head inspection and cleaning, or as directed by other procedures in this manual. When removing the servo head also remove read/write head number two. This allows room for the head cable and connectors to pass between the adjacent head arms with a lessened chance of doing damage.

1. Remove connector support bracket or servo pre-amplifier shield and disconnect head arm connector for subject head (for servo head, also remove head cable from cable clip and disconnect tie point connector).
2. Remove head mounting screw and associated hardware.

3. Manually extend heads far enough to be able to grasp front of head arm from inside pack area.

CAUTION

Head pads and gimbal springs are extremely delicate and easily damaged. Grasp head arms carefully and only be edges of head arm. If head pad is touched, perform head cleaning procedure.

4. Carefully grasp subject head arm at front and also push gently on rear of head arm as shown in figure 2-32. Guide head arm and connector(s) through adjacent head arms and into pack area.
5. Perform required maintenance procedure.
6. Install head arm assembly by fully extending heads into pack area, and guiding head arm connector between adjacent head arms. Use care not to damage adjacent heads.
7. Seat head arm in both front and rear notches on carriage.
8. Carefully position head arm as required in order to insert head mounting screw. Support head arm from opposite side when inserting head mounting screw or forward pressure of wrench may dislodge head arm.
9. Ensure that head arm assembly is aligned in relation to remainder of heads where they protrude into pack area.
10. Tighten screw, securing head arm assembly to carriage, until torque is between 1.3 and 1.4 N·m (11.5 and 12.5 lbf·in).
11. Carefully reconnect head arm connector and replace related hardware removed in step 1.
12. Perform Head Arm Adjustment procedure.

Repair

The drive has a positive pressure filtration system that eliminates the need for periodic inspection and cleaning of heads. The heads should be inspected for the following reasons only:

1. A problem is traced to a specific head or heads; for example, excessive data errors.

2. Head to disk contact is suspected. This may be indicated by an audible ping, scratching noise, or a burning odor when the heads are over the disk area.
3. Concentric scratches are observed on the disk surfaces.
4. Contamination of pack is suspected (possibly due to improper storage of the pack).
5. The pack has been physically damaged (possibly due to dropping or bumping).

CAUTION

Do not attempt to operate the media on another drive until full assurance is made that no damage or contamination has occurred to the media.

Do not attempt to operate the drive with another media until full assurance is made that no damage or contamination has occurred to the drive heads or to the shroud area.

Head Inspection

CAUTION


Do not smoke when inspecting or cleaning heads. Use extreme care not to damage the head.

Do not touch the head pad or gimbal spring with fingers or tools.

If head must be laid down, do not allow the head pad or gimbal spring to touch anything.

Remove suspected head as described in the Read/Write Servo Head/Arm Replacement procedure. Referring to figure 2-34, observe the head/arm, and perform the suggested remedy as follows:

1. If reddish-brown oxide deposits exist on the head, replace or clean the head/arm assembly.
2. If head appears scratched, replace or clean the head/arm assembly.
3. If head appears damaged, replace the head/arm assembly.
4. If the gimbal spring (it holds the head pad to the arm) is bent or damaged, replace the head/arm assembly.



9H159

Figure 2-34. Typical Head/Arm Components

Head Cleaning

CAUTION

Head cleaning is a delicate procedure which is not recommended. It should not be undertaken unless it is absolutely necessary and then it should be performed by properly trained personnel only.

Refer to figure 2-35 if head cleaning is required and perform the following procedure. Use care not to damage any part of the head arm assembly.

CAUTION

In the following step, hold the can of dust remover upright (vertical). If the can is not held upright, liquid propellant will be sprayed on the head.

1. Use super dry dust remover (see list of Maintenance Tools and Materials) to blow off all loose particles from the head pad (flying surface), from the edge of the head pad, and from the holes in the head pad. Hold the nozzle 6 to 12 mm (1/4 to 1/2 in) from the head pad. Spray with a back and forth motion across the head pad, making certain to hold the can only in a vertical position.
2. Clean a smooth, flat working surface, for example, a glass or formica table top.




Figure 2-35. Head Cleaning Motion

3. Place a blank tab card (see list of Maintenance Tools and Materials) or a new, unpunched, clean computer card with the back side up (printing down) on the clean flat working surface as shown in figure 2-35.

CAUTION

Care should be taken to avoid excess cleaning solution. Excess solution on the head cable may remove the plasticizer and make the cable stiff. A stiff cable reduces the flexibility of the head pad and could cause broken wires.

4. Moisten a small area in the center of the card with head cleaning solution. (Refer to the list of Maintenance Tools and Materials.)

CAUTION

Inspect the head cleaning solution for contamination, rust, dirt, etc. Do not use contaminated solution.

5. Very carefully place the head pad flying surface on moistened area and move head pad from moistened area to dry area in a zig-zag motion as shown in figure 2-35. Move head in a direction away from curved end of head pad. If it is moved in the opposite direction the sharp edge of the curved end will cut into the computer card and prevent movement and proper cleaning.
6. Blow off the head again using the super dry dust remover as in step 1.

NOTE

Discoloration of head cleaning solution and tab card indicate that oxide particles are being removed from head pad flying surface.

7. Repeat steps 3, 4, 5 and 6 using a clean computer card and clean head cleaning solution each time until no discoloration on card is present.
8. After discoloration has ceased, inspect head to determine that oxide deposits were removed. If deposits remain but show signs of being removed repeat cleaning procedure until deposits are removed.
9. If oxide deposits cannot be removed, replace head/arm assembly.
10. If oxide deposits were removed and head passes inspection according to the Head/Arm Replacement Criteria, reinstall head.
11. Follow Read/Write or Servo/Head Arm Replacement procedure to install cleaned head or a replacement head as required.

Head/Arm Replacement Criteria

A head arm assembly requires replacement if any of the following conditions exist:

1. Consistent oxide buildup on the same head, indicating repeated head to disk contact.
2. Appreciable oxide buildup which cannot be removed.

3. Scratches on the head flying surface.
4. Imbedded particles in the head pad flying surface.
5. Bent or damaged gimbal spring.
6. Any apparent physical damage to head/arm assembly.

CABLE ASSEMBLIES (W1 THROUGH W4, W6, W11, W12)

Part numbers for all cable assemblies are listed on figure 3-22, sheet 1. Cable assemblies are not illustrated in their entirety; however, all connectors, pin, etc, are illustrated (and the part numbers given) at the point of origin or destination. This information is, therefore, spread throughout the parts data section.

Adjustment

Other than positioning the cable assemblies to provide proper strain relief, no adjustment of the cable assemblies is required.

Removal-Replacement

The cable assemblies rarely, if ever, need to be removed from the drive. However, during normal maintenance, it may be necessary to separate the cable from the item to which it is attached. The connectors on all cables in the drive may be removed directly, or simply by squeezing its locking devices. If a connector does not separate easily from its mating half, carefully insert a blunt tool between the two halves and gently pry them apart. Trying to exert excessive force, in the process of separating a connector, could cause damage to other components in the drive.

Repair

Repair of the various cable assemblies consists of replacing broken or damaged parts. All parts of the cable assemblies are called out in the parts data section. Some of the connections in the drive are crimp-type, and require the use of expensive tools. These connections can be repaired by first tinning the wires and then carefully crimping them into the pins with a pair of pliers. To ensure electrical and mechanical integrity of these connections, they should then be carefully reheated with a soldering iron to allow the solder to flow onto the pin.

SECTION 3

PARTS DATA

INTRODUCTION

This section provides an Illustrated Parts Breakdown and a Spare Parts List for all the storage module drives (SMDs) listed in the preface of this manual.

Information in this section is divided into two major categories as follows:

Illustrated Parts Breakdown - This breakdown provides part number information for all field replaceable items.

Spare Parts List - This is a list of recommended spare parts.

NOTE

Parts listed in the illustrated parts breakdown, but not in the spare parts list, may be long lead time items subject to significant delays.

SECTION 3A

ILLUSTRATED PARTS BREAKDOWN

GENERAL

The Illustrated Parts Breakdown (IPB) provides the information needed to order field replaceable parts. This information is presented in assembly illustrations and parts lists.

The symbols used in this section are explained in the following paragraphs along with a definition of some of the abbreviations used. Refer to the front of this manual for a complete list of abbreviations.

The illustrated parts breakdown is structured as follows. Each major assembly is shown in an exploded view and assigned a figure number. More than one illustration per figure number may be required for a complex assembly. In this case, the illustrations are titled Figure X (sheet 1); figure X (sheet 2), etc. The parts shown on the illustration are numbered. A parts list for each illustration begins on the page facing the illustration. The numbers on the figure correspond to the index numbers on the associated parts list. In some cases, the parts list will have more than one page for the corresponding sheet of a figure.

The Illustrated Parts Breakdown is divided into four columns:

Index Number Column - The numbers given in this column correspond to the numbers shown on the illustration. When more than one entry is given for a particular index number, the use of each part is defined in the Notes column. Items may be listed without index numbers, and are mentioned for reference only. These items do not appear on the illustration.

Part Number Column - This column provides the eight digit number by which a part may be ordered. There are several conditions when there will be an incomplete number or no number at all. In some cases the last two digits (referred to as tab numbers) may be shown as XX. This situation exists when an assembly changes tab numbers rapidly in the course of normal factory build. If it is necessary to order an assembly catalogued in this manner, the actual part number can be found

on the part number label attached to the assembly. If the actual part number cannot be determined, be sure to include on the order the series code of the machine and a listing of all the change orders installed. NFR in the part number column indicates that an assembly is not field replaceable. If repair of the NFR item is necessary, refer to the maintenance section of this manual for further information.

The symbol ## in the part number column indicates that the item is a recommended spare part, and that the part number is located in the Spare Parts List section. To find the part number refer to the instructions for using the Spare Parts List (section 3B).





Description Column - This column gives the name and a brief description of each part and assembly. The relationship of parts and assemblies is shown within the column by means of indentation. Each indented item is part of the previously listed item as a lesser indentation.

When the attaching hardware or associated parts for an item cannot be shown on the illustration, the note (ATTACHING PARTS) or (ASSOCIATED PARTS) appears in the Description column. All attaching/associated parts for the previously listed part or assembly are listed beneath this note and are separated from the rest of the parts list by the symbol ---*---.


When necessary, items are identified as being right side or left side. Right and left are determined by facing the front (pack end) of the drive.


Notes Column - This column defines multiple part number entries for a single index number. Multiple entries may be necessary to identify differences such as machine configuration (for example, whether the part is for a 50 Hz or 60 Hz unit) or to track history (for example, the part issued only on a series code 17 unit with Engineering Change Order (ECO) 48700 installed). Information that is unique to one particular equipment or application will also be noted in this column.

TABLE 3-1. COLOR CODE CHART

C O L O R C O D E	CASE 			PACK ACCESS COVER		FRONT DOOR		REAR DOOR		LEFT SIDE PANEL		RIGHT SIDE PANEL		TOP PANEL 		CASE DOOR 		FRONT PANELS PAINT-ED SET		CASE 		C O M M E N T S	
	ASSY TAB		PC PT TAB	ASSY TAB	PC PT TAB	ASSY TAB	PC PT TAB	ASSY TAB	PC PT TAB	ASSY TAB	PC PT TAB	ASSY TAB	PC PT TAB	ASSY TAB	PC PT TAB	ASSY TAB	PC PT TAB	ASSY TAB	PC PT TAB	ASSY TAB	PC PT TAB		
	*	+					**	++															
A	00	02	03	32	09	-	-	-	-	-	-	-	-	-	-	-	03	-	-	-	-	S/C 32 & BLW	
A	00	02	03	64	09	-	-	-	-	-	-	-	-	-	-	-	03	-	-	07	01	S/C 33 & ABV	
B	01	06	03	32	09	-	-	-	-	-	-	-	-	-	-	-	03	-	-	-	-	S/C 32 & BLW	
B	01	06	03	64	09	-	-	-	-	-	-	-	-	-	-	-	03	-	-	07	02	S/C 33 & ABV	
C	01	07	03	32	09	-	06	-	-	06	-	03	-	03	-	03	-	03	-	-	-	S/C 32 & BLW	
C	01	07	03	64	09	-	06	-	-	06	-	03	-	03	-	03	-	03	-	-	28	01	S/C 33 & ABV
D	01	09	03	31	09	-	-	05	18	09	-	-	-	-	-	-	03	-	02	20	00		
E	01	09	03	31	09	-	-	06	19	09	-	-	-	-	-	-	03	-	02	-	-		
F	01	23	03	31	09	01	09	05	18	09	02	03	03	03	-	-	-	-	-	78	01		
G	01	23	03	31	09	01	09	06	19	09	02	03	03	03	-	-	-	-	-	-	-		
H	02	08	36	42	36	-	36	-	-	37	-	37	-	37	-	36	-	-	-	-	-	S/C 32 & BLW	
H	02	08	36	74	36	-	36	-	-	37	-	37	-	37	-	36	-	-	-	-	-	S/C 33 & ABV	
J	04	10	72	45	71	-	71	-	-	71	-	72	-	72	-	72	-	-	-	-	-		
K	03	09	63	43	66	-	63	-	-	64	-	65	-	65	-	63	-	63	-	-	-	S/C 32 & BLW	
K	03	09	63	75	66	-	63	-	-	64	-	65	-	65	-	63	-	63	-	-	-	S/C 33 & ABV	
L	-	04	34	28	33	-	33	-	-	33	-	34	-	34	-	34	-	34	-	-	-	S/C 15 W/O 48576 & BLW	
L	-	01	03	28	33	-	33	-	-	33	-	03	-	03	-	03	-	03	-	-	-	S/C 15 S/C 16 W/48576	
L	01	07	03	44	33	-	33	-	-	33	-	03	-	03	-	03	-	03	-	-	-	S/C 17 - S/C 32	
																						(See Note *)	
L	01	07	03	76	33	-	33	-	-	33	-	03	-	03	-	03	-	03	-	-	-	S/C 33 & ABV	
M	-	11	34	18	33	05	33	-	29	33	10	34	11	34	-	-	-	-	-	-	-	S/C 15 W/O 48576 & BLW	
M	-	04	03	18	33	03	33	-	29	33	02	03	03	03	-	-	-	-	-	-	-	S/C 15,S/C 16 W/48576	

* W/55I55B ** S/C 40 & ABV
 + W/O 55I55B ++ S/C 39 & BLW

 Used on all 50 Hz
 S/C 48 & Blw 60 Hz





 S/C 49 & Abv 60 Hz

This color code chart, used in conjunction with the equipment configuration chart (see front of this manual) and the parts list, will provide the eight-digit number needed to order painted parts for all units covered by this manual.


KØR 0659-1A

First, determine the correct color code by referring to the equipment configuration chart. Then, find that code in the color code column of this chart. Following the code are the tab numbers for each painted part. If an entire assembly is being replaced, use the two digits listed under ASSY TAB. If just the piece part is needed use the two digits listed under PC PT TAB. In cases where only PC PT TAB number is listed, attaching parts must be ordered separately. The parts list contains the first six digits of each part number plus the symbol "***" (for example 775601**). The complete number is obtained by substituting the tab numbers in place of the symbol "***".

TABLE 3-1. COLOR CODE CHART

C O L O R C O D E	CASE 			PACK ACCESS COVER		FRONT DOOR		REAR DOOR			LEFT SIDE PANEL		RIGHT SIDE PANEL		TOP PANEL 		CASE DOOR 		FRONT PANELS PAINTED SET		CASE 		COMMENTS	
	* +	+	PC PT TAB	ASSY TAB	PC PT TAB	ASSY TAB	PC PT TAB	ASSY TAB	PC PT TAB	ASSY TAB	PC PT TAB	ASSY TAB	PC PT TAB	ASSY TAB	PC PT TAB	ASSY TAB	PC PT TAB	ASSY TAB	PC PT TAB	ASSY TAB	PC PT TAB	ASSY TAB		PC PT TAB
	M	01	23	03	35	33	05	33	08	21	33	02	03	03	03	-	-	-	-	-	-	78		01
N	-	06	34	18	33	-	-	-	21	33	-	-	-	-	-	-	-	-	-	-	-	-	S/C 15 W/O 48576 & BLW	
N	-	01	03	18	33	-	-	-	21	33	-	-	-	-	-	-	-	-	-	-	-	-	S/C 15,S/C 16 W/48576	
N	01	09	03	35	33	-	-	08	21	33	-	-	-	-	-	-	03	-	11	20	00	S/C 17 & ABV (See Note*)		
P	-	-	-	30	04	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
R	-	06	34	18	33	-	-	-	25	33	-	-	-	-	-	-	-	-	-	-	-	-	S/C 15 W/O 48576 & BLW	
R	01	09	03	18	35	-	-	12	25	33	-	-	-	-	-	-	-	-	-	-	-	-	S/C 15 & ABV W/ 48576 (See Note *)	
S	05	27	81	45	80	18	79	13	26	79	30	81	31	81	-	-	-	-	-	74	21			
T	04	15	81	45	80	-	-	13	26	79	-	-	-	-	-	-	81	-	18	25	08			
U	04	15	81	45	80	-	-	14	27	79	-	-	-	-	-	-	81	-	18	-	-			
V	06	13	74	49	73	-	74		74	-	74	-	74	-	74	-	74	-	-	-	-	-	S/C 32 & BLW	
V	06	13	74	80	73	-	74		74	-	74	-	74	-	74	-	74	-	-	30	13		S/C 33 & ABV	
W	07	15	85	51	85	-	85		84	-	84	-	84	-	84	-	85	-	-	-	-	-	S/C 32 & BLW	
W	07	15	85	81	85	-	85		84	-	84	-	84	-	84	-	85	-	-	31	15		S/C 33 & ABV	
X	-	19	73	26	73	15	74	-	47	74	26	74	27	74	-	-	-	-	-	-	-	-	S/C 21 & BLW W/O 55155B (See Note +)	
X	12	35	73	43	73	15	74	31	44	74	26	74	27	74	-	-	-	-	-	-	-	-	S/C 21 & ABV W/ 55155B (See Note *)	
Y	-	19	73	26	73	15	74	-	48	74	27	74	27	74	-	-	-	-	-	-	-	-	S/C 21 & BLW W/O 55155B (See Note +)	
Y	12	19	73	43	73	15	74	32	45	74	27	74	27	74	-	-	-	-	-	-	-	-	S/C 21 & ABV W/ 55155B (See Note *)	
Z	05	27	81	45	80	18	79	33	46	79	30	81	31	81	-	-	-	-	-	-	-	-		
AA	05	16	87	46	86	-	-	15	28	88	-	-	-	-	-	-	87	-	19	-	-	-		
AB	14	37	87	46	86	19	88	15	28	88	34	87	35	87	-	-	-	-	-	-	-	-		
AC	06	17	04	30	04	-	-	16	29	04	-	-	-	-	-	-	04	-	03	-	-	-		

* W/55155B **S/C 40 & ABV
 + W/O 55155B ++S/C 39 & BLW

 Used on all 50 Hz
 S/C 48 & Blw 60 Hz










 S/C 49 & Abv 60 Hz


TABLE 3-1. COLOR CODE CHART

C O L O R	C O D E	CASE 			PACK ACCESS COVER		FRONT DOOR		REAR DOOR		LEFT SIDE PANEL		RIGHT SIDE PANEL		TOP PANEL 		CASE DOOR 		FRONT PANELS PAINT-SET		CASE 		C O M M E N T S
		ASSY TAB		PC PT TAB	ASSY TAB	PC PT TAB	ASSY TAB	PC PT TAB	ASSY TAB	PC PT TAB	ASSY TAB	PC PT TAB	ASSY TAB	PC PT TAB	ASSY TAB	PC PT TAB	ASSY TAB	PC PT TAB	ASSY TAB	PC PT TAB	ASSY TAB	PC PT TAB	
		*	+					*	+														
AD	00	22	02	30	04	21	04	03	16	04	38	04	39	04	-	-	-	-	-	-	-	-	
AE	-	06	76	31	77	-	75			75	-	76	-	76	-	76	-	76	-	-	-	-	S/C 21 & BLW W/O
																							55155B (See Note +)
AE	05	11	76	47	77	-	75			75	-	76	-	76	-	76	-	76	-	-	-	-	S/C 21-S/C 32 (See Note *)
AE	05	11	76	79	77	-	75			75	-	76	-	76	-	76	-	76	-	-	29	14	S/C 33 & ABV
AF	16	39	91	48	92	22	92	36	49	92	40	91	41	91	-	-	-	-	-	-	-	-	
AG	16	39	91	48	92	22	92	37	50	92	40	91	41	91	-	-	-	-	-	-	-	-	
AH	00	02	03	53	03	-	-			-	-	-	-	-	-	-	03	-	-	-	-	-	S/C 32 & BLW
AH	00	02	03	83	03	-	-			-	-	-	-	-	-	-	03	-	-	-	-	-	S/C 33 & ABV
AJ	08	16	99	54	98	-	98			-	-	99	-	99	-	99	-	99	-	-	-	-	S/C 32 & BLW
AJ	08	16	99	84	98	-	98			99	-	99	-	99	-	99	-	99	-	-	32	16	S/C 33 & ABV
AK	10	09	05	86	02	-	03			05	-	00	-	00	-	05	-	05	-	-	34	02	
AL	23	-	00	54	-	28	-	38	51	-	48	-	49	-	-	-	-	-	-	-	53	10	
AM	-	-	-	32	09	-	-			-	-	-	-	-	-	-	-	-	-	-	-	-	S/C 32 & BLW
AM	-	-	-	64	09	-	-			-	-	-	-	-	-	-	-	-	-	-	-	-	S/C 33 & ABV
AN	01	-	03	56	06	30	06	-	52	06	02	03	03	03	-	-	-	-	-	-	-	-	S/C 39 & BLW
AN	49	-	24	75	26	50	25	39	-	23	88	25	89	25	-	-	-	-	-	-	68	20	S/C 40 - 51 
AP	01	-	03	56	06	30	06	-	53	06	02	03	03	03	-	-	-	-	-	-	-	-	S/C 39 & BLW
AP	49	-	24	75	26	50	25	40	-	23	88	25	89	25	-	-	-	-	-	-	-	-	S/C 40 - 51 
AR	02	-	96	58	09	-	-			-	-	-	-	-	-	-	96	-	-	-	-	-	S/C 32 & BLW
AR	02	-	96	88	09	-	-			-	-	-	-	-	-	-	96	-	-	-	06	01	S/C 33 & ABV
AS	26	-	17	57	03	32	13	24	37	05	54	15	55	14	-	-	-	-	-	-	-	-	S/C 41 & BLW
AS	26	-	17	78	03	32	13	24	37	05	54	15	55	14	-	-	-	-	-	-	64	16	S/C 42 & ABV
AT	27	-	17	58	03	33	13	25	38	05	56	15	57	14	-	-	-	-	-	-	-	-	S/C 41 & BLW
AT	27	-	17	78	03	33	13	25	38	05	56	15	57	14	-	-	-	-	-	-	-	-	S/C 42 & ABV
AU	10	-	10	57	03	-	-			-	-	-	-	-	-	-	12	-	07	-	-	-	S/C 41 & BLW
AU	10	-	10	78	03	-	-			-	-	-	-	-	-	-	12	-	07	23	06	-	S/C 42 & ABV
AV	10	-	10	58	03	-	-			-	-	-	-	-	-	-	12	-	07	-	-	-	S/C 41 & BLW

* W/55155B **S/C 40 & ABV
+ W/O 55155B ++S/C 39 & BLW

 Used on all 50 Hz
S/C 48 & Blw 60 Hz

 S/C 49 & Abv 60 Hz

 S/C 52 W/O DJ00660 & Blw.
For S/C 52 W/DJ00660 &
Abv, see color code DR.


 S/C 52 W/O DJ00660 & Blw. For S/C 52
W/DJ00660 & Abv, see color code DP.

TABLE 3-1. COLOR CODE CHART

C O L O R	C O D E	CASE \triangle		PACK ACCESS COVER		FRONT DOOR		REAR DOOR		LEFT SIDE PANEL		RIGHT SIDE PANEL		TOP PANEL \triangle		CASE DOOR \triangle		FRONT PAN- ELS PAINT- SET		CASE \triangle		C O M M E N T S		
		ASSY TAB	PC PT TAB	ASSY TAB	PC PT TAB	ASSY TAB	PC PT TAB	ASSY TAB	PC PT TAB	ASSY TAB	PC PT TAB	ASSY TAB	PC PT TAB	ASSY TAB	PC PT TAB	ASSY TAB	PC PT TAB	ASSY TAB	PC PT TAB	ASSY TAB	PC PT TAB		ASSY TAB	PC PT TAB
AV	10	-	10	78	03	-	-			-	-	-	-	-	-	-	12	-	07	-	-	S/C 42 & ABV		
AW	12	-	72	69	71	-	71			71	-	72	-	72	-	72	-	72	-	-	-	-	S/C 29 W/O 55925 & BLW	
AW	17	-	72	69	71	-	71			71	-	72	-	72	-	72	-	72	-	-	36	12	S/C 29 W/55925 & ABV	
AX	01	-	11	59	11	-	-			-	-	-	-	-	-	-	11	-	-	-	-	-	S/C 32 & BLW	
AX	02	-	00	89	11	-	-			-	-	-	-	-	-	-	02	-	-	06	00	-	S/C 33 & ABV	
AY	13	-	22	36	22	-	22			22	-	23	-	23	-	23	-	22	-	-	-	-	S/C 32 & BLW	
AY	13	-	22	13	22	-	22			22	-	23	-	23	-	22	-	22	-	-	-	-	S/C 33 & ABV	
AZ	09	-	45	40	46	-	45			44	-	44	-	44	-	45	-	45	-	-	-	-	S/C 32 & BLW	
AZ	09	-	45	72	46	-	45			44	-	44	-	44	-	45	-	45	-	-	37	00	S/C 33 & ABV	
BA	14	-	20	62	21	-	20			20	-	20	-	20	-	20	-	20	-	-	-	-	S/C 32 & BLW	
BA	18	-	00	92	00	-	00			00	-	00	-	00	-	00	-	00	-	-	-	-	S/C 33 & ABV	
BB	03	-	19	61	18	-	-			-	-	-	-	-	-	-	19	-	-	-	-	-	S/C 32 & BLW	
BB	03	-	19	91	18	-	-			-	-	-	-	-	-	-	19	-	-	-	-	-	S/C 33 & ABV	
BC	15	-	03	41	53	-	54			54	-	53	-	53	-	54	-	54	-	-	-	-	S/C 32 & BLW	
BC	15	-	03	73	53	-	54			54	-	53	-	53	-	54	-	54	-	-	-	-	S/C 33 & ABV	
BD	11	-	06	62	08	-	-	43	56	-	-	-	-	-	-	-	15	-	08	21	03	-		
BE	30	-	07	62	08	37	27	43	56	08	62	12	63	18	-	-	-	-	-	57	11	-		
BF	30	-	07	62	08	37	27	44	57	08	62	12	63	18	-	-	-	-	-	-	-	-		
BG	01	-	00	00	03	-	-			-	-	-	-	-	-	-	03	-	-	-	-	-		
BH	32	-	10	64	01	39	31	46	59	13	66	00	67	00	-	-	-	-	-	-	59	12		
BJ	32	-	10	64	01	39	31	47	60	13	66	00	67	00	-	-	-	-	-	-	-	-		
BK	12	-	07	64	01	-	-	46	59	13	-	-	-	-	-	-	16	-	00	22	04	-		
BL	12	-	07	64	01	-	-	47	60	13	-	-	-	-	-	-	16	-	00	-	-	-		
BM	33	-	12	65	14	40	11	48	61	14	68	09	69	09	-	-	-	-	-	61	14	-		
BN	33	-	36	65	14	40	11	49	62	14	68	09	69	09	-	-	-	-	-	-	-	-		
BP	03	-	96	94	95	-	-			-	-	-	-	-	-	-	96	-	-	-	-	-		
BR	40	-	96	66	95	42	95	50	63	95	72	96	73	96	-	-	-	-	-	-	-	-		
BS	09	-	09	55	20	-	-			-	-	-	-	-	-	-	09	-	06	-	-	-		
BT	24	-	18	55	20	29	20	22	35	02	50	18	51	12	-	-	-	-	-	65	17	-		

* W/55155B **S/C 40 & ABV
 + W/O 55155B ++S/C 39 & BLW

\triangle Used on all 50 Hz
 S/C 48 & Blw 60 Hz

\triangle S/C 49 & Abv 60 Hz

83322150 AR

TABLE 3-1. COLOR CODE CHART

C O L O R C O D E	CASE \triangle			PACK ACCESS COVER		FRONT DOOR		REAR DOOR			LEFT SIDE PANEL		RIGHT SIDE PANEL		TOP PANEL \triangle		CASE DOOR \triangle		FRONT PANELS PAINT-ED SET		CASE \triangle		C O M M E N T S
	ASSY TAB		PC PT TAB	ASSY TAB	PC PT TAB	ASSY TAB	PC PT TAB	ASSY TAB		PC PT TAB	ASSY TAB	PC PT TAB	ASSY TAB	PC PT TAB	ASSY TAB	PC PT TAB	ASSY TAB	PC PT TAB	ASSY TAB	PC PT TAB	ASSY TAB	PC PT TAB	
	*	+					**	++															
BU	24	-	18	55	20	29	20	23	36	02	50	18	51	12	-	-	-	-	-	-	-	-	
BV	41	-	14	67	04	43	08	51	64	17	74	07	75	15	-	-	-	-	-	-	-	-	
BW	42	-	16	68	18	44	03	52	65	16	76	06	77	05	-	-	-	-	-	-	-	-	
BX	44	-	13	70	16	46	07	54	67	18	80	16	81	07	-	-	-	-	-	-	-	62	09
BY	44	-	34	70	16	46	07	55	68	18	80	16	81	07	-	-	-	-	-	-	-	-	
BZ	46	-	21	71	19	47	24	56	69	19	82	22	83	22	-	-	-	-	-	-	-	66	13
CA	01	-	03	95	08	-	-	-	-	-	-	-	-	-	-	03	-	-	-	-	-	-	
CB	14	-	12	80	31	-	-	-	-	-	-	-	-	-	61	-	28	-	-	-	-	-	
CC	15	-	13	57	14	-	-	-	-	-	-	-	-	-	14	-	19	-	07	-	-		S/C 41 & BLW
CC	15	-	13	78	14	-	-	-	-	-	-	-	-	-	14	-	19	-	-	-	-	-	S/C 42 & ABV
CD	19	-	06	96	13	-	05	-	03	-	07	-	07	-	06	-	20	-	-	-	38	03	
CE	04	-	04	-	-	-	-	-	-	-	-	-	-	-	-	-	00	-	-	-	08	02	
CF	-	-	-	80	31	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
CG	20	-	07	77	14	-	07	-	07	-	23	-	23	-	23	-	07	-	-	-	39	04	
CH	48	-	23	74	25	49	23	58	22	86	24	87	24	-	-	-	-	-	-	-	67	14	
CJ	16	-	14	73	24	-	-	57	65	-	-	-	-	-	-	-	06	-	21	-	-	-	
CK	47	-	22	73	24	48	27	57	65	84	23	85	23	-	-	-	-	-	-	-	-	-	
CL	21	-	08	97	15	-	08	-	08	-	08	-	08	-	07	-	08	-	-	-	-	-	
CL	25	-	13	03	23	-	12	-	11	-	13	-	13	-	12	-	25	-	-	-	43	08	S/C 44 W/OJ00309 & BLW S/C 44 W/DJ00309 & ABV
CM	22	-	09	98	16	-	14	-	14	-	09	-	09	-	08	-	10	-	-	-	40	05	
CN	29	-	08	61	11	36	16	54	11	61	13	60	17	-	-	-	-	-	-	-	58	05	
CP	15	-	20	47	21	20	21	48	21	36	20	37	20	-	-	-	-	-	-	-	-	-	
CR	01	-	03	77	28	52	28	75	25	02	03	03	03	-	-	-	-	-	-	-	55	02	
CS	23	-	10	99	17	-	09	-	02	-	10	-	10	-	09	-	21	-	-	-	41	06	
CT	04	-	02	01	19	-	-	-	-	-	-	-	-	-	-	-	23	-	-	-	05	00	
CU	24	-	12	02	20	-	11	-	09	-	12	-	12	-	10	-	24	-	-	-	42	07	
CV	16	-	02	93	07	-	04	-	04	-	04	-	04	-	02	-	13	-	-	-	-	-	S/C 45 & BLW
CV	26	-	14	04	27	-	13	-	12	-	14	-	14	-	13	-	27	-	-	-	48	18	S/C 46 & ABV
CW	26	-	14	04	27	-	13	-	12	-	14	-	14	-	13	-	29	-	-	-	-	-	

* W/55155B ** S/C 40 & Abv
 + W/O 55155B ++ S/C 39 & Blw

\triangle Used on all 50 Hz
 S/C 48 & Blw 60 Hz


\triangle S/C 49 & Abv 60 Hz

TABLE 3-1. COLOR CODE CHART

C O L O R	C O D E	CASE Δ		PACK ACCESS COVER		FRONT DOOR		REAR DOOR		LEFT SIDE PANEL		RIGHT SIDE PANEL		TOP PANEL Δ		CASE DOOR Δ		FRONT PANELS PAINTED SET		CASE Δ		C O M M E N T S	
		ASSY TAB	PC PT TAB	ASSY TAB	PC PT TAB	ASSY TAB	PC PT TAB	ASSY TAB	PC PT TAB	ASSY TAB	PC PT TAB	ASSY TAB	PC PT TAB	ASSY TAB	PC PT TAB	ASSY TAB	PC PT TAB	ASSY TAB	PC PT TAB	ASSY TAB	PC PT TAB		
CY		05	05	07	29	-	-	-	-	-	-	-	-	-	-	29	-	-	-	-	-		
CZ		27	15	07	29	-	15	-	13	-	15	-	15	-	14	-	29	-	-	-	-	-	
DA		09	45	85	46	-	45	-	44	-	44	-	44	-	44	-	45	-	-	33	11		
DB		46	16	09	31	-	17	-	16	-	16	-	16	-	15	-	31	-	-	-	-		
DC		76	28	81	34	54	34	65	28	96	*30	97	30	-	-	-	-	-	-	-	-		
DD		19	17	81	34	-	-	65	28	-	-	-	-	-	-	30	-	23	-	-	-		
DE		-	-	09	31	-	17	-	16	-	16	-	16	-	-	-	-	-	-	47	17		
DF		-	-	08	30	-	16	-	15	-	03	-	03	-	-	-	-	-	-	28	01		
DG		10	07	11	34	-	-	-	-	-	-	-	-	-	-	33	-	-	-	-	-		
DH		09	00	11	34	-	-	-	-	-	-	-	-	-	-	33	-	-	-	-	-		
DJ		87	30	82	35	56	37	67	31	00	33	01	33	-	-	-	-	-	-	-	-		
DK		28	19	82	35	-	-	67	31	-	-	-	-	-	-	33	-	25	-	-	-		
DL		11	07	12	35	-	-	-	-	-	-	-	-	-	-	34	-	-	10	04			
DM		50	17	12	35	-	18	-	17	-	17	-	17	-	16	-	34	-	-	49	09		
DN		01	03	00	09	00	09	00	09	02	03	03	03	-	-	-	-	-	-	-	-		
DP		49	24	75	26	58	40	70	35	88	25	89	25	-	-	-	-	-	-	68	20		
DR		49	24	75	26	58	40	69	35	88	25	89	25	-	-	-	-	-	-	-	-		

Δ All 50 Hz
60 Hz S/C 48 & Blw

Δ 60 Hz S/C 49 & Abv



14-108(1)A

Figure 3-1. Final Assembly (Sheet 1 of 2)

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-1		FINAL ASSEMBLY (Sheet 1 of 2)	
1		FINAL ASSEMBLY, Pedestal (See Figure 3-2)	To dotted line 60 Hz S/C 48 & Blw plus all 50 Hz units.
2		FINAL ASSEMBLY, 30 inch Rack Mount (See Figure 3-5)	
2		FINAL ASSEMBLY, 36 inch Rack Mount (See Figure 3-6)	
3		FINAL ASSEMBLY, Acoustic Cabinet (See Figure 3-3)	
4		FINAL ASSEMBLY, Acoustic Drawer (See Figure 3-4)	





Figure 3-1. Final Assembly (Sheet 2)

INDEX NO	PART NO	PART DESCRIPTION	NOTE
-------------	------------	------------------	------

3-1		FINAL ASSEMBLY (Sheet 2)	
1		FINAL ASSEMBLY, Universal Cabinet (See Figure 3-6)	
2		FINAL ASSEMBLY, Nude (See Figure 3-7)	
3		FINAL ASSEMBLY, Basic (See Figure 3-22)	



14-200(1)D

Figure 3-2. Final Assembly - Pedestal (Sheet 1 of 2)

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-2		FINAL ASSEMBLY, Pedestal (Sheet 1 of 2)	
1		CASE ASSEMBLY, Pedestal (See Figure 3-8)	
2	76419100	SPACER, Pack Cover	S/C 32 & Blw
2	75174202	WASHER, Slide	S/C 33 & Abv
3	41274008	BEARING, Flanged	S/C 32 & Blw
3	76429600	BUSHING, Pack Cover	S/C 33 & Abv
4	75070000	HINGE, Pin	Right Side, S/C 32 & Blw
4	75070002	HINGE, Pin	Right Side, S/C 33 & Abv
4	75070001	HINGE, Pin (Not Shown)	Left Side, S/C 32 & Blw
4	75070003	HINGE, Pin (Not Shown)	Left Side, S/C 33 & Abv
5	10125714	SCREW, Flat Head, 6-32 x 3/8	
5	10127176	SCREW, Pan Head, 6-32 x 7/16	Attaches Left Side Nut Plate
6		DRIVE ELECTRONICS (See Figure 3-22)	
7	75173306	PLATE, Nut	
7	83243200	PLATE, Nut Bracket (Not Shown)	
8	10127147	SCREW, Pan Head Machine, 10-32 x 1	
9	93109282	SPACER, Stand Off	
10		PACK ACCESS COVER ASSEMBLY, Non-acoustic (See Figure 3-14)	
11	92033221	RING, Retaining	
12	75071700	PIN, Cover Pivot	
13		SPRING, Gas (See Deck Assembly, Sheet 6, For Part Number)	
14	10126403	WASHER, External Tooth Lock, #10	




Figure 3-2. Final Assembly - Pedestal (Sheet 2)

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-2		FINAL ASSEMBLY, Pedestal (Sheet 2)	
	47308701	FRAME ASSEMBLY	All 50 Hz. 60 Hz S/C 48 & Blw
	47308703	FRAME ASSEMBLY	60 Hz S/C 49 & Abv
1	10127131	SCREW, Pan Head Machine, 10-24 x 3/8	
2	10126403	WASHER, External Tooth Lock, #10	
3	94369530	CABLE, Ground	
4	92151017	SCREW, Hex Head, 5/16-18 x 5/8	
5	10125807	WASHER, Spring Lock, 5/16	
6	92703015	CASTER	
7	10127121	SCREW, Pan Head Machine, 8-32 x 5/16	
8	10126402	WASHER, External Tooth Lock, #8	
9	76418400	HINGE, Lower Door	
10	47297800	FRAME, Base	All 50 Hz. 60 Hz S/C 48 & Blw
10	92575000	FRAME, Base	60 Hz S/C 49 & Abv
11	10125606	WASHER, Flat, #8	
12	75074800	KEEPER, Latch	
13	16345307	RIVET	
14	93325001	CATCH, Spring	
15	75074900	HINGE, Upper Door	
16	94374903	STRIP, Contact	60 Hz S/C 49 & Abv only
17		FRONT AND REAR DOOR, Nonacoustic (See Figure 3-16)	
18	94274140	TERMINAL, Quick Connect	
19		SIDE PANEL ASSEMBLY, Nonacoustic (See Figure 3-20)	
20	93697013	LEVELER	
21	10125303	NUT, Hex, 3/8-16	
22	93847001	BEARING, Flanged	
23	765160**	PANEL, Top	All 50 Hz. 60 Hz S/C 48 & Blw only
24	93326004	STUD, Ball	
25	10125607	WASHER, Flat, #10	




Figure 3-2. Final Assembly - Pedestal (Sheet 3)

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-2		FINAL ASSEMBLY, Pedestal (Sheet 3)	
		FRAME ASSEMBLY	
1	81567790	BRACKET, Strain Relief Ground	60 Hz S/C 49 & Abv & only
2	10126403	WASHER, External Tooth Lock, #10	
3	10127142	SCREW, Pan Head Machine, 10-32 x 3/8	
4	81567760	CLAMP, Shielded Cable	
5	10127145	SCREW, Pan Head Machine, 10-32 x 3/4	
6	81567761	CLAMP, Shielded Cable	




Figure 3-3. Final Assembly - Acoustic Cabinet (Sheet 1 of 4)

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-3		FINAL ASSEMBLY, Acoustic Cabinet (Sheet 1 of 4)	
1		CASE ASSEMBLY, Acoustic Cabinet (See Figure 3-9)	
2	76429600	BEARING, Flanged	
3	77560300	PIVOT, Cover Pin	Right Side
3	77560200	PIVOT, Cover Pin (Not Shown)	Left Side
4	92958206	SCREW, Flat Head, 8-32 x 7/16	
5	75173315	PLATE, Nut	Right Side
5	77560400	PLATE, Nut (Not Shown)	Left Side
6		DRIVE ELECTRONICS (See Figure 3-22)	
7	10127143	SCREW, Pan Head Machine, 10-32 x 1/2	
8	10125805	WASHER, Spring Lock, #10	
9	10125607	WASHER, Flat, #10	
10		PACK ACCESS COVER, Acoustic (See Figure 3-15)	
11	92033221	RING, Retaining	
12	75071700	PIN, Cover Pivot	
13		SPRING, Gas (See Deck Assembly Sheet 6, For Part Number)	
14	76419100	SPACER, Pack Cover	




Figure 3-3. Final Assembly - Acoustic Cabinet (Sheet 2)

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-3		FINAL ASSEMBLY, Acoustic Cabinet (Sheet 2)	
1		REAR DOOR ASSEMBLY, Acoustic Cabinet (See Figure 3-18)	
2	10125106	NUT, Hex, 8-32	
3	10126402	WASHER, External Tooth Lock, #8	
4	10125606	WASHER, Flat, #8	
5	92602002	CLAMP, Nylon Cable	S/C 41 & Blw
5	92602003	CLAMP, Nylon Cable	S/C 42 & Abv
6	94281494	CABLE, Ground	
7	94274105	TERMINAL, Quick Connect	
8	10126403	WASHER, External Tooth Lock, #10	
9	93592428	SCREW, Hex Head, 10-32 x 3/8	
10		SIDE PANEL ASSEMBLY, Acoustic (See Figure 3-21)	
11		FRONT DOOR ASSEMBLY, Acoustic (See Figure 3-17)	
	77563200	FRAME ASSEMBLY	S/C 21 W/O 55155B & Blw
	472914XX	FRAME ASSEMBLY	S/C 21 W/55155B & Abv
12	77561600	HINGE, Lower Front Door	
13	10125747	SCREW, Flat Head, 10-32 x 1/2	
14	10127142	SCREW, Pan Head Machine, 10-32 x 3/8	
15	10126105	WASHER, Internal Tooth Lock, #10	
16	77561700	HINGE, Door	
17	76428300	HINGE, Top	
18	92373004	NYLINER, Snap In	
19	70948500	PIN, Hinge	
20	10125804	WASHER, Spring Lock, #8	






Figure 3-3. Final Assembly - Acoustic Cabinet (Sheet 3)

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-3		FINAL ASSEMBLY, Acoustic Cabinet (Sheet 3)	Unless Otherwise Noted All Parts And Assemblies Listed Here Are Common To Both The Acoustic Cabinet And The Acoustic Drawer.
		FRAME ASSEMBLY (See Sheet 2 for Additional Frame Information)	
1	92602002	CLAMP, Nylon Cable	S/C 41 & Blw
1	92602003	CLAMP, Nylon Cable	S/C 42 & Abv
2	10125106	NUT, Hex, 8-32	
3	10126402	WASHER, External Tooth Lock, #8	
4	94281494	CABLE, Ground	
5	83285600	FRAME, Main	50/60 Hz S/C 21 W/O 55155B & Blw
5	47291200	FRAME, Main	50 Hz S/C 21 W/ 55155B & Abv. 60 Hz S/C 21-48 W/ 55155B
5	92300600	FRAME, Main	60 Hz S/C 49 & Abv
6	10126501	SCREW, Hex Head, 1/4-20 x 5/8	
7	10125806	WASHER, Spring Lock, 1/4	
8	10125608	WASHER, Flat, 1/4	
9	75007400	BRACKET, Side Panel	
10	94237703	TRIM, Black Safety	
11	41282100	CLIP, Safety Trim	
12	76429302	SEAL, Acoustical	
13	76429300	SEAL, Acoustical	
14	10125302	NUT, Hex, 5/16-18	
15	10125807	WASHER, Spring Lock, 5/16	
16	92703005	CASTER	
17	93697021	LEVELER	
18	10125747	SCREW, Flat Head, 10-32 x 1/2	
19	77561800	KEEPER, Latch	
20	10125607	WASHER, Flat, #10	

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-3		FINAL ASSEMBLY, Acoustic (Sheet 3 Contd)	
21	10126105	WASHER, Internal Tooth Lock, #10	
22	10125108	NUT, Hex, 10-32	
23	75007300	BRACKET, Panel	
24	76429301	SEAL, Acoustical	
25	##	FILTER, Aluminum	
26	93993001	EXTRUSION, Rubber	
27	40029500	BRACKET, Stud	
28	10125062	SCREW, Hex Head, 10-32 x 1/2	
29	75031800	PLATE, Nut	
30	93573004	STUD ASSEMBLY (ATTACHING PARTS)	
	93571002	GROMMET	
	93572001	RING, Snap	
		- - - * - - -	
31	76428400	LATCH, Door	
32	92008601	LATCH, Slide Bolt	S/C 21 W/55155B & Abv only
33	75173313	PLATE, Nut	
34	10127142	SCREW, Pan Head Machine, 10-32 x 3/8	
35	10126403	WASHER, External Tooth Lock, #10	
36	73029700	BRACKET, Mounting Latch	
37	93573004	STUD ASSEMBLY, (ATTACHING PARTS)) S/C 21 W/O) 55155B & Blw) only
	93571002	GROMMET)
	93572001	RING, Snap)
		- - - * - - -	
38	11060828	GASKET, RFI)
39	81567700	GASKET, Side Angle)
39	81567730	GASKET, End Angle (Not Shown)) 60 HZ S/C 49) & Abv only
40	93592570	SCREW, Hex Head Machine, 8-32 x 3/8))

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-3		FINAL ASSEMBLY, Acoustic Cabinet (Sheet 3 Contd)	
41	94355602	FASTENER, Quarter Turn Receptacle (ASSOCIATED PARTS)	Note 1
	10125903	SCREW, Flat Head, 4-40 x 3/4	
	94355603	FASTENER, Quarter Turn Spacer	
	10125603	WASHER, Flat, #4	
	10125801	WASHER, Spring Lock, #4	
	10125103	NUT, Hex, 4-40 - - - * - - -	
42	83268200	BRACKET, Rear Lock	Note 1
43	83287000	BRACKET, Front Lock	Note 1

NOTE 1: BK5A9R/S S/C 52 W/
DJ00660 & Above only




14-302(4)C

Figure 3-3. Final Assembly - Acoustic Cabinet (Sheet 4)

INDEX NO	PART NO	PART DESCRIPTION	NOTE
-------------	------------	------------------	------


3-3		FINAL ASSEMBLY, Acoustic (Sheet 4)	
		FRAME ASSEMBLY	
1	10126403	WASHER, External Tooth Lock, #10	
2	10127142	SCREW, Pan Head Machine, 10-32 x 3/8	
3	81567790	BRACKET, Strain Relief & Ground	
4	10127145	SCREW, Pan Head Machine, 10-32 x 3/4	
5	81567761	CLAMP, Shielded Cable	
6	81567760	CLAMP, Shielded Cable	
7	81914010	BRACKET, Mounting	
8	10127123	SCREW, Pan Head Machine, 8-32 x 1/2	
9	10126402	WASHER, External Tooth Lock, #8	
10	10126105	WASHER, Internal Tooth Lock, #10	
11	10125107	NUT, Hex, 10-24	
12	82391130	CABLE ASSEMBLY	
13	10126104	WASHER, Internal Tooth, #8	
14	10125108	NUT, Hex, 10-32	
15	10125607	WASHER, Flat, #10	
16	82391140	STRAIN RELIEF	
17	10125606	WASHER, Plain, #8	
18	92027190	BAR, Strain Relief Mounting	



14-400(1)D

Figure 3-4. Final Assembly - Acoustic Drawer (Sheet 1 of 2)


INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-4		FINAL ASSEMBLY, Acoustic Drawer (Sheet 1 of 2)	
1		REAR DOOR ASSEMBLY, Acoustic Drawer (See Figure 3-19)	
2	10126402	WASHER, External Tooth Lock, #8	
3	10125106	NUT, Hex, 8-32	
4	10125606	WASHER, Flat, #8	
5	92602002	CLAMP, Nylon Cable	S/C 41 & Blw
5	92602003	CLAMP, Nylon Cable	S/C 42 & Abv
6	10126244	SCREW, Socket Hex Head, 10-32 x 3/8	
7	10126105	WASHER, Internal Tooth Lock, #10	
8	10125608	WASHER, Flat, 1/4	
9	10126502	SCREW, Hex Head, 1/4-20 x 3/4	
10	10125806	WASHER, Spring Lock, 1/4	
11	94393001	SLIDE	Right Side
11	94393000	SLIDE (Not Shown)	Left Side
12		PLATE, Nut	Supplied As Part Of Slide
13	77563300	BALLAST	
14	10125746	SCREW, Flat Head, 10-32 x 3/8	
15	76422600	WASHER, Special	
16	836638**	PANEL, Front Painted Set	
17	76428100	KEEPER LATCH	
18	10127143	SCREW, Pan Head, 10-32 x 1/2	
19	10127122	SCREW, Pan Head, 8-32 x 3/8	
20		CABLE GROUND (See Final Assembly Acoustic Cabinet for P/N)	
21		FRAME (See Final Assembly Acoustic Cabinet for P/N)	
22	10127121	SCREW, Pan Head, 8-32 x 5/16	
	94386402	MOUNT, Cable) All 50 Hz.
	94386407	MOUNT, Cable) 60 Hz S/C 48) & Blw only)
	94277424	STRAP, Cable Tie	Secures A Cable
	77523505	STRAP, Cable	on base of frame
	82377300	CLAMP	
	93154110	TUBING, Heat Shrink	
23	10125804	WASHER, Spring Lock, #8	



14-400(2)D

Figure 3-4. Final Assembly - Acoustic Drawer (Sheet 2)

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-4		FINAL ASSEMBLY, Acoustic Drawer (Sheet 2)	
1		CASE ASSEMBLY, Acoustic Drawer (See Figure 3-10)	
2	76429600	BEARING, Flanged	
3	77560300	PIVOT, Cover Pin	Right Side
3	77560200	PIVOT, Cover Pin (Not Shown)	Left Side
4	92958206	SCREW, Flat Head, 8-32 x 7/16	
5	75173315	PLATE, Nut	Right Side
5	77560400	PLATE, Nut (Not Shown)	Left Side
6		DRIVE ELECTRONICS (See Figure 3-22)	
7		PACK ACCESS COVER ASSEMBLY, Acoustic (See Figure 3-15)	
8	92033221	RING, Retaining	
9	75071700	PIN, Cover Pivot	
10		SPRING, Gas (See Deck Assembly Sheet 6, For Part Number)	
11	76419100	SPACER, Pack Cover	



14-500D

Figure 3-5. Final Assembly - 30 Inch Rack Mount

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-5		FINAL ASSEMBLY, 30 Inch Rack Mount	
1		CASE ASSEMBLY, 30 Inch Rack Mount (See Figure 3-11)	
2		PACK ACCESS COVER ASSEMBLY, Nonacoustic (See Figure 3-14)	
3	10125714	SCREW, Flat Head, 6-32 x 3/8	
3	10127176	SCREW, Pan Head, 6-32 x 7/16	Attaches Left Side Nut Plate
4	75070000	HINGE, Pin	Right Side, S/C 32 & Blw
4	75050002	HINGE, Pin	Right Side, S/C 33 & Abv
4	75070001	HINGE, Pin (Not Shown)	Left Side, S/C 32 & Blw
4	75070003	HINGE, Pin (Not Shown)	Left Side, S/C 33 & Abv
5	41274008	BEARING, Flanged	S/C 32 & Blw
5	76429600	BUSHING, Pack Cover	S/C 33 & Abv
6	76419100	SPACER, Pack Cover	S/C 32 & Blw
6	75174202	WASHER, Slide	S/C 33 & Abv
7	75173306	PLATE, Nut	
7	83243200	PLATE, Nut (Not Shown)	
8		DRIVE ELECTRONICS (See Figure 3-22)	
9	75071700 77569501	PIN, Cover Pivot SLIDE ASSEMBLY	Not applicable when customer provides their own
10	10126105	WASHER, Internal Tooth Lock, #10	
11	10125062	SCREW, Pan Head Machine, 10-32 x 3/8	
12	94383601	SLIDE	Right Side
13	94383600	SLIDE	Left Side
14		PLATE, Nut	Supplied As Part Of Slide
15	10125746	SCREW, Flat Head, 10-32 x 3/8	
16	76422600	WASHER, Special	
17	10125931	SCREW, Flat Head, 10-32 x 7/16	
18	77564700	KEEPER, Latch	
19		SPRING, Gas (See Deck Assembly Sheet 6 For Part Number)	
20	92033221	RING, Retaining	





Figure 3-6. Final Assembly - 36 Inch Rack Mount

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-6		FINAL ASSEMBLY, 36 Inch Rack Mount	
3-6		FINAL ASSEMBLY, Universal Cabinet	
1		CASE ASSEMBLY, 36 Inch Rack Mount (See Figure 3-12)	
1		CASE ASSEMBLY, Universal Cabinet (See Figure 3-13)	
2		PACK ACCESS COVER ASSEMBLY, Nonacoustic/Universal (See Figure 3-14)	
3	10125714	SCREW, Flat Head, 6-32 x 3/8	
3	10127176	SCREW, Pan Head, 6-32 x 7/16	Attaches Left Side Nut Plate
4	75070000	HINGE, Pin	Right Side, S/C 32 & Blw
4	75070002	HINGE, Pin	Right Side, S/C 33 & Abv
4	75070001	HINGE, Pin (Not Shown)	Left Side, S/C 32 & Blw
4	75070003	HINGE, Pin (Not Shown)	Left Side, S/C 33 & Abv
5	41274008	BEARING, Flanged	S/C 32 & Blw
5	76429600	BUSHING, Pack Cover	S/C 33 & Abv
6	76419100	SPACER, Pack Access Cover	S/C 32 & Blw
6	75174202	WASHER, Slide	S/C 33 & Abv
7	75173306	PLATE, Nut	
7	83243200	PLATE, Nut (Not Shown)	
8		SPRING, Gas (See Deck Assembly, Sheet 6 for Part Number)	
	77569500	SLIDE ASSEMBLY	All units except BK5A1G/H
	77569502	SLIDE ASSEMBLY	BK5A1G/H only
9	10125062	SCREW, Hex Head Machine, 10-32 x 1/2	All units except BK5A1G/H
9	10127142	SCREW, Pan Head Machine, 10-32 x 3/8	BK5A1G/H only
10	10126105	WASHER, Internal Tooth Lock, #10	
11	92633003	BUMPER, Grommet	
12	10125746	SCREW, Flat Head, 10-32 x 3/8	

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-6		FINAL ASSEMBLY, 36 Inch Rack Mount (Contd)	
13	10125747	SCREW, Flat Head, 10-32 x 1/2	
14	76030900	KEEPER, Pin	
14A	73052000	KEEPER, Latch	Right side; BK5A1G/H only
14B	73052100	KEEPER, Latch (not shown)	Left side; BK5A1G/H only
15	94393001	SLIDE	Right Side
15	94383600	SLIDE	Left Side; BK5A1G/H only
16	94393000	SLIDE	Left Side
16	94383601	SLIDE	Right Side; BK5A1G/H only
	77569502	SLIDE ASSEMBLY	BK5A1G/H only
17		PLATE, Nut	Supplied as Part Of Slide
18	76422600	WASHER, Special	
18A	10125607	WASHER, Flat, #10	BK5A1G/H only
18B	10125108	NUT, Hex, 10-32	BK5A1G/H only
18C	10127144	SCREW, Pan Head Machine, 10-32 x 5/8	BK5A1G/H only
19	75071700	PIN, Cover Pivot	
20		DRIVE ELECTRONICS (See Figure 3-22)	
21	92033221	RING, Retaining	



14-3500C

Figure 3-7. Final Assembly - Nude

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-7		FINAL ASSEMBLY, Nude	
1	76429600	BEARING, Flanged	
2	76419100	SPACER, Pack Cover	
3	77560300	PIVOT, Cover Pin	
3	77560200	PIVOT, Cover Pin (Not Shown)	
4	92958206	SCREW, Flat Head Machine, 8-32 x 7/16	
5	75173307	PLATE, Nut	
5	77560400	PLATE, Nut (Not Shown)	
6		DRIVE ELECTRONICS (See Figure 3-22)	
7		PACK ACCESS COVER, Acoustic (See Figure 3-15)	
8	92033221	RING, Retaining	
9	75071700	PIN, Cover Pivot	
10		SPRING, Gas (See Deck Assembly Sheet 6, For Part Number)	




Figure 3-8. Case Assembly - Pedestal (Sheet 1 of 2)

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-8	472021**	CASE ASSEMBLY, Pedestal (Sheet 1 of 2)	S/C 21 W/O 55155B & Blw
3-8	472901**	CASE ASSEMBLY, Pedestal	S/C 21 W/55155B & Abv
1	473691**	DOOR, Case	All 50 Hz. 60 Hz S/C 48 & Blw only
2	474540**	CASE, Top	All 50 Hz. 60 Hz S/C 48 & Blw only
2	805330**	CASE, Top	
3	10125106	NUT, Hex, 8-32	
4	10125804	WASHER, Spring Lock, #8	
5	10125606	WASHER, Flat, #8	
6	75257700	RETAINER, Filter	
7	##	FILTER, Air	
8	92628413	TAPE, Foam	
9	93826236	SCREW, Self-Locking Pan Head, 10-32 x 3/8	
10	76427601	ARM, Case Support	
11	75062400	WASHER, Insulator	
12	92033037	RING, Retaining	
13	46819300	SPRING, Extension	
14	75065200	PIN, Case Pivot	
15	93530021	PIN, Roll	
16	92628302	TAPE, Black Adhesive Back	
17	10126402	WASHER, External Tooth Lock, #8	
18	94274105	TERMINAL, Quick Connect	
19	75040479	PANEL, Acoustical Foam (Left Side)	S/C 21 W/O 55155B & Blw
19	47291100	PANEL, Acoustical Foam (Left Side)	50 Hz S/C 21 W/55155B & Abv. 60 Hz S/C 21-48 W/55155B
19	75040480	PANEL, Acoustical Foam (Right Side - Not Shown)	S/C 21 W/O 55155B & Blw
19	47291101	PANEL, Acoustical Foam (Right Side - Not Shown)	50 Hz S/C 21 W/55155B & Abv. 60 Hz S/C 21-48 W/55155B

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-8		CASE ASSEMBLY, Pedestal (Sheet 1 Contd)	
20	76429332	SEAL, Acoustical	
21	75040426	PANEL, Acoustical Foam	All 50 Hz. 60 Hz S/C 48 & Blw
22	10127113	SCREW, Pan Head Machine, 6-32 x 3/8	
23	10126103	WASHER, Internal Tooth Lock, #6	
24	10125714	SCREW, Flat Head, 6-32 x 3/8	S/C 21 W/O 55155B & Blw
24	10125716	SCREW, Flat Head, 6-32 x 5/8	S/C 21 W/55155B & Abv
25	47198100	CLIP, Case	
26	47175200	LATCH, Case (Left Side)	S/C 21 W/O 55155B & Blw
26	47175201	LATCH, Case (Right Side - Not Shown)	S/C 21 W/O 55155B & Blw
27	47195300	SPACER, Latch	S/C 21 W/O 55155B & Blw
28	47195500	SPRING, Torsion	S/C 21 W/O 55155B & Blw
29	75257301	SCREW, Modified	
30	10126105	WASHER, Internal Tooth Lock, #10	
31	92373001	NYLINER, Snap In	
32	15000601	EMBLEM, 97xxSMD Product Identification	The part numbers listed are for standard CDC emblems only.
33	94365001	EMBLEM, CDC Exterior Identification	
34	92097031	SCREW, Nylon Socket Head, 10-32)) 50 Hz S/C 21
35	10125805	WASHER, Lock Spring, #10) W/55155B &
36	10125607	WASHER, Flat, #10) Abv. 60 Hz
37	82337200	LATCH, Case) S/C 21-48 W/
38	93790156	SCREW, Self Locking Pan Head Machine, 6-32 x 3/16) 55155B)





Figure 3-8. Case Assembly - Pedestal (Sheet 2)

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-8		CASE ASSEMBLY, Pedestal (Sheet 2)	60 Hz S/C 49 & Abv
1	82337201	LATCH, Case	
2	92453400	ARM, Case Latch	
3	92097031	SCREW, Nylon Socket Head, 10-32	
4	10125805	WASHER, Spring Lock, #10	
5	10125607	WASHER, Flat, #10	
6	93790156	SCREW, Self Locking Pan Head Machine, 6-32 x 3/16	
7	10125716	SCREW, Flat Head, 6-32 x 5/8	
8	41798100	CLIP, Case	
9	92628302	TAPE, Black Adhesive Back	
10	93530021	PIN, Roll	
11	75065200	PIN, Case Pivot	
12	93826236	SCREW, Self Locking Pan Head, 10-32 x 3/8	
13	75062400	WASHER, Insulator	
14	76427601	ARM, Case Support	
15	75257700	RETAINER, Filter	
16	10125106	NUT, Hex, 8-32	
17	10125804	WASHER, Spring Lock, #8	
18	10125606	WASHER, Flat, #8	
19	##	FILTER, Air	
20	92628413	TAPE, Foam	

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-8		CASE ASSEMBLY, Pedestal (Sheet 2 Contd)	
21	10126402	WASHER, External Tooth Lock, #8	
22	94274105	TERMINAL, Quick Connect	
23	92033037	RING, Retaining	
24	46819300	SPRING, Extension	
25	805330**	CASE, Top	
26	15000601	EMBLEM, 97xx SMD Product Identification	The part numbers listed are for standard CDC emblems only
27	94365001	EMBLEM, CDC Exterior Identification	
28	47291103	PANEL, Acoustical Foam	Left Side
28	47291102	PANEL, Acoustical Foam (Not Shown)	Right Side
29	76429332	SEAL, Acoustical	
30	47291104	PANEL, Acoustical Foam	Top




14-800C

Figure 3-9. Case Assembly - Acoustic Cabinet

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-9	775628**	CASE ASSEMBLY, Acoustic Cabinet	S/C 21 W/O 55155B & Blw
3-9	472915**	CASE ASSEMBLY, Acoustic Cabinet	S/C 21 W/55155B & Abv
1	75040478	PANEL, Acoustical Foam	
2	474548**	CASE, Acoustical Top	S/C 21 W/O 55155B & Blw
2	472913**	CASE, Acoustical Top	50 Hz S/C 21 W/ 55155B & Abv
2	814499**	CASE, Acoustical Top	60 Hz
3	77561000	SUPPORT, Rod	
4	93530021	PIN, Roll	
5	75065200	PIN, Pivot Case	
6	10125106	NUT, Hex, 8-32	
7	94274105	TERMINAL, Quick Connect	All units except BK5A9T
8	10126402	WASHER, External Tooth Lock, #8	All units except BK5A9T
9	75040450	PANEL, Acoustical Foam	
10	92033037	RING, Retaining	
11	46819300	SPRING, Extension	
12	92033087	RING, Retaining	
13	75040451	PANEL, Acoustical Foam	
14	75040448	PANEL, Acoustical Foam	Left Side
14	75040449	PANEL, Acoustical Foam (Not Shown)	Right Side

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-9		CASE ASSEMBLY, Acoustic Cabinet (Contd)	
15	76429320	SEAL, Acoustical	
16	75040474	PANEL, Acoustical Foam	
17	94303500	RECEPTACLE, Clip In	S/C 21 W/O 55155B & Abv only
18	76429322	SEAL, Acoustical	
19	15000601	EMBLEM, 97xxSMD Product Identification	The part numbers listed are for S/C 37 & Abv; BK5C4R/S only
19	83641600	EMBLEM, Product (ICL)	standard CDC emblems only.
20	94365000	EMBLEM, CDC Exterior Identification	S/C 37 & Abv; BK5C4R/S only
20	47427501	CHANNEL, Logo Carrier	S/C 21 W/55155B & Abv only
21	73029800	KEEPER, Latch	S/C 21 W/55155B & Abv only
22	10126105	WASHER, Internal Tooth Lock, #10	S/C 21 W/55155B & Abv only
23	10127141	SCREW, Pan Head Machine, 10-32 x 5/16	S/C 21 W/55155B & Abv only
24	10125804	WASHER, Spring Lock, #8	BK5A9T only




14-900E

Figure 3-10. Case Assembly - Acoustic Drawer

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-10	472022**	CASE ASSEMBLY, Acoustic Drawer	S/C 21 W/O 55155B & Blw color codes A thru AT only
3-10	472904**	CASE ASSEMBLY, Acoustic Drawer	S/C 21 W/55155B & Abv color codes AU & Abv only
1	473691**	DOOR, Case	All Units except BK5C5A/B, BK5A3M, BK5C4C/D, BK5A7T & BK5A7V/W
1	473692**	DOOR, Case	BK5A3-M, BK5C4C/D, BK5A7T, BK5A7V/W, BK5C5A/B only
2	474510**	CASE, Acoustical	S/C 21 W/O 55155B Blw
2	472907**	CASE, Acoustical	50 Hz S/C 21 W/55155B & Abv 60 Hz S/C 21-48 W/55155B
2	934058**	CASE, Acoustical	60 Hz S/C 49 & Abv
3	76427900	SCREW, Modified	
4	75062400	WASHER, Insulator	
5	93826236	SCREW, Self-Locking Pan Head, 10-32 x 3/8	
6	76427601	ARM, Case Support	
7	10127113	SCREW, Pan Head Machine, 6-32 x 3/8	
8	10126401	WASHER, External Tooth Lock, #6	
9	10125605	WASHER, Flat, #6	
10	76428000	LATCH, Rack Mount	
11	76428201	ACTUATOR, Latch	
12	40063200	SPRING, Extension	
13	76428001	LATCH, Rack Mount	
14	10125106	NUT, Hex, 8-32	
15	10126402	WASHER, External Tooth Lock, #8	

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-10		CASE ASSEMBLY, Acoustic Drawer (Contd)	
16	94274105	TERMINAL, Quick Connect	
17	92033037	RING, Retaining	
18	46819300	SPRING, Extension	
19	93530021	PIN, Roll	
20	75065200	PIN, Case Pivot	
21	92628302	TAPE, Black Adhesive Back	
22	75040498	PANEL, Acoustical Foam	
23	76429320	SEAL, Acoustical	
24	47195500	SPRING, Torsion	S/C 21 W/O 55155B & Blw only
25	47175200	LATCH, Case	Left Side, S/C 21 W/O 55155B & Blw only
25	47175201	LATCH, Case (Not Shown)	Right Side, S/C 21 W/O 55155B & Blw only
26	47195300	SPACER, Latch	S/C 21 W/O 55155B & Blw only
27	10125714	SCREW, Flat Head, 6-32 x 3/8	S/C 21 W/O 55155B & Blw only
28	47198100	CLIP, Case	
29	10126103	WASHER, Internal Tooth Lock, #6	
30	92373001	NYLINER, Snap In	
31	10126105	WASHER, Internal Tooth Lock, #10	
32	75257301	SCREW, Modified	
33	92633021	BUMPER, Grommet	
34	76429310	SEAL, Acoustical	
35	76429309	SEAL, Acoustical	
36	15000601	EMBLEM, 97xx SMD Product Identification	The part numbers listed are for standard CDC emblems only.
37	94365001	EMBLEM, CDC Exterior Identification	
38	93790156	SCREW, Self Locking Mach- ine, 6-32 x 3/16	S/C 21 W/55155B & Abv only
39	73029200	LATCH, Right Side Case	S/C 21 W/55155B & Abv only
40	94204001	SPRING, Extension	S/C 21 W/55155B & Abv only
41	73029300	LATCH, Left Side Case	S/C 21 W/55155B & Abv only
42	10125716	SCREW, Flat Head, 6-32 x 5/8	S/C 21 W/55155B




14-1000E

Figure 3-11. Case Assembly - 30 Inch Rack Mount

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-11	775663**	CASE ASSEMBLY, 30 Inch Rack Mount	S/C 21 W/O 55155B & Blw
3-11	472903**	CASE ASSEMBLY, 30 Inch Rack Mount	S/C 21 W/55155B & Abv
1	473691**	DOOR, Case	
2	474541**	CASE, Mount Rack	S/C 21 W/O 55155B & Blw
2	472906**	CASE, Mount Rack	50 Hz S/C 21 W/ 55155B & Abv. 60 Hz S/C 21-48 W/55155B.
2	922438**	CASE, Mount Rack	60 Hz S/C 49 & Abv
3	10125106	NUT, Hex, 8-32	
4	10125804	WASHER, Spring Lock, #8	
5	10125606	WASHER, Flat, #8	
6	75257700	RETAINER, Filter	
7	##	FILTER, Air	
8	92628413	TAPE, Foam	
9	93826236	SCREW, Self-Locking Pan Head, 10-32 x 3/8	
10	76427601	ARM, Case Support	
11	75062400	WASHER, Insulator	
12	92633021	BUMPER, Grommet	
13	92033237	RING, Retaining	
14	46819300	SPRING, Extension	
15	93530021	PIN, Roll	
16	75065200	PIN, Case Pivot	
17	92628302	TAPE, Black Adhesive Backed	
18	10126402	WASHER, External Tooth Lock, #8	
19	94274105	TERMINAL, Quick Connect	
20	10127113	SCREW, Pan Head Machine, 6-32 x 3/8	
21	10126103	WASHER, Internal Tooth Lock, #6	
21A	10126103	WASHER, Internal Tooth Lock, #6	
22	10125605	WASHER, Flat, #6	
23	77564800	PIN, Latch	

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-10		CASE ASSEMBLY, 30 Inch Rack Mount (Contd)	
24	94205791	SPRING, Compression	
25	77564900	BASE, Latch	
26	77565003	ARM, Latch	All units except BK5B5R, BK5A1K/N, BK5A1J/L
26	77565005	ARM, Latch	BK5A1N & BK5B5R
26	77565001	ARM, Latch	BK5A1K
26	77565004	ARM, Latch	BK5A1J/L
26	77565007	ARM, Latch	BK5A1P
27	10125714	SCREW, Flat Head, 6-32 x 3/8	S/C W/O 55155B & Blw only
28	49718100	CLIP, Case	
29	47175200	LATCH, Case	Left Side, S/C 21 W/O 55155B & Blw only
29	47175201	LATCH, Case (Not Shown)	Right Side, S/C 21 W/O 55155B & Blw only
30	47195300	SPACER, Latch	S/C 21 W/O 55155B & Blw only
31	47195500	SPRING, Torsion	S/C 21 W/O 55155B & Blw only

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-11		CASE ASSEMBLY, 30 Inch Rack Mount (Contd)	
32	75040426	PANEL, Acoustical Foam	
33	76429332	SEAL, Acoustical	
34	75040480	PANEL, Acoustical Foam	Left Side, S/C 21 W/O 55155B & Blw
34	47291101	PANEL, Acoustical Foam	Left Side, S/C 21 W/O 55155B & Blw
34	75040479	PANEL, Acoustical Foam (Not Shown)	Right Side, S/C 21 W/O 55155B & Blw
34	47291100	PANEL, Acoustical Foam	Right Side, S/C 21 W/O 55155B & Blw
35	75257301	SCREW, Modified	
36	10126105	WASHER, Internal Tooth Lock, #10	
37	92373001	NYLINER, Snap In	
38	15000601	EMBLEM, 97xxSMD Product Identification	The part numbers listed are for standard CDC emblems only.
39	94365001	EMBLEM, CDC Exterior Identification	
40	93790156	SCREW, Self-Locking Mach- ine, 6-32 x 3/16	S/C 21 W/55155B & Abv only
41	73029200	LATCH, Right Side Case	S/C 21 W/55155B & Abv only
42	94204001	SPRING, Extension	S/C 21 W/55155B & Abv only
43	73029300	LATCH, Left Side Case	S/C 21 W/55155B & Abv only
44	10125716	SCREW, Flat Head, 6-32 x 5/8	S/C 21 W/55155B & Abv only



14-1100 E

Figure 3-12. Case Assembly - 36 Inch Rack Mount

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-12	472020**	CASE ASSEMBLY, 36 Inch Rack Mount	S/C 21 W/O 55155B & Blw
3-12	472902**	CASE ASSEMBLY, 36 Inch Rack Mount	S/C 21 W/55155B & Abv
1	473691**	DOOR, Case	
2	832859**	CASE, Rack Mount	S/C 21 W/O 55155B & Blw
2	472905**	CASE, Rack Mount	S/C 21 W/55155B & Abv 50 Hz.
2	928548**	CASE, Rack Mount	S/C 21-48 W/ 55155B 60 Hz 60 Hz S/C 49 & Abv
3	10125106	NUT, Hex, 8-32	
4	10125804	WASHER, Spring Lock, #8	
5	10125606	WASHER, Flat, #8	
6	75257700	RETAINER, Filter	
7	93826236	SCREW, Self-Locking Pan Head, 10-32 x 5/16	
8	76427601	ARM, Case Support	
9	75062400	WASHER, Insulator	
10	92033037	RING, Retaining	
11	46819300	SPRING, Extension	
12	75065200	PIN, Case Pivot	
13	93530021	PIN, Roll	
14	##	FILTER, Air	
15	92628413	TAPE, Foam	
16	10127122	SCREW, Pan Head Machine, 8-32 x 3/8	
17	76030400	HANDLE, Rack Mount	
18	92628302	TAPE, Black Adhesive Backed	
19	10126402	WASHER, External Tooth Lock, #8	
20	94274105	TERMINAL, Quick Connect	
21	10127331	SCREW, Pan Head Machine, 6-32 x 3/16	
22	10125803	WASHER, Spring Lock, #6	
23	93530083	PIN, Roll	
24	76417500	PIN, Latch	
25	76417600	SPRING, Compression	
26	76030600	GUIDE, Pin	
27	75040480	PANEL, Acoustical Foam	Left Side, S/C 21 W/O 55155B & Blw
27	47291101	PANEL, Acoustical Foam	Left Side, S/C 21 W/55155B & Abv

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-12		CASE ASSEMBLY, 36 Inch Rack Mount (Contd)	
27	75040479	PANEL, Acoustical Foam (Not Shown)	Right Side, S/C 21 W/O 55155B & Blw
27	47291100	PANEL, Acoustical Foam (Not Shown)	Right Side, S/C 21 W/55155B & Abv
28	76429332	SEAL, Acoustical	
29	75040426	PANEL, Acoustical Foam	
30	10125714	SCREW, Pan Head Machine, 6-32 x 3/8	S/C 21 W/O 55155B & Blw only
31	47198100	CLIP, Case	
32	47175200	LATCH, Case	Left Side, S/C 21 W/O 55155B & Blw only
32	47175201	LATCH, Case (Not Shown)	Right Side, S/C 21 W/O 55155B & Blw only
33	47195300	SPACER, Latch	S/C 21 W/O 55155B & Blw only
34	47195500	SPRING, Torsion	S/C 21 W/O 55155B & Blw only
35	75257301	SCREW, Modified	
36	10126105	WASHER, Internal Tooth Lock, #10	
37	92373001	NYLINER, Snap In	
38	15000601	EMBLEM, 97xxSMD Product Identification	The part numbers listed are for standard CDC emblems only
39	94365001	EMBLEM, CDC Exterior Identification	
40	93790156	SCREW, Self-Locking Mach- ine, 6-32 x 3/16	S/C 21 W/55155B & Abv only
41	73079200	LATCH, Right Side Case	S/C 21 W/55155B & Abv only
42	94204001	SPRING, Extension	S/C 21 W/55155B & Abv only
43	73029300	LATCH, Left Side Case	S/C 21 W/55155B & Abv only
44	10125716	SCREW, Flat Head, 6-32 x 5/8	S/C 21 W/55155B & Abv only





Figure 3-13. Case Assembly - Universal (Sheet 1 of 2)

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-13	751659**	CASE ASSEMBLY, Universal (Sheet 1 of 2)	
1	92373001	NYLINER, Snap In	
2	10126105	WASHER, Internal Tooth Lock, #10	
3	75257301	SCREW, Modified	
4	47369103	DOOR, Case	
5	47198100	CLIP, Case	
6	10125716	SCREW, Cross Recessed Flat Head, 6-32 x 5/8	
7	73029200	LATCH, Right Rack Case	
8	73051603	CASE, Universal Cabinet	
9	47291100	PANEL, Acoustical Foam	
10	94364903	FILTER, Aluminum Washable Air	
11	10127123	SCREW, Pan Head Machine, 8-32 x 1/2	
12	94397016	EMBLEM, Product Identifi- cation	
13	75040426	PANEL, Acoustical Foam	
14	47291101	PANEL, Acoustical Foam	
15	76429332	SEAL, Acoustical	
16	73051719	PANEL, Front Case	
17	10126103	WASHER, Internal Tooth Lock, #6	
18	93725143	SCREW, Phillips Truss Head Machine	
19	93790156	SCREW, Selflocking Pan Head Machine	
20	94204001	SPRING, Extension	
21	73029300	LATCH, Left Rack Case	



14-903(2)A

Figure 3-13. Case Assembly - Universal (Sheet 2)

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-13		CASE ASSEMBLY, Universal (Sheet 2)	
1	76427900	SCREW, Modified Cross Threaded	
2	75062400	WASHER, Insulator	
3	93826236	SCREW, Pan Head Machine, 10-32 x 5/16	
4	76427601	ARM, Case Support	
5	73051800	LATCH, Left	
6	10127113	SCREW, Pan Head Machine, 6-32 x 3/8	
7	10126401	WASHER, External Tooth Lock, #6	
8	10125605	WASHER, Flat, #6	
9	40063202	SPRING, Extension	
10	73051900	LATCH, Right	
11	10125106	NUT, Hexagon Machine, 8-32	
12	10126402	WASHER, External Lock, #8	
13	94274105	TERMINAL, Quick Connect	
14	92633021	BUMPER, Grommet Type	
15	92033037	RING, Retaining	
16	46819300	SPRING, Extension	
17	73052200	LATCH, Actuator	
18	93530021	PIN, Roll, 0.75 x 0.062	
19	75065200	PIN, Case Pivot	





Figure 3-14. Pack Access Cover Assembly - Nonacoustic

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-14	750602**	PACK ACCESS COVER ASSEMBLY, Nonacoustic	Units with color codes CV & A thru CS except BK5A1G/H, & BK5B9R/S S/C 44 W/DJ00309 & Abv BK5A1G/H only
3-14	730531**	PACK ACCESS COVER ASSEMBLY, Universal	
3-14	823995**	PACK ACCESS COVER ASSEMBLY	Units with color codes AY, CT & Abv & BK5B9R/S S/C 44 W/DJ00309 & Abv
1	75070200	RETAINER, Pack Cover	S/C 32 & Blw
1	73063600	RETAINER, Pack Cover	S/C 33 & Abv
2	93749157	SCREW, Pan Head Machine, 6-32 x 7/32	
3	10126401	WASHER, External Tooth Lock, #6	
4	94369529	CABLE, Ground	All units except BK5A5V/W
4	94369547	CABLE, Ground	BK5A5V/W only
5	10127111	SCREW, Pan Head Machine, 6-32 x 1/4	
6	94276611	TAPE, Foam	
7	92033107	RING, Retaining	
8	75070900	ROD, Latch Pivot	
9	75071401	LATCH AND SPRING ASSEMBLY	S/C 16 & Blw
9	75071406	LATCH AND SPRING ASSEMBLY	S/C 17 & Abv
10	77462900	HANDLE, Pack Access Cover	
11	778189**	COVER, Pack Access	S/C 16 & Blw
11	474549**	COVER, Pack Access	S/C 17 & Abv
11	473116**	COVER, Pack Access	BK4A5C/D BK5A5N/P only

INDEX NO	PART NO	PART DESCRIPTION	NOTE
-------------	------------	------------------	------


3-14		PACK ACCESS COVER ASSEMBLY Nonacoustic (Contd)	
11	730523**	COVER, Pack Access	BK5A1G/H only
12	93549018	BUMPER, Nylon	
12A	73052500	BAR, Pinch	BK5A1G/H only
12B	94206500	SPRING, Compression	
		(ITEMS LISTED BELOW THIS NOTE ARE NOT PART OF THE PACK ACCESS COVER ASSEMBLY)	
13	75070701	BUMPER, Self Sticking	
14	76421800	KEEPER, Interlock	
15	10127102	SCREW, Pan Head Machine, 4-40 x 1/4	
16	10126400	WASHER, External Tooth Lock, #4	



14-1300G

Figure 3-15. Pack Access Cover Assembly - Acoustic

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-15	775630**	PACK ACCESS COVER ASSEMBLY, Acoustic	All units except BK5C6D
3-15	818146**	PACK ACCESS COVER ASSEMBLY, Acoustic	BK5C6D
1	77560600	RETAINER, Pack Cover	
2	10127131	SCREW, Pan Head Machine, 10-24 x 3/8	
3	10126403	WASHER, External Tooth Lock, #10	
4	94369526	CABLE, Ground	All units except BK5A7M & BK5A9U
4	94369534	CABLE, Ground	BK5A7M & BK5A9U S/C 42 & Blw
4	94369582	CABLE, Ground	BK5A7 L/M, BK5A9T/U, BK5C5A/B S/C 42 & Abv
5	10125607	WASHER, Flat, #10	
6	10127113	SCREW, Pan Head Machine, 6-32 x 3/8	BK5C6D
7	93725141	SCREW, Truss Head Machine	
8	83227400	COVER, Inner	
9	77561401	GASKET, Extended Sponge	
10	92033107	RING, Retaining	
11	75070900	ROD, Latch Pivot	
12	77563100	LATCH AND SPRING ASSEMBLY	S/C 16 & Blw
12	77563101	LATCH AND SPRING ASSEMBLY	S/C 17 & Abv
13	77462900	HANDLE, Pack Access Cover	
14	10127111	SCREW, Pan Head Machine, 6-32 x 1/4	
15	75040455	PANEL, Acoustical Foam	
16	832858**	COVER Pack Access	All units except BK4A9E/F/G, BK5A7V/W, BK5C4C/D/E/F/R&S
16	473316**	COVER, Pack Access	BK4A9E/F/G, BK5A7V/W, BK5C4C/D/E/F/R&S only
17	75040454	PANEL, Acoustical Foam	
18	75040456	PANEL, Acoustical Foam	
19	10126103	WASHER, Internal Tooth Lock, #6	
20	10126105	WASHER, Internal Tooth Lock, #10	
21	94206500	SPRING Compression	
22	73085200	HOOK, Interlock	BK5C6D



14-1400A

Figure 3-16. Front and Rear Door - Nonacoustic

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-16		FRONT AND REAR DOOR, Nonacoustic	
1	765158**	DOOR, Front	
1	765159**	DOOR, Rear	
2	10127131	SCREW, Pan Head Machine, 10-24 x 3/8	
3	10126403	WASHER, External Tooth Lock, #10	
4	94274140	TERMINAL, Quick Connect	
5	92633021	BUMPER, Grommet	
6	94221400	LATCH, Flush	
7		SPRING, Latch	Supplied With
8		BRACKET, Latch	Flush Latch
9	94224907	SPACER, Latch	




Figure 3-17. Front Door Assembly - Acoustic

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-17	775624**	FRONT DOOR ASSEMBLY, Acoustic Cabinet	
1	92373003	NYLINER, Snap In	
2	76429317	SEAL, Acoustical	
3	75040460	PANEL, Acoustical Foam	All units except BK5A9R/S S/C 52 W/DJ00660 & Abv
3	75040494	SEAL, Acoustic Foam	BK5A9R/S S/C 52 W/DJ00660
4	76429314	SEAL, Acoustical	
5	76429315	SEAL, Acoustical	
6	76429313	SEAL, Acoustical	
7	94224906	SPACER, Latch	
8	94221400	LATCH, Flush	
9		SPRING, Latch	Supplied With
10		BRACKET, Latch	Flush Latch
11	775615**	DOOR, Front	All units except BK4A9E/F/G, BK5A7V/W, BK5B1-H, BK5C4C/D/E/F/R/S/ U
11	473154**	DOOR, Front	BK4A9E/F/G, BK5A7V/W, BK5B1-H, BK5C4C/D/E/F/R/S/ U
12	94355600	FASTENER, Quarter Turn Stud	BK5A9R/S S/C 52 W/DJ00660 & Abv only
13	94355601	FASTENER, Quarter Turn Grommet	BK5A9R/S S/C 52 W/DJ00660 & Abv only




Figure 3-18. Rear Door Assembly - Acoustic Cabinet

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-18	775625**	REAR DOOR ASSEMBLY, Acoustic Cabinet	
1	10127115	SCREW, Pan Head Machine, 6-32 x 5/8	
2	10125605	WASHER, Flat, #6	
3	40034600	GUARD, Finger	
4	94253100	FAN, Venturi	60 Hz
4	94247101	FAN, Venturi	50 Hz
5	10125105	NUT, Hex, 6-32	
6	10126401	WASHER, External Tooth Lock, #6	
7	93592158	SCREW, Self Tapping Hex Head, 6-32 x 1/4	
8	92602002	CLAMP, Nylon Cable	
9		W11 CABLE ASSEMBLY (See Drive Electronics Assembly For Part Number)	
10	93948003	CONNECTOR, Pin Housing (P400)	
		(ASSOCIATED PARTS)	
	93942009	CONTACT, Pin	
		- - - * - - -	
11	77561900	PANEL, Fan Mounting	
12	94221400	LATCH, Flush	
13		SPRING, Latch	Supplied With
14		BRACKET, Latch	Flush Latch
15	92373003	NYLINER, Snap In	
16	778180**	DOOR, Rear	
17	76429316	SEAL, Acoustical	
18	75040467	PANEL, Acoustical Foam	
19	76429314	SEAL, Acoustical	
20	76429315	SEAL, Acoustical	
21	75040466	PANEL, Acoustical Foam	
22	75040468	PANEL, Acoustical Foam	
23	75040458	PANEL, Acoustical Foam	
24	76429313	SEAL, Acoustical	
25	94224906	SPACER, Latch	
26	75040461	PANEL, Acoustical Foam (ITEMS LISTED BELOW THIS NOTE ARE NOT PART OF THE REAR DOOR ASSEMBLY)	
27	93947004	CONNECTOR, Pin Housing (J400) (Part of W12)	
		(ASSOCIATED PARTS)	
	93943009	CONTACT, Pin	
		- - - * - - -	




Figure 3-19. Rear Door Assembly - Acoustic Cabinet

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-19	775601**	REAR DOOR ASSEMBLY, Acoustic Drawer	S/C 39 & Blw
3-19	823988**	REAR DOOR ASSEMBLY Acoustic Drawer	S/C 40 - 41
3-19	823999**	REAR DOOR ASSEMBLY Acoustic Drawer	All units except BK5C6D S/C 42 & ABV BK5C6D
3-19	934134**	REAR DOOR ASSEMBLY Acoustic Drawer	
1	94221400	LATCH, Flush	
2		SPRING, Latch	Supplied With
3		BRACKET, Latch	Flush Latch
4	92373003	NYLINDER, Snap In	
5	10127116	SCREW, Pan Head Machine, 6-32 x 3/4	
6	81417040	GUARD, Fan	All units except BK5C6D
6	94375401	GUARD, Finger	BK5C6D
7	778181**	DOOR, Rear	All units except BK4A9E/F/G, BK5B1-H, BK5C5D, BK5A7V/W, BK5A8H, BK5C4C/D/E/F/R/ S/U
7	473155**	DOOR, Rear	BK4A9E/F/G, BK5A7V/W, BK5B1-H, BK5C4C/D/E/F/R/ S/U, BK5A8H, BK5C5D
8	76429316	SEAL, Acoustical	
9	75040470	PANEL, Acoustical Foam	
10	92602003	CLAMP, Nylon Cable	
11	76429315	SEAL, Acoustical	
12	10126401	WASHER, External Tooth Lock, #6	
13	10125105	NUT, Hex, 6-32	
14		W11 CABLE ASSEMBLY (See Drive Electronics Assembly For Part Number)	
15	93948003	CONNECTOR, Pin Housing (P400)	
	93942009	(ASSOCIATED PARTS) CONTACT, Pin	
		- - - * - - -	

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-19		REAR DOOR ASSEMBLY, Acoustic Drawer (Contd)	
15	51905901	CONNECTOR, Receptacle (P400)	BK5C6D W11 Cable Assembly
	51905807	(ASSOCIATED PARTS) CONTACT, Pin - - - * - - -	
16	94224906	SPACER, Latch	
17	75040469	PANEL, Acoustical Foam	
18	76429313	SEAL, Acoustical	
19	76429314	SEAL, Acoustical	
20	94253100	FAN, Venturi	60 Hz 120 V AC
20	94253102	FAN, Venturi	60 Hz 220/240 V AC
20	94247101	FAN, Axial	50 Hz
21	81417060	COVER, Muffin Fan	BK5C6D
22	94355600	FASTENER, Quarter Turn Stud	BK5A9R/S S/C 52 W/DJ00600 & Abv only
23	94355601	FASTENER, Quarter Turn Grommet	BK5A9R/S S/C 52 W/DJ00600 & Abv only
		(ITEMS LISTED BELOW THIS NOTE ARE NOT PART OF THE REAR DOOR ASSEMBLY)	
300	93947004	CONNECTOR, Pin Housing (J400) (Part of W12)	
	93943001	(ASSOCIATED PARTS) CONTACT, Pin - - - * - - -	
300	51906001	CONNECTOR, Plug (J400) (Part of W12)	BK5C6D
	51906207	(ASSOCIATED PARTS) CONTACT, Pin - - - * - - -	




Figure 3-20. Side Panel - Nonacoustic

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-20		SIDE PANEL, Nonacoustic	
1	760299**	PANEL, Side	Left Side
1	760298**	PANEL, Side	Right Side
2	10127131	SCREW, Pan Head Machine 10-24 x 3/8	
3	10126403	WASHER, External Tooth Lock, #10	
4	94274140	TERMINAL, Quick Connect	
5	93592428	SCREW, Self Tapping Hex Head, 10-32 x 3/8	
6	77568600	BRACKET, Panel Mounting	
7	76429342	SEAL, Acoustical	Left Side Panel
7	76429345	SEAL, Acoustical	Right Side Panel
8	76429343	SEAL, Acoustical	Left Side Panel
8	76429344	SEAL, Acoustical	Right Side Panel




Figure 3-21. Side Panel Assembly - Acoustic

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-21	775622**	SIDE PANEL ASSEMBLY, Acoustic	
1	76429303	SEAL, Acoustical	
2	93592428	SCREW, Self Tapping Hex Head, 10-32 x 3/8	
3	77561300	BRACKET, Receptacle	
4	94303500	RECEPTACLE, Clip In	
5	75040459	PANEL, Acoustical Foam	
6	75194502	BRACKET, Support	
7	75040464	PANEL, Acoustical Foam	Left Side Panel
7	75040465	PANEL, Acoustical Foam	Right Side Panel
8	75194503	BRACKET, Support	
9	76429304	SEAL, Acoustical	
10	76429308	SEAL, Acoustical	Left Side Panel
10	76429307	SEAL, Acoustical	Right Side Panel
11	75040462	PANEL, Acoustical Foam	Left Side Panel
11	75040463	PANEL, Acoustical Foam	Right Side Panel
12	76429312	SEAL, Acoustical	
13	76429311	SEAL, Acoustical	
14	76429305	SEAL, Acoustical	Left Side Panel
14	76429306	SEAL, Acoustical	Right Side Panel
15	764290**	PANEL, Left Side	All units except BK5C4C/D, BK5A7V/W
15	473156**	PANEL, Right Side	BK5A7V/W & BK5C4C/D only
15	764292**	PANEL, Right Side	All units except BK4A9E/F/G, BK5A7V/W, BK5C4C/D/E/F/R/S
15	473261**	PANEL, Left Side	BK5A7V/W BK5C4C/D/E/F/R/S, BK4A9E/F/G only




Figure 3-22. Drive Electronics Assembly (Sheet 1 of 4)

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-22		DRIVE ELECTRONICS ASSEMBLY (Sheet 1 of 4)	
1		LOGIC CHASSIS ASSEMBLY (A2) (See Figure 3-24)	
2	10126259	SCREW, Socket Head, 1/4 x 20 1-1/4	
3	10125806	WASHER, Spring Lock, 1/4	
4		DECK ASSEMBLY (A3) (See Figure 3-25)	
5	76420600	SPACER, Shock	
6		BASE ASSEMBLY (A1) (See Figure 3-32)	All units except BK4B7B, BK5A1K, BK5A7M, BK5A9U, & BK5C1F
6		BASE ASSEMBLY (A1) (See Figure 3-33)	BK4B7B, BK5A1K BK5A7M, BK5A9U, & BK5C1F only
7	94261810	BODY, Connector (P201) (Part of W3)	
		(ASSOCIATED PARTS)	
	94245601	CONTACT, Crimp	
		- - - * - - -	
8		CONTROL PANEL ASSEMBLY (A3A01) (See Figure 3-23)	
9	10126264	SCREW, Socket Head, 1/4 x 20 x 2-1/2	
10	##	LOGIC CARDS	
11	10126259	SCREW, Socket Head, 1/4-20 x 1-1/4	
12	10127122	SCREW, Pan Head Machine, 8-32 x 3/8	
13	10125804	WASHER, Spring Lock, #8	
14	10125606	WASHER, Flat, #8	
15	10125608	WASHER, Flat, 1/4	
16	93564065	WASHER, Nylon	
		(THE PART NUMBERS FOR ALL CABLES AND HARNESSES APPEAR BELOW)	
	47172700	W1 HARNESS ASSEMBLY	50 Hz S/C 30 & Blw. All 60 Hz except BK4B7B, BK5A1K, BK5A7M, BK5A9U & BK5C1F S/C 33 & Blw

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-22		DRIVE ELECTRONICS ASSEMBLY (Sheet 1 of 4) (Contd)	
	47172702	W1 HARNESS ASSEMBLY	50 Hz S/C 31 & Abv; 60 Hz S/C 34 & Abv, all units except BK4B7B, BK5A1K, BK5A7M, BK5A9U, BK5C/F
	47172701	W1 HARNESS ASSEMBLY	50 Hz S/C 30 & Blw; 60 Hz S/C 33 & Blw, BK4B7B, BK5A1K, BK5A7M, BK5A9U, BK5C1F,
	47172703	W1 HARNESS ASSEMBLY	50 Hz S/C 31 & Abv; 60 Hz S/C 34 & Abv, BK4B7B, BK5A1K, BK5A7M, BK5A9U, BK5C1F
	92572300	W1 HARNESS ASSEMBLY	50 Hz, BK5C6D
	47171900	W2 CABLE ASSEMBLY	
	47174600	W3 HARNESS ASSEMBLY	Used on units W/3 Card Power Supply
	47437500	W3 HARNESS ASSEMBLY	Used on units W/2 Card Power Supply except BK5C6D
	92368900	W3 HARNESS ASSEMBLY	BK5C6D
	47437501	W3 HARNESS ASSEMBLY	BK5A5V/W only

INDEX NO	PART NO	PART DESCRIPTION	NOTE
-------------	------------	------------------	------

3-22

DRIVE ELECTRONICS ASSEMBLY
(Sheet 1 of 4) (Contd)

47437502	W3	HARNESS ASSEMBLY	BK5A7 L/M, BK5A9T/U, BK5C5A/B S/C 42 & Abv
47172100	W4	CABLE ASSEMBLY	
83276700	W6	CABLE ASSEMBLY	
77562001	W11	CABLE ASSEMBLY	S/C 39 & Blw
77562004	W11	CABLE ASSEMBLY	S/C 40-41
77562006	W11	CABLE ASSEMBLY	S/C 42 & Abv
93733800	W11	CABLE ASSEMBLY	BK5C6D
77562901	W12	CABLE ASSEMBLY	Not used on basic units S/C 39 & Blw
77562906	W12	CABLE ASSEMBLY	Not Used on Basic Units S/C 40-41
77562909	W12	CABLE ASSEMBLY	Not used on basic units S/C 42 & above
81818200	W12	CABLE ASSEMBLY	BK5C6D

(TERMINALS AND CONNECTORS FOR ALL HARNESSING
ARE SHOWN AT THEIR ORIGINS AND DESTINATIONS)




Figure 3-22. Drive Electronics Assembly (Sheet 2)

INDEX NO	PART NO	PART DESCRIPTION	NOTE
----------	---------	------------------	------

3-22		DRIVE ELECTRONICS ASSEMBLY (Sheet 2)	
1	93749162	SCREW, Pan Head Machine, 6-32 x 3/8	
2	10126103	WASHER, Internal Tooth Lock, #6	
3	10125605	WASHER, Flat, #6	
4	47173200	PANEL, Logic Chassis Protective	All Units S/C 34 & Blw. BK5A6 G/H, BK5B5N/P, BK5C4C/D & Units W/O S&IOABC S/C 35 & Abv
4	47173202	PANEL, Logic Chassis Protective	All Units S&IOABC except BK5A6 G/H, BK5B5 N/P, BK5C4C/D S/C 35 & Abv
5	94261807	BODY, Connector (PA07) (Part of W2) (ASSOCIATED PARTS)	
	94245602	CONTACT, Socket - - - * - - -	
6	94261811	BODY, Connector (PA09) (Part of W3) (ASSOCIATED PARTS)	
	94245606	CONTACT, Socket - - - * - - -	
7	94261810	BODY, Connector (JA81) (Part of W4) (ASSOCIATED PARTS)	
	94245602	CONTACT, Socket	
	94245607	CONTACT, Socket	
	94245604	CONTACT, Socket - - - * - - -	
8	94261810	BODY, Connector (PA03) (JA80) (Part of W3) (ASSOCIATED PARTS)	
	94245601	CONTACT, Socket	
	94245606	CONTACT, Socket - - - * - - -	

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-22		DRIVE ELECTRONICS ASSEMBLY (Sheet 2) (Contd)	
9	93541016	TERMINAL, Ring Tongue (Part of W3)	Quick Connect Connector used in Older Units
10		CABLE, Ground (See Base Assembly For Part Number)	
11	47203103	JUMPER PLUG ASSEMBLY	Single Channel Units Only
12	10127119	SCREW, Pan Head Machine, 6-32 x 1 1/4	
13	10126103	WASHER, Internal Tooth Lock, #6	
14	##	I/O CARD, Channel I _XYV COMP ASSY (A2D1)	
15	##	I/O CARD, Channel II _XYV COMP ASSY (A2D2)	Dual Channel Units Only
16	92742178	SCREW, Pan Head Machine, 6-32 x 1 3/4)
17	10125605	WASHER, Flat, #6)
18	82377300	CLAMP, I/O (All units except BK5A6G/H)) See Note 1
19	82377200	SPACER, I/O Clamp)
20	##	TERMINATOR, _YDV COMP ASSY (A2C1) (Not Shown)	See Note 2
21	##	TERMINATOR, _YDV COMP ASSY (A2C2) (Not Shown)	See Note 2

NOTE 1

Packaged separately in
75038346 I/O Cable Hardware
Kit & shipped with 60 Hz
units S/C 49 & Abv.

INDEX NO	PART NO	PART DESCRIPTION	NOTE
----------	---------	------------------	------

3-22		DRIVE ELECTRONICS ASSEMBLY (Sheet 2 Contd)	
22	81914000	BRACKET, Strain Relief) All 60 Hz
23	81567760	CLAMP, Shielded Cable) units except
24	10126403	WASHER, External Tooth Lock, #10) rack mount &) 2X acoustic
25	10127145	SCREW, Pan Head Machine, 10-32 x 3/4) drawers S/C) 49 & Abv only.
26	81567761	CLAMP, Shielded Cable) BK5A7L/M,
27	10126401	WASHER, External Tooth Lock, #6) BK5A9T/U S/C) 51 W/DJ00603) & Abv only.

(ITEMS LISTED BELOW THIS
NOTE ARE NOT PART OF THE
DRIVE ELECTRONICS ASSEMBLY)

28	10127112	SCREW, Pan Head, 6-32 x 5/16	
29	10125105	NUT, Hexagon, 6-32	
30	47203107	JUMPER PLUG ASSEMBLY	All units with S&IOABC except BK5A6G/H, BK5B5N/P, BK5C4C/D S/C 35 & Abv.

NOTE 2

Used to terminate D1 and D2
if drives are in Star Con-
figuration or if drive is
last unit in string.





Figure 3-22. Drive Electronics Assembly (Sheet 3)
S/C 19 & Below W/O FCO 55172


INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-22		DRIVE ELECTRONICS ASSEMBLY (Sheet 3)	All units S/C 19 & Below W/O FCO 55172
1		BAFFLE, Air (See Deck Assembly Sheet 6 for Part Number)	
2	83278600	PIVOT, Upper	
3	93749162	SCREW, Pan Head Machine, 6-32 x 3/8	
4	94347107	WASHER, Shoulder	
5	83278300	ARM, Upper Deck Support	
6	94218000	NUT, Self Locking, 6-32	
7	83278400	ARM, Lower Deck Support	
8	92033037	RING, Retaining	
9	10127142	SCREW, Pan Head Machine, 10-32 x 3/8	
10	10126403	WASHER, External Tooth Lock, #10	
11	83278500	PIVOT, Lower Deck Support	
12	83278700	SHAFT, Grooved	
13	83278800	STUD	
14	83278601	PIVOT, Upper	
15	94391514	LABEL, Upper Bracket Danger	
16	94391520	LABEL, Lower Bracket Danger	



14-2001(3)B

Figure 3-22. Drive Electronics Assembly (Sheet 4)
 S/C 20 & Above
 S/C 19 & Below With Optional FCO 55172


INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-22		DRIVE ELECTRONICS ASSEMBLY (Sheet 4)	All units
1		BAFFLE, Air (See Deck Assembly, Sheet 6 for Part Number)	S/C 20 & Above & on units S/C 19 & Below if optional FCO 55172 is installed.
2	83278600	PIVOT, Upper	
3	93749162	SCREW, Pan Head Machine, 6-32 x 3/8	
4	94347107	WASHER, Shoulder	
5	47443800	ARM, Upper Deck Support	
6	94218000	NUT, Self Locking, 6-32	
7	47443700	ARM, Lower Deck Support	
8	92033037	RING, Retaining	
9	10127142	SCREW, Pan Head Machine, 10-32 x 3/8	
10	10126403	WASHER, External Tooth Lock, #10	
11	83278500	PIVOT, Lower Deck Support	
12	83278700	SHAFT, Grooved	
13	83278800	STUD	
14	83278601	PIVOT, Upper	
15	94391515	LABEL, Danger	
16	10127113	SCREW, Pan Head Machine, 6-32 x 3/8	
17	94391516	LABEL, Danger	
18	10125605	WASHER, Flat, #6	
19	82345100	RETAINER, Nylon	
20	82345000	SCREW, Thumb	
21	82345200	SPRING, Torsion	
22	93749160	SCREW, Pan Head Machine, 6-32 x 5/16	



14-2100A

Figure 3-23. Control Panel Assembly


INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-23	##	CONTROL PANEL ASSEMBLY (A3A01)	All except basic units
1	17901505	SCREW, Phillips Thread Roll, 4-40 x 3/4	
2	##	COMPONENT ASSEMBLY, Type _ZYN	
3	94367112	LED, Diffused Lens (1CR2, 1CR3, 1CR4, 1CR6)	
4	94363701	SWITCH, Keyboard (S1, S4)	
5	94363700	SWITCH, Keyboard (S3)	
6	94364816	SWITCH, Programmable (S2)	
7	94365600	HEADER, Pin	
8	92742011	SCREW, Pan Head Machine, 2-56 x 7/16	
9	10125102	NUT, Hex, 2-56	
10	75068300	BUTTON, Front Panel	
11	76422400	BEZEL, Front Panel	All units except BK5C4R/S
11	76422402	BEZEL, Front Panel	BK5C4R/S only
12	10125603	WASHER, Flat, #4 (ITEMS LISTED BELOW THIS NOTE ARE NOT PART OF THE CONTROL PANEL ASSEMBLY)	
13	82353600	KIT, Logic Plug	Packaged separately and shipped with unit
	943724XX	KEY, Programmable Insert (Logical Address Plug) (Tab 00-15)	Part number tab corresponds to to key number



14-2200C

Figure 3-24. Logic Chassis Assembly (Sheet 1 of 2)
S/C 16 & Blw


INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-24	471742XX	LOGIC CHASSIS ASSEMBLY (Sheet 1 of 2)	S/C 16 & Blw
1	10127111	SCREW, Pan Head Machine, 6-32 x 1/4	
2	47198400	SPRING, Logic Chassis Flat	
3	51911752	FASTENER, 1/4 Turn	
4	94379800	ACCESSORIES, 1/4 Turn Fastener	
5	94379801	ACCESSORIES, 1/4 Turn Fastener	
6	94379802	ACCESSORIES, 1/4 Turn Fastener	
7	93988002	RETAINER, Split Ring	
8	471741XX	WIRE WRAP ASSEMBLY	
	94245409	POST, Wire Wrap (.732)	
	94245410	POST, Wire Wrap (1.122)	
	94245411	POST, Wire Wrap (1.122 Soldered To Ground)	
	94245415	POST, Wire Wrap (.695)	
9	46490200	RAIL, Guide	
10	10125105	NUT, Hex, 6-32	
11	10126103	WASHER, Internal Tooth Lock, #6	
12	83255200	SUPPORT, I/O Card	
13	93114216	STANDOFF, Tapped Post Hex	
14	47171300	PANEL, Logic Chassis End	
15	10127113	SCREW, Pan Head Machine, 6-32 x 3/8	
16	10125605	WASHER, Flat	
17	10127115	SCREW, Pan Head Machine, 6-32 x 5/8	
18	47170900	PANEL, Logic Chassis Right Side	
19	47171000	PANEL, Logic Chassis Left Side	
20	10126401	WASHER, External Tooth Lock, #6	
21	47205800	INSULATOR, I/O	
22	94274101	TERMINAL, Quick Connect	



14-2204 B

Figure 3-24. Logic Chassis Assembly (Sheet 2)
S/C 17 & Abv

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-24	832812XX	LOGIC CHASSIS ASSEMBLY (Sheet 2)	All units except BK5C6D S/C 17 & Abv
3-24	93166700	LOGIC CHASSIS ASSEMBLY	BK5C6D
1	73022600	COVER, Magnet	
2	83279700	HINGE, Logic Chassis	
3	10125016	SCREW, Hex Head Machine, 6-32 x 3/8	
4	10126103	WASHER, Internal Tooth Lock, #6	
5	95510026	NUT, Hex, 6-32	
6	10125605	WASHER, Flat, #6	
7	94103017	FASTENER, U-Type	
8	94274101	TERMINAL, Quick Connect	
9	47205802	INSULATOR, I/O	
10	94369581	CABLE, Ground	BK5A7L/M, BK5A9 T/U, BK5C5A/B S/C 42 & Abv only
11	94060003	CHANNEL, Rubber	Not used on BK5C6D
12	51911752	ACCESSORIES, 1/4 Turn Bail Head	
13	94379800	ACCESSORIES, 1/4 Turn Fastener	
14	94379801	ACCESSORIES, 1/4 Turn Fastener	
15	94379802	ACCESSORIES, 1/4 Turn Fastener	
16	93988002	WASHER, Retaining	
17	46490200	RAIL, Guide	
18	471741XX	WIRE WRAP ASSEMBLY	All units except BK5C6D
18	95657600	WIRE WRAP ASSEMBLY	BK5C6D
	94245409	POST, Wire Wrap (.732)	
	94245410	POST, Wire Wrap (1.122)	
	94245411	POST, Wire Wrap (1.122 Soldered To Ground)	
	94245415	POST, Wire Wrap (.695)	
19	83281900	SUPPORT, I/O Cards	
20	93290003	NUT, Internal Wrenching	
21	93114216	STANDOFF, Tapped Post, Hex	
22	83279801	CHASSIS, Logic	
23	95105905	TAPE, Transparent	



14-2300(1)M

Figure 3-25. Deck Assembly (Sheet 1 of 6)

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-25		DECK ASSEMBLY (A3) (Sheet 1 of 6)	
1		MAGNET ASSEMBLY (See Figure 3-29)	
2	10127142	SCREW, Pan Head Machine, 6-32 x 1/2	
3	10126103	WASHER, Internal Tooth Lock, #6	
4		POWER AMPLIFIER, (A3A04) (_VTN Card) (See Figure 3-31)	
5	10125605	WASHER, Flat, #6	
6	77563700	WINDOW, Shroud	
7	77563800	GASKET, Shroud Window	
8	93749238	SCREW, Pan Head Machine, 10-24 x 3/8	
9	94277503	BASE, Mounting	
10	10127113	SCREW, Pan Head Machine, 6-32 x 3/8	
11	10125803	WASHER, Spring Lock, #6	
12	10127119	SCREW, Pan Head Machine, 6-32 x 1/4	
13	10126401	WASHER, External Tooth Lock, #6	
14	76425300	SHIELD, Servo Preamplifier	
15	73479800	HOUSING, Preamplifier	
16	73592482	SCREW, Washer Hex Head, 4-40 x 1/4	
17	47194100	PLATE, Preamplifier Mounting	
18		SPINDLE ASSEMBLY (See Figure 3-26)	
19	93569200	SHROUD Pack	
20	92004120	SCREW, Pan Head Machine, 4-40 x 5/16	
21	10125801	WASHER, Spring Lock, #4	
22	93211105	WASHER, Flat, #4	
23	73083500	CATCH, Pack Access Cover	
24		CARRIAGE AND COIL ASSEMBLY (See Figure 3-28)	
25	92004121	SCREW, Pan Head Machine, 6-32 x 1/4	
26	##	SWITCH, Pack Cover (A3S3)	
27	94279417	BUTTON, Plug Recessed Head	
28		RAIL BRACKET ASSEMBLY (See Figure 3-27)	

INDEX NO	PART NO	PART DESCRIPTION	NOTE
----------	---------	------------------	------

3-25		DECK ASSEMBLY (A3) (Contd)	
29	94060002	CHANNEL, Rubber	
30	##	SERVO PREAMPLIFIER (A3A05) (_ZQN Card)	
31	82335100	DEFLECTOR, Air	Units W/2 card power supply only
32	10127111	SCREW, Pan Head Machine, 6-32 x 1/4	Units W/2 card power supply only
33	10125605	WASHER, Flat, #6	Units W/2 card power supply only
34	10125803	WASHER, Spring Lock, #6	Units W/2 card power supply only
35	73029000	COVER, Connector Pin	
35A	95643966	SPACER	
35B	10126105	WASHER, Internal Tooth Lock, #10	
35C	10127136	SCREW, Pan Head, 10-24 x 1 (ITEMS LISTED BELOW THIS NOTE ARE NOT PART OF THE DECK ASSEMBLY)	
36	93342098	SCREW, Nylon	
37	93564042	WASHER, Nylon	
38		HEAD ASSEMBLIES	
	##	HEAD ARM ASSEMBLY, Data Head 1 2 4	
	##	HEAD ARM ASSEMBLY, Data Head 0 3	
	##	HEAD ARM ASSEMBLY, Servo Head	
	75017500	SCREW, Head Arm Mounting (Part of HEAD ARM ASSEMBLY)	

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-25		DECK ASSEMBLY (A3) (Cont'd)	
39	51906006	CONNECTOR, Plug (P200) (Part of W3) (ASSOCIATED PARTS) CONTACT, Socket - - - * - - -	
40	95643225	CONNECTOR, Quick Connect (S3) (Part of W3)	
40	93942001	CONNECTOR, Quick Connect (S3) BK5C6D (Part of W3)	
41	94309802	POD, Terminal (PA) (Part of W3) (ASSOCIATED PARTS)	
	93747125	RECEPTACLE, Slide On - - - * - - -	
42	94261803	BODY, Connector (P8) (Part of W3) (ASSOCIATED PARTS)	
	94245601	CONTACT, Socket (24-26 Gauge)	
	94245606	CONTACT, Socket (20-22 Gauge) - - - * - - -	




Figure 3-25. Deck Assembly (Sheet 2A)

INDEX	PART	PART DESCRIPTION	NOTE
NO	NO		
3-25		DECK ASSEMBLY (A3) (Sheet 2A)	
1	83243401	INTERLOCK ASSEMBLY (A3L3)	S/C 16 & Blw
2	76420500	STOP, Interlock	
3	10125711	SCREW, Flat, 6-32 x 3/16	
4	76422000	BRACKET, Interlock Mounting	
5	94237900	SOLENOID, DC	
6	10127314	SCREW, Pan Head Machine, 2-56 x 1/2	
7	10125107	NUT, Hex, 10-24	
8	10126403	WASHER, External Tooth Lock, #10	
9	76422100	BRACKET, Interlock Pivot	
10	10127122	SCREW, Pan Head Machine, 8-32 x 3/8	
11	10126402	WASHER, External Tooth Tooth, #8	
12	10125606	WASHER, Flat, #8	
13	10127123	SCREW, Pan Head Machine, 8-32 x 1/2	
14	76422200	BRACKET, Interlock Spring	
15	76421901	SPACER, Interlock	
16	76421700	LATCH, Interlock	
17	76421900	SPACER, Interlock	
18	92541005	SCREW, Shoulder, 10-24 x 5/8	
19	46819300	SPRING, Extension	
20	10125800	WASHER, Spring Lock, #2	
21	10125102	NUT, Hex, 2-56	
22	83281500	INTERLOCK ASSEMBLY (A3L3)	S/C 17 & Abv
23	83281400	BRACKET, Interlock Mounting	
24	93533079	PIN, Roll	
25	83281300	LATCH, Interlock	
26	93533117	PIN, Roll	
27	82338100	SPRING, Compression	
28	94237900	SOLENOID, DC	
29	10127111	SCREW, Pan Head Machine, 6-32 x 1/4	
30	10126401	WASHER, External Tooth Lock, #6	
31	10125605	WASHER, Plain, #6	
31A	94277504	BASE, Mounting	
32	94309801	POD, Terminal (A3L1) (Part of W3) (ASSOCIATED PARTS)	
33	93747060	RECEPTACLE, Slide On - - - * - - -	
34	93749200	SCREW, Phillips Pan Head Machine, 8-32 x 3/8	
35	10125606	WASHER, Flat, #8	




Figure 3-25. Deck Assembly (Sheet 2B)

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-25		DECK ASSEMBLY (A3) (Sheet 2B)	
1		SHROUD, Pack (See Sheet 1 for Part Number)	
2	10127131	SCREW, Pan Head Machine, 10-24 x 3/8	BK5C6D
3	10125805	WASHER, Spring Lock, #10	BK5C6D
4	##	INTERLOCK ASSEMBLY (ITEMS BELOW ARE PART OF THE INTERLOCK ASSEMBLY)	BK5C6D
5	83641100	LATCH, Interlock	
6	83627600	SWITCH	
7	10125602	WASHER, Flat #2	
8	10126100	WASHER, Internal Tooth Lock, #2	
9	10127315	SCREW, Pan Head Machine, 2-56 x 5/8	
10	40063200	SPRING, Extension	
11	73077800	CABLE ASSEMBLY, Top Cover	
12	93549009	BUMPER, Nylon	
13	42602001	CLAMP, Nylon Cable	
14	10127345	SCREW, Pan Head Machine	
15	93943001	CONTACT, Socket	
16	93947009	CONNECTOR (Socket Housing	
17	93533146	PIN, Roll, 1.250 x 0.125	
18	73076100	SOLENOID, 20 V dc	
19	95660411	TAPE, Poly(CDC Class H App.)	
20	10126402	WASHER, External Tooth Lock, #8	
21	10127120	SCREW, Pan Head Machine, 8-32 x 1/4	
22	10127131	SCREW, Pan Head Machine, 10-24 x 3/8	
23	10126403	WASHER, External Tooth Lock, #10	
24	83641000	BRACKET, Interlock Mounting	
25	94376723	PLATE, Nut	
26	83641200	BLOCK, Interlock Mounting	
27	93533085	PIN, Roll, .500 x .094	




Figure 3-25. Deck Assembly (Sheet 3)

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-25		DECK ASSEMBLY (Sheet 3)	
1	10127113	SCREW, Pan Head Machine, 6-32 x 3/8	
2	92001702	SCREW, Washer Pan Head, 6-32 x 5/16	
3		NOT USED	
4	76031600	BLOCK, Stop	
5		PLATE, Shroud Seal (See Sheet 5 For Part Number) (ITEMS LISTED BELOW THIS NOTE ARE NOT PART OF THE DECK ASSEMBLY)	
6	81567740	FLANGE, Shroud	60 Hz Acoustic Cabinet & Drawer S/C 49 & Abv only
7	94487000	RIVET, Drive	
8	10125105	NUT, Hex, 6-32	
9	93749162	SCREW, Pan Head Machine 6-32 x 3/8	
10	95655516	SCREW, Sheet Metal, 6-20 x 3/8	
11	10126401	WASHER, External Tooth Lock, #6	
12		CABLE, Ground (See Sheet 4 For Part Number)	
13	76423408	STIFFENER, Gasket	Acoustic Units Only
14	76423407	STIFFENER, Gasket	
15	76423500	GASKET, Left Side Shroud	Note 1
15	76423503	GASKET, Left Side Shroud	Note 2
16	76423501	GASKET, Right Side Shroud	Note 1
16	76423502	GASKET, Right Side Shroud	Note 2
17	76423403	STIFFENER, Gasket	Note 1
17	76423406	STIFFENER, Gasket	Note 3
17	76423409	STIFFENER, Gasket	Note 2
18	10125105	NUT, Hex, 6-32	Note 3
18	10125106	NUT, Hex, 8-32	Note 2
19	10126401	WASHER, External Tooth Lock, #6	Note 3
19	10126402	WASHER, External Tooth Lock, #8	Note 2
20	94296700	CABLE, Ground	BK5A7L/M, BK5A9T/U, BK5C5A/B S/C 42 & Abv only

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-25		DECK ASSEMBLY (Sheet 3 Contd)	
21	10125939	SCREW, Flat Head, 6-32 x 3/8	Note 3
21	10125725	SCREW, Flat Head	Note 2
22	10125605	WASHER, Flat, #6	

- NOTES:
1. All units except BK5A9T/U, BK5A7L/M, BK5C5A/B W/DJ00661 & Abv.
 2. BK5A9T/U, BK5A7L/M, BK5C5A/B S/C 53 W/DJ00661 & Abv.
 3. BK5A9T/U, BK5A7L/M, BK5C5A/B S/C 53 W/O DJ00661 & Blw.





Figure 3-25. Deck Assembly (Sheet 4)

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-25		DECK ASSEMBLY (Sheet 4)	
1	94241008	CLIP, Adhesive Back Cable	
2	15012412	BUSHING, Snap-In	
3	77824500	GASKET, Shroud	
4	##	SPEED SENSOR ASSEMBLY (A3L1) (Speed Transducer)	
5	94368004	CONNECTOR, Housing (J202) (ASSOCIATED PARTS)	
	93942023	CONTACT, Pin	
		- - - * - - -	
6	82337900	PLATE, Nut	S/C 17 & Abv
7	77825600	DECK	
8	10126226	SCREW, Hex Head Socket, 8-32 x 1/2	
9	10125804	WASHER, Spring Lock, #8	
10	75070700	STOP, Bumper	
11	75070802	BLOCK, Stop	
12	93749158	SCREW, Washer Pan Head, 6-32 x 1/4	S/C 16 & Blw
12	10127335	SCREW, Washer Pan Head, 6-32 x 1/2	S/C 17 & Abv
13	10126104	WASHER, Internal Tooth Lock, #8	Units W/O Interlock Assy Only
14	10127120	SCREW, Pan Head Machine, 8-32 x 1/4	Units W/O Interlock Assy Only
15	10125605	WASHER, Flat, #6	
16	92541068	SCREW, Soc. Hd Shoulder	
17	92373005	NYLINER, Snap-In	
18	75073700	LOCK, Brake, Spindle	
19	94205789	SPRING, Compression	
20	92001702	SCREW, Washer Pan Head, 6-32 x 5/16	
21	94001102	TAPE, Foam	

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-25		DECK ASSEMBLY (Sheet 4 Contd)	
22	73084500	PAD, Rubber	
23	93913855	COVER, Stop Block	
24	93276375	SCREW, Button Head, 4-40 x 1/4	
25	10125801	WASHER, Spring Lock, #4	
26	10125603	WASHER, Flat, #4	
		(ITEMS LISTED BELOW THIS NOTE ARE NOT PART OF THE DECK ASSEMBLY)	
300	93749160	SCREW, Washer Pan Head, 6-32 x 5/16	
301	93947005	CONNECTOR, Socket Housing (P202) (Part of W3) (ASSOCIATED PARTS)	
302	76426700	BRACKET, Connector	
303		CONNECTOR (See Magnet Assembly For Part Number)	
304	93947009	CONNECTOR, Socket Housing (J22) (Part of W2) (ASSOCIATED PARTS)	
	93943000	CONTACT, SOCKET	
		- - - * - - -	




14-2300(4)G

Figure 3-25. Deck Assembly (Sheet 5)

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-25		DECK ASSEMBLY (SHEET 5)	
1	83275400	BRACKET, Pivot	S/C 16 & Blw
1	83280900	BRACKET, Pivot	S/C 17 & Abv
2	51805800	BUMPER, Self-Sticking	
3	10126226	SCREW, Socket Hex Head, 8-32 x 1/2	
4	10125606	WASHER, Flat, #8	
5	10125804	WASHER, Spring Lock, #8	
6	75173310	PLATE, Nut	
7	92742176	SCREW, Pan Head Machine, 6-32 x 1-1/2	
8	10125605	WASHER, Flat, #6	
9	10127118	SCREW, Pan Head Machine, 6-32 x 1	
10	47171600	AIR DUCT, Logic Chassis	
11	93109210	STANDOFF, Spacer Round	
12	10125803	WASHER, Spring Lock, #6	
13	93109271	STANDOFF, Spacer	
14	##	COMPONENT ASSEMBLY (A3A02), Type _ZJN,	
15	10127116	SCREW, Pan Head Machine, 6-32 x 3/4	
16	##	COMPONENT ASSEMBLY (A3A03), Type _ZKN,	
17	10125105	NUT, Hex, 6-32	
18	10127110	SCREW, Pan Head Machine, 4-40 x 1-1/4	
19	10125103	NUT, Hex, 4-40	
20	47201500	GASKET, Air Plenum (ITEMS LISTED BELOW THIS NOTE ARE NOT PART OF THE DECK ASSEMBLY)	
21	75065300	ROD, Logic Chassis Support	S/C 16 & Blw
22	75244500	BRACKET, Connector Support	
23	95604057	TERMINAL, Ring Tongue (Part of W3)	Not used on all units
24	94274105	TERMINAL, Quick Connect	All units S/C 41 & Blw. All units except BK5A7L/M, BK5A9 T/U, BK5C5A/B S/C 42 & Abv.

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-25		DECK ASSEMBLY (SHEET 5 Contd)	
25	10126402	WASHER, External Tooth Lock, #8	
26	94281467	CABLE, Ground (Deck to Shroud)	All units S/C 41 & Blw. All units except BK5A7L/M, BK5A9 T/U, BK5C5A/B S/C 42 & Abv.
27	94261810	BODY, Connector (P101) (Part of W4) (ASSOCIATED PARTS)	
	94245602	CONTACT, Socket	
	94245607	CONTACT, Socket	
	94245604	CONTACT, Socket	
		- - - * - - -	
28	92033237	RING, Retaining	S/C 16 & Blw
29	94276607	TAPE, Foam	
30	10126227	SCREW, Hex Head Machine 8-32 x 5/8	




14-2304(5)A

Figure 3-25. Deck Assembly (Sheet 6)

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-25		DECK ASSEMBLY (Sheet 6)	
1	##	SWITCH, Solid State, AC (A3K5) (Start Triac)	
2	93660079	SCREW, Pan Head Machine, 8-32 x 1/2	All units except BK5A5 V/W
2	93342193	SCREW, Nylon	BK5A5V/W Only
3	83245301	RESISTOR	
4	93749160	SCREW, Pan Head Machine, 6-32 x 5/16	
5	10125803	WASHER, Spring Lock, #6	
6	10125605	WASHER, Flat, #6	
7	94277503	BASE, Mounting	
8	##	BELT, Flat Drive	
9	92001702	SCREW, Washer Pan Head, 6-32 x 5/16	
10	94001133	TAPE, Foam	
11	95649704	GROMMET	
12	76429800	BAFFLE, Air	S/C 16 & Blw
12	83277900	BAFFLE, Air	S/C 17 & Abv
13	##	CAPACITOR, Drive Motor AC (A3C6)	
14	94260504	ACCESSORIES, Plastic Capacitor	
15	10125735	SCREW, Flat Head, 10-24 x 3/8	
16	94260501	ACCESSORIES, Steel Capacitor	60 Hz
16	94260502	ACCESSORIES, Steel Capacitor	50 Hz
17	47172300	ROD, Motor Adjusting	
18	92071004	NUT, Self Tapping Hex, 1/4-20	
19	47201300	SPRING, Compression	
20	47172401	GUIDE, Spring	
21	76021200	INLET, Blower	S/C 16 & Blw
21	83277800	INLET, Blower	S/C 17 & Abv
22	10125713	SCREW, Flat Head, 6-32 x 1/4	
23	47172500	BRACKET, Adjusting Rod	
24		DRIVE MOTOR (A3DM1) AND BRAKE (A3HB1) ASSEMBLIES (See Figure 3-30)	
25	10127134	SCREW, Pan Head Machine, 10-24 x 3/4	
26	10127113	SCREW, Pan Head Machine, 6-32 x 3/8	

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-25		DECK ASSEMBLY (Sheet 6) (Contd)	
27	10126401	WASHER, External Tooth Lock, #6	
28	94369522	CABLE, Ground	
29	76408000	SPRING, Ground	
30	10127115	SCREW, Pan Head Machine, 6-32 x 5/8	
31	75069800	HOLDER, Ground Spring	All units
32	83289900	RESISTOR ASSEMBLY	W/2 card power supply only
33	93749162	SCREW, Pan Head Machine, 6-32 x 3/8	All units W/2 card power supply only
34	94241018	CLIP, Cable (ITEMS LISTED BELOW THIS NOTE ARE NOT PART OF THE DECK ASSEMBLY)	
35	76424600	PLATE, Shroud Seal	
36	76429330	SEAL, Acoustical	Drawer Units
36	76429318	SEAL, Acoustical	Cabinet Units
37	76429331	SEAL, Acoustical	Drawer Units
37	76429362	SEAL, Acoustical	Cabinet Units
38	92033221	RING, Retaining	All units except BK5A5V/W
38	92033037	RING, Retaining	BK5A5V/W only
39	73229007	STUD	All units except BK5A5V/W
39	73229006	STUD	BK5A5V/W only
40	94354901	SPRING, Gas	
41	94309802	POD (Part of W3)	
42	93747002	RECEPTACLE, Slide On	
43		TERMINAL, Flag Quick Connect (See Drive Motor and Brake Assemblies for Part Number)	
44	93564001	WASHER, Nylon, 3/16)
45	76429601	BUSHING, Nylon)
46	93749240	SCREW, Pan Head Machine 10-24 x 1/2)
47	10125607	WASHER, Flat, #10) BK5A5V/W only
48	92373004	NYLINER, Snap-In)
49	93564002	WASHER, Nylon, 1/4)
50	82365400	INSULATOR)
51	10127114	SCREW, Pan Head, 6-32 x 1/2)
52	10126402	WASHER, Internal Tooth Lock, #8	



14-2400B

Figure 3-26. Spindle Assembly

INDEX	PART	PART DESCRIPTION	NOTE
NO	NO		
3-26	##	SPINDLE ASSEMBLY	
1	75074200	LOCKSHAFT, Spindle	BK4XX
1	76425600	LOCKSHAFT, Spindle	BK5XX
2	75074600	SPRING, Lockshaft Compression	
3	75074000	WASHER, Stainless Steel Lockshaft	
4	75074001	WASHER, Brass Lockshaft	
5	75072700	SPRING, Compression	
6	92541059	SCREW, Shoulder, 10-24 x .38 x 2.50	
7	75259000	SHAFT, End Seal (ITEMS LISTED BELOW THIS NOTE ARE NOT PART OF THE SPINDLE ASSEMBLY)	
8	92723396	SCREW, Button Socket Head	
9	10125807	WASHER, Spring Lock, 5/16	




Figure 3-27. Rail Bracket Assembly

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-27	NFR	RAIL BRACKET ASSEMBLY	
1	10127111	SCREW, Pan Head Machine, 6-32 x 1/4	
2	10125803	WASHER, Spring Lock, #6	
3	10125605	WASHER, Flat, #6	
4	76420400	BRACKET, Switch Mounting	S/C 24 & Below
4	82376300	BRACKET, Switch Mounting	S/C 25 & Above
5	10127105	SCREW, Pan Head Machine, 4-40 x 1/2	
6	10126101	WASHER, Internal Tooth Lock, #4	
7	##	SWITCH, Mini Integral Actuator (A3S2)	
8	46807000	BRACKET, Pretravel Adjustment	
9	10126219	SCREW, Socket Hex Head, 6-32 x 1/2	
10	75015600	CAM, Tower	
11	10125705	SCREW, Flat Head	
12	75071100	BLOCK, Upper Stop	
13	75070700	STOP, Bumper	
14	10127106	SCREW, Pan Head, 4-40 x 5/8	S/C 25 & Above only
15	10125103	NUT, 4-40	S/C 25 & Above only
16	10125603	WASHER, Flat, #4	S/C 25 & Above only
		(ITEMS LISTED BELOW THIS NOTE ARE NOT PART OF THE BRACKET ASSEMBLY)	
17	10127112	SCREW, Pan Head Machine, 6-32 x 5/16	
18	76425202	CARRIAGE LOCKING PIN AND RING ASSEMBLY	
19	10125605	WASHER, Flat, #6	
20	92602001	CLAMP, Nylon Cable	
21	93749162	SCREW, Washer Pan Head, 6-32 x 3/8	
22	72874270	RETAINER, Head Cable	
23	95643227	TERMINAL, Quick Connect (S2) (Part of W3)	S/C 16 & Below
23	93747017	TERMINAL, Quick Connect, (S2) (Part of W3)	S/C 17 & Above
24	93749158	SCREW, Pan Head Washer Machine 6-32 x 1/4	
25	94277503	BASE, Mounting	
26	73023600	GUARD, Switch	





Figure 3-28. Carriage And Coil Assembly

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-28	NFR	CARRIAGE AND COIL ASSEMBLY (A3VC1)	
1	76426800	FLEX LEAD ASSEMBLY	
2	10127124	SCREW, Pan Head Machine, 8-32 x 5/8	
3	94047048	WASHER, Flat, #8	
4	70738902	SPACER	
5	93564002	WASHER, Nylon	
6	82375800	RETAINER, Flex Lead (ITEMS LISTED BELOW THIS NOTE ARE NOT PART OF THE CARRIAGE AND COIL)	
7	10127112	SCREW, Pan Head Machine, 6-32 x 5/16	
8	10125803	WASHER, Spring Lock, #6	
9	10125605	WASHER, Flat, #6	
10	94309802	POD, Terminal (VC1 & VC2) (Part of W3) (ASSOCIATED PARTS)	
	93747125	RECEPTACLE, Slide On - - - * - - -	



14-2700G

Figure 3-29. Magnet Assembly

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-29	47200702	MAGNET ASSEMBLY	
1	93530148	PIN, Roll, 1.38 x .125	S/C 16 & Blw
2	47171100	BRACKET, Logic Chassis Mounting	S/C 16 & Blw
3	10127122	SCREW, Pan Head Machine, 8-32 x 3/4	S/C 16 & Blw
4	10125804	WASHER, Spring Lock, #8	S/C 16 & Blw
5	83254800	BRACKET, Logic Chassis Slide	S/C 16 & Blw
5A	76416700	STOP, Rear Carriage	S/C 25 & Blw
5A	73082900	STOP, Rear Carriage	S/C 26 & Abv
(ITEMS LISTED BELOW THIS NOTE ARE NOT PART OF THE MAGNET ASSEMBLY)			
6	93749162	SCREW, Washer Pan Head, 6-32 x 3/8	
7	76425801	ROD, Extension	
8	73072900	STOP, Transducer Safety	
9	##	TRANSDUCER ASSEMBLY (A3L2)	
10	93948008	CONNECTOR, Pin Housing (4 Pin)	
	93942014	(ASSOCIATED PARTS) CONTACT, Pin	
		- - - * - - -	
11	10126234	SCREW, Socket Hex Head, 10-24 x 1/2	
12	10125805	WASHER, Spring Lock, #10	
13	75257100	COVER, Magnet	




Figure 3-30. Drive Motor And Brake Assemblies

INDEX NO	PART NO	PART DESCRIPTION	NOTE
----------	---------	------------------	------

3-30

DRIVE MOTOR AND BRAKE ASSEMBLY

Unless otherwise noted all parts and assemblies listed here are common to both the non-floating and the floating brake assemblies.

INDEX NO	PART NO	PART DESCRIPTION	NOTE
		DRIVE MOTOR ASSEMBLY	
1	77398000	MOTOR, End Mounting	60 Hz, 120 V AC
1	77398100	MOTOR, End Mounting	60 Hz, 100 V AC
1	77398101	MOTOR, End Mounting	50 Hz, 100 V AC
1	92003700	MOTOR, End Mounting	50 Hz, 220/240 V AC
1	92003701	MOTOR, End Mounting	50 Hz, 220 V AC BK5C6D
2	93948003	CONNECTOR, Pin Housing (3 Pin) (P304) (ASSOCIATED PARTS)	
	93942002	CONTACT, Pin - - - * - - -	
		W6 CABLE ASSEMBLY	
3	93947004	CONNECTOR, Socket Housing (3 Pin) (J304) (ASSOCIATED PARTS)	
	93942002	CONTACT, Socket - - - * - - -	
4	95643208	CONNECTOR, Quick Connect	
5	95643232	CONNECTOR, Quick Connect	
6	93948009	CONNECTOR, Pin Housing (ASSOCIATED PARTS)	
	93942002	CONTACT, Pin - - - * - - -	
7	76409200	PLATE, Motor Mounting	
8	10125804	WASHER, Spring Lock, #8	
9	10126226	SCREW, Hexagon Socket Head Cap, 8-32 x 1/2	
10	10127361	SCREW, Slotted Pan Head, 10-24 x 1/4	Floating Brake
11	10126105	WASHER, Internal Tooth Lock, #10	Floating Brake

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-30		DRIVE MOTOR AND BRAKE ASSEMBLY (Contd)	
12	94369591	JUMPER ASSEMBLY (ASSOCIATED PARTS)	Floating Brake
	95604018	TERMINAL, Ring Tongue - - - * - - -	
13	73078800	STANDOFF, Motor Brake Ground	Floating Brake
14	75241200	BRACKET, Brake Mount	Non-Floating Brake
14	73053200	BRACKET, Brake Mount	Floating Brake
15	95649726	GROMMET	
16	10125107	NUT, Hexagon, 10-24	Non-Floating Brake
17	10126227	SCREW, Hexagon Socket Head, 8-32 x 5/8	
18	10125805	WASHER, Spring Lock, #10	Non-Floating Brake
19	10125607	WASHER, Flat, #10	Non-Floating Brake
20	93210008	WASHER, Flat, #8	Non-Floating Brake
21	10126104	WASHER, Internal Tooth Lock, #8	Floating Brake
22	93947005	CONNECTOR, Socket Housing (2 Pin) (Part of W3) (ASSOCIATED PARTS)	
	93943017	CONTACT, Socket - - - * - - -	
23	## 93948004	HYSTERESIS BRAKE ASSEMBLY CONNECTOR, Pin Housing (2 Pin) (J303) (ASSOCIATED PARTS)	
	93942023	CONTACT, Pin - - - * - - -	
24	94382300	BRAKE, Hysteresis	
25	47402210	BRAKE COLLAR ASSEMBLY	
26		NOT USED	
27	93287014	COLLAR, Shaft	
28	76051302	PULLEY, Motor	60 Hz S/C 45 & Blw. All units except BK5B1E, BK5A8F, BK5A5V S/C 46 & Abv
28	76051305	PULLEY, Motor	60 Hz BK5B1E, BK5A8E, BK5A%v S/C 46 & Abv

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-30		DRIVE MOTOR & BRAKE ASSEMBLY (Contd)	
28	76051303	PULLEY, Motor	50 Hz S/C 45 & Blw. All units except BK5B1F, BK5A8F, BK5A5W S/C 46 & Abv
28	76051306	PULLEY, Motor	50 Hz BK5B1E, BK5A8E, BK5A5W S/C 46 & Abv
29	94281404	CABLE, Ground	All units except BK4B7B, BK5A1K, BK5A7M, BL5A9U, BK5C1F
		(ASSOCIATED PARTS)	
	95604057	CONNECTOR, Insulated Ring Tongue	
		- - - * - - -	
30		CABLE, Ground	Used on BK4B7B, BK5A1K, BK5A7M, BK5A9U & BK5C1F only
		(ASSOCIATED PARTS)	
	93541018	TERMINAL, Ring Tongue	
		- - - * - - -	
31		NUT, Hexagon	Supplied with motor
32	10126402	WASHER, External Tooth, #8	
		(ITEMS LISTED BELOW THIS NOTE ARE NOT PART OF THE DRIVE MOTOR AND BRAKE ASSEMBLY).	
300	75062805	WASHER, Shoulder	
301	75062400	WASHER, Shoulder	
302	94047052	WASHER, Insulator	
303	10125805	WASHER, Special	
304	10126235	SCREW, Socket Head, 10-24 x 5/8	





Figure 3-31. Power Amplifier

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-31	##	POWER AMPLIFIER, Component Assembly (Type _VTN) (A3A04)	
1	##	TRANSISTOR, SNPN-T03 Darlington Power (Q3, Q4, Q5)	
2	95597957	RESISTOR, 15 W 0.5 Ω +1% Fixed Wire Wound	
3	95597900	RESISTOR, 15 W 1 Ω +10% Fixed Wire Wound	
4	95510026	NUT, Hex	
5	10126103	WASHER, Internal Tooth Lock, #6	used on 5VTN card only
5	10125803	WASHER, Spring Lock, #6	used on AVTN card only
6	94388100	INSULATOR, Transistor Wafer	
7	94261001	HEAT SINK, Transistor	
8	##	TRANSISTOR, SPNP-T03 Darlington Power (Q1, Q2)	



14-3000(1)M

Figure 3-32. Base Assembly (Sheet 1 of 4)

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-32	471718XX	BASE ASSEMBLY (A1) (Sheet 1 of 5)	All units except BK4B7B, BK5A1K, BK5A7M, BK5A9U, BK5C1F. BK5C6D BK5C6D
3-32	92611701	BASE ASSEMBLY (A1)	
1	93755236	SCREW, Washer Pan Head, 10-32 x 5/16	
2	10125607	WASHER, Flat, #10	
3	##	TRANSFORMER, Ferro (AC Power) (A1T1)	
4	94091007	CONNECTOR, (P100) (ASSOCIATED PARTS)	
	51906200	CONTACT, Socket - - - * - - -	
5	95643212	TERMINAL, Quick Connect	
6	10126401	WASHER, External Tooth Lock, #6	
7	10124114	SCREW, Pan Head Machine, 6-32 x 1/2	
8	10125605	WASHER, Flat, #6	
9	70125900	COVER, Fuse Block	
10	95673165	SPACER, Threaded	
11	10125714	SCREW, Flat Head Machine, 6-32 x 3/8	
12	95662500	FUSE BLOCK	
13	10126103	WASHER, Internal Tooth Lock, #6	
14	10127111	SCREW, Pan Head Machine, 6-32 x 1/4	
15	##	FUSE, Cartridge, 10 Amp	
16	##	FUSE, Cartridge, 7 Amp	
17	95688121	SCREW, Flat Head, 6-32 x .375	
18	##	FUSE, Cartridge, 6.25 Amp	
19	10125105	NUT, Machine Screw, 6-32	
20	10126401	WASHER, External Tooth Lock, #6	
21	##	SWITCH, Modified (Run Traiac) (A1K1)	
22	10125907	SCREW, Flat Head Machine, 6-32 x 3/16	

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-32		BASE ASSEMBLY (A1) (Contd)	
23	92633023	BUMPER, Grommet Type	
24	10127320	SCREW, Pan Head Machine, 4-40 x 1/4	
25	##	SWITCH, Deck Interlocking (A1S4)	
26	93749162	SCREW, Washer Pan Head, 6-32 x 3/8	
27	92602001	CLAMP, Nylon Cable	
28	94362600	MOUNT, Shock	
29		POWER SUPPLY ASSEMBLY (See Figure 3-34 or 38)	
30	47172600	BASE	S/C 16 & Blw
30	47331900	BASE	50 Hz S/C 17-30, 60 Hz S/C 17-33
30	730573XX	BASE	50 Hz S/C 31 & Abv. 60 Hz S/C 34 & Abv
31	10125106	NUT, Machine Screw, 8-32	
32	10126402	WASHER, External Tooth Lock, #8	
33	10127121	SCREW, Pan Head Machine, 8-32 x 5/16	
34	47171700	GUIDE, Deck	
35	10126233	SCREW, Socket Hex Head, 10-24 x 3/8	
36	91481473	CABLE, Ground	BK5A7L, BK5A9T, BK5C5A S/C 42 & Abv
37	10125805	WASHER, Spring Lock, #10	
38	75244900	BRACKET, Shock Lock	
39	10125939	SCREW, Flat Head Machine, 6-32 x 5/16	
40	76423801	GASKET, Base Side	
41	10125804	WASHER, Spring Lock, #8	
42	94281495	CABLE, Ground	
43	10126403	WASHER, External Tooth, #10	
44	94374904	STRIP, Contact	60 Hz S/C 49 & Abv only
45	93826236	SCREW, Self-Locking Pan Head, 10-32 x 5/16	
46	76427600	ARM, Case Support	
47	10126404	WASHER, External Tooth, Lock, 1/4	
48	51812019	SCREW, Nylon	BK5A5V/W only

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-32	471718XX	BASE ASSEMBLY (A1) (Contd)	
48	10127141	SCREW, Pan Head Machine 10-32 x5/16	
49	76423800	GASKET, Base Side	
50	##	FILTER, Air	
51	77475800	CLAMP, Air Filter	
52	24501605	BLOCK, Terminal (A1TB1)	
53	24501658	COVER, Terminal Block	
54		CONNECTOR, Socket Housing (See Deck Assembly Sheet 4, For Part Number)	
55	76419000	GASKET, Shock Mount	Used as Spacer Under Shock Mounts
56		CABLE, Ground (Drive Motor Ground Cable. See Drive Motor and Brake Assembly for Part Number)	
57	93541028	TERMINAL, Ring Tongue (Part of W3)	Not used on all units
58	94281327	RECEPTACLE, Slide on (A1S4) (Part of W3)	
59	94309802	POD, Terminal (A1K1) (Part of W1) (Part of W3)	
		(ASSOCIATED PARTS)	
	93747029	RECEPTACLE, Slide on	
		- - - * - - -	




Figure 3-32. Base Assembly (Sheet 2)

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-32		BASE ASSEMBLY (Sheet 2)	
1	93755236	SCREW, Washer Pan Head, 10-32 x 5/16	
2	10126105	WASHER, Internal Tooth Lock, #10	
3	76417700	BRACKET, Capacitor	
4	95027403	TAPE, Double Adhesive Foam	
5	##	CAPACITOR, 50V 21000µf Electrolytic (Servo Capacitor) (A1C1, A1C2)	
6	93750198	SCREW, Pan Head Machine, 8-32 x 5/16	
7	95643601	CLAMP, Capacitor	
8	##	CAPACITOR, 660 VAC 6µf (Transformer Tuning Capacitor) (A1C8)	
9	95582501	BOOT, Double Entrance	
10	10125725	SCREW, Flat Head, 8-32 x 1/2	
11	76422601	WASHER, Special	
12	47173700	PLENUM, Logic Chassis Air	
13	10127121	SCREW, Pan Head Machine, 8-32 x 5/16	
14	10125606	WASHER, Flat, #8	
15	47201500	GASKET, Air Plenum	
16	10127120	SCREW, Pan Head Machine, 8-32 x 1/4	
17	10125804	WASHER, Spring Lock, #8	
18	92826001	BRACKET, Wraparound Capacitor	
19	##	CAPACITOR, 370 VAC 4µf (Blower Motor Start Capacitor) (A1C5)	
20	##	BLOWER ASSEMBLY (A1BM1)	
21	93948003	CONNECTOR, Pin Housing (J301)	
		(ASSOCIATED PARTS)	
	93942001	CONTACT, Pin (.080-.100 D1A)	
	93942002	CONTACT, Pin (.100-.130 D1A)	
		- - - * - - -	
22	94309802	POD, Terminal (ASSOCIATED PARTS)	
	93747022	TERMINAL, Quick Connect (.080-.100 D1A)	
	93747125	TERMINAL, Quick Connect (.100-.130 D1A)	
		- - - * - - -	

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-32		BASE ASSEMBLY (Sheet 2 Contd)	
23	93747022	TERMINAL, Quick Connect	
24	76424400	GASKET, Blower	
25	94364000	GROMMET, Square Shoulder	
26	47201501	TAPE, Foam, 3/8 x 3/8	
27	93541018	TERMINAL, Ring Tongue (Chassis Ground) (Part of W1)	
28		TERMINAL, Quick Connect (See Base Assembly Sheet 1 For Part Number)	
29	93947004	CONNECTOR (P301) (Part of W1) (ASSOCIATED PARTS)	
	93943002	CONTACT, Socket - - - * - - -	
30	75244802	BAR, Buss	
31	10126402	WASHER, External Tooth Lock, #8	
32	95604039	CONNECTOR, Ring Tongue (C1 & C2) (Part of W3)	
33	93755238	SCREW, Pan Head Machine, 10-32 x 3/8	
34	10128141	SCREW, Pan Head Machine, 1-32 x 5/16	2 card power supply only
35	82330800	BRACKET, Capacitor	2 card power supply only
36	95027403	TAPE, Double Adhesive Foam	2 card power supply only
37	10125805	WASHER, Spring Lock, #10	2 card power supply only
38	##	CAPACITOR, 65 DC 16000 μ F (Servo) (A1C3)	2 card power supply only
39	94275215	CLAMP, Hose	2 card power supply only
40	82338200	BRACKET, Capacitor Protection	2 card power supply only
41	94277400	STRAP, Cable Tie	
42	94277503	BASE, Mounting	
43	94385500	GROMMET, Extruded (170 ft.)	BK5A5V/W only




Figure 3-32. Base Assembly (Sheet 3)

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-32		BASE ASSEMBLY (Sheet 3)	
1	##	ELAPSED TIME METER (A1M1)	
2		HARDWARE, Attaching	Supplied With Elapsed Time Meter
3	75256100	PLATE, Component Mounting	
4	93749158	SCREW, Washer Pan Head, 6-32 x 1/4	
5	93541012	TERMINAL, Ring Tongue (Part of W12)	
6	93749086	SCREW, Washer Pan Head, 4-40 x 3/8	
7	10127113	SCREW, Pan Head Machine, 6-32 x 3/8	
8	##	CIRCUIT BREAKER (AC Power Circuit Breaker) (A1CB1)	
9	##	CIRCUIT BREAKER (Power Supply Circuit Breaker) (A1CB2)	
10	76416500	INSULATOR, Terminal	
11		NUT, Hex	Supplied With Circuit Breakers
12	10126105	WASHER, Internal Tooth Lock, #10	
13	75259400	POWER CABLE ASSEMBLY	60 Hz
13	75259401	POWER CABLE ASSEMBLY	50 Hz
14	92801010	CLAMP, Cable	
15	10127141	SCREW, Pan Head Machine, 10-32 x 5/16	
16	10126403	WASHER, External Tooth Lock, #10	
17	95672701	BUMPER, Molded Recess	
18	##	FILTER, Line (A1FL1)	
19		HARDWARE, Attaching	
20		COVER, Line Filter	Supplied With Line Filter
21	10127121	SCREW, Pan Head Machine, 8-32 x 5/16	
22	10126402	WASHER, External Tooth Lock, #8	
23	10125606	WASHER, Flat, #8	
24	10126401	WASHER, External Tooth Lock, #6	
25	94369552	CABLE, Ground	
26	93541028	TERMINAL, Ring Tongue (Part of W1)	
27	93541018	TERMINAL, Ring Tongue (Part of W1)	

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-32		BASE ASSEMBLY (Sheet 3) (Contd)	
28	93541021	TERMINAL, Ring Tongue (Part of W1)	
29	75073100	SPACER, Flat	
30	95660411	TAPE, Nylon	
31	10125108	NUT, Hex, 10-32	
32	##	VARISTOR	50 Hz, 220/240
33	92261118	SLEEVING	50 Hz, 220/240
34	93541012	TERMINAL, Ring Tongue	50 Hz, 220/240
35	40125601	TERMINAL, Quick Connect	
36	93326004	STUD, Ball	
37	10125803	WASHER, Spring Lock, #6	
38	94369569	CABLE, Ground	BK5A7L only; Other end attached to frame ground
	95604057	TERMINAL, Ring Tongue	

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-32		BASE ASSEMBLY (Sheet 4)	
1	##	ELAPSED TIME METER (A1M1)	Supplied with Elapsed Time Meter
2		HARDWARE, Attaching	
3	75256100	PLATE, Component Mounting	
4	93749158	SCREW, Pan Head Machine, 6-32 x 1/4	
5	93541012	TERMINAL, Ring Tongue (Part of W1 & W2)	
6	93749086	SCREW, Phillips Pan Head Machine, 4-40 x 3/8	
7	10127113	SCREW, Pan Head Machine, 6-32 x 3/8	
8	##	CIRCUIT BREAKER (AC Power Circuit Breaker) (A1CB1)	
9	##	CIRCUIT BREAKER (Power Supply Circuit Breaker) (A1CB2)	
10	76416500	INSULATOR, Terminal	Supplied with Circuit Breakers
11		NUT, Hex	
12	10126105	WASHER, Internal Tooth Lock, #10	
13	75168300	POWER CORD	50 Hz
13	75168302	POWER CORD	60 Hz; All units except BK5C1J
13	75168312	POWER CORD	BK5C1J only
14	10127143	SCREW, Pan Head Machine, 10-32 x 5/16	
15	10126403	WASHER, External Tooth Lock, #10	
16	95672701	BUMPER, Molded Recess	
17	##	FILTER, Line (A1FL1)	
18	10127113	SCREW, Pan Head Machine, 6-32 x 3/8	
19	10126401	WASHER, External Tooth Lock, #6	
20	94369552	CABLE, Ground	All units except BK5A5V/W
21	93541028	TERMINAL, Ring Tongue (Part of W1)	
22	93541018	TERMINAL, Ring Tongue (Part of W1)	
23	95660411	TAPE, Nylon	
24	10125108	NUT, Hex, 10-32	




Figure 3-32. Base Assembly (Sheet 4)

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-32		BASE ASSEMBLY (Sheet 4) (Contd)	
25	94274140	TERMINAL, Quick Connect	All units S/C 41 & Blw. All units except BK5A7L, BK5A9T, BK5C5A S/C 42 & Abv
26	75070702	BUMPER, Stop	Glued to base pan. See table 2-1 for adhesive.
27	10127121	SCREW, Pan Head Machine, 8-32 x 5/16	
28	##	VARISTOR	
29	92261118	SLEEVING	
30	24501602	BLOCK, Terminal	
31	24501658	BLOCK, Terminal Caps	
32	93749162	SCREW, Pan Head, 8-32 x 3/8	
33	45584801	CLAMP, Cable	
34	10127114	SCREW, Pan Head Machine, 6-32 x 1/2	
35	10125605	WASHER, Flat, #6	
36	92602005	CLAMP, Nylon	
37	10127142	SCREW, Pan Head, 10-32 x 3/8	
	94391546	LABEL, Warning Information (Not Shown)	
38	10125106	NUT, Hex, 8-32)
39	10126402	WASHER External Tooth Lock, #8)
40	10126104	WASHER Internal Tooth Lock, #8)S/C 40 W/)DJ00030 & Abv)
41	93541018	TERMINAL, Ring Tongue)
42	94296700	CABLE, Ground) BK5A7L, BK5A9T, BK5C5A S/C 42 & Abv
43	10125066	SCREW, Hex Head Machine 10-32 x 1)
44	94047052	WASHER, Special)
45	94369545	CABLE, Ground) BK5A5V/W only
46	10125607	WASHER, Flat, #10)
47	75062803	WASHER, Shoulder)
48	75062400	WASHER, Insulator)
49	94369504	CABLE, Ground)




Figure 3-32. Base Assembly (Sheet 5)

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-32		BASE ASSEMBLY (Sheet 5)	
1	75038333	BRACKET, Strain Relief & Ground	
2	81567761	CLAMP, Shielded Cable	
3	10127144	SCREW, Pan Head Machine, 10-32 x 5/8	
4	10126403	WASHER, External Tooth Lock, #10	
5	81567760	CLAMP, Shielded Cable	
6	10127143	SCREW, Pan Head Machine, 10-32 x 1/2	
7	10125108	NUT, Hex, 10-32	
8	10127141	SCREW, Pan Head Machine, 10-32 x 5/16	
9	10126105	WASHER, Internal Tooth, #10	
10	10125607	WASHER, Flat, #10	
11	75038331	HOUSING, Extension	
12	93592082	SCREW, Hex Head, 4-40 x 1/4	
13	75038332	COVER, Housing	




Figure 3-33. Base Assembly 832619XX (Sheet 1 of 4)

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-33	832619XX	BASE ASSEMBLY (A1) (Sheet 1 of 4)	BK4B7B, BK5A1K, BK5A7M, BK5A9U & BK5C1F only
1	10127141	SCREW, Pan Head Machine, 10-32 x 5/16	
2	24501605	BLOCK, Terminal (A1TB1)	
3	10125607	WASHER, Flat, #10	
4	##	TRANSFORMER, Ferro (AC Power) (A1T1)	
5	94091007	CONNECTOR, (P100) (ASSOCIATED PARTS)	
	93943003	CONTACT, Socket - - - * - - -	
6	95643212	TERMINAL, Quick Connect	
7	10127320	SCREW, Pan Head Machine, 4-40 x 1/4	
8	##	SWITCH, Deck Interlock (A1S4)	
9	10127113	SCREW, Washer Pan Head, 6-32 x 3/8	
10	24501658	COVER, Terminal Block	
11	10125605	WASHER, Flat, #6	
12	92602001	CLAMP, Nylon Cable	
13	##	SWITCH, Modified (Run Triac) (A1K1)	
14	10125106	NUT, Machine Screw, 8-32	
15		POWER SUPPLY ASSEMBLY (See Figure 3-34 or 3-38)	
16	94362600	MOUNT, Shock	
17	92633023	BUMPER, Grommet Type	
18	10125711	SCREW, Flat Head Machine, 6-32 x 3/16	
19	47331900	BASE	S/C 30 & Blw
19	730573XX	BASE	S/C 31 & Abv
20	10127121	SCREW, Pan Head Machine, 8-32 x 5/16	
21	10126402	WASHER, External Tooth Lock, #8	
22	47171700	GUIDE, Deck	
23	10126243	SCREW, Socket Hex Head, 10-32 x 3/8	
24	10125805	WASHER, Spring Lock, #10	
25	75244900	BRACKET, Shock Lock	
26	76423801	GASKET, Base Side	
27	94369536	CABLE, Ground	
28	92826236	SCREW, Self-Locking Pan Head, 10-32 x 5/16	
29	76427600	ARM, Case Support	

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-33	832619XX	BASE ASSEMBLY (A1) (Sheet 1) (Contd)	
30	##	FILTER, Air	
31	10125804	WASHER, Spring Lock, #8	
32	77475800	CLAMP, Air Filter	
33	76423800	GASKET, Base Side	
34	10125939	SCREW, Flat Head Machine, 6-32 x 5/16	
35	10125801	WASHER, Spring Lock, #4	
36	10125803	WASHER, Spring Lock, #6 (ITEMS LISTED BELOW THIS NOTE ARE NOT PART OF THE BASE ASSEMBLY)	
37		CONNECTOR, Socket Housing (See Deck Assembly Sheet 4 for Part Number)	
38	76419000	GASKET, Shock Mount	Used as Spacer under Shock Mounts
39		CABLE, Ground (Drive Motor Ground Cable See Drive Motor and Brake Assembly for Part Number)	
40	95604057	CONNECTOR, Ring Tongue (Part of W3)	
41	94281327	RECEPTACLE, Slide On (A1S4) (Part of W3)	
42	94309802	POD, Terminal (A1K1) (Part of W1) (Part of W3) (ASSOCIATED PARTS)	
	93747029	RECEPTACLE, Slide On - - - * - - -	
43	10125105	NUT, Machine Screw, 6-32	
44	10126401	WASHER, External Tooth Lock, #6	
45	94281473	CABLE, Ground	BK5A9U, BK5A7M, BK5C5B S/C 42 & Abv
46	10127141	SCREW Pan Head Machine, 10-32 x 5/16	
47	10126403	WASHER, External Tooth, #10	
48	10126404	WASHER, External Tooth Lock, 1/4	




Figure 3-33. Base Assembly (Sheet 2)

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-33		BASE ASSEMBLY (Sheet 2)	
1	10127141	SCREW, Pan Head Machine, 10-32 x 5/16	
2	10125805	WASHER, Spring Lock, #10	
3	82330800	BRACKET, Capacitor	
4	95027403	TAPE, Double Adhesive Foam	
5	##	CAPACITOR, 50V 21000µf Electrolytic (Servo Capacitor (A1C1, A1C2)	
6	93755236	SCREW, Pan Head Machine, 10-32 x 5/16	
7	95643601	CLAMP, Capacitor	
8	##	CAPACITOR, 660 VAC 6µf (Transformer Tuning Capacitor) (A1C8)	
9	95582501	BOOT, Double Entrance	
10	10125725	SCREW, Flat Head, 8-32 x 1/2	
11	76422601	WASHER, Special	
12	47173700	PLENUM, Logic Chassis Air	
13	10127120	SCREW, Pan Head Machine, 8-32 x 1/4	
14	10125606	WASHER, Flat, #8	
15	47201501	GASKET, Air Plenum	
16	10127121	SCREW, Pan Head Machine, 8-32 x 5/16	
17	10125804	WASHER, Spring Lock, #8	
18	92826001	BRACKET, Wraparound Capacitor	
19	##	CAPACITOR, 370 VAC 4µf (Blower Motor Start Capacitor) (A1C5)	
20	##	BLOWER ASSEMBLY (A1BM1)	
21	51905901	CONNECTOR, Pin Housing (J301)	
		(ASSOCIATED PARTS)	
	51905802	CONTACT, Pin (.080-.100 DIA)	
	51905815	CONTACT, Pin (.100-.130 DIA)	
		- - - * - - -	
22	94309802	POD, Terminal (ASSOCIATED PARTS)	
	93747025	TERMINAL, Quick Connect (.100-.130 DIA)	
		- - - * - - -	

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-33		BASE ASSEMBLY (Sheet 2) (Contd)	
23	93747022	TERMINAL, Quick Connect	
24	76424400	GASKET, Blower	
25	94364000	GROMMET, Square Shoulder	
26	93755238	SCREW, Pan Head Machine, 10-32 x 3/8	
27	93541018	TERMINAL, Ring Tongue (Chassis Ground) (Part of W1)	
28		TERMINAL, Quick Connect (See Base Assembly Sheet 1 For Part Number)	
29	51906001	CONNECTOR (P301) (Part of W1) (ASSOCIATED PARTS)	
	51906202	CONTACT, Socket - - - * - - -	
30	75244802	BAR, Buss	
31	10126402	WASHER, External Tooth Lock, #8	
32	95604039	CONNECTOR, Ring Tongue (C1 & C2) (Part of W3)	
33	##	CAPACITOR, 65 VCD 16000 μ f (Retract) (A1C7)	
34	94275215	CLAMP, Hose	
35	82338200	BRACKET, Capacitor Protection	
36	94277503	BASE, Mounting	
37	94277400	STRAP, Cable Tie	




Figure 3-33. Base Assembly (Sheet 3)

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-33		BASE ASSEMBLY (Sheet 3)	
1	##	ELAPSED TIME METER (AlM1)	
2		HARDWARE, Attaching	Supplied with Elapsed Time Meter
3	75256100	PLATE, Component Mounting	
4	93749158	SCREW, Pan Head Machine, 6-32 x 1/4	
5	10125803	WASHER, Spring Lock, #6	
6	10127104	SCREW, Pan Head Machine, 4-40 x 3/8	
7	10125801	WASHER, Spring Lock, #4	
8	##	CIRCUIT BREAKER (AC Power Circuit Breaker) (AlCB1)	
9	##	CIRCUIT BREAKER (Power Supply Circuit Breaker) (AlCB2)	
10	76416500	INSULATOR, Terminal	
11		NUT, Hex	Supplied with Circuit Breakers
12	10126105	WASHER, Internal Tooth Lock, #10	
13	83269311	POWER CABLE ASSEMBLY	
14	92801010	CLAMP, Cable	
15	10127142	SCREW, Pan Head Machine, 10-32 x 3/8	
16	10125805	WASHER, Spring Lock, #10	
17	95672701	BUMPER, Molded Recess	
18	##	FILTER, Line (AlFL1)	
19		HARDWARE, Attaching	Supplied with Line Filter
20		COVER, Line Filter	
21	10127120	SCREW, Pan Head Machine, 10-32 x 5/16	
22	10125804	WASHER, Spring Lock, #10	
23	10125606	WASHER, Flat, #10	
24	10127113	SCREW, Pan Head Machine, 6-32 x 3/8	
25	94369552	CABLE, Ground	
26	93541028	TERMINAL, Ring Tongue (Part of W1)	
27	93541018	TERMINAL, Ring Tongue (Part of W1)	
28	93541021	TERMINAL, Ring Tongue (Part of W1)	
29	75073100	SPACER, Flat	
30	95660411	TAPE, Nylon	
31	10125108	NUT, Hex, 10-32	

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-33		BASE ASSEMBLY (Sheet 3) (Contd)	
32	10126403	WASHER, External Tooth Lock, #10	
33	10126401	WASHER, External Tooth Lock, #6	
34	93541012	TERMINAL, Ring Tongue (Part of W12)	
35	##	VARISTOR	50 Hz, 220/240 only
36	92261118	SLEEVING	50 Hz, 220/240 only
37	93541046	TERMINAL, Ring Tongue	50 Hz, 220/240 only





Figure 3-33. Base Assembly (Sheet 4)

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-33		BASE ASSEMBLY (Sheet 4)	
1	##	ELAPSED TIME METER (A1M1)	
2		HARDWARE, Attaching	Supplied with Elapsed Time Meter
3	75256100	PLATE, Component Mounting	
4	93749158	SCREW, Pan Head Machine, 6-32 x 1/4	
5	10127104	SCREW, Pan Head Machine, 4-40 x 3/8	
6	10125801	WASHER, Spring Lock, #4	
7	##	CIRCUIT BREAKER (Power Supply Circuit Breaker) (A1CB2)	
8	##	CIRCUIT BREAKER (AC Circuit Breaker) (A1CB1)	
9	76416500	INSULATOR, Terminal	
10	93541012	TERMINAL, Ring Tongue (Part of W1 & W12)	
11	93541018	TERMINAL, Ring Tongue (Part of W1)	
12	10126105	WASHER,	
13		NUT, Hex	Supplied with Circuit Breakers
14	##	FILTER, Line (A1FL1)	
15	10125108	NUT, Hex Machine, 10-32	
16	10126403	WASHER, External Tooth Lock, #10	
17	95672701	BUMPER, Molded Recess	Not used on all units
18	10127143	SCREW, Pan Head, 10-32 x 1/2	
19	10127113	SCREW, Pan Head, 6-32 x 3/8	
20	10125803	WASHER, Spring Lock, #6	
21	45584801	CLAMP, Cable	
22	10127114	SCREW, Pan Head, 6-32 x 1/2	
23	10126401	WASHER, External Tooth Lock, #6	
24	10125605	WASHER, Flat, #6	
25	92602005	CLAMP, Nylon Cable	
26	75168300	POWER CABLE	
27	93749162	SCREW, Washer External Tooth, 8-32 x 3/8	
28	75070702	BUMPER, Stop	
29	10127121	SCREW, Pan Head, 8-32 x 5/16	
30	24501602	BLOCK, Terminal	

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-33		BASE ASSEMBLY (Sheet 4) (Contd)	
31	24501658	CAPS, Terminal Block	
32	##	VARISTOR	
33	92261118	SLEEVING	
34	95660411	TAPE, Nylon	
35	10127142	SCREW, Pan Head, 10-32 x 3/8	
36	10127112	SCREW, Pan Head, 6-32 x 5/16	
37	94369515	CABLE, Ground	
38	94281430	CABLE, Ground	BK5A7M S/C 41 & Blw only
38	94296700	CABLE, Ground	Used on BK5A9U, BK5A7M, BK5C5B S/C 42 & Abv
39	10125106	NUT, Hex, 8-32)
40	10126402	WASHER External Tooth Lock, #8)
41	10126104	WASHER Internal Tooth Lock, #8)S/C 40 W/)DJ00030 & Abv
42	93541018	TERMINAL, Ring Tongue)



14-3100F

Figure 3-34. 3 Card Power Supply Assembly

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-34	47174000	3 CARD POWER SUPPLY ASSEMBLY	S/C 20 & Blw
1	47170800	CHASSIS, Power Supply	
2	10127113	SCREW, Phillips Pan Head Machine, 6-32 x 3/8	
3	10125803	WASHER, Spring Lock, #6	
4	93114322	STANDOFF, Tapped Hex, 6-32 x 2	
5	77568300	MOTHERBOARD (Component Assembly Type _VQN)	
6	95510024	NUT, Hex	
7	10126101	WASHER, Internal Tooth Lock, #4	
8	10125603	WASHER, Flat, #4	
9	94378503	RELAY, Clip Plug	
10	94378509	RELAY, 11 Pin Plug 3 Pole (Emergency Retract) (A1K2)	
10A	10125605	Washer, Flat, #6 (ITEMS LISTED BELOW THIS NOTE ARE NOT PART OF THE POWER SUPPLY ASSEMBLY)	
11	10125909	SCREW, Flat Head, 6-32 x 5/16	
12		COMPONENT ASSEMBLY, Type _SJV (+42V Power Supply and Emergency Retract) (A1A01) (See Figure 3-35)	
13		COMPONENT ASSEMBLY, Type _SKV (+20V, +12V Power Supply) (A1A02) (See Figure 3-36)	
14		COMPONENT ASSEMBLY, Type _SHV (+5V Power Supply) (A1A03) (See Figure 3-37)	
15		CONNECTOR (P100) (See Base Assembly Sheet 1 For Part Number)	
16	51906005	CONNECTOR (P1A) (Part of W3) (ASSOCIATED PARTS)	
	51906200	CONTACT, Socket - - - * - - -	
17	51906006	CONNECTOR (P1B) (Part of W3) (ASSOCIATED PARTS)	
	51906200	CONTACT, Socket - - - * - - -	
18	47174800	COVER, Power Supply	
19	10125606	WASHER, Flat, #8	
20	10126402	WASHER, External Tooth Lock, #8	
21	10127122	SCREW, Pan Head Machine, 8-32 x 1/32	
22	83274400	LABEL, Chassis Map	





Figure 3-35. Component Assembly, Type _SJV
Used on 3 Card Power Supply Only


INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-35	##	COMPONENT ASSEMBLY, Type _SJV (\pm 42V Power Supply and Emergency Retract) (A1A01)	3 card power supply only
1	95575000	RECTIFIER, Hi-Current Silicon	
2	94383701	CAPACITOR, 5,500 UF 50 V \pm 100% -10% Electrolytic	
3	##	FUSE, 6 Amp Quick-Acting	
4	95597919	RESISTOR, 510 Ω \pm 10% 15W Fixed	
5	92496185	CAPACITOR, 82,000 PF 200 V \pm 10% Nonelectrolytic	
6	95212446	RESISTOR, 2 W 1,000 Ω \pm 10%	



14-3300A

Figure 3-36. Component Assembly, Type _SKV
Used on 3 Card Power Supply Only

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-36	##	COMPONENT ASSEMBLY, Type _SKV (<u>+20 V, +12 V Power Supplies</u>) (A1A02)	3 card power supply only
1	94383702	CAPACITOR, 14,000 UF 15 V +100% -10% Electrolytic	
2	94383700	CAPACITOR, 7,500 UF 35 V +100% -10% Electrolytic	
3	95594112	RESISTOR, 51 Ω +10% 10 W Fixed	
4	##	FUSE, 2 Amp Quick-Acting	
5	50240415	DIODE, 12 V +5% Silicon	
6	10125108	NUT, Hex, 10-32	
7	10125805	WASHER, Spring Lock, #10	
8	50240515	DIODE, 10 W 12 V +5% Zener Silicon	
9	47478600	HEAT SINK	
10	95575000	RECTIFIER, Hi Current Silicon	
11	92512825	RESISTOR, 1,000 Ω +5% 1/2 W	



14-3400A

Figure 3-37. Component Assembly, Type _SHV
Used on 3 Card Power Supply Only

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-37	##	COMPONENT ASSEMBLY, Type _SHV (± 5 V Power Supply) (A1A03)	3 card power supply only
1	94383702	CAPACITOR, 14,000 UF 15 V $\pm 100\%$ -10% Electrolytic	
2	92427152	CAPACITOR, 1,500 UF 16 V $\pm 100\%$ -10% Electrolytic	
3	92825001	RESISTOR, 7 W, 0.1 Ω $\pm 1\%$ Wire Wound Fixed Power	
4	50221301	TRANSISTOR, Silicon Power (Q4, Q9, Q10)	
5	95510026	NUT, Hex	
6	10126103	WASHER, Internal Tooth Lock, #6	
7	94261001	HEAT SINK, Transistor	
8	92512913	RESISTOR, 33 Ω $\pm 10\%$ 2 W	
9	92427133	CAPACITOR, 100 UF 15 V +75% -10% Electrolytic	
10	92617031	POTENTIOMETER, 2.00 Ω Wire Wound	
11	##	FUSE, 6 Amp Quick-Acting	
12	92512256	RESISTOR, 1,800 Ω $\pm 5\%$ 1/4 W	
13	92512151	RESISTOR, 56 Ω $\pm 5\%$ 1/4 W	
14	92512248	RESISTOR, 68 Ω $\pm 5\%$ 1/4 W	
15	92512259	RESISTOR, 5,600 Ω $\pm 5\%$ 1/4 W	
16	92512157	RESISTOR, 470 Ω $\pm 5\%$ 1/4 W	
17	94356143	CAPACITOR, 560 PF 200 V Nonelectrolytic	
18	95596100	VOLTAGE REGULATOR, I-C	
19	92512160	RESISTOR, 2,200 Ω $\pm 5\%$ 1/4 W	
20	50240108	DIODE, 7 Ω $\pm 5\%$ 6.2 V Silicon	
21	50221401	TRANSISTOR, Power PNP Silicon (Q6)	
22	92427139	CAPACITOR, 45 UF 30 V $\pm 20\%$ Electrolytic	
23	94262016	TRIAC, Bi-Directional	
24	94360322	RESISTOR, 1,690 Ω $\pm 1\%$	
25	92512245	RESISTOR, 27 Ω $\pm 5\%$ 1/4 W	
26	92583002	NUT, Lock	

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-37	##	COMPONENT ASSEMBLY, Type _SHV (Contd)	
27	10126101	WASHER, Internal Tooth Lock, #4	
28	95592500	VOLTAGE, Negative I-C Regulator	
29	50210610	TRANSISTOR, 25 V SPNP	
30	50221001	TRANSISTOR, 60 V SPNP	
31	92427089	CAPACITOR, 22 UF 15 V $\pm 10\%$ Electrolytic	
32	95597946	RESISTOR, 15 W 0.62 Ω $\pm 10\%$ Fixed Wire Wound	
33	94354826	CAPACITOR, 0.1 UF $\pm 20\%$ Ceramic High K	
34	95575000	RECTIFIER, Hi Current Silicon	
35	92427087	CAPACITOR, 4.7 UF 50 V $\pm 20\%$ Electrolytic	





Figure 3-38. 2 Card Power Supply Assembly

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-38		2 CARD POWER SUPPLY ASSEMBLY	S/C 21 & Abv
		NOTE:	
		All parts listed below are field replaceable and must be ordered separately.	
1	10127122	SCREW, Pan Head Machine, 8-32 x 3/8	All units except BK5A5V/W
1	93342191	SCREW, Nylon, 8-32 x 3/8	BK5A5V/W only
2	10125804	WASHER, Spring Lock, #8	
3	82335200	COVER, Power Supply	
4	##	COMPONENT ASSEMBLY, Type _XKV (See Figure 3-39)	
5	10126402	WASHER, External Tooth Lock, #8	
6	47289700	BASE, Power Supply	
7	10125909	SCREW, Flat Head Machine, 6-32 x 5/16	
8	93749087	SCREW, Pan Head Machine, 4-40 x 7/16	
9	10125606	WASHER, Flat, #8	
10	##	COMPONENT ASSEMBLY, Type _XFV	
11	73028800	COVER, Protective	
12	10125603	WASHER, Flat, #4	
13	93749200	SCREW, Phillips Pan Head Machine	
14	73078200	Insulator, Hybrid	Not used on all units
15	93564001	WASHER, Nylon, 3/16	BK5A5V/W only

FOR
OPPOSITE
SIDE OF CARD
SEE SHEET 2



14-3800(1)D

Figure 3-39. Component Assembly, Type_XKV (Sheet 1 of 2)
Used on 2 Card Power Supply Only

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-39	##	COMPONENT ASSEMBLY, Type _XKV (Power Supply) (Sheet 1 of 2)	2 card power supply only
1	95587700	NUT, Push-in Expansion	
2	95655530	SCREW, Sheet Metal Pan Head, 8-18 x 1/2	
3	95524700	TERMINAL, Quick Connect	
4	93549019	BUMPER, Nylon	
5	95575001	RECTIFIER, Hi Current Silicon	
6	92496127	CAPACITOR, 0.01 UF 200 V Non-electrolytic	
7	92512933	RESISTOR, 560 Ω 2 W	
8	92512859	RESISTOR, 47 Ω 1/2 W	
9	95594119	RESISTOR, 510 Ω 10 W Fixed	
10	95588400	CLIP, Fuse	
11	##	FUSE, Amp Cartridge, 6.25	All units except BK5B1E/F, BK5A8E/F
	##	FUSE, Quick Acting, 8 Amp	BK5B1E/F BK5A8E/F only
12		NOT USED	
13	##	FUSE, Cartridge	All units except BK5B1E/F, BK5A8E/F
13	##	FUSE, Quick Acting, 5 Amp	BK5B1E/F BK5A8E/F only
14	92427027	CAPACITOR 35 V \pm 20% Electrolytic	
15	95575000	RECTIFIER, Hi Current Silicon	
16	95882803	PIN HEADER ASSEMBLY	
17	95524401	WASHER, Lock	
18	94047078	WASHER, Special	
19	92751158	SCREW, Pan Head Machine, 6-32 x 1/4	
20	95882804	PIN HEADER ASSEMBLY	
21	94395528	CAPACITOR, 220 UF Electrolytic	
22	94389102	RESISTOR, Flameproof 2 W	
23	95593201	RECEPTACLE, PC BOARD	
24	94825900	RECTIFIER, Silicon	
25	15162000	REGULATOR, Voltage Hybrid	

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-39	##	COMPONENT ASSEMBLY, Type _XKV	2 card power (Power Supply) (Sheet 1 Contd) supply only
26	92512242	RESISTOR, 15 Ω 1/4 W	
27	94360331	RESISTOR, 2100 Ω 1/4 W	
28	94360317	RESISTOR, 1500 Ω 1/4 W	
29	94391208	POTENTIOMETER	
30	92512807	RESISTOR, 120 Ω 1/2 W	
31	24553500	DIODE, Silicon	
32	50211411	TRANSISTOR, SPNP 40 V	
33	95653100	LABEL, High Voltage	
34	94360378	RESISTOR, 6490 Ω 1/4 W	
35	92496157	CAPACITOR, 4700 PH 200 V Non-Electrolytic	




Figure 3-39. Component Assembly, Type_XKV (Sheet 2)
Used on 2 card Power Supply Only

INDEX NO	PART NO	PART DESCRIPTION	NOTE
3-39		COMPONENT ASSEMBLY, Type _XKV (Power Supply) (Sheet 2)	2 card power supply only
1	76871500	CHASSIS, Power Supply	
2	94261000	HEAT SINK, Transistor	
3	92751168	SCREW, Phillips Head Machine, 6-32 x 3/4	
4	95644205	BUSHING, Insulation	
5	94783900	WASHER, Mica	
6	95797301	WASHER, Phenolic	
7	95524401	WASHER, Lock	
8	94047078	WASHER, Special	
9	95524700	TERMINAL, Quick Connect	
10	95643216	CONNECTOR, Quick Connect	
11	94383709	CAPACITOR, Electrolytic (C5)	
12	94277422	STRAP, Cable Tie	
13	95661328	CAPACITOR, 27 000 UF 18 V (C2)	
14	94383710	CAPACITOR, Electrolytic (C12, C15)	
15	95604039	CONNECT, Ring Tongue	
16	93234236	SCREW, Pan Head Machine, 10-32 x 5/16	
17	95524408	WASHER, Lock	
18	94047081	WASHER, Special	
19	94277400	STRAP, Cable Tie	
20	50223800	TRANSISTOR, SNPN Darlington (Q5, Q6)	

SECTION 3B

SPARE PARTS LIST

SPARE PARTS LIST

3B

GENERAL

The Spare Parts List serves as an aid in determining the interchangeability of assemblies and parts to be spared. An example of the columns used in the Spare Parts List is shown on the next page.

NOTE

The spare parts list establishes the support service level of the unit. Individual parts, assemblies, or components not on this list may be long lead time items subject to significant delays.

The Spare Parts List is divided into four columns:

Items Appear On - This column cross-references the part number in the spare parts list to the associated figure number, page number, and index number in the illustrated parts breakdown.

Description - This column gives the name and a brief description of the part or assembly. This column also tracks series code history information.

Part Number - Contains the part number of the part when the unit was manufactured or as a result of the latest FCO. This part can be used as a replacement on the series code and types of units indicated in the Description and Notes columns. However, always use Replacement Part Number when ordering new parts or spares.

Replacement Part Number - Contains the interchangeable replacement part number. Use this number for ordering replacement or spare parts.

Notes - This column provides additional information such as Field Change Order (FCO), Special Purchase Order (SPO), serial number, and machine configuration.

EXAMPLE OF SPARE PARTS LIST

ENGINEERING RECOMMENDED SPARE PARTS LIST						
ITEMS APPEAR ON			DESCRIPTION	PART NUMBER	REPLACE- MENT PART NUMBER	NOTES
Fig.	Page	Index				
No.	No.	No.				
3-11	3-37	25	CONTROL PANEL ASSEMBLY, A3A01 Used S/C 14 and above	WWWWW	XXXXX	

In the example above, the control panel assembly is referenced as index 25 on figure 3-11, which appears on page 3-37. The original part number was WWWWW; order part number XXXXX if it

must be replaced. WWWWW cannot be ordered from the factory but field spares can still be used on series code 14 and above units.

ENGINEERING RECOMMENDED SPARE PARTS LIST

ITEMS APPEAR ON Fig. Page Index No. No. No.	DESCRIPTION	PART NUMBER	REPLACE- MENT PART NUMBER	NOTES
---	-------------	----------------	---------------------------------	-------

COMPONENT ASSEMBLIES

LOGIC

3-22	3-81	10	_LSV Comp. Assy, Loc A2A01 CLSV - Used S/C 10 & above	54276503	54276503	
3-22	3-81	10	_FRV Comp. Assy, Loc A2A03 GFRV - Used S/C 10 & above HFRV - Used S/C 10 & above	54226112 54226113	54226112 54226113	BK4XX BK5XX
3-22	3-81	10	_KFV Comp. Assy, Loc A2A04 DKFV - Used s/C 10 & above RKFV - Used S/C 20 & above	54262104 54262119	54262104 54262119	All units except BK4B7A/B & BK5C1E/F/J/K BK4B7A/B & BK5C1E/F/J/K
3-22	3-81	10	_LRV Comp. Assy, Loc A2A05 HLRV - Used S/C 10 & above KLRV - Used S/C 21 & above	54276108 54276111	54276108 54276111	All units except BK4A5E/F, BK5A1J/L, BK5A5V/W, BK5B6A-D BK5B6A-D, BK4A5E/F, BK5A1J/L BK5A5V/W
3-22	3-81	10	_LZV Comp. Assy, Loc A2A06 BLZV - Used S/C 10 & above	54279303	54279303	

ENGINEERING RECOMMENDED SPARE PARTS LIST

ITEMS APPEAR ON			DESCRIPTION	PART NUMBER	REPLACE- MENT PART NUMBER	NOTES
Fig. No.	Page No.	Index No.				

COMPONENT ASSEMBLIES (Contd)

LOGIC (Contd)

3-22	3-81	10	_LQV Com. Assy, Loc A2A07			
			BLQV - Used S/C 10 - 23	54275703	54275713	BK4XX
			LLQV - Used S/C 24 - 32	54275712	54275713	BK4XX
			MLQV - Used S/C 33 & above	54275713	54275713	BK4XX
			JLQV - Used S/C 10-40	54275710	54275715	BK5XX
			NLQV - Used S/C 41 & above	54275715	54275715	BK5XX
3-22	3-81	10	_LUV Comp. Assy, Loc A2A08			
			ELUV - Used S/C 10 & above	54277306	54277306	BK5XX
			FLUV - Used S/C 10 & above	54277307	54277307	BK4XX
3-22	3-81	10	_LPV Comp. Assy, Loc A2A09			
			FLPV - Used S/C 10 & above	54275307	54275307	
3-22	3-81	10	_SGV Comp. Assy, Loc A2A10			
			6SGV - Used S/C 10 & above	54152501	54152501	All units except BK5C4R/S
			KSGV - Used S/C 48 & above	54152529	54152529	BK5C4R/S
3-22	3-81	10	_TVV Comp. Assy, Loc A2B01			
			FTVV - Used S/C 10 & above	54167707	54167707	CH I, units w/ 50/60 pin I/O only
			GTVV - Used A/C 10 & above	54167708	54167708	CH I, units w/ S & IOBC only

ENGINEERING RECOMMENDED SPARE PARTS LIST

ITEMS APPEAR ON			DESCRIPTION	PART NUMBER	REPLACE- MENT PART NUMBER	NOTES
Fig. No.	Page No.	Index No.				

COMPONENT ASSEMBLIES (Contd)

LOGIC (Contd)

3-22	3-81	10	_RVV Comp. Assy, Loc A2B02 JRJV - Used S/C 10 & above	54147711	54147711	
3-22	3-81	10	_TVV Comp. Assy, Loc A2B03 FTVV - Used S/C 10 & above	54167707	54167707	CH II, units w/ 50/60 pin I/O only.
			GTVV - Used S/C 10 & above	54167708	54167708	CH II, units w/ S & IOBC only.
3-22	3-81	10	_RVV Comp. Assy, Loc A2B04 JRJV - Used S/C 10 & above	54147711	54147711	Dual channel only
3-22	3-81	10	_KHV Comp. Assy, Loc A2B05 AKHV - Used S/C 10-14 BKHV - Used S/C 15-17 EKHV - Used S/C 17 & above	54272902 54262903 54262906	54262906 54262906 54262906	Dual channel only
3-22	3-81	10	_LWV Comp. Assy, Loc A2B06 FLWV - Used S/C 10 & above	54278107	54278107	

ENGINEERING RECOMMENDED SPARE PARTS LIST

ITEMS APPEAR ON			DESCRIPTION	PART NUMBER	REPLACE- MENT PART NUMBER	NOTES
Fig.	Page	Index				
No.	No.	No.				

COMPONENT ASSEMBLIES (Contd)

LOGIC (Contd)

3-22	3-81	10	- LXV Comp. Assy, Loc A2B07			
			DLXV - Used S/C 10 & above	54278504	54278504	BK4XX
			ELXV - Used S/C 10 & above	54278505	54278505	BK5XX; units W/O S & IOABC
			FLXV - Used S/C 30 & above	54278508	54278508	BK5XX; units W/ S & IOABC
			LLXV - Used S/C 56 & above	54278515	54278515	BK5A3N/P, BK5C7C/D
3-22	3-81	10	- LTV Comp. Assy, Loc A2B08			
			FLTV - Used S/C 10 & above	54276907	54276907	
3-22	3-81	10	- LVV Comp. Assy, Loc A2B09			
			MLVV - Used S/C 10 & above	54277713	54277713	BK5XX
			NLVV - Used S/C 10 & above	54277714	54277714	BK4XX
3-22	3-81	10	- SMV Comp. Assy, Loc A2B10			
			6SMV - Used S/C 10 & above	54154500	54154500	All units except BK5C6D
			ESMV - Used S/C 47 & above	54154506	54154506	BK5C6D

ENGINEERING RECOMMENDED SPARE PARTS LIST

ITEMS APPEAR ON			DESCRIPTION	PART NUMBER	REPLACE- MENT PART NUMBER	NOTES
Fig. No.	Page No.	Index No.				
<u>COMPONENT ASSEMBLIES (Contd)</u>						
NON-LOGIC						
3-22	3-85	14	_XYV Comp. Assy, Loc A2D1			
			AXYV - Used S/C 10 & above	75838900	75838900	60 pin I/O only
			CXYV - used S/C 10 & above	75838902	75838902	50 pin I/O only
3-22	3-85	15	_XYV Comp. Assy, Loc A2D2			
			BXYV - Used S/C 10 & above	75838901	75838901	Dual channel, 60 pin I/O only
			DXYV - Used S/C 10 & above	75838903	75838903	Dual channel, 50 pin I/O only
3-22	3-87	20	_YDV Comp. Assy, Loc A2C1 (Terminator)			
			AYDV Used S/C 10 & above	75841300	75841300	60 pin I/O only
			BYDV Used S/C 10 & above	75841301	75841301	50 pin I/O only
3-22	3-87	21	_YDV Comp. Assy, Loc A2C2 (Terminator)			
			AYDV - Used S/C 10 & above	75841300	75841300	60 pin I/O only
			BYDV - Used S/C 10 & above	75841301	75841301	50 pin I/O only

ENGINEERING RECOMMENDED SPARE PARTS LIST

ITEMS APPEAR ON			DESCRIPTION	PART NUMBER	REPLACE- MENT PART NUMBER	NOTES
Fig. No.	Page No.	Index No.				

COMPONENT ASSEMBLIES (Contd)

NON-LOGIC (Contd)

3-23	3-93	2	_ ZYN Comp. Assy. Loc A3A01 HZYN - Used S/C 10 & above	75072009	75072009	Not used on Basic units (Basic units do not have control panels)
3-25	3-113	14	_ ZJN Comp. Assy, Loc A3A02 NZJN - Used S/C 10 & above PZJN - Used S/C 10 & above	75061715 75061716	75061715 75061716	BK5XX BK4XX
3-25	3-113	16	_ ZKN Comp. Assy, Loc A3A03 CZKN - Used S/C 10 & above EZKN - Used S/C 10 & above	75062105 75062107	75062105 75062107	BK4XX BK5XX
3-25	3-101	30	_ ZQN Comp. Assy, Loc A3A05 DZQN - Used S/C 10 & above FZQN - Used S/C 10 & above	73485309 73485311	73485309 73485311	BK4XX BK5XX

ENGINEERING RECOMMENDED SPARE PARTS LIST

ITEMS APPEAR ON	DESCRIPTION	PART NUMBER	REPLACE- MENT PART NUMBER	NOTES
Fig. Page Index				
No. No. No.				

COMPONENT ASSEMBLIES (Contd)

NON-LOGIC (Contd)

3-31	3-133	_VTN Comp. Assy, Loc A3A04 5VTN - Used S/C 10 & above AVTN - Used S/C 10 & above	77569100 77569101	77569100 77569101	All units except Basic Basic units
3-35	3-169	_SJV Comp. Assy, Loc A1A01 5SJV - Used S/C 10 & above	54153300	54153300	3 Card Power Supply
3-36	3-171	_SKV Comp. Assy, Loc A1A02 5SKV - Used S/C 10 & above	54153700	54153700	3 Card Power Supply
3-37	3-173	_SHV Comp. Assy, Loc A1A03 ASHV - Used S/C 10 & above	54152901	54152901	3 Card Power Supply
3-38	3-177 10	_XFV Comp. Assy AXFV - Used S/C 21 & above	75832100	75832100	2 Card Power Supply

ENGINEERING RECOMMENDED SPARE PARTS LIST

ITEMS APPEAR ON			DESCRIPTION	PART NUMBER	REPLACE- MENT PART NUMBER	NOTES
Fig.	Page	Index				
No.	No.	No.				

COMPONENT ASSEMBLIES (Contd)

NON-LOGIC (Contd)

3-39	3-178.1		_XKV Comp. Assy,			2 Card P.S. All units except BK5BIE/F, BK5A8E/F
			BXKV - Used S/C 21-24	75833702	75833708	
			CXKV - Used S/C 25 thru 47	75833704	75833708	
			EXKV - Used S/C 48 & above	75833708	75833708	
			CXKV - Used S/C 25 & above	75833704	75833704	BK5BIE/F, BK5A8E/F

TOOLS AND ACCESSORIES

Head Alignment Kit	See table 2-1
Speed Sensor Adjustment Tool	See table 2-1
Card Extender Assembly	See table 2-1

PARTS AND ASSEMBLIES

3-3	3-23	25	Filter, Air Aluminum, Washable			
3-8	3-39	7				
3-11	3-51	7				
3-12	3-55	14	Used S/C 10 & above	94364902	94364902	Rack Mount Units
			Used S/C 10 & above	00815481	00815481	Cabinet Units

ENGINEERING RECOMMENDED SPARE PARTS LIST

ITEMS APPEAR ON			DESCRIPTION	PART NUMBER	REPLACE- MENT PART NUMBER	NOTES
Fig. No.	Page No.	Index No.				

PARTS AND ASSEMBLIES (Contd)

3-23	3-93		Control Panel (A3A01) Used S/C 10 & above	76422501	76422501	All units except basic units & BK5C4R/S BK5C4R/S
			Used S/C 34 & above	76422504	76422504	
3-25	3-99	26	Switch, Pack Cover (A3S3) Used S/C 10 & above	93560003	93560003	
3-25	3-101	38	Head Arm Assy 1, 2, 4 Used S/C 10 & above	75010102	75010102	BK5XX
3-25	3-101	38	Head Arm Assy 0, 3 Used S/C 10 & above	75010103	75010103	BK5XX
3-25	3-101	38	Head Arm Assy (Servo Head) Used S/C 10 & above	75010105	75010105	BK5XX
3-25	3-101	38	Head Arm Assy 1, 2, 4 Used S/C 10 & above	75010002	75010002	BK4XX
3-25	3-101	38	Head Arm Assy 0, 3 Used S/C 10 & above	75010003	75010003	BK4XX

ENGINEERING RECOMMENDED SPARE PARTS LIST

ITEMS APPEAR ON			DESCRIPTION	PART NUMBER	REPLACE- MENT PART NUMBER	NOTES
Fig.	Page	Index				
No.	No.	No.				
<u>PARTS AND ASSEMBLIES (Contd)</u>						
3-25	3-101	38	Head Arm Assy (Servo Head) Used S/C 10 & above	75010005	75010005	BK4XX
3-25	3-103	4	Interlock Assembly Used S/C 47 & above	73077702	73077702	BK5C6D
3-25	3-109	4	Speed Sensor Assy (A3L1) Used S/C 10 & above	77387101	77387101	
3-25	3-117	1	Switch, Solid State, AC (A3K5) (Start Triac) Used S/C 10 & above	94371305	94371305	60 Hz
3-25	3-117	1	Switch, Solid State, AC (A3K5) (Start Triac) Used S/C 10-41 Used S/C 42 & above	94376501 94376503	94376503 94376503	50 Hz; All units except BK5C1K, BK5B9H, BK5C4Z, BK5C6D
3-25	3-117	1	Switch, Solid State, AC (A3K5) (Start Triac) Used S/C 47 & above Used S/C 38 & above Used S/C 47 & above	94376502 94371305 94376502	94387502 94371305 94387502	50 Hz; BK5C1K BK5B9H, BK5C4Z BK5C6D

ENGINEERING RECOMMENDED SPARE PARTS LIST

ITEMS APPEAR ON			DESCRIPTION	PART NUMBER	REPLACE- MENT PART NUMBER	NOTES
Fig. No.	Page No.	Index No.				

PARTS AND ASSEMBLIES (Contd)

3-25	3-117	8	Belt, Flat Drive Used S/C 10 & above	92314113	92314113	60 Hz
3-25	3-117	8	Belt, Flat Drive Used S/C 10 & above	92314119	92314119	50 Hz
3-25	3-117	13	Capacitor, 165 VRMS AC Motor (A3C6) Used S/C 10 & above	94255116	94255116	60 Hz; All units except BK5C1J, BK5B9G, BK5C4Y
3-25	3-117	13	Capacitor, V AC 220 DC Motor (A3C6) Used S/C 10-14 Used S/C 15-19 Used S/C 20-26 Used S/C 27 & above	94255115 94255109 94255101 94255120	94255120 94255120 94255120 94255120	50 Hz; All units except BK5C1K, BK5B9H, BK5C4Z, BK5C6D

ENGINEERING RECOMMENDED SPARE PARTS LIST

ITEMS APPEAR ON Fig. Page Index No. No. No.	DESCRIPTION	PART NUMBER	REPLACE- MENT PART NUMBER	NOTES
---	-------------	----------------	---------------------------------	-------

PARTS AND ASSEMBLIES (Contd)

3-25	3-117	13	Capacitor, V AC DC Motor (A3C6)			50/60 Hz 100 V; BK5C1J/K, BK5B9G/H, BK5C4Y/Z
			Used S/C 33 & above	94255115	94255115	
			Used S/C 47 & above	94255121	94255121	50 Hz; BK5C6D
3-26	3-121		Spindle Assy			BK5XX
			Used S/C 10 & above	75074714	75074714	
3-26	3-121		Spindle Assy			BK4XX
			Used S/C 10 & above	75074713	75074713	
3-27	3-123	7	Switch, Mini Integral Actuator (A3S2)			
			Used S/C 10 & above	93786026	93786026	
3-29	3-127	10	Transducer Assy (A3L2)			
			Used S/C 10 & above	76427300	76427300	
3-30	3-129		Drive Motor Kit (A3DM1)			60 Hz; All units except BK5C1K, BK5B9G, BK5C4Y
			Used S/C 10 & above	77398410	47204303	

ENGINEERING RECOMMENDED SPARE PARTS LIST

ITEMS APPEAR ON			DESCRIPTION	PART NUMBER	REPLACE- MENT PART NUMBER	NOTES
Fig. No.	Page No.	Index No.				

PARTS AND ASSEMBLIES (Contd)

3-30	3-129		Drive Motor Kit			60 Hz 100V; BK5C1K, BK5B9G, BK5C4Y
			Used S/C 33 & above	77398408	47204302	
3-30	3-129		Drive Motor Kit (A3DM1)			50 Hz; All units except BK4B7B, BK5A1K, BK5A7M, BK5A9U, BK5C1F/J, BK5B9H, BK5C4Z, BK5C6D
			Used S/C 10 - 19	77398413	47204318	
			Used S/C 20 & above	77398419	47204318	
3-30	3-129		Drive Motor Kit			50 Hz 100V; BK5C1J, BK5B9H, BK5C4Z
			Used S/C 33 & above	77398414	47204306	
3-30	3-129		Drive Motor Kit			50 Hz BK4B7B, BK5A1K, BK5A7M, BK5A9U, BK5C1F
			Used S/C 10 & above	77398420	47204319	
			Used 47 & above	93456000	93456000	BK5C6D

ENGINEERING RECOMMENDED SPARE PARTS LIST

ITEMS APPEAR ON			DESCRIPTION	PART NUMBER	REPLACE- MENT PART NUMBER	NOTES
Fig. No.	Page No.	Index No.				

PARTS AND ASSEMBLIES (Contd)

3-30	3-129		Hysteresis Brake Feature (A3HB1) Used S/C 10 & above	75241501	75241501	
3-31	3-133	1	Transistor, Darlington Power (Q3, Q4, Q5) Used S/C 10 - 16 Used S/C 17 & above	50222102 50223703	50223703 50223703	
3-31	3-133	8	Transistor, Darlington Power (Q1, Q2) Used S/C 10 - 16 Used S/C 17 & above	50222002 50223603	50223603 50223603	
3-32	3-135	4	Transformer, Ferro (AlT1) Used S/C 10 & above	76840400	76840400	60 Hz;3 card power supply
3-32	3-135	4	Transformer, Ferro (AlT1) Used S/C 10 & above	76846800	76846800	50 Hz;3 card power supply

ENGINEERING RECOMMENDED SPARE PARTS LIST

ITEMS APPEAR ON			DESCRIPTION	PART NUMBER	REPLACE- MENT PART NUMBER	NOTES
Fig. No.	Page No.	Index No.				

PARTS AND ASSEMBLIES (Contd)

3-32	3-135	3	Transformer, Ferro (AlT1)			60 Hz; used W/2 card power supply only
3-33	3-151	3				
			Used S/C 20 & above	76875600	76875600	
3-32	3-135	3	Transformer, Ferro (AlT1)			50 Hz; used W/2 card power supply All units except BK5C6D
3-33	3-151	4				
			Used S/C 20 & above	76875700	76875700	
			Used S/C 47 & above	70122200	70122200	BK5C6D
3-32	3-135	21	Switch, Modified, (Run Triac)			60 Hz
			Used S/C 10 & above	76427409	76427409	
3-32	3-135	21	Switch, Modified, (Run Triac)			50 Hz All units except BK5C1K, BK5B9H, BK5C4Z
3-33	3-151	13	(AlK1)			
			Used S/C 10-41	76427410	76427412	
			Used S/C 42 & above	76427412	76427412	
3-32	3-135	21	Switch, Modified, (Run Triac)			50 Hz
			(AlK1)			
			Used S/C 10 thru 37	76427410	76427409	BK5C1K
			Used S/C 38 & above	76427409	76427409	BK5B9H, BK5C4Z

ENGINEERING RECOMMENDED SPARE PARTS LIST

ITEMS APPEAR ON			DESCRIPTION	PART NUMBER	REPLACE- MENT PART NUMBER	NOTES
Fig.	Page	Index				
No.	No.	No.				

PARTS AND ASSEMBLIES (Contd)

3-32	3-136	25	Switch, Deck Interlock (ALS4)	93560002	93560002	
3-33	3-151	8				
3-32	3-137	50	Filter-Air Used S/C 10 & above	94364700	94364700	
3-33	3-153	30				
3-32	3-139	5	Capacitor, 21000 uf 50 V Electro (AlC1, AlC2) Used S/C 10 & above	95578111	95578111	
3-33	3-155	5				
3-32	3-139	8	Capacitor, 660 V ac NON-PCB (AlC8) Used S/C 10 & above	95686701	95686701	
3-33	3-155	8				
3-32	3-139	19	Capacitor, 370 V AC 4 uf (AlC5) Used S/C 10 & above	76878900	76878900	
3-33	3-155	19				
3-32	3-139	20	Blower Assy (AlBM1)			60 Hz; 100V/120V
			Used S/C 10 & above	75240304	75240304	50 Hz; 100V

ENGINEERING RECOMMENDED SPARE PARTS LIST

ITEMS APPEAR ON			DESCRIPTION	PART NUMBER	REPLACE- MENT PART NUMBER	NOTES
Fig.	Page	Index				
No.	No.	No.				
<u>PARTS AND ASSEMBLIES (Contd)</u>						
3-32	3-139	20	Blower Assy (A1BM1) Used S/C 10 & above	75240305	75240305	50 Hz; 220/240V
3-32	3-155	20	Blower Assy (A1BM1) Used S/C 10 & above	75240307	75240307	50 Hz; BK4A1D, BK4B7B, BK5A1K, BK5A7M, BK5A9U, BK5C1F, BK5C6D
3-32	3-141	38	Capacitor, 65 V DC, 16000 @f (Servo) (A1C3) Used S/C 21 & above	95578108	95578108	Used W/2 card power supply
3-33	3-157	38				
3-32	3-146.1	1	Elapsed Time Meter, 115 V AC (A1M1) Used S/C 10 & above	94313800	94313800	60 Hz
3-32	3-146.1	1	Elapsed Time Meter, 240 V AC (A1M1) Used S/C 10 & above	94313807	94313807	50 Hz; All units except BK5C1J, BK5B9H, BK5C4Z
3-33	3-163	1				

ENGINEERING RECOMMENDED SPARE PARTS LIST

ITEMS APPEAR ON			DESCRIPTION	PART NUMBER	REPLACE- MENT PART NUMBER	NOTES
Fig.	Page	Index				
No.	No.	No.				

PARTS AND ASSEMBLIES (Contd)

3-32	3-146.1	1	Elapsed Time Meter, 115V (AlM1)			50 Hz 100V; BK5C1J, BK5B9H, BK5C4Z
			Used S/C 33 & above	94313801	94313801	
3-32	3-146.1	8	Circuit Breaker, 15A 240 V AC Long (AlCB1)			60 Hz
			Used S/C 10-13	94345218	94345218	
			Used S/C 14 & above	94245217	94245217	
3-32	3-143	8	Circuit Breaker, 8A 240 V AC			50 Hz;All units
3-33	3-163	8	Long (AlCB1)			except BK5C1J BK5B9H, BK5C4Z
			Used S/C 10-13	94345206	94345206	
			Used S/C 14 & above	94245205	94245205	
3-32	3-146.1	8	Circuit Breaker, 15A 240 V AC (AlCB1)			50 Hz 100V; BK5C1J, BK5B9H, BK5C4Z
			Used S/C 33 & above	94245207	94245207	

ENGINEERING RECOMMENDED SPARE PARTS LIST

ITEMS APPEAR ON			DESCRIPTION	PART NUMBER	REPLACE- MENT PART NUMBER	NOTES
Fig.	Page	Index				
No.	No.	No.				
<u>PARTS AND ASSEMBLIES (Contd)</u>						
3-32	3-146.1	9	Circuit Breaker, 5A 125 V AC (AlCB2) Used S/C 10 & above	92696065	92696065	60 Hz
3-32	3-146.1	9	Circuit Breaker, 5A 250 V AC			50 Hz; All units except BK5C1J, BK5B9H, BK5C4Z
3-33	3-163	9	AlCB2) Used S/C 10 only	92696069	92696079	
			Used S/C 11 & above	92696079	92696079	
3-32	3-146.1	9	Circuit Breaker, 8A 250 V AC (AlCB2) Used S/C 33 & above	92696081	92696081	50 Hz 100V; BK5C1J, BK5B9H, BK5C4Z
3-32	3-146.1	17	Filter, Line (AlFL1) Used S/C 10 - 33 Used S/C 34 & above	94371200 92009801	94371200 92009801	60 Hz
3-32	3-146.1	17	Filter, Line (AlFL1)			50 Hz
3-33	3-163	18	Used S/C 10 - 30	83222200	83222200	
			Used S/C 31 & above	92009801	92009801	

ENGINEERING RECOMMENDED SPARE PARTS LIST

ITEMS APPEAR ON			DESCRIPTION	PART NUMBER	REPLACE- MENT PART NUMBER	NOTES
Fig. No.	Page No.	Index No.				

PARTS AND ASSEMBLIES (Contd)

3-32	3-147	28	Varistor			50 Hz only
3-33	3-165	35	Used S/C 10 & above	94395600	94395600	
3-35	3-169	3	Fuse, Quick Acting, 6 Amp Used S/C 10 - 23	95647605	95647605	
3-36	3-171	4	Fuse, Quick Acting, 2 Amp Used S/C 10 - 23	95647602	95647602	
3-37	3-173	11	Fuse, Quick Acting, 6 Amp Used S/C 10 - 23	95647605	95647605	
3-39	3-135	18	Fuse, Cartridge, 6.25 Amp			All units except BK5B1E/F BK5A8E/F
3-39	3-178.1	11	Used S/C 24	95647605	51650227	
			Used S/C 25 thru 47	95647606	51650227	
			Used S/C 48 & above	51650227	51650227	
3-32	3-135	15	Fuse, Cartridge, 10 Amp Used S/C 47 & above	51650233	51650233	BK5C6D

ENGINEERING RECOMMENDED SPARE PARTS LIST

ITEMS APPEAR ON			DESCRIPTION	PART NUMBER	REPLACE- MENT PART NUMBER	NOTES
Fig. No.	Page No.	Index No.				
<u>PARTS AND ASSEMBLIES (Contd)</u>						
3-32	3-135	16	Fuse, Cartridge, 7 Amp Used S/C 47 & above	51650228	51650228	BK5C6D
3-39	3-178.1	11	Fuse, Quick Acting, 8 Amp Used S/C 25 & above	95647606	95647606	BK5B1E/F BK5A8E/F only
3-39	3-178.1	13	Fuse, Cartridge Used S/C 24 thru 47 Used S/C 48 & above	95647604 51650226	51650226 51650226	All units except BK5B1E/F BK5A8E/F
3-39	3-178.1	13	Fuse, Quick Acting, 5 Amp Used S/C 48 & above	95647604	95647604	BK5B1E/F BK5A8E/F only

APPENDIX A

DECISION LOGIC TABLES

(DLTs)

**for SMDs with 2
Card Power Supplies**

CONTENTS

APPENDIX A	
Introduction	A-1
Using the DLT	A-2
Useful Troubleshooting Aids	A-2
Using a VOM to Check a Capacitor	A-2
In-Circuit Diode Checking With A VOM	A-3
DECISION LOGIC TABLES	
DLT 1 - Power Up	A-7
DLT 2 - DC Voltage Check	A-9
DLT 3 - Isolating Faults in the ± 5 V Loads	A-10
DLT 4 - Isolating Faults in the ± 20 V Loads	A-12
DLT 5 - Isolating Faults in the ± 12 V Loads	A-13
DLT 6 - Isolating Faults in the ± 42 V Loads	A-14
DLT 7 - First Seek	A-15
DLT 8 - RTZ, Continuous Seeks	A-17
DLT 9 - Write	A-19
DLT 10 - Read	A-20
DLT 11 - Power Down	A-21
PROCEDURES	
Procedure A: Checking DC Voltages	A-23
Procedure B: Checking AC Inputs to Power Supplies	A-25
Procedure C: Troubleshooting Heat-Generated Problems	A-30
Procedure D: Pin-Pointing Voltage Faults in the Logic Chassis	A-31

FIGURES

A-1	AC-Input Probe Points on <u>XKV</u> Board	A-26
A-2	T1 Inputs to Power Supply (<u>XKV</u>) Board	A-29

TABLES

A-1	Voltages Used by Electronic Components	A-4
A-2	Checking DC Voltages	A-23
A-3	Failure Symptom in Power Supplies	A-24
A-4	Checking for Shorted <u>XKV</u> Board	A-27
A-5	Checking AC Inputs to <u>XKV</u> Board	A-28

DECISION LOGIC TABLES (DLTs)

INTRODUCTION

Decision logic tables help maintenance technicians organize their thinking when problems occur in the drive. For a given fault condition (or set of conditions), actions are recommended to locate and correct the fault. The actions are arranged so that the corrective measures that are easiest to perform (checking a fuse or changing a card in the logic chassis, for example) are listed before the more difficult tasks such as replacing the head/arm assembly or drive motor.

A Useful Troubleshooting Aids section contains two general-interest maintenance procedures, as well as a voltages-used table that should prove helpful throughout the troubleshooting effort.

The DLTs consist of 11 tables, described briefly below.

- DLT 1 shows how to correct problems that occur when attempting to "power-up" the drive, including the failure of any of the three dc power supplies.
- DLT 2 helps to define the origin of ± 5 V load fault - either in the loads or in the supply itself.
- DLT 3 shows how to isolate a ± 5 V load fault to a given area or electrical component.
- DLTs 4, 5, and 6 show how to locate and correct faults in the ± 20 V loads, ± 12 V loads, and ± 42 V loads.
- DLTs (7 through 10 are used with the FTU (TB303) to correct various seek and read/write errors).
- DLT 11 shows what to do when a drive does not "powerdown" properly.

The procedures referred to in the DLTs form the last portion of this discussion.

USING THE DLT

The DLT is divided into four quadrants. The upper-left quadrant, **CONDITIONS**, contains the various test conditions that can be answered "yes" or "no". The **CONDITIONS** quadrant is prefaced by any **ASSUMPTIONS** (that is, pre-conditions) that must be observed if the test results are to be valid. Sometimes, prerequisite actions other than the **ASSUMPTIONS** must be taken before the test for a given condition is made. Such steps are included in the **CONDITIONS** quadrant. The yes (Y) or no (N) answers to each condition are shown in numbered columns in the top-right **Situations** quadrant.

To use the DLT, first determine whether the result of a condition tested is Y or N. If two or more conditions exist simultaneously, look for a **Situations** column that combines the appropriate Y-N answers for those conditions. A dash (-) in the top-right **Situations** quadrant means that the related Condition is not a factor in determining what actions are to be taken for that situation.

Next, determine what action should be taken for a given test result (i.e., situation) by following down the selected column to the row marked "1" in the lower-right **Sequence** quadrant. (If there is only one recommended action for a given situation, an "X" appears instead of the "1".) The recommended action is then located by moving across to the lower-left **ACTIONS** quadrant. A dash in a column of the **Sequence** quadrant indicates that the related Action isn't applicable.

After taking the first recommended action, repeat the test that gave rise to the situation. If the test results haven't changed (same situation), try recommended action 2, and so on, being sure to repeat the test after each such action.

Column 1 is generally reserved for an "everything OK" situation. If a DLT requires more than one sheet, this "no problem" column is repeated on each sheet. Similarly, the last **ACTION** on each sheet is a recommendation to "call field support". Don't brood over your inadequacy if you reach this last entry; not every situation can be covered in a DLT.

USEFUL TROUBLESHOOTING AIDS

USING A VOM TO CHECK A CAPACITOR

1. Remove power from the equipment.
2. Discharge capacitor by momentarily shorting the leads with a jumper wire. (Use screwdriver for large capacitors.)

3. Isolate the capacitor by disconnecting one lead from the circuit.
4. Set VOM to X1000 (ohms) scale.
5. Connect the VOM across the capacitor leads. The condition of the capacitor is interpreted as follows:

<u>Meter reading</u>	<u>Interpretation</u>
Needle goes rapidly to full scale (0Ω), then regresses to infinity (∞). (See NOTE.)	Capacitor OK
Needle goes rapidly to full scale and remains there.	Capacitor shorted
Needle deflects slightly or not at all.	Capacitor open

NOTE

Speed with which needle returns to infinity (∞) is a function of capacity rating. Return swing is rapid for small capacitors, becoming slower as capacity increases. To a lesser degree, return swing is also dependent upon which meter scale is used.

IN-CIRCUIT DIODE CHECKING WITH A VOM

A diode that is suspect can be given a preliminary check without disconnecting it from the circuit. Merely check the diode twice, reversing the meter leads between the two readings. Of course, power should be off, and for your own peace of mind any capacitors in the circuit should be discharged.

Keep in mind that the forward drop across a good diode is in the range 5 - 15 Ω ; the reverse drop is on the order of 1 M Ω . Parallel resistances in the circuit will, of course, significantly reduce the higher of these two readings, but if one is low and the other high, chances are the diode is OK. If both are low, the diode is probably shorted; if both are high, it's probably open.

This check can also be used for a bridge rectifier. You'll probably want to check at least two diodes in the bridge, because back-circuits may give different readings across different diodes.

TABLE A-1. VOLTAGES USED BY ELECTRONIC COMPONENTS
(Sheet 1 of 2)

Volt- ages	A1 - Power Supply							A3 - Deck					VC1
	Servo Cap Board C1 C2	Run Triac K1	Em. Retr. Relay K2	Contr Pnl A01	Hd Rd A02	Sel Amp A03	Writ- er A04	Pwr Amp A05	Ser- vo Pre- Amp A05	Start Triac K5	Hyst Brake HB1	Pack Cover Sol L3	
+5 V		x		x	x	x				x			
-5 V					x	x							
+12 V					x				x				
-12 V					x				x				
+20 V			x		x						x	x	
-20 V													
+42 V	x						x	x					
-42 V		x						x					

TABLE A-1. VOLTAGES USED BY ELECTRONIC COMPONENTS
(Sheet 2)

A2 - Logic Chassis

Volt-ages	A01	A02	A03	A04	A05	A06	A07	A08	A09	A10	B01	B02	B05	B06	B07	B08	B09	B10
+5 V	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x	x
-5 V	x	x	x	x	x	x		x	x	x	x	x	x		x			
+12 V																		
-12 V																		
+20 V	x	x	x	x	x	x	x	x	x	x								
-20 V	x	x	x	x	x	x	x	x	x									
+42 V				x					x	x								
-42 V				x					x									

DECISION LOGIC TABLES

DLT 1		POWER UP		(sheet 1 of 2)				
Warning: Tuning capacitor AlC8 is charged to 440 volts. Treat it with respect!								
Enters from: Assumptions								
Procedures: B								
References: Logic Diagrams								
Exits to: Sheet 2, or DLT 2								
Assumption: 1. Drive connected to ac power 2. Disk pack installed 3. Attempt to power up and start drive from SMD panel.								
CONDITIONS								
	1	2	3	4	5	6	7	8
1. Turn on AC POWER brkr (CB1). Does CB1 trip?	N	Y	N	N	N	N	N	-
2. Does blower motor start when CB1 is actuated?	Y	-	N	N	Y	-	-	-
3. Do door fans start when CB1 is actuated?	Y	-	N	Y	N	-	-	-
4. POWER SUPPLY brkr (CB2) trips when actuated?	N	-	-	-	-	Y	-	-
5. Does CB1 or drive motor thermal brkr trip when CB2 is actuated?	N	-	-	-	-	-	Y	-
6. Is smell of burning insulation detected soon after turning on CB2?	N	-	-	-	-	-	-	Y
ACTIONS								
1. Continue with Condition 7 on sheet 2.	X							
2. If pwr plug customer-provided, chk phase and gnd connections.	1	1						
3. Suspect blower. Separate P/J301; if trouble persists, blower is OK.	2							
4. Suspect time meter. Disconnect, then try again to verify.	3							
5. Suspect door fans. Separate P/J400, then try again to verify.	4							
6. Suspect CB1--check continuity.		2						
7. Check for ac in and out of line filter.		3						
8. Chk for open blower motor, cable, or blower motor capacitor AlC5.			1					
9. Suspect shorted tuning cap (AlC8). See WARNING above.						1		
10. Suspect short in -XKV (p.s.) board. To check, do steps 1-5 of Procedure B.						2		
11. Suspect short in T1 wiring or T1 itself. To check, go to step 6 of Procedure B.						3		
12. Suspect Run triac energized before START switch has been pressed. Troubleshoot logic, starting with card A2A10.							1	
13. Chk Run triac for shorted LOAD contacts (terminals 1,2).							2	
14. You have lost +5 V power. IMMEDIATELY TURN OFF CB2 TO PREVENT BURNING UP THE VOICE COIL. To check on voltage loss, go to sheet 2.								X
15. Check continuity of door fans and cabling.						1		
16. Check for blown fuses on T1 fuse block. If one of the fuses is blown, check for a short circuit in wiring from P1 to power supply boards.							4	
17. Call Field Support	-	5	4	2	2	5	3	-

KØR-0679-2

DLT 1

POWER UP

(sheet 2 of 2)

Warning: Tuning capacitor AlC8 is charged to 440 volts!

Enters from: Sheet 1

Procedures: C

References: Logic Diagrams, DLT 7

Exits to: DLT 2, DLT 8

Assumption:
 1. Drive connected to ac power
 2. Disk pack installed
 3. Attempt to power up and start drive from SMD panel.

CONDITIONS

	1	9	10	11	12	13	14	15
7. Press START switch. Does either CB1 or drive thermal brkr trip?	N	Y	N	N	N	N	N	N
8. Does START light come on when START sw is pressed?	Y	-	N	N	Y	Y	Y	Y
9. Does drive motor start when START sw is pressed?	Y	-	Y	N	N	Y	Y	Y
10. Does drive motor come up to speed?	Y	-	-	-	-	N	Y	Y
11. Do heads load? (READY light comes on.)	Y	-	-	-	-	-	N	Y
12. Does drive motor cut out after 15-second timeout expires?	N	-	-	-	-	Y	-	N
13. Does CB2 (PS brkr) trip after drive has been operating normally?	N	-	-	-	-	-	-	Y

ACTIONS

17. Power-up and First Seek completed properly. Go to DLT 8.	X	-	-	-	-	-	-	-
18. Suspect shorted Start triac (A3K5).	-	1	-	-	-	-	-	-
19. Suspect shorted drive motor start capacitor (A3C6).	-	2	-	-	5	-	-	-
20. Suspect open Start winding in drive motor.	-	3	-	-	8	-	-	-
21. START indicator burned out. Replace START ind/sw.	-	-	1	-	-	-	-	-
22. Check all interlocks.	-	-	-	1	-	-	-	-
23. Go to DLT 2 to check for presence of +5 volts.	-	-	-	2	-	-	-	-
24. Chk that Local/Remote sw (card A10) is set to LOCAL.	-	-	-	-	1	-	-	-
25. Chk drive motor thermal brkr. If tripped, check cause.	-	-	-	-	2	-	-	-
26. Suspect Run logic--start with card A10.	-	-	-	-	3	-	-	-
27. Suspect Run triac (A1K1).	-	-	-	-	4	1	-	-
28. Check hysteresis brake for mechanical binding.	-	-	-	-	6	2	-	-
29. Suspect brake logic continuously energized--card A10.	-	-	-	-	7	3	-	-
30. Suspect speed sensor and/or attendant logic--card A10.	-	-	-	-	-	4	-	-
31. Suspect open Run winding on drive motor.	-	-	-	-	9	-	-	-
32. Refer to DLT 7--First Seek.	-	-	-	-	-	-	X	-
33. Suspect overloaded (overheated) power supply. Go to Procedure C.	-	-	-	-	-	-	-	1
34. Call Field Support.	-	4	2	3	10	5	-	2

KØR-0679-2

DLT 2	DC VOLTAGE CHECK																						
Warning: Tuning capacitor AlC8 is charged to 440 volts. Treat it with respect!																							
Enters from: DLT 1 or when a dc voltage is suspect																							
Procedures: A																							
References: Logic Diagrams																							
Exits to: DLTs 3,4,5,6; or DLT 1 if this table was entered from Actions 14 or 22 of DLT 1.																							
Assumption: Lack of one or more dc voltages is indicated or suspected. Initial voltage measurements are made with all dc loads connected, using Procedure A.																							
CONDITIONS												1	2	3	4	5	6	7	8	9	10	11	12
1. ±5 voltages OK with load?												Y	N	N	N	N	-	-	-	-	-	-	-
2. With ±5 V loads disconnected, is there +5 V at J2-03 and -5V at J2-05? (Use J2-01 as ground.) (1)												-	-	Y	N	N	-	-	-	-	-	-	-
3. ±12, ±20, ±42 voltages significantly low?												N	-	-	-	Y	-	-	-	-	-	-	-
4. ±20 voltages OK?												Y	-	-	-	-	N	N	-	-	-	-	-
5. 20 V fuse(s) blown? (2)												N	-	-	-	-	N	Y	-	-	-	-	-
6. ±12 voltages OK with load?												Y	-	-	-	-	-	-	N	-	-	-	-
7. With ±12 V loads disconnected, is there +12 V at J2-10 and -12 V at J2-08? (Use J2-01 as ground.) (1) (3)												-	-	-	-	-	-	-	-	N	Y	-	-
8. ±42 voltages OK?												Y	-	-	-	-	-	-	-	-	-	N	N
9. 42 V fuse(s) blown? (2)												N	-	-	-	-	-	-	-	-	-	N	Y
ACTIONS																							
1. DC voltages all OK.												X	-	-	-	-	-	-	-	-	-	-	-
2. Separate P/J2 (on -XKV brd) and try again, checking Condition 2.												-	X	-	-	-	-	-	-	-	-	-	-
3. Trouble is in the ±5 V loads. Go to DLT 3.												-	-	X	-	-	-	-	-	-	-	-	-
4. Replace -XKV board or, optionally, the entire p.s. assembly.												-	-	-	1	-	1	-	-	1	-	1	-
5. Suspect open AlC8. See WARNING, above.												-	-	-	-	1	-	-	-	-	-	-	-
6. Trouble is in the ±20 V loads. Go to DLT 4.												-	-	-	-	-	-	X	-	-	-	-	-
7. Separate P/J2 and try again, checking Condition 7.												-	-	-	-	-	-	-	X	-	-	-	-
8. Trouble is in the ±12 V loads. Go to DLT 5.												-	-	-	-	-	-	-	-	-	X	-	-
9. Trouble is in the ±42 V loads. Go to DLT 6.												-	-	-	-	-	-	-	-	-	-	-	X
10. Call Field Support.												-	-	-	2	2	2	-	-	2	-	2	-
(1) Reconnect P/J2 before going to next Condition.																							
(2) Check with VOM. Fuse is bad if supply voltage does not appear on both sides of fuse. (Use J2-01 as ground.)																							
(3) If no voltage, check the 39Ω resistors. An open resistor means a drastic overload has occurred. Be sure to check out the loads (DLT 5) after replacing the supply.																							

KØR-0679-3

DLT 3 ISOLATING FAULTS IN THE ±5 V LOADS																																					
Warning: None																																					
Enters from: DLT 2																																					
Procedures: D																																					
References: None																																					
Exits to: DLT 1 to complete the Power-Up diagnostic																																					
Assumption: P/J2 on power supply (-XKV brd) has been reconnected so as to provide a load for the ±5 V supply. Start each Condition by turning off PS brkr (CB2).																																					
CONDITIONS											1	2	3	4	5	6	7	8	9	10	11	12															
1. Check out the logic chassis:																																					
a) Remove Faston from A1K1-3 (Run triac).																																					
b) Remove Faston from A3K5-3 (Start triac).																																					
c) Separate connectors P/JA80 and P/JA81.																																					
d) Turn on CB2. Is ±5 V present at logic chassis Fastons?												Y	N	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-		
2. Add Control Panel (A3A01) to ±5 V load:																																					
a) Reconnect P/JA80.																																					
b) Turn on CB2. Is ±5 V still present at logic chassis Fastons?												-	-	Y	N	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
3. Reconnect Run triac Faston. Turn on CB2. Is ±5 V still present?												-	-	-	-	Y	N	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
4. Reconnect Start triac Faston. Turn on CB2. ±5 V still present?												-	-	-	-	-	-	Y	N	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
5. Add A3A02 (Hd Sel/Rd Amp) and A3A03 (Writer) to ±5 V load:																																					
a) Reconnect P/JA81.																																					
b) Turn on CB2. Is ±5 V still present at logic chassis?												-	-	-	-	-	-	-	-	-	-	Y	N	-	-	-	-	-	-	-	-	-	-	-	-	-	
6. Isolate A3A03 from A3A02:																																					
a) Remove piggy-back writer board (A3A03) from A3A02.																																					
b) Turn on CB2. Is ±5 V still present at logic chassis?												-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	Y	N	-	-	-	
ACTIONS											1	2	3	4	5	6	7	8	9	10	11	12															
1. ±5 V to logic chassis is OK. Go to Condition 2.												X	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
2. ±5 V fault is in logic chassis. To correct, go to Procedure D.												-	X	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
3. ±5 V to control panel is OK. Go to Condition 3.												-	-	X	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
4. Replace control panel (A3A01).												-	-	-	X	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
5. Run triac is OK. Go to Condition 4.												-	-	-	-	X	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
6. Replace Run triac (A1K1).												-	-	-	-	-	X	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
7. Start triac is OK. Go to Condition 5.												-	-	-	-	-	-	X	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
8. Replace Start triac (A3K5).												-	-	-	-	-	-	-	X	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
9. ±5 V distribution is OK.												-	-	-	-	-	-	-	-	-	-	X	-	-	-	-	-	-	-	-	-	-	-	-	-	-	
10. Go to Condition 6.												-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	X	-	-	-	-	
11. Replace writer board (A3A03).												-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	X	-	-	-	
12. Replace Hd Sel/Rd Amp board (A3A02).												-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	-	X	-	-	

KØR-0679-3

DLT 4 ISOLATING FAULTS IN THE ±20 V LOADS		1	2	3	4	5	6	7	8
Warning: None									
Enters from: DLT 2									
Procedures: D									
References: DLT 5									
Exits to: DLT 1 to complete the Power-Up diagnostic									
Assumption: The ±20 V supply is known to be good, but F1 or F2 blows when an attempt is made to power up the drive with the ±20 V loads connected. Replace blown fuse(s) before testing Conditions 1 or 2.									
CONDITIONS									
1. Eliminate all ±20 V loads except the logic chassis:									
a) Turn off POWER SUPPLY breaker (CB2).									
b) Separate P/JA81. (1)									
c) Turn on CB2. Does F1 or F2 blow? (2)									N Y - -
2. Add A3A02 (Hd Sel/Rd Amp) to ±20 V load:									
a) Turn off CB2.									
b) Reconnect P/JA81.									
c) Turn on CB2. Does F1 or F2 blow? (2)									- - N Y
ACTIONS									
1. ±20 V load in logic chassis is OK. Go to Condition 2.									X - - -
2. To check ±20 V fault in logic chassis, go to Procedure D.									- X - -
3. ±20 V distribution is OK. Chances are that the fault appears only when the logic connects the emergency retract relay coil or the hysteresis brake to +20 V. Most probable cause is a shorted (grounded) coil in one of these components.									- - 1 -
4. Replace A3A02.									- - - 1
5. Call Field Support.									- - 2 2
(1) This retains the ±12 V (unfused) power to the servo preamp, A3A05. The alternative is to disconnect P/J8, which is not recommended because reconnecting the cable to A3A05 isn't easy. In any event, the 12-volt regulators have current limiters that prevent damage to the supply or components if the ±12 V loads are faulty.									
(2) Fuse integrity is most easily checked by monitoring the ±20 V Faston connectors at the logic chassis. If in doubt, ohm-out the fuse. (On the bench--not in the supply!)									

KØR-0679-2

DLT 5 ISOLATING FAULTS IN THE ±12 V LOADS

Warning: None

Enters from: DLT 2

Procedures: None

References: Table A-2 in Procedure A

Exits to: DLT 1 to complete the Power-Up diagnostic

Assumption: The ±12 V supply is known to be good, but when the ±12 V load is connected, voltage readings per Procedure A indicate a load fault.

CONDITIONS	1	2	3	4	5	6	7	8
1. Limit the ±12 V load to A3A05 (servo preamp):								
a) Turn off POWER SUPPLY breaker (CB2).								
b) Separate P/JA81.								
c) Turn on CB2, then wait one minute before going to d), below.								
d) Check for +12 V and -12 V, using probe points given in table A-2 of Procedure A. Are voltages present?	Y	N	-	-	-	-		
2. Does the magnitude of the two voltage readings differ by 0.6 V or more? [e.g., (+12)-(-11.2) = 0.8 V magnitude dif.]	-	-	N	Y	-	-		
3. Add A3A02 (Hd Sel/Rd Amp) to ±12 V load:								
a) Turn off CB2.								
b) Reconnect P/JA81.								
c) Turn on CB2.								
d) Check voltages as in Condition 1d. Are voltages within the tolerance specified in table A-2 of Procedure A?	-	-	-	-	N	Y		

ACTIONS	1	2	3	4	5	6	7	8
1. Go to Condition 2.	X	-	-	-	-	-		
2. Replace A3A05 board.	-	1	-	-	-	-		
3. Servo preamp is OK. Go to Condition 3.	-	-	X	-	-	-		
4. A voltage difference here could cause unequal amplification of servo dibits, giving an On Cylinder null signal that is not centered over the servo track. This "permanent offset" could cause Read errors in a pack written on another drive, or when a pack written on this drive was read on another drive. You may wish to replace A3A05 rather than take that chance. Now go to Condition 3.	-	-	-	X	-	-		
5. Replace A3A02 board.	-	-	-	-	1	-		
6. ±12 V loads are OK. Go back to DLT 1.	-	-	-	-	-	X		
7. Call Field Support.	-	2	-	-	2	-		

KØR-0679-2

DLT 6 ISOLATING FAULTS IN THE ±42 V LOADS

Warning: None

Enters from: DLT 2

Procedures: D

References:

Exits to: DLT 1 to complete the Power-Up diagnostic

Assumption: All power supplies are known to be good, but F3 or F4 blows when the ±42 V loads are connected. Start each Condition by turning off PS brkr (CB2).

CONDITIONS	1	2	3	4	5	6	7	8
1. Limit the ±42 V load to servo capacitors AlC1 and AlC2:								
a) Separate P/J200 (on pwr amp brd, A3A04).								
b) Turn on CB2. Does either F3 or F4 blow? (1)	N	Y	-	-	-	-	-	-
2. Add power amp (A3A04) to ±42 V load:								
a) Remove PA09 from w/w pins at location A09 of logic chassis.								
b) Reconnect P/J200.								
c) Turn on CB2. Does either F3 or F4 blow? (1)	-	-	N	Y	-	-	-	-
3. Add logic chassis to ±42 V load:								
a) Reconnect P/JA09 (on logic chassis backpanel).								
b) Separate P/JA81 (on logic chassis).								
c) Turn on CB2. Does either F3 or F4 blow? (1)	-	-	-	-	N	Y	-	-
4. Add writer (A3A03) to ±42 V load:								
a) Reconnect P/JA81.								
b) Turn on CB2. Does either F3 or F4 blow? (1)	-	-	-	-	-	-	Y	N

ACTIONS	1	2	3	4	5	6	7	8
1. Servo caps are OK. Go to Condition 2.	X	-	-	-	-	-	-	-
2. Replace AlC1 (+42) or AlC2 (-42), depending upon which fuse blew.	-	1	-	-	-	-	-	-
3. Power amp is OK. Go to Condition 3.	-	-	X	-	-	-	-	-
4. Replace power amp (A3A04).	-	-	-	1	-	-	-	-
5. ±42 V in logic chassis is OK. Go to Condition 4.	-	-	-	-	X	-	-	-
6. ±42 V fault in logic chassis. To check out, go to Procedure D.	-	-	-	-	-	X	-	-
7. Replace Writer (A3A03).	-	-	-	-	-	-	1	-
8. ±42 V loads now check out OK. Return to DLT 1.	-	-	-	-	-	-	-	X
9. Call Field Support.	-	2	-	2	-	-	2	-
(1) Test fuse with a VOM between ground and each side of fuse. No voltage on one side, fuse blown. Voltage on both sides, fuse OK. (Or remove fuse and ohm it out.)								

KØR-0679-2

DLT 7

FIRST SEEK

(sheet 1 of 2)

Warning: None

Enters from: DLTs 1 through 6

Procedures: See sheet 2

References: Logic diagrams

Exits to: DLT 8 or sheet 2 of this DLT

Assumption: START light is on, drive is coming up to speed.

CONDITIONS

	1	2	3	4	5	6	7	8
1. READY light comes on, signifying successful First Seek?	Y	N	N	N	N	N		
2. First Seek attempted?	-	N	N	N	N	N		
3. Check that Heads Loaded switch (A3S2) is transferring:								
a) Press START sw to stop disk. Do not turn off breakers.								
b) Manually push voice coil forward to move heads off unloading ramp. Does voice coil resist fwd movement?	-	-	N	Y	Y	Y		
4. Check for forward drive to voice coil:								
a) Disconnect black lead from voice coil (term. 2 in c.r. 282).								
b) Attach + probe of VOM to black wire, com. probe to logic gnd.								
c) Press START.								
d) Wait 15-20 sec for up-to-speed time out to expire, then chk VOM. Does VOM read approx +40 V?	-	-	-	-	N	Y		

ACTIONS

1. No problem--go to DLT 8.	X	-	-	-	-	-		
2. Go to Condition 3.	-	X	-	-	-	-		
3. Suspect leads to (or contacts in) E.R. relay AlK2.	-	-	1	-	-	-		
4. Suspect open voice coil.	-	-	2	-	-	-		
5. Replace A3S2 (Hds Loaded sw).	-	-	3	-	-	-		
6. Replace power amp ass'y.	-	-	4	-	6	-		
7. A3S2 is OK. Go to Condition 4 to chk fwd drive on voice coil.	-	-	-	X	-	-		
8. Suspect card A09 (pwr amp control).	-	-	-	-	1	-		
9. Suspect card B09 (direction control).	-	-	-	-	2	-		
10. Suspect card A07 (summing amp).	-	-	-	-	3	-		
11. Suspect card B06 (diff cntr, CAR).	-	-	-	-	4	-		
12. Suspect card A10 (speed control).	-	-	-	-	5	-		
13. Voice coil should attempt First Seek upon expiration of up-to-speed timeout. Go to Condition 5 on sheet 2.	-	-	-	-	-	X		
14. Call Field Support.	-	-	5	-	7	-		

KØR-0679-2

DLT 8

RTZ/CONTINUOUS SEEKS

Warning: None
Enters from: DLT 7
Procedures: None
References: Logic Diagrams
Exits to: DLT 9

Assumption: 1. TB304 FTU is connected to drive via A and B I/O cables
 2. Local/Remote switch on drive (card A10) set to REMOTE
 3. LAP installed and drive selected from FTU.

CONDITIONS	1	2	3	4	5	6	7	8
1. Actuate RTZ sw on FTU. Is RTZ seek successful?	Y	N	-	-	-			
2. Set up and perform continuous seeks.								
a) Set FTU's Access Mode sw to CONT.								
b) Set all FTU Cyl Adrs switches to "off" (down).								
c) Actuate START sw (on FTU).								
d) Sequentially select/deselect cylinder address switches (1,2,4...256, 512) to step actuator between track 0 and track selected by active cyl adrs switch.								
Is Continuous Seek successful?	Y	-	N	-	-			
3. Select track (cyl) 822 on FTU panel:								
• Set Cyl Adrs switches to 1466g; START.								
Was seek to track 822 successful?	Y	-	-	N	-			
4. Select track (cyl) 823 on FTU panel:								
• Set Cyl Adrs switches to 1467g; START.								
Does Seek Error result when seeking to track 823?	Y	-	-	-	N			

ACTIONS	1	2	3	4	5	6	7	8
1. Seeks properly executed. Go to DLT 9.	X	-	-	-	-			
2. Replace card B08 (Access Control, Index/Sector Decode).	-	1	1	1	1			
3. Replace card B09 (Access Control 1).	-	2	-	-	-			
4. Replace card A08 (Access Control 2).	-	3	-	-	-			
5. Replace card A07 (D/A Function Generator).	-	4	3	3	3			
6. Replace cards B02 (Ch 1 rcurs), B04 (Ch 2 rcurs).	-	5	4	4	4			
7. Replace card B06 (Diff Generator and Control).	-	-	2	2	2			
8. Call Field Support.	-	6	5	5	5			

K0R-0679-2

Warning: None
Enters from: Sheet 1
Procedures: None
References: Logic Diagrams
Exits to: DLT 10

Assumption: 1. FTU connected to drive and FTU switches set per "Preliminary Set-up" in Operation section of TB304 manual. In addition, FTU Wrt-Rd Select switch set for either WRT or WRT FORMAT operation.

CONDITIONS

	5	6	7	8	9	10	11	12	13	14	
2,3. FAULT indications on both SMD and FTU panels? (From sheet 1.)	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	
4. Is fault limited to certain groups of contiguous addresses?	Y	N	-	-	-	-	-	-	-	-	
5. Does fault appear only for WRT FORMAT operations?	-	-	Y	N	-	-	-	-	-	-	
6. Set FTU Addr/Sect Mk switch to SECT MK and try again. Does FAULT light still come on?	-	-	-	-	N	Y	-	-	-	-	
7. Check LEDs on operator panel:											
a) WRT FLT on?	-	-	-	-	-	-	Y	-	-	-	
b) HD SEL FLT on?	-	-	-	-	-	-	-	Y	-	-	
c) WR · RD FLT on?	-	-	-	-	-	-	-	-	Y	-	
d) $\overline{\text{ON CYL}} \cdot (W + R)$ on?	-	-	-	-	-	-	-	-	-	Y	

ACTIONS

5. Replace card B06 (Cyl Addr Reg).	1	-	-	-	-	-	-	-	-	-	
6. Go to Condition 5.	-	X	-	-	-	-	-	-	-	-	
7. Go to Condition 6.	-	-	X	-	-	-	-	-	-	-	
8. Go to Condition 7.	-	-	-	X	-	-	-	-	-	-	
9. Suspect cards A02, B10 (Address Mark Enable).	-	-	-	-	1	-	-	-	-	-	
10. Restore sw to ADDR MK position, repeat test and go to Condition 7.	-	-	-	-	-	X	-	-	-	-	
11. Chk that FTU's Servo Offset sw is "off" (center position).	-	-	-	-	-	-	1	1	1	1	
12. Replace card A01 (Write PLO).	-	-	-	-	-	-	2	-	-	-	
13. Replace card B07 (NRZ → MFM).	-	-	-	-	-	-	3	-	-	-	
14. Replace cards B02 (ch 1 rcurs) and B04 (ch 2 rcurs).	-	-	-	-	-	-	4	2	2	-	
15. Replace card A10 (Write Protect).	-	-	-	-	-	-	5	-	3	2	
16. Replace card B09 (On Cyl).	-	-	-	-	-	-	-	-	-	3	
17. Replace Writer (A3A03).	2	-	-	-	2	-	6	-	4	4	
18. Replace Hd Sel/Rd Amp (A3A02).	-	-	-	-	-	-	-	3	-	-	
19. Call Field Support.	3	-	-	-	3	-	7	4	5	5	

DLT 10	READ															
Warning: None																
Enters from: DLT 9																
Procedures: Head Replacement, Alignment (section 2C)																
References: Logic Diagrams																
Exits to: DLT 11																
Assumption: FTU connected to drive. FTU switches set per "Preliminary Set-up" in Operation section of TB304 manual. In addition, FTU Wrt-Rd Select switch set to RD.																
CONDITIONS								1	2	3	4	5	6	7	8	
1. Was address read properly? (1)								Y	Y	Y	N	N				
2. Was data read properly? (1)								Y	Y	N	-	-				
3. Are errors head-related?								-	N	Y	N	Y				
ACTIONS																
1. No problem. Go to DLT 11.								X	-	-	-	-				
2. Check that Data switches on FTU are set to read the pattern previously written on the disk.								-	1	-	-	-				
3. Replace card A06 (Read PLO; MFM + NRZ).								-	2	-	2	-				
4. Replace card A05 (Data latch).								-	3	-	3	-				
5. Replace card A08 (Offset).								-	4	-	4	-				
6. Replace cards B02, B04 (Ch 1, Ch 2 rcurs).								-	5	-	5	-				
7. Replace cards B01, B03 (Ch 1, Ch 2 xmtrs).								-	6	1	6	1				
8. Check head alignment (see Procedures, above).								-	7	2	7	2				
9. Replace Hd Sel/Rd Amp (A3A02).								-	8	-	8	-				
10. Replace faulty head(s). See Procedures, above.								-	-	3	-	3				
11. Reformat disk per WRT FORMAT procedure in TB304 manual.								-	-	-	1	-				
12. Call Field Support.								-	9	4	9	4				
(1) A NO answer here implies that the procedures given in the TB304 manual's Trouble Analysis DLT have already been tried in an attempt to recover the address or data, but to no avail.																

KØR-0679-2

PROCEDURES

PROCEDURE A: CHECKING DC VOLTAGES


This procedure defines dc-voltage check-points on the drive for both load and no-load conditions. It is used in conjunction with DLT2 or whenever a dc voltage is suspect.

The voltage readings in table A-2 may be obtained by using either a standard (needletype) or digital volt-ohmmeter. Table A-3 gives the usual symptoms for a malfunctioning power supply. Because spare parts for the components in the various supplies are not usually provided, a power supply is not normally repaired in the field, but simply replaced by substituting either a new power supply board or an entire power supply assembly.

TABLE A-2. CHECKING DC VOLTAGES

Voltage to be Checked	Volt-Ohmmeter Connections				Voltage Readings
	Normal Load (A1P/J2 Mated)		No Load (A1P/J2 Separated)		
	+Probe	-Probe	+Probe	-Probe	
+5	+5 Faston	Either of the GND Fastons on logic chassis or the ground-plane foil of the_XKV brd (see figure A-1).	J2-03		+5.1 (± 0.05)
-5	-5 Faston		J2-05	J2-01	-5.1 (± 0.05)
+12	U9-2 * **		J2-10	or	+12 (± 2)
-12	U8-2 * **		J2-08	J2-02	-12 (± 2)
+20	+20 Faston		J2-06	or	+20 (± 2)
-20	-20 Faston		J2-04	J2-12	-20 (± 2)
+42	AlF3		J2-13	or	+42 (± 2)
-42	AlF4		J2-09	J2-09	-42 (± 2)

* U8, U9 Pin Arrangement



** If ± 12 voltages remain in the range 7-9 V (\pm) or fluctuate between ± 12 V and 0 V, suspect a fault in the dc loads. Verify with no-load readings. Heavy overloads such as a dead short will cause the regulator's thermal protect feature to drop the output voltage to zero.

TABLE A-3. FAILURE SYMPTOMS IN POWER SUPPLIES

Symptom	Probable Cause
1. Noticable ripple at output (checked with oscilloscope)	Open diode or open filter capacitor
2. Less than specified output (ac input ok)	Shorted diode or shorted filter capacitor
3. Output decreases significantly when load is connected.	Open bleeder resistor

Procedure:

1. Turn off POWER SUPPLY breaker (CB2).
2. Raise logic chassis to maintenance position to give access to voltage Fastons.
3. Be sure that P/J2 is mated to provide loads for the supplies to be checked.
4. Turn on CB2.
5. Using the VOM probe connections from the NORMAL LOAD columns of table A-2, check each supply voltage.
6. If any voltage is outside the tolerance given in table A-2, or is nonexistent, proceed to check the no load voltages by separating P/J2 and using the probe connections specified in the NO LOAD columns of the table. (Turn off CB2 before separating P/J2).
7. If the ± 5 V readings are outside the tolerances of table A-2, adjust those voltages as described under the Plus and Minus 5 Volt Adjustment procedure in section 2C.
8. If further maintenance is not to be performed at this time:
 - a. turn off CB2
 - b. reconnect P/J2
 - c. return the logic chassis to its normal position and secure the 1/4-turn fastener.
 - d. turn on CB2 to restore normal drive functions.

PROCEDURE B: CHECKING AC INPUTS TO POWER SUPPLY BOARDS

This procedure verifies that a given secondary winding of ferroresonant transformer T1 has sufficient voltage to drive its associated power supply. The procedure should be performed whenever T1 is suspected as the cause for a lower-than-normal dc voltage, as measured using Procedure A. Steps 6 through 16 should also be performed whenever either the power supply assembly or the XKV power supply board has been replaced, to assure that the previously malfunctioning supply did not damage the transformer.

NOTE

The ± 5 , ± 20 , and ± 42 V supplies constitute the load for T1 and its tuning capacitor, A1C8. Without a load, T1 would oscillate and produce meaningless voltage readings. For this reason, do not separate P/J1 in an attempt to measure the ac input voltages directly at the pin-sockets of P1.

The first five steps in the procedure, along with the resistance readings in table A-4, assure that the XKV board itself is not shorted. This ensures that the subsequent ac input readings will be valid indication of the transformer's performance. Table A-5 shows the oscilloscope connections for monitoring the ac input to each supply. Figure A-1 gives the location of those monitoring points on the XKV board. Figure A-2 shows the square-wave input (secondary-winding output) and the nominal ac voltages, the latter given more precisely in table A-5.

PROCEDURE:

Steps 1 through 5 ensure that there are no shorts in the power supplies on the XKV board that might give the erroneous impression that T1 was at fault rather than the board itself.

1. Turn off CB2 (Power Supply breaker)
2. Remove the plastic cover protecting the XKV board.
3. Isolate the XKV board by separating connectors P/J1 (to T1) and P/J2 (to dc loads).
4. Referring to table A-4, check the input resistance of each supply. Allow time for the input capacitor to charge before determining the final reading.

5. If any of the four readings are significantly lower than those given in table A-4, the _XKV board should be replaced.

Steps 6 through 16 check the ac input to the _XKV board.

6. Reconnect P/J1.
7. Plug in the test scope and set the trigger control to LINE. Turn on the scope and when the horizontal trace becomes visible, center it on the graticule.
8. Connect the scope's ground probe to the ground-plane foil of the _XKV board (refer to figure A-1).




Figure A-1. AC-Input Probe Points on _XKV Board

TABLE A-4. CHECKING FOR SHORTED _XKV BOARD

Power Supply	VOM Connections to J1	Resistance (VOM Scale: Rx100)
+5 V	1,3	Inf.
-5 V	5,7	Inf.
±20 V	6,8	4300Ω
±42 V	2,4	4300Ω

9. Turn on CB2.
10. Connect the scope's + probe (i.e., CH1 or CH2, depending upon scope set-up) to either lead of the input filter capacitor listed in table A-5 for the voltage to be checked. (Refer to figure A-1 for capacitor locations.)
11. Adjust scope's TIME/DIV control to secure a stable square-wave trace (ref: figure A-2).
12. Adjust scope's VOLTS/DIV control to allow easy mental reckoning of the voltage represented by the trace, as shown against the graticule lines.
13. Record the voltage (or make a mental note, if you trust your visual memory) from the ground reference line on the graticule to the top and bottom plateaus of the trace, as indicated by "E" in figure A-2 (two readings).
14. Repeat step 13 with the + probe connected to the other lead of the input capacitor.
15. If both steps 13 and 14 show a symmetrical waveshape about the ground reference line (that is, all four voltage readings are the same), and are within the tolerance specified in table A-5, the T1 winding for that particular supply is ok.

TABLE A-5. CHECKING AC INPUTS TO _XKV BOARD

Supply to be Checked for AC Input	Scope Connections (Refer to Figure A-1)		AC Input Voltages (Check each Side of Input Capacitor)
	+Probe	-Probe	
+5 V	(AC Input) C1	(Ground) Ground-plane foil of _XKV board (see fig. A-1)	11 v \pm 1 V
-5 V	C7		11 V \pm 1 V
\pm 20 V	C11		22 V \pm 1 V
\pm 42 V	C16		44 V \pm 2 V

NOTE

If you suspect a disparity between the sets of readings taken in steps 10 and 11, check the probe points again with a VOM, which will make any difference more distinguishable. Keep in mind that the VOM readings will be less because they are effective, not peak, voltages.

16. If the voltage readings are not the same, or if they are the same but not within the tolerance given in table A-5, the problem has to be a shorted winding in T1. You may be able to confirm this by sniffing the transformer for evidence of burned insulation, although this is not a definite test. Proceed to step 17.

WARNING

Tuning capacitor AlC8 is charged to 440 volts. Be sure to discharge it before starting step 17.

17. Replace transformer T1, using the procedure given in section 2D.
18. Check the newly installed transformer by repeating steps 6 through 14.

Figure A-2. T1 Inputs to Power Supply (XKV Board)

OSCILLOSCOPE SETTINGS


SCOPE GND TO LOGIC GND

VOLTS/DIV
 CH 1 - ①
 CH 2 - NA

TIME/DIV
 A - VARY FOR CONVENIENT TRACE
 B - NA

TRIGGERING
 A (USE X1 PROBE) - LINE
 B (USE X PROBE) - NA

PROBE CONNECTIONS
 CH 1 (USE X1 PROBE) - ②
 CH 2 (USE X PROBE) - NA



- ① ±5 V: E=11 V
- ±20 V: E=22 V
- ±42 V: E=44 V

- ② SEE TABLE

9K68

PROCEDURE C: TROUBLESHOOTING HEAT-GENERATED PROBLEMS

CAUTION

If the heads perform an unscheduled retract and the START and FAULT lights are both off, immediately turn off the POWER SUPPLY breaker; you have dropped +5 V and run the risk of burning up the voice coil. Only after you've shut off dc power should you check to see if the power-down resulted from a failure on the ac line. (Hint: check to see if the blower is still on).

If you commit the above CAUTION to memory and act instinctively upon it, you may one day save yourself a lot of trouble; failure of the +5 V supply is a common cause for abnormal shut-downs.

Heat-related problems are easy to diagnose: they occur only when the drive gets hot, and they disappear when the drive has had a chance to cool off. If you suspect a problem is heat-related, let the drive cool down, then note the failure (or more accurately, the absence of the failure) when the drive is started up again. Often the troubleshooting period can be shortened by applying artificial heat to the suspected area (a hair dryer is useful here). Once you've diagnosed the problem, correct it as you would any other malfunction.

Heat problems are of two types -- those originating in the power supplies and those developing in the various loads. Should a load fault take out a 20 V or 42 V fuse, the course is clear: simply refer to the applicable "load" DLT. If the load does not pop a fuse but merely brings up a FAULT light (on the back of the operator panel), the table below should offer a starting point for correcting the problem. (If the +5 V supply goes, of course, the fault lights won't work.)

<u>FAULT</u>	<u>PROBLEM RELATED TO</u>
Voltage (except +5 V)	A03, A04, A09
On Cyl. (W+R)	A03, B02, B09
Write	A03, A04, B01, A3A03 Write Driver board)
W·R	A04, B02
Hd Sel	A02, A04, A3A02 (Hd Sel/Rd Amp board)

Losing ± 5 V can be bothersome because those supplies maintain a uniform output voltage right up to their current limit, and then drop to 0 V when that limit is exceeded. Should this happen, check to see if the supply itself is the culprit by disconnecting the 5 V load. If the voltage returns to 5 V, the fault lies in the load, not the supply.

PROCEDURE D: PIN-POINTING VOLTAGE FAULTS IN THE LOGIC CHASSIS

This procedure locates ± 5 V, ± 20 V, and ± 42 V faults on cards in the logic chassis or in the logic chassis backpanel wiring. (There is no ± 12 V load in logic chassis assembly A2.)

The test procedure may be conducted in either of two ways. The first method is to check the ± 5 V, ± 20 V, and ± 42 V loads individually by entering Procedure D from the applicable DLT:

± 5 V -- Condition 1 of DLT 3

± 20 V -- Condition 1 of DLT 4

± 42 V -- Condition 3 of DLT 6

The second method is to check all three loads at the same time. The test for load faults in each voltage is made by adding cards to the logic chassis one at a time, so it is more efficient to check all three loads on a given card at one time. (Of course, some cards will not require all three checks.)

The second method is the one described below, and requires that the tests for Conditions 1 and 2 of DLT 6 have been satisfactorily completed before entering the procedure.

NOTE

It should be pointed out that, as shown in table A-1, only +5 V is used on every card. If there is no +5 V fault in the logic chassis, only the cards using the faulted voltage(s) need to be removed.

1. Be certain that Conditions 1 and 2 of DLT 6 have been tested with satisfactory results before proceeding to step 2. (Condition 1 checks the servo capacitors, Condition 2 the power amplifier.)
2. Turn off the POWER SUPPLY (PS) breaker.
3. Separate PA80 and PA81 from their jacks on the logic chassis.
4. Ensure that all other connectors are properly mated.
5. Remove all cards from the logic chassis. (See NOTE, above, for possible exception to this "all cards: rule.")
6. Turn on the PS breaker.
7. Load faults caused by wiring errors in (or damage to) the logic chassis backpanel will show up as a blown fuse. Check the integrity of each fuse as described in DLT 2. If a fuse blows, carefully raise the logic chassis to the maintenance position and check backpanel for grounds caused by bent pins or dangling wires. After clearing the fault, restore the logic chassis to its normal position.
8. Turn off the PS breaker. You are now ready to start putting the cards back in the logic chassis one at a time, checking for faults after each one has been inserted.
9. Before inserting a card, examine both sides for evidence of arcing across the foil. Often the carbon residue around an arc area can be removed with an alcohol swab and the card won't give any more trouble.
10. Insert the selected card properly.
11. Turn on the PS breaker.
12. Using table A-1 to determine which voltages are present on the card, check the integrity of the applicable fuses.

13. If step 12 shows a blown fuse, turn off the PS breaker, replace the card just installed with a fresh one from the spare parts bin and try the test again.
14. If step 12 shows that the fuses are OK, turn off the PS breaker and, selecting another card, repeat steps 9 through 14.
15. When all cards have been checked good, return to the applicable "load fault" DLT to continue the dc-load checkout on the additional assemblies.

APPENDIX B

DECISION LOGIC TABLES

(DLTs)

**for SMDs with 3
Card Power Supplies**

CONTENTS

APPENDIX B	
Introduction	B-1
Using the DLT	B-2
Useful Troubleshooting Aids	B-3
Using a VOM to Check a Capacitor	B-3
In-Circuit Diode Checking With A VOM	B-3
DECISION LOGIC TABLES	
DLT 1 - Power Up	B-7
DLT 2 - Isolating Problems in the ± 5 V Network	B-10
DLT 3 - Isolating Faults in the ± 5 V Loads	B-11
DLT 4 - Isolating Faults in the ± 20 V Loads	B-13
DLT 5 - Isolating Faults in the ± 12 V Loads	B-14
DLT 6 - Isolating Faults in the ± 42 V Loads	B-15
DLT 7 - First Seek	B-17
DLT 8 - RTZ, Continuous Seeks	B-19
DLT 9 - Write	B-21
DLT 10 - Read	B-22
DLT 11 - Power Down	B-23
PROCEDURES	
Procedure A: Checking DC Voltages	B-25
Procedure B: Checking AC inputs to Power Supply Boards	B-28
Procedure C: Troubleshooting Heat-Generated Problems	B-32
Procedure D: Pin-Pointing Voltage Faults in the Logic Chassis	B-33

FIGURES

B-1	T1 Input to Power Supplies	B-30
-----	----------------------------	------

TABLES

B-1	Voltages Used by Electronic Components	B-5
B-2	Checking DC Voltages	B-26
B-3	Failure Symptom in Power Supplies	B-26
B-4	Checking AC Inputs to Power Supplies	B-29

DECISION LOGIC TABLES (DLTs)

INTRODUCTION

Decision logic tables help maintenance technicians organize their thinking when problems occur in the drive. For a given fault condition (or set of conditions), actions are recommended to locate and correct the fault. The actions are arranged so that the corrective measures that are easiest to perform (checking a fuse or changing a card in the logic chassis, for example) are listed before the more difficult tasks such as replacing the head/arm assembly or drive motor.

A Useful Troubleshooting Aids section contains two general-interest maintenance procedures, as well as a voltages-used table that should prove helpful throughout the troubleshooting effort.

The DLTs consist of 11 tables, described briefly below.

- DLT 1 shows how to correct problems that occur when attempting to "power-up" the drive, including the failure of any of the three dc power supplies.
- DLT 2 helps to define the origin of ± 5 V load fault -- either in the loads or in the supply itself.
- DLT 3 shows how to isolate a ± 5 V load fault to a given area or electrical component.
- DLTs 4, 5, and 6 show how to locate and correct faults in the ± 20 V loads, ± 12 V loads, and ± 42 V loads.
- DLTs (7 through 10 are used with the FTU (TB303) to correct various seek and read/write errors).
- DLT 11 shows what to do when a drive does not "powerdown" properly.

The procedures referred to in the DLTs form the last portion of this discussion.

USING THE DLT

The DLT is divided into four quadrants. The upper-left quadrant, CONDITIONS, contains the various test conditions that can be answered "yes" or "no". The CONDITIONS quadrant is prefaced by any ASSUMPTIONS (that is, pre-conditions) that must be observed if the test results are to be valid. Sometimes, prerequisite actions other than the ASSUMPTIONS must be taken before the test for a given condition is made. Such steps are included in the CONDITIONS quadrant. The yes (Y) or no (N) answers to each condition are shown in numbered columns in the topright Situations quadrant.

To use the DLT, first determine whether the result of a condition tested is Y or N. If two or more conditions exist simultaneously, look for a situations column that combines the appropriate Y-N answers for those conditions. A dash (-) in the top-right Situations quadrant means that the related Condition is not a factor in determining what actions are to be taken for that situation.

Next, determine what action should be taken for a given test result (i.e., situation) by following down the selected column to the row marked "1" in the lower-right Sequence quadrant. (If there is only one recommended action for a given situation, an "X" appears instead of the "1".) The recommended action is then located by moving across to the lower-left ACTIONS quadrant. A dash in a column of the Sequence quadrant indicates that the related Action isn't applicable.

After taking the first recommended action, repeat the test that gave rise to the situation. If the test results haven't changed (same situation), try recommended action 2, and so on, being sure to repeat the test after each such action.

Column 1 is generally reserved for an "everything OK" situation. If a DLT requires more than one sheet, this "no problem" column is repeated on each sheet. Similarly, the last ACTION on each sheet is a recommendation to "call field support". Don't brood over your inadequacy if you reach this last entry; not every situation can be covered in a DLT.

USEFUL TROUBLESHOOTING AIDS

USING A VOM TO CHECK A CAPACITOR

1. Remove power from the equipment.
2. Discharge capacitor by momentarily shorting the leads with a jumper wire. (Use screwdriver for large capacitors.)
3. Isolate the capacitor by disconnecting one lead from the circuit.
4. Set VOM to X1000 (ohms) scale.
5. Connect the VOM across the capacitor leads. The condition of the capacitor is interpreted as follows:

<u>Meter reading</u>	<u>Interpretation</u>
Needle goes rapidly to full scale (0Ω), then regresses to infinity (∞). (See NOTE.)	Capacitor OK
Needle goes rapidly to full scale and remains there.	Capacitor shorted
Needle deflects slightly or not at all.	Capacitor open

NOTE

Speed with which needle returns to infinity (∞) is a function of capacity rating. Return swing is rapid for small capacitors, becoming slower as capacity increases. To a lesser degree, return swing is also dependent upon which meter scale is used.

IN-CIRCUIT DIODE CHECKING WITH A VOM

A diode that is suspect can be given a preliminary check without disconnecting it from the circuit. Merely check the diode twice, reversing the meter leads between the two readings. Of course, power should be off, and for your own peace of mind any capacitors in the circuit should be discharged.

Keep in mind that the forward drop across a good diode is in the range 5 - 15 Ω ; the reverse drop is on the order of 1 M Ω . Parallel resistances in the circuit will, of course, significantly reduce the higher of these two readings, but if one is low and the other high, chances are the diode is OK. If both are low, the diode is probably shorted; if both are high, it's probably open.

This check can also be used for a bridge rectifier. You'll probably want to check at least two diodes in the bridge, because back-circuits may give different readings across different diodes.

TABLE B-1. VOLTAGES USED BY ELECTRONIC COMPONENTS

Volt- ages	A1 - Power Supply								A3 - Deck					VC1
	Servo Cap Board C1 C2	Run Triac K1	Em. Retr. Relay K2	Contr Pnl A01	Hd Rd A02	Sel Amp A03	Writ- er A03	Pwr Amp A04	Ser- vo Pre- Amp A05	Start Triac K5	Hyst Brake HB1	Pack Cover Sol L3		
+5 V		x		x	x	x	x			x				
-5 V						x	x							
+12 V						x			x					
-12 V						x			x					
+20 V			x			x					x	x		
-20 V														
+42 V	x						x	x				x		
-42 V		x						x				x		

DECISION LOGIC TABLES

DLT 1	POWER UP	(sheet 1 of 3)														
Warning: Tuning capacitor A1C8 is charged to 440 volts!																
Enters from: Assumptions																
Procedures: See sheet 2																
References: Logic Diagrams																
Exits to: Sheet 2																
Assumption: 1. Drive connected to ac power 2. Disk pack installed 3. Attempt to power up and start drive from SMD panel.																
CONDITIONS								1	2	3	4	5	6	7	8	
1. AC POWER (AC) breaker trips when actuated?								N	Y	N	N	N	N	N	N	-
2. Blower motor starts when AC breaker is actuated?								Y	-	N	N	Y	-	-	-	
3. Door fans start when AC breaker is actuated?								Y	-	N	Y	N	-	-	-	
4. POWER SUPPLY (PS) breaker trips when actuated?								N	-	-	-	-	Y	-	-	
5. AC or drive motor thermal brkr trips when PS brkr is actuated?								N	-	-	-	-	-	Y	-	
6. The smell of burning insulation detected after actuating PS brkr?								N	-	-	-	-	-	-	Y	
ACTIONS																
1. Continue with Condition 7 on sheet 2.								X	-	-	-	-	-	-	-	
2. If pwr plug customer-provided, chk phase and grd connections.								-	1	1	-	-	-	-	-	
3. Suspect blower--separate J/P301; if trouble persists, blower is OK.								-	2	-	-	-	-	-	-	
4. Suspect time meter--disconnect, then try again to verify.								-	3	-	-	-	-	-	-	
5. Suspect door fans--separate J/P400, then try again to verify.								-	4	-	-	-	-	-	-	
6. Check for ac in and out of line filter A1FL1.								-	-	2	-	-	-	-	-	
7. Suspect open blower cap A1C5, or open in blower motor or cable.								-	-	-	1	-	-	-	-	
8. Check AC breaker for continuity.								-	5	3	-	-	-	-	-	
9. Check continuity of door fans and cabling.								-	-	-	-	1	-	-	-	
10. Suspect shorted tuning capacitor A1C8--see WARNING, above.								-	-	-	-	-	1	-	-	
11. Trouble may be a shorted p.s. board, a short in T1 wiring, or a short in T1 itself. To check further, go to sheet 2 voltage checks.								-	-	-	-	-	2	-	-	
12. Suspect Run triac energized before START sw has been pressed. Troubleshoot logic, starting with logic card at location A10.								-	-	-	-	-	-	1	-	
13. Chk Run triac for shorted LOAD contacts (Terminals 1,2).								-	-	-	-	-	-	2	-	
14. You have lost +5 V power. IMMEDIATELY TURN OFF THE POWER SUPPLY BREAKER TO PREVENT BURNING UP THE VOICE COIL. To check on voltage loss, go to sheet 2.								-	-	-	-	-	-	-	X	
15. Call Field Support.								-	6	4	2	2	3	3	-	

KØR-0679-2

DLT 1

POWER UP

(sheet 2 of 3)

Warning: Tuning capacitor AlC8 is charged to 440 volts!

Enters from: Sheet 1

Procedures: A, B

References: Logic Diagrams

Exits to: Sheet 3 and DLTs 4,5,6

Assumption: Use Procedure A to check dc voltages in Conditions shown.

CONDITIONS		1	9	10	11	12	13	14	15	16	17	18
7. ±5 voltages OK?		Y	N	N	N	-	-	-	-	-	-	-
8. ±12, ±20, ±42 voltages significantly low?		N	Y	N	N	-	-	-	-	-	-	-
9. Are either of the 9.2 V fuses on ±5 V p.s. board blown? ①		-	-	Y	N	-	-	-	-	-	-	-
10. ±20 voltages OK?		Y	-	-	-	N	N	Y	Y	Y	-	-
11. Are either of the 20 V fuses on the ±20 V p.s. board blown? ①		-	-	-	-	Y	N	-	N	N	-	-
12. ±12 voltages OK with load connected?		Y	-	-	-	-	-	N	N	N	-	-
13. ±12 voltages OK with load disconnected per Action 22?		-	-	-	-	-	-	-	Y	N	-	-
14. ±42 voltages OK?		Y	-	-	-	-	-	-	-	-	N	N
15. Are either of the 42 V fuses on the ±42 V p.s. board blown? ①		-	-	-	-	-	-	-	-	-	Y	N
ACTIONS												
16. Continue with Condition 16 on sheet 3.		X	-	-	-	-	-	-	-	-	-	-
17. Suspect open tuning capacitor--see WARNING, above.		-	1	-	-	-	-	-	-	-	-	-
18. Trouble may be either on the ±5 V p.s. board or in the ±5 V loads. To see which, go to DLT 2.		-	-	X	-	-	-	-	-	-	-	-
19. Faulty supply or T1 winding. To see which, go to Procedure B.		-	-	-	1	-	1	-	-	-	-	1
20. Trouble is in the ±20 V loads. Go to DLT 4.		-	-	-	-	X	-	-	-	-	-	-
21. Replace ±20 V p.s. board.		-	-	-	-	-	-	-	-	1	-	-
22. Isolate load by separating P/J1A and P/J1B, then go to Condition 13.		-	-	-	-	-	-	X	-	-	-	-
23. Trouble is in the ±12 V loads. Go to DLT 5.		-	-	-	-	-	-	-	X	-	-	-
24. Trouble is in the ±42 V loads. Go to DLT 6.		-	-	-	-	-	-	-	-	-	X	-
25. Call Field Support.		-	2	-	2	-	2	-	-	2	-	2
① Check with VOM between ground and each side of fuse. If supply voltage appears on only one side, fuse is bad.												

KØR-0679-3

DLT 1

POWER UP

(sheet 3 of 3)

Warning: None

Enters from: Sheet 2

Procedures: A, C

References: Logic Diagrams

Exits to: DLT 7

Assumption:

CONDITIONS								1	19	20	21	22	23	24	25	
16.	AC brkr or motor thermal brkr trips when START sw is pressed?	N	Y	N	N	N	N	N	N	N	N	N	N	N	N	N
17.	START light comes on when START switch is pressed?	Y	-	N	N	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y
18.	Drive motor starts when START switch is pressed?	Y	-	Y	N	N	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y
19.	Drive motor comes up to speed?	Y	-	-	-	-	N	Y	Y	Y	Y	Y	Y	Y	Y	Y
20.	Heads load? (READY light comes on.)	Y	-	-	-	-	-	N	Y	Y	Y	Y	Y	Y	Y	Y
21.	Drive motor cuts out after 15-second timeout expires?	N	-	-	-	-	Y	-	-	-	-	-	-	-	-	-
22.	PS brkr trips after drive has been operating satisfactorily?	N	-	-	-	-	-	-	-	-	-	-	-	-	-	Y

ACTIONS								1	19	20	21	22	23	24	25	
26.	Power up completed satisfactorily. Go to DLT 7.	X	-	-	-	-	-	-	-	-	-	-	-	-	-	-
27.	Suspect Run logic--start with card A10.	-	-	-	-	3	-	-	-	-	-	-	-	-	-	-
28.	Suspect Run triac.	-	-	-	-	4	1	-	-	-	-	-	-	-	-	-
29.	Suspect Start triac.	-	1	-	-	-	-	-	-	-	-	-	-	-	-	-
30.	Suspect drive motor Start capacitor (A3C6).	-	2	-	-	5	-	-	-	-	-	-	-	-	-	-
31.	Suspect open Start winding on drive motor.	-	3	-	-	8	-	-	-	-	-	-	-	-	-	-
32.	Suspect START switch/indicator.	-	-	1	-	-	-	-	-	-	-	-	-	-	-	-
33.	Check all interlocks.	-	-	-	1	-	-	-	-	-	-	-	-	-	-	-
34.	Check for presence of +5 V (using Procedure A).	-	-	-	2	-	-	-	-	-	-	-	-	-	-	-
35.	Chk that Local/Remote sw (card A10) is in LOCAL position.	-	-	-	-	1	-	-	-	-	-	-	-	-	-	-
36.	Suspect tripped drive motor thermal brkr--reset and check cause.	-	-	-	-	2	-	-	-	-	-	-	-	-	-	-
37.	Check hysteresis brake for mechanical binding.	-	-	-	-	6	2	-	-	-	-	-	-	-	-	-
38.	Suspect brake logic continuously energized--start with card A10.	-	-	-	-	7	3	-	-	-	-	-	-	-	-	-
39.	Suspect speed sensor and/or attendant logic--card A10.	-	-	-	-	4	-	-	-	-	-	-	-	-	-	-
40.	Suspect open Run winding on drive motor.	-	-	-	-	9	-	-	-	-	-	-	-	-	-	-
41.	Refer to DLT 7, First Seek.	-	-	-	-	-	-	-	-	-	-	-	-	X	-	-
42.	Suspect overloaded (overheated) supply. Go to Procedure C.	-	-	-	-	-	-	-	-	-	-	-	-	-	-	1
43.	Call Field Support.	-	4	2	3	10	5	-	2	-	-	-	-	-	-	-

KØR-0679-2

DLT 2 ISOLATING PROBLEMS IN THE ±5 V NETWORK

Warning: None

Enters from: DLT 1

Procedures: None

References: None

Exits to: DLT 3

Assumption: No ±5 V, other voltages are present. Fuse(s) on ±5 V p.s. board blown, indicating a problem either in the loads or in the supply itself.

CONDITIONS		1	2	3	4	5	6	7	8
1. Check out unregulated portion of ±5 V p.s. board:									
a) Turn off AC breaker; reset PS breaker if tripped.									
b) Remove fuses F1 and F2.									
c) Disconnect loads by separating connectors P/J1B and P/J1A.									
d) Remove ±20 V p.s. board.									
e) Remove ±42 V p.s. board.									
f) Turn on AC breaker.									
Does PS breaker trip?		N	Y	-	-				
2. Check out regulated portion of ±5 V p.s. board:									
a) Turn off PS breaker.									
b) Replace F1 and F2. (Use good fuses!)									
c) Turn on PS breaker.									
Does either F1 or F2 blow?		-	-	N	Y				
ACTIONS									
1. Unregulated portion is OK. Go to Condition 2.		X	-	-	-				
2. Turn off PS breaker and replace ±5 V p.s. board, then reinstall ±42 V and ±20 V p.s. boards.		-	X	-	X				
3. ±5 V board is OK, so problem must be in the load. Turn off the PS breaker, rejoin connectors P/J1A and P/J1B, then go to DLT 3.		-	-	X	-				

KØR-0679-2

DLT 4 ISOLATING FAULTS IN THE ±20 V LOADS

Warning: None

Enters from: DLT 1

Procedures: D

References: DLT 5

Exits to:

Assumption: ±20 V power supply board installed in power supply assembly; ±5 V and ±42 V boards removed. P/J1A and P/J1B connected.

CONDITIONS	1	2	3	4	5	6	7	8
1. Restrict ±20 V load to logic chassis:								
a) Turn off PS breaker.								
b) Separate P/JA81 on logic chassis. (1)								
c) Turn on PS breaker.								
Does either 20 V fuse blow? (2)	N	Y	-	-				
2. Add A3A02 (Hd Sel/Rd Amp) to +20 V load:								
a) Turn off PS breaker.								
b) Reconnect P/JA81.								
c) Turn on PS breaker.								
Does +20 V fuse blow? (2)	-	-	N	Y				
ACTIONS								
1. ±20 V loads in logic chassis are OK. Go to Condition 2.	X	-	-	-				
2. Go to Procedure D to check logic chassis.	-	X	-	-				
3. ±20 V power distribution is OK. Chances are that the fault appears when the logic connects the emergency retract relay coil, the hysteresis brake, or the pack cover solenoid to +20 V. Most probable cause is a shorted or grounded coil in one of these components.	-	-	1	-				
4. Replace A3A02.	-	-	-	1				
5. Call Field Support.	-	-	2	2				
(1) This arrangement retains the ±12 V power (unfused) to the servo preamp, assembly A3A05. The alternative is to disconnect P8, which is hardly worth the effort since properly reconnecting it to A3A05 is rather difficult. In any event, current-limiting resistors in the 12 V circuits prevent damage to the supply or components if the 12 V loads are faulty. See DLT 5 for checking the 12 V loads.								
(2) Test fuses by using a VOM between ground and each side of the fuseholder. If there is no voltage on the load side of the fuse, the fuse has blown.								

KØR-0679-2

DLT 5 ISOLATING FAULTS IN THE ±12 V LOADS

Warning: None

Enters from: DLT 1 or DLT 4

Procedures: None

References: Procedure A

Exits to:

Assumption: ±20 V (±12 V) board and ±5 V board installed in power supply assembly; ±42 V board removed. P/J1A and P/J1B connected.

CONDITIONS

	1	2	3	4	5	6	7	8
1. Isolate ±12 V load to A3A05 (servo preamp):								
a) Turn off PS breaker.								
b) Separate P/JA81 from logic chassis.								
c) Turn on PS breaker.								
d) Using VOM, check between +12 V Zener diode VR1 (red wire) on ±20 V p.s. board and ground, and between -12 V diode VR2 (blue wire) and ground. Do the voltages differ from one another by more than 0.3 volts?	N	Y	-	-				
2. Add A3A02 (Hd Sel/Rd Amp) to ±12 V load:								
a) Turn off PS breaker.								
b) Reconnect P/JA81.								
c) Turn on PS breaker.								
d) Check voltages at VR1 and VR2 as in Condition 1d). Are voltages within the tolerance given in Procedure A?	-	-	Y	N				

ACTIONS

	1	2	3	4	5	6	7	8
1. Servo preamp is OK. Go to Condition 2.	X	-	-	-				
2. A voltage difference here could cause unequal amplification of the servo dibits, resulting in an On Cylinder null signal that is not centered over the servo track. This "permanent offset" may give sporadic Read errors, or even cause reading of the wrong data track. The voltage disparity could be caused by a Zener that doesn't work properly under load, or by a faulty servo preamp. Replace the ±20 V p.s. board first, and if that doesn't help, go to Action 4.	-	1	-	-				
3. If you're reading this, you must have come down the wrong column. At any rate, you no longer have a ±12 V load fault!	-	-	X	-				
4. Replace servo preamp (A3A05).	-	2	-	-				
5. Replace Hd Sel/Rd Amp (A3A02).	-	-	-	1				
6. Call Field Support.	-	3	-	2				

KØR-0679-2

DLT 7

FIRST SEEK

(sheet 1 of 2)

Warning: None

Enters from: DLTs 1 through 6

Procedures: See sheet 2

References: Logic diagrams

Exits to: DLT 8 or sheet 2 of this DLT

Assumption: START light is on, drive is coming up to speed.

CONDITIONS

	1	2	3	4	5	6	7	8
1. READY light comes on, signifying successful First Seek?	Y	N	N	N	N	N		
2. First Seek attempted?	-	N	N	N	N	N		
3. Check that Heads Loaded switch (A3S2) is transferring:								
a) Press START sw to stop disk. Do not turn off breakers.								
b) Manually push voice coil forward to move heads off unloading ramp. Does voice coil resist fwd movement?	-	-	N	Y	Y	Y		
4. Check for forward drive to voice coil:								
a) Disconnect black lead from voice coil (term. 2 in c.r. 282).								
b) Attach + probe of VOM to black wire, com. probe to logic gnd.								
c) Press START.								
d) Wait 15-20 sec for up-to-speed time out to expire, then chk VOM.								
Does VOM read approx +40 V?	-	-	-	-	N	Y		

ACTIONS

1. No problem--go to DLT 8.	X	-	-	-	-	-		
2. Go to Condition 3.	-	X	-	-	-	-		
3. Suspect leads to (or contacts in) E.R. relay AlK2.	-	-	1	-	-	-		
4. Suspect open voice coil.	-	-	2	-	-	-		
5. Replace A3S2 (Hds Loaded sw).	-	-	3	-	-	-		
6. Replace power amp ass'y.	-	-	4	-	6	-		
7. A3S2 is OK. Go to Condition 4 to chk fwd drive on voice coil.	-	-	-	X	-	-		
8. Suspect card A09 (pwr amp control).	-	-	-	-	1	-		
9. Suspect card B09 (direction control).	-	-	-	-	2	-		
10. Suspect card A07 (summing amp).	-	-	-	-	3	-		
11. Suspect card B06 (diff cntr, CAR).	-	-	-	-	4	-		
12. Suspect card A10 (speed control).	-	-	-	-	5	-		
13. Voice coil should attempt First Seek upon expiration of up-to-speed timeout. Go to Condition 5 on sheet 2.	-	-	-	-	-	X		
14. Call Field Support.	-	-	5	-	7	-		

KØR-0679-2

Warning: None
Enters from: Sheet 1
Procedures: Head-Arm Replacement (section 2D); Hd-Arm Alignment (section 2C)
References: Logic Diagrams
Exits to: DLT 8
Assumption: START light is on; drive attempts First Seek.

CONDITIONS	7	8	9	10	11	12	13
1. READY light indicates successful First Seek? (From sheet 1.)	N	N	N	N	N	N	N
2. First Seek attempted? (From sheet 1.)	Y	Y	Y	Y	Y	Y	Y
5. Drive attempts First Seek, then unloads?	Y	Y	Y	Y	-	-	-
6. Servo preamp input to card A03 OK?	-	N	Y	Y	-	-	-
7. Track Servo signal present at A03-09B?	-	-	N	Y	-	-	-
8. Drive seeks to forward mechanical stop, FAULT light comes on (+42 fuse blows) but heads don't unload--unit can't pwr down?	-	-	-	-	Y	-	-
9. Drive seeks to fwd mech stop, waits for FAULT light (+42 fuse blows), then retracts?	-	-	-	-	-	Y	-
10. Drive loads heads, hesitates, then creeps to fwd EOT?	-	-	-	-	-	-	Y

ACTIONS	7	8	9	10	11	12	13
15. Not sensing dibits. Chk servo preamp input to card A03 pin 23B (+ dibits) and A03-25B (- dibits), then go to Condition 6.	X	-	-	-	-	-	-
16. Chk for continuity/gnds in servo preamp cable (input to A03).	-	1	-	-	-	-	-
17. Replace A3A05 (servo preamp).	-	2	-	-	-	-	-
18. Replace and align servo head (see Procedures, above).	-	3	-	-	-	-	-
19. Suspect card A03.	-	-	1	-	-	-	-
20. Suspect propagation of Track Servo signal logic through cards A08, A07, A09, B09.	-	-	-	1	-	-	-
21. Replace power amp A3A04.	-	-	-	-	3	2	-
22. Suspect velocity transducer and attendant logic on cards A08, A09, B09.	-	-	-	-	2	-	-
23. Check Fine Enable logic (cards A08, B09).	-	-	-	-	1	-	1
24. Suspect cards A03, A07, A09.	-	-	-	-	-	1	2
25. Call Field Support.	-	4	2	2	4	3	3

DLT 8

RTZ/CONTINUOUS SEEKS

Warning: None

Enters from: DLT 7

Procedures: None

References: Logic Diagrams

Exits to: DLT 9

Assumption: 1. TB304 FTU is connected to drive via A and B I/O cables
2. Local/Remote switch on drive (card A10) set to REMOTE
3. LAP installed and drive selected from FTU.

CONDITIONS

Table with 8 columns (1-8) and multiple rows of conditions. Row 1: '1. Actuate RTZ sw on FTU. Is RTZ seek successful?' with values Y, N, -, -, -. Row 2: '2. Set up and perform continuous seeks.' with empty cells. Row 3: 'a) Set FTU's Access Mode sw to CONT.' with empty cells. Row 4: 'b) Set all FTU Cyl Adrs switches to "off" (down).' with empty cells. Row 5: 'c) Actuate START sw (on FTU).' with empty cells. Row 6: 'd) Sequentially select/deselect cylinder address switches (1,2,4...256, 512) to step actuator between track 0 and track selected by active cyl adrs switch.' with empty cells. Row 7: 'Is Continuous Seek successful?' with values Y, -, N, -, -. Row 8: '3. Select track (cyl) 822 on FTU panel:' with empty cells. Row 9: '• Set Cyl Adrs switches to 1466g; START.' with empty cells. Row 10: 'Was seek to track 822 successful?' with values Y, -, -, N, -. Row 11: '4. Select track (cyl) 823 on FTU panel:' with empty cells. Row 12: '• Set Cyl Adrs switches to 1467g; START.' with empty cells. Row 13: 'Does Seek Error result when seeking to track 823?' with values Y, -, -, -, N.

ACTIONS

Table with 8 columns (1-8) and 8 rows of actions. Row 1: '1. Seeks properly executed. Go to DLT 9.' with values X, -, -, -, -. Row 2: '2. Replace card B08 (Access Control, Index/Sector Decode).' with values -, 1, 1, 1, 1. Row 3: '3. Replace card B09 (Access Control 1).' with values -, 2, -, -, -. Row 4: '4. Replace card A08 (Access Control 2).' with values -, 3, -, -, -. Row 5: '5. Replace card A07 (D/A Function Generator).' with values -, 4, 3, 3, 3. Row 6: '6. Replace cards B02 (Ch 1 rcurs), B04 (Ch 2 rcurs).' with values -, 5, 4, 4, 4. Row 7: '7. Replace card B06 (Diff Generator and Control).' with values -, -, 2, 2, 2. Row 8: '8. Call Field Support.' with values -, 6, 5, 5, 5.

KØR-0679-2

Warning: None

Enters from: Sheet 1

Procedures: None

References: Logic Diagrams

Exits to: DLT 10

Assumption: 1. FTU connected to drive and FTU switches set per "Preliminary Set-up" in Operation section of TB304 manual. In addition, FTU Wrt-Rd Select switch set for either WRT or WRT FORMAT operation.

CONDITIONS		5	6	7	8	9	10	11	12	13	14
2,3.	FAULT indications on both SMD and FTU panels? (From sheet 1.)	Y	Y	Y	Y	Y	Y	Y	Y	Y	Y
4.	Is fault limited to certain groups of contiguous addresses?	Y	N	-	-	-	-	-	-	-	-
5.	Does fault appear only for WRT FORMAT operations?	-	-	Y	N	-	-	-	-	-	-
6.	Set FTU Addr/Sect Mk switch to SECT MK and try again. Does FAULT light still come on?	-	-	-	-	N	Y	-	-	-	-
7.	Check LEDs on operator panel:										
a)	WRT FLT on?	-	-	-	-	-	-	Y	-	-	-
b)	HD SEL FLT on?	-	-	-	-	-	-	-	Y	-	-
c)	WR · RD FLT on?	-	-	-	-	-	-	-	-	Y	-
d)	ON CYL · (W + R) on?	-	-	-	-	-	-	-	-	-	Y

ACTIONS		5	6	7	8	9	10	11	12	13	14
5.	Replace card B06 (Cyl Addr Reg).	1	-	-	-	-	-	-	-	-	-
6.	Go to Condition 5.	-	X	-	-	-	-	-	-	-	-
7.	Go to Condition 6.	-	-	X	-	-	-	-	-	-	-
8.	Go to Condition 7.	-	-	-	X	-	-	-	-	-	-
9.	Suspect cards A02, B10 (Address Mark Enable).	-	-	-	-	1	-	-	-	-	-
10.	Restore sw to ADDR MK position, repeat test and go to Condition 7.	-	-	-	-	-	X	-	-	-	-
11.	Chk that FTU's Servo Offset sw is "off" (center position).	-	-	-	-	-	-	1	1	1	1
12.	Replace card A01 (Write PLO).	-	-	-	-	-	-	2	-	-	-
13.	Replace card B07 (NRZ → MFM).	-	-	-	-	-	-	3	-	-	-
14.	Replace cards B02 (ch 1 rcurs) and B04 (ch 2 rcurs).	-	-	-	-	-	-	4	2	2	-
15.	Replace card A10 (Write Protect).	-	-	-	-	-	-	5	-	3	2
16.	Replace card B09 (On Cyl).	-	-	-	-	-	-	-	-	-	3
17.	Replace Writer (A3A03).	2	-	-	-	2	-	6	-	4	4
18.	Replace Hd Sel/Rd Amp (A3A02).	-	-	-	-	-	-	-	3	-	-
19.	Call Field Support.	3	-	-	-	3	-	7	4	5	5

DLT 10	READ							
Warning: None								
Enters from: DLT 9								
Procedures: Head Replacement, Alignment (section 2C)								
References: Logic Diagrams								
Exits to: DLT 11								
Assumption: FTU connected to drive. FTU switches set per "Preliminary Set-up" in Operation section of TB304 manual. In addition, FTU Wrt-Rd Select switch set to RD.								
CONDITIONS								
1. Was address read properly? ^①	1	2	3	4	5	6	7	8
2. Was data read properly? ^①	Y	Y	Y	N	N			
3. Are errors head-related?	-	N	Y	N	Y			
ACTIONS								
1. No problem. Go to DLT 11.	X	-	-	-	-			
2. Check that Data switches on FTU are set to read the pattern previously written on the disk.	-	1	-	-	-			
3. Replace card A06 (Read PLO; MFM → NRZ).	-	2	-	2	-			
4. Replace card A05 (Data latch).	-	3	-	3	-			
5. Replace card A08 (Offset).	-	4	-	4	-			
6. Replace cards B02, B04 (Ch 1, Ch 2 rcurs).	-	5	-	5	-			
7. Replace cards B01, B03 (Ch 1, Ch 2 xmtrs).	-	6	1	6	1			
8. Check head alignment (see Procedures, above).	-	7	2	7	2			
9. Replace Hd Sel/Rd Amp (A3A02).	-	8	-	8	-			
10. Replace faulty head(s). See Procedures, above.	-	-	3	-	3			
11. Reformat disk per WRT FORMAT procedure in TB304 manual.	-	-	-	1	-			
12. Call Field Support.	-	9	4	9	4			
^① A NO answer here implies that the procedures given in the TB304 manual's Trouble Analysis DLT have already been tried in an attempt to recover the address or data, but to no avail.								

KØR-0679-2

DLT 11	POWER DOWN							
Warning: None								
Enters from: DLT 10 or as desired								
Procedures: None								
References: Logic Diagrams								
Exits to: None (Diagnostics terminate with this DLT)								
Assumption: Remote operation - Attempt to power down the drive from FTU panel Local operation - Press START sw on SMD panel to extinguish START light and power down the drive.								
CONDITIONS								
	1	2	3	4	5	6	7	8
1. START light goes out? (LOCAL mode only.)	Y	Y	Y	Y	N			
2. Heads unload?	Y	Y	Y	N	-			
3. Drive motor brakes to a stop?	Y	N	N	-	-			
4. Drive motor coasts to a stop?	N	N	Y	-	-			
ACTIONS								
1. Diagnostics have been completed satisfactorily.	X	-	-	-	-			
2. Check deck interlock sw (A1A4), or wiring, for grounds.	-	1	-	-	-			
3. Check that Heads Loaded sw (A3S2) has transferred. A10-30B should be at ground.	-	2	-	-	-			
4. Check hysteresis brake and intervening connectors (JA80,J303). If OK, go to next recommended Action.	-	-	1	-	-			
5. Replace card A10 (Start, Braking Control).	-	3	2	-	-			
6. Replace card B09 (RTZ Latch).	-	-	-	1	-			
7. Replace card A07 (Summing Amp).	-	-	-	2	-			
8. Replace card A09 (Pwr Amp Control).	-	-	-	3	-			
9. Cathode of START indicator (LED) grounded. Check card A10 diagrams for how.	-	-	-	-	1			
10. Call Field Support.	-	4	3	4	2			

KØR-0679-2

PROCEDURES

PROCEDURE A: CHECKING DC VOLTAGES

This procedure, in addition to defining voltage checkpoints for a normal-load situation, also defines checkpoints on the power supply boards themselves. These are helpful in the event that the dc loads have been disconnected (by separating connectors P/J1A and P/J1B) for a checking a supply.

NOTE

Output voltage from the ± 5 V regulated supply will fall to 0 volts when the 5 V loads are removed. As implied in table B-2, no-load readings on this supply will prove fruitless.

Voltage readings in table B-2 may be obtained by using either a standard (needle type) or digital volt-ohmmeter. Table A-3 gives the usual symptoms for a malfunctioning power supply. Because spare parts for the components on the supply boards are not usually provided, a power supply board is normally not repaired in the field, but simply replaced.

PROCEDURE:

1. Turn off POWER SUPPLY breaker.
2. Raise logic chassis (assembly A2) to maintenance position.
3. Remove the spanner bar from the card extender to gain clearance for the components on the p.s. boards.
4. Remove the ± 20 V p.s. board (A1A02) from assembly A1 and install in the card extender.
5. Insert the extender (and A1A02) into the A1 mother board.
6. Turn on the POWER SUPPLY breaker.
7. Using the probe connections from the NORMAL LOAD columns on table B-2, check each supply voltage.

TABLE B-2. CHECKING DC VOLTAGES*

Volt-Ohmmeter Connections

Voltage to be checked	Normal Load P/J1A Mated P/J1B Mated		No Load - P/J1A Separated P/J1B Separated		Voltage Readings
	+ Probe	- Probe	+ Probe	- Probe	
+5	+5 Faston	GND Faston	Cannot be checked		+5.0 (±0.05)
-5	GND Faston	-5 Faston	Cannot be checked		+5.0 (±0.05)
+12	AlA02-27A	AlA02-01A	AlA02-27A	AlA02-01A	+12.0 (±0.3)
-12	AlA02-01A	AlA02-08A	AlA02-29A	AlA02-08A	+12.0 (±0.3)
+20	+20 Faston	GND Faston	AlA02-29A	AlA02-01A	+20.0 (±1.0)
-20	Gnd Faston	-20 Faston	AlA02-01A	AlA02-05A	+20.0 (±1.0)
+42	A2A04-32B	A2A09-17B	AlA01-33A	AlA01-01A	+42.0 (±2.0)
-42	A2A09-17B	A2A04-03B	AlA01-01A	AlA01-02A	+42.0 (±2.0)

*Power supply boards AlA01 (±42 V) and AlA02 (±12, ±20 V) must be fitted to a card extender to permit access to the pins. Other connections are available when the logic chassis (A2) is raised to the maintenance position.

TABLE B-3. FAILURE SYMPTOMS IN POWER SUPPLIES

Symptom	Probable Cause
1. Noticeable ripple at output (checked with oscilloscope)	Open diode or open filter capacitor.
2. Less than specified output (ac input OK)	Shorted diode or shorted filter capacitor
3. Output decreases significantly when load is connected.	Open bleeder resistor

NOTE

The connections shown facilitate using a continuous-scale meter. For a meter having a zero-center scale, it is not necessary to switch the probes for minus-voltage readings.

8. Turn off the POWER SUPPLY breaker.
9. Separate connectors P/J1B and P/J1A, located at the front of the A1 motherboard. Press in on the plastic locking tabs with the fingers of one hand while pulling up on the connector with the other hand.
10. Turn on the POWER SUPPLY breaker.
11. Using the probe connections shown in the NO LOAD columns of table B-2, check the ± 12 and ± 20 voltages. (Note that the ± 4 voltages cannot be checked without a load.)
12. Turn off the POWER SUPPLY breaker.
13. Remove the card extender from slot A1A02, and the ± 42 V p.s. board from slot A1A01.
14. Remove the ± 20 V p.s. board from the card extender.
15. Install the ± 42 V p.s. board in the card extender and insert the extender in slot A1A01.

NOTE

Future steps will be easier if you do not install the ± 20 V p.s. board in A1 at this time.

16. Turn on the POWER SUPPLY breaker.
17. Check the ± 42 NO LOAD voltages, using the probe connections from table B-2.
18. Turn off the POWER SUPPLY breaker.
19. Remove the card extender and reinstall the ± 20 V and ± 42 V p.s. boards in A1.
20. Reconnect P/J1A and P/J1B.
21. Return the logic chassis to its normal position if further maintenance is not to be performed at this time.

PROCEDURE B: CHECKING AC INPUTS TO POWER SUPPLY BOARDS

This procedure verifies that a given secondary winding of ferroresonant transformer T1 has the required voltage to drive its associated power supply board. The procedure should also be performed after a power supply board has been repaired or replaced, and before that board is reinserted in assembly A1, to ensure that the previously malfunctioning supply did not damage the transformer.

SPECIAL NOTE

The three power supply boards constitute the load for transformer T1 and its tuning capacitor, A1C8. When using procedure B to check the ac input to these boards, do not remove more than two boards at any one time. To do so will cause T1 to go into oscillation, producing meaningless readings.

Table B-4 shows the oscilloscope connections for monitoring the ac input to each supply board. Figure B-1 shows the square-wave input and specified voltages, the latter also given in the table.

NOTE

Don't forget that the card pins are numbered 34 through 21, and 17 through 01; pins 20, 19, and 18 are omitted. The pins are given as they appear, left to right, in the card extender that is installed in the appropriate slot in assembly A1 in order to give easy access to the motherboard.

Procedure:

1. Turn off POWER SUPPLY (PS) breaker.
2. Determine which power supply board is to have its ac input checked, and remove that board from power supply assembly A1.
3. Insert a card extender in the A1 slot vacated by the removed board.
4. Plug in the test scope and set the trigger control to LINE. Turn on the scope and when the horizontal trace becomes visible, center it on the graticule.

TABLE B-4. CHECKING AC INPUTS TO POWER SUPPLIES*

Supply To Be Checked for AC Input	Scope Connections		AC Input Put Voltages ($\pm 5\%$)
	+Probe (AC Input)	GND Probe (Center Tap)	
± 5 V	AlA03-17A AlA03-15A	AlA03-28A	11 V
± 20 V	AlA02-23A AlA02-21A	AlA02-01A	22 V
± 42 V	AlA01-14A AlA01-12A	AlA01-01A	44 V
* Use card extender for easy access to motherboard pins listed in table.			

5. Connect the scope's ground probe to the appropriate pin given in table B-4.
6. Turn on the POWER SUPPLY (PS) breaker.
7. Connect the scope's + probe (i.e., CH1 or CH2, depending upon scope set-up) to either of the AC INPUT pins given in the table.
8. Adjust scope's TIME/DIV control to secure a stable square-wave trace (ref: figure B-1).
9. Adjust scope's VOLTS/DIV control to allow easy mental reckoning of the voltage represented by the trace, as shown against the graticule lines.
10. Record the voltage (or make a mental note if you trust your visual memory) from the ground reference line on the graticule to the top and bottom of the trace, (two readings) as indicated by "E" in figure B-1.
11. Repeat step 10 with the + probe connected to the other ac input pin.

Figure B-1. T1 Input to Power Supplies

OSCILLOSCOPE SETTINGS

SCOPE GND TO LOGIC GND

VOLTS/DIV

CH 1 - ①
CH 2 - NA

TIME/DIV


A - VARY FOR CONVENIENT TRACE
B - NA

TRIGGERING

A (USE X1 PROBE) - LINE
B (USE X PROBE) - NA

PROBE CONNECTIONS

CH 1 (USE X1 PROBE) - ②
CH 2 (USE X PROBE) - NA



- ① ± 5 V: E = 11 V
 ± 20 V: E = 22 V
 ± 42 V: E = 44 V

- ② SEE TABLE

9K68

12. If both steps 10 and 11 show a symmetrical waveshape about the ground reference line (that is, all four voltage readings are the same), and are within the 5% tolerance specified in tabel B-4, the T1 windings for that particular supply are OK. If you wish to check the no-load dc voltages of the supply as outlined in Procedure A, turn off the PS breaker and insert a good p.s. board in the card extender. Otherwise, remove the extender and insert a good p.s. board in the motherboard (assembly A1).
13. If the voltage readings are not the same, or if they are the same but not up to the 5% tolerance of table B-4, the problem has to be a shorted winding in T1. (You may be able to confirm this by sniffing the transformer for evidence of burned insulation, although this is not a definitive test.) Proceed to step 14.

WARNING

Tuning capacitor AlC8 is charged with 440 volts. Treat it with respect.

14. Replace T1: Turn off the AC and PS breakers; discharge AlC8 and remove leads connecting it to T1; separate P/J100 (it will be necessary first to separate connectors P/J1B and P/J1A); note the position of the two T1 leads connected to T1 and remove those leads from T1. Install the new transformer by reversing this process.
15. Check the new transformer by repeating steps 5 through 11.

Procedure C: Troubleshooting Heat-Generated Problems

CAUTION

If the heads perform an unscheduled retract and the START and FAULT lights are both off, immediately turn off the POWER SUPPLY breaker; you have dropped +5 V and run the risk of burning up the voice coil. Only after you've shut off dc power should you check to see if the power-down resulted from a failure on the ac line. (Hint: check to see if blower is still on).

If you commit the above CAUTION to memory and act instinctively upon it, you may one day save yourself a lot of trouble; failure of the +5 V supply is a common cause for abnormal shut-downs.

Heat-related problems are easy to diagnose: they occur only when the drive gets hot, and they disappear when the drive has had a chance to cool off. If you suspect a problem is heat-related, let the drive cool down, then note the failure (or more accurately, the absence of the failure) when the drive is started up again. Often the troubleshooting period can be shortened by applying artificial heat to the suspected area (a hair dryer is useful here). Once you've diagnosed the problem, correct it as you would any other malfunction.

Heat problems are of two types -- those originating in the power supplies and those developing in the various loads. Should a load fault take out a 20 V or 42 V fuse, the course is clear: simply refer to the applicable "load" DLT. If the load does not pop a fuse but merely brings up a FAULT light (on the back of the operator panel), the table below should offer a starting point for correcting the problem. (If the +5 V supply goes, of course, the fault lights won't work.)

<u>FAULT</u>	<u>PROBLEM RELATED TO</u>
Voltage (except +5 V)	A03, A04, A09
On Cyl. (W+R)	A03, B02, B09
Write	A03, A04, B01, A3A03 (Write Driver Board)
W·R	A04, B02
Hd Sel	A02, A04, A3A02 (Hd Sel/Rd Amp board)

Losing ± 5 V can be bothersome because those supplies maintain a uniform output voltage right up to their current limit, and then drop to 0 V when that limit is exceeded. Should this happen, check to see if the supply itself is the culprit by disconnecting the 5 V load. If the voltage returns to 5 V, the fault lies in the load, not the supply.

PROCEDURE D: PIN-POINTING VOLTAGE FAULTS IN THE LOGIC CHASSIS

This procedure locates ± 5 V, ± 20 V, and ± 42 V faults on cards in the logic chassis or in the logic chassis backpanel wiring. (There is no ± 12 V load in logic chassis assembly A2.)

The test procedure may be conducted in either of two ways. The first method is to check the ± 5 V, and ± 42 loads individually by entering Procedure D from the applicable DLT:

± 5 V -- Condition 1 of DLT 3

± 20 V -- Condition 1 of DLT 4

± 42 V -- Condition 3 of DLT 6

The second method is to check all three loads at the same time. The test for load faults in each voltage is made by adding cards to the logic chassis one at a time, so it is more efficient to check all three loads on a given card at one time. (Of course, some cards will not require all three checks.)

The second method is the one described below, and requires that the tests for Conditions 1 and 2 of DLT 6 have been satisfactorily completed before entering the procedure.

NOTE

It should be pointed out that, as shown in table B-1, only ± 5 V is used on every card. If there is no ± 5 V fault in the logic chassis, only the cards using the faulted voltage(s) need to be removed.

1. Be certain that Conditions 1 and 2 of DLT 6 have been tested with satisfactory results before proceeding with step 2. (Condition 1 checks the servo capacitors, Condition 2 the power amplifier.)
2. Turn off the POWER SUPPLY (PS) breaker.
3. Ensure that all three power supply boards are properly seated in the power supply motherboard.
4. Separate PA80 and PA81 from their jacks on the logic chassis.
5. Ensure that all other connectors are properly mated.
6. Remove all cards from the logic chassis. (See NOTE, above, for possible exception to this "all cards" rule.)
7. Turn on the PS breaker.
8. Load faults caused by wiring errors in (or damage to) the logic chassis backpanel will show up as a blown fuse. Check the integrity of each fuse as described in DLT 1 and others. If a fuse blows, carefully raise the logic chassis to the maintenance position and check backpanel for grounds caused by bent pins or dangling wires. After clearing the fault, restore the logic chassis to its normal position.
9. Turn off the PS breaker. You are now ready to start putting the cards back in the logic chassis one at a time, checking for faults after each has been inserted.
10. Before inserting a card, examine both sides for evidence of arcing across the foil. Often the carbon residue around an arc area can be removed with an alcohol swab and the card won't give any more trouble.
11. Insert the selected card properly.
12. Turn on the PS breaker.
13. Using table B-1 to determine which voltages are present on the card, check the integrity of the applicable fuses.

14. If step 13 shows a blown fuse, turn off the PS breaker, replace the card just installed with a fresh one from the spare parts bin and try the test again.
15. If step 13 shows that the fuses are OK, turn off the PS breaker and, selecting another card, repeat steps 10 through 15.
16. When all cards have been checked good, return to the applicable "load fault" DLT to continue the dc-load check-out on the additional assemblies.