



3725/3726

**Communication Controller and Expansion
Maintenance Information Manual (MIM) Part 1
Volume 1**

Preface

Eight Edition (June 1986)

This major revision obsoletes SY33-2018-6 and Technical Newsletter SN33-7126. Changes or additions to the text and illustrations are indicated by a vertical line to the left of the change. This edition reflects the 3725 Release 4 enhancements.

Changes are made periodically to the information herein. Any such changes will be reported in subsequent revisions or Technical Newsletters.

The drawings and specifications contained herein shall not be reproduced in whole or in part without written permission.

IBM has prepared this maintenance manual for the use of IBM customer engineers in the installation, maintenance, or repair of the specific machines indicated. IBM makes no representations that it is suitable for any other purpose.

Reference in this publication to IBM products, programs, or services do not imply that IBM intends to make these available in all countries in which IBM operates. Any reference to an IBM program product in this publication is not intended to state or imply that only IBM's program product may be used. Any functionally equivalent program may be used instead.

Publications are not stocked at the addresses given below. Requests for IBM publications should be made to your IBM representative or to the IBM branch office serving your locality.

A form for readers' comments is provided at the back of this publication. If the form has been removed, comments may be addressed to either of the following:

- International Business Machines Corporation
Department 6R1LG
180 Kost Road
Mechanicsburg
PA 17055

or

- IBM France
Centre d'Etudes et Recherches
Department 0762
06610 La Gaude
France

IBM may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation to you.

This publication is intended for the customer engineer who maintains the IBM 3725 Models 1 and 2 Communication Controller and the IBM 3726 Communication Controller Expansion.

For the 3725 Model 1 and 3726, this manual should be used in conjunction with the 3725/3726 Maintenance Information Manual (MIM) Part 2 for locating and replacing failing field replaceable units within the communication controller and expansion.

For the 3725 Model 2, this manual should be used in conjunction with the 3725 Model 2 Maintenance Information Manual (MIM) Part 2.

Organization

The manual is divided into two volumes:

- Volume 1 contains introductory and how to fix information.
- Volume 2 contains detailed descriptions of 3725/3726 functional units as well as extended troubleshooting procedures for each unit.

Troubleshooting notes are added, where appropriate. These enable you to continue troubleshooting when card and FRU replacements have not removed the trouble, and to determine if a board, cable, or top connector is the failing part.

Prerequisite Publications

The reader should have an understanding of telecommunications and modems. The following manuals provide a training on the 3725/3726:

- 3725 Model 1 Communication Controller, Introduction, GA33-0010
- 3725 Model 2 Communication Controller, Introduction, GA33-0021

Corequisite Publications

The following manuals provide the procedures for operating the communication controller:

- 3725/3726 Communication Controller and Expansion, Diagnostic Descriptions, SY33-2027
- 3725 Communication Controller, Operator's Guide, GA33-0044
- 3725 Communication Controller, Problem Determination and Extended Services, GA33-0014

Summary of Contents : Volume 1

Go to:

Chapter 1. Introduction	<input type="text" value="1. Intro"/>	User Application Network, Controller General Description, Data Flow, Control Subsystem, Transmission Subsystem, Maintenance and Operator Subsystem, Maintenance Philosophy
Chapter 2. Service Procedures	<input type="text" value="2. Svc Proc"/>	Functions Called From the Host, Error Log Function and BER Descriptions, TSS Functions, Utility Programs, Troubleshooting Guidelines
Chapter 3. Maintenance Aids	<input type="text" value="3. Aids"/>	Tools and Test Equipment, Disabling RDV from IOC Bus, Disabling CA from Host Channel Interface, BER Display from MOSS Storage
Chapter 4. Locations and Jumpers	<input type="text" value="4. Loc"/>	Component Locations, Board Layout, Voltage Plan, Card Location, Cabling between Boards, Signal Tables, IOC Wire Continuity, High Speed Clock Distribution, CA Cable Routing, Scanner Board Information, Line Interfaces, Jumpers
Chapter 5. Adjustments and Removals	<input type="text" value="5. Adj"/>	CCU Board Replacement, ESD Instructions, Jumper Replacement, Card Replacement, Scoping Points, Power Supply Adjustments
Chapter 6. 3725 Initialization (IML, IPL)	<input type="text" value="6. Ctrl"/>	Control Panel, Operator Console, Console Connections, Controller Resets, Controller Initialization, Phase Description, MOSS IML Step Description
Chapter 7. 51TD Diskette Drive	<input type="text" value="7. Disk"/>	General Description, Theory of Operation, Repair Procedures, Part Replacement and Adjustments
Chapter 8. B/M Installation and Preventive Maintenance	<input type="text" value="8. B/M"/>	Hardware EC/MES Installation Microcode and Diagnostic EC Installation, Preventive Maintenance
Chapter 9. System Operations	<input type="text" value="9. Oper"/>	System Interrupts, IPL Exchanges, Message Exchanges, CCU/Scanner Exchanges, Protocol Handling
Abbreviations and Glossary	<input type="text" value="Abbr"/>	Definitions of Abbreviations and Terms used in this manual
Index	<input type="text" value="Index"/>	

Summary of Contents: Volume 2

Go to:

Chapter 10. Central Control Unit	10. CCU	CCU Data Flow and Description, Characteristics and Packaging, Storage, Interrupts, IOC and MIOC Control Logic, Instruction Format and Decoding, Input/Output Registers, Storage Protect and Address Exceptions, Timers, CCU and Storage Troubleshooting
Chapter 11. IOC Bus and Redrive	11. IOCB	PIO Operation, AIO Operation, Address/Command Formats on IOC Bus, Scanner/Line Addressing, Redrive, IOC Bus Troubleshooting
Chapter 12. Channel Adapter	12. CA	Packaging, Interfaces to Channel, Connections to CCU, NSC Mode, ESC Mode, Data Transfers, Channel-Initiated Sequences, Unusual Conditions, Error Recovery Procedures, Local Store and Register Contents, Waveforms, Channel Adapter Troubleshooting
Chapter 13. Transmission Subsystem	13. TSS	Communication Scanner Processors, Front-End Scanners, Line Interface Cards, Internal Clock Cards, FES Operation, Error Detection and Reporting, Register Description, Transmission Subsystem Troubleshooting
Chapter 14. Maintenance and Operator Subsystem	14. MOSS	Description, MOSS/CCU Connections and Register Description (MCC Status, Interrupt, BT/AC, Indirect Operation, LSSD), MOSS/Diskette Drive Description, Diskette Occupation, I/O, MOSS Microcode, MOSS Interrupt Level Description, Register and Storage Maps, MOSS NCP/EP Communication, Detection of MOSS Error, MOSS Troubleshooting
Chapter 15. Token Ring Subsystem	15. TRSS	Description of the TRSS. Token Ring Adapter, Token Ring Multiplexer Card, Token Ring Interface Card, Communication Interface, Commands Description, Error Detection and Reporting Token Ring Subsystem Troubleshooting.
Abbreviations and Glossary	Abbr	Definitions of Abbreviations and Terms used in this manual
Index	Index	

Bibliography

The bibliography lists the publications that describe the 3725 Communication Controller and its software support. The publications are grouped into introductory, planning and installation, operating, and maintenance.

Type	Title of Publication	Form Number
Introductory	3725 Model 1 Communication Controller, Introduction 3725 Model 2 Communication Controller, Introduction ACF/NCP/EP General Information IBM Diskette General Information Manual	GA33-0010 GA33-0021 GC30-3071 GA21-9182
Planning and installation	TNL to IBM Input/Output Equipment Installation Manual - Physical Planning: System/360, System/370, 4300 Processors 3725 Communication Controller, Original Equipment Manufacturer's Information 3725 Communication Controller, Template 3725 Model 1 Communication Controller, Configuration Guide 3725 Model 2 Communication Controller, Configuration Guide ACF/NCP, Installation and Resource Definition Guide ACF/NCP, Installation and Resource Definition Guide ACF/NCP, Resource Definition Guide 3725 Model 1 Communication Controller - CE Installation Instructions 3725 Model 2 Communication Controller - CE Installation Instructions EP Generation and Utilities Guide and Reference EP Generation and Utilities Guide and Reference ACF/NCP and SSP Network Definition Guide 3704/3705/3725 Assembler Language	GN22-2302 GA33-0017 GX22-7092 SA33-0012 SA33-0022 SC30-3178 SC30-3178 SC30-3179 Part number Part number SC30-3172 SC30-3172 GC30-3020 GC30-3003
Operating	3725 Communication Controller, Principles of Operation 3725 Communication Controller, Operator's Guide 3725 Communication Controller, Problem Determination and Extended Services 3725 Channel Adapter Card 3727 Operator Console, Reference and Problem Analysis Guide 7427 Switching Unit Customer Information ACF/NCP, Customization for the 3725 ACF/NCP, System Support Program Messages	GA33-0013 GA33-0044 GA33-0014 GA33-0045 GA33-0015 GA33-0018 LY30-3071 SC30-3169
Maintenance	3725/3726 Communication Controller, Maintenance Information Manual (Part 1) 3725/3726 Communication Controller, Power Supplies Theory of Operation 3725/3726 Communication Controller, Maintenance Information Manual (Part 2) 3725/3726 Communication Controller Channel Adapter On-line Tests 3725 Model 2 Communication Controller, Power Supplies Theory of Operation 3725 Model 2 Communication Controller, Maintenance Information Manual (Part 2) 3725/3726 Communication Controller, Diagnostic Descriptions 3727 Operator Console, Maintenance Information Manual 3727 Operator Console, Repair Center Maintenance Information Manual 3725/3726 Communication Controller, Parts Catalog 7427 Switching Unit Maintenance Information ACF/SSP Diagnosis Reference ACF/NCP for the IBM 3725 Diagnosis Reference ACF/NCP/SSP for the IBM 3725 Diagnosis Guide Emulation Program for the IBM 3725 Logic ACF/NCP for the 3725; EP for the 3725, Reference Summary and Data Areas	SY33-2018 SY33-2020 Part number D99-3725A SY33-2026 Part number SY33-2027 SY33-2019 SY12-8229 S135-2008 SY33-2022 LY30-3060 LY30-3071 SC30-3181 LY30-3055 LY30-3070

Maintenance Library : 3725 Model 1 and 3726

Identifier	Title	Order Number	Contents
3725 MI Vol. A01	3725-1/3726 MIM Part 2, Start	(Part number)	Start of problem isolation
3725 MI Vol. A02	3725-1/3726 MIM Part 2, Power 3725-1/3726 Power Supplies TO	(Part number) SY33-2020	Power MAPs, references, and theory of operation
3725 MI Vol. A03	3725/3726 MIM Part 1, Volume 1	SY33-2018	General information: Chapters 1 to 9
3725 MI Vol. A04	3725/3726 MIM Part 1, Volume 2	SY33-2018	General information: Chapters 10 to 14
3725 MI Vol. A05	3725 Diagnostic Descriptions	SY33-2027	Diagnostic general information
3725 MI Vol. A06	3725 Problem Determination and Extended Services	GA33-0014	Operating procedures, Wrap tests, and Stand Alone link tests for maintenance personnel
3725 MI Vol. A07	3725/3726 Parts Catalog 3725-1 CE Installation Instructions	S135-2008 (Part number)	Parts catalog and installation instructions
3725 MD Vol. B01	3725-1 Component Locations 3725-1 Wiring Diagrams 3725-1 EC/PN Cross References	(Part number) (Part number) (Part number)	Maintenance information support for frame 01 (YZ/ZZ pages)
3725 MD Vol. B02	3725-1 Board Pin/Net List	(Part number)	Maintenance information support for frame 01
3726 MD Vol. A01 (optional)	3726 Wiring Diagrams 3726 Board Pin/Net List 3726 CE Installation Instructions	(Part number) (Part number) (Part number)	Maintenance information support for frame 02 (YZ pages) and installation instructions

Note:

- Three copies of the 3725 Channel Adapter Card, GA33-0045, are included in the shipping group.
- One copy of the 3725 Operator's Guide, GA33-0044 (operating procedures for the customer personnel) is included in the shipping group.

Maintenance Library: 3725 Model 2

Identifier	Title	Order Number	Contents
3725 MI Vol. A01	3725-2 MIM Part 2, Start	(Part number)	Start of problem isolation
3725 MI Vol. A02	3725-2 MIM Part 2, Power 3725-2 Power Supplies IO	(Part number) SY33-2026	Power MAPs, references, and theory of operation
3725 MI Vol. A03	3725/3726 MIM Part 1, Volume 1	SY33-2018	General information: Chapters 1 to 9
3725 MI Vol. A04	3725/3726 MIM Part 1, Volume 2	SY33-2018	General information: Chapters 10 to 14
3725 MI Vol. A05	3725 Diagnostic Descriptions	SY33-2027	Diagnostic general information
3725 MI Vol. A06	3725 Problem Determination and Extended Services	GA33-0014	Operating procedures, Wrap test, and Stand Alone link tests for maintenance personnel
3725 MI Vol. A07	3725/3726 Parts Catalog 3725-2 CE Installation Instructions	S135-2008 (Part number)	Parts catalog and installation instructions
3725 MD Vol. B01	3725-2 Component Locations 3725-2 Wiring Diagrams 3725-2 EC/PN Cross References	(Part number) (Part number) (Part number)	Maintenance information Support
3725 MD Vol. B02	3725-2 Board Pin/Net List	(Part number)	Maintenance information support

Note:

- Three copies of the 3725 Channel Adapter Card, GA33-0045, are included in the shipping group.
- One copy of the 3725 Operator's Guide, GA33-0044 (operating procedures for the customer personnel), is included in the shipping group.

CE General Safety (Part 1 of 2)

This product meets IBM safety standards.

The following information has been included in this publication for the use and safety of IBM personnel. For more information, see Electrical Safety for IBM Service Representatives, S229-8124, and Safety/Health Guidelines for IBM Service Representatives, S241-5493.

GENERAL SAFETY DURING WORK

Use these rules to ensure general safety:

- Observe good housekeeping in the area of the machines during maintenance and after completing it.
- Use only field-supply items (such as adhesives, cleaning fluids, lubricants, paints, and solvents) that have been approved by IBM, that is, are supplied under an IBM part number.
- When lifting any heavy object:
 1. Ensure that you can stand safely without slipping.
 2. Balance the weight of the object between your two feet.
 3. Use a slow lifting force. Never move suddenly or twist when you attempt to lift.
 4. Lift by standing or by pushing up with your leg muscles; this action removes the strain from the muscles in your back. Do not attempt to lift any objects that you think are too heavy for you.
- Do not perform any action that causes hazards to the customer or that makes the equipment unsafe.
- Put removed covers and other parts in a safe place, away from all personnel, while you are servicing the machine.
- Always keep your tool case away from walk areas so that other persons will not trip over it; for example, put it under a desk or table.

- Do not wear loose clothing that can be trapped in the moving parts of a machine. Ensure that your sleeves are fastened or are rolled up above the elbows. If your hair is long, fasten it.

- Do not wear jewelry, chains, metal-frame eyeglasses, or metal fasteners for your clothing.

Remember:

A metal object lets more current flow if you touch a live conductor.

- Insert the ends of your necktie or scarf inside other clothing or fasten the necktie with a clip, preferably nonconductive, approximately 8 centimeters (3 inches) from the ends.
- Wear safety glasses when you are:
 - Using a hammer to drive pins or similar parts
 - Drilling with a power hand-drill
 - Using spring hooks or attaching springs
 - Soldering parts
 - Cutting wire or removing steel bands
 - Cleaning parts with solvents, chemicals, or cleaning fluids
 - Working in any other conditions that might be hazardous to your eyes.

- Before you start the machine, ensure that other service representatives and the customer's personnel are not in a hazardous position.

- After maintenance, reinstall all safety devices such as shields, guards, labels, and ground wires. Exchange any safety device that is worn or defective for a new one.

Remember:

Safety devices protect personnel from hazards. You destroy the purpose of the devices if you do not reinstall them before completing your service call.

- Reinstall all covers correctly before returning the machine to the customer.

SAFETY WITH ELECTRICITY

Observe these additional rules when working on equipment powered by electricity:

- Find the room emergency power-off (EPO) switch or disconnecting switch. If an electrical accident occurs, you can then operate the switch quickly.
 - Do not work alone under hazardous conditions or near equipment that has hazardous voltages. Always inform your manager of any possible problem or if you must work alone.
 - Disconnect all power:
 - Before removing or installing main units
 - Before working near power supplies
 - Before doing a mechanical inspection of power supplies
 - Before installing changes in machine circuits.
 - Before you start to work on the machine, unplug the machine's power cable. If you cannot unplug the cable easily, ask the customer to switch off the wall box switch that supplies power to the machine, and either:
 - Lock the wall box switch in the off position, or
 - Attach a DO NOT OPERATE tag, Z229-0237, to the wall box switch.
- Note: A non-IBM attachment to an IBM machine can be powered possibly from another source and controlled by a different disconnecting switch or circuit breaker. If you determine that this condition is present, ensure that you remove (eliminate) this hazard before you start work.
- If you need to work on a machine that has exposed electrical circuits, observe the following precautions:
 - Ensure that another person, who is familiar with the power-off controls, is near you.

Remember:

Another person must be there to switch off the power, if necessary.

- CAUTION

SOME IBM HAND TOOLS HAVE HANDLES COVERED WITH A SOFT MATERIAL THAT DOES NOT INSULATE YOU WHEN WORKING WITH LIVE ELECTRICAL CIRCUITS.

.....
.....
.....
.....

Use only those tools and testers that are suitable for the job you are doing.

- Use only one hand when working with powered-on electrical equipment; keep the other hand in your pocket or behind your back.

Remember:

There must be a complete circuit to cause electrical shock. By observing the above rule, you may prevent a current from passing through the vital parts of your body.

- When using testers, set the controls correctly and use the IBM-approved probe leads and accessories intended for that tester.

- CAUTION

MANY CUSTOMERS HAVE, NEAR THEIR EQUIPMENT, RUBBER FLOOR MATS THAT CONTAIN SMALL CONDUCTIVE FIBERS TO DECREASE ELECTROSTATIC DISCHARGES. DO NOT USE THIS WRONG TYPE OF MAT TO PROTECT YOURSELF FROM ELECTRIC SHOCK.

.....
.....
.....

Stand on suitable rubber mats (obtained locally, if necessary) to insulate you from grounds such as metal floor strips and machine frames.

CE General Safety (Part 2 of 2)

- Observe the special safety precautions when you work with very high voltages; these instructions are given in IBM safety service memorandums (SMs) and the safety sections of maintenance information. Use extreme care when measuring high voltages.
- Do not use tools or testers that have not been approved by IBM. Ensure that electrical hand tools, such as power drills and Wire-Wrap (1) tools, are inspected regularly.
- Do not use worn or broken tools and testers.
- Never assume that power has been disconnected from a circuit. First check that it has been switched off.
- Always look carefully for possible hazards in your work area. Examples of these hazards are: moist floors, nongrounded power extension cables, power surges, and missing safety grounds.
- Do not touch live electrical circuits with the glass surface of a plastic dental mirror. The surface is conductive; such touching can cause personal injury and machine damage.
- Unless the maintenance information specifically lets you, do not service the following parts with power on them when they are removed from their normal operating places in a machine:
 - Power supply units
 - Pumps
 - Blowers and fans
 - Motor generators

and similar units. (This rule ensures correct grounding of the units.)
- If an electrical accident occurs:
 - Use caution do not become a victim yourself.
 - Switch off power.
 - Send another person to get medical aid.
 - If the victim is not breathing, decide whether to give rescue breathing.

These actions are described below.

(1) Trademark of the Gardner-Denver Co.

(2) If you want to be trained in giving this aid, ask a suitable organization (such as the Red Cross) in your area.

(3) A rescue-breathing face covering (mask) or similar unit can be used if you have been taught how to use it.

EMERGENCY FIRST AID

When giving rescue breathing after an electrical accident:

- Use Caution. If the victim is still in contact with the electrical-current source remove the power; to do this, you may need to use the room emergency power-off (EPO) switch or disconnecting switch.

If you cannot find the switch, use a dry wooden rod or some other non conductive object to pull or push the victim away from contact with the electrical-current source.
- Work Quickly. If the victim is unconscious, he or she possibly needs rescue breathing. If the heart has stopped beating, the victim may also need external cardiac compression.

Only a trained and certified (2) person should perform external cardiac compressions.
- Get Medical Aid. Call a rescue group, an ambulance, or a hospital immediately.

RESCUE BREATHING PROCEDURES


Determine if the victim needs rescue breathing:

1. Prepare the victim:

Ensure that the victim's airway is open and not obstructed. Check the mouth for objects (such as chewing gum, food, dentures, or the tongue) that can obstruct the flow of air.

Place the victim on his or her back, then put one hand under the victim neck and the other hand on the victim's forehead.

Lift the neck with one hand (A) and press the forehead backward with the other hand.




2. Look, listen, and feel to determine if the victim is breathing freely: Put your cheek near the victim's mouth and nose.

Listen and feel for the breathing-out of air. At the same time, look at the victim's chest and upper abdomen to see if they move up and down.

If the victim is not breathing correctly and you decide that you want to give rescue breathing:

3. Continue to press on the victim's forehead with your hand and pinch together the victim's nostrils (B) with the thumb and finger.




4. CAUTION


USE EXTREME CARE WHEN GIVING RESCUE BREATHING TO A VICTIM WHO POSSIBLY HAS BREATHE-IN AIR THAT THE VICTIM HAS BREATHED-OUT.

.....

Open your mouth wide and take a deep breath. Make a tight seal with your mouth (3) around the victim's mouth (C) and blow into it.



5. Remove your mouth and let the victim breathe out while you check that the victim's chest (D) moves down.



6. Repeat steps 4 and 5 once every 5 seconds until the victim breathes normally again or until medical aid comes.

REPORTING ACCIDENTS

Report to your manager or to your IBM site all accidents, possible hazards, and accidents that nearly occurred.

Remember : An accident that nearly occurred can be caused by a design problem. Quick reporting ensures quick solving of the problem.

Report also each small electric shock, because the conditions that caused it need only differ slightly to cause serious injury.

CE Safety Inspection Procedures (Part 1 of 3)

INTRODUCTION

The following procedures help the IBM CE check whether the 3725/3726 conforms to IBM safety criteria. They are to be run each time the 3725/3726 safety is suspected.

Any deficiencies detected by running these procedures, if they make the 3725/3726 unsafe, must be reported to the owner and/or user. Then, before any repair action is performed, the IBM CE will correct these deficiencies by:

- Following the repair procedures given in the maintenance package
- Ordering the missing or failing parts, using the 3725/3726 Parts Catalog, S135-2008, (Vol A07).

The 3725/3726 areas and functions checked through these procedures are:

1. External covers
2. Safety labels
3. Safety covers and shields
4. Grounding
5. Circuit breaker and protector rating
6. Input power voltage
7. Power-on indicator
8. Emergency power off

Notes:

1. Since the 3725/3726 can be remotely powered on, all the following procedures must be performed with the Power Control switch on the 3725 control panel set to 'Local'.
2. The 3725 and 3726 each have their own power system, but the 3726 is powered on and off through the 3725.
3. Hazardous voltages are still present in some areas of the 3725/3726 when power is off.
4. Steps 1 through 6 must be performed with the 3725/3726 power off, that is, on the 3725 and 3726:
 - a. CBIs tripped (switched off), and
 - b. Power cords unplugged from the customer's mains.

1. EXTERNAL COVERS

(Read Notes 1 through 4 before starting the procedure.)

Check that:

- They are all present on the 3725 (frame 01) and 3726 (frame 02).
- They are locked with IBM locks and keys (refer to 3725/3726 Parts Catalog, Vol. A07).
- They can be fully opened.
- Cable stays are present.
- Appropriate service clearance and access are provided around the frames with external covers opened.

Leave all external covers opened to allow further safety inspection steps.

2. SAFETY LABELS

Check that:

- All the safety labels are stuck at the places indicated by letters in the drawings on page xi).
- Each label is of the model corresponding to the model letter as shown on page xii.

3. SAFETY COVERS AND SHIELDS

Check that:

- All the safety covers shown on page xi are present and secured with screws.
- All the voltage terminal boards (TBs) are protected by a plastic shield screwed on top of the TB.

4. GROUNDING

Refer to page xi for ground bus locations, and to the YZ pages for ground distribution diagrams.

Check that:

- Electrical continuity is assured, within each frame, between the frame ground and the terminals indicated on ground distribution diagrams.
- Electrical continuity is assured between frame 01 and 02 grounds.
- The 3725 and 3726 frame grounds are effectively connected to the premises grounding system, through their respective power cords.

5. CIRCUIT BREAKER AND PROTECTOR RATING

Refer to page xi for CB and CP locations, and to page xii for CB and CP identifications and ratings.

Check that:

- All the CBs and CPs in the 3725 and 3726 frames are rated as indicated on page xii. If the rating is not indicated, check the part number against the 3725/3726 Parts Catalog.

6. INPUT POWER VOLTAGE

Labels on the 3725 and 3726 (see page xi, labels G, for locations) indicate the input voltage for which the 3725 and 3726 are wired.

Refer to page xi for the 3725 and 3726 primary power box location, and the YZ pages for wiring options.

Check that:

- The input voltage leads are plugged according to the voltage level measured at customer's mains.
- The labels are consistent with this voltage level. Correct if necessary.

7. POWER-ON INDICATOR

Once the controller is powered on, check that the Power On lamp on the 3725 control panel is lit.

8. EMERGENCY POWER-OFF

Connect the power plugs to the customer's mains, put both CBIs on, and power on the 3725/3726 (Power Control switch to 'Local' on the 3725 control panel). Then operate the Unit Emergency power off switch, and check that:

- The controller comes to power off state.
- The diskette drive on the 3725 is stopped.
- The fans on the 3725 and 3726 are stopped.
- The convenience outlets on the 3725 are still supplied with ac power.

Relatch the Unit Emergency switch, then set the controller power on again.

CE Safety Inspection Procedures (Part 3 of 3)

SAFETY LABEL IDENTIFICATION

(See the previous page for label locations.)

A - P/N 1743129

HAZARDOUS AREA TRAINED
SERVICE PERSONNEL ONLY

B - P/N 138754

LINE VOLTAGE
PRESENT WITH
MACHINE POWER
OFF 138754

C - P/N 82370

TURN MAIN
LINE SWITCH
"OFF" BEFORE
REMOVING

D - P/N 4422117

 DANGER
PELIGRO
PERIGO
危険
550 V

E - P/N 1203359

WARNING: Motor may start
unexpectedly when power is
ON.

F - P/N 737858

WARNING
DUE TO CONNECTED EQUIPMENT OTHER
THAN NORMAL VOLTAGES MAY BE
PRESENT AT ANY TIME

G - P/N 845762

THIS MACHINE IS
WIRED FOR $\sqrt{3}$
SEE LOGIC DRAWINGS FOR
ALTERNATE VOLTAGE INSN

H - P/N 2667694

DANGER
MULTIPLE POWER SOURCES
CB1 DISCONNECTS POWER
FROM THIS FRAME ONLY

J - P/N 2667695

CAUTION
UNIT WEIGHT
EXCEEDS 27KG
2667695

K - P/N 1859279

CAUTION
SWITCH MACHINE TO LOCAL
POWER CONTROL BEFORE
SERVICING TO PREVENT
UNEXPECTED POWER UP.

COUNTRY LABELS

The safety labels shown as models on this page are in the English language. Most of them are available in the local language. The following table gives the label part numbers according to their model and to the country in which the 3725/3726 is installed.

LANGUAGE OR COUNTRY	A	B	C	D	E	F	G	H	J	K
ENGLISH US	1743129	138754	82370	4422117	1203359	737858	845762	2667694	2667695	1859279
CANADA	8326799	6815184 138754	8323797	4422117	984124	1743497	8323796 6812825	6081051	6081053	4712900
FRANCE	8326722	6815187	1731480	4422117	6841193	4413711	6815192	2667100	6081025	4712901
ENGLISH UK	1743129	138754	82370	4422117	1203359	737858	845762	2667694	2667695	1859279
FINLAND	8326801	6825818	6081036	4422117	6841187	6825871	6825864	2667248	6081026	4712902
BELGIUM	6081052	6843729	6081037	4420468	6081045	6081048	8329449	6081011	6081027	4712903
GERMANY	8326802	6825819	6081038	4422117	6841186	4413713	6815195	6081013	6081028	4712904
ITALY	8326800	6825820	6081039	4422117	6841188	4413712	6815191	6081015	6081029	4712905
NORWAY	1743129	6843726	82370	4422117	1203359	737858	845762	2667694	2667695	1859279
BRAZIL	6081056	6815188	6081040	4422117	6081046	6081049	6081050	6081017	6081030	4712906
SPANISH	8326798	6825821	6081041	4422117	6841189	4413734	6815190	6081019	6081031	4712907
SWEDEN	6081016	8551903	6081042	4422117	6081047	8551934	5688621	6081021	6081032	4712908
JAPAN	8326797	6825840	6081043	4422117	6841177	4413714	6825867	6081023	6081033	4712910
DENMARK	6081058	6081059	6081060	4422117	6081062	6081063	6081064	6081066	6081065	4712909

CIRCUIT BREAKERS AND CIRCUIT PROTECTORS

Area	3725 Model 1 or 2			3726		
	Rating	P/N	Name	Rating	P/N	Name
Main CB	2P-15A	5719456	CB 1	2P-15A	5719456	CB 1
Phase Control Xmer	1P-15A	2644455	CP 2	1P-10A	2306660	CP 1/CP 4
PS1	1P-0.7A	2644456	CP 6	1P-0.7A	2644456	CP 7
PS2	1P-2.5A	1805224	CP 3	1P-2.5A	1805224	CP 2
PS3	-	-	-	1P-2.5A	1805224	CP 5
PS9	-	-	-	2P-3A	5518550	CP 6
Convenience Outlets:						
- 50Hz EMEA	2P-3A	5518550	CP 1	-	-	-
- 60Hz US and Japan	1P-2.5A	1805224	CP 1	-	-	-
Blowers/Fans	2P-3A	5518550	CP 4	2P-3A	5518550	CP 3
Diskette Drive Motor	2P-3A	5518550	CP 5	-	-	-

Contents

CHAPTER 1. INTRODUCTION

User Application Network (Part 1 of 2)	1-010
Communication Controller Interfaces	
Channel Interface	
User Application Network (Part 2 of 2)	1-011
Transmission Interface	
Data Circuit-Terminating Equipment	
Data Terminal Equipment	
Channel/Link-Attached Controller	
Controller General Description (Part 1 of 4)	1-020
Controller Organization	
Control Subsystem (CSS)	
Transmission Subsystem (TSS)	
Token Ring Subsystem (TRSS)	
Maintenance and Operator Subsystem (MOSS)	
Configurations	
Single-Frame Configurations: 3725 Model 2	
3725 Model 2 Block Diagram	
Controller General Description (Part 2 of 4)	1-021
Single-Frame Configurations: 3725 Model 1	
3725 Model 1 Block Diagram	
Controller General Description (Part 3 of 4)	1-022
Two-Frame Configuration: 3725/3726	
3725 Model 1/3726 Block Diagram	
Controller General Description (Part 4 of 4)	1-023
Programming Support for the 3725	
Network Control Program	
Emulation Program	
Partitioned Emulation Programming (PEP) Extension	
Programming Support for the Host	
Program Generation	
Network Configuration Changes	
Reliability, Availability, and Serviceability	
Data Flow	1-030
Control Subsystem (Part 1 of 2)	1-040
Central Control Unit (CCU)	
Machine Instructions	
Interrupt System	
Cycle Steal Mechanism	
Main Storage	
Functional Organization	
Storage Size	
Control Subsystem (Part 2 of 2)	1-041
Local Storage	
Channel Adapter	
Packaging (3725/3726)	
Packaging (3725 Model 2)	
Board Characteristics (3725/3726)	
Board Characteristics (3725 Model 2)	
Channel Adapter Driver Receiver	
Two-Processor Switch	
Channel Interface	
Channel-to-CCU Interconnection	
Redrive	
Channel Operation	
Channel Adapter Addressing	
Channel Adapter Modularity (3725/3726)	
Channel Adapter Modularity (3725 Model 2)	
Transmission and Token-Ring Subsystem (Part 1 of 5)	1-050
Packaging	

Board Characteristics (3725/3726)	
Board Characteristics (3725 Model 2)	
LAB Numbering	
Redrive (RDV)	
Communication Scanner Processor (CSP)	
CSP Modularity (3725/3726)	
CSP Modularity (3725 Model 2)	
Transmission and Token-Ring Subsystem (Part 2 of 5)	1-051
Front-End Scanner (FES)	
FES Modularity (3725/3726)	
FES Modularity (3725 Model 2)	
Communication Scanner (CS)	
Functions	
Scanner and TRA Modularity (3725/3726)	
Scanner and TRA Modularity	
Scanner Modularity (3725 Model 2)	
Scanner Performance (both Models)	
Line Operating Modes	
Normal Mode	
Character Mode	
Burst Mode	
Service Mode	
Transmission and Token-Ring Subsystem (Part 3 of 5)	1-052
Internal Clock Card (ICC)	
ICC Modularity (3725/3726)	
ICC Modularity (3725 Model 2)	
LIC/ICC Compatibility	
Limitations	
Line Interface Coupler Card (LIC)	
LIC Weight	
LIC Modularity	
Speed Mixing on LIC	
Transmission and Token-Ring Subsystem (Part 4 of 5)	1-053
LIC Type 1 (LIC1)	
LIC Type 2 (LIC2)	
LIC Type 3 (LIC3)	
LIC Type 4A (LIC4A)	
LIC Type 4B (LIC4B)	
Transmission and Token-Ring Subsystem (Part 5 of 5)	1-054
Token Ring Adapter (TRA)	
Functions	
TRA Modularity	
Limitations	
Token Ring Multiplexer (TRM) Card	
Token Ring Interface Coupler Card (TIC)	
TIC Weight	
TIC Type	
Maintenance and Operator Subsystem	1-060
MOSS Processor Storage and Microcode	
Adapters	
CCU Adapter	
Diskette Adapter	
Controller Diskette	
Service Diskette	
Control Panel	
Operator Console	
Maintenance Philosophy (Part 1 of 2)	1-070
Concurrent Maintenance	
Repair Action in Case of Solid Error	
Box Error Record (BER) Description	
Tentative Repair Action (Intermittent Error)	
Additional BER Information	
No FRU Isolated	

Maintenance Philosophy (Part 2 of 2)	1-071
CHAPTER 2. SERVICE PROCEDURES	
SECTION 1. FUNCTIONS	
3725 Console Functions	2-010
Screen Layouts	2-020
Basic Layout	
Controller Diskette - Two Primary Menus	
Customer Primary Menu	
Maintenance Primary Menu	
Service Diskette - One Primary Menu	
Host Traces (Part 1 of 3)	2-030
Host Traces in an ACF/VTAM Environment	
ACF/VTAM Environment	
Buffer Content Trace	
VTAM Internal Trace	
Buffer Use Trace	
VTAM I/O Trace	
Host Traces (Part 2 of 3)	2-031
Host Traces in an ACF/VTAM Environment	
ACF/TCAM Environment	
Dispatcher Subtask Trace	
Buffer and Extended Buffer Trace	
PIU Trace	
Channel I/O Interrupt Trace	
Host Traces (Part 3 of 3)	2-032
Host Traces (Environment-Independent)	
Host NLDM Trace	
NCP Traces (Channel Adapter, Session, GPT, and Branch)	2-033
NCP Channel Adapter Trace	
NCP Session Trace	
NCP Generalized PIU Trace (GPT)	
Overview	
Tracing Outbound PIUs	
Tracing Inbound PIUs	
Limitations	
NCP Branch Trace	
NCP Traces (Address, Line, and Transmission Group)	2-034
NCP Address Trace	
NCP Line Trace	
EP Line Trace	
NCP Transmission Group Trace	
NTRI Traces	
Line and IOH Trace	
TIC Internal Trace	
Activation of traces	
ACF/TAP editing and RU formats	
NCP SIT (Part 1 of 4)	2-035
Trace Objectives	
Trace Limitations	
High-Speed Trace Limitations for NCP/SIT	
NCP SIT (Part 2 of 4)	2-036
NCP SIT Record Units	
TRU Formats	
IOH/IOHI Field	
Parameter Field	
Data Field	
Status Field	

Checkpoint Data Field				
Overrun Field				
SIT Trace Records				
NCP SIT (Part 3 of 4)	2-037			
Line Character Trace				
SDLC (Normal Mode)				
BSC (Normal Mode)				
BSC (Character Mode)				
Start-Stop (Character Mode)				
Line Error Trace				
SDLC				
BSC				
NCP SIT (Part 4 of 4)	2-038			
Start-Stop				
Microcode Checkpoint Trace	2-040			
Trace Objectives				
Scanner Microcode Sequence of Operation				
Address Look-Up Table				
Microcode Checkpoint Trace Records				
Trace Summary	2-042			
Trace Comparison				
Communication Function Traces				
LOGREC Display with EREP				
File Transfer to the Host				
Wrap Tests Controlled from the Host	2-044			
Wrap Test at Tailgate Level				
Modem or NTT Cable				
Token-Ring Wrap Tests				
Wrap Tests Controlled from the MOSS	2-046			
Wrap Test at Tailgate Level				
Modem or NTT Cable				
Wrap Test at Tailgate Level	2-048			
Wrap Test Initialization Screen				
Control Lead Wrap Test Pattern				
Selection Screen				
Wrap Test Start Screen				
Alarm/Alert List	2-050			
Alarms				
Alerts				
NPDA Messages				
Online Test Group (Part 1 of 4)	2-150			
Requirements				
Running Time				
Selection				
Tested Part (Both Models)				
Online Test Group (Part 2 of 4)	2-151			
Procedure				
Online Test Group (Part 3 of 4)	2-152			
CA OLT Responder				
CA OLTs				
Selection				
D99-3725A Contents				
Routine List				
OLT Running Restrictions				
Messages				
Online Test Group (Part 4 of 4)	2-153			
OLT CDS For the 3725				
3725 CDS Card and Storage Layout				
Range Definition Card Layout				
System Tests	2-160			
ST370				
NST-2				
ST4300				
Error Log Function (Part 1 of 4)	2-170			
BER Generation				
BER Formatting				
Example of Date and Time				
BER Storage on Diskette				
BER Storage When Diskette is				
Not Operational				
BER File Erasure				
BER Display				
Error Log Function (Part 2 of 4)	2-171			
BER Structure				
Approach to Problem Isolation				
Thresholds				
BERs That Are Not Machine Errors				
Unresolved Interrupts				
BER Handling Tools				
Error Log Function (Part 3 of 4)	2-172			
BER Display Sample Sequence				
BER Display Procedure				
With Controller Diskette				
With Service Diskette				
BER Display Sample Sequence				
Error Log Function (Part 4 of 4)	2-173			
BER Updating				
BER Flag Explanation				
BER Flag Updating				
BER Display Screens (Part 1 of 3)	2-180			
BER Summary Display				
Field Description for BER Summary Screen				
BER List Display				
Field Description for BER List Screen				
PF Keys on BER List Screen				
BER Display Screens (Part 2 of 3)	2-181			
BER Detail Displays				
Finding the Appropriate BER Detail Screen				
Common Fields in Header Lines				
PF Key on BER Detail Screen				
BER Display Screens (Part 3 of 3)	2-182			
Fields Common to Many BER Detail Screens				
X'76' and X'76'U				
Redrive Address and Error Register				
Address and Command Format on the IOC Bus				
at TA Time				
CHAPTER 2. SERVICE PROCEDURES				
CA (Type 10) BER Detail Displays (Part 1 of 4)	2-190			
CA BER, Type 10 - Summary				
CA (Type 10) BER Detail Displays (Part 2 of 4)	2-191			
CA BER (Type 10) Summary (Continued)				
CA (Type 10) BER Detail Displays (Part 3 of 4)	2-192			
CA BER, Type 10 - IDs 18, 1C, 1E, 97,				
9B (foC1)				
CA BER, Type 10 - IDs 14, 16, 91, 9A (foC2)				
CA BER, Type 10 - IDs 10, 1B, 1F, 90, 92,				
93, 94, 95, 96, 98, 99, 9C, 9E, 9F (foC3)				
CA BER, Type 10 - IDs 33, 34, 35, B1, B2,				
B5, B6 (foC4)				
CA (Type 10) BER Detail Displays (Part 4 of 4)	2-193			
CA BER, Type 10 - Field Explanation				
TSS (Type 11) BER Detail Displays (Part 1 of 4)	2-200			
TSS BER, Type 11 - Summary				
TSS (Type 11) BER Detail Displays (Part 2 of 4)	2-201			
TSS BER (Type 11) Summary (Continued)				
TSS BERs, Type 11 - ID 14, 16, 91, 92,				
93 (foT1)				
TSS BER, Type 11 - IDs 18, 1B, 97, 98,				
9C (foT2)				
TSS BER, Type 11 - IDs 1E, 1F, 95, 96, 99,				
9A, 9B (foT3)				
TSS BER, Type 11 - ID A1 (foT4)				
TSS (Type 11) BER Detail Displays (Part 3 of 4)	2-202			
TSS BER, Type 11 - ID A2, A4 (foT5)				
TSS BER, Type 11 ID B1 (foT6)				
TSS BER, Type 11 ID 1C (foT7)				
TSS (Type 11) BER Detail Displays (Part 4 of 4)	2-203			
TSS BER, Type 11 - Field				
Explanation (Continued)				
NCP/EP (Type 12) BER Detail Displays	2-210			
NCP/EP BER, Type 12 - Summary				
NCP/EP BER, Type 12 - IDs 11 thru 19 (foN1)				
NCP/EP BER, Type 12 - ID 21 (foN2)				
NCP/EP BER, Type 12 - Field Explanation				
CCU (Type 13) BER Detail Displays (Part 1 of 2)	2-220			
CCU BER, Type 13 - Summary				
CCU (Type 13) BER Detail Displays (Part 2 of 2)	2-221			
CCU BER, Type 13 - IDs 91 thru 95 (foU1)				
CCU BER, Type 13 - IDs C1 thru C6 (foU2)				
CCU BER, Type 13 - IDs 32, B1 (foU3)				
CCU BER, Type 13 - Field Explanation				
IOC (Type 14) BER Detail Displays	2-230			
IOC BER, Type 14 - Summary				
IOC BER, Type 14 - All IDs (91, 92, 93,				
95) (foI1)				
IOC BER, Type 14 - Field Explanation				
TRSS (Type 15) BER Detail Display (Part 1 of 3)	2-231			
TRSS BER, Type 15 - Summary				
TRSS BER, Type 15 - IDs 14, 16, 91, 92,				
93 (foR1)				
TRSS BERs, Type 15 - IDs 18, 97, 98,				
9C (foR2)				
TRSS BER, Type 15 - ID 96, 99, 9A,				
9B (foR3)				
TRSS BER, Type 15 - IDs A3, A4, A5, A7,				
A8 (foR4)				
TRSS (Type 15) BER Detail Display (Part 2 of 3)	2-232			
TRSS BER, Type 15 - IDs AC (foR5)				
TRSS BER, Type 15 - IDs AF (foR6)				
TRSS BER, Type 15 - IDs B2 (foR7)				
TRSS BER, Type 15 - IDs B3, B4, B5,				
B6 (foR8)				
TRSS BER, Type 15 - Field Explanation				
TRSS (Type 15) BER Detail Display (Part 3 of 3)	2-233			
MOSS (Type 01) BER Detail Display (Part 1 of 3)	2-240			
MOSS BER, Type 01 - Summary				
MOSS (Type 01) BER Detail Display (Part 2 of 3)	2-241			
MOSS BER, Type 01 - Summary (Continued)				
MOSS (Type 01) BER Detail Display (Part 3 of 3)	2-242			
MOSS BER, Type 01 - Summary (Continued)				
BER/Alarm/Alert Mechanism (Part 1 of 2)	2-250			
BER/Alarm/Alert Mechanism on 3725				
Catastrophic Errors (3725 Down)				
CCU Hardcheck				
Hardware Error				

Software Error, Hardware Detected	MOSS BER, ID 06 (Part 4 of 5)	2-323	Reset CCU/LSSD (Part 1 of 2)	2-360
Software Error, Software Detected	SCB (Scanner Control Block)		Selection	
BER/ALARM/ALERT Mechanism (Part 2 of 2)	CS (Scanner Errors)		Function Message Line	
BER/ALARM/ALERT Mechanism on 3725	F IML Error Flag			
Catastrophic Errors (3725 Down)	MOSS BER ID 06 (Part 5 of 5)	2-324	Reset CCU/LSSD (Part 2 of 2)	2-361
Analysis of a BER/ALARM/ALERT Sequence	Register Descriptions on IPL Check		Mode of Operation	
MOSS BER, ID 00 (Part 1 of 2)	X71		IPL CCU/TSS (Part 1 of 2)	2-365
MOSS BER, Type 01 - ID 00 (foM0)	X72		IPL Menu	
MOSS BER (Type 01) ID 00 -	CCU User Indicator		Selection	
Field Explanation	Storage User Indicator		Available Functions	
MEF Status Byte	HKNG Register		One Scanner IML	
PSW (Condition Codes and Page Pointer)	HDCK Register		Selection	
TTA (Current TTA Entry Byte)			IML Termination	
CNT (Current Error Counter)	MOSS BER, ID 07	2-325	IPL CCU/TSS (Part 2 of 2)	2-366
MOSS BER, ID 00 (Part 2 of 2)	MOSS BER, Type 01 ID 07 (foM13)		3725 IPL	
Data (Contents of Three-Byte Field)	MOSS BER, Type 01-ID 07 Error		Selection	
MOSS BER, ID 01	04/08/40/80 (foM13)		IPL Phases	
MOSS BER, Type 01 - ID 01 (foM1)	MOSS BER, Type 01-ID 07 Error FF (foM13)		Normal IPL (Option 1)	
MOSS BER (Type 01) ID 01 -	MOSS BER, Type 01-ID 07 Error 00 (foM13)		Step-by-Step IPL (Option 2)	
Field Explanation	MOSS BER, Type 01-ID 07 Error FE (foM13)		Bypass Phase 1 (Option 3)	
AREG (CCU/MOSS Status A Register)	MOSS BER, Type 01-ID 07 Field Explanation			
Error (Error Codes)	ERROR (Error Code)		TSS Functions	2-370
Status	ERR-EXT (Error Code Extension)		Selection from the Controller Diskette	
MOSS BER, ID 02 (Part 1 of 2)	MOSS BER, ID 91, B3, C1, C2	2-330	Selection from the Service Diskette	
MOSS BER, Type 01 - ID 02 (foM2)	MOSS BER, Type 01 - IDs 91 B3 C1 C2 (foM8)		Messages	
MOSS BER (Type 01) ID 02 -	Field Explanation (Type 01 IDs 91		Select/Release Scanner	
Field Explanation	B3,C1,C2, NCP/EP)		Selection	
CMD (Logical Command)	BER Layout in Diskette (Part 1 of 3)	2-340	Select a Scanner	
Error (Error Codes)	BER Layout on Diskette (Part 2 of 3)	2-341	Release a Scanner	
MOSS BER, ID 02 (Part 2 of 2)	BER layout on Diskette (Part 3 of 3)	2-342	Dump/IML Scanner	2-371
PCW (Processor Control Word)	MOSS Bers (Type 01) (Continued)		Selection	
Byte Definition	Machine Status Area (Part 1 of 5)	2-350	Dump a Scanner	
MOSS BER, ID 03	MSA with Scanner Information		IML a Scanner	
MOSS BER, Type 01 - ID 03 (foM3)	MSA with TRA Information		Mode Control (Scanner)	2-372
MOSS BER (Type 01) ID 03 -	MSA with CCU/Scanner IPL Information		Selection	
Field Explanation	General Information		Connected	
CMD (Logical Commands)	Field a		Disconnected	
ARC (Adapter Return Codes)	Field b		DPLY/ALT Store (Scanner)	2-373
MOSS BER, ID 04	Field c		Selection	
MOSS BER, Type 01 - ID 04 (foM4)	Machine Status Area (Part 2 of 5)	2-351	Display	
MOSS BER (Type 01) ID 04 -	Field d		Alter	
Field Explanation	Field e		PF Keys	
MOSS BER, ID 05 (Part 1 of 2)	Field f		DPLY/ALT Blocks (Scanner)	2-375
MOSS BER, Type 01 - ID 05 (foM5)	Field g		Selection (3725/3726)	
MOSS BER ID 05 (Part 2 of 2)	Field h		Selection (3725 Model 2)	
MOSS BER (Type 01) ID 05 -	Field i		DPLY/ALT LSR and XREG (Scanner)	2-376
Field Explanation	Field j		DPLY/ALT LSR	
BERs Printed on Host	Machine Status Area (Part 3 of 5)	2-352	DPLY/ALT XREG	
ERROR (Error Codes)	Field k		Address Compare (Scanner)	2-377
ERR-EXT (Error Code Extension)	Field l		Selection	
MOSS BER, ID 06 (Part 1 of 5)	Scanner Information		Deactivating the Scanner Address Compare	
MOSS BER, Type 01 - ID 06 (IPL) (foM6)	Field m		Checkpoint Trace (Scanner)	2-378
MOSS BER, Type 01 - ID 06 (not IPL) (foM7)	Field n		Selection	
MOSS BER (Type 01) ID 06 -	Field o		TRA Select, Connect/Disconnect	2-380
Field Explanation	Field p		Introduction	
MOSS BER, ID 06 (Part 2 of 5)	Field q		Selection from the Controller Diskette	
MOSS BER, Type 01 - ID 06 (foM9)	Machine Status Area (Part 4 of 5)	2-353	Messages	
MOSS BER, Type 01 - ID 06 (foM10)	CCU/Scanner IPL Information		TRA Select (1)	
MOSS BER, Type 01 - ID 06 (foM11)	Field r		TRA Connect/Disconnect (2)	
MOSS BER, Type 01 - ID 06 (foM12)	Field s		Display/Alter TRM Registers (3)	2-381
ERROR (Error Codes)	Field t		Display/Alter TIC Interrupt Register (4)	2-382
MOSS BER, ID 06 (Part 3 of 5)	Field u		Display TIC Storage (5)	2-383
ERROR-EXT (Error Code Extension)	Field v		Display	
IPL REQ	Field w		TIC Internal RAM Format	
C REQ (Cancel Request)	Field x			
STAT (System Status)	Machine Status Area (Part 5 of 5)	2-354		
DISK (Diskette Errors)	TRA/TIC Information			
	Field m*			
	Field n*			
	Field o*			
	Field p*			
	Field q*			

- Dump TIC Storage (6) 2-384
TIC Functional Blocks
- Display SCB, SSB and Parameter Block (7, 8) 2-385
Display SCB, SSB (7)
Display Parameter Block (8)
- Display Token Ring Status (9) 2-386
Token Ring Status
- TRSS Modes 2-387
NTRI MAC Status and Corresponding TIC Mode
- Utility Programs 2-390
Selection from the Controller Diskette
Selection from the Service Diskette
Messages
- MOSS, Scanner, and TRSS Dump Display/Delete
(Part 1 of 2) 2-391
Selection
MOSS or Scanner Dump Display
TRSS Dump Display
- MOSS, Scanner, and TRSS Dump Display/Delete
(Part 2 of 2) 2-392
MOSS or Scanner Dump Delete
TRSS Dump Delete
- MOSS Store and Module Display 2-393
MOSS Store Display (Moss Storage Display)
Selection
Module DPLY (Module Display)
Selection
- ZAP Area on Diskette 2-394
ZAP Identification
Creating a ZAP
Erasing a ZAP
- Selecting the ZAP Functions 2-395
Selection
ZAP Functions
- Apply, Restore, and Modify (ZAP) 2-396
Apply (ZAP)
Restore (ZAP)
Modify (ZAP)
Selection
ALTER Command
DELETE Command
INSERT Command
- Scan and Erase (ZAP) 2-397
Scan (ZAP)
Erase (ZAP)
- Create a ZAP 2-398
Selection
File ZAP in ZAP area
- Update Spare Diskette 2-399
Selection
COPY ZAPs on Spare Diskette
- CDF: Select and Create 2-400
Selection
Create
- CDF: Verify 2-401
Verify
- CDF: Display/Update (Part 1 of 4) 2-402
Display/Update Menu
All
CCU/MOSS
Display/Update LAB/CAB (3725/3726)
Display/Update C2LB/LAB (3725 Model 2)

- CDF: Display/Update (Part 2 of 4) 2-403
Channel Adapters (3725/3726)
Channel Adapters (3725 Model 2)
Scanners/TRAS
3725/3726 Model 1 LABs
3725 Model 2 C2LB and C2LB2
3725/3726 Model 1 and Model 2 LAB Type C
- CDF: Display/Update (Part 3 of 4) 2-404
LSSD
LSSD Bit Identification
- CDF: Display/Update (Part 4 of 4) 2-405
CDF Information
- MLT 2-407
Selection
ZAP History Table
- Diskette Swap (Part 1 of 3) 2-408
Selection
- Diskette Swap (Part 2 of 3) 2-409
SAVE BER
- Diskette Swap (Part 3 of 3) 2-410
PURGE BER
- MOSS, Scanner, and TRSS Dumps 2-440
MOSS Dump
Automatic MOSS Dump
Manual MOSS Dump
Scanner Dump
Automatic Scanner Dump
Manual Scanner Dump
TRSS TIC Dump
Manual TIC Dump
Automatic TIC Dump
- File Transfer 2-450
Transferring Dump Files to the Host
Transferring Other 3725 Files to the Host
Transferring Dump Files Using a
Maintenance Device
Receiving Files Using a Maintenance Device
Copying a Diskette Using Two
Maintenance Devices
- Transferring a File: MD to VM and/or MD to MD 2-451
MD to VM File Transfer
MD to MD File Transfer
- Receiving a File: Data Base to MD (Part 1 of 6) 2-452
3725 Diskette Label Format and Definitions
Microcode Patch Strategy
When to Patch
Microcode Download Procedure
- Receiving a file: Data Base to MD (Part 2 of 6) 2-453
3725 Diskette Requirements
MD Diskette Requirements
Sequence Numbers
Diskette Boundaries
- Receiving a file: Data Base to MD (Part 3 of 6) 2-454
Tools Required
Data Base Telephone Numbers
Time Recording
Trouble Reporting
Step by Step Procedure
- Receiving a file: Data Base to MD (Part 4 of 6) 2-454
- Receiving a file: Data Base to MD (Part 5 of 6) 2-456
- Receiving a file: Data Base to MD (Part 6 of 6) 2-457
Updating Machine Diskettes from MD
Distribution Diskettes
Errors and Warnings

- Receiving a File: MD to MD 2-458
- Copying a Diskette: MD to MD 2-459
- File Printing: MLT File 2-460
MLT File
- File Printing: CDF (Part 1 of 3) 2-461
Configuration Data File (CDF)
CDF Data Organization
CCU Record (S1,R0)
- File Printing: CDF (Part 2 of 3) 2-462
MOSS Record (S1,R1)
Redrive Records (S1,R2, R3)
RDV1 (S1,R2)
RDV2 (S1,R3)
Channel Adapter Records (S1,R5, R6)
General Scanner Configuration
Frame (S2,R0-R4)
- File Printing: CDF (Part 3 of 3) 2-463
Scanner/TRA Detailed Information
Records (S2,R5-R6,S3,S4)
- File Printing: ZAP History Table 2-465
- File Printing: BER List 2-466
- File Printing: MOSS Dump (Part 1 of 2) 2-467
- File Printing: MOSS Dump (Part 2 of 2) 2-468
- Hexadecimal/Decimal Conversion 2-470
Conversion Rules
From Hex
From Decimal
Conversion Tables
- Message Directory (Part 1 of 4) 2-480
- Message Directory (Part 2 of 4) 2-490
- Message Directory (Part 3 of 4) 2-491
- Message Directory (Part 4 of 4) 2-492
- Utility Program Messages (Part 1 of 5) 2-500
- Utility Program Messages (Part 2 of 5) 2-501
- Utility Program Messages (Part 3 of 5) 2-502
- Utility Program Messages (Part 4 of 5) 2-503
- Utility Program Messages (Part 5 of 5) 2-504
- TSS Function Messages (Part 1 of 5) 2-510
- TSS Function Messages (Part 2 of 5) 2-511
- TSS Function Messages (Part 3 of 5) 2-512
- TSS Function Messages (Part 4 of 5) 2-513
- TSS Function Messages (Part 5 of 5) 2-514
- TRSS Function Messages (Part 1 of 4) 2-520
- TRSS Function Messages (Part 2 of 4) 2-521
- TRSS Function Messages (Part 3 of 4) 2-522
- TRSS Function Messages (Part 4 of 4) 2-523
- SECTION 2. EXTENDED TROUBLESHOOTING USING BERS
- BER Recovery Procedures 2-800
MOSS
Central Control Unit (CCU)

BER Analysis Procedures (Part 1 of 5)	2-801	Extended Problem Analysis Tools	3-040	Power Board Layout	4-021
Multiple BERs		PT-2		Card and Connector Assignments	
MOSS Subsystem Storage Errors		Output 79 Sync		Voltage Pin Assignments	
BER Analysis Procedures (Part 2 of 5)	2-802	PT-2/TP Line Monitor (TPLM)		Board Pin Assignments (Pin Side)	
Central Control Unit (CCU)		PT-2 SNA Edit and Display Program (SNAPED)		CCU Board Layout	4-022
CCU Hardcheck		PT-2 High-Speed Trace Programs		Card and Connector Assignments (Card Side)	
BER Analysis Procedures (Part 3 of 5)	2-803	PT-2 TP Exercise Program (TPEXER)		Voltage Plan (Board Side)	
Storage Double-Bit Errors		PT-2 Channel Monitor (CHIM)		Board Pin Assignments (Card Side)	
Manual Routine B001		Modem Interface Test Set		Signal Routing Documentation (Part 1 of 2)	4-030
CCU Clock		Maintenance Device 2 (MD2)		Pin Lists	
BER Analysis Procedures (Part 4 of 5)	2-804	Stand-Alone Link Tests (SALT)	3-045	Net Lists	
IOC Bus and Adapters		Testing an INN Link		Pin List (Example)	
BER Analysis Procedures (Part 5 of 5)	2-805	SDLC Terminals Exerciser without CP Loaded		Signal Routing Documentation (Part 2 of 2)	4-031
RDV Address and Error Registers		RECMS (MDR): BSC/SS Device or Line Errors		Net List (Example)	
TSS BER Processing		(Part 1 of 3)	3-050	Pin Addressing	
TRSS BER Processing		Permanent BSC/SS Device or Line Errors		Drawing Interpretation	
Scanner Errors Without BERs	2-806	Permanent BSC/SS Line Error-RECMS Decoding		Board Voltage Plan (Part 1 of 4)	4-040
Unresolved Interrupts (Part 1 of 2)	2-807	RECMS (MDR): BSC/SS Device or Line Errors		Board Voltage Plan (Part 2 of 4)	4-041
Unresolved Interrupts (Part 2 of 2)	2-808	(Part 2 of 3)	3-051	Board Voltage Plan (Part 3 of 4)	4-042
Troubleshooting IOC Bus Problems with BERs		Chart A		Board Voltage Plan (Part 4 of 4)	4-043
BER 11 IC Mechanism		Chart B		Control Panel Card (01L) Voltage Pins	
BER 11 B1/A4 Mechanism		RECMS (MDR): BSC/SS Device or Line Errors		Card and Board Organization	4-050
CHAPTER 3. MAINTENANCE AIDS		(Part 3 of 3)	3-052	Card Location (Part 1 of 5)	4-060
Tools and Test Equipment (Part 1 of 4)	3-010	Chart C		Board: MMB	
General Purpose Tools		Chart D		Board: CCUB	
Shipping Group Tools		Chart E		Card Location (Part 2 of 5)	4-061
Board		RECMS (MDR): BSC/SS Station Statistics	3-053	Board CLAB1	
Channel Adapters		RECMS (MDR): SNA Link Permanent Errors	3-054	Board CLAB2	
Console		RECMS (MDR): SNA Station Permanent Errors	3-055	Card Location (Part 3 of 5)	4-062
Diskette		RECMS (MDR): SDLC Line Error (Part 1 of 3)	3-056	Board LABA	
Lines		Permanent SDLC Line Error		Board LABB	
General		Chart F		Card Location (Part 4 of 5)	4-063
Tools and Test Equipment (Part 2 of 4)	3-011	RECMS (MDR): SDLC Line Error (Part 2 of 3)	3-057	LAB C Board	
CELIA Card (Part 1865015)		Chart G		Card Location	
CELIA LED Testing		Chart I		Crossover Location	
CELIA Card Functions		RECMS (MDR): SDLC Line Error (Part 3 of 3)	3-058	Board CAB	
Straight Indicator		Chart H		Board PWB1	
CELIA Card Data Flow		Chart J		Card Location (Part 5 of 5)	4-064
Tools and Test Equipment (Part 3 of 4)	3-012	EREP Unit Check Records		Board PWB2	
Diskette Tools		CHAPTER 4. LOCATIONS AND JUMPERS		Board C2LB	
Communications Wrap Block and Wrap Cable		Component Locations (Part 1 of 4)	4-010	Board C2LB2	
Torque Screwdriver (Part 4134750)		Frame 01, 3725 Model 1		Cabling Between Boards	4-070
Tools and Test Equipment (Part 4 of 4)	3-013	Component Locations (Part 2 of 4)	4-011	General View	
Flat Cable Extractor (Part 2360340)		Frame 01, 3725 Model 2		Primary IOC Bus: Signal Tables	4-080
Module Extractor/Aligner (Part 1715889)		Component Locations (Part 3 of 4)	4-012	CCU-to-Storage Bus: Signal Tables	4-081
Module Extractor (Part 453400)		Frame 02		MIOC Bus: Signal Tables	4-082
Card Extractor (Part 1310707)		Component Locations (Part 4 of 4)	4-013	MOSS Buses: Signal Tables	4-083
Console Wrap Block (Part 2667737)		Thermal Switch Locations		MOSS-to-Diskette Cable	
Removing RDV or CADR Cards	3-020	Locations 01ATH, 01BTH, 02ATH, 02BTH, 02CTH		MOSS-to-Control-Panel Cable	
Removing the RDV from the IOC Bus		Locations 01HTH, 02DTH		Channel Adapter Cables: Signal Tables	4-084
Removing the CADR from the Host		Thermal Switch Type Airflow Detector		Channel Adapter Cables	
Channel Interface		Thermal Switch		Secondary IOC Bus: Signal Tables	4-085
BER Display from MOSS Storage	3-030	MMB, C2LB, C2LB2, CLAB, LAB, and CAB		IOC Wire Continuity (Part 1 of 3)	4-090
Display Procedure		Board Layout	4-020	Cables from CCU Board to CAB	
Hex Display/BER Decode		Card and Connector Assignments (Card Side)			
Diskette BERs		Voltage Pin Assignments			
BER Storage when Diskette is		Card Pin Assignments (Board and			
not Operational		Top Connector)			
		Board Pin Assignments (Pin Side)			

IOC Wire Continuity (Part 2 of 3)	4-091	Communication Interfaces: TICs	4-131	LIC Type 3 Direct Attachment to Terminal (Part 1 of 2)	4-200
Cables from CAB to LAB Position 8		Ring Interface Electrical Characteristics		Cable to Terminal	
IOC Wire Continuity (Part 3 of 3)	4-092	Ring Receiver		Wrap Cable (Part 1733979)	
Terminator Card (BUSTERM) Diagram	4-095	LIC Type 1 DCE Interface (Except Japan NTT) (Part 1 of 2)	4-140	LIC Type 3 Direct Attachment to Terminal (Part 2 of 2)	4-201
High-Speed Clock Distribution (From ACLK Card)	4-100	Cable to DCE		Interchange Circuits	
Other Machine Clocks		Wrap Block (Part 1733977)		Cable ID Signals	
Clock Scoping		Adapter Cables		Voltage Levels	
Clock Cable Routing		UK			
High-speed Clock Board Pins		Belgium			
CA Cable Routing (Part 1 of 5)	4-110	LIC Type 1 DCE Interface (Except Japan NTT) (Part 2 of 2)	4-141	LIC Type 4A DCE Interface (Part 1 of 2)	4-210
Frame 01		Interchange Circuits		Cable to DCE	
CA Cable Removal		Cable ID Signals		Wrap Block (Part 1733977)	
CA Cable Routing (Part 2 of 5)	4-111	Voltage Levels		LIC Type 4A DCE Interface (Part 2 of 2)	4-211
Frame 02		LIC Type 1 DCE Interface (Japan NTT Only) (Part 1 of 2)	4-150	Interchange Circuits	
CA Cable Routing (Part 3 of 5)	4-112	Wrap Block (Part 1733977)		Cable ID Signals	
CA Cable Routing (Part 4 of 5)	4-113	Cable to DCE		Voltage Levels	
CA Connection Details (From a Top Connector to the Tailgate)		Adapter Cable (Part 1743583)		LIC Type 4A Direct Attachment to Terminal (Part 1 of 2)	4-220
CA Connection (From a Top Connector to the Tailgate)		Test Switch Logical Function		Cable to Terminal	
CA Cable Routing (Part 5 of 5)	4-114	LIC Type 1 DCE Interface (Japan NTT Only) (Part 2 of 2)	4-151	Wrap Block (Part 1733977)	
Cable Continuity		Interchange Circuits		LIC Type 4A Direct Attachment to Terminal (Part 2 of 2)	4-221
C2LB, Scanner Board Information	4-120	Cable ID Signals		Interchange Circuits	
C2LB Board 01A-A3 - Scanner 1		Test/Operate Switch		Cable ID Signals	
C2LB2, Scanner Board Information	4-121	Voltage Levels		Voltage Levels	
C2LB2 Board 01B-A2 - Scanner 3		LIC Type 1 Auto Call Unit Interface (Part 1 of 2)	4-160	LIC Type 4B DCE Interface (Except France) (Part 1 of 2)	4-230
CLAB1, Scanner Board Information	4-122	Cable to ACU		Cable to DCE	
CLAB1 Board (Type A) - 01A-A3 - Scanner 1		Adapter Cable (UK)		Wrap Block (Part 1733977)	
CLAB2 and LAB3, Scanner Board Information	4-123	Wrap Block (Part 1733977)		LIC Type 4B DCE Interface (Except France) (Part 2 of 2)	4-231
CLAB2 Board (Type A) - 01B-A2 - Scanner 3		Thread Wrap Block (Part 147440, Japan Only)		Interchange Circuits	
LAB Board Position 3 (Type A) - 01B-A1 - Scanner 5		LIC Type 1 Auto Call Unit Interface (Part 2 of 2)	4-161	Cable ID Signals	
LAB Board Position 3 (Type B) - 01B-A1 - Scanners 5 and 6		Interchange Circuits		Voltage Levels	
LAB 3, Scanner and Token-Ring Adapter Board Information	4-124	Cable ID Signals		LIC Type 4B DCE Interface (France Only - Transmic) (Part 1 of 2)	4-232
LAB Board Position 3 (LAB TYPE C) - 01B-A1 - Scanners 5 and TRA 6		Voltage Levels		Cable to DCE	
LAB 4, Scanner and Token-Ring Adapter Board Information	4-125	LIC Type 1 Direct Attachment to Terminal (Part 1 of 2)	4-170	Wrap Block (Part 1733977)	
LAB Board Position 4 - 02A-A3		Cable to Terminal		LIC Type 4B DCE Interface (France Only - Transmic) (Part 2 of 2)	4-233
LAB 5, Scanner and Token-Ring Adapter Board Information	4-126	Wrap Block (Part 1733977)		Interchange Circuits	
LAB Board Position 5 - 02A-A2		LIC Type Direct 1 Attachment to Terminal (Part 2 of 2)	4-171	Cable ID Signals	
LAB 6, Scanner and Token-Ring Adapter Board Information	4-127	Interchange Circuits		Voltage Levels	
LAB Board Position 6 - 02A-A1		Cable ID Signals		LIC Type 4B Direct Attachment to Terminal (Part 1 of 2)	4-240
LAB 7, Scanner and Token-Ring Adapter Board Information	4-128	Voltage Levels		Cable to Terminal	
LAB Board Position 7 - 02B-A3		Data Terminal Ready and Ring Indicator Leads		Wrap Block (Part 1733977)	
LAB 8, Scanner and Token-Ring Adapter Board Information	4-129	Other Circuits		LIC Type 4B Direct Attachment to Terminal (Part 2 of 2)	4-241
LAB Board Position 8 - 02B-A2		LIC Type 3 DCE Interface (Part 1 of 2)	4-190	Interchange Circuits	
Communication Interfaces: LICs	4-130	Cable to DCE		Cable ID Signals	
Signal Name Abbreviations		Adapter Cable (France)		Voltage Levels	
		Wrap Cable (Part 1733979)		Jumpers	4-260
		LIC Type 3 DCE Interface (Part 2 of 2)	4-191	Jumpers Installed on Boards	4-270
		Interchange Circuits		LAB, CLAB, C2LB, C2LB2, and CAB	
		Cable ID Signals		Address Jumpers	
		Voltage Levels		Clock Select Jumper	
				3725/3726	
				3725 Model 2	
				Board C2LB	
				Speed Selection	

Jumpers Installed on Cards (Part 1 of 4)	4-280				
Select Out Priority Jumpers (on CADR)					
Jumpers Installed on Cards (Part 2 of 4)	4-281				
NSC Address Jumpers (on CADR)					
Examples					
LIC Type 4A, 4B Jumpers					
Jumpers Installed on Cards (Part 3 of 4)	4-282				
ESC Address Range Jumpers (on CHIN)					
Data In/Data Out Jumper (on CHIN)					
Jumpers Installed on Cards (Part 4 of 4)	4-283				
Burst Length (on CCIN)					
Lock/Unlock NCP Buffers (on CCIN)					
Jumpers on IOC Bus	4-290				
IOC Bus Terminator Jumpers					
IOC Bus Continuity Plugs					
Power Jumpers	4-300				
Power Terminator Cards					
Frame 01					
Frame 02					
Five-Volt Power Supply Jumpers					
CHAPTER 5. REPLACEMENTS, MACHINE CLOCKING, AND ADJUSTMENTS					
CCU Board Replacement	5-010				
Removing the CCU Board					
Replacing the CCU Board					
ESD Instructions	5-020				
ESD Sensitive Parts Handling.					
ESD Precautions					
Card Module Information					
Jumper on Card	5-030				
How to Remove a Jumper Pin					
Card Replacement (Part 1 of 3)	5-040				
MPC Card Replacement (01A-A1T2)					
MROS Card Replacement (01A-A1U4)					
TIC Card Replacement					
Old Style					
New Style					
DAC Card Replacement (01A-A1R2)					
Card Replacement (Part 2 of 3)	5-041				
MMC Card Replacement (01A-A1S2)					
MEM Card Replacement (01A-A1B2 through N2)					
CCU Card Replacement (01A-A2)					
LIC Card Replacement					
Card Replacement (Part 3 of 3)	5-042				
LIC Card Replacement (continued)					
RDV Card Replacement					
CADR Card Replacement					
CA Card Location					
CADR Card Removal					
CADR Card Plugging					
Clock Scoping (Part 1 of 5)	5-050				
Limits					
Scope Point References					
Clock Scoping					
CCU Clock					
Clock Signal Relationship					
Clock Scoping (Part 2 of 5)	5-051				
High-Speed Clock					
Clock Cable Routing					
Low-Speed Clock					
Scoping Procedure					
Scope Points					
Clock Scoping (Part 3 of 5)	5-052				
Scope Points					
LAB A, B and C Locations					
		Clock Scoping (Part 4 of 5)	5-053		
		Clock Scoping (Part 5 of 5)	5-054		
		Power Supply Adjustments	5-060		
		DC Voltage Adjustment			
		AC Voltage Adjustment			
		CHAPTER 6. 3725 INITIALIZATION (IML, IPL)			
		Control Panel (Part 1 of 2)	6-010		
		Channel Adapter and MOSS Control			
		Program Wait Lamp (Green)			
		MOSS Inoperative Lamp (Red)			
		MOSS Message Lamp (Green)			
		Hex Display			
		Channel Adapter Enable Switches			
		All Channel Adapters Disabled Lamp (Green)			
		Console Switch			
		Function Start Switch			
		Function Select Switch			
		Control Panel (Part 2 of 2)	6-011		
		Power Control			
		Power Mode Switch			
		Control Panel Connections	6-020		
		MOSS Connection to Control Panel			
		3727 Operator Console (Part 1 of 5)	6-030		
		Controls and Locations			
		Power On/Off Switch			
		Power On Light			
		Test/Normal Switch			
		Light 1			
		Light 2			
		3727 Operator Console (Part 2 of 5)	6-031		
		Adjustment and Tests			
		Adjusting the Video Element			
		Operator Console Test			
		Console Link Test			
		3727 Operator Console (Part 3 of 5)	6-032		
		Element Removal and Replacement Procedures			
		Video Element Replacement			
		Keyboard Element Replacement			
		3727 Operator Console (Part 4 of 5)	6-033		
		Logic Element Replacement			
		3727 Operator Console (Part 5 of 5)	6-034		
		Anti-Glare Filter Feature			
		Removal Procedure			
		Cleaning Procedure			
		Replacement Procedure			
		Keyboard Palm Rest Feature			
		Removal			
		Replacement			
		3727 Operator Console Connection	6-040		
		Controller Resets	6-050		
		Remote Power Off (RPO)			
		Reset Functions			
		Controller Initialization	6-060		
		Initialization of a Channel-Attached 3725			
		Initialization of a Link-Attached 3725			
		Initialization Requests			
		Requesting a MOSS IML			
		Controller Initialization			
		Sequence (Part 1 of 2)	6-070		
					Controller Initialization
					Sequence (Part 2 of 2)
					6-071
					Controller Initialization Flow
					6-080
					Phase 1A: Controller IPL
					Phase 1B: Controller Re-IPL
					Phase 2: Load and Start CLDP in CCU
					CCU Rollout Area
					Phase 3: Scanner IML
					Phase 4: CCU Loading Support
					Abnormal Conditions During
					Controller Initialization
					6-100
					Using CCU Functions During Initialization
					MOSS IML Step Description
					6-110
					Introduction
					MOSS IML Steps
					Step 0: MOSS Reset
					Step 1: MOSS Processor Checkout
					Step 2: MOSS IOC Bus Testing/RAM Testing
					Step 3: I/O Selection and
					Interrupt Mechanism
					Step 4: Diskette Testing
					Step 5: Execute Disk Bootstrap
					Step 6: CCA Card Test
					Step 7: EIA Card and Console Attached Test
					Steps 8 and 9: MCC and MMC Card Test
					Step 10: Microcode Load in MOSS
					Step 11: MOSS Initialization
					Scanner IML Step Description
					6-120
					Introduction
					IML Principle
					IML Steps
					Controller Initialization Request Handling
					6-130
					Handling Write IPL Requests on the
					MOSS Side
					IPL Exchanges over Channel IPL Port
					6-140
					IPL Exchange Mechanism (Channel IPL Port)
					Dump Exchanges over Channel IPL Port
					6-150
					Dump Exchange Mechanism (Channel IPL Port)
					IPL Exchanges over Link IPL Port
					6-160
					Remote End Line Trace of Remote
					Load (Part 1 of 2)
					6-170
					Remote End Line Trace of Remote
					Load (Part 2 of 2)
					6-171
					Dump Exchanges over Link IPL Port
					6-180
					Remote End Line Trace of Remote NCP Abend and
					Dump Transfer (Part 1 of 2)
					6-190
					Remote End Line Trace of Remote NCP Abend and
					Dump Transfer (Part 2 of 2)
					6-191
					CHAPTER 7. DISKETTE DRIVE
					General Description (Part 1 of 2)
					7-010
					Diskette Description
					Diskette Use
					Inserting the Diskette
					Removing the Diskette
					Maintenance
					General Description (Part 2 of 2)
					7-011
					Diskette Drive Special Tools
					Diskette Drive Characteristics
					Diskette Functional Characteristics

Safety 7-020
 Personal Safety
 Diskette Drive Safety
 Diskette Safety

Diskette Drive Support Logic Locations 7-030
 3725 Controller - Frame 01

Diskette Drive Detail Locations 7-040

Theory of Operation (Part 1 of 5) 7-050
 Diskette Drive Control Card and MMB
 Board Connections

Theory of Operation (Part 2 of 5) 7-051
 Interconnection Lines Description
 Write Data
 +Inner Tracks
 +Write Gate
 +Select Head 1
 +Erase Gate
 +Switch Filter
 +Write/Erase Enabled
 File Data
 +Index
 Diskette Sense
 Access Lines 0 and 1
 +Head Engage
 Mechanical Operation
 Typical Device Operation

Theory of Operation (Part 3 of 5) 7-052
 Read/Write Operation Principles
 Write Data
 FM Encoding
 MFM Encoding
 Write Operation
 Format Write Operation
 Record (Update) Write Operation
 Read Data
 File Data

Theory of Operation (Part 4 of 5) 7-053
 Read Data: FM Encoded
 Scope Setup
 File Data Signal
 Scope Setup
 Read Data: MFM Encoded
 Scope Setup
 MFM File Data
 Scope Setup

Theory of Operation (Part 5 of 5) 7-054
 Diskette Drive Test Pins
 Diskette Drive Control Card Cable
 Diskette Drive Control Card

On/Off and Replacement Procedures 7-060
 Diskette Drive AC Power On/Off
 Diskette Drive AC/DC Power Off
 Diskette Drive AC/DC Power On
 Diskette Drive Removal/Replacement

Diskette Drive Service Check 7-061
 LED, PTX, and Drive Control Card
 Verification of Correct Operation
 LED Service Check
 Diskette Drive Control Card Service Check
 PTX Service Check
 Removal and Replacement of the Diskette
 Drive Control Card

Stepper Motor Removal/Replacement 7-062
 Stepper Motor Removal
 Stepper Motor Replacement
 Adjustments after Stepper
 Motor Installation

Drive Band Replacement and Adjustment 7-070
 Drive Band Service Check
 Drive Band Replacement
 Drive Band and Head/Carriage Adjustment

Head/Carriage Service Check 7-080

Head/Carriage Adjustment 7-090

Head/Carriage Replacement 7-100

Bail and Solenoid Checks and Adjustments 7-110
 Service Check
 Head Gap Adjustment
 Bail Adjustment

Bail and Solenoid Replacement 7-120

Collet/Flat Spring Replacement and Adjustment 7-130

LED and PTX Replacement 7-140
 LED (Light Emitting Diode) Replacement
 PTX (Phototransistor) Replacement
 PTX Installation Notes

Drive Motor Removal/Replacement 7-150
 Drive Motor Removal
 Drive Motor Installation
 Diskette Drive Motor Fan
 Capacitor Replacement

Diskette Drive Connectors (Part 1 of 2) 7-160
 Diskette Drive Control Card
 Diskette Drive Control Card Connectors

Diskette Drive Connectors (Part 2 of 2) 7-161
 MMB Cable Connector Test Procedure

Diskette Drive Testing 7-170

CHAPTER 8. B/M INSTALLATION AND PREVENTIVE MAINTENANCE

B/M Installation 8-010
 Hardware EC/MES Installation
 Microcode and Diagnostic EC Installation

Preventive Maintenance 8-020

LIC or ICC Move from One Board to Another 8-030
 Introduction
 Description of the LIC or ICC Move Phases
 Phase One (Before Moving)
 Phase Two
 Phase Three (Housekeeping/Bring-up)

Physical Representation of LIC Move 8-035
 3725 Model 1
 3726
 3725 Model 2

Before Moving the LIC(s) or the ICC(s) 8-040
 Recording the Machine Configuration
 Testing the Machine Before the LIC or
 ICC Move

LIC Move Procedure (Part 1 of 3) 8-045
 Step A. DCE Cable Moving
 Step B. Flat Cable Removal

LIC Move Procedure (Part 2 of 3) 8-050
 Step C. LIC Card Move
 Step D. Flat Cable Installation
 Tailgate Connector Installation
 Power On
 Updating the Configuration Data File (CDF)
 for the LIC

LIC Move Procedure (Part 3 of 3) 8-055

ICC Move Procedure 8-060
 ICC Removal/Installation
 Power On After ICC Card Move
 Updating the Configuration Data File (CDF)
 for ICC

Housekeeping (Part 1 of 2) 8-065
 Running TSS Diagnostics After LIC or ICC
 Move Procedure
 Diskette Swap

Housekeeping (Part 2 of 2) 8-070
 General IPL

CHAPTER 9. SYSTEM OPERATIONS

System Interrupts 9-010
 Examples
 Interrupt Levels

Message Exchanges 9-030
 NSC Address with NCP
 Message Format
 Exchange Sequence
 ESC Address with EP
 Message Format
 Exchange Sequence

CCU/Scanner Exchanges 9-040
 Normal Mode
 Character Mode
 Burst Mode

Protocol Handling 9-050

CHAPTER 10. CENTRAL CONTROL UNIT

SECTION 1. UNIT DESCRIPTION

CCU in 3725 Data Flow 10-010

CCU Data Flow 10-010

CCU Data Flow 10-020
 Error Checking Circuits

CCU Circuit Description (Part 1 of 2) 10-030
 Arithmetic and Logic Unit (ALU)
 Function Registers
 Instruction Address Register (IAR *)
 IOC Registers (A and D)
 Lagging Address Register (LAR *)
 Maintenance Data Operand Register (MDOR)
 Operation Register (OP Reg *)
 Pre-Fetch Address Register (PFAR)
 Pre-Fetch Operation Register (POPR)
 CCU Read-Only Storage (ROS)
 Storage Address Register (SAR)
 Work Registers (WKR *)
 Write Storage Data Register (WSDR)
 Z Register

CCU Circuit Description (Part 2 of 2) 10-031
 ROS Operation
 CCU/ROS Operation

CCU Characteristics and Packaging 10-040
 Connectors
 Timing
 Interrupts
 CCU Board Packaging
 Cycle Steals
 Instruction Set
 CCU Main Storage
 Logic Partitioning

Main Storage Description	10-050	RS Instructions on Halfword and Word (Part 2 of 2)	10-171	CCU Isolation and Clocking Checks (A) (B) (C)	10-800
Data Flow		Cycle Sequence Tables		CCU Isolation: Disconnect IOC Bus (A)	
Storage Buses and Packaging		Register and Storage with Addition (RSA) Instructions	10-180	CCU Isolation: Disconnect Storage (B)	
Storage Addressing		ICT and STCT		Disconnecting the CCU Memory Cards	
ECC Mechanism		Cycle Sequence Tables		CCU/Storage Clocking Checks (C)	
Storage Operations		Data Flow for RSA Instruction		CCU Storage Refresh Timing Checks (D)	10-810
Storage Word		Operation		Input X'70' Scoping Checks (E)	10-820
Storage Operation Timing	10-060	Branch (RT) Instructions	10-190	Storage Control Out Tag: Output X'74' (F)	10-825
Read		Branch on bit (BB)		ECC Modes	
Write		Cycle Sequence Table		Diagnostic Facilities	
Output X'74' (ECC Control)		Branch (B)		Wrap-Up	
Input X'70' (Read Storage Size)		Branch on C Latch (BCL)		Force Hard Errors	
Refresh		Branch on Z Latch (BZL)		Force Hardware Checkers	
Storage Data Flow and Partitioning	10-070	Cycle Sequence Table		Force ECC-Only	
Storage Configurations		Branch on Count (BCT)		CCU-to-Storage Bus Scoping (G) (Part 1 of 4)	10-830
CCU Program Level Priorities and Interrupts (Part 1 of 2)	10-080	Cycle Sequence Table		Running the Routine	
Interrupt Mechanism		Exit Instruction	10-200	CCU-to-Storage Bus Scoping (G) (Part 2 of 4)	10-831
Multiple Interrupt Requests on Same Level		Cycle Sequence Table		Signal Characteristics for the	
Setting/Resetting Interrupt Requests		Operation		Different Modes	
CCU Program Level Priorities and Interrupts (Part 2 of 2)	10-081	Register External (RE)		R030401, R030402, and R030403	
Interrupt Request Sources		Instructions (Part 1 of 2)	10-210	R030404	
MIOC Control Logic	10-090	Input Instruction		R030405	
MIOC Data Flow		Invalid Input Instructions		R030406	
Direct Operations		Cycle Sequence Tables		CCU-to-Storage Bus Scoping (G) (Part 3 of 4)	10-832
Indirect Operations		Data Flow for Input RE Instruction		Read Storage Timing on Board 01A-A1	
LSSD Operations		Operation		CCU-to-Storage Bus Scoping (G) (Part 4 of 4)	10-833
IOC Control Logic		Register External (RE)		Read/Modify/Write Storage Timing on	
Instruction Formats	10-100	Instructions (Part 2 of 2)	10-211	Board 01A-A1	
Instruction Decoding	10-110	Output Instruction (RE)		Storage Signal Routing (H) (Part 1 of 2)	10-840
Register and Immediate Address (RA) Instructions	10-120	Invalid Output Instructions		Storage Signal Routing (H) (Part 2 of 2)	10-841
BALR Instruction		Cycle Sequence Tables		Pin/Net List	
LA Instruction		Data Flow for Output RE Instruction		Unexpected CCU Interrupt Processing (I)	10-850
IOHI Instruction		Operation		CHAPTER 11. IOC BUS AND REDRIVE	
Cycle Sequence Tables		External Register Functions	10-220	SECTION 1. UNIT DESCRIPTION	
Data Flow for IOHI Instruction		Input Registers		IOC Bus and RDV in 3725 Data Flow	11-010
Operation		Output Registers		IOC Bus Structure (Part 1 of 2)	11-015
Register Immediate (RI) Instructions	10-130	Input X'7x' - Register Bits (Part 1 of 2)	10-230	IOC Control Logic	
Data Flow for RI Instruction		Input X'7x' - Register Bits (Part 2 of 2)	10-231	PIO Bus Protocol	
Operation		IOC Internal Status Table		IOC Bus Line Descriptions	
Register to Register (RR) Instructions	10-140	Output X'7x' - Register Bits	10-240	TA (Address/Command Tag)	
RR Instructions on Character		Storage Protect/Address Exception (SP/AE)	10-250	TD (Data Tag)	
RR Instructions on Halfword and Word		Main Storage Protection States		IRR (Interrupt Request Removed)	
Data Flow for RR Instruction		SP/AE Key Types		CSRH (Cycle Steal Request High)	
Operation		SP/AE Storage		CSRL (Cycle Steal Request Low)	
Exceptions to RR Instructions	10-150	SP/AE Instructions		CSGH (Cycle Steal Grant High)	
Branch and Link Register		Error Handling		CSGL (Cycle Steal Grant Low)	
Cycle Sequence Table		CCU Timers	10-260	I/O (Input/Output)	
Adapter Input/Output (IOH)		100-ms Interval Timer		HLT (Halt)	
Cycle Sequence Table		High/Low Resolution Timer		IOC Bus Structure (Part 2 of 2)	11-016
Data Flow for IOH Instruction		Timer Operation		RST (Reset)	
Operation		Cycle Counter Operation		R/W (Out)	
RS Instructions on Character	10-160	SECTION 2. TROUBLESHOOTING GUIDELINES		VB (Valid Byte)	
IC, STC		DC Voltages and Tolerances at Board Pin Level	10-600	VH (Valid Halfword)	
Cycle Sequence Table		CCU and Storage Troubleshooting Techniques (Part 1 of 2)	10-750	EOC (End of Chain)	
Data Flow for RS Instruction on Character		Operation		M (Modifier)	
Operation		CCU and Storage Troubleshooting Techniques (Part 2 of 2)	10-751	PV (Parity Valid)	
RS Instructions on Halfword and Word (Part 1 of 2)	10-170	Operation		Data Bus Bytes 0 and 1	
L and LH, ST and STH		Data Flow for RS Instruction		PIO Operation (Part 1 of 3)	11-020
Data Flow for RS Instruction		Operation		PIO Operation Sequence	
Operation				PIO Initiated by the CCU	
				PIO Initiated by the MOSS	

PIO Operation (Part 2 of 3) 11-021
 Table 1. PIO Operation Sequence (Initialization)
 Table 2. PIO Operation Sequence (Data Transfer)

PIO Operation (Part 3 of 3) 11-022
 PIO Write Timing
 PIO Read Timing

AIO Operation (Part 1 of 4) 11-030
 AIO Operation (Cycle Stealing)
 Table 3. AIO Operation Sequence (Initialization)

AIO Operation (Part 2 of 4) 11-031
 Table 4. AIO Operation Sequence (CSCW Transfer)
 Table 5. AIO Operation Sequence (Storage Address Transfer)

AIO Operation (Part 3 of 4) 11-032
 Table 6. AIO Operation Sequence (Data Transfer in Write)
 Table 7. AIO Operation Sequence (Data Transfer in Read)

AIO Operation (Part 4 of 4) 11-033
 AIO Write Timing
 AIO Read Timing

Address/Command Formats on IOC Bus 11-040
 IOC BUS: Address/Command Format
 At TA Time
 AIO - CSCW Contents
 IOC BUS: Address/Command Description
 At TD Time

Scanner, TRA and Line Addressing (Part 1 of 2) 11-050
 Line Attachment Board Address
 Line Group
 Line Interface Address
 3725/3726
 3725 Model 2
 Scanner and TRA Addressing
 Scanner/TRA Pre-Auto Selection
 CCU Level 2 Interrupt Requests
 Cycle Steal Requests

Channel Adapter Addressing 11-055
 Input/Output (IOH)
 Input/Output Immediate (IOHI)

Redrive Cards 11-060
 Functions
 Redrive Card Implementation
 IOC Bus Connection

Redrive Addressing 11-070
 RDV Group Address
 Primary Redrive Address
 Secondary Redrive Address
 Redrive Addresses and Commands
 Redrive Addressing on Boards

Redrive Functions 11-080
 Redrive Error Register
 Reset

Redrive State Definitions 11-090
 Enabled
 Disabled
 Board Disabled by Jumper
 Deactivated
 Disconnected
 Summary Table
 Data Flow

Redrive Commands (Part 1 of 2) 11-100
 Command List
 Command Format
 Poll (X'0')

Read Error Register (X'1' or X'9')

Write Error Register (X'0' or X'8')

Redrive Commands (Part 2 of 2) 11-101
 Disable Driver (X'1' or X'9')

Enable Driver (X'2' or X'A')

Reset Redrive (X'5' or X'D')

Diagnostic Write (X'6' or X'E')

Diagnostic Read (X'A')

SECTION 2. TROUBLESHOOTING GUIDELINES

DC Voltages and Tolerances at Board Pin Level . 11-600

IOC Bus Troubleshooting Techniques 11-750

Warning Notes 11-800
 CDF Change Warning
 Channel Adapter Reset Warning
 IOC Bus Terminator Power Warning
 Secondary Bus Enabling Warning

Bus Configuration and RDV States 11-801
 IOC Bus Configuration
 Redrive States

IOC Bus IFT Diagnostics 11-802
 Section I
 Section J
 Section JA
 Section JB
 JA and JB Failing
 Section JC

IOC Bus Isolation 11-803
 RDV Disconnection
 IOC Bus Shortening

RDV Clocking Checks 11-804

PIO Scoping Routine 11-805
 Running the Routine
 Option
 TA and TD

PIO Scoping Address and Commands 11-806
 Address (TA) Formats
 Redrive TA Format
 Command Format
 Error Register in the Redrive
 Redrive TD Format

PIO Scoping, Redrive Cards 11-807
 Redrive Card Scoping
 Redrive Card Scoping (Via Board RDV-4)

PIO Scoping Scanners 11-808
 CSP TA Format
 CCU L1 and L2 Interrupts from
 Adapter Scoping

PIO Scoping, Channel Adapters 11-809
 Channel Adapter TA Format
 Channel Adapter Scoping
 PCI Level 3 Interrupt for a Given Channel
 Adapter Scoping

PIO Scoping, Error Reporting 11-810
 Error Reporting
 Register In X'76'

PIO Scoping TRAs 11-811
 TRA TA Format
 TRM Card Scoping (via Board RDV-3)

PIO Timings 11-812
 Read Timing
 Write Timing
 IOC Bus Signal Scoping

Cycle Steal Timing 11-813

IOC Bus Adapter Interrupts 11-814
 Level 1 Interrupt Request
 Interrupt Level 2 Test
 Level 3 Interrupt Request
 Scanner Interrupt Request to the MOSS

CHAPTER 12. CHANNEL ADAPTER

SECTION 1. UNIT DESCRIPTION

Channel Adapter in 3725 Data Flow 12-003

Introduction 12-005
 3725/3726
 3725 Model 2
 Card Descriptions
 Channel-to-CCU Interconnection (CCIN) Card
 Channel Interface (CHIN) Card
 Channel Adapter Driver Receiver (CADR) Card
 Card Vendor Transistor Logic
 Socket Location
 3725/3726
 3725 Model 2
 Host Unit Control Word (UCW) Definition

Channel Adapter Operating Environment 12-010
 Modes of Operation
 NSC Mode
 ESC Mode

Data Transfer Methods (Part 1 of 2) 12-015
 Controlling the Channel Adapter
 Channel Adapter States
 Channel Adapter Ready State
 Channel Adapter Initial Selection State
 Channel Adapter Data Transfer State
 Channel Adapter Status Transfer State
 Channel Adapter Disabled State
 Channel Adapter Device Addresses
 Channel Adapter Interrupt Requests
 Level 1
 Level 3
 Accessing Channel Adapter Registers
 Input/Output (IOH)

Data Transfer Methods (Part 2 of 2) 12-016
 Input/Output Immediate (IOHI)
 CA Broadcast Commands

Local Store and Register Contents (Part 1 of 3) 12-020

Local Store and Register Contents (Part 2 of 3) 12-021

Local Store and Register Contents (Part 3 of 3) 12-022

Registers X'0' and X'1' 12-025
 Input X'0' (Initial Selection Control)
 Byte 0, Bit 0: Initial Selection Interrupt
 Byte 0, Bit 1: Interface Disconnect
 Byte 0, Bit 2: Selective Reset
 Byte 0, Bit 3: Channel Bus Out Check
 Byte 0, Bit 4: Emulation
 Subchannel Operation
 Byte 0, Bit 5: Stacked Initial Status
 Byte 0, Bit 6: Status Byte Cleared
 Byte 0, Bit 7: System Reset
 Output X'0' (Reset Initial Selection)
 Input X'1' (Initial Selection Address
 and Command)
 Output X'1' (Initial Selection Address
 and Command)

Register X'2' (Part 1 of 3)	12-030	Byte 1, Bit 4: CA3 Interface A Enabled	CA Functional Partitioning and Selection	12-065
Input X'2' (Data/Status Control)		Byte 1, Bit 5: CA3 Interface B Enabled	Channel Adapter Selection	
Byte 0, Bit 0: Outbound Data Transfer Sequence		Byte 1, Bit 6: CA4 Interface A Enabled	Output X'7'	
Byte 0, Bit 1: Inbound Data Transfer Sequence		Byte 1, Bit 7: CA4 Interface B Enabled	Input/Output (IOH)	
Byte 0, Bit 2: Status Transfer Sequence		Output X'7' (Channel Adapter Control)	Input/Output Immediate (IOHI)	
Byte 0, Bit 3: Emulation Subchannel = 1		Byte 0, Bit 0: Enable Autoselection	Autoselection	
Byte 0, Bit 4: Channel End Presented		Byte 0, Bit 1: Disable Autoselection		
Byte 0, Bit 5: Channel Stop/Interface Disconnect		Byte 0, Bit 2: Select CA Addressed by Bits 4-6		
Byte 0, Bit 6: Suppress Out Monitor Interrupt		Register X'7' (Part 2 of 2)	CA Enabling/Disabling, Interrupt Requests and Control Characters	12-070
Byte 0, Bit 7: Program Requested Interrupt		Byte 0, Bit 3: Execute Output on CA Addressed by Bits 4-6	CA Enabling/Disabling	
Byte 1, Bit 0: Channel Bus Out Check		Byte 0, Bits 4-6: Channel Adapter Address Bits	Level 1 Interrupt Requests	
Byte 1, Bit 1: Selective Reset		Byte 0, Bit 7: Channel Adapter Reset	Level 3 Interrupt Requests	
Byte 1, Bit 2: Suppress Out		Byte 1, Bit 0: Set Suppress Out Monitor	Control Character Recognition	
Byte 1, Bit 3: Stacked Ending Status		Byte 1, Bit 1: Set Program Requested Interrupt		
Register X'2' (Part 2 of 3)	12-031	Byte 1, Bit 2: Reset CA Interrupt Level 1 Checks	Two-Processor Switches (Part 1 of 2)	12-075
Byte 1, Bit 4: Priority Outbound Service		Byte 1, Bit 3: Reset System Reset/NSC Address Active	Two-Processor Switch (Loosely-Coupled Host Attachment)	
Byte 1, Bits 5-7: Residual Byte Count		Byte 1, Bit 4: Set Allow Channel Interface Enable (A and B)	Two-Processor Switch (Tightly-Coupled/Alternate Path Host Attachment)	
Output X'2' (Data/Status Control)		Byte 1, Bit 5: Set ESC Operational	Tightly-Coupled/Alternate Path Host Operations	
Byte 0, Bit 0: Set/Reset Outbound Data Transfer Sequence		Byte 1, Bit 6: Set ESC Command Free		
Byte 0, Bit 1: Set/Reset Inbound Data Transfer Sequence		Byte 1, Bit 7: Set Allow Channel Interface Disable (A and B)		
Byte 0, Bit 2: Set/Reset Status Transfer Sequence		Registers X'B' and X'C'	Two-Processor Switches (Part 2 of 2)	12-076
Byte 0, Bit 3: Set/Reset ESC Operation		Input/Output X'B' (ESC Test I/O Address and Status)	Presentation of Status	
Byte 0, Bit 4: Set/Reset PIO Mode		Input X'C' (Cycle Steal Mode Control)	Effect of System Reset	
Byte 0, Bit 5: Reset Initial Selection Interrupt		Byte 0, Bit 0: SYN Monitor Latch	System Reset over Interface	
Byte 0, Bit 6: Reset Data/Status Interrupt		Byte 0, Bit 1: DLE Remember Control Latch	Having Allegiance	
Register X'2' (Part 3 of 3)	12-032	Byte 0, Bit 2: USASCII Monitor Control Latch	System Reset over Interface Not Having Allegiance	
Byte 1, Bit 0: Set Monitor for Circle B		Byte 0, Bit 3: EBCDIC Monitor Control Latch	System Reset when the CA is in Neutral	
Byte 1, Bit 2: Set Monitor for 2848 ETX		Byte 1, Bits 0-7: Residual Byte Count	Effect of Selective Reset	
Byte 1, Bit 3: Set Suppressible Status		Output X'C' (Cycle Steal Mode Control)	Selective Reset over Interface Not Having Allegiance	
Byte 1, Bit 4: Priority Outbound Service		Byte 0, Bit 0: SYN Monitor Control Latch	Selective Reset over Interface Having Allegiance	
Byte 1, Bits 5-7: Request Byte Count		Byte 0, Bit 1: DLE Remember Control Latch		
Registers X'3', X'4' and X'5'	12-035	Byte 0, Bit 3: EBCDIC Monitor Control Latch	CA Error Condition	12-080
Input/Output X'3' (ESC Address and Status Byte)		Byte 1, Bit 0-7: Request Byte Count	IOC Bus Parity Error	
Input/Output X'4' and X'5' (Data Buffer)		Register X'D'	Internal Bus Parity Error	
Program-Initiated Operation (PIO)		Input X'D' (CA Level 1 Interrupt Check)	CCIN Card Check	
Adapter-Initiated Operation (AIO)		Byte 0, Bit 0: IOC Bus Parity Error	CHIN Card Check	
Register X'6'	12-040	Byte 0, Bit 1: Internal Bus Parity Error	Address Compare Error	
Input X'6' (NSC Status/Control)		Byte 0, Bit 2: CCIN Card Check	Initiate Service Latch Ungated	
Byte 0, Bit 0: CA Switched to Interface B		Byte 0, Bit 4: CHIN Card Check	Output Exception Check	
Byte 0, Bit 1: CA Switched to Interface A		Byte 0, Bit 5: Address Compare Error	PIO Halt Remember Latch	
Byte 1, Bits 0-7: NSC Status Byte		Byte 0, Bit 6: Initiate Service Latch Ungated	Cycle Steal Halt Remember Latch	
Output X'6' (NSC Status/Control)		Byte 1, Bit 0: Output Exception Check	Bus-In Check (A and B)	
Byte 0, Bit 0: Set Force A Busy		Byte 1, Bit 1: PIO Halt Remember Latch	Ground Fault Error	
Byte 0, Bit 1: Set Force B Busy		Byte 1, Bit 2: Cycle Steal Halt Remember Latch	CADR Card Check (A and B)	
Byte 0, Bit 2: Force Error		Byte 1, Bit 3: Bus-In Check Interface A		
Byte 0, Bit 3: Diagnostic Storage Mode		Byte 1, Bit 4: Ground Fault Error	Initial Selection (Part 1 of 2)	12-085
Byte 0, Bit 5: Check the Checkers		Byte 1, Bit 5: Bus-In Check Interface B	Initial Status Transfer	
Byte 0, Bit 6: A/B Data Buffer Diagnostic Mode		Byte 1, Bit 6: CADR Card Check Interface A	Stacked Initial Status	
Byte 0, Bit 7: Reset to Neutral State		Byte 1, Bit 7: CADR Card Check Interface B	ESC Initial Status Chart - Command to ESC Address	
Byte 1, Bits 0-7: Set NSC Status Byte		Registers X'E' and X'F'	Initial Selection (Part 2 of 2)	12-086
Register X'7' (Part 1 of 2)	12-045	Input X'E' (CA Level 1 Interrupt Requests)	NSC Initial Status - Command to NSC Address	
Input X'7' (Channel Adapter Condition)		Byte 0, Bits 4-6: Channel Adapter Address Bits	Data Transfer Sequences (Part 1 of 4)	12-090
Byte 0, Bit 0: CA5 Enabled		Input X'F' (CA Level 3 Interrupt Requests)	Data Transfer in AIO Mode (Cycle Stealing)	
Byte 0, Bit 2: CA6 Enabled		Byte 0, Bit 1: TPS Installed	Outbound Data Transfer Sequence in AIO Mode	
Byte 0, Bit 5: NSC Address Active		Byte 0, Bit 2: Selected CA Initial Selection L3 Interrupt Request	Inbound Data Transfer Sequence in AIO Mode	
Byte 0, Bit 6: PIO Mode		Byte 0, Bit 3: Selected CA Data/Status L3 Interrupt Request	Data Transfer Sequences (Part 2 of 4)	12-091
Byte 1, Bit 0: CA1 Interface A Enabled		Byte 0, Bits 4-6: Channel Adapter Address Bits	Data Transfer in PIO Mode	
Byte 1, Bit 1: CA1 Interface B Enabled			Outbound Data Transfer Sequence in PIO Mode	
Byte 1, Bit 2: CA2 Interface A Enabled			Data Transfer Sequences (Part 3 of 4)	12-092
Byte 1, Bit 3: CA2 Interface B Enabled			Byte Multiplex Channel	
			Block Multiplex or Selector Channel	
			Transfer Termination	
			Inbound Data Transfer Sequence in PIO Mode	
			Data Transfer Sequences (Part 4 of 4)	12-093
			Block Multiplex or Selector Channel	

CA Data Flow	12-095
Final Status Transfer/Sense	
Definition (Part 1 of 2)	12-100
NSC Final Status Transfer	
NSC Stacked Final Status	
ESC Final Status Transfer	
ESC Stacked Final Status	
Final Transfer Status/Sense	
Definition (Part 2 of 2)	12-101
CA Monitoring Task Final	
Status/Sense Information	
Channel Loader Dump Program Final	
Status/Sense Information	
NCP Channel Commands Information	12-110
NCP Status Information	12-115
NCP Sense Information	12-120
EP Channel commands	12-125
EP Ending Statuses (Part 1 of 2)	12-130
Ending Status to Halt I/O (Start-Stop)	
Ending Status to Halt I/O (BSC)	
EP Ending Statuses (Part 2 of 2)	12-131
Ending Status CE, DE, and UE (Start-Stop)	
Ending Status CE, DE, and UE (BSC)	
EP Sense Information (Part 1 of 2)	12-135
Sense Bit = 0: Command Reject	
Sense Bit = 0 (Continued)	
Sense Bit = 1: Intervention Required	
Sense Bit = 1 (Continued)	
EP Sense Information (Part 2 of 2)	12-136
Sense Bit = 2: Bus-Out Parity Check	
Sense bit = 3: Equipment Check	
Sense Bit = 4: Data Check	
Sense Bit = 5: Overrun	
Sense Bit = 6: Lost Data	
Sense bit = 7: Timeout	
Channel Tag Line Definitions (Part 1 of 2)	12-140
Address In	
Address Out	
Command Out	
Data In	
Data Out	
Operational In	
Operational Out	
Request In	
Channel Tag Line Definitions (Part 2 of 2)	12-141
Select Out, Select In, and Hold Out	
Service In	
Service Out	
Status In	
Suppress Out	
Selector Channel	12-200
CU Forced Burst Mode	12-205
Multiplexer Channel	12-210
Block-Multiplexer Channel (Part 1 of 2)	12-215
Block-Multiplexer Channel (Part 2 of 2)	12-216

SECTION 2. TROUBLESHOOTING GUIDELINES

DC Voltages and Tolerances at Board Pin Level	12-600
Channel Adapter Troubleshooting Techniques	12-750
Enabling/Disabling Checks (Part 1 of 3)	12-800
Clocking	
Channel Enabling/Disabling	
All Channel Adapters Disabled Lamp	
Hexadecimal Display Codes X'EE1'	
through X'EEA'	
3725/3726	
Channel Adapter Enable Switch	
Circuit Routing	
All Channel Adapters Disabled 'Dot Or'	
Circuit Routing	
Enabling/Disabling Checks (Part 2 of 3)	12-801
3725 Model 2	
Channel Adapter Enable Switch	
Circuit Routing	
All Channel Adapters Disabled 'DOT OR'	
Circuit Routing	
Enabling/Disabling Checks (Part 3 of 3)	12-802
Channel Adapter Enabled Signal Routing (CA	
Boards to MMB Board)	
3725 Model 2	
Autoselection Troubleshooting	12-803
CA Autoselection Troubleshooting	
Autoselection Signal Description	
Priority Bus Bits 4 through 7 to Interface	
Hold to Interface	
Common Valid Feed Auto	
Autoselection Signal Routing (Part 1 of 2)	12-804
Channel Adapter Autoselect Signal	
Routing (3725/3726)	
Autoselection Signal Routing (Part 2 of 2)	12-805
Channel Adapter Autoselect Signal Routing	
(3725 Model 2)	
Autoselection Timing	12-806
Autoselection, Scoping Routine (Part 1 of 2)	12-807
Channel Adapter Scoping Routine for	
Autoselect Mechanism	
Running the Routine	
Autoselection, Scoping Routine (Part 2 of 2)	12-808
Error Reporting	
CA Cycle Steal Troubleshooting	12-809
CA Cycle Steal Operations (AIO)	
Cycle Steal, Signal Routing (Part 1 of 4)	12-810
Cycle Steal Routing (3725/3726)	
Cycle Steal, Signal Routing (Part 2 of 4)	12-811
Cycle Steal Routing (3725 Model 2)	
Cycle Steal, Signal Routing (Part 3 of 4)	12-812
Cycle Steal Signal Routing During	
AIO (3725/3726)	
Cycle Steal, Signal Routing (Part 4 of 4)	12-813
Cycle Steal Signal Routing During AIO	
(3725 Model 2)	
Cycle Steal, Timing and Scoping	12-820
CA Cycle Steal Timing	
Channel Interface Scoping	
CA I/O Instruction Failure Scoping	

Cycle Steal, Scoping Routine (Part 1 of 2)	12-830
Channel Adapter Scoping Routine for Cycle	
Steal Mechanism	
Running the Routine	
Channel Adapter Number	
Storage Address for Cycle Steal	
Data for Cycle Steal	
Cycle Steal, Scoping Routine (Part 2 of 2)	12-831
Error Reporting	
CHAPTER 13. TRANSMISSION SUBSYSTEM	
SECTION 1. UNIT DESCRIPTION	
TSS in 3725 Data Flow	13-005
Communication Scanner Processor (Part 1 of 4)	13-010
Purpose	
Packaging	
Components	
Data Flow	
Local Storage	
Read-Only Storage	
Control Storage	
Communication Scanner Processor (Part 2 of 4)	13-011
CSP External Registers	
Communication Scanner Processor (Part 3 of 4)	13-012
CCU/CSP Register Use	
CSP/FES Register Use	
Ping/Pong Buffers	
Processor Characteristics	
Hardstop	
Communication Scanner Processor (Part 4 of 4)	13-013
Scanner State	
Inoperative	
Initialized	
Connected	
Disconnected	
Reset	
Scanner Commands	
Front-End Scanner (Part 1 of 2)	13-020
Purpose	
Throughput	
Data Flow	
Packaging	
Components	
Front-End Scanner (Part 2 of 2)	13-021
Functions	
Scheduler	
Scanner Base Layer	
Front-End Layer	
Storages	
Reset	
General Reset	
Programmed Reset	
Line Interface Card (Part 1 of 2)	13-030
Purpose	
Packaging	
Components	
Data Flow	
LIC Registers	
Register '00'	
Register '01'	
Register '10'	
Register '11'	

Line Interface Card (Part 2 of 2)	13-031	Microcode Interaction with FES (Part 1 of 2) .	13-130	Error Status Description (Part 1 of 3)	13-350
Reset		Reserved Scanner Storage Areas		Error Status Type 1 (Two Bytes)	
General Reset		FES Parameter/Status		Byte 0	
Line Reset		Line Interface Buffers		Byte 1	
Line Disabled/No-Operation		FES Storages		Error Status Type 2 (Two Bytes)	
Communication Interface		RAM A		Byte 0	
Internal Clock Card	13-040	RAM B		Byte 1: CCU	
Purpose		Microcode Interaction with FES (Part 2 of 2) .	13-131	Byte 1: MOSS	
Packaging		RAM C		Error Status Type 3 (Two Bytes)	
Jumpering (for Direct-Attached Terminals)		Commands		Byte 0	
Data Flow		Receive and Transmit Commands		Byte 1:	
Components		Reset/Freeze Command		Error Status Description (Part 2 of 3)	13-351
Register (for Modems without Clocks)		Microcode Interaction with MOSS	13-140	Error Status Type Hardstop (Two Bytes)	
Reset		Control Block Relationship	13-210	Byte 0	
Scanner Microcode Organization (Part 1 of 2) .	13-110	Data Transfers		Byte 1	
Functions		Instruction Operation (Part 1 of 2)	13-230	NCP/EP Command Status	
General Data Flow		Start Line Initial		Command Status (except Character and	
Scanner Microcode Organization (Part 2 of 2) .	13-111	Get Error Status		Burst Modes)	
Line Operating Modes		Instruction Operation (Part 2 of 2)	13-231	Character and Burst Modes Command Status	
Normal Mode		Start Line		Line Communication Status (LCS)	
Character Mode		Get Line Identification		Error Status Description (Part 3 of 3)	13-352
Burst Mode		FES Operation (Part 1 of 2)	13-260	MOSS Command Completion (Two Bytes)	
Service Mode		Parameter Transfer		Byte 0	
Microcode Levels		Parameter/Status Transfer Mechanism		Byte 1	
Level 0		Status Transfer		MOSS Command Status (Two Bytes)	
Level 1		Data Transfers		Byte 0	
Level 2		Receive Operation		Byte 1	
Level 3		Transmit Operation		Local Storage Register Description	13-420
Level 7		Data Transfer Mechanism		External Register Description (Part 1 of 5) . .	13-430
Microcode Interaction with Control Program		FES Operation (Part 2 of 2)	13-261	X'00': IOC Bus Control 1	
(Part 1 of 5)	13-120	Scanning Operation		X'01': IOC Bus Control 2	
Reserved CCU Storage Areas		Scanner Configuration Example		X'02': IOC Bus Service	
Parameter/Status Area (PSA)		Scanning Sequence		X'03': CSP Error	
Line Vector Table (LNVT)		Modem Line Management		External Register Description (Part 2 of 5) . .	13-431
Microcode Interaction with Control Program		Modem Change Detection		X'04': Miscellaneous/Adapter Address	
(Part 2 of 5)	13-121	LIC Driver Check		X'05': External Interrupt Request/Priority	
Data Buffers		Error Detection (Part 1 of 2)	13-320	X'07': Synchro/Configuration Data Set	
Reserved Scanner Storage Areas		TSS Hardware Errors: Data Flow		X'08': Error Indicators/Bad	
Storage MAP		Error Detection (Part 2 of 2)	13-321	Parity Generator	
Scanner Control Block		CSP/IOC Bus Errors		External Register Description (Part 3 of 5) . .	13-432
Line Control Block		CSP Internal Errors		X'10': Extended Interrupt Request	
Interface Control/Parameter Status Area		CSP/FES Errors		X'12': Interrupt Request	
Line Interface Buffer		Reporting Errors to the CCU (Part 1 of 2) . . .	13-330	X'13': Line Interface Address (Read/Write)	
Parameter/Status Area		CSP/IOC Bus Errors		X'14': Data In/Out	
CCU Instructions		Errors during PIO		X'15': Asynchronous Operation Command	
IOH Format		Errors during AIO		X'16': Asynchronous Operation Status	
Microcode Interaction with Control Program		Reporting Errors to the CCU (Part 2 of 2) . . .	13-331	External Register Description (Part 4 of 5) . .	13-433
(Part 3 of 5)	13-122	CSP Internal Errors		X'17': FES General Commands	
IOHI Format		Detected by Hardware		X'19': CSP Interrupt Request	
R2 and R Contents		Detected by Microcode		X'1A': Current CSP Interrupt Level	
Start Line Initial		CSP/FES Errors		X'1B': Address Compare Control	
Microcode Interaction with Control Program		Reporting Errors to the MOSS	13-340	External Register Description (Part 5 of 5) . .	13-434
(Part 4 of 5)	13-123	CSP/IOC Bus Errors		X'1C': Address Compare Byte 0	
Get Error Status		Errors during PIO		X'1D': Address Compare Byte 1	
Start Line		Errors during AIO		X'1E': CSP Interrupt Masks	
Get Line Identification		CSP Internal Errors		X'1F': Local Storage Address	
Set LNVT High/Low		Detected by Microcode		FES RAM A Description (Part 1 of 3)	13-510
Microcode Interaction with Control Program		Detected by Hardware		RAM A Receive	
(Part 5 of 5)	13-124	CSP/FES Errors		Parallel Data Field (PDF)	
Commands				Secondary Control Field (SCF)	
Common Commands				Interrupt Request	
NCP Commands				Control Storage Addressing	
EP Commands				Scanner Base Control	
Character Mode Command					
Burst Mode Command					
Miscellaneous Commands					

FES RAM A Description (Part 2 of 3)	13-511	LIC/ICC Register Description (Part 1 of 2)	13-540	MOSS Description (Part 3 of 3)	14-012
Timer		LIC Type 1		MOSS Card Interconnection	
RAM A Transmit		LIC Type 2		PIO Bus Protocol	
Timer Control		LIC/ICC Register Description (Part 2 of 2)	13-541	MOSS/CCU Communication	14-020
Secondary Control Field (SCF)		LIC Type 3		MIOC and MCC Cards	
Parallel Data Field (PDF)		LIC Type 4 (A or B)		MOSS/CCU Operations	
Interrupt Request		ICC Register		Direct Operations	
Control Storage Addressing		Scanner Storage MAP	13-550	Indirect Operations	
FES RAM A Description (Part 3 of 3)	13-512	Scanner Storage Map (X'8000'		LSSD Operations	
Scanner Base Control		through X'9B1F')		MCC Status Register Description	14-030
FES RAM B Description (Part 1 of 2)	13-520	SCB (Part 1 of 2)	13-551	Interrupt Register Description	14-040
RAM B Receive		Scanner Control Block (X'9500'		MOSS-to-CCU Status Register (X'14')	
Serial Data Field (SDF)		through X'96FF')		CCU-to-MOSS Status A Register (X'11')	
Secondary Control Field (SCF)		SCB (Part 2 of 2)	13-552	CCU-to-MOSS Status B Register (X'06')	
Parallel Data Field (PDF)		LCB	13-553	CCU-to-MOSS Status C Register (X'07')	
Primary Control Field (PCF)		Line Control Blocks (Addresses X'8A00'		CCU-to-MOSS Status D Register (X'0F')	
Synchronization		through X'8BFF')		CCU-to-MOSS Status E Register (X'01')	
FES RAM B Description (Part 2 of 2)	13-521	ICB/PSA	13-554	CCU-to-MOSS Status F Register (X'05')	
RAM B Transmit		Interface Control/Parameter Status Area		Branch Trace/Address Compare Register	
Serial Data Field (SDF)		Blocks (X'8C00' through		Description (Part 1 of 2)	14-050
Secondary Control Field (SCF)		LIB	13-555	Branch Trace Function	
Parallel Data Field (PDF)		Line Interface Buffers (X'8000'		Branch Trace Buffer	
Primary Control Field (PCF)		through X'87FF')		Branch Trace Extra Records	
Data Link Escape (DLE)		SECTION 2. TROUBLESHOOTING GUIDELINES		Address Compare Function	
Synchronization		DC Voltages and Tolerances at Board Pin Level	13-600	Single-Address Compare	
FES RAM C Description (Part 1 of 5)	13-530	TSS Troubleshooting Techniques	13-750	Two Single-Address Compares	
Line Type Identification		Transmission Subsystem Troubleshooting	13-800	Double-Address Compare	
SDLC Receive		Transmission Subsystem		Branch Trace/Address Compare Register	
Set Mode		Isolation (3725/3726)		Description (Part 2 of 2)	14-051
Control		Transmission Subsystem Clocking		Mode Control Register A (X'10')	
Block Check Character (BCC)		CSP Troubleshooting		Branch Trace Level Control Register (X'04')	
Modem-In		CELIA Card		CCU-to-MOSS Status Register C (X'07')	
Mask		CSP Timing Chart in Cycle Steal Mode		MOSS Indirect Operation Register Description	14-060
FES RAM C Description (Part 2 of 5)	13-531	CSP Storage Refresh		LSSD Operation (Part 1 of 2)	14-070
SDLC Transmit		Interrupt Requests to CCU (Part 1 of 2)	13-810	Shift Register Latch	
Set Mode		Preselection Mechanism		SRL Operation	
Control		Interrupt Preselection		Clock Pulse Timing (Not Displayable)	
Block Check Character (BCC)		Interrupt Autoselection		Data Flow Simplified Representation	
Modem-Out		Interrupt Priority Structure		LSSD Testing Circuit	
Mask		Interrupt Requests to CCU (Part 2 of 2)	13-811	LSSD Operation (Part 2 of 2)	14-071
FES RAM C Description (Part 3 of 5)	13-532	Cycle Steal Requests to CCU (Part 1 of 2)	13-820	SRL Read Operation	
BSC Receive		Cycle Steal Preselection		SRL Set/Reset Operation	
Set Mode: BSC, Normal		Cycle Steal Autoselection		CCU Strings	
Set Mode: BSC, ASCII or EBCDIC		Cycle Steal Priority Structure		LSSD Register Description	
Control		LIC to DCE Scoping		MOSS/Diskette Drive Interaction (Part 1 of	
Block Check Character (BCC)		Cycle Steal Requests to CCU (Part 2 of 2)	13-821	2)	14-080
Modem-In		CHAPTER 14. MAINTENANCE AND OPERATOR SUBSYSTEM		Diskette Commands	
Mask		SECTION 1. UNIT DESCRIPTION		Read/Write Operations	
FES RAM C Description (Part 4 of 5)	13-533	MOSS Description (Part 1 of 3)	14-010	Timeout Considerations	
BSC Transmit		MOSS Description (Part 2 of 3)	14-011	Diskette Adapter Status Register	
Set Mode		MOSS Functions		MOSS/Diskette Drive Interaction (Part 2 of	
Control		MOSS Processor		2)	14-081
Block Check Character (BCC)		Data Flow		Diskette Sense Byte	
Modem-Out		MOSS Interrupt Level Organization		Diskette Mapping	
Mask		MOSS Storages		I/O Connections	14-090
FES RAM C Description (Part 5 of 5)	13-534	MOSS Storage Map		MOSS/Console Connections	
Start-Stop Receive		MPC and MMC Cards		CCA Card Functions	
Set Mode				CCA Basic Status Register	
Control				EIA Card Control	
Modem-In				MOSS/Control Panel Connections	
Mask				MOSS Microcode (Part 1 of 2)	14-100
Start-Stop Transmit				General Information	
Set Mode				Mailbox Protocol	
Control				MOSS States	
Modem-Out					
Mask					

MOSS Microcode (Part 2 of 2)	14-101
MOSS Changes of State	
Interrupt Levels	14-110
Level 0	
Level 1	
Level 2	
Level 3	
Level 4	
Level 5	
Level 6	
Level 7	
Register Map	14-120
MOSS Register Space Allocation (1K Bytes)	
Storage Mapping (Part 1 of 2)	14-130
Storage Mapping (Part 2 of 2)	14-135
DCF Translate Table Array (TTA)	
Communication between MOSS and NCP/EP (Part 1 of 2)	14-140
CCU Control Program/MOSS Communications	
Mailbox Description	
CCU to MOSS Communication (Out Mailbox)	
Exchange Procedure	
MOSS to CCU Communication (In Mailbox)	
Exchange Procedure	
Communication Between MOSS and NCP/EP (Part 2 of 2)	14-141
Exchange Timeouts	
Mailbox Commands	
Sense Codes	
Mailbox Status	
Scanner/MOSS Communication	14-150
Scanner Communication Area Commands	
Detection of MOSS Errors	14-160
Hardware Checking	
Software Checking	
SECTION 2. TROUBLESHOOTING GUIDELINES	
DC Voltages and Tolerances at Board Pin	14-600
Board and Bus Organization	14-750
MOSS Troubleshooting Techniques	14-800
Introduction	
MOSS Isolation and Clocking Checks	14-810
MOSS Isolation	
Clocking Checks	
Code Other Than X'F01' (Part 1 of 2)	14-820
MOSS Completely Down	
Power On/Machine Reset Checks	
Blank Display Checks	
Code Other Than X'F01' (Part 2 of 2)	14-821
Display is Other than X'F01'	
(Including Blank)	
Display Reaches X'F01' but MESSAGE Lamp	
does not Light	
PIO Bus Checking (Part 1 of 2)	14-830
Introduction	
Static Checking	
MOSS Reduced Configuration	
PIO Bus Checking (Part 2 of 2)	14-831
Loop On Error	
Console Signals	

PIO Bus Signal Routing (Part 1 of 2)	14-835
PIO Bus Signal Routing (Part 2 of 2)	14-836
MPC Timing Charts	14-840
Read Command Timing Chart	
Write Command Timing Chart	
Storage Address Test	
Permanent Interrupt after Reset	14-850
IOIR Scope Points	
Diskette Drive Bus Errors (Part 1 of 2)	14-860
Disk Adapter ROS Tests (X'E70'	
through X'E75')	
Disk Adapter ROS Test Phase 0 (X'E70')	
Disk Adapter ROS Test Phase 1 (X'E71')	
Disk Adapter ROS Test Phase 2 (X'E72')	
Diskette Drive Bus Errors (Part 2 of 2)	14-861
Disk Adapter ROS Test Phase 3 (X'E73')	
Disk Adapter ROS Test Phase 4 (X'E74')	
Disk Adapter ROS Test Phase 5 (X'E75')	
MIOC Bus Connections	14-880
MIOC Bus Write Operation	14-881
MIOC Bus, Read Operation	14-882
MIOC Bus Scoping Routine	14-883
Running the Routine	
Signal Characteristics	
CHAPTER 15. TOKEN-RING SUBSYSTEM	
SECTION 1: UNIT DESCRIPTION	
Overview of the IBM Token-Ring Network (Part 1 of 3)	15-020
Purpose of the IBM Token-Ring Network	
What is an IBM Token-Ring Network	
Definition	
Cabling System (Ring)	
Transmission Media	
Token-Ring Adapter	
Overview of the IBM IBM Token-Ring Network (Part 2 of 3)	15-021
Access Protocol	
General Frame Format	
Token-Ring Access Control Protocol	
Token-Ring Encoding	
Major System Components	
Nodes	
Interface Adapters	
Overview of the IBM Token-Ring Network (Part 3 of 3)	15-022
Multistation Access Unit 8228	
Bridges	
Typical Multi-Floor Wiring	
The Token-Ring Subsystem Data Flow	15-030
The Token-Ring Subsystem in the 3725	15-031
Introduction	
LAB Type C	
Token-Ring Interface Coupler Card (Part 1 of 3)	15-040
Token-Ring Interface Coupler Card (TIC)	
Description	
TIC Data Flow	
TIC Card Data Flow	

Token-Ring Interface Coupler Card (Part 2 of 3)	15-041
The Front End	
The Protocol Handler	
The Message Processor	
IOC Bus Interface Control	
Token-Ring Interface Coupler Card (Part 3 of 3)	15-042
Receive Operation	
Transmit Operation	
Token-Ring Multiplexor Card (Part 1 of 2)	15-050
TRM Card Description	
IOC Bus Interface	
Summary of the IOC Bus Interface Signal Lines	
Token-Ring Multiplexor Card (Part 2 of 2)	15-051
TIC Bus Interface	
TIC Bus Signal Lines	
Summary of the TIC Bus Signal Lines	
TRM Arbitration Mechanism	
Machine Internal Communications	15-060
PIO-MMIO Operations	
CS-DMA Operations	
Interrupt Operations	
Impact of TRSS on NCP Level 1 Code	
Programmed Input/Output Operations	15-100
Token-Ring Encoding	
Major System Components	
Nodes	
Interface Adapters	
Overview of the IBM Token-Ring Network (Part 3 of 3)	15-022
Multistation Access Unit 8228	
Bridges	
Typical Multi-Floor Wiring	
The Token-Ring Subsystem in the 3725	15-031
Introduction	
LAB Type C	
Token-Ring Interface Coupler Card (Part 1 of 3)	15-040
Token-Ring Interface Coupler Card (TIC) Description	
TIC Data Flow	
TIC Card Data Flow	
Token-Ring Interface Coupler Card (Part 2 of 3)	15-041
The Front End	
The Protocol Handler	
The Message Processor	
IOC Bus Interface Control	
Token-Ring Interface Coupler Card (Part 3 of 3)	15-042
Receive Operation	
Transmit Operation	
Token-Ring Multiplexor Card (Part 1 of 2)	15-050
General PIO Operations	
TRM PIO Operation	
PIO Format and Types (Part 1 of 4)	15-105
PIO Format at TA Time	
List of the PIO Types	
PIO Types for TIC	
PIO Format and Types (Part 2 of 4)	15-106
Set/get TRM Control Register	
Set/get TIC Control Register	
Write/Read Interrupt Request and Bus Request	
Register	
TRM Buffer and Extended Buffer	

PIO Format and Types (Part 3 of 4)	15-107	TRM Error Detection and Reporting (Part 1 of 2)..	15-160
TRM Level 1 Error Status Register		Parity Checker to the IOC Bus (1)	
TRM Level 2 Error Status Registers		Parity Checker to the TIC Bus (2)	
PIO Format and Types (Part 4 of 4)	15-108	Internal Parity Checker (3)	
MOSS Error Status Register		DTACK Checker (Timer) (4)	
TRM PIO Functional Description	15-110	AS/DS Checker (Timer) (5)	
TRM PIO Initialization		TRM Hardware Checkers Placement	
TRM Selection		Idle Checker of the TIC Bus Tags (6)	
TRM PIO Management		Idle Checker of the TIC Address/Data Bus (7)	
PIO Write Sequence		Data Strobe Checker (8)	
PIO Read Sequence:		Invalid PIO Checker (9)	
TRM Mapping of PIO to MMIO	15-115	TRM Error Detection and Reporting (Part 2 of 2)..	15-161
TIC Interface Management by the TRM		TRA Interaction with Control Program (Part 1 of 2)	15-170
PIO/MMIO Hand-Shaking Mechanism		TIC Initialization	
PIO/MMIO Write		TIC Read Interrupt Register (Initialize)	
PIO/MMIO Read		Bits 12-15 - Bring-Up Error Code (Test = 1)	
TRM PIO Command Description	15-120	Bits 12-15 - Initialization Error Code (Test = 0)	
Get Line Identification		TRA Interaction with Control Program (Part 2 of 2)	15-171
Read Computed Line ID by MOSS		Commands to TIC	
Read/Load Line ID Base		DC Voltages and Tolerances at Board Pin Level	15-600
Get Command Completion		Ring Interface Electrical Characteristics	
Set Command		Ring Receiver	
Programmed Reset TRM		Ring Transmitter	
Read CSCW		SECTION 2: TRSS TROUBLESHOOTING GUIDELINES	
TRM Cycle Steal Operations	15-130	TRSS Extended Troubleshooting Techniques	15-750
Direct Long and Indirect Operation for Normal		Token-Ring Subsystem Troubleshooting	15-800
Cycle Steal		Token-Ring Adapter Isolation (3725/3726)	
Direct Short Operation for Error Cycle Steal		TRSS Clocking	
Operation		TRSS Diagnostics Organization	
Cycle Steal Sequence Description		Interrupt Requests to CCU (Part 1 of 2) with TRA	
TRM Mapping of DMA to Cycle Steal		(LABC) installed on any LAB pos 3 to 8)	15-810
TRM Interrupt Operations (Part 1 of 4)	15-135	Preselection Mechanism	
Level 1 Interrupt		Interrupt Preselection	
General Operation		Interrupt Autoselection	
Scenario for IOC Level 1 Error Recovery		Interrupt Priority Structure	
Disconnect Operation Scenario		Interrupt Requests to CCU (Part 2 of 2) with TRA	
Level 2 Interrupt		(LABC) installed on any LAB pos 3 to 8)	15-811
Line Identification (Line ID) Generation		Cycle Steal Requests to CCU (Part 1 of 2)	15-820
General Description		Cycle Steal Preselection	
TRM Interrupt Operations (Part 2 of 4)	15-136	Cycle Steal Autoselection	
TIC Interrupts		Cycle Steal Priority Structure	
TIC Interrupt Scenario		Cycle Steal Requests to CCU (Part 2 of 2)	15-821
TRM Interrupt Operations (Part 3 of 4)	15-137		
TRM Interrupt Scenario			
Line ID Loading			
TIC Adapter Check Register			
TRM Interrupt Operations (Part 4 of 4)	15-138		
TIC Adapter Check Register Decoding (Two Bytes)			
Interrupt to MOSS			
General Operation			
Scenario for Interrupt to MOSS			
TRSS Disconnect/Connect Function	15-150		
Disconnect Function			
Connect Function			
TRA Reset Operations	15-155		
Hardware Reset Function			
Programmed Reset Function			
Reset TIC Function			

Contents

CHAPTER 1. INTRODUCTION

User Application Network (Part 1 of 2)	1-010	Transmission and Token-Ring Subsystem (Part 1 of 5)	1-050	Maintenance Philosophy (Part 1 of 2)	1-070
Communication Controller		Packaging		Concurrent Maintenance	
Interfaces		Board Characteristics (3725/3726)		Repair Action in Case of Solid Error	
Channel Interface		Board Characteristics (3725 Model 2)		Box Error Record (BER) Description	
User Application Network (Part 2 of 2)	1-011	LAB Numbering		Tentative Repair Action	
Transmission Interface		Redrive (RDV)		(Intermittent Error)	
Data Circuit-Terminating Equipment		Communication Scanner Processor (CSP)		Additional BER Information	
Data Terminal Equipment		CSP Modularity (3725/3726)		No FRU Isolated	
Channel/Link-Attached Controller		CSP Modularity (3725 Model 2)		Maintenance Philosophy (Part 2 of 2)	1-071
Controller General Description (Part 1 of 4)	1-020	Transmission and Token-Ring Subsystem (Part 2 of 5)	1-051		
Controller Organization		Front-End Scanner (FES)			
Control Subsystem (CSS)		FES Modularity (3725/3726)			
Transmission Subsystem (TSS)		FES Modularity (3725 Model 2)			
Token Ring Subsystem (TRSS)		Communication Scanner (CS)			
Maintenance and Operator Subsystem (MOSS)		Functions			
Configurations		Scanner and TRA Modularity (3725/3726)			
Single-Frame Configurations: 3725 Model 2		Scanner and TRA Modularity			
3725 Model 2 Block Diagram		Scanner Modularity (3725 Model 2)			
3725 Model 2 Block Diagram		Scanner Performance (both Models)			
Controller General Description (Part 2 of 4)	1-021	Line Operating Modes			
Single-Frame Configurations: 3725 Model 1		Normal Mode			
3725 Model 1 Block Diagram		Character Mode			
Controller General Description (Part 3 of 4)	1-022	Burst Mode			
Two-Frame Configuration: 3725/3726		Service Mode			
3725 Model 1/3726 Block Diagram		Transmission and Token-Ring Subsystem (Part 3 of 5)	1-052		
Controller General Description (Part 4 of 4)	1-023	Internal Clock Card (ICC)			
Programming Support for the 3725		ICC Modularity (3725/3726)			
Network Control Program		ICC Modularity (3725 Model 2)			
Emulation Program		LIC/ICC Compatibility			
Partitioned Emulation Programming		Limitations			
(PEP) Extension		Line Interface Coupler Card (LIC)			
Programming Support for the Host		LIC Weight			
Program Generation		LIC Modularity			
Network Configuration Changes		Speed Mixing on LIC			
Reliability, Availability,		Transmission and Token-Ring Subsystem (Part 4 of 5)	1-053		
and Serviceability		LIC Type 1 (LIC1)			
Data Flow	1-030	LIC Type 2 (LIC2)			
Control Subsystem (Part 1 of 2)	1-040	LIC Type 3 (LIC3)			
Central Control Unit (CCU)		LIC Type 4A (LIC4A)			
Machine Instructions		LIC Type 4B (LIC4B)			
Interrupt System		Transmission and Token-Ring Subsystem (Part 5 of 5)	1-054		
Cycle Steal Mechanism		Token Ring Adapter (TRA)			
Main Storage		Functions			
Functional Organization		TRA Modularity			
Storage Size		Limitations			
Control Subsystem (Part 2 of 2)	1-041	Token Ring Multiplexer (TRM) Card			
Local Storage		Token Ring Interface Coupler Card (TIC)			
Channel Adapter		TIC Weight			
Packaging (3725/3726)		TIC Type			
Packaging (3725 Model 2)		Maintenance and Operator Subsystem	1-060		
Board Characteristics (3725/3726)		MOSS Processor Storage and Microcode			
Board Characteristics (3725 Model 2)		Adapters			
Channel Adapter Driver Receiver		CCU Adapter			
Two-Processor Switch		Diskette Adapter			
Channel Interface		Controller Diskette			
Channel-to-CCU Interconnection		Service Diskette			
Redrive		Control Panel			
Channel Operation		Operator Console			
Channel Adapter Addressing					
Channel Adapter Modularity (3725/3726)					
Channel Adapter Modularity (3725 Model 2)					

User Application Network (Part 1 of 2)

A user application network (also called a "user network") is a configuration of data processing products, such as processors, controllers, and terminals, for the purpose of data processing and information exchange. This configuration may use circuit-switched, packet-switched, and leased-circuit services provided by common carriers or by post telephone and telegraph (PTT) administrations.

COMMUNICATION CONTROLLER

In the user network, the IBM 3725 Communication Controller and IBM 3726 Communication Controller Expansion control the data transfers between the host processor (hereafter called the "host") and the terminals. The controller comprises:

- A base unit: the IBM 3725 Communication Controller
- An expansion unit (optional): the IBM 3726 Communication Controller Expansion

In this manual, the 3725 with its 3726 expansion is called the "controller", or the "3725" when compared with other communication controllers.

The controller exchanges data with the host at high speed, and with the terminals at speeds adapted to the transmission lines. It also handles line protocols and error detection and reporting.


INTERFACES

The controller has two network interfaces:

- Channel interface
- Transmission interface

Channel Interface

The channel interface is the interface between the controller and the host processor(s). Several hosts may be attached to the same controller via multiple channel connections.



User Application Network (Part 2 of 2)

Transmission Interface

The transmission interface is the interface between the controller and the user network. The controller can communicate with a wide range of terminals using asynchronous or synchronous transmission, with different line speeds (from 50 bps through 256 000 bps), and with different protocols. (start/stop, BSC, SDLC, and token ring protocol).

The controller may attach via the transmission interface:

- Data circuit-terminating equipment (DCE)
- Data terminal equipment (DTE)

Data Circuit-Terminating Equipment

The DCE, a modem for example, establishes, maintains, and releases the connection, and provides for signal conversion between the controller and the transmission line. Another DCE is needed at the remote end of the line to provide the symmetrical functions between the line and the DTE or link-attached controller.

Data Terminal Equipment

The DTE serves as a data receiver, data transmitter, or both, and provides for the data communication control function according to protocols. The DTE is remote when connected to the controller through a transmission line via DCEs or the IBM Token-Ring Network. It is direct attached when connected to the controller without a DCE.

Channel/Link-Attached Controller

A controller may be attached to the host processor in two ways:

- Via a channel adapter
- Via a telecommunication line connected to the host via another controller

A controller that is attached to a host processor via a channel adapter is called a channel-attached (or local) controller. For example, controller 1 in the accompanying figure is channel-attached to hosts 1 and 2.

A controller that is attached to a host processor via a telecommunication line and another controller is called a link-attached (or remote) controller. For example, controller 2 is link-attached to hosts 1 and 2. In an SNA network, a transmission line connecting two controllers is called a cross-domain link.

A controller may be channel-attached to one host, and link-attached to another. For example, controller 3 is channel-attached to host 3 and link-attached to hosts 1 and 2. The type of attachment for a controller must be specified with respect to a particular host.

Controller General Description (Part 1 of 4)

The 3725 expands IBM's communication controller family, and:

- Preserves compatibility with existing 3704/3705 Communications Controllers
- Increases performance by a higher throughput and greater storage capacity
- Improves attachment capabilities
- Provides an operator console (the IBM 3727 Console with its display and keyboard features) for operator interface and maintenance functions
- Simplifies the machine structure
- Uses new versions of the network control program and the emulation program
- Complements and enhances communication network management
- Improves the reliability, availability, and serviceability (RAS)

CONTROLLER ORGANIZATION

The controller is organized in four functional subsystems each equipped with processors:

- Control subsystem (CSS)
- Transmission subsystem (TSS)
- Token Ring Subsystem (TRSS)
- Maintenance and operator subsystem (MOSS)

Control Subsystem (CSS)

The control subsystem (CSS) controls the data transfers over the channel interface and executes the control program. It is composed of the central control unit (CCU) with its associated storage, and zero to six channel adapters. The maximum number of channel connections is eight.

Transmission Subsystem (TSS)

The transmission subsystem (TSS) controls the data transfer over the transmission interface. It is packaged in up to eight line attachment boards (LABs). Each board includes one or two scanning processors (communication scanners) and the necessary circuits to attach up to 32 lines. The maximum number of lines that may be attached to a controller is 256.

Token Ring Subsystem (TRSS)

The TRSS has the capability to attach one or several token-ring native terminals to the SNA network thru the 3725 in native mode. The TRSS controls the data transfer over the IBM Token-Ring Network. The TRSS may have up to two token ring adaptors (TRA) and up to eight ring interfaces for 3725 Model 1 with 3726 attached (one TRA in 3725 Model 1 and one TRA in 3726 or 2 TRAs in 3726). Only one TRA (4 ring interfaces) may be installed on a 3725 Model 1 without expansion or on a 3725 Model 2. The TRA is packaged in LAB type C and shares the board with one scanner.

Maintenance and Operator Subsystem (MOSS)

The maintenance and operator subsystem (MOSS) provides the operating and service facilities to the customer's operator and to the customer engineer (CE). The MOSS includes a processor and storage, a diskette drive, a control panel, and their adapters.

A primary operator console (the IBM 3727 Console with its display and keyboard features) is attached to the MOSS. Optionally, an alternate operator console can be installed, in addition to the primary one.


CONFIGURATIONS

Single-Frame Configurations: 3725 Model 2

The 3725 Model 2 configuration consists of the 3725 Model 2 frame, the primary console, and optionally, an alternate console. The 3725 Model 2 frame contains:

- The central control unit (CCU)
- The storage (512K through 3072K bytes by increments of 256K)
- The MOSS
- Up to four channel adapters
- From one to 80 duplex and/or half-duplex telecommunication lines
- Up to four token ring transmission interfaces (one TRA)

3725 Model 2 Block Diagram




Controller General Description (Part 2 of 4)

Single-Frame Configurations: 3725 Model 1

A single-frame configuration consists of the 3725 Model 1, the primary operator console, and, optionally, an alternate console. The 3725 Model 1 frame contains:

- The central control unit (CCU)
- The storage (512K through 3072K bytes by increments of 256K)
- The MOSS
- Zero, one, or two channel adapters
- Zero, one, or two two-processor switches
- From one to 96 duplex and/or half-duplex telecommunication lines
- Up to four token ring transmission interfaces (one TRA).

3725 Model 1 Block Diagram




Controller General Description (Part 3 of 4)

Two-Frame Configuration: 3725/3726

3725 Model 1/3726 Block Diagram

The two-frame configuration consists of the 3725 Model 1, the 3726, the primary operator console, and, optionally, an alternate operator console. The 3726 frame contains:

- Up to four additional channel adapters (total for the controller: six channel adapters)
- Up to two additional two-processor switches
- Up to 160 additional transmission lines (total for the controller: 256 lines)
- Up to two token-ring adapters (TRAs) and up to eight token-ring transmission interfaces (four per TRA).



- Legend:**
- CCU : Central Control Unit
 - CSS : Control Subsystem
 - IOC : Input/Output Control
 - MOSS: Maintenance and Operator Subsystem
 - TSS : Transmission Subsystem
 - TRA : Token Ring Adapter
 - TRSS: Token Ring Subsystem

Controller General Description (Part 4 of 4)

PROGRAMMING SUPPORT FOR THE 3725

The control program that runs in the CCU may be:

- Advanced Communications Function for Network Control Program (ACF/NCP) Version 2 or 3
- Emulation Program for the IBM 3725 (EP/3725)
- Partitioned emulation programming (PEP) extension
- A program written by the customer

Network Control Program

Advanced Communication Functions for Network Control Program (ACF/NCP) Version 2 or 3 (called simply NCP in this manual) is an IBM licensed program product. NCP provides major capabilities for SNA user application networks with SDLC. However, NCP is not limited to SDLC devices, and existing start-stop and binary synchronous networks can be migrated to the 3725.

NCP works with the following access methods:

- ACF/Virtual Telecommunications Access Method (VTAM) Version 1 and 2
- ACF/Telecommunications Access Method (TCAM) Version 2

The network terminal option (NTO) is a licensed program product available to provide start-stop support for NCP in the 3725.

NCP supports the communication network management (CNM) concept when operating with the following IBM licensed programs:

- Network Communication Control Facility (NCCF)
- Network Problem Determination Application (NPDA)
- Network Logical Data Manager (NLDM)

In the 3725, the communication network management is supported by sending failure messages called alerts from the MOSS to the host for display. For most failures, these messages are sufficiently explicit so that the customer can take the appropriate corrective action. Similar messages, called alarms, are sent to the operator console of the controller.

Emulation Program

The Emulation Program for the 3725 (EP/3725, called simply EP in this manual) emulates most of the functions of the IBM, 2701 Data Adapter Unit, 2702 Transmission Control, or 2703 Transmission Control, and can communicate with various access methods running in the host. EP can run only in a channel-attached controller. When EP is used, the host must provide a separate subchannel for each line.

EP works with the following access methods:

- Telecommunications Access Method (TCAM)
- Basic Telecommunications Access Method (BTAM)
- BTAM Extended Support (BTAM-ES)

Partitioned Emulation Programming (PEP) Extension

The partitioned emulation programming (PEP) extension, in addition to performing the usual NCP functions, allows designated lines of the 3725 to operate as a 2701, 2702, or 2703, or any combination of the three. Most programs written for these machines can operate in the 3725 without modification. However, programs that involve timing or special hardware considerations may have to be changed. The PEP is the Network Control Program and Emulation Program merged into one. Most of the code in these two programs remains the same as in their stand-alone versions. However, some program functions are identical and shared. These functions are:

- Level 1, 2, and 3 routers
- Timer
- Channel adapter
- Panel routines
- Direct-addressable storage
- RAS procedures in levels 1 and 4
- Access method line trace routines

Requests that are directed to EP subchannels are handled in the same way as in the stand-alone emulation program. The NCP level 3 router directs initial selection interrupts to the EP initial selection routine, and data service interrupts to the EP data service routine.

PROGRAMMING SUPPORT FOR THE HOST

A number of IBM system support programs (SSPs) are available. They are executed in the host and are used to:

- Generate the control programs
- Load them into the controller
- Dump the controller storage on the host printer
- Transfer diskette files to the host

Program Generation

The control program is generated from standard program modules using the SYSGEN procedure in accordance with the controller configuration required. Several control programs can be generated to handle different subsets of lines attached to the same controller.

The control program for the CCU is kept as a data set on the host storage, but the microcodes for the scanners and MOSS processor are kept as data sets on the diskette.

Network Configuration Changes

The host may issue special commands to the control program to make changes in the network configuration by:

- Adding or deleting SDLC lines
- Adding or deleting terminals or cluster controllers, for example

An option of PEP is the ability to operate the same transmission line alternately in NCP mode or EP mode. The change from one mode to the other is made during program execution via commands sent from the access method.

For terminals and line protocols having no IBM support, the user must provide the routines and incorporate them into the control program.

RELIABILITY, AVAILABILITY, AND SERVICEABILITY


The controller hardware, control program, CNM programs (when installed), and MOSS work together to provide a high degree of reliability, availability, and serviceability. The following main features contribute to this:

- LSI technology with high reliability.
- Functional building block design.
- Storage protection mechanisms.
- Error detection and correction codes on CCU main storage and scanners.
- Fault checking logic.
- Error retries by the microcode.
- Interactive console facilities for the customer and the CE.
- Removable MOSS diskettes to make engineering changes and diagnostics easier. The diskettes also store error messages, microcode, initial program load (IPL) code, and other files.
- Alert messages to the host processor and alarm messages to the console.
- Host-independent problem isolation for most hardware failures.

Data Flow

Note 1: As the CLAB and the CL2B boards are split into two parts in this figure, one for the channel adapter and one for the scanner, the redrive (RDV) function is shown twice for clarity. However, there is one RDV per CLAB or C2LB board.

Note 2: LAB Pos. 3 to 8 organization if LAB type C installed




Legend:

----- Clock signals
 _____ Data/control signals

Legend

- ALU arithmetic and logic unit
- BSMI basic storage module interconnection
- BTAC branch trace/address compare
- CAB channel adapter board
- CADR channel adapter driver receiver
- CCIN channel-to-CCU interconnection
- CHIN channel interconnection
- CCU central control unit
- CCUB CCU board
- CLAB channel and line attachment board
- C2LB2 channels (two) and line attachment board 2
- C2LB channels (two) and line attachment board
- CSP communication scanner processor
- CSS control subsystem
- CVTL card - vendor transistor logic
- ECC error checking and correction
- FES front-end scanner
- ICC internal clock card
- IOC input/output control
- LAB line attachment board
- LIC line interface card
- MCC MOSS control card
- MIOC MOSS input/output control
- MMB memory and MOSS board
- MOSS maintenance and operator subsystem
- RDV redrive
- TPS two-processor switch (feature)
- TRA token ring adapter
- TSS transmission subsystem
- TRSS token ring subsystem



Control Subsystem (Part 1 of 2)

The control subsystem (CSS) consists of the following main components:

- Central control unit (CCU)
- Storage
- Programming support
- Channel adapters (CAs)

CENTRAL CONTROL UNIT (CCU)

The central control unit (CCU) is an interrupt-driven processor with a stored program (called the "control program" in this manual) that controls the data transfers on the channel and transmission interfaces. The central control unit board (CCUB) includes:

- Data flow, local store, controls, arithmetic and logic unit (ALU), branch trace/address compare (BTAC)
- CCU clock
- Input/output control (IOC) for transfer of controls and data to and from the channel adapters and scanners via the IOC bus
- MOSS input/output control (MIOC) for transfer of controls and data to and from the MOSS

Machine Instructions

The instruction set consists of 53 instructions. Two of these (IOH and IOHI) are new with respect to the 3704/3705 instruction set, and are designed to manage I/O operations on the IOC bus (see Chapter 10 for details). Of the 51 remaining instructions, all but three are compatible with the 3704/3705 instruction set at both source and object code level. The three exceptions are compatible at source code level only.

Most of the machine instructions are register-oriented, and use two registers, or a register and immediate data, or a register and a storage position.

Interrupt System

The controller has four interrupt levels (numbered 1 through 4), a base level numbered 5, and 128 external registers (numbered X'00' through X'7F'). The first 40 registers are called the 'general registers'. They are associated, eight-by-eight, to the five program levels, and reflect at any time the contents of the instruction address register (IAR) and the seven working registers of the current program level.

Should an interrupt of higher priority be requested, the usual housekeeping before entering the higher program level is already performed. When the level is re-entered, the eight corresponding general registers are transferred into the IAR and working registers, so that the processing resumes where it left off.

- Level 1 handles those situations requiring the most urgent attention: errors and requests for IPL.
- Level 2 handles program-controlled interrupts (PCIs) for line handling, data transfer, and MOSS diagnostics.
- Level 3 handles the interrupts from the channel adapters, timers, and control panel. It also handles PCIs for transmission processing that can be deferred from level 2.
- Level 4 handles PCIs for overall management of system resources, buffer management, queue manipulation, and dispatching of level 5 tasks. It also handles interrupts from the MOSS.
- Level 5 is the background level of the controller. It executes all the low-priority, non-time-dependent functions of the controller, such as line management, data and message handling, control command decoding and execution, and block handling routines, as well as most SNA functions.


I/O commands are executed on levels 2, 3, and 4. Attempts to execute I/O commands on level 5 result in an I/O error.

MAIN STORAGE


The main storage contains the control program. It is packaged on the memory and MOSS board (MMB) and is controlled by a storage control (SCTL) card and an error checking and correction (ECC) card, which corrects single-bit errors, and signals double-bit errors on storage words. The MMB includes a clock to distribute timing to the channel adapters and scanners via the redrive (RDV) cards.

The storage address register is 22 bits long. The read cycle time is 400 ns and the write cycle time is 600 ns.

The storage word consists of 4 bytes referenced as follows:



FUNCTIONAL ORGANIZATION



Parts of the storage may be protected against write operation by read-only keys set during initialization. A program level trying to write in a read-only segment causes an address exception (except for the MOSS, which may write anywhere in the storage).

Storage Size

The storage is from 512K through 3072K bytes by increments of 256K.

Cycle Steal Mechanism

The cycle steal mechanism is an adapter initiated operation (AIO). It avoids the overhead caused by data transfers between the host and the CCU storage, and between the CCU storage and the scanners. Cycle stealing transfers data without involving the processing of the control program.

Control Subsystem (Part 2 of 2)

LOCAL STORAGE

The local storage contains the external registers. It includes the 40 general registers, but not registers X'70' through X'7F' which are CCU hardware registers.

CHANNEL ADAPTER

Packaging (3725/3726)

The channel adapters are packaged on one of the following types of board, via the RDV logic:

- Channel and line attachment board (CLAB1 and CLAB2)
- Channel attachment board (CAB)

Packaging (3725 Model 2)

- On the 3725 Model 2 two channel adapters are packaged on each of the following boards: the C2LB and the C2LB2.

Inside a board, a channel adapter is composed of the following cards:

- One channel adapter driver receiver (CADR)
- Channel interface (CHIN)
- Channel-to-CCU interconnection (CCIN)
- Additional functions to CHIN and CCIN (CVTL)

Board Characteristics (3725/3726)

One channel adapter and one line attachment base for up to 32 lines are packaged on each CLAB (1 and 2). The CLABs are packaged in the 3725.

Up to four channel adapters (and no line attachment base) are packaged on the CAB. The CAB is packaged in the 3726.

Board	Channel Adapter	TPS	Channel Connections
CLAB1	1	0 or 1	1 or 2
CLAB2	1	0 or 1	1 or 2
CAB	1 to 4	0 to 2	1 to 4

Board Characteristics (3725 Model 2)

One or two channel adapters and one line attachment for up to 24 lines are packaged on the C2LB and C2LB2 boards.

Board	Channel Adapter	TPS	Channel Connections
C2LB	1 to 2	None	1 or 2
C2LB2	1 to 2	None	1 or 2

Channel Adapter Driver Receiver

Each channel adapter is equipped with a channel adapter driver receiver (CADR) that drives and receives the channel cable signals.

Two-Processor Switch

The two-processor switch (TPS) is a feature of the channel adapter that provides a second CADR card to attach a second channel. With the TPS, the channel adapter can attach either:

- Two channels of the same host, or
- One channel of one host and one channel of another host

However, only one channel connection is active at any one time.

Up to four TPSs may be installed to give up to eight channel connections; the last two TPSs are mutually exclusive to channel adapters 5 and 6.

Channel Interface

The channel interface (CHIN) card includes the necessary logic to:

- Decode commands and addresses received from the host via the channel
- Buffer the data received from or transmitted to the host
- Control the channel tags, the clock, and the timeouts
- Detect errors

Channel-to-CCU Interconnection

The channel-to-CCU interconnection (CCIN) card includes the necessary logic to:

- Control PIO operations with the CCU via the IOC bus
- Control cycle stealing by adapter initiated operation (AIO) with the CCU via the IOC bus
- Control the internal timing, and the CCU and channel bids
- Perform the autoselect function with the other channel adapters
- Detect errors

Redrive

The redrive (RDV) card connects the IOC bus and repowers the bus signals at the entrance to the board.

Channel Operation

With NCP, the channel adapter attaches to a byte-multiplex, block-multiplex, or selector channel. With EP, the channel must be byte-multiplex.

The channel adapter interacts with the CCU by means of:

- Program-initiated operation (PIO) to transfer commands and data between the CCU storage and the channel adapter registers.
- Adapter-initiated operation (AIO) to provide high-speed data transfer in cycle steal between channel adapter and CCU storage.
- Interrupts initiated from the channel adapter to signal an event to the CCU. Interrupt level 1 is used for errors and level 3 for normal operation.

PIO and AIO are initiated by IOH/IOHI instructions.

Channel Adapter Addressing

Each of the six channel adapters is separately addressable from the controller. NCP requires only one subchannel to a host for all traffic; EP requires one subchannel per line controlled.

Channel Adapter Modularity (3725/3726)

For a channel-attached controller, the minimum configuration corresponds to one channel adapter (CA position 1 or CA-1) included in CLAB1. CA-1 may have a TPS feature (TPS-1).

CA-2 is implemented in CLAB2 and may have a TPS feature (TPS-2).

The other channel adapters, CA-3 through CA-6, are implemented in the CAB. CA-3 and CA-4 may each have a TPS feature (TPS-3 and TPS-4 respectively). When TPS-3 is installed, CA-6 is not installed. When TPS-4 is installed, CA-5 is not installed.

The maximum number of channel adapters is six, and the maximum number of channel connections with TPS installed is eight. However, with a TPS, only one of the channels connected to the channel adapter may be active at any given time.

Unit	Board	Channel Adapter Position	Channels (Total)	
			W/o TPS	With TPS
3725	CLAB1 CLAB2	1	1	2
		2	2	4
3726	CAB	3	3	6
		4	4	8
		5	5	None
		6	6	None

Channel Adapter Modularity (3725 Model 2)

For a channel-attached controller, the minimum configuration corresponds to one channel adapter (CA position 1 or CA-1). An additional channel adapter (CA position 2) can be installed in the C2LB board. Two channel adapters may be installed on the C2LB2 board. No TPS feature is available for the two channel adapters.

Unit	Board	Channel Adapter Position	Channels (Total)	
			W/o TPS	With TPS
3725 Mdl 2	C2LB C2LB2	1 and 2	2	None
		3 and 4	4	None

Transmission and Token Ring Subsystem (Part 1 of 5)

PACKAGING

The line attachments are packaged in one of the following types of board:

- Channel and line attachment board (CLAB)
- Line attachment board type A (LABA)
- Line attachment board type B (LABB)
- Line attachment board type C (LABC)

Each board type A or B includes the following cards:

- Redrive (RDV) card
- Communication scanner processor (CSP1 and 2) cards
- Communication scanner storage (CSM) card
- Front-end scanner (FES) card
- Line interface card (LIC)
- Optionally, internal clock cards (ICC)
- For LAB type C, in addition, the token-ring adapter (TRA) includes a TRM card and up to four TIC cards.

Board Characteristics (3725/3726)

One or two channel adapters and one line attachment base for up to 32 lines are packaged on CLAB1 and CLAB2. A LAB type A includes one line attachment with a single scanner; a LAB type B includes one line attachment with two scanners. A LAB type C includes one line attachment with one scanner and one TRA (neither type of LAB includes a channel adapter).

Board	Number of				
	Scanner	TRA	LICs	ICCs	TICs
CLAB1	1	0	1 to 8	0 or 2	0
CLAB2	1	0	1 to 8	0 or 2	0
LABtypeA	1	0	1 to 8	0 or 2	0
LABtypeB	2	0	1 to 8	0 or 2	0
LABtypeC	1	1	1 to 4	0 or 1	1 to 4

Board Characteristics (3725 Model 2)

One or two channel adapters and one line attachment for up to 24 lines are packaged on the C2LB and the C2LB2. Board characteristics for LAB type A, B, or C are as shown for the 3725/3726.

Board	Number of				
	Scanner	TRA	LICs	ICCs	TICs
C2LB	1	0	1 to 6	2	0
CLAB2	1	0	1 to 6	0 or 2	0
LABtypeA	1	0	1 to 8	0 or 2	0
LABtypeB	2	0	1 to 8	0 or 2	0
LABtypeC	1	1	1 to 4	0 or 1	1 to 4

LAB Numbering

Because CLAB1 and CLAB2 include one line attachment base each (equivalent to LAB type A position 1 and LAB type B position 2 respectively), the LABs are numbered from LAB type A, B or C position 3 (LABx-3) through LAB type A, B or C position 8 (LABx-8). For the 3725 Model 2, only one LAB exists: the LABx-3.

REDRIVE (RDV)

The redrive (RDV) card connects the IOC bus and repowers the bus signals at board entry.

COMMUNICATION SCANNER PROCESSOR (CSP)

The communication scanner processor (CSP) is loaded with microcode that controls the connected lines. The microcode is loaded from the diskette during IPL. Error checking and correction are included in the CSP storage circuits.

The CSP interacts with the CCU via the IOC bus by means of:

- Program-initiated operation (PIO) to transfer commands from the CCU to the CSP.
- Adapter-initiated operation (AIO) to provide high-speed data transfer in cycle steal between the CCU and CSP storage.

Interrupts initiated from the CSP to signal an event to the CCU. Interrupt level 1 is used for errors and level 2 for normal operation.


PIO and AIO are initiated by IOH/IOHI instructions.

CSP Modularity (3725/3726)

Number of CSPs per CLAB1 : 1
 Number of CSPs per CLAB2 : 1
 Number of CSPs per LAB type A : 1
 Number of CSPs per LAB type B : 2
 Number of CSPs per LAB type C : 1
 Total number of CSPs : 14 maximum

CSP Modularity (3725 Model 2)

Number of CSPs per C2LB : 1
 Number of CSPs per C2LB2 : 1
 Number of CSPs per LAB type A : 1
 Number of CSPs per LAB type B : 2
 Number of CSPs per LAB type C : 1
 Total number of CSPs : 4 maximum



Transmission and Token Ring Subsystem (Part 2 of 5)

FRONT-END SCANNER (FES)

One front-end scanner (FES) is associated with each CSP to form a 'scanner'. It consists of hardware only.

FES Modularity (3725/3726)

Number of FESs per CLAB1 : 1
 Number of FESs per CLAB2 : 1
 Number of FESs per LAB type A: 1
 Number of FESs per LAB type B: 2
 Number of FESs per LAB type C: 1
 Total number of FESs : 14 maximum

FES Modularity (3725 Model 2)

Number of FESs per C2LB : 1
 Number of FESs per C2LB2 : 1
 Number of FESs per LAB type A: 1
 Number of FESs per LAB type B: 2
 Number of FESs per LAB type C: 1
 Total number of FESs : 4 maximum

COMMUNICATION SCANNER (CS)

Each communication scanner (CS) is made up of one CSP and one FES.

Functions

The main functions of a scanner are to:

- Provide buffers for the transmitted or received data, and control the transfers to the CCU
- Support start-stop, BSC, SDLC, auto-call, and X.21 protocols
- Control the transmission interface of the controller
- Provide service facilities
- Serialize/deserialize the transmitted and received characters
- Manage the line services

Scanner and TRA Modularity (3725/3726)

The minimum controller configuration corresponds to one scanner (scanner position 1) included in CLAB1. The other scanners (scanner position 3 and scanner positions 5 through 16) are optional. Scanner positions 2 and 4 do not exist, so that the maximum number of scanners is 14.

Scanner and TRA Modularity:

Unit	Board	Scanner Position		LAB Type C		Lines (Max)
		any CLAB LAB type A	LAB type B	CS	TRA	
3725	CLAB1	1	N/A	N/A	N/A	32
	CLAB2	3	N/A	N/A	N/A	64
	LABPos3	5	5/6	5	6	96
3726	LABPos4	7	7/8	7	8	128
	LABPos5	9	9/10	9	10	160
	LABPos6	11	11/12	11	12	192
	LABPos7	13	13/14	13	14	224
	LABPos8	15	15/16	15	16	256

Scanner Modularity (3725 Model 2)

The controller configuration corresponds to one scanner (scanner position 1) included in C2LB.

Unit	Board	Scanner Position		LAB Type C		Lines (Max)
		C2LB and C2LB2 LAB type A	LAB type B	CS	TRA	
3725 Mod. 2	C2LB	1	N/A	N/A	N/A	24
	C2LB2	3	N/A	N/A	N/A	48
	LABPos3	5	5/6	5	6	80

Scanner Performance (both Models)

Depending on the protocols and transmission speeds, the scanner can handle the following number of lines:

Protocol	Speed (bps)	Number of Lines
SDLC duplex	4 800	32
	9 600	16
	64 000	4
	128 000	2
SDLC half duplex	256 000	1
	9 600	32
	64 000	4
BSC EBCDIC	128 000	2
	64 000	4
BSC ASCII	9 600	32
	4 800	16
	64 000	4
BSC (Character Mode)*	1 200 or less	8 half-duplex
Start-stop (Character Mode)*	300	32 half-duplex
	600	20 half-duplex
	1 200	8 half-duplex
Start-stop (Burst Mode)	1 200	32 half-duplex
	2 400	16 half-duplex
	4 800	8 half-duplex
	9 600	4 half-duplex
	19 200	2 half-duplex
ALC	2 400	16 duplex
	4 800	8 duplex
	9 600	4 duplex
	14 400	3 lines/per LIC
Line Control	19 200	2 lines/per LIC

* After microcode EC 873051, character mode for tributary station is no longer necessary; BURST mode may be used instead.

LINE OPERATING MODES

The microcode operates the lines in normal mode, character mode, or service mode.

The operating mode is selected on a line-by-line basis and the scanner may run all three modes at the same time.

Normal Mode

The microcode normally uses this mode to transfer data using messages (several characters) in a burst.

Character Mode

This mode is similar to the operating mode of the communication scanner type 2 of the 3705 which transfers data character by character.

Burst Mode

This mode allows data transfer by bursts of up to four characters.

Service Mode

In service mode, the scanner executes the commands sent from the MOSS. The scanner may be connected to NCP or disconnected from NCP.

Transmission and Token Ring Subsystem (Part 3 of 5)

INTERNAL CLOCK CARD (ICC)

The internal clock card ICC type 1 or 2 may provide through the LICs, the clock control for internal and external clocked DTE (S/S, BSC, and SDLC protocols). At plant the speed is set to 9600 bps; and at installation time, it may be changed by the CE on a per-LIC basis.

(For details see the following diagram).

Type of Operation	Direct or Local-attached of DTE		DCE Attachment of DTE		
	Internal Clocking **	External Clocking ***	Internal Clocking **	External Clocking	
Start/Stop	50 75* 100* 110 134.5 200 300 600 1200 2400* 4800* 9600* 19200* bps	2400 4800 9600 19200	50 75* 100* 110 134.5 200 300 600 1200 2400* 4800* 9600* 19200* bps		N/A
Synchronous	50 110 134.5 200 300 600 1200 bps (BSC only)	2400 4800 9600 19200 5600 245760* bps (BSC and SDLC)	50 110 134.5 200 300 600 1200 bps		N/A

* Additional speeds provided by ICC-2 card.

** The selection of the clock speeds may be done by software at generation time or by hardware (Jumper).

*** The selection of the clock speeds may be done only by hardware (Jumper).

ICC Modularity (3725/3726)

Number of LICs per ICC : 4 maximum
 Number of lines per ICC : 16 maximum
 Number of ICCs per LAB : 2 maximum
 Number of ICCs per CLAB : 2 maximum

ICC Modularity (3725 Model 2)

(For C2LB and C2LB2 boards)
 Number of LICs for two ICCs : 6 maximum
 Number of lines for two ICCs: 24 maximum
 Number of ICCs per board : 2
 (For LAB3 board)
 Number of LICs per ICC : 4 maximum
 Number of lines per ICC : 16 maximum
 Number of ICCs per LAB : 2 maximum

LIC/ICC Compatibility

LIC Type	DTE clocking	Direct-Attached Terminal
1	Allowed with ICC (up to 19 200 bps)	Allowed with ICC (up to 19 200 bps)
2	Not allowed	Not allowed
3	Not allowed	Allowed with ICC (up to 245 760 bps)
4A	Not allowed	Allowed with ICC (up to 9600 bps)
4B	Not allowed	Allowed with ICC (up to 245760 bps)

Limitations

If the transmission speed of any of the lines connected to a scanner exceeds 9600 bps, the maximum number of LICs for that scanner is 4.

LINE INTERFACE COUPLER CARD (LIC)

One line interface card (LIC) attaches up to four lines to the controller. There are several types of LICs depending on the different transmission interfaces (see Chapter 4 for descriptions of the physical interfaces). Most types of LICs may attach either:

- A DCE (transmission line attachment), or
- A DTE (direct attachment)

LIC Weight

The weight of a LIC is a value (12 through 100) that represents the percentage of scanner occupation. The sum of the weights of all the LICs connected to a scanner must be equal to or less than 100. Several types of LIC may be mixed in the same scanner. On a LIC with several ports (line connections), the weight of the LIC is determined by the speed of the 'heaviest' line. The weights for each LIC type are given in the following tables:

Example 1:

A scanner equipped with eight LICs type 1 with weight = 12 (32 half-duplex lines at 9600 bps) has a total weight of 96.

Example 2:

A scanner equipped with two LICs type 1 with weight = 50 (eight duplex lines at 19 200 bps) has a total weight of 100.

Example 3:

A scanner equipped with one LIC type 2 with weight = 100 (one duplex line at 230 400 bps) has a weight of 100.

LIC Modularity:

Number of lines per LIC : 4 maximum
 Number of LICs per LAB : 8 maximum
 Number of lines per LAB : 32 maximum
 Number of LICs per C2LB/C2LB2 : 6 maximum
 Number of lines per CLAB/C2LB2: 24 maximum
 Number of LICs per CLAB : 8 maximum
 Number of lines per CLAB : 32 maximum

Speed Mixing on LIC

Terminals with different transmission speeds may be connected to the same LIC, with the following exception: if several direct-attached terminals are connected to the same LIC, their transmission speeds must be identical.

Transmission and Token Ring Subsystem (Part 4 of 5)

LIC Type 1 (LIC1)

Line interfaces : V.24 (RS-232C) and V.25 autocall (RS-366)
 Transmission speed: Up to 19 200 bps
 Number of lines : Up to four
 Transfer mode : Half-duplex or duplex
 Protocols : Start-stop, BSC, SDLC
 DTE clocking : Allowed with ICC (up to 19 200 bps)
 Direct attachment : Allowed with ICC (up to 19 200 bps)
 LAB type : A, B, or C

Weight:

Protocol	Max Speed (bps)	Weight
Autocall	N/A	12
SDLC duplex	4 800	12
	9 600	25
	14 400	42
	19 200	50
SDLC half-duplex	9 600	12
	14 400	25
	19 200	25
BSC EBCDIC	9 600	12
	14 400	25
	19 200	25
BSC ASCII	4 800	12
	9 600	25
	14 400	37
	19 200	50
BSC (Character Mode)(5)	1 200	42
Start-stop (Burst Mode)	1 200	12
	2 400	25
	4 800	50
	9 600	100
	14 400	100
Start-stop (Character Mode)*	300	12
	600	18
	1 200	37
ALC duplex	2 400	25
	4 800	50
	9 600	100
	14 400	100 (2)
	19 200	100 (1)

Notes:

1. Only two ports per LIC1 are used at 19 200 bp
2. Only two ports per LIC1 are used at 14 400 bp
3. Externally clocked DTEs.
4. At 14 400 bps only, two ports of the LIC type
5. After microcode EC 873051, character mode for longer necessary; BURST mode may be used inst

LIC Type 2 (LIC2)

Line interfaces : US wideband, services 5703/8803, 5701/8801, and 5751/5700

Transmission speed: Up to 230 400 bps

Number of lines : One
 Transfer mode : Half-duplex or duplex
 Protocols : BSC and SDLC
 DTE clocking : Not allowed
 Direct attachment : Not allowed
 LAB type : A, B, or C

Weight:

Protocol	Max Speed (bps)	Weight
SDLC half-duplex	64 000	25
	72 000	25
	128 000	50
	230 400	100
SDLC duplex	64 000	25
	128 000	50
	230 400	100
BSC EBCDIC	64 000	25
BSC ASCII	64 000	25

LIC Type 3 (LIC3)

Line interfaces : V.35 high-speed
 Transmission speed: Up to 256 000 bps
 Number of lines : One
 Transfer mode : Half-duplex or duplex
 Protocols : BSC and SDLC
 DTE clocking : Not allowed
 Direct attachment : Allowed with ICC (up to 245 760 bps)

LAB type : A, B, or C

Weight:

Protocol	Max Speed (bps)	Weight
SDLC half-duplex	64 000	25
	72 000	25
	128 000	50
	256 000	100
SDLC duplex	32 000	25
	64 000	25
	128 000	50
	256 000	100
BSC EBCDIC	64 000	25
BSC ASCII	64 000	25

LIC Type 4A (LIC4A)

Line interfaces : X.21 medium-speed
 Transmission speed: Up to 9600 bps
 Number of lines : Four
 Transfer mode : Half-duplex or duplex
 Protocol : SDLC
 DTE clocking : Not allowed
 Direct attachment : Allowed with ICC (up to 9600 bps)

LAB type : A, B, or C

Weight:

Protocol	Max Speed (bps)	Weight
SDLC half-duplex	9 600	12
SDLC duplex	4 800	12
	9 600	25

LIC Type 4B (LIC4B)

Line interfaces : X.21 high-speed
 Transmission speed: Up to 256 000 bps
 Number of lines : One
 Transfer mode : Half-duplex or duplex
 Protocol : SDLC
 DTE clocking : Not allowed
 Direct attachment : Allowed with ICC (up to 245 760 bps)

LAB type : A, B, or C

Weight:

Protocol	Max Speed (bps)	Weight
SDLC half-duplex	64 000	25
	72 000	25
	256 000	100
SDLC duplex	64 000	25
	256 000	100

Transmission and Token Ring Subsystem (Part 5 of 5)

TOKEN RING ADAPTER (TRA)

The token ring adapter (TRA) is a part of the token ring subsystem (TRSS) to support the IBM Token-Ring Network. The NCP Token-Ring Interconnection (NTRI) program is the program running in the CCU to support the IBM Token-Ring Network. Each TRA is made of one token ring multiplexer (TRM) card and up to 4 token ring interface coupler cards (TIC) to support up to four token ring transmission interfaces.

Functions


The main functions of the TRA are:

- Provide buffers for the command processor for the transmitted and received data.
- Serialize/deserialize the transmitted and received data.
- Control the token ring transmission to the token-ring network.
- Provide service facilities.

TRA Modularity

A TRA must be installed in a LAB type C board and share the board with one scanner. A LAB C board may be installed in any LAB position 3 to 8.

LAB 3 to 8 organization if LAB type C installed:



Limitations

3725/3726 Model 1

A maximum of 2 TRAs may be installed, giving up to 8 token ring transmission interfaces (8 TIC cards). One TRA may be installed in 3725 and one TRA in 3726 or 2 TRAs in 3726.

3725 Model 2

Only one TRA can be installed in a LAB C on LAB position 3 giving up to 4 token ring transmission interfaces (4 TIC cards).

Performance

No performance impact related to the number of token ring interface installed.

Characteristics

The token ring protocol is the protocol supported (4 Mbits per second).

TOKEN RING MULTIPLEXER (TRM) CARD

Manages the interface between the IOC bus and the different TIC cards. Converts PIO operation into MMIO operation.

TOKEN RING INTERFACE COUPLER CARD (TIC)

Each TIC card handles, with the help of in housed processor, the token ring transmission interface.

TIC Weight

No weight dependency.

TIC Type

Only one type.

Maintenance and Operator Subsystem

The MOSS contains the following main components:

- MOSS processor, storage, and microcode
- Adapters
- Diskette drive
- Control panel
- Operator console

MOSS PROCESSOR STORAGE AND MICROCODE

The MOSS processor and storage are packaged in the memory and MOSS board (MMB). The MOSS microcode is loaded from the diskette during IML.

The main functions of the MOSS are to:

- Provide the operator with functions for initialization of the controller and the line interfaces
- Support network problem determination through the host by generating alert messages to the host (NCP only) and alarm messages to the operator console, and by running diagnostics in the controller
- Maintain the controller files defining the machine configuration and parameters of the channel and line connections
- Retry automatically failing hardware or software, and re-IPL after nonrecoverable failure when possible
- Provide the CE with utility programs to dump the storages of the CCU, CSP, TIC, and MOSS
- Provide box error handling and recording

ADAPTERS

Adapters for the CCU, diskette drive, control panel, and operator console are packaged in the MMB.

CCU ADAPTER

The CCU adapter accepts commands from the MOSS processor in PIO mode. Data is passed between the MOSS and the CCU via shared storage areas (mailboxes).

DISKETTE ADAPTER

The diskette adapter accepts commands from the MOSS processor in PIO mode and data by direct storage access.

A diskette has two sides, 77 tracks per side, 26 sectors per track, and 256 bytes per sector, making a total of 1 million bytes of storage per diskette. The data transfer rate is 62.5 kbps and the average access time is 40 ms.

Two diskettes are needed:

- Controller diskette, for normal operation
- Service diskette, for maintenance in offline mode

A copy of each diskette is included as a spare in the shipping group. Their updating is under the responsibility of the CE, except for the customer's procedures and the configuration files.

Controller Diskette

The controller diskette contains the following files:

1. IPL checkout procedures
2. MOSS microcode
3. Controller load/dump program
4. Scanner microcode
5. IPL ports table
6. Box error record (BER) file (CHGCIL)
7. Configuration data file (CDF)
8. Graphic configuration file (GCF)
9. Machine load table (MLT)
10. Control program (pre-cataloged and user-written) procedures
11. One dump buffer area (CHGDMP), which may contain either the MOSS microcode dump or the scanner microcode dump.
12. Line description file (LDF)
13. Port swap file
14. One dump buffer (CHGTRSS), which may contain one to four TIC dumps.

Service Diskette

The service diskette contains the following files:

1. Basic MOSS microcode
2. Diagnostics with the diagnostic control facility (DCF)
3. Limited set of service procedures
4. Files duplicated via the diskette swap procedure


CONTROL PANEL

The control panel is located on the 3725 and contains switches and indicators for the use of the customer's operator and CE to:

- Enable and disable the channel connections
- Power on or off the controller
- Test local/remote control power
- Select the primary or alternate operator console
- IPL the controller and load the microcodes and diagnostics
- Check the controller operation
- Reset certain error conditions

OPERATOR CONSOLE

The console adapter operates in PIO mode and transmits data to the operator console in start-stop mode at 2400 bps without a modem.



Maintenance Philosophy (Part 1 of 2)

The maintenance of the 3725 is based on:

1. Error detection by hardware and software
2. Error collection by the control program and the MOSS microcode
3. Error notification to the customer through alarm and alert messages (NCP), or alarm messages (EP).
4. Problem determination by the customer at the host site and the controller site so as to call the appropriate service personnel.
5. Problem isolation by service personnel
6. FRU replacement, repair, and verification

(See illustration page 1-071.)

Concurrent Maintenance

Generally, the controller is not available to the customer when the diagnostics are being run, or a field replaceable unit (FRU) is being replaced. However, the controller is available to the customer when a repair is being made in the diskette drive or the operator console, or when diagnostics are being run only for testing the MOSS.

This mode of operation is called concurrent maintenance.

Repair Action in Case of Solid Error

A failing FRU may be indicated by the following error information:

- Repair action codes (RACs) given by the offline diagnostics on the operator console
- Error codes given by the IPL checkout programs on the control panel hexadecimal display
- Error information given on the CE indicator card

Any error indication points to a list of suspected FRUs and replacement procedures in the MIM Part 2.

Box Error Record (BER) Description

The BER is a record generated by NCP or the MOSS. It is logged on a MOSS error file which is used to identify all error occurrences in the 3725. (See page 2-170 for more details).

Tentative Repair Action (Intermittent Error)

An intermittent error is not confirmed by the diagnostics. BER analysis may identify suspected FRUs. Should the same error appear, the flag byte determines the meaning of the BER and the status of the problem that caused the BER.

Additional BER Information

- BER handling: MIM Part 1, Chapter 2 pages 2-170 to 2-342.
- BER Control Blocks:
 - ACF for NCP/EP for 3725, Reference Summary and Data Areas (NCP Handbook), LY30-3070 section 2.
- CE actions based on BERs (usage): MIM Part 2, START entry.
- FRUs pointed by BERs: MIM Part 2, Chapter R5
- Extended Troubleshooting using BERs: MIM Part 1, starting with page 2-800.
- Aids for BERs: MIM Part 1, page 3-030
- BER File printout at Host: 3725 Problem Determination and Extended Services, GA33-0014, Chapter 5, and ACF for NCP/SSP for 3725, Diagnosis Guide, SC30-3181.

No FRU Isolated

Errors not isolated by the maintenance package, and design errors on hardware, microcode, or diagnostics are handled on site with the assistance of the support structure.

Maintenance Philosophy (Part 2 of 2)

Error Detection on 3725/3726 Site

Sequence:

1. The control program in the 3725 controller and the MOSS microcode gather error information for problem determination, problem isolation, and FRU replacement.

2. The error information is sent to the MOSS and RECMS (if any) is sent to the host.

3. The customer is notified of the error through alarm on the 3725 controller, and alert messages on the host if NCP is loaded in the 3725.

Problem Determination on 3725/3726 Site

4. The customer uses the host system console and message manual, the host NPDA guide (if CNM environment), and the trace information to determine the failing area. If the controller is suspected, the customer may perform further problem determination.

Problem Isolation on 3725/3726 Site

5. The CE identifies the failing element (FRU) inside the controller by:

- . Using the customer error information
- . Following the procedures in 3725/3726 MIM Part 2
- . Running diagnostic programs
- . Analyzing the recorded BERs
- . Using maintenance aids and tools

If the problem appears to be in the micro code or control program, the MIM Part 2 indicates the appropriate action

6. The identified FRU is replaced and, if necessary, repaired, and verification is performed.

3725/3726 Internal Error (Box Error)

Hardware, control program, or microcode

NCP gathers:

- CA level 1 errors
- CSP level 1, 2 errors
- Unresolved level 1, 2, 3, 4 software error

MOSS gathers:

- Other errors


RECMS with equipment check for line related errors (NCP only)
NCP/EP and MOSS microcode build RECFMS and BER

1. A BER is generated by NCP or MOSS
2. Time and date are stamped by MOSS (if NCP) or sequentially numbered by MOSS (if EP)
3. BER is stored in the BER file on diskette


Box Error Record

Header Error Data

or MOSS storage if diskette failure



Alert/Alarm messages based on BER are generated by MOSS



The Alert is time and date stamped, and indicates the affected element and recommended customer action. Message exchange if CNM: RECFMS00, RECFMS05

Error in 3725/3726 Attached Network


Line, Station, Modem

NCP builds RECMS

Contents:

- Unresolved interrupts and program checks
- Solid SNA link/station errors
- SNA statistics
- BSC/SS station statistics and line errors

Error Reporting Path to Host



Note: No Alert is sent to the access method when EP is running in a 3725 controller. EP works the same way in a 3725 controller as in any other 370X controller.

The customer uses the 3725 facilities:

- 3725 Operating Guide
- MOSS functions available from the console

Problem determination ends when the customer identifies

- Failing Software: Customer calls appropriate software support
- Failing hardware, including control codes: Customer calls 3725/3726 support for problem isolation
- Other failures such as DCEs, OEM machines, user errors: Customer calls appropriate service personnel

Chapter 2. Service Procedures

Section 1. Functions

Contents

SECTION 1. FUNCTIONS

3725 Console Functions	2-010	SDLC (Normal Mode) BSC (Normal Mode) BSC (Character Mode) Start-Stop (Character Mode) Line Error Trace SDLC BSC	Error Log Function (Part 1 of 4)	2-170	
Screen Layouts	2-020	NCP SIT (Part 4 of 4)	2-038	BER Generation BER Formatting Example of Date and Time BER Storage on Diskette BER Storage When Diskette is Not Operational BER File Erasure BER Display	
Basic Layout		Microcode Checkpoint Trace	2-040	Error Log Function (Part 2 of 4)	2-171
Controller Diskette - Two Primary Menus		Trace Objectives		BER Structure	
Customer Primary Menu		Scanner Microcode Sequence of Operation		Approach to Problem Isolation	
Maintenance Primary Menu		Address Look-Up Table		Thresholds	
Service Diskette - One Primary Menu		Microcode Checkpoint Trace Records		BERs That Are Not Machine Errors	
Host Traces (Part 1 of 3)	2-030	Trace Summary	2-042	Unresolved Interrupts	
Host Traces in an ACF/VTAM Environment		Trace Comparison		BER Handling Tools	
ACF/VTAM Environment		Communication Function Traces		Error Log Function (Part 3 of 4)	2-172
Buffer Content Trace		LOGREC Display with EREP		BER Display Sample Sequence	
VTAM Internal Trace		File Transfer to the Host		BER Display Procedure	
Buffer Use Trace		Wrap Tests Controlled from the Host	2-044	With Controller Diskette	
VTAM I/O Trace		Wrap Test at Tailgate Level		With Service Diskette	
Host Traces (Part 2 of 3)	2-031	Modem or NTT Cable		BER Display Sample Sequence	
Host Traces in an ACF/VTAM Environment		Token-Ring Wrap Tests		Error Log Function (Part 4 of 4)	2-173
ACF/TCAM Environment		Wrap Tests Controlled from the MOSS	2-046	BER Updating	
Dispatcher Subtask Trace		Wrap Test at Tailgate Level		BER Flag Explanation	
Buffer and Extended Buffer Trace		Modem or NTT Cable		BER Flag Updating	
PIU Trace		Wrap Test at Tailgate Level	2-048	BER Display Screens (Part 1 of 3)	2-180
Channel I/O Interrupt Trace		Wrap Test Initialization Screen		BER Summary Display	
Host Traces (Part 3 of 3)	2-032	Control Lead Wrap Test Pattern		Field Description for BER Summary Screen	
Host Traces (Environment-Independent)		Selection Screen		BER List Display	
Host NLDM Trace		Wrap Test Start Screen		Field Description for BER List Screen	
NCP Traces (Channel Adapter, Session, GPT, and Branch)	2-033	Alarm/Alert List	2-050	PF Keys on BER List Screen	
NCP Channel Adapter Trace		Alarms		BER Display Screens (Part 2 of 3)	2-181
NCP Session Trace		Alerts		BER Detail Displays	
NCP Generalized PIU Trace (GPT)		NPDA Messages		Finding the Appropriate BER Detail Screen	
Overview		Online Test Group (Part 1 of 4)	2-150	Common Fields in Header Lines	
Tracing Outbound PIUs		Requirements		PF Key on BER Detail Screen	
Tracing Inbound PIUs		Running Time		BER Display Screens (Part 3 of 3)	2-182
Limitations		Selection		Fields Common to Many BER Detail Screens	
NCP Branch Trace		Tested Part (Both Models)		X'76' and X'76'U	
NCP Traces (Address, Line, and Transmission Group)	2-034	Online Test Group (Part 2 of 4)	2-151	Redrive Address and Error Register	
NCP Address Trace		Procedure		Address and Command Format on the IOC Bus	
NCP Line Trace		Online Test Group (Part 3 of 4)	2-152	at TA Time	
EP Line Trace		CA OLT Responder		CHAPTER 2. SERVICE PROCEDURES	
NCP Transmission Group Trace		CA OLTs		CA (Type 10) BER Detail Displays (Part 1 of 4)	2-190
NTRI Traces		Selection		CA BER, Type 10 - Summary	
Line and IOH Trace		D99-3725A Contents		CA (Type 10) BER Detail Displays (Part 2 of 4)	2-191
TIC Internal Trace		Routine List		CA BER (Type 10) Summary (Continued)	
Activation of traces		OLT Running Restrictions		CA (Type 10) BER Detail Displays (Part 3 of 4)	2-192
ACF/TAP editing and RU formats		Messages		CA BER, Type 10 - IDs 18, 1C, 1E, 97,	
NCP SIT (Part 1 of 4)	2-035	Online Test Group (Part 4 of 4)	2-153	9B (foC1)	
Trace Objectives		OLT CDS For the 3725		CA BER, Type 10 - IDs 14, 16, 91, 9A (foC2)	
Trace Limitations		3725 CDS Card and Storage Layout		CA BER, Type 10 - IDs 10, 1B, 1F, 90, 92,	
High-Speed Trace Limitations for NCP/SIT		Range Definition Card Layout		93, 94, 95, 96, 98, 99, 9C, 9E, 9F (foC3)	
NCP SIT (Part 2 of 4)	2-036	System Tests	2-160	CA BER, Type 10 - IDs 33, 34, 35, B1, B2,	
NCP SIT Record Units		ST370		B5, B6 (foC4)	
TRU Formats		NST-2		CA (Type 10) BER Detail Displays (Part 4 of 4)	2-193
IOH/IOHI Field		ST4300		CA BER, Type 10 - Field Explanation	
Parameter Field				TSS (Type 11) BER Detail Displays (Part 1 of 4)	2-200
Data Field				TSS BER, Type 11 - Summary	
Status Field					
Checkpoint Data Field					
Overrun Field					
SIT Trace Records					
NCP SIT (Part 3 of 4)	2-037				
Line Character Trace					

Contents

TSS (Type 11) BER Detail Displays (Part 2 of 4)	2-201	Software Error, Hardware Detected	MOSS BER, ID 06 (Part 3 of 5)	2-322
TSS BER (Type 11) Summary (Continued)		Software Error, Software Detected	ERROR-EXT (Error Code Extension)	
TSS BERs, Type 11 - ID 14, 16, 91, 92, 93 (foT1)		BER/ALARM/ALERT Mechanism (Part 2 of 2)	IPL REQ	
TSS BER, Type 11 - IDs 18, 1B, 97, 98, 9C (foT2)		BER/ALARM/ALERT Mechanism on 3725	C REQ (Cancel Request)	
TSS BER, Type 11 - IDs 1E, 1F, 95, 96, 99, 9A, 9B (foT3)		Catastrophic Errors (3725 Down)	STAT (System Status)	
TSS BER, Type 11 - ID A1 (foT4)		Analysis of a BER/ALARM/ALERT Sequence	DISK (Diskette Errors)	
TSS (Type 11) BER Detail Displays (Part 3 of 4)	2-202	MOSS BER, ID 00 (Part 1 of 2)	MOSS BER, ID 06 (Part 4 of 5)	2-323
TSS BER, Type 11 - ID A2, A4 (foT5)		MOSS BER, Type 01 - ID 00 (foM0)	SCB (Scanner Control Block)	
TSS BER, Type 11 ID B1 (foT6)		MOSS BER (Type 01) ID 00 -	CS (Scanner Errors)	
TSS BER, Type 11 ID 1C (foT7)		Field Explanation	F IML Error Flag	
TSS (Type 11) BER Detail Displays (Part 4 of 4)	2-203	MEF Status Byte	MOSS BER ID 06 (Part 5 of 5)	2-324
TSS BER, Type 11 - Field Explanation (Continued)		PSW (Condition Codes and Page Pointer)	Register Descriptions on IPL Check	
NCP/EP (Type 12) BER Detail Displays	2-210	TTA (Current TTA Entry Byte)	X71	
NCP/EP BER, Type 12 - Summary		CNT (Current Error Counter)	X72	
NCP/EP BER, Type 12 - IDs 11 thru 19 (foN1)		MOSS BER, ID 00 (Part 2 of 2)	CCU User Indicator	
NCP/EP BER, Type 12 - ID 21 (foN2)		Data (Contents of Three-Byte Field)	Storage User Indicator	
NCP/EP BER, Type 12 - Field Explanation		MOSS BER, ID 01	HKNG Register	
CCU (Type 13) BER Detail Displays (Part 1 of 2)	2-220	MOSS BER, Type 01 - ID 01 (foM1)	HDCK Register	
CCU BER, Type 13 - Summary		MOSS BER (Type 01) ID 01 -	MOSS BER, ID 07	2-325
CCU (Type 13) BER Detail Displays (Part 2 of 2)	2-221	Field Explanation	MOSS BER, Type 01 ID 07 (foM13)	
CCU BER, Type 13 - IDs 91 thru 95 (foU1)		AREG (CCU/MOSS Status A Register)	MOSS BER, Type 01-ID 07 Error	
CCU BER, Type 13 - IDs C1 thru C6 (foU2)		Error (Error Codes)	04/08/40/80 (foM13)	
CCU BER, Type 13 - IDs 32, B1 (foU3)		Status	MOSS BER, Type 01-ID 07 Error FF (foM13)	
CCU BER, Type 13 - Field Explanation		MOSS BER, ID 02 (Part 1 of 2)	MOSS BER, Type 01-ID 07 Error 00 (foM13)	
IOC (Type 14) BER Detail Displays	2-230	MOSS BER, Type 01 - ID 02 (foM2)	MOSS BER, Type 01-ID 07 Error FE (foM13)	
IOC BER, Type 14 - Summary		MOSS BER (Type 01) ID 02 -	MOSS BER, Type 01-ID 07 Field Explanation	
IOC BER, Type 14 - All IDs (91, 92, 93, 95) (foI1)		Field Explanation	ERROR (Error Code)	
IOC BER, Type 14 - Field Explanation		CMD (Logical Command)	ERR-EXT (Error Code Extension)	
TRSS (Type 15) BER Detail Display (Part 1 of 3)	2-231	Error (Error Codes)	MOSS BER, ID 91, B3, C1, C2	2-330
TRSS BER, Type 15 - Summary		MOSS BER, ID 02 (Part 2 of 2)	MOSS BER, Type 01 - IDs 91 B3 C1 C2 (foM8)	
TRSS BERs, Type 15 - IDs 14, 16, 91, 92, 93 (foR1)		PCW (Processor Control Word)	Field Explanation (Type 01 IDs 91 B3, C1, C2, NCP/EP)	
TRSS BERs, Type 15 - IDs 18, 97, 98, 9C (foR2)		Byte Definition	BER Layout in Diskette (Part 1 of 3)	2-340
TRSS BER, Type 15 - ID 96, 99, 9A, 9B (foR3)		MOSS BER, ID 03	BER Layout on Diskette (Part 2 of 3)	2-341
TRSS BER, Type 15 - IDs A3, A4, A5, A7, A8 (foR4)		MOSS BER, Type 01 - ID 03 (foM3)	BER Layout on Diskette (Part 3 of 3)	2-342
TRSS (Type 15) BER Detail Display (Part 2 of 3)	2-232	MOSS BER (Type 01) ID 03 -	MOSS Bers (Type 01) (Continued)	
TRSS BER, Type 15 - IDs AC (foR5)		Field Explanation	Machine Status Area (Part 1 of 5)	2-350
TRSS BER, Type 15 - IDs AF (foR6)		CMD (Logical Commands)	MSA with Scanner Information	
TRSS BER, Type 15 - IDs B2 (foR7)		ARC (Adapter Return Codes)	MSA with TRA Information	
TRSS BER, Type 15 - IDs B3, B4, B5, B6 (foR8)		MOSS BER, ID 04	MSA with CCU/Scanner IPL Information	
TRSS BER, Type 15 - Field Explanation		MOSS BER, Type 01 - ID 04 (foM4)	General Information	
TRSS (Type 15) BER Detail Display (Part 3 of 3)	2-233	MOSS BER (Type 01) ID 04 -	Field a	
MOSS (Type 01) BER Detail Display (Part 1 of 3)	2-240	Field Explanation	Field b	
MOSS BER, Type 01 - Summary		MOSS BER, ID 05 (Part 1 of 2)	Field c	
MOSS (Type 01) BER Detail Display (Part 2 of 3)	2-241	MOSS BER, Type 01 - ID 05 (foM5)	Machine Status Area (Part 2 of 5)	2-351
MOSS BER, Type 01 - Summary (Continued)		MOSS BER ID 05 (Part 2 of 2)	Field d	
MOSS (Type 01) BER Detail Display (Part 3 of 3)	2-242	MOSS BER (Type 01) ID 05 -	Field e	
MOSS BER, Type 01 - Summary (Continued)		Field Explanation	Field f	
BER/Alarm/Alert Mechanism (Part 1 of 2)	2-250	BERs Printed on Host	Field g	
BER/Alarm/Alert Mechanism on 3725		ERROR (Error Codes)	Field h	
Catastrophic Errors (3725 Down)		ERR-EXT (Error Code Extension)	Field i	
CCU Hardcheck		MOSS BER, ID 06 (Part 1 of 5)	Field j	
Hardware Error		MOSS BER, Type 01 - ID 06 (IPL) (foM6)	Machine Status Area (Part 3 of 5)	2-352
		MOSS BER, Type 01 - ID 06 (not IPL) (foM7)	Field k	
		MOSS BER (Type 01) ID 06 -	Field l	
		Field Explanation	Scanner Information	
		MOSS BER, ID 06 (Part 2 of 5)	Field m	
		MOSS BER, Type 01 - ID 06 (foM9)	Field n	
		MOSS BER, Type 01 - ID 06 (foM10)	Field o	
		MOSS BER, Type 01 - ID 06 (foM11)	Field p	
		MOSS BER, Type 01 - ID 06 (foM12)	Field q	
		ERROR (Error Codes)		

Contents

Machine Status Area (Part 4 of 5)	2-353	Address Compare (Scanner)	2-377	Scan and Erase (ZAP)	2-397
CCU/Scanner IPL Information		Selection		Scan (ZAP)	
Field r		Deactivating the Scanner Address Compare		Erase (ZAP)	
Field s		Checkpoint Trace (Scanner)	2-378	Create a ZAP	2-398
Field t		Selection		Selection	
Field u		TRA Select, Connect/Disconnect	2-380	File ZAP in ZAP area	
Field v		Introduction		Update Spare Diskette	2-399
Field w		Selection from the Controller Diskette		Selection	
Field x		Messages		COPY ZAPs on Spare Diskette	
Machine Status Area (Part 5 of 5)	2-354	TRA Select (1)		CDF: Select and Create	2-400
TRA/TIC Information		TRA Connect/Disconnect (2)		Selection	
Field m*		Display/Alter TRM Registers (3)	2-381	Create	
Field n*		Display/Alter TIC Interrupt Register (4)	2-382	CDF: Verify	2-401
Field o*		Display TIC Storage (5)	2-383	Verify	
Field p*		Display		CDF: Display/Update (Part 1 of 4)	2-402
Field q*		TIC Internal RAM Format		Display/Update Menu	
Reset CCU/LSSD (Part 1 of 2)	2-360	Dump TIC Storage (6)	2-384	All	
Selection		TIC Functional Blocks		CCU/MOSS	
Function Message Line		Display SCB, SSB and Parameter Block (7, 8)	2-385	Display/Update LAB/CAB (3725/3726)	
Reset CCU/LSSD (Part 2 of 2)	2-361	Display SCB, SSB (7)		Display/Update C2LB/LAB (3725 Model 2)	
Mode of Operation		Display Parameter Block (8)		CDF: Display/Update (Part 2 of 4)	2-403
IPL CCU/TSS (Part 1 of 2)	2-365	Display Token Ring Status (9)	2-386	Channel Adapters (3725/3726)	
IPL Menu		TRSS Modes	2-387	Channel Adapters (3725 Model 2)	
Selection		NTRI MAC Status and Corresponding TIC Mode		Scanners/TRAS	
Available Functions		Utility Programs	2-390	3725/3726 Model 1 LABs	
One Scanner IML		Selection from the Controller Diskette		3725 Model 2 C2LB and C2LB2	
Selection		Selection from the Service Diskette		3725/3726 Model 1 and Model 2 LAB Type C	
IML Termination		Messages		CDF: Display/Update (Part 3 of 4)	2-404
IPL CCU/TSS (Part 2 of 2)	2-366	MOSS, Scanner, and TRSS Dump Display/Delete		LSSD	
3725 IPL		(Part 1 of 2)	2-391	LSSD Bit Identification	
Selection		Selection		CDF: Display/Update (Part 4 of 4)	2-405
IPL Phases		MOSS or Scanner Dump Display		CDF Information	
Normal IPL (Option 1)		TRSS Dump Display		MLT	2-407
Step-by-Step IPL (Option 2)		MOSS, Scanner, and TRSS Dump Display/Delete		Selection	
Bypass Phase 1 (Option 3)		(Part 2 of 2)	2-392	ZAP History Table	
TSS Functions	2-370	MOSS or Scanner Dump Delete		Diskette Swap (Part 1 of 3)	2-408
Selection from the Controller Diskette		TRSS Dump Delete		Selection	
Selection from the Service Diskette		MOSS Store and Module Display	2-393	Diskette Swap (Part 2 of 3)	2-409
Messages		MOSS Store Display (Moss Storage Display)		SAVE BER	
Select/Release Scanner		Selection		Diskette Swap (Part 3 of 3)	2-410
Selection		Module DPLY (Module Display)		PURGE BER	
Select a Scanner		Selection		MOSS, Scanner, and TRSS Dump=	2-440
Release a Scanner		ZAP Area on Diskette	2-394	MOSS Dump	
Dump/IML Scanner	2-371	ZAP Identification		Automatic MOSS Dump	
Selection		Creating a ZAP		Manual MOSS Dump	
Dump a Scanner		Erasing a ZAP		Scanner Dump	
IML a Scanner		Selecting the ZAP Functions	2-395	Automatic Scanner Dump	
Mode Control (Scanner)	2-372	Selection		Manual Scanner Dump	
Selection		ZAP Functions		TRSS TIC Dump	
Connected		Apply, Restore, and Modify (ZAP)	2-396	Manual TIC Dump	
Disconnected		Apply (ZAP)		Automatic TIC Dump	
DPLY/ALT Store (Scanner)	2-373	Restore (ZAP)		File Transfer	2-450
Selection		Modify (ZAP)		Transferring Dump Files to the Host	
Display		Selection		Transferring Other 3725 Files to the Host	
Alter		ALTER Command		Transferring Dump Files Using a	
PF Keys		DELETE Command		Maintenance Device	
DPLY/ALT Blocks (Scanner)	2-375	INSERT Command		Receiving Files Using a Maintenance Device	
Selection (3725/3726)				Copying a Diskette Using Two	
Selection (3725 Model 2)				Maintenance Devices	
DPLY/ALT LSR and XREG (Scanner)	2-376				
DPLY/ALT LSR					
DPLY/ALT XREG					

Contents

Transferring a File: MD to VM and/or MD to MD . . . 2-451	Message Directory (Part 1 of 4) 2-480
MD to VM File Transfer	Message Directory (Part 2 of 4) 2-490
MD to MD File Transfer	Message Directory (Part 3 of 4) 2-491
Receiving a File: Data Base to MD (Part 1 of 6) 2-452	Message Directory (Part 4 of 4) 2-492
3725 Diskette Label Format and Definitions	Utility Program Messages (Part 1 of 5) 2-500
Microcode Patch Strategy	Utility Program Messages (Part 2 of 5) 2-501
When to Patch	Utility Program Messages (Part 3 of 5) 2-502
Microcode Download Procedure	Utility Program Messages (Part 4 of 5) 2-503
Receiving a file: Data Base to MD (Part 2 of 6) 2-453	Utility Program Messages (Part 5 of 5) 2-504
3725 Diskette Requirements	TSS Function Messages (Part 1 of 5) 2-510
MD Diskette Requirements	TSS Function Messages (Part 2 of 5) 2-511
Sequence Numbers	TSS Function Messages (Part 3 of 5) 2-512
Diskette Boundaries	TSS Function Messages (Part 4 of 5) 2-513
Receiving a file: Data Base to MD (Part 3 of 6) 2-454	TSS Function Messages (Part 5 of 5) 2-514
Tools Required	TRSS Function Messages (Part 1 of 4) 2-520
Data Base Telephone Numbers	TRSS Function Messages (Part 2 of 4) 2-521
Time Recording	TRSS Function Messages (Part 3 of 4) 2-522
Trouble Reporting	TRSS Function Messages (Part 4 of 4) 2-523
Step by Step Procedure	
Receiving a file: Data Base to MD (Part 4 of 6) 2-454	SECTION 2. EXTENDED TROUBLESHOOTING USING BERS
Receiving a file: Data Base to MD (Part 5 of 6) 2-456	BER Recovery Procedures 2-800
Receiving a file: Data Base to MD (Part 6 of 6) 2-457	MOSS
Updating Machine Diskettes from MD	Central Control Unit (CCU)
Distribution Diskettes	BER Analysis Procedures (Part 1 of 5) 2-801
Errors and Warnings	Multiple BERS
Receiving a File: MD to MD 2-458	MOSS Subsystem Storage Errors
Copying a Diskette: MD to MD 2-459	BER Analysis Procedures (Part 2 of 5) 2-802
File Printing: MLT File 2-460	Central Control Unit (CCU)
MLT File	CCU Hardcheck
File Printing: CDF (Part 1 of 3) 2-461	BER Analysis Procedures (Part 3 of 5) 2-803
Configuration Data File (CDF)	Storage Double-Bit Errors
CDF Data Organization	Manual Routine B001
CCU Record (S1,R0)	CCU Clock
File Printing: CDF (Part 2 of 3) 2-462	BER Analysis Procedures (Part 4 of 5) 2-804
MOSS Record (S1,R1)	IOC Bus and Adapters
Redrive Records (S1,R2, R3)	BER Analysis Procedures (Part 5 of 5) 2-805
RDV1 (S1,R2)	RDV Address and Error Registers
RDV2 (S1,R3)	TSS BER Processing
Channel Adapter Records (S1,R5, R6)	TRSS BER Processing
General Scanner Configuration	Scanner Errors Without BERS 2-806
Frame (S2,R0-R4)	Unresolved Interrupts (Part 1 of 2) 2-807
File Printing: CDF (Part 3 of 3) 2-463	Unresolved Interrupts (Part 2 of 2) 2-808
Scanner/TRA Detailed Information	Troubleshooting IOC Bus Problems with BERS
Records (S2,R5-R6,S3,S4)	BER 11 IC Mechanism
File Printing: ZAP History Table 2-465	BER 11 B1/A4 Mechanism
File Printing: BER List 2-466	
File Printing: MOSS Dump (Part 1 of 2) 2-467	
File Printing: MOSS Dump (Part 2 of 2) 2-468	
Hexadecimal/Decimal Conversion 2-470	
Conversion Rules	
From Hex	
From Decimal	
Conversion Tables	

3725 Console Functions

The following tables:

1. List the functions that the user can select via the CCU function key, or from one of the three primary menus.
2. Indicate in which manual the function is described:
 - a. This manual (page number), or
 - b. 3725 Problem Determination and Extended Services (Vol. A06), referred to as "PD and ES" in the tables
 - c. 3725 Diagnostic Descriptions (Vol. A05), referred to as "Diag" in the tables


Primary Menu Functions	Diskettes	Described In
CCU Functions (CCU FNCTN)		
Address Compare	Both	PD and ES
Branch Trace	Both	PD and ES
Display/Alter	Both	PD and ES
Display Long	Both	PD and ES
System Control	Both	PD and ES
Data Exchange	Both	PD and ES
AC/BT Parameters	Both	PD and ES
Cancel AC	Both	PD and ES
Cancel BT	Both	PD and ES
CA Status/Registers	Both	PD and ES
Reset CCU/LSSD	Both	2-360
IPL CCU/TSS (==> I)		
One Scanner IML	Controller	2-365
3725 IPL	Controller	2-365
Link Test Requester	Controller	PD and ES
Link Test Responder	Controller	PD and ES
Line Functions (==> L)		
Wrap Test (Modem, Cable)	Controller	PD and ES
Wrap Test (Tailgate)	Controller	2-048
Line Interface Display	Controller	PD and ES
(Stand-Alone) Link Test	Controller	PD and ES
Port Swap File	Controller	PD and ES
Line Description File	Controller	PD and ES
Token Ring INTF	Controller	PD and ES
Error log (==> E)		
	Both	2-170
GCF/IPL Ports (==> P)		
	Controller	PD and ES
Control pgm proc (==> C)		
Directory	Controller	PD and ES
Display	Controller	PD and ES
Create/Copy	Controller	PD and ES
Erase	Controller	PD and ES
Modify	Controller	PD and ES
Execute	Controller	PD and ES
Catalog	Controller	PD and ES

Primary Menu Functions	Diskettes	Described In
TSS Functions (==> S)		
Select/Release	Controller	2-371
Dump/IML	Controller	2-371
Mode Control	Controller	2-372
Display/Alter Storage	Controller	2-373
Display/Alter Block	Controller	2-375
Display/Alter LSR	Controller	2-376
Display/Alter X Reg	Controller	2-376
Address Compare	Controller	2-377
Checkpoint Trace	Controller	2-378
TRSS FNCTN (==> R)		
Select	Controller	2-380
Connect/Disc	Controller	2-380
TRM Registers	Controller	2-381
TIC Interrupt Register	Controller	2-382
Display TIC Storage	Controller	2-383
Dump	Controller	2-384
Display SCB, SSB	Controller	2-385
Display parameters block	Controller	2-385
TIC error status	Controller	2-386
Diagnostics (==> D)		
	Service	Diag
Utility Programs (==> U)		
Dump Display/Delete	Both	2-391
MOSS Store Display	Both	2-392
Module Display	Both	2-392
ZAP	Both	2-394
CDF	Both	2-400
MLT	Both	2-407
Diskette Swap	Both	2-408
Immediate Functions		
CCU Stop (==> SP)	Both	PD and ES
CCU Start (==> ST)	Both	PD and ES
CCU Reset (==> RT)	Both	PD and ES
Date/Time (==> Q)	Both	PD and ES
Terminate (==> T)	Both	PD and ES

Screen Layouts

BASIC LAYOUT

The operator console has a screen capacity of 2000 characters, organized in 25 rows of 80 characters. These 25 rows are divided into eight areas, each being reserved for specific information and actions.




For 3727 operation information, see description in the 3727 Reference and Problem Analysis Guide, GA33-0015, inserted at the back of the console keyboard.

Warning: Before operating the console switch, you must properly terminate (enter T) any operation on the selected console.

CONTROLLER DISKETTE - TWO PRIMARY MENUS

These are the menus available for normal and maintenance operations on the 3725 by the customer.

Customer Primary Menu




SERVICE DISKETTE - ONE PRIMARY MENU


This menu is available for maintenance operations on the 3725.

The service diskette must be mounted. The maintenance files from the controller diskette must be copied as required to the service diskette before use (see "Diskette Swap" on page 2-408). The maintenance files consist of the BER file, the 3725/3726 configuration data file (CDF), and the machine load table (MLT).

When and how to substitute diskettes is described in the MIM Part 2 (Vol. A01).



Maintenance Primary Menu




Host Traces (Part 1 of 3)

This section gives a general overview of tracing on the 3725 to help the CE select the type of trace applicable to a specific problem. It is not intended to give a detailed explanation of tracing.

Note: The 3725 does not affect BTAM operation.

HOST TRACES IN AN ACF/VTAM ENVIRONMENT

ACF/VTAM Environment



Buffer Content Trace

The buffer content trace shows what is passing back and forth at two points within ACF/VTAM itself. One of the points is just inside ACF/VTAM code near the application program interface (API); the other point is internally within the ACF/VTAM code. The user data portion (RU) of buffer content trace records written from these two points should be identical for the same PIU, since ACF/VTAM does not modify user data which it handles.

The OS/VS VTAM buffer trace records up to 212 bytes of data (224 bytes for DOS) from VTAM buffers during the transmission of an inbound or outbound message to a locally-attached device or NCP. The VTAM buffer trace includes the transmission header (TH), and the request/response header (RH). VTAM adds 32 bytes of header information to the OS and DOS trace data records. GTF adds up to 12 bytes of header information to OS/VTAM trace data records.

Because the buffer content trace shows contents of the PIU, this trace is sometimes called the PIU trace.

VTAM Internal Trace

The internal trace can be used to trace various kinds of internal activity within ACF/VTAM. This trace can be helpful if you suspect that ACF/VTAM is malfunctioning.

Buffer Use Trace

The OS/VS ACF/VTAM buffer use trace contains information about the 11 user-defined ACF/VTAM buffer pools. This trace is useful to help 'tune' an ACF/VTAM system for optimum number of buffer pools.

The DOS/VS PDAID trace can be used to trace a number of internal functions, but its main use, so far as ACF/VTAM is concerned, is to provide statistics on ACF/VTAM buffer use. Although the PDAID trace is functionally different from the OS/VS buffer use trace, it provides similar information on buffer-pool use.

VTAM I/O Trace

The I/O trace shows what is passing back and forth between ACF/VTAM and NCP.


The OS/VS VTAM I/O trace (RNIO) and DOS/VS I/O trace (IO) (part of PDAIDs) record up to 20 bytes of data during the transmission of an inbound or outbound message to NCP. This data includes the transmission header (TH), request/response header (RH), and a variable portion of the request/response unit (RU). OS/VTAM does not add any header information to the RNIO trace; however, ACF/TAP creates a 32-byte header for it. GTF adds up to 36 bytes of header information to the RNIO trace. DOS/VTAM adds a 32-byte header to the IO trace. RNIO or IO trace is similar to a short buffer trace in content if user data is being transmitted and received. However, certain control buffer sequences that do not appear in VTAM buffer traces may appear in RNIO or IO traces.

You use the RNIO or IO trace to determine if the SNA sequences between VTAM and NCP are correct. Because the RNIO or IO trace is abbreviated, you save trace file space by using it instead of the VTAM buffer trace.

Host Traces (Part 2 of 3)

HOST TRACES IN AN ACF/VTAM ENVIRONMENT

ACF/TCAM Environment



Dispatcher Subtask Trace

The dispatcher subtask trace keeps a sequential record in main storage of the subtasks activated by the ACF/TCAM dispatcher.

Buffer and Extended Buffer Trace

- Buffer trace provides a record of ACF/TCAM buffer contents before processing.
- Extended buffer trace allows a user to request a buffer trace entry during processing.

PIU Trace

PIU traces record 38 bytes of information passing in either direction between TCAM and NCP. This information includes indexes to the terminal name table for the destination name and source name, transmission header (TH), request/response header (RH), and the first 15 bytes of the request/response unit (RU). The RU portion of the PIU trace is padded with hexadecimal zeros if necessary to fill out the 15 bytes. TCAM adds a 4-byte header to the PIU trace data containing the source and destination terminal-name table indexes. ACF/TAP does not convert the indexes to trace-name table information for the PIU trace record.

Channel I/O Interrupt Trace

The channel I/O interrupt trace sequentially records the I/O interruptions that occur on a specified non-NCP line or on a channel to a 3725 working under NCP. Optionally, the user may specify that the trace be activated when an I/O error occurs on a line or on an NCP channel. ACF/TCAM stores information about the interruption, including the channel status word (CSW), channel command words (CCWs) and data transferred, as an entry in the channel I/O interrupt trace table. A maximum of 50 emulated subchannels and native channels can be traced at a time.

Host Traces (Part 3 of 3)

HOST TRACES (ENVIRONMENT-INDEPENDENT)

Host NLDM Trace

The Network Logical Data Manager (NLDM) executes on operating systems and access methods supported by NCCF Release 2 and NPDA Release 2E. NCCF Release 2 and NPDA Release 2E are prerequisite for NLDM.

NLDM is an IBM licensed program for the continuous collection of session-related data. It has functions for monitoring session activity and completing problem determination of errors which, typically, manifest themselves as a 'hung' terminal session.

NLDM establishes session awareness in an NCCF application. The control and data flows between NLDM and the access methods provide the session knowledge to accommodate network enhancements in the areas of connectivity, configuration, performance, accounting, and problem determination. NLDM is structured to facilitate the addition of network functions that relate to sessions.

NLDM provides an interactive session trace capability that captures access method PIUs and selected NCP control information about a session. NLDM can be compared to existing TRACE capabilities in the same way that NPDA can be compared to EREP. Both NLDM and NPDA take a traditional batch, offline function and provide an interactive structured facility based on a logical subset of large amounts of data.

The capturing of session data by NLDM allows for continuous capture if desired by the user. The user must be able to turn ON/OFF data capture by session type and/or session name. To provide efficient data capture, NLDM maintains active session wrap areas in virtual storage. Upon session termination the virtual storage wrap areas is migrated to VSAM data base for history. The size of the wrap areas and the amount of history is specified by the user.

NLDM collects session information from two sources: the access method (VTAM or TCAM), and the boundary (NCP).

The functions provided by NLDM are oriented to the CE and the system programmer. These functions correlate and format internal session-related data and require SNA level expertise for full understanding.

NLDM provides information on:

- Activation and deactivation of session trace
- Session name lists
- Most recent sessions
- Session connectivity
- Bind
- Access method PIU trace data

A formatted PIU trace is provided for all supported sessions. Each PIU entry includes the transmission header (TH), the request/response header (RH), and the first 11 bytes of the request unit (RJ). PIU sequence numbers (last four) from the NCP (see description of session trace in NLDM documentation) are correlated with the PIUs from the access methods.

- NCP control block data

Selected fields from NCP control blocks accompany the last four sequence numbers sent to NLDM by the NCP for a specific session. These fields are interpreted and formatted for display to the user (see "NCP Session Trace" on page 2-033).

- Hex display of access method PIUs

At times it may be necessary for the CE or systems programmer to view the actual hex representation of the captured PIUs. This facility is available for each of the session types supported.

NCP Traces (Channel Adapter, Session, GPT, and Branch)

NCP CHANNEL ADAPTER TRACE

The channel adapter trace is an optional debugging aid that stores certain fields from the channel control block into a trace table. A maximum of 256 trace entries can be specified at SYSGEN time.

The channel adapter trace can be activated or deactivated from the 3727 console using the CCU functions (see 3725 Problem Determination and Extended Services Vol. A06).

The trace table can be examined in a storage dump or by using the CCU display facilities at the MOSS console (3727). For details of control blocks and tables, refer to ACF/NCP Program Reference Handbook.

Any combination of up to six channels can be traced.

NCP SESSION TRACE

NCP continuously captures the last sequence/reference numbers sent to and from a boundary node resource. When the session ends, if session trace is enabled for the resource, the sequence/reference number plus additional information from control blocks of the NCP are sent unsolicited to the access method CNMI where the Network Logical Data Manager (See NLDM) formats and displays this information.

NCP session trace is totally independent of any other NCP trace facilities, including the generalized PIU trace function added to the NCP for this release.

Session trace can be activated and deactivated via a REQMS RU from any host that is the owner of the NCP. The PIU sequence/reference number capturing for support of the session trace function will operate continuously after the NCP is loaded and initialized. Storage for saving of sequence/reference numbers is allocated for each resource when the NCP is generated.

NCP provides the session trace NLDM function of capturing, continuously, PIU sequence numbers flowing to or from each SNA boundary node resource (LUs and PUs) for each SSCP-NCP session. For pre-SNA boundary node resources, unique reference numbers and the FIO PIUs are captured continuously.

Both numbers for each resource are sent to the NLDM application using a solicited/unsolicited RECFMS type 04 RU. Unsolicited RECFMSs are sent at session termination, (LU-LU, SSCP-PU), but not for SSCP-NCP PU sessions, for SNA resources and only when an abnormal or error condition is detected for pre-SNA resources.

Solicited RECFMSs are sent to NLDM when an REQMS type 4 is received for a specific resource.

Trace can be activated for the following resources:

- NCP physical services (PU)
- SDLC type 1 and 2 physical units (PUs)
- SDLC logical units (LUs)
- Start-stop devices (DVBs)

Any type of resource not included in the above list is not eligible for trace activation. The following are examples of noneligible resources:

- All NEO programmed resources
- SDLC links
- Start-stop links
- BSC links
- SDLC type 4 stations

NCP GENERALIZED PIU TRACE (GPT)

Overview

The generalized PIU trace facility allows the network operator to select a network addressable resource for the NCP to trace. NCP traces all header and limited data sent between the boundary function and the virtual routing function of the NCP. Trace records are sent from the NCP to the SNA access method for logging and later formatting by ACF/TAP.

Tracing Outbound PIUs

Each PIU is traced in its FID4 format immediately before the NCP delivers the PIU to the connection point manager (CPM) of the resource. The presence of the PIU in the trace data guarantees that the PIU was successfully received by the NCP, passed all explicit and virtual routing requirements, and was destined for a known boundary node resource. It does not guarantee that the PIU was actually sent on a data link control functions.

Tracing Inbound PIUs

Each PIU is traced in its FID4 format after the boundary node has delivered the PIU to the virtual routing component. 'Inbound' here means 'to the virtual route function', not necessarily from the resource being traced. For example, an activate physical request to a PU type 1 resource is turned around by the NCP boundary node and is not actually delivered to the device. This activate physical request is traced in the outbound flow, and the response is traced in the inbound flow.

Limitations

The number of bytes traced varies depending on resource type. The number of bytes traced is listed below and includes the FID4 header.

Resource Type	Number of Bytes Traced
SNA Boundary node LU	40 (TH + RH + 11 bytes of RU)
SNA Boundary node PU	40 (TH + RH + 11 bytes of RU)
BSC 3270 display	44 (TH + RH + 15 bytes of RU)
BSC 3270 controller	44 (TH + RH + 15 bytes of RU)
NCP PU	40 (TH + RH + 15 bytes of RU)
NEO Programmed PU	40 (TH + RH + 11 bytes of RU)
NEO Programmed LU	40 (TH + RH + 11 bytes of RU)

The maximum number of resources that can be traced simultaneously is limited by buffer and cycle utilizations considerations. The NCP always accepts a request to activate GPT (assuming validity checks are passed) even when performance is degraded.

NCP BRANCH TRACE

The mechanism of the branch trace facility allows the CCU to record, in a predefined buffer, the non-sequential operations occurring in the flow of the CCU control program. When a branch occurs in the CCU, the 'come from' and 'go to' addresses are stored in the buffer as well as the corresponding 'come from' and 'go to' program level.

The branch trace buffer can be displayed on the MOSS console (3727) or dumped to the host.

The branch trace is started from the 3727 console (see 3725 Problem Determination and Extended Services Vol. A06).

This trace is more specifically oriented to software activities. However, it can be used by the CE for problem determination or isolation activities.

NCP Traces (Address, Line, and Transmission Group)

NCP ADDRESS TRACE

Address trace is a service aid that records the contents of selected areas of controller storage and selected external registers at each successive interrupt. Certain types of interrupts, or all interrupts, can be recorded. The network control program records the trace data in a trace table in control storage. When the desired data has been recorded, the contents of the trace table can be displayed on the console. For details of control blocks and tables, refer to ACF/NCP Program Reference Handbook. The contents of controller storage can be transferred to the host processor via the Dump program and the contents of the trace table examined in the listing of the dump.

The address trace facility allows the user to select any combination of up to four external registers, general registers, and storage halfwords whose contents are to be recorded each time data is loaded from or stored into a specified storage address at a specified program level.

Address trace is activated or deactivated from the 3727 console for the user specified storage address or external register, using the control program procedures (see 3725 Problem Determination and Extended Services Vol. A06).

NCP LINE TRACE

At the boundary between the CCU and the CSP, the NCP parameter and status information (PSA) as well as line data are placed into line trace buffers by NCP. This information is then transferred to the host where ACF/TAP retrieves and prints it (see ACF/TAP User's Guide, SC30-3115).

A new parameter added to the NCP line trace specifies the amount of data that is to be traced per I/O operation. This parameter can indicate that all data is to be recorded, or that zero to 254 bytes per I/O operation can be traced.

X'FF' indicates all data to be traced.

Note: For starting or ending trace, see ACF/NCP/SSP for the IBM 3725 Diagnosis Guide, SC30-3181.

EP LINE TRACE

The line trace facility of the emulation program is a service aid that permits detailed analysis of the operation of any telecommunication line controlled by the program. This facility records operating parameters of a line each time a level 2 or level 3 interrupt occurs for that line. The program accumulates this information in a trace table within the controller storage. The line trace records can be examined in a storage dump or by using the CCU display facilities at the 3727 console.

The line trace facility does not interfere with normal operation of the telecommunication line. Performance may be diminished somewhat because of the additional processing needed each time a character service interrupt occurs for the line or lines being traced. The amount of decrease in performance depends on how heavily the communication controller is currently loaded. Inclusion of the line trace facility has no effect on performance except when a line is being traced.

Line trace is started or stopped by the host Dynadump utility or by the MOSS/CCU data exchange procedure (CCU services). The 'option' statement of the Dynadump allows the CE to request an EP line trace (with or without data), or a scanner interface trace (with or without data), or both.

A maximum of 16 SIT traces can run concurrently. There is no limit to the number of EP line traces that can be run. In a PEP system, EP can run 16 SIT traces in addition to the eight traces that can run in NCP.

NCP TRANSMISSION GROUP TRACE

The line trace with the transmission group (TG) option provides the facility to trace all SNA-dependent information, such as: SNA headers, SNA requests, and SNA responses, as they enter and leave an NCP on a cross-domain link. The facility includes the transportation of the traced data to an SNA 4. SSCP (TCAM/VTAM) and the formatting and printing of the traced data at the host by ACF/TAP.

In the NCP, this facility is a special case of the existing line trace facility and as such the TG trace is tightly coupled to a cross-domain link. Activation and deactivation are requested by referencing one and only one of the links in the TG to be traced. Both the TG PIU trace for all links in the TG, and the line trace for the referenced link in the TG, are activated. Additional links in the TG may be line traced in the present mode of activation. The TG trace continues as long as the line trace on the referenced line continues and the line is not removed from the TG.

NTRI TRACES

NCP/Token-Ring Interconnection program (NTRI) provides the user with three traces: Line trace, IOH trace and TIC trace. The trace function records activity on a designated physical link. The information is then transferred to the host, where ACF/TAP retrieves and prints it (see ACF/TAP User's Guide, SC30-3115 for details). It is used later to isolate a problem into the NTRI or TRM/TIC area. An NTRI link is a high-speed line and one line may be traced at a time. The trace function is supported only for physical links.

LINE AND IOH TRACE.

The traced IOHs are the ones dedicated to a TIC and the ones dedicated to the TRM that control this TIC. The IOHs are traced into an IOH trace area and then reported to the host by the line trace process. The IOH trace is activated/deactivated with the line trace.

ACF/TAP EDITING AND RU FORMATS

The data of the different traces are transferred to the host using RECTRD PIUs. ACF/TAP receives the LINE and IOH trace records in the following format:

GTF HDR	VTAM HDR	RECTRD RU	Line/IOH element	. . .	Line/IOH element
				. . .	

ACF/TAP receives the TIC internal records in the following format:

GTF HDR	VTAM HDR	RECTRD RU	TIC intern element	. . .	TIC intern element
				. . .	

Each record has a GTF header, followed by a VTAM header, followed by a RECTRD RU, followed by a number of TIC internal trace, line and IOH elements. NTRI is only concerned about the RECTRD RU header, and the line/IOH elements, and the TIC internal trace elements.

(See ACF/NCP/SSP for the 3725 Diagnosis Guide, SC30-3181).

TIC INTERNAL TRACE.

TIC internal trace data are transferred to NTRI as MAC frames. To start/stop TIC internal trace, NTRI sends a new SCB command. Line trace and IOH trace run together and are activated/deactivated from the host or by the NTRI normal services in case of a slowdown.

ACTIVATION OF TRACES

In NCP three types of trace can be activated: Line trace, Scanner trace and internal trace (including TG). Line trace and IOH trace are activated at the same time, that is, started with the same PIU. NTRI has to activate two traces: Line/IOH trace and TIC internal trace. They are mapped as follows:

- Line and IOH traces are activated by ACTTRACE RU with type=LINE.
- TIC internal is activated by ACTTRACE RU with type=SIT.
- A negative return code is answered on ACTTRACE of TG.

TRACE OBJECTIVES

The NCP scanner interface trace (SIT) objectives are:

- Problem determination between 3725 hardware and NCP/EP software
- Problem isolation in the transmission subsystem and IOC areas (CSP and its microcode, FES, LIC, IOC bus).

This trace allows you to get, for each line interface, data and parameter information from both sides of the CSP.

Between FES and CSP, the values traced are transferred data and FES status.

Between CSP and CCU, the IOH, parameters, and status of each scanner command are traced. The NCP/EP line trace provides a correlation between both traces when they are run concurrently.

The trace information is as follows:

- To and from the control program: IOH, parameter and status
- From the FES: data

The trace information is transferred from the CSP to the CCU by cycle steal. It is stored in the host in the same data set as the NCP/EP line trace for later retrieval, formatting, and printing using ACF/TAP or Dynadump (EP).

In addition to the NCP/EP record types, new trace record types have been defined for the SIT.

A new parameter added to the access method line trace command in the host starts the scanner interface trace alone or together with the NCP line trace. Additionally, it is possible to specify in a parameter of this command the number of data bytes to be traced for each message.


In an EP environment, the starting and stopping of the SIT is done using the host Dynadump facility in a similar way to the EP line trace, or using MOSS/CCU data exchange procedure. The Dynadump formats the trace records so that they are accepted as input to ACF/TAP.

The OPTION statement of the Dynadump allows the CE to request a SIT trace (with or without data), an EP line trace (with or without data), or both.

Note: For starting or ending trace, see ACF/NCP/SSP for the IBM 3725 Diagnosis Guide, SC30-3181.

Using NCP SIT with NCP Line Trace: NCP V2 R1 has two types of traces for isolating telecommunication line problems: scanner interface trace (SIT) and line trace. A maximum of eight traces can be active at one time (these can be any combination of SIT and line traces). Both traces are started from the host. This requires an additional indicator on the activate trace and deactivate trace RUs to specify SIT. The amount of data to be traced by line trace and SIT per I/O operation may be specified by the SSCP in the ACTRACE PIU.

The line trace is a trace of the control program/CSP boundary as seen by the control program. The scanner interface trace is a trace of the control program/CSP/FES boundaries as seen by the CSP. SIT recording is a new function in NCP V2 R1.



Legend:

— Line interface traced by line trace

■ Interface trace by SIT

Correlating Line Trace and SIT: When it is necessary to run both line trace and SIT concurrently, the trace correlation count (TCC) in the parameter zone of the NCP parameter status area (PSA) can be used to correlate the line trace entry for an IOH operation with the SIT entry for that operation.

The TCC is used in the parameter zone of the PSA when line trace is in progress for a telecommunication line. Each time the NCP to CSP (IOH command) or CSP to NCP transfer completes, NCP line trace captures the parameter zone, then increments the TCC by 1. The trace reader can then use the TCCs to match line trace entries with the corresponding SIT entries.

TRACE LIMITATIONS

For SDLC lines the limitations are as follows:

- Up to 9600 bps, 4 interfaces per scanner
- Above 9600 bps, 2 interfaces per scanner
- Up to 16 interfaces for the whole TSS (eight concurrent traces). This limit, imposed by the NCP, is shared between the NCP line trace and the SIT.

The following table shows the scanner performance possibilities when the SIT is running. The additional checkpoint trace does not modify the results. The values are indicative and do not stand as specifications for the performances.

Protocol and Line Speeds (bps)	Maximum Number of Lines		
	No Trace Activity	Trace Activity Lines Being Traced	Other Lines
SDLC FDX			
2 400	32	2	30
4 800	32	2	27
9 600	16	2	11
14 400	10	2	5
19 200	8	1	5
19 200	8	2	3
57 600	2	1	0
64 000	2	1	0
256 000	1	1*	0
SDLC HDX BSC			
2 400	32	2	30
4 800	32	2	30
9 600	32	2	27
14 400	20	2	16
19 200	16	2	11
57 600	4	1	2
64 000	4	1	1
256 000	1	1*	0
Start-Stop			
2 400	16	2	12
4 800	8	2	4
9 600	4	1	2
14 400	2	1	1
19 200	2	1	0
ALC FDX			
2 400	16	2	14
4 800	8	2	6
9 600	4	1	3
14 400	3	1	1
19 200	2	1	0

* In the case of high-speed lines, the traced data is limited to 40 bytes per SDLC frame.

High-Speed Trace Limitations for NCP/SIT

The following tables show the maximum number of lines which can be active during a trace, based on the following assumptions:

- Duplex lines
- 50% utilization
- 40-byte trace records
- 70% maximum CCU and I/O bus utilization
- Speed: 256 kbps for each line (one line per scanner)
- Using NCP V2-R1

Note: The following figures are indicative only.

2000-Byte Blocks (PIUs)

	No Trace	LT	SIT	LT/SIT
No trace	7	N/A	N/A	N/A
One line traced	N/A	7	7	7
All lines traced	N/A	6	6	5

500-Byte Blocks (PIUs)

	No Trace	LT	SIT	LT/SIT
No trace	4	N/A	N/A	N/A
One line traced	N/A	3	3	3
All lines traced	N/A	2	3	2

Note: Performance analysis shows that one 256-kbps duplex line or two half-duplex lines may be traced with full data on the NCP line trace. This condition may require other lines to be disconnected in the controller.

NCP SIT (Part 2 of 4)

NCP SIT RECORD UNITS

The trace information is stored in the CCU buffer areas. Every IOH or IOHI instruction processed for the interface being traced causes a trace record unit (TRU) to be stored. Each TRU contains the IOH/IOHI, the parameter area of the PSA, the data (if any) as exchanged between the scanner and the line interface, and the status area of the PSA, in that order. If checkpoint trace has not been deactivated from the MOSS, checkpoint data, comprising the interface control block (ICB) control and status information, is also stored.

The scanner moves the trace data into the current buffer (or buffer chain) until it is completely filled. TRU recording may be continued by providing a new buffer (or buffer chain) via a second trace command.

TRU Formats

The TRU field formats are as follows:

IOH/IOHI Field

Byte 0 contains the character 'I' identifying an IOH/IOHI field.

Bytes 1 and 2 contain the byte count (always 5).

Byte 3 contains an X'00' pad byte.

Bytes 4 and 5 contain the first halfword of the IOH/IOHI instruction.

Bytes 6 and 7 contain the second halfword of the IOH/IOHI instruction.

Parameter Field

Byte 0 contains the character 'P' identifying a parameter field.

Bytes 1 and 2 contain the data count (equal to 16 for a normal command or 6 for a 370X emulation command).

Byte 3 contains an X'00' pad byte.

Bytes 4 through 19 (normal mode) or 4 through 9 (emulation mode) contain the parameter area of the PSA.

Data Field

Byte 0 contains the character 'R' for received data, or 'X' for transmitted data.

Bytes 1 and 2 contain the data count (depends on the length of the data burst).

Byte 3 contains an X'00' pad byte.

Bytes 4 through 'n' contain the data burst. The data burst is a maximum of 8 bytes long, rounded to the next even (halfword) count. The true burst count may be found in the FES status.

The remaining bytes contain the scanner status.

Status Field

Byte 0 contains the character 'S' identifying a status field.

Bytes 1 and 2 contain the data count (equal to 12 for a normal command or 6 for an emulation command).

Byte 3 contains an X'00' pad byte.

Bytes 4 through 15 (normal mode) or 4 through 9 (emulation mode) contain the status area of the PSA.

Checkpoint Data Field

Byte 0 contains the character 'C' identifying a checkpoint data field.

Bytes 1 and 2 contain the byte count (always 5).

Byte 3 contains an X'00' pad byte.

Bytes 4 and 5 contain the scanner micro-code checkpoint entry address.

Byte 6 contains the ICB status byte.

Byte 7 contains the ICB control byte.

Overrun Field

Byte 0 contains one of the characters 'I', 'P', 'R', 'X', 'S', or 'C' identifying the type of TRU that the scanner was trying to store when the overrun occurred.

Bytes 1 and 2 contain the byte count (always 0).

Byte 3 contains an X'00' pad byte.

Notes:

1. The first 4 bytes of every field contain a 1-byte field identifier, a 2-byte count of the data contained in each field, and a pad character to round out the header field to 4 bytes.
2. The data count field specified in the TPSA is reinitialized each time there is a turnaround on the line, or a new SDLC frame is transmitted or received.

SIT Trace Records

Record Identifiers

Identifiers (ID) added to SIT help to differentiate between records.

ID

I	IOH	(SIT)
R/X	Data	(SIT)
P	Param Area	(SIT)

(See page 2-040 for field explanation.)

Note: To find the actual format of an edited SIT, or the description of the PSA field, refer to ACF/NCP and SSP Diagnosis Guide, Chapter 6.

NCP SIT (Part 3 of 4)

LINE CHARACTER TRACE

SDLC (Normal Mode)

During reception, the non-flag characters, the CRC characters, and the first ending flag are available in the data bursts. The leading flags before the first non-flag character are deleted by the FES.

During transmission, all the flags, the non-flag characters, and the pads are in the traced burst. The CRC characters are built by the FES and not available in the burst.

BSC (Normal Mode)

During reception, the following characters are not available in the burst because they are deleted by the FES:

- The phase SYN characters and all the following SYNs up to a non-SYN character
- All the SYN characters when in control mode or in normal text
- All the DLE-SYN characters and the first DLE of a DLE-DLE sequence when in transparent text mode
- The BCC characters

Note: The EIB (if requested) is built by the FES and inserted in the burst after an ITB character.

During transmission, all the SYN and control characters, the data, and the pads are available in the traced burst. The following are not traced because built by the FES:

- The SYN-SYN or DLE-SYN sequence generated every second
- The continuous SYN or DLE-SYN sequences generated when underrun occurs
- The BCC characters

BSC (Character Mode)

During reception, all the received characters are available in the parameter-status (PSA) except the phase SYN-SYN sequence.

During transmission, all the transmitted characters are available in the PSA except the SYN-SYN or DLE-SYN sequence generated when an underrun occurs.

Start-Stop (Character Mode)

All the received and transmitted characters are traced in the PSA. The start and stop bits are not available because they are deleted and inserted respectively by the FES.

LINE ERROR TRACE

The following tables gives the traced line errors.

1. The first column list the line error types.
2. The second column shows the errors recorded in the FES status associated to the burst.
3. The third column shows the errors that are recorded in the extended interrupt register (EIRR). The EIRR is not traced.
4. The last column shows how the error is recorded in the traced NCP/EP command status.

SDLC

Type of Line Error	Recorded in		Recorded in the Command Status as:
	FES Status	EIRR	
Extra bits inserted or deleted in flag streams	Yes		CRC check or receive text timeout (receive only)
Extra bits inserted or deleted in data streams	Yes		Flag off boundary, abort (receive only), or idle
Change in bit values	Yes		CRC check (receive only)
Line broken	Yes		Idle or abort (receive only)
Other side aborted	Yes		Abort (receive only)
Modem errors	Yes	Yes	Modem check and LCS
Hardware error in CSP, FES, LIC, or ICC		Yes	Internal box error and LCS
Nothing received after turn around			Timeout and LCS (receive only)

BSC

Type of Line Error	Recorded in		Recorded in the Command Status as:
	FES Status	EIRR	
Extra bits inserted or deleted in control mode		Yes	Timeout (receive only)
Extra bits inserted or deleted in text mode	Yes		CRC check (receive only)
No SYN received at least every one second and for no more than 3 seconds		Yes	Timeout (receive only)
Line broken			Timeout (receive only)
Modem errors	Yes	Yes	Modem check and LCS
Hardware error in CSP, FES, LIC, or ICC		Yes	Internal box error and LCS
Nothing received after turn around			Timeout and LCS (receive only)

NCP SIT (Part 4 of 4)

Start-Stop

Type of Line Error	Recorded in		Recorded in the Command Status as:
	FES Status	EIRR	
Invalid stop bit	Yes		Stop bit check (receive only)
Extra bits inserted or deleted	Yes		Stop bit check (receive only)
Line broken	Yes		Stop bit check and all zero characters if a line break generates a continuous space (receive only)
Receive line break (attention) during transmission		Yes	Line break (receive only)

Microcode Checkpoint Trace

TRACE OBJECTIVES

To improve problem isolation between hardware and the scanner microcode, a checkpoint trace is provided within the scanner.

It traces predefined checkpoint addresses in the scanner microcode, when the instructions at these addresses are executed, and records predefined data. The trace output is inserted between the scanner interface trace fields, and therefore follows the SIT process.

The checkpoint trace is always ready to start at the same time as the SIT trace. If you want to stop the checkpoint trace use the TSS function, selection 9 (see page 2-378). From a user point of view (transfer to the host and printing/editing) this could be considered as a subset of the SIT.

You must correlate the trace output with the functional flowchart of each operation provided with the documentation. Any discrepancy in the microcode address sequencing points to a microcode anomaly, allowing you to take the appropriate corrective action.

SCANNER MICROCODE SEQUENCE OF OPERATION

Using the CPT trace records only and the address look-up tables. You may identify the sequence of operations that took place for a specific command.

The address look-up table that follows is an example. It lists all the microcode modules with their storage addresses for SDLC Receive and Receive Monitor commands.

ADDRESS LOOK-UP TABLE

SDLC Receive or Receive Monitor Command			
Storage Address*	Symbolic Name of Module	Process/Description	Number of Occurrences
'D1B7'	CHHCBR00	Receive or receive monitor command handling	1
'D1FC'	CHHEBA01	Prepare and cycle steal IOH parameters from CCU	1
'D24F'	CHHCBR04	Receive 1st data	0, 1
'A82F'	CHHCSEND	Ending Status (LVL 3)	1
'A8C8'	CHHCSCCU	Start CS Status to CCU (Request LVL 2 to CCU)	1
'D1B7'	CHHCBR13	Receive continue command handling	1
'D407'	CHHEBR14	Prepare and cycle steal parameters from CCU	1
'A82F'	CHHCSEND	Ending Status (LVL 3)	1
'A8C8'	CHHCSCCU	Start CS Status to CCU (Request LVL 2 to CCU)	1

* Addresses may change with the scanner microcode level

These addresses are only provided as an example. (Charts of correct operations are found in the MIM Part 2, Chapter R6.)

MICROCODE CHECKPOINT TRACE RECORDS

An identifier (C) indicates the data pertaining to the checkpoint trace within the SIT.

The IOH (SIT record) indicates the executed command, and the Address 1 (CPT record) gives the scanner storage address of the module that starts this execution of the command. Then Address 2 (CPT record) indicates the address of the second module in sequence, and so on.

ID

I	IOH	(SIT)	<--	ex. SDLC Receive or Receive Monitor Card
C	Address 1	(CPT)	<--	D1B7 (CHNCBR00 Module)
R/X	Data	(SIT)	<--	Data SIT record
P	Parm area	(SIT)	<--	Parameters SIT record
C	Address 2	(CPT)	<--	D1FC (CHHEBA01 Module)

↓

Until end of Trace

CPT Record Contents

C	ADDR = D6AC							
	Bytes 0	Byte 1	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7
							XXXX4567
C	Address			Status	Control			

Identifier Checkpoint entry address ICB status (Note 1) ICB control (Note 2)

Notes:

1. For ICB status and control information, see page 13-554.
2. If a hardware/microcode error occurs, bits 4, 5, 6, and 7 indicate the type of error. Otherwise, the status bits are all zero.

Trace Summary

TRACE COMPARISON

	Line Trace	Scanner Interface Trace	Checkpoint Trace
Goal	Check communication line functions	Check scanner functions in correlation with NCP/EP line trace	Problem isolation between the scanner micro-code and scanner hardware
Method	Trace data and control information in CCU	Trace data and control information for each IOH	Internal trace of key entry points for each IOH
Limitations	1 line at a time for EP; 8 lines at a time for NCP	Max 4 interfaces up to 9600 bps. Max 2 interfaces up to 256 kbps (see note)	Max 4 interfaces up to 9600 bps. Max 2 interfaces up to 256 kbps (see note)
Customer Impact	In line mode (performance impact)	In line mode (performance impact)	In line mode (performance impact)
Start-Stop	Host (NCP/EP) or 3727 console for EP	Host (NCP/EP) or 3727 console for EP	Host (with SIT) Option select from MOSS
Output	Host	Host	Host
Hard Copy	Yes	Yes (ACF/TAP)	Yes (SIT imbedded)
Doc Support		Access method for operation. ACF/TAP Dynadump for output	MIM Part 1 MIM Part 2
Contents	IOH Data Parameter A Status A	IOH TCC CCU Parm/Status FES Status Data	CSP Address ICB Control ICB Status

Note: At 256 kbps, control information is fully traced, but data is traced only for 40 bytes.

COMMUNICATION FUNCTION TRACES

The following table summarizes the available traces for 3725 communication functions in which the 3725 might be involved.

Trace Type	Called by	Output Returned via	Users
Applications	Host	Host	Customer
VTAM/TCAM	Host	ACF/TAP	Customer or CE
Buffer	Host	ACF/TAP	Customer or CE
I/O	Host	ACF/TAP	Customer or CE
PIU	Host	ACF/TAP	Customer or CE
Internal	Host	VTAM/TCAM dump	Customer or CE
NLDM	Host	NLDM	Customer or CE
EP Line	Host/ MOSS (*)	Dynadump	Customer or CE
NCP Line	Host	ACF/TAP	Customer or CE
NCP TG	Host	ACF/TAP	Customer or CE
NCP gen.PIU	Host	ACF/TAP	Customer or CE
NCP session	Host	NLDM	Customer or CE
NCP CA	MOSS (*)	NCP dump	Customer or CE
NCP address	MOSS (*)	NCP dump	Customer or CE
Branch	MOSS	MOSS console	Customer or CE
SIT	Host	ACF/TAP/Dynadump	Customer or CE
Checkpoint	Host/ MOSS	ACF/TAP/Dynadump	CE

* Called via CCU services, or as control program procedures

More detailed accounts of host/control program tracing can be found in the following IBM publications:

- ACF/VTAM OS/VS Debugging Guide, SY27-8006
- ACF/VTAM VSE Diagnosis Guide, SY38-3020
- DOS/VSE Serviceability Aids and Debugging Procedures, GC33-5380
- ACF/VTAM DOS/VS Debugging Guide, GC27-0021
- ACF/VTAM DOS/VSE Diagnostic Techniques, SY38-3020
- ACF/VTAM OS/VS Diagnostic Techniques, SY38-3029
- DOS/VS2 MVS/VTAM Debugging Guide, GC27-0023
- ACF/TCAM Diagnosis, SC30-3137
- ACF/NCP Diagnosis Guide for the IBM 3725, SC30-3228

- NCP/TCAM Network User's Guide, GC30-3009
- NLDM Diagnosis, GC30-3166

LOGREC DISPLAY WITH EREP

The environmental recording, editing, and printing program (EREP) edits and prints statistical error records that have been stored on the LOGREC file of the recorder file (SYSREC) by the recovery management support recorder (RMSR).

Note: EREP is not available on System/370 Models 115 and 125 that do not support RMSR. For ACF/VTAM, EREP records permanent errors on the channels that connect local 3270 devices or communication controllers. It also maintains miscellaneous data recorder (MDR) records from communication controllers. These contain error information for lines or logical units connected to the controller.

For the 3725/3726 communication controller, the objective of EREP is to read LOGREC for RECMS with equipment check for line-related errors. (See "Maintenance Philosophy" page 1-070).

For information on how and when to run EREP, refer to OS/VS Environmental Recording, Editing, and Printing (EREP) Program, GC28-0772.

FILE TRANSFER TO THE HOST

For information concerning how, when, and which files to transfer to the host, refer to page 2-450 and to the 3725 Problem Determination and Extended Services (Vol. A06).

Wrap Tests Controlled from the Host

The following figure shows the different wrap test possibilities on the communication link, with the progression of testing procedures from the TSS or TRSS to the terminal.

The wrap tests controlled from the MOSS are shown for comparison on page 2-046.

WRAP TEST AT TAILGATE LEVEL


The wrap test at the tailgate level, referred to as "Wrap Block/Wrap Cable" in the figure at right, is available in maintenance mode only. (See page 2-048 for details.)

MODEM OR NTT CABLE

The wrap tests at modem or NTT cable level are part of the line functions and are described in the 3725 Problem Determination and Extended Services (Vol. A06).

Notes:

1. The primary modems are 3865 Model 1 modems equipped with the data multiplexing feature.
2. The telecommunication line is a 4-wire nonswitched line.
3. The master secondary modem is a 3863 or 3864 Model 1 equipped with the tail circuit attachment accessory. This device allows the recognition of the "raise IC" pattern to which the primary modems are transparent.
4. The tailed secondary modem is a 3864 or 3865.




TOKEN-RING WRAP TESTS:

Using NCP/TRI

Under NCP/TRI a wrap test is performed at each TIC open command processing as a first step before inserting itself into the ring. The TIC internal lobe media test, tests the ring up to and including the local IBM 8228 Multistation Access Unit or equivalent (the 8228 is a wiring concentrator). Also it tests the ring up to the point where it is unplugged before the 8228. (I.E. At the tailgate, at the wall connector, etc.) The lobe media test is only invoked on the open command and is not performed as a result of the reset or initialization commands. Note that a disconnected cable during the lobe media test will cause a lobe wire fault check to appear in both the display token-ring status function (See page 2-386) and the ring status field (field E) of the token-ring interconnect function (See the Problem Determination and Extended Service Guide, GA33-0014, under token-ring interconnect function.) When a lobe wire fault is detected the TIC will be frozen and the status will remain unchanged until the next open is issued.

Using TRSS diagnostics

Using the TRSS diagnostic routine TGOI, a wrap test is also performed up to and including the 8228 or up to the point at which the ring is unplugged before the 8228. (See 3725 Diagnostic Description, SY33-2027, Vol A05). However, no open command are issued by the diagnostic routine so a lobe wire fault will not be detected.



Wrap Tests Controlled from the MOSS


The wrap tests controlled from the MOSS are shown on this page only to compare them with the wrap tests controlled from the host (see page 2-044).

WRAP TEST AT TAILGATE LEVEL

The wrap test at the tailgate level, referred to as, "Wrap Block/Wrap Cable" in the figure at right, is available in maintenance mode only. (See page 2-048 for details.)

MODEM OR NTT CABLE

The wrap tests at modem or NTT cable level are part of the line functions and are described in the 3725 Problem Determination and Extended Services (Vol. A06).



Notes:

1. A line position can be plugged with a line cable, or be without a line cable, or can be plugged with a wrap block (LIC type 1, 2, 4A, or 4B), or with a wrap cable (LIC type 3). The CDF for each line must be updated accordingly when running the diagnostics.

When the TSS IFTs are run, the hardware for a selected line is:

 - a. Tested up to the LIC drivers if the line cable is present.
 - b. Tested up to the LIC and ICC (if present) card level for a line without cable.
 - c. Fully tested if a wrap block or a wrap cable is present on the selected line. Plugging a wrap block or wrap cable and updating the CDF automatically selects the manual intervention section QC.
2. During LIC wrap mode operation, the transmit data line and the control lines are not deactivated at the modem interface.
3. Although this is not a user-activated test, an "echo-check" mechanism (inline) checks the transmitted data in wrap mode (refer to "LIC Driver Check", page 13-261).
4. For selection of the NTT manual intervention routine QD, refer to 3725 Diagnostic Descriptions, SY33-2027 (Vol. A05).
5. In these wrap modes, the clocking is taken from the 480-Hz clock. Therefore, an error such as an overrun, detected at the operational speed, might not occur at the above testing speed.
6. If the cable is NTT with the connector switch set to "operate", the test indicator (TI) signal is not forwarded to the connected modem, so that the received pattern differs from the expected one.

Wrap Test at Tailgate Level

This wrap test level is available with the line functions (select 1) in maintenance mode only.

The tailgate level is a third option that you can select at wrap test initialization. It is run in a similar way to that for modem level or cable level. These are described in detail in the 3725 Problem Determination and Extended Services (Vol. A06). The following only gives additional information specific to tailgate level, and makes reference to the above manual.

WRAP TEST INITIALIZATION SCREEN

In Maintenance mode, the initialization screen offers three wrap level options:

1: MODEM
2: NTT CABLE
3: TAILGATE

CONTROL LEAD WRAP TEST PATTERN SELECTION SCREEN

A default pattern is available with all LIC types for the tailgate level wrap (whereas with LIC type 1 it is available only for modem or NTT cable level wrap). These default patterns are as follows:

LIC type 1:

TRANSMIT PATTERN: 11111011 10000011
EXPECTED PATTERN: 11111011 10100011

LIC type 2:

TRANSMIT PATTERN: 11101011 10000011
EXPECTED PATTERN: 11110011 10100011

LIC type 3:

TRANSMIT PATTERN: 11101011 10000011
EXPECTED PATTERN: 11011011 10000011

LIC type 4:

TRANSMIT PATTERN: 11000011 10000011
EXPECTED PATTERN: 01000011 00000011

If you prefer to create your own pattern (instead of using the above default patterns) as proposed by option 3 of the pattern selection screen, you should refer to the 3725 Problem Determination and Extended Services for control lead bit definitions. This manual also gives the bit meanings for the above default patterns.

WRAP TEST START SCREEN

This screen gives the actions to be taken before the test is started. These depend on the level option you selected at wrap test initialization.

With the option TAILGATE, the prompt on the screen is:

- PLUG APPROPRIATE WRAP FACILITY AT TAILGATE, THEN PRESS SEND TO START THE WRAP

The wrap facility requires one of the following CE tools (refer to Chapter 3 for details):

- Wrap block, part 1733977, for LIC types 1, 2, 4A, and 4B
- Wrap cable, part 1733979, for LIC type 3

Alarm/Alert List

ALARMS

When the operator console is powered on:

- You are informed that an alarm is generated by an audible alarm and by the MOSS Message lamp on the control panel.
- When an alarm is already displayed, you are informed that another one is waiting for display by the alarm indicator (an M on line 24).

When the operator console is powered off, you are informed that an alarm is waiting for display by the MOSS Message lamp on the control panel. Power on the operator console and the alarm will appear on line 24 of the screen.

Alarms are also recorded in the BER file. You can display them using the error log function, described in Chapter 2.

The alarm appears on line 24 and remains until you display the next one by pressing MSG. Up to five alarms may be stacked. If a sixth one is generated, it is stacked but the oldest one is erased.

Pressing MSG when no alarms are waiting clears the alarm area.

3725 ALARM MESSAGES

A0	MOSS IML EXCEPTION xxx yyy zzz	hhmsss
A2	MOSS RECOVERABLE ERROR, TRANSFER DUMP	hhmsss
A3	DISKETTE DOWN, DO NOT ATTEMPT TO IPL	hhmsss
A4	DISKETTE MEDIA ERROR	hhmsss
A6	MOSS OFFLINE, ALERT SENT	hhmsss
A7	HARDWARE ERROR, 3725 RE-IPL	hhmsss
A8	CONTROL PROGRAM ABEND xxxx 3725 RE-IPL	hhmsss
A9	CHANNEL ADAPTER x DOWN	hhmsss
A10	GENERAL IPL CHECK	hhmsss
A11	SCANNER xx DOWN (LINES xxx-yyy) IML SCANNER	hhmsss
A12	SCANNER xx DOWN (LINES xxx-yyy) IML SCANNER	hhmsss
A13	SCANNER xx DOWN (LINES xxx-yyy) IML SCANNER	hhmsss
A14	SCANNER xx DOWN (LINES xxx-yyy) IML SCANNER	hhmsss
A15	LINE ADAPTER xxx DOWN	hhmsss
A28	TRM xx DOWN (TIC 1-4)	hhmsss
A29	TIC x DOWN ON TRM xx	hhmsss

ALERTS

For a complete description of:

- VTAM alerts, refer to ACF for VTAM, Messages and Codes, SC27-0467.
- TCAM alerts, refer to ACF TCAM release 4 Messages, SC30-3140.

Alerts related to 3725 alarms except alerts IST757E and IST761E, for which there is no alarm.

VTAM ALERT MESSAGES

IST757E	MOSS UNAVAILABLE - HARDWARE ERROR
IST758E	MOSS RELOADED - HARDWARE ERROR
IST759E	MOSS DISKETTE UNUSABLE
IST760E	MOSS DISKETTE HARDWARE ERROR
IST761E	MOSS CONSOLE UNAVAILABLE
IST762I	MOSS IN MAINTENANCE MODE
IST763I	PHYSICAL UNIT RELOADED - HARDWARE ERROR
IST764I	PHYSICAL UNIT RELOADED - PRIOR ABEND CODE WAS xxxx
IST765E	CHANNEL ADAPTER x UNAVAILABLE - HARDWARE ERROR
IST767E	SCANNER xx (yyy - zzz) UNAVAILABLE - HARDWARE ERROR
IST768E	SCANNER xx (yyy - zzz) UNAVAILABLE - HARDWARE ERROR
IST769E	SCANNER xx (yyy - zzz) UNAVAILABLE - SOFTWARE ERROR
IST770E	SCANNER xx (yyy - zzz) UNAVAILABLE - SOFTWARE ERROR
IST771E	SCANNER xx LINE xxx UNAVAILABLE - HARDWARE ERROR

TCAM ALERT MESSAGES

IED301E	3725 MOSS UNAVAILABLE - HARDWARE ERROR
IED302E	3725 MOSS RELOADED - HARDWARE ERROR
IED303E	3725 MOSS DISKETTE UNUSABLE
IED304E	3725 MOSS DISKETTE - HARDWARE ERROR
IED305E	3725 MOSS CONSOLE UNAVAILABLE
IED306I	3725 MOSS IN MAINTENANCE MODE
IED307I	3725 RELOADED - HARDWARE ERROR
IED308I	3725 RELOADED - ABEND xxxx
IED309E	3725 CHANNEL ADAPTER x UNAVAILABLE - HARDWARE ERROR
IED311E	3725 SCANNER xx (yyy - zzz) UNAVAILABLE - HARDWARE ERROR
IED312E	3725 SCANNER xx (yyy - zzz) UNAVAILABLE - HARDWARE ERROR
IED313E	3725 SCANNER xx (yyy - zzz) UNAVAILABLE - SOFTWARE ERROR
IED314E	3725 SCANNER xx (yyy - zzz) UNAVAILABLE - SOFTWARE ERROR
IED315E	3725 SCANNER xx LINE xxx UNAVAILABLE - HARDWARE ERROR

NPDA MESSAGES

For a complete description, refer to Network Problem Determination: User Action Guide, SC34-2032.

NPDA MESSAGES

BACKUP TIMEOUT: RING INTERFACE COUPLER
BACKUP TIMEOUT: RING MULTIPLEXER
DEADMAN TIMEOUT: RING INTERFACE COUPLER
HARDWARE ERROR: CHANNEL ADAPTER
HARDWARE ERROR: COMMUNICATION CONTROLLER RE-IPLD
HARDWARE ERROR: LINE ADAPTER
HARDWARE ERROR: SCANNER
INITIALIZATION FAILURE: RING INTERFACE COUPLER
INITIALIZATION FAILURE: RING SUBSYSTEM ATTACHMENT
MOSS HARDWARE DOWN - IPL SHOULD NOT BE TRIED: MOSS
MOSS RECOVERABLE ERROR - TRANSFER MOSS DUMP: MOSS
MOSS DISKETTE DOWN - IPL SHOULD NOT BE TRIED: MOSS
MOSS DISKETTE ERROR: DISKETTE MEDIA
MOSS CONSOLE UNAVAILABLE: MOSS CONSOLE/ADAP/CABLE
MOSS OFFLINE: MAINTENANCE MODE
NCP LEVEL 1 ERROR: RING MULTIPLEXER
NCP LEVEL 2 ERROR: RING INTERFACE COUPLER
NCP LEVEL 2 ERROR: RING MULTIPLEXER
SCANNER ERROR: COMMUNICATION CONTROLLER PROGRAM
SOFTWARE ERROR: COMMUNICATION CONTROLLER RE-IPLD

Online Test Group (Part 1 of 4)

The online test group is divided into two parts:

1. CA OLT responder (group 6)
2. CA OLTs

The CA OLT responder (routine MA), when loaded and running in the CCU, replies to commands from the OLTs that run in the host.

REQUIREMENTS

The following sequence must be followed:

On the 3725:

1. Load the channel adapter OLT responder from the 3725 console

On the host:

2. Load OLTEP, or IPL OLTSEP
3. Select the required OLT number

Note:

Refer to the appropriate OS OLTEP, DOS OLTEP manuals, or operator's guides, or to the OLTEP Guide for the following:

- To start the online test
- For test description and routine selection
- To run the option selection

RUNNING TIME

Load OLT responder	1 min 21 sec (Note)
CA OLT	50 sec

Note: The loading of the OLT responder takes 30 sec when the command processor has already been loaded in the CCU by a previous IOCB or CA run request.

SELECTION

For running offline diagnostics, see Chapter 1 of the 3725/3726 Diagnostic Descriptions (Vol. A05).

DIAG==>_

6

Move the cursor from its initial position (DIAG==>) to the next after each parameter is entered. To skip a parameter entry, press the --> key.

ADP#==>

Enter the selected CA number in the range:

1 to 6 for the 3725/3726
1 to 4 for the 3725 Model 2

LINE==>


(Not applicable)

OPT==>

For option display and description, see Chapter 1 of the 3725/3726 Diagnostic Descriptions.

TESTED PART (BOTH MODELS)

(It is assumed that CA1 interface A has been selected.)



Online Test Group (Part 2 of 4)

PROCEDURE

```

PROCESS  STOP-CCU-CHK SERVICE-MODE
          BYP-ADP-CHK

D:DIAGNOSTICS          U:UTILITY PGM      SP:CCU STOP   Q:DATE/TIME
E:ERROR LOG           ST:CCU START      T:TERMINATE
RT:CCU RESET

DIAG |ADP# |LINE |
1 ALL
2 CCU
3 IOCB
*4 CA |1-> 6|
*5 TSS |1->16| 0->31
*6 OLT |1-> 6|
*7 TRSS |6->16| 1-> 4

          AND                      DIAG - RUN INIT

OPT = Y IF MODIFY
OPTION REQUIRED

ENTER REQUEST ACCORDING TO THE DIAG.MENU
DIAG==> 6   ADP#==> 2   LINE==>   OPT==> N

==>

```

* For the 3725 Model 2 the display is as follows:

```

4 CA |1-> 4|
5 TSS |1-> 6| 0->31
6 OLT |1-> 4|
7 TRSS |6| 1-> 4

```

On the above screen, the CA OLT responder is selected. CA number 2 will be tested.

Press SEND to execute the request. Then:

1. Check that the All Channel Adapters Disabled light is on at the control panel.
2. At the request of the responder, and using the Enbl/Dsbl switch on the control panel, enable the channel adapter interface A or B to be tested, then press SEND.

3. The following message is then displayed:

IF ESC REQUIRED, ENTER RE THEN PRESS SEND

Enter RE to enable the ESC range of addresses and the execution of OLT sections requiring these addresses.

The following routines fail if invoked without E being entered:

T3725AK3, AK4, AK7, AM01, and AM02.

4. The following message is displayed:

PRESS SEND TO CONTINUE OR ABORT RTN TO RELEASE CA

If the host is in the "hung" state, you must comply with these instructions to release the CA.

If the host is not in the hung state, just press SEND.

Warning: The routine must not be aborted when the host is not in the hung state.

5. When the All Channel Adapters Disabled light turns off, the OLT responder is loaded and is ready to communicate with the host. "Routine MA01 ADP nn" is displayed on the 3727 operator console.

6. INTERRUPT L1 RELOAD, and

INTERRUPT L3 RELOAD

messages indicate that the responder cannot be loaded. In that case, the IOC bus and the CA diagnostic groups have to be run.

One channel adapter is tested at a time.

Online Test Group (Part 3 of 4)

CA OLT RESPONDER

The CA OLT responder runs under the control of the DCM in the MOSS and the command processor in the CCU.

CA OLTS

Selection

The OLT selection and loading procedure is described in the appendix to the host OLT documentation: 3725 Channel Adapter OLTS, internal reference D99-3725A.

D99-3725A Contents

- OLT loading and running procedures
- OLT routine description
- OLT messages
- OLT CDS description for 3725
- OLT CDS card preparation

The OLTS are numbered from 3725AA to 3725AN.

Routine List

Routine	Function Tested
T3725AA01	Check No-Op command causes channel end
T3725AA02	Check illegal commands are rejected
T3725AA03	Check ending status of WRT break
T3725AA04	Check Write IPL command and Write command
T3725AB01	Check Halt I/O (NSC, ESC)
T3725AB02	Check ending status of test I/O (NSC, ESC)
T3725AC01	Check Halt I/O (NSC)
T3725AC02	Check ending status of test I/O (NSC)
T3725AD01	Check data wrap using command chaining
T3725AE01	Check No-Op on NSC and ESC address
T3725AE02	NSC preparation busy condition
T3725AE03	NSC TIO short busy condition
T3725AE04	ESC short busy condition
T3725AE05	ESC TIO short busy condition
T3725AF01	Normal wrap mode - 16 bytes (NSC, ESC)
T3725AF02	Cycle steal mode test - 36 bytes (NSC, ESC)
T3725AF03	ETB/ETX recognition in EBCDIC mode - 36 bytes (NSC, ESC)
T3725AF04	ETB/ETX recognition in ASCII mode - 36 bytes (NSC, ESC)
T3725AF05	DLE-STX recognition in EBCDIC and ASCII (NSC, ESC)
T3725AF06	DLE remember test in EBCDIC and ASCII (NSC, ESC)
T3725AF07	SYN character monitor - pass 1 (NSC, ESC)
T3725AF08	SYN character monitor - pass 2 (NSC, ESC)
T3725AG01	Cycle steal 250-byte wrap test (NSC, ESC)
T3725AG02	Cycle steal 255-byte wrap test (NSC, ESC)
T3725AG03	Cycle steal 520-byte wrap test (NSC, ESC)
T3725AH01	Sense 3725 ID is sent to the host
T3725AI01	Circle-B decode test (NSC, ESC)
T3725AI02	2848-ETX decode test (NSC, ESC)
T3725AJ01	Check No-Op on NSC address
T3725AJ02	NSC preparation busy condition
T3725AJ03	NSC TIO short busy condition
T3725AK01	Normal wrap mode - 16 bytes (NSC)
T3725AK02	Cycle steal mode test - 36 bytes (NSC)
T3725AK03	ETB/ETX non-recognition in EBCDIC mode - 36 bytes (NSC)
T3725AK04	ETB/ETX non-recognition in ASCII mode - 36 bytes (NSC)
T3725AK05	DLE-STX recognition in EBCDIC and ASCII (NSC)
T3725AK06	DLE remember test in EBCDIC and ASCII (NSC)
T3725AK07	SYN character monitor - pass 1 test (NSC)
T3725AK08	SYN character monitor - pass 2 test (NSC)
T3725AL01	Cycle steal 250-byte wrap test (NSC)
T3725AL02	Cycle steal 255-byte wrap test (NSC)
T3725AL03	Cycle steal 520-byte wrap test (NSC)
T3725AM01	Circle-B non-decode test (NSC)
T3725AM02	2848-ETX non-decode test (NSC)
T3725AN01	Request for shutdown

OLT Running Restrictions

1. The following sections need two addresses to run (primary address = NSC, secondary address = ESC). They are:

T3725AB
T3725AE
T3725AF
T3725AG
T3725AI

If you do not specify the ESC address, these sections will be bypassed with message notification.

2. The following sections need a primary address (NSC) only. They are:

T3725AC
T3725AJ
T3725AK
T3725AL
T3725AM

If you specify the ESC address, these sections will be bypassed with message notification.

These sections are run with block multiplexer or selector channel, which uses NSC address only.

3. The following routines run under OLTSEP in a standalone environment. They are bypassed when using OLTEP.

T3725AB routine 1
T3725AC routine 1
T3725AE routines 2, 3, 4, and 5
T3725AJ routines 2, and 3

4. The following routines are automatically bypassed (with notification to the user) when you run OLTS on a 308X under NST 370XA mode:

T3725AE routines 2, 3, 4, and 5
T3725AJ routines 2, and 3

Messages

Refer to D99-3725A.

Online Test Group (Part 4 of 4)

OLT CDS FOR THE 3725

3725 CDS Card and Storage Layout

One CDS card is required for each NSC address. This card is punched as follows:

Note: A CDS must be created for each subchannel address.

CDS Byte Location (Host)	Card Columns	Contents/Description
	1	Must be blank
	2-4	CDS
	5-9	Must be blank
0-3	10-17	Native subchannel unit address in hexadecimal (right justified). Example: 0000003A
4-5	18-21	Must be blank
6-7	22-25	Class and type code for 3725: 40A0
	26-29	Must be blank
9	30-31	Flags code: (Use a 4, otherwise leave blank) Col 30: Device shared with another system CPU Col 31: The CA has a two-processor switch
10-11	32-35	Must be blank
12-13	36-39	Emulator subchannel (ESC) unit address in hex of lowest IBM 2701, 2702, or 2703 emulator line address. Example: 00F1
14	40-41	Enter number of contiguous emulator line addresses in hex, or leave blank if no ESC
	42	/ (end of CDS)

Range Definition Card Layout

Each emulation line address in the range defined by the channel data CDS card (columns 36-41) must be defined by an appropriate CDS entry, otherwise the message 'NO CDS ENTRY' will print for each undefined address. To prevent these messages from printing for unused lines (those lines not defined as an IBM 2701, 2702, or 2703 by a CDS entry), punch a dummy CDS entry for each unused address using the format that follows.

The range is a card punched as follows:

Card Columns	Contents/Description
1	Must be blank
2-4	CDS
5-9	Must be blank
10-17	Unused ESC unit address: The emulation subchannel (ESC) unit address, in hexadecimal, of an undefined emulation line address. The address range is defined by the channel data CDS card.
18-21	Must be blank
22-25	4001
26-51	Must be blank
52	/ End of range definition card
53-80	Must be blank

System Tests

Warning: To run ST370, NST-2, and ST4300

1. Only one 3725 channel adapter interface may be enabled.
2. Power on and initialize the 3725 Communication Controller (see 3725 Communication Controller, Problem Determination and Expanded Services, Vol. A06).
3. After initialization, verify that the 3725 control panel hex display is 000.

ST370

ST370 is a standalone program used as a system test on all System/370 Models and the 3033 processor. The main purpose is to test the interface and interaction of most attached devices. It is assumed all other CPU and device diagnostics are running clean. ST370 is interrupt-driven and attempts to issue SIOs and run devices as quickly as they are available. It is not designed to be a stress test and sets no criteria as to the number of times a device is run in any given period of time.

For more information on ST370, see the ST370 Users Guide, D99-0370.

NST-2

The new systems test-2 (NST-2) is a diagnostic program that supports the IBM 3031, 3032, 3033, 3081 Processors and 3041 and 3042 Attached Processors. NST-2 also supports the attached, supported I/O for each of the specified processors. User options are entered and messages are displayed using menu frames.

Menu displays and their associated help frames assist the user with the methods of entry and the options available.

NST-2 messages provide the information the user needs to understand non-machine detected errors and NST-2 responses to user input requests.

For more information on NST-2, see the NST-2 Users' Guide, D99-NST2A.

ST4300


ST4300 is a standalone system checkout program that tests the interface and interaction of most attached devices on a system. It resides on S0SPC volumes and is self-configuring.

ST4300 is derived from ST370 and operates in the same way as ST370, with some exceptions.

For more information on ST4300, refer to the diagnostic information section of the Maintenance Information Logic Volume supplied with the 4300 system.

Error Log Function (Part 1 of 4)

This section describes the generation, formatting, storage, and display of the box error records (BERs).



BER GENERATION

The BERs are created by the MOSS, from error information supplied either by NCP/EP or by the MOSS itself.

If the MOSS is offline or not operational, NCP/EP stores the error information in the check record pool (CRP) located in main storage. When the CRP is full, each attempt to store more error information increments a count in the CRP, but the error information itself is lost. This count is entered into the last BER of the CRP (field LOST in NCP/EP BERs). When the MOSS comes back online, the contents of the CRP are transferred to the MOSS (see "BER Recovery Procedures" page 2-800).

BER TYPE:

One byte points to the general area of BER occurrence

- X'01'-- MOSS- related errors (plus errors/events recorded by MOSS when MOSS takes control of the box or operations such as CCU Hardcheck, scanner errors...)

- X'10'-- Errors related to Channel Adapter operations
- X'11'-- Errors related to Transmission Subsystem operations
- X'12'-- Control Program exceptions (software errors detected by the hardware)
- X'13'-- CCU- related errors when NCP/EP has control (excluding the CCU Hardcheck)
- X'14'-- IOC Bus- related errors (when not possible to attribute them to a specific adapter)
- X'15'-- TRSS Related errors when NCP/NTRI has control.

BER ID: When the BER is created by NCP/EP, 1 byte identifies the category of error or event :

- Bit 0-- probable cause of the error
 - bit 0 = 0 the most probable cause is the Control Program
 - bit 0 = 1 the most probable cause is the Hardware or Microcode
- Bits 1,2,3-- Program level that recorded the error/event
 - 001 = Control Program level 1
 - 010 = " " " 2
 - 011 = " " " 3
 - 100 = " " " 4

When the BER is created by MOSS, a byte identifies the origin of error or event :

- ID=X'00'created by MOSS int. lvl 0
- X'01' " " " level 1
- X'02' " " Mailbox support
- X'03' " " MOSS int. lvl 5
- X'04' " " " " lvl 3
- X'05' " " " " lvl 4
- X'06' " " program lvl 7
- X'07' " " MOSS int. lvl 4 (TRSS)

Therefore the ID does not refer to error categories as in NCP/EP. For MOSS BERs, the error categories are found in another byte, either called MOSS CHECK Code or ERROR Code.

BER FORMATTING

The MOSS formats the error information together with date, time, flag, and other control bytes in the MOSS RAM 365-byte buffer as follows:

Byte	Contents
1	Total BER length in bytes
2	Flag
3	Month (in packed decimal)
4	Day (in packed decimal)
5	Year (in packed decimal)
6-9	Time of day (binary value in seconds)
10	BER type
11	BER ID
12-n	Error information (hexadecimal) (n is the total BER length)

Note: NCP supplies both date and time, but EP supplies time only.

MOSS formats the labels according to the following rules:

- Labels should be self explanatory
- Labels should refer to NCP/EP control blocks whenever applicable

The exact layout depends on the BER type and BER ID. Pages 2-340, 2-341 and 2-342 give all possible layouts and BER contents.

Example of Date and Time

Byte	3	4	5	6	7	8	9
Contents	18	12	84	00	00	F5	8F
Meaning	18th	Dec	1984	One bit=1 second 62 863 sec = 17h27m43s			

(See conversion tables page 2-470)

BER STORAGE ON DISKETTE

The MOSS stores the BERs, prepared in the MOSS RAM, on the wraparound BER file on diskette in order of arrival. The BER file can contain from 20 to 250 BERs depending on the length of the BERs.

When the BER file is full, the next BER to arrive overwrites the oldest BER (or BERs) in the BER file. No count is kept of such overwrites.

BER STORAGE WHEN DISKETTE IS NOT OPERATIONAL

When the diskette is not operational, the MOSS keeps the BERs in the 340-byte buffer in MOSS RAM. When the buffer becomes full, new BERs are lost, but a count is kept in the last byte of the buffer of the BERs lost. This is called the lost record count. The 640-byte buffer in MOSS RAM is preserved during MOSS IML. during MOSS IML. To read this buffer, see page 3-030.

When the diskette becomes operational again, MOSS stores the 640-byte buffer in the BER file on diskette, together with a BER giving the number of lost BERs in the error description line (Type 01, ID 06, error 02).

BER FILE ERASURE

The entire BER file can be erased using the DUMP/DPLY DEL utility program.

The BER file should be erased only in exceptional cases, since:

- It is not possible to erase individual BERs in the file, but only the entire BER file.
- The service personnel might need old BERs for history purposes.
- The BER file, when full, writes the most recent BERs on the diskette space used by the 'oldest' BERs (wraparound file). When the BER file is erased, a BER to this effect is logged in the file.

BER DISPLAY

Normally, you access the BER file on MOSS diskette using the error log function from the 3727 operator console. For full details, refer to the 3725 Problem Determination and Extended Services (Vol. A06).

However, if a 3725 control panel error occurs, or if a MOSS IML threshold is reached, the BERs in the MOSS RAM can be displayed on the hexadecimal display on the control panel. Refer to page 3-030.


BER display screens are explained on page 2-180.

Error Log Function (Part 2 of 4)

BER STRUCTURE


The BERs have a hierarchical structure, which allows going from the general problem area to the specific failing element. Here is a typical BER tree structure, based on a real example. We also give indications on where the information is found.

The "types" and "IDs" are given by "MOSS BER LIST" and "BER DETAIL" display screens.



APPROACH TO PROBLEM ISOLATION

The following chart explains why the BER formats and contents of NCP/EP-generated records are different from the MOSS-generated records.



THRESHOLDS

There is one BER for each error occurrence in the whole 3725 except in one case, when the Diskette drive CAC retries operations. The BER (Type 01 ID 03) contains the retry count, indicating the number of retries before success. Therefore no BER is created by threshold only (except in the particular diskette case).

Thresholds, when existing, are solely used to:

- Trigger recovery (e.g. PIO retry, MOSS re-IML...)
- Define level of box degradation (e.g. Scanner or MOSS down...)
- Generate Alarms/Alerts.

The thresholds are defined on a per case basis. This is indicated in the following "BER Types Summary" tables (Alarm or Alert column). For NCP/EP BERs subject to retries and thresholds, it is possible to see if one specific BER is the result of a threshold: the byte F (Indicator Flag) will then have bit 1 on. For the whole machine, passing a threshold does not change the BER Type and ID, except for one instance:

- When two BERs of type 11 and ID 97 (PIO errors) are generated within 100 msec, a BER type 11 and ID 98 is created.

BERs That Are Not Machine Errors

BER Type 11 ID 96:

- Scanner disconnect state. The scanner has been disconnected by a request from the MOSS operator, and is reporting this to the Control Program

BER type 15 ID 96:

- TRA disconnect state. The TRA has been disconnected by request from the MOSS operator, and is reporting this to the control program.

BER Type 11 ID A4:

- BER Type 01 ID 06 ERR 01: BER File deleted on the diskette by a MOSS Command.
- BER Type 01 ID 06 ERR 05: 3725 Re-IPL end.
- BER Type 01 ID 06 ERR 07: MOSS Offline request by the operator.

Unresolved Interrupts

The Control Program logs BERs based on "unresolved situations" following interrupts. See "BER/Alarm/Alert/ Mechanisms" starting page 2-250 for the complete list.

BER Handling Tools

BER Functions	See for details in:
Displays at console	MIM part 1, starting page 2-180
Display MOSS processor BERs at operator panel	MIM part 1, starting page 3-030
Host print request for BERs	ACF for NCP/SSP for the 3725 Diagnosis Guide Chapter "Printing NCP, MOSS, or CSP Dump"
BER format	3725 PD and Ext.Ser. Chap. 5, and MIM part 1, page 2-340
BER save and purge	MIM part 1, pages 2-409 and 2-410
BER flagging	MIM part 1, page 2-172 and MIM part 2, Chapter 2


Error Log Function (Part 3 of 4)

BER DISPLAY SAMPLE SEQUENCE

There are three kinds of BER display screens:

- BER summary
- BER list
- BER detail

When faultfinding, you should normally display the BER summary, then the BER list, and lastly the BER detail(s) appropriate to the fault. An example is given in the following figure.



BER DISPLAY PROCEDURE

With Controller Diskette

1. Press SELN AREA to position the cursor.
2. Press M followed by SEND to display the 'MAINTENANCE' primary menu.

Note: If you do not press M, the BER DETAIL screen that will be displayed will not contain coded maintenance information (see customer BER DETAIL screen).

3. Press E followed by SEND to select the 'ERROR LOG' function.

With Service Diskette

1. Press SELN AREA to position the cursor.
2. Press E followed by SEND to select the 'ERROR LOG' function. If you press E then SEND, the following screen is displayed:

BER Display Sample Sequence

SEL#	NAME	BER SUMMARY	TYPE	PENDING BERs	DATE 1ST BER MM/DD HH:MM	TOTAL IN FILE
1	CA (CHANNEL ADAPTERS)		10	0		0
2	TSS (TRANSMISSION SUBSYSTEM)		11	5	04/23 20:38	5
3	CP (CONTROL PROGRAM)		12	0		0
4	CCU (CENTRAL CONTROL UNIT)		13	0		0
5	IOC (I/O CONTROL)		14	0		0
6	MOSS (MAINTENANCE OPERATOR SUBSYSTEM)		01	1	04/21 07:00	2
7	ALARMS			1	04/23 20:40	2
8	TRSS (TOKEN RING SUBSYSTEM)		15	0		0
9	ALL (ALL FILE CONTENTS)			2	04/23 07:00	9

- ENTER SEL# OR NAME ==>

If you type 'ALL' or '8' with "BER SUMMARY" displayed, the following BER 'ALL LIST' screen is displayed:

SEL#	DATE/TIME	FLAG	NAME	TYPE	ID	ALL LIST ERROR DESCRIPTION	BER TYPE:	TOTAL:9
1	04/23 20:40		ALARMS			A11 SCANNER 01 DOWN(LINE 000-031)IPL SCAN		
2	04/23 20:40		CS1 LINE31	11	98	PIO OUT ERROR		
3	04/23 20:39		CS1 LINE31	11	98	PIO OUT ERROR		
4	04/23 20:38		CS1 LINE31	11	98	PIO OUT ERROR		
5	04/23 20:38		CS1 LINE31	11	98	PIO OUT ERROR		
6	04/23 20:38		CS1 LINE31	11	B1	SCANNER COMMAND TIME OUT		
7	04/22 08:00	FF	ALARMS		A4	DISKETTE ERROR		
8	04/22 08:00	FF	MOSS DISK	01	03	CRC ON READ DATA FILE:CHGPROC		
9	04/21 07:00		MOSS APPL	01	06	BER FILE DELETED		

*** END OF FILE ***
- ENTER SEL# OR NAME ==>
PF1:BER SUMMARY PF4:BACKWARD PF5:FORWARD

In maintenance mode, if you type '6' (SEL #) with BER "ALL LIST" displayed, the following screen is displayed:

BER DETAIL	
SEL#:006	FLAG:00 DATE:04/23 TIME:20:38 TYPE:11 ID:B1 LOST: CP-ABEND:
CS1 LINE31	SCANNER COMMAND TIME OUT
F:10000000	
TA:10	TD:1F NW:DCC0 LNVT:08F0 LCS:00
PSA:DA06	0000 0000 0000 0191 0000 0000 0000 0592 0800 0000 0000 0191 0000

OVERWRITE FLAG VALUE WITH NEW HEXADECIMAL VALUE
PF1: BER SUMMARY PF2: BER LIST PF4: PREVIOUS BER PF5: NEXT BER

This screen contains the coded maintenance information appropriate to the type of BER.

In customer mode, if you type '6' (SEL#) with BER "ALL LIST" displayed, the following screen is displayed:

BER DETAIL	
SEL#:006	FLAG:00 DATE:04/23 TIME:20:38 TYPE:11 ID:B1 LOST:ddd CP-ABEND:hyyy
CS1 LINE31	SCANNER COMMAND TIME OUT

PF1: BER SUMMARY PF2: BER LIST PF4: PREVIOUS BER PF5: NEXT BER

This display is explained in the 3725 Problem Determination and Extended Services (Vol. A06) under "Error Log Function."

Error Log Function (Part 4 of 4)

BER UPDATING

The only field updatable in a BER is the flag.

This flag can be updated only when displaying the BER DETAIL screen.

BER Flag Explanation

An intermittent error is not confirmed by the diagnostics (tentative repair action). An analysis of the BERs may identify the suspected FRUs.

Should the same error appear, the flag byte value determines the meaning of the BER and the status of the problem that caused the BER.

How to handle these flag values is described in MIM Part 2, Chapter 2.

BER Flag Updating

The BER flag should be updated on the primary controller diskette for a standard reference.

The maintenance mode must be entered from the primary menu before selecting the BER details to be updated.

To update the flag:

1. Place cursor under hh value of FLAG:hh field.
2. Override with new hexadecimal value.
3. Press SEND.

The procedures in MIM Part 2, Chapter 2, show the value required when updating the BER flag in the course of repair action, or tentative repair action.

BER Flag	Meaning
00	No action taken
0F	BER recorded for information only
1x	Hardware suspected
2x	Microcode suspected
3x	Control program suspected
4x	Hardware suspected, save/purge requested
5x	Microcode suspected, save/purge requested
6x	Control program suspected, save/purge requested
7x	Hardware suspected, saved
8x	Microcode suspected, saved
9x	Control Program suspected, saved

x Value	Meaning
0	No repair action taken
1-9	Number of repair action
A	Action pending
B	This unit not at fault
C	Customer responsibility
D	No repair action required
E	FRU list exhausted
F	Problem resolved

BER Display Screens (Part 1 of 3)

BER SUMMARY DISPLAY

SEL# NAME		BER SUMMARY		DATE 1ST BER	TOTAL
		TYPE	PENDING BERS	MM/DD HH:MM	IN FILE
1	CA (CHANNEL ADAPTERS)	10	0		0
2	TSS (TRANSMISSION SUBSYSTEM)	11	2	04/23 20:39	4
3	CP (CONTROL PROGRAM)	12	0		0
4	CCU (CENTRAL CONTROL UNIT)	13	0		0
5	IDC (I/O CONTROL)	14	0		0
6	MOSS (MAINTENANCE OPERATOR SUBSYSTEM)	01	0		1
7	ALARMS		1	04/23 20:40	2
8	TRSS (TOKEN RING SUBSYSTEM)	15	0		0
9	ALL (ALL FILE CONTENTS)		2	04/23 07:00	9

- ENTER SEL# OR NAME ==>

Field Description for BER Summary Screen

SEL#: A number in the left-hand column, which may be typed at the cursor position, to select the appropriate BER list screen.

NAME: An acronym in the next column, which may be typed at the cursor position, in place of SEL# to select the appropriate BER list.

TYPE: The number that categorizes the BER by its origin.

PENDING BERS: BERS that contain a flag with value X0 (that is, no repair action taken).

DATE 1ST BER: The time and date of the oldest BER in this category that is not updated (pending BER).

TOTAL IN FILE: The total number of BERS of this category in the BER file.

You use the data in this screen to help you in selecting the BER list.

Note: If you already know the precise origin of the fault (such as CS3, or LINE7), you can type this at the cursor position instead of SEL# or NAME. For example, typing CS3 displays only those BERS associated with CS3.

BER LIST DISPLAY

As an example, the display below shows a BER 'ALL LIST' screen.

SEL#	DATE/TIME	FLAG	NAME	TYPE	ALL LIST	ERROR DESCRIPTION	BER TYPE:	TOTAL:9
1	04/23 20:40		ALARMS			A11 SCANNER 01 DOWN(LINE 000-031)IPL SCAN		
2	04/23 20:40		CS1 LINE31	11 98		PIO OUT ERROR		
3	04/23 20:39		TRM6 TIC1	15 91		AIO ERROR		
4	04/23 20:38		TRM12 TIC2	15 B4		DEADMAN TIMER		
5	04/23 20:38		CS1 LINE31	11 98		PIO OUT ERROR		
6	04/23 20:38		CS1 LINE31	11 B1		SCANNER COMMAND TIME OUT		
7	04/22 08:00	FF	ALARMS		A4	MEDIA ERROR		
8	04/22 08:00	FF	MOSS DISK	01 03		CRC ON READ DATA FILE:CHGPROC		
9	04/21 07:00		MOSS APPL	01 06		BER FILE DELETED		

*** END OF FILE ***
 - ENTER SEL# OR NAME ==>
 PF1:BER SUMMARY PF4:BACKWARD PF5:FORWARD

Field Description for BER List Screen

XXX LIST: The criterion XXX of selection from the BER summary, or from the previous BER list (ALL in this example).

BER TYPE: The type of BERS corresponding to the selection from the BER summary.

TOTAL: The number of BERS corresponding to the selection from the BER summary.

SEL#: The sequence number of the BER in the BER file. BERS are numbered in ascending order from the most recent to the oldest (compare with DATE 1ST BER in BER summary).

Enter this SEL# when you want the corresponding BER DETAIL screen. The detail screen gives additional maintenance information concerning the BERS.

Note: The BER file is not frozen while you work. New BERS may be logged while you troubleshoot, but they do not appear on the screen. These new BERS (with a new SEL number) will appear next time a BER LIST display is requested.

DATE: Four digits defining month and day. EP does not handle the date (in EP, DATE: 00/00).

TIME: Four digits defining hour and minute.

Note: Under NCP, the time and date information comes from the host. If the host is remote, the time recorded on the BER may differ from the 3725 time.

FLAG: Two hex digits (00-FF) being the status of the BER (see page 2-172). The FLAG field is not updatable on the LIST screen.

For better readability, a 00 flag does not appear on this screen, and is therefore left blank.

NAME: More precise information about the origin of a BER (for example, CS, line, or channel number). The NAME may be typed at the cursor position to obtain the appropriate BER list. The NAME is repeated in the error description line of the BER DETAIL screen.

TYPE The number that categorizes the BER.

ID Two hex digits that give more precision to the origin of the BER.

ERROR DESCRIPTION Up to 40 characters that describe the error.

PF Keys on BER List Screen

PF1: Return to BER SUMMARY.

PF4: This key enables you to scroll backwards, 10 BERS at a time.

PF5: This key enables you to scroll forwards, 10 BERS at a time.

BER Display Screens (Part 2 of 3)

BER DETAIL DISPLAYS

To display an individual BER detail screen, type the corresponding SEL# (sequence number in BER file) on the BER LIST screen, at the cursor position. The layout is the following:

```

                BER DETAIL
SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd:dd TYPE:hh ID:hh LOST:ddd CP-ABEND:hhhh
< error description line >
X:bbbbbbbb
XX:hh XX:hh XX:hhhh XXXX:hhhh XXX:hh
XXX:hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh
                >

OVERWRITE FLAG VALUE WITH NEW HEXADECIMAL VALUE
PF1: BER SUMMARY PF2: BER LIST PF4: PREVIOUS BER PF5: NEXT BER
    
```

This screen contains the coded maintenance information appropriate to the type of BER selected.

Note: When used in customer mode, the screen layout is different (an example with real data for "MAINTENANCE" and 'CUSTOMER' display screens is given on page 2-171).

Finding the Appropriate BER Detail Screen

Use the following table to find the page for BER DETAIL screen explanations for a given BER type and BER ID. This table also shows what created the BERs (control program or MOSS).

For software information on BERs originated by NCP/EP, refer to BER in ACF/NCP Control Program for the 3725; Emulation Program for the 3725 Reference Summary and Data Areas, LY30-3070.

Type	Meaning	Created by	Page Number
01	MOSS-related BER		2-240
	ID 00	MOSS	2-260
	ID 01	MOSS	2-270
	ID 02	MOSS	2-280
	ID 03	MOSS	2-290
	ID 04	MOSS	2-300
	ID 05	MOSS	2-310
	ID 06	MOSS	2-320
	ID 07	MOSS	2-325
	ID 91,B3,C1,C2	NCP/EP	2-330
10	CA-related BER	NCP/EP	2-190
11	TSS-related BER	NCP/EP	2-200
12	NCP/EP-related BER	NCP/EP	2-210
13	CCU-related BER	NCP/EP	2-220
14	IOC-related BER	NCP/EP	2-230
15	TRSS-related BER	NCP/NTRI	2-231
02	See Note on page 2-466		

If you scroll through BER detail screens and see one that shows anomalies, such as a blank screen or unformatted hexadecimal characters, this means that the BER file is full and cannot renumber the BERs correctly. To correct this problem, press PF2. This gives a new, correct BER list.

Common Fields in Header Lines

In each detail screen, the top two lines and the bottom line always have the same format. The field descriptions are:

SEL#: Three digits (from 1 to 255) defining the SEL# (BER file sequence number).

This is either the BER corresponding to the SEL# (from the BER LIST screen), or the next or previous BER of the same selection criteria (obtained when pressing PF4 or PF5).

Note: You may alter these three digits by placing the cursor under the digits, then pressing ENTER. This displays the BER DETAIL screen corresponding to that new SEL#.

FLAG: Two hexadecimal digits defining the BER status.

This field may be updated on the BER detail screen (see page 2-172).

DATE: Four digits defining month and day (contains 00/00 in EP). Same as in LIST screen.

TIME: Four digits defining hour and minute. Same as in LIST screen.

TYPE: Two-digit hexadecimal number that categorizes the BER.

ID: Two-digit hexadecimal number that specifies the origin of the BER (BER identifier).

For a BER created by NCP/EP, the BER ID contains the interrupt level at which the error was detected and recorded, as shown in the following table:

Bit	Meaning
0	0 = software error 1 = hardware error (including microcode errors)
1	Control program level bit 0
2	Control program level bit 1
3	Control program level bit 2
4	Specific error bit 0
5	Specific error bit 1
6	Specific error bit 2
7	Specific error bit 3

LOST: Three digits defining the number of BERs, if any, that have been lost after creation of this BER. This field applies only to CP BERs.

CP-ABEND: Four hexadecimal digits defining the abend code (this field does not apply to MOSS BERs).

ERROR DESCRIPTION: One line giving a description of the error (same as on the BER LIST screen, but the maximum length is 80).

PF Key on BER Detail Screen

PF1: Display BER summary.

PF2: Display BER list. Pressing this key displays the LIST screen from which the BER detail was selected. The new LIST screen starts with the BER requested in BER DETAIL.

PF4: Scroll back to previous BER (this is the previous BER in the list from which the BER detail was selected).

PF5: Scroll forward to next BER (this is the next BER in the list from which the BER detail was selected).

Note: Using PF4 or PF5, you may request a BER that is outside the selected list; the message 'SEL# range limited to 255' appears when you do this.

BER Display Screens (Part 3 of 3)

FIELDS COMMON TO MANY BER DETAIL SCREENS

Address and Command Format on the IOC Bus at TA Time

X'76' and X'76'U

After storing the IOC bus error register in X'76', the control program starts reading each RDV address and error register in order to place its contents in the BER fields. If another IOC bus error occurs while filling in the BER fields, the contents of the IOC bus error register for the second error are placed in the X'76'U field of the IOC BER.

Redrive Address and Error Register

Bit	Meaning
0-0	1
0-1	Enable/Disable Latch (1 = disable state)
0-2	Primary RDV Address DB0 5
0-3	Primary RDV Address DB0 6
0-4	Primary RDV Address DB0 7
0-5	Secondary RDV Address DB1 4
0-6	Secondary RDV Address DB1 5
0-7	Secondary RDV Address DB1 6
1-0	IOC bus parity inbound
1-1	IOC bus parity outbound
1-2	IOC tag check outbound
1-3	IOC tag check inbound
1-4	Halt remember
1-5	Select out secondary
1-6	Cycle steal grant secondary
1-7	Command reject

Note: Details are given on page 11-040.

Byte-->	DB0		DB1		
Type	0123	4567	0123	4567	Comments
RDV	0100	000.	CCCC	Format
	CCCC	Command Write
0	Read
1	
C2LB0	000.	3725-2
CLAB10	000.	3725-1
C2LB20	001.	3725-2
CLAB20	001.	3725-1
LAB pos 30	010.	3725-1/2
CAB0	011.	3726
FRAME1	000.	3726
LAB pos 41	011.	3726
LAB pos 51	100.	3726
LAB pos 61	101.	3726
LAB pos 71	110.	3726
LAB pos 81	111.	3726

Board Position	Redrive Number	Redrive Address	
		Primary Field (DB0) 5 6 7	Secondary Field (DB1) 4 5 6
C2LB	1	0 0 0	0 0 0
CLAB1	1	0 0 0	0 0 0
C2LB2	2	0 0 0	0 0 1
CLAB2	2	0 0 0	0 0 1
LAB pos 3	3	0 0 0	0 1 0
CAB	10	0 0 0	0 1 1
Frame	4	0 0 1	0 0 0
LAB pos 4	7	0 0 1	0 1 1
LAB pos 5	6	0 0 1	1 0 0
LAB pos 6	5	0 0 1	1 0 1
LAB pos 7	8	0 0 1	1 1 0
LAB pos 8	9	0 0 1	1 1 1

CA (Type 10) BER Detail Displays (Part 1 of 4)

CA BER, Type 10 - Summary

BER	BER For- mat (1)	Ctrl Pgm Abend Code	Error Description	Recovery or Program Action	Alarm or Alert
10	foC3	0915	Invalid ESC address - EP or NEO is CA owner - Mismatch between Sysgen and the hardware, if found at IPL time. - Program error (such as possible overwrite of Control Blocks where ESC values are kept), if found in normal operations.	3725 reIPL	A8 (4)
14	foC2	0910	Address exception (AIO). X'76' bit 0.0 on.	3725 reIPL	A8 (4)
16	foC2	0911	Storage protect (AIO). X'76' bit 0.1 on.	3725 reIPL	A8 (4)
18	foC1	0912	Invalid channel adapter selection in control program (attempt to select a non-install. CA). Control Program issuing an Output X'7' with either bit 0.2 or bit 0.3 set, and bits 0.4 and 0.6 indicating select bits.	3725 reIPL	A8 (4)
1B	foC3	0913	Invalid IOH/IOHI input to channel adapter. X'7E' bit 0.5 on.	3725 reIPL	A8 (4)
1C	foC1	0914	Output Sequence issued in error to CA	3725 reIPL	A8 (4)
1E	foC1	0913	Invalid IOH/IOHI output to channel adapter. Output X'D', X'E', or X'F'.	3725 reIPL	A8 (4)
1F	foC3	0913	Invalid IOH/IOHI output to channel adapter (hardware detected). X '7E' bit 0.5 on.	3725 reIPL	A8 (4)
33	foC4	091E	Unresolved CA level 3 interrupt. 1- Lvl 3 but no CAB for this CA and not for EP 2- Lvl 3 but no Initial Select nor Data Status	3725 reIPL	A8 (4)
34	foC4	091F	Level 3 IPL CA not first interrupt 1- Stacked status cleared by Initial select for the 1st time, or transfer of Final status but not on the IPLing CA. 2- PRI	3725 reIPL	A8 (4)
35	foC4	0	ESC address out of range (level 3 detected).	-	no
90	foC3	0	Invalid ESC address. EP or NEO not CA owner, NCP is the owner on an ESC Address Compare.	CP retry	no (2)
90	foC3	0	Invalid ESC address (limit threshold)	CA down	A9 (3)
90	foC3	0924	Invalid ESC address (last CA). All CAs have been disabled.	3725 reIPL	A7 (4)
91	foC2	0	AIO Error. X'75' bit 0.0 off X'76' bit 0.4 on for IOC timeout X'76' bit 0.5 on for Bus in parity error X'76' bit 0.6 on in both cases (AIO) X'76' bits 0.0, 0.1, 0.2, and 0.3 contain the IOC Status at the time of error.	CP retry	no (2)
91	foC2	0	AIO Error (limit threshold).	CA down	A9 (3)
91	foC2	0924	AIO Error (last channel adapter). All CAs have been disabled.	3725 reIPL	A7 (4)
92	foC3	0922	Level 1 from CA during recovery (interrupt from a CA which is already being disabled by Error Recovery Procedures as a result of level 1 checks). Indicates the probable failure of the disable sequence.	3725 reIPL	A7 (4)

BER	BER For- mat (1)	Ctrl Pgm Abend Code	Error Description	Recovery or Program Action	Alarm or Alert
93	foC3	0	Driver/receiver card check. X'D' bit 1.6 or 1.7 on.	CP retry	no (2)
93	foC3	0	Driver/receiver card check (limit threshold).	CA down	A9 (3)
93	foC3	0924	Driver/receiver card check (last CA). All CAs have been disabled.	3725 reIPL	A7 (4)
94	foC3	0	Level 1 from a CA not generated active. X'7E' bit 0.5 on.	CP retry	no (2)
94	foC3	0921	Level 1 from a CA not generated active (limit threshold).	3725 reIPL	A7 (4)
95	foC3	0	Unresolved adapter level 1 interrupt. (CA reg X'E' did not specify a CA with the level 1 interrupt).	CP retry	no (2)
95	foC3	0919	Unresolved adapter level 1 interrupt (limit threshold).	3725 reIPL	A7 (4)
96	foC3	0	Channel bus in check. X'D' bit 1.3 or 1.5 on.	CP retry	no (2)
96	foC3	0	Channel bus in check (limit threshold).	CA down	A9 (3)
96	foC3	0924	Channel bus in check (last CA). All CAs have been disabled.	3725 reIPL	A7 (4)
97	foC1	0	PIO error (input or output IOH failed). X'75' bit 0.0 off X'76' bit 0.4 on for IOC timeout X'76' bit 0.5 on for Bus in parity error X'76' bit 0.6 off in both cases.	CP retry	no (2)
97	foC1	0	PIO error (limit threshold).	CA down	A9 (3)
97	foC1	0924	PIO error (last channel adapter). All CAs have been disabled.	3725 reIPL	A7 (4)
98	foC3	0	Internal adapter error. X'7E' bit 0.5 on. X'E' bits to indicate CAs. The Control Program checks the level 3 instruction that failed. If it is a valid IOH/IOHI, retry the instruction in the interrupted level. If it is not a valid IOH/IOHI, attempt to disable the CA.	CP retry	no (2)
98	foC3	09F0	Internal adapter error (final status transfer) Not enough information available to recover when a Data/Status interrupt is pending during level 1 processing.	3725 reIPL	A7 (4)
98	foC3	09F1	Internal adapter error. Status byte cleared (X'0' bit 0.6) Not enough information available to recover when an Initial Selection Interrupt is pending during level 1 processing.	3725 reIPL	A7 (4)
98	foC3	0	Internal adapter error (limit threshold).	CA down	A9 (3)
98	foC3	0924	Internal adapter error (last CA). All CAs have been disabled.	3725 reIPL	A7 (4)
99	foC3	0923	Ground fault. X'D' bit 1.4 on.	3725 reIPL	A7 (4)
9A	foC2	0920	IOH failed in level 1 - abort AIO recovery. Control program cannot get the registers needed to determine the error.	3725 reIPL	A7 (4)
9B	foC1	0920	IOH failed in level 1 - abort PIO recovery. IOH required for the recovery failed twice in level 1, or output IOH X'7' failed twice in level 1.	3725 reIPL	A7 (4)

CA (Type 10) BER Detail Displays (Part 2 of 4)

CA BER (Type 10) Summary (Continued)

BER	BER For- mat (1)	Ctrl Pgm Abend Code	Error Description	Recovery or Program Action	Alarm or Alert
9C	foC3	0920	IOH failed in level 1 - abort ADP recovery.	3725 reIPL	A7 (4)
9E	foC3	0	Unresolved error on CA level 1, CA register X'D' did not specify any adapter error bit. See "BER/Alarm/Alert Mechanism" page 2-250.	CP retry	no (2)
9E	foC3	0	Unresolved error on CA level 1 (limit threshold).	CA down	A9 (3)
9E	foC3	0924	Unresolved error on CA level 1 (last CA). All CAs have been disabled.	3725 reIPL	A7 (4)
9F	foC3	0925	ESC interrupt - EP or NEO is not the CA owner. X'F' bits 0.2 or 0.3 on. ESC address in X'3' byte 0.	3725 reIPL	A7 (4)
B1	foC4	0	Unresolved CA level 3. Initial select interrupt (X'F' bit 0.2), but no bit on in X'0'.	CP retry	no (2)
B1	foC4	091C	Unresolved CA level 3 initial select interrupt (limit threshold). See "BER/Alarm/Alert Mechanism" page 2-250.	3725 reIP	A7 (4)
B2	foC4	0	Unresolved CA level 3 data/status interrupt (X'F' bit 0.3), but no bit on in X'2'.	CP retry	no (2)
B2	foC4	091D	Not a system reset. Unresolved CA level 3 data/status interrupt (limit threshold).	3725 reIPL	A7 (4)
B5	foC4	0	Level 3 cannot disable CA. Permanent X'77' bit 1.0 on.	CP retry	no (2)
B5	foC4	0927	Level 3 cannot disable CA (limit threshold).	3725 reIPL	A7 (4)
B6	foC4	0	Inappropriate command (not NOP nor IIO) on Stacked Initial Status (X'0' bit 0.5).	CP retry	no (2)
B6	foC4	0926	Inappropriate command (not NOP nor IIO) on Stacked Initial Status (limit threshold).	3725 reIPL	A7 (4)

Notes:

- BERs have different formats and different detail display screens according to the type of error reported:
 - foC1: Level 1 during a PIO operation
 - foC2: Level 1 during an AIO operation
 - foC3: Channel adapter error reported at level 1
 - foC4: Unresolved error reported at level 3
- The control program maintains an error counter. When the threshold is reached, the control program action is as indicated in the table. The threshold is 2 per 0.1 seconds per adapter.
- The control program continues in degraded mode, keeping track of the lost resources (CA), if any.
- The alert/alarm is triggered by MOSS BER ID 06, error code 05.

CA (Type 10) BER Detail Displays (Part 3 of 4)

CA BER, Type 10 - IDs 18, 1C, 1E, 97, 9B (foC1)

Program level 1 generates one of the following BERs when an error occurs during a PIO operation on a channel.

```

BER DETAIL
SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd:dd TYPE:10 ID:hh LOST:ddd CP-ABEND:hhhh
CAn < description of the error >
F:bbbbbbbbb
X7E:hhhh X76U:hhhh ETA:hhhh RHB:hh X74:hhhhhhhh CAA:hh
X79:hh IAR:hhhhhh I:hhhh TA:hhhh TD:hhhh

                (see note)
                |
                v
-----v-----
X76      XD      CLA1 CLA2 LAB3 CABR FRDV LAB6 LAB5 LAB4 LAB7 LAB8
hhhh bbbbbbbb bbbbbbbb hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh
CAB/CHCB:hhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh
hhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh CABCNTL:hhhh
X 0:hhhh X 1:hhhh X 2:hhhh X 3:hhhh X 4:hhhh X 5:hhhh X 6:hhhh
X 7:hhhh X B:hhhh X C:hhhh X D:hhhh X E:hhhh X F:hhhh
OVERRIDE FLAG VALUE WITH NEW HEXADECIMAL VALUE
PF1: BER SUMMARY PF2: BER LIST PF4: PREVIOUS BER PF5: NEXT BER
    
```

CA BER, Type 10 - IDs 14, 16, 91, 9A (foC2)

Program level 1 generates one of the following BERs when an error occurs during an AIO operation with a channel.

```

BER DETAIL
SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd:dd TYPE:10 ID:hh LOST:ddd CP-ABEND:hhhh
CAn < description of the error >
F:bbbbbbbbb
X7E:hhhh X76U:hhhh ETA:hhhh RHB:hh X3M:hhhhhhhh X75:hhhh

                (see note)
                |
                v
-----v-----
X76      XD      CLA1 CLA2 LAB3 CABR FRDV LAB6 LAB5 LAB4 LAB7 LAB8
hhhh bbbbbbbb bbbbbbbb hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh
CAB/CHCB:hhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh
hhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh CABCNTL:hhhh
X 0:hhhh X 1:hhhh X 2:hhhh X 3:hhhh X 4:hhhh X 5:hhhh X 6:hhhh
X 7:hhhh X B:hhhh X C:hhhh X D:hhhh X E:hhhh X F:hhhh
OVERRIDE FLAG VALUE WITH NEW HEXADECIMAL VALUE
PF1: BER SUMMARY PF2: BER LIST PF4: PREVIOUS BER PF5: NEXT BER
    
```

Note: For the 3725 Model 2, CLA1 information applies to the C2LB board, CLA2 applies C2LB2; except LAB3, all other information has no meaning for Model 2.

CA BER, Type 10 - IDs 10, 1B, 1F, 90, 92, 93, 94, 95, 96, 98, 99, 9C, 9E, 9F (foC3)

Program level 1 generates one of these BERs when a CA reports an error on its level 1.

```

BER DETAIL
SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd:dd TYPE:10 ID:hh LOST:ddd CP-ABEND:hhhh
CAn < description of the error >
F:bbbbbbbbb ETA:hhhh
X7E:hhhh X76U:hhhh RHB:hh X74:hhhhhhhh CAA:hh BRR:hhhh XE:hhhh

                (see note)
                |
                v
-----v-----
X76      XD      CLA1 CLA2 LAB3 CABR FRDV LAB6 LAB5 LAB4 LAB7 LAB8
hhhh bbbbbbbb bbbbbbbb hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh
CAB/CHCB:hhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh
hhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh CABCNTL:hhhh
X 0:hhhh X 1:hhhh X 2:hhhh X 3:hhhh X 4:hhhh X 5:hhhh X 6:hhhh
X 7:hhhh X B:hhhh X C:hhhh X D:hhhh X E:hhhh X F:hhhh
OVERRIDE FLAG VALUE WITH NEW HEXADECIMAL VALUE
PF1: BER SUMMARY PF2: BER LIST PF4: PREVIOUS BER PF5: NEXT BER
    
```

CA BER, Type 10 - IDs 33, 34, 35, B1, B2, B5, B6 (foC4)

Program level 3 generates one of the following BERs when a CA request at level 3 remains unresolved.

```

BER DETAIL
SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd:dd TYPE:10 ID:hh LOST:ddd CP-ABEND:hhhh
CAn < description of the error >
X77:hhhh X7F:hhhh X0:hhhh X1:hhhh X2:hhhh X3:hhhh X4:hhhh X5:hhhh
X6:hhhh X7:hhhh XB:hhhh XC:hhhh XF:hhhh
CAB/CHCB:hhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh
hhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh CABCNTL:hhhh
OVERRIDE FLAG VALUE WITH NEW HEXADECIMAL VALUE
PF1: BER SUMMARY PF2: BER LIST PF4: PREVIOUS BER PF5: NEXT BER
    
```

Notes:

- When the registers are set to "FF", the information they contain is not valid.
- For the 3725 Model 2, CLA1 information applies to the C2LB board, CLA2 applies C2LB2; except for LAB3, all other information has no meaning for Model 2.

CA (Type 10) BER Detail Displays (Part 4 of 4)

CA BER, Type 10 - Field Explanation

Field Name	Meaning	Details on Page
BRR	Board RDV response to poll Contains the RDV address and error register indicating the CA position (see CDF)	2-182 2-403
CAn	Channel adapter number (1 to 6) in error description field This CA number (decimal) is derived from: - field CAA for PIO operation - field XE for CA error reported at level 1 - field X75 for AIO operation - field XF for CA error reported at level 3	
CAA	CA address (defined by the bits 4, 5, and 6 of this byte) as used by NCP/EP in its control blocks (not to be confused with ESC or NSC address used by NCP/EP) CAA field decoding (hh): 0123 4567 0000 0000 CA 1 hh = 0 0000 0010 CA 2 hh = 2 0000 0100 CA 3 hh = 4 0000 0110 CA 4 hh = 6 0000 1000 CA 5 hh = 8 0000 1010 CA 6 hh = A	
CAB/ CHCB	48 bytes of fields from the channel adapter control block (CAB), from CABCOND up to and including CABXR6F. For EP, the fields CASEL through TERMADR are included from the EP CHCB (16 bytes). The remaining space is padded with xFF. CABCNTL: Channel adapter contact control flags. Padded with xFF for EP.	
CABC CNTL	Channel adapter contact control flags. Padded with xFF for EP.	
CABR CLA1 CLA2	CAB RDV address and error register CLA1 CLAB1 RDV address and error register (see Note) CLA2 CLAB2 RDV address and error register (see Note)	2-182 2-182
ETA	TA field of IOH failure in level 1	
F	Indicator flag byte x... .. 1 Control program is NCP or PEP 0 Control program is EP .1.. Adapter down ..1. Control program put adapter down ...1 Error on invalid ESC 1... Unused1.. Unused1. CA is being disabled1 IOH or IOHI on level 1 failed twice	
FRDV	Frame RDV address and error register (see Note)	2-182

Note:

For the 3725 Model 2, CLA1 information applies to the C2LB board, CLA2 information has no meaning for Model 2.
applies C2LB2; except LAB

Field Name	Meaning	Details on Page
I	First two bytes of instruction	
IAR	IAR of interrupt level	
LABn	LAB position n RDV address and error register (see note) 2-182 (where n is 3, 4, 5, 6, 7, and 8)	
RHB	RDV hash byte is the OR of byte 1 of all 'read RDV address and error register' commands	
TA	IOHI image -- TA data registers X'50', X'70' (TA:hhhh means data bytes 0 and 1)	11-040
TD	IOHI image -- TD data adapter specific bytes (TD:hhhh means data bytes 0 and 1)	11-040
X3M	CA cycle steal fixed pointer register	12-090
X0	X'0' - CA initial selection register	12-025
X1	X'1' - CA CSCW and subchannel address	12-025
X2	X'2' - data status register	12-030
X3	X'3' - CA ESC subchannel	12-035
X4	X'4' - CA IOH bytes 1 and 2	12-035
X5	X'5' - CA IOH bytes 3 and 4	12-035
X6	X'6' - CA NSC status register	12-040
X7	X'7' - CA enabled indications	12-045
XB	X'B' - CA ESC IIO address and status	12-050
XC	X'C' - CA AIO operations register	12-050
XD	X'D' - CA error register	12-055
XE	X'E' - CA level 1 error register	12-060
XF	X'F' - CA level 3 interrupt request (see CAn)	12-060
X74	X'74' - Cycle steal control word register	10-230
X75	X'75' - LAR bytes (see CAn)	10-230
X76	X'76' - IOC error summary register	10-230
X76U	X'76' - Cause of error not found (PIO to read error register failed)	10-230 2-182
X77	X'77' - Interrupt request reg - adapter level 2 and 3	10-230
X79	X'79' - Utility	10-230
X7E	X'7E' - CCU level 1 interrupt	10-230
X7F	X'7F' - Interrupt request reg - CCU level 2, 3, and 4	10-230

Notes:

- PF keys and header fields (such as SEL#) are explained on page 2-181.
- All values are in hexadecimal format (X'0' to X'F'), except for:
 - a. The flag byte F and XD, which are in bit format (8 and 16 bits, 0 or 1)
 - b. The error description line with a CA number in decimal (1 to 6)

TSS (Type 11) BER Detail Displays (Part 1 of 4)

TSS BER, Type 11 - Summary

BER	BER For- mat (1)	Ctrl Pgm Abend Code	Error Description	Recovery or Program Action	Alarm or Alert
14	foT1	0930	Address exception (AIO) X'76' bit 0.0 on.	3725 reIPL	A8 (4)
16	foT1	0931	Storage protect (AIO) X'76' bit 0.1 on.	3725 reIPL	A8 (4)
18	foT2	0932	IOH/IOHI to CS not installed X'7E' bit 0.5 on. IOC Bus check in Error Status Type 1 of CSP: bits 0.1 and 0.5 on (X'02' bits 0.1 and 0.5).	3725 reIPL	A8 (4)
1B	foT2	0933	Invalid IOH input to CS X'7E' bit 0.5 on. Origin given in Error Status type 1 of CSP, bit 1.7 on.	3725 reIPL	A8 (4)
1C	foT7	0	Line command reject. See "BER/Alarm/Alert Mechanism" page 2-250.	Line down	A15
1E	foT3	0	Invalid IOH output to CS (pgm reset done) X'7E' bit 0.5 on. Undefined IOH instruction sent to the CSP. Origin given in Error Status type 3 of CSP (bit 1.1 on).	CS down	A14(3)
1E	foT3	0	Invalid IOH output to CS (disable rdv done).	CS down	A13(3)
91	foT1	0	CS AIO error X'75' bit 0.0 on X'76' bit 0.4 on for IOC Timeout X'76' bit 0.5 on for IOC Bus In parity error X'76' bit 0.6 on in both cases (AIO) X'76' bits 0.0, 0.1, 0.2, 0.3 contain the IOC internal status at time of error.	CS retry	no (2)
91	foT1	0	CS AIO error (threshold-pgm reset done).	CS down	A12(3)
91	foT1	0	CS AIO error (threshold-disable rdv done).	CS down	A11(3)
92	foT1	0	CS AIO error unresolved. See "BER/Alarm/Alert Mechanism" page 2-250.	CS retry	no (2)
92	foT1	0	CS AIO error unresolved (limit threshold - pgm reset done).	CS down	A12(3)
92	foT1	0	CS AIO error unresolved (limit threshold - disable rdv done).	CS down	A11(3)
93	foT1	0	CS AIO invalid CSCW X'75' bit 0.0 on X'76' bits 0.2 and 0.6 on.	CS retry	no (2)
93	foT1	0	CS AIO invalid CSCW (limit threshold - pgm reset done).	CS down	A12(3)
93	foT1	0	CS AIO invalid CSCW (limit threshold - disable rdv done).	CS down	A11(3)
95	foT3	0	CS hardstop X'7E' bit 0.5 on. Origin given in Error Status type H of CSP.	CS down	A12(3)
96	foT3	0	CS disconnect state (following request from MOSS) X'7E' bit 0.5 on. Error Status type 1, bit 1.3 on. Ext Reg X'01' bit 5 on.	CS off line	no

BER	BER For- mat (1)	Ctrl Pgm Abend Code	Error Description	Recovery or Program Action	Alarm or Alert
97	foT2	0	CS PIO error - output IOH/IOHI X'75' bit 0.0 on X'76' bit 0.4 on for IOC Timeout X'76' bit 0.5 on for IOC Bus In parity error X'76' bit 0.6 off in both cases Origin given in Error Status type 1 of CSP.	CP retry	no (2)
98	foT2	0	CS PIO error - output IOH/IOHI (limit threshold reached on two 11 97 BERs - pgm reset done).	CS down	A12(3)
98	foT2	0	CS PIO error - output IOH/IOHI (limit threshold - disable rdv done).	CS down	A11(3)
99	foT3	0	CS adapter error X'7E' bit 0.5 on. Origin given in Error Status type 3 of CSP.	CS retry	no
99	foT3	0	CS adapter error (pgm reset done)	CS down	A12(3)
99	foT3	0	CS adapter error (disable rdv done)	CS down	A11(3)
9A	foT3	0	CS adapter error unresolved - CSP on LAB type A and Error Status = 0. - CSP on LAB type B and Error Status = 0 from one CSP plus an error in the Get Error Status to the other CSP. See "BER/Alarm/Alert Mechanism" page 2-250.	-	no
9A	foT3	0	CS adapter error unresolved (pgm reset done).	CS down	A12(3)
9A	foT3	0	CS adapter error unresolved (disable rdv done)	CS down	A11(3)
9B	foT3	0	Interrupt from disconnected CS level 1 interrupt presented to NCP/EP while the scanner is disconnected (X'01' bit 5 on). X'7E' bit 0.5 on.	-	no
9B	foT3	0	Interrupt from disconnected CS (disable rdv done).	CS down	A11(3)
9C	foT2	0	CS PIO error - input on get line ID (see BER 11 97 for general PIO errors).	CP retry	no (2)
9C	foT2	0937	CS PIO error - input on get line ID (limit threshold).	3725 reIPL	A7 (4)
A1	foT4	0	Unresolved level 2 interrupt If spurious retry count (the interrupt occurred on a non-defined line) See "BER/Alarm/Alert Mechanism" page 2-250.	CF .retry	no (2)
A1	foT4	0936	Unresolved level 2 interrupt (limit threshold)	3725 reIPL	A7 (4)

(Continued on next page)

Notes:

- BERs have different formats and different BER DETAIL screen layouts, according to the type of error reported:
 - foT1: Level 1 during an AIO operation
 - foT2: Level 1 during a PIO operation
 - foT3: Error reported by scanner on level 1
 - foT4: Unresolved error reported on level 3
 - foT5: Scanner error reported on level 2
 - foT6: Scanner error reported on level 3
 - foT7: Control program error reported on level 1
- The control program maintains an error counter. When the threshold is reached, the control program action is as indicated in the table. The threshold is 2 per 0.1 seconds per adapter.
- The control program continues in degraded mode, keeping track of the lost resources (CS), if any.
- The alert/alarm is triggered by MOSS BER ID 06, error code 05.

TSS (Type 11) BER Detail Displays (Part 2 of 4)

TSS BER (Type 11) Summary (Continued)

BER	BER For- mat (1)	Ctrl Pgm Abend Code	Error Description	Recovery or Program Action	Alarm or Alert
A2	foT5	0	Internal CS error reported via level 2 X'77' bit 0.1 on. Origin in LCS.	Line down	A15
A4	foT5	0	Recovery done on NCP backup timer expired. See "BER/Alarm/Alert Mechanism" page 2-250.		A15
B1	foT6	0	CS command timeout. Command sent to the scanner; backup timer in NCP/EP Lvl 3 expired before receiving a level 2 from scanner to process it. See "BER/Alarm/Alert Mechanism" page 2-250.	Line down	A15

TSS BERs, Type 11 - ID 14, 16, 91, 92, 93 (foT1)

Program level 1 generates one of the following BERs when an error occurs during an AIO operation on a scanner.

```

                                BER DETAIL
SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd:dd TYPE:11 ID:hh LOST:ddd CP-ABEND:hhhh
CSnn LINEnn < error description >
F:bbbbbbbbb
X7E:hhhh X76U:hhhh ETA:hhhh RHB:hh X3F:hhhhhhhh X75:hhhh

                                (See Note)
                                |
                                v
X76      CS STATUS2  CLA1 CLA2 LAB3 CABR FRDV LAB6 LAB5 LAB4 LAB 7 LAB8
hhhh bbbbbbbb bbbbbbbb hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhh h hhhh

OVERVERRIDE FLAG VALUE WITH NEW HEXADECIMAL VALUE
PF1: BER SUMMARY PF2: BER LIST PF4: PREVIOUS BER PF5: NEXT B ER
    
```

TSS BER, Type 11 - IDs 18, 1B, 97, 98, 9C (foT2)

Program level 1 generates one of these BERs when an error occurs during a PIO operation on a scanner.

```

                                BER DETAIL
SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd:dd TYPE:11 ID:hh LOST:ddd CP-ABEND:hhhh
CSnn LINEnn < error description >
F:bbbbbbbbb
X7E:hhhh X76U:hhhh ETA:hhhh RHB:hh X74:hhhhhhhh
X79:hh IAR:hhhhhh I:hhhh TA:hhhh TD:hhhh

                                (See Note)
                                |
                                v
X76      CS STATUS1  CLA1 CLA2 LAB3 CABR FRDV LAB6 LAB5 LAB4 LAB7 LAB8
hhhh bbbbbbbb bbbbbbbb hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh

OVERVERRIDE FLAG VALUE WITH NEW HEXADECIMAL VALUE
PF1: BER SUMMARY PF2: BER LIST PF4: PREVIOUS BER PF5: NEXT BER
    
```

TSS BER, Type 11 - IDs 1E, 1F, 95, 96, 99, 9A, 9B (foT3)

Program level 1 generates one of these BERs when an error is reported by a scanner on level 1.

```

                                BER DETAIL
SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd:dd TYPE:11 ID:hh LOST:ddd CP-ABEND:hhhh
CSnn LINEnn < error description >
F:bbbbbbbbb
X7E:hhhh X76U:hhhh RHB:hh CSPA:hh BRR:hhhh ETA:hhhh

                                (See Note)
                                |
                                v
X76      CS STATUS3/H CLA1 CLA2 LAB3 CABR FRDV LAB6 LAB5 LAB4 LAB7 LAB8
hhhh bbbbbbbb bbbbbbbb hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh

OVERVERRIDE FLAG VALUE WITH NEW HEXADECIMAL VALUE
PF1: BER SUMMARY PF2: BER LIST PF4: PREVIOUS BER PF5: NEXT BER
    
```

TSS BER, Type 11 - ID A1 (foT4)

Program level 1 generates one of these BERs when a requested TSS level 2 interrupt remains unresolved.

```

                                BER DETAIL
SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd:dd TYPE:11 ID:hh LOST:ddd CP-ABEND:hhhh
CSnn LINEnn < error description >
F:bbbbbbbbb TA:hh TD:hh NW:hhhh IDR:hhhh LNVT:hhhhhhhh LCS:hh
PSA:hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh
IOB/LXB:hhhhhhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh
hhhhhhhh hhhh hhhh
SCB:hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh SCBCSCF:hh
AXB ACB TRACE:hhhhhhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh
AXB PSA TRACE:hhhhhhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh
CCB:hhhhhhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh
hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh
OVERVERRIDE FLAG VALUE WITH NEW HEXADECIMAL VALUE
PF1: BER SUMMARY PF2: BER LIST PF4: PREVIOUS BER PF5: NEXT BER
    
```

TSS (Type 11) BER Detail Displays (Part 3 of 4)

TSS BER, Type 11 - ID A2, A4 (foT5)

Program level 2 generates one of these BERs when a scanner internal error or a transient line error is detected.

```

                                BER DETAIL
SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd:dd TYPE:11 ID:hh LOST:ddd CP-ABEND:hhhh
CSnn LINEnn < error description >
F:bbbbbbbbb TA:hh TD:hh NW:hhhh IDR:hhhh LCS:hh
PSA:hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh
IOB/LXB:hhhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh
hhhhhhhh hhhhhhhh
SCB:hhhh hhhhhhhh hhhhhhhh hhhhhhhh hhhh SCBCSCF:hh
AXB ACB TRACE:hhhhhhhhh hhhhhhhh hhhhhhhh hhhh
AXB PSA TRACE:hhhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh hh
CCB:hhhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh
hhhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh
OVERRIDE FLAG VALUE WITH NEW HEXADECIMAL VALUE
PF1: BER SUMMARY PF2: BER LIST PF4: PREVIOUS BER PF5:NEXT BER
    
```

Note: For the 3725 Model 2, CLA1 information applies to the C2LB board, CLA2 applies C2LB2; except LAB3, all other information has no meaning for Model 2.

TSS BER, Type 11 ID 1C (foT7)

Program level 1 generates one of these BERs when a command reject is reported by a scanner on level 1 (control program error).

```

                                BER DETAIL
SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd:dd TYPE:11 ID:hh
CSnn LINEnn < error description >
F:bbbbbbbbb
TA:hh TD:hh IDR:hhhh LCS:hh
PSA:hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh
OVERRIDE FLAG VALUE WITH NEW HEXADECIMAL VALUE
PF1: BER SUMMARY PF2: BER LIST PF4: PREVIOUS BER PF5:NEXT BER
    
```

TSS BER, Type 11 ID B1 (foT6)

Program level 3 generates one of these BERs when a timeout occurs on a command sent to the scanner.

```

                                BER DETAIL
SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd:dd TYPE:11 ID:hh
CSnn LINEnn < error description >
F:bbbbbbbbb TA:hh TD:hh NW:hhhh IDR:hhhh LCS:hh
PSA:hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh
IOB/LXB:hhhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh
hhhhhhhhh hhhhhhhh
SCB:hhhh hhhhhhhh hhhhhhhh hhhhhhhh hhhh SCBCSCF:hh
AXB ACB TRACE:hhhhhhhhh hhhhhhhh hhhhhhhh hhhh
AXB PSA TRACE:hhhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh hh
CCB:hhhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh
hhhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh
OVERRIDE FLAG VALUE WITH NEW HEXADECIMAL VALUE
PF1: BER SUMMARY PF2: BER LIST PF4: PREVIOUS BER PF5:NEXT BER
    
```

Note: For the 3725 Model 2, CLA1 information applies to the C2LB board, CLA2 applies C2LB2; except LAB3, all other information has no meaning for Model 2.

TSS (Type 11) BER Detail Display (Part 4 of 4)

TSS BER, Type 11 - Field Explanation

Field Name	Meaning	Details on page
AXB ACB TRACE	14 bytes from the adapter control block extension (AXB), from field AXBTCTL through AXBSTAT3 inclusive. For EP, this area contains the CCB extension starting at the EP CCB offset x'60'.	
AXB PSA TRACE	17 bytes from the adapter control block extension PSA trace area (fields AXBISSCF through AXBTROFF). For EP, this area contains the remaining portion of the EP CCB extension padded with 16 bytes of x'FF'.	
BRR	Board RDV response to poll Contains the RDV address and error register	2-182
CABR	CAB RDV address and error register	2-182
CCB	64 bytes from the character control block. For NCP, the fields come from CCBL2 through CCBPOLL inclusive. For EP, the fields come from CCBTROPT thru CCBXPTR inclusive.	
CLA1 CLA2	CLAB1 RDV address and error register (see Note) CLAB2 RDV address and error register (see Note)	2-182 2-182
CSnn	CS number (decimal) in error description field This CS number is derived from: - field TA for PIO operation for CS error reported at level 2 for CA error reported at level 3 - field X75 for AIO operation - field CSPA for CS error reported at level 1 If no n is specified (blank CS), problem isolation by program was not possible. For explanation, see "Line Group" on page 11-050 (bits 1-4=0110, all scanners responded).	
CS STAT	CS STATUS1: CSP error status 1 CS STATUS2: CSP error status 2 CS STATUS3/H: CSP error status 3	13-350 13-350 13-350
CSPA	CSP address used by NCP/EP (see CSn and LINEnn)	
ETA	TA field of IOH failure in level 1	
F	Indicator Flag x... .. 1 Control program is NCP or PEP 0 Control program is EP .1.. Adapter down ..1. Control program put adapter down ...1 Redrive disabled 1... Unused1.. Error on 'Get error status'1. CA is being disabled1 IOH or IOHI on level 1 failed twice	
FRDV	Frame RDV address and error register (see Note)	2-182
I	First two bytes of instruction	
IAR	IAR of interrupt level	
IDR	Get line ID response	13-123

TSS BER, Type 11 - Field Explanation (Continued)

IOB/ LXB	36 bytes of the LINK ID control block (LXB) for SDLC lines of the output block (IOB) for BSC/SS lines.	
LABn	LAB position n RDV address and error register (see Note) (where n is 3, 4, 5, 6, 7, and 8)	2-182 2-182
LCS	Line communication status	13-351
LINEnn	Line number (0 to 31) within the CS (in error description line)	
LNVT	Line vector table	13-120
LOST	Lost record count (LRC)	
NW	Network address (NCP) or CA number and ESC (EP)	
PSA	Parameter area (16 bytes) - status area (12 bytes) The byte contents of the PSA depend on the current command (CCMD).	13-554
RHB	RDV hash byte is the OR of byte 1 of all read 'RDV address and error register' commands	
SCB	16 bytes from the station control block, from Field SCBSSCF through SCBRTCNT inclusive. For BSC/SS lines and for EP, this area is padded with x'FF'.	
SCBC/ CSF	Configurable station control flags from the station control block (SCB) padded with x'FF' for EP and BSC/SS lines.	
TA	IOH/IOHI image -- TA data registers X'50', X'70' (TA:hh means TA data byte 0) (see CSn and LINEnn)	11-040
TD	IOH/IOHI image -- TD data adapter specific bytes (TD:hh means TD data byte 1)	11-040
X3F	CSP shared pointer register	2-182
X74	X'74' - LAR bytes (See CSn and LINEnn)	10-230
X75	X'75' - Cycle steal control word register	10-230
X76	X'76' - IOC error summary register	10-230
X76U	X'76' - Cause of error not found (PIO to read error register failed)	10-230 2-182
X77	X'77' - Interrupt request reg - adapter level 2 & 3	10-230
X79	X'79' - Interrupt level	10-230
X7E	X'7E' - CCU level 1 interrupt	10-230
X7F	X'7F' - Interrupt request reg - CCU level 2, 3, & 4	10-230

Notes:

- PF keys and header fields (such as SEL#) are explained on page 2-181.
- All values are in hexadecimal format (x'0' to x'F'), except for:
 - a. The flag byte F and CS STAT, which are in bit format (8 or 16 bits, 0 or 1)
 - b. The error description line with a CS number and line number, which are in decimal.

NCP/EP (Type 12) BER Detail Displays

NCP/EP BER, Type 12 - Summary

BER	BER Format (1)	Ctrl Pgm Abend Code	Error Description	Recovery or Program Action	Alarm or Alert
11	foN1	000A	IN/OUT or IOH/IOHI on Level 5. IAR not 0, retry not possible.	3725 reIPL	A8
12	foN1	001B	Invalid Operation Code X'7E' bit 0.4 on.	3725 reIPL	A8
13	foN1	0950	Address Exception - I fetch X'7E' bit 1.1 on.	3725 reIPL	A8
14	foN1	0951	Address Exception - I execution X'7E' bit 1.3 on.	3725 reIPL	A8
15	foN1	0952	Storage Protect - I fetch IAR not 0. X'7E' bit 1.2 on.	3725 reIPL	A8
16	foN1	0953	Storage Protect - I execution X'7E' bit 1.4 on.	3725 reIPL	A8
17	foN1	0954	Level 5 branch to storage location 0. IAR = 0.	3725 reIPL	A8
18	foN1	0955	User (non-NCP Code) branch to storage location 0. IAR = 0.	3725 reIPL	A8
19	foN1	000E	Level 1 code error (interrupt reason lost). Program check in level 1.	3725 reIPL	A8
21	foN2	0	Level 2 PCI The level 2 PCI should be off because level 1 has reset it (X'77' bit 0.7). If it is on (hot level 2 PCI), or if spurious retry count from a PCI level 2 interrupt.	-	no (2)
21	foN2	0956	Level 2 PCI (limit threshold)	3725 reIPL	A8

Notes:

- BERs have different formats and different BER DETAIL screen layouts, according to the type of error reported:
foN1: NCP/EP program exception reported at level 1
foN2: Program-controlled interrupt request at level 2 unresolved
- The control program maintains a counter of error occurrences. When the threshold is reached, the control program action is as indicated in the table. The threshold is 2 per 0.1 seconds.

NCP/EP BER, Type 12 - IDs 11 thru 19 (foN1)

Program level 1 generates one of these BERs when a NCP/EP program exception occurs.

BER DETAIL	
SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd:dd TYPE:12 ID:hh LOST:ddd CP-ABEND:hhhh	< error description line >
X7E:hhhh X74:hhhhh X79:hh IAR:hhhhh I:hhhh	
OVERRIDE FLAG VALUE WITH NEW HEXADECIMAL VALUE	
PF1: BER SUMMARY PF2: BER LIST PF4: PREVIOUS BER PF5:NEXT BER	

NCP/EP BER, Type 12 - ID 21 (foN2)

Program level 1 generates one of these BERs when a program controlled interrupt request at level 2 remains unresolved.

BER DETAIL	
SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd:dd TYPE:12 ID:21 LOST:ddd CP-ABEND:hhhh	< error description line >
X7F:hhhh IAR3:hhhhhhh IAR4:hhhhhhh	
OVERRIDE FLAG VALUE WITH NEW HEXADECIMAL VALUE	
PF1: BER SUMMARY PF2: BER LIST PF4: PREVIOUS BER PF5:NEXT BER	

NCP/EP BER, Type 12 - Field Explanation

Field Name	Meaning	Details on page
I	First two bytes of instruction	
IAR	IAR of interrupt level	
IAR3	IAR contents of level 3	
IAR4	IAR contents of level 4	
X74	X'74' - Lagging Address Register	10-230
X79	X'79' - Byte 1 interrupted levels	10-230
X7E	X'7E' - CCU level 1 interrupt	10-230
X7F	X'7F' - Interrupt request reg - CCU level 2, 3, and 4	10-230

Notes:

- PF keys and header fields (such as SEL#) are explained on page 2-181.
- All values are in hexadecimal format (X'0' to X'F').

CCU (Type 13) BER Detail Displays (Part 1 of 2)

CCU BER, Type 13 - Summary

BER	BER For- mat (1)	Ctrl Pgm Abend Code	Error Description	Recovery or Program Action	Alarm or Alert
32	foU3	0	Level 3 interrupt configuration check. Invalid level 3 interrupt (such as CA interrupt on a link-attached box). Can be a Sysgen error.	-	no (3)
32	foU3	0978	Level 3 interrupt configuration check (limit threshold).	3725 reIPL	A8
91	foU1	0	Unresolved level 1 interrupt. No bit in CA reg X'E'.	-	no (3)
91	foU1	0970	Unresolved level 1 interrupt (limit threshold).	3725 reIPL	A7
92	foU1	0971	Unresolved interrupted level. Interrupt level not 2, 3, 4, 5 as per content of X'79' bits 1.0, 1.1, 1.2, 1.3.	3725 reIPL	A7
93	foU1	0972	Unexpected CCU hardcheck (CCU not stopped). Not possible to reset X'77', bit 0.1, or MOSS has not reset this bit after IPL.	3725 reIPL	A7
94	foU1	0973	Unexpected IPL request. Not possible to reset X'77' bit 0.0, or MOSS has not reset this bit after IPL.	3725 reIPL	A7
95	foU1	0971	Invalid level 1 interrupt, IAR (IN X'79').	3725 reIPL	A7
B1	foU3	0	Unresolved level 3 interrupt. NCP reading out X'77' does not find bit 1.0 on (CA Lvl 3) and X'7F' bits 0.2, 0.6, 1.5 and 1.6 on, (level 3 raised by MOSS Diag, User, Timer, or PCI).	-	no (3)
B1	foU3	0974	Unresolved level 3 interrupt (limit threshold)	3725 reIPL	A7
C1	foU2	0	Unresolved level 4 interrupt. NCP reading out X'7F' does not find bits 0.3, 0.4, 0.7 and 1.7 on (Lvl 4 interrupt raised by MOSS request SVC, MOSS response SVC, PCI or SVC).	-	no (3)
C1	foU2	0975	Unresolved level 4 interrupt (limit threshold)	3725 reIPL	A7
C2	foU2	0	Unresolved level 4 PCI. Level 4 PCI (X'7F' bit 0.7) and not Wait state, but no bytes are set in level 4 Control Block of NCP. Mask used to set interrupt does not indicate: Lease, Slowdown, Dispatcher Request, SVC Interrupt, or Mask indicates Wait state plus MOSS offline, Outmail box, CRP request for MOSS transfer, or MOSS request.	-	no (3)
C2	foU2	0976	Unresolved level 4 PCI (limit threshold).	3725 reIPL	A7

BER	BER For- mat (1)	Ctrl Pgm Abend Code	Error Description	Recovery or Program Action	Alarm or Alert
C3	foU2	0	Hot/Spurious level 4 PCI interrupt. Level 4 PCI latch (X'7F' bit 0.7) does not go off, after a reset by Output X'77' bit 1.6.	-	no (3)
C3	foU2	0977	Hot/Spurious level 4 PCI interrupt (limit threshold).	3725 reIPL	A7
C4	foU2	0979	Unresolved level 4 SVC interrupt. Level 4 SVC interrupt (X'7F' bit 1.7) but CCU is in Wait state. Abend if Hot SVC interrupt (X'7F' bit 1.7 still on after reset latch by Out X'77' bit 1.7).	3725 reIPL	A7
C5	foU2	0	Continuous/unresolved MOSS level 4 request (X'7F' bit 0.3 still on after reset latch by Out X'77' bit 0.4).	-	no (3)
C5	foU2	097A	Continuous/unresolved MOSS Level 4 request (limit threshold).	3725 reIPL	A7
C6	foU2	0	Continuous/unresolved MOSS level 4 request (X'7F' bit 0.4 still on after reset latch by Out X'77' bit 0.5).	-	no (3)
C6	foU3	097B	Continuous/unresolved MOSS level 4 request (limit threshold).	3725 reIPL	A7

Notes:

- BERs have different formats and different BER DETAIL screen layouts, according to the type of error reported:
 - foU1: level 1 generated for CCU-related errors
 - foU2: level 4 generated for CCU-related errors
 - foU3: level 3 generated for CCU-related errors (only for link-attached 3725)
- The alert/alarm is triggered by MOSS BER ID 06 error code 05.
- The control program maintains a counter of errors. When the threshold is reached, the control program action is as indicated in the table. The threshold is 2 per 0.1 seconds.

CCU (Type 13) BER Detail Displays (Part 2 of 2)

CCU BER, Type 13 - IDs 91 thru 95 (foU1)

Program level 1 generates one of these BERs when a CCU-related error occurs.

```

                                BER DETAIL
SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd:dd TYPE:13 ID:hh LOST:ddd CP-ABEND:hhhh
< error description line >
X7E:hhhh X74:hhhhh X79:hh IAR:hhhhh X7D:hhhh
XD:hhhh XE:hhhh

OVERRIDE FLAG VALUE WITH NEW HEXADECIMAL VALUE
PF1: BER SUMMARY PF2: BER LIST PF4: PREVIOUS BER PF5: NEXT BER
    
```

CCU BER, Type 13 - IDs C1 thru C6 (foU2)

Program level 4 generates one of these BERs when a CCU-related error occurs.

```

                                BER DETAIL
SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd:dd TYPE:13 ID:hh LOST:ddd CP-ABEND:hhhh
< error description line >
X77:hhhh X7F:hhhh RCB:hhhh hhhh hhhh hhhh

OVERRIDE FLAG VALUE WITH NEW HEXADECIMAL VALUE
PF1: BER SUMMARY PF2: BER LIST PF4: PREVIOUS BER PF5: NEXT BER
    
```

CCU BER, Type 13 - IDs 32, B1 (foU3)

Program level 3 generates one of these BERs only if the 3725 is link-attached (remote) and an interrupt from a channel adapter is detected via the CCU external register X'77'.

```

                                BER DETAIL
SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd:dd TYPE:13 ID:hh LOST:ddd CP-ABEND:hhhh
< error description line >
X77:hhhh X7F:hhhh X0 :hhhh X1 :hhhh X2 :hhhh X3 :hhhh X4 :hhhh X5 :hhhh
X6 :hhhh X7 :hhhh XB :hhhh XC :hhhh XD :hhhh XE :hhhh XF :hhhh

OVERRIDE FLAG VALUE WITH NEW HEXADECIMAL VALUE
PF1: BER SUMMARY PF2: BER LIST PF4: PREVIOUS BER PF5: NEXT BER
    
```

CCU BER, Type 13 - Field Explanation

Field Name	Meaning	Details on page
IAR	IAR of interrupt level	
RCB	Level 4 router control block	
X0	X'0' - Channel adapter initial selection register	12-025
X1	X'1' - CA CSCW and subchannel address	12-025
X2	X'2' - data status register	12-030
X3	X'3' - CA ESC subchannel	12-035
X4	X'4' - CA IOH bytes 1 and 2	12-035
X5	X'5' - CA IOH bytes 3 and 4	12-035
X6	X'6' - CA NSC status register	12-040
X7	X'7' - CA enabled indications	12-045
XB	X'B' - CA ESC TIO address and status	12-050
XC	X'C' - CA AIO operations register	12-050
XD(=X6D)	X'D' - CA error register	12-055
XE(=X6E)	X'E' - CA level 1 error register	12-060
XF	X'F' - CA level 3 interrupt request and CA number	12-060
X74	X'74' - Cycle steal control word register	10-230
X77	X'77' - Interrupt request reg - adapter level 2 and 3	10-230
X79	X'79' - Interrupted level	10-230
X7D	X'7D' - CCU hardcheck register	10-230
X7E	X'7E' - CCU level 1 interrupt	10-230
X7F	X'7F' - Interrupt request reg - CCU level 2, 3, and 4	10-230

Notes:

1. PF keys and header fields (such as SEL#) are explained on page 2-181.
2. All values are in hexadecimal format (X'0' to X'F').

IOC (Type 14) BER Detail Displays

IOC BER, Type 14 - Summary

BER	BER For- mat (1)	Ctrl Pgm Abend Code	Error Description	Recovery or Program Action	Alarm or Alert
91	foI1	0	Unresolved adapter level 1.	-	no (2)
91	foI1	0990	Unresolved adapter level 1 (limit threshold).	3725 reIPL	A7
92	foI1	0	Unresolved AIO level 1.	-	no (2)
92	foI1	0991	Attempt to cycle steal by CSP or CA as indicated by X'75' bit 0.0. Unresolved AIO level 1 (limit threshold).	3725 reIPL	A7
93	foI1	0	Unresolved PIO level 1.	-	no (2)
93	foI1	0992	PIO error detected by the IOC that was found unresolved (no Time out nor Parity error, in X'76' bit 0.4 and 0.5). Unresolved PIO level 1 (limit threshold).	3725 reIPL	A7
95	foI1	0994	All read RDV error registers failed Read Redrive Error regs (X'1' or X'9') fails multiple times in level 1. The RDV slot in the BER contains X'FFFF' if the Read RDV Error reg fails, and X'FFyy' if the Write RDV Error reg fails; (yy contains the Error reg while the first byte contains the Address).	3725 reIPL	A7

Notes:

- All IOC BERs (type 14) have the same format and the same BER DETAIL screen layout:
foI1: Level 1 when an error occurs on the IOC bus.
- The control program maintains a counter of errors. When the threshold is reached, the control program action is as indicated in the table. The threshold is 2 per 0.1 seconds.
- If a read RDV error register command fails multiple times in level 1, the control program stores 'FF' in byte 1 of BER types 11 and 14. If this happens for all the RDVs, the BER type 14, ID 95, is generated.

IOC BER, Type 14 - All IDs (91, 92, 93, 95) (foI1)

Program level 1 generates one of these BERs when an error occurs on the IOC bus.

```

                                BER DETAIL
SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd:dd TYPE:14 ID:hh LOST:ddd CP-ABEND:hhhh
< error description line >
F:bbbbbbbb
X7E:hhhh X76U:hhhh RHB:hh X74:hhhhhhhh X75:hhhh

                                (see Note 3)
                                |
-----v-----
X76 CLA1 CLA2 LAB3 CABR FRDV LAB6 LAB5 LAB4 LAB7 LAB8
hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh

OVERWRITE FLAG VALUE WITH NEW HEXADECIMAL VALUE
PF1: BER SUMMARY PF2: BER LIST PF4: PREVIOUS BER PF5: NEXT BER
    
```

IOC BER, Type 14 - Field Explanation

Field Name	Meaning	Details on page
CABR	CAB RDV address and error register	
CLA1	CLAB1 RDV address and error register (see Note 3)	2-182
CLA2	CLAB2 RDV address and error register (see Note 3)	2-182
F	Indicator flag byte x... 1 Control program is NCP or PEP 0 Control program is EP .1.. Adapter down ..1. Control program put adapter down ...1 Error on invalid ESC 1... Second CSP on board is down1.. Error on 'Get error status'1. CA is being disabled1 IOH or IOHI on level 1 failed twice	
FRDV	Frame RDV address and error register (see Note 3)	2-182
LABn	LAB position n RDV address and error register (where n is 3, 4, 5, 6, 7, and 8) (see Note 3)	2-182
RHB	RDV hash byte is the OR of byte 1 of all read 'RDV address and error register' commands	
X74	X'74' - Cycle steal control word register	10-230
X75	X'75' - Lagging Address Register (LAR) bytes	10-230
X76	X'76' - IOC error summary register	10-230
X76U	X'76' - Cause of error not found (PIO to read error register failed)	10-230
X7E	X'7E' - CCU level 1 interrupt	2-182 10-230

Notes:

- PF keys and header fields (such as SEL#) are explained on page 2-181.
- All values are in hexadecimal format (X'0' to X'F'), except for the flag indicator F, which is in bit format (8 bits, 0 or 1)
- For the 3725 Model 2, CLA1 information applies to the C2LB board, CLA2 applies C2LB2; except LAB3, all other information has no meaning for Model 2.

TRSS (Type 15) BER Detail Display (Part 1 of 3)

TRSS BER, Type 15 - Summary

BER	BER For- mat (1)	Ctrl Pgm Abend Code	Error Description	Recovery or Program Action	Alarm or Alert
14	foR1	0B01	Address exception (AIO)	3725 down	A8 (4)
16	foR1	0B02	Storage protect (AIO)	3725 down	A8 (4)
18	foR2	0	IOH/IOHI to TRA not installed (PIO)(.)
91	foR1	0	TRM AIO error	TRM retry	no (2)
91	foR1	0	TRM AIO error (threshold)	TRM down	A28(3)
91	foR1	0	TRM AIO error (RDV disabled)	TRM down	A28(3)
92	foR1	0	TRM AIO error unresolved	TRM retry	no (2)
92	foR1	0	TRM AIO error unresolved (threshold)	TRM down	A28(3)
92	foR1	0	TRM AIO error unresolved (RDV disabled)	TRM down	A28(3)
93	foR1	0	TRM AIO invalid CCW	TRM retry	no (2)
93	foR1	0	TRM AIO invalid CCW (threshold)	TRM down	A28(3)
93	foR1	0	TRM AIO invalid CCW (RDV disabled)	TRM down	A28(3)
96	foR3	0	TRM disconnect state (request by MOSS)	TRM off	...(.)
97	foR2	0	TRM PIO error	TRM retry	no (2)
98	foR2	0	TRM PIO error (threshold)	TRM down	A28(3)
98	foR2	0	TRM PIO error (RDV disabled)	TRM down	A28(3)
99	foR3	0	TRM adapter error	TRM retry	no (2)
99	foR3	0	TRM adapter error	TRM down	A28(3)
9A	foR3	0	Unresolved TRM error	TRM down	A28(3)
9B	foR3	0	Disconnected TRM Interrupt	TRM down	no (2)
9C	foR2	0	TRM PIO error - input on get line ID	TRM retry	no (2)
9C	foR2	09x3	TRM PIO error - input on get line ID	3725 down	A7 (4)
A3	foR4	0	Invalid level 2 interrupt	TRM down	A28(3)
A4	foR4	0	DMA or Interrupt vector error	TIC retry	no (2)
A4	foR4	0	DMA or Interrupt vector error	TIC down	A29(3)
A5	foR4	0	DMA or Interrupt vector error	TRM down	A28(3)
A7	foR4	0	PIO-MMIO error	TIC retry	no (2)
A7	foR4	0	PIO-MMIO error	TIC down	A29(3)
A8	foR4	0	PIO-MMIO error	TRM down	A28(3)
AC	foR5	0	TIC adapter check	TIC down	A29(3)
AF	foR6	0	TIC check at Open time	TIC down	A29(3)
B2	foR7	0	TIC check at Initialization time	TIC retry	no (2)
B2	foR7	0	TIC check at Initialization time	TIC down	A29(3)
B3	foR8	0	Back-up Time out	TIC down	A29(3)
B4	foR8	0	Deadman Time out	TIC down	A29(3)
B5	foR8	0	Back-up Time out	TIC down	A29(3)
B6	foR8	0	Incomplete frame Time out	TIC down	A29(3)

Notes:

- BERs have different formats and different BER DETAIL screen layouts, according to the type of error reported:
 - foR1: Level 1 during an AIO operation
 - foR2: Level 1 during a PIO operation
 - foR3: Error reported by TRM on level 1
 - foR4: Error detected by TRM on level 2
 - foR5: TIC error reported on level 2
 - foR6: TIC error at open time reported on level 2
 - foR7: TIC error reported on level 3
 - foR8: TRM error reported on level 3
- The control program maintains an error counter. When the threshold is reached, the control program action is as indicated in the table.
- The control program continues in degraded mode, keeping track of the lost resources, if any.
- The alert/alarm is triggered by MOSS BER ID 06, error code 05.

TRSS BER, Type 15 - IDs 14, 16, 91, 92, 93 (foR1)

Program level 1 generates one of these BERs when an error occurs during a AIO operation on a TRA.

```

                                BER DETAIL
SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd TYPE:15 ID:hh LOST:ddd CP-ABEND:hhhh
TRMnn TICn < error description >
F:bbbbbbbbb
X7E:hhhh X76U:hhhh ETA:hhhh RHB:hh X3F:hhhhhhhh X75:hhhh

X76 TRM STATUS1 CLA1 CLA2 LAB3 CAB FRDV LAB6 LAB5 LAB4 LAB7 LAB8
hhhh bbbbbbbb bbbbbbbb hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh
    
```

TRSS BERs, Type 15 - IDs 18, 97, 98, 9C (foR2)

Program level 1 generates one of the following BERs when an error occurs during an PIO operation on a TRA.

```

                                BER DETAIL
SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd TYPE:15 ID:hh LOST:ddd CP-ABEND:hhhh
TRMnn TICn < error description >
F:bbbbbbbbb
X7E:hhhh X76U:hhhh ETA:hhhh RHB:hh X74:hhhhhhhh
X79:hh IAR:hhhhhh I:hhh TA:hhhh ID:hhhh

X76 TRM STATUS1 CLA1 CLA2 LAB3 CAB FRDV LAB6 LAB5 LAB4 LAB7 LAB8
hhhh bbbbbbbb bbbbbbbb hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh
    
```

TRSS BER, Type 15 - ID 96, 99, 9A, 9B (foR3)

Program level 1 generates one of the following BER when a TRM is disconnected by MOSS, or when an error is exported by a TRM on level 1.

```

                                BER DETAIL
SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd: TYPE:15 ID:96
TRMnn TICn < error description >
F:bbbbbbbbb
X7E:hhhh X76U:hhhh RHB:hh TRMA:hh BRR:hhhh

X76 TRM STATUS1 CLA1 CLA2 LAB3 CAB FRDV LAB6 LAB5LAB4 LAB7 LAB8
hhhh bbbbbbbb bbbbbbbb hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh
    
```

TRSS BER, Type 15 - IDs A3, A4, A5, A7, A8 (foR4)

Program level 2 generates one of the following BERs when an error occurs when internal TRM error or TIC.

```

                                BER DETAIL
SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd TYPE:15 ID:hh
TRMnn TICn < error description >
F:bbbbbbbbb
TA:hhhh TICA:hh
TRM STATUS2
bbbbbbbbb bbbbbbbb
    
```

TRSS (Type 15) BER Detail Display (Part 2 of 3)

TRSS BER, Type 15 - IDs AC (foR5)

Program level 2 generates the following BER when a TIC adapter check occurs on a TIC.

```

                                BER DETAIL
SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd TYPE:15 ID:AC
TRMnn TICn < error description >
F:bbbbbbbb
TA:hhhh TICA:hh
TRM STATUS2
bbbbbbbb bbbbbbbb
TIC ADAPTER CHECK STATUS:
bbbbbbbb bbbbbbbb hhhh hhhh hhhh
    
```

TRSS BER, Type 15 - IDs AF (foR6)

Program level 2 generates the following BER when a TIC check occurs at open time.

```

                                BER DETAIL
SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd TYPE:15 ID:AF
TRMnn TICn < error description >
F:bbbbbbbb
TA:hhhh TICA:hh
TRM STATUS2
bbbbbbbb bbbbbbbb
bbbbbbbb bbbbbbbb
    
```

TRSS BER, Type 15 - IDs B2 (foR7)

Program level 3 generates the following BER when a TIC/TRM check occurs on a command seat to a TRM.

```

                                BER DETAIL
SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd TYPE:15 ID:B2
TRMnn TICn < error description >
F:bbbbbbbb
TA:hhhh TICA:hh
TRM IIR TIC CTL REGISTER
bbbbbbbb bbbbbbbb bbbbbbbb bbbbbbbb
    
```

TRSS BER, Type 15 - IDs B3, B4, B5, B6 (foR8)

Program level 3 generates one of the following BERs when a time-out occurs on a command seat to a TRM.

```

                                BER DETAIL
SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd TYPE:15 ID:hh
TRMnn TICn < error description >
F:bbbbbbbb
TA:hhhh TICA:hh
TRM IR/BR TIC CTL REGISTER
bbbbbbbb bbbbbbbb bbbbbbbb bbbbbbbb
    
```

TRSS BER, Type 15 - Field Explanation

Field Name	Meaning	Details on Page
BRR	Board RDV response to poll Contains the RDV address and error register	2-182
CABR	CAB RDV address and error register	2-182
CLA1	CLAB1 RDV address and error register (see Note)	2-182
CLA2	CLAB2 RDV address and error register (see Note)	2-182
ETA	TA field of IOH failure in level 1	
F	Indicator Flag at level 1 x... .. 1 Control program is NCP or PEP .. 0 Control program is EP .1.. Adapter down ..1. Control program put adapter down ...1 Redrive disabled 1... Reserved1.. Error on 'Get error status'1. CA is being disabled1 IOH or IOHI on level 1 failed twice Indicator Flag at level 2 and 3 x... .. 1 Control program is NCP or PEP .. 0 Control program is EP .1.. Adapter down ..1. Reserved ...1 Reserved 1... TIC dump requested1.. Reserved1. Reserved1 Reserved	
FRDV	Frame RDV address and error register (see Note)	2-182
I	First two bytes of instruction	
IAR	IAR of interrupt level	
IDR	Get line ID response	
LABn	LAB position n RDV address and error register (see Note) (where n is 3, 4, 5, 6, 7, and 8)	2-182 2-182
LOST	Lost record count (LRC)	
NW	Network address (NCP)	
RHB	RDV hash byte is the OR of byte 1 of all read 'RDV address and error register' commands	
SSB	System Status Block	
TA	IOH/IOHI image -- TA data registers X'50', X'70' (TA:hh means TD data byte 1)	11-040
TD	IOH/IOHI image -- TD data adapter specific bytes (TD:hh means TD data byte 1)	11-040
TICA	TIC internal address 00-03 (within the TRM)	
TRM STAT2	TRA Level 2 error status	15-107

continued on next page

TRSS (Type 15) BER Detail Display (Part 3 of 3)

Field Name	Meaning	Details on Page
TRMnn	TRM number (decimal in error description field) This TRM number is derived from: - field TA for PIO operation for CS error reported at level 2 for CA error reported at level 3 - field X75 for AIO operation - field TRM Status LVL1 for TRM adapter error reported at LVL1 If no nn is specified (blank), problem isolation by program was not possible.	
TICn	TIC number 1-4 within the TRM	
TIC ADPT CHECK STAT	Four halfwords giving reason for TIC microcode ABEND	15-137
TRM STAT1	TRA level 1 error status	15-107
TRM IR/ BR	Interrupt request/Bus request flags	15-108
TIC CTL REG	TIC control register	15-106
TRM IIR	TIC interrupt register (initialize)	15-170
X3F	CSP shared pointer register	2-182
X74	X'74' - LAR bytes	10-230
X75	X'75' - Cycle steal control word register	10-230
X76	X'76' - IOC error summary register	10-230
X76U	X'76' - Cause of error not found (PIO to read error register failed)	10-230 2-182
X77	X'77' - Interrupt request reg - adapter level 2 and 3	10-230
X79	X'79' - Interrupt level	10-230
X7E	X'7E' - CCU level 1 interrupt	10-230
X7F	X'7F' - Interrupt request reg - CCU level 2, 3, and 4	10-230

Notes:

1. PF keys and header fields (such as SEL) are explained on page 2-181.
2. All values are in hexadecimal format (X'0' to X'F'), except for:
 - a. The flag byte F and TIC ADPT CHECK STAT, SSB, TRM IR/BR, TIC CTL Register, TRM IIR, TRM status 1, TRM status 2, which are in bit format (8 or 16 bits, 0 or 1)
 - b. The error description line with a TRM number and TIC number, which are in decimal.

MOSS (Type 01) BER Detail Display (Part 1 of 3)

MOSS BER, Type 01 - Summary

BER ID	MOSS Check or Error Code	BER Format (1)	Error Description	Recovery or Control Pgm /Microcode Action	Alarm	Alert	ECR on t (6)
00	02	foM0	Storage parity check on data fetch. Register space parity error. Detected by level 0 (MCPC register bit 2).	MOSS re-IML	no	no	Y
00	03	foM0	TTA parity error MOSS level 0. Detected by level 0 (MCPC register bit 2).	MOSS re-IML	no	no	Y
00	04	foM0	Storage parity check on I fetch. Detected by level 0 (MCPC register bits 2).	MOSS re-IML	no	no	Y
00	06	foM0	I/O error on CCA. PIO time out or inbound parity error. Detected by level 0 (MCPC register bits 0 or 1).	MOSS re-IML	no	no	Y
00	07	foM0	Level 0 I/O error on MCC. PIO time out or inbound parity error (MCPC register bit 2 and MCC Status reg 2, bit 5). CCU time out on MIOC command (MCC Status reg 2, bits 1 and 5). CCU interface parity error on MIOC command (MCC Status reg 2, bits 5 and 7) MIOC Interface parity error on MIOC command (MCC Status reg 2, bits 4 and 5) Invalid command issued by MOSS microcode (MCC Status reg 2, bit 5).	MOSS re-IML	no	no	Y
00	08	foM0	Level 0 I/O error on diskette adapter. PIO time-out or inbound parity error on command to the diskette (Diskette Adapter Status reg, bit 5).	MOSS re-IML	no	no	Y
00	0C	foM0	CCU time-out unrecoverable (MCC Status reg 2, bits 1 and 5).	MOSS re-IML	no	no	Y
00	0D	foM0	CCU-MOSS connection parity error (MCC Status reg 2, bits 5 and 7).	MOSS re-IML	no	no	Y
00	0E	foM0	MIOC interconnection parity error (MCC Status reg 2, bits 5 and 6).	MOSS re-IML	no	no	Y
00	0F	foM0	PIO retry threshold on MCC error (MCC Status reg 2, bit 5).	MOSS re-IML	no	no	Y

BER ID	MOSS Check or Error Code	BER Format (1)	Error Description	Recovery or Control Pgm /Microcode Action	Alarm	Alert	ECR on t (6)
00	all other	foM0	MOSS level 0 reported error. All these errors correspond to MOSS CHECK situations. The complete list is given in the MIM Part 2, Chapter R5. They trigger MOSS complete recovery. Origin : Level 0 Level 1 Level 2 (unexpected interrupts) MOSS supervisor microcode Console support microcode Diskette support microcode MCC support microcode Operator control microcode Mailbox microcode MOSS applications	MOSS dump and reIML	A2	A2	Y
00	any	foM0	MOSS level 0 hardstop (limit threshold). On all the above MOSS CHECK errors, the MOSS attempts recovery by re-IMLing itself. If there are more than 10 such recoveries within 1 hour, the MOSS declares itself down and sends MOSS Inop to NCP/EP (MCC Status Reg 1, bit 3). A HEX Code is displayed on the Ctrl Panel. The Control Program then creates a BER 01 ID 91 and sends Alert A1 to the HOST (NCP only).	MOSS down	no	A1	
01	02	foM1	IOC operation error during MIOH (CCU to MOSS Status A reg, X'11', bit 0)	MOSS reset	no	no	Y
01	02	foM1	IOC operation error (limit threshold)	MOSS down	no	A1	
01	03	foM1	Adapter clock check (MCC Status Reg 2, bit 4)	MOSS reset	no	no	Y
01	03	foM1	Adapter clock check (limit threshold).	MOSS down	no	A1	
01	04	foM1	CCU clock check (MCC Status Reg 2, bit 3).	MOSS reset	no	no	Y
01	04	foM1	CCU clock check (limit threshold).	MOSS down	no	A1	
01	05	foM1	CCU hardcheck detected (CCU to MOSS Status A reg, X'11', bit 6) Upon detection of this event, MOSS will start a CCU automatic re-IPL. See Specific Mechanisms below.	3725 re-IPL	(7)	(7)	
01	07	foM1	Control program abend (CCU to MOSS Status A reg, X'11', bit 1 corresponding to X'79' bit 0.2) Upon detection of this event, MOSS will start a CCU automatic re-IPL. See "BER/Alarm/Alert Mechanism" page 2-250.	3725 re-IPL	(7)	(7)	

For notes, see page 2-242

MOSS (Type 01) BER Detail Display (Part 2 of 3)

MOSS BER, Type 01 - Summary (Continued)

BER ID	MOSS Check or Error Code	BER Format (1)	Error Description	Recovery or Control Pgm /Microcode Action	Alarm	Alert	ECront (6)
01	09	foM1	Address exception check in CCU (CCU to MOSS Status A reg, X'11', bit 5).	MOSS down	no	A1	
01	0A	foM1	MOSS/MIOC operation check, CCU detected (CCU to MOSS Status A reg, X'11', bit 7).	MOSS down	no	A1	
02	any	foM2	CCU logical interface. (2)	MOSS down	no	A1	
02	any	foM2	CCU logical interface. (2)	MOSS fnc message	no	no	
03	any	foM3	Diskette drive and/or adapter error. CNT = 10 and ERROR = X'8x'.	MOSS inop	A3	A3	Y
03	any	foM3	Diskette file error (3). CNT not 10 and ERROR = X'4x'.	-	A4	A4	Y
04	0A	foM4	Console CAC detected exception.	Console unavailable	no	A5	
04	0C	foM4	Console CAC detected error.	unavailable	no	A5	
04	40	foM4	Console error (CCA Basic Status Reg bits 4 and 5).	unavailable	no	A5	
05	any	foM5	MOSS-Scanner interface error. Error detected by MOSS levels 1 or 4, when communicating with a scanner. (MCC Status reg 1, bit 6, at level 4) (CCU to MOSS Status A reg X'11' bit 0, and X'76' bits 0.6 or 0.7, at level 1).	MOSS fnc message	no	no	
06	01	foM7	BER file deleted (via MOSS command)	File purged	no	no	
06	02	foM7	BER stack overflow in MOSS storage. MOSS maintains a 256 byte buffer to stack incoming BERs, before logging on the diskette. Some BERs have been lost.	BERs lost	no	no	
06	03	foM6	3725 IPL error (IPL not stopped). (4) Some errors do not prevent the completion of IPL :console msg -scanner not IMLed successfully -bad parameters passed by Control Program -errors in CA monitoring task -error found on the diskette which is not detrimental for the IPL -console or console adapter error. Corresponding BERs are in the BER File. There is a message on the Console.	IPL completion	no	no	

BER ID	MOSS Check or Error Code	BER Format (1)	Error Description	Recovery or Control Pgm /Microcode Action	Alarm	Alert	ECront (6)
06	04	foM7	Scanner/IOC Bus error during 3725 IPL (IPL not stopped). This BER complements BER 01 03 above, and is specific of one scanner in error. Created upon Checkout results (found in CS field). There is a message on the Console.	IPL Completion Console Msg	A11	A11	
06	05	foM7	3725 re-IPL end. MOSS creates this entry to end the re-IPL and generate the Alert reporting the error that caused the re-IPL. See Specific Mechanisms below.	-	no	(5)	
06	06	foM6	3725 IPL check. The MOSS Microcode action is dependent upon the kind of 3725 IPL or IML error found, see Hex Display (MIM Part 2 Chapter R4).	IPL stopped	A10	no	
06	07	foM7	MOSS offline request by operator.	MOSS offline	A6	A6	
06	08	foM9	3725 re-IPL for CCU hardcheck (CCU to MOSS Status A reg, bit 6). See BER 01 01 05 which precedes it. This BER allows MOSS to create an Alarm. See "BER/Alarm/Alert Mechanism" page 2-250 below.	IPL process Phase 1B	A7	no	
06	08	foM10	3725 re-IPL for Control Program Abend, no BER in CRP, (Ext. reg X'79' bit 0.2, raising CCU to MOSS reg X'11' bit 1 in MOSS) see BER 01 01 07 which precedes it. This BER allows MOSS to create an Alarm. See "BER/Alarm/Alert Mechanism" page 2-250.	IPL process Phase 1B	A8	no	
06	09	foM11	CLDP check (Output X'70' with cause of check in External Reg X'72' bytes 0 and 1). Hex Display indication at Control Panel.				
06	0A	foM12	Unexpected level 1 due to a CA error detected by MOSS during CA monitoring task. (CA level 1 reg X'D', raising CCU level 1 reg X'7E' bit 0.5).		no	no	
07	any	foM13	Moss/TRA interface error Error detected by MOSS level 1, 4 or 7 when communicating with a TRA	Moss appl Message	no	no	

For notes, see page 2-242

MOSS (Type 01) BER Detail Display (Part 3 of 3)

MOSS BER, Type 01 - Summary (Continued)

BER ID	MOSS Check or Error Code	BER Format (1)	Error Description	Recovery or Control Pgm /Microcode Action	Alert	Alarm	EC
The BER IDs that follow are generated by NCP/EP (8)							
91		foM8	Level 1 interrupt MOSS Down passed to Control Program, by MOSS (MCC Status reg 1, bit 3 giving a X'7E' input reg bit 0.0 in the CCU). BER built by Control Program, and saved in the CRP. If this BER is in the diskette BER File, it means that it has been passed to MOSS, when MOSS was re-IMled and set Online. Reason for MOSS down might be found in the BER File itself, by looking at other BERs built by MOSS, which triggered the MOSS Inop bit in MCC Status reg.	MOSS down	no	A1	
B3		foM8	CP/MOSS connection Out Mailbox command time-out at level 3 in Control Program	MOSS down	no	A1	
C1		foM8	CP/MOSS connection Out Mailbox request error at level 4 in Control Program	MOSS down	no	A1	
C2		foM8	CP/MOSS connection In Mailbox command error at level 4 in Control Program	MOSS down	no	A1	

Notes:

1. BERs have different formats and different BER DETAIL screen layouts, according to the type of error reported:

- foM0: Error generated by MOSS microcode level 0
- foM1: Error generated by MOSS microcode level 1
- foM2: Error occurred during CCU/MOSS exchanges
- foM3: Error occurred on diskette drive or diskette drive adapter
- foM4: Error occurred on console or console adapter card
- foM5: Error occurred on a scanner/TRA
- foM6: Error occurred in the BER file during controller initialization
- foM7: Error occurred in the BER file outside controller initialization
- foM8: Error generated by NCP/EP level 3 and 4 (mailbox exchanges)
- foM9: Error generated by MOSS when a re-IPL is started after a CCU hardcheck
- foM10: Error generated by MOSS when the control program abends
- foM11: Error generated by MOSS when a CLDP ends
- foM12: Error generated by MOSS when a channel adapter level 1 error is detected during CA monitoring
- foM13: Error occurred on a TRA

2. MOSS microcode action depends on the logical command content (see page 2-280 for details).

3. Alert/alarm depends on the value of the adapter return code (see page 2-290 for details). These alerts/alarms are sent when the threshold is reached (I/O retries). The number of retries is written in the count (CNT) field of the BER.

4. MOSS microcode action depends on the kind of IPL error found (see page 2-320 for details).

5. BER which triggers the alerts/alarms according to BER ID bit 0 generated by the control program. Bit 0 on causes A7. Bit 0 off causes A8. If no BER is found in the CRP, the alert is A8.

6. A 'Y' in the error count column means that the MOSS microcode maintains an error counter. On reaching the threshold, the action taken by the MOSS microcode is as indicated in the table. The threshold is 10 errors per hour.

7. The alert/alarm is delayed and is triggered later in the re-IPL process:

- a. Alert is triggered by MOSS BER ID 06, error code 05.
- b. Alarm is triggered by MOSS BER ID 06, error code 08.

8. NCP/EP program level 4 generates this BER if an error occurs during mailbox exchanges.

ID 91 is set when the MOSS signals that it is down (MOSS level 1). IDB3, C1, and C2 are set when NCP/EP detects an error on the MIOC card.

All these BERs are logged on the diskette by the MOSS:

- a. After a MOSS intermittent error when the MOSS has successfully completed its own re-IML. The MOSS can retrieve the BERs recorded in the NCP/EP check record pool (CRP).
- b. After a MOSS error has been fixed without powering down the entire controller (for example, a diskette error). BERs stored in the CCU main storage are lost if power down occurs.

Time and date stamping, which is performed by the MOSS, reflects the sequence of events as described above.

BER/Alarm/Alert Mechanism (Part 1 of 2)

BER/ALARM/ALERT MECHANISM ON 3725 CATASTROPHIC ERRORS (3725 DOWN)

Whenever a 3725 down condition is detected, there is a BER/alert/alarm generation mechanism during the automatic 3725 re-IPL initiated by MOSS. The possible causes of the 3725 down condition are:

- CCU hardcheck
- Hardware error
- Software error, hardware detected
- Software error, software detected

For each of these cases the BER/alert/alarm mechanism differs slightly.

CCU Hardcheck

No CP abend

No BER created at detection time

1. MOSS BER type 01, ID 01 (level 1), error code 05 (CCU hardcheck) is created. MOSS initiates re-IPL.
2. MOSS BER (post mortem) type 01, ID 06, error code 08 (3725 re-IPL) is created.
3. MOSS triggers alarm A7 during Phase 1B and stores it in the BER file.
4. MOSS BER type 01, ID 06, error code 05 (automatic re-IPL end) is created. The origin (CCU hardcheck) is displayed on the error description line of the screen (byte 13 of BER contains X'05').

Hardware Error

CP abend.

1. A CP BER is stored in the check record pool (CRP).
2. MOSS BER type 01, ID 01 (level 1), error code 07 (control program abend) is created. MOSS initiates re-IPL.

3. MOSS retrieves the CP BER from the CRP, formats it, and stores it in the BER file.
4. MOSS triggers alarm A7 during Phase 1B and stores it in the BER file.
5. MOSS BER type 01, ID 06, error code 05 (automatic re-IPL end) is created. The origin (CP abend) is displayed on the error description line of the screen (byte 13 of BER contains X'07', bytes 14 and 15 contain the CP abend code)

Software Error, Hardware Detected

CP abend

1. A CP BER is stored in the CRP MOSS BER type 01, ID 01 (level 1), error code 07 (control program abend) is created. MOSS initiates re-IPL.
2. MOSS retrieves the CP BER from the CRP, formats it, and stores it in the BER file.
3. MOSS triggers alarm A8 during Phase 1B and stores it in the BER file
4. MOSS BER type 01, ID 06, error code 05 (automatic re-IPL end) is created. The origin (CP abend) is displayed on the error description line of the screen (byte 13 of BER contains X'07', bytes 14 and 15 contain the CP abend code)

Software Error, Software Detected

CP abend

No BER created at detection time

1. MOSS BER type 01, ID 01 (level 1), error code 07 (CP abend) is created. MOSS initiates re-IPL.
2. MOSS BER (post mortem) type 01, ID 06, error code 08 (3725 re-IPL) is created.
3. MOSS triggers alarm A8 during Phase 1B and stores it in the BER file.
4. MOSS BER type 01, ID 06, error code 05 (automatic re-IPL end) is created. The origin (CP abend) is displayed on the error description line of the screen (byte 13 of BER contains X'07', bytes 14 and 15 contain the CP abend code).

BER/Alarm/Alert Mechanism (Part 2 of 2)

BER/ALARM/ALERT MECHANISM ON 3725 CATASTROPHIC ERRORS (3725 DOWN)

The following table summarizes the BER/ALARM/ALERT generation mechanism during the automatic 3725 re-IPL initiated by MOSS, whenever a 3725 down condition is detected. The step numbers refer to the sequence of successive events.

STEP		CCU HARDCHECK	HARDWARE ERROR CAUSING A 3725 re-IPL	SOFTWARE ERROR CAUSING A 3725 DOWN HARDWARE DET.	SOFTWARE ERROR CAUSING A 3725 DOWN SOFTWARE DET.
	CP Abend	no	yes	yes	yes
1	BER created by	no BER at detect. time	CP (BER in CRP)	CP (BER in CRP)	no BER at detection time
2	BER signaling a Level 1 from CCU; MOSS then initiates re-IPL	01 01 05	01 01 07	01 01 07	01 01 07
3	BER triggering the ALARM during Phase 1B	No BER exists in CCU; MOSS builds a BER (post mortem) 01 06 08 05	BER retrieved by MOSS from CRP	BER retrieved by MOSS from CRP	No BER found in CCU; MOSS builds a BER (post mortem) 01 06 08 07
4	ALARM logged in BER file	A7	A7	A8	A8
5	BER signaling the end of 3725 re-IPL, and triggering the ALERT	01 06 05 05	01 06 05 07	01 06 05 07	01 06 05 07
6	ALERT sent to the Host	A7	A7	A8	A8

Note: In the above table, the BERs are identified by the string :

- Type, ID, Error code, (plus Error code extension, when applicable) see MOSS BER list for details.

Analysis of a BER/ALARM/ALERT Sequence

Any error detected by MOSS during the reIPL checkout tests and the reIPL process will be also logged in between the BERs signaling the start and the end of re-IPL (Steps 2 and 5 in the table on your left). Also any pending BER found by MOSS in the CRP will be fetched and logged during the re-IPL phase 1B.

Therefore a typical sequence would appear like this, as seen in the BER File retrieval screen, option "ALL" :

```

MOSS BER, "ReIPL end"
....
ALARM
BER related to the detected error <---
....
MOSS BER, level 1 received
(CCU Hardcheck or CP Abend)
.
.

```

<----- possible additional
<----- BERs likely to be
<----- related to the error,
<----- but not necessary
<----- for first level
<----- troubleshooting.

ALARM notifying the user about the problem

BER to consider in order to start the
troubleshooting (MIM-2).

Note that BERs are displayed in inverted chronological sequence (most recent first).

MOSS BER, ID 00 (Part 1 of 2)

MOSS BER, Type 01 - ID 00 (foM0)

MOSS microcode level 0 generates the following BER:

```

                BER DETAIL
SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd:dd TYPE:01 ID:00
LVLO < error description line >
MOSS-CHECK:hh LL:hh MCPC:hh IOIR:hh PIRR:hh CM:hh MEF:hh
DATA:hhhhh TTA:hh PSW:hhhh hh hh I:hhhh CNT:hh

OVERRIDE FLAG VALUE WITH NEW HEXADECIMAL VALUE
PF1: BER SUMMARY PF2: BER LIST PF4: PREVIOUS BER PF5: NEXT BER
    
```

MOSS BER (Type 01) ID 00 - Field Explanation

Field Name	Meaning	Details on page
CM	Common mask register (bits 0 thru 7 = levels 0 thru 7)	
CNT	Current error counter (X'00' to X'FF')	This page
DATA	Three bytes. Contents depend on MOSS Check code	Next page
I	Hexa code of failing MOSS instruction (reserved)	
IOIR	IOIR register	14-160
LL	Last level interrupt (bits 0 thru 7 = levels 0 thru 7)	
MCPC	MCPC register	14-160
MEF	Storage expansion feature status byte	This page
MOSS-CHECK	MOSS processor check (abend) code (explained in the error description line) (MIM Part 2 lists all MOSS Checks)	Next page
PIRR	PIRR register (bits 0 thru 7 = levels 0 thru 7)	
PSW	IAR of interrupt level (bytes 0 and 1 of PSW) Condition code and page pointer (PSW bytes 2 and 3)	This page
TTA	Current TTA entry byte	This page

Notes:

1. PF keys and header fields (such as SEL#) are explained on page 2-181.
2. All values are in hexadecimal format (X'0' to X'F').

MEF Status Byte

Bit	Meaning
0	Inhibit latch on
1	TTA parity error
2	Write protect violation
3	16K module installed
4	MEF enabled
5	(not used)
6	(not used)
7	(not used)

PSW (Condition Codes and Page Pointer)

(Bytes 2 and 3 of PSW field)

Bit	Meaning
0-0	Z Condition code
0-1	H Condition code
0-2	Secondary page pointer-bit 0
0-3	Secondary page pointer-bit 1
0-4	Secondary page pointer-bit 2
0-5	Secondary page pointer-bit 3
0-6	Secondary page pointer-bit 4
0-7	Secondary page pointer-bit 5
1-0	C condition code
1-1	V condition code
1-2	Primary page pointer-bit 0
1-3	Primary page pointer-bit 1
1-4	Primary page pointer-bit 2
1-5	Primary page pointer-bit 3
1-6	Primary page pointer-bit 4
1-7	Primary page pointer-bit 5

TTA (Current TTA Entry Byte)

Bit	Meaning
0	0=0 write allowed 0=1 write protected
1	Real 4K block number-bit 0
2	Real 4K block number-bit 1
3	Real 4K block number-bit 2
4	Real 4K block number-bit 3
5	Real 4K block number-bit 4
6	Real 4K block number-bit 5
7	Real 4K block number-bit 6

CNT (Current Error Counter)


Bit	Meaning
0	MOSS re-IML requested
1	MOSS dump requested
2	(not used)
3	(not used)
4	Current error count-bit 0
5	Current error count-bit 1
6	Current error count-bit 2
7	Current error count-bit 3

The current error count may have values between X'0' and X'A'.

MOSS BER, ID 00 (Part 2 of 2)

Data (Contents of Three-Byte Field)

DATA : hh hh hh



MOSS Check	Data Byte 0 Contents	Data Byte 1 Contents	Data Byte 2 Contents
00	X'FF'	X'FF'	X'FF'
01	CCA basic status reg	MCC status reg 2	Diskette status reg
02	Store addr byte 0	Store addr byte 1	Real 4K block numb
02	Reg addr byte 0	Reg addr byte 1	X'FF'
03	X'FF'	X'FF'	X'FF'
04	Store addr byte 0	Store addr byte 1	Real 4K block numb
05	X'FF'	X'FF'	X'FF'
05	Store addr byte 0	Store addr byte 1	X'FF'
05	Store addr byte 0	Store addr byte 1	X'98'
06	CCA basic status reg	X'FF'	X'FF'
07	X'FF'	MCC status reg 2	X'FF'
08	X'FF'	X'FF'	Diskette status reg
09	X'FF'	X'FF'	X'FF'
0A	X'FF'	X'FF'	X'FF'
0B	KBD status reg	MCC status reg 2	Diskette status reg
0C	X'FF'	MCC status reg 2	X'FF'
0D	X'FF'	MCC status reg 2	X'FF'
0E	X'FF'	MCC status reg 2	X'FF'
0F	X'FF'	MCC status reg 2	X'FF'
10	X'FF'	X'FF'	X'FF'
E1	X'FF'	X'FF'	X'FF'

MCC status register 2: see page 14-030

Diskette adapter status register: see page 14-080

CCA basic status register: see page 14-090

MOSS BER, ID 01

MOSS BER, Type 01 - ID 01 (foM1)

MOSS microcode level 1 generates the following BER:

```

                                BER DETAIL
SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd:dd TYPE:01 ID:01
LVL1 < error description line >
ERROR:hh AREG:hh X75:hhhhh X76:hhhhh STAT:bbbbbbb CP-ABEND:hhh

OVERRIDE FLAG VALUE WITH NEW HEXADECIMAL VALUE
PF1: BER SUMMARY PF2: BER LIST PF4: PREVIOUS BER PF5: NEXT BER
    
```

MOSS BER (Type 01) ID 01 - Field Explanation

Field Name	Meaning	Details on page
AREG	CCU/MOSS status A register	This page
CP-ABEND	CP abend code (see corresponding CP BER) (used only with ERROR code 07, program request IPL; otherwise: 'FFFF')	
ERROR	Error code	This page
STAT	MIOC status register 1	This page
X75	X'75' - AIO CSCW byte X, byte 0, byte 1 (only used with ERROR code 07, program request IPL)	10-230
X76	X'76' - IOC level 1 interrupt request (only used with ERROR code 07, program request IPL)	10-230

Notes:

1. When AREG bit 0 is on, X75 and 76 are meaningful.
2. PF keys and header fields (such as SEL#) are explained on page 2-181.
3. All values are in hexadecimal format (X'0' to X'F').

AREG (CCU/MOSS Status A Register)

Bit	Meaning
0	IOC operation error
1	Program request IPL
2	CA request IPL
3	CCU hardstop (no HILR)
4	Program output X'70'
5	Address exception check
6	CCU hardcheck
7	MOSS operation check

The contents of the AREG (MOSS status A register and MCC status register 2, bits 3-7) cause the MOSS level 1 microcode to process the request. Any request processed successfully causes the corresponding error code to be as follows:

Error (Error Codes)

Value	Meaning
01	Scanner IOH error detected
02	IOC operation error
03	Adapter clock check
04	CCU clock check
05	CCU hardcheck detected
06	Output X'70' issued by control program
07	Control program abend
08	Channel (host) IPL request
09	Address exception check in CCU
0A	MOSS/MIOC operation check (CCU detected)

Status

Bit	Meaning
0	Enable timer
1	Enable CCU interrupts
2	Enable scanner interrupts
3	MOSS inoperative
4	Timer interrupt
5	CCU high-level interrupt
6	Scanner interrupt
7	CCU low-level interrupt

MOSS BER, ID 02 (Part 1 of 2)

MOSS BER, Type 01 - ID 02 (foM2)

The MOSS microcode generates the following BER when an error occurs during CCU/MOSS exchanges.

BER DETAIL	
SEL#:ddd	FLAG:hh DATE:dd/dd TIME:dd:dd TYPE:01 ID:02
MIOC	< error description line >
ERROR:hh	CMD:hh PCW:hh hhhh hhhh hhhh hh
MB:hh hh	hhhh hh hhhhhh hhhh hhhh hhhh hhhh
	hhhh hh hhhhhh hhhh hhhhhhhh hhhhhhhh
OVERRIDE FLAG VALUE WITH NEW HEXADECIMAL VALUE PF1: BER SUMMARY PF2: BER LIST PF4: PREVIOUS BER PF5: NEXT BER	

MOSS BER (Type 01) ID 02 - Field Explanation

Field Name	Meaning	Details on page
CMD	Logical command (used in the error description line)	This page
ERROR	Error code (used in the error description line)	This page
MB or PCW	Mailbox contents (16 bytes + 16 bytes) Panel control word byte definition (8 bytes)	14-141 Next page

Notes:

- The logical command (CMD) indicates which field (PCW or MB) is concerned:
 - If the first byte of CMD is 0 or 2, the PCW contents are displayed.
 - If the first byte of CMD is 4 or 8, the MB contents are displayed.
- All values are in hexadecimal format (X'0' to X'F').
- PF keys and header fields (such as SEL#) are explained on page 2-181.

CMD (Logical Command)

CMD	Meaning
80	In mailbox request
81	In mailbox response
40	Out mailbox request
41	Out mailbox response
20	Control Program buffer reading
21	Control Program buffer writing
04	Interrupt level 4 processing
02	MIOC request
01	Read MCC status register 1 impossible

Error (Error Codes)

Err	Meaning
80	Physical error reported (no answer from scanner when the operator performs a SELECT or RELEASE action).
40	Busy bit error
20	Unresolved interrupt l4 cause
10	Unexpected in-mailbox response from control program
08	In mailbox timeout response
04	Invalid out-mailbox request
02	Invalid parameters in microcode request
01	LSSD string select error

PCW (Processor Control Word) Byte Definition

Op type Byte 1 (Note 1)	Byte 2	Byte 3	Byte 4	Byte 5	Byte 6	Byte 7	Byte 8
RD Reg CMDDR-44				XR a	AC MOD		Value
WR Reg CMDDW-45				XR a	AC MOD		Pattern
W LSSD CMDWL-C9			CLKON/ CLKOFF (Note 2)	DIAG/ NODIAG			String TBL a
R LSSD CMDRL-C8		ADJON/ ADJOFF (Note 3)	CLKON/ CLKOFF (Note 3)	DIAG/ NODIAG			String TBL a
EXEC RD CMDER-04			ROS a				Read Value
EXEC WR CMDEW-05			ROS a				Data to Write
RD LSR CMDRR-06	ADDR (Note 4)		ROS a	LSR a			Read Value/ Data MOSS ADDR
WR LSR CMDWR-07	Count (Note 5)		ROS a	LSR a			Data to Write
RD RAM CMDRM-08	NCP RAM Address			(Note 6)			Read Value
RD RAM MULT CMDMR-09	NCP RAM Address			Count			MOSS BUF a
WR RAM CMDWM-0A	NCP RAM Address			(Note 6)			Data to Write
WR RAM MULT CMDMW-0B	NCP RAM Address			Count			MOSS BUF a
IOH CMDIR-03	CAIOHSW/SCAIOHSW: TA value (Note 7)						TD Value
RD PAN CMDRP-C6				CMD Type	Adapter address		Value
WR PAN CMDWP-C7			SET/ RESET (Note 8)	CMD Type	Adapter address		Data

Notes:

1. In byte 1, bit 0 means 'no adapter check'.
2. CLKON: allow set clock on after LSSD operation.
CLKOFF: CAC leave clock off after LSSD operation.
3. ADJON: Last scan out to readjust LSSD strings is executed.
ADJOFF: Last scan out is not executed (used by diagnostics).
4. If ADDR = 00, data read is in data/value of PCW.
If ADDR = 80, data read is at address defined in PCW
(ADDR = number of LSRs to read).
5. If count = 0, only one write LSR operation is executed.
If count = 1, it is a count of LSRs to be written with same data
(in 3 bytes of data/value) operation starting at LSR address
defined in PCW.
6. Only one halfword is read or written.
7. CAIOHSW: Indicate IOH for channel adapter.
SCAIOHSW: Indicate IOH for scanner.
8. SET/RESET: Usable only with 'WRMIOCSR' or 'WRPANSR' command type.

MOSS BER, ID 03

MOSS BER, Type 01 - ID 03 (foM3)

The MOSS microcode generates the following BER when an error occurs in the diskette, diskette drive or diskette drive adapter.

```

                                BER DETAIL
SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd:dd TYPE:01 ID:03
DISK < error description line >
ERROR:hh CMD:hh REQ:hh
CAC= F:hh RCNT:hh ARC:hh STAT:hh TTA:hh ADDR:hhhh
BCLE= F:hh CMD:hh BCNT:hhhh ADDR:hxxxxxxxxx
FILE=eeeeeeee CYL:hh HD:hh REC:hxxx

OVERWRITE FLAG VALUE WITH NEW HEXADECIMAL VALUE
PF1: BER SUMMARY PF2: BER LIST PF4: PREVIOUS BER PF5: NEXT BER
    
```

MOSS BER (Type 01) ID 03 - Field Explanation

Field Name	Meaning	Details on page
CMD	Logical command	This page
ERROR	Error code - X'80' = adapter (only this table) suspect DAC or diskette drive X'40' = diskette drive (add next table) suspect diskette drive: replace it with the spare one	
REQ	Function request code (reserved)	
F	Error record flag from CAC (reserved)	
RCNT	Retry count from CAC (see Note 3)	
ARC	Adapter return code from CAC	This page
STAT	DAC basic status register	14-080
TTA	TTA byte related to ADDR	2-260
ADDR	Storage address register (virtual storage)	

The following additional fields appear when the ERROR code is X'40' (diskette drive)

BCLE	Last executed buffer control list element (CAC related information)	
F	Flag indicator, last BCLE executed	
CMD	Last BCLE command	
BCNT	BCLE related byte count	
ADDR	Last BCLE related address	
FILE	File name or load module (in EBCDIC)	
CYL	Cylinder number	
HD	Header number	
REC	Record number	

CMD (Logical Commands)

Value	Meaning
01	Open
02	Write
03	Read
04	Close
05	Load
06	Direct execute

ARC (Adapter Return Codes)

The error description line is built from the contents of the ARC.

Value	Meaning
20	Indeterminate equipment check
28	Seek check
29	Head check
2A	DMA check during read
2B	DMA check during write
2C	Write current during read
2D	Write current during write
2E	Write control error
34	Overrun
38	MOSS internal bus parity error
3A	CRC error ID
3B	Data CRC error
3C	CRC error on ID control
3D	CRC error on data control
3E	Exception/record not found
3F	Data not extracted
62	Diskette not ready
6D	Diskette speed too low or not running
6E	Diskette speed too high
6F	Invalid diskette format

Notes:

1. PF keys and header fields (such as SEL#) are explained on page 2-181.
2. All values are in hexadecimal format (X'0' to X'F'), except for the file name or module name (FILE), which is in EBCDIC.
3. The CAC will make several retries (up to 10). The retry count contains the number of retries before the diskette operation was successfully terminated.

If RCNT is lower than 10, the last I/O operation was successful. The error was intermittent. If RCNT = 10, the decision (recovery or program action) will be taken by the MOSS application that activated the diskette operation. The error is solid.

MOSS BER, ID 04

MOSS BER, Type 01 - ID 04 (foM4)

The MOSS microcode generates the following BER when an error occurs on the console or on its adapter cards:

BER DETAIL

SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd:dd TYPE:01 ID:04
 DPLY <error description line >
 ERROR:hh CMD:hh BSTAT:hh ASTAT:hh CSTAT:hhhh MSTAT:hh

OVERWRITE FLAG VALUE WITH NEW HEXADECIMAL VALUE
 PF1: BER SUMMARY PF2: BER LIST PF4: PREVIOUS BER PF5: NEXT BER

MOSS BER (Type 01) ID 04 - Field Explanation

Field Name	Meaning	Details on page
ASTAT	Adapter error status register	This page
BSTAT	CCA card basic status register	This page
CMD	Logical command	This page
CSTAT	Console status	This page
ERROR	Error code	This page
MSTAT	M status register	This page

Notes:

1. PF keys and header fields (such as SEL#) are explained on page 2-181.
2. All values are in hexadecimal format (X'0' to X'F').

ERROR (Error Codes)

Value	Meaning
40	Console error
0C	CAC detected error ASTAT = adapter error
0A	CAC detected exception ASTAT = adapter exception status

CMD (Logical Commands)

CMD	Meaning
81	Open console
80	Open CCA adapter
40	Write adapter
20	Read/write adapter
10	Close adapter
08	Lock keyboard

ASTAT - ERROR: X'0C' (Adapter Error)

Bit	Meaning
0	Parity error on receive data
1	DCE error
2	RCV line at space
3	RCV data buffer too short (overflow)
4	Reserved
5	Machine check error
6	RCV text timeout
7	Lost data (overrun)

ASTAT- ERROR: X'0A' (Adapter Exception Status)

Bit	Meaning
0	Read/open halted
1	XMIT/RCV contention occurred
2	BREAK character received
3	Reserved
4	Reserved
5	Reserved
6	Reserved
7	Reserved

BSTAT (Sense Register 3)

Value	Meaning
80	CSR - input request
40	CSR - output request
20	Modem interrupt
10	Timer interrupt
08	Exception interrupt
04	MCPC interrupt
02	Adapter enabled
01	Adapter interrupt pending

CSTAT (Console Status - ERROR: X'40')

Bit	Meaning
0-0	Parity bit
0-1	Not bit 2
0-2	Communication buffer overrun
0-3	Line parity error detected
0-4	Command error detected
0-5	Reserved
0-6	Keyboard locked
0-7	Reserved
1-0	Parity bit
1-1	Not bit 2
1-2	Block mode
1-3	Half-duplex mode
1-4	Reserved
1-5	Reserved
1-6	Program mode
1-7	Reserved

The correct console status is X'4030'

MSTAT (Sense Register 4)

Value	Meaning
80	Data set ready (DSR)
40	Clear to send (CTS)
20	Received line signal detector (RLSD)
10	Ring indicator
08	DSR transitioned
04	Reserved
02	RLSD transitioned
01	CTS transitioned

MOSS BER, ID 05 (Part 1 of 2)

MOSS BER, Type 01 - ID 05 (foM5)

The MOSS microcode generates the following BERs when an error occurs on a scanner or on the MOSS/scanner connections.

MOSS BER, Error Code 00 (foM5)

```

                                BER DETAIL
SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd:dd TYPE:01 ID:05
SCNR SCANNER DUMP COMPLETE
ERROR:00 ADDR:hh
  
```

```

OVERWRITE FLAG VALUE WITH NEW HEXADECIMAL VALUE
PF1: BER SUMMARY PF2: BER LIST PF4: PREVIOUS BER PF5: NEXT BER
  
```

MOSS BER, Error Code 01 (foM5)

```

                                BER DETAIL
SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd:dd TYPE:01 ID:05
SCNR CHECK OUT FAILURE
ERROR:01 ADDR:hh CSCHK:hhhh
  
```

```

OVERWRITE FLAG VALUE WITH NEW HEXADECIMAL VALUE
PF1: BER SUMMARY PF2: BER LIST PF4: PREVIOUS BER PF5: NEXT BER
  
```

MOSS BER, Error Code 02 (foM5)

```

                                BER DETAIL
SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd:dd TYPE:01 ID:05
SCNR MAILBOX ERROR STATUS
ERROR:02 ADDR:hh MBST:hhhh
  
```

```

OVERWRITE FLAG VALUE WITH NEW HEXADECIMAL VALUE
PF1: BER SUMMARY PF2: BER LIST PF4: PREVIOUS BER PF5: NEXT BER
  
```

MOSS BER, Error Code 04 (foM5)

```

                                BER DETAIL
SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd:dd TYPE:01 ID:05
SCNR UNRESOLVED INTERRUPT
ERROR:04 ADDR:hh
  
```

```

OVERWRITE FLAG VALUE WITH NEW HEXADECIMAL VALUE
PF1: BER SUMMARY PF2: BER LIST PF4: PREVIOUS BER PF5: NEXT BER
  
```

MOSS BER, Error Code 05 (foM5)

```

                                BER DETAIL
SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd:dd TYPE:01 ID:05
SCNR INOPERATIVE
ERROR:05 ADDR:hh TD:hhhh
  
```

```

OVERWRITE FLAG VALUE WITH NEW HEXADECIMAL VALUE
PF1: BER SUMMARY PF2: BER LIST PF4: PREVIOUS BER PF5: NEXT BER
  
```

MOSS BER, Error Codes: 10, 20, and 40 (foM5)

```

                                BER DETAIL
SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd:dd TYPE:01 ID:05
SCNR ERROR DETECTED ON LVL4
ERROR:hh ADDR:hh X76:hhhhhh STAT:hhhh
  
```

```

OVERWRITE FLAG VALUE WITH NEW HEXADECIMAL VALUE
PF1: BER SUMMARY PF2: BER LIST PF4: PREVIOUS BER PF5: NEXT BER
  
```

MOSS BER, Error Codes: 08, and 80 (foM5)

```

                                BER DETAIL
SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd:dd TYPE:01 ID:05
SCNR ERROR DETECTED ON LVL1
ERROR:hh ADDR:hh X76:hhhhhh STAT:hhhh
  
```

```

OVERWRITE FLAG VALUE WITH NEW HEXADECIMAL VALUE
PF1: BER SUMMARY PF2: BER LIST PF4: PREVIOUS BER PF5: NEXT BER
  
```

MOSS BER, Error Code FF (foM5)

```

                                BER DETAIL
SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd:dd TYPE:01 ID:05
SCNR DUMP FAILURE
ERROR:FF ERR-EXT:hh ADDR:hh TD:hhhh
  
```

```

OVERWRITE FLAG VALUE WITH NEW HEXADECIMAL VALUE
PF1: BER SUMMARY PF2: BER LIST PF4: PREVIOUS BER PF5: NEXT BER
  
```

MOSS BER, ID 05 (Part 2 of 2)

MOSS BER (Type 01) ID 05 - Field Explanation

Field Name	Meaning	Details on page
ADDR	Scanner address as shown in "Scanner Addressing" (Hex)	11-050
X76	X'76' (bytes X, 0, and 1 of field X76 on screen) or MOSS command completion (bytes 0 and 1; X not used) depending on the error code (see "ERROR", on this page)	10-230 13-352
STAT	Error status or mailbox status depending on the error code (see "ERROR", on this page)	13-352
TD	Last command (DB0 and DB1 at TD time)	13-122
MBST	Mailbox error status	14-141
CSCHK	Scanner checkout code (microcode)	

Notes:

1. PF keys and header fields (such as SEL#) are explained on page 2-181.
2. All values are in hexadecimal format (X'0' to X'F').
3. For details of scanner/MOSS communication, see page 14-150.
4. When the error is found during a scanner IML, the following message is displayed:

SCANNER CHECKOUT FAILED: RETURN CODE = xxxx

In this case, return code xxxx is the value of the STAT field of the BER with the error status condition. This STAT field is also displayed on the CE latched indicator (CELIA) card, which allows the error to be isolated. See MIM Part 2, Chapter R3, under FIC and BER 'STAT' Field Index.

BERs Printed on Host

The length of the BERs printed from the diskette on the host is not significant. When the BER detail is displayed on the console display, only the useful information is given. The remaining BER bytes, if any, printed but not displayed have no meaning. Do not try to interpret them, they may lead to erroneous actions.

ERROR (Error Codes)

Code	Meaning
FF	Scanner dump request failed ADDR = scanner address ERR-EXT = error code extension (this page) TD = last command
80	Error detected by level 1 X76 = Register X'76' (bytes X, 0, and 1) STAT = MOSS status (page 13-352)
40	Error detected by level 4 X76 = MOSS command completion (bytes 0 and 1) STAT = MOSS status (page 13-352)
20	Error detected by level 4 X76 = MOSS command completion (bytes 0 and 1) STAT = mailbox status (page 14-141)
10	Error detected by level 4 without information STAT = FFFF
08	Error detected by level 1 during MIOH X76 (bytes X, 0, 1 = X'000000' STAT = MOSS status (page 13-352)
05	Scanner set inoperative, expected interrupt not received TD = last command (page 13-122)
04	Error detected by TSS functions, unexpected interrupt received
02	Error detected by TSS functions, MBST = mailbox status (page 14-141)
01	Logical error detected by scanner IML CSCHK = scanner checkout code
00	Scanner dump request fulfilled

ERR-EXT (Error Code Extension)

ERR-EXT	Decoding for Error Code FF
01	Dump failure due to file full
02	Dump failure due to diskette error
03	Dump failure due to hardware error (MIOC/TSS)

MOSS BER, ID 06 (Part 1 of 5)

MOSS BER, Type 01 - ID 06 (IPL) (foM6)

The MOSS microcode generates the following BER when an error occurs in the BER file during controller initialization.

```

                                BER DETAIL
SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd:dd TYPE:01 ID:hh
APPL < error description line >
ERROR:hh IPLREQ:hh C REQ:hh STAT:hh IPL-CHECK:hhhh
SCB:hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh
    hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh
DISK:hhhh hhhh hhhh hhhh hhhh
CS:hhhh hhhh hhhh hhhh hhhh hhhh hhhh hhhh F:hh
X71:hhhhh X72:hhhhh

OVERRIDE FLAG VALUE WITH NEW HEXADECIMAL VALUE
PF1: BER SUMMARY PF2: BER LIST PF4: PREVIOUS BER PF5: NEXT BER
    
```

MOSS BER, Type 01 - ID 06 (not IPL) (foM7)

The MOSS microcode generates the following BER when an error occurs in the BER file outside controller initialization.

The error description line contains information such as the CP abend code, the scanner address, or the number of BERs lost.

```

                                BER DETAIL
SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd:dd TYPE:01 ID:06
APPL < error description line >
ERROR:hh

OVERRIDE FLAG VALUE WITH NEW HEXADECIMAL VALUE
PF1: BER SUMMARY PF2: BER LIST PF4: PREVIOUS BER PF5: NEXT BER
    
```

Note: For abends, see ACF/NCP for the 3725, Emulation Program for the 3725 Reference Summary and Data Areas, LY30-3070, and ACF for System Support Programs, Diagnosis Reference, LY30-3060.

MOSS BER (Type 01) ID 06 - Field Explanation

foM6 format displays all fields described below.

foM7 format displays only the ERROR field.

Field Name	Meaning	Details on page
C REQ	Cancel request	2-322
CS	Scanner error	2-323
DISK	Diskette error	2-322
ERROR	Error code	2-321
IPL-CHECK	IPL CHECK code assigned by MOSS (corresponds to hex display value preceded by 0)	
IPL REQ	Controller IPL type	2-322
F	IPL error flag	2-323
SCB	Scanner control block	2-323
STAT	System status	2-322

FoM9, foM10, foM11 and foM12 may display the following additional fields:

Field Name	Meaning	Details on page
CCUI	CCU user indicator	2-324
CP-ABEND	Control program abend code	(see Note)
ERROR-EXT	Error code extension	2-322
HDCK	Hardcheck register	2-324
HKNG	Register HKNG	2-324
IAR	CCU instruction address register	10-030
IPL-CHECK	IPL application abend code (0F1B: CLDP abend)	
LAR	Lagging address register	10-030
PARITY	Parity byte (0 to 7) associated with the previous field (SAR, IAR, or LAR)	
SAR	Storage address register	10-030
STUI	Storage user indicator	2-324
WKRx	CCU work registers 1 to 7 (work register 0: IAR)	10-030
X71,72	Registers	10-230
X76,7D,7E	Registers	10-230
X0-X7 XB-XF	Channel adapter registers	12-025

MOSS BER, ID 06 (Part 2 of 5)

MOSS BER, Type 01 - ID 06 (foM9)

The MOSS microcode generates the following BER when a CCU hardcheck occurs and a Re-IPL is started.

The error description line contains information fetched from the LSSD strings saved when the error occurs.

```

                                BER DETAIL
SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd:dd TYPE:01 ID:06
APPL < error description line >
ERROR:hh ERROR-EXT:hh HKNG:hhhhhh SAR:hhhhhh PARITY:hh
IAR:hhhhhh PARITY:hh LAR:hhhhhh PARITY:hh
HDCK:hhhhhh CCUI:hh STUI:hh
X7D:hhhh X7E:hhhh X76:hhhh

OVERRIDE FLAG VALUE WITH NEW HEXADECIMAL VALUE
PF1: BER SUMMARY PF2: BER LIST PF4: PREVIOUS BER PF5: NEXT BER

```

Error description line: '3725 RE-IPL STARTED FOR CCU HARDCHECK'

MOSS BER, Type 01 - ID 06 (foM10)

The MOSS microcode generates the following BER when the control program abends:

```

                                BER DETAIL
SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd:dd TYPE:01 ID:06
APPL < error description line >
ERROR:hh ERROR-EXT:hh CP-ABEND:hhhh

OVERRIDE FLAG VALUE WITH NEW HEXADECIMAL VALUE
PF1: BER SUMMARY PF2: BER LIST PF4: PREVIOUS BER PF5: NEXT BER

```

Error description line: '3725 RE-IPL STARTED FOR CP ABEND hhhh'

MOSS BER, Type 01 - ID 06 (foM11)

The MOSS microcode generates the following BER when the CLDP dump abends:

```

                                BER DETAIL
SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd:dd TYPE:01 ID:06
APPL < error description line >
ERROR:hh IPL-CHECK:hhhh X71:hhhhhh X72:hhhhhh IAR:hhhhhh
WKR1:hhhhhh WKR2:hhhhhh WKR3:hhhhhh WKR4:hhhhhh WKR5:hhhhhh
WKR6:hhhhhh WKR7:hhhhhh

OVERRIDE FLAG VALUE WITH NEW HEXADECIMAL VALUE
PF1: BER SUMMARY PF2: BER LIST PF4: PREVIOUS BER PF5: NEXT BER

```

Error description line: '3725 CLDP CHECK hhhh' (codes given in MIM2)

Notes:

- Use CCU Function "10" to display the CA regs; if reg "E" indicates a CA Int. lvl 1, then record the contents of all the CA registers.
- The contents of WKR's with useful information when X72=001002 are listed below:

Field name	Content
WKR 3	IN '7E'
WKR 4	IN '7D'
WKR 5	IN '76'

- If the abend is caused by a CA Level 1 error, WRK 6 will contain in 'D' and WRK 7 will contain in 'E'.

MOSS BER, Type 01 - ID 06 (foM12)

The MOSS microcode generates the following BER when a channel adapter level 1 error occurs during CA monitoring:

```

                                BER DETAIL
SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd:dd TYPE:01 ID:06
APPL < error description line >
ERROR:hh X0:hhhh X1:hhhh X2:hhhh X3:hhhh X4:hhhh
X5:hhhh X6:hhhh X7:hhhh XB:hhhh XC:hhhh XD:hhhh
XE:hhhh XF:hhhh

OVERRIDE FLAG VALUE WITH NEW HEXADECIMAL VALUE
PF1: BER SUMMARY PF2: BER LIST PF4: PREVIOUS BER PF5: NEXT BER

```

Error description line: 'CAN LVL1 ERROR'

ERROR (Error Codes)

Error code	Meaning	Fields on Screen
03	IPL complete (with errors)	Format foM6 (all fields)
06	IPL not complete (with errors)	Format foM6 (all fields)
0A	IPL not complete	Format foM6
01	BER file deleted	Format foM7
07	MOSS offline	Format foM7
02	BER lost, count purged	Format foM7 Number of BERs lost in the error description line
04 '10')	Scanner not IMled	Format foM7 Scanner address (X'01' to in the error description line
05	CCU automatic re-IPL	Format foM7
08	3725 re-IPL started	Format foM9 CCU hard check, program request IPL, and CP abend code in the) foM10 error description line)
09	CLDP check	Format foM11 3725 loader/dump abend (1)
0A	CA monitoring level 1 error	Format foM12 3725 channel adapter registers

Note 1: If register E indicates a CA level 1 interrupt, display and record the CA registers 6D and 6F.

MOSS BER, ID 06 (Part 3 of 5)

ERROR-EXT (Error Code Extension)

Error code	Meaning	Fields on Screen
05	Re-IPL started for CCU hardcheck	Format foM9
07	Re-IPL started for a CP abend	Format foM10

IPL REQ

Bit	Function
0	Spare
1	Spare
2	Spare
3	Power on IPL
4	Function switch on NORMAL
5	Spare
6	I from console (CCU/Scanners)
7	Cancel request (see C REQ field)

C REQ (Cancel Request)

Byte value	Meaning
05	CCU hardcheck
07	Program request IPL
08	CA request IPL

STAT (System Status)

Bit	Function
0	Reserved
1-2	00 MOSS alone 01 MOSS offline 10 3725 operational 11 Reserved
3	MOSS IMLed
4	Reserved
5	CCA card down
6	Console not connected (power off or in test mode)
7	Reserved

DISK (Diskette Errors)

Five halfwords, all having the same bit use and meaning (see below), record diskette errors during IPL. Their content is as follows:

HW1 Errors during Open commands
 HW2 Errors during Read commands
 HW3 Errors during Load commands
 HW4 Errors during Write commands
 HW5 Errors during Close commands

Halfword Contents	File Name	Module Name	IPL Error Description	IPL Check
1... ..	CHGCDS	--	CDF not accessible	F14
.1... ..	CHGROA	--	Roll-in not available	(None)
..1... ..	CHGMOD37	CHIGDP00	CCU test not performed	(None)
...1... ..	CHGMOD37	CHIGJBCK	IOC bus checkout test failed	F18
....1... ..	CHGCDS	--	IPL ports table not accessible	F19
.... .1... ..	CHGLSR	--	LSR not saved	(None)
.... ..1... ..	CHGMOD37	CHGCLDP	CLDP not accessible	F1A
.... ...1... ..	CHGMOD37	CHIIPMVR	First 16K of storage not saved on diskette	F23
....1... ..	CHGMDJIB	CHHMCSP	IPL fails on all scanners	F24
....XXX XXXX	-	--	(spare)	

The IPL check codes are both displayed on the hex display of the control panel, and the field 'W' of the MSA (IPL CHECK xxx). The IPL abends on IPL check.

The file or module location and contents are as follows:

File or Module Name	Diskette	Contents
CHGCDS	Both	Configuration data file
CHGROA	Controller	CCU roll-in/roll-out area (file)
CHIGDP00	Controller	CCU full instruction test module
CHIGJBCK	Controller	IOC bus test module
CHGCDS	Controller	IPL port table (file)
CHGLSR	Controller	Local store save area (file)
CHGCLDP	Controller	3725 load/dump module
CHIIPMVR	Controller	IPL mover module
CHHMCSP	Controller	Scanner load module

The CHGxxx files can be displayed using the 'DUMP DPLY/DEL' utility program (see page 2-391). This function despite its name, can be used for displaying, but not deleting the files.

The CHxxx modules can be displayed using the 'MODULE DPLY' utility program (see page 2-393).

MOSS BER, ID 06 (Part 4 of 5)

SCB (Scanner Control Block)

Each of the 16 bytes gives information concerning one of the scanners (from 1 to 16 except 2 and 4, which are not valid).

The position of the byte gives the corresponding scanner number.

Byte Contents	Meaning
1... ..	Scanner present physically during scanner IML.
.1... ..	Scanner/TRA is the one currently selected by the scanner task.
..1... ..	Scanner/TRA is on CLAB or on a LAB type A (set up during scanner IML).
...1... ..	Scanner went down: an automatic dump request is pending or in process (set up in error log function).
.... 1... ..	Automatic scanner IML has failed, or scanner went down twice in the minimum time range, or scanner could not be set up by scanner task or during general IPL.
.... .1... ..	CSP reset has been done by the control program
.... ..1... ..	Command engaged with scanner has failed with a level 1 interrupt to MOSS: Interrupt handler has tried a get error status that failed.
....1... ..	Scanner has been successfully IML'd, and no action (stop, go, connect, disconnect, or reset) has been performed and no scanner error has been detected. If TRA: No error found for this TRA.
.... 1... ..	TIC 1 is physically present.
....1... ..	TIC 2 is physically present.
....1... ..	TIC 3 is physically present.
....1... ..	TIC 4 is physically present.
.... 1... ..	TRA is physically present.
....xxx	Spare

CS (Scanner Errors)

In each halfword, the bit position gives the scanner number (bit 0 = scanner 1 ... bit 15 = scanner 16 except scanners 2 and 4, which do not exist).

Scanner error (eight halfwords) description by halfword:

HW1	Not present (according to "NCP to Scanner Load Module ID" table)
HW2	Bad IOC bus test result
HW3	Error during scanner load module load
HW4	Bad scanner checkout result
HW5	Timeout during MIOH on scanner (could be a bad checkout result)
HW6	Bad block transfer between CCU and scanner
HW7	Bad scanner initialization
HW8	Reserved

Example: CS: 0000 8000 0000 0000 0000 0000 0000 0000
The meaning of this line is: scanner 1 has a bad IOC test result.

F IML Error Flag

Byte contents:


1... ..	Bad branch trace buffer length
.1... ..	Bad check record pool
..1... ..	Bad control program interconnection table
...1... ..	Level 1 on CA during CA monitoring (see HW8)
.... 1... ..	MIOC error during CA monitoring
.... ..1... ..	CCA down flag
.... ...1... ..	Error when reading X 71
....1... ..	CLDP reload request

MOSS BER ID 06 (Part 5 of 5)


REGISTER DESCRIPTIONS ON IPL CHECK

X71


Byte X



Byte 0



Byte 1



CA or link address,
according to IOC bus format

X72

This register contains the CLDP codes.
For detailed information, see MIM Part 2
vol. A01, Section R-2, CLDP table.

CCU User Indicator

Bits								Meaning
0	1	2	3	4	5	6	7	
x	x	x	x	x	0	0	0	Idle
x	x	x	x	x	0	0	1	Spare
x	x	x	x	x	0	1	0	MOSS using MIOC
x	x	x	x	x	0	1	1	Branch trace
x	x	x	x	x	1	0	0	Branch trace wrap
x	x	x	x	x	1	0	1	Error during interrupt
x	x	x	x	x	1	1	0	IOC during AID
x	x	x	x	x	1	1	1	Error during program instruction execution

Storage User Indicator

Bits								Meaning
0	1	2	3	4	5	6	7	
x	x	x	x	x	0	0	0	Storage idle
x	x	x	x	x	0	0	1	Spare
x	x	x	x	x	0	1	0	MOSS using storage
x	x	x	x	x	0	1	1	Branch trace
x	x	x	x	x	1	0	0	Error during IPF
x	x	x	x	x	1	0	1	IPF during interrupt handling
x	x	x	x	x	1	1	0	IOC using storage
x	x	x	x	x	1	1	1	Error during program execution

HKNG Register

CCU errors from register X7D

Byte X

Bit	Function
0	ALU compare error on byte x
1	ALU compare error on byte 0
2	ALU compare error on byte 1

Byte 0

Bit	Function
0	POP parity error
1	MDOR parity error
2	MIOC error latch
3	Double-bit error detected
4	BSM control error
6	Storage address/data parity error
7	Local store parity error

Byte 1

Bit	Function
1	A/B bus parity error
2	IOC parity error
4	SAR parity error
5	ROS parity error
6	ZR parity error
7	Level 1 error re-entry

HDCK Register

Byte X

Bit	Function
0	MDOR parity error
1	A/B bus parity error
2	Level 1 error re-entry
3	BSM control error
4	Double-bit error detected
5	MIOC error latch
6	Spare
7	Spare

Byte 0

Bit	Function
0	Spare
1	IOC CCU error
2	IOC timeout error
3	IOC bus in parity error
4	Spare
5	Spare
6	IOC address exception
7	IOC storage protection

Byte 1

Bit	Function
0	LS parity error
1	Storage address/data parity error
2	POP parity error
3	ROS parity error
4	SAR parity error
5	ZR parity error
6	IOC parity error
7	Spare

MOSS BER, ID 07

MOSS BER, Type 01 ID 07 (foM13)

The MOSS generates the following BERs when an error occurs on a TRA or on the MOSS/TRA connections.

MOSS BER, Type 01-ID 07 Error 04/08/40/80 (foM13)

```

                                BER DETAIL
SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd TYPE:01 ID:07
TRM < description of the error >
ERROR:hh ADDR:hhhh X76:hhhhhh
MOSS ERROR STATUS:hhhh
LEVEL1 ERROR STATUS:hhhh
LEVEL2 ERROR STATUS:
TIC1:hhhh TIC2:hhhh TIC3:hhhh TIC4:hhhh
TIC CTL REGISTER:
bbbbbbbb bbbbbbbb

OVERRIDE FLAG VALUE WITH NEW HEXADECIMAL VALUE
PF1: BER SUMMARY PF2: BER LIST PF4: PREVIOUS BER PF5: NEXT BER
    
```

MOSS BER, Type 01-ID 07 Error FF (foM13)

```

                                BER DETAIL
SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd TYPE:01 ID:07
TRM TIC DUMP FAILURE
ERROR:FF ERROR-EXT:hh ADDR:hh TIC NBR:hh

OVERRIDE FLAG VALUE WITH NEW HEXADECIMAL VALUE
PF1: BER SUMMARY PF2: BER LIST PF4: PREVIOUS BER PF5: NEXT BER
    
```

MOSS BER, Type 01-ID 07 Error 00 (foM13)

```

                                BER DETAIL
SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd TYPE:01 ID:07
TRM TIC DUMP COMPLETE
ERROR:00 ADDR:hh TIC NBR:hh

OVERRIDE FLAG VALUE WITH NEW HEXADECIMAL VALUE
PF1: BER SUMMARY PF2: BER LIST PF4: PREVIOUS BER PF5: NEXT BER
    
```

MOSS BER, Type 01-ID 07 Error FE (foM13)

```

                                BER DETAIL
SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd TYPE:01 ID:07
TRM TIC SET STG BLK FAILURE
ERROR:FE TRM INPUT ADDR:hhhh TRM OUTPUT ADDR:hhhh
TIC ADDR:hh
2K BLOCK:hh INITIAL REQUESTED FINAL
                hhhh hhhh hhhh
STOP COMMAND CNT:hh

OVERRIDE FLAG VALUE WITH NEW HEXADECIMAL VALUE
PF1: BER SUMMARY PF2: BER LIST PF4: PREVIOUS BER PF5: NEXT BER
    
```

MOSS BER (type 01) ID 07 Field explanation

Field Name	Meaning	Details on Page
ADDR	TRA address TA field	15-105
GET COMMAND COMPLETION	TRA interrupt information	15-120
MOSS ERROR STATUS	MOSS/TRA error information	15-108
LEVEL1 ERROR STATUS	TRA error information	15-107
LEVEL2 ERROR STATUS	TIC error information	15-107
TIC CTL REGISTER	TIC Control Register	15-106
TIC NBR/TIC ADDR	TIC number (1-4)	
TRM INPUT ADDR	TA of last input MIOH	15-105
TRM OUTPUT ADDR	TA of last output MIOH	15-105
2K BLOCK	Initial, requested and final 2K byte block of TIC storage	
STOP COMMAND CNT	Number of increments of 2K block Storage pointer done (Subtract 1 from this number)	

ERROR (Error Code)

Bit	Meaning
00	Automatic TIC dump request complete
04	Error detected by TRSS services Expected interrupt not received from TRA
08	Error detected by level 1 with get error status MIOH
40	Error detected by level 4 with get error status MIOH
80	Error detected by level 1
FE	Error setting TIC 2K storage block during dump or display
FF	Automatic TIC dump failed

ERR-EXT (Error Code Extension)

ERR-EXT	Decoding for Error Code FF
01	Dump failure due to file full
02	Dump failure due to diskette error
03	Dump failure due to hardware error (MIOC/TRA)
04	Dump failure due to select error

MOSS BER, ID 91, B3, C1, C2

MOSS BER, Type 01 - IDs 91 B3 C1 C2 (foM8)

NCP/EP program level 1 generates BER 91 when the MOSS goes down.

NCP/EP program level 4 generates BERs B3, C1, and C2 if a MOSS error occurs during a mailbox exchange. This BER will be transferred to MOSS if MOSS successfully recovers from the MOSS error. These BERs should always be accompanied by MOSS BER IDs 00, 01, 02, or 03. When the BER ID 91 is not accompanied by one of these BERs, it only means that the MOSS has been inoperative during a period of time (MOSS re-IML, MOSS dump) and the BER ID is logged for information only.

```

                                BER DETAIL
SEL#:ddd FLAG:hh DATE:dd/dd TIME:dd:dd TYPE:01 ID:hh
CP < error description line >
MB:hh hh hhhh hh hhhhhh hhhh hhhh hhhh hhhh
   hhhh hh hhhhhh hhhhhhhhhhhhhhhhhhhhh

OVERRIDE FLAG VALUE WITH NEW HEXADECIMAL VALUE
PF1: BER SUMMARY  PF2: BER LIST  PF4: PREVIOUS BER  PF5: NEXT BER
    
```

Field Explanation (Type 01 IDs 91 B3,C1,C2, NCP/EP)

Field Name	Meaning	Details on page
MB	bytes 1 thru 16 (hex 0 thru F): Mailbox REQUEST zone (in/out) (first line on the screen)	14-140
	bytes 17 thru 32 (hex 10 thru 1F): Mailbox RESPONSE zone (in/out) (second line of the screen)	14-140

BER Layout on Diskette (Part 1 of 3)

CA BERs (Type 10)

foC1 (page 2-190)

TYPE: 10 ID: 18 1C 1E 97 9B	
Byte	Field
1-9	Header
10-11	TYPE-ID
12	LOST
13-14	Abend
15-16	x7E
17-18	x76
19-20	I
21-24	x74
25-26	xD
27-28	x76U
29-30	ETA
31	n/a
32	CAA
33	F
34	RHB
35-36	CLA1
37-38	CLA2
39-40	LAB3
41-42	CABR
43-44	FRDV
45-46	LAB4
47-48	LAB5
49-50	LAB6
51-52	LAB7
53-54	LAB8
55-56	n/a
57-60	IAR
61-62	TA
63-64	TD
65-112	CAB/CHCB
113-114	CABCNTL
115-140	CA Regs x0-xF

foC2 (page 2-190)

TYPE: 10 ID: 14 16 91 9A	
Byte	Field
1-9	Header
10-11	TYPE-ID
12	LOST
13-14	Abend
15-16	x7E
17-18	x76
19-20	x75
21-22	n/a
23-24	ETA
25-26	x6D
27-28	x76U
29-32	x3M
33	F
34	RHB
35-36	CLA1
37-38	CLA2
39-40	LAB3
41-42	CABR
43-44	FRDV
45-46	LAB4
47-48	LAB5
49-50	LAB6
51-52	LAB7
53-54	LAB8
55-56	n/a
57-104	CAB/CHCB
105-106	CABCNTL
107-132	CA Regs x0-xF

foC3 (page 2-190)

TYPE: 10 ID: 10 1B IF 90 92 93 94 95 96 98 99 9C 9E 9F	
Byte	Field
1-9	Header
10-11	TYPE-ID
12	LOST
13-14	Abend
15-16	x7E
17-18	x76
19	CAA
20	n/a
21-24	x74
25-26	xD
27-28	x76U
29-30	BRR
31-32	xE
33	F
34	RHB
35-36	CLA1
37-38	CLA2
39-40	LAB3
41-42	CABR
43-44	FRDV
45-46	LAB4
47-48	LAB5
49-50	LAB6
51-52	LAB7
53-54	LAB8
55-56	n/a
57-58	ETA
59-106	CAB/CHCB
107-108	CABCNTL
109-134	CA Regs x0-xF

foC4 (page 2-190)

TYPE: 10 ID: 33 34 35 B1 B2 B5 B6	
Byte	Field
1-9	Header
10-11	TYPE-ID
12	LOST
13-14	Abend
15-16	x77
17-18	x7F
19-20	x0\
21-22	x1
23-24	x2
25-26	x3
27-28	x4
29-30	x5>CA
31-32	x6 Regs
33-34	x7
35-36	x8
37-38	xC
39-40	xF/
41-88	CAB/CHCB
89-90	CABCNTL

TSS BERs (Type 11)

foT1 (page 2-200)

TYPE: 11 ID: 14 16 91 92 93	
Byte	Field
1-9	Header
10-11	TYPE-ID
12	LOST
13-14	Abend
15-16	x7E
17-18	x76
19-20	x75
21-22	n/a
23-24	ETA
25-26	CS STATUS2
27-28	x76U
29-32	x3F
33	F
34	RHB
35-36	CLA1
37-38	CLA2
39-40	LAB3
41-42	CABR
43-44	FRDV
45-46	LAB4
47-48	LAB5
49-50	LAB6
51-52	LAB7
53-54	LAB8

foT5 (page 2-200)

TYPE: 11 ID: A2 A4	
Byte	Field
1-9	Header
10-11	TYPE-ID
12	LOST
13-14	Abend
15	F
16	n/a
17-18	IDR
19-46	PSA
38	LCS
47	TA (byte 0)
48	TD (byte 1)
49-50	NW
51-86	IOB/LXB
87-150	CCB
151-164	AXB IOB Trace
165-181	AXB PSA Trace
182-197	SCB
198	SCBCSCF

foT2 (page 2-200)

TYPE: 11 ID: 18 1B 97 98 9C	
Byte	Field
1-9	Header
10-11	TYPE-ID
12	LOST
13-14	Abend
15-16	x7E
17-18	x76
19-20	I
21-24	x74
25-26	CS STATUS1
27-28	x76U
29-30	ETA
31-32	n/a
33	F
34	RHB
35-36	CLA1
37-38	CLA2
39-40	LAB3
41-42	CABR
43-44	FRDV
45-46	LAB4
47-48	LAB5
49-50	LAB6
51-52	LAB7
53-54	LAB8
55-56	n/a
57	x79
58-60	IAR
61-62	TA
63-64	TD

foT6 (page 2-200)

TYPE: 11 ID: B1	
Byte	Field
1-9	Header
10-11	TYPE-ID
12	LOST
13-14	Abend
15	F
16	n/a
17-18	LNVT
19-46	PSA
38	LCS
47	TA (byte 0)
48	TD (byte 1)
49-50	NW
51-86	IOB/LXB
87-150	CCB
151-164	AXB ACB Trace
165-181	AXB PSA Trace
182-197	SCB
198	SCBCSCF

foT3 (page 2-200)

TYPE: 11 ID: 1E 1F 95 96 99 9A 9B	
Byte	Field
1-9	Header
10-11	TYPE-ID
12	LOST
13-14	Abend
15-16	x7E
17-18	x76
19	CSPA
20	N/A
21-24	x74 LAR
25-26	CS STATUS3
27-28	x76U
29-30	BRR
31-32	xE
33	F
34	RHB
35-36	CLA1
37-38	CLA2
39-40	LAB3
41-42	CABR
43-44	FRDV
45-46	LAB4
47-48	LAB5
49-50	LAB6
51-52	LAB7
53-54	LAB8
55-56	n/a
57	x79
58-60	IAR
61-62	TA
63-64	TD

foT7 (page 2-200)

TYPE: 11 ID: 1C	
Byte	Field
1-9	Header
10-11	TYPE-ID
12	LOST
13-14	Abend
15	F
16	Int. Lvl1
17-18	LNVT
19-46	PSA
19-34	Parameter Area
35	Previous SCF
36	Previous LCS
37-38	Lvl1 Get Error Status
39-40	Lvl1 Get and Reject Status
41-44	Logging IAR
45-46	n/a
47	TA (byte 0)
48	TD (byte 1)
49-50	n/a

foT4 (page 2-200)

TYPE 11, ID A1	
Byte	Field
1-9	Header
10-11	TYPE-ID
12	LOST
13-14	Abend
15	F
16	n/a
17-18	IDR
19-46	PSA
38	LCS
47	TA (byte 0)
48	TD (byte 1)
49-50	NW
51-54	LNVT
55-90	IOB/LXB
91-154	CCB
155-168	AXB ACB Trace
169-185	AXB PSA Trace
186-201	SCB
202	SCBCSCF

BER Layout on Diskette (Part 2 of 3)

NCP-EP BER (Type 12)

foN1 (page 2-210)

TYPE: 12	
ID: 11 thru 19	
Byte	Field
1-9	Header
10-11	TYPE-ID
12	LOST
13-14	Abend
15-16	X7E
17-20	X74
21	X79, byte 1
22-24	IAR
25-26	I

foN2 (page 2-210)

TYPE: 12	
ID: 21	
Byte	Field
1-9	Header
10-11	TYPE-ID
12	LOST
13-14	Abend
15-16	X7F
17-20	IAR3
21-24	IAR4

CCU BER (Type 13)

foU1 (page 2-220)

TYPE: 13	
ID: 91 thru 95	
Byte	Field
1-9	Header
10-11	TYPE-ID
12	LOST
13-14	Abend
15-16	X7E
17-20	X74
21	X79, byte 1
22-24	IAR
25-26	X7D
27-28	CA Reg X'D'
29-30	CA Reg X'E'

foU2 (page 2-220)

TYPE: 13	
ID: C1 thru C4	
Byte	Field
1-9	Header
10-11	TYPE-ID
12	LOST
13-14	X'0000'
15-16	X77
17-18	X7F
19-26	RCB

foU3 (page 2-220)

TYPE: 13	
ID: 32, B1	
Byte	Field
1-9	Header
10-11	TYPE-ID
12	LOST
13-14	Abend
15-16	X77
17-18	X7F
19-20	X0
21-22	X1
23-24	X2
25-26	X3
27-28	X4
29-30	X5
31-32	X6
33-34	X7
35-36	XB
37-38	XC
39-40	XF
41-42	CA Reg XD
43-44	CA Reg XE

IOC BERS (Type 14)

foI1 (page 2-230)

TYPE: 14	
91 thru 95	
Byte	Field
1-9	Header
10-11	TYPE-ID
12	LOST
13-14	Abend
15-16	X7E
17-18	X76
19-20	X75
21-24	X74
25-26	n/a
27-28	X76U
29-32	n/a
33	F
34	RHB
35-36	CLA1
37-38	CLA2
39-40	LAB3
41-42	CABR
43-44	FRDV
45-46	LAB6
47-48	LAB5
49-50	LAB4
51-52	LAB7
53-54	LAB8

MOSS BERs (Type 01)

foM0 (page 2-240)

TYPE: 01, ID: 00	
Byte	Field
1-9	Header
10-11	TYPE-ID
12	CHECK
13	LL
14	MCPC
15	IOIR
16	PIRR
17	CM
18-20	DATA
21	MEF
22	TTA
23-24	I
25-28	PSW
29	CNT

foM1 (page 2-240)

TYPE: 01, ID: 01	
Byte	Field
1-9	Header
10-11	TYPE-ID
12	ERROR
13	AREG
14-16	X75
17-19	X76
20	STATUS
21-22	Abend

foM2 (page 2-240)

TYPE: 01, ID: 02	
Byte	Field
1-9	Header
10-11	TYPE-ID
12	ERROR
13	CMD
14-21	PCW
14-45	or MB

foM3 (page 2-240)

TYPE: 01, ID: 03	
Byte	Field
1-9	Header
10-11	TYPE-ID
12	ERROR
13	CMD (CAC)
14	REQ
15	F (CAC)
16	CNT (CAC)
17	n/a
18	ARC
19	BSTAT
20	SENSE
21-23	n/a
24	TTA
25-26	ADDR (CAC)

If ERROR: X'40'
(diskette drive)
add:

27	F (BCLE)
28	CMD (BCLE)
29	CNT (BCLE)
31-34	ADDR (BCLE)
35	CYL
36	HD
37-38	REC
39-46	FILE

foM4 (page 2-240)

TYPE: 01, ID: 04	
Byte	Field
1-9	Header
10-11	TYPE-ID
12	ERROR
13	CMD
14	BSTAT
15	ASTAT
16-17	CSTAT
18	MSTAT

foM5 (page 2-240)

TYPE: 01, ID: 05	
ERROR: 08 10 20	
40 80	
Byte	Field
1-9	Header
10-11	TYPE-ID
12	ERROR
13	ADDR
14-16	x76
17-18	STATUS

or
(see next column)

foM5 (page 2-240)

TYPE: 01, ID: 05	
ERROR: 00 04	
Byte	Field
1-9	Header
10-11	TYPE-ID
12	ERROR 00,04
13	ADDR

or

TYPE: 01, ID: 05	
ERROR: 01 02 05	
Byte	Field
1-9	Header
10-11	TYPE-ID
12	ERROR 01, 02,05
13	ADDR
14-15	CSCHK or TD or MBST

or

TYPE: 01, ID: 05	
ERROR: FF	
Byte	Field
1-9	Header
10-11	TYPE-ID
12	ERROR FF
13	ERR-EXT
14	ADDR
15-16	TD

foM6 (page 2-240)

TYPE: 01, ID: 06	
ERROR: 03 06	
Byte	Field
1-9	Header
10-11	TYPE-ID
12	ERROR 03 06
13	IPL-REQ
14	CREQ
15	STAT
16-17	IPL-CHECK
18-49	SCB
50-59	DISK
60-75	CS
76	F
77-79	x71
80-82	x72

foM7 (page 2-240)

TYPE: 01, ID: 06	
ERROR: 01 07	
Byte	Field
1-9	Header
10-11	TYPE-ID
12	ERROR 01 07

or

TYPE: 01, ID: 06	
ERROR: 02 04	
Byte	Field
1-9	Header
10-11	TYPE-ID
12	ERROR 02 04
13	LOST, ERR 2 or CSPA, ERR 04

foM8 (page 2-240)

TYPE: 01	
ID: 91 B3 C1 C2	
Byte	Field
1-9	Header
10-11	TYPE-ID
12	LOST
13-14	x'0000'
15-46	MB
31-32	Status

foM9 (page 2-240)

TYPE: 01, ID: 06	
ERROR: 08, EXT:05	
Byte	Field
1-9	Header
10-11	TYPE-ID
12	ERROR 08
13	05 = CCU hardcheck
14	IAR parity
15-17	IAR
18	LAR parity
19-21	LAR
22	SAR parity
23-25	SAR
26-28	X76
29-31	X7D
32-34	X7E
35-37	HKNG
38-40	HDCK
41	CCUI
42	STUI

foM10 (page 2-240)

TYPE: 01, ID: 06	
ERROR: 08, EXT:07	
Byte	Field
1-9	Header
10-11	TYPE-ID
12	ERROR 08
13	07=CP
14-15	Request IPL CP CHECK

foM11 (page 2-240)

TYPE: 01, ID: 06	
ERROR: 09	
Byte	Field
1-9	Header
10-11	TYPE-ID
12	ERROR 09
13-14	IPL-CHECK
15-17	x71
18-20	x72
21-23	WKRO=IAR
24-26	WKR1
27-29	WKR2
30-32	WKR3
33-35	WKR4
36-38	WKR5
39-41	WKR6
42-44	WKR7

foM12 (page 2-240)

TYPE: 01, ID: 06	
ERROR: 0A	
Byte	Field
1-9	Header
10-11	TYPE-ID
12	ERROR 0A
13-14	x0
15-16	x1
17-18	x2
19-20	x3
21-22	x4
23-24	x5
25-26	x6
27-28	x7
29-30	xB
31-32	xC
33-34	xD
35-36	xE
37-38	xF
39	CAn

BER Layout on Diskette (Part 3 of 3)

MOSS BERS (TYPE 01) (CONTINUED)

foM13 (page 2-240)

TYPE: 01 ID: 07 ERROR: 04 08 40 80	
Byte	Field
1-9	Header
10-11	TYPE-ID
12	ERROR
13-14	TRA ADDR
15-16	Get Cmd Compl.
17-18	Lvl 2 Error Status TIC1
19-20	Lvl 2 Error Status TIC2
21-22	Lvl 2 Error Status TIC3
23-24	Lvl 2 Error Status TIC4
25-26	MOSS ERROR STATUS
27-29	x76

TYPE: 01 ID: 07 ERROR: FE	
Byte	Field
1-9	Header
10-11	TYPE-ID
12	error FE
13-14	TRA input addr
15-16	TRA output addr
17	TIC number
18-19	Initial block number
20-21	Requested block number
22-23	Final block number
24	Stop CMD count

TYPE: 01 ID: 07 ERROR: 00 FF	
Byte	Field
1-9	Header
10-11	TYPE-ID
12	ERROR
13	ERROR EXT.
14	TRA number
15	TIC number

TRSS BERS (Type 15)

foR1 (page 2-231)

TYPE: 15 ID: 14 16 91 92 93	
Byte	Field
1-9	Header
10-11	TYPE-ID
12	LOST
13-14	Abend
15-16	x7E
17-18	x76
19-20	x75
21-22	n/a
23-24	ETA
25-26	TRM STATUS1
27-28	x76U
29-32	x3F
33	F
34	RHB
35-36	CLA1
37-38	CLA2
39-40	LAB3
41-42	CABR
43-44	FRDV
45-46	LAB4
47-48	LAB5
49-50	LAB6
51-52	LAB7
53-54	LAB8

foR2 (page 2-231)

TYPE: 15 ID: 18 97 98 9C	
Byte	Field
1-9	Header
10-11	TYPE-ID
12	LOST
13-14	Abend
15-16	x7E
17-18	x76
19-20	I
21-24	x74
25-26	TRM STATUS1
27-28	x76U
29-30	ETA
31-32	n/a
33	F
34	RHB
35-36	CLA1
37-38	CLA2
39-40	LAB3
41-42	CABR
43-44	FRDV
45-46	LAB4
47-48	LAB5
49-50	LAB6
51-52	LAB7
53-54	LAB8
55-56	n/u
57	x79
58-60	IAR
61-62	TA
63-64	TD

foR3 (page 2-231)

TYPE: 15 ID: 96 99 9A 9B	
Byte	Field
1-9	Header
10-11	TYPE-ID
12	LOST
13-14	Abend
15-16	x7E
17-18	x76
19	TRM Address
20-24	n/a
25-26	TRM STATUS1
27-28	x76U
29-30	ETA
31-32	n/a
33	F
34	RHB
35-36	CLA1
37-38	CLA2
39-40	LAB3
41-42	CABR
43-44	FRDV
45-46	LAB4
47-48	LAB5
49-50	LAB6
51-52	LAB7
53-54	LAB8
55-56	n/u
57-58	ETA

foR4 (page 2-231)

TYPE: 15 ID: A3... A8	
Byte	Field
1-9	Header
10-11	TYPE-ID
12	LOST
13-14	Abend
15	F
16	TIC number
17-18	TA data
19-20	TRM STATUS2

foR5 (page 2-231)

TYPE: 15 ID: AC	
Byte	Field
1-9	Header
10-11	TYPE-ID
12	LOST
13-14	Abend
15	F
16	TIC number
17-18	TA data
19-20	TRM STATUS2
21-28	Adpt check Status

foR6 (page 2-231)

TYPE: 15 ID: AF	
Byte	Field
1-9	Header
10-11	TYPE-ID
12	LOST
13-14	Abend
15	F
16	TIC number
17-18	TA data
19-20	TRM STATUS2
21-24	SSB Open Completion

foR7 (page 2-231)

TYPE: 15 ID: B3... B6	
Byte	Field
1-9	Header
10-11	TYPE-ID
12	LOST
13-14	Abend
15	F
16	TIC number
17-18	TA data
19-20	TRM IR/BR Register
21-22	TIC Control Register

foR8 (page 2-231)

TYPE: 15 ID: B2	
Byte	Field
1-9	Header
10-11	TYPE-ID
12	LOST
13-14	Abend
15	F
16	TIC number
17-18	TA data
19-20	TIC Init Interrupt Register
21-22	TIC Control Register

Machine Status Area (Part 1 of 5)

You are permanently informed of the 3725 status by the information displayed on the first three lines of the operator console screen: the machine status area (MSA).


The first two lines of the MSA show CCU and MOSS information. The third one shows:

- Selected scanner information (service personnel only), or
- CCU/Scanner IPL information, or
- Selected TRA information


In the three screens shown on the right, each letter is a key that refers to the explanation following the three figures.

The MSA is updated every 500ms.


MSA WITH SCANNER INFORMATION



MSA WITH TRA INFORMATION



MSA WITH CCU/SCANNER IPL INFORMATION



GENERAL INFORMATION

a	b	c	d	e	f				
g	h	i	j	k	l				
m		n	o	p	q				

Field a

Field 'a' displays the CCU mode:

PROCESS Normal processing
I-STEP Instruction step

Field b

Field 'b' displays the CCU check mode:

STOP-CCU-CHK The system will stop on a CCU check (default or after function RESET BYPASS CCU CHECK).
BYP-CCU-CHK You initiated function SET BYPASS CCU CHECK so the system will not stop on a CCU check.

Field c

Field 'c' shows whether MOSS is connected to the CCU control program:

MOSS-ONLINE MOSS is connected to the CCU control program.
MOSS-OFFLINE MOSS is not connected to the CCU control program.
MOSS-ALONE MOSS is operational while the CCU control program is not loaded or no longer operational.
SERVICE-MODE MOSS is in service mode (service personnel only).

The statuses of the MOSS after the different IMLs and IPLs are as follows:

After a:	MOSS Status	Hex Display Code
Initialization (general IPL)	MOSS-ONLINE	X'000'
MOSS IML	MOSS-OFFLINE if CP loaded	X'FEE'
	MOSS-ALONE if CP is not loaded	X'FEF'
CCU/Scanner IPL	MOSS-ONLINE	X'000'
STEP BY STEP IPL	MOSS-ONLINE	X'000'
BYPASS PHASE 1 IPL	MOSS-ONLINE	X'000'
BYPASS PHASE 3 IPL	MOSS-ONLINE	X'000'

Machine Status Area (Part 2 of 5)

a	b	c	d	e	f
g	h	i	j	k	l
m	n	o	p	q	

Field d

Field 'd' displays information on the CCU address compare function:

AC the Address Compare function is active.

If you selected MOSS INTERRUPT=Y and/or CCU STOP=Y when defining the address compare, the following are displayed:

AC HIT A single or double address compare is successful.
 AC HIT1 A two-single address compare is successful on the first address.
 AC HIT2 A two-single address compare is successful on the second address.

Field e

Field 'e' is updated each time an output X'71' instruction is executed, by the control program, for example, when using the CCU data exchange function or the control program procedures.

Output X'71' contents are buffered. If the buffers are overrun due to intensive outputting, some data may be lost; however, the last value outputted will be displayed.

X71:xxxxxx Contents of CCU X'71' output register
 X71:ERROR Error when accessing the register.
 Register contents cannot be displayed.

Field f

Field 'f' is displayed, along with field 'l', when the CCU status is STOP X'70', STOP PGM, STOP BT, STOP AC, or HARD-STOP (see field g)

LAR:xxxxxx OP:xxxx C:x (field f)
 IAR:xxxxxx ILVL:xxxx Z:x (field l)

LAR:xxxxxx Address of the last executed instruction
 OP:xxxx Last executed instruction
 C:x Value of the C-latch (0 or 1)

IAR:xxxxxx Address of the next instruction to be executed

ILVL:xxxx Active CCU interrupt levels
 Z:x Value of the Z-latch (0 or 1)

CCU INTERRUPTS DISABLED (field f)
 nothing displayed (field l)

No interrupts can be received from the CCU:

- During a MOSS IML from the control panel, just after power on
- While performing CCU IPL to avoid automatic CCU re-IPL in case of HARDCHECK (see field g)
- While mounting a new diskette (service personnel only)
- While performing some utility programs (service personnel only) to prevent interference with the utility program. All communications between the CCU and MOSS are delayed. For example, a BER generated by the control program is kept until the utility program ends and MOSS is back online.

CCU REGISTERS (in field f)
 NOT ACCESSIBLE (in field l)

Appropriate registers cannot be read, so it is impossible to display LAR, OP, C, IAR, ILVL, and Z information.

Field g

Field 'g' displays the CCU status:

RUN Instructions are being executed or data transferred.
 RESET The control program stopped since you initiated function RESET CCU; to restart the CCU, perform an IPL.
 HARDCHK The control program stopped on a hardcheck error. An automatic re-IPL is attempted. In certain cases, however, (for example if the hardcheck occurs during a general IPL) there is no re-IPL.
 HARDSTOP You selected the CCU check reset function to reset the CCU check condition. To restart, select the CCU Start function from the primary menu or press PF3:CCU START or PF3:ST if displayed on the screen.
 IPL-REQ A CCU IPL was requested and is in progress.
 STOP-X70 The control program stopped on an output X'70' instruction executed by the control program.
 STOP-PGM The control program stopped because you initiated function CCU STOP or function SET I-STEP.
 STOP-BT The control program stopped because the Branch Trace function that you initiated with CCU STOP is deactivated.
 STOP-AC The control program stopped because the address compare function that you initiated with CCU STOP (CCU ACTION=S) is successful.

Field h

Field 'h' shows whether the 3725 will stop on an IOC check.

BYP-IOC-CHK The system will not stop on an IOC check. (default or after a RESET IOC CHECK STOP).
 STOP-IOC-CHK You initiated the function SET IOC CHECK STOP to force the system stop on an IOC check.

Field i

Field 'i' displays the last MOSS check code (See Chapter R1 in MIM Part 2, Vol. A01).

LASTMCHK:xxx last MOSS check code

Field j

Field 'j' displays BT when the Branch Trace function is active.

Machine Status Area (Part 3 of 5)

a	b	c	d	e	f
g	h	i	j	k	l
m	n	o	p	q	

Field k

Field 'k' is updated each time an output X'72' instruction is executed by the control program, for example, when using the CCU data exchange function or the control program procedures.

Output X'72' contents are buffered. If the buffers are overrun due to intensive outputting, some data may be lost; however, the last value outputted will be displayed.

X72:xxxxxx Contents of CCU X'72' output register.
 X72:ERROR Error when accessing the register.
 Register contents cannot be displayed.

Field l

Field 'l' is displayed along with field f. See field 'f' description.

SCANNER INFORMATION

Field m

Field 'm' displays information on the selected scanner:

NO SCANNER SELECTED

You selected a scanner function before selecting a scanner

SCANNER XX yyyyyyyyyyyy

where xx is the number of the selected scanner (1 to 16), and yyyyyyyyyyyy is any of the following:

- CONNECTED The scanner is operational and under control of the CCU control program.
- INITIALIZED The control code is loaded and the front-end adapter is operational.
- INOPERATIVE The scanner is inoperative, or the CCU is not in RUN status.
- DISCTD-STOP Disconnected-stop: The control code is no longer under control of the CCU control program, either after command STOP or after a

- DISCTD-GO scanner address compare hit. Disconnected-go: You entered command GO while in status DISCTD/STOP. The scanner remains disconnected but the control code execution continues.
- RESET You entered command RESET, and you may initiate an IML or a DUMP.
- UNKNOWN-MODE The scanner is selected but it is impossible to identify its status.

Field n

Field 'n' displays the scanner option:

- IML A scanner IML is being started
- DUMP A dump is in progress

Field o

Field 'o' displays the function for which you requested a delay in the execution (scanner display/alter functions):

- DELAYED-ALTER
- or
- DELAYED-DISPLAY

Field p

Field 'p' displays the scanner address compare parameters that you specified:

AC xxxx yyyy zzzzzzz

where:

- xxxx is the address
- yyyy is the type of access:
 - F for I-fetch or data-fetch
 - S for data store
 - R for cycle steal read
 - W for cycle steal write

zzzzzzz is the action:

- DISPLAY
- ALTER
- STOP
- OP-MSG (no action)

Field q

Field 'q' shows that the scanner address compare function is:

- HIT-FS Successful on I-fetch, load, or store
- HIT-RW Successful on read or write
- ERROR Successful but an error is encountered while performing the action you specified

Machine Status Area (Part 4 of 5)

CCU/SCANNER IPL INFORMATION

CCU/scanner IPL information instead of scanner information is displayed on the third line.

A short time after successful completion of the IPL, the third line of the MSA is cleared.

a	b	c	d	e	f	
g	h	i	j	k	l	
r	s	t	u	v	w	x

Field r

IPL ENTERED Shows that a CCU IPL is started.

Field s

PHASE 1 Indicates the start of phase 1 (CCU test and initialization). This field is blank when phase 1 is bypassed.

Field t

PHASE 2 Shows the start of phase 2 (load from the diskette and start the control program loader/dump). This field is always present.

Field u

PHASE 3 Shows the start of phase 3 (load and initialize the scanners). This field is blank when phase 3 is bypassed.

Field v

PHASE 4 Shows the start of phase 4 (load from the host and initialize the control program). This field is always present.

Field w

CA IPL DETECTED ON CA x
The control program loading/dumping is started on a channel-attached 3725. x is the channel adapter number.

CONTROL PROGRAM LOADED
The control program is loaded.

DUMP IN PROGRESS ON CA x
A control program dump is being taken on a channel-attached 3725. The progression of the dump is indicated in MSA field k that displays control program storage addresses. x is the channel adapter number.

DUMP IN PROGRESS ON L xxx
A control program dump is being taken on a link-attached 3725. The progression of the dump is indicated in MSA field k that displays control program storage addresses. xxx is the channel adapter number.

ENABLED PORTS CA xxxxxx L xxxxxxxx
Indicates which channel adapters or link IPL ports are enabled. x can be either Y or N.

In the CA field, Ys indicate which channel adapters are enabled, and Ns which channel adapters are not enabled.

In the L field, Ys indicate which link IPL ports are enabled. N is used for the link IPL ports not enabled.

IPL CANCELED The 3725 initialization is canceled by:

- The operator (immediate function Terminate).
- 3727 power-off when the IPL was requested from the console.
- Switching from one console to the other (primary/alternate) when the IPL was requested from the initial console.
- The operator console switching from normal mode to test mode.
- MOSS automatic re-IML during a CCU/scanner step-by-step IPL, or
- Two MOSS automatic re-IMLs during a CCU/scanner IPL.

IPL CHECK xxx

The IPL ends abnormally. The check code (xxx) is also displayed on the hex display of the control panel.

IPL CHECK F1B CLDP ABEND xxxx
The IPL ends abnormally. xxxx is the hexadecimal control program loader/dump abend code.

IPL COMPLETE The IPL is successfully completed.

IPL COMPLETE + ERRORS
The IPL is complete although an error has been encountered. If the error comes from a scanner, Alarm All is displayed.

For any other intermittent errors (for example, diskette errors) no alarm is displayed. The 3725 should run normally.

LINK IPL DETECTED ON L xxx
The control program loading/dumping is started on a link-attached 3725.

LINK IN PROGRESS ON CA x
The control program is being loaded on a channel-attached 3725. The progression of the load is indicated in MSA field k where CCU storage addresses are displayed. x is the channel adapter number.

LOAD IN PROGRESS ON L xxx
The control program is being loaded on a link-attached 3725. The progression of the load is indicated in MSA field k where CCU storage addresses are displayed. xxx is the decimal communication line address.

RPO DETECTED ON L xxx
The Remote Power Off (RPO) command is detected on the communication line xxx. xxx is the decimal communication line address.

SCANNER(S) NOT IMLD: xxxx
Indicates that one or more scanners are not IMLed. xxxx consists of four hexadecimal digits (16 bits). Each bit corresponds to a scanner (CS) number. This bit on (1) corresponds to a scanner not IMLed.

Field x

IPL STOP Indicates that the IPL stopped at the beginning of a phase or on operator's request (PF1:STOP).

Machine Status Area (Part 5 of 5)

TRA/TIC INFORMATION

a	b	c	d	e	f
g	h	i	j	k	l
m*	n*	o*	p*	q*	

Field m*

TRA Number

- TRA xx: where xx is 6-16. Indicates which TRA has been selected. The same number as for scanners is used.

Field n*

TRA Mode

This field indicates the mode of the selected TRA. If none is selected, it is left blank. This field is updated after each TRA select and after a connect/disconnect operation. See "TRSS Modes" on page 2-387 for a description of the modes.

- CONNECT
- DISCONNECT
- UNKNOWN

If field f indicates 'CCU INTERRUPTS DISABLED' then the TRA Mode has no meaning.

Field o*

TIC Selected

- TIC x: where x is 1-4. Identifies the TIC selected. This field is updated after each TIC select.

Field p*

TIC Mode

This field displays the current mode of the selected TIC. If no TIC is selected or if NTRI is OFFLINE, it is blank. This field is updated after each TIC Select. See "TRSS Modes" on page 2-387 for a description of the modes.

- IDLE
- RESET
- INITIALIZED
- OPEN
- CLOSED
- FROZEN
- DISABLED

Field q*

NRTI OFFLINE: Indicates that:

- At the IPL of NCP, NTRI was not available and did not pass necessary TRSS information to MOSS.

OR

- An error has occurred when trying to access NTRI control blocks needed by TRSS services.

Several functions which depend upon NTRI will not be available. This field is updated after each function selection from the secondary menu.

Reset CCU/LSSD (Part 1 of 2)

All CCU functions except reset CCU/LSSD are described in the 3725 Problem Determination and Extended Services, (Vol. A06).

Use the reset CCU/LSSD function to reset:

- The entire CCU (LSSD, IOC, local store registers, storage protect/address exception keys, and 3725 storage), or
- The LSSD only

the channel adapter registers are not reset.

Warning: This function destroys the current state of the CCU control program.

SELECTION

Press the CCU FNCTN key to display the CCU function menu.

Type 11 followed by SEND to select RESET CCU/LSSD.

WARNING: THIS FUNCTION DESTROYS THE CCU CONTROL PROGRAM

- ENTER R OR L ==>

R = TO RESET ALL THE CCU
L = TO RESET THE LSSD ONLY

< Function message line >

FUNCTION MESSAGE LINE

The Following messages may be displayed in the function message line:

INVALID INPUT:

Neither 'R' nor 'L' has been selected.

ENTER 'R' or 'L' according to desired function, or press SELECT AREA key either to select another CCU function or leave CCU functions.

FUNCTION IN PROGRESS

RESET CCU/LSSD function is running.
The function cannot be stopped or canceled during its processing.

FUNCTION COMPLETED

RESET CCU/LSSD function is completed.

CCU/MOSS PARITY ERROR: RESET CCU FUNCTION CANCELED

A CCU/MOSS parity error occurred during the function processing.

The function is canceled. You should re-IML the MOSS before retrying the function.

DISKETTE ERROR: RESET CCU FUNCTION CANCELED

Message sent when any diskette error occurred during the function processing.

The function is canceled. You should re-IML the MOSS before retrying the function.

Reset CCU/LSSD (Part 2 of 2)

MODE OF OPERATION

The different operations performed by reset CCU/LSSD are listed in the following table.

Reset		Operation Description
CCU	LSSD	
X	X	1. Force channel monitoring task to stop if MOSS IML has been performed with the controller diskette.
X	X	2. Reset panel adapter (adapter down, mailbox in indicator, panel timer, I/O request block queues).
X	X	3. Reset MOSS inoperative bit in the MIOC status register 1, disable CCU and scanner interrupts, reset instruction step mode.
X	X	4. Set power on remember bit, AIO and program stop in mode control register B.
X	X	5. Reset LSSD : a. Read CCU LSSD latches and write them on diskette in CHGCDS file (1st sector). b. Read LSSD initialization out of diskette from CHGCDS file (2nd sector) and write them to CCU. c. Read CCU LSSD latches written in operation 'b' and compare them with LSSD initialization for write error detection.
X	X	6. Reset clock step control register.
X	X	7. Reset IDC.
X		8. Initialize 128 local store registers with correct parity, reset CCU hardcheck, enable CCU interrupts, and disable ECC mechanism (local store 74).
X		9. Read In X'70' to get CCU storage size installed.
X		10. Set SP/AE keys: storage keys, read keys, user keys, cycle steal keys, address exception keys for installed storage and address exception keys for non-installed storage.

(Continued)

Reset		Operation Description
CCU	LSSD	
X		11. Enable storage protection and address exception mechanism.
X		12. Set on bypass CCU check.
X		13. Issue storage test pattern to align parity and ECC bits (ECC mechanism being disabled at the operation 8), write zeroes in the whole storage, start a timer for 1.3 seconds, wait for high level interrupt request or timer completion.
X		14. Stop ROS task by resetting CCU busy bit in CCU to MOSS B register, test if address exception is on in CCU to MOSS A register, and reset it.
X		15. Reset CCU hardcheck and MOSS disable bit, and enable CCU interrupts.
X		16. Set off bypass CCU check and re-init CCU LSSD strings to disable storage protection and address exception mechanism.
X	X	17. Reset CCU hardcheck and MOSS disable bits if set on during LSSD initialization, and enable CCU interrupts and scanner interrupts.
X	X	18. Enable ECC mechanism.
X	X	19. Signal to machine status display task that CCU is now initialized, which in turn displays on status line 1 'PROCESS', 'CCU/MOSS ENABLED', and on status line 2 'RESET'.
X	X	20. Reset picture image registers.

IPL CCU/TSS (Part 1 of 2)

Use the IPL functions to IML one scanner or to IPL the CCU and scanners of the 3725. Options are available to the CE only for the 3725 IPL: normal IPL, step-by-step, or bypass phase 1.

To perform any of the IPL functions:

- The MOSS must be running (MOSS-alone status).
- The controller diskette must be in the disk drive.

The IPL CCU/TSS messages are listed starting on page 2-490.

IPL MENU

Selection

1. Press SELN AREA to position the cursor.
2. Press M followed by SEND to display the maintenance primary menu.
3. Press I followed by SEND to display the IPL CCU/TSS secondary menu.

The screen is displayed as follows:

```

(Machine Status Area)
I: IPL CCU/TSS      G: GCF/IPL Ports  S: TSS FNCTN   SP: CCU STOP   Q: DATE/TIME
L: LINE FNCTN      C: CNTRL PGM PROC U: UTILITY PGM ST: CCU START T: TERMINATE
E: ERROR LOG       N: CUSTOMER MENU  R: TRSS FNCTN  RS: CCU RESET

1 ONE SCANNER IML
2 3725 IPL
3 LINK TEST REQ
4 LINK TEST RESP

===>
```

Available Functions

The link test requester (REQ) and link test responder (RESP) functions are documented in 3725 Problem Determination and Extended Services, (Vol. A06).

The only functions that can be performed while IPLing the CCU are the CCU functions.

Notes:

1. No CCU function can be selected before IPL phase 2 (hex display = FF2).

2. When an IPL CCU/TSS function is already selected the Terminate (T) function (see 3725 Problem Determination and Extended Services, Vol. A06, for details) must be used before selecting another IPL function.

3. The IPL/IML is canceled if one of the following occurs before the IPL/IML is complete.

- The immediate function Terminate is selected.
- The operator console is switched from normal mode to test mode.
- The other operator console is selected.
- The operator console is powered off.

ONE SCANNER IML

Use this function to IML only one scanner.

Warning: Before IMLing a scanner, stop all the lines on that scanner, using the NCP facilities.

Selection

1. Press SELN AREA to position the cursor.
2. Press I followed by SEND to display the IPL CCU/TSS secondary menu.
3. Press 1 followed by SEND to select One Scanner IML.

For the 3725/3726, you are requested to enter the scanner number preceded by S (S1 to S16) or the line address (0 to 255).

For the 3725 Model 2, you are requested to enter the scanner number preceded by S (S1 to S6) or the line address (0 to 95).

IML Termination

When the IML is complete, the following message is displayed:

IML FOR SCANNER XX COMPLETED - SCANNER IS CONNECTED

To terminate the One Scanner IML function when the IML COMPLETE message is displayed in the MSA use the Terminate function.

IPL CCU/TSS (Part 2 of 2)

3725 IPL

Use this function to IPL the CCU and IML the scanners.

Selection

1. Press SELN AREA to position the cursor.
2. Press I followed by SEND to display the IPL CCU/TSS secondary menu.
3. Press 2 followed by SEND to select 3725 IPL.

You are then requested to select one IPL option:

- 1 = NORMAL
- 2 = STEP-BY-STEP
- 3 = BYPASS PHASE 1

These options are only available in the maintenance menu; they are not available in the customer menu.

IPL Phases

During 3725 IPL, with any options selected, the IPL phases are indicated on:

- The third line of the MSA (fields r to x)
- The hex display on the control panel

(See the 3725 Problem Determination and Extended Services, Vol. A06, for details.)

To stop the IPL during a phase, press PF1. To resume, press PF2.

To terminate the IPL function, when the IPL COMPLETE message is displayed in the MSA, use the Terminate function.

Normal IPL (Option 1)

Use this option to normally IPL the CCU and IML the scanners. When you select 1 in the 3725 IPL menu, the IPL starts immediately.

The following message is displayed while the IPL is in progress:

CCU AND SCANNER IPL

Step-by-Step IPL (Option 2)

Use this option to IPL the 3725 in step-by-step mode. When you select 2 in the 3725 IPL menu, the IPL stops automatically at the start of each phase, so that you may take appropriate action, such as executing a CCU function. To continue, press PF2.

The following message is displayed while the IPL is in progress:

STEP-BY-STEP IPL

Bypass Phase 1 (Option 3)

Use this option to IPL to CCU without CCU test and initialization, and IML the scanners. When you select 3 in the 3725 IPL menu, the IPL bypasses phase 1 and stops automatically at the beginning of the following phases.

The following message is displayed while the IPL is in progress:

BYPASS PHASE 1 IPL

TSS Functions

TSS functions help you debug the 3725 scanners.

They can be selected only from controller diskette.

The TSS functions that can be selected depend on the diskette installed.

SELECTION FROM THE CONTROLLER DISKETTE

1. Press SELN AREA to position the cursor.
2. Press M followed by SEND to display the MAINTENANCE primary menu.
3. Press S followed by SEND to display the TSS FNCTN (functions).

All TSS functions are then displayed in the secondary menu:

MENU	See Page
1 SELECT/RELEASE	2-370
2 DUMP/IML	2-371
3 MODE CONTROL	2-372
4 DPLY/ALT STORE	2-373
5 DPLY/ALT BLOCKS	2-375
6 DPLY/ALT LSR	2-376
7 DPLY/ALT XREG	2-376
8 ADDRESS COMPARE	2-377
9 CHK-POINT TRACE	2-378

SELECTION FROM THE SERVICE DISKETTE

1. Press SELN AREA to position to cursor.
2. Press V followed by SEND to select the scanner dump function.

The only TSS functions that you can use when the service diskette is mounted are:

- Select/release
- Dump

Only one dump file (CHJDMP) is defined on the service diskette. This file is used to dump MOSS or a scanner.

Warning: TSS functions may disrupt communications on the lines attached to the selected scanner.

The following table identifies the potential risks:

Secondary Selection	Disruptive	Functions
1	No	Select/Release
2	Always	Dump/iml
3	Always	Stop reset
4	May be	Alter control store
5	May be	Alter control blocks
6	May be	Alter LSR
7	May be	Alter XREG
8	Always	Address compare stop
9	May be	Chk-point trace

MESSAGES

Refer to page 2-480 onwards for the message explanations and for the action to be taken for each message displayed when TSS functions are run.

SELECT/RELEASE SCANNER

Selection

Select TSS function menu then enter 1 followed by SEND

Before you call any TSS function (except for checkpoint trace where the selection is made automatically), you must select a scanner. If you try to call a TSS function before selecting a scanner, the message SELECT A SCANNER is displayed.

```

- TO SELECT A SCANNER, ENTER:

  THE SCANNER NUMBER PRECEDED BY S (S1 TO S16)
                                     (S1 TO S6) *
OR
  THE LINE ADDRESS (0 TO 255)
                                     (0 TO 95) *
                                     ==> S1
- TO RELEASE SELECTED SCANNER, ENTER REL
    
```

* For the 3725 Model 2

The correspondence between line address and scanner number is given under "Scanner Board Information" starting on page 4-120.

Select a Scanner

To select a scanner you may enter either its number or the address of one of its lines.

Note: Scanners number 2 and 4 are not used.

Release a Scanner

To release the scanner previously selected, enter REL.

Dump/IML Scanner

Warning: IML and dump functions are always disruptive to the selected scanner.

Before doing a CSP dump, it is necessary to disconnect the scanner, (as explained on page 2-372).

SELECTION:

Select a scanner (as explained on page 2-370), then enter 2 followed by SEND.

```
- ENTER D FOR DUMP OR I FOR IML      ==>
```

DUMP A SCANNER

Note: Do not change the diskette once a dump has been requested, and until this dump is completed.

To take a scanner dump, enter D followed by SEND.

The following screen is then displayed:

```
                SCANNER DUMP
- ENTER DUMP LIMITS:
  LOWER LIMIT ADDRESS (HALFWORDS) ==> 8000
  UPPER LIMIT ADDRESS (HALFWORDS) ==> FFFF
A      HEX ROS LIMITS: 000 - FFF (4K)
A      HEX RAM LIMITS: 8000 - FFFF (32K)
```

A gives the dump limit ranges

Once you have entered the dump limits and pressed SEND, the dump is immediately taken and filed in the CHGDMP (controller diskette), and the following message is displayed:

```
| DUMP FILED IN CHGDMP. TO PRINT DUMP, TRANSFER IT TO HOST
```

Refer to next page for dump transfer to the host.

| If the CHGDMP dump file is already occupied with a previous dump, the following frame is displayed:

```
- TO CLEAR DUMP FILE, ENTER C, OTHERWISE PRESS SEND ==>
```

```
| A CHGDMP MOSS/SCANNER DUMP FILE IS NOT EMPTY
```

You may either erase the previous dump or keep it.

- If you clear the dump file, the new dump is immediately taken.
- If you keep the dump, you may either display it at the operator console, transfer it to the host in order to print it, or transfer it to a support function, using an MD.

- To display the dump, use the DUMP/DPLY/DEL utility program:

```
SELN AREA T SEND (to cancel the DUMP function)
```

```
SELN AREA U SEND 1 SEND (to select the utility program)
```

Once you have displayed the dump, you may erase it using the same utility program, or transfer it to the host.

- To transfer the dump to the host, refer to page 2-450.
- To transfer the dump using an MD, refer to page 2-451.

IML A SCANNER

To IML the selected scanner enter I followed by SEND.

You are informed that the IML is complete by the message:

```
IML FOR SCANNER XX COMPLETE - SCANNER CAN BE CONNECTED
```

If an error prevents a scanner from being re-IMLed, the following message is displayed:

```
SCANNER CHECKOUT FAILED: RC=xxxx
```

This return code (RC) is found in the STAT field of the BER type 01, ID05, that has been created. See page 2-310 for further information.

Mode Control (Scanner)

Warning: Some mode control commands are disruptive to the selected scanner.

SELECTION

Select a scanner (as explained on page 2-370), then enter 3 followed by SEND.

Use this function to modify the mode of the scanner.

```
-SELECT SCANNER CONTROL COMMAND (SP, ST, CT, DS, RT)==>

SP = STOP
ST = START
CT = CONNECT
DS = DISCONNECT
RT = RESET
```

The following table lists the scanner commands that you may use to modify the scanner mode. It also gives the new mode resulting from the command, and the indications that appear in the machine status area of the screen. DUMP and IML commands can be used by selecting dump/IML on the TSS function menu. The START, STOP, CONNECT, and RESET commands can be used by selecting mode control on the TSS function menu.

MOSS must be in ONLINE mode:

- to control a scanner fully,
- to IML a scanner

With MOSS in OFFLINE mode, only START, STOP, RESET, and DUMP, commands can be executed.

With MOSS in ALONE mode, only the RESET, DUMP, and IML commands can be executed.

Current Mode	Possible Scanner Commands	Resulting Mode	MSA Field m
Connected	STOP DISCONNECT RESET DUMP IML	Disconnected/stop Disconnected/stop Reset Reset Initialized	DISCTD/STOP DISCTD/STOP RESET RESET INITIALIZED
Disconnected/go	STOP DISCONNECT RESET DUMP IML	Disconnected/stop Disconnected/stop Reset Reset Initialized	DISCTD/STOP DISCTD/STOP RESET RESET INITIALIZED
Disconnected/stop	START RESET DUMP IML	Disconnected/go Reset Reset Initialized	DISCTD/GO RESET RESET INITIALIZED
Reset (or unknown mode)	RESET DUMP IML	Reset Reset Initialized	RESET RESET INITIALIZED
Initialized	STOP DISCONNECT CONNECT RESET IML DUMP	Disconnected/stop Disconnected/stop Connected Reset Initialized Reset	DISCTD/STOP DISCTD/STOP CONNECTED RESET INITIALIZED RESET
Inoperative	RESET DUMP IML	Reset Reset Initialized	RESET RESET INITIALIZED

CONNECTED

The scanner is connected when it runs under the control of the control program. The errors on CCU I/O instructions are reported to the control program, and the errors on MOSS I/O instructions are reported to the MOSS.

DISCONNECTED

The scanner is disconnected when it does not run under the control of the control program but under the control of the MOSS microcode. Only the MOSS I/O instructions are executed. Any instructions from the CCU are rejected (IOC timeout), or not answered. **Warning:** DISCONNECT, STOP, RESET, IML, and DUMP are always disruptive.

DPLY/ALT Store (Scanner)

Warning: Any Alter may be disruptive

SELECTION:

Select a scanner (as explained page 2-370), then enter 4 followed by SEND

```
A - ENTER HALFWORD STORAGE ADDRESS ==> 8000
   ROS: 000 TO FFF - RAM: 8000 TO FFFF
   - ENTER NUMBER OF HALFWORDS TO DISPLAY (UP TO 32)==> 32

B - ENTER I FOR IMMEDIATE EXECUTION, D FOR DELAYED ==> I

C TO ALTER DATA, SPECIFY AN IMMEDIATE DISPLAY
```

- A This gives the limits of the storage you can display.
- B If you enter D, the execution of the display is delayed. See "Address Compare (Scanner)", page 2-377.
- C This reminds you that, if you want to alter data, you must first perform an immediate display of the data to be altered.

DISPLAY

Data is displayed as follows:

```
-ENTER HALFWORD STORAGE ADDRESS ==> A700
   ROS: 000 TO FFF - RAM: 8000 TO FFFF
   -ENTER NUMBER OF HALFWORDS TO DISPLAY (UP TO 32)==> 32

-ENTER I FOR IMMEDIATE EXECUTION, D FOR DELAYED ==> I

A A700 2BF8 33FE 5072 67FD 5272 671D 50C2 686A
  A708 8A64 CB25 8A30 4A20 510E 9638 F76F 8C60
  A710 4B0B 33E1 51C6 E870 4318 31EE 219E 0700
  A718 31EE 0700 B10F 4820 67C9 D17F 4A82 CB05

PF1:ALTER PF4:BACKWARD PF5:FORWARD PF2:REFRESH
```

The cursor is positioned so that you can select another address.

- A The first four characters of each displayed line give the storage addresses.

ALTER

To alter data, press PF1. The following frame is displayed:

```
- ENTER HALFWORD STORAGE ADDRESS ==>A700
   ROS: 000 TO FFF - RAM: 8000 TO FFFF
   - ENTER NUMBER OF HALFWORDS TO DISPLAY (UP TO 32) ==>32

A - ENTER I FOR IMMEDIATE EXECUTION, D FOR DELAYED ==>I
  A700 2BF8 33FE 5072 67FD 5272 671D 50C2 686A
  A708 8A64 CB25 8A30 4A20 510E 9638 F76F 8C60
  A710 4B0B 33E1 51C6 E870 4318 31EE 219E 0700
  A718 31EE 0700 B10F 4820 67C9 D17F 4A82 CB05
  PF3:IGNORE ALTER
  B TO DELAY ALTER, CHANGE I TO D. ENTER NEW DATA, PRESS SEND
```

A if you enter D, the execution of the alter is delayed. See "Address Compare (Scanner)", page 2-377.

- B This reminds you that you can delay the execution of the alter function (See function "Address Compare (Scanner)").

The cursor is automatically positioned below the first character of the displayed data. If you wish to delay the alter, replace I by D on line A, then press --> to move the cursor back to the data you want to alter. When you have altered all desired characters, press SEND. All displayed data, altered or not, is transmitted to the scanner.

PF KEYS

PF1:ALTER - See "Alter" above.

PF2:REFRESH - Redisplays data every 500ms. This allows you to view data in its most updated state. To stop the refresh, press ATTN.

PF3:IGNORE ALTER - Cancels alter mode. The modifications you have already entered on the screen are ignored.

PF4:BACKWARD - Displays preceding data. The amount of data that will be displayed has already been specified when defining the Display function.

PF5:FORWARD - Displays next data. The amount of data that will be displayed has already been specified when defining the Display function.

DPLY/ALT Blocks (Scanner)

SELECTION (3725/3726)

Select a scanner (as explained page 2-370), then enter 5 followed by SEND.

```
A - ENTER HEX LINE INTERFACE ADDRESS (0 TO 3F) ==>
B - ENTER HALFWORD TO DISPLAY FIRST ==> 0
C - ENTER NBR OF HALFWORDS TO DISPLAY (OPTIONAL) ==>
D - ENTER BLOCK IDENTIFICATION (1 TO 10) ==>
    1=ICB 3=LIB 5=RAMA 7=RAMC 9=LIC
    2=PSA 4=LCB 6=RAMB 8=ICC 10=FPS
E - ENTER I FOR IMMEDIATE EXECUTION, D FOR DELAYED ==> I
```

F TO ALTER DATA, SPECIFY AN IMMEDIATE DISPLAY.

A Specify a hexadecimal interface address, between 0 and 1F for scanners installed on LABs type B, and between 0 and 3F for scanners installed on LAB type A and CLAB.

B Specify the halfword from which the block will be displayed; if you enter no operand, the block will be displayed from its first halfword.

C Specify the number of halfwords that you want to display, starting from the halfword specified on line B. The message INVALID INPUT is displayed when the input is incorrect (for example, 0 to specify the number of halfwords to display).

The size of each block is:

```
ICB = 16   RAMB = 4
PSA = 16   RAMC = 4
LIB = 32   ICC = 1
LCB = 16   LIC = 2
RAMA = 4   FPS = 16
```

For ICC and LIC, you may ignore this request.

D Specify the block that you want to display:

```
ICB: interface control block
PSA: parameter/status area (copy of CCU PSA for this
line)
LIB: line interface buffer
LCB: line control block
RAMA: random access memory A
RAMB: random access memory B
RAMC: random access memory C
ICC: internal clock circuit
LIC: line interface card
FPS: FES parameter/status
```

Refer to Chapter 13 for a detailed description of these blocks.

E If you enter D, the execution of the display is delayed. See "Address Compare (Scanner)", page 2-377.

F This message reminds you that, if you want to alter data, you must first perform an immediate display of the data to be altered.

The display/alter block function, and the descriptions of the PF keys available, are similar to those of the display/alter storage function. However, the first four characters of each displayed line give:

- The address of the ICB, PSA, LIB, LCB, or FPS block, or
- The name of the RAMA, RAMB, RAMC, ICC, or LIC block

SELECTION (3725 MODEL 2)

Select a scanner (as explained page 2-370), then enter 5 followed by SEND.

```
A - ENTER HEX LINE INTERFACE ADDRESS (0 TO 17) ==>
B - ENTER HALFWORD TO DISPLAY FIRST ==> 0
C - ENTER NBR OF HALFWORDS TO DISPLAY (OPTIONAL) ==>
D - ENTER BLOCK IDENTIFICATION (1 TO 10) ==>
    1=ICB 3=LIB 5=RAMA 7=RAMC 9=LIC
    2=PSA 4=LCB 6=RAMB 8=ICC 10=FPS
E - ENTER I FOR IMMEDIATE EXECUTION, D FOR DELAYED ==> I
```

F TO ALTER DATA, SPECIFY AN IMMEDIATE DISPLAY.

A Specify a hexadecimal interface address, between 0 and 17 for scanners installed on C2LB board.

B, C, D, E, and F same as for 3725/3726.

DPLY/ALT LSR and XREG (Scanner)

DPLY/ALT LSR

Select a scanner (as explained page 2-370), then enter 6 followed by SEND.

```
A - ENTER HEXADECIMAL PAGE NUMBER ==>
B - ENTER ADDRESS OF LSR TO DISPLAY (0 TO 7) ==>
  (FOR ALL LSRs OF THE PAGE, ENTER NOTHING)
C - ENTER I FOR IMMEDIATE EXECUTION, D FOR DELAYED ==> I
D LSR  0 1  2 3  4 5  6 7  8 9  A B  C D  E F
E DATA 1914 9914 0000 0000 0000 0000 C6EB 07AB
F TO ALTER DATA, SPECIFY AN IMMEDIATE DISPLAY
```

XXXX = Contents of a register pair (hexadecimal)

- A Enter 'X' (when X = 0 through F) to select one of the 16 LSR pages (one LSR page = 8 one-byte registers).
- B Enter the address of the register to be displayed, or press SEND.
 - If a register address is entered, a single even/odd register pair is displayed. The least significant bit of the register address is ignored.
 - If SEND is pressed, and the page number entered in step A was even, then all 16 registers of the even/odd pages are displayed, numbered 0 through 7.
 - If SEND is pressed, and the page number entered in step A was odd, only the eight registers of the odd page are displayed, numbered 0 through 7.
- C If you enter D, the execution of the display is delayed. See function "Address Compare (Scanner)", page 2-377.
- D Line D gives the LSR numbers.
- E Line E gives the LSR contents.
- F This message reminds you that, if you want to alter data, you must first perform an immediate display of the data to be altered.

The display/alter of LSR function, and the descriptions of the PF keys available, are similar to those of the display/alter storage function.

DPLY/ALT XREG

Select a scanner (as explained page 2-370), then enter 7 followed by SEND.

```
A - ENTER HEX ADDRESS OF XREG TO DISPLAY FIRST ==>
B - ENTER NUMBER OF XREGS TO DISPLAY ==>
C - ENTER I FOR IMMEDIATE EXECUTION, D FOR DELAYED ==> I
XREG 00 01 02 03 04 05 07 08
DATA xx xx xx xx xx xx ** xx xx ** ** ** ** ** ** ** ** ** ** **
XREG 10 12 13 14 15 16 17 19 1A 1B 1C 1D 1E 1F
      xx ** xx xx xx xx xx ** xx xx xx xx xx xx xx
D TO ALTER DATA, SPECIFY AN IMMEDIATE DISPLAY
```

- A Specify the hexadecimal address of the external register you want to display first. This parameter is mandatory.
- B Specify the number of external registers that you want to display. If SEND is pressed, all 32 registers are displayed.
- C If you enter D, the execution of the display is delayed. See function "Address Compare (Scanner)", page 2-377.
- D This message reminds you that, if you want to alter data, you must first perform an immediate display of the data to be altered.

The display/alter external registers function, and the descriptions of the PF keys available are similar to those of the display/alter storage function.

Notes:

1. Independent of the register specified or the number of registers displayed, the display always starts with an even register and ends with an odd register.
2. A pair of asterisks under a register position indicates that the register does not exist.

Address Compare (Scanner)

You execute a scanner address compare to force the scanner to perform an action when a storage address detected during a specific access operation matches the contents of a register.

You must specify the address, the access operation, and the scanner action.

Warning: The address compare function with action STOP (line D) is always disruptive.

SELECTION

Select a scanner (as explained page 2-370), then enter 8 followed by SEND.

```
A - ENTER A TO ACTIVATE AC OR D TO DEACTIVATE ==> A
B - ENTER HALFWORD STORAGE ADDRESS (8000 TO FFFF)==> 8000
C - SELECT 1 TO 4 STORAGE ACCESSES (F, S, R, W) ==> RW
  F = I-FETCH OR DATA LOAD   S = DATA STORE
  R = CYCLE STEAL READ        W = CYCLE STEAL WRITE
D - SELECT ONE SCANNER ACTION (1, 2, 3, 4, 5) ==>
  1 = NO ACTION               2 = START DELAYED DISPLAY
  3 = START DELAYED ALTER     4 = STOP SCANNER
  5 = STOP SCANNER BUT LEAVE AC ACTIVE
```

A Activate or deactivate the address compare. Refer to "Deactivating the Scanner Address Compare" on the same page.

B Specify an address within the range indicated.

C Specify any combination of the following storage access operations. When the address specified on line B is detected during any one of these operations, the address compare is successful.

F: Address detected during I-fetch or load
S: Address detected during store
R: Address detected during cycle steal read
W: Address detected during cycle steal write

The scanner action you specify on line C is executed immediately after the execution of the storage access operation (F, S, R, W).

D You can specify only one scanner action:

1. NO ACTION: You just want to be informed of the completion of the address compare in field q of the MSA.

After completion, the address compare is automatically deactivated.

2. START DELAYED DISPLAY: When the address compare is successfully completed, the delayed display that you specified in a display/alter function is performed and the address compare is automatically deactivated. The keyboard is locked until the address compare is successfully completed. If you want to unlock the keyboard, press ATTN. This action also deactivates the address compare.

If you specified a delayed display, field o of the MSA displays DELAYED-DISPLAY.

If you forgot to specify a delayed display and you specified in the address compare ACTION ==> 2, the following message is displayed:

NO DELAYED DISPLAY. SPECIFY IT IN A DISP/ALT FUNCTION

3. START DELAYED ALTER: When the address compare is successfully completed, the delayed alter that you specified in a display/alter function is executed and the address compare is automatically deactivated. The keyboard is locked until the address compare is successfully completed. If you want to unlock the keyboard, press ATTN. This action also deactivates the address compare.

If you specified a delayed alter, field o of the MSA displays DELAYED-ALTER.

If you forgot to specify a delayed alter and you specified ACTION ==> 3 in the address compare, the following message is displayed:

NO DELAYED ALTER. SPECIFY IT IN A DISP/ALT FUNCTION

4. STOP SCANNER: When the address compare is successfully completed, the scanner is no longer under control of the CCU control program and the address compare is automatically deactivated. The scanner is in DISCONNECTED/STOP state (see field m of the MSA).

5. STOP SCANNER BUT LEAVE AC ACTIVE: When the address compare is successfully completed, the scanner, in DISCONNECTED/STOP state, is no longer under control of the CCU control program but the address compare remains active.

To restart the scanner, use scanner command START:

SELN AREA
3 followed by SEND
ST followed by SEND

DEACTIVATING THE SCANNER ADDRESS COMPARE

- Scanner address compare is automatically deactivated after successful completion for address compare with action 1, 2, 3, or 4.
- To deactivate the address compare function with action 5, press D followed by SEND.
- To deactivate the address compare function before completion of the address compare, proceed according to the type of address compare action:

- Action 1, 4, or 5: press D SEND

- Action 2 or 3: press ATTN

If the address compare frame is no longer displayed, you must call again the Address Compare function to deactivate it:

SELN AREA
8 followed by SEND
D followed by SEND

- The scanner address compare is also deactivated when:
 - You release the scanner.
 - You select the Terminate (T) FUNCTION.

Checkpoint Trace (Scanner)

SELECTION

1. Press SELN AREA to position the cursor.
2. Press M followed by SEND to display the MAINTENANCE primary menu.
3. Press 9 followed by SEND to select the scanner checkpoint trace.

The checkpoint trace is always ready to start at the same time as the SIT trace starts. Use this function to stop the checkpoint trace. To perform the checkpoint trace function, you need not select a scanner. The checkpoint trace is described on page 2-040.

A single screen is displayed:

```
- ENTER A DECIMAL LINE ADDRESS FROM 0 to 255 ==>
      OR FROM 0 to 95* ==>

  ENTER T FOR TRANSMIT, R FOR RECEIVE

- ENTER ON OR OFF          ==>

  ON - CHECKPOINT TRACE WILL START WITH
      SCANNER INTERFACE TRACE (SIT)
  OFF - CHECKPOINT TRACE NOT EFFECTIVE

ENTER ANY INTERFACE:RELEASE/SELECT SCANNER IS AUTOMATIC
```

* For the 3725 Model 2

TRA Select, Connect/Disconnect

INTRODUCTION

TRSS functions are designed to provide debugging facilities for the token ring subsystem. Supported adapters are the token ring adapters (TRA), which are composed of the token ring multiplexer card (TRM) and the token ring interface coupler card (TIC).

SELECTION FROM THE CONTROLLER DISKETTE

1. Press SELN AREA to position the cursor.
2. Press M followed by SEND to display the MAINTENANCE primary menu.
3. Press R followed by SEND to display the TRSS FNCTN (functions).

All TRSS functions are then displayed in the secondary menu:

Menu	See Page	Disruptive
1 SELECT	2-380	no
2 CONNECT/DISC	2-380	yes
3 TRM REGS	2-381	yes (alter)
4 TIC INTR REG	2-382	yes (alter)
5 DPLY STORAGE	2-383	yes
6 DUMP	2-384	yes
7 DPLY SCB, SSB	2-385	no
8 DPLY PARM BLK	2-385	no
9 TIC ERR STAT	2-386	no

Warning: TRSS functions may disrupt communications on the ring attached to the selected TRA. See the table above to identify the potential risks.

MESSAGES

Refer to page 2-520 onwards for the message explanations and for the action to be taken for each message displayed when TRSS functions are run.

TRA SELECT (1)

Select TRSS function menu, then enter "1" followed by SEND.

```

PROCESS STOP-CCU-CHK MOSS-ONLINE      X71:hhhhh
RUN      BYP-IOC-CHK                   X72:hhhhh
TRA nn   xxxxxxxxxxxx                  xxxxxxxxxxxx

I: IPL CCU/TSS      G: GCF/IPL Ports   S: TSS FNCTN      SP: CCU STOP      Q: DATE/TIME
L: LINE FNCTN      C: CNTRL PGM PROC   U: UTILITY PGM   ST: CCU START    T: TERMINATE
E: ERROR LOG       N: CUSTOMER MENU    R: TRSS FNCTN   RS: CCU RESET

1 SELECT
2 CONNECT/DISC
3 TRM REGS
4 TIC INTR REG
5 DPLY STORAGE
6 DUMP
7 DPLY SCB, SSB
8 DPLY PARM BLK
9 TIC ERR STAT

                                SELECT
                                ENTER THE TRA # ==> nn   TRA # LINE ADDRESS  TIC(S)
                                nn   nnn nnn nnn nnn nnnn

                                PRESS SEND TO CONFIRM
                                TRA nn SELECTED: LOOK IN MSA FOR MODE

====>

```

Before selecting any service, the maintenance operator must choose a TRA by entering TRA number (6 - 16). A table is provided in the work area to assist the operator in making a selection. The line numbers associated with the available TRAs are shown. The TICs attached to each TRM are also given. MOSS builds this table from the hardware CDF.

All maintenance operator requests will then be routed to this TRA, known as the "selected TRA".

To access a different TRA, the operator must repeat the selection process.

The mode of the selected TRA is shown in the MSA line 3.

TRA Connect/Disconnect (2)

Enter "2" in the selection area followed by SEND.

```

                                TRA CONNECT/DISCONNECT

                                TYPE CT TO CONNECT
                                DS TO DISCONNECT ==> DS

                                PRESS SEND TO CONFIRM

```

The maintenance operator can change the mode of the selected TRA. See "TRSS Modes" on page 2-387 for a definition of these modes.

CONNECT: To connect a TRA, enter "CT" followed by SEND.

DISCONNECT: To disconnect a TRA, enter "DS" followed by SEND.

Display/Alter TRM Registers (3)

Enter "3" in the selection area followed by SEND.

```

PROCESS  STOP-CCU-CHK MOSS-ONLINE   X71:hhhhh
RUN      BYP-IOC-CHK LASTMCHK:hhh   X72:hhhhh
TRA nn   xxxxxxxxxxxx                xxxxxxxxxxxx

I: IPL CCU/TSS      G: GCF/IPL Ports  S: TSS FNCTN  SP: CCU STOP  Q: DATE/TIME
L: LINE FNCTN      C: CNTRL PGM PROC  U: UTILITY PGM ST: CCU START  T: TERMINATE
E: ERROR LOG       N: CUSTOMER MENU  R: TRSS FNCTN  RS: CCU RESET

1 SELECT
2 CONNECT/DISC
3 TRM REGS
4 TIC INTR REG
5 DPLY STORAGE
6 DUMP
7 DPLY SCB, SSB
8 DPLY PARM BLK
9 TIC ERR STAT

                DISPLAY/ALTER TRM REGISTERS (1)
TRM CONTROL:      TIC CONTROL (R/W): 1 2 3 4
  RESET (R):      n      RESET          ==> n n n n
  HI PRIO (R/W) ==> n      INH INTR       ==> n n n n
                                INH DMA       ==> n n n n
                                MOSS CONTROL ==> n n n n
DIAG (R/W): TRM WRAP ==> n      DMA R(1)/W(0) ==> n
  PIO(1) DMA(0)   ==> n      ODD(1)/EVEN(0) ==> n
  TA,TD BAD PARITY ==> nn     BYTE 0,1       ==> nn
  FORCE TIMEOUT    ==> n      DMA COUNTER    ==> n
  FORCE IDLE ERROR ==> n      START          ==> n
  FORCE BAD PTY INT ==> n     CSCW,BUS BAD PTY ==> nn
PF1: ALTER  PF2: REFRESH  PF5: FORWARD

==>
    
```

Press PF5: FORWARD

```

PROCESS  STOP-CCU-CHK MOSS-ONLINE   X71:hhhhh
RUN      BYP-IOC-CHK LASTMCHK:hhh   X72:hhhhh
TRA nn   xxxxxxxxxxxx                xxxxxxxxxxxx

I: IPL CCU/TSS      G: GCF/IPL Ports  S: TSS FNCTN  SP: CCU STOP  Q: DATE/TIME
L: LINE FNCTN      C: CNTRL PGM PROC  U: UTILITY PGM ST: CCU START  T: TERMINATE
E: ERROR LOG       N: CUSTOMER MENU  R: TRSS FNCTN  RS: CCU RESET

1 SELECT
2 CONNECT/DISC
3 TRM REGS
4 TIC INTR REG
5 DPLY STORAGE
6 DUMP
7 DPLY SCB, SSB
8 DPLY PARM BLK
9 TIC ERR STAT

                DISPLAY/ALTER TRM REGISTERS (2)
LID BASE (R/W) ==> nnnn
DATA REGISTER (R/W) ==> nn nnnn

IR/BR (R/W):
  IR1 ==> n  IR2 ==> n  IR3 ==> n  IR4 ==> n
  BR1 ==> n  BR2 ==> n  BR3 ==> n  BR4 ==> n

CSCW (R): nnnn

LEVEL 1 ERROR STATUS (R): nnnn nnnn nnnn nnnn BINARY
PF1: ALTER  PF2: REFRESH  PF4: BACKWARD
    
```

The following table shows the TRM registers that may be displayed or altered:

Register	Read	Write	For details see pages
TRM state control	X	W	15-106
TIC state control	X	W	15-106
Level 1 error status	X		15-107
Line ID base register	X	W	15-120
IR/BR	X	W	15-106
Diag register	X	W	
Data buffer register	X	W	15-106
CSCW	X		15-121

X : Display function available

W : Alter function available and preceded by a warning

Detail : Contents are shown in bit format with meaning of each bit given

ALTER:

To alter the contents of a register, the operator must press PF1 twice: once to select alter mode and once to confirm. A warning message is displayed after the first PF1. The alterable fields will be highlighted. The operator may update these fields and press SEND to alter the register contents, or press PF3 to ignore the alter.

After the alter is complete, the contents of the registers are read and displayed again. This allows the operator to verify that the contents were actually updated.

The register contents are updated on the screen whenever the SEND key is pressed (but not in alter mode).

REFRESH: A refresh option is available, which updates the screen periodically.

PRESS PF2 to start refresh, ATTN to stop the refresh.

Display/Alter TIC Interrupt Register (4)

Enter "4" in the selection area, followed by SEND.

The maintenance operator can write or read the TIC interrupt register. The significance of each bit is given.

REFRESH: A refresh option is available, which updates the screen periodically.

Press PF2 to start refresh, ATTN to stop refresh.

ALTER: The alter procedure is the same as in "Display/Alter TRM Registers".

PROCESS	STOP-CCU-CHK	MOSS-ONLINE	X71:hhhhh
RUN	BYP-IOC-CHK		X72:hhhhh
TRA nn	xxxxxxxxxx		xxxxxxxxxx

I: IPL CCU/TSS	G: GCF/IPL Ports	S: TSS FNCTN	SP: CCU STOP	Q: DATE/TIME
L: LINE FNCTN	C: CNTRL PGM PROC	U: UTILITY PGM	ST: CCU START	T: TERMINATE
E: ERROR LOG	N: CUSTOMER MENU	R: TRSS FNCTN	RS: CCU RESET	

1 SELECT	
2 CONNECT/DISC	
3 TRM REGS	
4 TIC INTR REG	
5 DPLY STORAGE	
6 DUMP	
7 DPLY SCB, SSB	
8 DPLY PARM BLK	
9 TIC ERR STAT	

ENTER THE TIC ID (1, 2, 3 OR 4) ==> n

VALID CHOICES ARE: 1 2 3 4
LINE # : nnn nnn nnn nnn

==>

Enter the TIC ID followed by SEND.

PROCESS	STOP-CCU-CHK	MOSS-ONLINE	X71:hhhhh
RUN	BYP-IOC-CHK		X72:hhhhh
TRA nn	xxxxxxxxxx		xxxxxxxxxx

I: IPL CCU/TSS	G: GCF/IPL Ports	S: TSS FNCTN	SP: CCU STOP	Q: DATE/TIME
L: LINE FNCTN	C: CNTRL PGM PROC	U: UTILITY PGM	ST: CCU START	T: TERMINATE
E: ERROR LOG	N: CUSTOMER MENU	R: TRSS FNCTN	RS: CCU RESET	

1 SELECT		DISPLAY/ALTER TIC INTERRUPT REGISTER	
2 CONNECT/DISC		INTERRUPT ==> hhhh OR INTERRUPT ADAPTER ==>	n
3 TRM REGS		RESET ==>	nn
4 TIC INTR REG		SSB CLEAR ==>	nn
5 DPLY STORAGE		EXECUTE ==>	nn
6 DUMP		SCB REQUEST ==>	nn
7 DPLY SCB, SSB		RECEIVE CONTINUE ==>	nn
8 DPLY PARM BLK		RECEIVE VALID ==>	nn
9 TIC ERR STAT		XMIT VALID ==>	nn
		RESET SYSTEM INTR ==>	nn
		INITIALIZE CODE(R)	nnn
		INTERRUPT CODE(R)	nnn

PF1: ALTER PF2: REFRESH

==>

See page 15-170 for further description of the TIC interrupt register.

Display TIC Storage (5)

The operator can display TIC storage in hex and EBCDIC format.
 The selected TRA must be in DISCONNECT mode for this operation.
 Enter "5" in the selection area, followed by SEND.

```

PROCESS  STOP-CCU-CHK MOSS-ONLINE   X71:hhhhh
RUN      BYP-IOC-CHK                X72:hhhhh
TRA nn   xxxxxxxxxxxx   TIC n       xxxxxxxxxxxx

I: IPL CCU/TSS      G: GCF/IPL Ports  S: TSS FNCTN   SP: CCU STOP   Q: DATE/TIME
L: LINE FNCTN      C: CNTRL PGM PROC U: UTILITY PGM ST: CCU START T: TERMINATE
E: ERROR LOG       N: CUSTOMER MENU  R: TRSS FNCTN  RS: CCU RESET

1 SELECT
2 CONNECT/DISC
3 TRM REGS
4 TIC INTR REG
5 DPLY STORAGE
6 DUMP
7 DPLY SCB, SSB
8 DPLY PARM BLK
9 TIC ERR STAT

                DISPLAY TIC STORAGE
- ENTER ADDRESS OF START OF DISPLAY ==> h (HEX)
  (RAM: 0 TO FFF)
- ENTER NBR OF HALFWORDS TO DPLY (UP TO 48) ==> nn (DEC)

==>
    
```

Display

The maintenance operator must specify the address limits of storage (0 to x 'FFF') to be displayed. Scrolling is permitted. From 1 to 48 halfwords may be displayed at one time.

```

PROCESS  STOP-CCU-CHK MOSS-ONLINE   X71:hhhhh
RUN      BYP-IOC-CHK                X72:hhhhh
TRA nn   xxxxxxxxxxxx   TIC n       xxxxxxxxxxxx

I: IPL CCU/TSS      G: GCF/IPL Ports  S: TSS FNCTN   SP: CCU STOP   Q: DATE/TIME
L: LINE FNCTN      C: CNTRL PGM PROC U: UTILITY PGM ST: CCU START T: TERMINATE
E: ERROR LOG       N: CUSTOMER MENU  R: TRSS FNCTN  RS: CCU RESET

1 SELECT
2 CONNECT/DISC
3 TRM REGS
4 TIC INTR REG
5 DPLY STORAGE
6 DUMP
7 DPLY SCB, SSB
8 DPLY PARM BLK
9 TIC ERR STAT

                DISPLAY TIC STORAGE
- ENTER ADDRESS OF START OF DISPLAY ==> n (HEX)
  (RAM: 0 TO FFF)
- ENTER NBR OF HALFWORDS TO DPLY (UP TO 48) ==> nn (DEC)
0000 hhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh .....
0010 hhhhhhhh hhhhhhhh hhhhhhhh hhhhhhhh .....
0020 hhhhhhhh hhhhhhhh .....

PF4: BACKWARD PF5: FORWARD

==>
    
```

TIC INTERNAL RAM FORMAT

EBCDIC Format	COMMENTS
xxxxxxxxxxxxxxxx	- 000 Start of TIC RAM
.	
.	
xxxxxxxxxxxxxxxx	
szzzzzzzzzlluTR	- x'1000' Start of header info
A:dd TIC:d CC	
UID:xxxxxxxx TI	
ME:mm/dd/yy hh:m	
m:ss LID:xxxx BU	
FFER:xxxxxx CO	- Data Buffer Register
INTROL:xxxx DI	- TIC control 4 bits right justified
AG:xxxx IR	- Diagnostic Register
/BR:xx LI	- IR/BR 2 bits right justified
ERR:xxxx IN	- IR/BR 2 bits right justified
TR:xxxx IP	- TIC interrupts Register
B:xxxxxxxxxxxxxx	- Unit Parameter Block
xxxxxxxxxxxxxxxx	
xxxxxxxxxxxxxxxx	
xxxxxxxxxxxxxxxxOP	- Open Parameter Block
B:xxxxxxxxxxxxxx	
xxxxxxxxxxxxxxxx	
xxxxxxxxxxxxxxxx	
xxxxxxxxxxxxxxxx	
xx CH	
KSTAT:xxxxxxxxxx	- Adapter Check Status
xxxxxx RI	
INGSTAT:xxxx	- Ring Status

Notes:

- Bit 0=1 of "s" indicates an automatic TIC dump.
- Bit 1=1 of "s" indicates the dump was truncated due to error.
- "ll" contains the TIC lower dump limit.
- "uu" is the upper bound of the TIC dump.
- '0FFF'x is normal and means that a complete TIC dump was taken.
- Characters in capital letters are inserted literally into the dump.
- "x" indicates an EBCDIC hex value substitution. (i.e., 2 chars/byte).
- A blank indicates an EBCDIC blank character x'40'.
- "z" is non-essential data.

Dump TIC Storage (6)

The dump function dumps all installed RAM of the selected TIC. The following information is also provided:

Related TRM registers: Line ID base, data buffer, TIC state, diag, IR/BR, level 1 error status

TIC interrupt register
Init and open parameter blocks
TIC adapter check status
TIC token-ring status

Four TIC dumps may be stored on the CHGTRSS dump file on the controller diskette as shown below. A fixed portion of CHGTRSS is statically allocated to a TIC dump from each of the four possible TIC positions (1-4). The TRA position is not considered in determining TIC dump placement within CHGTRSS. The chart below describes CHGTRSS.

Sector in CHGTRSS

1	TRSS Dump Header
2	TRA x TIC 1 dump (RAM)
18	TRA x TIC 1 dump spare header
20	TRA x TIC 2 dump (RAM)
36	TRA x TIC 2 dump spare header
38	TRA x TIC 3 dump (RAM)
54	TRA x TIC 3 dump spare header
56	TRA x TIC 4 dump (RAM)
72	TRA x TIC 4 dump spare header
74 (73 last)	

The TRSS dump header is necessary to indicate the presence, timestamp, and characteristics of a TIC dump within CHGTRSS.

When a TIC dump area contains a dump, the operator is given a choice of overwriting or canceling the dump request.

A TIC dump may be deleted or examined using utility programs (See "DUMP DISPLAY/DELETE UTILITY").

The TRA must be in DISCONNECT mode for this operation.

Enter "6" in the selection area, followed by SEND.

TIC select screen is displayed first

TIC select screen

PROCESS	STOP-CCU-CHK	MOSS-ONLINE	X71:hhhhh
RUN	BYP-IOC-CHK		X72:hhhhh
TRA nn	xxxxxxxxxx	TIC n	xxxxxxxxxxxx

I: IPL CCU/TSS	G: GCF/IPL Ports	S: TSS FNCTN	SP: CCU STOP	Q: DATE/TIME
L: LINE FNCTN	C: CNTRL PGM PROC	U: UTILITY PGM	ST: CCU START	T: TERMINATE
E: ERROR LOG	N: CUSTOMER MENU	R: TRSS FNCTN	RS: CCU RESET	

1 SELECT	DUMP TIC STORAGE
2 CONNECT/DISC	
3 TRM REGS	
4 TIC INTR REG	
5 DPLY STORAGE	- ENTER "Y" TO DUMP TIC RAM ==> Y
6 DUMP	
7 DPLY SCB, SSB	
8 DPLY PARM BLK	
9 TIC ERR STAT	

==>

DUMP IS COMPLETE

Enter the TIC ID, followed by SEND.

Enter "Y", followed by SEND

If disk file contains a dump, the following prompt will appear in a clear work area:

THE DUMP AREA CONTAINS A TIC DUMP.
TYPE C TO CLEAR FILE, OTHERWISE PRESS SEND ==> _

The message "DUMP IS COMPLETE" is displayed after approximately 30 seconds.

TIC Functional Blocks

The maintenance operator can display parameters related to a selected TIC. These blocks are located in CCU storage and are controlled by NTRI.

Item	See note
Init parameter block contents	1
Open parameter block contents	1
RCV list chain address	2
XMIT list chain address	2
SCB address and contents	1
SSB address and contents	1

Notes:

1. The meaning of each byte, halfword, or word in the block is given.
2. An address of one of the lists in the chain is given.

Display SCB, SSB and Parameter Block (7, 8)

Display SCB, SSB (7)

Enter "7" in the selection area, followed by SEND.

PROCESS	STOP-CCU-CHK	MOSS-ONLINE	X71:hhhhhh
RUN	BYP-IOC-CHK		X72:hhhhhh
TRA nn	xxxxxxxxxx		

I: IPL CCU/TSS	G: GCF/IPL Ports	S: TSS FNCTN	SP: CCU STOP	Q: DATE/TIME
L: LINE FNCTN	C: CNTRL PGM PROC	U: UTILITY PGM	ST: CCU START	T: TERMINATE
E: ERROR LOG	N: CUSTOMER MENU	R: TRSS FNCTN	RS: CCU RESET	

1 SELECT		ENTER THE TIC ID (1, 2, 3 OR 4) ==> 1
2 CONNECT/DISC		
3 TRM REGS		
4 TIC INTR REG		
5 DPLY STORAGE		
6 DUMP		
7 DPLY SCB, SSB		
8 DPLY PARM BLK		
9 TIC ERR STAT		

VALID CHOICES ARE: 1 2 3 4
LINE # : nnn nnn nnn nnn

==>

Enter the TIC ID, followed by SEND.

PROCESS	STOP-CCU-CHK	MOSS-ONLINE	X71:hhhhhh
RUN	BYP-IOC-CHK		X72:hhhhhh
TRA nn	xxxxxxxxxx	TIC n	xxxxxxxxxxxxxx

I: IPL CCU/TSS	G: GCF/IPL Ports	S: TSS FNCTN	SP: CCU STOP	Q: DATE/TIME
L: LINE FNCTN	C: CNTRL PGM PROC	U: UTILITY PGM	ST: CCU START	T: TERMINATE
E: ERROR LOG	N: CUSTOMER MENU	R: TRSS FNCTN	RS: CCU RESET	

1 SELECT		DISPLAY TIC SCB, SSB (FROM NTRI)
2 CONNECT/DISC		
3 TRM REGS		
4 TIC INTR REG		
5 DPLY STORAGE		
6 DUMP		
7 DPLY SCB, SSB		
8 DPLY PARM BLK		
9 TIC ERR STAT		

SCB ADDRESS: nnnnnn
CONTENTS: nnnn
 nnnn
 nnnn

SSB ADDRESS: nnnnnn
CONTENTS: nnnn
 nnnn
 nnnn

PF2: REFRESH

==>

Refresh:
Press PF2 to start refresh mode.
Press ATTN to stop refresh mode.

Display Parameter Block (8)

Enter "8" in the selection area, followed by SEND

PROCESS	STOP-CCU-CHK	MOSS-ONLINE	X71:hhhhhh
RUN	BYP-IOC-CHK		X72:hhhhhh
TRA nn	xxxxxxxxxx	TIC n	xxxxxxxxxxxxxx

I: IPL CCU/TSS	G: GCF/IPL Ports	S: TSS FNCTN	SP: CCU STOP	Q: DATE/TIME
L: LINE FNCTN	C: CNTRL PGM PROC	U: UTILITY PGM	ST: CCU START	T: TERMINATE
E: ERROR LOG	N: CUSTOMER MENU	R: TRSS FNCTN	RS: CCU RESET	

1 SELECT		DISPLAY TIC INITIALIZE PARAMETER BLOCK (FROM NTRI)
2 CONNECT/DISC		
3 TRM REGS		
4 TIC INTR REG		
5 DPLY STORAGE		
6 DUMP		
7 DPLY SCB, SSB		
8 DPLY PARM BLK		
9 TIC ERR STAT		

OPTIONS: nnnn DMA ABORT THRESH: nnnn
INTR VECT CMD: nn SCB ADDRESS: nnnnnnnn
INTR VECT XMIT: nn SSB ADDRESS: nnnnnnnn
INTR VECT RCV: nn
INTR VECT RING: nn
INTR VECT SCB: nn
INTR VECT ADPT: nn
RCV BURST SIZE: nnnn
XMIT BURST SIZE: nnnn

PF5: FORWARD

==>

Enter PF5: FORWARD

PROCESS	STOP-CCU-CHK	MOSS-ONLINE	X71:hhhhhh
RUN	BYP-IOC-CHK		X72:hhhhhh
TRA nn	xxxxxxxxxx	TIC n	xxxxxxxxxxxxxx

I: IPL CCU/TSS	G: GCF/IPL Ports	S: TSS FNCTN	SP: CCU STOP	Q: DATE/TIME
L: LINE FNCTN	C: CNTRL PGM PROC	U: UTILITY PGM	ST: CCU START	T: TERMINATE
E: ERROR LOG	N: CUSTOMER MENU	R: TRSS FNCTN	RS: CCU RESET	

1 SELECT		DISPLAY TIC OPEN PARAMETER BLOCK (FROM NTRI)
2 CONNECT/DISC		
3 TRM REGS		
4 TIC INTR REG		
5 DPLY STORAGE		
6 DUMP		
7 DPLY SCB, SSB		
8 DPLY PARM BLK		
9 TIC ERR STAT		

OPEN OPTIONS: nnnn BUFFER SIZE: nnnn
NODE ADDRESS: nnnnnnnnnnnn EXT RAM START: nnnn
GROUP ADDRESS: nnnnnnnn EXT RAM END: nnnn
FUNCT ADDRESS: nnnnnnnn XMIT BUF COUNT: nnnn
RCV LIST SIZE: nnnn PROD ID ADDR: nnnnnnnn
XMIT LIST SIZE: nnnn

XMIT LIST CHAIN ADDR: nnnnnn
RCV LIST CHAIN ADDR: nnnnnn

PF4: BACKWARD

==>

Display Token Ring Status (9)

Token Ring Status

The operator can display the Token Ring status of the selected TIC. The bits are shown in detail with meanings.

Enter "9" in the selection area, followed by SEND.

PROCESS	STOP-CCU-CHK	MOSS-ONLINE	X71:hhhhh
RUN	BYP-IOC-CHK		X72:hhhhh
TRA nn	xxxxxxxxxx		

I: IPL CCU/TSS	G: GCF/IPL Ports	S: TSS FNCTN	SP: CCU STOP	Q: DATE/TIME
L: LINE FNCTN	C: CNTRL PGM PROC	U: UTILITY PGM	ST: CCU START	T: TERMINATE
E: ERROR LOG	N: CUSTOMER MENU	R: TRSS FNCTN	RS: CCU RESET	

1 SELECT		ENTER THE TIC ID (1, 2, 3 OR 4) ==> 1
2 CONNECT/DISC		
3 TRM REGS		
4 TIC INTR REG		
5 DPLY STORAGE		
6 DUMP		
7 DPLY SCB, SSB		
8 DPLY PARM BLK		
9 TIC ERR STAT		

VALID CHOICES ARE: 1 2 3 4
LINE # : nnn nnn nnn nnn

==>

Enter the TIC ID, followed by SEND.

PROCESS	STOP-CCU-CHK	MOSS-ONLINE	X71:hhhhh
RUN	BYP-IOC-CHK		X72:hhhhh
TRA nn	xxxxxxxxxx	TIC n	xxxxxxxxxxxx

I: IPL CCU/TSS	G: GCF/IPL Ports	S: TSS FNCTN	SP: CCU STOP	Q: DATE/TIME
L: LINE FNCTN	C: CNTRL PGM PROC	U: UTILITY PGM	ST: CCU START	T: TERMINATE
E: ERROR LOG	N: CUSTOMER MENU	R: TRSS FNCTN	RS: CCU RESET	

1 SELECT		TOKEN RING STATUS (FROM NTRI)	
2 CONNECT/DISC		SIGNAL LOSS:	n
3 TRM REGS		HARD ERROR:	n
4 TIC INTR REG		SOFT ERROR:	n
5 DPLY STORAGE		TRANSMIT BEACON:	n
6 DUMP		LOBE WIRE FAULT:	n
7 DPLY SCB, SSB		AUTO-REMOVAL ERROR 1:	n
8 DPLY PARM BLK		REMOVE RECEIVED:	n
9 TIC ERR STAT		COUNTER OVERFLOW:	n
	SINGLE STATION:	n	
	RING RECOVERY:	n	
	PF2: REFRESH		

==>

TRSS Modes

TRSS Functions are based on the concept of modes.

Each TRA must be in one of the three following modes:

- DISCONNECT:** The TRA is under MOSS control. Moss is expected to handle all interrupts and PIO to/from the TIC.
- CONNECT:** The TRA is under the NCP Token-Ring Interconnection (NTRI) control. NTRI is expected to handle all interrupts (except in the case of an MIOH error)
- UNKNOWN:** A non-recoverable error occurred during the connect or disconnect process, or an MIOC/IOC error occurred while getting level 1 error status during TRA select. connect/disconnect may be retried.

NTRI MAC STATUS AND CORRESPONDING TIC MODE

Medium Access Control Status	TIC Mode
Idle	IDLE
TIC resetting hard	"
TIC resetting soft	"
Initialization list xfer	RESET
Initialized	INITIALIZED
Open started	"
Receive initialization	"
Transmit initialization	"
Started	OPEN
Transmit in progress	"
Close in progress	"
Closed	CLOSED
Frozen	FROZEN
Disconnected	DISABLED

Each TIC must be in one of seven following modes (as reported by NTRI):

- IDLE:** The TIC has not yet been reset by NTRI.
- RESET:** The TIC has been reset by NTRI but not yet initialized.
- INITIALIZED:** The TIC has been initialized but not yet OPEN or DISABLED. Initialization parameters have been passed to the TIC by NTRI.
- OPEN:** The TIC has been inserted into the token ring and is in normal operation. Open parameters have been passed and received and transmit operations have been started.
- CLOSED:** The TIC has been opened since initialization but has been closed (by the host).
- FROZEN:** An error was detected and the following actions were taken by NTRI:
- Interrupts from this TIC are disabled.
 - DMA from this TIC is disabled.
 - The TIC is reset.
- DISABLED:** The associated TRA has been disconnected by MOSS. NTRI will send no PIO to this TIC.
- (blank):** There is no TIC mode if NTRI is not online.

Note: The TIC Mode is derived from the NTRI medium access control (MAC) Layer status obtained from NTRI.

Utility Programs

The procedure for selecting the utility programs depends on the diskette installed.

SELECTION FROM THE CONTROLLER DISKETTE

1. Press SELN AREA to position the cursor.
2. Press M followed by SEND to display the MAINTENANCE primary menu.
3. Press U followed by SEND to display the UTILITY PGM (programs).

All the utility programs are then displayed in the secondary menu:

MENU	See Page
1 DUMP DPLY/DEL	2-391
2 MOSS STORE DPLY	2-393
3 MODULE DPLY	2-393
4 ZAP	2-394
5 CDF	2-400
6 MLT	2-407
7 DISKETTE SWAP	2-408

SELECTION FROM THE SERVICE DISKETTE

1. Press SELN AREA to position the cursor.
2. Press U followed by SEND to select the utility programs.

All utility programs are then displayed in the secondary menu (see above).

MESSAGES

Refer to page 2-480 for the message explanations and for the action to be taken for each message displayed when utility programs are run.

MOSS, Scanner and TRSS Dump Display/Delete (Part 1 of 2)

This function allows you to display or delete a MOSS or scanner dump from the controller diskette. It also allows you to delete the contents of the BER file from the diskette.

Refer to page 2-440 for the MOSS, scanner, or TRSS dump procedure.

There is no dump file on the service diskette. (Refer to page 14-081 for diskette mapping).

SELECTION

1. Select the utility programs as explained page 2-390.
2. Enter 1 followed by SEND.

When you select the function, it is in display mode.

- ENTER FILE NAME ==>

CHGDMP = CS DUMP FILE (Note)
CHGTRSS = TRSS DUMP FILE

PF3:DELETE FUNCTION
PRESS SEND TO DISPLAY DUMP TITLES

Note: The CHGDMP dump area may contain a MOSS dump. In this case, "MOSS DUMP" is displayed.

If you press SEND, the following information on the dump files is displayed:

- Whether a dump exists
- Date and time of the dump (if it exists)
- Reasons for taking the dump

MOSS OR SCANNER DUMP DISPLAY

If you enter CHGDMP (and the dump area contains a MOSS dump file), you may display either the full dump file or only a specified area.

- SELECT AN ITEM (0 TO 19) ==>
CHGDMP DATE/TIME:07/28/82 18:27:26 TRS:BAD CP ANS

	---TCB---	---ACB---
0 TO 7: INTERRUPT DATA	11: BER	17: CNSL
8: ERROR COUNTERS	12: MSA	18: MIOC
9: SVT	13: CCUBG	19: DISK
10: BER STACK	14: CAM	
	15: OPCTL	
	16: IPL	

PF1:ITEM SELECT PF4:BACKWARD PF5:FORWARD
PRESS SEND TO DISPLAY FILE

The dump is displayed in hexadecimal format, as follows:

- ENTER FILE NAME ==>

```
036E0 000065B8 11104000 00040000 65B80000 .....
036F0 52ED1312 20000000 00005000 00007654 .....&.....
03700 15141000 20000000 74940000 81C41716 .....M..AD..
03710 08000000 000081C4 0000995C 59180400 .....AD..R*...
03720 00000000 0FA80168 B9469B1A 02000000 .....Y.....
03730 0000AF2C 016809CC 0768026E 025026D4 .....>.&.M.
03740 27982828 28E82914 26FE29A8 2AF00A16 Q...Y....Y.0..
03750 00000000 40000000 8000375C 376600FB .....*.....
03760 00000000 00000000 00000000 00000000 .....
03770 00000000 00000000 00000000 00000000 .....
PF1:ITEM SELECT PF3:DELETE FNCTN PF4:BACKWARD PF5:FORWARD
SET NEW START ADDRESS ON ANY LINE, PRESS SEND
```

If you enter CHGDMP and the dump area contains a scanner dump file, the following screen is displayed:

- SELECT AN ITEM (0 TO 1) ==>
CHGDMP DATE/TIME:00/00/00 00:31:11 SCANNER 01

0: PAGES 0 TO B AND PSWS
1: EXTERNAL REGISTERS

PF1:ITEM SELECT PF4:BACKWARD PF5:FORWARD
PRESS SEND TO DISPLAY FILE

TRSS DUMP DISPLAY

The TRSS Dump file may contain up to 4 TIC dumps and 4 TIC REGs and STATUS. Enter CHGTRSS to display the TRSS Dump file contents and select one of these 8 items.

- SELECT AN ITEM (0 TO 7) ==> 5
CHGTRSS TRSS DUMP FILE

0: EMPTY
1: EMPTY
2: EMPTY
3: EMPTY
4: TRA:06 TIC:3 RAM DATE/TIME:00/00/00/ 00:00:56
5: TRA:06 TIC:3 REGS & STATUS
6: TRA:06 TIC:4 RAM DATE/TIME:00/00/00/ 00:01:41
7: TRA:06 TIC:4 REGS & STATUS

PF1:ITEM SELECT

If you select 5 (TRA:06 TIC:3 REGS & STATUS), the following screen is displayed:

- SELECT AN ITEM (0 TO 7) ==> 5
CHGTRSS TRSS DUMP FILE
TRA:06 TIC:3 CCUID:00000000
TIME:00/00/00 00:00:56 LID:0000
BUFFER:000000 CONTROL:0110
DIAG:0000 IR/BR:00
LIERR:0110 INTR:0000
IPB:00000000000000000000000000000000
00000000000000000000000000000000
00000000000000000000000000000000
00000000000000000000000000000000
CHKSTAT:0000000000000000
RINGSTAT:0000
PF1:ITEM SELECT

If you select 4 (TRA:06 TIC:3 RAM etc...), the following screen is displayed:

- ENTER FILE NAME ==>
CHGTRSS TRSS DUMP FILE
00000 D0E00C4D D0E48C8D D07E8C8D D07E0C8D ...(.U...=...=..
00010 D07E0C8D D07E0C8D D07E0C8D D07E0C8D .=...=...=...=..
00020 00000000 00000000 00000000 00000000
00030 00000000 00000000 00000000 00000000
00040 00000000 00000000 00000000 00000000
00050 00000000 00000000 00000000 00000000
00060 00000000 00000000 00000000 00000000
00070 00000000 00000000 00000000 00000000
00080 00000000 00000000 00000000 00000000
00090 00000000 00000000 00000000 00000000
000A0 00000000 00000000 00000000 00000000
PF1:ITEM SELECT PF3:DELETE FNCTN PF4:BACKWARD PF5:FORWARD
SET NEW START ADDRESS ON ANY LINE, PRESS SEND

MOSS, Scanner, and TRSS Dump Display/Delete (Part 2 of 2)

MOSS OR SCANNER DUMP DELETE

If you press PF3, the following screen is displayed:

- ENTER FILE NAME TO BE DELETED ==>

```
CHGDMP  = CS    DUMP FILE
CHGTRSS = TRSS  DUMP FILE
CHGCIL  = BER   FILE
```

PF3: DUMP DISPLAY FUNCTION

Enter the name of the file to be deleted. To return to the file selection screen, press PF3.

There is no MOSS or CS Dump file on the service diskette. Refer to page 14-081 for diskette mapping.

TRSS DUMP DELETE

If you press PF3, the following screen is displayed:

- ENTER FILE NAME TO BE DELETED ==> CHGTRSS

```
CHGDMP  = CS    DUMP FILE
CHGTRSS = TRSS  DUMP FILE
CHGCIL  = BER   FILE
```

PF3: DUMP DISPLAY FUNCTION

Enter the name of the file to be deleted. To return to the file selection screen, press PF3.

If CHGTRSS has been entered, the following screen is displayed:

- SELECT AN ITEM (0 TO 3) ==> 3

```
0: EMPTY
1: EMPTY
2: TRA:06 TIC:3
3: TRA:06 TIC:4
```

PF3:QUIT

If you want to erase TIC 4 Dump, enter 3 and the following screen is displayed:

- SELECT AN ITEM (0 TO 3) ==> 3

TIC 4 DUMP NOW EMPTY

```
0: EMPTY
1: EMPTY
2: TRA:06 TIC:3
3: EMPTY
```

PF3:QUIT

MOSS Store and Module Display

MOSS STORE DISPLAY (MOSS STORAGE DISPLAY)

SELECTION

1. Select the utility programs as explained page 2-390.
2. Enter 2 followed by SEND.

```

- SELECT AN ITEM (0 TO 19) ==>

          ---TCB---      ---ACB---
0 TO 7: INTERRUPT DATA  11: BER          17: CNSL
 8: ERROR COUNTERS     12: MSA          18: MIOC
 9: SVT                 13: CCUBG         19: DISK
10: BER STACK           14: CAM
                       15: OPCTL
                       16: IPL

PF1:ITEM SELECT      PF4:BACKWARD      PF5:FORWARD
PRESS SEND TO DISPLAY FILE
    
```

The next screen depends on the selected item. If, for example, 11 was entered, the following screen is displayed:

```

- SELECT AN ITEM (0 TO 19) ==> 11

BER TCB AT 03762 PSW: 065B8 11 10 ECF:0004
FLAG:00 EP: 065B8 END: 80000 MASK:0000
 0-14 0000 0000 0000 0000 0000 0000 0000 0000
 16-30 0000 0000 0000 0000 0000 0000 0000 0000
TTA 0B 0C 02 03 04 0D 0E 0F 10 11 12 13 14 15 16 17

PF1:ITEM SELECT      PF4:BACKWARD      PF5:FORWARD
PRESS SEND TO DISPLAY FILE
    
```

The dump is displayed in hexadecimal format as follows:

```

                                MOSS STORE
HHHHH ..... interpretation
HHHHH ..... interpretation
HHHHH ..... interpretation
HHHHH ..... interpretation
HHHHH ..... interpretation
HHHHH ..... interpretation
HHHHH ..... interpretation
HHHHH ..... interpretation
HHHHH ..... interpretation
HHHHH ..... interpretation
HHHHH ..... interpretation
HHHHH ..... interpretation
PF1:ITEM SELECT PF3:DELETE PF4:BACKWARD PF5:FORWARD
SET NEW START ADDRESS ON ANY LINE, PRESS SEND
    
```

MODULE DPLY (MODULE DISPLAY)

SELECTION

Enter 3 followed by SEND.

```

ENTER FILE NAME ==> CHGUCMOD AND MODULE NAME ==>

CHGUCMOD= MOSS MODULES
CHGMDJIB= CS  MODULES
CHGMOD37= CCU  MODULES
    
```


ZAP Area on Diskette

The ZAP utility programs are used to make microcode changes to the diskette. ZAPs are temporary changes to the microcode released by engineering and installed in the field by CEs. They provide immediate fixes to problems that will be permanently fixed on the next possible EC-updated diskette.

The ZAPs are entered into a work area of the diskette (ZAP area). This ZAP area is acted upon by the ZAP functions Create, Modify, Scan, and Erase. The actual microcode load modules on the diskette are not changed by anything in the ZAP area until the ZAP function Apply is used. The microcode load modules can be restored to their original condition after the ZAP is applied by using the ZAP Restore function.

Once the microcode load modules are changed, an IML is required to get the changed microcode from the diskette into the various areas of the machine. This should be done by putting the Function Select switch to Normal and pressing the Power On Reset switch.

Restriction: The ZAP function must be terminated (enter T) before the CCU functions are used, otherwise an unpredictable error occurs.



ZAP IDENTIFICATION

Note: The ZAP identification area can handle or contain twelve characters, but the ZAP identification format is as follows: PXXXYYYYZZZ (eight characters)

- P is for "patch"
- XXX are the last three digits of the EC number
- Y is the code area
- ZZZ is the ZAP sequence number

CREATING A ZAP

Before you create a ZAP, make sure that:

1. The EC level of the diskette is correct. Use the MLT function to display the EC level and ZAPs previously applied or restored.
2. The prerequisite ZAPs have been applied. If not, apply them.

To correct one error, you may have to modify the microcode in several locations. Each modification corresponds to one ZAP record.

When you create a ZAP, the microcode is not modified immediately.

Each ZAP is stored in the ZAP area. It may contain one or more ZAP records.

Example:

ZAP P123T003	
ZAP record 1	
ZAP record 2	
ZAP P123T004	
ZAP record 1	
ZAP record 2	
ZAP record 3	

To perform the modification requested in each record, you must apply the ZAP.

To create a ZAP record, you have to know:

- The ZAP-ID (up to 12 characters, ZAP identification)
- The names of the file and module that are to be modified
- The address of the data to be modified
- The data to be modified, called the verify data
- The new data, called the replace data
- The ZAP checksum (computed from all the ZAP records, including the ZAP-ID)

Once applied, the ZAP remains in the ZAP area.

ERASING A ZAP

It is not recommended to erase a ZAP just after it has been applied. You may have to restore it if the result of the apply is not as expected.

Erasing a ZAP removes it from the ZAP area only. However, the ID for it remains in the MLT ZAP history table. The microcode load modules are not changed by the erase command. They are changed only by Apply or Restore commands.

Selecting the ZAP Functions

SELECTION

1. Select the utility programs as explained page 2-390.
2. Enter 4 followed by SEND.

To use the ZAP utility program, the MOSS must not be online. If it is, the following message is displayed just after you have selected the ZAP utility program:

ZAP FUNCTION CANNOT BE PERFORMED WHEN MOSS IS ONLINE

Then do the following:

1. Press CCU FNCTN
2. Enter 5 followed by SEND
3. Enter 12 followed by SEND.

The MOSS is then offline and you can select the ZAP utility program.

Note: The message CCU INTERRUPTS DISABLED appears on the screen when the ZAP function is active. It means that any interrupts generated by the CCU to the MOSS are stacked until the ZAP function terminates.

You are first requested to enter the date. Use the slash (/) to separate each element of the date (mm/dd/yy). You can then select one of the ZAPs and one of the ZAP functions displayed on the screen.

Depending upon the number of ZAPs entered on the diskette, the screen that appears is as follows:

1. Sixteen (or less) ZAPs entered on the diskette

```

A APPL = APPLIED    N-A = NON-APPLIED    BAD = BAD    CHECKSUM
B                   SCREEN 1 OF 1
C PXXXYZZZ APPL ==>      PXXXYZZZ APPL ==>
  PXXXYZZZ N-A ==>      PXXXYZZZ APPL ==>
  PXXXYZZZ BAD ==>      PXXXYZZZ APPL ==>
  PXXXYZZZ APPL ==>     PXXXYZZZ APPL ==>
  PXXXYZZZ APPL ==>     PXXXYZZZ APPL ==>
  PXXXYZZZ APPL ==>     PXXXYZZZ APPL ==>
  PXXXYZZZ APPL ==>     PXXXYZZZ APPL ==>
  PXXXYZZZ APPL ==>     PXXXYZZZ APPL ==>
  PXXXYZZZ APPL ==>     PXXXYZZZ APPL ==>
D - ENTER A COMMAND AGAINST ONE ZAP-ID, OR PRESS A PF KEY
  A = APPLY  R = RESTORE  M = MODIFY  S = SCAN  E = ERASE
E PF1:CREATE A ZAP  PF2:UPDATE SPARE DISKETTE
  message area
  
```

2. More than sixteen and up to a maximum of thirty-two ZAPs entered on the diskette. On this screen, PF5 appears to indicate that screen 2 will display the remaining ZAPs.

```

A APPL = APPLIED    N-A = NON-APPLIED    BAD = BAD    CHECKSUM
B                   SCREEN 1 OF 2
C PXXXYZZZ APPL ==>      PXXXYZZZ APPL ==>
  PXXXYZZZ N-A ==>      PXXXYZZZ APPL ==>
  PXXXYZZZ BAD ==>      PXXXYZZZ APPL ==>
  PXXXYZZZ APPL ==>     PXXXYZZZ APPL ==>
  PXXXYZZZ APPL ==>     PXXXYZZZ APPL ==>
  PXXXYZZZ APPL ==>     PXXXYZZZ APPL ==>
  PXXXYZZZ APPL ==>     PXXXYZZZ APPL ==>
  PXXXYZZZ APPL ==>     PXXXYZZZ APPL ==>
  PXXXYZZZ APPL ==>     PXXXYZZZ APPL ==>
D - ENTER A COMMAND AGAINST ONE ZAP-ID, OR PRESS A PF KEY
  A = APPLY  R = RESTORE  M = MODIFY  S = SCAN  E = ERASE
E PF1:CREATE A ZAP  PF2:UPDATE SPARE DISKETTE PF5:SCREEN 2
  message area
  
```

When you press PF5, screen 2 appears (see below). On screen 2, PF4 is used to go back to screen 1.

```

A APPL = APPLIED    N-A = NON-APPLIED    BAD = BAD    CHECKSUM
B                   SCREEN 2 OF 2
C PXXXYZZZ APPL ==>      PXXXYZZZ APPL ==>
  PXXXYZZZ N-A ==>      PXXXYZZZ APPL ==>
  PXXXYZZZ BAD ==>      PXXXYZZZ APPL ==>
  PXXXYZZZ APPL ==>     PXXXYZZZ APPL ==>
  PXXXYZZZ APPL ==>     PXXXYZZZ APPL ==>
  PXXXYZZZ APPL ==>     PXXXYZZZ APPL ==>
  PXXXYZZZ APPL ==>     PXXXYZZZ APPL ==>
  PXXXYZZZ APPL ==>     PXXXYZZZ APPL ==>
  PXXXYZZZ APPL ==>     PXXXYZZZ APPL ==>
D - ENTER A COMMAND AGAINST ONE ZAP-ID, OR PRESS A PF KEY
  A = APPLY  R = RESTORE  M = MODIFY  S = SCAN  E = ERASE
E PF1:CREATE A ZAP  PF2:UPDATE SPARE DISKETTE PF4:SCREEN 1
  message area
  
```

In the above example the diskette contains twenty-nine ZAPs.

- A Meaning of ZAP statuses. See page 2-397 for details about the BAD CHECKSUM status.
- B Indicates the screen on which an entered ZAP is shown.
- C Example of list of ZAPs, each with its identification and its status. Up to sixteen ZAPs can be listed on each screen.
- D The available ZAP functions.
- E PF4 and PF5 are used to go back and forth between screen 1 and 2. PF4:SCREEN 1 highlighted; PF5:SCREEN 2 highlighted.

ZAP FUNCTIONS

ZAP Functions	Selection	See Page
APPLY	A	2-396
RESTORE	R	2-396
MODIFY	M	2-396
SCAN	S	2-397
ERASE	E	2-397
CREATE A ZAP	PF1	2-398
UPDATE SPARE DISKETTE	PF2	2-399

Apply, Restore, and Modify (ZAP)

APPLY (ZAP)

This function allows you to apply a ZAP from the ZAP area to the microcode load modules.

When you apply a ZAP, an ID record is put into the MLT. This MLT record becomes permanent, and if the ZAP is restored the ID record indicates restored status for that ZAP.

After ZAPs are applied to the microcode load modules, the machine must be IMLed to get the changed microcode into the various areas of the machine.

When ZAPs are applied, re-IML MOSS.

Prerequisite ZAPs: These must be applied before the ZAPs for which they are prerequisite (see ZAP history table on page 2-407 for a complete ZAP history of this diskette).

Process: Refer to "ZAP Selection." You entered the command A against the ZAP-ID of the ZAP to be applied. To apply this ZAP, press SEND.

RESTORE (ZAP)

This function removes a ZAP by restoring the original ZAP verify data to the microcode load modules.

If the ZAP you applied does not give the results expected, you have to restore it.

Prerequisite ZAPs: These must be restored (removed) in the reverse order to that in which they were originally applied on page 2-407.

Process: Refer to "ZAP Selection." You entered the command R against the ZAP-ID of the ZAP to be restored. To restore this ZAP, press SEND.

After ZAPs are removed (restored) from the microcode load modules, the machine must be IMLed to get the changed microcode into the various areas of the machine.

MODIFY (ZAP)

Selection

This function allows you to modify a ZAP in the ZAP area.

You can modify only non-applied ZAPs.

You are first requested to enter the identification of the ZAP (12 characters maximum); then the following screen is displayed:

```

A  ZAP PXXXXZZZ      ZAP RECORD: 01
   -FILE NAME      = CHGUCMOD
   -MODULE NAME    = CHGIPL2
   -ADDRESS        = 7FE
   -VERIFY DATA   = D740 .....
   -REPLACE DATA  = FFFF .....

B  -AVAILABLE COMMANDS: A=ALTER, D=DELETE, I=INSERT ==>
   PF2:FILE  PF3:QUIT  PF4:CHANGE ZAP-ID  PF5:NEXT RECORD
                        PREVIOUS RECORD
  
```

A The first ZAP record is displayed. Use the PF5 key to locate the record that you want to modify, or before which you want to insert a new record. When the last ZAP record is displayed, LAST RECORD appears on this line.

B When the ZAP record is located, select a modify command on line B. You may alter, delete, and insert several records in the same ZAP. See this page (right) for detailed commands.

PF2:FILE - Must be used at the completion of any modify command to file (write) the modifications in the ZAP area.

PF3:QUIT - Used to return to ZAP function menu.

PF4
First record: CHANGE ZAP-ID Display the selected ZAP identification. You may modify it

Other records: PREVIOUS RECORD Display previous record.

Once a ZAP has been modified, file it (PF2:FILE). If you quit (PF3:QUIT) or select the Terminate (T) function before filing the ZAP, all the modifications that you entered are lost.

ALTER Command

You can modify any data: file name, module name, address, verify data, and replace data, in the ZAP records.

```

ZAP PXXXXZZZ      ZAP RECORD: XX      ALTER
- FILE NAME      ==> CHGUCMOD
- MODULE NAME    ==> CHGIPL2
- ADDRESS        ==> 7FE
- VERIFY DATA   ==> D740 .....
- REPLACE DATA  ==> FFFF .....

PF1:IGNORE ALTER
  
```

PF1: IGNORE ALTER - Cancels the altered ZAP record and returns to display mode.

DELETE Command

Once you have entered D for delete, the displayed ZAP record to be deleted is erased from the screen and the next ZAP record, if any, is displayed.

To delete an entire ZAP, use an erase function. Also, if all of its ZAP records are deleted, the entire ZAP is deleted.

INSERT Command

To insert a ZAP record in an existing ZAP, follow the procedure you used to enter a ZAP record when creating a ZAP.

```

ZAP PXXXXZZZ      ZAP RECORD: XX      INSERT
- FILE NAME      ==> CHGUCMOD
- MODULE NAME    ==> CHGIPL2
- ADDRESS        ==>
- VERIFY DATA   ==> D740 .....
- REPLACE DATA  ==> FFFF .....

PF1:IGNORE INSERT
  
```

PF1: IGNORE INSERT - Cancels the inserted ZAP record and displays the previous ZAP record.

Scan and Erase ZAP

SCAN (ZAP)

This function allows you to display applied or non-applied (including "bad-checksum") ZAPs from the ZAP area.

Process: Refer to "ZAP Selection." You entered the command S against the ZAP-ID of the ZAP to be displayed.

The following screen appears:

```

ZAP PXXXYZZZ                ZAP RECORD: 02
-FILE NAME   = CHGMDJIB
-MODULE NAME = CHHMCSP
-ADDRESS     = 1608
-VERIFY DATA = 4A04 .....
-REPLACE DATA = 4A84 .....

PF3:QUIT PF4:PREVIOUS RECORD PF5:NEXT RECORD
message area
    
```

PF3:QUIT - Cancels the scan function.

PF4:PREVIOUS RECORD - Displays the previous ZAP record.

PF5:NEXT RECORD - Displays the next ZAP record.

ERASE (ZAP)

This function allows you to erase a ZAP of any status from the ZAP area.

Process: Refer to "ZAP Selection." You entered the command E against the ZAP-ID of the ZAP to be erased.

Depending upon the number of ZAPs entered on the diskette, the screen that appears is as follows:

1. If sixteen (or less) ZAPs are entered on the diskette

```

APPL = APPLIED  N-A = NON-APPLIED  BAD = BAD CHECKSUM
                SCREEN 1 OF 1

PXXXYZZZ APPL ==>      PXXXYZZZ APPL ==>
PXXXYZZZ N-A ==>      PXXXYZZZ APPL ==>
PXXXYZZZ BAD ==>      PXXXYZZZ APPL ==>
PXXXYZZZ APPL ==>E    PXXXYZZZ APPL ==>
PXXXYZZZ APPL ==>      PXXXYZZZ APPL ==>
PXXXYZZZ APPL ==>      PXXXYZZZ APPL ==>
PXXXYZZZ APPL ==>      PXXXYZZZ APPL ==>
PXXXYZZZ APPL ==>      PXXXYZZZ APPL ==>

- ENTER "Y" TO CONFIRM ERASE AND "N" OTHERWISE ==> _
message area
    
```

If you enter Y and press SEND, the selected ZAP is immediately erased from the ZAP area on the diskette, and the number of ZAPs on this screen is decreased by one.

2. Up to sixteen ZAPs on the first screen, if the number of ZAPs entered on the diskette is more than sixteen.

```

APPL = APPLIED  N-A = NON-APPLIED  BAD = BAD CHECKSUM
                SCREEN 1 OF 2

PXXXYZZZ APPL ==>      PXXXYZZZ APPL ==>
PXXXYZZZ N-A ==>      PXXXYZZZ APPL ==>
PXXXYZZZ BAD ==>      PXXXYZZZ APPL ==>
PXXXYZZZ APPL ==>E    PXXXYZZZ APPL ==>
PXXXYZZZ APPL ==>      PXXXYZZZ APPL ==>
PXXXYZZZ APPL ==>      PXXXYZZZ APPL ==>
PXXXYZZZ APPL ==>      PXXXYZZZ APPL ==>
PXXXYZZZ APPL ==>      PXXXYZZZ APPL ==>

- ENTER "Y" TO CONFIRM ERASE AND "N" OTHERWISE ==> _
message area
    
```

If you enter Y and press SEND, the selected ZAP is immediately erased from the ZAP area on the diskette, and the seventeenth ZAP appears at the end of the list.

```

APPL = APPLIED  N-A = NON-APPLIED  BAD = BAD CHECKSUM
                SCREEN 2 OF 2

PXXXYZZZ APPL ==>      PXXXYZZZ APPL ==>
PXXXYZZZ N-A ==>      PXXXYZZZ APPL ==>
PXXXYZZZ BAD ==>      PXXXYZZZ APPL ==>
PXXXYZZZ APPL ==>E    PXXXYZZZ APPL ==>
PXXXYZZZ APPL ==>      PXXXYZZZ APPL ==>
PXXXYZZZ APPL ==>      PXXXYZZZ APPL ==>
PXXXYZZZ APPL ==>      PXXXYZZZ APPL ==>

- ENTER "Y" TO CONFIRM ERASE AND "N" OTHERWISE ==> _
message area
    
```

If you enter Y and press SEND, the selected ZAP is immediately erased from the ZAP area on the diskette, and the number of ZAPs on this screen is decreased by one.

Create a ZAP

SELECTION

This function allows you to create a ZAP in the ZAP area. (See page 2-394 for ZAP area details.)

You are first requested to enter the ZAP identification (see Note); then the following screen is displayed:

```

A ZAP PXXXXZZZ          ZAP RECORD: 01
B - FILE NAME  ==>
B - MODULE NAME ==>
  - ADDRESS    ==>
C - VERIFY DATA==>..... ..
D - REPLACE DATA==>..... ..
E          PF3:QUIT  PF4:CHANGE ZAP-ID
F PF2:FILE PF3:QUIT  PF4:PREVIOUS RECORD
  message area
  
```

A The ZAP identification you entered on the preceding screen.

The number of the ZAP record that you are creating is automatically displayed.

B The file and module names are repeated from the previous ZAP record. You do not have to enter them again if you create a ZAP record on the same file and same module.

C Verify data (hexadecimal). This is used to verify whether data at this location is the data that you want to modify.

D Replace data: new hexadecimal data.

The verify and replace data must have the same number of characters.

The periods (.) on lines C and D indicate where you enter the verify and replace characters.

Blank characters and embedded periods are invalid. To remove the last characters that you may have entered on line C or D, replace them by periods.

E For the first record (01) of the ZAP:

PF3:QUIT - Used to return to ZAP function menu.
PF4:CHANGE ZAP-ID Display the selected ZAP identification. You may modify it.

F For the other records of the ZAP:

PF2:FILE - Must be used at a completion of a create function to file (write) the created ZAP in the ZAP area.

PF3:QUIT - Used to return to ZAP function menu.

PF4:PREVIOUS RECORD Display previous record.

When a ZAP record is created, press SEND. You will be prompted to create another one.

When you have created all the records of a ZAP, you should file it. If you quit (PF3) or select the Terminate (T) function before filing, the ZAP is lost.

FILE ZAP IN ZAP AREA

To file a ZAP, press PF2. You are first requested to enter the ZAP checksum. This checksum is automatically verified.

If it is correct, the previous ZAP screen is displayed with the ZAP FILED message.

If it is not, the following message is displayed:

INPUT CHECKSUM DOES NOT MATCH THE COMPUTED ONE

You may then:

- Try to correct the error:
 - Correct the entered checksum if it is wrong.
 - Press PF1 to check the ZAP and correct the error if any (the checksum is computed with all records including the ZAP identification itself). Verify that all the records, including the last one, have been entered. Remember that, if you have entered parameters or modified data on a screen, you must first press SEND to transmit what you entered, then press the PF key.
- If the error cannot be corrected, press PF2 to file the ZAP with the BAD CHECKSUM status. This ZAP is filed, but is not applicable until you have found the error and corrected it.

Update Spare Diskette

SELECTION

Use this function to update the spare diskette, that is, to copy the same ZAPs that you have in the ZAP area of the original diskette. You are first requested to mount the spare diskette:

- MOUNT SPARE DISKETTE, THEN PRESS SEND

Note: From now on, and until you return to the original diskette, you are not allowed to terminate the function, nor to invoke CCU functions. If you try to do so, one of the following messages is displayed:

ZAP FUNCTION TERMINATION NOT ALLOWED, or
CCU FUNCTION NOT ALLOWED

At this time, the MOSS verifies that the EC level (number and suffix) of the spare diskette matches the original (IML) diskette. A mismatch would cause the following error message to be displayed:

"MOUNTED DISKETTE LEVEL IS DIFFERENT FROM ORIGINAL ONE"

If this occurs, UPDATE is not possible. You should then exit this function by re-installing the original diskette then, either:

- IML the MOSS, or
- Press SEND; then when the "spare" screen appears, press PF2.

If the EC levels match, you can then select any displayed ZAP function except the Create and Modify functions.

Refer to "Function Selection" page 2-395. You pressed PF2: UPDATE SPARE DISKETTE but you did not select any ZAP. The following screen is displayed:

```

A SPARE DISKETTE          nn ZAP(S) QUALIFIED FOR COPY
B                          SCREEN 1 OF 1

PXXXYZZZ APPL ==>        PXXXYZZZ APPL ==>
PXXXYZZZ N-A ==>         PXXXYZZZ APPL ==>
PXXXYZZZ BAD ==>         PXXXYZZZ APPL ==>
PXXXYZZZ APPL ==>        PXXXYZZZ APPL ==>
PXXXYZZZ APPL ==>        PXXXYZZZ APPL ==>
PXXXYZZZ APPL ==>        PXXXYZZZ APPL ==>
PXXXYZZZ APPL ==>        PXXXYZZZ APPL ==>

-ENTER A COMMAND AGAINST ONE ZAP-ID,OR PRESS A PF KEY
A = APPLY  R = RESTORE    S = SCAN   E = ERASE

E PF1:COPY ZAPS PF2:RETURN TO NORMAL DISKETTE
message area
    
```

The functions Apply ZAP, Restore ZAP, Scan ZAP, and Erase ZAP are identical to those described previously.

A "nn" indicates the number of ZAPs present on the normal diskette and missing on the spare one. If line A does not display "nn ZAP(S) QUALIFIED FOR COPY", this means that the spare diskette contains the same ZAPs as the normal diskette. Press PF2 (copy has already been done).

B/E In case the number of ZAPs present on the spare diskette are sixteen or less, line B displays: "SCREEN 1 of 1", and line E displays: "PF1:COPY ZAPS PF2:RETURN TO NORMAL DISKETTE". When the ZAPs present on the spare diskette are more than sixteen, line B displays: "SCREEN 1 OF 2", and line E displays: "PF1:COPY ZAPS PF2:RETURN TO NORMAL DISKETTE PF5:SCREEN 2". For the use of PF5 and PF4 see page 2-395.

COPY ZAPS ON SPARE DISKETTE

You must not create and modify ZAPs on the spare diskette, but only copy them from the original diskette.

When you select the copy function, all ZAPs from the ZAP area of the original diskette, which are not yet present on the spare diskette, are displayed. Enter any character against those that you want to copy.

Only sixteen ZAPs can be displayed on one frame. So, if more than sixteen ZAPs have to be copied from the normal diskette, line B displays: "SCREEN 1 of 2", and line E displays: "PF3:QUIT PF5:SCREEN 2" (see screen below).

The remaining ZAPs will be listed in a second frame. Line B will display: "SCREEN 2 of 2", and line E will display: "PF3:QUIT PF4:SCREEN 2".

If less than sixteen ZAPs have to be copied on the spare diskette, line B will display: "SCREEN 1 of 1", and line E will display: "PF3:QUIT" only.

For use of PF5 and PF4, if necessary, see page 2-395.

```

B ZAPS OF NORMAL DISKETTE NOT PRESENT ON SPARE ONE:
  SCREEN 1 OF 2

PXXXYZZZ APPL ==>        PXXXYZZZ APPL ==>
PXXXYZZZ N-A ==>         PXXXYZZZ APPL ==>
PXXXYZZZ BAD ==>         PXXXYZZZ APPL ==>
PXXXYZZZ APPL ==>        PXXXYZZZ APPL ==>
PXXXYZZZ APPL ==>        PXXXYZZZ APPL ==>
PXXXYZZZ APPL ==>        PXXXYZZZ APPL ==>
PXXXYZZZ APPL ==>        PXXXYZZZ APPL ==>
PXXXYZZZ APPL ==>        PXXXYZZZ APPL ==>
PXXXYZZZ APPL ==>        PXXXYZZZ APPL ==>

- ENTER ANY CHARACTER AGAINST ZAP(S) TO BE COPIED

E PF3:QUIT                PF5:SCREEN 2
message area
    
```

The copied ZAPs will not be automatically applied on the spare diskette. They must be specifically applied.

Before applying ZAPs on the spare diskette, make sure that the microcode modified by the same ZAP on the original diskette is running correctly.

When the spare diskette is updated, select PF2 to the return to original diskette.

The statuses of copied ZAPs are as follows:

- APPL becomes N-A
- N-A remains N-A
- BAD remains BAD

CDF: Select and Create

SELECTION

1. Select the utility programs as explained page 2-390.
2. Enter 5 followed by SEND.

The configuration data file (CDF), located on the diskette, contains the hardware description of the 3725. The 3725 CDF is used by the diagnostics and at 3725 initialization time. You can at any time:

- Create a new CDF to reflect the latest hardware modifications of the 3725
- Verify that the CDF is the exact image of the 3725
- Update and modify the CDF

Note: This function allows you to deactivate an RDV card in the CDF.

The CDF gives information on CCU/MOSS, LAB/CAB, channel adapters, scanners, and LSSD strings.

An additional screen, referred to as CDF information, explains some CDF data that you may have to update.

Once you have selected the CDF, the following screen is displayed:

```
- SELECT CDF OPTION (1, 2, 3) ==>
  1 = CREATE
  2 = VERIFY
  3 = DISPLAY/UPDATE
```

WARNING: CREATE DESTROYS ALL MANUALLY ENTERED DATA
function message line

CREATE

Warning: When you select the CDF create option, all fields are reset. Fields that reflect the machine configuration (hardware) are reinitialized accordingly. Conversely, the fields that have been manually initialized stay DESTROYED, and have to be manually initialized again.

If necessary, the spare diskette, which should be at the same level, might be used to retrieve the lost information.

To create the CDF, the MOSS must be in MOSS alone state. Field c of the MSA displays MOSS-ALONE (see page 2-350 for field c breakdown).

The creation of the CDF is automatic. You are informed of the progression as follows:

```
CDF CREATE STARTED
  CCU INFORMATION FETCHED
  CHANNEL ADAPTER INFORMATION FETCHED
  SCANNER AND TRSS INFORMATION FETCHED
CDF CREATE COMPLETED
```

A CDF CREATE does not initialize the channel adapter addresses (ESCL, ESCH, NSC), but it initializes the line clocking information to the default value (external clock).

To initialize the channel adapter addresses and/or to modify the cable clocking information, the CDF must be updated using the CDF display/update function.

VERIFY

Once the 3725 is installed, you should verify that the CDF reflects exactly the hardware configuration of the 3725.

The VERIFY OPTION does not handle the cable clocking information nor the channel adapter addresses (ESCL, ESCH, NSC).

You may verify the CDF at any other time to check whether the CDF corresponds to the actual 3725.

The verification phase is automatic. Once you have selected VERIFY, the first difference, if any, is displayed. You are requested to modify the diskette to reflect the actual machine configuration. Enter either Y or N, then press SEND. The next difference, if any, is displayed, and so on.

When you reach the end of the verification phase, the message VERIFY COMPLETED is displayed and the CDF, if updated, is automatically filed on the diskette.

```
                CDF - VERIFY OPTION IN PROGRESS
A  SCANNER:                01
A  LIC POS:                04

DIFFERENCE BETWEEN THE MACHINE AND THE DISKETTE:
B  VALUE FROM THE MACHINE:  01
B  VALUE FROM THE DISKETTE:  00
- TO UPDATE DISKETTE WITH MACHINE VALUE ENTER Y ==>
  OTHERWISE ENTER N
```

- A. This information varies according to the various frames displayed and the verified information. In the example given, LAB/CAB screen is presented.
- B. A machine failure may cause different values in "machine" and "diskette" fields. Before updating the diskette, make sure that the difference shown by the verify process is valid.

If during the verification phase, cable and/or channel adapters are modified on the diskette CDF, the corresponding cable information and channel adapter addresses must be manually updated, using the CDF display/update option.

After the preceding screen has been displayed, and if the LIC cables are not updated, the following screen will be displayed line-by-line.

Note: The LIC position is always referenced by the physical location (1 to 8) on the LAB, regardless of the LAB type (see page 4-062).

On the following example the cables on ports 2 and 3 are not present on the diskette but exist on the machine. Their code (4) means that they are modem attached (see page 2-405 for code details).

```
                CDF - VERIFY OPTION IN PROGRESS
A  SCANNER:                01
A  LIC POS:                04
   CABLE ID

DIFFERENCE BETWEEN THE MACHINE AND THE DISKETTE:
B  VALUE FROM THE MACHINE:  0440
B  VALUE FROM THE DISKETTE:  0000
- TO UPDATE DISKETTE WITH MACHINE VALUE ENTER Y ==>
  OTHERWISE ENTER N
```

CDF: Display/Update (Part 1 of 4)

DISPLAY/UPDATE MENU

```

CDF - DISPLAY OPTION
- SELECT ONE DISPLAY OPTION (1 TO 7) ==>

1 = ALL (2 TO 6)
2 = CCU/MOSS
3 = LAB/CAB
4 = CHANNEL ADAPTERS
5 = SCANNER/TRSS
6 = LSSD
7 = CDF INFORMATION

PF3:QUIT
    
```

When selecting display/update, the default is display mode.

To update the CDF press PF1:UPDATE. This is possible only when PF1:UPDATE is displayed. You are informed that you are in update mode by the term UPDATE displayed on the first line of the work area.

The cursor is positioned at the first UPDATABLE character. Use the tab key (-->) to move from one updatable character to another. When all fields have been updated, press SEND to enter the data.

To file the updated CDF on the diskette, press PF5:FILE, when this key is displayed.

If you select the terminate (T) function before filing the updated CDF, the modifications you entered are lost.

Warning:

If the CDF has been changed for maintenance, it is possible that bad board swaps may be made while reloading the box after CDF maintenance. That may require changes in the CDF for rectification. Unpredictable results may occur from changes in the CDF if they affect port swapped lines.

ALL

You select ALL to display all the CDF: CCU/MOSS, LAB/CAB, channel adapters, scanners, and LSSD. To go from this screen to the following one, press PF5:FORWARD.

Once an update has been performed, PF5:FILE is displayed. It is recommended to perform all the updates before pressing this key.

CCU/MOSS

```

CONTROLLER TYPE: 3725      MODEL: 01 (3725 Model 1)
                          02 (3725 Model 2)
CCU STORAGE SIZE: 768 K

MOSS SIZE: 128 K

DISKETTE: DS2D

OPERATOR CONSOLE: 3727

PF1:UPDATE PF3:QUIT PF5:FORWARD
    
```

DISPLAY/UPDATE LAB/CAB (3725/3726)

A	B	C	D	E	F
RDV NBR	BOARD TYPE	RDV ADDR	ADAPTER 1 # ADDR	ADAPTER 2 # ADDR	LIC/LINE, OR TIC L1L2L3L4 L5L6L7L8
*1	CLAB 1	4000	*CS 01 10	*CA 01 08	F F F F F F F F
*2	CLAB 2	4002	CS 03 11	CA 02 08	
*3	LABC 3	4004	*CS 05 12	*RA 06 4A	F 8 F F * *
4	FRDV	4100			
5	LABx 6	410A	CS 11 15	CS 12 25	
6	LABx 5	4108	CS 09 14	CS 10 24	
7	LABx 4	4106	CS 07 13	CS 08 23	
8	LABx 7	410C	CS 13 16	CS 14 26	
9	LABx 8	410E	CS 15 17	CS 16 27	
10	CAB	4006	CA 03 08	CA 04 08	
			CA 05 08	CA 06 08	
PF1:UPDATE		PF3: QUIT			

The * means present.

A Redrive number. If a redrive has been deactivated (jumper on RDV card, pin D11 to ground) and is still recorded as present (*), delete the (*).

Note: The RDV will also have to be in disconnected state to prevent failures on some IOC bus IFTs. For more information on redrive states, refer to page 11-090.

B Board type

x = A, B, or C according to the type of LAB installed

C Redrive address (for board address jumper, see page 4-270)

D and E

Give the number and the address of the channel adapters (CA), communication scanners (CS) and token-ring adapters (TRA).

F LIC/line installed (see CDF information on page 2-405). When TICs are installed, the hexadecimal code is replaced by an asterisk.

The codes in zone F of the screen are interpreted as follows: L1L2L3...L8: LIC position 1 through 8.

F(hexa code):
 Port number 1 2 3 4
 Line status 1 1 1 1
 Legend:

1 means line present
 0 means line absent

8(hexa code):
 Port number 1 2 3 4
 Line status 1 0 0 0

Note: When a LIC is absent, the hexa code (0 through F) is replaced by a point (.).

* means a TIC is present in this position.

Press PF1:UPDATE, and enter an asterisk at the left of the redrive sequence number to indicate that the redrive is present. No asterisk means not present.

DISPLAY/UPDATE C2LB/LAB (3725 MODEL 2)

A	B	C	D	E	F
RDV NBR	BOARD TYPE	RDV ADDR	ADAPTER 1 # ADDR	ADAPTER 2 # ADDR	LIC/LINE, OR TIC L1L2L3L4 L5L6L7L8
*1	C2LB	4000	*CS 01 10	*CA 01 08	F F F F F F F F
				*CA 02 08	
*2	C2LB2	4002	*CS 03 11	*CA 03 08	F 8 4 F 2 2
				*CA 04 08	
*3	LABC3	4004	*CS 05 12	*RA 06 4A	F F F 0 * *
				*CA 02 08	
PF1: UPDATE		PF3: QUIT		PF5: FORWARD	

The * means present.

CDF: Display/Update (Part 2 of 4)

CHANNEL ADAPTERS (3725/3726)

A	B	C	D	E	CHANNEL ADAPTER			
CA #	RDV ADDR	CAB TYPE	TPS		INTERFACE A		INTERFACE B	
					NSC	ESCL	ESCH	NSC
* 1	4000	CLAB	Y		00	00	00	00
* 2	4002	CLAB	Y		00	00	00	00
3	4006	CAB	N		00	00	00	00
4	4006	CAB	N		00	00	00	00
5	4006	CAB	-		00	00	00	00
6	4006	CAB	-		00	00	00	00

PF1:UPDATE PF3:QUIT

The * means present

CHANNEL ADAPTERS (3725 MODEL 2)

A	B	C	D	E	CHANNEL ADAPTER			
CA #	RDV ADDR	BOARD TYPE	TPS		NSC	ESCL	ESCH	
* 1	4000	C2LB	-		00	00	00	
* 2	4000	C2LB	-		00	00	00	
* 3	4002	C2LB2	-		00	00	00	
* 4	4002	C2LB2	-		00	00	00	

PF1:UPDATE PF3:QUIT

The * means present

- A Channel adapter number. The * indicates that the channel adapter is present. You can update this character. To deactivate a CA, delete the *.
- B Redrive address. See line C on the above screen.
- C Board type: C2LB, C2LB2, CLAB1, CLAB2, or CAB.
- D Two processor switch. Y means present, N means not present, and - means not applicable. You can update Y and N but not -. No TPS for the 3725 Model 2.
- E NSC: native subchannel address.

The range of emulated subchannel addresses:

ESCL: emulated subchannel address low (ESC lo)
ESCH: emulated subchannel address high (ESC hi)

For ESC and NSC address jumpering on cards CADR and CHIN, refer to pages 4-281 and 4-282. These addresses have to be entered manually.

SCANNERS/TRAS

Before displaying or updating the scanners, you are requested to enter the scanner number:

- ENTER CSP/TRA NUMBER (0 FOR ALL) ==>
(scanner/TRA number is 1, 3, 5 through 16;
enter 0 for all scanners/TRAs)

Typical scanner/TRA screens are shown below:

3725/3726 Model 1 LABs

A	SCANNER: 01	ADDR: 10	LAB: A	ICC-1: 11					
B	CS: 10	RDV: 4000	FES: 10	ICC-2: 11					
C	LIC POS:	1	2	3	4	5	6	7	8
D	LIC TYPE:	01	01	01	01	01	01	01	01
CLOCK (C) AND CABLE ID INFO (I)									
		C I	C I	C I	C I	C I	C I	C I	C I
E	PORT 1:	2 4	2 4	2 4	2 4	2 4	2 4	2 4	2 4
E	PORT 2:	2 4	2 4	2 4	2 4	2 4	2 4	2 4	2 4
E	PORT 3:	2 4	2 4	2 4	2 4	2 4	2 4	2 4	2 4
E	PORT 4:	2 4	2 4	2 4	2 4	2 4	2 4	2 4	2 4

PF1:UPDATE PF3:QUIT

3725 Model 2 C2LB and C2LB2

A	SCANNER: 01	ADDR: 10	LAB: C2LB	ICC-1: 10					
B	CS: 10	RDV: 4000	FES: 10	ICC-2: 10					
C	LIC POS:	1	2	3	4	5	6		
D	LIC TYPE:	01	01	01	01	01	01		
CLOCK (C) AND CABLE ID INFO (I)									
		C I	C I	C I	C I	C I	C I		
E	PORT 1:	2 4	2 4	2 4	2 4	2 4	2 4		
E	PORT 2:	2 4	2 4	2 4	2 4	2 4	2 4		
E	PORT 3:	2 4	2 4	2 4	2 4	2 4	2 4		
E	PORT 4:	2 4	2 4	2 4	2 4	2 4	2 4		

PF1:UPDATE PF3:QUIT

3725/3726 Model 1 and Model 2 LAB type C

A	TRA: 6	ADDR: 4A	LAB: C						
B	TRA TYP: 10	RDU: 40004							
C	TIC POS:			5	6	7	8		
D	TIC TYPE:			01	01	01	01		

PF1:UPDATE PF3:QUIT PF4:BACKWARD PF5:FORWARD

A Gives the scanner or TRA number, the scanner or TRA address, the LAB type (A, B, or C), the ICC presence, and the ICC type.

SCANNER or TRA number	1	3	5	6	7	8	9	10	11	12	13	14	15	16
SCANNER ADDR:	10	11	12	22	13	23	14	24	15	25	16	26	17	27
TRA ADDR:				4A		4B		4C		4D		4E		4F

B Gives the scanner or TRA presence, the redrive address, the FES and ICC presence, and the ICC type (00 = not present, 10 = present and ICC type 1, 11 = present and ICC type 2)

Any other value indicates a possible error.

C LIC position: 1 to 8 or TIC position 5 to 8.

D LIC or TIC type for each LIC position as follows:

Value	LIC Type
00	(No LIC)
01	1 *
02	2
03	3
04	4A
0C	4B

* There is only one TIC type=01

E Gives the clock and cable information for each port of a LIC, as follows:

Clock

C	Function
0	Not defined clock
1	Business machine clock
2	External clock (default)
3	Direct attachment

Cable Information

I	Function
0	Cable not installed
1	LIC type 1,2,4 wrap block
2	LIC type 3 wrap cable
4	Modem attachment
5	Direct attachment
6	Autocall (See Note 1)

See notes on next page.

CDF Display/Update (Part 3 of 4)

Notes:

1. For autocal units, the clock must be set to 0 (not defined).
2. Place "C" and "I" information in port 1 for the first line attached to a LIC (type 3, direct attachment) even if this line physically connects to another port of the LIC.

PF4:BACKWARD
PF5:FORWARD

This PF key information appears on the screen when it is possible to page backward or forward with the PF keys.

LSSD

For detailed information on level sensitive scan design (LSSD), see page 14-070.

Two sectors of LSSD can be displayed:

1. LSSD skeleton block sector 1: This is the LSSD saved by the MOSS during phase 1b of a controller re-IML when a CCU hardcheck occurs. If several CCU hardchecks occur, the LSSD skeleton kept corresponds to the latest hardcheck. Troubleshooting procedures for CCU hardchecks are provided in MIM Part 2.
2. LSSD init block sector 2: This is the actual CCU value for initializing the CCU.

Before displaying LSSD, you are requested to enter the LSSD block number:

- ENTER LSSD BLOCK NUMBER (0 FOR BOTH) ==>
(enter 1 or 2, or 0 for both)

The following screen is then displayed in hexadecimal format (H):


LSSD SKELETON BLOCK				CDF SECTOR 1		
0	4	8	C	10	14	
00	H.....	H.....	H.....	H.....	H.....	H.....
18	H.....	H.....	H.....	H.....	H.....	H.....
30	H.....	H.....	H.....	H.....	H.....	H.....
48	H.....	H.....	H.....	H.....	H.....	H.....
60	H.....	H.....	H.....	H.....	H.....	H.....
78	H.....	H.....	H.....	H.....	H.....	H.....
90	H.....	H.....	H.....	H.....	H.....	H.....
A8	H.....	H.....	H.....	H.....	H.....	H.....
C0	H.....	H.....	H.....	H.....	H.....	H.....
D8	H.....	H.....	H.....	H.....	H.....	H.....
F0	H.....	H.....	H.....	H.....	H.....	H.....

PF3:QUIT

LSSD strings are displayed in hexadecimal. Every string has a 3-byte header added that indicates:

- N String number
- L String length in bytes
- R Remaining string bits (0 ≤ L < 7)

Strings appear as follows on the console screen. FF is displayed after the last bit of the last string.




LSSD Bit Identification

Register HDCK String Bits		
1 094	0	+Level 1 error reentry
1 069		+MDOR parity error
1 068		+MIOC error latch
4 058		+BSM control error
4 056		+Double-bit error detected
4 057		+Storage address/data parity error
4 059		+POP parity (not used)
C 092		(not used)
C 091		(not used)
C 083		(not used)
C 076		+IOC1 CCW error
C 067		+IOC1 timeout error
C 077		+IOC1 bus in error
C 094		(not used)
C 093		(not used)
C 079		+IOC1 address exception
C 078		+IOC1 storage protect
4 016		+LS parity error
4 015		+ROS parity error
6 101		+A/B bus parity error
6 100		+IOC1 parity error
8 101		+SAR parity error
8 100		+ZR parity error
A 100		(not used)



Register HKNG String Bits (In '7D') Level 1 Interrupts		
4 059		+POP parity error
1 069		+MDOR parity error
1 068		+MIOC error
4 056		+Double-bit error
4 058		+Storage control error
4 057		+Storage addr/data parity error
4 016		+LS parity error
6 101		+A/B bus parity error
6 100		+IOC parity error
8 101		+SAR parity error
4 015		+ROS parity error
8 100		+Z reg parity error
1 094		+Level 1 error reentry
B 067		-ALU compare error X
B 099		-ALU compare error 0
B 131		-ALU compare error 1



CDF: Display/Update (Part 4 of 4)

Register INT1 String Bits Level 1 Interrupts (In X'76', In X'7E')	
C 079	+IOC address exception
C 078	+IOC storage protect
C 076	+IOC CCW error
C 067	+IOC timeout error
C 077	+IOC bus in error
1 034	+MOSS Inop level 1 interrupt request
1 079	+Level 5 I/O check
1 081	+Invalid Op code
A 025	+IOC1 interrupt bit 0.5
2 121	+address compare level 1 int request
4 067	+Prog EX AE
4 068	+Prog EX SP
4 069	+Instruction fetch AE
4 070	+Instruction fetch SP
1 028	+MOSS to CCU status register bit 1

Register INTA String Bits Adapter Level 2, 3 Interrupts (In X'77')	
6 058	+IOC1 interrupt bit 0.1
6 026	+IOC1 interrupt bit 1.0

Register INTC String Bits CCU level 2, 3, 4 Interrupts (In X'7F')	
1 075	+PCI level 2
1 027	+MOSS-to-CCU status register bit 0
1 029	+MOSS-to-CCU status register bit 2
1 030	+MOSS-to-CCU status register bit 3
1 031	+MOSS-to-CCU status register bit 4
1 033	+MOSS-to-CCU status register bit 6
1 077	+PCI level 4
1 078	+timer level 3
1 076	+PCI level 3
1 095	+SVC level 4

A A
 L----- LSSD bit number in string
 ----- LSSD string number

CDF INFORMATION

The following screen, obtained by entering 7 followed by SEND in the CDF menu, is to be used as a HELP for the CDF information:

```

TYPE (CS/FES/ICC-1/ICC-2) ==> 00 : NOT INSTALLED
                               = 10 : INSTALLED
LIC TYPES  CLOCK INFO (C)      CABLE ID INFO(I)
00:NO LIC  0:NOT DEFINED CLOCK  0:CABLE NOT INSTALLED
01:LIC1    1:BUSINESS MACHINE CLOCK 1:LIC1/2/4 WRAP BLOCK
02:LIC2    2:EXTERNAL CLOCK(DEFAULT 2:LIC3 WRAP BLOCK
03:LIC3    FOR INSTALLED CABLE)  4:MODEM ATTACHMENT
04:LIC4A   3:DIRECT ATTACHMENT    5:DIRECT ATTACHMENT
0C:LIC4B                                6:AUTOCALL
                                           7:RPQ8J5080,1,2
-LAB/CAB:LIC/LINE POS.GIVES BINARY PORT POSITION INSIDE
          LIC (A = 1010 LINES ON PORT 1 AND 3)
-UPDATED INFO.IS FILED ONLY AFTER "PF5=FILE" IS PRESSED
          PF3:QUIT
  
```

Note: See pages 13-540 and 13-541 for register bit details about LIC types and clock and cable information for specific LIC types.

MLT

The machine load table (MLT) provides the control program with:

- Customer identification
- 3725 serial number
- A record of the applied and restored ZAPs

The customer identification and machine serial number identify 3725 dumps on the host system.

SELECTION

1. Select the utility programs as explained page 2-390.
2. Enter 6 followed by SEND.

To initialize the MLT, enter the customer identification (any number of alphameric characters or blanks up to the end of the line), and the 3725 serial number (1 to 7 hex characters). These two fields are unprotected, and can be changed at any update if necessary. The MLT function is always in update mode.

To file the MLT once it is initialized or updated, press SEND, then terminate the function.

```

CUSTOMER ID: CONTROLLER
CONTROLLER TYPE: 3725 MODEL: 01 SERIAL NBR: 123
                  OR MODEL: 02
DISKETTE EC: 873051 CONTROL PROGRAM: 0000

PF5:ZAP HISTORY TABLE
    
```

ZAP HISTORY TABLE

If there are applied or restored ZAPs, PF5:ZAP HISTORY TABLE is displayed and ZAP HISTORY TABLE IS EMPTY is erased. Pressing PF5 displays ZAPs as follows:

ZAP HISTORY TABLE (A:APPLIED, R:RESTORED)					
ZAP ID	A/R	MM/DD/YY	ZAP ID	A/R	MM/DD/YY
PXXXYZZZ	R	07/22/82			
PXXXYZZZ	A	07/27/82			
PXXXYZZZ	A	07/27/82			
PXXXYZZZ	A	07/27/82			
PXXXYZZZ	A	07/29/82			
PXXXYZZZ	A	07/29/82			
PXXXYZZZ	A	07/29/82			
PXXXYZZZ	A	07/29/82			

PF4:BACKWARD

Diskette Swap (Part 1 of 3)

SELECTION

1. Select the utility programs as explained page 2-390.
2. Enter 7 followed by SEND.

Use the diskette swap function to:

- Copy all or some of the following files from one diskette to another: MLT, CDF, BER file, GCF, IPL ports, and the control program procedures
- Save selected BERs from the controller diskette to the service diskette BER file
- Purge selected BERs from the service diskette

- SELECT SWAP OPTION (1, 2, 3, 4, 5, 6) ==>

- 1 = CONTROLLER TO CONTROLLER DISKETTE
- 2 = CONTROLLER TO SERVICE DISKETTE
- 3 = SERVICE TO CONTROLLER DISKETTE
- 4 = SERVICE TO SERVICE DISKETTE
- 5 = SAVE BER (CONTROLLER TO SERVICE DISKETTE)
- 6 = PURGE BER (SERVICE TO SAME SERVICE DISKETTE)

If you selected:

1. Controller to controller, you can copy any file displayed (see screen below).
2. Controller to service, you can copy only the MLT, the CDF, and the BER file. No file selection is required. (see Note).
3. Service to controller, you can copy only the MLT and the CDF.
4. Service to service, same possibilities as option 2. (see Note).
5. Save BER, you save the selected BERs on the service diskette BER file. The saved BERs are those with the 'save' flag set using the 'ERROR LOG' function (refer to page 2-172).
6. Purge BER, you purge the selected BERs from the service diskette BER file. The purged BERs are those with the 'purge' flag set with the 'ERROR LOG' function (refer to page 2-172).

The controller-to-service and service-to-controller options require no selection from the operator. Files are copied automatically. The save and purge functions are described on pages 2-409 and 2-410.

Note: When option 2 or 4 above has been selected, a message reminds you that "BERs saved on Service diskette may be erased". You are therefore requested to confirm your selection.

The following screens apply to the CONTROLLER-TO-CONTROLLER option.

- SELECT FILES TO BE COPIED (Y=COPY, N=NO COPY)

```

          MLT ==> N
          CDF ==> N
          BER FILE ==> N
          GCF ==> N
          IPL PORTS ==> N
          CNTRL PGM PROC ==> N
          LDF ==> N
          PORT SWAP FILE ==> N
    
```

Once the files to be copied are selected, you are given the size and the status of each file. The maximum length of each file is given below, in sectors:

- MLT: 1 (when the MLT is selected, only the customer ID and the serial number are copied from one diskette to the other).
- IPL ports: 1
- CDF: 4 (LSSD records are not included because they are not copied)
- GCF: 3
- BER file: 26
- Control program procedures: 78
- LDF: 16
- Port swap file: 4

At this point in the procedure, the status can only be NOT TO BE COPIED, to identify the files that you did not select.

The size is given in sectors.

```

          MLT ==> N    000 NOT TO BE COPIED
          CDF ==> Y    004 COPIED
          BER FILE ==> N 000 NOT TO BE COPIED
          GCF ==> Y    003 COPIED
          IPL PORTS ==> Y 001 COPIED
          CNTRL PGM PROC ==> N 000 NOT TO BE COPIED
          LDF ==> N    000 FILE EMPTY/NOT COPIED
          PORT SWAP FILE ==> N 000 FILE EMPTY/NOT COPIED
    
```

- CHANGE DISKETTE, THEN PRESS SEND

Warning: Once you have been requested to change the diskette, and until you return to the original diskette, you must not terminate the function. If, for any reason, you do not want to continue the function, do the following:

1. Mount the original diskette.
2. Re-IML the MOSS.

When you have mounted the new diskette, press SEND. A screen similar to the following is displayed:

```

          MLT ==> N    000 NOT TO BE COPIED
          CDF ==> Y    004 COPIED
          BER FILE ==> N 000 NOT TO BE COPIED
          GCF ==> Y    003 COPIED
          IPL PORTS ==> Y 001 COPIED
          CNTRL PGM PROC ==> N 000 NOT TO BE COPIED
          LDF ==> N    000 FILE EMPTY/NOT COPIED
          PORT SWAP FILE ==> N 000 FILE EMPTY/NOT COPIED
    
```

The status may be:

- NOT TO BE COPIED, if you did not select the file
- COPIED, when the file is copied
- NOT COPIED with an error statement XXXXX, which gives the reason for not copying the file, such as:
 - READ ERROR
 - WRITE ERROR
 - FILE EMPTY

If the swap is successfully completed, you are requested to mount the original diskette:

- MOUNT ORIGINAL DISKETTE, THEN PRESS SEND

Note: The original diskette is the diskette that was mounted during the MOSS IML.

Diskette Swap (Part 2 of 3)

SAVE BER

The following screens apply to the SAVE BER option.

```

- DID YOU SELECT BER(S) WITH FLAG 'SAVE' (Y OR N) ==>

SAVE IS STARTED
    
```

If 'N' is selected, the new screen is:

```

- USE ERROR LOG DISPLAY TO SELECT BER(S)

SAVE COMPLETED
    
```

If 'Y' is selected, the new screen is either:

```

- NO BERS FLAGGED
- USE ERROR LOG DISPLAY TO SELECT BER(S)

SAVE COMPLETED
    
```

When no BERS are found with the 'SAVE', flag ON, or:

```

- XXX BERS TO BE SAVED

MOUNT SERVICE DISKETTE, THEN PRESS SEND
    
```

when XXX BERS are found with the 'SAVE' flag ON.

Once the service diskette has been mounted, press SEND.

If the 'SAVE' on the service diskette was successful, the following screen is displayed:

```

CONTROLLER                SERVICE
- XXX BERS TO BE SAVED    - XXX BERS SAVED

MOUNT ORIGINAL CONTROLLER DISKETTE, THEN PRESS SEND
    
```

If the BER file on the service diskette is found full, the following screen is displayed:

```

CONTROLLER                SERVICE
- XXX BERS TO BE SAVED    - YYY BERS SAVED

BER FILE IS FULL
- DO YOU WANT TO PURGE THE BER FILE (Y OR N) ==>
    
```

If 'N' is selected, a screen similar to the one at the top of this column is displayed again.

If 'Y' is selected, a caution message is added to the above screen, as follows:

```

CONTROLLER                SERVICE
- XXX BERS TO BE SAVED    - YYY BERS SAVED

BER FILE IS FULL
- DO YOU WANT TO PURGE THE BER FILE (Y OR N) ==>

      *** CAUTION ***
      YOU SELECTED THE PURGE OF THE WHOLE BER FILE

- TO CONFIRM SELECTION ENTER Y, OTHERWISE ENTER N ==>
    
```

If 'N' is entered, a screen similar to the one at the top of this column is displayed.

If 'Y' is entered, the BER file is purged and the BERS to be saved are written in this file. A screen similar to the one at the top of this column is then displayed.

Once you have mounted the original controller diskette, press SEND. A screen similar to the following one is displayed:

```

CONTROLLER                SERVICE
- XXX BERS TO BE SAVED    - XXX BERS SAVED
- XXX BERS FLAGGED 'SAVED'

SAVE COMPLETED
    
```

The SAVE operation is complete and the BERS to be saved are flagged 'SAVED'.

Diskette Swap (Part 3 of 3)

PURGE BER

If 'Y' is selected, the new screen is either:

- NO BERS FLAGGED
- USE ERROR LOG DISPLAY TO SELECT BERS(S)

PURGE COMPLETED

When no BERS are found with flag 'PURGE', or:

- SERVICE
- XXX BERS TO BE PURGED

- TO CONFIRM SELECTION ENTER Y, OTHERWISE ENTER N ==>

when XXX BERS are found with flag 'PURGE'.

If you enter 'N', the following screen is displayed:

- SERVICE
- XXX BERS TO BE PURGED
- 000 BERS PURGED

PURGE COMPLETED

If you enter 'Y', the following screen is displayed:

- SERVICE
- XXX BERS TO BE PURGED
- XXX BERS PURGED

PURGE COMPLETED

MOSS, Scanner, and TRSS Dumps

MOSS DUMP

A MOSS dump is the contents of MOSS microcode storage (see MOSS storage layout in Chapter 14) transferred to the diskette buffer area. With the use of System Support Program (SSP) facilities, the common buffer area CHGDMP of the controller diskette may be transferred to the host for printing. Using a Maintenance Device 2 (MD) and acoustic coupler, it can be transmitted from the controller diskette to plant engineering.

A MOSS dump may be started automatically or manually.

Automatic MOSS Dump

The automatic MOSS dump is started when MOSS abends taking a MOSS level 0 interrupt. A MOSS re-IML occurs after this dump. An alert A1 or A2 is then sent to the host. An alert A1 is sent by NCP to the host if the MOSS cannot successfully re-IML before a re-IML retry threshold is reached. An alert A2 is sent by the MOSS to the host if the MOSS is successfully IMLed. If another MOSS automatic dump is attempted before a previous dump is either transferred to the host or manually deleted, the previous dump remains protected and the following one is lost. This previous dump may have been taken manually or automatically.

Manual MOSS Dump

The MOSS must be set offline. Failure to do so results in a 3725 system abend.

The manual MOSS dump is started by placing the Function Select switch in the MOSS Dump position and pressing the Function Start switch on the control panel. Successful completion of the manual dump is indicated by the hex display D00. MOSS should then be manually re-IMLed using the control panel function MOSS IML. The manual MOSS dump always overlays any previous dump on the diskette.

You can perform this procedure while NCP is loaded and active without affecting NCP operation.

Performing a MOSS dump automatically places MOSS offline. To bring MOSS online after the dump is completed, use CCU FNCTN 5 (system control) and system control function 11.

SCANNER DUMP

A scanner dump is the contents of one scanner microcode storage transferred to the diskette buffer area. With the use of System Support Program (SSP) facilities the dump buffer area of the controller diskette may be transferred to the host for printing. Using a Maintenance Device 2 (MD) and acoustic coupler it can be transmitted from the diskette to plant engineering.

The scanner dump is put on the controller diskette. Field 'N' of the machine status area (MSA) on the 3727 screen will display 'DUMP' while a scanner dump is in progress.

A scanner dump may be started automatically or manually.

Automatic Scanner Dump

The automatic scanner dump is started whenever a condition exists that generates an alarm 12 or 14. Command reject by the scanner causes an alarm 14. A scanner AIO error, scanner adapter error, or scanner hardstop causes an alarm 12. (See page 2-200). The scanner must be manually re-IMLed and the 3725 Problem Determination and Extended Services, Vol. A06, gives the procedure under the alarm 12 and 14. If another scanner dump is attempted by this automatic method before a previous dump is either transferred to the host or manually deleted, the previous dump remains protected and the following one is lost. This previous dump may have been taken manually or automatically. Automatic scanner dump can also be started at NCP request by a specific command (F2). (Contact your Programming Service Representative.)

Manual Scanner Dump

The manual scanner dump may be started on the controller. A scanner dump is disruptive to the scanner and its link. On the controller diskette enter 'M' for the maintenance screen then 'S' for TSS functions. Select the desired scanner using function 1, then dump that scanner using function 2. The scanner must be re-IMLed using the TSS functions or IPL CCU/TSS functions.

If a scanner dump is attempted by the manual method before a previous dump is either transferred to the host or manually cleared (deleted), a message is displayed that the scanner dump file is not empty. If you respond with a 'C' to this message, the previous dump is cleared and the following dump is taken. The previous scanner dump may also be manually deleted (cleared) using the utility program function 1 (dump display/delete). The first screen in this function defines PF3 as the delete function (page 2-391). The next screen displayed after you press PF3 allows you to enter the file name to be deleted, and displays the choices available. Enter the file name desired, then press SEND.

TRSS TIC DUMP

A TIC dump is the contents of one token-ring interface coupler card (TIC card) storage, status and registers, transferred to the diskette buffer area. With the use of system support program (SSP) facilities, the dump buffer area of the controller diskette may be transferred to the host for printing. Using the Maintenance Device 2 (MD-2) and acoustic coupler, it can be transferred from the diskette to plant engineering. The TIC dump is put into the buffer area for TRSS dump (CHGTRSS) on the controller diskette, which is used only by the TRSS.

A TIC dump may be started manually or automatically. A dump for each of TIC 1 to 4, regardless of the TRA number, may be taken and stored in the TRSS dump file CHGTRSS.

The CHGTRSS dump file is only transferred to the host if the control program is NCP V4R2.

MANUAL TIC DUMP

The manual TIC dump can be started on the controller diskette. Only a manual TIC dump is disruptive to the TRA on which it is installed. The TRA must be disconnected. With the controller diskette loaded, enter 'M' for the maintenance screen, then 'R' for TRSS functions. Select the desired TRA using function 1, disconnect the TRA using function 2, then dump the TIC using function 6; when the dump is taken, reconnect the TRA using function 2. Then all TICs must be reactivated from the host.

If TIC dump is attempted before a previous dump is either transferred to the host or manually cleared (deleted), a message is displayed that the TIC dump file is not empty. If you respond with a 'C' to this message, the previous dump is cleared and the following dump is taken. The previous TIC dump may also be manually deleted (cleared) using the utility program function 1 (dump display/delete). The first screen in this function defines PF3 as the delete function (page 2-391). The next screen displayed after you press PF3 allows you to enter the file name to be deleted, and displays the choices available. Enter the file name desired, then press SEND.

AUTOMATIC TIC DUMP

The automatic TIC dump is started whenever a condition exists that generates an alarm A29. Any unrecoverable TIC error that brings the TIC down causes this alarm. The TIC must be reactivated from the host. If another TIC dump is attempted manually or automatically before a previous dump is either transferred to the host or manually cleared (deleted), a message is displayed that the TIC dump file is not empty. If you respond with a 'C' to this message, the previous dump is cleared and the following dump is taken. The previous TIC dump may also be manually deleted (cleared) using the utility program function 1 (dump display/delete). The first screen in this function defines PF3 as the delete function (page 2-391). The next screen displayed after you press PF3 allows you to enter the file name to be deleted, and displays the choices available. Enter the file name desired, then press SEND. Then, enter the number corresponding to the TIC to be deleted.

The 3725 files that can be transferred are:

- MOSS dump or scanner dump
- Configuration data file (CDF)
- ZAP
- Machine load table (MLT)
- Graphic configuration file (GCF)
- BER file
- Cataloged control program procedures
- TIC dump

Refer to page 14-081 for file mapping on both controller and service diskettes.

The last three files above are described in the 3725 Problem Determination and Extended Services, Vol. A06.

To print the 3725 files listed above, you must transfer them to the host.

The controller diskette holds up to 4 TIC dumps and either a MOSS dump or a scanner dump.

The TIC dump file, CHGTRSS, is only transferred if the control program is NCP V4R2.

Once a dump is taken to the diskette buffer area for dump, there are two ways to transfer dump files from this diskette. They may be transferred to the host for printing, or they may be transferred directly to your support function from the diskette using a maintenance device (MD).

TRANSFERRING DUMP FILES TO THE HOST

A dump can be transferred to the host from the controller diskette only.

Functions at the host are used to transfer the dump files from the controller diskette into the host and also to print them. These host functions are described in Advanced Communications Functions for Network Control Program and System Support Programs for the 3725 Diagnosis Guide, SC30-3181.

When a scanner or MOSS dump is transferred to the host, it is deleted automatically from the dump buffer of the diskette. The diskette is then ready to receive another scanner or MOSS dump if necessary.

The TRSS dump file, which can hold up to 4 TIC dumps, is also deleted automatically after the transfer to the host.

TRANSFERRING OTHER 3725 FILES TO THE HOST

The file transfer procedure is described in Advanced Communication Functions for Network Control Program and System Support Programs for the 3725 Diagnosis Guide, SC30-3181.

TRANSFERRING DUMP FILES USING A MAINTENANCE DEVICE

You may have to transmit a dump file using an MD to:

- A dial-up port on a VM system (see page 2-451).
- Another MD at the support function (see page 2-451).

When a dump is transferred using the MD, it has to be manually deleted from the dump buffer of the diskette. To delete manually a dump from the diskette, use the MOSS utility program function 1 (Dump Display/Delete). The first screen in this function defines PF3 as the delete function (page 2-391). The next screen displayed after you press PF3 allows you to enter the file name to be deleted, and displays the choices available. Enter the file name desired and press SEND. This manual deletion procedure may be used at any time and deletes whichever file is entered, regardless of any other factors. Be careful not to delete a file that may be needed and has not been saved.

RECEIVING FILES USING A MAINTENANCE DEVICE

You may have to receive a patch or ZAP file on a MD from:

- A data base through a dial-up port (see page 2-452).
- Another MD at the support function (see page 2-458).

COPYING A DISKETTE USING TWO MAINTENANCE DEVICES

In an emergency, you may copy a diskette from a MD to another MD (see page 2-459).

Transferring a File: MD to VM and/or MD to MD

MD TO VM FILE TRANSFER

This procedure is used when transferring files to your support function. This will be done only at the request of the support function.

1. Load MD utility diskette into the MD, then IPL reset

	<u>MD Messages</u>	<u>Action/Response</u>
2.	"MAINTENANCE DEVICE MAINTENANCE AND APPLICATION DISKETTE"	FWD
3	"DO YOU WANT TO REPAIR/TEST THIS MD?"	NO
4.	"DO YOU WANT TO RUN THE MD EDUCATION MODULE?"	NO
5.	"SELECT ACTIVITY 1 = MAP EXERCISE 2 = APPLICATIONS 3 = END"	2 ENTER
6.	"SELECT UTILITY TYPE 1. DISPLAY 2. REMOTE 3. DISKETTE"	2 ENTER
7.	"1. REMOTE PROCESSOR 2. DUMP XMIT PROGRAM 3. PRINT DISKETTE 4. BSYNCRFT TEST"	3 ENTER
8.	"ARE YOU CONNECTING TO A VM/370 SYSTEM?"	YES
9.	"SELECT PRINT FORMAT: 1 = 16 BYTE HEX/CHAR 2 = 32 BYTE HEX"	1 ENTER
10.	"xxxxxx = MD NODE ID xxxxxxxx = DEST xxxxxxxxxxxxxxxxxxxx IS THIS VALID?"	NO
11.	"ENTER NODE ID (8MAX) EG: DPCXSUPP"	Enter the data given to you by your support function.
12.	"ENTER- USERID -OR- LOCID/USERID EG: DPCXDUMP"	Enter the data given to you by your support function.
13.	"XXXXXX = MD NODE ID xxxxxxxx = DEST xxxxxxxxxxxxxxxxxxxx IS THIS VALID?"	Check with the data you were given. YES or NO
14.	"*** DSKT DUMP PRG PASS WORD ="	No password required. ENTER
15.	"** ARE YOU ATTACHING TO A MODEM?"	YES
16.	"** DOES YOUR MODEM REQUIRE BUSINESS MACHINE CLOCKING?"	YES
17.	"** PLUG THE MD'S EIA CABLE INTO THE MODEM"	No keyboard action required.
18.	"** WHEN THE DATA CONNECTION IS COMPLETED.. PRESS ENTER TO CONTINUE."	Dial the phone number you were given. ENTER
19.	"**DSKT DUMP PROGRAM .. WAITING FOR SYSTEM"	No action needed
20.	"DO YOU WISH TO CHANGE DISKETTE?"	YES

21.	"INSERT NEW DUMP DISKETTE . . ."	Put 3725 diskette into the MD.
22.	"**SIGNON COMPLETE . . ENTER EXTENTS EXAMPLE = 01010101"	Enter the 8 digit extents given to you by your support function. ENTER
23.	"**DSKT DUMP PROGRAM SENDING ID CARD (PF - ABORT)"	No action required.
24.	"**DSKT DUMP PROGRAM SENDING DUMP DATA (PF - ABORT) SECTOR = XXXX"	No action required.
25.	"**DSKE DUMP PROGRAM ..DUMP COMPLETE ANY MORE TO SEND? (PF = RESTART)-"	Transfer of data complete.

MD TO MD FILE TRANSFER

This procedure is used when transferring files to your support function. This will be done only at the request of the support function.

1. Load MD utility diskette into the MD.

	<u>MD Messages</u>	<u>Action/Response</u>
2.	"MAINTENANCE DEVICE MAINTENANCE AND APPLICATION DISKETTE"	FWD
3	"DO YOU WANT TO REPAIR/TEST THIS MD?"	NO
4.	"DO YOU WANT TO RUN THE MD EDUCATION MODULE?"	NO
5.	" SELECT ACTIVITY 1 = MAP EXERCISE 2 = APPLICATIONS 3 = END"	2 ENTER
6.	"SELECT UTILITY TYPE 1. DISPLAY 2. REMOTE 3. DISKETTE"	3 ENTER
7.	"1. DISPLAY ALTER 2. COPY DISKETTE 3. DISK ANALYSIS 4. HEAD ALIGNMENT"	2 ENTER
8.	"ARE YOU USING TWP MD'S?"	YES
9.	"ARE YOU USING EITHER AN ACOUSTIC COUPLER OR A MODEM?"	YES
10.	"IS BUSINESS MACHINE CLOCKING REQUIRED?"	YES
11.	"SELECT CLOCK SPEED. 1. 600 BPS OR 2. 1200 BPS"	2 ENTER
12.	"IF USING FE UPAC OR EPAC SET THE MODE SWITCH TO 0 -1200 NO EIA CLOCK"	Set switch then, ENTER
13.	"ARE YOU THE SENDER?"	YES
14.	"DO YOU WISH TO CHANGE DISKETTE?"	YES
15.	"INSERT NEW DISKETTE."	Put 3725 diskette

16.	"ENTER DISK TYPE 1. DISKETTE 1 33FD 2. DISKETTE 2 43FD 3. DISKETTE 2D 53FD"	3 ENTER
17.	"CONNECT EIA CABLE TO COUPLER OR MODEM AND DIAL UP OTHER MD. FWD WHEN DONE."	Dial number given to you by the support function. FWD
18.	"DO YOU WANT TO COPY THE ENTIRE DISKETTE?"	NO
19.	"ENTER DISK EXTENTS IN HEX: EXAMPLE 0101 0C01"	Enter the 8 digit extents given to you by the support function. ENTER
20.	"MAKE RECEIVING MD READY TO RECEIVE. PRESS FWD."	Place handset in coupler then FWD
21.	"OPENING EIA PORT"	No action required.
22.	"SENDING DATA FOR EXTENTS xxxxx---x"	No action required.
23.	"DISKETTE COPIED DO YOU WANT TO COPY ANOTHER DISKETTE?"	YES -if you have more to copy, NO -to end operation.
24	"DO YOU WANT TO CHANGE DISKETTE?"	NO
25.	Go back to step 16.	

Receiving a File: Data Base to MD (Part 1 of 6)

3725 DISKETTE LABEL FORMAT AND DEFINITIONS

MACH: 3725	MOD: ALL	SER: Fnnn	DATE: YYMMDD
BM: 1733981	EC: nnnnnn	REA:	
GID: RAnnnnnn			
COMMENTS:	A23	MM DD YY	HH:MM
CONTROLLER DISKETTE		Lnnn - Lnnn	nnnn

Description of fields

MACH: Machine type

MOD: Machine Model this diskette can be used on.

SER: Serial number this diskette was written for, (in the case of 3725's all diskettes except RPQ diskettes will be zero's.)

DATE: The date the EC was released to manufacturing.

BM: B/M number for this diskette.

EC: The engineering change number of this diskette.

REA: If the diskette is released by an REA rather than an EC, this field will contain the REA number.

GID: The GID number is always RAnnnnnn on 3725 diskettes.

COMMENTS: A23 ID of diskette writer.

CONTROLLER DISKETTE: Define the function of this diskette.

Lnnn-Lnnn: Indicates the first and last patches in the ZAP area of this diskette.

DATE AND TIME WRITTEN: MM DD YY HH:MM

nnnn = MFG. SEQ. NO.

MICROCODE PATCH STRATEGY

The microcode patch strategy has been changed because manufacturing now uses a microcode image format process (MIF) which allows them to ship current level microcode. With the new MIF process, controller diskettes are within two or three patches (normally) of being current. This applies to new machines, EC's, MES's and diskettes from parts.

WHEN TO PATCH

Always patch to the highest level when the symptom of the customer's problem fits the description. It is not necessary to pull patches for new machines or EC's unless there is an excessive delay between the time you received the machine or EC and the time it takes you to install it; however, patches on the diskette you receive must be applied.

The other important time to patch is when there is a co-requisite patch released against an existing patch on your system. To keep you informed of these conditions, there is a tip maintained in RETAIN for each level of microcode. This RETAIN can be found by entering the SAS keyword P:3725UCODE.

MICROCODE DOWNLOAD PROCEDURE

This procedure is used to transmit microcode patches (ZAPS) from a data base to the Maintenance Device (MD) and has been updated to include the following:

- Boulder phone number change.
- New MD diskette.
- New Boulder messages.
- Corrections to known problems.

Definitions of the terms used in this section are as follows:

- Normal diskette: The diskette normally used to operate the machine.
- Spare diskette: The diskette used when receiving patches from the data base, and also used as a backup.
- Accumulator diskette: A diskette used to pull and accumulate patches from the data base. Use of this diskette is optional, as it is intended to be used for applying patches to more than one machine.
- Sequence number: A number written on the spare diskette when pulling patches from the data base. This number is also written by Manufacturing on diskettes obtained from Raleigh.
- Boundary: Used to define the beginning and end of the ZAP area on the diskette. The maximum number of ZAPS this area can hold is 32.
- ZAP: The term "ZAP" is used interchangeably with "Patch".
- Data base: In the United States, this is the Boulder RETAIN system.

If an accumulator diskette is always used to pull patches and the spare and normal diskettes are updated by copying from the accumulator, the spare and normal diskettes cannot be used to pull patches from the data base.

Patches should always be pulled and applied sequentially. Patches should not be removed (restored) once applied, unless instructed to do so by Engineering or the field support center.

Receiving a File: Data Base to MD (Part 2 of 6)

3725 DISKETTE REQUIREMENTS

The service procedure for this machine requires two controller diskettes and two service diskettes. A total of four diskettes ship with each machine. (Engineering changes to diskettes will contain two diskettes).

The spare controller diskette is used to pull patches from the data base. The spare diskettes are also the backup diskettes in the event the normal diskettes are damaged.

The normal controller diskette is used when running under customer operation. Updating of the normal diskette is accomplished by copying from the spare diskette to the normal diskette.

The normal and spare service diskettes are used by service personnel for diagnostic purposes and are used in the same manner as the controller diskette.

MD DISKETTE REQUIREMENTS

MD diagnostic diskette P/N8309864 at ECA33591E should be used when pulling patches from the data base. (This replaces MD diagnostic diskette P/N8547642 at EC339660E)

If the new diskette is not available, P/N8547642 at EC339660E can be used after applying MD diskette patches (using the Boulder system). There are several communication errors that are fixed by the patches.

To receive patches for the MD diagnostic diskette, hook up the MD per the 3725 ZAP update instructions and enter the P/N of the MD diskette to be updated.

Note: When the MD asks you to insert the diskette to be updated, open and close the diskette door on the MD. Unlike the 3725, the patches for the MD diskette will be applied directly to the diskette. Once hooked up, you should pull all patches (sequences), available.

SEQUENCE NUMBERS

A key point is that when pulling patches from the data base, the sequence number is updated on the diskette receiving the patches, (the spare diskette or the accumulator diskette).

When copying from the spare to the normal diskette, the sequence number is not copied. Since the data base always looks at the sequence number to determine the next sequence number to be transmitted, the same diskette must always be used to pull patches from the data base.

DISKETTE BOUNDARIES

The patch (ZAP) area on a diskette has fixed boundaries. When the number of patches exceeds the boundary of the ZAP area, you will have to apply, and erase the patches from the spare diskette to continue pulling patches.

The exception to this is when the boundary of a diskette is reached when connected to the data base and you receive a message which states "STOP-WARNING-STOP APPLY AND ERASE ALL PATCHES". When this occurs, you will be given the option to apply and erase the patches or to insert another diskette and continue to receive patches. This will be explained further in the step-by-step procedure.

The boundaries on diskettes at EC873052 and above are as follows:

First diskette	00 thru 1F
Second diskette	20 thru 3F
Third diskette	40 thru 5F

Note: A patch may require more than one address, so normally there will not be 32 patches before the end boundary is reached. Do not apply patches to the spare diskette until the boundary of the diskette has been reached otherwise the directory in the MLT may be adversely affected.

Receiving a File: Data Base to MD (Part 3 of 6)

TOOLS REQUIRED

Spare 3725 controller diskette
Maintenance Device II
MD diagnostic diskette, P/N 83098640 at EC A33591E E/UPAC
(acoustical coupler), or Portable Modem P/N 8309870.

Note: Problems have been experienced using the portable modem P/N8309870 on "digital" telephone systems. THE MODEM MAY BE DAMAGED. Verify that your telephone system is not a digital system before connecting the modem.

DATA BASE TELEPHONE NUMBERS

US

WATS LINE 1-800-525-7993
TIE LINE 8-347-2107
INSIDE COLORADO 1-303-441-2107

EMEA-AFE

Refer to your support function.

TIME RECORDING

All times associated with pulling and applying microcode patches should be written Service Code 33 ECA 999. The estimated time required to pull an apply patches is 1.5 hours.

TROUBLE REPORTING

All problems with this utility should be reported to the 3725 FSC. You should verify your UPAC, MD, and Phone Equipment before calling.

This procedure is used to receive a microcode ZAP from a data base to the maintenance device (MD).

STEP-BY-STEP PROCEDURE

The following procedures will allow authorized users to receive the latest microcode ZAPs (patches) via the MD (Maintenance Device). This utility will only provide ZAPs that pertain to the EC level of the controller diskette that you are using. It will not cross EC levels or suffix ECs. In other words, if you are running on a down-level diskette and want the latest ZAPs, you will have to upgrade to the latest EC level microcode.

After you have established communications with the data base system, the system will ask for the ZAP level if it is the first time (transmission) for this diskette. You will have to tell what level you are. As long as you use the same diskette, the system will write a sequence number on your diskette and update you automatically to the latest ZAPs available for that EC level. The ZAPs are transmitted to the ZAP data file on the diskette and are not yet applied.

When using the procedures, remember, the column on the left is what the MD is displaying, and the column on the right is the response or action you need to perform.

	<u>MD Message/Display</u>	<u>Action/Response</u>
1.	Blank	Load MD diagnostic diskette into the MD and press IPL RESET.
2.	"MD MAINTENANCE DISK PN: XXXXXXXX REL: X SEQUENCE NO: XX "DATE XX/XX (ENTER)"	Press ENTER.
3.	"DO YOU WANT TO REPAIR/TEST THIS MD?"	Press NO.
4.	"DO YOU WANT TO RUN THE MD EDUCATION MODULE?"	Press NO.
5.	"SELECT ACTIVITY 1 = MAP EXERCISE 2 = APPLICATIONS 3 = END"	Press NO.

Receiving a File: Data Base to MD (Part 4 of 6)

MD Message/Display	Action/Response
8. Either the step 10 message will be displayed. Go to the appropriate step.	
9. "SERIAL # = XXXXXX BRANCH # = XXX IS THIS CORRECT" ^L	If you press YES, go to step 12, or else press NO.
10. "ENTER YOUR SERIAL # NNNNNN"	Type in your serial number and press ENTER.
11. "ENTER YOUR BRANCH # BBB" -	Type in your branch number, press ENTER and go to Step 9.
12. "ENTER SECURITY CODE SSS" -	Type in your security code and press ENTER.
13. "DO YOU WANT THE MD TO PROVIDE CLOCKING" -	Press YES.
14. "SET MODE SWITCH ON E/UPAC TO: 0-1200 NO EIA CLOCK (ENTER)"	If using a UPAC, set MODE to 0-1200 (NO EIA CLOCK) and press ENTER. If using a PORTABLE MODEM, switch AUTO ANSWER to OFF and press ENTER.
15. "INSERT DISKETTE TO BE UPDATED ..."	Load the Accumulator (or spare) 3725 controller diskette you want to pull patches to.
16. "DO YOU WANT TO RETRIEVE A FIRST LEVEL RELEASE "	If you want to start pulling patches at one sequence number higher than the highest number in the patch area of the loaded diskette, press NO. If you want to start at sequence number 0 (has the effect of erasing the existing patch area), press YES and go to step 37.
17. "CURRENT DISKETTE IS: PN=XXXXXXXX SEQ=XX IS THIS CORRECT "	The EC to PN translation is explained in step 39. If correct, press YES, or else press NO and go to step 15.
18. If this is NOT your first pass through these instructions AND the communication link was NOT terminated, go to step 24.	
19. "CONNECT EIA CABLE TO E/UPAC FROM MD'S DTE CONNECTION. (ENTER)"	Naturally, if you are using a portable modem, connect the EIA cable between it and the MD's DTE connector. Press ENTER.
20. "DIAL DISTRIBUTION SYSTEM. AT SOUND OF TONE PLACE PHONE IN E/UPAC. (ENTER)"	Dial either 1-800-525-7993 or 1-303-924-2107. When you hear the tone you will have 10 seconds to do one of the following: If you are using a UPAC, place the handset in the UPAC, attach the cover and press ENTER. If you are using a PORTABLE MODEM, press ENTER and hang up the telephone.
21. "OPENING EIA PORT RESET=ABORT"	No action is required.
22. "SIGN-ON IN PROGRESS RESET=ABORT"	No action is required.

Notes:

1. Messages indicating communication errors are normally caused by poor connections. If this message is still being displayed after one minute, restart the procedure from the beginning.
2. When any message starting with "I/E DSTXXX" is on the display, the ENTER key must be pressed. XXX represents the message number.

Receiving a File: Data Base to MD (Part 5 of 6)

- | | | | | | |
|-----|--|--|-----|--|---|
| 23. | <p>"I DST001 IBM CORP.
PT-2 PROGRAM
DISTRIBUTION SYSTEM
- LINE=XXX"</p> | No action is required. | 36. | <p>"RETRIEVING:
PN=XXXXXXXX SEQ=XX

RESET=ABORT - "</p> | Swap diskettes now and go to step 25. |
| 24. | <p>"VERIFYING PART
NUMBER AVAILABILITY.

RESET=ABORT"</p> | No action is required. | 37. | <p>"==== WARNING ====
RETRIEVING THE FIRST
LEVEL RELEASE WILL
WRITE OVER THE ..."</p> | Press ENTER. |
| 25. | <p>"RETRIEVING:
PN=XXXXXXXX SEQ=XX

RESET=ABORT"</p> | If the step 26 message does not follow this one, go to step 40. | 38. | <p>"CONTENTS OF DISK.
ENTER TO CONTINUE
RESET TO ABORT - "</p> | Press ENTER. |
| 26. | <p>"PN=XXXXXXXX SEQ=XX
CYL XX SEC XX
COUNT REMAINING XXXX
RESET=ABORT"</p> | <p>No action is required.
This message will be refreshed as
the COUNT REMAINING field decrements
to 0000.</p> | 39. | <p>"ENTER THE PN TO
BE RETRIEVED
PPPPPPPP"
-</p> | <p>Type in a 0, then the six numerals
in the EC level, followed by a
numeral from below corresponding
to the suffix.</p> <p>no suffix=0 J=5
E=1 K=6
F=2 L=7
G=3 M=8
H=4 N=9</p> <p>For example: EC873053E would be
entered as 08730531.</p> |
| 27. | Either the step 28 or the step 30 message will be displayed.
Go to the appropriate step. | | 40. | <p>"PN=XXXXXXXX SEQ=XX
NOT IN LIBRARY.
WANT TO RETRIEVE
ANOTHER PN^L - "</p> | If you press YES, go to step 15,
or else press NO. |
| 28. | <p>"PN=XXXXXXXX SEQ=XX
TRANSFER COMPLETE.
DO YOU WANT TO GET
THE NEXT SEQ^L"</p> | If you press YES, go to step 25,
or else press NO. | 41. | <p>"SENDING:
SIGNOFF REQUEST - "</p> | No action is required. |
| 29. | <p>"DO YOU WANT TO
RETRIEVE ANOTHER PN^L"</p> | If you press YES, go to step 15,
or else press NO and go to step
41. | 42. | <p>"SESSION TERMINATED.
REMOVE PHONE FROM
E/UPAC.

(ENTER)"</p> | You should have successfully
pulled all of the desired patches.
If you have not, press ENTER and
return to step 9. |
| 30. | <p>"*****
* MESSAGE RECEIVED *

(ENTER)"</p> | Press ENTER. | | | |
| 31. | <p>"STOP-WARNING-STOP
APPLY AND ERASE
ALL PATCHES"</p> | Press ENTER. | | | |
| 32. | <p>"NEXT SEQ - WILL
OVERLAY PRESENT
PATCHES"</p> | Press ENTER. | | | |
| 33. | <p>"USING SECOND DISK^{LL}
SWAP DISK ONLY WHEN
... RETRIEVING PN= ..
IS DISPLAYED"</p> | Press ENTER. | | | |
| 34. | <p>"*****
* END OF MESSAGE *

REDISPLAY MESSAGES^L-"</p> | Press NO. | | | |
| 35. | <p>"PN=XXXXXXXX SEQ=XX
TRANFER COMPLETE.
DO YOU WANT TO GET
THE NEXT SEQ^L - "</p> | <p>If you want to continue, then when
you press YES, you will have 15
seconds before the MD will attempt
to start writing on a diskette, so
be prepared to remove the 'patch
full' diskette and load a 'patch
empty' diskette at the next step.</p> <p>If you do not want to continue,
press NO and go to step 29.</p> | | | |

Receiving a File: Data Base to MD (Part 6 of 6)

43. Remove the updated diskette.
Copy the ZAPs to the primary controller diskette and then apply them to the primary controller diskette (see pages 2-395 and 2-398 for procedures).

Note:

Because the update function has been designed to update the spare diskette, any mention of the spare diskette in the displayed messages must be understood to mean the primary controller diskette.

Do not apply the ZAPs to the spare controller diskette until you receive a full ZAP data file (00 through 0A, 0B through 14, etc). If you receive a partial ZAP data file and apply it to the spare controller diskette, on your next update your directory in the ZAP area will be wrong.

Always use the same spare controller diskette to receive ZAPs, because the system will read the sequence number last sent to you. Use a felt-tip pen to mark the diskette with. Never use a service diskette, because the ZAP area has a different physical location.

UPDATING MACHINE DISKETTES FROM MD DISTRIBUTION DISKETTES

This is a step-by-step procedure to update primary and secondary controller diskettes with ZAPs retrieved from the Distribution System from extra diskettes. Messages on the 3727 screen referring to SPARE means primary or secondary controller diskettes and NORMAL refers to the diskette(s) that was used to retrieve the ZAPs.

1. Take MOSS offline: Press CCU FNCTN key Enter 5, Press SEND Enter 12, MOSS is now offline.
2. Insert diskette with new ZAPs into 3725.
3. Select Utility program.
4. Select 4 ZAPs.
5. Enter date MM/DD/YY. ZAPs are now displayed.
6. Press PF2 (update spare diskette). ZAPs go into storage.
7. Insert primary diskette, press SEND. Message ZAP AREA EMPTY should appear on screen.
8. Press PF1 (copy ZAPs).
9. Enter any character next to each ZAP on the screen.
10. Press SEND.

11. Enter character A next to the first ZAP.
12. Press SEND. Repeat steps 11 and 12 until all ZAPs on the screen have been applied.
13. Enter character E next to the first ZAP.
14. Press SEND.
15. Enter character Y to confirm. Press SEND. Continue this sequence until all ZAPs have been erased.
16. Press PF2 (return to normal diskette). Message MOUNT NORMAL DISKETTE..etc., appears on the screen.
17. Insert diskette with the next group of ZAPs to be copied.
18. Press SEND.
19. Repeat steps 6 thru 18 until all ZAPs have been copied and applied to both primary and secondary controller diskettes, then insert the primary diskette.
20. Press SEND. Message ZAP AREA EMPTY appears on the screen.
21. Press SELN AREA.
22. Enter 6, press SEND.
23. When MLT screen appears, press PF5. All ZAPs on this diskette will now be displayed.
24. Press SELN AREA. Enter character T, press SEND.
25. Repeat step 1 and put MOSS online. You are now finished.

ERRORS AND WARNINGS

Error statuses and warnings dealing with the MD communications are given in the IBM Maintenance Device System Programmer Reference Manual, Z209-1500.

Receiving a File: MD to MD

This procedure is used when the support function wants to transfer a large patch file to the field.

1. Load MD utility diskette into the MD.

	<u>MD Messages</u>	<u>Action/Response</u>
2.	"MAINTENANCE DEVICE MAINTENANCE AND APPLICATION DISKETTE"	FWD
3.	"DO YOU WANT TO REPAIR/TEST THIS MD?"	NO
4.	"DO YOU WANT TO RUN THE MD EDUCATION MODULE?"	NO
5.	" SELECT ACTIVITY 1 = MAP EXERCISE 2 = APPLICATIONS 3 = END "	2 ENTER
6.	"SELECT UTILITY TYPE 1. DISPLAY 2. REMOTE 3. DISKETTE"	3 ENTER
7.	"1. DISPLAY ALTER 2. COPY DISKETTE 3. DISK ANALYSIS 4. HEAD ALIGNMENT"	2 ENTER
8.	"ARE YOU USING TWO MD'S?"	YES
9.	"ARE YOU USING EITHER AN ACOUSTIC COUPLER OR A MODEM?"	YES
10.	"IS BUSINESS MACHINE CLOCKING REQUIRED?"	YES
11.	"SELECT CLOCK SPEED. 1. 600 BPS OR 2. 1200 BPS"	2 ENTER
12.	"IF USING FE UPAC OR EPAC SET THE MODE SWITCH TO 0 -1200 NO EIA CLOCK"	Set switch, then press ENTER
13.	"ARE YOU THE SENDER?"	NO
14.	"DO YOU WISH TO CHANGE DISKETTE?"	YES

15.	"INSERT NEW DISKETTE."	Put 3725 diskette into MD and close the handle.
16.	"ENTER DISK TYPE 1. DISKETTE 1 33FD 2. DISKETTE 2 43FD 3. DISKETTE 2D 53FD"	3 ENTER
17.	"CONNECT EIA CABLE TO COUPLER OR MODEM AND DIAL UP OTHER MD. FWD WHEN DONE."	Dial the phone number given to you by the support function. FWD
18.	"OPENING EIA PORT"	No action required.

The transmit MD should take control and send the required data.

19.	"WAITING FOR DATA FOR EXTENTS xxx----x"	No action required.
20.	"DISKETTE COPIED DO YOU WANT TO COPY ANOTHER DISKETTE"	YES -if you have more, NO -end of operation.
21.	"DO YOU WISH TO CHANGE DISKETTE"	NO
22.	"ENTER DISK TYPE 1. DISKETTE 1 33FD 2. DISKETTE 2 43FD 3. DISKETTE 2D 53FD"	3 ENTER
23.	"WAITING FOR DISK EXTENTS FROM SENDING MD."	No action required.
24.	Go back to step 19.	

Copying a Diskette: MD to MD

The following procedure should be used only in an emergency to copy a 3725 diskette. One MD can be used, but it is a long and complicated process and susceptible to errors. Two MDs connected via the EIA ports allow the diskette to be copied with minimum of intervention.

1. Load MD utility diskette into the MD, then IPL reset.

	<u>MD Messages</u>	<u>Action/Response</u>
2.	"MAINTENANCE DEVICE MAINTENANCE AND APPLICATION DISKETTE"	FWD
3	"DO YOU WANT TO REPAIR/TEST THIS MD?"	NO
4.	"DO YOU WANT TO RUN THE MD EDUCATION MODULE?"	NO
5.	" SELECT ACTIVITY 1 = MAP EXERCISE 2 = APPLICATIONS 3 = END"	2 ENTER
6.	"SELECT UTILITY TYPE 1. DISPLAY 2. REMOTE 3. DISKETTE"	3 ENTER
7.	"1. DISPLAY ALTER 2. COPY DISKETTE 3. DISK ANALYSIS 4. HEAD ALIGNMENT"	2 ENTER
8.	"ARE YOU USING TWO MD'S?"	YES
9.	"ARE YOU USING EITHER AN ACOUSTIC COUPLER OR A MODEM?"	NO
13.	"ARE YOU THE SENDER?"	YES - on the "from" MD NO - on the "to" MD
14.	"DO YOU WISH TO CHANGE DISKETTE?"	YES
15.a	"INSERT NEW DISKETTE."	Put a 2D type diskette into the "to" MD.
15.b	"INSERT NEW DISKETTE."	Put the 3725 diskette to be copied into the "from" MD.
16.	"ENTER DISK TYPE 1. DISKETTE 1 33FD 2. DISKETTE 2 43FD 3. DISKETTE 2D 53FD"	3 ENTER
17.a	(From MD) "CONNECT EIA CABLE FROM SENDOR DTE TO RECEIVER DCE FWD WHEN DONE"	Do function, then FWD

17.b (To MD)
"OPENING EIA PORT"

Time out will display
an error.
Operation will retry.

At step 18 if you answer with a YES, you will copy a complete diskette without stopping and skip step 19. If you answer with a NO, you copy the areas that are requested. The extents required to do this change with each "EC". Your support function will have the required information.

18.	"DO YOU WANT TO COPY THE ENTIRE DISKETTE ?"	NO
19.	"ENTER DISK EXTENTS IN HEX: EXAMPLE 0101 0C01"	Enter the 8-digit extents given to you by the support function. Press ENTER
20.	"MAKE RECEIVING MD READY TO RECEIVE, PRESS FWD."	FWD
21.	"OPENING EIA PORTS"	No action.
22.	"SENDING DATA FOR EXTENTS X----X"	No action.
23.	"SENDING DATA FOR EXTENTS X----X"	No action.
24.	"DISKETTE COPIED. DO YOU WANT TO COPY ANOTHER DISKETTE?"	NO will end operation.

File Printing: MLT File

The file printing procedure is described in Advanced Communications Function for Network Control Program and System Support Programs Diagnosis Guide.

A sample of each printout is given in the following pages.

MLT FILE

The MLT information identifies the file printout on the host side.

"PRINT MOSS/CSP FILES" UTILITY

DATA WAS TRANSFERRED ON: 03/14/84 AT: 18:05:37

THE FOLLOWING DATA WILL BE FORMATTED:

GCF (GRAPHIC CONFIGURATION FILE)

CUSTOMER IDENTIFICATION: E52B CONTROLLER 03/01/84 TSS03/07 PE3

CONTROLLER TYPE: 3725 MODEL: 01 CCU IDENTIFICATION: 000230

MICROCODE LEVEL: 873051

For the MLT function description, see page 2-407.

For the GCF (graphic configuration file) description, refer to the 3725 Problem Determination and Extended Services, Vol. A06.

File Printing: CDF (Part 1 of 3)

CONFIGURATION DATA FILE (CDF)

CONFIGURATION DATA FILE

PAGE 10

```

SECTOR 1
CCU      00 0400 00F3 F7F2 F5F0 F1FF 3725 0002 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000
MOSS     24 0060 F3F7 F2F7 C4E2 F2C4 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000
RDV 1    48 1140 0021 4002 3140 0440 4100 5041 0A60 4108 7041 0680 410C 9041 0EA0 4006 0000 0000 0000
RDV 2    6C 1008 0811 0808 124A 0000 0000 1525 0014 2400 1323 0016 2600 1727 0008 0808 0800 0000 0000
NOT USED 90 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000
CA 1     B4 8111 0800 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000
CA 2     D8 1000 0000 0000 0000 0010 0000 0000 0000 0000 0000 0000 0000 0010 0000 0000 0000 0000
SPARE    FC 0000 0000

SECTOR 2
T(R)SS CONF 1 00 AC00 0100 0100 0101 0101 0101 0101 0101 0000 0000 0000 0000 0000 0000 0000 0000 0000
" " 2 24 8010 3FFF FFFF FFFF 0000 0000 0000 0000 8211 3FFF 0000 0000 0000 0000 0000 0000
" " 3 48 9412 3CF0 0000 0000 0055 4A00 F000 0000 0000 0613 0000 0000 0000 0017 2300 0000 0000
" " 4 6C 0814 0000 0000 0000 0019 2400 0000 0000 0A15 0000 0000 0000 001B 2500 0000 0000 0000
" " 5 90 0C16 0000 0000 0000 001D 2600 0000 0000 0E17 0000 0000 0000 001F 2700 0000 0000 0000
CSP 1    B4 8010 4000 8088 1111 1111 AAAA AAAA AAAA AAAA CCCC CCCC CCCC CCCC CCCC CCCC CCCC 0000
CSP 2    D8 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000
SPARE    FC 0000 0000

SECTOR 3
CSP 3    00 8011 4002 8088 1111 1111 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000
CSP 4    24 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000
CSP 5    48 9012 4004 8080 3333 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0600
TRA 6    6C 504A 4004 0000 1111 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0600
CSP 7    90 0013 4106 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000
CSP 8    B4 1023 4106 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000
CSP 9    D8 0014 4108 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000
SPARE    FC 0000 0000

SECTOR 4
CSP 10   00 1024 4108 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000
CSP 11   24 0015 410A 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000
CSP 12   48 1025 410A 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000
CSP 13   6C 3016 410C 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000
CSP 14   90 1026 410C 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000
CSP 15   B4 0017 410E 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000
CSP 16   D8 1027 410E 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000 0000
SPARE    FC 0000 0000
    
```

CDF DATA ORGANIZATION

Each sector of the CDF is divided into 7 records of 36 bytes each. Each sector can be selectively retrieved from the diskette and placed at a specific storage area.

Each record has a predefined format as follows.

	R0	R1	R2	R3	R4	R5	R6	Last 4 bytes
S1	CCU	MÖSS	RDV1	RDV2	Not Used	CA1	CA2	Spare
S2	General Scanner or TRA Configuration Frame					CSP1	CSP2	Spare
S3	CSP3	CSP4	CSP5	CSP6 or TRA6	CSP7	CSP8 or TRA8	CSP9	Spare
S4	CSP10 or TRA10	CSP11	CSP12 or TRA12	CSP13	CSP14 or TRA14	CSP15	CSP16 or TRA16	Spare

CCU Record (S1,R0)

Only the following bytes are used in this record.

- 0 : Storage size by increments of 128K (byte value: hex 02 to hex 08)
- 1 : Storage type (byte value: hex 00)
- 2 : Not used (byte value: hex 00 must be 00)
- 3,4,5,6 : Control unit type number (defined as a constant in microcode)
- 7,8 : Model (defined as a constant in microcode)
- 9,10,11,12: Sense data information for host (defined as a constant in microcode)

File Printing CDF (Part 2 of 3)

MOSS Record (S1,R1)

Only the following bytes are used in this record:

- 0 and 1: Storage size
- 2 to 5 : Keyboard/display identification
- 6 to 9 : Diskette identification
- 10 : CPA information (3 bits right justified)

Redrive Records (S1,R2, R3)

The first record (RDV1) deals with redrive information and the second (RDV2) gives addresses of adapters.

RDV1 (S1,R2)

This record gives redrive information. A group of 3 bytes are defined for each redrive card.

- Byte 0 bits 0 to 3: Redrive number
 Value : 1 = CLAB1 or C2LB
 2 = CLAB2 or C2LB2
 3 = LAB Position 3
 4 = Frame RDV
 5 = LAB Position 6
 6 = LAB Position 5
 7 = LAB Position 4
 8 = LAB Position 7
 9 = LAB Position 8
 10 = CAB
- bits 4 to 6: Not used
 bit 7 : 0 = Not present
 1 = Present

Byte 1 TA byte 0 : Redrive address

Byte 2 TA byte 1 : Redrive address

The last 6 bytes of this record are not used.

RDV2 (S1,R3)

Three bytes per redrive give the addresses of the adapters linked to each redrive.

Model 1

Redrive #	Byte #	Adapters
1	0 1 2	scanner 1 CA 1
2	3 4 5	scanner 3 CA 2
3	6 7 8	scanner 5 scanner/TRA 6
4	9 10 11	
5	12 13 14	scanner 11 scanner/TRA 12
6	15 16 17	scanner 9 scanner/TRA 10
7	18 19 20	scanner 7 scanner/TRA 8
8	21 22 23	scanner 13 scanner/TRA 14
9	24 25 26	scanner 15 scanner/TRA 16
10	27 28 29	CA 3 CA 4 CA 5 CA 6

Model 2

Redrive #	Byte #	Adapters
1	0 1 2	scanner 1 CA 1 and CA 2
2	3 4 5	scanner 3 CA 3 and CA 4
3	6 7 8	scanner 5 scanner/TRA 6

Channel Adapter Records (S1,R5, R6)

R5 deals with the basic frame of Model 1, or with Model 2. R6 deals with the expansion frame.

A group of 9 bytes is defined for each of the possible channel adapters.

- Byte 0 Bit 0 : 0 = CA not installed
 1 = CA installed
 Bits 2 to 3: CAB type
 00 = CLAB
 01 = CAB
 10 = C2LB or C2LB2
 Bits 4 to 7: CA position (right justified)
- Byte 1 Bits 0 to 3: CA type
 Bits 4 to 6: Not used
 Bit 7 : 0 = TPS feature not installed
 (always 0 for the 3725 Model 2)
 1 = TPS feature installed

Byte 2 Channel adapter address

Byte 3 NSC address in hex (Interface A)

Byte 4 ESC low address in hex (Interface A)

Byte 5 ESC high address in hex (Interface A)

Byte 6 NSC address in hex (Interface B if any)

Byte 7 Reserved

Byte 8 Reserved


Note: The NSC and ESC addresses can be entered only by the CE using the CDF UPDATE command. A VERIFY command does not address or change the contents of these 4 bytes.

General Scanner Configuration Frame (S2,R0-R4)

The five records in this second sector give the installed/not installed information for all possible elements of each scanner/TRA.

Record 0: Scanner/TRA summary

Bytes 0 and 1:



0 = scanner/TRA not installed
 1 = scanner/TRA installed

Bytes 2 to 17: scanner load module identification. (1 byte per scanner to be defined)


The load module identification table is created and maintained by the system IPL phase 4.

The other bytes are not used.

Records 1 to 4: Scanner/TRA information


- Record 1 contains information on scanners 1 to 4
- Record 2 contains information on scanners/TRA 5 to 8
- Record 3 contains information on scanners/TRA 9 to 12
- Record 4 contains information on scanners/TRA 13 to 16

Each scanner/TRA is represented by a group of 9 bytes as follows:




File Printing: CDF (Part 3 of 3)

Byte 3



Note: For the 3725 Model 2 the ICC1 and ICC2 are always present on the C2LB board.

Byte 4



Note: For the 3725 Model 2 only LIC1 through 6 are present.

Byte 5

POS 1 | POS 2

Byte 6

POS 3 | POS 4

Byte 7

POS 5 | POS 6

Byte 8

POS 7 | POS 8

Byte 9 Reserved

For each LIC, a half byte indicates the possible line position, as follows:

0 = Modem cable not plugged
1 = Modem cable plugged

Scanner/TRA Detailed Information Records (S2,R5-R6,S3,S4)

Each record of the TSS detailed information area (records CSP1 through CSP16) is associated with a specific scanner, and provides detailed information on it.

Byte 0 Bit 0 : 0 = Scanner not installed
 : 1 = Scanner installed
 Bit 1 : 0 = TRA not installed
 : 1 = TRA installed
 Bits 2,3 : LAB type
 00 = LAB type A
 01 = LAB type B
 01 + bit 1 ON=LABC
 10 = C2LB or C2LB2 (3725 Model 2)
 Bits 4,5 : Not used
 Bits 6,7 : Scanner type


Byte 1 Scanner/TRA address (7 bits right justified)

Bytes 2,3 Redrive address as shown in TA bytes 0 and 1

Byte 4 FES identification (N/A for TRA)

Bit 0 value: 0 = FES not installed
 value: 1 = FES installed
Bit 4 to 7 : 0000 = FES type 1
 0001 = FES type 2 (PRPQ)

Byte 5 ICC identification (N/A for TRA)



Note: For the 3725 Model 2, ICC1 and ICC2 are always installed on the C2LB board.

Bytes 6,9 LIC/TIC information

Eight identical half-bytes provide the LIC/TIC information for the installed LIC/TIC as follows:



0000 = No LIC
0001 = LIC/TIC type 1
0010 = LIC type 2
0011 = LIC type 3
0100 = LIC type 4A
1100 = LIC type 4B

Bytes 10 to 17 (N/A if TRA installed)

Cable clocking information.

These 8 bytes give clocking information on the lines attached on each LIC. Each byte corresponds to one LIC and provides the following information:

Bits 0,1 : Line position 0
Bits 2,3 : Line position 1
Bits 4,5 : Line position 2
Bits 6,7 : Line position 3


Values:
00 = Undefined
01 = Internal clock (ICC)
10 = External clock (default value)
11 = Local attachment

Note: This clocking information can be entered only by the CE using the CDF UPDATE command. A CREATE command resets this information to its default value. A VERIFY command does not address or change the contents of these 8 bytes.

Bytes 18 to 33 (N/A if TRA installed)

Cable identification

Eight halfwords of identical format give information on cables that can be installed on the four line positions of each LIC.




For each line position:

Bit 0 value 0 = cable not installed
 value 1 = cable installed

Bits 1 to 3 cable identifier
001 = LIC type 1/2/4 wrap block
010 = LIC type 3 wrap cable
100 = Modem attachment or Bell 303 type
101 = Local attachment
110 = Autocall equipment
111 = VHSA

Byte 34-35 not used

Byte 36 LAB type



File Printing : ZAP History Table

For ZAP function description, see page 2-393

ZAP HISTORY TABLE

CPL4420	APPLIED ON	11/05/82	CE050058	APPLIED ON	11/05/82	CE059060	APPLIED ON	11/05/82
CE061061	APPLIED ON	11/05/82	CE062062	APPLIED ON	11/05/82	BE047048	APPLIED ON	11/10/82
CE054058	APPLIED ON	11/10/82	BE21A063	APPLIED ON	11/16/82	BE21A064	APPLIED ON	11/16/82
CE21A065	APPLIED ON	11/16/82						

ZAP AREA CONTENTS

---ZAP-ID-----STATUS-----FILE-----MODULE----DISPL-----VERIFY/REPLACE DATA-----

BE21A063	APPLIED	CHGUCMOD	CHGBLMOD	00F54	VER: A3CB 2303 9616 REP: 4AD5 4B60 A9A3
		CHGUCMOD	CHGBLMOD	04560	VER: FFFF FFFF FFFF FFFF FFFF FFFF FFFF FFFF REP: A3CB 5300 910C 2303 9602 AF90 4A9F 4B70
		CHGUCMOD	CHGBLMOD	04570	VER: FFFF FFFF FFFF FFFF REP: AFA0 4A9F 4B3E AFA0
BE21A064	APPLIED	CHGUCMOD	CHGBLMOD	01CE2	VER: 0304 0506 0709 0A0B 0C0D 0E0F 1011 1213 REP: 0B0C 0D0E 0F11 1213 1415 1617 1819 1A1B
		CHGUCMOD	CHGBLMOD	01CF2	VER: 1415 1617 1819 1B1D 1F21 2325 2729 2B2D REP: 1C1D 1E1F 2021 2325 2729 2B2D 2F31 3335
		CHGUCMOD	CHGBLMOD	01D02	VER: 2F31 330B REP: 3739 3B0B
CE21A065	APPLIED	CHGMDJIB	CHHM CSP	04068	VER: 55C2 REP: 54C2
CE21A067	NON-APPLIED	CHGMDJIB	CHHM CSP	07D1A	VER: 23E6 4A24 REP: 6227 6459

File Printing: BER List

ERROR LOG-----BER LIST-----PAGE 15

DATE/TIME	SIZE	FLAG	TYPE	ID	ERROR DATA
05/08/82 11:03:27	1F		11	8A	00000000 00000000 00000000 00000000 0000F4F1
05/08/82 11:03:24	15		10	B2	00000000 00000000 F3F1
05/08/82 11:03:23	13		13	FE	00000000 0000F2F3
05/08/82 11:03:22	10		12	21	000000F1 F4
05/08/82 11:03:21	11		11	8A	00000000 F1F3
05/08/82 11:03:18	13		10	B2	00000000 0000F1F1
05/08/82 11:02:56	52		12	21	000000C1 E2D7C9C3 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 404040C1 E2D7C9C3 40404040 40404040 40404040
05/08/82 11:02:54	52		12	21	000000C1 E2D7C9C3 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 404040C1 E2D7C9C3 40404040 40404040 40404040
05/08/82 11:02:52	52		12	21	000000C1 E2D7C9C3 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 404040C1 E2D7C9C3 40404040 40404040 40404040
05/08/82 11:02:50	52		12	21	000000C1 E2D7C9C3 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 404040C1 E2D7C9C3 40404040 40404040 40404040
05/08/82 11:02:48	52		12	21	000000C1 E2D7C9C3 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 404040C1 E2D7C9C3 40404040 40404040 40404040
05/08/82 11:02:46	52		12	21	000000C1 E2D7C9C3 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 404040C1 E2D7C9C3 40404040 40404040 40404040
05/08/82 11:02:44	0D		01	06	0202
05/08/82 11:02:40	52		12	21	000000C1 E2D7C9C3 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 404040C1 E2D7C9C3 40404040 40404040 40404040
05/08/82 11:02:38	52		12	21	000000C1 E2D7C9C3 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 40404040 404040C1 E2D7C9C3 40404040 40404040 40404040
05/08/82 11:02:36	1A		13	C3	000000C1 E2D7C9C3 40404040 404040
05/08/82 11:02:34	1A		13	C3	000000C1 E2D7C9C3 40404040 404040
05/08/82 11:02:32	1A		13	C3	000000C1 E2D7C9C3 40404040 404040

Note: Due to the host program, a BER type 02 may appear on the BER list. This type 02 does not appear on any 3725 BER lists and should be ignored.

File Printing: MOSS Dump (Part 1 of 2)

MOSS DUMP TAKEN ON: 05/08/82 AT: 11:03:30 ABEND CODE 4B: PROGRAM ERROR DETECTED BY CAC

PAGE 29

THE SVT IS ASSUMED TO BE AT: 2486
 CONTENTS OF THE MOSS LEVEL 0 BER AT: 2152
 INTERRUPTED LEVEL: 5 PSW: 531E 8D 0C ON INSTRUCTION: 6004 AT ADDRESS: (08)531E
 MOFC: 00000000
 FIRR: 10000100
 CMASK: 11111111
 IOIR: 00000000
 NEF: 00001000
 ADAPTERS STATUS (KEYBOARD-DISPLAY: 11111111 PANEL: 11111111 DISKETTE: 11111111)
 IPL COUNTER: 11000001

MOSS DUMP TAKEN ON: 05/08/82 AT: 11:03:30 ABEND CODE 4B: PROGRAM ERROR DETECTED BY CAC

PAGE 31

-----TASK NAME-----	-----REGISTERS-----															
	0	2	4	6	8	10	12	14	16	18	20	22	24	26	28	30
PAGE 10-11 BER LOGGING	FEBF	0004	249F	6982	3662	682A	3662	237E	6B1C	001A	23BA	6AEA	671A	23D3	6AEA	237E
PAGE 12-13 MACHINE STATUS	FE08	3000	0008	5CD3	3F20	3F00	2486	21C2	0020	3DC4	3C02	0903	5294	0000	5D7C	3E54
PAGE 14-15 CCU BACKGROUND	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
PAGE 16-17 CHANNEL MONITORING	FE07	8B74	8B06	0000	8042	8332	218C	81B0	0000	0007	84D4	0000	8314	8314	801A	2486
PAGE 18-19 OPERATOR CONTROL	FE56	03A4	118F	9BC4	1014	1498	400A	113C	1EF2	9B1A	9B18	1556	1516	9B33	1554	2486
PAGE 1A-1B IPL SERVICES	FE00	2400	B700	2BD4	B0EE	2518	24C5	96FA	B962	0006	B6F0	B8C6	B6A4	B0CE	218C	2486
PAGE 1C-1D DMP SV L5	F500	0800	1000	0000	8100	0000	20CE	1152	0B01	0000	1E92	0000	1F00	1764	218C	2152
PAGE 1E-1F DMP SV L6	0400	0006	3400	311D	0008	10DE	01ED	01EF	01F2	8000	5410	0000	0FB8	FFFE	2152	20CE
PAGE 28-29 DIAGNOSTICS	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
PAGE 2C-2D LOOP DETECTION	FE00	232C	2000	0000	0000	0000	2486	0000	0000	0000	0000	0000	0000	0000	2486	37FE

MOSS DUMP TAKEN ON: 05/08/82 AT: 11:03:30 ABEND CODE 4B: PROGRAM ERROR DETECTED BY CAC

PAGE 30

-----PSN----- IAR PSC SP PP	-----REGISTERS-----															
	0	2	4	6	8	10	12	14	16	18	20	22	24	26	28	30
LEVEL 0 0A9E 0 03 02	BF98	FE01	0007	2327	5204	11CD	FCD1	001B	5464	FE01	538A	5442	5204	FCAB	2152	3264
TTA 80 81 02 03 04 05 06 07	10	11	12	13	14	15	16	98								
LEVEL 1 5B0A 8 05 04	BF80	2100	248A	9B32	1000	5C40	21C2	2486	5C74	0000	248F	5C52	5A2A	0000	5C52	2B4C
TTA 80 81 02 03 04 05 06 07	10	11	12	13	14	15	16	98								
LEVEL 2 5C30 0 07 06	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
TTA 98 0C 02 03 04 98 98 98	98	98	98	98	98	98	98	98								
LEVEL 3 663C 0 09 08	EF00	8043	2DF0	0000	2486	67A6	0054	248A	0000	5F8C	087A	67D0	64BE	5ECA	67D0	2C58
TTA 98 0C 02 03 04 05 06 98	10	11	12	13	14	15	16	17								
LEVEL 4 7062 8 09 0A	F703	8000	7ED3	7EE4	797C	7ADA	3264	81B0	7EE4	21C2	0040	7EA6	797C	0000	2486	248A
TTA 98 0C 02 03 04 98 06 07	10	11	12	13	14	15	16	17								
LEVEL 5 5320 8 0D 0C	8000	0C12	4800	000A	8100	539E	32E0	2486	0100	335C	1E92	5C26	1F7C	1764	218C	400A
TTA 80 81 02 03 04 08 0E 0F	10	11	12	13	14	15	16	17								
LEVEL 6 7538 8 0F 0E	FD88	0000	0006	1000	0003	7AFE	7FB2	2486	256E	0000	37FE	7F42	7888	252E	7F42	81B6
TTA 80 81 02 03 04 08 09 0A	08	11	12	13	14	15	16	17								
LEVEL 7 8320 4 17 16	FE07	8B74	8B06	0000	8042	8332	218C	81B0	0000	0007	84D4	0000	8314	8314	801A	2486
TTA 0B 0C 02 03 04 0D 0E 0F	10	11	12	13	14	15	16	17								

File Printing: MOSS Dump (Part 2 of 2)

MOSS DUMP TAKEN ON: 05/08/82 AT: 11:03:30 ABEND CODE 4B: PROGRAM ERROR DETECTED BY CAC

PAGE 32

-----OTHER REGISTER SPACES-----

```

PAGE 2A  00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
PAGE 2B  00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
PAGE 2E  00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
PAGE 2F  00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
PAGE 30  02 19 00 2C 00 00 00 00 80 5C 80 11 00 A1 00 00 0E
PAGE 31  54 6E 5C 20 59 EE 00 00 07 46 00 00 21 8C 00 68
PAGE 32  0B 05 08 00 09 20 00 00 30 1C EF EE A0 00 00 00
PAGE 33  60 64 00 00 60 C3 00 00 5A F8 60 A8 58 D4 58 E0
PAGE 34  01 01 68 05 08 31 2F FF FE 01 56 5C 20 00 00 17
PAGE 35  00 00 00 18 56 42 00 00 00 00 00 00 00 00 00 00
PAGE 36  00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
PAGE 37  00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
PAGE 38  00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
PAGE 39  00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
PAGE 3A  00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
PAGE 3B  00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
PAGE 3C  00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
PAGE 3D  00 00 00 00 00 00 00 00 00 00 00 00 00 00 00 00
PAGE 3E  0A 9E 83 02 10 0A 43 02 00 00 00 00 00 00 00 00
PAGE 3F  00 00 00 00 1F F0 1D 1C 53 5E 1F 9E 00 00 00 00
    
```

MOSS DUMP TAKEN ON: 05/08/82 AT: 11:03:30 ABEND CODE 4B: PROGRAM ERROR DETECTED BY CAC

PAGE 33

```

002000 20628183 08000000 00001764 206C0000 20AA0000 00000000 81A30800 00000000 *..AC.....AT.*
002020 1754206C 000020AA 00000000 00003100 000020F2 00001764 206C0000 20AA0000 *.....A..2.*
002040 00000000 81000000 00000000 00000000 000020A4 00000000 00000021 01000000 *.....A.....*
002060 FF0020CE 204420F2 2152218C B5201380 F1300060 09AD09AD 071A0014 50010801 *.....2.....*
002080 00000000 0100A622 81F53780 80002080 0000202E 00001F00 137C1636 202E0000 *.....W.A6G.*
002100 000015C3 F6100000 00000000 00000000 00100000 20FA0000 00000000 00000000 *.....H6.*
002120 20C20000 00000000 00000000 00000000 00001D4C 00000000 00001EE0 00000000 *..B.....*
002140 00000000 002E2044 00000000 00000000 00000193 00040000 09AC0022 60000000 *.....L.....*
002160 30000193 00040000 0A0C0022 80000000 80000193 00040000 0A8C0022 80000000 *.....L.....*
002180 80000193 00040000 09A30022 04000000 800001E3 00000000 00150001 00800000 *.....Y.....*
0021A0 800001E3 00000000 00150022 00800000 80001501 004B0500 0084FFFF FFFF0808 *.....T.....*
0021C0 6004531E 800CC105 00005320 8D0C7838 8F0E0AA0 03020AA0 03025B0A 85045000 *..A.....E.&.*
0021E0 500020CE 0E4C0836 0DCA0000 00004000 2480A100 00010488 00781000 00000000 *8.....<F.....*
002200 00000000 00000000 00000000 00000000 00000000 00000080 FF372500 00000000 *.....<F.....*
002220 00000000 00000000 80800000 10000140 00000000 00000000 0040F90B C03E0070 *.....PS.....*
002240 0403C940 97E20000 004040FF 48484B43 48000000 00000000 00000000 00000000 *.....9.....*
002260 00010000 00000000 00000000 00000000 00000000 00000000 00000000 00000000 *.....9.....*
002280 00000000 00000000 00000000 00000000 00000000 00000000 00000000 00000000 *.....9.....*
0022A0 DATA SAME AS ABOVE
0022C0 0000A001 02009800 08005001 80010800 08000500 08000800 08000300 08000800 *.....*
0022E0 00000100 0000000A 00000E10 0004000A 00000000 00000000 00000000 00000150 *.....A.....*
002300 80420403 02010F00 4AEE1300 4B2A1700 4B632100 4B914800 00000800 08000500 *.....J.....*
002320 47280430 0000F100 0000FF00 00000E00 00000000 00000000 00000000 000023D3 *.....L.....*
002340 24030340 40404040 0000009B 77050882 13C30000 00C1E2D7 C9C34040 40404040 *.....B.C..ASPIC*
002360 40000000 9B790508 8213C300 0000C1E2 D7C9C340 40404040 40400000 009B7805 *.....B.C..ASPIC*
002380 088213C3 000000C1 E2D7C9C3 40404040 40404019 00009B7D 05088213 C3000000 *..B.C..ASPIC*
0023A0 C1E2D7C9 C3404040 40404040 1C00009B 82050882 01004B65 000084FF FFFF0F08 *ASPIC.....B.C..*
0023C0 088213C3 000000C1 009B6D05 088213C3 000000C1 E2D7C9C3 40404040 40404000 *..A.....B.C..ASPIC*
0023E0 00009B6F 05088213 C3000000 C1E2D7C9 C3404040 40404040 0000009B 71050882 *..?..B.C..ASPIC*
002400 13C30000 00C1E2D7 C9C34040 40404040 40000000 9B730508 8213C300 0000C1E2 *C..ASPIC*
002420 D7C9C340 40404040 40400000 009B7505 088213C3 000000C1 E2D7C9C3 40400000 *PIC.....B.C..ASPIC*
002440 422D43DC AF204000 00000000 81B04B00 00592BD4 326432E0 00009B82 0508820B *.....A.....M.....B..B.*
002460 FFFF3554 36623670 367E368C 369A36A8 358C5000 00000000 00000000 40404040 *.....Y.....*
002480 40404040 00A0C3C8 C7E4E3D4 D6C468BC 80423686 40CC0000 2D5C252E 253E254E *.....CHGUTMOD.....*
0024A0 255E0000 0003FF00 80B031DC 80004000 20001000 08000400 02000100 00800040 *.....873044*
0024C0 00200010 00030004 00220001 01012233 F3F7F3F0 F4F44090 0000FFFF FFFFFFFF *.....*
0024E0 FFFFFFFF FFFFFFFF FFFFFFFF FFFF07C0 00000000 61B00000 00000000 00000000 *.....*
002500 00000000 00000000 00000000 00000000 00000000 00000000 00000000 00002500 *.....D.....*
002520 00000000 00000000 00000000 00008400 00000000 00000000 00000000 00000000 *.....D.....*
002540 9F16C9D9 C5E2C5C3 C3E640F8 F04B0F2 F140F1F3 4B1F1F00 CF73BFC3 81055140 *..IRESECHW 80.021 13.13...CA.*
002560 940202CE C2135303 9A02B9C7 53049A02 BBC95DCB 5209A02 B4D15210 9A02B6D3 *M..B.....G.....I.....J.....*
002580 5209A02 B8D55202 9A02B9C7 52019A02 BED35380 9A02B10D 53409A02 B3DF5320 *.....N.....R.....*
0025A0 9A0255E1 B2CFC7F3 AFF9AF90 9F16C9D9 C5E2C5C3 C3E640F8 F04B0F2 F140F1F3 *.....G3.9...IRESECHW 80.021 13.*
0025C0 4B43F600 CF73B905 5B409A02 B2CEC213 5309A02 B9C75304 9A02B9C9 BDC55220 *..36.....$ M...B.....G.....I.....*
0025E0 9A02B4D1 52109A02 B6D35208 9A02B8D5 52025A02 5CD95201 9A02B8D8 53809A02 *.....J.....L.....N.....R.....*
0025F0 810D5340 9A02B3DF 53209A02 B5E1B2CF C7F3AFF9 AF900000 9F16C9D9 C5E2D7C3 *.....G3.9...IRESPC*
002610 C2E640F8 F04B0F2 F140F1F9 4BF0F600 AF7AC7F3 B9C6B8C8 BDCAB2CE B4D0B6D2 *HW 80.021 19.06...F.H.....IR*
002630 B2C43CD3 BEDA81DC B3DEB5E0 CD03BDC4 BF42C7D3 BDCBAFF9 AFA00000 9F16C9D9 *..M.Q.....D..GL..9.....K*
002650 C5E2D7D5 C3E640F8 F04B0F2 F140F1F9 4BF1F900 AF7AC7F3 B9C6B8C8 BDCAB2CE *ESPNCW 80.021 19.19...F.H.....*
002670 34D0B6D2 B3D4BCD8 BEDA81DC B3DEB5E0 AFF9AFA0 9F16C9C8 C7C3E5C2 C9C440F8 *..K.M.Q.....9.....CHGCVBID 8*
002690 F24BF0F7 F240F2F3 4BF2F800 4A264B9C AAA3A519 CE13B383 B9854101 9F104A26 *2.075 23.28...TV...C.E.....*
002710 4B9CAAA3 A519CE13 B3B3B985 41004200 43019F0C 4B40C433 C428C14F AB48C12D *..TV...C.E.....D.D.A...A.*
    
```

MOSS Storage Address

Hexadecimal/Decimal Conversion

CONVERSION RULES

From Hex

Locate each hex digit in its corresponding column position and note the decimal equivalents. Add these to obtain the decimal value.

From Decimal

1. Locate the largest decimal value in the table that will fit into the decimal number to be converted.
2. Note its hex equivalent and hex column position.
3. Find the decimal remainder. Repeat the process on this and subsequent remainders.

HEXADECIMAL COLUMNS					
6	5	4	3	2	1
HEX = DEC	HEX = DEC	HEX = DEC	HEX = DEC	HEX = DEC	HEX = DEC
0	0	0	0	0	0
1 1 048 576	1 65 536	1 4 096	1 256	1 16	1 1
2 2 097 152	2 131 072	2 8 192	2 512	2 32	2 2
3 3 145 728	3 196 608	3 12 288	3 768	3 48	3 3
4 4 194 304	4 262 144	4 16 384	4 1 024	4 64	4 4
5 5 242 880	5 327 680	5 20 480	5 1 280	5 80	5 5
6 6 291 456	6 393 216	6 24 576	6 1 536	6 96	6 6
7 7 340 032	7 458 752	7 28 672	7 1 792	7 112	7 7
8 8 388 608	8 524 288	8 32 768	8 2 048	8 128	8 8
9 9 437 184	9 589 824	9 36 864	9 2 304	9 144	9 9
A 10 485 760	A 655 360	A 40 960	A 2 560	A 160	A 10
B 11 534 336	B 720 896	B 45 056	B 2 816	B 176	B 11
C 12 582 912	C 786 432	C 49 152	C 3 072	C 192	C 12
D 13 631 488	D 851 968	D 53 248	D 3 328	D 208	D 13
E 14 680 064	E 917 504	E 57 344	E 3 584	E 224	E 14
F 15 728 640	F 983 040	F 61 440	F 3 840	F 240	F 15
0 1 2 3	4 5 6 7	0 1 2 3	4 5 6 7	0 1 2 3	4 5 6 7
BYTE		BYTE		BYTE	

CONVERSION TABLES

Position		Position		Position		Position		Position		Position		Position		Position	
Dec	Hex	Dec	Hex	Dec	Hex	Dec	Hex	Dec	Hex	Dec	Hex	Dec	Hex	Dec	Hex
0000	000	0059	03B	0122	07A	0184	0B8	0246	0F6	0308	134	0370	172	0433	1B1
0001	001	0060	03C	0123	07B	0185	0B9	0247	0F7	0309	135	0371	173	0434	1B2
0002	002	0061	03D	0124	07C	0186	0BA	0248	0F8	0310	136	0372	174	0435	1B3
0003	003	0062	03E	0125	07D	0187	0BB	0249	0F9	0311	137	0373	175	0436	1B4
0004	004	0063	03F	0126	07E	0188	0BC	0250	0FA	0312	138	0374	176	0437	1B5
0005	005	0064	040	0127	07F	0189	0BD	0251	0FB	0313	139	0375	177	0438	1B6
0006	006	0065	041	0128	080	0190	0BE	0252	0FC	0314	13A	0376	178	0439	1B7
0007	007	0066	042	0129	081	0191	0BF	0253	0FD	0315	13B	0377	179	0440	1B8
0008	008	0067	043	0130	082	0192	0C0	0254	0FE	0316	13C	0378	17A	0441	1B9
0009	009	0068	044	0131	083	0193	0C1	0255	0FF	0317	13D	0379	17B	0442	1BA
0010	00A	0069	045	0132	084	0194	0C2	0256	100	0318	13E	0380	17C	0443	1BB
0011	00B	0070	046	0133	085	0195	0C3	0257	101	0319	13F	0381	17D	0444	1BC
0012	00C	0071	047	0134	086	0196	0C4	0258	102	0320	140	0382	17E	0445	1BD
0013	00D	0072	048	0135	087	0197	0C5	0259	103	0321	141	0383	17F	0446	1BE
0014	00E	0073	049	0136	088	0198	0C6	0260	104	0322	142	0384	180	0447	1BF
0015	00F	0074	04A	0137	089	0199	0C7	0261	105	0323	143	0385	181	0448	1C0
0016	010	0075	04B	0138	08A	0200	0C8	0262	106	0324	144	0386	182	0449	1C1
0017	011	0076	04C	0139	08B	0201	0C9	0263	107	0325	145	0387	183	0450	1C2
0018	012	0077	04D	0140	08C	0202	0CA	0264	108	0326	146	0388	184	0451	1C3
0019	013	0078	04E	0141	08D	0203	0CB	0265	109	0327	147	0389	185	0452	1C4
0020	014	0079	04F	0142	08E	0204	0CC	0266	10A	0328	148	0390	186	0453	1C5
0021	015	0080	050	0143	08F	0205	0CD	0267	10B	0329	149	0391	187	0454	1C6
0022	016	0081	051	0144	090	0206	0CE	0268	10C	0330	14A	0392	188	0455	1C7
0023	017	0082	052	0145	091	0207	0CF	0269	10D	0331	14B	0393	189	0456	1C8
0024	018	0083	053	0146	092	0208	0D0	0270	10E	0332	14C	0394	18A	0457	1C9
0025	019	0084	054	0147	093	0209	0D1	0271	10F	0333	14D	0395	18B	0458	1CA
0026	01A	0085	055	0148	094	0210	0D2	0272	110	0334	14E	0396	18C	0459	1CB
0027	01B	0086	056	0149	095	0211	0D3	0273	111	0335	14F	0397	18D	0460	1CC
0028	01C	0087	057	0150	096	0212	0D4	0274	112	0336	150	0398	18E	0461	1CD
0029	01D	0088	058	0151	097	0213	0D5	0275	113	0337	151	0399	18F	0462	1CE
0030	01E	0089	059	0152	098	0214	0D6	0276	114	0338	152	0400	190	0463	1CF
0031	01F	0090	05A	0153	099	0215	0D7	0277	115	0339	153	0401	191	0464	1D0
0032	020	0091	05B	0154	09A	0216	0D8	0278	116	0340	154	0402	192	0465	1D1
0033	021	0092	05C	0155	09B	0217	0D9	0279	117	0341	155	0403	193	0466	1D2
0034	022	0093	05D	0156	09C	0218	0DA	0280	118	0342	156	0404	194	0467	1D3
0035	023	0094	05E	0157	09D	0219	0DB	0281	119	0343	157	0405	195	0468	1D4
0036	024	0095	05F	0158	09E	0220	0DC	0282	11A	0344	158	0406	196	0469	1D5
0037	025	0096	060	0159	09F	0221	0DD	0283	11B	0345	159	0407	197	0470	1D6
0038	026	0097	061	0160	0A0	0222	0DE	0284	11C	0346	15A	0408	198	0471	1D7
0039	027	0098	062	0161	0A1	0223	0DF	0285	11D	0347	15B	0409	199	0472	1D8
0040	028	0099	063	0162	0A2	0224	0E0	0286	11E	0348	15C	0410	19A	0473	1D9
0041	029	0100	064	0163	0A3	0225	0E1	0287	11F	0349	15D	0411	19B	0474	1DA
0042	02A	0101	065	0164	0A4	0226	0E2	0288	120	0350	15E	0412	19C	0475	1DB
0043	02B	0102	066	0165	0A5	0227	0E3	0289	121	0351	15F	0413	19D	0476	1DC
0044	02C	0103	067	0166	0A6	0228	0E4	0290	122	0352	160	0414	19E	0477	1DD
0045	02D	0104	068	0167	0A7	0229	0E5	0291	123	0353	161	0415	19F	0478	1DE
0046	02E	0105	069	0168	0A8	0230	0E6	0292	124	0354	162	0416	1A0	0479	1DF
0047	02F	0106	06A	0169	0A9	0231	0E7	0293	125	0355	163	0417	1A1	0480	1E0
0048	030	0107	06B	0170	0AA	0232	0E8	0294	126	0356	164	0418	1A2	0481	1E1
0049	031	0108	06C	0171	0AB	0233	0E9	0295	127	0357	165	0419	1A3	0482	1E2
0050	032	0109	06D	0172	0AC	0234	0EA	0296	128	0358	166	0420	1A4	0483	1E3
0051	033	0110	06E	0173	0AD	0235	0EB	0297	129	0359	167	0421	1A5	0484	1E4
0052	034	0111	06F	0174	0AE	0236	0EC	0298	12A	0360	168	0422	1A6	0485	1E5
0053	035	0112	070	0175	0AF	0237	0ED	0299	12B	0361	169	0423	1A7	0486	1E6
0054	036	0113	071	0176	0B0	0238	0EE	0300	12C	0362	16A	0424	1A8	0487	1E7
0055	037	0114	072	0177	0B1	0239	0EF	0301	12D	0363	16B	0425	1A9	0488	1E8
0056	038	0115	073	0178	0B2	0240	0F0	0302	12E	0364	16C	0426	1AA	0489	1E9
0057	039	0116	074	0179	0B3	0241	0F1	0303	12F	0365	16D	0427	1AB	0490	1EA
0058	03A	0117	075	0180	0B4	0242	0F2	0304	130	0366	16E	0428	1AC	0491	1EB
		0118	076	0181	0B5	0243	0F3	0305	131	0367	16F	0429	1AD	0492	1EC
		0119	077	0182	0B6	0244	0F4	0306	132	0368	170	0430	1AE	0493	1ED
		0120	078	0183	0B7	0245	0F5	0307	133	0369	171	0431	1AF	0494	1EE
		0121	079									0432	1B0		

Message Directory (Part 1 of 4)

The following sections describe the messages displayed on the operator console. The sections are organized as follows:

The message directory lists messages in alphabetical order and indicates where they are documented:

- The following messages are documented in the 3725 Communication Controller, Problem Determination and Extended Services: Vol. A06.
 - Messages intended for customer personnel
 - Messages for Wrap tests at tail-gate level
 - Messages for Stand-Alone link tests They are indicated by "PD and ES" in the directory.
- Messages intended for the service personnel are documented respectively in the following three sections:
 - Utility Program Messages (page 2-500)
 - TSS Function Messages (page 2-510)
 - TRSS Function Messages (page 2-520)
- Some messages are intended for both customer and service personnel. These are documented in the 3725 Problem Determination and Extended Services manual, and also in the following sections.
- Some messages belong to more than one group, for example: "INVALID INPUT". They are documented in one group only, to avoid duplication.

Messages	Details in:
A0 MOSS IML EXCEPTION XXX YYY ZZZ	PD and ES
A2 MOSS RECOVERABLE ERROR, TRANSFER DUMP	PD and ES
A3 DISKETTE DOWN, DO NOT ATTEMPT TO IPL	PD and ES
A4 DISKETTE MEDIA ERROR	PD and ES
A6 MOSS OFFLINE, ALERT SENT	PD and ES
A7 HARDWARE ERROR, 3725 RE-IPL	PD and ES
A8 CONTROL PROGRAM ABEND XXXX, 3725 REIPL	PD and ES
A9 CHANNEL ADAPTER X DOWN	PD and ES
A10 GENERAL IPL CHECK	PD and ES
A11 SCANNER XX DOWN (LINES XXX-YYY) IML SCANNER	PD and ES
A12 SCANNER XX DOWN (LINES XXX-YYY) IML SCANNER	PD and ES
A13 SCANNER XX DOWN (LINES XXX-YYY) IML SCANNER	PD and ES
A14 SCANNER XX DOWN (LINES XXX-YYY) IML SCANNER	PD and ES
A15 LINE ADAPTER XXX DOWN	PD and ES
A28 TRM XX DOWN (TIC 1-4)	PD and ES
A29 TIC X DOWN ON TRM XX	PD and ES
A DELAYED DISPLAY OR ALTER HAS BEEN SPECIFIED	2-510
A SCANNER IS ALREADY SELECTED: RELEASE IT TO SELECT ANOTHER	2-510
ADDRESS COMPARE ALREADY SET: CANCEL IT OR WAIT FOR HIT	2-510
ADDRESS COMPARE ANOMALY: CANCEL ADDRESS COMPARE AND RETRY	2-510
ADDRESS COMPARE CANCELED ON OPERATOR REQUEST	2-510
ALL OR PART OF 'VERIFY DATA' IS OUTSIDE MODULE	2-500
ALTER COMPLETE	2-520
APPLIED ZAP CANNOT BE MODIFIED	2-500
AUTOMATIC DISPLAY BECAUSE OF ADDRESS COMPARE HIT	2-510
BER FILE IS UPDATED	2-500
BT BUFFER INCORRECTLY DEFINED	PD and ES
BUFFERS NOT AVAILABLE: WRAP TEST STOPPED	PD and ES
BUFFERS TEMPORARILY NOT AVAILABLE: WRAP FUNCTION CANCELED	PD and ES
CABLE DOES NOT EXIST	PD and ES
CABLE NOT INSTALLED	PD and ES
CA IPL DETECTED ON CA X	PD and ES
CANCELED: TARGET VALUE > END STEP NUMBER	PD and ES
CCU ERROR: WRAP TEST STOPPED	PD and ES
CCU FUNCTION NOT ALLOWED	2-500
CCU FUNCTION NOT ALLOWED NOW: MOUNT DISKETTE FIRST	2-500
CCU FNCTN REFUSED	PD and ES
CCU NOT IN THE RUN STATE (SEE MSA) - FUNCTION CANCELED	PD and ES
CCU/MOSS ERROR: AUTO SELECT NOT DISABLED	PD and ES
CCU/MOSS ERROR: AUTO SELECT NOT ENABLED	PD and ES
CCU/MOSS ERROR: BT BUFFER NOT ACCESSIBLE	PD and ES
CCU/MOSS ERROR: BT BUFFER NOT UPDATED	PD and ES
CCU/MOSS ERROR: CA CANNOT BE SELECTED	PD and ES
CCU/MOSS ERROR: CA REGISTER X'E' NOT ACCESSIBLE	PD and ES
CCU/MOSS ERROR: CA REGISTERS NOT ACCESSIBLE	PD and ES
CCU/MOSS ERROR: CA STATE NOT ACCESSIBLE	PD and ES
CCU/MOSS ERROR: CDF CREATION CANCELED	2-500
CCU/MOSS ERROR: CDF VERIFICATION CANCELED	2-500
CCU/MOSS ERROR: DISKETTE SWAP FAILED	2-500
CCU/MOSS ERROR: DUMP MAY BE INCOMPLETE	2-520
CCU/MOSS ERROR: FUNCTION NOT PERFORMED	2-510
CCU/MOSS ERROR: INITIAL CA CANNOT BE RESELECTED	PD and ES
CCU/MOSS ERROR: INPUT X'71', X'72' REG NOT ACCESSIBLE	PD and ES
CCU/MOSS ERROR: LINK TEST FUNCTION CANCELED	PD and ES
CCU/MOSS ERROR: MODE NOW UNKNOWN	2-520
CCU/MOSS ERROR: NOT CONNECTED	2-520
CCU/MOSS ERROR: STEP NOT EXECUTED	PD and ES
CCU/MOSS ERROR: TIC MODE NOT REPORTED	2-520
CCU/MOSS ERROR: TRA INTERRUPTS NOT ENABLED	2-520
CCU/MOSS ERROR: TRA SELECTED WITH UNKNOWN MODE	2-520
CCU/MOSS ERROR: WORK REGISTERS CANNOT BE ALTERED	PD and ES
CCU/MOSS ERROR: WRAP FUNCTION CANCELED	PD and ES
CCU/MOSS ERROR: ZAP FUNCTION CANNOT BE PERFORMED	2-500
CDF NOT CREATED: IPL PORT FUNCTION CANCELED	PD and ES

Message Directory (Part 2 of 4)

Messages	Details in:
CHANNEL ADAPTER NOT INSTALLED	PD and ES
CHECKPOINT TRACE SET XXX FOR LINE ADDRESS XXXX YYYYYYYY	2-510
CHJDMP DUMP FILE ALREADY CONTAINS A XXXX DUMP	2-510
COMMAND INCOMPATIBLE WITH SCANNER MODE: LOOK AT MSA	2-510
COMMAND REJECT RECEIVED DUE TO BUFFER OVERRUN	PD and ES
COMMAND REJECT RECEIVED DUE TO INVALID COMMAND	PD and ES
CONTROL PROGRAM LOADED	PD and ES
CONTROLLER DATA UNAVAILABLE, FUNCTION CANCELED	PD and ES
COPY COMPLETED	2-500
CS INOPERATIVE: CHECK CCU STATE AND IF NEEDED RE-IML CS	2-510
DATA MUST BE PAIRS OF HEX CHARS SEPARATED BY 1 BLANK	PD and ES
DATA RATE MUST NOT BE SPECIFIED WITH DIRECT-ATTACH	PD and ES
DELAYED ALTER PERFORMED BECAUSE OF ADDRESS COMPARE HIT	2-510
DISKETTE ERROR: BER FILE INCOMPLETELY RESTORED,	2-520
DISKETTE ERROR: CDF CREATION CANCELED	2-500
DISKETTE ERROR: CDF DISPLAY CANCELED	2-500
DISKETTE ERROR: CDF VERIFICATION CANCELED	2-500
DISKETTE ERROR: FUNCTION NOT PERFORMED	2-520
DISKETTE ERROR: DIRECTORY MAY BE DAMAGED	PD and ES
DISKETTE ERROR: DIRECTORY NOT ACCESSIBLE	PD and ES
DISKETTE ERROR: DUMP FUNCTION NOT AVAILABLE	2-520
DISKETTE ERROR: DUMP MAY BE INCOMPLETE	2-510
DISKETTE ERROR: FILE NOT FOUND	2-500
DISKETTE ERROR: FUNCTION CANCELED	PD and ES
DISKETTE ERROR: FUNCTION NOT AVAILABLE	2-510
DISKETTE ERROR: CLOSE NOT PERFORMED	2-520
DISKETTE ERROR: IML CANCELED	2-510
DISKETTE ERROR: IPL PORT FUNCTION CANCELED	PD and ES
DISKETTE ERROR: MLT FAILED	2-500
DISKETTE ERROR: PROCEDURE CANNOT BE FILED/MODIFIED	PD and ES
DISKETTE ERROR: PROCEDURE FILE MAY BE DAMAGED	PD and ES
DISKETTE ERROR: PROCEDURE NOT AVAILABLE	PD and ES
DISKETTE ERROR: REQUEST IGNORED	PD and ES
DISKETTE ERROR: SCANNER DUMP NOT AVAILABLE	2-510
DISKETTE ERROR: UNABLE TO LOAD FUNCTION MODULE	2-500
DISKETTE ERROR: WRAP FUNCTION CANCELED	PD and ES
DISKETTE ERROR: ZAP FNCTN CANCELED - MOUNT NORMAL DISKETTE	2-500
DISKETTE ERROR: ZAP FUNCTION CANCELED	2-500
DISKETTE STARTING	PD and ES
DISKETTE UNUSABLE	PD and ES
DISPLAY ADDRESS MODIFIED TO XXXX	2-520
DUMP CANCELED AS REQUESTED	2-520
DUMP COMPLETE	2-520
DUMP IN PROGRESS	2-520
DUMP IN PROGRESS ON CA XX	PD and ES
DUMP IN PROGRESS ON L XXX	PD and ES
DUMP FILE BEING TRANSFERRED: TRY LATER	2-510
DUMP FILED IN CHGTRSS: TO PRINT DUMP, TRANSFER IT TO HOST	2-520
DUMP FILED IN CHGDMP: TO PRINT DUMP, TRANSFER IT TO HOST	2-510
ENABLE COMMAND FAILED - LINK TEST FUNCTION CANCELED	PD and ES
ENABLE NOT ALLOWED: STOP THE CCU	PD and ES
ENABLED PORTS CA XXXXXX L XXXXXXXX	PD and ES
ENTER A DISPLAYED LINE PROTOCOL	PD and ES
ENTER A DISPLAYED LINE SPEED	PD and ES
ENTER A LINE ADDRESS WITHIN THE RANGE 0 TO 23	PD and ES
ENTER A LINE ADDRESS WITHIN THE RANGE 0 TO 255	PD and ES
ENTER ADDRESS WITHIN THE RANGE 0 TO 23	PD and ES
ENTER ADDRESS WITHIN THE RANGE 0 TO 255	PD and ES
ENTER ZAP IDENTIFICATION	2-500
ENTER MES NUMBER	PD and ES
ERROR DURING ERROR RECOVERY	PD and ES
ERROR GETTING TIC MODE: NOT REPORTED	2-520

Messages	Details in:
ERROR IN FRONT END SCANNER PROCESSOR	2-510
ERROR IN SCANNER DURING COMMAND PROCESSING	2-510
ERROR IN SCANNER: ICC/LIC FAILED OR IS NOT PRESENT	2-510
EXEC CANCELED ON OPERATOR REQUEST	PD and ES
EXEC CANCELED: OUTPUT X'71' REGISTER NOT ACCESSIBLE	PD and ES
'EXPECTED DATA' CANNOT BE ENTERED AFTER 'Y'	PD and ES
EXPECTED INTERRUPT NOT RECEIVED: FUNCTION CANCELED	2-520
FIRST STOP THE CCU	PD and ES
FORMAT CHECK	PD and ES
FUNCTION COMPLETED	PD and ES
FUNCTION IN PROGRESS	PD and ES
FUNCTION NOT AVAILABLE: TRY LATER	PD and ES
FUNCTION XX COMPLETED	PD and ES
FUNCTION XX IN PROGRESS	PD and ES
GCF IS INITIALIZED AND FILED	PD and ES
GCF UPDATE COMPLETED, GCF FILED ON DISKETTE	PD and ES
HARDWARE ERROR ON RECEIVE	PD and ES
HARDWARE ERROR ON TRANSMIT	PD and ES
IML FOR SCANNER XX COMPLETED	2-510
IML FOR SCANNER XX COMPLETED: SCANNER CAN BE CONNECTED	2-510
IML FOR SCANNER XX COMPLETED: SCANNER IS CONNECTED	2-510
IML FOR SCANNER XX IN PROGRESS	2-510
IML FOR SCANNER XX IN PROGRESS: CHECKOUT RETURN CODE= XXXX	2-510
INCOMPATIBLE OPTIONS: FULL DUPLEX AND NO DX FACILITY	PD and ES
INCOMPATIBLE OPTIONS: NON-SWITCHED LINE AND ANSWER TONE	PD and ES
INCOMPATIBLE OPTIONS: NON-SWITCHED LINE AND RING INDICATOR	PD and ES
INCOMPATIBLE OPTIONS: SWITCHED LINE AND DIRECT-ATTACH	PD and ES
INPUT CHECKSUM DOES NOT MATCH COMPUTED ONE	2-500
INPUT FOUND AGAINST MORE THAN ONE ZAP-ID	2-500
INPUT MUST BE PAIRS OF HEX CHARACTERS SEPARATED BY BLANKS	PD and ES
INPUT MUST BE 8 BINARY DIGITS	PD and ES
INSERT	PD and ES
INVALID	PD and ES
INVALID ACTION	PD and ES
INVALID ADDRESS FIELD RECEIVED	PD and ES
INVALID ADDRESS - RANGE IS 0 TO FFF (HEX)	2-520
INVALID ALTER REQUEST ON READ-ONLY STORAGE	2-510
INVALID BER RECORD n	2-500
INVALID CHANNEL ADAPTER NUMBER	PD and ES
INVALID CONTROL FIELD RECEIVED	PD and ES
INVALID DATA RECEIVED	PD and ES
INVALID DATA RECEIVED - TOO MUCH DATA RECEIVED	PD and ES
INVALID DATE	2-500
INVALID FILE NAME	2-500
INVALID FLAG VALUE	2-500
INVALID INPUT	2-500
INVALID INPUT: RE-ENTER FIELDS IN ERROR	2-520
INVALID INTERRUPT RECEIVED FROM TRA: FUNCTION CANCELLED	2-520
INVALID LINE ADDRESS	2-510
INVALID MODULE NAME	2-500
INVALID NUMBER OF HALWORDS: RANGE IS 1-48	2-520
INVALID SEL#	PD and ES
INVALID TTA DATA	2-500
IOC ERROR DURING ERROR RECOVERY	2-510
IOC/SCANNER ERROR: FUNCTION NOT PERFORMED	2-510
IOC/TRA ERROR: TRA SELECTED WITH UNKNOWN MODE	2-520
IOC/TRA ERROR: DUMP MAY BE INCOMPLETE	2-520
IOC/TRA ERROR: FUNCTION NOT PERFORMED	2-520
IOC/TRA ERROR: MODE NOW UNKNOWN	2-520
IOC/TRA ERROR: NOT CONNECTED	2-520
IOC/TRA ERROR: TRA INTERRUPTS NOT ENABLED	2-520
IPL CANCELED	PD and ES
IPL CHECK XXX	PD and ES
IPL CHECK FIB CLDP ABEND XXXX	PD and ES
IPL COMPLETE	PD and ES
IPL COMPLETE + ERRORS	PD and ES
IPL PORT TABLE UPDATED AND FILED	PD and ES
IPL STOP	PD and ES

Message Directory (Part 3 of 4)

Messages	Details in:
LASTMCHK: XXXX	PD and ES
LIC NOT INSTALLED	PD and ES
LINE ADDRESS DOES NOT BELONG TO AN INSTALLED SCANNER	2-510
LINE ADDRESS HAS ALREADY BEEN USED FOR ANOTHER LINK	PD and ES
LINE ADDRESS XXX IS ZZ IN SELECTED SCANNER XX	2-510
LINE CHECK 1	PD and ES
LINE CHECK 2	PD and ES
LINE NOT DISABLED /DEACTIVATED: WRAP FUNCTION CANCELED	PD and ES
LINE NOT YET INITIALIZED	PD and ES
LINE SPEED MAY BE 230 KBPS OR ABOVE	PD and ES
LINE SPEED MAY BE 230 KBPS OR ABOVE LEAD STATE NOT ACCIBLE	PD and ES
LINE NOT SYSTEM GENERATED: WRAP FUNCTION CANCELED	PD and ES
LINE TEMPORARILY NOT AVAILABLE: WRAP FUNCTION CANCELED	PD and ES
LINE TEST ACTIVE: WRAP FUNCTION CANCELED	PD and ES
LINE TRACE ACTIVE: WRAP FUNCTION CANCELED	PD and ES
LINK DISABLED - LINK TEST FUNCTION CANCELED	PD and ES
LINK IPL DETECTED ON L XXX	PD and ES
LINK NOT DEFINED IN IPL PORT TABLE	PD and ES
LINK TEST PROGRAM ABEND	PD and ES
LINK TEST PROGRAM LOADED	PD and ES
LINK TEST PROGRAM NOT LOADED - FUNCTION CANCELED	PD and ES
LOAD IN PROGRESS ON CA X	PD and ES
LOAD IN PROGRESS ON L XXX	PD and ES
LOCK-FORMAT CHECK	PD and ES
LOCK-LINE CHECK 1	PD and ES
LOCK-LINE CHECK 2	PD and ES
LOCK-RE-KEY	PD and ES
LOCK-SENDING	PD and ES
LOCK-SYSTEM COMMAND	PD and ES
LOOK AT MSA FOR ADDRESS COMPARE STATUS	2-510
LSSD NOT ON DISKETTE: CDS CREATION CANCELED	2-500
LSSD NOT ON DISKETTE: CDS VERIFICATION CANCELED	2-500
MICROCODE DETECTED ERROR DURING COMMAND PROCESSING	PD and ES
MLT ALREADY IN USE	2-500
MORE THAN 128 BYTES RECEIVED	PD and ES
MOSS IS NOT ALONE: 'CREATE' CDF NOT ALLOWED	2-500
MOSS IS NOT ALONE: 'VERIFY' CDF NOT ALLOWED	2-500
MOSS/TIC ERROR: FUNCTION CANCELLED	2-520
MOUNTED DISKETTE EC LEVEL IS DIFFERENT FROM ORIGINAL ONE	2-500
MOUNTED DISKETTE TYPE IS DIFFERENT FROM ORIGINAL ONE	2-500
NO ACKNOWLEDGE FROM TRA: MODE NOW UNKNOWN	2-520
NO ANSWER FROM CCU CONTROL PROGRAM: WRAP FUNCTION CANCELED	PD and ES
NO ANSWER FROM CONTROL PROGRAM: FUNCTION NOT PERFORMED	PD and ES
NO ANSWER FROM CONTROL PROGRAM: MODE NOW UNKNOWN	2-520
NO ANSWER FROM LINK TEST PROGRAM: FUNCTION CANCELED	PD and ES
NO ANSWER TO ERROR STATUS REQUEST DURING ERROR RECOVERY	2-510
NO CHANNEL ADAPTER SELECTED	PD and ES
NO CONTROL PROGRAM BUFFER: FUNCTION NOT PERFORMED	PD and ES
NO FILE TO SWAP - SWAP IS COMPLETED	2-500
NO FUNCTION VALUE	PD and ES
NO PROCEDURE TO CATALOG	PD and ES
NO SCANNER ANSWER: CHECK CCU STATE AND IF NEEDED RE-IML CS	2-510
NO SCANNER SELECTED	2-510
NO SELECTION MADE	2-500
NO SUPPORT FOR AUTOCALL LINE: WRAP FUNCTION CANCELED	PD and ES
NO SUPPORT FOR OEM LINE: WRAP FUNCTION CANCELED	PD and ES

Messages	Details in:
NO SWAP CHANGES: FUNCTION NOT SUPPORTED BY CTL PGM	PD and ES
NO SWAP CHANGES: MOSS IS NOT ONLINE	PD and ES
NO SWAP FILED	PD and ES
NO TRA'S INSTALLED: FUNCTION CANCELED	2-520
NO VALID SCANNER INSTALLED: FUNCTION CANCELED	PD and ES
NO VALID SCANNER INSTALLED: CDF CREATE CANCELED	2-500
NON-OPERATIONAL EP DUALCOM LINE: WRAP FUNCTION CANCELED	PD and ES
NOT ENOUGH SPACE IN ZAP AREA FOR ALL DATA	2-500
NOT ENOUGH SPACE IN ZAP AREA TO COPY ALL SELECTED ZAPS	2-500
NTRI/MOSS ERROR: FUNCTION CANCELLED	2-520
NTRI/MOSS ERROR: PRESS SEND TO CONTINUE	2-520
NTRI OFFLINE: FUNCTION IGNORED	2-520
PATTERN MUST CONTAIN AT LEAST 4 PAIRS OF HEX CHARACTERS	PD and ES
PRESS ATTN TO CANCEL ADDRESS COMPARE	2-510
PRESS ATTN TO STOP	PD and ES
PROCEDURE X CATALOGED	PD and ES
PROCEDURE X CREATED	PD and ES
PROCEDURE X ERASED	PD and ES
PROCEDURE X EXECUTED	PD and ES
PROCEDURE X MODIFIED	PD and ES
PROCEDURE IN STORAGE CANNOT BE EXECUTED	PD and ES
PROCEDURE NAME ALREADY USED	PD and ES
PROCEDURE NAME CANNOT START WITH CP	PD and ES
PROCEDURE NOT FOUND IN FILE	PD and ES
RECOVERY IN PROGRESS FOR ZAP XXXXXXXXXXXXX	2-500
RE-ENTER	PD and ES
REFRESH MODE: PRESS ATTN TO STOP REFRESH	2-520
REFUSED: CCU SIZE MUST BE 512, 768, OR 1024	2-500
REFUSED: DIRECTORY IS FULL	PD and ES
REFUSED: FILE SPACE EXCEEDED	PD and ES
REFUSED: INCOMPATIBLE LIC TYPES	PD and ES
REFUSED: a IS ALREADY SWAPPED WITH b	PD and ES
REFUSED: bbb IS UNKNOWN TO CONTROLLER	PD and ES
REFUSED: MAX NUMBER OF MESSAGES REACHED	PD and ES
REFUSED: MAX NUMBER OF STEPS REACHED	PD and ES
REFUSED: MAXIMUM NUMBER OF ZAPS REACHED	2-500
REFUSED: MEANINGLESS VALUES	PD and ES
REFUSED: THE FILE IS FULL, RESET A SWAP	PD and ES
REFUSED: ZAP AREA IS FULL	2-500
REFUSED BY CTL PGM: FUNCTION NOT SUPPORTED	PD and ES
REFUSED BY CTL PGM: a IS A SPARE	PD and ES
REFUSED BY CTL PGM: aaa IS EP LINE	PD and ES
REFUSED BY CTL PGM: aaa IS NON-IBM	PD and ES
REFUSED BY CTL PGM: b IS NOT A SPARE	PD and ES
REFUSED BY CTL PGM: aaa IS NOT INACTIVE	PD and ES
REFUSED BY CTL PGM: RESOURCE NOT AVAILABLE	PD and ES
REFUSED BY CTL PGM: UNDEFINED ERROR	PD and ES
RELEASED SCANNER IS IN RESET OR INOPERATIVE MODE	2-510
REQUEST IGNORED	PD and ES
REQUEST IGNORED: CCU NOT INITIALIZED	PD and ES
RESET CCU FAILED	PD and ES
RESET COMPLETED	PD and ES
RESET NOT ALLOWED	PD and ES
RESUME IGNORED	PD and ES
RESULTS UNPREDICTABLE - PF1 AGAIN TO CONFIRM, ELSE SEND	2-520
RPO DETECTED ON L XXX	PD and ES
SCANNER XX AUTOMATIC DUMP IN PROGRESS	2-510
SCANNER XX SELECTED: LOOK AT MSA FOR SCANNER MODE	2-510
SCANNER AC HIT BUT REQUESTED ACTION NOT PERFORMED	2-510
SCANNER AND/OR LINE TIME-OUT: WRAP TEST STOPPED	PD and ES
SCANNER CANNOT BE CONNECTED: MOSS IS NOT ONLINE	2-510
SCANNER CHECKOUT FAILED: RC = XXXX	2-510
SCANNER CONNECTED TO CCU CONTROL PROGRAM	2-510

Message Directory (Part 4 of 4)

Messages	Details in:
SCANNER CONNECTION REJECTED BY CCU CONTROL PROGRAM	2-510
SCANNER CYCLE STEAL TO/FROM CCU FAILED	2-510
SCANNER DUMP STARTED	2-510
SCANNER ERROR ON RECEIVE	PD and ES
SCANNER ERROR ON TRANSMIT	PD and ES
SCANNER HARDSTOP DURING COMMAND PROCESSING	PD and ES
SCANNER IN DISCONNECTED/GO MODE	2-510
SCANNER IN DISCONNECTED/STOP MODE	2-510
SCANNER IN RESET MODE	2-510
SCANNER NOT IML'ED - LINK TEST FUNCTION CANCELED	PD and ES
SCANNER NOT INSTALLED	PD and ES
SCANNER NOT OPERATIONAL - LINK TEST FUNCTION CANCELED	PD and ES
SCANNER x OVERLOADED (LINES x - y)	PD and ES
SCANNER PROCESSING RESUMED BUT SCANNER MODE IS UNKNOWN	2-510
SCANNER PROCESSING RESUMED THEN STOPPED ON AC HIT	2-510
SCANNER RELEASED BUT CURRENT MODE KEPT	2-510
SCANNER SELECTED BUT NO STATUS RECEIVED	2-510
SCANNER SELECTED BUT STATUS UNKNOWN	2-510
SCANNER TOTAL WEIGHT > 100	PD and ES
SCANNER(S) NOT IML'ED: XXXX	PD and ES
SCROLL IGNORED	2-520
SEL# RANGE LIMITED TO n	PD and ES
SELECT A FILE	2-500
SELECT A SCANNER	2-510
SELECT A TRA	2-520
SELECTED PROCEDURE IS FROM STORAGE	PD and ES
SELECTED TIC NOT AVAILABLE: REQUEST REJECTED	2-520
SENDING	PD and ES
SET MODE COMMAND FAILED - LINK TEST FUNCTION CANCELED	PD and ES
SPECIFY A DELAYED ALTER	2-510
SPECIFY A DELAYED DISPLAY	2-510
START CCU FAILED	PD and ES
START CCU IGNORED	PD and ES
START COMPLETED	PD and ES
START NOT ALLOWED	PD and ES
STEP 255 MUST BE THE END STATEMENT	PD and ES
STOP CCU COMPLETED	PD and ES
STOP CCU FAILED	PD and ES
STOP CCU IGNORED	PD and ES
STOP IGNORED	PD and ES
STOP NOT ALLOWED	PD and ES
STOP THE CCU THEN PRESS PF1 TO DISPLAY CA REGISTERS	PD and ES
STORE EXCEEDED (MAX 80 SECT.): USE 2 RUNS TO COPY FILES	2-500
SWAP COMPLETED	2-500
SWAP IS NOT ALLOWED, MOSS IS NOT OFFLINE	2-500
SWAP IS STARTED	2-500
a SWAP TO b	PD and ES
SYSTEM COMMAND	PD and ES
THE NAME OF THE PROCEDURE TO BE CATALOGED IS: XXXX	PD and ES
THIS BER IS NO LONGER IN THE BER FILE	2-500
TIC DUMP ALREADY EXISTS: AUTODUMP CANCELED	2-520
TIMEOUT ON RECEIVE	PD and ES
TIMEOUT ON TRANSMIT	PD and ES
TO ALTER DATA, SPECIFY AN IMMEDIATE DISPLAY	2-510
TO DELAY ALTER, ENTER NEW DATA, CHANGE I TO D, PRESS SEND	2-510
TOO MANY ZAPS SELECTED (WOULD EXCEED ZAP AREA CAPACITY)	2-500

Messages	Details in:
TOO MUCH DATA RECEIVED	PD and ES
TRA ALREADY CONNECTED: FUNCTION IGNORED	2-520
TRA ALREADY DISCONNECTED: FUNCTION IGNORED	2-520
TRA CAN NOT BE CONNECTED. MOSS IS NOT ONLINE.	2-520
TRA CONNECTED	2-520
TRA CONNECTION REJECTED BY CONTROL PROGRAM	2-520
TRA DISCONNECTED	2-520
TRA DISCONNECTED BUT ERROR RESETTING TRM REGS	2-520
TRA DISCONNECTED BUT NO CCU ACKNOWLEDGE	2-520
TRA DISCONNECTED BUT SOME TIC'S COULD NOT BE RESET	2-520
TRA DISCONNECTED WITH UNEXPECTED STATUS	2-520
TRA NOT DISCONNECTED: FUNCTION IGNORED	2-520
TRA SELECTED IS NOT INSTALLED: REQUEST REJECTED	2-520
TRA XX SELECTED: LOOK IN MSA FOR MODE	2-520
TRANSMISSION ERROR ON RECEIVE	PD and ES
TRANSMISSION ERROR ON TRANSMIT	PD and ES
UNABLE TO SET LINE TO WRAP MODE: WRAP FUNCTION CANCELED	PD and ES
UNABLE TO SET TIC STORAGE BOUNDARY	2-520
UNDEFINED PF KEY	2-500
UNEXPECTED SCANNER INTERRUPT: PRESS SEND TO RETRY	2-510
UNEXPECTED INTERRUPT RECEIVED: KEYBOARD INPUT IGNORED	2-520
UPDATE HIGHLIGHTED FIELDS, PRESS SEND	2-520
UPSHIFT	PD and ES
VERIFICATION NOT ALLOWED: MOSS MUST BE IN ALONE STATUS	2-500
'VERIFY DATA' AND 'REPLACE DATA' HAVE DIFFERENT LENGTHS	2-500
'VERIFY DATA' DOES NOT MATCH MODULE DATA	2-500
WARNING: AT LEAST ONE TARGET VALUE > END STEP NUMBER	PD and ES
WARNING: INCOMPATIBLE LINE PROTOCOLS, PRESS SEND TO BYPASS	PD and ES
WRAP FUNCTION CAN BE TERMINATED ONLY BY USING PF2	PD and ES
WRAP FUNCTION CANCELED ON OPERATOR REQUEST	PD and ES
WRAP FUNCTION COMPLETED	PD and ES
WRAP TEST COMPLETED	PD and ES
WRAP TEST STOPPED ON OPERATOR REQUEST	PD and ES
YOU CANNOT TERMINATE WRAP FUNCTION	PD and ES
ZAP ALREADY APPLIED	2-500
ZAP ALREADY EXISTS	2-500
ZAP APPLIED	2-500
ZAP APPLIED BUT NOT RECORDED IN HISTORY TABLE (TABLE FULL)	2-500
ZAP AREA IS NOW FULL	2-500
ZAP AREA OF NORMAL DISKETTE IS EMPTY	2-500
ZAP FILED	2-500
ZAP FUNCTION CANNOT BE PERFORMED WHEN MOSS IS ONLINE	2-500
ZAP FUNCTION TERMINATION NOT ALLOWED	2-500
ZAP IS NOT APPLIED	2-500
ZAP NOT APPLICABLE: BAD CHECKSUM	2-500
ZAP NOT APPLIED: DISKETTE ERROR WHILE CHECKING ZAP DATA	2-500
ZAP NOT APPLIED: ZAP DATA DO NOT MATCH MODULE DATA	2-500
ZAP NOT RESTORED: DISKETTE ERROR WHILE CHECKING ZAP DATA	2-500
ZAP NOT RESTORED: ZAP DATA DO NOT MATCH MODULE DATA	2-500
ZAP RESTORED	2-500
ZAPS OF NORMAL DISKETTE ARE ALL PRESENT ON SPARE DISKETTE	2-500
ZAP XXXXXXXXXXXXX ERASED	2-500
XX BYTES ALTERED	2-510

Utility Program Messages (Part 1 of 5)

ALL OR PART OF 'VERIFY DATA' IS OUTSIDE MODULE

Explanation: Considering the specified address, the 'VERIFY' data is outside the module.

Action: Either you entered too many bytes of 'VERIFY' data or the specified address is wrong. Make appropriate changes.

APPLIED ZAP CANNOT BE MODIFIED

Explanation: You entered 'M' against the ZAP-ID of an applied ZAP. The command is ignored.

Action: Enter 'R' to restore the ZAP, then enter 'M' to modify it.

BER FILE IS UPDATED

Explanation: BER flag is updated on diskette

Action: None

CCU FUNCTION NOT ALLOWED

Explanation: CCU functions are not available from the time the diskette mounting is requested until the original diskette is remounted.

Action: None.

CCU FUNCTION NOT ALLOWED NOW: MOUNT DISKETTE FIRST

Explanation: CCU functions are not allowed when diskette mounting is requested.

Action: Mount appropriate diskette.

CCU/MOSS ERROR: CDF CREATION CANCELED

Explanation: Error in hardware feature description (type, address, characteristics) when creating the configuration data file.

Action: See BER file.

CCU/MOSS ERROR: CDF VERIFICATION CANCELED

Explanation: Error in hardware feature description (type, address, characteristics) when verifying the configuration data file.

Action: See BER file

CCU/MOSS ERROR: DISKETTE SWAP FAILED

Explanation: MIOC end occurred. A BER is created.

Action: See BER type and ID

CCU/MOSS ERROR: ZAP FUNCTION CANNOT BE PERFORMED

Explanation: Self-explanatory.
A BER is created.

Action: Power-off the machine then power-on and perform a general IPL. If a CCU/MOSS error is detected during IPL then the MIOC adapter must be fixed.

COPY COMPLETED

Explanation: Self-explanatory.

Action: Apply ZAPs to be applied, and press PF2 to come back to the normal diskette.

DISKETTE ERROR: CDF CREATION CANCELED

Explanation: Error when using diskette

Action: See BER file

DISKETTE ERROR: CDF DISPLAY CANCELED

Explanation: Error when using diskette

Action: See BER file

DISKETTE ERROR: CDF VERIFICATION CANCELED

Explanation: Error when using diskette

Action: See BER file

DISKETTE ERROR: FILE NOT FOUND

Explanation: This file does not exist

Action: Enter the correct file name

DISKETTE ERROR: MLT FAILED

Explanation: Diskette error occurred while accessing the MLT file. The MLT function is canceled.

Action: Retry. If still unsuccessful, check the diskette.

DISKETTE ERROR: UNABLE TO LOAD FUNCTION MODULE

Explanation: Something is wrong with the diskette drive or the diskette.

Action: See BER file.

Utility Program Messages (Part 2 of 5)

DISKETTE ERROR: ZAP FNCTN CANCELED - MOUNT NORMAL DISKETTE

Explanation: A physical error occurred when using the SPARE diskette. The ZAP function is canceled. A BER is created.

Action: Mount normal diskette, select ZAP function, and retry the operation during which the error occurred. If the error occurs again, the spare diskette is out of order.

DISKETTE ERROR: ZAP FUNCTION CANCELED

Explanation: A physical error occurred when accessing the diskette. The ZAP function is canceled. A BER is created.

Action: Select ZAP function again. If the problem recurs, the diskette is out of order. Mount the SPARE diskette and re-IML MOSS.

ENTER ZAP IDENTIFICATION

Explanation: The ZAP create function has been selected. You are requested to enter the ZAP identification.

Action: Enter the ZAP identification, then press ENTER, or press QUIT (PF3) to leave the create function.

INPUT CHECKSUM DOES NOT MATCH COMPUTED ONE

Explanation: The checksum you entered does not match the checksum that has been calculated by the ZAP utility program using the ZAP data and ZAP identification.

Action: Correct the checksum if it is wrong, or:

- Press PF1 to check the ZAP records and correct error if any, or
- Press PF2 to file the ZAP with the BAD CHECKSUM status

INPUT FOUND AGAINST MORE THAN ONE ZAP-ID

Explanation: You tried to select several ZAPs.

Action: Blank out all your commands except one.

INVALID BER RECORD

Explanation: The BER record is too short or too long.

Action: None.

INVALID DATE

Explanation: Self-explanatory.

Action: Enter today's date.

INVALID FILE NAME

Explanation: The name you entered is not the name of a module file.

Action: Provide a correct file name.

INVALID FLAG VALUE

Explanation: You entered a non-hexadecimal value.

Action: Enter the correct value.

INVALID INPUT

Explanation: You did one of the following:

- You pressed SEND before entering the requested input on a screen
- You entered one or more invalid characters
- You entered an invalid value, for example, an address outside the specified range,
- You made a formatting error, or
- You entered a command which is not valid at this time.

Action: Do one of the following:

- Correct the erroneous input, or
- Press one of the PF keys displayed on the screen, if any.

INVALID MODULE NAME

Explanation: The module you does not exist in the specified file.

Action: Provide a correct module name or change the file name.

INVALID TTA DATA

Explanation: The conversion of data through the translate table area (TTA) is not possible.

Action: None.

LSSD NOT ON DISKETTE: CDF VERIFICATION CANCELED

Explanation: Level-sensitive scan design (LSSD) is not on diskette (should never occur).

Action: Return the diskette to manufacturing.

LSSD NOT ON DISKETTE: CDF CREATION CANCELED

Explanation: Level-sensitive scan design (LSSD) is not on diskette (should never occur).

Action: Return the diskette to manufacturing.

MLT ALREADY IN USE

Explanation: MLT file is being transferred to the host, so it cannot be accessed by the MLT function.

Action: None

MOSS IS NOT ALONE: 'CREATE' or 'VERIFY' CDF NOT ALLOWED

Explanation: Self-explanatory

Action: Perform a power-on reset (POR)

Utility Program Messages (Part 3 of 5)

MOUNTED DISKETTE EC LEVEL IS DIFFERENT FROM ORIGINAL ONE

Explanation: You mounted a diskette that does not have the same EC level as the diskette from which MOSS was IMLed.

Action: Mount correct diskette or, if none is available, remount original diskette and press PF2 again.

MOUNTED DISKETTE TYPE IS DIFFERENT FROM ORIGINAL ONE

Explanation: You mounted a diskette that is not of the same type (CONTROLLER or SERVICE) as the diskette from which MOSS was IMLed.

Action: Mount correct diskette or, if none is available, remount original diskette and press PF2 again.

NO FILE TO SWAP - SWAP IS COMPLETED

Explanation: You did not specify a file to be copied. The swap function is completed.

Action: None.

NO SELECTION MADE

Explanation: You did not specify which ZAPs you want to COPY or RESTORE.

Action: Specify ZAPs as indicated on the screen.

NO VALID SCANNER INSTALLED: CDF CREATE CANCELED

Explanation: Following a CDF create function, no scanner has been found on the machine.

Action: Check the machine configuration.

NOT ENOUGH SPACE IN ZAP AREA FOR ALL DATA

Explanation: The ZAP record you have just entered is not accepted as there is not enough room left in the ZAP area.

Action: Press PF2 to save the ZAP records that have already been entered. Use the ERASE function to make room in the ZAP area, then select the MODIFY function to complete the ZAP.

NOT ENOUGH SPACE IN ZAP AREA TO COPY ALL SELECTED ZAPS

Explanation: The space left in the ZAP area of the mounted diskette is not sufficient to contain the selected ZAPs.

Action: Use the ERASE function to make room in the ZAP area and restart COPY.

RECOVERY IN PROGRESS FOR ZAP XXXXXXXXXXXXX

Explanation: ZAP XXXXXXXXXXXXX has been partially applied (or restored) because of a MOSS check occurring during an APPLY (or RESTORE) operation. This situation is being recovered.

Action: Wait and see.

REFUSED: CCU SIZE MUST BE 512, 768, OR 1024

Explanation: CDF update with CCU storage size is not correct.

Action: Assign 512, 768, or 1024.

REFUSED: MAXIMUM NUMBER OF ZAPS REACHED

Explanation: No new ZAP can be created as the maximum number of ZAPs filed in the ZAP area is reached.

Action: Use the ERASE ZAP function to erase ZAP(s).

REFUSED: ZAP AREA IS FULL

Explanation: No new ZAP can be created as the ZAP area is full.

Action: Make room in the ZAP area by erasing ZAPs (use the 'ERASE ZAP' function).

SELECT A FILE

Explanation: Self-explanatory.

Action: As requested by message.

STORE EXCEEDED (MAX 75 SECTORS): USE TWO RUNS TO COPY FILES

Explanation: The total amount of data to be copied exceeds 75 sectors.

Action: Copy the files in two runs.

SWAP COMPLETED

Explanation: Self-explanatory.

Action: None.

SWAP IS NOT ALLOWED, MOSS IS NOT OFFLINE

Explanation: The SWAP functions cannot be performed because MOSS is in 'online' status.

Action: Use CCU function 5 to set MOSS offline.

SWAP IS STARTED

Explanation: This message is issued after having selected the file to be copied. It disappears when the SWAP functions request a diskette to be mounted.

Action: None.

Utility Program Messages (Part 4 of 5)

THIS BER IS NO LONGER IN THE BER FILE

Explanation: BER has been overlapped.

Action: None.

TOO MANY ZAPS SELECTED (WOULD EXCEED ZAP AREA CAPACITY)

Explanation: The number of ZAPs in the ZAP area of the mounted diskette plus the number of ZAPs to be copied exceed the ZAP area capacity.

Action: Select the ERASE function to decrease the number of ZAPs in the ZAP area and restart COPY.

UNDEFINED PF KEY

Explanation: You pressed a PF key that is not displayed on the screen.

Action: Do one of the following:

Press one of the PF keys displayed on the screen, if any, or

Enter requested input.

'VERIFY DATA' AND 'REPLACE DATA' HAVE DIFFERENT LENGTHS

Explanation: Self-explanatory.

Action: Enter as many bytes of REPLACE data as there are bytes of VERIFY data.

'VERIFY DATA' DOES NOT MATCH MODULE DATA

Explanation: The VERIFY data you entered is not found at the specified address in the specified module.

Action: Enter correct data.

ZAP ALREADY APPLIED

Explanation: You entered 'A' against the ZAP-ID of an already applied ZAP. The command is ignored.

Action: None.

ZAP ALREADY EXISTS

Explanation: You selected CREATE then you provided the ID of an existing ZAP.

Action: Provide another ZAP-ID, or use MODIFY instead of CREATE, or erase existing ZAP.

ZAP APPLIED

Explanation: The APPLY function is completed.

Action: None.

ZAP APPLIED BUT NOT RECORDED IN HISTORY TABLE (TABLE FULL)

Explanation: The ZAP has been applied in the microcode load module, but no record has been put in the MLT.

Action: None.

ZAP AREA IS NOW FULL

Explanation: ZAP data that you entered is accepted. The ZAP area is now full, and you cannot enter more data.

Action:

1. Press PF2 to file what you already entered.

2. If the ZAP is complete, no other action is required.

If the ZAP is not complete, clear some space in the ZAP area. To do so, use the ERASE function, and select MODIFY to complete the ZAP.

ZAP AREA OF NORMAL DISKETTE IS EMPTY

Explanation: You selected COPY but no ZAPs are to be copied.

Action: None.

ZAP FILED

Explanation: The ZAP you have just created or modified has been filed (that is, saved in the ZAP area on the diskette).

Action: None.

ZAP FUNCTION CANNOT BE PERFORMED WHEN MOSS IS ONLINE

Explanation: Self-explanatory.

Action: Select CCU FUNCTION 5 to set MOSS offline.

Utility Program Messages (Part 5 of 5)

ZAP FUNCTION TERMINATION NOT ALLOWED

Explanation: Termination of ZAP function is not accepted from the moment you selected 'UPDATE SPARE DISKETTE' until you return to the original diskette.

Action: Mount diskette if requested or press PF2 to return to original diskette.

ZAP IS NOT APPLIED

Explanation: You entered 'R' against the ZAP-ID of a non applied ZAP. The command is ignored.

Action: None.

ZAP NOT APPLICABLE: BAD CHECKSUM

Explanation: You entered 'A' against the ZAP-ID of a ZAP that has the BAD CHECKSUM status. Such a ZAP is not applicable.

Action: Modify the ZAP, correct any error in the ZAP records, or enter the good checksum in order to file this ZAP with the NON-APPLIED status. Then, apply the ZAP.

ZAP NOT APPLIED: DISKETTE ERROR WHILE CHECKING ZAP DATA

Explanation: The ZAP cannot be applied because of a diskette error.

Action: See whether a BER has been created or not. If YES, the message is due to a physical diskette error. If NO, this means that ZAP data has been damaged on the diskette. In this case:

1. Erase the ZAP
2. Recreate it (or recopy it on the spare diskette)
3. Apply it

ZAP NOT APPLIED: ZAP DATA DO NOT MATCH MODULE DATA

Explanation: Before applying a ZAP, the ZAP utility checks that the VERIFY data matches the module data. This checking has failed.

Action: Verify that the prerequisite ZAPs have been applied. Apply them if necessary.

This message may also mean that the ZAP data has been damaged on the diskette. In this case, check the ZAP by using the modify function and entering the 'A' (ALTER) command for each record.

ZAP NOT RESTORED: DISKETTE ERROR WHILE CHECKING ZAP DATA

Explanation: The ZAP cannot be restored because of a diskette error.

Action: See whether a BER has been created or not. If YES, the message is due to a physical diskette error. If NO, this means that ZAP data has been damaged on the diskette. The restore function cannot be performed and the diskette may be considered as out of order.

ZAP NOT RESTORED: ZAP DATA DO NOT MATCH MODULE DATA

Explanation: Before restoring a ZAP, the ZAP utility checks that the RESTORE data match the module data. This checking has failed.

Action: Verify that no other ZAP, for which this ZAP is prerequisite, has been restored first by mistake.

This message may also mean that the ZAP data has been damaged on the diskette. The restore function cannot be performed and the diskette may be considered as out of order.

ZAP RESTORED

Explanation: The RESTORE function is completed.

Action: None.

ZAPS OF NORMAL DISKETTE ARE ALL PRESENT ON SPARE DISKETTE

Explanation: Self-explanatory.

Action: If ZAPs have to be copied again, for example because they have been modified, erase them first from the spare diskette, then select the copy function (PF1).

ZAP XXXXXXXXXXXX ERASED

Explanation: Self-explanatory.

Action: None.

TSS Function Messages (Part 1 of 5)

A DELAYED DISPLAY OR ALTER HAS BEEN SPECIFIED

Explanation: The delayed operation that you entered has been validated and recorded. It can be used with address compare or snapshot trace functions.

Action: None.

A SCANNER IS ALREADY SELECTED: RELEASE IT TO SELECT ANOTHER

Explanation: You tried to select a scanner while one is already selected.

Action: Release the scanner currently selected, then retry the selection.

ADDRESS COMPARE ALREADY SET: CANCEL IT OR WAIT FOR HIT

Explanation: You tried to define an address compare operation while one was already set in the scanner.

Action: Cancel the current address compare, or wait for hit, which cancels the current address compare (except if action is 'STOP SCANNER AND LEAVE AC ACTIVE').

ADDRESS COMPARE ANOMALY: CANCEL ADDRESS COMPARE AND RETRY

Explanation: An abnormal situation has been detected in the address compare mechanism.

Action: Cancel the address compare and set it again. If the error persists, run diagnostics to isolate the error.

ADDRESS COMPARE CANCELED ON OPERATOR REQUEST

Explanation: You canceled the address compare operation.

Action: None.

AUTOMATIC DISPLAY BECAUSE OF ADDRESS COMPARE HIT

Explanation: You specified a delayed display which just appeared on the screen, due to an address compare hit.

Action: None.

CCU/MOSS ERROR: FUNCTION NOT PERFORMED

Explanation: The function that you selected cannot be performed because of a MOSS-to-CCU hardware error.
A BER is created: Type 01, ID 02.

Action: Terminate the function.

CHECKPOINT TRACE SET XXX FOR LINE ADDRESS YYY LLLLLLLL

Explanation: (XXX is either ON or OFF, YYY is the line address, LLLLLLLL is either TRANSMIT OR RECEIVE). You specified or removed (OFF) the checkpoint option to the scanner interface trace for the line interface address specified. This option becomes effective (only ON) when the corresponding scanner interface trace is started from the host.

Action: None.

COMMAND INCOMPATIBLE WITH SCANNER MODE: LOOK AT MSA

Explanation: You specified a command that cannot be executed when the scanner is in the mode 'displayed on MSA'.

Action: As requested by message.

DELAYED ALTER PERFORMED BECAUSE OF ADDRESS COMPARE HIT

Explanation: You specified a Delayed Display which just appeared on the screen, due to an address compare hit.

Action: None.

DISKETTE ERROR: DUMP MAY BE INCOMPLETE

Explanation: A diskette hardware error occurred during the scanner dump: the dump has been truncated.

Action: Use Dump Display functions to look at the dump and determine its real upper limit.

DISKETTE ERROR: FUNCTION NOT AVAILABLE

Explanation: The function that you selected is not available because of a hardware error on the diskette.

A BER is created: Type 01, ID 03.
Alarm A3 is displayed.

Action: Retry or terminate the function.

DISKETTE ERROR: IML CANCELED

Explanation: The scanner microcode is not accessible because of a hardware error on the diskette. The IML is canceled.

Action: Terminate the function.

TSS Function Messages (Part 2 of 5)

DISKETTE ERROR: SCANNER DUMP NOT AVAILABLE

Explanation: A diskette hardware error occurred at the beginning of scanner dump. The dump is not available.

Action: Terminate the function.

DUMP FILE BEING TRANSFERRED: TRY LATER

Explanation: You requested a scanner dump while the current dump file on the diskette was being transferred on host request.

Action: Try later.

DUMP FILED IN CHGDMP: TO PRINT DUMP, TRANSFER IT TO HOST

Explanation: The scanner or TIC dump that you requested is complete and ready to be transferred on host request.

Action: Notify the host operator.

ERROR IN FRONT END SCANNER PROCESSOR

Explanation: A scanner hardware error is detected. The function cannot be performed.

A BER is created: Type 01, ID 05.

Action: Terminate the function.

ERROR IN SCANNER DURING COMMAND PROCESSING

Explanation: A scanner hardware error is detected. The function cannot be performed.

A BER is created: Type 01, ID 05.

Action: Terminate the function.

ERROR IN SCANNER: ICC/LIC FAILED OR IS NOT PRESENT

Explanation: A scanner hardware error is detected. The function cannot be performed.

A BER is created: Type 01, ID 05.

Action: Terminate the function:

Use the GCF utility to display and check for the presence of the LIC corresponding to the line interface address that you specified.

IML FOR SCANNER XX COMPLETED

Explanation: The scanner IML that you requested is complete. The scanner is initialized but cannot be set operational because MOSS is not in 'online' status. MSA field m displays: 'SCANNER XX INITIALIZED'.

Action: Set MOSS online if appropriate, then go to TSS functions.

IML FOR SCANNER XX COMPLETED: SCANNER CAN BE CONNECTED

Explanation: The scanner IML that you requested is complete. The scanner is initialized but not yet operational. MSA field m displays: 'SCANNER XX INITIALIZED'.

Action: Use function 3 (bypass phase 1 IPL) to connect logically the scanner to the CCU control program.

IML FOR SCANNER XX COMPLETED: SCANNER IS CONNECTED

Explanation: The scanner is operational and under control of the CCU control program. MSA field m displays: 'SCANNER XX CONNECTED'.

Action: None.

IML FOR SCANNER XX IN PROGRESS

Explanation: The IML of scanner XX is being processed normally.

Action: None.

INVALID ALTER REQUEST ON READ-ONLY STORAGE

Explanation: You tried an alter operation on a ROS address in the scanner.

Action: None.

INVALID LINE ADDRESS

Explanation: The line address that you entered is not within the range 0 through 255.

Action: Check the line address, and enter it again.

ISS Function Messages (Part 3 of 5)

IOC ERROR DURING ERROR RECOVERY

Explanation: The scanner is not able to process the MOSS command. An IOC error was detected during the error recovery.

A BER is created: Type 01, ID 05.

Action: Re-IML the appropriate scanner.

IOC/SCANNER ERROR: FUNCTION NOT PERFORMED

Explanation: A hardware error is detected either in the scanner or in the IOC bus. The MOSS command cannot be performed.

A BER is created: Type 01, ID 05.

Action: Terminate the function.

LINE ADDRESS DOES NOT BELONG TO AN INSTALLED SCANNER

Explanation: There is no installed scanner corresponding to the line address that you entered.

Action: Check the line address and enter it again.

LINE ADDRESS XXX IS ZZ IN SELECTED SCANNER XX

Explanation: You selected the scanner XX by specifying the line address ZZ.

Action: None.

LOOK AT MSA FOR ADDRESS COMPARE STATUS

Explanation: The address compare operation you specified is now set. The MSA displays the status of the operation.

Action: None.

NO ANSWER TO ERROR STATUS REQUEST DURING ERROR RECOVERY

Explanation: The scanner is not able to process the MOSS command; it did not answer during error recovery.

A BER is created: Type 01, ID 05.

Action: Re-IPL the CCU/scanner.

NO SCANNER ANSWER: CHECK CCU STATE AND IF NEEDED RE-IML CS

Explanation: The scanner cannot answer MOSS commands because of the CCU or the scanner.

Action: Do one of the following:

- If CCU/Scanner not IPLed, IPL it and retry.
- Perform the CCU Reset All function, IML the scanner, and retry.

In both cases, the CCU state must be RUN or STOP-PGM. See MSA field g.

NO SCANNER SELECTED

Explanation: You tried to release a scanner, but no scanner is selected.

Action: None.

PRESS ATTN TO CANCEL ADDRESS COMPARE

Explanation: You specified an address compare operation with the Display or Alter action.

Action: Wait for hit, which cancels the current address compare

OR:

Press ATTN to force AC cancel.

REFRESH MODE: PRESS ATTN TO STOP

Explanation: You requested the refresh mode of the currently displayed data.

Action: Press ATTN to stop.

RELEASED SCANNER IS IN RESET OR INOPERATIVE MODE

Explanation: You released the selected scanner, which is in one of the following modes:

- RESET mode: Not operational for CCU control program.
- INOPERATIVE mode: Not operational for MOSS functions, may be operational for CCU control program. Action:
- RESET mode: Dump or IML the Scanner.
- INOPERATIVE mode: Select the scanner again. If it is selected with 'NO STATUS RECEIVED' or 'STATUS UNKNOWN', IML the scanner.

SCANNER AC HIT BUT REQUESTED ACTION NOT PERFORMED

Explanation: An address compare hit occurred for the operation that you specified, but the requested action did not take place because of a scanner error.

A BER is created: Type 01, ID 05.

Action: Terminate the function.

SCANNER CANNOT BE CONNECTED: MOSS IS NOT ONLINE

Explanation: Self-explanatory.

Action: Set MOSS online and re-IML the scanner:

SCANNER CHECKOUT FAILED: RC = XXXX

Explanation: A hardware error is detected in the scanner. The IML cannot be performed.

A BER is created: Type 01, ID 05.

Action:

1. Terminate the function.
2. Re-IPL CCU/scanner and retry.

TSS Function Messages (Part 4 of 5)

SCANNER CONNECTED TO CCU CONTROL PROGRAM

Explanation: The scanner is now operational; and the CCU control program can use it.

Action: None.

SCANNER CONNECTION REJECTED BY CCU CONTROL PROGRAM

Explanation: The scanner that you IMLed is not recognized by the CCU control program (the scanner is not operational).

A BER is created: Type 01, ID 05.

Action: Terminate the function using function terminate.

SCANNER CYCLE STEAL TO/FROM CCU FAILED

Explanation: The scanner is not able to exchange data with the CCU. The scanner recovery failed. The error is either a hardware error or a scanner microcode error (incorrect cycle steal parameters).

A BER is created: Type 01, ID 05.

Action:

1. Re-IML the appropriate scanner.
2. If the error persists, re-IPL the CCU/scanner.

SCANNER DUMP STARTED

Explanation: The scanner dump function found an empty dump file and started dump processing.

Action: None.

SCANNER IN DISCONNECTED/GO MODE

Explanation: The 'START' command is now processed. The scanner resumed the microcode execution; but stays unavailable to the CCU control programs.

Action: None.

SCANNER IN DISCONNECTED/STOP MODE

Cause: The 'STOP' command is processed. The scanner microcode execution is suspended. The scanner becomes unavailable to the CCU control program, and "listens" to the following MOSS request.

Action: None.

SCANNER IN RESET MODE

Explanation: The 'RESET' command is performed. The scanner is ready to be IMLed or dumped.

Action: None.

SCANNER PROCESSING RESUMED BUT SCANNER MODE IS UNKNOWN

Explanation: The 'START' is complete, but MOSS is not able to determine the scanner mode.

Action: Release the scanner and reselect.

SCANNER PROCESSING RESUMED THEN STOPPED ON AC HIT

Explanation: The 'START' command has been executed. The scanner resumed the microcode execution, but this execution has been stopped by an address compare hit.

Action: None.

SCANNER RELEASED BUT CURRENT MODE KEPT

Explanation: You released the selected scanner, which is left in its current mode.

Action: None.

SCANNER SELECTED BUT NO STATUS RECEIVED

Explanation: The scanner that you want to select is already selected, but was not able to provide its current mode to MOSS. Three BERs are created:

Type 1, ID 01
Type 1, ID 03
Type 1, ID 02

Action: None.

SCANNER SELECTED BUT STATUS UNKNOWN

Explanation: The scanner that you want to select is already selected, but provided MOSS with an unknown status.

Action: Re-IML, or proceed according to the function you want to perform.

SCANNER XX AUTOMATIC DUMP IN PROGRESS

Explanation: An automatic dump has been started, due to a BER generated by the control program.

Action: Wait until completion message. Then transfer it to the host as indicated by the completion message.

SCANNER XX SELECTED: LOOK AT MSA FOR SCANNER MODE

Explanation: The scanner that you want to select is already selected. Its current mode is displayed in MSA.

Action: As requested by message.

TSS Function Messages (Part 5 of 5)

SELECT A SCANNER

Explanation: You selected a TSS function without having selected a scanner.

Action: Select a scanner.

SPECIFY A DELAYED ALTER

Explanation: You requested an address compare function with action 'START DELAYED ALTER', but did not specify the delayed alter operation.

Action: Specify the delayed alter operation, and resume address compare.

SPECIFY A DELAYED DISPLAY

Explanation: You requested an address compare function with action 'START DELAYED ALTER', but did not specify the delayed alter operation.

Action: Specify the delayed display operation, and resume address compare.

TO ALTER DATA, SPECIFY AN IMMEDIATE DISPLAY

Explanation: You selected a display alter function. If you want to alter data, you must first display it.

Action: None.

TO DELAY ALTER, ENTER NEW DATA, CHANGE I TO D, PRESS SEND

Explanation: You selected the alter subfunction.

Action: As requested by message.

UNEXPECTED SCANNER INTERRUPT: PRESS SEND TO RETRY

Explanation: MOSS received a scanner interrupt on a command where no interrupt is expected.

A BER is created: Type 01, ID 05.

Action: Retry the command.

XX BYTES ALTERED

Explanation: You specified an immediate alter operation: XX bytes have been changed in scanner (control store, control blocks, local store, or external registers).

Action: None.

TRSS Function Messages (Part 1 of 4)

ALTER COMPLETE.

Explanation: Alter of register has been done.

ACTION: None.

CCU/MOSS ERROR: DUMP MAY BE INCOMPLETE.

Explanation: A complete TIC dump could not be taken because of an MIOC failure. A BER is created: 01 02. The DUMP SWAP cannot be performed.

ACTION: Retry or terminate function and use dump display function to look at dump and determine its real upper limit.

CCU/MOSS ERROR: TRA SELECTED WITH UNKNOWN MODE.

Explanation: Unsuccessful read of level 1 error status reg from the TIC due to MIOC failure. A BER is created: 01 02.

ACTION: Retry or continue.

CCU/MOSS ERROR: MODE NOW UNKNOWN.

Explanation: An MIOC error caused the TRA to be put in an intermediate or unknown state during the connect or disconnect. A BER is created: 01 02.

ACTION: Retry, terminate function, or continue with caution.

CCU/MOSS ERROR: NOT CONNECTED.

Explanation: An MIOC error during TRA start command caused termination of the connect operation. A BER is created: 01 02.

ACTION: Retry or terminate function.

CCU/MOSS ERROR: TIC MODE NOT REPORTED.

Explanation: An MIOC error occurred while trying to read the TIC mode from NTRI. A BER is created: 01 02.

ACTION: Continue or terminate function.

CCU/MOSS ERROR: TRA INTERRUPTS NOT ENABLED.

Explanation: An MIOC error prevented the TRA unmask command from being sent. A BER is created: 01 07.

ACTION: Terminate function or continue with caution.

DISKETTE ERROR: DUMP FUNCTION NOT AVAILABLE.

Explanation: The disk is inoperative or a physical disk I/O error occurred. A BER is created: 01 03. Alarm A3 is displayed.

ACTION: Retry or terminate function.

DISKETTE ERROR: DUMP MAY BE INCOMPLETE.

Explanation: A complete TIC dump could not be taken because of a diskette hardware error. A BER is created: 01 03. Alarm A3 is displayed.

ACTION: Use dump display functions to look at dump and determine its real upper limit.

DISKETTE ERROR: FUNCTION NOT PERFORMED.

Explanation: Overlay was not loaded properly. Bad return code from disk CAC. A BER is created: 01 03. Alarm A3 is displayed.

ACTION: Retry or terminate.

DISKETTE ERROR: CLOSE NOT PERFORMED.

Explanation: Close of the dump file could not be performed due to a diskette error. A BER is created: 01 03. Alarm A3 is displayed.

ACTION: Terminate function.

DISKETTE ADDRESS MODIFIED TO XXXX.

Explanation: An odd display TIC storage address was entered; only even addresses are valid. The odd address is rounded down to the nearest even address.

ACTION: Continue.

DUMP CANCELED AS REQUESTED

Explanation: The operator did not answer affirmatively to a DUMP TIC STORAGE screen prompt, canceling the dump request.

ACTION: None.

DUMP COMPLETE

Explanation: The TIC dump has completed without error.

ACTION: None.

DUMP FILE BEING TRANSFERRED: TRY LATER

Explanation: You requested a TIC dump file while the TRSS dump file on the diskette was being transferred to the host due to a host request.

ACTION: Try later.

DUMP FILED IN CHGTRSS: TO PRINT DUMP, TRANSFER IT TO HOST.

Explanation: The TIC autodump has completed and is ready to be transferred on host request.

ACTION: Notify host operator.

DUMP IN PROGRESS.

Explanation: The TIC dump has started and is being performed.

ACTION: None.

EXPECTED INTERRUPT NOT RECEIVED: FUNCTION CANCELED.

Explanation: An interrupt that was expected as the result of an MIOH was not received. A BER is created: 01 07.

ACTION: Terminate function.

IRSS Function Messages (Part 2 of 4)

INVALID ADDRESS - RANGE IS 0 TO FFF (HEX).

Explanation: The requested TIC storage address was outside of the indicated range.

ACTION: Enter correct address.

INVALID INPUT: RE-ENTER FIELDS IN ERROR.

Explanation: An input field is in error during an alter operation.

ACTION: As requested by message.

INVALID INTERRUPT RECEIVED FROM TRA: FUNCTION CANCELED.

Explanation: An interrupt was expected as the result of an MIOH but the interrupt expected bit was found to be on in the TCB (should have been reset by level 4). A BER is created: 01 07.

ACTION: Terminate function.

INVALID NUMBER OF HALFWORDS: RANGE IS 1-48.

Explanation: The requested amount of halfwords to display was out of range.

ACTION: Enter a valid value.

IOC/TRA ERROR: NOT CONNECTED.

Explanation: An IOC error during TRA start command caused termination of the connect operation. A BER is created: 01 07.

ACTION: Retry or terminate function.

IOC/TRA ERROR: DUMP MAY BE INCOMPLETE.

Explanation: A complete TIC dump could not be taken due to IOC or TRA hardware error. A BER is created 01 07.

ACTION: Use dump display functions to look at dump and determine its real upper limit.

IOC/TRA ERROR: FUNCTION NOT PERFORMED

Explanation: Function could not be performed because of a IOC or TRA hardware error. A BER is created: 01 07.

ACTION: Retry or terminate function.

IOC/TRA ERROR: TRA SELECTED WITH UNKNOWN MODE.

Explanation: Unsuccessful read of level 1 error status reg from the TIC. A BER is created 01 07.

ACTION: Retry or continue.

IOC/TRA ERROR: MODE NOW UNKNOWN.

Explanation: An IOC error caused the TRA to be put in an intermediate or unknown state during the connect or disconnect process.

ACTION: Retry, terminate function, or continue with caution.

IOC/TRA ERROR: TIC INTERRUPTS NOT ENABLED.

Explanation: An IOC error occurred while trying to read the TIC mode from NTRI. A BER is created: 01 07.

ACTION: Continue.

IOC/TRA ERROR: TRA INTERRUPTS NOT ENABLED.

Explanation: An IOC error prevented the TRA UNMASK command from being sent. A BER is created: 01 07.

ACTION: Terminate function or continue with caution.

MOSS/TIC ERROR: FUNCTION CANCELED

Explanation: An interrupt that was not expected was received after an MIOH was done to a TIC. If a refresh is active, it is terminated.

ACTION: Retry or terminate function.

NO ACKNOWLEDGE FROM TRA: MODE NOW UNKNOWN.

Explanation: The TRM did not respond with an interrupt to MOSS during the disconnect process. A BER is created: 01 07.

ACTION: Terminate function or continue with caution.

NO ANSWER FROM CONTROL PROGRAM: MODE NOW UNKNOWN.

Explanation: Mailbox to NCP was never answered during the connect process. A BER is created: 01 02.

ACTION: Terminate function. Check if control program running.

NO ANSWER TO ERROR STATUS REQUEST DURING ERROR RECOVERY.

Explanation: The TRA is not able to process the MOSS command. It did not answer during error recovery. A BER is created: 01 07.

ACTION: Terminate function.

NO TRA'S INSTALLED: FUNCTION CANCELED.

Explanation: No TRAs were found to be installed in the CDF. The select function is not entered.

ACTION: Check the CDF.

NTRI/MOSS ERR.: FUNCTION CANCELED.

Explanation: A matching MPT was not found for the selected TIC. NTRI is set offline. Since NTRI is needed for the current function, it is canceled.

ACTION: Check the CDF and control program sysgen.

NTRI/MOSS ERR.: PRESS SEND TO CONTINUE.

Explanation: A matching MPT was not found for the selected TIC. NTRI is set offline. The function continues after SEND is pressed.

ACTION: Press SEND, continue. Check the CDF and control program sysgen.

TRSS Function Messages (Part 3 of 4)

NTRI OFFLINE: FUNCTION IGNORED.

Explanation: Selected function is not permitted if NTRI is offline.

ACTION: IPL the CCU with NTRI.

REFRESH MODE: PRESS ATTN TO STOP REFRESH.

Explanation: Refresh mode is active.

ACTION: Press ATTN to stop.

RESULTS UNPREDICTABLE - PF1 AGAIN TO CONFIRM, ELSE SEND.

Explanation: Warning before write to TIC or TRM register.

ACTION: Press PF1 to continue. Press PF3 or SEND to terminate.

SCROLL IGNORED.

Explanation: An attempt was made to scroll backwards (PF4) or forwards (PF5) beyond the limits of TIC storage (0000-1FFF).

ACTION: Enter a valid address or press valid PF key.

SELECT A TRA.

Explanation: A function was chosen before a TRA was selected.

ACTION: Select a TRA.

SELECTED TIC NOT AVAILABLE: REQUEST REJECTED.

Explanation: Selected TIC is not shown installed in the CDF.

ACTION: Select an installed TRA or check CDF.

TIC DUMP ALREADY EXISTS: AUTODUMP CANCELED.

Explanation: A TIC dump already exists for the TIC that is to be autodumped.

ACTION: Notify host operator to transfer dump to host.

TRA ALREADY CONNECTED: FUNCTION IGNORED.

Explanation: The selected TRA is already in CONNECT mode.

ACTION: None.

TRA ALREADY DISCONNECTED: FUNCTION IGNORED.

Explanation: The selected TRA is already in DISCONNECT mode.

ACTION: None.

TRA CAN NOT BE CONNECTED. MOSS IS NOT ONLINE

Explanation: Self explanatory.

ACTION: Set MOSS online

TRA CONNECTED.

Explanation: The connection has been done.

ACTION: Continue.

TRA CONNECTION REJECTED BY CONTROL PROGRAM.

Explanation: The connect mailbox was rejected by the control program.

ACTION: Terminate function.

TRA DISCONNECTED.

Explanation: The disconnect request was successful.

ACTION: Continue.

TRA DISCONNECTED BUT ERROR RESETTING TRM STATUS REGS.

Explanation: An MIOC error occurred when trying to read the TRM level 2 error status registers. A BER is created: 01 07.

ACTION: Terminate function or continue with caution.

TRA DISCONNECTED BUT NO CCU ACKNOWLEDGE.

Explanation: The TRA is physically disconnected (bit in level 1 error status is on) but MOSS had to provide the "GET LEVEL 1 ERROR STATUS" request during the disconnect process. A BER is created: 01 07.

ACTION: Continue.

TRA DISCONNECTED BUT SOME TIC'S COULD NOT BE RESET.

Explanation: An MIOC/IOC error occurred during the setting of the TIC address register to '00AA'x or while writing to the TIC control register during the disconnect process.

ACTION: Terminate function or continue with caution.

TRA DISCONNECTED WITH UNEXPECTED STATUS.

Explanation: Level 4 detected an unexpected status condition in the get command completion of the disconnect interrupt. The MOSS bit was on and none of the MOSS Control bits were on in the TIC control reg. A BER is created: 01 07.

ACTION: Terminate function or continue with caution.

TRA NOT DISCONNECTED: FUNCTION IGNORED.

Explanation: The selected function requires that the TRA be disconnected.

ACTION: Disconnect the TRA or terminate function.

TRSS Function Messages (Part 4 of 4)

TRA SELECTED IS NOT INSTALLED: REQUEST REJECTED.

Explanation: The TRA is shown not installed in the CDF.

ACTION: Select an installed TRA or check the CDF.

TRA XX SELECTED: LOOK IN MSA FOR MODE.

Explanation: The selection was successful.

ACTION: Continue.

UNABLE TO SET TIC STORAGE BOUNDARY.

Explanation: The TIC did not correctly set the requested TIC 2KB storage boundary. A BER is created: 01 07.

ACTION: Terminate the function.

UNDEFINED PF KEY.

Explanation: An unassigned PF key was pressed.

ACTION: Press one of the PF keys displayed on the screen or enter requested input.

UNEXPECTED INTERRUPT RECEIVED: KEYBOARD INPUT IGNORED.

Explanation: An interrupt was received before or during the last Send/Receive (to 3727). The interrupt may not be related to the last keyboard input. A BER is created: 01 07.

ACTION: Retry last input or terminate function.

UPDATE HIGHLIGHTED FIELDS, PRESS SEND.

Explanation: Instructs operator to update fields to be altered and to then press the SEND key.

ACTION: As requested in message.

1900

1900



Chapter 2. Service Procedures

Section 2. Extended Troubleshooting Using BERs

BER Recovery Procedures

Before being logged and stored on the diskette, BERs are kept in MOSS and/or CCU storage. While in this transition stage, the BERs are volatile, and are lost if a power-off or power-on reset occurs. They can however be displayed using the following procedures:

MOSS

1. Catastrophic errors: The MOSS has stored a BER in the BER stack (in MOSS storage), but could not log it on the diskette. Display the BER using the procedure given on page 3-030 under "BER Display from MOSS Storage". This page also indicates the meaning of each byte.
2. All other errors:
 - a. Call the utilities.
 - b. Call MOSS store display
 - c. Call items 10 (BER Stack) and 11 (BER TCB).

The displayed bytes may be interpreted by referring to pages 2-340 and 2-341. The displayed format is identical to that stored on the diskette, except that there is no header present. The first byte displayed therefore corresponds to byte 10 on pages 2-340 and 2-341; the second byte displayed corresponds to byte 11, and so on.

CENTRAL CONTROL UNIT (CCU)

1. Call the utilities.
2. Call MOSS store display.
3. Display the control program information table (CPIT) (this table starts at address X'2200'). Starting at address X'2342' is a group of 20 bytes that contain the check record pool (CRP) for each interrupt level, as follows:

Address '2342'-----

Bytes 1-2	CRP entry count L1	CRP entry count L2
Bytes 3-4	CRP entry count L3	CRP entry count L4
Bytes 5-6	CRP entry length L1	1st CRP entry add. at L1 byte X
Bytes 7-8	First CRP entry address at L1 bytes 0 and 1	
Bytes 9-10	CRP entry length L2	1st CRP entry add. at L2 byte X
Bytes 11-12	First CRP entry address at L2 bytes 0 and 1	
Bytes 13-14	CRP entry length L3	1st CRP entry add. at L3 byte X
Bytes 15-16	First CRP entry address at L3 bytes 0 and 1	
Bytes 17-18	CRP entry length L4	1st CRP entry add. at L4 byte X
Bytes 19-20	First CRP entry address at L4 bytes 0 and 1	

Using the information obtained from the above table, call CCU Functions and display the BERs as stored in CCU main storage by the control program.

Refer also to ACF/NCP for the 3725, EP for the IBM 3725 Reference Summary and Data Areas, LY30-3070, for the control block structure of the BERs in the CRP.

BER Analysis Procedures (Part 1 of 5)

MULTIPLE BERS

The MIM Part 2 indicates that troubleshooting should start with the BER just below the ALARM. The following points should be noted:

1. Several BERS can be created and logged for a single failure, depending on:

- The duration of the failure.
- The situation at the subsystem boundaries.
- The current functions being performed by the control program and/or microcode.

Troubleshooting may therefore sometimes be improved by searching for possible 'bursts' of related BERS. The first BER reported (not necessarily under an ALARM) can also be a good starting point for error analysis.

2. Looking at several BERS together can detect overlapping FRUs in the FRU lists, and thus narrow down the possible range of failing components, or the order of FRU exchange (probability of failure). For example:

ALARM -
BER 1 Suspected FRUs: A, B, C
BER 2 Suspected FRUs: D, B, C

In this case, although according to the MIM Part 2, FRU A should normally be changed first, the above correlation shows that the priority might be changed to 'FRU B first'.

3. An error may be propagated from one subsystem to another by:

- A channel adapter and a scanner connected by the same redrive
- Several adapters on the IOC bus

In this case, the localization of the failing FRU may be improved by correlating different BERS on two or more adapters.

MOSS SUBSYSTEM STORAGE ERRORS

BERS type 01 ID 00, error codes 02 and 04 (MOSS parity check)

The storage address where the error was reported may be found by forming a data address as follows:

1. Take the entire contents of BER data byte 2; these 8 bits form the 8 high-order bits of the address.
2. Take the 4 low-order bits of data byte 0; these form the middle 4 bits of the address.
3. Take the entire contents of BER data byte 1; these 8 bits form the 8 low-order bits of the address.

The result is a 20-bit address, which can be used to locate the failing FRU, using the following table:

MOSS storage address	Corresponding FRU
00000 to 01FFF	MMM8 on MPC card
02000 to 0AFFF	MPC card
0B000 to 0FFFF	MMM24 on MPC card
10000 to 17FFF	MMM32-1 on MMC card
18000 to 1FFFF	MMM32-2 on MMC card

BER Analysis Procedures (Part 2 of 5)

CENTRAL CONTROL UNIT (CCU)

CCU Hardcheck

CCU failures are indicated in CCU registers X'7D', X'7E', and X'76'. For each type of failure, a list of FRUs is given in the following table by decreasing failure rate probability.

These FRU lists are used by manual intervention routine AB03, which is run in order to analyze the following BERs:

Type 01 - ID 06 - error code 08

Type 12 - ID 11 through 16

If several failures are present, an algorithm in the routine may take one of the following actions:

- Select the most probable failure and give the FRU list.
- Compute a new FRU list based on the different FRU lists corresponding to the failures.
- If the FRU list is flagged by two asterisks, the failure can be caused by the DFL5 card (if not already included), the redrive cards, or the adapters. Try and correlate with other BERs: IOC bus, TSS, or channel adapter, if any.

Register X'7D'

Byte	Bit	Meaning	Suspected FRUs (in order)
0	0	POP Pty	ECC SCTL BSMI CTL1 DFLN CTL2 MIOC DFL4 BTAC MEMN
	1	MDOR Pty	ECC DFLN MIOC BSMI SCTL DFL4 BTAC MEMN
	2	MIOC Pty	MIOC DFLN SCTL CTL2
	3	Stg 2 Bit Err	Storage double-bit error
	4	Stg Cntl Err	SCTL BSMI CTL2 CTL1 CCLK ECC
	5	(Reserved)	
	6	Stg Addr/Data LS Pty	BSMI SCTL DFLN CTL2 CTL1 MIOC ECC
1	0	0	
	1	A/B Bus Pty	DFL4 DFLN MIOC CTL1 BTAC CTL2
	2	IOC Data Pty	ECC SCTL DFL5 DFLN BSMI MIOC DFL4 CTL1 MEMN BTAC CTL2
	3	ALU Comp Err	DFL4 CTL1 DFLN
	4	SAR Pty	DFL4 CTL1 DFLN DFL5 CTL2 BTAC BSMI
	5	ROS Pty	CTL1 CTL2 DFLN
	6	Z Reg Pty	DFLN ECC DFL4 CTL2 MIOC BTAC SCTL MEMN
7	0		

Note: DFLN = FRU group DFL1, DFL2, and DFL3.

Register X'7E'

Byte	Bit	Meaning	Suspected FRUs (in order)
0	0	MOSS Inop	MIOC
	1	CCU Hard Sum	
	2	0	
	3	L5 I/O Error	CTL1 DFL4 DFLN CTL2 MIOC ECC BTAC MIOC
	4	Invalid Op	CTL1 DFL4 DFLN CTL2 SCTL ECC BTAC MIOC
	5	IOC1 Adp Req	DFL5 MIOC CTL2 CTL1 BTAC DFLN
	6	0	
7	IOC L1 Sum		
1	0	Addr Comp L1	BTAC MIOC CTL2 DFLN
	1	Addr Exc I F	SCTL CTL2 BSMI CTL1 DFLN MIOC ECC
	2	Stg Prot I F	SCTL CTL2 BSMI CTL1 DFLN MIOC ECC
	3	Addr Exc Pgm	CTL1 CTL2 MIOC BSMI DFLN DFL5 ECC
	4	Stg Prot Pgm	CTL1 CTL2 MIOC BSMI SCTL DFLN
	5	0	
	6	IPL L1	BTAC MIOC CTL2 DFLN
7	(Reserved)		

Note: DFLN = FRU group DFL1, DFL2, and DFL3.

Register X'76'

Byte	Bit	Meaning	Suspected FRUs (in order)
0	0	IOC Addr Exc	DFL5 DFLN CTL1 CTL2
	1	IOC Stg Prot	DFL5 DFLN CTL1 CTL2
	2	IOC Inv CCW	DFL5 DFLN
	3	See Note 2	
	4	IOC Time Out	DFL5 DFLN CCLK
	5	IOC Bus In	DFL5 DFLN CCLK
	6	IOC Init Op	DFL5 DFLN
7	IOC MOSS Op	DFL5 MIOC CTL2 CTL1 BTAC DFLN	
1	0	0	
	1	0	
	2	0	
	3	0	
	4	0	
	5	0	
	6	0	
7	0		

Notes:

1. DFLN = FRU group DFL1, DFL2, and DFL3.
2. No FRU list is given. Refer to Chapter 10 for a description of Input X'7X'.

BER Analysis Procedures (Part 3 of 5)

STORAGE DOUBLE-BIT ERRORS

Storage double-bit errors are handled in a different way.

RAC 7CF is indicated, which calls for the CCU BER analysis procedure. The most probable causes of storage double-bit errors are the ECC, SCTL, and BSMI cards. If the errors persist, change these cards and run routine B001.

MANUAL ROUTINE B001

The single-bit storage scan routine (B001) counts the single-bit errors for each storage card and indicates the storage cards for which the number of errors exceeds a given threshold. As the occurrence of double-bit storage errors (due to the storage) is related to the number of single-bit errors, storage cards should not be changed if this single-bit error threshold is not reached. However, if the double-bit storage error rate is high, replace the storage cards by groups of 2 to 4 cards.

To run the routine, proceed as follows:

1. Select routine B001. The message:

'STORAGE SOLID 1-BIT ERROR DETECTION ==> PRESS SEND'

is displayed.

2. At the end of the test, a second message is displayed:

'XXXX XXXX XXXX XXXX XXXX XXXX ==> PRESS SEND'

where XXXX is a storage card, or blank.

In the above message, if six or more cards with one bit of error count more than a fixed threshold are detected, a maximum of six cards are called.

3. Press SEND to end the routine.

Should a CCU hardware error prevent the execution of the CCU instructions, the following message is displayed:

'CCU HARD ERROR, IML THEN RUN CCU DIAGS'

When this message is displayed, the only valid action is to perform IML.

CCU Clock

CCLK errors are normally reported via an X'B24' code on the hexadecimal display (there is no associated BER on the diskette). However, an intermittent error in the CCU clocking can lead to different BERs depending on the way in which the error occurs. A correlation between several BERs (types 12, 13, 14, and CCU hardcheck) can point to a CCLK error.

Note: In general, the CCLK has not been specifically indicated in the suspected FRU lists (MIM Part 2).

BER Analysis Procedures (Part 4 of 5)

IOC BUS AND ADAPTERS

The following three BER types can occur for failures in this area.

BER Type 10

This BER occurs if an error was detected while the control program was in a transaction with a channel adapter and the control program has identified the channel adapter concerned.

BER Type 11

This BER occurs:

1. If an error was detected while the control program was in a transaction with a communication scanner and the control program has identified the scanner concerned.
2. If a specific communication scanner reported an error to the control program.

BER Type 14

This BER occurs if an error was detected while the control program was in a transaction with an adapter and no adapter could be identified as the source of the error.


BER Type 15

This BER occurs:

1. If an error was detected while the control program was in a transaction with a Token Ring Adapter and the control program has identified the TRA concerned.
2. If a specific Token Ring Adapter reported an error to the control program.


Note: A single intermittent error can be reported as BER types 10, 11, 14, or 15 depending on the time at which the error occurred and the control program or micro-code transaction that was taking place at that time. In this case, correlation may be useful to narrow down the range of possible failing components.

Example 1: CLAB1




An RDV error can lead to BER types 10 or 11; therefore, scan the error log for both BER types to aid fault isolation.

Example 2: Error Propagation for 3725 Model 2 C2LB



An RDV error can lead to BER types 10 or 11; therefore, scan the error log for both BER types to aid fault isolation.

Example 3: Error Propagation Along the Entire IOC Bus (3725/3726)



An RDV error can propagate along the entire IOC bus, thus creating BERs of different types on other adapters; therefore, scan the error log for all BER types to aid fault isolation.

BER Analysis Procedures (Part 5 of 5)

RDV ADDRESS AND ERROR REGISTERS

Regardless of the 3725/3726 configuration, all registers are given.

Each register is 2 bytes long. The high-order byte contains the RDV address; the low-order byte contains the RDV error register.

- If the redrive address is not as indicated in the table below, the RDV should be suspected.

Board	Redrive Address	Board	Redrive Address
C2LB	X'80'	FRDV	X'88'
CLAB1	X'80'	LAB4	X'8B'
C2LB2	X'81'	LAB5	X'8C'
CLAB2	X'81'	LAB6	X'8D'
LAB3	X'82'	LAB7	X'8E'
CABR	X'83'	LAB8	X'8F'

For the RDV error register, refer to Chapter 11 of this manual.

- Whenever an RDV error reports a value that is not X'00', suspect the RDV card and the connected adapter(s).

TSS BER PROCESSING

The following table indicates what actions are taken by NCP/EP and MOSS for the different kinds of TSS errors.

Detected error	NCP/EP ACTION						MOSS ACTION	
	BER IDs	Abend code	ADP down	CP put ADP down	RDV disabled	Pgm Reset done	ALERT and ALARM	Dump
Recoverable error in scanner	91,92,93,96,97,99,9A,9B,9C,A1,A4	000	no	no	no	no	none	no
Nonrecoverable error in TSS, line down	1C,A2,B1	000	no	no	no	no	A15	no
Nonrecoverable error in scanner, programmed reset	1E,1F	000	no	yes	no	yes	A14	yes
	91,92,93,98,99,9A	000	no	yes	no	yes	A12	yes
Nonrecoverable error in scanner, adapter is down	95	000	yes	no	no	no	A12	yes
Nonrecoverable error in scanner, disable redrive successful	1E,1F	000	no	no	yes	no	A13	no
	91,92,93,98,99,9A,9B	000	no	no	yes	no	A11	no
Nonrecoverable error in scanner, disable redrive unsuccessful	14,16,18,1B	93X	no	no	no	no	A8	no
	9B,9C,A1	93X	no	no	no	no	A7	no

TRSS BER PROCESSING

The following table indicates what actions are taken by NCP/NTRI and MOSS for the different kinds of TRSS errors.

Detected error	NCP ACTION					MOSS ACTION	
	BER IDs	Abend code	CP put TRA down	RDV disabled	CP freeze TIC	ALARM	TIC Dump
Recoverable error in TRSS, TIC	A4,A7	000	no	no	no	none	no
Nonrecoverable error in TRSS, TIC Frozen	A3,A4,A7,AC,B2,B3,D4,B6,AF	000	no	no	yes	A29	yes
Recoverable error in TRA	91,92,93,96,97,A5,A8	000	no	no	no	none	no
Nonrecoverable error in TRA, programmed reset	91,92,93,98,A5,A8,B5	000	yes	no	yes	A28	no
Nonrecoverable error in TRA, not installed	18	000	no	no	no	A28	no
Nonrecoverable error in TRA, disable redrive successful	91,92,93,98	000	no	yes	no	A28	no
Nonrecoverable error in TRA, disable redrive unsuccessful	14	B01	no	no	no	A8	no
	16	B02	no	no	no	A8	no
	9C	9x3	no	no	no	A7	no

Scanner Errors Without BERS


Some errors in a communication scanner may not lead to a BER, although information within the scanner is available to help in fault isolation. Use the following procedure:

1. Start a scan interface trace (SIT). Refer to the 3725 Problem Determination and Extended Services Chapter 15.
2. When the problem occurs, stop the SIT.
3. Analyse the SIT. Use the TSS services to display the scanner storage:

Buffer Number	SIT Buffer Start/End Address	Next Available SIT Buffer
1	X'9520'	X'950D'
2	X'9548'	X'9535'
3	X'9570'	X'955D'
4	X'9598'	X'9585'

Example:


1. If location X'9520' contains X'F0F3', the SIT buffer is between X'F000' and X'F300' (refer to the following figure).
2. If location X'950D' contains X'F123', the last halfword of the last 'trace record unit' is at address X'F122' (refer to the following figure).



Each status entry begins with X'E2'. Refer to ACF/NCP for the 3725, Emulation Program for the IBM 3725 Reference Summary and Data Areas, LY30-3070 for details of the SIT control blocks and formats.

In each record, the line communication status (LCS) can help to locate an error. For the LCS format and details, refer to Chapter 13.

Example:



The information contained in the MIM Part 2 for BERs Type 11 and ID = A2 can now be used as an entry to the maintenance package.

Unresolved Interrupts (Part 1 of 2)

1. Unresolved CA Level 1 Adapter error (BER 10 95)

There are two possible types of unresolved CA level 1 interrupts. The first is when a CA level 1 occurs and no bits are on in CA External Register X"E". The second type occurs when there is a CA level 1 and none of the following bits are on in CA External register X"D":

- 0.0 IOC Bus Parity error
- 0.1 Internal bus parity error
- 0.2 CCIN card check
- 0.4 CHIN card check
- 0.5 Address Compare error
- 1.0 Output exception check
- 1.1 PIO Halt remember latch
- 1.2 Cycle Steal Halt remember latch
- 1.3 Bus In check Interface A
- 1.4 Ground Fault error
- 1.5 Bus In check Interface B
- 1.6 CADR card check Interface A
- 1.7 CADR card check Interface B

2. Level 3 Unresolved CA Initial selection

The following bits in X"0" are checked. If none are on, the Control Program builds a BER 10 B1:

- 0.0 (Normal) Initial selection interrupt
- 0.1 Interface disconnect
- 0.2 Selective reset
- 0.3 Channel Bus Out check
- 0.5 Stacked Initial status
- 0.6 ESC Status byte cleared
- 0.7 System reset

3. Level 3 Unresolved CA Data/Status

The following bits in X"2" are checked. If none of these bits are set and the System Reset bit in X"0" is not set (bit 0.7), the Control Program builds a BER 10 B2:

- 0.0 Outbound data transfer sequence
- 0.1 Inbound data transfer sequence
- 0.2 (Final) Status transfer sequence
- 0.5 Channel stop/interface disconnect

- 0.6 Suppress out monitor interrupt
- 1.1 Data/Status Selective reset
- 1.3 Stacked ending status

4. Unresolved level 3 CA interrupt

If a CA Control Block in NCP/EP/PEP is not found that has Select bits matching those of the interrupting CA, then a BER 10 33 is built.

5. Scanner AIO unresolved errors (BER 11 92)

For the TSS, interrupts are unresolved if:

- in X"7E" bit 0.7 IOC Level 1 Summary is on
- in X"76" bit 0.6 Adapter Initiated Operation is on
- in X"75" bit 0.0 AIO CSCW is on
Then following the IOH to read the Error Status, one of the following bits is on in X"76":
- 0.4 IOC Time out
- 0.5 IOC Bus In parity error

6. Scanner Adapter unresolved error (BER 11 9A)

- in X"7E" bit 0.5 IOC Adapter level 1 request
- the error status returned an IOH read error status command = 0.

7. Scanner level 2 unresolved (BER 11 A1)

There are 3 types of unresolved/undefined interrupts:

- a level 2 interrupt occurs on a non-Sysgenned line.
- there is a level 2 interrupt from a Sysgenned line, but the SCF, SES, and LCS are all zero.
- there is a level 2 interrupt from a Sysgenned line, but the received status does not coincide with one of the expected ones.

8. Control Program unresolved errors (BER 12 21)

Level 2 PCI: Level 2 should never be PCI'ed.

9. CCU Level 1 unresolved interrupts

The following bits in X"7E" are checked. If none are set, the Control Program builds a BER 13 91:

- 0.0 MOSS inoperative
- 0.1 Any CCU Hard error
- 0.3 Level 5 I/O error

- 0.4 Invalid Operation
- 0.5 IOC Adapter Level 1 request
- 1.0 Address Compare Level 1
- 1.1 Address Exception I fetch
- 1.2 Storage Protect I fetch
- 1.3 Address Exception Pgm execution
- 1.4 Storage Protect Pgm execution
- 1.6 IPL Level 1 request

10. CCU Level 3 unresolved interrupt

This condition can occur in three different environments: NCP only, PEP, and Remote NCP. The checking are then different.

- a. NCP only
The following bits are checked. If none of them are set, the Control Program builds a BER 13 B1:
 - X"77" bit 1.0 CA level 3 interrupt
 - X"7F" bit 0.6 User Interrupt request level 3
 - X"7F" bit 1.5 Internal timer interrupt level 3
 - X"7F" bit 1.6 PCI level 3
- b. PEP
The following bits are checked. If none of them are set, the Control Program builds a BER 13 B1:
 - X"F" bit 0.2 CA Level 3 initial selection request
 - X"F" bit 0.3 CA Level 3 Data/status request
 - X"7F" bit 0.6 User interrupt request
 - X"7F" bit 1.5 Internal timer Level 3
 - X"7F" bit 1.6 PCI Level 3
- c. Remote NCP
The following bits are checked. If none of them are set, the Control program builds a BER 13 B1:
 - X"77" bit 1.0 CA level 3 interrupt
 - X"7F" bit 0.6 User interrupt request
 - X"7F" bit 1.5 Internal timer Level 3
 - X"7F" bit 1.6 PCI Level 3
In case X'77' bit 1.0 is set, and the other bits are reset, the Control program builds a BER "Unresolved interrupt", even though it is really a configuration check.

Unresolved Interrupts (Part 2 of 2)

11. CCU Unresolved Level 4 Router

There are two conditions that may be detected by the Level 4 router. One is a general unresolved condition, the other is unresolved with respect to a PCI Level 4.

a. General unresolved condition

If none of the following bits are set in the X"7F" when a Level 4 interrupt occurs, the Control Program builds a BER 13 C1 :

- X"7F" bit 0.3 MOSS Request service
- X"7F" bit 0.4 MOSS Response service
- X"7F" bit 0.7 PCI Level 4 interrupt
- X"7F" bit 1.7 Service request

b. Unresolved Level 4 PCI

If X"7F" bit 0.7 is set, and no reason byte is set in the Level 4 Router Control Block, then the Control Program builds a BER 13 C2. Another error that falls under this category is when the Control Program cannot reset the Level 4 PCI latch (BER 13 C3).

12. Unresolved IOC Bus errors

a. Unresolved Adapter level 1 (BER 14 91)

In X"7E" bit 0.5, IOC Adapter level 1 request, is on. Following an IOH Broadcast Poll command to identify the board with the adapter problem, X"7E" bit 0.7, IOC Level 1 Summary, is on.

b. Unresolved AIO Level 1 (BER 14 92)

- X"7E" bit 0.7, IOC level 1 Summary, is on
- X"76" bit 0.6, Adapter initiated operation, is on
- X"75" is invalid. This is true when:
 - either X"76" bit 0.2, IOC invalid CSCW, is on,
 - or X"76" bit 0.4, IOC Timeout, is on and IOC Status (X"76" bits 0.0 to 0.3) = 2 (no response to TA tag or cycle steal grant)
 - or X"76" bit 0.5, IOC Bus in parity error, is on and IOC Status (X"76" bits 0.0 to 0.3) = B (Loading the CSCW)


c. Unresolved PIO level 1 (BER 14 93)

- X"7E" bit 0.7, IOC Level 1 Summary, is on
- X"76" bit 0.6, Adapter initiated operation, is off
- X"76" bits 0.4, IOC Timeout, and 0.5, IOC Bus in parity error, are off


TROUBLESHOOTING IOC BUS PROBLEMS WITH BERS

Correlation between BERS is necessary in most cases for complex problems (BERS Type 10, 11, and 14). See MIM Part 1, page 2-804

BER 11 1C MECHANISM



BER 11 B1/A4 MECHANISM



Contents

CHAPTER 3. MAINTENANCE AIDS

Tools and Test Equipment (Part 1 of 4)	3-010	RECMS (MDR): BSC/SS Station Statistics	3-053
General Purpose Tools		RECMS (MDR): SNA Link Permanent Errors	3-054
Shipping Group Tools		RECMS (MDR): SNA Station Permanent Errors	3-055
Board		RECMS (MDR): SDLC Line Error (Part 1 of 3)	3-056
Channel Adapters		Permanent SDLC Line Error	
Console		Chart F	
Diskette		RECMS (MDR): SDLC Line Error (Part 2 of 3)	3-057
Lines		Chart G	
General		Chart I	
Tools and Test Equipment (Part 2 of 4)	3-011	RECMS (MDR): SDLC Line Error (Part 3 of 3)	3-058
CELIA Card (Part 1865015)		Chart H	
CELIA LED Testing		Chart H (Continued)	
CELIA Card Functions		Chart J	
Straight Indicator		EREP Unit Check Records	
CELIA Card Data Flow			
Tools and Test Equipment (Part 3 of 4)	3-012		
Diskette Tools			
Communications Wrap Block and Wrap Cable			
Torque Screwdriver (Part 4134750)			
Tools and Test Equipment (Part 4 of 4)	3-013		
Flat Cable Extractor (Part 2360340)			
Module Extractor/Aligner (Part 1715889)			
Module Extractor (Part 453400)			
Card Extractor (Part 1310707)			
Console Wrap Block (Part 2667737)			
Removing RDV or CADR Cards	3-020		
Removing the RDV from the IOC Bus			
Removing the CADR from the Host			
Channel Interface			
BER Display from MOSS Storage	3-030		
Display Procedure			
Hex Display/BER Decode			
Diskette BERs			
BER Storage when Diskette is not Operational			
Extended Problem Analysis Tools	3-040		
PT-2			
Output 79 Sync			
PT-2/TP Line Monitor (TPLM)			
PT-2 SNA Edit and Display Program (SNAPED)			
PT-2 High-Speed Trace Programs			
PT-2 TP Exercise Program (TPEXER)			
PT-2 Channel Monitor (CHIM)			
Modem Interface Test Set			
Maintenance Device 2 (MD2)			
Stand-Alone Link Tests (SALT)	3-045		
Testing an INN Link			
SDLC Terminals Exerciser without CP Loaded			
RECMS (MDR): BSC/SS Device or Line Errors (Part 1 of 3)	3-050		
Permanent BSC/SS Device or Line Errors			
Permanent BSC/SS Line Error-RECMS Decoding			
RECMS (MDR): BSC/SS Device or Line Errors (Part 2 of 3)	3-051		
Chart A			
Chart B			
RECMS (MDR): BSC/SS Device or Line Errors (Part 3 of 3)	3-052		
Chart C			
Chart D			
Chart E			

Tools and Test Equipment (Part 1 of 4)

The following tools and test equipment must be available to the CE when maintaining the communication controller and its expansion. They are shipped with the machine or with an MES, or are general purpose tools and are part of the CE tool kit. They can also be branch office tools, depending on the country.

GENERAL PURPOSE TOOLS

Qty	Tool	Part No.	Page
1	Torque screwdriver	4134750	3-012
1	Module extractor/aligner	1715889	3-013
1	Module extractor	453400	3-013
1	Flat cable extractor	2360340	3-013
	Digital multimeter (Worldwide)	8496278	-
	Digital multimeter (EMEA only)	8309874	-
1	Oscilloscope: 454 Tektronix* or, 453 Tektronix* or, 475 Tektronix*	459559 453047 453215	-
-	High voltage probe	453698	-

* Trademark of Tektronix, Inc.

SHIPPING GROUP TOOLS

Board

Qty	Tool	Part No.	Page
1	Indicator card (CELIA) *	1865015	3-011
4	Continuity plug (Base machine)	1736670	3-020
6	Continuity plug (3726)	1736670	3-020
1	Card extractor	1310707	3-013

* Not in EMEA

Channel Adapters

Qty	Tool	Part No.	Page
1	CADR jumper block	4712553	5-042
2	Segment board (Base machine)	5997533	4-130
2	Segment board (3726)	5997533	4-130
21	Jumpers (Base machine)	2731801	4-260
35	Jumpers (3726)	2731801	4-260

Console

Qty	Tool	Part No.	Page
1	Console wrap block	2667737	3-013

Diskette

(See Chapter 7 for description and use).

Qty	Tool	Part No.	Page
1	Timing pin	5562019*	3-012
1	Force gauge	460870	3-012
1	Head/carriage adjustment spring	4240631*	3-012
1	Track 40 adjustment clip	4240632*	3-012
2	Jumpers	829117	-

* These diskette tools are stored in the diskette drive itself, as shown on page 3-012.

Lines

Qty	Tool	Part No.	Page
1	LIC type 1, 2, and 4 wrap block	1733977	3-012
1	LIC type 3 wrap cable	1733979*	3-012

* This wrap cable is sent one per frame when the corresponding LIC type is present on that frame.

General

Qty	Tool	Part No.
2	Cover keys	6834390


Tools and Test Equipment (Part 2 of 4)

CELIA CARD (PART 1865015)

Warning: The CELIA card must not be plugged on the MMB, CAB, or CCU boards. Use the card to isolate failing FRUs in the 3725 or the 3726 during initialization, or when running specific diagnostic routines. See MIM Part 2 for the use of this card for troubleshooting. The CELIA card may be plugged with the controller powered on. Plug the card on the pin side of any CLAB, LAB type A, LAB type B, or LAB type C, in the reserved locations:

- YA, for collecting troubleshooting information
- YJ, for checking that the card LEDs are working correctly (always on)

CELIA LED Testing



16 LEDs can be used as straight indicators, or to display the first or last event on a bus.

All LEDs should be ON with the card plugged in the YJ position of a CLAB, a LAB type A, a LAB type B or a LAB type C.

All LEDs should be OFF with the indicator card plugged in the YA position of one of these boards, and with a jumper installed from pin M05 of the board's RDV to ground.

Note: If CELIA is present on a board during a scanner IML, the LED set by hardware (LED 4 or LED 16) must flash for a short time (approximately 1 sec).

CELIA Card Functions

The indicator card provides many different functions as it is a general purpose tool used on many IBM machines.

Specifically, on the IBM 3725/3726, the CELIA card works as a straight indicator.

The indicators give the FRU isolation Code (FIC). The FIC is used in trouble shooting procedure (MIM 2) to isolate a FRU.

Straight Indicator

When used as a straight indicator, the card is plugged into the YA position of a CLAB, a LAB type A, or a LAB type B or a LAB type C. Connect pin 3 to pin 7, to allow the LEDs to show the signals assigned to their input (see data flow, right).

Out of the 16 LEDs of the card, only LEDs 1 through 4 and 13 through 16 carry significant troubleshooting information:

Used by odd scanners

LED	Set by	Via
1	Microcode	CSP ext reg 08, bit 5
2	Microcode	CSP ext reg 08, bit 6
3	Microcode	CSP ext reg 08, bit 7
4	Hardware	CSP ext reg 03, bit 2

Used by even scanners

LED	Set by	Via
13	Microcode	CSP ext reg 08, bit 5
14	Microcode	CSP ext reg 08, bit 6
15	Microcode	CSP ext reg 08, bit 7
16	Hardware	CSP ext reg 03, bit 2

Bits set by the microcode carry error codes for scanner troubleshooting using the MIM Part 2.


Bits 4 and 16 indicate a scanner processor hardware check.

On a LAB type B, LEDs 1 through 4 provide the status of the first scanner (odd). LEDs 13 through 16 provide the status of the second scanner (even).

The second scanner of a LAB type B is indicated between parentheses in the table (right).

Scanner	Board Name	Board Address
1	CLAB1 or C2LB	01A-A3
3	CLAB2 or C2LB2	01B-A2
5-(6)	LAB pos 3	A1
7-(8)	LAB pos 4	02A-A3
9-(10)	LAB pos 5	A2
11-(12)	LAB pos 6	A1
13-(14)	LAB pos 7	02B-A3
15-(16)	LAB pos 8	A2

CELIA CARD DATA FLOW



Tools and Test Equipment (Part 3 of 4)


DISKETTE TOOLS

Use the diskette tools to:

- Adjust or check the drive band tension
- Adjust or service the read/write head carriage stepper motor pulley
- Keep the thickness gauge in contact with the adjustment surface of track 40
- Keep the head carriage in place against the thickness gauge when adjusting the head carriage.

For information on how and when to use the diskette tools, see Chapter 7.

Tools B, C, and D are stored in the diskette drive as shown.



COMMUNICATIONS WRAP BLOCK AND WRAP CABLE


A wrap block and a wrap cable are used to test the LICs. Inserting the corresponding wrap block or wrap cable on the tailgate in place of the modem cable connector enables diagnostics and wrap programs to test the ISS circuits in the wrap mode on a particular line. The wrap block (Part 1733977) is used on LIC type 1, LIC type 2, and LIC type 4. The wrap cable (Part 1733979) is used on LIC type 3.

The MIM Part 2 shows how to use the wrap block and the wrap cable during troubleshooting procedures.


The wire function and wire wrap routing in the wrap block or the wrap cable is shown with the line interfaces in Chapter 4, starting on page 4-140.

TORQUE SCREWDRIVER (PART 4134750)

Use the torque screwdriver when plugging or unplugging a card or a connector on the CCU board (see page 5-010). A calibrated spring inside the tool enables the card holding screws to be tightened to the correct torque value.



Tailgate in Frame 01 or 02




Tools and Test Equipment (Part 4 of 4)

FLAT CABLE EXTRACTOR (PART 2360340)

In the CCU board, there are three signal connectors:

- 01A-A2-A3 with three flat cables
- 01A-A2-B1 with five flat cables
- 01A-A2-V2 with two flat cables


Use the flat cable extractor to remove any single flat cable from its connector.




MODULE EXTRACTOR/ALIGNER (PART 1715889)

Warning: Pluggable modules of the MPC and MMC cards are ESD-sensitive parts. See instructions for working with ESD-sensitive parts in Chapter 5.

Use the module extractor/aligner to align bent pins on modules.




Bottom View of Pin Aligner




MODULE EXTRACTOR (PART 453400)

Use the module extractor to pull out the pluggable modules on the CSP1, MPC, and MMC cards.




CARD EXTRACTOR (PART 1310707)



CONSOLE WRAP BLOCK (PART 2667737)

The console wrap block is connected as shown when the console adapter and interface (including the cable) are to be tested.



MIM Part 2, Chapter 6, explains when and how to use this block for maintenance testing.

ISO 2110
25 pins


6	0-	---	Data channel received line
9	0-	<---	Signal detector
10	0-	<---	Ready for sending (Clear to send)
12	0-	---	Request to send
12	0-	---	Transmitted data
11	0-	<---	Received data
8	0-	---	Data terminal ready
19	0-	<---	Data set ready

Removing RDV or CADR Cards

REMOVING THE RDV FROM THE IOC BUS

For troubleshooting purposes, a board RDV card can be removed from the IOC bus cables as follows:

1. Switch power off.
2. Unplug the IOC bus cable connectors from the RDV top connectors.
3. Connect the continuity plugs (Part 1736670) in place of the RDV card as shown below.



Note: The continuity plugs can be replaced by four jumpers on the IOC bus cable connector as follows:

On connector 4: Pin B02 --> pin D02

On connector 4: Pin B03 --> pin D03

On connector 5: Pin B02 --> pin D02

On connector 5: Pin B03 --> pin D03

A continuity plug is also installed on connector 3, but is not used.

4. Switch power on.

Refer to "Redrive State Definitions" in Chapter 11.

REMOVING THE CADR FROM THE HOST CHANNEL INTERFACE

Use the CADR jumper block (part 4712553). Refer to page 5-042 for removing and replacing a CADR card.

BER Display from MOSS Storage

The following errors cause a MOSS level 0 interrupt but do not force an automatic MOSS re-IML. They are:


- IML stop on error: codes Exx
- IML stop on diskette error: codes Dxx, except code D00
- Panel I/O error: codes Bxx
- MOSS re-IML threshold reached (10 MOSS IML attempts within a given period): codes Cxx
- Error recovery reentry: codes Axx; for hex display error description, see MIM Part 2, Chapter R4.

These errors flash on the hex display lamps as Axx, Bxx, Cxx, Dxx, or Exx. They indicate a failure found while running the MOSS microcode. A sixteen-byte BER is created for codes Axx and Cxx. Depending on the error, not all the BER fields may be updated. Fields not updated are filled with 'FF'. It is not written on the diskette, because of the failure type but kept in MOSS storage.

DISPLAY PROCEDURE

Ground pin 01A-A1U2G13 on the MMB board to display the 16-byte BER from storage.

As soon as the pin is grounded, the error that was flashing is replaced in hex lamps 2 and 3 by the first byte of the BER. Hex lamp 1 indicates the position of the displayed byte within the BER.



Hex lamp 1 automatically displays the following BER byte positions up to F. The BER is displayed repeatedly until pin G13 is off the ground.

When the jumper is removed, the hex display lamps show the original error code again.

Warning:
Remove the jumper from pin 01A-A1U2G13 when troubleshooting is finished. If you do not remove the jumper, the MOSS IML ends with E61.

HEX DISPLAY/BER DECODE

This BER is a MOSS BER type 01, ID 00. It has no header as it has not yet been processed by MOSS. For details of BER contents, refer to page 2-240.

The column "Hex Display pos 2, 3" is left blank for the CE to write down the byte information read on the hex display.

Hex Display	Hex Display	Decode (BER Type 01, ID00)
Pos 1	Pos 2,3	Meaning
0		CHECK: MOSS check
1		LL : last level interrupt
2		MCPC : MCPC register
3		IOIR : IOIR register
4		PIRR : PIRR register
5		CM : common mask register
6		DATA : Data byte 0
7		Data byte 1
8		Data byte 2
9		MEF : Storage expansion feature
A		TTA : Current TTA entry byte
B/C		I : failing instruction
D/E		PSW : IAR of interrupted level (bytes 0 and 1 of PSW)
F		Not used

DISKETTE BERS

A MOSS BER related to a diskette error (type 01 ID 03) is kept in MOSS storage because it cannot be recorded in the diskette BER file. You can retrieve this BER by mounting the spare diskette and performing a MOSS IML from the control panel.

If the diskette drive itself is the cause of the error, you must first repair it before you can retrieve any BER from storage. To do so, follow the troubleshooting procedures given in the MIM Part 2.

BER STORAGE WHEN DISKETTE IS NOT OPERATIONAL

When the diskette is not operational, the MOSS keeps the BERS in the 365-byte buffer in MOSS RAM. When the buffer becomes full, new BERS are lost, but a count is kept in the last byte of the buffer of the BERS lost. This is called the lost record count. The 365-byte buffer in MOSS RAM is preserved during MOSS IML. To read this buffer, see the "Display Procedure" paragraph on this page. When the diskette becomes operational again, MOSS stores the 365-byte buffer in the BER file on diskette, together with a BER giving the number of lost BERS in the error description line (Type 01, ID 06, error 02).

Extended Problem Analysis Tools

PT-2

The PT-2 is a general purpose programmable service system designed for on-site and remote maintenance of a wide range of products and systems.

The PT-2 consists of the following:

- A processor with 64K bytes of storage.
- A keyboard that contains 78 keys used for system control, program control, and data entry.
- A video unit for displaying data information and instructions. There are two display formats: 16 lines of 64 characters or 24 lines of 80 characters.
- A tape cartridge unit that has a storage capacity up to 2.1 million bytes and is used as an I/O device for programs and data.
- A teleprocessing link through an acoustical coupler or data access arrangement.
- A service interface that provides the link between the PT-2 programs and the product or system being maintained. Through the service interface the PT-2 programs can monitor, control or interrogate the product or system. Information or data received through the service interface can be stored in memory or on tape.
- An auxiliary interface is provided for connecting selected external I/O units.

OUTPUT 79 SYNC

The Sync points in output "79" can now be used as a Problem Determination aid for intermittent problems. MIM part 1, page 10-240 "OUTPUT 79" describes Byte 1, bits 6 and 7 as Scope syncs, pulse 1 and 2. The SST, Biomation, or scope can be used on these points for a trigger to the failure. Note that this is possible only with APAR IR61608, applicable to both EP and NCP. Byte 1, bit 6 (pulse 1) will be triggered by Level 1 interrupts. Byte 1, bit 7 (pulse 2) will be triggered by the Box Error Record processor. Using these triggers to isolate the failure will prevent long hours of record review time.

PT-2/TP LINE MONITOR (TPLM)

The PT-2/TPLM is a data capture/presentation tool used for problem determination in a TP network environment. The transmit and/or receive data of the communication network, along with control line changes, are monitored and recorded on tape under control of the PT-2 application programs. The PT-2/TPLM supports start-stop, BSC, and SDLC line protocols. The recorded data can be displayed and analyzed by the on-site CE or it can be transmitted to a remote site for analysis.

PT-2 SNA EDIT AND DISPLAY PROGRAM (SNAPED)

The SNAPED program formats and edits SDLC/SNA data recorded on tape by the SDLC or the high speed SDLC trace programs.

SDLC/SNA debugging is enhanced by displaying the data in two modes.

1. SDLC mode, the data on the trace tape is formatted to display:
 - Address
 - SDLC command (bytes are decoded to mnemonic form)
 - Poll/final bit
 - N/S transmitter sequence count
 - N/R receiver sequence count
 - Frame check sequence (FCS)
2. SNA Mode, the data on the trace tape is formatted to display:
 - Address
 - FID type
 - Request/response header
 - SNA commands
 - Request/response unit
 - Data

PT-2 HIGH-SPEED TRACE PROGRAMS

The high speed trace programs (HISDTR - high speed SDLC and HIBSTR - high speed BiSync) capture data from TP links or loops operating at speeds of 19.2 kbps to 56 kbps.

The trace data from the TP line monitor is stored in a 40K byte buffer area in the PT-2 main storage. All repetitive characters are compressed to achieve maximum high speed data capture and storage.

PT-2 TP EXERCISE PROGRAM (TPEXER)

The TP exercise programs, in conjunction with the PT-2 TPLM, exercise data terminal equipment (DTE) and/or data communication equipment (DCE) in start-stop, BSC or SDLC modes.

TP devices can be exercised remotely or locally.

There are two modes of TP exercise operation:

1. Manual Mode: Data to be transmitted (exercise data) is entered via the PT-2 keyboard. All TP activity is displayed and recorded on tape.
2. Tape Mode: Data to be transmitted (exercise data) is contained on a prerecorded tape from a previous line trace or manual exercise operation. In this mode of operation, the CE can compare the responses from DTE/DCE with what is on tape by selecting "compare mismatch stop". Expected responses can then be compared visually with actual responses from the DTE/DCE.

The PT-2/TPLM utilizes external clocks or the TPLM internal exercise clocks (600, 1200, 2400, 4800 or 9600).

PT-2 CHANNEL MONITOR (CHIM)

The PT-2/channel monitor can be attached to any System/370, 4331, or 4341 I/O Channel and to the DASD (file) CTL-I interface. The PT-2/CHIM, under program control, monitors all I/O channel bus and tag lines, stores up to 4096 electronic snapshots of the monitored lines, and time stamps and record multiple events on the PT-2 tape. The PT-2/CHIM can perform its functions in unattended mode. An offline edit program provides search capabilities and presents recorded bus and tag line data on the PT-2 display. The data is displayed in time-related sequences for reconstruction and analysis of channel events.

MODEM INTERFACE TEST SET

The modem interface test set is a hand-held battery-powered device that enables a TP CE to display, monitor, or control the 24 leads of an EIA data set cable. The polarities of commonly used lines are displayed in LEDs, and other lines can be jumpered to spare LEDs. All lines are brought out to jumper connections enabling the CE to make inter-line connections for diagnostic purposes or temporary repairs. This tool helps the CE readily identify problems on the EIA interface, such as not-ready conditions, no polling, no replies, and line interruptions.

MAINTENANCE DEVICE 2 (MD2)

The MD2 is a CE branch office tool that may be used with an acoustic coupler to perform various tasks directly with the 3725 diskette.

These tasks are detailed in Chapter 2, under "File Transfer".

Stand-Alone Link Tests (SALT)

The stand-alone link tests, also called "link tests", are used to test:

- The link between two communication controllers
- The link between a 3725 and an SDLC terminal

The link tests consist of two programs: (1) the link test requester (REQ), for use in the requester 3725, and (2) the link test responder (RESP), for use in the responder 3725. Both programs are recorded on the controller diskette. They destroy the control program when they are loaded and run in stand-alone mode instead of control program mode.

The link tests are particularly useful for link-attached controllers when the control program cannot be loaded over the normal IPL link.

The link tests are loaded from the operator console using the IPL/TSS functions. (The procedures are described in 3725 Problem Determination and Extended Services, GA33-0028, Vol. A06.)

TESTING AN INN LINK

The link tests can be used to check an intermediate network node (INN) link between two 3725s, or between a 3725 and a 3705. The INN link is an SDLC leased or manually switched line.

The link to be tested must be defined as an IPL port in the IPL port table of the requester controller, and also in the responder controller (if the link tests are to be used as responder). (See details in 3725 Problem Determination and Extended Services.)

SDLC TERMINALS EXERCISER WITHOUT CP LOADED

Test Purpose

The link tests can also be used to exercise SDLC terminals provided that they:

- Reply correctly to SDLC test frames (see 3725 Problem Determination and Extended Services for SDLC test frame description)
- Do not require the following options:
 - Transmit two flags before frame
 - Transmit flags between frames
 - Transmit with new SYNC
- Do not use the 3725 internal clock

The lines to be exercised must be defined as IPL ports in the IPL PORT table. They should be removed from the IPL PORT table at end of test. Also, if customer-defined IPL ports have been overridden, they must be redefined.

Procedure

1. Start as follows:
 - a. Use the CDF functions to create (if not already done) and update the CDF, and check the clocking, as required (see page 2-401).
 - b. Record the customer IPL ports manually, or via the printer, if installed, to be able to re-establish them after the test.
2. Define the lines to be tested as IPL ports in the link IPL PORT table according to the terminal and line characteristics (see 3725 Problem Determination and Extended Services).

Notes:

- 1) Up to eight lines can be defined in the IPL PORT table. If more than eight lines have to be tested, define the first eight in the IPL PORT table and test them as described below. Then, define new lines by updating the IPL PORT table and restart the procedure at step 3.
- 2) If you override an existing customer IPL port, do not forget to re-establish it after the test.

3. Proceed as follows:

- a. Load the link test program requester in the CCU.

Warning:

The link tests destroy the control program that may be running in the CCU. In such case, before loading the link tests, ask the customer to vary off-line the lines and channels connected to the controller.

- b. Disable all the channel ports at the control panel.
- c. Press SELN AREA, then I followed by SEND to display the IPL CCU/TSS menu.
- d. Enter 3 to start loading the link test requester.

4. Invoke the link test function as follows:

- a. Enter T to terminate the LOAD function.
- b. Enter L to display the LINE FNCTN menu.
- c. Enter 3 followed by SEND to invoke the LINK TEST function.

5. Be sure that the terminal to be tested is powered on.

Also, in case of a programmable terminal, be sure that the terminal is initialized (refer to appropriate terminal documentation) and that its host communication link is active.

6. Perform the test by providing the required information (see 3725 Problem Determination and Extended Services) considering the following notes:

Notes:

- 1) The responder address is the address of the terminal.
 - 2) The data pattern to be used for the test should not be longer than the size of the terminal buffer as the terminal will reflect back only the data it is able to receive. So, for terminals with a buffer size less than 128 bytes, the use of the personal pattern option is recommended.
 - 3) The personal pattern option allows defining an empty pattern (containing no data). This facility must be considered for terminals that are not able to reflect back the received data (or that send back their own data).
7. When the test is completed for a given line, return to step 4 to perform the test on another line, or to step 2 if new IPL ports must be defined.

Warning:

Never forget to reload the link test program each time the IPL PORT table is updated.

Error Reporting

When running in investigation mode, the test stops on the first error encountered and error information is displayed. (The error messages are explained in 3725 Problem Determination and Extended Services.)

Status codes (SCF, LCS, SES) may also be displayed along with some messages. (See MIM Part 2, Vol A01, Chapter R1 for an interpretation of these codes.)



RECMS (MDR) : BSC/SS Device or Line Errors (Part 1 of 3)

The miscellaneous data recorder (MDR) record is a subset of the RECMS record. NCP may refer to a RECMS record by the term "MDR record".

All information herein is a duplicate from the Advanced Communications Function for Network Control Program for the IBM 3725; Emulation Program for the IBM 3725 Reference Summary and Data Areas, LY30-3070. Pages 3-050 to 3-058 give an understanding of what information is needed and what kind of logic is used by an NCP specialist for troubleshooting. The complete and up-to-date manual to make reference to, for error analysis is the above-cited licensed handbook.


PERMANENT BSC/SS DEVICE OR LINE ERRORS

The line error recorder routine (CXDILER) and LPDA terminator (CXDKCET) build this RECMS RU.

RECMS PIU offset 55(37)												
1(1) Physical maint.service X'03'	2(2) Request code (RECMS) X'81'	3(3) Network address of the BSC/SS device or line			5(5) Line Interface Address (CCBBAR) (Note 1)		7(7) Recording Mode=X'80'		8(8) Record ID=X'25'			
9(9) Level of information changes X'01'		10(A) Reserved			13(D) BTU command (BCHCMD) (Note 1)		14(E) BTU modifier (BCHMOD) (Note 1)		15(F) BTU flags (BCHSFLAG) (Note 1)			
17(11) IOB command (IOBCMAND) (Note 1)		1B(12) IOB modifiers (IOBCMODS) (Note 1)		20(14) IOB immediate control flags (IOBIMCTL) (Note 1)		21(15) IOB status (IOBSTAT) (Note 1)		23(17) IOB extended status (IOBEXTST) (Note 1)		24(18) IOB initial error status byte 0 (IOBERST) (Note 1)		
25(19) IOB initial error status byte 1. (IOBERST) (Note 1)		26(1A) IOB initial error exten- ded status (IOBEREST) (NOTE 1)		27(1B) Transmission counter (DVBSDRT) (Note 1)		29(1D) Reserved			31(1F) Temporary error counter (DVBSDRE) (Note 1)			
33(21) 2740 graphic response byte (Note 2)		34(22) Device features (DVBFEAT1) (Note 1)		36(24) Device type (DVBTYPY) (Note 1)		37(25) NPDA alarm parameter		38(26) Link subsystem type (Note 3)		39(27) LPDA control (1st byte)		40(28) LPDA remote status (1st byte) (Note 4)
41(29) LPDA remote status (1st byte) (Note 4)		42(2A) LPDA local status (Note 4)		44(2C) LPDA local and remote self-test results (Note 4)								

- Notes:**
1. Indicates the control block field from which this RECMS-RU field is loaded
 2. 2740 graphic response byte is zero if not applicable
 3. Link subsystem type:
X'00'-No link subsystem data
X'01'-Link Problem Determination Aid
(LPDA) test data
 4. These fields are not present for a line without LPDA testing facilities or for which the LPDA test could not be initiated. The LPDA control byte is always present. If the remaining fields are not present, the control byte is marked "execution not attempted" for all tests.

PERMANENT BSC/SS LINE ERROR-RECMS DECODING



RECMS (MDR): BSC/SS Device or Line Errors (Part 2 of 3)

CHART A

<u>IOBERST Second Byte Bits 0-6</u>	<u>Error</u>	<u>Error Description</u>	<u>Probable Cause</u>
00,20 40,60	Timeout	Some character(s) have been received.	Communications/ secondary failure
04,24 44,64	Cutoff	Control length field was too long.	Communications/ secondary failure
06,26 46,66	Abort	Reply to transmitted data was an ENQ.	Communications/ secondary failure
08,28 48,68	Text in Control Mode	Text received in control mode. (No SOH, STX, or Circle D).	Communications/ secondary failure
0A,2A 4A,6A	DLE Control End	Undefined or DLE and character sequence was received.	Communications/ secondary failure
0C,2C 4C,6C	Wrong ACK	Wrong ACK received.	Secondary failure
0E,2E 4E,6E	Negative ACK	Negative ACK received.	Communications/ secondary failure
10,30 50,70	Received Sub-block	Received sub-block has ended before the end of the transmission block.	Secondary failure
1E,3E 5E,7E	WACK	WACK received.	Secondary failure
80	Timeout	Nothing received.	Communications/ secondary failure
82	Command Reject	Command could not be carried out because of specification error	Program failure
84	Buffer Depleted	Level 2 and 3 buffer pools depleted.	Program failure
88	DLE/EOT	Received disconnect signal.	Secondary failure

CHART B

<u>IOBERST Second Byte Bits 0-6</u>	<u>Error</u>	<u>Error Description</u>	<u>Probable Cause</u>
8A	Data not expected	Data was received when it was not expected.	Communications/ secondary failure
8C	Reset	Immediate X10 command has caused the current command to end prematurely.	Program failure
90	Transmit sub-block end	Sub-block sent has ended before the end of the transmission block.	Program failure
92	EOT sent after Wack	The command ended when EOT was sent, after the Wack reply was received.	Secondary failure
94	Break in text	Break was received while receiving text.	Communications/ secondary failure
96	Poll stop	Poll Stop-Dev. was polled to the polling limit and responded negatively.	Secondary failure
9A	Break in Transmit	Break was received while in the process of transmitting (normal operation).	Secondary failure
9C	Discon- nected	Command issued to a line that is disabled.	Host program failure
E0	User error	Normally indicates an incorrect NCP generation (MTA).	Program failure
E4	Scanner check	Level 1 communication scanner check occurred.	Hardware failure
E8	Adapter check	Communications line adapter check occurred when level 2 interrupt not received.	Hardware failure

RECMS (MDR): BSC/SS Device or Line Errors (Part 3 of 3)

CHART C

<u>IOBERST Second Byte Bits 0-6</u>	<u>Error</u>	<u>Error Description</u>	<u>Probable Cause</u>
EA	Adapter Feedback Check	Communication adpt. feedback check has occurred.	Hardware failure
EC	Equipment Check	Operation ended because of a 3725 hardware failure.	Hardware failure
F0	Modem Error	DSR or CTS dropped during command operation.	Modem interface failure
F2	Modem Clock Error	When in transmit mode and the first character cannot be transmitted.	Modem interface failure
F4	DSR - On Check	For leased lines, indicates DSR did not come up within 3 seconds after DTR.	Modem interface failure
F8	DSC - Off Check	Indicates DSR did not drop within 3 seconds of DTR dropping.	Modem interface failure
FC	ACU Check	No response from ACU.	Modem interface failure
FE	Program Failure	A negative data length was computed.	Program failure

CHART D

<u>IOBERST Bit</u>	<u>Error</u>	<u>IOBERST First Byte</u>	<u>Error Description</u>	<u>Probable Cause</u>
0=1	Underrun	4=1	Character transmitted more than once.	Program/hardware failure
	Overrun	4=0	Receive character overlaid.	Program/hardware failure
1=1	Line quiet timeout	N/A	Data still being received after block ended.	Communications failure
2=1	DLE format exception	N/A	Invalid DLE line control sequence	Secondary failure
3=1	Sub-block error flag	N/A	Error recovery failed to retry a recoverable error.	Communications/secondary failure

CHART E

<u>IOBERST First Byte</u>	<u>Error</u>	<u>Error Description</u>	<u>Probable Cause</u>
3=1	Data check	Block check character error.	Communications failure
1=1	Format exception	Bad line control sequence.	Secondary failure
2=1	Sync check	Stop bit error (start-stop only).	Communications failure
7=1	Length check	Ending character detected before count exhausted (transmit).	Host program

RECMS (MDR): BSC/SS Station Statistics

The line error recorder routine (CXDILER) and LPDA terminator (CXDKCET) build this RECMS RU.

RECMS PIU offset
55(37)

1(1) Physical maint.service X'03'		2(2) Request code (RECMS) X'81'		3(3) Network address of the BSC/SS station		5(5) Line interface address (CCBBAR) (Note 1)		7(7) Recording Mode X'81'		8(8) Record ID=X'25'		0(0) Network services X'01'	
9(9) Level of information changes X'01'		10(A) Reserved				13(D)							
Hex Zeros													
Hex Zeros				27(1B) Transmission Counter (DVBSDRT) (Note 1)		29(1D) Reserved			31(1F) Temporary error counter (DVBSDRE) (Note 1)				
34(22) Device features (DVBFEAT1) (Note 1)		36(24) Device type (DVBTYP) (Note 1)		37(25) NPDA alarm parameter		38(26) Link subsystem type (Note 2)		39(27) LPDA control (1st byte)		40(28) LPDA remote status (1st byte) (Note 3)			
41(29) LPDA remote status (2nd byte) (Note 3)		42(2A) LPDA local status (Note 3)		44(2C) Reserved									

Notes:

1. Indicates the control block field from which this RECMS-RU field is loaded
2. Link subsystem type:
X'00'-No link subsystem data
X'01'-Link Problem Determination Aid (LPDA) test data
3. These fields are not present for a line without LPDA testing facilities or for which the LPDA test could not be initiated. The LPDA control byte is always present. If the remaining fields are not present, the control byte is marked "execution not attempted" for all tests.

RECMS (MDR): SNA Link Permanent Errors

RECMS PIU offset
55(37)

The line error recorder routine (CXDILER) and LPDA terminator (CXDKCET) build this RECMS RU.

1(1) Physical maint.service X'03'	2(2) Request code (RECMS) X'81'	3(3) Network address of SNA link	5(5) Line interface address (CCBBAR) (Note 1)	7(7) Recording mode X'82'	8(8) Record ID=X'25'	0(0) Network services X'01'
9(9) Level of information changes X'02'	Hex zeros					
17(11) I/O command (LXBCMAND) (Note 1)	18(12) Command modifier field (LXBCMODS) (Note 1)	20(14) Immed.ctrl command field (LXBIMCTL) (Note 1)	21(15) Current error status (LXBSTAT) (Note 1)	23(17) Extended error status (LXBEXTST) (Note 1)	24(18) 1st error status (byte 1) (LXBERST) (Note 1)	
25(19) Hold SDLC status (byte 2) (LXBHSTAT) (Note 1)	26(1A) 1st error ex- tended status (LXBEREST) (Note 1)	Hex zeros		30(1E) Received BLU command field (LXBRBLUC) (Note 1)	Hex zeros	
Hex zeros		34(22)(Note2) Transmit BLU command (CCBCFLD) (Note 1)	Hex zeros		39(27) Control flags (CCBRSPON) (Note 1)	40(28) Line type (CCBTYP E) (Note 1)
41(29)(Note3) Command received from sec. station.	42(2A)(Note3) N(R) and N(S) received from sec. station.	43(2B)(Note3) Command reject reason	44(2C)(Note6) Dial control flags (CCBTYP EC) (Note 1)	Hex zeros		
57(39) (Note 6) X'21' call progress signals	59(3B) NPDA alarm parameter	60(3C) Link subsystem type (Note 4)	61(3D) LPDA control (1st byte)	62(3E) LPDA remote status (Note 5)	64(40) LPDA local status (1st byte) (Note 5)	
65(41) LPDA local status (2nd byte) (Note 5)	66(42) LPDA local and remote self-test results (Note 5)					

Notes:

1. Indicates the control block field from which this RECMS-RU field is loaded
2. This field contains the transmit BLU command for a duplex link; contains X'00' for a half-duplex link
3. This field contains the indicated data only if a command reject caused the RECMS; otherwise, it contains X'00'
4. Link subsystem type:
X'00'-No link subsystem data
X'01'-Link Problem Determination Aid (LPDA) test data
5. These fields are not present for a line without LPDA testing facilities or for which the LPDA test could not be initiated. The LPDA control byte is always present. If the remaining fields are not present, the control byte is marked "execution not attempted" for all tests
6. These fields will be zero for non X.21 switched lines.

RECMS (MDR): SNA Station Permanent Errors

The line error recorder routine (CXDILER) and LPDA terminator (CXDKCET) build this RECMS RU.

RECMS PIU offset
55(37)

1(1) Physical maint. service X'03'		2(2) Request code (RECMS) X'81'		3(3) Network address of the SDLC station		5(5) Line interface address (CCBBAR) (Note 1)		7(7) Recording mode X'83'		8(8) Record ID=X'25'		0(0) Network services X'01'			
9(9) Level of information changes X'02'		10(A) Reserved				13(D) Service-seeking control flags (SCBSSCF) (Note 1)		15(F) Output control flag (SCBOCF) (Note 1)		16(10) Reserved					
17(11) I/O command (LXBCMAND) (Note 1)		18(12) Command modifier field (LXBCMODS) (Note 1)		20(14) Immed. ctrl command field (LXBIMCTL) (Note 1)		21(15) Current error status (LXBSTAT) (Note 1)		23(17) Extended error status (LXBEXTST) (Note 1)		24(18) 1st error status (byte 1) (LXBERST) (Note 1)					
25(19) Hold SDLC status (byte 2) (LXBHSTAT) (Note 1)		26(1A) 1st error extended status (LXBEREST) (Note 1)		27(1B) Total I-format transmission counter (SCBTCNT) (Note 1)		29(1D) Reserved		30(1E) Received BLU Command field (LXBRBLUC) (Note 1)		31(1F) Total retry counter (SCBTRTCT) (Note 1)					
33(21) Station type (SCBTYP) (Note 1)		34(22) Transmit BLU command (CCBCFLD) (Note 1)		35(23) Current outstanding count (SCBCOC) (Note 1)		36(24) Pass limit (SCBPCNT) (Note 1)		37(25) Receive count (bits 4,5,6) (SCBNR) (Note 1)		38(26) Send count (bits 4,5,6) (SCBNS) (Note 1)		39(27) Control flags (CCBRSPON) (Note 1)		40(28) Line type (CCBTYP) (Note 1)	
41(29) Command received from sec. station		42(2A) N(R) and N(S) received from sec. station		43(2B) Command reject reason		44(2C) Reserved		45(2D) Receive I-format error counter (SCBRECNT) (Note 1)		47(2F) Total transmission counter (SCBTPCNT) (Note 1)					
49(31) I-format received counter (error free) (SCBRCNT) (Note 1)		51(33) S-format received counter (error free) (SCBRPCNT) (Note 1)				53(35) Total ACK'd I-format counter (SCBTIACT) (Note 1)		55(37) Total I-format retransmissions counter (SCBTINCT) (Note 1)							
57(39) Reserved				59(3B) NPDA alarm parameter		60(3C) Link subsystem type (Note 3)		61(3D) LPDA control (1st byte)		62(3E) LPDA remote status (Note 4)		64(40) LPDA local status (1st byte) (Note 4)			
65(41) LPDA local status (2nd byte) (Note 4)		66(42) LPDA local and remote self-test results (Note 4)													

Notes:

1. Indicates the control block field from which this RECMS-RU field is loaded
2. This field contains the transmit BLU command for a duplex link; contains X'00' for a half-duplex link.
3. Link subsystem type:
X'00'-No link subsystem data
X'01'-Link Problem Determination Aid (LPDA) test data.
4. These fields are not present for a line without LPDA testing facilities or for which the LPDA test could not be initiated. The LPDA control byte is always present. If the remaining fields are not present, the control byte is marked "execution not attempted" for all tests.

RECMS (MDR): SDLC Line Error (Part 1 of 3)

PERMANENT SDLC LINE ERROR




CHART F

LXBHSTAT Bits 0-6	Error	Error Description	Probable Cause
00	Timeout	Received RR, RNH or REJ.	Communication/secondary failure
0C	Partial or negative acknowledgement	Partial acknowledgement (sequence number changed) or negative acknowledgement (sequence number did not change).	Communication/secondary failure
0E	SDLC REJ. received	Line is not duplex. Format exception.	Secondary failure
1C	SDLC RR received	Received RR in NS phase. Format exception.	Secondary failure
1E	SDLC XID received	Received XID in RR or RNR phase. Format exception.	Secondary failure
20	Timeout	Received address and control fields.	Communication/secondary failure
24	Buffer cutoff	Exceeded buffer limit.	Program failure
2C	Partial or negative acknowledgement	Partial acknowledgement (sequence number changed) or negative acknowledgement (sequence number did not change).	Communication/secondary failure
60	Timeout	Flag received.	Communication/secondary failure
62	SDLC command reject received	SDLC command reject displacement: X'YY'=08 Invalid N(R) 04 Frame too long 02 Data in S or NS format 01 Invalid command	Communication/failure

RECMS (MDR): SDLC Line Error (Part 2 of 3)

CHART G

LXBHSTAT Bits 0-6	Error	Error Description	Probable Cause
64	Buffer cutoff	Buffer limit exceeded.	Program failure
80	Timeout	Nothing received.	Communication/secondary failure
84	Buffer pool depleted	No more buffers available.	Program failure
8C	Reset	End run command.	Program failure
8E	Invalid address	Invalid address received from secondary.	Secondary failure
96	Poll stop	Device was polled to the polling limit and responded negatively.	Secondary failure
9C	Disabled	Command issued to a line that is disabled.	Host program failure
A0	Timeout	Timeout flag received.	Communication/secondary failure
A2 and LXBERST Byte 0.1 =1	Received invalid SDLC command	Format exception.	Secondary failure
A4	Invalid N(R) count	Invalid (incongruous N(R) in I or S format received.	Program/secondary failure
A6	Link activity timeout	No flags received (remote NCP only).	Primary communication failure
A8 and LXBERST Byte 0.1 =1	Received SDLC DISC	Format exception.	Secondary failure

CHART I

LXBEREST Bit	Error	LXBERST Bit	Error Description	Probable Cause
0=1	Underrun	4=1	Character transmitted more than once.	Program/hardware failure
0=1	Overrun	4=0 3=0	Received character overlaid.	Program/hardware failure
0=1	Frame check sequence error	4=0 3=1	Data check	Communication failure
4=1	Block overrun		Level 3 block processing in progress when another block available from level 2.	Program failure
6=1	Abort received		Eight consecutive 1-bits received.	Communication/secondary failure
7=1	Monitor count overflow		64 temporary I-format receive errors have occurred.	Communication/secondary failure

RECMS (MDR): SDLC Line Error (Part 3 of 3)

CHART H

<u>LXBHSTAT</u> <u>Bits 0-6</u>	<u>Error</u>	<u>Error Description</u>	<u>Probable Cause</u>
AC and LXBERST Byte 0.1 =1	Received SDLC SNRM	Format exception.	Secondary failure
B6 and LXBERST Byte 0.1 =1	Received SDLC ROL	Format exception. Can be caused by system reset at the secondary.	Secondary failure
BC and LXBERST Byte 0.1 =1	Received SDLC NSA	Received SDLC NSA in RR or RNR phase. Format exception.	Secondary failure
E2	Modem check	CTS dropped during command.	Modem failure
E8	Adapter check	Timer has detected no level 2 interrupt. Modem self-test failed to get a level 2 interrupt. Enable or dial failed to get a level 2 interrupt.	Hardware failure
EA	Adapter feedback check	Communication adapter feedback check has occurred. Improper system generation for the adapter in use.	Hardware failure
EC	Equipment check	Equipment check.	Hardware failure
EE	Modem check	DSR dropped during command.	Modem failure

CHART H (CONTINUED)

<u>LXBERST</u> <u>Bits 0-6</u>	<u>Error</u>	<u>Error Description</u>	<u>Probable Cause</u>
F0	Modem error	. DSR dropped during Xmit or RCVE operation. . Can be set by the timer. . CTS drops while transmitting.	Modem interface failure
F2	Transmit clock or CTS failure	Transmit clock or CTS failure.	Modem interface failure
F4	DSR turn on check	For leased lines indicates DSR did not come up within 3 seconds after DTR.	Modem interface failure
F6			No cable installed
F8	DSR turn off check	DSR failed to drop during a disable operation.	Modem interface failure
FC	ACU check	Incorrect autocall interface sequence.	Modem interface failure
FE	Program failure	Negative data length was completed.	Program failure

CHART J

<u>LXBERST</u>	<u>Error</u>	<u>Error Description</u>	<u>Probable Cause</u>
3=1	Frame check sequence error	Frame check sequence error (data check).	Communication failure
1=1	Format exception	Invalid SDLC format.	Secondary failure

EREP Unit Check Records

The EREP unit check records should be correlated with console error messages and customer reports to pinpoint failure times and causes.

To analyze a unit check record:

1. Determine if the channel unit address A is the NSC (native subchannel) address.
2. Determine the device type B (3725 or emulated device).
3. Check the CCW for the command code C (see description of EP channel commands and NCP channel commands in Chapter 12).
4. Check the channel status D and/or unit status E for error indications.
5. Check the sense byte F .

NSC: Use NCP status/sense information in Chapter 12.

ESC: Determine terminal type G .
For start-stop and BSC see EP sense information in Chapter 12.

Note: Statistical data H is accumulated in the access method (program counters).

---RECORD ENTRY TYPE - UNIT CHECK		SOURCE - OUTBOARD		MODEL- 145	SERIAL NO. 123456	
OS/V5 REL X						
DATE- 103 XX		DAY YEAR	HH MM SS.TH	JOB IDENTITY ABCDEFGH		
			TIME- 08 09 10 11	C1C2C3C4 C5C6C7C8		
DEVICE TYPE		2703 B				
PRIMARY CHANNEL UNIT ADDRESS		000B8 A				
ALTERNATE CHANNEL UNIT ADDRESS		0000008				
COMMUNICATION ADAPTER TYPE		IBM TERM I				
TERMINAL TYPE		1050 G				
FAILING CCW		C CC CA FL C1	K CA US CS CT			
		02 004000 40 00 0088	CSW F0 03EFF8 0E 00 0008			
UNIT STATUS E		CHANNEL STATUS D	STATISTICAL DATA H		STATISTICAL DATA	
ATTENTION	0	PRGM-CTLD TRPT	0	TEMPY READS	000	TEMPY WRITES 015
STATUS MODIFIER	0	INCORRECT LENGTH	0	INTRVN REQD	000	BUS OUT CHK 015
CONTROL UNIT END	0	PROGRAM CHECK	0	EQUIP CHK	000	OVERRUN 015
BUSY	0	PROTECTION CHECK	0	LOST DATA	000	TIMEOUT 015
CHANNEL END	1	CHAN DATA CHECK	0	NOT USED	000	NOT USED 006
DEVICE END	1	CHAN CTL CHECK	0	NOT USED	000	NOT USED 006
UNIT CHECK	1	I/F CTL CHECK	0	NOT USED	000	NOT USED 006
UNIT EXCEPTION	0	CHAINING CHECK	0	NOT USED	000	CHAN DATA CHK 006
SENSE BYTE DATA F						
BYTE 0	06					
CMND REJ	0					
INTV REQD	0					
BUS C CHK	0					
EQUIP CHK	0					
DATA CHK	0					
OVERRUN	1					
RECEIVING	1					
TIMEOUT	0					
HEX DUMP OF RECORD						
HEADER	30550800	00000000	0071103F	08091011	00123456	01300000
0018	01020304	05060708	09004000	40000088	F003EFF8	DEB00008
0038	00000003	0F0F0F0F	0F0F0F0F	06060606	06060606	06060606
					00000103	01004013

Contents

CHAPTER 4. LOCATIONS AND JUMPERS

Component Locations (Part 1 of 4) Frame 01, 3725 Model 1	4-010	Card Location (Part 5 of 5) Board PWB2 Board C2LB Board C2LB2	4-064	LAB 3, Scanner and Token-Ring Adapter Board Information LAB Board Position 3 (LAB TYPE C) - 01B-A1 - Scanners 5 and TRA 6	4-124
Component Locations (Part 2 of 4) Frame 01, 3725 Model 2	4-011	Cabling Between Boards General View	4-070	LAB 4, Scanner and Token-Ring Adapter Board Information LAB Board Position 4 - 02A-A3	4-125
Component Locations (Part 3 of 4) Frame 02	4-012	Primary IOC Bus: Signal Tables	4-080	LAB 5, Scanner and Token-Ring Adapter Board Information LAB Board Position 5 - 02A-A2	4-126
Component Locations (Part 4 of 4) Thermal Switch Locations Locations 01ATH, 01BTH, 02ATH, 02BTH, 02CTH Locations 01HTH, 02DTH Thermal Switch Type Airflow Detector Thermal Switch	4-013	CCU-to-Storage Bus: Signal Tables	4-081	LAB 6, Scanner and Token-Ring Adapter Board Information LAB Board Position 6 - 02A-A1	4-127
MMB, C2LB, C2LB2, CLAB, LAB, and CAB Board Layout Card and Connector Assignments (Card Side) Voltage Pin Assignments Card Pin Assignments (Board and Top Connector) Board Pin Assignments (Pin Side)	4-020	MIOC Bus: Signal Tables	4-082	LAB 7, Scanner and Token-Ring Adapter Board Information LAB Board Position 7 - 02B-A3	4-128
Power Board Layout Card and Connector Assignments Voltage Pin Assignments Board Pin Assignments (Pin Side)	4-021	MOSS Buses: Signal Tables MOSS-to-Diskette Cable MOSS-to-Control-Panel Cable	4-083	LAB 8, Scanner and Token-Ring Adapter Board Information LAB Board Position 8 - 02B-A2	4-129
CCU Board Layout Card and Connector Assignments (Card Side) Voltage Plan (Board Side) Board Pin Assignments (Card Side)	4-022	Channel Adapter Cables: Signal Tables Channel Adapter Cables	4-084	Communication Interfaces: LICs Signal Name Abbreviations	4-130
Signal Routing Documentation (Part 1 of 2) Pin Lists Net Lists Pin List (Example)	4-030	Secondary IOC Bus: Signal Tables	4-085	Communication Interfaces: TICs Ring Interface Electrical Characteristics Ring Receiver Ring Transmitter	4-131
Signal Routing Documentation (Part 2 of 2) Net List (Example) Pin Addressing Drawing Interpretation	4-031	IOC Wire Continuity (Part 1 of 3) Cables from CCU Board to CAB	4-090	LIC Type 1 DCE Interface (Except Japan NTT) (Part 1 of 2) Cable to DCE Wrap Block (Part 1733977) Adapter Cables UK Belgium	4-140
Board Voltage Plan (Part 1 of 4)	4-040	IOC Wire Continuity (Part 2 of 3) Cables from CAB to LAB Position 8	4-091	LIC Type 1 DCE Interface (Except Japan NTT) (Part 2 of 2) Interchange Circuits Cable ID Signals Voltage Levels	4-141
Board Voltage Plan (Part 2 of 4)	4-041	IOC Wire Continuity (Part 3 of 3)	4-092	LIC Type 1 DCE Interface (Japan NTT Only) (Part 1 of 2) Wrap Block (Part 1733977) Cable to DCE Adapter Cable (Part 1743583) Test Switch Logical Function	4-150
Board Voltage Plan (Part 3 of 4)	4-042	Terminator Card (BUSTERM) Diagram	4-095	LIC Type 1 DCE Interface (Japan NTT Only) (Part 2 of 2) Interchange Circuits Cable ID Signals Test/Operate Switch Voltage Levels	4-151
Board Voltage Plan (Part 4 of 4) Control Panel Card (01L) Voltage Pins	4-043	High-Speed Clock Distribution (From ACLK Card) Other Machine Clocks Clock Scoping Clock Cable Routing High-speed Clock Board Pins	4-100	LIC Type 1 Auto Call Unit Interface (Part 1 of 2) Cable to ACU Adapter Cable (UK) Wrap Block (Part 1733977) Thread Wrap Block (Part 147440, Japan Only)	4-160
Card and Board Organization	4-050	CA Cable Routing (Part 1 of 5) Frame 01 CA Cable Removal	4-110	LIC Type 1 Auto Call Unit Interface (Part 2 of 2) Interchange Circuits Cable ID Signals Voltage Levels	4-161
Card Location (Part 1 of 5) Board: MMB Board: CCUB	4-060	CA Cable Routing (Part 2 of 5) Frame 02	4-111		
Card Location (Part 2 of 5) Board CLAB1 Board CLAB2	4-061	CA Cable Routing (Part 3 of 5)	4-112		
Card Location (Part 3 of 5) Board LABA Board LABB	4-062	CA Cable Routing (Part 4 of 5) CA Connection Details (From a Top Connector to the Tailgate) CA Connection (From a Top Connector to the Tailgate)	4-113		
Card Location (Part 4 of 5) LAB C Board Card Location Crossover Location Board CAB Board PWB1	4-063	CA Cable Routing (Part 5 of 5) Cable Continuity	4-114		
		C2LB, Scanner Board Information C2LB Board 01A-A3 - Scanner 1	4-120		
		C2LB2, Scanner Board Information C2LB2 Board 01B-A2 - Scanner 3	4-121		
		CLAB1, Scanner Board Information CLAB1 Board (Type A) - 01A-A3 - Scanner 1	4-122		
		CLAB2 and LAB3, Scanner Board Information CLAB2 Board (Type A) - 01B-A2 - Scanner 3 LAB Board Position 3 (Type A) - 01B-A1 - Scanner 5 LAB Board Position 3 (Type B) - 01B-A1 - Scanners 5 and 6	4-123		

Contents

LIC Type 1 Direct Attachment to Terminal (Part 1 of 2) Cable to Terminal Wrap Block (Part 1733977)	4-170	LIC Type 4B DCE Interface (France Only - Transmic) (Part 1 of 2) Cable to DCE Wrap Block (Part 1733977)	4-232
LIC Type Direct 1 Attachment to Terminal (Part 2 of 2) Interchange Circuits Cable ID Signals Voltage Levels	4-171	LIC Type 4B DCE Interface (France Only - Transmic) (Part 2 of 2) Interchange Circuits Cable ID Signals Voltage Levels	4-233
LIC Type 2 DCE Interface (Part 1 of 2) Cable to DCE Wrap Block (Part 1733977)	4-180	LIC Type 4B Direct Attachment to Terminal (Part 1 of 2) Cable to Terminal Wrap Block (Part 1733977)	4-240
LIC Type 2 DCE Interface (Part 2 of 2) Interchange Circuits Cable ID Signals Voltage Levels Data Terminal Ready and Ring Indicator Leads Other Circuits	4-181	LIC Type 4B Direct Attachment to Terminal (Part 2 of 2) Interchange Circuits Cable ID Signals Voltage Levels	4-241
LIC Type 3 DCE Interface (Part 1 of 2) Cable to DCE Adapter Cable (France) Wrap Cable (Part 1733979)	4-190	Jumpers	4-260
LIC Type 3 DCE Interface (Part 2 of 2) Interchange Circuits Cable ID Signals Voltage Levels	4-191	Jumpers Installed on Boards LAB, CLAB, C2LB, C2LB2, and CAB Address Jumpers Clock Select Jumper 3725/3726 3725 Model 2 Board C2LB Speed Selection	4-270
LIC Type 3 Direct Attachment to Terminal (Part 1 of 2) Cable to Terminal Wrap Cable (Part 1733979)	4-200	Jumpers Installed on Cards (Part 1 of 4) Select Out Priority Jumpers (on CADR)	4-280
LIC Type 3 Direct Attachment to Terminal (Part 2 of 2) Interchange Circuits Cable ID Signals Voltage Levels	4-201	Jumpers Installed on Cards (Part 2 of 4) NSC Address Jumpers (on CADR) Examples LIC Type 4A, 4B Jumpers	4-281
LIC Type 4A DCE Interface (Part 1 of 2) Cable to DCE Wrap Block (Part 1733977)	4-210	Jumpers Installed on Cards (Part 3 of 4) ESC Address Range Jumpers (on CHIN) Data In/Data Out Jumper (on CHIN)	4-282
LIC Type 4A DCE Interface (Part 2 of 2) Interchange Circuits Cable ID Signals Voltage Levels	4-211	Jumpers Installed on Cards (Part 4 of 4) Burst Length (on CCIN) Lock/Unlock NCP Buffers (on CCIN)	4-283
LIC Type 4A Direct Attachment to Terminal (Part 1 of 2) Cable to Terminal Wrap Block (Part 1733977)	4-220	Jumpers on IOC Bus IOC Bus Terminator Jumpers IOC Bus Continuity Plugs	4-290
LIC Type 4A Direct Attachment to Terminal (Part 2 of 2) Interchange Circuits Cable ID Signals Voltage Levels	4-221	Power Jumpers Power Terminator Cards Frame 01 Frame 02 Five-Volt Power Supply Jumpers	4-300
LIC Type 4B DCE Interface (Except France) (Part 1 of 2) Cable to DCE Wrap Block (Part 1733977)	4-230		
LIC Type 4B DCE Interface (Except France) (Part 2 of 2) Interchange Circuits Cable ID Signals Voltage Levels	4-231		

Component Locations (Part 1 of 4)

FRAME 01, 3725 MODEL 1


See 3725 MD Vol. B01 YZ pages for cross references to detailed drawings of subassemblies described here.

The main areas of frame 01 are indicated by bold letters on the 3725 drawings. Identify the area using the following table:



Area	Main Area Identification
A	Gate A A1: MMB A2: CCUB A3: CLAB1 (Ca or TPS position 1 and LAB type A position 1) A4: Series regulator J1: IOC bus connector J2: Blower connector
B	Gate B A1: LAB type A, B, or C position 3 A2: CLAB2 (CA or TPS position 2 and LAB type A position 2) J1: IOC bus connector J2: Blower connector
C	Diskette drive
D	Connector area A1 to A4: TPS position 2 (CLAB2) B1 to B4: CA position 2 (CLAB2) C1 to F8: LIC connectors (CLAB2) G1 to K8: LIC connectors (CLAB1) L1 to L4: CA position 1 (CLAB1) M1 to M4: CA position 1 (CLAB1) For LAB type A or B N1 to R8: LIC connectors For LAB type C N2, P2, Q2, R2 Ring connectors N5 to N8: LIC connectors P5 to P8: LIC connectors Q5 to Q8: LIC connectors R5 to R8: LIC connectors J1: Primary operator console J2: Alternate operator console J8 to J11: EPO connectors
E	DC common bus bar
H*	Power tub A1: PS1 (+5 V to CLAB2 and LAB position 3) A2: PS2 (-4.3 V to CCUB) A3: PS3 (+5 V to MMB and CLAB1) A4: Blower
L*	Control panel
N*	Primary power box (T1, PS6, CB1)
P*	Phase control transformer (T4)
Q*	T2, PS4 power ferro A
R*	Power board (PWB1)
S*	Power factor capacitors
W*	Frame ground

* Refer to the 3725/3726 MI Volume A02 for power details, and to the 3725/3726 MD Volume B01/B02 for wiring diagrams.

FRAME 01



DISPLAY CONNECTOR



Detail B with LAB C installed in LAB pos.3

Component Locations (Part 2 of 4)



FRAME 01, 3725 MODEL 2

The main areas of frame 01 for the 3725 Model 2 are indicated by bold letters on the 3725 drawings. Identify the area using the following table:


Area	Main Area Identification
A	Gate A A1: MMB A2: CCUB A3: C2LB (CA position 1 and 2, and TSS position 1) A4: Series regulator J1: IOC bus connector J2: Blower connector
B	Gate B A1: LAB type A, B, or C pos 3 A2: C2LB2 (CA position 3 and 4, and TSS position 2) J1: IOC bus connector J2: Blower connector
C	Diskette drive
D	Connector area G1 to K6: LIC connectors (C2LB) L1 to L4: CA position 2 (C2LB) M1 to M4: CA position 1 (C2LB) B1 to B4: CA position 3 (C2LB2) A1 to A4: CA position 4 (C2LB2) C1 to F6: LIC connectors (C2LB2) For LAB type A or B N1 to R8: LIC connectors For LAB type C N2, P2, Q2, R2 Ring Connectors N5 to N8: LIC Connectors P5 to P8: LIC Connectors Q5 to Q8: LIC Connectors R5 to R8: LIC Connectors J1: Primary operator console J2: Alternate operator console J8 to J11: EPO connectors
E	DC common bus bar
H*	Power tub A1: PS1 (+5 V to C2LB2 and LAB position 3) A2: PS2 (-4.3 V to CCUB) A3: PS3 (+5 V to MMB and C2LB) A4: Blower
L*	Control panel
N*	Primary power box (T1, PS6, CB1)
P*	Phase control transformer (T4)
Q*	T2, PS4 power ferro A
R*	Power board (PWB1)
S*	Power factor capacitors
W*	Frame ground

* Refer to the 3725 Model 2 MI Volume A02 for power details, and to the 3725/3726 MD Volume B01/B02 for wiring diagrams.


See 3725 MD Vol. B01 YZ pages for cross references to detailed drawings of subassemblies described here.



Power Tub
Detail A



Detail B



Detail B with LAB C installed in LAB pos.3

Component Locations (Part 3 of 4)


FRAME 02

See 3726 MD Vol. A01 YZ pages for cross references to detailed drawings of subassemblies described here.

FRAME 02

The main areas of frame 02 are indicated by bold letters on the 3726 drawings. Identify the area using the following table:

Area	Main Area Identification
A	Gate A A1: LAB type A, B, or C pos 6 A2: LAB type A, B, or C pos 5 A3: LAB type A, B, or C pos 4 J1: IOC bus connector J2: Blower connector
B	Gate B A2: LAB type A, B, or C pos 8 A3: LAB type A, B, or C pos 7 J1: IOC bus connector J2: Blower connector
C	Gate C A1: CAB (CA pos 3, CA pos 4, CA pos 5 or TPS pos 4, CA pos 6 or TPS pos 3) J1: IOC bus connector
D*	Power Tub A1: PS1 (+5 V to LAB position 6) A2: PS2 (+5 V to LAB position 5) A3: PS3 (+5 V to LAB position 4) A5: PS5 (+5 V to LAB position 8) A6: PS6 (+5 V to LAB position 7) A7: Blower
E	DC common bus bar
F*	Primary power supply (T1, PS10)
G*	Ferro power supply (T2, PS8)
H*	Ferro power supply (T3, PS9)
J*	Power board (PWB2)
K*	Transformer (T4)
L*	Transformer (T5)
M*	Power factor capacitors
P	Connector area E1-H8: Line or Ring connectors (LAB pos 6) J1-M8: Line or Ring connectors (LAB pos 5) N1-R8: Line or Ring connectors (LAB pos 4)
Q	Connector area A1-A4: CA pos 6 or TPS pos 3 (CAB) B1-B4: CA pos 5 or TPS pos 4 (CAB) C1-C4: CA pos 4 (CAB) D1-D4: CA pos 3 (CAB) J1-M8: Line or Ring connectors (LAB pos 8) N1-R8: Line or Ring connectors (LAB pos 7) J8-J11: EPO connectors
W*	Frame ground



* Refer to the 3725/3726 MI Volume A02 for power details, and to the 3725/3726 MD Volume A01 for wiring diagrams.


with LAB C installed in LAB pos. 4,5,6.

Detail B with LAB C installed in LAB pos. 7,8


Component Locations (Part 4 of 4)

THERMAL SWITCH LOCATIONS


Locations 01ATH, 01BTH, 02ATH, 02BTH, 02CTH




Locations 01HTH, 02DTH



THERMAL SWITCH TYPE AIRFLOW DETECTOR




THERMAL SWITCH





MMB, C2LB, C2LB2, CLAB, LAB, and CAB Board Layout



CARD AND CONNECTOR ASSIGNMENTS (CARD SIDE)



VOLTAGE PIN ASSIGNMENTS


For voltage pin assignments, refer to the board voltage plan starting on page 4-040.

CARD PIN ASSIGNMENTS (BOARD AND TOP CONNECTOR)



Detail A

BOARD PIN ASSIGNMENTS (PIN SIDE)



Power Board Layout


CARD AND CONNECTOR ASSIGNMENTS

For card and connector assignments, see page 4-060.

VOLTAGE PIN ASSIGNMENTS

For voltage pin assignments, refer to the board voltage plan starting on page 4-040.


BOARD PIN ASSIGNMENTS (PIN SIDE)




CCU Board Layout

CARD AND CONNECTOR ASSIGNMENTS (CARD SIDE)

Warning: The torque screwdriver (part 4134750) must be used to tighten cards and connectors in place.



BOARD PIN ASSIGNMENTS (CARD SIDE)



VOLTAGE PLAN (BOARD SIDE)

No voltage checking is possible on the pin side of the CCUB board.

Dots represent pins; bold dots represent power pins; all others are signal pins or are not used. The following table indicates the voltages on the different pins of the CCU board:

Symbol	Voltage
△	Ground
◇	-1.50V
□	-4.3V
○	+5.00V
×	-5.00V

Signal Routing Documentation (Part 1 of 2)

The YZ5xx pages provide pin lists and net lists.

PIN LISTS

These lists relate each board pin to its associated net name and signal name. The I/O column indicates when the signal is leaving the pin (O), or entering the pin (I). "V" indicates a voltage pin, and "#" indicates a connector pin leaving the board.

NET LISTS

These lists relate each signal name to net name, and indicate the pins wired together for that net on the board. Signal names are listed in alphabetic order.

PIN LIST (EXAMPLE)

PINS I/O NET NAME	SIGNAL NAME	PINS I/O NET NAME	SIGNAL NAME
H5D10 O \$EK-BYT0005	MEMORY DATA BUS BYTE 0	J6E04 V LA008#135	GND
H5D11 O \$EK-BYT0003	MEMORY DATA BUS BYTE 0	J6E02 V LA008#134	GND
H5D12 O \$EK-BYT0000	MEMORY DATA BUS BYTE 0	J6E04 # \$ED-CAF03	M3
H5D13 O \$EC-PC0	MEMORY DATA BUS BIT PC	K2B02 O \$EK-BYT0 P	MEMORY DATA BUS BYTE Y
J2B02 O \$EK-BYT0 P	MEMORY DATA BUS BYTE Y	K2B03 O \$EK-BYT005	MEMORY DATA BUS BYTE Y
J2B03 O \$EK-BYT005	MEMORY DATA BUS BYTE Y	K2B04 O \$EK-BYT003	MEMORY DATA BUS BYTE Y
J2B04 O \$EK-BYT003	MEMORY DATA BUS BYTE Y	K2B05 O \$EK-BYT001	MEMORY DATA BUS BYTE Y
J2B05 O \$EK-BYT001	MEMORY DATA BUS BYTE Y	K2B07 O \$EK-BYTX0 P	MEMORY DATA BUS BYTE X
J2B07 O \$EK-BYTX0 P	MEMORY DATA BUS BYTE X	K2B08 O \$EK-BYTX006	MEMORY DATA BUS BYTE X
J2B08 O \$EK-BYTX006	MEMORY DATA BUS BYTE X	K2B09 O \$EK-BYTX004	MEMORY DATA BUS BYTE X
J2B09 O \$EK-BYTX004	MEMORY DATA BUS BYTE X	K2B10 O \$EK-BYTX001	MEMORY DATA BUS BYTE X
J2B10 O \$EK-BYTX001	MEMORY DATA BUS BYTE X	K2B12 O \$EK-BYTX002	MEMORY DATA BUS BYTE X
J2B12 O \$EK-BYTX002	MEMORY DATA BUS BYTE X	K2D02 O \$EK-BYTY007	MEMORY DATA BUS BYTE Y
J2D02 O \$EK-BYTY007	MEMORY DATA BUS BYTE Y	K2D04 O \$EK-BYTY006	MEMORY DATA BUS BYTE Y
J2D04 O \$EK-BYTY006	MEMORY DATA BUS BYTE Y	K2D05 O \$EK-BYTY004	MEMORY DATA BUS BYTE Y
J2D05 O \$EK-BYTY004	MEMORY DATA BUS BYTE Y	K2D06 O \$EK-BYTY002	MEMORY DATA BUS BYTE Y
J2D06 U \$EK-BYTY002	MEMORY DATA BUS BYTE Y	K2D07 O \$EK-BYTY000	MEMORY DATA BUS BYTE Y
J2D07 O \$EK-BYTY000	MEMORY DATA BUS BYTE Y	K2D09 O \$EK-BYTX007	MEMORY DATA BUS BYTE X
J2D09 U \$EK-BYTX007	MEMORY DATA BUS BYTE X	K2D10 U \$EK-BYTX005	MEMORY DATA BUS BYTE X
J2D10 U \$EK-BYTX005	MEMORY DATA BUS BYTE X	K2D11 U \$EK-BYTX003	MEMORY DATA BUS BYTE X
J2D11 U \$EK-BYTX003	MEMORY DATA BUS BYTE X	K2D12 O \$EK-BYTX000	MEMORY DATA BUS BYTE X
J2D12 U \$EK-BYTX000	MEMORY DATA BUS BYTE X	K2D13 U \$EC-PA0	MEMORY DATA BUS BIT PA
J2D13 U \$EC-PA0	MEMORY DATA BUS BIT PA	K3B03 O \$EC-PB0	MEMORY DATA BUS BIT PB
J3B03 U \$EC-PB0	MEMORY DATA BUS BIT PB	K3B04 I \$EK-MEMA005	MEMA ADDRESS BIT FROM BSMI
J3B04 I \$EK-MEMA005	MEMA ADDRESS BIT FROM BSMI	J3B07 I \$EK-LFA006	REFRESH ADDRESS BITS 0 TO 6
J3B07 I \$EK-LFA006	REFRESH ADDRESS BITS 0 TO 6	K3B08 I LK100A00	+5 VOLTS
J3B08 I LK100A00	+5 VOLTS	K3B09 I \$EK-REFA004	REFRESH ADDRESS BITS 0 TO 6
J3B09 I \$EK-REFA004	REFRESH ADDRESS BITS 0 TO 6	K3B10 I \$EK-REFA002	REFRESH ADDRESS BITS 0 TO 6
J3B10 I \$EK-REFA002	REFRESH ADDRESS BITS 0 TO 6	K3B12 I \$EK-REFA000	REFRESH ADDRESS BITS 0 TO 6
J3B12 I \$EK-REFA000	REFRESH ADDRESS BITS 0 TO 6	K3D02 I \$EK-MEMA003	MEMA ADDRESS BIT FROM BSMI
J3D02 I \$EK-MEMA003	MEMA ADDRESS BIT FROM BSMI	K3D03 V LK100A00	+5 VOLTS
J3D03 V LK100A00	+5 VOLTS	K3D04 I \$FA-D00	+DOG MEMORY
J3D04 I \$FA-D00	+DOG MEMORY	K3D06 I \$EK-MEMH001	MEMA ADDRESS BIT FROM BSMI
J3D06 I \$EK-MEMH001	MEMA ADDRESS BIT FROM BSMI	K3D07 O \$FA-MEMD108	MEMORY CARD
J3D07 O \$FA-MEMD108	MEMORY CARD	K3D09 I \$EK-SCTL004	SCTL ADDRESS BIT FROM BSMI
J3D09 I \$EK-SCTL004	SCTL ADDRESS BIT FROM BSMI	K3D11 I \$FA-REF0	REFRESH TO MEMORY CARD
J3D11 I \$FA-REF0	REFRESH TO MEMORY CARD	K3D12 I \$EK-MEMH007	MEMA ADDRESS BIT FROM BSMI
J3D12 I \$EK-MEMH007	MEMA ADDRESS BIT FROM BSMI	K4B02 I \$EK-REFH003	REFRESH ADDRESS BITS 0 TO 6
J4B02 I \$EK-REFH003	REFRESH ADDRESS BITS 0 TO 6	K4B03 I \$EK-MEMH006	MEMA ADDRESS BIT FROM BSMI
J4B03 I \$EK-MEMH006	MEMA ADDRESS BIT FROM BSMI	K4B04 I \$EK-LFA004	MEMA ADDRESS BIT FROM BSMI
J4B04 I \$EK-LFA004	MEMA ADDRESS BIT FROM BSMI	K4B05 I \$EK-REFH005	REFRESH ADDRESS BITS 0 TO 6
J4B05 I \$EK-REFH005	REFRESH ADDRESS BITS 0 TO 6	K4B07 I \$LJ-GND0	GROUND LJ
J4B07 I \$LJ-GND0	GROUND LJ	K4B10 I \$LJ-GND0	GROUND LJ
J4B10 I \$LJ-GND0	GROUND LJ	K4B13 I \$FA-W0	HEAD - WHITE TO MEMORY CARD
J4B13 I \$FA-W0	HEAD - WHITE TO MEMORY CARD	K4D02 I \$EK-REFH001	REFRESH ADDRESS BITS 0 TO 6
J4D02 I \$EK-REFH001	REFRESH ADDRESS BITS 0 TO 6	K4D04 I \$EK-MEMH002	MEMA ADDRESS BIT FROM BSMI
J4D04 I \$EK-MEMH002	MEMA ADDRESS BIT FROM BSMI	K4D05 I \$EK-MEMA000	MEMA ADDRESS BIT FROM BSMI
J4D05 I \$EK-MEMA000	MEMA ADDRESS BIT FROM BSMI	K4D07 I \$LJ-GND0	GROUND LJ
J4D07 I \$LJ-GND0	GROUND LJ	K4D08 V \$LJ-GND0	GROUND LJ
J4D08 V \$LJ-GND0	GROUND LJ	K4D09 I \$LJ-GND0	GROUND LJ
J4D09 I \$LJ-GND0	GROUND LJ	K4D12 I \$FA-SELO 08	MEMORY CARDS CNTRL STORE SEL
J4D12 I \$FA-SELO 08	MEMORY CARDS CNTRL STORE SEL	K5B02 O \$EK-BYT10 P	MEMORY DATA BUS BYTE 1
J5B02 O \$EK-BYT10 P	MEMORY DATA BUS BYTE 1	K5B03 O \$EK-BYT100J	MEMORY DATA BUS BYTE 1
J5B03 O \$EK-BYT100J	MEMORY DATA BUS BYTE 1	K5B04 O \$EK-BYT1003	MEMORY DATA BUS BYTE 1
J5B04 O \$EK-BYT1003	MEMORY DATA BUS BYTE 1	K5B05 O \$EK-BYT1001	MEMORY DATA BUS BYTE 1
J5B05 O \$EK-BYT1001	MEMORY DATA BUS BYTE 1	K5B07 O \$EK-BYT00 P	MEMORY DATA BUS BYTE 0
J5B07 O \$EK-BYT00 P	MEMORY DATA BUS BYTE 0	K5J08 U \$EK-BYT10006	MEMORY DATA BUS BYTE 0
J5J08 U \$EK-BYT10006	MEMORY DATA BUS BYTE 0	K5B09 O \$EK-BYT0004	MEMORY DATA BUS BYTE 0
J5B09 O \$EK-BYT0004	MEMORY DATA BUS BYTE 0	K5B10 U \$EK-BYT0001	MEMORY DATA BUS BYTE 0
J5B10 U \$EK-BYT0001	MEMORY DATA BUS BYTE 0	K5B12 O \$EK-BYT0002	MEMORY DATA BUS BYTE 0
J5B12 O \$EK-BYT0002	MEMORY DATA BUS BYTE 0	K5B13 O \$EC-PD0	MEMORY DATA BUS BIT PD
J5B13 O \$EC-PD0	MEMORY DATA BUS BIT PD	K5D02 O \$EK-BYT1007	MEMORY DATA BUS BYTE 1
J5D02 O \$EK-BYT1007	MEMORY DATA BUS BYTE 1	K5D04 O \$EK-BYT1006	MEMORY DATA BUS BYTE 1
J5D04 O \$EK-BYT1006	MEMORY DATA BUS BYTE 1	K5D05 U \$EK-BYT1004	MEMORY DATA BUS BYTE 1
J5D05 U \$EK-BYT1004	MEMORY DATA BUS BYTE 1	K5D06 O \$EK-BYT1002	MEMORY DATA BUS BYTE 1
J5D06 O \$EK-BYT1002	MEMORY DATA BUS BYTE 1	K5D07 O \$EK-BYT1000	MEMORY DATA BUS BYTE 1
J5D07 O \$EK-BYT1000	MEMORY DATA BUS BYTE 1	K5D09 O \$EK-BYT0007	MEMORY DATA BUS BYTE 0
J5D09 O \$EK-BYT0007	MEMORY DATA BUS BYTE 0	K5D10 O \$EK-BYT0005	MEMORY DATA BUS BYTE 0
J5D10 O \$EK-BYT0005	MEMORY DATA BUS BYTE 0	K5D11 O \$EK-BYT0003	MEMORY DATA BUS BYTE 0
J5D11 O \$EK-BYT0003	MEMORY DATA BUS BYTE 0	K5D12 O \$EK-BYT0000	MEMORY DATA BUS BYTE 0
J5D12 O \$EK-BYT0000	MEMORY DATA BUS BYTE 0	K5D13 U \$EC-PC0	MEMORY DATA BUS BIT PC
J5D13 U \$EC-PC0	MEMORY DATA BUS BIT PC	J6C02 # \$ED-CAF05	M5
J6C02 # \$ED-CAF05	M5	J6C04 # \$ED-CAF06	M6
J6C04 # \$ED-CAF06	M6	J6D02 # \$ED-CAF04	M4
J6D02 # \$ED-CAF04	M4	K6H02 # \$ED-CAF02	M2
K6H02 # \$ED-CAF02	M2	K6H04 # \$ED-CAF01	M1
K6H04 # \$ED-CAF01	M1	K6B02 # \$EK+SPW0	+RD+HRT
K6B02 # \$EK+SPW0	+RD+HRT	K6B04 # \$EK+STG00	+STG GO
K6B04 # \$EK+STG00	+STG GO		

COMMENTS:

LEGEND : # BOARD CONNECTOR PIN
I CARD INPUT SIGNAL PIN
O CARD OUTPUT SIGNAL PIN
V VOLTAGE PIN

Signal Routing Documentation (Part 2 of 2)

NET LIST (EXAMPLE)

SIGNAL NAME	NET NAME	A	B	C	D	E	F	G	H	J	K	L	M	N	P	Q	R	S	T	U	V	W	X	Y	Z
*9MHZ OUTPUT	IC020A84																								
+A	EC016ABn5														0_2202										
-1 CLOCK CHECK	AF-CCHK																				1_3D04				
ACCESS 0	SF-AC0																								
ACCESS 1	SF-AC1																								
+AD CLOCK CAP'D CHECK	LV110AA16																								
-AD CLOCK CAP'D CHECK	LV110AA15																								
+ADAPTER CHECK	LV110AA10																								
-ADAPTER CHECK	LV110AA09																								
ADDRESS MATCH	SEG-ADMA1																								
-ADDRESS 0	SU-SAP0																								
-ADDRESS 1	SU-SAP1																								
-ADDRESS 10	SU-SAP10																								
-ADDRESS 11	SU-SAP11																								
-ADDRESS 12	SU-SAP12																								
-ADDRESS 13	SU-SAP13																								
-ADDRESS 14	SU-SAP14																								
-ADDRESS 15	SU-SAP15																								
-ADDRESS 2	SU-SAR2																								
-ADDRESS 3	SU-SAR3																								
-ADDRESS 4	SU-SAR4																								
-ADDRESS 5	SU-SAR5																								
-ADDRESS 6	SU-SAR6																								
-ADDRESS 7	SU-SAR7																								
-ADDRESS 8	SU-SAR8																								
-ADDRESS 9	SU-SAR9																								
HDR 4	SU-AUR4																								
-AIO/HOLD TO PERFORM	SEE-AIDP0																								
-ANY INSTRUCTION	SEG-ANYI0																								
+B	EC016ABA6														0_2203										
B CLOCK	SU-BLCK																								
BIT P1 (FROM ECC CARD)	SEC-BITP1																								
-BUS IN GOOD PTY	LV110AA19																								
-BUS OUT P RDV	LV110AA56																								
BYTE SELECT FROM BSMI	SEK+SBS0 X																								
	SEK+SBS0 Y																								
	SEK+SBS0 00																								
	SEK+SBS0 01																								

PIN ADDRESSING

On the drawing of the board, the pin addressing has the following format:
x-yztt

- x = # indicates a board connector pin.
- x = I indicates that the signal is entering the pin.
- x = O indicates that the signal is leaving the pin.
- x = V indicates a voltage pin.
- y varies from 1 to 6 and indicates the board horizontal row.
- z indicates the column address of the pin.

The pin can be a board pin (A, B, C, D, E, G, J, M, P, S, or U) or a card top connector pin (W, X, Y, or Z).

tt indicates the pin number in the z column address.

DRAWING INTERPRETATION

- Several "Os" (outputs) and "Is" (inputs) may appear on the same horizontal line. This indicates that different adapter cards are connected to the same net line.
- Several horizontal lines may belong to one signal name and one net name. This indicates connections between pins of the same card.
- Several horizontal lines may belong to one signal name, with different net names. This indicates connection to a bus. The net name shows the bit number on the bus.
- "O" alone on a net shows that the pin is not used, or is a card test point.

COMMENTS:
LEGEND :# BOARD CONNECTOR PIN
I CARD INPUT SIGNAL PIN
O CARD OUTPUT SIGNAL PIN
V VOLTAGE PIN

BOARD P/N : 8275736
BOARD LEVEL : REA 63-04594
OR EC 873521

Board Voltage Plan (Part 1 of 4)

The following tables indicate the voltage assigned to each pin of the board.

For the CCU board voltage plan, see page 4-022. For card locations, see page 4-060 onward.

		B Pins											
Board	Card	02	03	04	05	06	07	08	09	10	11	12	13
MMB	MEM	-5	+12	.	.
	ECC	-5
	SCTL	-5
	MMC	-5	+8.5	.	.
	MPC	-5	+8.5	.	.
	DAC	-5	+8.5	.	.
	CPA	-5
	MCC	-5
	CCA	-5	+8.5	.	.
EIA	-5	+8.5	.	.	
C2LB CLAB1 C2LB2 CLAB2 LABs	CSM	-5	+12	.	.
	CSM	-5	+12	.	.
	CSP1	-5
	CSP1	-5
	CSP2	-5
	FES	-5
	LIC	-5
	ICC	-5
	RDV	-5
	TIC	-5
	TRM	-5
			-5
C2LB CLAB1 C2LB2 CLAB2 CAB	CADR	-5
	CADR	-5
	CADRUK	-5
	CADRUK	-5
	CCIN	-5
	CHIN	-5
RDV	-5	
CVTL	
PWB1	PWCA1
	PWCL1
	PH1
	ARC1	12ac	12ac	.	.	+24	.
	PWRC
PWB2	PWCA2
	PWCL2
	PH2
	PH4
	PWRC

* PWRC: + 24V on pins A1 B11 and A1 D11.
Ground on pin B1 C11.

		D Pins											
Board	Card	02	03	04	05	06	07	08	09	10	11	12	13
MMB	MEM	.	+5	Gnd
	ECC	.	+5	Gnd
	SCTL	.	+5	Gnd
	MMC	.	+5	Gnd
	MPC	.	+5	Gnd
	DAC	.	+5	Gnd
	CPA	.	+5	Gnd
	MCC	.	+5	Gnd
	CCA	.	+5	Gnd
EIA	.	+5	Gnd	
C2LB CLAB1 C2LB2 CLAB2 LABs	CSM	.	+5	Gnd
	CSM	.	+5	Gnd
	CSP1	.	+5	Gnd
	CSP1	.	+5	Gnd
	CSP2	Gnd	+5	Gnd	.	.	+5	.	.
	FES	Gnd	+5	Gnd	.	.	+5	.	.
	LIC	Gnd	+5	Gnd	.	.	+5	.	.
	ICC	Gnd	+5	Gnd	.	.	+5	.	.
	RDV	.	+5	Gnd
	TIC	.	+5	Gnd
	TRM	.	+5	Gnd
			.	+5	Gnd
C2LB CLAB1 C2LB2 CLAB2 CAB	CADR	.	+5	Gnd
	CADR	.	+5	Gnd
	CADRUK	.	+5	Gnd
	CADRUK	.	+5	Gnd
	CCIN	.	+5	Gnd
	CHIN	.	+5	Gnd
RDV	.	+5	Gnd	
CVTL	.	+5	Gnd	
PWB1	PWCA1	.	+5	.	.	.	-12	Gnd	.	.	+12	.	.
	PWCL1	.	+5	.	.	.	-12	Gnd	.	.	+12	.	.
	PH1	.	+5	Gnd
	ARC1
	PWRC
PWB2	PWCA2	.	+5	.	.	.	-12	Gnd	Gnd	.	+12	.	.
	PWCL2	.	+5	.	.	.	-12	Gnd	.	.	+12	.	.
	PH2	-12	Gnd	.	.	+12	.	.
	PH4	-12	Gnd	.	.	+12	.	.
	PWRC	+24	.	+24	.	.	.	Gnd

Board Voltage Plan (Part 2 of 4)

The following tables indicate the voltage assigned to each pin of the board.

For the CCU board voltage plan, see page 4-022. For card locations, see page 4-060 onward.

		G Pins											
Board	Card	02	03	04	05	06	07	08	09	10	11	12	13
MMB	MEM	-5	+12	.	.
	ECC	-5
	SCTL	-5
	MMC	-5	+8.5	.	.
	MPC	-5	+8.5	.	.
	DAC	-5	+8.5	.	.
	CPA	-5
	MCC	-5
	CCA	-5	+8.5	.	.
	EIA	.	.	+12	.	-5	+8.5	.	.
C2LB CLAB1 C2LB2 CLAB2 LABs	CSM	+12	.	.
	CSM	+12	.	.
	CSP1
	CSP1
	CSP2
	FES
	LIC	-8.5
	ICC
	RDV
	TIC
TRM	
C2LB CLAB1 C2LB2 CLAB2 CAB	CADR
	CADR
	CADRUk
	CADRUk
	CCIN
	CHIN
	RDV
	CVTL
PWB1	PWCA1
	PWCL1
	PH1
PWB2	PWCA2
	PWCL2
	PH2
	PH4
	ARC2
								12ac	12ac				

		J Pins											
Board	Card	02	03	04	05	06	07	08	09	10	11	12	13
MMB	MEM	.	+5	Gnd
	ECC	.	+5	Gnd
	SCTL	.	+5	Gnd
	MMC	.	+5	Gnd
	MPC	.	+5	Gnd
	DAC	.	+5	Gnd
	CPA	.	+5	Gnd
	MCC	.	+5	Gnd
	CCA	.	+5	Gnd
	EIA	.	+5	Gnd	.	.	.	-12	.
C2LB CLAB1 C2LB2 CLAB2 LABs	CSM	.	+5	Gnd
	CSM	.	+5	Gnd
	CSP1	Gnd	+5	Gnd	.	.	+5	.	.
	CSP1	Gnd	+5	Gnd	.	.	+5	.	.
	CSP2	Gnd	+5	Gnd	.	.	+5	.	.
	FES	Gnd	+5	Gnd	.	.	+5	.	.
	LIC	Gnd	+5	Gnd	.	.	+5	.	.
	ICC	Gnd	+5	Gnd	.	.	+5	.	.
	RDV	.	+5	Gnd
	TIC	.	+5	Gnd
TRM	.	+5	Gnd	
C2LB CLAB1 C2LB2 CLAB2 CAB	CADR	.	+5	Gnd
	CADR	.	+5	Gnd
	CADRUk	.	+5	Gnd
	CADRUk	.	+5	Gnd
	CCIN	.	+5	Gnd
	CHIN	.	+5	Gnd
	CVTL	.	+5	Gnd
PWB1	PWCA1	.	+5	.	.	.	-12	Gnd	.	.	+12	.	.
	PWCL1	.	+5	.	.	.	Gnd	Gnd	.	Gnd	.	Gnd	.
	PH1	.	.	Gnd	.	Gnd	.	Gnd
PWB2	PWCA2	.	+5	.	.	.	-12	Gnd	.	.	+12	.	.
	PWCL2	.	+5	.	.	.	Gnd	Gnd	.	Gnd	.	Gnd	.
	PH2	.	.	Gnd	.	Gnd	.	Gnd	.	Gnd	.	Gnd	.
	PH4	.	.	Gnd	.	Gnd	.	Gnd	.	Gnd	.	Gnd	.
	ARC2	.	+5	Gnd

Board Voltage Plan (Part 3 of 4)

The following tables indicate the voltage assigned to each pin of the board.

For the CCU board voltage plan, see page 4-022. For card locations, see page 4-060 onward.

		M Pins											
Board	Card	02	03	04	05	06	07	08	09	10	11	12	13
MMB	MEM	-5	+12	.	.
	ECC	-5
	SCTL	-5
	MMC	-5	+8.5	.	.
	MPC	-5	+8.5	.	.
	DAC	-5	+8.5	.	.
	MCC CCA	-5	+8.5	.	.
C2LB CLAB1 C2LB2 CLAB2 LABs	CSM	-5	+12	.	.
	CSM	-5	+12	.	.
	CSP1	-5
	CSP1	-5
	CSP2	-5
	FES	-5
	LIC	-5
	ICC	-5
	RDV	-5
	TIC TRM
C2LB CLAB1 C2LB2 CLAB2 CAB	CADR
	CADR
	CADRUk
	CADRUk
	CCIN
	CHIN RDV CVTL
PWB1	PWCA1
	PWCL1
	PH1
PWB2	PWCA2
	PWCL2
	PH2
	PH4
	ARC2

		P Pins											
Board	Card	02	03	04	05	06	07	08	09	10	11	12	13
MMB	MEM	.	+5	Gnd
	ECC	.	+5	Gnd
	SCTL	.	+5	Gnd
	MMC	.	+5	Gnd
	MPC	.	+5	Gnd
	DAC	.	+5	Gnd
	MCC CCA	.	+5	Gnd
C2LB CLAB1 C2LB2 CLAB2 LABs	CSM	.	+5	Gnd
	CSM	.	+5	Gnd
	CSP1	Gnd	+5	Gnd	.	.	+5	.	.
	CSP1	Gnd	+5	Gnd	.	.	+5	.	.
	CSP2	Gnd	+5	Gnd	.	.	+5	.	.
	FES	Gnd	+5	Gnd	.	.	+5	.	.
	LIC	Gnd	+5	Gnd	.	.	+5	.	.
	ICC	Gnd	+5	Gnd	.	.	+5	.	.
	RDV	.	+5	Gnd
	TIC	.	+5	Gnd
	TRM	.	+5	Gnd
	C2LB CLAB1 C2LB2 CLAB2 CAB	CADR	.	+5	Gnd
CADR		.	+5	Gnd
CADRUk		.	+5	Gnd
CADRUk		.	+5	Gnd
CCIN		.	+5	Gnd
CHIN RDV CVTL		.	+5	Gnd
PWB1	PWCA1	.	+5	.	.	.	-12	Gnd	.	.	+12	.	.
	PWCL1	.	+5	Gnd	+24
	PH1	.	.	Gnd	.	Gnd	.	Gnd	.	Gnd	.	Gnd	.
PWB2	PWCA2	.	+5	.	.	.	-12	Gnd	.	.	+12	.	.
	PWCL2	.	+5	Gnd
	PH2	.	.	Gnd	.	Gnd	.	Gnd	.	Gnd	.	Gnd	.
	PH4	.	.	Gnd	.	Gnd	.	Gnd	.	Gnd	.	Gnd	.
	ARC2	12ac	12ac

Board Voltage Plan (Part 4 of 4)

The following tables indicate the voltage assigned to each pin of the board.


For the CCU board voltage plan, see page 4-022. For card locations, see page 4-060 onward.

		S Pins												
Board	Card	02	03	04	05	06	07	08	09	10	11	12	13	
MMB	MEM	-5	+12	.	.	
	ECC	-5	
	SCTL	-5	
	MMC	-5	
	MPC	-5	
	DAC	-5	
	MCC	-5	
CCA	-5		
C2LB	CLAB1	+12	.	.	
	CLAB2	+12	.	.	
	CSP1	+8.5	
	CSP2	+8.5	
	FES	
	LIC	+8.5	
	ICC	
RDV		
TIC	+8.5		
TRM	+8.5		
C2LB	CADR	+8.5	
	CLAB1	+8.5	
	C2LB2	+8.5	
	CLAB2	+8.5	
	CAB	+8.5	
	CVTL	
PWB1	PWCA1	Gnd	
	PWCL1	
	PH1	
	PWCA2	
	PWCL2	
	PH2	
PWB2	PH4	
	PH1	
	PH2	
	PH4	

CONTROL PANEL CARD (01L) VOLTAGE PINS


Voltage	Pin
+ 5V CNTL	P4 B10
+ 5V	P5 B04
+ 5V	P5 B17

For more information on control panel connector pins, see page YZ136. See also "Control Panel Connections" on page 6-020.




		U Pins												
Board	Card	02	03	04	05	06	07	08	09	10	11	12	13	
MMB	MEM	.	+5	Gnd	
	ECC	.	+5	Gnd	
	SCTL	.	+5	Gnd	
	ACLK	.	+5	Gnd	
	MMC	.	+5	Gnd	
	MPC	.	+5	Gnd	
	DAC	.	+5	+5*	.	.	.	Gnd	
MCC	.	+5	Gnd		
CCA	.	+5	Gnd		
C2LB	CSM	.	+5	Gnd	
	CLAB1	.	+5	Gnd	
	C2LB2	Gnd	+5	Gnd	.	.	+5	.	.	
	CLAB2	Gnd	+5	Gnd	.	.	+5	.	.	
	LABs	Gnd	+5	Gnd	.	.	+5	.	.	
	CSP1	Gnd	+5	Gnd	.	.	+5	.	.	
	CSP2	Gnd	+5	Gnd	.	.	+5	.	.	
	FES	Gnd	+5	Gnd	.	.	+5	.	.	
	LIC	Gnd	+5	Gnd	.	.	+5	.	.	
	ICC	Gnd	+5	Gnd	.	.	+5	.	.	
RDV	Gnd	+5	Gnd	.	.	+5	.	.		
TIC	.	+5	Gnd		
TRM	.	+5	Gnd		
C2LB	CADR	.	+5	Gnd	
	CLAB1	.	+5	Gnd	
	C2LB2	.	+5	Gnd	
	CLAB2	.	+5	Gnd	
	CAB	.	+5	Gnd	
	CVTL	Gnd	+5	Gnd	.	.	+5	.	.	
PWB1	PWCA1	.	+5	.	.	.	-12	Gnd	.	.	+12	.	.	
	PWCL1	.	+5	Gnd	.	.	.	Gnd	.	
	PH1	.	.	Gnd	.	Gnd	.	Gnd	.	Gnd	.	Gnd	.	
PWB2	PWCA2	.	+5	.	.	.	-12	Gnd	.	.	+12	.	.	
	PWCL2	.	+5	Gnd	.	.	.	Gnd	.	
	PH2	.	.	Gnd	.	Gnd	.	Gnd	.	Gnd	.	Gnd	.	
	PH4	.	.	Gnd	.	Gnd	.	Gnd	.	Gnd	.	Gnd	.	

* This special 5 volts (+5 sp) is generated on the control panel card as shown in the following figure:



Card and Board Organization



Card Location (Part 1 of 5)

This page shows the card locations on the different types of board in the communication controller and its expansion. The same information for the power boards is in Volume A02.

When present on a board, cards are identified by a group of alphameric characters that indicate the name of the card. A card name may be followed by a hyphen (-) and a digit. The digit shows the sequence of implementation of:

- Cards on this board (MEM- cards or LICx- cards)
- Groups of cards (for example, the cards that make up a channel adapter, such as CCIN-6, CHIN-6, and CADR-6A)

Notes:


1. On a LAB type B, FES-1 controls LIC positions 1 through 4, and FES-2 controls LIC positions 5 through 8.
2. This card contains pluggable modules and/or jumpers. See Chapter 5 for module and jumper identification and for the plugging procedure. See the YZ pages for up-to-date jumper positions.
3. In the United Kingdom, card CADRUK replaces card CADR.
4. ICC-1 distributes its clock signals to LIC positions 1 through 4; ICC-2 distributes its clock signals to LIC positions 5 through 8.
5. PROM is used to patch the ROS on the CSP1 card. It is received when needed to make a temporary fix.
6. The figure on the crossover indicates its part number. There is no relationship of figures between boards. To identify crossover part numbers, see YZ pages and the 3725/3726 Parts Catalog.
7. MROS is used to patch the ROS on the MPC card of the MMB board. It is received when needed to make a temporary fix.
8. The MEM cards (up to 12) can be of different types depending on the EC level of the machine. (See page 10-050 for details.)

BOARD: MMB

Board Location: 01A-A1


Card Part Numbers: See the ZZ pages

Card Locations



Crossover Part Numbers: See Note 6

Crossover Locations



* Crossover 3 can be of a different type (Q3 only) depending on the EC level of the machine.

Install the crossovers with the corner identification as shown in the figure above.


Warning: Check that the crossovers are properly seated after a card is replaced. Check also the crossovers adjacent to the card.

BOARD: CCUB

Board Location: 01A-A2


Card Part Numbers: See the ZZ pages

Card Locations



Crossover Part Numbers: See Note 6

Crossover Locations



Install the crossovers with corner identification as shown in the figure above.


Card Location (Part 2 of 5)

BOARD CLAB1

Board Location: 01A-A3


Card Part Numbers: See the ZZ pages

Card Location



Crossover Part Numbers: See Note 6, page 4-060

Crossover Location




Install crossovers with corner identification on crossovers as shown. If the crossovers are polarized, see page YZ-026.

BOARD CLAB2

Board Location: 01B-A2


Card Part Numbers: See the ZZ pages

Card Location



Crossover Part Numbers: See Note 6, page 4-060

Crossover Location



Install crossovers with corner identification on crossovers as shown. If the crossovers are polarized, see page YZ-031.


Card Location (Part 3 of 5)

BOARD LABA

Board Location: See table on this page


Card Part Numbers: See the ZZ pages

Card Location



Crossover Part Numbers: See Note 6, page 4-060

Crossover Location




Install crossovers with corner identification on crossovers as shown.

BOARD LABB

Board Location: See table on this page


Card Part Numbers: See the ZZ pages

Card Location



Crossover Part Numbers: See Note 6, page 4-060

Crossover Location




Install crossovers with corner identification on crossovers as shown.

Card Location (Part 4 of 5)

LAB C BOARD


Board Location: Any Lab Pos 3 to 8.
Card Part Numbers: See the ZZ pages

Card Location



Crossover Part Numbers: See Note 6, page 4-060


Crossover Location



Note: TRM patch card may be present, and Cross overs will also be present.


BOARD CAB

Board Location: 02C-A1
Card Part Numbers: See the ZZ pages
Card Location



Crossover Part Numbers: See note 6, page 4-060

Crossover Location




CA Connectors:

- From/To 02Q-A (CA Pos 6)
- From/To 02Q-B (CA Pos 5)
- From/To 02Q-B (if TPS Pos 4)
- From/To 02Q-C (CA Pos 4)
- From/To 02Q-A (if TPS Pos 3)
- From/To 02Q-D (CA Pos 3)

Install crossovers with corner identification on crossovers as shown. If polarized crossovers, see page YZ-316.

BOARD PWB1

Board Location: 01R-A1
(Refer to page YZ156 for part numbers)
PWB1 is shown in the open position.




* For the 3725 Model 2, the sense cable is replaced by a terminator card.

Note: "X0" in the card name can be 50 or 60 Hz according to the ac input power frequency.

Card Location (Part 5 of 5)


BOARD PWB2

Board Location: 02J-A1
(Refer to page YZ411 for part numbers)




BOARD C2LB

Board Location: 01A-A3
Card Part Numbers: See the ZZ pages
Card Location



Crossover Part Numbers: See Note 6, page 4-060


Crossover Location



Install crossovers with corner identification on crossovers as shown. If the crossovers are polarized, see page YZ-026.


BOARD C2LB2

Board Location: 01B-A2
Card Part Numbers: See the ZZ pages
Card Location




Crossover Part Numbers: See Note 6, page 4-060

Crossover Location



Install crossovers with corner identification on crossovers as shown. If the crossovers are polarized, see page YZ-026.



Cabling Between Boards

GENERAL VIEW

This figure shows the cabling between the boards within the 3725 Model 1, the 3725 Model 2, and the 3726 expansion.

Power board cables are not represented; for details of these cables, see Volume A02.

The numbers in circles relate to the signal tables that list the signal names and signal voltages of all the leads in the cables.

The signal tables follow in this chapter starting at page 4-080.

Notes:

1. Bold lines represent the IOC bus cables that route signals from the CCU board (positions A3A, B, and C) to the different channel adapters and scanners. The maximum machine configuration is shown.

From the CLAB, or the C2LB, the routing is via the card top connectors (TC) and the gate connectors (J1 sockets on a gate side). A gate connector may be plugged with:


- a. IOC bus cables routing signals to the other gates
- b. A terminator card (BUSTERM) containing mainly resistors to load the lines

The gate to which a connector is plugged depends on the machine configuration.

When plugged, the terminator card receives power from the nearest board. The power cable is plugged in position J1A2 on the gate connector, and on pins B2-E14 and B3-E01 on the board pin side.

To check wire continuity between the top connector pins, see page 4-090.

2. For the connections from the LIC top card connectors to the line sockets on the tailgates, see page 4-120.
3. For the connections from the channel adapter cards on the boards to the host channel sockets on the tailgates, see page 4-110.
4. For the adapter clock distribution from the ACLK card to the various board RDVs, see page 4-100.



5. This Cable is in two parts, each part having its own part number. The connection between them is done through 01B-J1. The continuity between YK and YL is assured by a jumper cable (part 4712959).

When Frame 02 is not installed, the part of the cable pertaining to the board 01B-A2 is provided but not connected, and the jumper cable between YK and YL is not installed.

Primary IOC BUS : Signal Tables

For IOC wire distribution up to the CAB board, see page 4-090.

Cable 1

Cable 2

Cable 3

CCU		Cable A (IOC Bus)	RDV on CLAB1	
01A-A2A3A Pin Ref on Board Cable		Signal Names with Polarities	01A-A3A3 Pin Ref on Cable TC(1)	
02	B1	-Data Bus 1.7	D13	X13
03	B2	-CS Req High RDV to CCU	B13	X33
04	B3	-Data Bus 1.6	D12	X12
06	B4	-CS Req Low RDV to CCU	B12	X32
07	B5	-CS Req Prty Line	B11	X31
08	B6	-Data Bus 1.5	D10	X10
10	B7	-L2 Priority Line	B10	X30
11	B8	-Data Bus 1.4	D09	X09
12	B9	-Data Bus 1.3	D08	X08
14	C1	-L2 Request to RDV	B08	X28
15	C2		B07	X27
16	C3	-Data Bus 1.2	D07	X07
18	C4		B06	X26
19	C5	-Data Bus 1.P	B05	X25
20	C6	-Data Bus 1.1	D05	X05
22	C7	-Data Bus 1.0	D04	X04
23	C8		D03	X03
24	C9		D02	X02
01	A1	-----+--- Signal Ground ----+---	B04	X24
05	A2	----- -----	B09	X29
09	A3	----- -----	D06	X06
13	A4	----- -----	D11	X11
17	A5	----- -----		
21	A6	----- -----		
25	A7	----- -----		

CCU		Cable B (IOC Bus)	RDV on CLAB1	
01A-A2A3B Pin Ref on Board Cable		Signal Names with Polarities	01A-A3A4 Pin Ref on Cable TC(1)	
02	B1	-Data Bus 0.7	D13	Y13
03	B2	-Valid Halfword from Adapter	B13	Y33
04	B3	-Data Bus 0.6	D12	Y12
06	B4	-Parity Valid from Adapter	B12	Y32
07	B5	-Modifier from RDV	B11	Y31
08	B6	-Data Bus 0.5	D10	Y10
10	B7	-Scanner Interrupt to MOSS	B10	Y30
11	B8	-Data Bus 0.4	D09	Y09
12	B9	-Data Bus 0.3	D08	Y08
14	C1	-CA Req IPL Detect	B08	Y28
15	C2	-RDV Error Reg Out	B07	Y27
16	C3	-Data Bus 0.2	D07	Y07
18	C4	-RDV L1 Pending Out	B06	Y26
19	C5	-Data Bus 0.P	B05	Y25
20	C6	-Data Bus 0.1	D05	Y05
22	C7	-Data Bus 0.0	D04	Y04
		-CS Grant Low Out RDV to RDV	B03	Y23
23	C8	-CS Grant Low Out CCU to RDV	D03	Y03
		-CS Grant High Out RDV to RDV	B02	Y22
24	C9	-CS Grant High Out CCU to RDV	D02	Y02
01	A1	-----+--- Signal Ground ----+---	B04	Y24
05	A2	----- -----	B09	Y29
09	A3	----- -----	D06	Y06
13	A4	----- -----	D11	Y11
17	A5	----- -----		
21	A6	----- -----		
25	A7	----- -----		

CCU		Cable C (IOC Bus)	RDV on CLAB1	
01A-A2A3C Pin Ref on Board Cable		Signal Names with Polarities	01A-A3A5 Pin Ref on Cable TC(1)	
02	B1	-15.258 us Pulse	D13	Z13
03	B2		B13	Z33
04	B3	-4.9152 MHz Clock	D12	Z12
06	B4	-Power On Reset to Adapter	B12	Z32
07	B5	-Reset Tag CCU to Adapter	B11	Z31
08	B6	-100 ms Pulse	D10	Z10
10	B7	+Read, -Write Tag CCU to Adapter	B10	Z30
11	B8	-End of Chain from Adapter	D09	Z09
12	B9	-Valid Byte from Adapter	D08	Z08
14	C1	-Halt Tag CCU to Adapter	B08	Z28
15	C2	-TD Tag CCU to Adapter	B07	Z27
16	C3	-Inter Req Removed from Adapter	D07	Z07
18	C4	-TA Tag CCU to Adapter	B06	Z26
19	C5	-I/O Tag CCU to Adapter	B05	Z25
20	C6	-Exception from Adapter	D05	Z05
22	C7	-480 Hz Clock	D04	Z04
		-Select Out RDV to RDV	B03	Z23
23	C8	-Select In	D03	Z03
		-Allow Poll Response Out	B02	Z22
24	C9	-Allow Poll Response In	D02	Z02
01	A1	-----+--- Signal Ground ----+---	B04	Z24
05	A2	----- -----	B09	Z29
09	A3	----- -----	D06	Z06
13	A4	----- -----	D11	Z11
17	A5	----- -----		
21	A6	----- -----		
25	A7	----- -----		

(1) TC: Pin on card top connector.

(1) TC: Pin on card top connector.

(1) TC: Pin on card top connector.

CCU-to-Storage BUS: Signal Tables

Cable 7

CCU *		Storage cable A (Data bus bytes X, Y)	MMB	
01A-A2B1A Pin Ref on Board Cable		Signal Names with Polarities	01A-A1A2 Pin Ref on Cable Board	
02	B1	-Memory Data Bus Byte X (0)	D13	A2 D13
03	B2	-Memory Data Bus Byte X (1)	B12	A2 B12
04	B3	-Memory Data Bus Byte X (2)	B13	A2 B13
06	B4	-Memory Data Bus Byte X (3)	D11	A2 D11
07	B5	-Memory Data Bus Byte X (4)	B10	A2 B10
08	B6	-Memory Data Bus Byte X (5)	D10	A2 D10
10	B7	-Memory Data Bus Byte X (6)	B09	A2 B09
11	B8	-Memory Data Bus Byte X (7)	D09	A2 D09
12	B9	-Memory Data Bus Byte X (P)	B08	A2 B08
14	C1	-Memory Data Bus Byte Y (0)	D07	A2 D07
15	C2	-Memory Data Bus Byte Y (1)	B06	A2 B06
16	C3	-Memory Data Bus Byte Y (2)	D06	A2 D06
18	C4	-Memory Data Bus Byte Y (3)	B05	A2 B05
19	C5	-Memory Data Bus Byte Y (4)	D05	A2 D05
20	C6	-Memory Data Bus Byte Y (5)	B04	A2 B04
22	C7	-Memory Data Bus Byte Y (6)	D03	A2 D03
23	C8	-Memory Data Bus Byte Y (7)	D02	A2 D02
24	C9	-Memory Data Bus Byte Y (P)	B02	A2 B02
01	A1	-----+--- Signal Ground ---+-----	D12	A2 D12
05	A2	-----+----- -----	B11	A2 B11
09	A3	-----+----- -----	D08	A2 D08
13	A4	-----+----- -----	B07	A2 B07
17	A5	-----+----- -----	D04	A2 D04
21	A6	-----+----- -----	B03	A2 B03
25	A7	-----+----- -----		

Cable 9

CCU *		Storage cable C (Data bus bytes 0, 1)	MMB	
01A-A2B1C Pin Ref on Board Cable		Signal Names with Polarities	01A-A1A5 Pin Ref on Cable Board	
02	B1	-Memory Data Bus Byte 0-Bit 0	D13	A5 D13
03	B2	-Memory Data Bus Byte 0-Bit 1	B12	A5 B12
04	B3	-Memory Data Bus Byte 0-Bit 2	B13	A5 B13
06	B4	-Memory Data Bus Byte 0-Bit 3	D11	A5 D11
07	B5	-Memory Data Bus Byte 0-Bit 4	B10	A5 B10
08	B6	-Memory Data Bus Byte 0-Bit 5	D10	A5 D10
10	B7	-Memory Data Bus Byte 0-Bit 6	B09	A5 B09
11	B8	-Memory Data Bus Byte 0-Bit 7	D09	A5 D09
12	B9	-Memory Data Bus Byte 0-Bit P	B08	A5 B08
14	C1	-Memory Data Bus Byte 1-Bit 0	D07	A5 D07
15	C2	-Memory Data Bus Byte 1-Bit 1	B06	A5 B06
16	C3	-Memory Data Bus Byte 1-Bit 2	D06	A5 D06
18	C4	-Memory Data Bus Byte 1-Bit 3	B05	A5 B05
19	C5	-Memory Data Bus Byte 1-Bit 4	D05	A5 D05
20	C6	-Memory Data Bus Byte 1-Bit 5	B04	A5 B04
22	C7	-Memory Data Bus Byte 1-Bit 6	D03	A5 D03
23	C8	-Memory Data Bus Byte 1-Bit 7	D02	A5 D02
24	C9	-Memory Data Bus Byte 1-Bit P	B02	A5 B02
01	A1	-----+--- Signal Ground ---+-----	D12	A5 D12
05	A2	-----+----- -----	B11	A5 B11
09	A3	-----+----- -----	D08	A5 D08
13	A4	-----+----- -----	B07	A5 B07
17	A5	-----+----- -----	D04	A5 D04
21	A6	-----+----- -----	B03	A5 B03
25	A7	-----+----- -----		

Cable 11

CCU *		Storage cable E (Controls)	MMB	
01A-A2B1E Pin Ref on Board Cable		Signal Names with Polarities	01A-A1ZE Pin Ref on Cable Board	
02	B1	-4.9152 MHz Clock	D13	P6 C02
03	B2	-4.9152 MHz Clock	B12	P6 B04
04	B3	-Dog Byte 0 BSMI	B13	P6 C04
06	B4	-Dog Byte 1	D11	P6 A02
07	B5	-Dog Byte X	B10	N6 E04
08	B6	-Dog Byte Y	D10	N6 E02
10	B7	-Dog BSMI Parity Bits	B09	N6 D04
11	B8	+STG Cntl Error to CCU	D09	N6 D02
12	B9	+STG Add/Data Pty Error to CCU	B08	N6 C04
14	C1	+SP Write Inhibit from BSMI	D07	N6 B02
15	C2	-Input 70	B06	N6 A04
16	C3	-STG Cntl Out Tag from BSMI	D06	N6 A02
18	C4	-2 Bits STG Error to CCU	B05	M6 E04
19	C5	+STG Byte Select Y	D05	M6 E02
20	C6	+STG Byte Select X	B04	M6 D04
22	C7	+STG Byte Select 0	D03	M6 C02
23	C8	+STG Byte Select 1	D02	M6 B02
24	C9	+Refresh In Progress to BSMI	B02	M6 B04
01	A1	-----+--- Signal Ground ---+-----	D12	P6 B02
05	A2	-----+----- -----	B11	P6 A04
09	A3	-----+----- -----	D08	N6 C02
13	A4	-----+----- -----	B07	N6 B04
17	A5	-----+----- -----	D04	M6 D02
21	A6	-----+----- -----	B03	M6 C04
25	A7	-----+----- -----		

Cable 8

CCU *		Storage cable B (Addressing)	MMB	
01A-A2B1B Pin Ref on Board Cable		Signal Names with Polarities	01A-A1A3 Pin Ref on Cable Board	
02	B1	-Read Mode	D13	A3 D13
03	B2	-SCTL Address Bit 4 from BSMI	B12	A3 B12
04	B3	+Refresh Address Bit 0 from BSMI	B13	A3 B13
06	B4	+Refresh Address Bit 1 from BSMI	D11	A3 D11
07	B5	+Refresh Address Bit 2 from BSMI	B10	A3 B10
08	B6	+Refresh Address Bit 3 from BSMI	D10	A3 D10
10	B7	+Refresh Address Bit 4 from BSMI	B09	A3 B09
11	B8	+Refresh Address Bit 5 from BSMI	D09	A3 D09
12	B9	+Refresh Address Bit 6 from BSMI	B08	A3 B08
14	C1	-Memory Address Bit 0 from BSMI	D07	A3 D07
15	C2	+Memory Address Bit 1 from BSMI	B06	A3 B06
16	C3	-Memory Address Bit 2 from BSMI	D06	A3 D06
18	C4	-Memory Address Bit 3 from BSMI	B05	A3 B05
19	C5	-Memory Address Bit 4 from BSMI	D05	A3 D05
20	C6	-Memory Address Bit 5 from BSMI	B04	A3 B04
22	C7	-Memory Address Bit 6 from BSMI	D03	A3 D03
23	C8	-Memory Address Bit 7 from BSMI	D02	A3 D02
24	C9	+CCU STG Grant	B02	A3 B02
01	A1	-----+--- Signal Ground ---+-----	D12	A3 D12
05	A2	-----+----- -----	B11	A3 B11
09	A3	-----+----- -----	D08	A3 D08
13	A4	-----+----- -----	B07	A3 B07
17	A5	-----+----- -----	D04	A3 D04
21	A6	-----+----- -----	B03	A3 B03
25	A7	-----+----- -----		

Cable 10

CCU *		Storage cable D (Clocks and controls)	MMB	
01A-A2B1D Pin Ref on Board Cable		Signal Names with Polarities	01A-A1ZD Pin Ref on Cable Board	
02	B1	-SCTL Address Bit 0 from BSMI	D13	L6 D02
03	B2	-SCTL Address Bit 1 from BSMI	B12	L6 C04
04	B3	-SCTL Address Bit 2 from BSMI	B13	L6 D04
06	B4	-SCTL Address Bit 3 from BSMI	D11	L6 B02
07	B5		B10	L6 A04
08	B6	-SCTL Address Bit 5 from BSMI	D10	L6 A02
10	B7	-SCTL Address Bit 6 from BSMI	B09	K6 E04
11	B8	-SCTL Address Bit 7 from BSMI	D09	K6 E02
12	B9	-SCTL Address Bit 8 from BSMI	B08	K6 D04
14	C1	-SCTL Address Bit 9 from BSMI	D07	K6 C02
15	C2	+STG Go	B06	K6 B04
16	C3	-STG Read, +STG Write	D06	K6 B02
18	C4	-M1 Clock Signal	B05	K6 A04
19	C5	-M2 Clock Signal	D05	K6 A02
20	C6	-M3 Clock Signal	B04	J6 E04
22	C7	-M4 Clock Signal	D03	J6 D02
23	C8	-M5 Clock Signal	D02	J6 C02
24	C9	-M6 Clock Signal	B02	J6 C04
01	A1	-----+--- Signal Ground ---+-----	D12	L6 C02
05	A2	-----+----- -----	B11	L6 B04
09	A3	-----+----- -----	D08	K6 D02
13	A4	-----+----- -----	B07	K6 C04
17	A5	-----+----- -----	D04	K6 E02
21	A6	-----+----- -----	B03	J6 D04
25	A7	-----+----- -----		

* Not accessible

MIOC BUS: Signal Tables

Cable 12

CCU *		CCU-to-MOSS cable (Clocks and controls)	MMB	
01A-A2V2C Pin Ref on Board Cable		Signal Names with Polarities	01A-A1ZG Pin Ref on Cable Board	
02	B1	-Scan Inter to MOSS	D13	V6 A02
03	B2		B12	U6 E04
04	B3	-100 ms Pulse	B13	V6 A04
06	B4	-480 Hz Clock	D11	U6 D02
07	B5	-15.258 us Pulse	B10	U6 C04
08	B6	-15.258 us Pulse	D10	U6 C02
10	B7	-Power On Reset	B09	U6 B04
11	B8	-Remote Pwr Off	D09	U6 B02
12	B9	+CCU Clock Card Check	B08	U6 A04
14	C1	-Write Strobe	D07	T6 E02
15	C2	-Read Strobe	B06	T6 D04
16	C3	-Read Ack	D06	T6 D02
18	C4	-Write Ack	B05	T6 C04
19	C5	-MOSS Inoperative	D05	T6 C02
20	C6	-HLIR to MIOC	B04	T6 B04
22	C7	-LLIR to MIOC	D03	T6 A02
23	C8	-CCU/MOSS Parity Check	D02	S6 E02
24	C9		B02	S6 E04
01	A1	-----+--- Signal Ground -----+---	D12	U6 E02
05	A2	-----+--- -----+---	B11	U6 D04
09	A3	-----+--- -----+---	D08	U6 A02
13	A4	-----+--- -----+---	B07	T6 E04
17	A5	-----+--- -----+---	D04	T6 B02
21	A6	-----+--- -----+---	B03	T6 A04
25	A7	-----+--- -----+---		

Cable 13

CCU *		CCU-to-MOSS cable (Data and address busses)	MMB	
01A-A2V2D Pin Ref on Board Cable		Signal Names with Polarities	01A-A1ZH Pin Ref on Cable Board	
02	B1	-MIOC Data Bus (P)	D13	X6 E02
03	B2	-MIOC Address Bus (P)	B12	X6 D04
04	B3	-MIOC Data Bus (0)	B13	X6 E04
06	B4	-MIOC Address Bus (0)	D11	X6 C02
07	B5	-MIOC Data Bus (1)	B10	X6 B04
08	B6	-MIOC Address Bus (1)	D10	X6 B02
10	B7	-MIOC Data Bus (2)	B09	X6 A04
11	B8	-MIOC Address Bus (2)	D09	X6 A02
12	B9	-MIOC Data Bus (3)	B08	W6 E04
14	C1	-MIOC Address Bus (3)	D07	W6 D02
15	C2	-MIOC Data Bus (4)	B06	W6 C04
16	C3	-MIOC Address Bus (4)	D06	W6 C02
18	C4	-MIOC Data Bus (5)	B05	W6 B04
19	C5	-MIOC Address Bus (5)	D05	W6 B02
20	C6	-MIOC Data Bus (6)	B04	W6 A04
22	C7		D03	
23	C8	-MIOC Data Bus (7)	D02	V6 D02
24	C9	+PRGM Wait	B02	V6 D04
01	A1	-----+--- Signal Ground -----+---	D12	X6 D02
05	A2	-----+--- -----+---	B11	X6 C04
09	A3	-----+--- -----+---	D08	W6 E02
13	A4	-----+--- -----+---	B07	W6 D04
17	A5	-----+--- -----+---	D04	W6 A02
21	A6	-----+--- -----+---	B03	V6 E04
25	A7	-----+--- -----+---		

* Not accessible

MOSS Buses: Signal Tables

MOSS-TO-DISKETTE CABLE

MOSS-TO-CONTROL-PANEL CABLE

Cable 15

MMB 01A-A1YR Pin Ref on Board Cable	MOSS-to-diskette Signal Names with Polarities	Diskette 01C-J1 Pins on Signal Gnd
V1 E11	D03 +5 Volts	B01
W1 A13	B04 +Index	B04 A04
W1 A11	D04 +Diskette sense	B05 A05
W1 B13	B05 +Write/Erase Enable	B06 A06
W1 B11	D05 +File Data	B07 A07
W1 C13	B06 +Inner Tracks	B08 A08
W1 C11	D06 +Erase Gate	B09 A09
W1 D13	B07 +Access 0	B10 A10
W1 D11	D07 +Select Head 1	B11 A11
W1 E13	B08 +Access 1	B13 A13
W1 E11	D08 ----- Signal Ground -----	A02
X1 A13	B09 +Write Gate	B14 A14
X1 A11	D09 +Head Engage	B15 A15
X1 B13	B10 +Switch Filter	B16 A16
X1 B11	D10 +Write Data	B17 A17
X1 C11	D11 -5 Volts	A01
	D12	
	D13	

Cable 16

MMB 01A-A1YH Pin Ref on Board Cable	MOSS to control panel (Primary/alternate console) Signal Names with Polarities	Panel Card 01L-P3 Pins
V1 D08	B02 +Transmit Data	A01
V1 D06	D02 +RLSD	B01
V1 E08	B03 +Data Terminal Ready	A03
	D03	
W1 A08	B04 +Receive Data	A04
W1 A06	D04 +Ready For Sending	B04
W1 B08	B05 +Request To Send	A05
W1 B06	D05 +Data Set Ready	B05
	B06	
W1 C06	D06 -Primary Console	B06
W1 D08	B07 -Start No	A07
W1 D06	D07 +Panel MOSS Inoperative	B07
W1 E08	B08 +Message	A08
W1 E06	D08 ----- Signal Ground -----	B08
	B09	
X1 A06	D09 -Normal	B09
X1 B08	B10 -MOSS IML	A10
X1 B06	D10 -MOSS Dump	B10
	B11	
X1 C06	D11 -Maintenance	B11
X1 D08	B12 -Console Link Test	A12
	D12	
	D13	

Cable 17

MMB 01A-A1YQ Pin Ref on Board Cable	MOSS to control panel (Lamps and display) Signal Names with Polarities	Panel Card 01L-P5 Pins
S1 E13	B02 +Hex A 1	A01
S1 E11	D02 +Hex A 2	A03
T1 A13	B03 +Hex A 4	A04
	D03	
T1 B13	B04 +Hex A 8	A06
T1 B11	D04 +Hex B 1	A07
T1 C13	B05 +Hex B 2	A08
T1 C11	D05 +Hex B 4	A09
	B06	A10
T1 D11	D06 +Hex B 8	A11
T1 E13	B07 +Hex C 1	A12
T1 E11	D07 +Hex C 2	A13
U1 A13	B08 +Hex C 4	A14
U1 A11	D08 ----- Signal Ground -----	A15
U1 B13	B09 +Hex C 8	A16
U1 B11	D09 +Hex Valid	A17
U1 C13	B10 +All CA Disabled	A18
U1 C11	D10 +PRGM Wait	A19
	B11	
	D11	
	B12	
	D12	
	B13	
	D13	

On the MOSS to diskette cable, interference between signals is prevented by using twisted pairs; the pin assignment is as follows:

```

+----+
+index-----|----|--> B04
Signal Ground-----+ ---> A04

```

A single wire carries the 24 Vdc from the primary power box 01N (see page 7-161).

Cable 18

MMB 01A-A1YG Pin Ref on Board Cable	MOSS to control panel (Switches and power control) Signal Names with Polarities	Panel Card 01L-P5 Pins
S1 E08	B02 -CA-1 A Enable	B01
S1 E06	D02 -CA-2 A Enable	B02
	B03	
T1 A06	D03 +5 volts	B04
T1 B08	B04 -CA-3 A Enable	B05
	D04	
T1 C08	B05 -CA-4 A Enable	B07
T1 C06	D05 -CA-5 A Enable	B08
	B06	
T1 D06	D06 -CA-6 A Enable	B09
T1 E08	B07 -CA-1 B Enable	B10
T1 E06	D07 -CA-2 B Enable	B11
U1 A08	B08 -CA-3 B Enable	B12
U1 A06	D08 ----- Signal Ground -----	B13
U1 B08	B09 -CA-4 B Enable	B14
U1 B06	D09 -Diskette Drive Power Off	B15
U1 C08	B10 -Diskette Drive Reset	B16
U1 C06	D10 +5 volts sp	B17
	B11	B18
U1 D06	D11 -Power On Reset	B19
U1 E08	B12 +Remote Power Off	B20
	D12	
	B13	
	D13	

Channel Adapter Cables: Signal Tables

CHANNEL ADAPTER CABLES

Cable 19 (3725/3726)

Cable 20 (3725/3726)

Cable 21 (3725/3726)

MMB 01A-A1YF Pin Ref on Board Cable		Cable to CA position 1 (CA-1) Signal Names with Polarities	CLAB1 01A-A3YH Pin Ref on Board Cable	
Q1 A08	B02	-CA-1 A Enable	B02	V1 D08
	D02		D02	
Q1 B08	B03	-CA-1 B Enable	B03	V1 E08
	D03		D03	
	B04		B04	
Q1 C06	D04	+Interface CA-1 A Enabled	D04	W1 A06
	B05		B05	
Q1 D06	D05	+Interface CA-1 B Enabled	D05	W1 B06
	B06		B06	
	D06		D06	
R1 A08	B07	+All CA Disabled	B07	W1 D08
	D07		D07	
R1 B08	B08	-CA-2 A Enable	B08	W1 E08
R1 B06	D08	----- Signal Ground -----	D08	W1 E06
	B09		B09	
R1 C06	D09	-CA-2 B Enable	D09	X1 A06
	B10		B10	
R1 D06	D10	-Interface CA-2 A Enabled	D10	X1 B06
	B11		B11	
	D11		D11	
S1 A08	B12	-Interface CA-2 B Enabled	B12	X1 D08
	D12		D12	
	B13		B13	
	D13		D13	

CLAB1 01A-A3YD Pin Ref on Board Cable		Cable to CA position 2 (CA-2) Signal Names with Polarities	CLAB2 01B-A2YH Pin Ref on Board Cable	
J1 C08	B02	-CA-2 A Enable	B02	V1 D08
	D02		D02	
J1 D08	B03	-CA-2 B Enable	B03	V1 E08
	D03		D03	
	B04		B04	
J1 E06	D04	-Interface CA-2 A Enabled	D04	W1 A06
	B05		B05	
K1 A06	D05	+Interface CA-2 B Enabled	D05	W1 B06
	B06		B06	
	D06		D06	
K1 C08	B07	+All CA Disabled	B07	W1 D08
	D07		D07	
K1 D08	B08	-Priority Bus Bit 4 to Interface	B08	W1 E08
K1 D06	D08	----- Signal Ground -----	D08	W1 E06
K1 E08	B09	-Priority Bus Bit 5 to Interface	B09	X1 A08
K1 E06	D09	-Priority Bus Bit 6 to Interface	D09	X1 A06
L1 A08	B10	-Priority Bus Bit 7 to Interface	B10	X1 B08
L1 A06	D10	-Hold to Interface	D10	X1 B06
	B11		B11	
L1 B06	D11	-CA Sample Trap to Interface	D11	X1 C06
L1 C08	B12	+Common Valid Feed Auto	B12	X1 D08
L1 C06	D12	-Sample Out to I/F Repowered	D12	X1 D06
L1 D08	B13	-Sample Out Wrap Dot Repowered	B13	X1 E08
L1 D06	D13	-CA Installed Received	D13	X1 E06

MMB 01A-A1YE Pin Ref on Board Cable		Cable to CA positions 3, 4, 5, and 6 Signal Names with Polarities	CAB 02C-A1YE Pin Ref on Board Cable	
M1 B08	B02	-CA-3 A Enable	B02	M1 B08
M1 B06	D02	-CA-4 A Enable	D02	M1 B06
M1 C08	B03	-CA-5 A Enable	B03	M1 D08
	D03		D03	
	B04		B04	M1 D08
M1 D08	B04	-CA-6 A Enable	D04	M1 D06
M1 D06	D04	-CA-3 B Enable	B05	M1 E08
M1 E08	B05	-CA-4 B Enable	D05	M1 E06
M1 E06	D05	-Interface CA-3 A Enabled	B06	
	B06		D06	N1 A06
N1 A06	D06	-Interface CA-4 A Enabled	B07	N1 B08
N1 B08	B07	-Interface CA-5 A Enabled	D07	N1 B06
N1 B06	D07	-Interface CA-6 A Enabled	B08	N1 C08
N1 C08	B08	-Interface CA-3 B Enabled	D08	N1 C06
N1 C06	D08	----- Signal Ground -----	B09	N1 D08
N1 D08	B09	-Interface CA-4 B Enabled	D09	N1 D06
N1 D06	D09	+All CA Disabled	B10	
	B10		D10	
	D10		B11	
	B11		D11	
	D11		B12	
	B12		D12	
	D12		B13	
	B13		D13	
	D13			

Cable 19 (3725 Model 2)

Cable 20 (3725 Model 2)

Cable 21 (3725 Model 2)

MMB 01A-A1YF Pin Ref on Board Cable		Cable to CA position 1 (CA-1) and CA position 2 (CA-2) Signal Names with Polarities	C2LB 01A-A3YH Pin Ref on Board Cable	
Q1 A08	B02	-CA-1 A Enable	B02	V1 D08
	D02		D02	
Q1 B08	B03	-CA-1 B Enable	B03	V1 E08
	D03		D03	
	B04		B04	
Q1 C06	D04	+Interface CA-1 A Enabled	D04	W1 A06
	B05		B05	
Q1 D06	D05	+Interface CA-1 B Enabled	D05	W1 B06
	B06		B06	
	D06		D06	
R1 A08	B07	+All CA Disabled	B07	W1 D08
	D07		D07	
R1 B08	B08	-CA-2 A Enable	B08	W1 E08
R1 B06	D08	----- Signal Ground -----	D08	W1 E06
	B09		B09	
R1 C06	D09	-CA-2 B Enable	D09	X1 A06
	B10		B10	
R1 D06	D10	-Interface CA-2 A Enabled	D10	X1 B06
	B11		B11	
	D11		D11	
S1 A08	B12	-Interface CA-2 B Enabled	B12	X1 D0
	D12		D12	
	B13		B13	
	D13		D13	

C2LB 01A-A3YD Pin Ref on Board Cable		Cable to CA position 3 (CA-3) and CA position 4 (CA-4) Signal Names with Polarities	C2LB2 01B-A2YH Pin Ref on Board Cable	
	B02		B02	V1 D08
	D02		D02	
	B03		B03	V1 E08
	D03		D03	
	B04		B04	
	D04		D04	W1 A06
	B05		B05	
	D05		D05	W1 B06
	B06		B06	
	D06		D06	
	B07		B07	W1 D08
	D07		D07	
K1 D08	B08	-Priority Bus Bit 4 to Interface	B08	W1 E08
K1 D06	D08	----- Signal Ground -----	D08	W1 E06
K1 E08	B09	-Priority Bus Bit 5 to Interface	B09	X1 A08
K1 E06	D09	-Priority Bus Bit 6 to Interface	D09	X1 A06
L1 A08	B10	-Priority Bus Bit 7 to Interface	B10	X1 B08
L1 A06	D10	-Hold to Interface	D10	X1 B06
	B11		B11	
L1 B06	D11	-CA Sample Trap to Interface	D11	X1 C06
L1 C08	B12	+Common Valid Feed Auto	B12	X1 D08
L1 C06	D12	-Sample In (from CA-2)	D12	X1 D06
L1 D08	B13	-Sample Out Wrap Dot Repowered	B13	X1 E08
L1 D06	D13	-CA Installed Send	D13	X1 E06

MMB 01A-A1YE Pin Ref on Board Cable		Cable to CA positions 3, and 4 Signal Names with Polarities	C2LB2 02C-A1YE Pin Ref on Board Cable	
M1 B08	B02	-CA-3 A Enable	B02	M1 B08
M1 B06	D02	-CA-4 A Enable	D02	M1 B06
M1 C08	B03	-CA-5 A Enable (not installed)	B03	M1 D08
	D03		D03	
	B04		B04	M1 D08
M1 D08	B04	-CA-6 A Enable (not installed)	D04	M1 D06
M1 D06	D04		B05	M1 E08
M1 E08	B05	-Interface CA-3 A Enabled	D05	M1 E06
M1 E06	D05		B06	
	B06		D06	N1 A06
N1 A06	D06	-Interface CA-4 A Enabled	B07	N1 B08
N1 B08	B07	-Intrf. CA-5 A Enab.(not instal.)	D07	N1 B06
N1 B06	D07	-Intrf. CA-6 A Enab.(not instal.)	B08	N1 C08
N1 C08	B08	----- Signal Ground -----	D08	N1 C06
N1 C06	D08		B09	N1 D08
N1 D08	B09	+All CA Disabled	D09	N1 D06
N1 D06	D09		B10	
	B10		D10	
	D10		B11	
	B11		D11	
	D11		B12	
	B12		D12	
	D12		B13	
	B13		D13	
	D13			

Secondary IOC Bus : Signal Tables

Cable 22

CLAB2				CA position 2 to CA positions 3, 4, 5, and 6		CAB	
01B-A2 Board Pin	YK Cable Pin	YL Cable Pin	01B-J1A2 Cable Pin	Signal Names with Polarities		02C-A1YD Pin Ref on Board	Cable
			D02	B02		B02	
			B02	D02		D02	
			D03	B03		B03	
			B03	D03		D03	
			D04	B04		B04	
			B04	D04		D04	
			D05	B05		B05	
			B05	D05		D05	
			D06	B06		B06	
			B06	D06		D06	
			D07	B07		B07	
			B07	D07		D07	
E1 A13	B08	B08	D08	B08	-Priority Bus Bit 4 to Interface	B08	K1 D08
E1 A11	D08	D08	B08	D08	----- Signal Ground -----	D08	K1 D06
E1 B13	B09	B09	D09	B09	-Priority Bus Bit 5 to Interface	B09	K1 E08
E1 B11	D09	D09	B09	D09	-Priority Bus Bit 6 to Interface	D09	K1 E06
E1 C13	B10	B10	D10	B10	-Priority Bus Bit 7 to Interface	B10	L1 A08
E1 C11	D10	D10	B10	D10	-Hold to Interface	D10	L1 A06
			D11	B11		B11	
E1 D11	D11	D11	B11	D11	-CA Sample Trap to Interface	D11	K1 B06
E1 E13	B12	B12	D12	B12	+Common Valid Feed Auto	B12	K1 C08
E1 E11	D12	D12	B12	D12	-Sample Out to I/F Repowered	D12	K1 C06
F1 A13	B13	B13	D13	B13	-Sample Out Wrap Dot Repowered	B13	L1 D08
F1 A11	D13	D13	B13	D13	-CA Installed Received	D13	L1 D06

Cable 24

CAB		Frame RDV to board RDV (IOC cable B)	RDV on LAB position 6		
02C-A1B4 Pin Ref on TC(1) Cable	Signal Names with Polarities		02A-A1A4 Pin Ref on Cable TC(1)		
Y13	D13	-Data Bus 0.7	D13	Y13	
Y33	B13	-Valid Halfword from Adapter	B13	Y33	
	D12	-Data Bus 0.6	D12	Y12	
Y32	B12	-Parity Valid from Adapter	B12	Y32	
Y31	B11	-Modifier from RDV	B11	Y31	
Y10	D10	-Data Bus 0.5	D10	Y10	
Y30	B10	-Scanner Inter to MOSS	B10	Y30	
Y09	D09	-Data Bus 0.4	D09	Y09	
Y08	D08	-Data Bus 0.3	D08	Y08	
Y28	B08	-CA Request IPL	B08	Y28	
Y27	B07	-RDV Error Register Out	B07	Y27	
Y07	D07	-Data Bus 0.2	D07	Y07	
Y26	B06	-RDV L1 Pending Out	B06	Y26	
Y25	B05	-Data Bus 0.P	B05	Y25	
Y05	D05	-Data Bus 0.1	D05	Y05	
Y04	D04	-Data Bus 0.0	D04	Y04	
Y23	B03	-CS Grant Low Out RDV to RDV	B03	Y23	
Y03	D03	-CS Grant Low In CCU to RDV	D03	Y03	
Y22	B02	-CS Grant High Out RDV to RDV	B02	Y22	
Y02	D02	-CS Grant High In CCU to RDV	D02	Y02	
Y24	B04	-----+--- Signal Ground ---+---	B04	Y24	
Y29	B09	----- -----	B09	Y29	
Y06	D06	----- -----	D06	Y06	
Y11	D11	----- -----	B11	Y11	

(1) TC: Pin on top card connector.

For IOC wire distribution up to LAB board position 8, see page 4-091.

Cable 23

CAB		Frame RDV to board RDV (IOC cable A)	RDV on LAB position 6		
02C-A1B3 Pin Ref on TC(1) Cable	Signal Names with Polarities		02A-A1A3 Pin Ref on Cable TC(1)		
X13	D13	-Data Bus 1.7	D13	X13	
X33	B13	-CS Req High RDV to CCU	B13	X33	
X12	D12	-Data Bus 1.6	D12	X12	
X32	B12	-CS Req Low RDV to CCU	B12	X32	
X31	B11	-CS Req Prty Line	B11	X31	
X10	D10	-Data Bus 1.5	D10	X10	
X30	B10	-L2 Priority Line	B10	X30	
X09	D09	-Data Bus 1.4	D09	X09	
X08	D08	-Data Bus 1.3	D08	X08	
X28	B08	-L2 Request to Redrive	B08	X28	
X27	B07		B07	X27	
X07	D07	-Data Bus 1.2	D07	X07	
X26	B06		B06	X26	
X25	B05	-Data Bus 1.P	B05	X25	
X05	D05	-Data Bus 1.1	D05	X05	
X04	D04	-Data Bus 1.0	D04	X04	
X23	B03		B03	X23	
X03	D03		D03	X03	
X22	B02		B02	X22	
X02	D02		D02	X02	
X24	B04	-----+--- Signal Ground ---+---	B04	X24	
X29	B09	----- -----	B09	X29	
X06	D06	----- -----	D06	X06	
X11	D11	----- -----	B11	X11	

Cable 25

CAB		Frame RDV to board RDV (IOC cable C)	RDV on LAB position 6		
02C-A1B5 Pin Ref on TC(1) Cable	Signal Names with Polarities		02A-A1A5 Pin Ref on Cable TC(1)		
Z13	D13	-15.258 us Pulse	D13	Z13	
Z33	B13		B13	Z33	
Z12	D12	-4.9152 MHz Clock	D12	Z12	
Z32	B12	-Power On Reset to Adapter	B12	Z32	
Z31	B11	-Reset Tag CCU to Adapter	B11	Z31	
Z10	D10	-100 ms Pulse	D10	Z10	
Z30	B10	+Read, -Write Tag CCU to Adapter	B10	Z30	
Z09	D09	-End of Chain from Adapter	D09	Z09	
Z08	D08	-Valid Byte from Adapter	D08	Z08	
Z28	B08	-Halt Tag CCU to Adapter	B08	Z28	
Z27	B07	-TD Tag CCU to Adapter	B07	Z27	
Z07	D07	-Inter Request Removed from Adap	D07	Z07	
Z26	B06	-TA Tag CCU to Adapter	B06	Z26	
Z25	B05	-I/O Tag CCU to Adapter	B05	Z25	
Z05	D05	-Exception from Adapter	D05	Z05	
Z04	D04	-480 Hz Clock	D04	Z04	
Z23	B03	-Select Out RDV to RDV	B03	Z23	
Z03	D03	-Select In	D03	Z03	
Z22	B02	-Allow Poll Response Out	B02	Z22	
Z02	D02	-Allow Poll Response In	D02	Z02	
Z24	B04	-----+--- Signal Ground ---+---	B04	Z24	
Z29	B09	----- -----	B09	Z29	
Z06	D06	----- -----	D06	Z06	
Z11	D11	----- -----	B11	Z11	


IOC Wire Continuity (Part 1 of 3)

CABLES FROM CCU BOARD TO CAB

These are the primary IOC cables.

This figure shows the IOC wire distribution between the CCU board and the CAB. The next page shows the IOC distribution between the CAB and LAB position 8. These figures can be used to check wire continuity.

Note that the paths of most wires can be checked for continuity all at once as the RDV cards receive the signals in parallel. Four wires on an RDV do not follow this rule and must be checked from RDV to RDV in sequence. When an RDV is not present on a board, these four wires are jumpered with continuity plugs placed on the IOC connector as shown.




A continuity plug connects:

Cable position 3: (plug present but not used)

Cable position 4: Pin B02 to D02
Pin B03 to D03

Cable position 5: Pin B02 to D02
Pin B03 to D03




Note: For cable identification, see page 4-070. For signal identification, see page 4-080.

IOC Wire Continuity (Part 2 of 3)

CABLES FROM CAB TO LAB POSITION 8

These are the secondary IOC cables.



Note: For cable identification, see page 4-070. For signal identification, see page 4-085.

IOC Wire Continuity (Part 3 of 3)

You can probe the IOC bus signals on the bus terminator (BUSTERM) card. The following tables relate signal names and pins of the RDV card top connector, and of the BUSTERM card.

IOC Bus: Cable A

Signal Names (With Polarities)	RDV TC (1) Pin	BUSTERM Pin
-Data Bus 1.7	X13	J13
-CS Req High RDV to CCU	X33	G13
-Data Bus 1.6	X12	J12
-CS Req Low RDV to CCU	X32	G12
-CS Req Prty Line	X31	G11
-Data Bus 1.5	X10	J10
-L2 Priority Line	X30	G10
-Data Bus 1.4	X09	J09
-Data Bus 1.3	X08	J08
-L2 Request to RDV	X28	G08
	X27	G07
-Data Bus 1.2	X07	J07
	X26	G06
-Data Bus 1.P	X25	G05
-Data Bus 1.1	X05	J05
-Data Bus 1.0	X04	J04
	X03	J03
	X02	J02
Signal Ground	X24	G04
Signal Ground	X29	G09
Signal Ground	X06	J06
Signal Ground	X11	J11

(1) Pin on RDV card top connector (TC)

IOC Bus: Cable B

Signal Names (With Polarities)	RDV TC (1) Pin	BUSTERM Pin
-Data Bus 0.7	Y13	P13
-Valid Halfword from Adapter	Y33	M13
-Data Bus 0.6	Y12	P12
-Parity Valid from Adapter	Y32	M12
-Modifier from RDV	Y31	M11
-Data Bus 0.5	Y10	P10
-All CAs Disabled	Y30	M10
-Data Bus 0.4	Y09	P09
-Data Bus 0.3	Y08	P08
-CA Req IPL Detect	Y28	M08
-RDV Error Reg Out	Y27	M07
-Data Bus 0.2	Y07	P07
-RDV L1 Pending Out	Y26	M06
-Data Bus 0.P	Y25	M05
-Data Bus 0.1	Y05	P05
-Data Bus 0.0	Y04	P04
-CS Grant Low Out RDV to RDV	Y23	M03
-CS Grant Low Out CCU to RDV	Y03	P03
-CS Grant High Out RDV to RDV	Y22	M02
-CS Grant High Out CCU to RDV	Y02	P02
Signal Ground	Y24	M04
Signal Ground	Y29	M09
Signal Ground	Y06	P06
Signal Ground	Y11	P11




(1) Pin on RDV card top connector (TC)

IOC Bus: Cable C

Signal Names (With Polarities)	RDV TC (1) Pin	BUSTERM Pin
-15.258 us Pulse (A Clock)	Z13	U13
	Z33	S13
-4.9152 MHz Clock	Z12	U12
-Power On Reset to Adapter	Z32	S12
-Reset Tag CCU to Adapter	Z31	S11
-100 ms Pulse	Z10	U10
+Read, -Write Tag CCU to Adapter	Z30	S10
-End of Chain from Adapter	Z09	U09
-Valid Byte from Adapter	Z08	U08
-Halt Tag CCU to Adapter	Z28	S08
-TD Tag CCU to Adapter	Z27	S07
-Inter Req Removed from Adapter	Z07	U07
-TA Tag CCU to Adapter	Z26	S06
-I/O Tag CCU to Adapter	Z25	S05
-Exception from Adapter	Z05	U05
-480 Hz Clock	Z04	U04
-Select Out RDV to RDV	Z23	S03
-Select In	Z03	U03
-Allow Poll Response Out	Z22	S02
-Allow Poll Response In	Z02	U02
Signal Ground	Z24	S04
Signal Ground	Z29	S09
Signal Ground	Z06	U06
Signal Ground	Z11	U11

(1) Pin on RDV card top connector (TC)

Terminator Card (BUSTERM) Diagram



From	To	Signal Names
G08	X28	- L2 Request
G12	X32	- CS Request Low
G13	X33	- CS Request High
M06	Y26	- RDV L1 Pending
M07	Y27	- RDV Error Reg Out
M08	Y28	- CA Request IPL Detect
M10	Y30	- CSP Interrupt to MOSS
M12	Y32	- Parity Valid
U05	Z05	- Exception
U07	Z07	- Inter Request Removed
U08	Z08	- Valid Byte
U09	Z09	- End of Chain

Voltage	Pins
Signal	S04, U06, S09, U11, Z06, Z11, Z24, Z29, M04, P06, M09, P11, Y06, Y11, Y24, Y29, G04, J06, G09, J11, X06, X11, X24, X29, D08
+5	D03

High-Speed Clock Distribution (From ACLK Card)

The high-speed clock signals (29.4912 MHz) are generated by the ACLK card on the MMB board.

They are distributed via five coaxial cables from the pin side of the ACLK card to the pin side of the RDV cards (those that are present in the machine). The first figure (right) shows the cable routing assuming a maximum machine configuration; the second figure lists the pin assignments for continuity checking the clock signal, or scoping. For high-speed clock scoping and signal waveforms, refer to page 5-051.


Low-speed clock signals are also generated by the ACLK card, and are distributed via the IOC cables.

See the signal tables on page 4-080 onward for clock wire identification, and the IOC wire continuity diagrams on page 4-090 for continuity checking.

Note: The 3-pin connector that carries the clock signals may be plugged either way up.


CLOCK CABLE ROUTING

Note: Refer to table below for board pin locations.



HIGH-SPEED CLOCK BOARD PINS

From ACLK	To RDV	From RDV	To RDV	From RDV	To RDV
MMB 01A-A1X4D07 Ground: D08 D09	LAB Pos 4 02A-A3A2B02 Ground: B03 B04	LAB Pos 4 02A-A3A2D05 Ground: D06 D07	LAB Pos 5 02A-A2A2B02 Ground: B03 B04	LAB Pos 5 02A-A2A2D05 Ground: D06 D07	LAB Pos 6 02A-A1A2B02 Ground: B03 B04
MMB 01A-A1X4B02 Ground: B03 B04	LAB Pos 7 02B-A3A2B02 Ground: B03 B04	LAB Pos 7 02B-A3A2D05 Ground: D06 D07	LAB Pos 8 02B-A2A2B02 Ground: B03 B04		
MMB 01A-A1X4B07 Ground: B08 B09	CAB 02C-A1A2B02 Ground: B03 B04				
MMB 01A-A1X5B02 Ground: B03 B04	CLAB2 or C2LB2 01B-A2A2B02 Ground: B03 B04	CLAB2 or C2LB2 01B-A2A2D05 Ground: D06 D07	LAB Pos 3 01B-A1A2B02 Ground: B03 B04		
MMB 01A-A1X5D07 Ground: D08 D09	CLAB1 or C2LB 01A-A3A2B02 Ground: B03 B04				



OTHER MACHINE CLOCKS


1. CCU clock is internal to the CCU board (see pin lists and net lists in MD volume B02).
2. For ICC clocks, see direct-attachment clock select jumper on page 4-270.

CLOCK SCOPING

For clock scoping and signal waveforms, refer to Chapter 5.

CA Cable Routing (Part 1 of 5)


FRAME 01



CA Cable Removal

Do not pull out a CA connector (from a tailgate socket or from a CADR card) unless you are sure that the host system is not using this channel interface.

You can display the status of the channel interfaces by using the CCU FNCTN key on the 3727 operator console, and selecting the subfunction 10. If the CA interface is enabled, switch the Enbl/Dsbl switch to Dsbl on the 3725 control panel. When the CA operation stops, the CA interface becomes disabled. You can check regularly the status of the CA with the CCU FNCTN key.



C2LB (Note)	Tailgate Connectors Channel (Rear)	Interface
01A-A3X2 X3 X4 X5	01D-MB1 A1 B2 A2	01D-MB3 A3 B4 A4 CA Pos 1
01A-A3W2 W3 W4 W5	01D-LB1 A1 B2 A2	01D-LB3 A3 B4 A4 CA Pos 2

CLAB1 (Note)	Tailgate Connectors Channel (Rear)	Interface
01A-A3X2 X3 X4 X5	01D-MB1 A1 B2 A2	01D-MB3 A3 B4 A4 1A CA Pos 1
01A-A3W2 W3 W4 W5	01D-LB1 A1 B2 A2	01D-LB3 A3 B4 A4 1B TPS Pos 1


CLAB2 (Note)	Tailgate Connectors Channel (Rear)	Interface
01B-A2B2 B3 B4 B5	01D-BB1 A1 B2 A2	01D-BB3 A3 B4 A4 2A CA Pos 2
01B-A2C2 C3 C4 C5	01D-AB1 A1 B2 A2	01D-AB3 A3 B4 A4 2B TPS Pos 2

C2LB2 (Note)	Tailgate Connectors Channel (Rear)	Interface
01B-A2B2 B3 B4 B5	01D-BB1 A1 B2 A2	01D-BB3 A3 B4 A4 CA Pos 3
01B-A2C2 C3 C4 C5	01D-AB1 A1 B2 A2	01D-AB3 A3 B4 A4 CA Pos 4

Note: Top card connector on CADR card.

CA Cable Routing (Part 2 of 5)

FRAME 02




Notes:

1. Interface A of CA position 6 or (mutually exclusive) interface B of CA position 3 if TPS position 3
2. Interface A of CA position 5 or (mutually exclusive) interface B of CA position 4 if TPS position 4
3. Interface A of CA position 4
4. Interface A of CA position 3

CAB (Note 1)	Tailgate Connectors Channel	Connectors (Rear)	Interface
02C-A1W2 W3 W4 W5	02Q-DB1 A1 B2 A2	02Q-DB3 A3 B4 A4	3A CA Pos 3
02C-A1V2 V3 V4 V5	02Q-AB1 A1 B2 A2	02Q-AB3 A3 B4 A4	3B TPS Pos 3 (Note 2)
02C-A1R2 R3 R4 R5	02Q-CB1 A1 B2 A2	02Q-CB3 A3 B4 A4	4A CA Pos 4
02C-A1Q2 Q3 Q4 Q5	02Q-BB1 A1 B2 A2	02Q-BB3 A3 B4 A4	4B TPS Pos 4 (Note 3)
02C-A1L2 L3 L4 L5	02Q-BB1 A1 B2 A2	02Q-BB3 A3 B4 A4	5A CA Pos 5 (Note 3)
02C-A1G2 G3 G4 G5	02Q-AB1 A1 B2 A2	02Q-AB3 A3 B4 A4	6A TPS Pos 6 (Note 2)

Notes:

1. Top card connector on CADR card.
2. TPS position 3 and CA position 6 are mutually exclusive.
3. TPS position 4 and CA position 5 are mutually exclusive.



CA Cable Routing (Part 3 of 5)

A	B	C	D	
(CADR) Top Card Connector Probe/Pin	(CADR) Top Card Cable #2 Probe/Pin	Bus out Tailgate NPL Probe/Pin	Bus in Tailgate NPL Probe/Pin	Channel Interface Cable Pin Signal Name

W02 <—>	D02 <—>			> Ground
W03 <—>	D03 <—>	Y-B1B03	Y-B3B03 <—>	#-B03 <—> Bus Out P bit
				Bus Out P bit
W04 <—>	D04 <—>	Y-B1B05	Y-B3B05 <—>	#-B05 <—> Bus Out 1 bit
				Bus Out 1 bit
W05 <—>	D05 <—>	Y-B1B08	Y-B3B08 <—>	#-B08 <—> Bus Out 3 bit
W06 <—>	D06 <—>	Y-B1B08	Y-B3B08 <—>	#-B08 <—> Bus Out 3 bit
W07 <—>	D07 <—>	Y-B1B10	Y-B3B10 <—>	#-B10 <—> Bus Out 5 bit
				Bus Out 5 bit
W08 <—>	D08 <—>	Y-B1B12	Y-B3B12 <—>	#-B12 <—> Bus Out 7 bit
				Bus Out 7 bit
W09 <—>	D09 <—>			> Ground
W10 <—>	D10 <—>			> Ground
W11 <—>	D11 <—>			> No Connection
W12 <—>	D12 <—>			> No Connection
W13 <—>	D13 <—>			> No Connection

W22 <—>	B02 <—>			> Ground
W23 <—>	B03 <—>	Y-B1D04	Y-B3D04 <—>	#-D04 <—> Bus Out 0 bit
				Bus Out 0 bit
W24 <—>	B04 <—>	Y-B1D06	Y-B3D06 <—>	#-D06 <—> Bus Out 2 bit
				Bus Out 2 bit
W25 <—>	B05 <—>	Y-B1D09	Y-B3D09 <—>	#-D09 <—> Bus Out 4 bit
W26 <—>	B06 <—>	Y-B1D09	Y-B3D09 <—>	#-D09 <—> Bus Out 4 bit
W27 <—>	B07 <—>	Y-B1D11	Y-B3D11 <—>	#-D11 <—> Bus Out 6 bit
				Bus Out 6 bit
W28 <—>	B08 <—>	Y-B1D13	Y-B3D13 <—>	#-D13 <—> **Mark Out
				**Mark Out
W29 <—>	B09 <—>			> Ground
W30 <—>	B10 <—>			> Ground
W31 <—>	B11 <—>			> No Connection
W32 <—>	B12 <—>			> No Connection
W33 <—>	B13 <—>			> No Connection

Y02 <—>	D02 <—>			> Ground
Y03 <—>	D03 <—>	Y-B2B03	Y-B4B03 <—>	#-B03 <—> Operational In
				Operational In
Y04 <—>	D04 <—>	Y-B2B05	Y-B4B05 <—>	#-B05 <—> Address In
				Address In
Y05 <—>	D05 <—>	Y-B2B08	Y-B4B08 <—>	#-B08 <—> Select In
Y06 <—>	D06 <—>	Y-B2B08	Y-B4B08 <—>	#-B08 <—> Select In
Y07 <—>	D07 <—>	Y-B2B10	Y-B4B10 <—>	#-B10 <—> Address Out
				Address Out
Y08 <—>	D08 <—>	Y-B2B12	Y-B4B12 <—>	#-B12 <—> Suppress Out
				Suppress Out
Y09 <—>	D09 <—>			> Ground
Y10 <—>	D10 <—>			> Ground
Y11 <—>	D11 <—>			> No Connection
Y12 <—>	D12 <—>			> No Connection
Y13 <—>	D13 <—>			> No Connection

Y22 <—>	B02 <—>			> Ground
Y23 <—>	B03 <—>	Y-B2D04	Y-B4D04 <—>	#-D04 <—> Status In
				Status In
Y24 <—>	B04 <—>	Y-B2D06	Y-B4D06 <—>	#-D06 <—> Service In
				Service In
Y25 <—>	B05 <—>	Y-B2D09	Y-B4D09 <—>	#-D09 <—> Select Out
Y26 <—>	B06 <—>	Y-B2D09	Y-B4D09 <—>	#-D09 <—> Select Out
Y27 <—>	B07 <—>	Y-B2D11	Y-B4D11 <—>	#-D11 <—> Command Out
				Command Out
Y28 <—>	B08 <—>	Y-B2D13	Y-B4D13 <—>	#-D13 <—> Service Out
				Service Out
Y29 <—>	B09 <—>			> Ground
Y30 <—>	B10 <—>			> Ground
Y31 <—>	B11 <—>			> No Connection
Y32 <—>	B12 <—>			> No Connection
Y33 <—>	B13 <—>			> No Connection

← Bus Connections →

A	B	C	D	
(CADR) Top Card Connector Probe/Pin	(CADR) Top Card Cable #3 Probe/Pin	Bus out Tailgate NPL Probe/Pin	Bus in Tailgate NPL Probe/Pin	Channel Interface Cable Pin Signal Name

X02 <—>	D02 <—>			> Ground
X03 <—>	D03 <—>	Y-A1B03	Y-A3B03 <—>	#-G03 <—> Bus In P bit
				Bus In P bit
X04 <—>	D04 <—>	Y-A1B05	Y-A3B05 <—>	#-G05 <—> Bus In 1 bit
				Bus In 1 bit
X05 <—>	D05 <—>	Y-A1B08	Y-A3B08 <—>	#-G08 <—> Bus In 3 bit
X06 <—>	D06 <—>	Y-A1B08	Y-A3B08 <—>	#-G08 <—> Bus In 3 bit
X07 <—>	D07 <—>	Y-A1B10	Y-A3B10 <—>	#-G10 <—> Bus In 5 bit
				Bus In 5 bit
X08 <—>	D08 <—>	Y-A1B12	Y-A3B12 <—>	#-G12 <—> Bus In 7 bit
				Bus In 7 bit
X09 <—>	D09 <—>			> Ground
X10 <—>	D10 <—>			> Ground
X11 <—>	D11 <—>			> No Connection
X12 <—>	D12 <—>			> No Connection
X13 <—>	D13 <—>			> No Connection

X22 <—>	B02 <—>			> Ground
X23 <—>	B03 <—>	Y-A1D04	Y-A3D04 <—>	#-J04 <—> Bus In 0 bit
				Bus In 0 bit
X24 <—>	B04 <—>	Y-A1D06	Y-A3D06 <—>	#-J06 <—> Bus In 2 bit
				Bus In 2 bit
X25 <—>	B05 <—>	Y-A1D09	Y-A3D09 <—>	#-J09 <—> Bus In 4 bit
X26 <—>	B06 <—>	Y-A1D09	Y-A3D09 <—>	#-J09 <—> Bus In 4 bit
X27 <—>	B07 <—>	Y-A1D11	Y-A3D11 <—>	#-J11 <—> Bus In 6 bit
				Bus In 6 bit
X28 <—>	B08 <—>	Y-A1D13	Y-A3D13 <—>	#-J13 <—> **Mark In
				**Mark In
X29 <—>	B09 <—>			> Ground
X30 <—>	B10 <—>			> Ground
X31 <—>	B11 <—>			> No Connection
X32 <—>	B12 <—>			> No Connection
X33 <—>	B13 <—>			> No Connection

← Tag Connections →

Z02 <—>	D02 <—>			> Ground
Z03 <—>	D03 <—>	Y-A2B03	Y-A4B03 <—>	#-G03 <—> **Clock Out
				**Clock Out
Z04 <—>	D04 <—>	Y-A2B05	Y-A4B05 <—>	#-G05 <—> **Metering In
				**Metering In
Z05 <—>	D05 <—>	Y-A2B08	Y-A4B08 <—>	#-G08 <—> Data In
Z06 <—>	D06 <—>	Y-A2B08	Y-A4B08 <—>	#-G08 <—> Data In
Z07 <—>	D07 <—>	Y-A2B10	Y-A4B10 <—>	#-G10 <—> Data Out
				Data Out
Z08 <—>	D08 <—>	Y-A2B12	Y-A4B12 <—>	#-G12 <—> Hold Out
				Hold Out
Z09 <—>	D09 <—>			> Ground
Z10 <—>	D10 <—>			> Ground
Z11 <—>	D11 <—>			> No Connection
Z12 <—>	D12 <—>			> No Connection
Z13 <—>	D13 <—>			> No Connection


Z22 <—>	B02 <—>			> Ground
Z23 <—>	B03 <—>	Y-A2D04	Y-A4D04 <—>	#-J04 <—> **Metering Out
				**Metering Out
Z24 <—>	B04 <—>	Y-A2D06	Y-A4D06 <—>	#-J06 <—> Request In
				Request In
Z25 <—>	B05 <—>	Y-A2D09	Y-A4D09 <—>	#-J09 <—> (Reserved Spare)
Z26 <—>	B06 <—>	Y-A2D09	Y-A4D09 <—>	#-J09 <—> (Reserved Spare)
Z27 <—>	B07 <—>	Y-A2D11	Y-A4D11 <—>	#-J11 <—> **Disconnect In
				**Disconnect In
Z28 <—>	B08 <—>	Y-A2D13	Y-A4D13 <—>	#-J13 <—> Operational Out
				Operational /ut
Z29 <—>	B09 <—>			> Ground
Z30 <—>	B10 <—>			> Ground
Z31 <—>	B11 <—>			> No Connection
Z32 <—>	B12 <—>			> No Connection
Z33 <—>	B13 <—>			> No Connection

Legend:
** This signal is not used in this machine.

CA Cable Routing (Part 4 of 5)

CA CONNECTION DETAILS (FROM A TOP CONNECTOR TO THE TAILGATE)

- Frame 01, CLAB2 or C2LB2
- Frame 02, CAB



CA CONNECTION (FROM A TOP CONNECTOR TO THE TAILGATE)

- Frame 01, CLAB1 or C2LB

CA Connection (from a top connector to the tailgate):
Frame 01, CLAB1 or C2LB


Cable 2

Cable 3

Cable 4

Cable 5

CADR jumper blocks on socket X4 (see page 5-042)



Note:

For light gray connectors (CADR Card) to dark gray connectors (CA), connectors are not reversed: D02 -> D02

CA Cable Routing (Part 5 of 5)

CABLE CONTINUITY

Cables and connectors identified in the figures on page 4-113 and on this page are as follows:

Cable n: Looking at cable end to CADR top card.

(1A)(2A)(3A)(4A): Cable connectors and corresponding face of tailgate connector (A side)

(1B)(2B)(3B)(4B): Cable connectors and corresponding face of tailgate connector (B side)

Note that the probe side of the cable connector and its tailgate connector side are reversed:

- Probe side: D13 - D02
B13 - B02
- Tailgate side: D02 - D13
B02 - B13

(BO): Bus out tailgate connector (A or B)

(TO): Tag out tailgate connector (A or B)

(BI): Bus in tailgate connector (A or B)





(TI): Tag in tailgate connector (A or B)

Note that the front side of a bus or tag in connector and its rear side are reversed:

- Front side (card side): D02 - D13
B02 - B13
- Rear side (CA side): B02 - B13
D02 - D13

Channel Adapter (CADR) Location	Two Processor Switch (CADR) Location
------------------------------------	---

3725 - CA/TPS 1	01A-A3X2	01A-A3W2
3725 - CA/TPS 2	01B-A2B2	01B-A2C2
3726 - CA/TPS 3	02C-A1W2	02C-A1V2
3726 - CA/TPS 4	02C-A1R2	02C-A1Q2
3726 - CA - 5	02C-A1I2	N/A
3726 - CA - 6	02C-A1G2	N/A



C2LB, Scanner Board Information

C2LB BOARD 01A-A3 - SCANNER 1

Scanner	Line Addr	ICC	FES	CSM	CSP1	CSP2	RDV	Scanner IOC Bus Addr	RDV IOC Bus Addr
1	000-015 016-023	P2 J2	F2	C2	D2	E2	A2	10X0/1 20X0/1	40X0/1 40X0/1

Note: Fill in the next table with the line information for your customer's installation:


Even line interface addresses are transmit interfaces.

Odd line interface addresses are receive interfaces.

C2LB Line Information

Line Address *	Line I/F Addr	NCP Line Addr	EP Line Addr	LIC Type	C2LB Scanner Number	Tailgate Position 01D	LIC CABLE Position 01A-A3	LIC Pos	LIC Card 01A-A3
00(00) 01(01) 02(02) 03(03)	000/001 002/003 004/005 006/007				1	01D-G1 01D-H1 01D-J1 01D-K1	N2 N3 N4 N5	1	N2
04(04) 05(05) 06(06) 07(07)	008/009 010/011 012/013 014/015				1	01D-G2 01D-H2 01D-J2 01D-K2	M2 M3 M4 M5	2	M2
08(08) 09(09) 10(10) 11(11)	016/017 018/019 020/021 022/023				1	01D-G3 01D-H3 01D-J3 01D-K3	L2 L3 L4 L5	3	L2
12(12) 13(13) 14(14) 15(15)	024/025 026/027 028/029 030/031				1	01D-G4 01D-H4 01D-J4 01D-K4	K2 K3 K4 K5	4	K2
16(16) 17(17) 18(18) 19(19)	032/033 034/035 036/037 038/039				1	01D-G5 01D-H5 01D-J5 01D-K5	H2 H3 H4 H5	5	H2
20(20) 21(21) 22(22) 23(23)	040/041 042/043 044/045 046/047				1	01D-G6 01D-H6 01D-J6 01D-K6	G2 G3 G4 G5	6	G2

* The number in parentheses is the line relative address within the board.



C2LB2, Scanner Board Information

C2LB2 BOARD 01B-A2 - SCANNER 3

Scanner	Line Addr	ICC	FES	CSM	CSP1	CSP2	RDV	Scanner IOC Bus Addr	RDV IOC Bus Addr
3	032-046 047-055	P2 S2	T2	W2	V2	U2	A2	11X0/1 21X0/1	40X2/3 40X2/3

Note: Fill in the next table with the line information for your customer's installation:


Even line interface addresses are transmit interfaces.

Odd line interface addresses are receive interfaces.

C2LB2 Line Information

Line Address *	Line I/F Addr	NCP Line Addr	EP Line Addr	LIC Type	C2LB2 Scanner Number	Tailgate Position 01D	LIC CABLE Position 01B-A2	LIC Pos	LIC Card 01B-A2
32(00) 33(01) 34(02) 35(03)	064/065 066/067 068/069 070/071				3	01D-C1 01D-D1 01D-E1 01D-F1	K2 K3 K4 K5	1	K2
36(04) 37(05) 38(06) 39(07)	072/073 074/075 076/077 078/079				3	01D-C2 01D-D2 01D-E2 01D-F2	L2 L3 L4 L5	2	L2
40(08) 41(09) 42(10) 43(11)	080/081 082/083 084/085 086/087				3	01D-C3 01D-D3 01D-E3 01D-F3	M2 M3 M4 M5	3	M2
44(12) 45(13) 46(14) 47(15)	088/089 090/091 092/093 094/095				3	01D-C4 01D-D4 01D-E4 01D-F4	N2 N3 N4 N5	4	N2
48(16) 49(17) 50(18) 51(19)	096/097 098/099 100/101 102/103				3	01D-C5 01D-D5 01D-E5 01D-F5	Q2 Q3 Q4 Q5	5	Q2
52(20) 53(21) 54(22) 55(23)	104/105 106/107 108/109 110/111				3	01D-C6 01D-D6 01D-E6 01D-F6	R2 R3 R4 R5	6	R2

* The number in parentheses is the line relative address within the board.



CLAB1, Scanner Board Information

CLAB1 BOARD (TYPE A) - 01A-A3 - SCANNER 1

Note: There is no scanner 2 on this board.

Scanner	Line Addr	ICC	FES	CSM	CSP1	CSP2	RDV	Scanner IOC Bus Addr	RDV IOC Bus Addr
1	000-015 016-031	S2 M2	G2 G2	D2 D2	E2 E2	F2 F2	A2 A2	10X0/1 20X0/1	40X0/1 40X0/1

Note: Fill in the next table with the line information for your customer's installation:


Even line interface addresses are transmit interfaces.

Odd line interface addresses are receive interfaces.

CLAB1 Line Information

Line Address *	Line I/F Addr	NCP Line Addr	EP Line Addr	LIC Type	CLAB1 Scanner Number	Tailgate Position 01D	LIC CABLE Position 01A-A3	LIC Pos	LIC Card 01A-A3
00(00) 01(01) 02(02) 03(03)	000/001 002/003 004/005 006/007				1	01D-G1 01D-H1 01D-J1 01D-K1	R2 R3 R4 R5	1	R2
04(04) 05(05) 06(06) 07(07)	008/009 010/011 012/013 014/015				1	01D-G2 01D-H2 01D-J2 01D-K2	Q2 Q3 Q4 Q5	2	Q2
08(08) 09(09) 10(10) 11(11)	016/017 018/019 020/021 022/023				1	01D-G3 01D-H3 01D-J3 01D-K3	P2 P3 P4 P5	3	P2
12(12) 13(13) 14(14) 15(15)	024/025 026/027 028/029 030/031				1	01D-G4 01D-H4 01D-J4 01D-K4	N2 N3 N4 N5	4	N2
16(16) 17(17) 18(18) 19(19)	032/033 034/035 036/037 038/039				1	01D-G5 01D-H5 01D-J5 01D-K5	L2 L3 L4 L5	5	L2
20(20) 21(21) 22(22) 23(23)	040/041 042/043 044/045 046/047				1	01D-G6 01D-H6 01D-J6 01D-K6	K2 K3 K4 K5	6	K2
24(24) 25(25) 26(26) 27(27)	048/049 050/051 052/053 054/055				1	01D-G7 01D-H7 01D-J7 01D-K7	J2 J3 J4 J5	7	J2
28(28) 29(29) 30(30) 31(31)	056/057 058/059 060/061 062/063				1	01D-G8 01D-H8 01D-J8 01D-K8	H2 H3 H4 H5	8	H2

* The number in parentheses is the line relative address within the board.



CLAB2 and LAB3, Scanner Board Information

CLAB2 BOARD (TYPE A) - 01B-A2 - SCANNER 3

Note: There is no scanner 4 on this board.

Scanner	Line Addr	ICC	FES	CSM	CSP1	CSP2	RDV	Scanner IOC Bus Addr	RDV IOC Bus Addr
3	032-047 048-063	L2 R2	S2 S2	V2 V2	U2 U2	T2 T2	A2 A2	11X0/1 21X0/1	40X2/3 40X2/3

Note: Fill in the next table with the line information for your customer's installation:

CLAB2 Line Information

Line Address *	Line I/F Addr	NCP Line Addr	EP Line Addr	LIC Type	CLAB2 Scanner Number	Tailgate Position 01D	LIC Cable Position 01B-A2	LIC Pos	LIC Card 01B-A2
32(00) 33(01) 34(02) 35(03)	064/065 066/067 068/069 070/071				3	01D-C1 01D-D1 01D-E1 01D-F1	G2 G3 G4 G5	1	G2
36(04) 37(05) 38(06) 39(07)	072/073 074/075 076/077 078/079				3	01D-C2 01D-D2 01D-E2 01D-F2	H2 H3 H4 H5	2	H2
40(08) 41(09) 42(10) 43(11)	080/081 082/083 084/085 086/087				3	01D-C3 01D-D3 01D-E3 01D-F3	J2 J3 J4 J5	3	J2
44(12) 45(13) 46(14) 47(15)	088/089 090/091 092/093 094/095				3	01D-C4 01D-D4 01D-E4 01D-F4	K2 K3 K4 K5	4	K2
48(16) 49(17) 50(18) 51(19)	096/097 098/099 100/101 102/103				3	01D-C5 01D-D5 01D-E5 01D-F5	M2 M3 M4 M5	5	M2
52(20) 53(21) 54(22) 55(23)	104/105 106/107 108/109 110/111				3	01D-C6 01D-D6 01D-E6 01D-F6	N2 N3 N4 N5	6	N2
56(24) 57(25) 58(26) 59(27)	112/113 114/115 116/117 118/119				3	01D-C7 01D-D7 01D-E7 01D-F7	P2 P3 P4 P5	7	P2
60(28) 61(29) 62(30) 63(31)	120/121 122/123 124/125 126/127				3	01D-C8 01D-D8 01D-E8 01D-F8	Q2 Q3 Q4 Q5	8	Q2

* The number in parentheses is the line relative address within the board.

LAB BOARD POSITION 3 (TYPE A) - 01B-A1 - SCANNER 5

Scanner 5 (LAB Type A)

Scanner	Line Addr	ICC	FES	CSM	CSP1	CSP2	RDV	Scanner IOC Bus Addr	RDV IOC Bus Addr
5	064-079 080-095	L2 R2	F2 F2	C2 C2	D2 D2	E2 E2	A2 A2	12X0/1 22X0/1	40X4/5 40X4/5

LAB BOARD POSITION 3 (TYPE B) - 01B-A1 - SCANNERS 5 AND 6

Scanner 5 and 6 (LAB Type B)

Scanner	Line Addr	ICC	FES	CSM	CSP1	CSP2	RDV	Scanner IOC Bus Addr	RDV IOC Bus Addr
5 6	064-079 080-095	L2 R2	F2 S2	C2 V2	D2 U2	E2 T2	A2 A2	12X0/1 12X0/1	40X6/7 40X6/7

Note: Fill in the next table with the line information for your customer's installation:

LAB Position 3 Line Information

Line Address *	Line I/F Addr	NCP Line Addr	EP Line Addr	LIC Type	LAB A Scanner Number	LAB B Scanner Number	Tailgate Position 01D	LIC Cable Position 01B-A1	LIC Pos	LIC Card 01B-A1
64(00) 65(01) 66(02) 67(03)	128/129 130/131 132/133 134/135				5	5	01D-N1 01D-P1 01D-Q1 01D-R1	G2 G3 G4 G5	1	G2
68(04) 69(05) 70(06) 71(07)	136/137 138/139 140/141 142/143				5	5	01D-N2 01D-P2 01D-Q2 01D-R2	H2 H3 H4 H5	2	H2
72(08) 73(09) 74(10) 75(11)	144/145 146/147 148/149 150/151				5	5	01D-N3 01D-P3 01D-Q3 01D-R3	J2 J3 J4 J5	3	J2
76(12) 77(13) 78(14) 79(15)	152/153 154/155 156/157 158/159				5	5	01D-N4 01D-P4 01D-Q4 01D-R4	K2 K3 K4 K5	4	K2
80(16) 81(17) 82(18) 83(19)	160/161 162/163 164/165 166/167				5	6	01D-N5 01D-P5 01D-Q5 01D-R5	M2 M3 M4 M5	5	M2
84(20) 85(21) 86(22) 87(23)	168/169 170/171 172/173 174/175				5	6	01D-N6 01D-P6 01D-Q6 01D-R6	N2 N3 N4 N5	6	N2
88(24) 89(25) 90(26) 91(27)	176/177 178/179 180/181 182/183				5	6	01D-N7 01D-P7 01D-Q7 01D-R7	P2 P3 P4 P5	7	P2
92(28) 93(29) 94(30) 95(31)	184/185 186/187 188/189 190/191				5	6	01D-N8 01D-P8 01D-Q8 01D-R8	Q2 Q3 Q4 Q5	8	Q2

* The number in parentheses is the line relative address within the board.

LAB 3, Scanner and Token-Ring Adapter Board Information

LAB BOARD POSITION 3 (LAB TYPE C) - 01B-A1 - SCANNERS 5 AND TRA 6


Scanner or TRA	Line Addr	ICC	FES	CSM	CSP1	CSP2	TRM	RDV	Scanner IOC Bus Addr	RDV IOC Bus Addr
5	064-079	R2	S2	V2	U2	T2		A2	12X0/1	40X6/7
6	080,081 082,083						C2	A2	12X0/1	40X6/7

Note: Fill in the next table with the line information for your customer's installation.


LAB Position 3 Line Information

Line Address *	Line I/F Addr	NCP Line Addr	EP Line Addr	LIC Type	LAB C Scanner or TRA Number	Tailgate Position 01D	LIC/TIC Cable Position 01B-A1	TIC LIC Pos	LIC TIC 01B-A1
080	50				6	01D-N2	E2	5	E2
081	51				6	01D-P2	F2	6	F2
082	52				6	01D-Q2	G2	7	G2
083	53				6	01D-R2	H2	8	H2
64(16) 65(17) 66(18) 67(19)	128/129 130/131 132/133 134/135				5	01D-N5 01D-P5 01D-Q5 01D-R5	M2 M3 M4 M5	1	M2
68(20) 69(21) 70(22) 71(23)	136/137 138/139 140/141 142/143				5	01D-N6 01D-P6 01D-Q6 01D-R6	N2 N3 N4 N5	2	N2
72(24) 73(25) 74(26) 75(27)	144/145 146/147 148/149 150/151				5	01D-N7 01D-P7 01D-Q7 01D-R7	P2 P3 P4 P5	3	P2
76(28) 77(29) 78(30) 79(31)	152/153 154/155 156/157 158/159				5	01D-N8 01D-P8 01D-Q8 01D-R8	Q2 Q3 Q4 Q5	4	Q2

* The number in parentheses is the line relative address within the board.



TYPICAL MOUNTING FOR LAB C
In any LAB Pos. 3 to 8



LAB 4, Scanner and Token-Ring Adapter Board Information

LAB BOARD POSITION 4 - 02A-A3

Scanner 7 (LAB Type A)

Scanner	Line Addr	ICC	FES	CSM	CSP1	CSP2	RDV	Scanner IOC Bus Addr	RDV IOC Bus Addr
7	096-111 112-127	L2 R2	F2 F2	C2 C2	D2 D2	E2 E2	A2 A2	13X0/1 23X0/1	41X6/7 41X6/7

Scanners 7 and 8 (LAB Type B)

Scanner	Line Addr	ICC	FES	CSM	CSP1	CSP2	RDV	Scanner IOC Bus Addr	RDV IOC Bus Addr
7	096-111	L2	F2	C2	D2	E2	A2	13X0/1	41X6/7
8	112-127	R2	S2	V2	U2	T2	A2	21X0/1	41X6/7

Note: Fill in the next table with the line information for your customer's installation:

LAB Position 4 Line Information

Line Address *	Line I/F Addr	NCP Line Addr	EP Line Addr	LIC Type	LAB A Scanner Number	LAB B Scanner Number	Tailgate Position 01D	LIC Cable Position 02A-A3	LIC Pos	LIC Card 02A-A3
96(00) 97(01) 98(02) 99(03)	192/193 194/195 196/197 198/199				7	7	02P-N1 02P-P1 02P-Q1 02P-R1	G2 G3 G4 G5	1	G2
100(04) 101(05) 102(06) 103(07)	200/201 202/203 204/205 206/207				7	7	02P-N2 02P-P2 02P-Q2 02P-R2	H2 H3 H4 H5	2	H2
104(08) 105(09) 106(10) 107(11)	208/209 210/211 212/213 214/215				7	7	02P-N3 02P-P3 02P-Q3 02P-R3	J2 J3 J4 J5	3	J2
108(12) 109(13) 110(14) 111(15)	216/217 218/219 220/221 222/223				7	7	02P-N4 02P-P4 02P-Q4 02P-R4	K2 K3 K4 K5	4	K2
112(16) 113(17) 114(18) 115(19)	224/225 226/227 228/229 230/231				7	8	02P-N5 02P-P5 02P-Q5 02P-R5	M2 M3 M4 M5	5	M2
116(20) 117(21) 118(22) 119(23)	232/233 234/235 236/237 238/239				7	8	02P-N6 02P-P6 02P-Q6 02P-R6	N2 N3 N4 N5	6	N2
120(24) 121(25) 122(26) 123(27)	240/241 242/243 244/245 246/247				7	8	02P-N7 02P-P7 02P-Q7 02P-R7	P2 P3 P4 P5	7	P2
124(28) 125(29) 126(30) 127(31)	248/249 250/251 252/253 254/255				7	8	02P-N8 02P-P8 02P-Q8 02P-R8	Q2 Q3 Q4 Q5	8	Q2

* The number in parentheses is the line relative address within the board.

Scanner 7 and TRA 8 (LAB type C with TRA)

Scanner or TRA	Line Addr	ICC	FES	CSM	CSP1	CSP2	TRM	RDV	Scanner IOC Bus Addr	RDV IOC Bus Addr
7 8	096-111 112,113 114,115	R2	S2	V2	U2	T2	C2	A2 A2	13X0/1 21X0/1	41X6/7 41X6/7

Note: Fill in the next table with the line information for your customer's installation.

LAB Position 4 Line Information

Line Address *	Line I/F Addr	NCP Line Addr	EP Line Addr	LIC Type	LAB C Scanner or TRA Number	Tailgate Position 01D	LIC/TIC Cable Position 02A-A3	TIC LIC Pos	LIC TIC 02A-A3
112	70				8	02P-N2	E2	5	E2
113	71				8	02P-P2	F2	6	F2
114	72				8	02P-Q2	G2	7	G2
115	73				8	02P-R2	H2	8	H2
96(00) 97(01) 98(02) 99(03)	192/193 194/195 196/197 198/199				7	02P-N5 02P-P5 02P-Q5 02P-R5	M2 M3 M4 M5	1	M2
100(04) 101(05) 102(06) 103(07)	200/201 202/203 204/205 206/207				7	02P-N6 02P-P6 02P-Q6 02P-R6	N2 N3 N4 N5	2	N2
104(08) 105(09) 106(10) 107(11)	208/209 210/211 212/213 214/215				7	02P-N7 02P-P7 02P-Q7 02P-R7	P2 P3 P4 P5	3	P2
108(12) 109(13) 110(14) 111(15)	216/217 218/219 220/221 222/223				7	02P-N8 02P-P8 02P-Q8 02P-R8	Q2 Q3 Q4 Q5	4	Q2

* The number in parentheses is the line relative address within the board.

LAB 5, Scanner and Token-Ring Adapter Board Information

LAB BOARD POSITION 5 - 02A-A2

Scanner 9 (LAB Type A)

Scanner	Line Addr	ICC	FES	CSM	CSP1	CSP2	RDV	Scanner IOC Bus Addr	RDV IOC Bus Addr
9	128-143 144-159	L2 R2	F2 F2	C2 C2	D2 D2	E2 E2	A2 A2	14X9/1 24X9/1	41X8/9 41X8/9

Scanners 7 and 8 (LAB Type B)

Scanner	Line Addr	ICC	FES	CSM	CSP1	CSP2	RDV	Scanner IOC Bus Addr	RDV IOC Bus Addr
9 10	128-143 144-159	L2 R2	F2 S2	C2 V2	D2 U2	E2 T2	A2 A2	14X0/1 24X0/1	41X8/9 41X8/9

Note: Fill in the next table with the line information for your customer's installation:

LAB Position 5 Line Information

Line Address *	Line I/F Addr	NCP Line Addr	EP Line Addr	LIC Type	LAB A Scanner Number	LAB B Scanner Number	Tailgate Position 01D	LIC Cable Position 02A-A2	LIC Pos	LIC Card 02A-A2
128(00) 129(01) 130(02) 131(03)	256/257 258/259 260/261 262/263				9	9	02P-J1 02P-K1 02P-L1 02P-M1	G2 G3 G4 G5	1	G2
132(04) 133(05) 134(06) 135(07)	264/265 266/267 268/269 270/271				9	9	02P-J2 02P-K2 02P-L2 02P-M2	H2 H3 H4 H5	2	H2
136(08) 137(09) 138(10) 139(11)	272/273 274/275 276/277 278/279				9	9	02P-J3 02P-K3 02P-L3 02P-M3	J2 J3 J4 J5	3	J2
140(12) 141(13) 142(14) 143(15)	280/281 282/283 284/285 286/287				9	9	02P-J4 02P-K4 02P-L4 02P-M4	K2 K3 K4 K5	4	K2
144(16) 145(17) 146(18) 147(19)	288/289 290/291 292/293 294/295				9	10	02P-J5 02P-K5 02P-L5 02P-M5	M2 M3 M4 M5	5	M2
148(20) 149(21) 150(22) 151(23)	296/297 298/299 300/301 302/303				9	10	02P-J6 02P-K6 02P-L6 02P-M6	N2 N3 N4 N5	6	N2
152(24) 153(25) 154(26) 155(27)	304/305 306/307 308/309 310/311				9	10	02P-J7 02P-K7 02P-L7 02P-M7	P2 P3 P4 P5	7	P2
156(28) 157(29) 158(30) 159(31)	312/313 314/315 316/317 318/319				9	10	02P-J8 02P-K8 02P-L8 02P-M8	Q2 Q3 Q4 Q5	8	Q2

* The number in parentheses is the line relative address within the board.

Scanner 9 and TRA 10 (LAB type C with TRA)

Scanner or TRA	Line Addr	ICC	FES	CSM	CSP1	CSP2	TRM	RDV	Scanner IOC Bus Addr	RDV IOC Bus Addr
9 10	128-143 144,145, 146,147,	R2	S2	V2	U2	T2	C2	A2 A2	14X0/1 24X0/1	41X8/9 41X8/9

Note: Fill in the next table with the line information for your customer's installation.

LAB Position 5 Line Information

Line Address *	Line I/F Addr	NCP Line Addr	EP Line Addr	LIC Type	LAB C Scanner or TRA Number	Tailgate Position 01D	LIC/TIC Cable Position 02A-A3	TIC LIC Pos	LIC TIC 02A-A3
144	90				10	02P-J2	E2	5	E2
145	91				10	02P-K2	F2	6	F2
146	92				10	02P-L2	G2	7	G2
147	93				10	02P-M2	H2	8	H2
128(00) 129(01) 130(02) 131(03)	256/257 258/259 260/261 262/263				9	02P-J5 02P-H5 02P-L5 02P-M5	M2 M3 M4 M5	1	M2
132(04) 133(05) 134(06) 135(07)	264/265 266/267 268/269 270/271				9	02P-J6 02P-H6 02P-L6 02P-M6	N2 N3 N4 N5	2	N2
136(08) 137(09) 138(10) 139(11)	272/273 274/275 276/277 278/279				9	02P-J7 02P-H7 02P-L7 02P-M7	P2 P3 P4 P5	3	P2
140(12) 141(13) 142(14) 143(15)	280/281 282/283 284/285 286/287				9	02P-J8 02P-H8 02P-L8 02P-M8	Q2 Q3 Q4 Q5	4	Q2

* The number in parentheses is the line relative address within the board.

LAB 6, Scanner and Token-Ring Adapter Board Information

LAB BOARD POSITION 6 - 02A-A1

Scanner 11 (LAB Type B)

Scanner	Line Addr	ICC	FES	CSM	CSP1	CSP2	RDV	Scanner IOC Bus Addr	RDV IOC Bus Addr
11	160-175 176-191	L2 R2	F2 F2	C2 C2	D2 D2	E2 E2	A2 A2	15X0/1 25X0/1	41XA/B 41XA/B

Scanners 11 and 12 (LAB Type B)

Scanner	Line Addr	ICC	FES	CSM	CSP1	CSP2	RDV	Scanner IOC Bus Addr	RDV IOC Bus Addr
11 12	160-175 176-191	L2 R2	F2 S2	C2 V2	D2 U2	E2 T2	A2 A2	15X0/1 25X0/1	41XA/B 41XA/B

Note: Fill in the next table with the line information for your customer's installation:

LAB Position 6 Line Information

Line Address *	Line I/F Addr	NCP Line Addr	EP Line Addr	LIC Type	LAB A Scanner Number	LAB B Scanner Number	Tailgate Position 01D	LIC Cable Position 02A-A2	LIC Pos	LIC Card 02A-A2
160(00) 161(01) 162(02) 163(03)	320/321 322/323 324/325 326/327				11	11	02P-E1 02P-F1 02P-G1 02P-H1	G2 G3 G4 G5	1	G2
164(04) 165(05) 166(06) 167(07)	328/329 330/331 332/333 334/335				11	11	02P-E2 02P-F2 02P-G2 02P-H2	H2 H3 H4 H5	2	H2
168(08) 169(09) 170(10) 171(11)	336/337 338/339 340/341 342/343				11	11	02P-E3 02P-F3 02P-G3 02P-H3	J2 J3 J4 J5	3	J2
172(12) 173(13) 174(14) 175(15)	344/345 346/347 348/349 350/351				11	11	02P-E4 02P-F4 02P-G4 02P-H4	K2 K3 K4 K5	4	K2
176(16) 177(17) 178(18) 179(19)	342/353 354/355 356/357 358/359				11	12	02P-E5 02P-F5 02P-G5 02P-H5	M2 M3 M4 M5	5	M2
180(20) 181(21) 182(22) 183(23)	360/361 362/363 364/365 366/367				11	12	02P-E6 02P-F6 02P-G6 02P-H6	N2 N3 N4 N5	6	N2
184(24) 185(25) 186(26) 187(27)	368/369 370/371 372/373 374/375				11	12	02P-E7 02P-F7 02P-G7 02P-H7	P2 P3 P4 P5	7	P2
188(28) 189(29) 190(30) 191(31)	376/377 378/379 380/381 382/383				11	12	02P-E8 02P-F8 02P-G8 02P-H8	Q2 Q3 Q4 Q5	8	Q2

* The number in parentheses is the line relative address within the board.

Scanner 11 and TRA 12 (LAB type C with TRA)

Scanner or TRA	Line Addr	ICC	FES	CSM	CSP1	CSP2	TRM	RDV	Scanner IOC Bus Addr	RDV IOC Bus Addr
11 12	160-175 176,177, 178,179	R2	S2	V2	U2	T2	C2	A2 A2	15X0/1 25X0/1	41XA/B 41XA/B

Note: Fill in the next table with the line information for your customer's installation.

LAB Position 6 Line Information

Line Address *	Line I/F Addr	NCP Line Addr	EP Line Addr	LIC Type	LAB C Scanner or TRA Number	Tailgate Position 01D	LIC/TIC Cable Position 02A-A3	TIC LIC Pos	LIC TIC 02A-A3
176	B0				12	02P-E2	E2	5	E2
177	B1				12	02P-F2	F2	6	F2
178	B2				12	02P-G2	G2	7	G2
179	B3				12	02P-H2	H2	8	H2
160(00) 161(01) 162(02) 163(03)	320/321 322/323 324/325 326/327				11	02P-E5 02P-F5 02P-G5 02P-H5	M2 M3 M4 M5	1	M2
164(04) 165(05) 166(06) 167(07)	328/329 330/331 332/333 334/335				11	02P-E6 02P-F6 02P-G6 02P-H6	N2 N3 N4 N5	2	N2
168(08) 169(09) 170(10) 171(11)	336/337 338/339 340/341 342/343				11	02P-E7 02P-F7 02P-G7 02P-H7	P2 P3 P4 P5	3	P2
172(12) 173(13) 174(14) 175(15)	344/345 346/347 348/349 350/351				11	02P-E8 02P-F8 02P-G8 02P-H8	Q2 Q3 Q4 Q5	4	Q2

* The number in parentheses is the line relative address within the board.

LAB7, Scanner and Token-Ring Adapter Board Information

LAB BOARD POSITION 7 - 02B-A3

Scanner 13 (LAB Type A)

Scanner	Line Addr	ICC	FES	CSM	CSP1	CSP2	RDV	Scanner IOC Bus Addr	RDV IOC Bus Addr
13	192-207 208-223	L2 R2	F2 F2	C2 C2	D2 D2	E2 E2	A2 A2	16X0/1 26X0/1	41XC/D 41XC/D

Scanners 13 and 14 (LAB Type B)

Scanner	Line Addr	ICC	FES	CSM	CSP1	CSP2	RDV	Scanner IOC Bus Addr	RDV IOC Bus Addr
13 14	192-207 208-223	L2 R2	F2 S2	C2 V2	D2 U2	E2 T2	A2 A2	16X0/1 26X0/1	41XC/D 41XC/D

Note: Fill in the next table with the line information for your customer's installation:

LAB Position 7 Line Information

Line Address *	Line I/F Addr	NCP Line Addr	EP Line Addr	LIC Type	LAB A Scanner Number	LAB B Scanner Number	Tailgate Position 01D	LIC Cable Position 02A-A2	LIC Pos	LIC Card 02A-A2
192(00) 193(01) 194(02) 195(03)	384/385 386/387 388/389 390/391				13	13	02Q-N1 02Q-P1 02Q-Q1 02Q-R1	G2 G3 G4 G5	1	G2
196(04) 197(05) 198(06) 199(07)	392/393 394/395 396/397 398/399				13	13	02Q-N2 02Q-P2 02Q-Q2 02Q-R2	H2 H3 H4 H5	2	H2
200(08) 201(09) 202(10) 203(11)	400/401 402/403 404/405 406/407				13	13	02Q-N3 02Q-P3 02Q-Q3 02Q-R3	J2 J3 J4 J5	3	J2
204(12) 205(13) 206(14) 207(15)	408/409 410/411 412/413 414/415				13	13	02Q-N4 02Q-P4 02Q-Q4 02Q-R4	K2 K3 K4 K5	4	K2
208(16) 209(17) 210(18) 211(19)	416/417 418/419 420/421 422/423				13	14	02Q-N5 02Q-P5 02Q-Q5 02Q-R5	M2 M3 M4 M5	5	M2
212(20) 213(21) 214(22) 215(23)	424/425 426/427 428/429 430/431				13	14	02Q-N6 02Q-P6 02Q-Q6 02Q-R6	N2 N3 N4 N5	6	N2
216(24) 217(25) 218(26) 219(27)	432/433 434/435 436/437 438/439				13	14	02Q-N7 02Q-P7 02Q-Q7 02Q-R7	P2 P3 P4 P5	7	P2
220(28) 221(29) 222(30) 223(31)	440/441 442/443 444/445 446/447				13	14	02Q-N8 02Q-P8 02Q-Q8 02Q-R8	Q2 Q3 Q4 Q5	8	Q2

* The number in parentheses is the line relative address within the board.

Scanner 13 and TRA 14 (LAB type C with TRA)

Scanner	Line Addr	ICC	FES	CSM	CSP1	CSP2	TRM	RDV	Scanner IOC Bus Addr	RDV IOC Bus Addr
13 14	192-207 208,209, 210,211	R2	S2	V2	U2	T2	C2	A2 A2	16X0/1 26X0/1	41XC/D 41XC/D

Note: Fill in the next table with the line information for your customer's installation.

LAB Position 7 Line Information

Line Address *	Line I/F Addr	NCP Line Addr	EP Line Addr	LIC Type	LAB C Scanner or TRA Number	Tailgate Position 01D	LIC/TIC Cable Position 02A-A3	TIC LIC Pos	LIC TIC 02A-A3
208	D0				14	02Q-N2	E2	5	E2
209	D1				14	02Q-P2	F2	6	F2
210	D2				14	02Q-Q2	G2	7	G2
211	D3				14	02Q-R2	H2	8	H2
192(00) 193(01) 194(02) 195(03)	384/385 386/387 388/389 390/391				13	02Q-N5 02Q-P5 02Q-Q5 02Q-R5	M2 M3 M4 M5	1	M2
196(04) 197(05) 198(06) 199(07)	392/393 394/395 396/397 398/399				13	02Q-N6 02Q-P6 02Q-Q6 02Q-R6	N2 N3 N4 N5	2	N2
200(08) 201(09) 202(10) 203(11)	400/401 402/403 404/405 406/407				13	02Q-N7 02Q-P7 02Q-Q7 02Q-R7	P2 P3 P4 P5	3	P2
204(12) 205(13) 206(14) 207(15)	408/409 410/411 412/413 414/415				13	02Q-N8 02Q-P8 02Q-Q8 02Q-R8	Q2 Q3 Q4 Q5	4	Q2

* The number in parentheses is the line relative address within the board.

LAB 8, Scanner and Token-Ring Adapter Board Information

LAB BOARD POSITION 8 - 02B-A2

Scanner 15 (LAB Type A)

Scanner	Line Addr	ICC	FES	CSM	CSP1	CSP2	RDV	Scanner IOC Bus Addr	RDV IOC Bus Addr
15	224-239 240-255	L2 R2	F2 F2	C2 C2	D2 D2	E2 E2	A2 A2	17X0/1 27X0/1	41XE/F 41XE/F

Scanners 15 and 16 (LAB Type B)

Scanner	Line Addr	ICC	FES	CSM	CSP1	CSP2	RDV	Scanner IOC Bus Addr	RDV IOC Bus Addr
15 16	224-239 240-255	L2 R2	F2 S2	C2 V2	D2 U2	E2 T2	A2 A2	17X0/1 27X0/1	41XE/F 41XE/F

Note: Fill in the next table with the line information for your customer's installation:

LAB Position 8 Line Information

Line Address *	Line I/F Addr	NCP Line Addr	EP Line Addr	LIC Type	LAB A Scanner Number	LAB B Scanner Number	Tailgate Position 01D	LIC Cable Position 02A-A2	LIC Pos	LIC Card 02A-A2
224(00) 225(01) 226(02) 227(03)	448/449 450/451 452/453 454/455				15	15	02Q-J1 02Q-K1 02Q-L1 02Q-M1	G2 G3 G4 G5	1	G2
228(04) 229(05) 230(06) 231(07)	456/457 458/459 460/461 462/463				15	15	02Q-J2 02Q-K2 02Q-L2 02Q-M2	H2 H3 H4 H5	2	H2
232(08) 233(09) 234(10) 235(11)	464/465 466/467 468/469 470/471				15	15	02Q-J3 02Q-K3 02Q-L3 02Q-M3	J2 J3 J4 J5	3	J2
236(12) 237(13) 238(14) 239(15)	472/473 474/475 476/477 478/479				15	15	02Q-J4 02Q-K4 02Q-L4 02Q-M4	K2 K3 K4 K5	4	K2
240(16) 241(17) 242(18) 243(19)	480/481 482/483 484/485 486/487				15	16	02Q-J5 02Q-K5 02Q-L5 02Q-M5	M2 M3 M4 M5	5	M2
244(20) 245(21) 246(22) 247(23)	488/489 490/491 492/493 494/495				15	16	02Q-J6 02Q-K6 02Q-L6 02Q-M6	N2 N3 N4 N5	6	N2
248(24) 249(25) 250(26) 251(27)	496/497 498/499 500/501 502/503				15	16	02Q-J7 02Q-K7 02Q-L7 02Q-M7	P2 P3 P4 P5	7	P2
252(28) 253(29) 254(30) 255(31)	504/505 506/507 508/509 510/511				15	16	02Q-J8 02Q-K8 02Q-L8 02Q-M8	Q2 Q3 Q4 Q5	8	Q2

* The number in parentheses is the line relative address within the board.

Scanner 15 and TRA 16 (LAB type C with TRA)

Scanner or TRA	Line Addr	ICC	FES	CSM	CSP1	CSP2	TRM	RDV	Scanner IOC Bus Addr	RDV IOC Bus Addr
15 16	224-239 240,241, 242,243	R2	S2	V2	U2	T2	C2	A2 A2	17X0/1 27X0/1	41XE/F 41XE/F

Note: Fill in the next table with the line information for your customer's installation.

LAB Position 8 Line Information

Line Address *	Line I/F Addr	NCP Line Addr	EP Line Addr	LIC Type	LAB C Scanner or TRA Number	Tailgate Position 01D	LIC/TIC Cable Position 02A-A3	TIC LIC Pos	LIC TIC 02A-A3
240	F0				16	02Q-J2	E2	5	E2
241	F1				16	02Q-K2	F2	6	F2
242	F2				16	02Q-L2	G2	7	G2
243	F3				16	02Q-M2	H2	8	H2
224(00) 225(01) 226(02) 227(03)	448/449 450/451 452/453 454/455				15	02Q-J5 02Q-K5 02Q-L5 02Q-M5	M2 M3 M4 M5	1	M2
228(04) 229(05) 230(06) 231(07)	456/457 458/459 460/461 462/463				15	02Q-J6 02Q-K6 02Q-L6 02Q-M6	N2 N3 N4 N5	2	N2
232(08) 233(09) 234(10) 235(11)	464/465 466/467 468/469 470/471				15	02Q-J7 02Q-K7 02Q-L7 02Q-M7	P2 P3 P4 P5	3	P2
236(12) 237(13) 238(14) 239(15)	472/473 474/475 476/477 478/479				15	02Q-J8 02Q-K8 02Q-L8 02Q-M8	Q2 Q3 Q4 Q5	4	Q2

* The number in parentheses is the line relative address within the board.

Communication Interfaces: LICs

Access to the external telecommunications environment is via the following interfaces:


1. Analog transmission to remote DTEs:
 - CCITT V.24 LIC type 1 (to stand-alone DCEs)
 - CCITT V.25 LIC type 1 (to autocal units)
 - CCITT V.35 LIC type 3 (to stand-alone DCEs)
 - Bell 303 LIC type 2 (to Bell Data Station Type 303)
 - CCITT X.21 LIC type 4A and LIC type 4B (to stand-alone DCEs)
2. Digital transmission to local DTEs:
 - V.24 low-speed direct-attachment LIC type 1 (to local low-speed IBM terminals)
 - V.24 medium-speed direct-attachment LIC type 1 (to local medium-speed terminals)
 - V.35 high-speed direct-attachment LIC type 3 (to local high-speed terminals)
 - X.21 direct-attachment LIC type 4A and LIC type 4B (to X.21 local terminals)

SIGNAL NAME ABBREVIATIONS

AC	Abandon call
AGC	Automatic gain control
C	Control
CI	Calling indicator
CR	Call request
CTS	Clear to send
DCRLSD	Data channel receive line signal detector
DLO	Data line occupied
DP	Digit present
DSC	Distant station connected
DSR	Data set ready
DSRS	Data signaling rate selector
DS0	Digit signal 2 to power 0
DS1	Digit signal 2 to power 1
DS2	Digit signal 2 to power 2
DS3	Digit signal 2 to power 3
DTR	Data terminal ready
I	Indication
LLB	Local loop back
LT	Local test
NS	New sync
PI	Power indication
PND	Present next digit
R	Receive
RD	Received data
RI	Ring indicator
RFS	Ready for sending
RSET	Receive signal element timing
RTS	Request to send
SCR	Serial clock receive
SCT	Serial clock transmit
SD	Send data
SET	Signal element timing
SG	Signal ground
T	Transmit
TD	Transmitted data
TI	Test indicator
TSET	Transmitter signal element timing
WB	Wrap back

Note: The following correspondences exist:

Data channel receive line signal detector	= Carrier detector
Ready for sending	= Clear to send
Receiver signal element timing	= Receive clock
Transmitter signal element timing	= Transmit clock
Ring indicator	= Calling indicator
Abandon call	= Abandon call and retry





Note: Use the circled numbers as connector identifications in the following pages.

Communication Interfaces : TICs

The access to the Ring Interface is via the attachment cable.

Signal name	Color	Pin Connector (socket Side)
+ Ring out A	Black	Pos 16
+ Ring out B	Orange	Pos 15
+ Ring in A	Green	Pos 1
+ Ring in B	Red	Pos 2



Note: Cable checking procedure: By removing the TIC card connector the wire continuity may be checked between connector pin position 16 and 1, and pin position 15 and 2.

RING INTERFACE ELECTRICAL CHARACTERISTICS


Ring Receiver

Minimum input signal: 50 millivolts peak-to-peak.

Ring Transmitter


Output signal: between 3.0 and 4.5 Volts peak-to-peak.
Output load: 150 Ohms ± 10%

In the case where the ring is made of a telephone twisted pair a "Data Grade Media to Type 3 Media Filter" must be inserted between the end of the telephone twisted pair and the 3725/3726.



Data Grade Media to Type 3 Media Filter

LIC Type 1 DCE Interface (Except Japan NTT) (Part 1 of 2)



- Notes:**
1. Japan NTT: See page 4-150
 2. UK : See below for adapter cable.
 3. Belgium: See below for adapter cable.

CABLE TO DCE


Feature Code	No of Lines	Coming From:	Cable Group	Key No.	Cable P/N	Length, m (ft) Standard or Regular	Maximum
4911 (LIC1)	Up to 4	V.24 DCE (except Japan NTT, UK, and Belgium)	1404	1404	6081088	13.5 (45)	
					6089075	13.5 (45)	
			0691	0691	1736733	10.6 (35)	35 (115) see Note
					6089075	10.6 (35)	10.6 (35)
4911 (LIC1)	Up to 4	V.24 DCE United Kingdom only	0092	0092A 0092B*	6081088	13.5 (45)	
					1743584		
					1736733	13.5 (45)	35 (115) see Note
					6089075	13.5 (45)	13.5 (45)
					1743584		
4911 (LIC1)	Up to 4	V.24 DCE Belgium only	0096	0096A 0096B*	6081088	13.5 (45)	
					1489985		
					6089075	13.5 (45)	13.5 (45)
					1736733	13.5 (45)	35 (115) see Note
					1489985		

* = Adapter cable

Note: When the DCE is an IBM 3863, 3864, or 3865 Modem, the maximum length is 100 m (328 ft). If the suffix level of the modem (two alphabetic characters on the date tag) is FG or later for the US and America/Far East, or KF or later for Europe/Middle East/Africa. For earlier suffix level modems, if data multiplexer feature 3260 is not installed, the modem must have EC 344120 installed. If data multiplexer feature 3260 is installed, the modem must have EC 323406 installed.


WRAP BLOCK (PART 1733977)

Install in (2) (ports 1, 2, 3, and 4).




ADAPTER CABLES

UK



* These wires are not present in the adapter cable because the UK DCEs do not use these signals.

Belgium




Pins not used on 3725/26: 1

LIC Type 1 DCE Interface (Except Japan NTT) (Part 2 of 2)

INTERCHANGE CIRCUITS

For physical layout, see page 4-130.



Legend:


->- Driver
-<- Receiver

CABLE ID SIGNALS


The cable ID signals 0-2 indicate the cable attachment type to the scanner. They correspond to bits 3-5 of register 10 in the LIC. For a DCE attachment, 'cable ID0' is connected to ground; 'cable ID1' and 'cable ID2' are not connected.

VOLTAGE LEVELS

1. Install the wrap block in (2).
2. Measure voltages at (3) between signals and ground (they should be in shaded areas).
3. These voltage measurements apply only to the configuration with the wrap block installed. They are used to verify the correct operation of the 3725 circuitry. Measurements with other configurations may be different.



LIC Type 1 DCE Interface (Japan NTT Only) (Part 1 of 2)




CABLE TO DCE

Feature Code	No of Lines	Coming From:	Cable Group	Key No.	Cable P/N	Length, m (ft) Standard or Regular	Maximum see Note
4911 (LIC1)	Up to 4	V.24 DCE (Japan NTT only)	0081	0081	2667349	13.5 (45)	35 (115)
					6089076	13.5 (45)	13.5 (45)

Note: When the DCE is an IBM 3863, 3864, or 3865 Modem, the maximum length is 100 m (328 ft). If the suffix level of the modem (two alphabetic characters on the date tag) is FG or later for the US and America/Far East, or KF or later for Europe/Middle East/Africa. For earlier suffix level modems, if data multiplexer feature 3260 is not installed, the modem must have EC 344120 installed. If data multiplexer feature 3260 is installed, the modem must have EC 323406 installed.


WRAP BLOCK (PART 1733977)

Install in (2) (ports 1, 2, 3, or 4).




ADAPTER CABLE (PART 1743583)

(Used at (1) if connector hood is too large to fit DCE socket.)



TEST SWITCH LOGICAL FUNCTION


(Used at (1)).



LIC Type 1 DCE Interface (Japan NTT Only) (Part 2 of 2)

INTERCHANGE CIRCUITS

For physical layout, see page 4-130.



Legend:


->- Driver
-<- Receiver

Note: This connector is equipped with a test/operate switch. The figure on the right gives the details of this switch (shown in "Operate" position).

CABLE ID SIGNALS


The cable ID signals 0-2 indicate the cable attachment type to the scanner. They correspond to bits 3-5 of register 10 in the LIC. For a DCE attachment, 'cable ID0' is connected to ground; 'cable ID1' and 'cable ID2' are not connected.

TEST/OPERATE SWITCH




VOLTAGE LEVELS

1. Install the wrap block in (2).
2. Measure voltages at (3) between signals and ground (they should be in shaded areas).
3. These voltage measurements apply only to the configuration with the wrap block installed. They are used to verify the correct operation of the 3725 circuitry. Measurements with other configurations may be different.



LIC Type 1 Auto Call Unit Interface (Part 1 of 2)




Note: For UK adapter cable, see below.

CABLE TO ACU

Feature Code	No of Lines	Coming From:	Cable Group	Key No.	Cable P/N	Length, m (ft) Standard or Regular	Maximum
4911 (LIC1)	Up to 4	V.25 autocal unit (except Japan, UK, and French Caducee)	0082 and/or 0682	0082 and/or 0682	1733747	13.5 (45)	35 (115)
					6089077	13.5 (45)	13.5 (45)
					6089077		13.5 (45)
4911 (LIC1)	Up to 4	V.25 autocal unit (Japan)	0093	0093	2667696	13.5 (45)	35 (115)
					6089078	13.5 (45)	13.5 (45)
4911 (LIC1)	Up to 4	V.25 autocal unit (United Kingdom)	0094	0094A 0094B*	1733747	13.5 (45)	35 (115)
					674570		
4911 (LIC1)	Up to 4	V.25 autocal unit (French Caducee)	0083	0083	1733914	13.5 (45)	35 (115)
					6406254	13.5 (45)	13.5 (45)


* = Adapter cable

ADAPTER CABLE (UK)



WRAP BLOCK (PART 1733977)


Install in (2) (ports 1, 2, 3, or 4).



THREAD WRAP BLOCK (PART 147440, JAPAN ONLY)

Install in (1).

ISO 2110
25 pins




Cable ID 1 = gnd for autocal
 DS 0 : 2 power 0 = 1
 DS 1 : 2 power 1 = 2
 DS 2 : 2 power 2 = 4
 DS 3 : 2 power 3 = 8

LIC Type 1 Auto Call Unit Interface (Part 2 of 2)

INTERCHANGE CIRCUITS

For physical layout, see page 4-130.



* Japan only (for maintenance purposes)

Legend:


->- Driver
-<- Receiver

CABLE ID SIGNALS


The cable ID signals 0-2 indicate the cable attachment type to the scanner. They correspond to bits 3-5 of register 10 in the LIC. For a DCE attachment, 'cable ID0' is connected to ground; 'cable ID1' and 'cable ID2' are not connected.

VOLTAGE LEVELS

1. Install the wrap block in (2).
2. Measure voltages at (3) between signals and ground (they should be in shaded areas).
3. These voltage measurements apply only to the configuration with the wrap block installed. They are used to verify the correct operation of the 3725 circuitry. Measurements with other configurations may be different.




LIC Type 1 Direct Attachment to Terminal (Part 1 of 2)



WRAP BLOCK (PART 1733977)

Install in (2) (ports 1, 2, 3, or 4).



CABLE TO TERMINAL


Feature Code	No of Lines	Coming From:	Cable Group	Key No.	Cable P/N	Length, m (ft)	Standard	Maximum
4911 (LIC1)	Up to 4	V.24 direct attachment (except 3101 and Teletype)	1400 or 0690	1400 or 0690	1733746	13.5 (45)		See note
4911 (LIC1)	Up to 4	V.24 direct attachment (3101 and Teletype)	0085 or 0683	0085 or 0683	2667351	13.5 (45)		See note

Note: A maximum length of 35 m (115 ft) meets the CCITT specifications, however, if the terminal is a 3725, it operates correctly at distances up to 150 m (492 ft).

LIC Type 1 Direct Attachment to Terminal (Part 2 of 2)

INTERCHANGE CIRCUITS

For physical layout, see page 4-130.



* 3725 provides TR (transmit) and RCV (receive) clocks to the terminal.

Legend:


->- Driver
-<- Receiver

CABLE ID SIGNALS


The cable ID signals 0-2 indicate the cable attachment type to the scanner. They correspond to bits 3-5 of register 10 in the LIC. For a DCE attachment, 'cable ID0' is connected to ground; 'cable ID1' and 'cable ID2' are not connected.

VOLTAGE LEVELS

1. Install the wrap block in (2).
2. Measure voltages at (3) between signals and ground (they must be within shaded areas).
3. These voltage measurements apply only to the configuration with the wrap block installed. They are used to verify the correct operation of the 3725 circuitry. Measurements with other configurations may be different.




LIC Type 2 DCE Interface (Part 1 of 2)



WRAP BLOCK (PART 1733977)

Install in (2) (port 1 only).




CABLE TO DCE

Feature Code	No of Lines	Coming From:	Cable Group	Key No.	Cable P/N	Length, m (ft)	
						Standard	Maximum
4921 (LIC2)	1	Wide-band DCE	0086	0086	2667779	13.5 (45)	
			0684	0684	1733817	10.6 (35)	13.5 (45)

LIC Type 2 DCE Interface (Part 2 of 2)

INTERCHANGE CIRCUITS

For physical layout, see page 4-130.



Legend:

→ Driver
← Receiver


CABLE ID SIGNALS

The cable ID signals 0-2 indicate the cable attachment type to the scanner. They correspond to bits 3-5 of register 10 in the LIC. For a DCE attachment, 'cable ID0' is connected to ground; 'cable ID1' and 'cable ID2' are not connected.


VOLTAGE LEVELS

1. Install the wrap block in (2).
2. Measure voltages at (3) between signals and ground (they should be in shaded areas).
3. These voltage measurements apply only to the configuration with the wrap block installed. They are used to verify the correct operation of the 3725 circuitry. Measurements with other configurations may be different.


Data Terminal Ready and Ring Indicator Leads



Other Circuits



LIC Type 3 DCE Interface (Part 1 of 2)



Note: For French adapter cable, see below.

CABLE TO DCE


Feature Code	No of Lines	Coming From:	Cable Group	Key No.	Cable P/N	Length, m (ft) Standard Maximum
4931 (LIC3)	1	V.35 DCE (except French PTT modems)	0087 0685	0087 0685	6081094 1733820	13.5 (45) 35 (115) See note
4931 (LIC3)	1	V.35 DCE (French PTT modems)	0095	0095A 0095B*	6081094 1749352 1733820 1749352	13.5 (45) 35 (115) See note

* = Adapter cable

Note: For speeds greater or equal to 64 000 bps, the maximum cable length is 13.5 m (45 ft).


ADAPTER CABLE (FRANCE)

At (1).



WRAP CABLE (PART 1733979)

Install in (2) (sockets 1 and 2, reversible).



8 = Twisted pair

This CE wrap cable is plugged between socket 1 and socket 2. Socket plugging is reversible. In order to fully test the LIC3 card, it is necessary to reverse the LIC3 wrap cable after a first test pass, then run the test again.

* Clocks are generated by socket 2 and received by socket 1. Other signals are identical in socket 1 and socket 2.

** Note that B12" and B13", D05" and D06" are respectively inverted in the wrap cable.

Pins B05, B06, and D02 are connected together after wrap cable installation.

Note: To run QA or QB diagnostics on LIC 3 with the wrap cable installed, manually enter CDF configuration as shown:

```

C I
Port 1 2 2
Port 2 0 2
    
```

At the end of diagnostics, when the test is finished, restore the CDF to normal configuration as shown:


```

C I
Port 1 2 2
Port 2 0 0
    
```

LIC Type 3 DCE Interface (Part 2 of 2)

INTERCHANGE CIRCUITS

For physical layout, see page 4-130.



Legend:


- 8- Twisted pairs
- == Shielded wire
- > Driver
- < Receiver

CABLE ID SIGNALS


The cable ID signals 0-2 indicate the cable attachment type to the scanner. They correspond to bits 3-5 of register 10 in the LIC. For a DCE attachment, 'cable ID0' is connected to ground; 'cable ID1' and 'cable ID2' are not connected.

VOLTAGE LEVELS

1. Install the wrap block in (2).
2. Measure voltages at (3) (they should be in shaded areas)
 - a. Balanced circuits: Between wire A and wire B of the given signal for:
 - ± Transmitted data
 - ± Received data
 - ± Receiver signal element timing
 - ± Transmitter signal element timing




- b. Unbalanced circuits: Between signals and ground for other circuits




3. These voltage measurements apply only to the configuration with the wrap block installed. They are used to verify the correct operation of the 3725 circuitry. Measurements with other configurations may be different.

LIC Type 3 Direct Attachment to Terminal (Part 1 of 2)



WRAP CABLE (PART 1733979)

Install in (2) (sockets 1 and 2).



CABLE TO TERMINAL

Feature Code	No of Lines	Coming From:	Cable Group	Key No.	Cable P/N	Length, m (ft) Standard Maximum
4931 (LIC3)	1	V.35 direct attachment	0088 0686	0088 0686	1733822 1733822	30 (100) 150(492) 13.5 (45) See note

Note:
For speeds greater or equal to 64 000 bps, the maximum cable length is 13.5 m (45 ft).

-8- = Twisted pair

This CE wrap cable is plugged between socket 1 and socket 2. Socket plugging is reversible. In order to fully test the LIC3 card, it is necessary to reverse the LIC3 wrap cable after a first test pass, then run the test again.

* Clocks are generated by socket 2 and received by socket 1. Other signals are identical in socket 1 and socket 2.

** Note that B12" and B13", D05" and D06" are respectively inverted in the wrap cable.

Pins B05, B06, and D02 are connected together after wrap cable installation.

Note: To run QA or QB diagnostics on LIC 3 with wrap cable installed, manually enter CDF configuration as shown:

```

C I
Port 1 2 2
Port 2 0 2
    
```

At the end of diagnostics, when the test is finished, restore the CDF to normal configuration as shown:


```

C I
Port 1 2 2
Port 2 0 0
    
```


LIC Type 3 Direct Attachment to Terminal (Part 2 of 2)

INTERCHANGE CIRCUITS

For physical layout, see page 4-130.



Legend:


- 8- Twisted pair
- == Shielded wire
- > Driver
- < Receiver

CABLE ID SIGNALS


The cable ID signals 0-2 indicate the cable attachment type to the scanner. They correspond to bits 3-5 of register 10 in the LIC. For a DCE attachment, 'cable ID0' is connected to ground; 'cable ID1' and 'cable ID2' are not connected.

VOLTAGE LEVELS

1. Install the wrap block in (2)
2. Measure voltages at (3) (they should be in shaded areas)
 - a. Balanced circuits: Between wire A and wire B of the given signal for:
 - ± Transmitted data
 - ± Received data
 - ± Receiver signal element timing
 - ± Transmitter signal element timing




- b. Unbalanced circuits: Between signals and ground for other circuits.




3. These voltage measurements apply only to the configuration with the wrap block installed. They are used to verify the correct operation of the 3725 circuitry. Measurements with other configurations may be different.

LIC Type 4A DCE Interface (Part 1 of 2)



WRAP BLOCK (PART 1733977)

Install in (2) (ports 1, 2, 3, or 4).




CABLE TO DCE

Feature Code	No of Lines	Coming From:	Cable Group	Key No.	Cable P/N	Length, m (ft)	Standard	Maximum
4941 (LIC4A)	Up to 4	X.21 DCE	0089 0687	0089 0687	6081096 1733825	13.5 (45)	13.5 (45)	150(492)

LIC Type 4A DCE Interface (Part 2 of 2)

INTERCHANGE CIRCUITS

For physical layout, see page 4-130.



Legend:


- 8- Twisted pair
- >- Driver
- <- Receiver

CABLE ID SIGNALS


The cable ID signals 0-2 indicate the cable attachment type to the scanner. They correspond to bits 3-5 of register 10 in the LIC. For a DCE attachment, 'cable ID0' is connected to ground; 'cable ID1' and 'cable ID2' are not connected.

VOLTAGE LEVELS

1. Install the wrap block in (2).
2. Measure voltages at (3) between plus and minus wires of a given signal (they should be in shaded areas).
3. These voltage measurements apply only to the configuration with the wrap block installed. They are used to verify the correct operation of the 3725 circuitry. Measurements with other configurations may be different.



LIC Type 4A Direct Attachment to Terminal (Part 1 of 2)



WRAP BLOCK (PART 1733977)

Install in (2) (ports 1, 2, 3, or 4).

CABLE TO TERMINAL


Feature Code	No of Lines	Coming From:	Cable Group	Key No.	Cable P/N	Length, m (ft) Standard Maximum
4941 (LIC4A)	Up to 4	X.21 direct attachment	0091 0688	0091 0688	6081097 2667352	30 (100) 30 (100) See note

Note:
The maximum distance to meet the CCITT specifications is:

Up to 56 000 bps 150 m (492 ft)
Above 56 000 bps 60 m (197 ft)

However, if the terminal is a 3725, it operates correctly:


Up to 19 200 bps 600 m (1969 ft)
Above 19 200 bps 300 m (984 ft)



LIC Type 4A Direct Attachment to Terminal (Part 2 of 2)

INTERCHANGE CIRCUITS

For physical layout, see page 4-130.



Legend:


- 8- Twisted pair
- >- Driver
- <- Receiver

CABLE ID SIGNALS


The cable ID signals 0-2 indicate the cable attachment type to the scanner. They correspond to bits 3-5 of register 10 in the LIC. For a DCE attachment, 'cable ID0' is connected to ground; 'cable ID1' and 'cable ID2' are not connected.

VOLTAGE LEVELS

1. Install the wrap block in (2).
2. Measure voltages at (3) between plus and minus wires of a given signal (they should be in shaded areas).
3. These voltage measurements apply only to the configuration with the wrap block installed. They are used to verify the correct operation of the 3725 circuitry. Measurements with other configurations may be different.



LIC Type 4B DCE interface (Except France) (Part 1 of 2)




CABLE TO DCE

Feature Code	No of Lines	Coming From:	Cable Group	Key No.	Cable P/N	Length, m (ft)	Standard	Maximum
4942 (LIC4B)	1	X.21 DCE	0089 0687	0089 0687	6081096 1733825	13.5 (45)	13.5 (45)	See note

Note: The maximum length is:
 150 m (492 ft) up to 56 kbps
 60 m (197 ft) up to 128 kbps
 30 m (98 ft) up to 256 kbps

WRAP BLOCK (PART 1733977)


Install in (2) (port 1 only).



LIC Type 4B DCE Interface (Except France) (Part 2 of 2)

INTERCHANGE CIRCUITS

For physical layout, see page 4-130.




Legend:
 -8- Twisted pair
 ->- Driver
 -<- Receiver

CABLE ID SIGNALS


The cable ID signals 0-2 indicate the cable attachment type to the scanner. They correspond to bits 3-5 of register 10 in the LIC. For a DCE attachment, 'cable ID0' is connected to ground; 'cable ID1' and 'cable ID2' are not connected.

VOLTAGE LEVELS

1. Install the wrap block in (2).
2. Measure voltages at (3) between plus and minus wires of a given signal (they should be in shaded areas).
3. These voltage measurements apply only to the configuration with the wrap block installed. They are used to verify the correct operation of the 3725 circuitry. Measurements with other configurations may be different.




LIC Type 4B DCE Interface (France Only-Transmix) (Part 1 of 2)



WRAP BLOCK (PART 1733977)

Install in (2) (port 1 only).



CABLE TO DCE

Feature Code	No of Lines	Coming From:	Cable Group	Key No.	Cable P/N	Length, m (ft)	Standard	Maximum
4942 (LIC4B)	1	X.21 DCE	0155	0155	4712548	13.5 (45)		See note
	1		0155	0155	2667777	30 (100)		


Note: The maximum length is:

- 150 m (492 ft) up to 56 kbps
- 60 m (197 ft) up to 128 kbps
- 30 m (98 ft) up to 256 kbps

LIC Type 4B DCE Interface (France Only-Transmix) (Part 2 of 2)

INTERCHANGE CIRCUITS

For physical layout, see page 4-130.



Legend:


- 8- Twisted pair
- >- Driver
- <- Receiver

CABLE ID SIGNALS


The cable ID signals 0-2 indicate the cable attachment type to the scanner. They correspond to bits 3-5 of register 10 in the LIC. For a DCE attachment, 'cable ID0' is connected to ground; 'cable ID1' and 'cable ID2' are not connected.

VOLTAGE LEVELS

1. Install the wrap block in (2).
2. Measure voltages at (3) between plus and minus wires of a given signal (they should be in shaded areas).
3. These voltage measurements apply only to the configuration with the wrap block installed. They are used to verify the correct operation of the 3725 circuitry. Measurements with other configurations may be different.




LIC Type 4B Direct Attachment to Terminal (Part 1 of 2)



WRAP BLOCK (PART 1733977)

Install in (2) (port 1 only).



CABLE TO TERMINAL

Feature Code	No of Lines	Coming From:	Cable Group	Key No.	Cable P/N	Length, m (ft)	
4942 (LIC4B)	1	X.21 direct attachment	0091 0688	0091 0688	6081097 2667352	30 (100)	See note

Note:
The maximum distance to meet the CCITT specifications is:

Up to 56 000 bps 150 m (492 ft)
Above 56 000 bps 60 m (197 ft)


However, if the terminal is a 3725, it operates correctly:

Up to 19 200 bps 600 m (1969 ft)
Above 19 200 bps 300 m (984 ft)

LIC Type 4B Direct Attachment to Terminal (Part 2 of 2)

INTERCHANGE CIRCUITS

For physical layout, see page 4-130.



Legend:


- 8- Twisted pair
- >- Driver
- <- Receiver

CABLE ID SIGNALS

The cable ID signals 0-2 indicate the cable attachment type to the scanner. They correspond to bits 3-5 of register 10 in the LIC. For a DCE attachment, 'cable ID0' is connected to ground; 'cable ID1' and 'cable ID2' are not connected.

VOLTAGE LEVELS

1. Install the wrap block in (2).
2. Measure voltages at (3) between plus and minus wires of a given circuit (they should be in shaded areas).
3. These voltage measurements apply only to the configuration with the wrap block installed. They are used to verify the correct operation of the 3725 circuitry. Measurements with other configurations may be different.



Jumpers

All machine configurations require jumpers for proper machine operation. In the text that follows, the word 'jumper' can define a card, a switch, a connecting block, or the usual jumper wire. The table (right) lists all jumpers in the communication controller and expansion. They are installed on:

- The pin side of boards
- The component side of cards
- The IOC bus cable end
- The power supplies
- The CADR cable end

For up-to-date jumper plugging information and part numbers, refer to the YZ pages of the 3725 Volume B01, and 3726 Volume A01.

Jumper	MD Vol. B01		Function	Quantity	When to Install	Part Number
	Fr.01	Fr.02				
LAB and CLAB YB socket LIC socket	YZ161 YZ201	YZ426 YZ451	LAB and CLAB address Direct attach clock (ICC feature present)	Up to 4 jumpers per board 1 jumper per LIC	MES or board replacement (Note 1)	816645 1774335
CADR	YZ186	YZ436	Select out priority NSC address	3 jumpers per CA Up to 9 jumpers per CA	Card replacement (Note 1) Card replacement (Note 1)	2731801 2731801
CADRUK	YZ191	YZ441	Select out priority NSC address	3 jumpers per CA Up to 9 jumpers per CA	Card replacement (Note 1) Card replacement (Note 1)	2731801 2731801
CCIN	YZ206	YZ456	Lock/unlock NCP buffer Burst length control	1 jumper 2 jumpers per CA	Card replacement (Note 1) Card replacement (Note 1)	2731801 2731801
CHIN	YZ196	YZ446	ESC address range Data in/out	Up to 10 jumpers per CA 1 jumper per CA	Card replacement (Note 1) Card replacement (Note 1)	2731801 2731801
LIC type 4	YZ166	YZ431	Select type A or type B	4 jumpers per LIC	Card replacement (Note 1)	2731801
IOC bus end			Bus terminator (frame 01) Bus terminator (frame 02)	1 terminator card Up to 2 terminator cards	MES or cable replacement MES or cable replacement	6081177 6081177
Along IOC bus			Bus continuity plug	2 continuity plugs per LAB not installed	MES or cable replacement (Note 2)	1736670
Frame 01 Power board 01R-A1ZA 5 volt block	YZ156 YZ126		Frame 02 not installed LAB pos 3 not installed	1 terminator card 1 jumper	MES (Notes 2 and 3) MES (Note 3)	2667338 2667338
Frame 02 Power board 02J-A1F5 Power board 02J-A1A2 Power board 02J-A1A3 Power board 02J-A1A4 Power board 02J-A1A5 Power board 02J-A1YA Power board 02J-A1YB	YZ411		CAB not installed LAB pos 4 not installed LAB pos 5 not installed LAB pos 6 not installed LAB pos 7 not installed always present LAB pos 8 not installed	1 terminator card 1 terminator card 1 terminator card 1 terminator card 1 terminator card 1 terminator card 1 terminator card	MES (Note 3) MES (Note 3) MES (Note 3) MES (Note 3) MES (Note 3) Power board replacement (Note 3) MES (Note 3)	2667228 2667228 2667228 2667228 2667228 2667228 2667228
CADR cable end			Bus continuity	1 jumper	CADR card replacement	4712553

MOSS board DAC, MMC, MPC (YZ171-181) For jumpers and modules replacement,
see Chapter 5


Notes:

1. These jumpers are set at 3725/3726 installation time, for an MES installation, or on customer request.
2. Or for troubleshooting.
3. Or power board replacement.

Jumpers Installed on Boards

LAB, CLAB, C2LB, C2LB2, AND CAB ADDRESS JUMPERS

The CLAB and LAB address jumpers are grouped on the board pin side of the YB socket.



The CLAB1, C2LB, C2LB2, CLAB2, and CAB board addresses are set in the printed circuit of the board at the plant. No jumpers are changed in the field.

The LAB location in the machine determines its address. Address jumpers must be installed if a LAB board is added, relocated, and/or replaced.


Use the following table to determine where to plug the LAB address jumpers (part 816645).

Board	E08 to E07	D08 to D07	C08 to C07	B08 to B07
LAB pos 3 01B-A1D1		X		
LAB pos 4 02A-A3D1	X	X		X
LAB pos 5 02A-A2D1			X	X
LAB pos 6 02A-A1D1	X		X	X
LAB pos 7 02B-A3D1		X	X	X
LAB pos 8 02B-A2D1	X	X	X	X

CLOCK SELECT JUMPER

3725/3726

This jumpering provides clock signals to terminals attached to the communication controller without modems (direct-attached terminals) or modems without clocks (up to 1200 bps). On the board, ICC position 1 distributes the clock signals to LIC positions 1 through 4, and ICC position 2 distributes clock signals to LIC positions 5 through 8. All the clock speeds are expressed in hertz.



3725 Model 2

On the C2LB and C2LB2 boards, ICC position 1 distributes the clock signals to LIC positions 1 through 4, and ICC position 2 distributes clock signals to LIC positions 5 and 6. All the clock speeds are expressed in hertz. LAB-3 board, has the same clock signal distribution than that of the 3725/3726.

BOARD C2LB

Board Location: 01A-A3
 Card Part Numbers: See the ZZ pages
 Card Location

Speed Selection

To locate a LIC card on a board, refer to page 4-061.

As supplied from the plant, LIC jumpers connect U07 to S09 and select the 9600-Hz clock for all LIC cards attached to the ICC cards. Change the jumpering only if a different speed in the range of the following table is required. If any of the four LIC cards attached to the ICC does not require a direct-attached line speed, the jumpers are overridden by the 3725 software. Nevertheless, these jumpers must remain installed for 9600 Hz to prevent diagnostic errors.

When the ICC card is not present, the diagnostic and wrap tests use the 480-Hz clock signal coming through the RDV card. This signal is connected to the LIC cards pin G04 with a printed circuit net (no jumpers required). This 480-Hz signal can be scoped on pin U04 of each LIC card (see page 5-053).

ICC Local Clock	ICC Clock Bus on LIC Card	LIC Input Clock Pin	Line Speed
2400 Hz	U06	S09	2400 bps
4800 Hz	U09	S09	4800 bps
9600 Hz*	U07*	S09*	9600 bps*
19200 Hz	S07	S09	19200 bps
56000 Hz	S13	S09	56000 bps
245760 Hz	M12	S09	245760 bps

* This is the factory setting.

Notes: At generation time the selected lines must be defined as "local attached. This jumper should not exceed a length of 42 mm (1 5/8 in.) to avoid electromagnetic radiation.

To select a clock for the lines attached to a LIC, plug a jumper from the ICC clock bus pin on the LIC card to the corresponding LIC input clock pin.


Jumpers Installed on Cards (Part 1 of 4)

For jumpers and modules required on DAC, MMC, TIC, and MPC cards, refer to Chapter 5.

SELECT OUT PRIORITY JUMPERS (ON CADR)

Control units attached to a host channel have high or low selection priority according to their sequential positions on the channel interface, and their jumpering. On the communication controller the select out priority jumpers are located on the CADR cards (see table below for CADR card locations).





Warning: Do not pull out a CADR card, even if the communication controller is powered off, unless you are sure that the host system is not using the channel interface attached to the CADR. If the host system is using the channel interface, refer to the CADR replacement procedure in Chapter 5 before pulling out the CADR card.



CA Card Location

CA and TPS	CA I/F	Board Address	CADR	CHIN	CCIN	CVTL	Board Name
CA pos 1	1A	01A-A3	X2	V2	U2	T2	C2LB
CA pos 2	2A		W2	S2	R2	Q2	
CA pos 3	3A	01B-A2	B2	F2	E2	D2	C2LB2
CA pos 4	4A		C2	J2	H2	G2	
CA pos 1	1A	01A-A3	X2	V2	U2	T2	CLAB1
TPS pos 1	1B		W2				
CA pos 2	2A	01B-A2	B2	F2	E2	D2	CLAB2
TPS pos 2	2B		C2				
CA pos 3	3A	02C-A1	W2	U2	T2	S2	CAB
TPS pos 3	3B		V2				
CA pos 4	4A	02C-A1	R2	P2	N2	M2	CAB
TPS pos 4	4B		Q2				
CA pos 5	5A	02C-A1	L2	K2	J2	H2	CAB
CA pos 6	6A	02C-A1	G2	F2	E2	D2	CAB

Determine with the customer the selection priority for every channel adapter in the communication controller, and plug the jumpers (part 2731801) as indicated below:



Jumpers Installed on Cards (Part 2 of 4)

NSC ADDRESS JUMPERS (ON CADR)

Channel adapter addresses are required on two separate occasions:

- At initial selection, the channel adapter must be able to recognize the address presented to it.
- At control unit initiated selection sequence (request in), the channel adapter must present a valid address to the channel before it can transfer data or status information.

Obtain from the user the NSC addresses for the channel adapters present on the machine.

The NSC address may be set to any value in the range 0 through 255. If the two-processor switch is installed on a channel, the two interfaces (A and B) are assigned separately, and may be either the same or different NSC addresses.

The ESC addresses are located on the CHIN card. Refer to page 4-280 for CHIN card locations and page 4-282 for plugging.

The NSC address jumpers are located on the CADR cards.



Refer to page 4-280 for CADR card locations.

Notes:

1. If emulation is not required, ESC address jumpers must be plugged to low = X'C0' and high = X'53'.
2. The address assigned for the NSC may be one of the addresses in the range of addresses assigned to the ESC. In this case, however, the NSC address cannot be used for the ESC.

Warning: Do not pull out a CADR card, even if the communication controller is powered off, unless you are sure that the host system is not using this channel interface. If the host system is using the channel interface, refer to the CADR replacement procedure in Chapter 5 before pulling out the CADR card.

Set the NSC address jumpers (part 2731801) as follows. A jumper in place forces the corresponding NSC address bit value to 1. After the address bit jumpers have been set, place a jumper on the P position to have an odd total number of jumpers.



Examples

Address Bit	0	1	2	3	4	5	6	7	P
A3	1	0	1	0	0	0	1	1	1
0E	0	0	0	0	1	1	1	0	0


Note: Insert jumper for 1, remove it for 0.

LIC TYPE 4A, 4B JUMPERS

To change from LIC 4A to LIC 4B or conversely, move jumpers as shown below (jumper part 2731801).

Notes:

1. LIC type 4A is for speeds up to 9600 bps. The card is not wide-band and provides four ports.
2. LIC type 4B is for speeds above 9600 bps. The card is wide-band and provides one port only.



FOR CARD P/N 8610093 (OLD)

LIC Type	Jumper Positions							
	1-2	2-3	4-5	4-10	6-7	6-11	8-9	8-12
4A	X		X		X		X	
4B		X		X		X		X

FOR CARD P/N 8610994 (NEW)


LIC Type	Jumper Positions							
	1-2	2-3	4-5	4-10	6-7	6-11	8-9	8-12
4A	X		NA		NA		NA	
4B		X		NA		NA		NA

Jumpers Installed on Cards (Part 3 of 4)


ESC ADDRESS RANGE JUMPERS (ON CHIN)

The ESC device addresses must form a group of consecutive addresses. The lowest address in the group may be set to 0, or to any multiple of 16 from 16 to 240. The highest address in the group may be set to one of the values 4n-1, where n is any number from 1 through 64, that is, from 3 to 255 by steps of 4.

For example:



The plugging of the corresponding low and high addresses for the above example (address range X'30' through X'F3') is as follows:



If the two-processor switch is installed, only NSC addresses are used, either in native or in partitioned mode.


Obtain from the user the ESC address range for the channel adapters present on the machine.

The ESC address range jumpers are located on the CHIN cards. A jumper in place forces the ESC address bit value 1.

Refer to page 4-280 for CHIN card locations.

Set the ESC address range jumpers (part 2731801) as follows:

Note: In NCP mode only, ESC address jumpers must be plugged to low = X'C0' and high = X'53'.



ESC Low Address Jumpers

Low Channel Address	Pin on CHIN Card				
	Hex	Dec	1-2	3-4	5-6
00	00	—	—	—	—
10	16	—	—	—	Jumper
20	32	—	—	Jumper	—
30	48	—	—	Jumper	Jumper
40	64	—	Jumper	—	—
50	80	—	Jumper	—	Jumper
60	96	—	Jumper	Jumper	—
70	112	—	Jumper	Jumper	Jumper
80	128	Jumper	—	—	—
90	144	Jumper	—	—	Jumper
A0	160	Jumper	—	Jumper	—
B0	176	Jumper	—	Jumper	Jumper
C0	192	Jumper	Jumper	—	—
D0	208	Jumper	Jumper	—	Jumper
E0	224	Jumper	Jumper	Jumper	—
F0	240	Jumper	Jumper	Jumper	Jumper

Legend:

— : No jumper
Jumper : Part 2731801

ESC High Address Jumpers

High Channel Address	Pin on CHIN Card							
	Hex	Dec	9-10	11-12	13-14	15-16	17-18	19-20
03	3	—	—	—	—	—	—	—
07	7	—	—	—	—	—	—	Jumper
0B	11	—	—	—	—	Jumper	—	—
0F	15	—	—	—	—	Jumper	Jumper	—
13	19	—	—	—	Jumper	—	—	—
17	23	—	—	—	Jumper	—	—	Jumper
1B	27	—	—	—	Jumper	Jumper	—	—
1F	31	—	—	—	Jumper	Jumper	Jumper	—
23	35	—	—	Jumper	—	—	—	—
27	39	—	—	Jumper	—	—	—	Jumper
2B	43	—	—	Jumper	—	Jumper	—	—
2F	47	—	—	Jumper	—	Jumper	—	—
33	51	—	—	Jumper	Jumper	—	—	—
37	55	—	—	Jumper	Jumper	—	—	Jumper
3B	59	—	—	Jumper	Jumper	Jumper	—	—
3F	63	—	—	Jumper	Jumper	Jumper	Jumper	—
43	67	—	Jumper	—	—	—	—	—
47	71	—	Jumper	—	—	—	—	Jumper
4B	75	—	Jumper	—	—	Jumper	—	—
4F	79	—	Jumper	—	—	Jumper	Jumper	—
53	83	—	Jumper	—	Jumper	—	—	—
57	87	—	Jumper	—	Jumper	—	—	Jumper
5B	91	—	Jumper	—	Jumper	Jumper	—	—
5F	95	—	Jumper	—	Jumper	Jumper	Jumper	—
63	99	—	Jumper	Jumper	—	—	—	—
67	103	—	Jumper	Jumper	—	—	—	Jumper
6B	107	—	Jumper	Jumper	—	Jumper	—	—
6F	111	—	Jumper	Jumper	—	Jumper	Jumper	—
73	115	—	Jumper	Jumper	Jumper	—	—	—
77	119	—	Jumper	Jumper	Jumper	—	—	Jumper
7B	123	—	Jumper	Jumper	Jumper	Jumper	—	—
7F	127	—	Jumper	Jumper	Jumper	Jumper	Jumper	—
83	131	Jumper	—	—	—	—	—	—
87	135	Jumper	—	—	—	—	—	Jumper
8B	139	Jumper	—	—	—	Jumper	—	—
8F	143	Jumper	—	—	—	Jumper	Jumper	—
93	147	Jumper	—	—	Jumper	—	—	—
97	151	Jumper	—	—	Jumper	—	—	Jumper
9B	155	Jumper	—	—	Jumper	Jumper	—	—
9F	159	Jumper	—	—	Jumper	Jumper	Jumper	—
A3	163	Jumper	—	Jumper	—	—	—	—
A7	167	Jumper	—	Jumper	—	—	—	Jumper
AB	171	Jumper	—	Jumper	—	Jumper	—	—
AF	175	Jumper	—	Jumper	—	Jumper	Jumper	—
B3	179	Jumper	—	Jumper	Jumper	—	—	—
B7	183	Jumper	—	Jumper	Jumper	Jumper	—	Jumper
BB	187	Jumper	—	Jumper	Jumper	Jumper	Jumper	—
BF	191	Jumper	—	Jumper	Jumper	Jumper	Jumper	Jumper
C3	195	Jumper	Jumper	—	—	—	—	—
C7	203	Jumper	Jumper	—	—	—	—	Jumper
CB	207	Jumper	Jumper	—	—	Jumper	—	—
CF	211	Jumper	Jumper	—	—	Jumper	Jumper	—
D3	215	Jumper	Jumper	—	Jumper	—	—	—
D7	219	Jumper	Jumper	—	Jumper	—	—	Jumper
DB	223	Jumper	Jumper	—	Jumper	Jumper	—	—
DF	227	Jumper	Jumper	Jumper	—	—	—	—
E3	231	Jumper	Jumper	Jumper	—	—	—	Jumper
E7	235	Jumper	Jumper	Jumper	—	Jumper	—	—
EB	239	Jumper	Jumper	Jumper	—	Jumper	Jumper	—
EF	243	Jumper	Jumper	Jumper	Jumper	—	—	Jumper
F3	247	Jumper	Jumper	Jumper	Jumper	—	—	Jumper
FB	251	Jumper	Jumper	Jumper	Jumper	Jumper	—	—
FF	255	Jumper	Jumper	Jumper	Jumper	Jumper	Jumper	Jumper

Legend:
— : No jumper
Jumper : Part 2731801

Data In/Data Out Jumper (on CHIN)

Remove jumper 21 to 22 if 'Data In/Data Out' feature is available on all host channel interfaces attached to this channel adapter.

Leave this jumper installed in all other cases.

'Data In/Data Out' fully available	Pins 21-22 on CHIN card
Yes	-----
No	Jumper

Legend:

-----: No jumper
Jumper: Part 2731801

CPU Type (S/370)	Data In/Data Out Support (X)	
	Byte Channel	Block or Selector Channel
148		X
158		X
303X		X
308X	X	X
4321	X	X
4331	X	X
4341	X	X
4361	X	X
4381	X	X

1. All interconnecting interface cables must be capable of handling 'Data In/Data Out.'
2. All control units on the channel must also pass 'Data In/Data Out.'
3. Channel interface cable terminators type 370 must be used.
4. All possible alternate channel paths to the 3725 must meet the preceding conditions.

Jumpers Installed on Cards (Part 4 of 4)

BURST LENGTH (ON CCIN)

Number of Bytes in Buffer	Jumper	
	4-5	6-7
8	1	1
16	0	1
32	1	0
64	0	0

The CCIN card controls the burst mode data transfer operation for a channel adapter attached to a host byte multiplexor channel. This transfer operation is automatically overridden if the channel adapter is attached to a block multiplex or selector channel.

The CCIN card controls the length of the data burst to the host. The number of bytes that can be transferred on the byte multiplex channel without dropping the 'operational in' tag is equal to 8, 16, 32, or 64 bytes, depending upon the host system.

Notes:

1. If no devices other than 3725s or devices that cannot be overrun (for example, all buffered devices, 3705 or 3725 with NCP) are attached to the byte multiplex channel, set the byte length to 64 for EP and PEP; for NCP there is no limitation.
2. If devices that can be overrun are attached to the byte multiplex channel, set the burst length jumpers for maximum throughput, depending on the type of host, as follows:

System Type	Burst Length
S/370: 3115, 3125, 3155, 3158, 4331, 4361.	8 bytes
S/370: 4341, 4381.	16 bytes
S/370: 2870B, 3031, 3032, 3033, 308X, 3135, 3138, 3145, 3148.	32 bytes


Note: If the system type is not in the above table, set the burst length to 8.

LOCK/UNLOCK NCP BUFFERS (ON CCIN)

Jumper	1-2	2-3
NCP burst control		X
Burst length control	X	

Notes:

1. Jumper on 2-3 overrides the burst length jumper setting of positions 4 through 7, and forces the burst length to 255.
2. Jumper on 1-2 enables the burst length jumper setting of positions 4 through 7, setting the burst length to 8, 16, 32, or 64 bytes.



Jumpers on IOC Bus

IOC BUS TERMINATOR JUMPERS

The plugging position of the terminator cards (BUSTERM) depends on the boards that are installed. Check the plugging using the following tables and refer to pages 4-070, 4-090, and 4-091). IOC bus routing and location.





Plug the primary IOC bus terminator card in:	When:
01A-J1	Single-frame machine (Model 2 only)
01B-J1	Single-frame machine (Model 1 and Model 2)
02C-J1	Two-frame machine

Plug the secondary bus terminator card in:	When:
02A-J1	Gate 02A installed and gate 02B not installed
02B-J1	Gate 02B installed

The terminator card needs dc voltages. When moving BUSTERM, ensure that the new socket position on the board has its power cable plugged into J1A2. If not, move the power cable to the new BUSTERM location too. Connect the other end of the power cable to the board pin side, according to the following table:

Part 6081389 CLAB1 or C2LB CLAB2 or C2LB2	Part 1736774 CAB LAB	Volt- age	Wire Color
B2-E14 B3-E01	B3-E01 B2-E14	+5 0	Yellow Black

Warning: Interchanging of the cable types, or incorrect plugging of the voltage connector will burn the voltage land pattern on the BUSTERM card.



IOC BUS CONTINUITY PLUGS

When a board is not installed on the IOC bus, three jumper plugs (part 1736670) are required for signal continuity.

Connect these plugs in the place of the missing RDV card as shown. A continuity plug connects:


Cable position 3 : (plug present but not used)

Cable position 4 : Pin B02 to D02
Pin B03 to D03

Cable position 5 : Pin B02 to D02
Pin B03 to D03

The following signals are propagated:

- Cycle steal grant high
- Cycle steal grant low
- Allow poll response
- Select out



Power Jumpers

POWER TERMINATOR CARDS

Frame 01

Terminator cards in the power boards tie down the sense signals for features that are not present on the 3725/3726. You should not attempt to sense these features. When a power supply is added the corresponding power cable replaces the terminator card. The terminator card connects together the pins of the power board socket as indicated in the various tables. No manual jumpering is necessary on the card.


Terminator Card 01R-A1ZA (Part 2667338)

Pin	Signal	Wiring
D05	Expansion 1-Fault	-----+
B05	Expansion 2 Fault	-----
D08	Ground	-----+

For the 3725 Model 2, a terminator card is installed in position 01R-F3.

Plug the terminator card in position 01R-A1-ZA when there is no expansion frame 02.

3725: PWB1
Location: 01R-A1



Note:
PWB1 board is shown in the open position.

Frame 02

The terminator cards on the power board in frame 02 all have the same part number. The wire that is active depends on the terminal block position on the board. See the tables below:


Terminator Card 02J-A1A3, A4, YA, YB (Part 2667228)

Pin	Signal	Wiring
D05	+5 volts sense	-----+
D06	+5 volts LAB Sense	-----
D07	+5 volts undervoltage	-----+
D08	Ground	-----+

Terminator Card 02J-A1A2, A5 (Part 2667228)



Pin	Signal	Wiring
B02	+5 volts sense	-----+
B03	+5 volts LAB sense	-----
B04	+5 volts undervoltage	-----+
D02	+12 PS overcurrent	-----+
D03	+ 8.5 PS overcurrent	-----
D04	- 8.5 PS overcurrent	-----+
D05	- 5 PS overcurrent	-----
D06	+ 12 PS undervoltage	-----+
D07	+ 8.5 PS undervoltage	-----
D09	- 8.5 PS undervoltage	-----+
D10	- 5 undervoltage	-----
D08	Ground	-----+
D11	Thermal switch 2	-----+
D12	Thermal switch 2 return	-----
D13		-----+
B13		-----

3726: PWB2
Location: 02J-A1



Five-Volt Power Supply Jumpers

In frame 01, on the connector PS1 EC1, remove Jumper C5-C6 when LAB position 3 is installed.








Contents

CHAPTER 5. REPLACEMENTS, MACHINE CLOCKING, AND ADJUSTMENTS

CCU Board Replacement	5-010
Removing the CCU Board	
Replacing the CCU Board	
ESD Instructions	5-020
ESD Sensitive Parts Handling.	
ESD Precautions	
Card Module Information	
Jumper on Card	5-030
How to Remove a Jumper Pin	
Card Replacement (Part 1 of 3)	5-040
MPC Card Replacement (01A-A1T2)	
MR0S Card Replacement (01A-A1U4)	
TIC Card Replacement	
Old Style	
New Style	
DAC Card Replacement (01A-A1R2)	
Card Replacement (Part 2 of 3)	5-041
MMC Card Replacement (01A-A1S2)	
MEM Card Replacement (01A-A1B2 through N2)	
CCU Card Replacement (01A-A2)	
LIC Card Replacement	
Card Replacement (Part 3 of 3)	5-042
LIC Card Replacement (continued)	
RDV Card Replacement	
CADR Card Replacement	
CA Card Location	
CADR Card Removal	
CADR Card Plugging	
Clock Scoping (Part 1 of 5)	5-050
Limits	
Scope Point References	
Clock Scoping	
CCU Clock	
Clock Signal Relationship	
Clock Scoping (Part 2 of 5)	5-051
High-Speed Clock	
Clock Cable Routing	
Low-Speed Clock	
Scoping Procedure	
Scope Points	
Clock Scoping (Part 3 of 5)	5-052
Scope Points	
LAB A, B and C Locations	
Clock Scoping (Part 4 of 5)	5-053
Clock Scoping (Part 5 of 5)	5-054
Power Supply Adjustments	5-060
DC Voltage Adjustment	
AC Voltage Adjustment	

CCU Board Replacement



Removing the CCU Board

Using the torque screwdriver (part 4134750):

1. Unscrew slightly the eight screws that secure the plastic mask over the pins, and disconnect power cables on pin side of board.
2. Disconnect cables on card side of CCU board.
3. Unscrew the screws that retain the CCU board assembly to the controller.
4. Carefully remove the board assembly and place it on a flat surface.
5. Remove cards and dummy cards (item 8).
6. Remove capacitor assemblies (item 6).
7. Remove screws (item 5) and sideplates (item 4).
8. Remove screws (item 3) and card guides (item 2).

Replacing the CCU Board

Replace the CCU board in the reverse order.

ESD Instructions

Warning: The 3725 Communication Controller uses parts that are sensitive to electrostatic discharge (ESD). These parts are located on the following boards.

- MOSS board for MPC and MMC cards
- CCU board for DFL1-1, -2, and -3, DFL4, DFL5, CCLK, CTL1, CTL2, BTAC, and MIOC
- Channel and scanner/TRA boards for RDV, CADR, CSP1, CSP2, FES, ICC, LICs, TRM, and TICs.

Note: As only a few cards are not ESD-sensitive on the 3725 controller, it is recommended to handle all of them as if ESD-sensitive.

ESD SENSITIVE PARTS HANDLING.

ESD Precautions

The new procedures and tools for handling all ESD (Electro Static Discharge) sensitive parts are detailed in the 19-minute video tape, "When ESD Strikes", Order No. ZZ25-7319.

All persons involved in the handling and distribution of parts are required to view this video training film. Time spent on the ESD training should be recorded as service code 51, course code 40365.

A folder, consisting of questions and answers, is intended to supplement the training film (Order No. ZZ25-8157). As new information becomes available, it will appear in RETAIN TIP "ESD HANDLING", (TIP TOOL 014-TD42579).

Generally, all logic is to be considered ESD SENSITIVE and must be handled using the ESD Field ESD Kit, Part 6428316. This kit contains:

IBM Part	Description
6428166	ESD Cord
6428274	ESD Mat, safe work surface
6428275	Conductive black plastic box
6428317	Label, containing instructions (Inside lid of box)
6428318	Label, outside identification

In addition to the kit, a wrist strap is needed for personnel grounding.

Two sizes are available and must be ordered separately:

IBM Part	Description
6428167	Wrist band, small (Beige)
6428169	Wrist band, large (blue)

The small wrist band is for persons having a wrist circumference less than 16.5 cm (6 1/2 inches). The large one is for wrist circumferences over 16.5 cm (6 1/2 inches).

The instructions included with the kit must be read before using these tools. They give SAFETY considerations, which MUST BE FOLLOWED, and general practices.

ALL OTHER WRIST STRAPS ARE OBSOLETE with the new ESD Field Kit and should be discarded.

Two new ESD protective card caddies have been released:

IBM Part	Description
6428141	Conductive, soft-sided caddy (Capacity = 36 4W X 3H cards)
6317023	Conductive, soft-sided caddy (1/2 size = 18 4W X 3H cards)

Both caddies have a snap for attaching the ESD cord part 6428166 (part of the ESD field kit). This feature enables the caddy to serve as a large ESD-safe work surface.


Another feature is the strap carrying handle. It was made long enough to permit over-the-shoulder carrying. For most people, this frees up one hand to carry the tool bag on the same side. This is less tiring than carrying with the hand over longer distances.

The new soft-sided caddies are intended for logic, but in some instances may include small mechanical parts (if the caddy is stocked) to support a particular product. Large, heavy parts should not be carried in the new soft sided caddies. Present caddies will remain useful for carrying mechanical parts and other items.


CARD MODULE INFORMATION

There are four lines of text on the top side of a card module. The information provided by these lines is given in the following figure. Always read these lines starting from the plugging identifier bezel of the module.

Module top view




Module side view




Jumper on Card

HOW TO REMOVE A JUMPER PIN

1. Remove the jumper cover from the assembly.




5. When installing the jumper in its housing, ensure that it is correctly seated.



2. Remove the old jumper from the housing.
3. If a new jumper is needed, use jumper part 1809763.
4. Carefully cut off the jumper pins that are not needed.

Warning: Failure to support the jumper assembly with duck bill pliers as shown may damage the carrier strip and cause unreliable jumper operation.



Card Replacement (Part 1 of 3)

Warning: Power off the 3725 or 3726 before card replacement.


MPC CARD REPLACEMENT (01A-A1T2)

When the MPC card is replaced, the new card is received:

- Without the pluggable modules (1) and (2)
- Without the jumpers (3) and (4)
- With jumpers plugged between H and J, and G to K

The pluggable modules and jumper (3) must be removed from the old card and installed on the new. Jumper (4) is not required. Jumpers (5) and (6) must be installed as shown on the following drawing.

To remove modules use the puller part 1715889 and part 453400. Use extreme care when handling the MPC card and its modules, which are ESD-sensitive. For information on handling ESD-sensitive parts, refer to page 5-020.



Use the following table to select the proper pluggable storage module and to make the correct jumper assembly.

Module 1	Module 2	Jumper 3 Part 1809763	Jumper 4 Part 1809763	Jumper 5	Jumper 6
8K ROS MMM8	24K RAM MMM24 (See note)		Not required	Must be present	H to G

Note: For module ordering, refer to page ZZ012.

MR05 CARD REPLACEMENT (01A-A1U4)


The MR05 is used to fix temporarily a microcode error in the ROS of the MPC card.

1. Remove the MPC card from the board (01A-A1T2).
2. Unplug the MPC ROS module (1).
3. Plug the connector in place of the ROS module just removed. Ensure that the cable is leaving the card as shown.
4. Plug the MPC card on the MMB board.
5. Plug the MR05 card in location 01A-A1U4.
6. Connect the 32-pin cable connector to the MR05.

TIC CARD REPLACEMENT


OLD STYLE

When a TIC card old style is replaced, make sure that jumpers (9) are present.



NEW STYLE

When a TIC card new style is replaced, make sure that the jumper (4) is present and the rocker switches (3) are all in ON position.



The pluggable modules (1, 2) and jumper (4) must be removed from the old card and installed on the new.


Use extreme care when handling the TIC card and its modules, which are ESD-sensitive. For information on handling ESD-sensitive parts, refer to page 5-020.

Note: For module ordering, refer to page ZZ012.

DAC CARD REPLACEMENT (01A-A1R2)


When the DAC card is replaced with a new card, the new card is received without the pluggable jumpers (1) and (2).

These jumpers must be removed from the old card and installed on the new card. There must be no jumpers in positions (3) and (4).



If a new jumper must be installed, use jumper part 1809763.

Jumpers 1 and 2	Jumpers 3 and 4
	Not required



Card Replacement (Part 2 of 3)

Warning: Power off the 3725 or 3726 before card replacement.


MMC CARD REPLACEMENT (01A-A1S2)

When the MMC card is replaced with a new card, the new card is received:

- Without the pluggable modules
- Without the jumper (1)

These pluggable modules and the jumper (1), which defines a 16K or 32K module, (part 1794401) must be removed from the old card and installed on the new card.

To remove the modules, use puller part 453400. Use extreme care when handling the MMC card and its modules, which are ESD sensitive parts. For information on handling ESD-sensitive parts, refer to page 5-020.




Module 1	Jumper 1
32K RAM MMM 32	Must be present and plugged in AB (32K)

CCU CARD REPLACEMENT (01A-A2)

Also, use extreme care not to break or bend pins when replacing the CCU or MEM cards. The resulting shorts would damage several cards attached to the storage data bus.


Use the torque screwdriver (part 4134750) when plugging or unplugging a card or a connector on the CCU board. A calibrated spring inside the tool allows you to tighten the card-holding screws to the correct torque value.




LIC CARD REPLACEMENT

To unplug a LIC card:


1. Slide out the flat cables attached to the LIC top connectors.
2. Unplug the LIC card by pulling out the LIC holder.
3. Unlatch the LIC holder from the LIC card (1) and (2).



4. Rotate the LIC card.



5. Unlatch the top connector end of the LIC card by pulling the holder away from the card.



6. Separate the holder from the LIC card.

MEM CARD REPLACEMENT (01A-A1B2 THROUGH N2)

When a MEM card is replaced, or when two MEM cards are swapped, make sure that they are of the same type: depending on the EC level of the machine, 128K cards, 256K cards, or both, can be found on the MMB board.


Card Replacement (Part 3 of 3)

Warning: Power off the 3725 or 3726 before card replacement


LIC CARD REPLACEMENT (CONTINUED)

To plug a LIC card:

1. Latch the LIC top connector end by placing the LIC card as shown, and then rotating the LIC card towards the LIC holder.



2. Latch the LIC holder to the LIC card.



3. Plug the LIC card to the board by pushing on the top connector edge.
4. Slide in the flat cables attached to the LIC top connectors.

RDV CARD REPLACEMENT

Use extreme care when handling this card, which has ESD-sensitive parts. For information on handling ESD-sensitive parts, see page 5-020.

Note: Interference from a board to the IOC bus cables can be prevented by jumpering pin D11 of the RDV card to ground. This troubleshooting facility is used by the IOC diagnostics (see page 2-080). See also "Redrive State Definition" in Chapter 11.

CA Card Location

CA and TPS	CA I/F	Board Address	CADR	CHIN	CCIN	CVTL	Board Name
CA pos 1	1A	01A-A3	X2	V2	U2	T2	C2LB
CA pos 2	2A		W2	S2	R2	Q2	
CA pos 3	3A	01B-A2	B2	F2	E2	D2	C2LB2
CA pos 4	4A		C2	J2	H2	G2	
CA pos 1	1A	01A-A3	X2	V2	U2	T2	CLAB1
TPS pos 1	1B		W2				
CA pos 2	2A	01B-A2	B2	F2	E2	D2	CLAB2
TPS pos 2	2B		C2				
CA pos 3	3A	02C-A1	W2	U2	T2	S2	CAB
TPS pos 3	3B		V2				
CA pos 4	4A	02C-A1	R2	P2	N2	M2	CAB
TPS pos 4	4B		Q2				
CA pos 5	5A	02C-A1	L2	K2	J2	H2	CAB
CA pos 6	6A	02C-A1	G2	F2	E2	D2	CAB

CADR CARD REPLACEMENT

Use extreme care when handling this card, which has ESD sensitive parts. For information on handling ESD-sensitive parts, see page 5-020.


Warning: Do not pull out a CADR card, even if the communication controller is powered off, unless you are sure that the host system is not using this channel interface.

You can display the status of the channel interfaces by using the CCU FNCTN key and then selecting the subfunction number 10.

If the host system is using the channel interface, you must follow the CADR card removal procedure described on this page to ensure that the propagation of 'select in' and 'select out' signals is not broken. Use jumper block (part 4712553).

CADR CARD REMOVAL

1. Set the CA interface switch to DSBL on the control panel.
2. Plug a jumper block (part 4712553) to the eight-position connector located on the side of cable socket 4 of the selected CADR card.



3. Unplug the cable connectors from the CADR card.
4. Unplug the CADR card.

CADR CARD PLUGGING

1. Plug the CADR in place.
2. Plug back the cable connectors to the CADR card.
3. Unplug the jumper block from cable connector 4.

Clock Scoping (Part 1 of 5)

LIMITS

You may scope the following controller areas using the oscilloscopes listed in Chapter 3:

- Adapter clock distribution from the ACLK card to the RDV cards
- CCU clock to SCTL card on the MMB (scope on MMB board only)
- Lines of the channel to CA interface
- Line interfaces (scope on LIC top connectors)
- 3727 console interface (scope on the pin side of the MMB board)

In the field, scoping the CCU board is not used in the 3725 maintenance.

SCOPE POINT REFERENCES

- CA interface : Pages 4-110 and 4-112
- Line interface : Pages 4-130 to 4-241
- 3727 interface : Page 6-040

CLOCK SCOPING

CCU Clock


The CCU clock is internal to the CCU and cannot be checked on the CCU board with the scope.

The clock signals driving the storage are generated on the CCLK card. They can be probed on the MMB board.

Board Name: MMB Location: 01A-A1

Clock	Socket	SCTL Card
M1	YDB05	Q2U02
M2	YDD05	Q2U04
M3	YDB04	Q2U05
M4	YDD03	Q2U06
M5	YDD02	Q2U07
M6	YDB02	Q2U09

Clock Signal Relationship



Waveform # 001


Scope Setting

Channel 1
 Probe x 10 on pin: 01A-A1Q2 U02
 Signal name: M1
 Voltage: .2V/Div.
 Speed: 50 ns

Channel 2
 Probe x 10 on pin: 01A-A1Q2 U05
 Signal name: M3
 Voltage: .2V/Div.

Sync: Internal/Channel 1 only

Mode:



Waveform # 001a


Scope Setting

Channel 1
 Probe x 10 on pin: 01A-A1Q2 U02
 Signal name: M1
 Voltage: .2V/Div.
 Speed: 50 ns

Channel 2
 Probe x 10 on pin: 01A-A1Q2 U07
 Signal name: M5
 Voltage: .2V/Div.

Sync: Internal/Channel 1 only

Mode:



Clock Scoping (Part 2 of 5)

HIGH-SPEED CLOCK

The high-speed clock signals (29.4912 MHz) are generated by the ACLK card on the MMB board (see cable routing below). They are distributed via coaxial cables from the pin side of the ACLK card to the pin side of the RDV cards as shown on page 4-100.

The high-speed clock is free running.

LOW-SPEED CLOCK

The low-speed clock signals are generated by the ACLK card on the MMB board. They are distributed via the IOC cables. To identify the clock signals, refer to the signal tables on:

- Page 4-080 for the primary IOC cables
- Page 4-085 for the secondary IOC cables


For IOC continuity checking, see pages 4-090 to 4-093.

The low-speed clocks are free running.

Scoping Procedure

Slightly pull out the clock cable connector and place a hook probe on the selected board pin. The following scope screens are shown when checking for the presence of the clock signal on the CLAB1 board.

Note: The 3-pin connector that carries the clock signals may be plugged either way up.



Waveform # 002


Scope Setting

Channel 1
 Probe x 10 on pin: see table
 Signal name: High-speed clock
 Voltage: .1V/div
 Speed: 5 ns


Channel 2
 Probe x 10 on pin:
 Signal name:
 Voltage:

Sync: Internal/channel 1 only

Mode: Channel 1



CLOCK CABLE ROUTING



Scope Points

From ACLK	To RDV	From RDV	To RDV	From RDV	To RDV
MMB 01A-A1X4D07 Ground: D08 D09	LAB pos 4 02A-A3A2B02 Ground: B03 B04	LAB pos 4 02A-A3A2D05 Ground: D06 D07	LAB pos 5 02A-A2A2B02 Ground: B03 B04	LAB pos 5 02A-A2A2D05 Ground: D06 D07	LAB pos 6 02A-A1A2B02 Ground: B03 B04
MMB 01A-A1X4B02 Ground: B03 B04	LAB pos 7 02B-A3A2B02 Ground: B03 B04	LAB pos 7 02B-A3A2D05 Ground: D06 D07	LAB pos 8 02B-A2A2B02 Ground: B03 B04		
MMB 01A-A1X4B07 Ground: B08 B09	CAB 02C-A2X2B02 Ground: B03 B04				
MMB 01A-A1X5B02 Ground: B03 B04	CLAB2 or C2LB2 01B-A2A2B02 Ground: B03 B04	CLAB2 or C2LB2 01B-A2A2D05 Ground: D06 D07	LAB pos 3 01B-A1A2B02 Ground: B03 B04		
MMB 01A-A1X5D07 Ground: D08 D09	CLAB1 or C2LB 01A-A3A2B02 Ground: B03 B04				

Clock Scoping (Part 3 of 5)

SCOPE POINTS

Board name: MMB Location: 01A-A1

Clock	Card Name and Location		
Signal	MCC V2	CPA U2	ACLK X4
15 us 100 ms	M09 U07	D12	G05 J12

LAB A, B AND C LOCATIONS

3725/3726

Scanner	Board Name	Board Address
1	CLAB1	01A-A3
3 5-(6)	CLAB2 LAB pos 3	01B-A2 A1
7-(8) 9-(10) 11-(12)	LAB pos 4 LAB pos 5 LAB pos 6	02A-A3 A2 A1
13-(14) 15-(16)	LAB pos 7 LAB pos 8	02B-A3 A2

The second scanner or TRA of a LAB type B or C is indicated in brackets.

3725 Model 2

Scanner	Board Name	Board Address
1	C2LB	01A-A3
3	C2LB2	01B-A2
5-(6)	LAB pos 3	01B-A1

The second scanner of a LAB type B or C is indicated in brackets.

Board name		Card Name and Location								
and Location	Top conn. on RDV RDVAD	RDV RDVAD	CSP1	CSP2	FES	LIC TIC	ICC	CVTL	TRM	
C2LB Mod 2 01A-A3		A2	D2	E2	F2	N2,M2,L2, K2,H2,G2,	P2,J2	Q2,T2		
CLAB1 01A-A3		A2	E2	F2	G2	H2,J2,K2, L2,N2,P2, Q2,R2	M2,S2	T2		
C2LB2 (Mod 2) 01B-A2		A2	V2	U2	T2	K2,L2,M2, N2,Q2,R2,	P2,S2	D2,G2		
CLAB2 01B-A2		A2	U2	T2	S2	G2,H2,J2, K2,M2,N2, P2,Q2	L2,R2	D2		
LAB-A See Location on this page		A2	D2	E2	F2	G2,H2,J2, K2,M2,N2, P2,Q2	L2,R2			
LAB-B See Location on this page		A2	D2 U2	E2 T2	F2 S2	G2,H2,J2, K2,M2,N2, P2,Q2	L2,R2			
LAB-C See Location on this page		A2	U2	T2	S2	M2,N2, P2,Q2	R2		C2	
CAB		A2 B2 X2						D2,H2 M2,S2		
Clock Signal and Scoping Points	5 Mhz 100 ms 480 Hz 15 us CLK1* CLK2* CLK3* CLK4*	Z12 Z10 Z04 Z13	U12 U10 U04 U13 D04 D09 D13 G02	D13	P04	J06 G07 G04 J05 U07 G05	J10 S03 P13	M06 P07	B03 B05 B04	

* CLK1 through CLK4 are generated on the RDV card from the high-speed clock signals distributed via coaxial cables.

Clock Scoping (Part 4 of 5)

Waveform # 003

| Scope Setting

Channel 1
| Probe x 10 on pin: 01A-A3 A2 U12
Signal Name: 5 MHz
Voltage: .2V/Div.
Speed: 100 ns

Channel 2
| Probe x 10 on pin:
Signal Name:
Voltage:

Sync: Internal/Channel 1 only

Mode: Channel 1

Waveform # 004

| Scope Setting

Channel 1
| Probe x 10 on pin: 01A-A1 X4 J12
Signal Name: 100 ms
Voltage: .2V/Div.
Speed: 20 ms

Channel 2
| Probe x 10 on pin:
Signal Name:
Voltage:

Sync: Internal/Channel 1 only

Mode: Channel 1

Waveform # 005

| Scope Setting

Channel 1
| Probe x 10 on pin: 01A-A3 A2 U04
Signal Name: 480 Hz
Voltage: .2V/Div.
Speed: .5 ms

Channel 2
| Probe x 10 on pin:
Signal Name:
Voltage:

Sync: Internal/Channel 1 only

Mode: Channel 1

Waveform # 006





| Scope Setting

Channel 1
| Probe x 10 on pin: 01A-A1 X4 G05
Signal Name: 15 us
Voltage: .2V/Div.
Speed: 5 us

Channel 2
| Probe x 10 on pin:
Signal Name:
Voltage:

Sync: Internal/Channel 1 only

Mode: Channel 1



Clock Scoping (Part 5 of 5)

Waveform # 007

| Scope Setting

Channel 1

| Probe x 10 on pin: 01A-A3 A2 D09
| Signal Name: CLK2
| Voltage: .2V/Div.
| Speed: 50 ns

Channel 2

| Probe x 10 on pin: 01A-A3 A2 D04
| Signal Name: CLK1
| Voltage: .2V/Div.

Sync: Internal/Channel 2

Mode: Chopped

Waveform # 008

| Scope Setting

Channel 1

| Probe x 10 on pin: 01A-A3 A2 D13
| Signal Name: CLK3
| Voltage: .2V/Div.
| Speed: 50 ns

Channel 2

| Probe x 10 on pin: 01A-A3 A2 D04
| Signal Name: CLK1
| Voltage: .2V/Div.

Sync: Internal/Channel 2

Mode: Chopped

Waveform # 009

| Scope Setting

Channel 1




| Probe x 10 on pin: 01A-A3 A2 G02
| Signal Name: CLK4
| Voltage: .2V/Div.
| Speed: 50 ns

Channel 2

| Probe x 10 on pin: 01A-A3 A2 D04
| Signal Name: CLK1
| Voltage: .2V/Div.

Sync: Internal/Channel 2

Mode: Chopped



Power Supply Adjustments


DC VOLTAGE ADJUSTMENT

There is no dc voltage adjustment in the field. Dc voltages must be within the specified limits (see 3725/3726 Power Supplies, Theory of Operation, SY33-2020, in Volume A03.

AC VOLTAGE ADJUSTMENT

For ac voltage verification and adjustment, see 3725/3726 Power Supplies, Theory of Operation, in Volume A03.





Contents

CHAPTER 6. 3725 INITIALIZATION (IML, IPL)

Control Panel (Part 1 of 2)	6-010	Controller Initialization Phase Descriptions	6-090
Channel Adapter and MOSS Control		Phase 0: Controller Reset and MOSS IML	
Program Wait Lamp (Green)		Phase 1A: Controller IPL	
MOSS Inoperative Lamp (Red)		Phase 1B: Controller Re-IPL	
MOSS Message Lamp (Green)		Phase 2: Load and Start CLDP in CCU	
Hex Display		CCU Rollout Area	
Channel Adapter Enable Switches		Phase 3: Scanner IML	
All Channel Adapters Disabled Lamp (Green)		Phase 4: CCU Loading Support	
Console Switch		Abnormal Conditions During	
Function Start Switch		Controller Initialization	6-100
Function Select Switch		Using CCU Functions During Initialization	
Control Panel (Part 2 of 2)	6-011	MOSS IML Step Description	6-110
Power Control		Introduction	
Power Mode Switch		MOSS IML Steps	
Control Panel Connections	6-020	Step 0: MOSS Reset	
MOSS Connection to Control Panel		Step 1: MOSS Processor Checkout	
3727 Operator Console (Part 1 of 5)	6-030	Step 2: MOSS IOC Bus Testing/RAM Testing	
Controls and Locations		Step 3: I/O Selection and	
Power On/Off Switch		Interrupt Mechanism	
Power On Light		Step 4: Diskette Testing	
Test/Normal Switch		Step 5: Execute Disk Bootstrap	
Light 1		Step 6: CCA Card Test	
Light 2		Step 7: EIA Card and Console Attached Test	
3727 Operator Console (Part 2 of 5)	6-031	Steps 8 and 9: MCC and MMC Card Test	
Adjustment and Tests		Step 9: TTA Test, Loader Move, Loading of	
Adjusting the Video Element		the MOSS	
Operator Console Test		Step 10: Microcode Load in MOSS	
Console Link Test		Step 11: MOSS Initialization	
3727 Operator Console (Part 3 of 5)	6-032	Scanner IML Step Description	6-120
Element Removal and Replacement Procedures		Introduction	
Video Element Replacement		IML Principle	
Keyboard Element Replacement		IML Steps	
3727 Operator Console (Part 4 of 5)	6-033	Controller Initialization Request Handling	6-130
Logic Element Replacement		Handling Write IPL Requests on the	
3727 Operator Console (Part 5 of 5)	6-034	MOSS Side	
Anti-Glare Filter Feature		IPL Exchanges over Channel IPL Port	6-140
Removal Procedure		IPL Exchange Mechanism (Channel IPL Port)	
Cleaning Procedure		Dump Exchanges over Channel IPL Port	6-150
Replacement Procedure		Dump Exchange Mechanism (Channel IPL Port)	
Keyboard Palm Rest Feature		IPL Exchanges over Link IPL Port	6-160
Removal		Remote End Line Trace of Remote	
Replacement		Load (Part 1 of 2)	6-170
3727 Operator Console Connection	6-040	Remote End Line Trace of Remote	
Controller Resets	6-050	Load (Part 2 of 2)	6-171
Remote Power Off (RPO)		Dump Exchanges over Link IPL Port	6-180
Reset Functions		Remote End Line Trace of Remote NCP Abend and	
Controller Initialization	6-060	Dump Transfer (Part 1 of 2)	6-190
Initialization of a Channel-Attached 3725		Remote End Line Trace of Remote NCP Abend and	
Initialization of a Link-Attached 3725		Dump Transfer (Part 2 of 2)	6-191
Initialization Requests			
Requesting a MOSS IML			
Controller Initialization			
Sequence (Part 1 of 2)	6-070		
Controller Initialization			
Sequence (Part 2 of 2)	6-071		
Controller Initialization Flow	6-080		

Control Panel (Part 1 of 2)

CHANNEL ADAPTER AND MOSS CONTROL

The 3725 control panel carries the switches and indicators necessary for the operator to:

- Control the power system
- Interface with the maintenance and operator subsystem (MOSS)
- Enable the channel adapters

Additional switches are provided for the CE to trace a power system fault. These switches are normally behind the machine cover in the power service area, and are not accessible to the customer operator (see page 6-011).

Program Wait Lamp (Green)

When on, indicates that the 3725 control program is in wait status.

MOSS Inoperative Lamp (Red)


When on, indicates that the MOSS is not available to the CCU.

MOSS Message Lamp (Green)

When on, indicates that the MOSS has a message waiting for the operator.

Hex Display

Displays IPL phases and IML steps, MOSS error codes, or power error codes.



Channel Adapter Enable Switches

Enable the associated channel interface.

All Channel Adapters Disabled Lamp (Green)

When on, indicates that all channel adapters are disabled.

Console Switch

Switch MOSS interface to primary or alternate console.

Warning: Before operating this switch you must properly terminate any operation with the presently selected console.

Function Start Switch

Starts the MOSS running according to the Function Select switch

Function Select Switch

Sensed by the MOSS to determine what type of function is to be performed at power on, or at power on reset, or when the Function Start switch is operated.

The positions are:

- **Normal:** This causes initial microcode load (IML) of MOSS, CCU, and scanners, followed by a CCU IPL.
- **MOSS IML:** This causes IML of MOSS only.
- **MOSS Dump:** This resets MOSS and dumps MOSS microcode onto the diskette. The MOSS dump is rejected (error code E65) after a power-on IML because the storage is empty.
- **Maintenance:** This loads MOSS microcode from the service diskette, and sets the controller to service mode.
- **Cnsl Link Test:** This runs a wrap test up to the end of the console cable (see cable interface on page 6-040).

Control Panel (Part 2 of 2)

POWER CONTROL

Power Mode Switch

- **Test 1:** Activates the hex display to check that the power error scanning is running and that the display has no failure.

This position also enables the CE to power on the controller during an undervoltage condition to facilitate faultfinding.

When the 3725/3726 is power on, activating Test 1 does not power off the 3725/3726.

- **Normal:** This is the position required for normal controller operation.
- **Test 2:** Forces a power off to enable the CE to check the power off status of the various fault detectors (OV, UV, OC). In this position, the power fault scanner can be advanced, step by step, by the Manual switch.


Manual Step Switch: Pressing this switch causes the power fault scanner to advance one step (when the Power Mode switch is set to Test 2).

Unit Emergency Switch

- **Power Enable:** This is the normal position.
- **Power Off:** Drops prime power to all contactors, removing all voltages from the machine (except in the primary power box).

This switch should be used only to power off during an emergency, as it latches mechanically in the off position, requiring a CE call to reset it for power enable.

Unlatching the Unit Emergency Switch




Power Control Switch

Warning: The machine may auto restart with power control switch set to Remote or Network. It automatically powers itself on after ac power is restored.

For more information on auto restart, see 3725/3726 Power Supplies T0.

- **Remote:** Allows power on and off to be controlled by the host machine.
- **Local:** Allows power on and off to be controlled by the operator panel Power On/Off switch.
- **Network:** Allows power on to be controlled by the operator panel Power On/Off switch and, power off to be controlled by the telecommunications network receiving a 'remote power off' signal.



Power Check Lamp (Red)

Lights when any of the following power faults is detected:

- Overvoltage (OV)
- Undervoltage (UV)
- Overcurrent (OC)
- Thermal
- Open circuit protector chain
- Clock fault

Note: Any of the above faults also causes the machine to power down.

Hex Display

When the machine is in the 'power check' condition, the hex display shows a three-digit code that indicates the power fault symptom (as indicated in 3725/3726 Power Supplies T0).

Power On Lamp (Red)


Lights as soon as the power on sequence starts, and goes off as soon as the controller powers down.

Power On/Off Switch

Current Machine Status	Action when switch is set to:	
	ON	OFF
Power OFF	Power on sequence or IML/IPL	Not applicable
Power ON	Reset *, or IML/IPL	Power off sequence
Power OFF + Power check	---	Power check reset

* In local mode only. Before using this reset function, all channels must be disabled (see "Controller Resets", page 6-050).

Control Panel Connections



3727 Operator Console (Part 1 of 5)

Detailed information on operating the operator console is given in the 3725 Operator's Guide.

Problem analysis procedures are given in the 3727 Reference and Problem Analysis Guide, located in a compartment under the keyboard element.

The 3727 Maintenance Information Manual is available in countries where 3727 FRUs may be replaced on site by service personnel.

CAUTION

Be careful when moving the 3727 Operator Console, as the video element is simply placed on the logic element.

CONTROLS AND LOCATIONS


Power On/Off Switch

Press "I" Power ON
 Press "O" Power OFF

Power On Light

Lights when the Power On/Off switch is ON.

Note: Turning the Power switch off, then on quickly, may cause a reversed screen (green background with no characters displayed). If this happens, turn the Power switch off, wait several seconds, then turn it back on.



Test/Normal Switch

In normal communication operation, this switch is set to NORMAL. When this switch is set to TEST, the self-testing program checks the terminal functions.



Light 1

Blinks when the TEST/NORMAL switch is set to TEST and stays off when the switch is set to NORMAL.

Light 2

Lights when the 3727 is ready to communicate with the 3725 or when the Test/Normal switch is set to TEST.

Note. On latest console models, the keyboard is different but the keys are the same.




Turning this knob clockwise increases the volume.

The audible alarm sounds to alert the operator under the following conditions:

- When a character is entered in the 8th position before the end of the last line of the screen.
- When the Test/Normal switch is set to TEST.
- When the uppercase of reverse slash key is pressed.
- When an error is detected during a diagnostic request run ALL.

Keyboard Element



Legend
 [Shaded] Mechanically-Locked Keys
 [Dotted] Typamatic (Repeat-Action) Keys
 [White] Non-Typamatic Keys



3727 Operator Console (Part 2 of 5)

ADJUSTMENT AND TESTS

Operator Console Test

Adjusting the Video Element

You can tilt the video element to either 10 or 15 degrees and swivel it up to 12.5 degrees in either direction from the normal position. To tilt, lift the front of the element and move it forward or backward until its feet fit into the appropriate groove of the logic element.



When the 3727 is in test mode, if the above conditions are not met, refer to:

- 3727 Reference and Problem Analysis Guide, to determine the faulty element.
- 3727 Maintenance Information Manual, to determine the faulty FRU (depending on the maintenance strategy in your country).

Console Link Test

See the 3725/3726 Maintenance Information Manual, Part 2 (Volume A01) to run the console link test from the 3725 controller.

3727 Operator Console (Part 3 of 5)


ELEMENT REMOVAL AND REPLACEMENT PROCEDURES

These procedures are given for machines that are under "Element Exchange" contract only.

Note: If you return a video element equipped with an anti-glare filter to the IBM Repair Center, remove the anti-glare filter before shipment. No repair service is provided for the filter.

Video Element Replacement


1. Turn Power switch OFF (O).




2. Unplug the power cord.




3. Unscrew the connector of the video element cable and disconnect it from the receptacle labeled 2. (Do not remove thumb screws from the connector.) Omit this step if the connector has already been removed.




4. Replace the failing video element with a good one.



5. Connect the cable of the new video element.



6. Plug the power cable into the power outlet.
7. Turn Power switch ON (I) and verify that the terminal operates normally.



8. Run the operator console test to check that the exchanged element is working correctly.

Set the Test/Normal switch to NORMAL.


If the customer operations function correctly, the repair procedure is finished.

If the customer operations do not function correctly, refer to the 3725 Problem Determination and Extended Services.

Keyboard Element Replacement

Note: If you return a keyboard element equipped with a palm rest to the IBM Repair Center, remove the palm rest before shipment. No repair service is provided for the palm rest.


1. Turn Power switch OFF (O).



2. Unplug the power cord.




3. Unscrew the connector of the keyboard element cable and disconnect it from the receptacle labeled 5. (Do not remove thumb screws from the connector.) Omit this step if the connector has already been removed.



4. Replace the failing keyboard element with a good one.

5. Connect the keyboard element cable of the new element to the logic element.



6. Plug the power cable into the power outlet.
7. Turn Power switch ON (I) and verify that the terminal operates normally.



8. Run the operator console test to check that the exchanged element is working correctly.


Set the Test/Normal switch to NORMAL.

If the customer operations function correctly, the repair procedure is finished.

3727 Operator Console (Part 4 of 5)

Logic Element Replacement


1. Turn Power switch OFF (O).




2. Unplug the power cord.




3. Loosen the screws on all the cables from the rear side of the logic element and disconnect them. Do not disconnect the power cord.



4. Replace the failing logic element.



5. Connect all the cables disconnected in Step 3 to the logic element.
6. Plug the power cable into the power outlet.
7. Turn Power switch ON (I) and verify that the terminal operates normally.
8. Set alarm to the desired volume (in TEST mode).



9. Run the operator console test to check that the exchanged element is working correctly.

Set the Test/Normal switch to NORMAL.

If the customer operations function correctly, the repair procedure is finished.

If the customer operations do not function correctly, refer to the 3725 Problem Determination and Extended Services.

3727 Operator Console (Part 5 of 5)


ANTI-GLARE FILTER FEATURE

This filter has a specially-coated glass that reduces reflectance of ambient light.


Note: If you return a video element to the IBM Repair Center, remove the anti-glare filter before shipment. No repair service is provided for the filter.

Removal Procedure


1. Push the upper left corner and pull the bottom right corner until the bottom edge comes out.



2. Grasp the left and right edges and rotate the top edge of the filter forward gently.



3. Pull the filter to remove.



Cleaning Procedure

Turn display terminal power off.


Wash the filter with a clean, soft cloth and either plain water or water and detergent. Dry the filter with a clean, soft cloth.

Do not use paper for cleaning; it may be abrasive.


Warning: Do NOT use acid solutions or abrasive products, such as cleansers or scouring pads, because these products will damage the filter.

Replacement Procedure


1. Hold both sides of the anti-glare filter.



2. Put the right edge of the filter into the filter groove.



3. Push the left edge of the filter into the other groove.




KEYBOARD PALM REST FEATURE

This palm rest extends the depth of the keyboard element toward the operator by approximately 60 mm for comfortable operation.


Note: If you return a 3727 keyboard element to the IBM Repair Center, remove the keyboard palm rest before shipment. No repair service is provided for the palm rest.

Removal

1. Tilt the keyboard to the position shown below.




2. Remove the palm rest from the keyboard by rotating it as shown below.




Replacement


1. Tilt the keyboard and position the palm rest as shown below.



2. Hold the keyboard and the palm rest in position by placing your thumb on the tab as shown. Tap the palm rest with the other hand until it snaps into position.



3. Hold the other side of the keyboard and palm rest in position by placing your thumb on the tab as shown. Tap the palm rest with the other hand until it snaps into position.





3727 Operator Console Connection

Primary and alternate operator consoles connect directly to the 3725 via a CCITT interface in start-stop mode at 2400 bps, using ASCII code with one stop bit only.

Depending on the position of the Primary/Alternate Console switch on the control panel, only one console is connected at a time.

The IBM 7427 Console Switch (RPQ) allows one primary or one alternate console to be shared among several 3725 controllers.




- Signal Names**
- ⊗ LED on 7427 Console Switching Unit (RPQ)
 - Transmitted Data
 - Received Data
 - Data Channel Received Line Signal Detector
 - Request to Send
 - Ready for Sending (Clear to Send)
 - Data Set Ready
 - Data Terminal Ready
 - Signal Ground

- ⊗ LED on 7427 Console Switching Unit (RPQ)
- Transmitted Data
 - Received Data
 - Data Channel Received Line Signal Detector
 - Request to Send
 - Ready for Sending (Clear to Send),
 - Data Set Ready
 - Data Terminal Ready
 - Signal Ground

Wrap Block Part 2667737 to install in ①

1S02110
25 pins



* Pin 1 is connected to the cable shield on the controller end of the cable. The console is not connected to this shield. However, when a 7427 Console Switching Unit (RPQ) is installed between the controller and console, the latter is connected to the shield of the additional cable, through connector pin 13.

Controller Resets

Resetting the 3725 causes a hardware reset followed by a MOSS load/dump or other operations called by the switches.

Warning: Before initiating a reset, you must disable all channels to avoid propagation of channel errors to the host system.

The reset depends on the four switches on the control panel:

1. Power On/Off
2. Power Control
3. Function Select
4. Function Start

- Resetting is generally done by using the Power On/Off switch.
- The Function Select switch determines the operation that follows a MOSS reset:
 - Normal
 - MOSS IML (for the controller diskette)
 - MOSS Dump
 - Maintenance
 - Console link test
- The MOSS is reset and the selected operation starts when the Function Start switch is pressed.

There are three modes of operation, depending on Power Control switch setting:

1. In local mode, the 3725 is reset (except for power faults) using the 'on' position of the Power On/Off switch.

To reset power faults, the switch should first be set to off, then to on.

 - a. Off clears the fault indicators
 - b. On causes a power-on reset (POR)

2. In remote mode, the 3725 is powered on and off by a pulse sent by the first channel-attached host that is powered on.

The 'on' and 'off' positions of the Power On/Off switch are inoperative.

3. In network mode, the 'off' position of the Power On/Off switch is inoperative because power off can come only from the CCU that received a remote power off signal via a telecommunication line.

In network mode, the 'on' position is active only at initial 3725 power on. After the 3725 has been powered on, the 'on' position is inactive and will not cause a 3725 reset if pressed.

Note: The 3725 is also reset when the input voltage is restored after an ac power loss (automatic power on, auto restart function).


In both cases, the POR signal itself is generated by the power logic card PWCL1 in the power board PWB1.

REMOTE POWER OFF (RPO)

This is an SNA command (010209) issued when the access method operator requests that the remote controller be powered off. An SDLC command precedes the remote power off so that if a control program is loaded, a re-IPL occurs and CLDP is called in to respond to the remote power off command. If CLDP is already loaded, a re-IPL does not occur. A remote power off may be a parameter of any of the following commands:

- Deactivate
- Dump
- Z (closedown)

CLDP informs MOSS that a remote power off command has been received by issuing an output X'71' (With byte X, bit 3 on). MOSS then displays the following message in field w of the MSA area of the 3727 screen "RPO detected on L XXX", where XXX is the decimal communication line address. CLDP then issues an output X'79' (With byte 0, bit 4 on) which activates the power off circuitry of the power supply. The power control switch must be in the "Network with Auto Power On" position for the power off to occur. If the switch was not in the proper position, setting it to the correct position has no effect after the output has been issued.



RESET FUNCTIONS

From the control panel, the reset line signal is sent to the CCU board (MIOC and BTAC cards). It is also sent to the CPA card.

The reset line starts the microcode in the MOSS by forcing a branch to storage address 0000 (MOSS ROS).

The hardware POR line, which is also sent from the CCU to the scanners, is not used. Instead, the adapter reset line in the IOC bus is sent to the adapters. This reset line is generated by the MOSS microcode at the beginning of each 3725 initialization phase 1 (see Table 2 on page 6-071).

Controller Initialization

The initialization of the 3725:

1. Tests the MOSS IML circuits using microcode from MOSS ROS and the TSS IML circuits using microcode from the TSS ROS.
2. Loads and initializes the MOSS microcode in MOSS storage (MOSS IML).
3. Initializes the hardware in the CCU (CCU IML).
4. Loads and initializes the 3725 load/dump program (CLDP) in the CCU storage, along with the IPL port(s) defined for this 3725 (channel and link).
5. Loads and initializes the microcode in the scanner(s) (scanner IML).
6. Either loads and initializes the control program in the CCU storage (CCU IPL). This program is received from the host through a channel-attached or link-attached IPL port. Or dumps the contents of CCU storage to the host through a channel or link IPL port.

The initialization step in progress (IML, then IPL) is displayed on the hex display of the control panel, and on line 3 of the machine status area (MSA) of the operator console.

When the initialization is complete, the message 'IPL COMPLETE' is displayed on the operator console, and message 000 stays on the hex display.

When initialization fails, an error code is displayed on the hex display and on the MSA.

The initialization is under control of the controller load/dump program (CLDP).

INITIALIZATION OF A CHANNEL-ATTACHED 3725

1. CLDP is loaded
2. Write IPL command is received, followed by a Write Break if loading or by a Write if dumping.
3. Scanners are IMLed (see note).
4. Multiple Write and No Op commands load the control program, or multiple Write and Read commands dump CCU storage.
5. Write Break followed by Write command ends a load.
6. If loading, the control program is now loaded and is given control. If dumping, the dump is complete and CLDP prepares for a load.

Note: The scanners may be IMLed before the Write IPL is received. However, the Write IPL may be detected and acted upon as soon as CLDP is loaded. In this case, the control program load and the scanner IMLs take place at the same time.

INITIALIZATION OF A LINK-ATTACHED 3725

1. The control program is loaded in the channel-attached 3725.
2. CLDP is loaded in the link-attached 3725 (see note).
3. Scanners are IMLed.
4. IPL Init or Dump Init is received on a defined link IPL port.
5. Multiple IPL texts load the control program, or Dump texts unload CCU storage.
6. IPL Final or Dump Final is received.

7. If loading, the control program is now loaded and is given control. If dumping, the dump is complete and CLDP prepares for a load. See descriptions of IPL exchanges and dump exchanges in this chapter for details.

Note: No Write IPL is received on any channel adapter of the link-attached 3725 before completion of the link IPL.

INITIALIZATION REQUESTS

The controller initialization can be started by the operator from the host console, from the 3725 control panel, or from the 3727 operator console.

The controller initialization can also be started automatically to recover from a faulty condition in the 3725. This is the case when NCP abends, when MOSS abends, when the ac input voltage is restored after a break, or on a CCU hardcheck.

The headings in the following table identify the extent of 3725 initialization caused by the conditions listed under each heading. The conditions not listed as automatic are manual requests.


Requesting a MOSS IML

The MOSS may be IMLed automatically or manually.

MOSS is automatically IMLed when Power On occurs or when the Power On Reset Switch is operated and the Function Select switch is in the Normal, MOSS IML, or Maintenance position. MOSS may also be IMLed automatically by microcode.

1. If the control program (NCP) is running, set MOSS offline (CCU function 5, selection 12).
2. Set the Function Select switch to the MOSS IML or Maintenance position.
3. Operate the Function Start switch.
4. the progress of the MOSS IML will be displayed on the hex display.
5. If the control program (NCP) is running, set MOSS online (CCU function 5, selection 11).

MOSS, CCU, and Scanner IML (Function Select switch in normal position)
<ul style="list-style-type: none"> ==> At host site: <ul style="list-style-type: none"> . Power on from host (applies to CA-attached controller with Power Control switch in remote position and an EPO cable installed) ==> At 3725 site: <ul style="list-style-type: none"> . Power on . Function start from control panel ==> Automatic: <ul style="list-style-type: none"> . Repowering after ac power loss (with auto power on)
MOSS IML
<ul style="list-style-type: none"> ==> At 3725 site: <ul style="list-style-type: none"> . Power on with Function Select switch in MOSS IML or Maintenance position. . Function Start switch with Function Select switch in MOSS IML or Maintenance position ==> Automatic: <ul style="list-style-type: none"> . Re-IML on MOSS Abend
CCU and Scanner IML
<ul style="list-style-type: none"> ==> At host site: <ul style="list-style-type: none"> . Control program load ==> At 3725 site: <ul style="list-style-type: none"> . Reload request from console ==> Automatic: <ul style="list-style-type: none"> . Access method request . NCP request on NCP abends . Reload attempt on CCU hard checks
Selective Scanner IML
<ul style="list-style-type: none"> ==> At 3725 site: <ul style="list-style-type: none"> . TSS services . CCU and scanner IML menu



Controller Initialization Sequence (Part 1 of 2)


The following tables list the phases and steps of a controller initialization. IPL phase 0 shows the initialization sequence starting from a MOSS that is not running. IPL phases 1 to 4 show the initialization sequence continuing from a MOSS that is running.

Phases 1A and 1B are mutually exclusive in a controller initialization. Phase 1B runs when an initialization results from:

1. A CCU hardcheck
2. The function start switch gets activated with the function select switch at normal and the 3725 is loaded with the control program.

The MOSS IML sequence itself varies with the request. In the following figure the request (power on, software, or start) points to the selected sequence of MOSS actions during phase 0 (A, B, C, or D in Table 1).

The hex display shows the initialization step in progress. The step can be part of MOSS IML, scanner IML, or CCU IML, or can be part of the control program loading (IPL). Any other value indicates an initialization error (refer to the 3725/3726 MIM Part 2).



Software Requests		Power-On Requests	
Maintenance	MOSS Auto IML MOSS Dump MOSS IML	Maintenance	MOSS IML Normal
A	B	C	D

Note: For explanation of A, B, C, and D, see "MOSS Actions" in Table 1.

Notes:

1. This step is skipped if a MOSS dump is requested.
2. MOSS stops on this step and waits for operator action when the Function Select switch is set to Console Link Test.

Table 1: MOSS Not Running

IPL Phase	Hex Step	MOSS Action	MOSS Storage	MOSS Actions			
				A	B	C	D
0		CONTROLLER RESET AND MOSS IML					
		MOSS processor checkout	ROS				
		. Basic MPC Test	*	x	x	x	x
		. ROS CRC Calculation	*	x	x	x	x
		. MPC Instruction Test	*	x	x	x	x
		. Register Space Part 2	*	x	x	x	x
		. Internal PIO Bus to CPA	*	x	x	x	x
		. Internal PIO Bus to Console	*	x	x	x	x
		. Hex Display Register (Wrap Mode)	*	x	x	x	x
		. ROS Test Controller Initialization	*	x	x	x	x
	F00	. IML/IPL Decode and CPA test	*	x	x	x	x
	F01	. Register Space (Part 1)	*			x	x
		. Partial Storage Test (Note 1)	*	x	x		
		. Complete Storage Test (MOSS storage reset to zero value)	*			x	x
	F03	. MPC Communication Adapter	*	x	x	x	x
		. External I/O Bus	*	x	x	x	x
	F04	. IOIRR Test	*	x	x	x	x
		. Interrupt Test	*	x	x	x	x
		. DAC Test	*	x	x	x	x
		. Diagnostic Exit Service	*	x	x	x	x
	F05	. RAM Test Controller Initialization	RAM	x	x	x	x
	F06	CCA TEST	*	x	x	x	x
		. Valid Command Recognition	*	x	x	x	x
		. Test Rejection of Invalid Commands	*	x	x	x	x
		. Test Control Reg - Set/Reset/Read	*	x	x	x	x
		. Test Modem Control Reg - Write/Read	*	x	x	x	x
		. Test Modem Status Register	*	x	x	x	x
		. Timer Test (Part 1)	*	x	x	x	x
		. Timer Test (Part 2)	*	x	x	x	x
		. Enable/Disable Bit	*	x	x	x	x
		. Output Request/Receive Clock Run	*	x	x	x	x
		. Input Request	*	x	x	x	x
		. Input Request with RCV Mode Off	*	x	x	x	x
		. Overrun Bit/Set/Reset	*	x	x	x	x
		. Invalid Character Bit/Set/Reset	*	x	x	x	x
		. Break Byte Detected-Set/Reset	*	x	x	x	x
	F07	. CCA Wrap Test	*	x	x	x	x
		. Console Link Test (Note 2) (Function Select Switch on Console Link Test)	*	x			
		. Console Attached Test	*	x	x	x	x
		. Hex Display Test	*	x			
	F08	. MCC Test	*	x	x	x	x
		. MMC Test (Part 1)	*	x	x	x	x
	F09	. MMC Test (Part 2)	*	x	x	x	x
	F0A	MOSS Microcode Loading	*	x	x	x	x
	F0B	MOSS Initialization (Part 1)	*	x	x	x	x
	F0E	MOSS Initialization (Part 2)	*	x	x	x	x
	FEF	MOSS IML Complete	*	x			

Controller Initialization Sequence (Part 2 of 2)


Table 2: MOSS Running

IPL Phase	Hex Step	MOSS/CCU Action	Scanner Action
1A	FF0 FF1	<p>CONTROLLER INITIALIZATION CONTROLLER IPL -----></p> <ul style="list-style-type: none"> . LSSD Initialization . CCU LSRs Initialization to zero value . Main Storage Initialization to zero value with parity . Disable Storage Protect/Address Exception Mechanism . Initialize CA register with parity . Run CCU Initial Tests . Run IOC Bus Initial Tests 	<p>The reset sent to IOC adapters starts the scanner test from CSP ROS:</p> <ul style="list-style-type: none"> . Start Initialization . CSP Branch . CSP LRI . CSP RI Type . CSP RR Type . CSP XI Type . CSP Copy Type . LS Byte Address . LS Space - (Odd) 0, 1 pattern . LS Space - (Even) 0, 1 pattern . Interrupt Mechanism . Masking Mechanism . Control Store 0/1 Instructions . Control Store Addressing . Control Store Patterns . AC XR1C (Part 1) . AC XR1D (Part 2) . AC Enable Data Store (Part 3) . AC Enable Data Fetch (Part 4) . FES to CSP Bus Test . Error Reg XR03 . Parity Check . IOC-Bus Connection XR00 . IOC-Bus Connection XR01 . IOC-Bus Connection XR02 . IOC-Bus Connection Ping Buffer . IOC-Bus Connection Pong Buffer . IOC-Bus Connection Ping Busy (Write) . IOC-Bus Connection Ping Busy (Read) . IOC-Bus Connection Ping Pong Busy . IOC-Bus Connection Pong Busy (Write) . IOC-Bus Connection Pong Busy (Read) . L1 Interrupt to CCU . Autoselect L2 Interrupt to CCU . Priority and Channel Request Test . IOC-Bus Test - Phase 1 . IOC-Bus Test - Phase 2 (ROS) . IOC-Bus Test - Phase 2 (RAM) . Timer (100 ms) . Interrupt to MOSS Test (TSS only) . Hard Stop Test

Table 2 (continued): MOSS Running

IPL Phase	Hex Step	MOSS/CCU Action	Scanner Action
1B	FF1	<p>CONTROLLER RE-IPL</p> <ul style="list-style-type: none"> . Stop Channel Monitoring Task . Stop CCU . Read Out LSSD and Store Contents on Diskette . Initialize LSSD . Reset IOC adapters . Enable redrive . Restart Channel Monitoring Task . Read Out LSRs and Store Contents on Diskette . Roll Out Last 16K bytes of Main Storage and Save Contents on Diskette . Get BERs in Storage (if any) and Store Contents on Diskette . Stop Channel Monitoring Task . Run CCU Initial Tests (except for host IPL request) . Run IOC Bus Initial Tests . Enable redrive . Restart Channel Monitoring 	As for phase 1A
2	FF2	<p>LOAD AND START CLDP</p> <ul style="list-style-type: none"> . Load CLDP and IPL Port Definition in Rollout Area . Previously saved LSSD and LSR contents sent to CLDP (re-IPL only) . Give control to CLDP to monitor IPL ports and signal the hosts that control program loading may be started on a channel IPL port. 	No action
3	FF3	<p>SCANNER IML</p> <p>(Selective scanner IML is a MOSS function and is not part of the controller initialization.)</p> <ul style="list-style-type: none"> . First use of mailbox to send to CLDP the list of scanners that have completed IML. . CLDP starts monitoring the defined link IPL ports for an IPL Init. 	CSP storage set to zero Microcode on diskette broadcast to scanners by MOSS. The scanner code is sent on a block basis using the CCU/Scanner buffer. MOSS transmits blocks to the CCU buffer and each scanner gets each block through cycle steal. After a timeout, MOSS gets the "completion block" from each working scanner and resumes RAM loading with the next block.
4	FF4 FF5 FF6 FF7 000	<p>CCU LOADING, DUMPING, AND INIT</p> <ul style="list-style-type: none"> . The control program can start from the host if loading on link-IPL port . Start Branch Trace . Write IPL command detected (from host) Loading on channel IPL port. . Loading on link IPL port. . CCU control program loaded . CCU initialization with CDF parameters . MOSS initialization with control program information table (CPIT) . CONTROLLER INITIALIZATION COMPLETE WITHOUT ERROR . Stop "Branch Trace" activity 	The scanner handles the load traffic.

Controller Initialization Flow



Legend:

- ① Scanner IMLs complete
- ② Roll in 16K
- ③ Roll in complete
- ④ Control program loaded
- ⑤ Control program parameters
- ⑥ Control program parameters saved
- ⑦ CDF information requested
- ⑧ CDF information available
- ⑨ Control program initialized

Controller Initialization Phase Descriptions

PHASE 0: CONTROLLER RESET AND MOSS IML

This phase takes place only at power on. It consists of:

1. A controller reset (MOSS, MIOC, BTAC)
2. MOSS testing and MOSS IML

PHASE 1A: CONTROLLER IPL

Phase 1A activates the following steps in turn:

1. CCU LSSD initialization.
2. IOC bus adapter reset, which starts the scanner ROS diagnostics.
3. CCU local store register initialization with good parity and zero value.
4. CCU storage initial tests. All address exception bits for installed or not-installed storage blocks are initialized, the entire memory is reset to zero, and the correct parity and ECC bits are initialized.

At the end of the test, the storage protect and address exception mechanism remains disabled.
5. CCU initial tests.
6. IOC bus initial tests, in conjunction with the scanner checkout test.

Any error during phase 1A stops the controller initialization.

PHASE 1B: CONTROLLER RE-IPL

Phase 1B activates the following steps in turn:

1. CCU stop.
2. Read out CCU LSSDs, which are saved on the diskette.
3. CCU LSSD initialization.
4. IOC bus adapter reset, which starts the scanner ROS diagnostic.
5. Read out CCU local store registers, which are saved on the diskette.

6. Roll out last 16K bytes of CCU storage, which are saved on the diskette.
7. Get the last BERs not transmitted to the MOSS (if any) from the check record pool and log them on the diskette.
8. CCU initial tests, except when the first IPL request is initiated from the host.
9. IOC bus initial tests.


Any error during the last two tests stops the controller initialization.

PHASE 2: LOAD AND START CLDP IN CCU

During this phase the controller loader/dump program is loaded from the diskette into the CCU rollout area along with the IPL port definition. The previously-saved CCU LSSD and local store registers are also passed to the CLDP, if they are available (controller re-IPL only).

The CLDP then monitors the CA IPL ports, if any CA(s) are installed and enabled, and signals to the host(s) that the controller is ready to receive the control program or a dump request.

CCU Rollout Area



Communication with the CLDP:

- CCU work register 1 points to the CCU local store registers saved before the controller re-IPL.
- CCU work Register 2 contains a code indicating which information was retrieved:
R2 = 0 ==> Both LSSD and local store registers available
R2 = 1 ==> LSSD not available
R2 = 2 ==> Local store registers not available
R2 = 3 ==> Neither LSSD nor local store registers available

External registers X'51' and X'52' contain the sense ID information to be returned to the host upon receipt of a sense ID command.

These registers are invalid when selected during CCU normal operation; they are however used for communication with CLDP during initialization.

X'51' X'52'

FF37	2500
------	------

This value is fixed and identifies the 3725 controller.

PHASE 3: SCANNER IML

In this phase, the scanner IML support in the MOSS loads each scanner.

At the end of phase 3, the MOSS sends a 'scanner IML complete' mailbox command to the CLDP along with a list of the scanners that have performed IML. The CLDP then monitors any defined link-IPL ports for an IPL Init or Dump Init if an IPL or dump request has not yet been received over a channel adapter.

PHASE 4: CCU LOADING SUPPORT

The CCU control program is received from a host processor directly via a channel adapter (local controller), or indirectly via a TP link. If the IPL or dump request is received via a channel adapter, the actual loading of the control program or dump could have begun at the end of phase 2. The following steps take place during phase 4:

1. Process the Rollin 16K mailbox command.

If the IPL is preceded by a dump, the dump routine is given control in the CCU by the CLDP, and the dump takes place. When the CCU rolled out area is needed, the CLDP sends this mailbox command to the MOSS which rolls back in the 16K storage block and returns to the CLDP the Rollin Complete mailbox command.

2. Process the Control Program Loaded mailbox command.

When the CLDP finishes loading the NCP/EP, a message is passed to the MOSS, which displays it on the screen. It indicates that CCU control has been passed to the NCP/EP initialization by CLDP.

3. Process the Control Program Parameters mailbox command.

Starts the "Branch Trace" activity on: all CCU levels, and all the CCU storage. When the branch trace buffer is full wrap mode is applied, CCU does not stop and there is no MOSS low level interrupt request.

Once loaded, the CCU control program starts its initialization. One step of the initialization procedure passes to the MOSS the control program addresses, kept in the control program information table. This table points to specific areas in storage that the MOSS needs for executing CCU operations.

4. Send the Control Program Parameters Saved mailbox command.

Once the parameters have been saved, this command is sent to the NCP/EP initialization to resume processing.

5. Process the CDF Request mailbox command.

On this request, the MOSS passes to NCP/EP the CDF information used mainly by the CCU level 1 handler, and signals their ready state with the mailbox command CDF Information Available.

6. Process the Control Program Initialized mailbox command.

At this time, the initialization of the control program is complete. The MOSS now displays the message 'IPL complete', and enters the 'MOSS online' state.

The MOSS stops the "Branch Trace" activity.

Abnormal Conditions During Controller Initialization

1. An unconditional controller IPL request coming from a host during the processing of a previous IPL request is detected and serviced immediately. The controller initialization restarts from phase 1A unless the controller loader dump program remains in the CCU. In this case, the CLDP handles the initialization request, which can be control program dump or IPL. MOSS is transparent to this new request.
2. If a CLDP abend occurs (output X'70'), the MOSS stops the IPL application. A manual intervention is required to restart the initialization, which resumes from phase 1B.
3. If an NCP/EP initialization abend occurs (output X'79' + X'70'), the MOSS automatically resumes the initialization from phase 1B.
4. Program abends from the CLDP or NCP/EP initialization cause a CLDP rollout.
5. Any hardware check on the elements of the initialization path (MOSS, CCU, IPL port) causes an IPL abend.
6. A BER is logged if an IPL abend occurs, or when initialization is complete with non-blocking errors (for example, a scanner that cannot be IMLed).

USING CCU FUNCTIONS DURING INITIALIZATION

You may use the CCU functions (for example, display, alter) as soon as the CCU initialization is complete (phase 1A or 1B). During this phase, the LSSD strings, LSRs, and storage are initialized. Using the CCU function key (CCU FNCTN), you may switch from the initialization process to the CCU services, and conversely. This key can be used at any time during any initialization phase.

During step-by-step IPL, the CCU FNCTN must be used only when the IPL stop message, indicating a step end, is displayed on the console.

MOSS IML Step Description

INTRODUCTION

MOSS IML is done in steps starting from the MOSS physical reset and ending with the initialization of the MOSS microcode.

The IML microcode used is stored:

- On the MOSS ROS for IML steps 1 through 5
- On the diskette for the remaining steps

A description of these steps follows. MOSS IML stops when an error is encountered. An error code is displayed on the hex display of the control panel.

MOSS IML STEPS

Step 0: MOSS Reset

During this step the MOSS hardware components are physically reset when the initialization request comes from either the Power On/Off Switch (reset position) or the Function Start switch.

After this, or for other MOSS IML requests, the MOSS ROS test controller is given control. Hardware or software indicators are available to the ROS to identify any IML request.

Step 1: MOSS Processor Checkout

The IML code in the ROS is entered immediately at the end of the reset pulse or directly by a branch instruction from the MOSS level 0, which detects the MOSS re-IML request.

This step is dedicated to the testing of the MOSS processor. The main tested functions are:

- Instruction set
- Control store and register space
- ROS CRC calculation
- Console hardware in MPC

Functions performed in step 1 stop the IML if they are not successful.

During this step the ROS test controller tests the IML type.

Step 2: MOSS IOC Bus Testing/RAM Testing

During step 2, the MOSS internal bus and the RAM are tested. Functions performed in step 2 stop the IML if they are not successful.

Step 3: I/O Selection and Interrupt Mechanism

During step 3, the I/O selection and interrupt mechanisms are tested.

Functions performed in this step stop the IML if they are not successful.

Step 4: Diskette Testing

Step 4 is a disk adapter test. Functions performed in this step stop the IML if they are not successful.

Step 5: Execute Disk Bootstrap

During step 5, the diskette read and write functions are exercised.

The ROS IML section ends with the execution of the disk bootstrap, which loads the 'RAM test controller/MOSS loader' from a fixed address on the diskette into a fixed address in the RAM, to manage the rest of the IML sequence within the RAM.

Functions performed in step 5 stop the IML if they are not successful.

Diskette tests are made during the loading phase.

Step 6: CCA Card Test

During step 6, the CCA card is tested.

Step 7: EIA Card and Console Attached Test

When the function selected is 'maintenance', the hex display function is tested before executing the following steps.

Steps 8 and 9: MCC and MMC Card Test

During steps 8 and 9, the MCC card is tested.

Step 9: TTA Test, Loader Move, Loading of the MOSS

Step 10: Microcode Load in MOSS

Step 11: MOSS Initialization

Before being operational, the MOSS microcode must be initialized. After a first basic initialization (PSW, translate table array, switching from ROS to RAM support for MOSS levels 1 and 5, console initialization if power on), a second initialization takes place. This second initialization is done according to the request and to the MOSS environment.

- For 'Normal' or 'MOSS IML', the initialization ends as follows:
 - 'MOSS only running'
 - 'MOSS disconnected' from the rest of the system (if MOSS has been re-IML'd by the operator).

The MOSS operator command 'MOSS online' sent via 'CCU services', is necessary to reconnect logically the MOSS to the CCU and to reach the 'system running' state, or one of the following states:
 - 'Controller IPL in progress' (in case of 'normal')
 - 'System running' (in case of MOSS auto re-IML and auto-reconnection)Finally the MOSS general menu is displayed on the console.
- For 'Maintenance' IML, the initialization phase first checks whether the service diskette is on the drive, and initializes the MOSS accordingly:
 - The BER logging task is deactivated, as its space in storage is required for the DCM.
 - The CCU background task is deactivated, as its space in storage is also required for the DCM.
 - The service diskette general menu is displayed.If the service diskette is not on the drive, this diagnostic IML is rejected, and an abend code (FEB) is displayed on the hex display.

Scanner IML Step Description

INTRODUCTION

Loading the microcode into the scanners is either a general function common to all scanners, or a selective function related to one scanner only.

From a scanner point of view, general or selective IML functions are supported by the same scanner ROS code.

From a MOSS point of view, the general IML of the scanners is a phase of the controller initialization, whereas the selective IML of a scanner is a TSS function.

IML requests are presented to the MOSS, which controls the scanner IML.

IML PRINCIPLE

An IML responder is located in the scanner ROS (CSP card).

The IML is done on a block transfer basis, between the MOSS diskette and the CSP RAM, via the MOSS RAM and the CCU main storage scanner communication area (see page 14-140).

This block transfer is completely transparent to the control program running in the CCU.

Blocks of code along with control information transit through the MOSS/scanner dedicated area, which is the last 2K bytes of the CCU RAM (minus the area for the CCU/MOSS mailboxes).

CCU commands are simulated via the MIOC interface.

IML STEPS

The IML of a scanner takes four steps.

Step 1: TSS Reset/IML

1. A general 'reset' signal is sent to every scanner (general IML) by the MOSS microcode during phase 1 of the controller initialization.
2. On the scanner side, checkout starts when the 'reset' signal is received. The checkout stops when it has exchanged the commands requested by the IOC bus test, which runs in the CCU during phase 1A or 1B of the controller initialization.

At this time, the scanner ROS is ready to handle the scanner IML commands.

Step 2: Get CSP Checkout Result

After a timeout, the MOSS fetches and tests the checkout result of any scanner. It uses IOH instructions sent to each scanner and specifying a 'read checkout status' command.

The MOSS flags the scanner as 'not IMLed' if the checkout result is bad, or if the scanner does not answer the IOH. The error is logged, and the IML sequence goes on if at least one scanner is working.

Step 3: Transfer of Block of Code

1. The MOSS sends the first IML commands with two MIOHs indicating the address of the communication area in the CCU RAM. Each scanner can then determine its address in the mailbox and the address of the buffer part of the communication area (see page 14-140).
2. The MOSS starts transferring the microcode under a block format. The block length is 1500 bytes (max).
3. The MOSS loads each block from the diskette to the 'buffer part' of the MOSS/scanner dedicated area in the CCU. In addition, the MOSS loads the 'control part' of each scanner within the dedicated area with command parameters such as:
 - a. Block length
 - b. Block address in RAM
4. The MOSS sends an MIOH instruction to each scanner specifying:
 - a. Scanner address
 - b. IML command
5. The MOSS initiates a timeout counter and waits for the end of transfer for the current block.
6. On the other side, receiving the MIOH command causes the scanner to cycle steal both the control information and the current block, and to store it in its RAM.

A transfer completion code is sent back into the dedicated area. If an error occurs, the scanner sends back an error status into the dedicated area.

Step 4: Get Block Transfer Completion

1. When the transfer of blocks of code is finished (MOSS timeout), the MOSS reads the transfer completion code returned by each scanner in its dedicated area.
2. If the command failed, the scanner is flagged as 'not IMLed' in the scanner configuration block residing in the MOSS RAM, and the error is logged.
3. The MOSS then loops, transferring the remaining blocks to the working scanners.
4. When scanner loading is complete, MOSS sends the 'init' signal to leave the scanners in the initialized state.

Controller Initialization Request Handling

HANDLING WRITE IPL REQUESTS ON THE MOSS SIDE

When a Write IPL command is detected by the MOSS ('IPL detect' signal) all channels must be monitored by the MOSS to avoid timeout problems on the host, until the CLDP is ready to take over.

port channel. All other installed channel adapters are then considered non-IPL port channels.

1. The MOSS does not require more than 5 ms to stop the CCU because the handling of 'IPL detect' is performed in the MOSS level 1 code.

In the case of a MOSS automatic re-IML, the NCP rejects the IPL request coming from the host. The MOSS forces an IML as if it were requested by the MOSS operator, provided the 'IPL detect' signal has been kept by the MIOC.

2. The 'write IPL detect' signal is propagated directly to the MOSS without any intervening CCU logic. It is latched in the MIOC.

This latch is reset either by the MOSS level 1 microcode when initiating the IPL procedure, or by the hardware system reset of the controller.

The information is kept until one of the two above events occurs. The MOSS does not have to respond to this signal itself on the IPL port channel, but only to start the IPL procedure.

3. The 'write IPL detect' signal causes a level 1 interrupt on the MOSS. During this interrupt, the CCU is stopped and a cancel request is posted to the MOSS supervisor (level 6). The cancel handler not only cancels active tasks but also initiates a resident task, the channel adapter monitor, which runs on level 7.

The channel adapter monitor surveys all installed channel adapters. Its main functions are:

- a. To terminate all active or new channel adapter commands with (CE), DE, UC except for Sense, Sense I/O, or Write IPL.

- b. If a Sense is received it is answered 'not initialized' and a CE/DE status if a Write IPL has not been already received and 'command reject, not initialized', with CE, DE, UE if a Write IPL has been received.
- c. If a Sense I/O is received the channel identification is returned.
- d. If a Write IPL is received it has already been answered with CE by the channel adapter. The channel adapter monitor does nothing on a channel adapter with Write IPL.

For non-IPL port channels the handling is as follows depending on the condition detected on the channel:

For stacked status:

- Monitor for dropping of 'suppress out'.
- Present the status stored in the channel adapter.

For bus out check:

- If initial selection, reset the bus out check only.
- If not initial selection, reset the bus out check and present CE, DE, UC status.

For selective system reset:

- Reset system reset/NSC address active.

For level 1 interrupts:

- The error is logged and the IPL is aborted.
- DE is sent to the IPL port channel.
- The controller is reset, thus disabling all channel adapters.

For halt I/O (Interface Disconnect):

- The MOSS does not know the status of ESC operations so it does not present any status to interface disconnect.
- If the interface disconnect is for the NSC, and if 'NSC address active' is set, an ending status (CE), DE, UC is presented.

Note: The channel adapter monitor task is called whenever a CCU control program is running when a re-IPL is requested, except for a re-IPL due to a CCU hard check.

The channel adapter monitor calls itself back every 500 ms and monitors all channel adapter interrupts on both levels 3 and 4 of the CCU. It is deactivated by IPL phase 2 when control is given to the CLDP, and when the CCU and IOC bus test runs in phase 1.

The IPL application is then loaded. For a reinitialization of the controller, phase 1B is loaded. It causes a run of the CCU and IOC bus test diagnostics. Phase 2 then loads the CLDP and gives control to it. Initialization then continues with phases 3 and 4.

If the MOSS is down, the Write IPL detect is ignored by the MOSS. In this case, the NCP must reject the IPL request by presenting DE, UC then Command Reject to the following Sense.

The channel adapter hardware always answers with an immediate CE to a Write IPL command. The MOSS accepts the first and rejects any other conditional IPL by answering Sense with 'not initialized' and CE, DE if first or 'not initialized' and CE, DE, UE status if not first. Write IPL is handled as follows:

- If no re-IPL is in progress, the MOSS level 1 starts the initialization
- If a re-IPL is in progress (up to the end of CLDP: 'NCP loaded' in mailbox or CLDPabend) the Write IPL is ignored on the MOSS side. It is handled by CLDP, which rejects any subsequent Write IPL with DE, UC and answers the following sense command with 'command reject, not initialized'.

CLDP also rejects any conditional IPL (Sense) when an IPL port has been accepted. This rejection is made with 'not initialized', CE, DE, UE.

Note: All commands received on an ESC subchannel, with the exception of Sense, are ignored; however, interrupts are reset. Sense is answered with timeout no matter what the preceding command was.

IPL Exchanges over Channel IPL Port


This figure indicates the sequence of loading a control program into the 3725 over a channel IPL port when an IPL has been started, except when the IPL is initiated from the host.

When the IPL is initiated from the host, the DE, UC, and sense are not sent by the 3725, but the remaining sequences are the same.

During and IPL, the responder is CLDP in the 3725. The host system can start sending the control program to the 3725 as soon as the CLDP has been loaded (end of IPL phase 2). The host continues sending the remainder of the control program to the 3725 through IPL phase 5.

For events that cause an IPL, see "Initialization Requests" on page 6-060.

IPL EXCHANGE MECHANISM (CHANNEL IPL PORT)



Notes:

- Refer to Chapter 7 of the 3725 Problem Determination and Extended Services for a description of the IPL progress messages that appear on line 3 of the machine status area.
- FF4 is displayed only if a Write IPL command has not been received from the host before the scanners are IMLed.
- FF6 is displayed only during an IPL or dump over a link IPL port.
- On line 2 of the machine status area, X72: XXXXXX indicates the progression of the IPL by displaying the CCU storage addresses. The X'72' contents increment until the IPL is complete.


Dump Exchanges over Channel IPL Port

DUMP EXCHANGE MECHANISM (CHANNEL IPL PORT)

This figure indicates the sequence of dumping the storage contents of a 3725 after a control program abend via a channel adapter. After the abend MOSS loads CLDP and CLDP is the responder during the dump sequence. If a dump is initiated from the host with a control program still active (no abend), the DE, UC, and sense are not sent by the 3725 but the remaining sequences are the same.


The dump can proceed as soon as CLDP has been loaded (end of IPL phase). The dump continues until the last read command is received by CLDP. The C is then ready to receive another dump or program load sequence. The hex display remains FF5 after the dump is completed.

Caution: After a control program abend, a control program dump may be taken. MOSS console or operator panel switches should not be used before or during the dump.



Notes:

- Refer to Chapter 7 of the 3725 Problem Determination and Extended Services for a description of the IPL progress messages that appear on line 3 of the machine status area.
- FF4 is displayed only if a Write IPL command has not been received from the host before the scanners are IMLed.
- On line 2 of the machine status area, X72: XXXXXX indicates the progression of the dump by displaying the CCU storage addresses. The X'72' contents increment until the dump is complete, that is, the Dump Complete message appears on the host console.



IPL Exchanges over Link IPL Port


The figure on the following page indicates the sequence of loading a control program into a link-attached 3725 over a link IPL port. The CLDP is the responder in the link-attached 3725. The control program has to be already loaded in the channel-attached 3725.

IPL phases 0 through 3 are not shown, since IPL phase 4 has to be entered before an IPL over a link can take place (scanners must be IMled). Refer to pages 6-070 and 6-090 for descriptions of IPL phases 0 through 3 and expected hex displays. Refer to page 6-170 for a trace of a remote load.

The following notes correspond to the note references on the next page.

Notes:

1. Refer Chapter 7 of the 3725 Problem Determination and Extended Services for a description of the IPL progress messages that appear on line 3 of the machine status area.
2. FF5 is displayed only during IPL or over a channel adapter IPL port.
3. On line 2 of the machine status area, X'72': XXXXXX indicates the progression of the IPL by displaying the CCU storage addresses. The X'72' contents increment until the IPL is complete.
4. The NCP with the highest-numbered subarea becomes the primary and generates the SNRM. An SNRM with an X10 may occur before the SNRM/UA.
5. These first four lines of exchange may or may not occur depending upon individual generation parameters.



Remote End Line Trace of Remote Load (Part 1 of 2)

(Note 1)	(Note 2)
IPL local NCP	<u>XID</u> 7E FF BF 24 2C FF F0 00 00 00 00 40 08 00 06 77 01 00 00 00 06 00 00 D9 00 80 E2 7E RIM 7E 50 17 8E B8 7E XID and RIM sequences repeat
Activate local NCP	<u>DISC</u> 7E FF 53 99 90 7E UA 7E 50 73 AC 9D 7E Line activity stops
Activate link to remote	<u>XID</u> 7E FF BF 24 2C FF F0 00 00 00 00 40 08 00 06 77 01 00 00 00 06 00 00 D9 00 80 E2 7E RIM 7E 50 17 8E B8 7E Line activity stops
IPL remote NCP	<u>DISC</u> 7E FF 53 99 90 7E UA 7E 50 73 AC 9D 7E

(Note 3)	(Note 2)			
	<u>SIM</u> 7E FF 17 89 94 7E SIMs may repeat UA 7E 50 73 AC 9D 7E <u>RR</u> 7E 50 11 B8 DD 7E <u>RR</u> 7E 50 11 B8 DD 7E RRs repeat			
(IPL INIT)	<u>I</u> 7E 50 00 1C 00 60 00 30 00 00 15 00 08 0B 80 00 01 02 03 60 31 CC F9 7E <u>RR</u> 7E 50 11 B8 DD 7E			
(IPL INIT RESPONSE)	<u>I</u> 7E 50 30 1C 00 30 00 60 00 00 15 00 06 8B 80 00 01 02 03 0C FD 7E <u>RR</u> 7E 50 31 BA FC 7E <u>RR</u> 7E 50 31 BA FC 7E RRs repeat			
(IPL TEXT)	<u>I</u> 7E 50 22 1C 00 60 00 30 00 00 16 02 08 0B 80 00 01 02 04 60 31 71 4C 01 E4 EA FA 7E <u>RR</u> 7E 50 31 BA FC 7E			
(IPL TEXT RESPONSE)	<u>I</u> 7E 50 52 1C 00 30 00 60 00 00 16 00 06 8B 80 00 01 02 04 EC 4D 7E <u>RR</u> 7E 50 51 BC 9F 7E <u>RR</u> 7E 50 51 BC 9F 7E RRs repeat			
	<table border="0"> <tr> <td style="vertical-align: middle;"> <u>I</u> <u>RR</u> <u>I</u> <u>RR</u> <u>RR</u> </td> <td style="vertical-align: middle; font-size: 2em;">}</td> <td style="vertical-align: middle;"> > The IPL text sequence is repeated as above for the remainder of the program load. </td> </tr> </table>	<u>I</u> <u>RR</u> <u>I</u> <u>RR</u> <u>RR</u>	}	> The IPL text sequence is repeated as above for the remainder of the program load.
<u>I</u> <u>RR</u> <u>I</u> <u>RR</u> <u>RR</u>	}	> The IPL text sequence is repeated as above for the remainder of the program load.		

Remote End Line Trace of Remote Load (Part 2 of 2)

```

(IPL Final)      I      7E 50 00 1C 00 60 00 30 00 02 45 00 0C 0B 80 00 01 02 05 60 31 00 04 50 48 DD 5D 7E
                  RR      7E 50 11 B8 DD 7E
(IPL Final Response) I      7E 50 30 1C 00 30 00 60 00 02 45 00 06 8B 80 00 01 02 05 83 D9 7E
                  RR      7E 50 31 BA FC 7E
                  RR      7E 50 31 BA FC 7E
                  XID     7E FF BF 24 2C FF 00 00 00 00 04 00 08 00 06 77 01 00 00 00 06 00 00 D9 ..... 00 80 E2 7E

```

(Note 4) XIDs repeat from local NCP while remote CLDP passes control to remote NCP

```

XID      7E FF BF 24 2C FF 00 00 00 00 04 00 08 00 00 00 01 00 00 00 09 00 00 D9 ..... 00 81 4A 7E
XID      7E FF BF 24 2C FF 00 00 00 00 04 00 08 00 06 77 01 00 00 00 06 00 07 D9 D4 D7 E3 F0 F2
          D3 40 00 00 01 21 00 00 00 30 00 00 07 00 00 00 00 00 31 A57E
SNRM   7E FF 93 95 56 7E
UA     7E 06 73 8B 1A 7E

```

Notes:

1. These first four lines of exchange may or may not occur depending upon individual GEN parameters.
2. Receive data is shown underscored, for example, XID.
3. Comments between parentheses, for example (IPL Init), are SNA requests or responses.
4. The local and remote NCPs exchange XIDs. The XIDs contain descriptive data about the NCPs including their subarea address. The NCP with the highest subarea address is resolved to become the primary station and transmits a SNRM. The NCP with the lower subarea address becomes the secondary and responds by transmitting a UA. For further details of these records, see Systems Network Architecture Reference Summary, GA27-3136.


2000 2001 2002 2003 2004 2005 2006 2007 2008 2009 2010 2011 2012 2013 2014 2015 2016 2017 2018 2019 2020 2021 2022 2023 2024 2025 2026 2027 2028 2029 2030

Dump Exchanges over Link IPL Port

The figure indicates the sequence of dumping a control program over a link IPL port. In this example, the remote NCP has abended and CLDP must be loaded to act as a responder in the remote. For an example of the trace of a remote dump, see page 6-190.

Notes:

1. FF5 is displayed only during IPL over a channel adapter.
2. FF6 is displayed during the dump and dump completion. The CLDP is then ready to receive another dump or load sequence.
3. Refer to Appendix A of the 3725 Operating Guide for a description of the IPL progress messages in the machine status area.
4. On the 3727 screen, X'72' indicates the progression of the dump by displaying addresses that increment until the dump is complete.



Remote End Line Trace of Remote NCP Abend and Dump Transfer (Part 1 of 2)

Any normal line activity may be taking place when the remote NCP abends
All line activity stops while CLDP is being loaded in the remote 3725 and the local NCP is timing out

(Note 2)

```
Local NCP Error Recovery DISC 7E FF 53 99 90 7E
                          UA 7E F9 73 4B E5 7E
                          XID 7E FF BF 24 2C FF F0 00 00 00 00 40 08 00 06 77 01 00 00 00 06 00 00 D9 ..... 17 69 C0 7E
Remote CLDP Req. Initialization RIM 7E F9 17 69 C0 7E
```

Local NCP notifies host of lost line

Host displays console message that remote outage has occurred

Host operator enters dump request for remote NCP

```
(Note 1) SIM 7E FF 17 B9 94 7E
          SIM 7E FF 17 B9 94 7E
          UA 7E F9 73 4B E5 7E
          RR 7E F9 11 5F A5 7E
(Dump Init) RR 7E F9 11 55 A5 7E
            I 7E F9 00 1C 00 60 00 30 00 02 4A 00 08 0B 80 00 01 02 06 60 31 81 89 7E
            RR 7E F9 11 5F A5 7E
(Dump Init Response) I 7E F9 30 1C 00 30 00 60 00 02 4A 01 92 8B 80 00 01 02 06 00 10 08 01 00 00 1B BA 00 00
                   00 00 00 01 CC C0 00 00 44 00 00 00 1E 4C 00 00 00 1D 00 01 CB FC 00 00 ..... 00 6A EB 7E
                   RR 7E F9 31 5D 84 7E
                   RR 7E F9 31 5D 84 7E
```

RRs may repeat

```
(Dump Text) I 7E F9 22 1C 00 60 00 30 00 02 4B 00 0E 0B 80 00 01 02 07 60 31 00 00 00 00 02 00 04 0E 7E
            RR 7E F9 31 BA FC 7E
(Dump Text Response) I 7E F9 52 1C 00 30 00 60 00 02 4B 02 06 8B 80 00 01 02 07 71 4C 01 AA 71 ..... 00 2A BA 7E
                   RR 7E F9 51 4A 92 7E
```

Dump text sequences repeat for the remainder of remote storage

```
(Dump Final) I 7E F9 AA 1C 00 60 00 30 00 0A 4B 00 08 0B 80 00 01 02 08 60 31 46 B9 7E
            RR 7E F9 B1 B2 78 7E
(Dump Final Response) I 7E F9 DA 1C 00 30 00 60 00 0A 4B 00 06 8B 80 00 01 02 08 B2 65 7E
                   RR 7E F9 D1 B4 1B 7E
                   RR 7E F9 D1 B4 1B 7E
```


All line activity stops and host console displays message that dump is complete

Remote End Line Trace of Remote NCP Abend and Dump Transfer (Part 2 of 2)

```
(Dump Final      I      7E F9 AA 1C 00 60 00 30 00 0A 4B 00 08 0B 80 00 01 02 08 60 31 46 B9 7E
                 RR      7E F9 B1 B2 78 7E
(Dump Final      I      7E F9 DA 1C 00 30 00 60 00 0A 4B 00 06 8B 80 00 01 02 08 B2 65 7E
Response)       RR      7E F9 D1 B4 1B 7E
                 RR      7E F9 D1 B4 1B 7E
All line activity stops
```

Notes:

1. Comments between parentheses, for example (IPL Init), are SNA requests or responses.
2. Receive data is shown underscored, for example, XID.





Contents

CHAPTER 7. DISKETTE DRIVE

General Description (Part 1 of 2)	7-010	On/Off and Replacement Procedures	7-060
Diskette Description		Diskette Drive AC Power On/Off	
Diskette Use		Diskette Drive AC/DC Power Off	
Inserting the Diskette		Diskette Drive AC/DC Power On	
Removing the Diskette		Diskette Drive Removal/Replacement	
Maintenance			
General Description (Part 2 of 2)	7-011	Diskette Drive Service Check	7-061
Diskette Drive Special Tools		LED, PTX, and Drive Control Card	
Diskette Drive Characteristics		Verification of Correct Operation	
Diskette Functional Characteristics		LED Service Check	
Safety	7-020	Diskette Drive Control Card Service Check	
Personal Safety		PTX Service Check	
Diskette Drive Safety		Removal and Replacement of the Diskette	
Diskette Safety		Drive Control Card	
Diskette Drive Support Logic Locations . . .	7-030	Stepper Motor Removal/Replacement	7-062
3725 Controller - Frame 01		Stepper Motor Removal	
Diskette Drive Detail Locations	7-040	Stepper Motor Replacement	
Theory of Operation (Part 1 of 5)	7-050	Adjustments after Stepper	
Diskette Drive Control Card and MMB		Motor Installation	
Board Connections		Drive Band Replacement and Adjustment . . .	7-070
Theory of Operation (Part 2 of 5)	7-051	Drive Band Service Check	
Interconnection Lines Description		Drive Band Replacement	
Write Data		Drive Band and Head/Carriage Adjustment	
+Inner Tracks		Head/Carriage Service Check	7-080
+Write Gate		Head/Carriage Adjustment	7-090
+Select Head 1		Head/Carriage Replacement	7-100
+Erase Gate		Bail and Solenoid Checks and Adjustments . .	7-110
+Switch Filter		Service Check	
+Write/Erase Enabled		Head Gap Adjustment	
File Data		Bail Adjustment	
+Index		Bail and Solenoid Replacement	7-120
Diskette Sense		Collet/Flat Spring Replacement and Adjustment	7-130
Access Lines 0 and 1		LED and PTX Replacement	7-140
+Head Engage		LED (Light Emitting Diode) Replacement	
Mechanical Operation		PTX (Phototransistor) Replacement	
Typical Device Operation		PTX Installation Notes	
Theory of Operation (Part 3 of 5)	7-052	Drive Motor Removal/Replacement	7-150
Read/Write Operation Principles		Drive Motor Removal	
Write Data		Drive Motor Installation	
FM Encoding		Diskette Drive Motor Fan	
MFM Encoding		Capacitor Replacement	
Write Operation		Diskette Drive Connectors (Part 1 of 2) . . .	7-160
Format Write Operation		Diskette Drive Control Card	
Record (Update) Write Operation		Diskette Drive Control Card Connectors	
Read Data		Diskette Drive Connectors (Part 2 of 2) . . .	7-161
File Data		MMB Cable Connector Test Procedure	
Theory of Operation (Part 4 of 5)	7-053	Diskette Drive Testing	7-170
Read Data: FM Encoded			
Scope Setup			
File Data Signal			
Scope Setup			
Read Data: MFM Encoded			
Scope Setup			
MFM File Data			
Scope Setup			
Theory of Operation (Part 5 of 5)	7-054		
Diskette Drive Test Pins			
Diskette Drive Control Card Cable			
Diskette Drive Control Card			

General Description (Part 1 of 2)

IBM diskette drives are direct access read/write storage devices. They use a flexible magnetic disk as the storage medium.

The diskette drive can read from and write to both sides of a 2D diskette. It can read and write in either frequency modulation (FM) or modified frequency modulation (MFM).

DISKETTE DESCRIPTION

The IBM diskette is a thin flexible disk, permanently contained in its protective jacket. Information is stored magnetically on the diskette surface, which is covered with the magnetic recording material. The diskette is free to turn inside the jacket; as the diskette turns, the inner surface of the jacket cleans the diskette.

The diskette jacket has three holes:

- The first (central) hole is used by the drive to turn the diskette.
- The second hole allows the read/write head to make contact with the diskette.
- The third hole allows the photosensor to sense the index hole in the diskette.



For storage, the diskette (in its jacket) can be placed in a protective envelope.

Information is stored on the diskette on a circular path called a 'track'. As the diskette turns, the track passes under the read/write head.


Each side of the diskette contains 77 tracks (tracks 00 through 76). The outside track (track 00) is reserved as a label track, and cannot be used for data. Tracks 75 and 76, the two tracks closest to the center, are reserved as alternate tracks, and can be used only for data if another track becomes damaged. A total of 74 tracks is thus available for data on each side of a diskette 2D.

As the diskette is double sided, the two tracks (one on either side) that are accessible for one position of the read/write heads are collectively referred to as a 'cylinder'.

Each track is divided into 26 'sectors'; each sector can store 256 bytes (except for track 00, side 0, which can store only 128 bytes per sector).




Diskette 2D



DISKETTE USE

Inserting the Diskette

1. Turn the operator knob to the 'open' position.
2. Remove the diskette from its protective envelope.
3. Insert the diskette squarely into the diskette drive with the label facing the knob. The slot for the read/write heads must be horizontal and must enter the drive first, as shown in the figure below:



4. Turn the operator knob to the closed position.

Removing the Diskette

1. Turn the operator knob to the 'open' position.
2. Remove the diskette from the drive.
3. Replace the diskette in its protective envelope.

MAINTENANCE

The diskette drive requires no planned maintenance. Failures in the diskette drive and its interface to the MOSS (DAC card) may be diagnosed with the help of the MAPs in Part 2 of this manual. When an adjustment, service check, or FRU replacement is required, the MAPs refer to maintenance procedures in this section.

Note: The drive may be powered off independently to perform these procedures.

Diskette repair actions can be verified online during MOSS IPL without disturbing controller operations.

The head/carriage assembly, the drive hub, and the pulley are adjusted and tested at the factory. The head/carriage assembly may be changed in the field; the drive hub and the pulley cannot. If the track 40 adjustment surface, or the drive hub and pulley assembly is damaged, the entire diskette drive must be changed.

General Description (Part 2 of 2)

DISKETTE DRIVE SPECIAL TOOLS

- Force gauge (A) (part 460870) to perform the service check or to adjust the drive band tension.
- Timing pin (B) (part 5562019) to perform the service check or to service the read/write head carriage stepper motor pulley. This part is supplied with each drive, and stored on the head cable guide (see page 7-040).
- Clip (C) (part 4240632) to keep the thickness gauge in contact with the track 40 adjustment surface.
- Spring (D) (part 4240631) to keep the head/carriage in place against the thickness gauge when performing the head/carriage adjustments. This part is supplied with each drive.

Note: The spring must match view (E).

DISKETTE DRIVE CHARACTERISTICS

- Diskette type: 51TD on the 3725 controller
- Weight: 5 kg (11 lb)
- Diskette speed: 360 rpm
- Drive motor voltage: 220 Vac, 50/60 Hz. Note however that the drive has enough tolerance to run on any ac input between 180 and 254 Vac. To keep the diskette speed constant at 360 rpm, a different pulley is used for 50 Hz and 60 Hz mains supplies.


DISKETTE FUNCTIONAL CHARACTERISTICS

The format of data on a diskette is changed when the number of bytes per sector is changed. The format used in the 3725 is as follows:

- 256 bytes per sector for all tracks except track 00 on side 0.
- 128 bytes per sector for track 00, side 0. 'E2B 77 tracks per side:
 - Track 00 is the label track.
 - Tracks 1 through 74 are data tracks.
 - Tracks 75 and 76 are alternate tracks.
- Total formatted data storage capacity is 985088 bytes.

The other characteristics of the diskette drive are as follows:

- Data rate: 250 kilobits (31.25 kilobytes) per second, with MF encoding for track 00.
- 500 kilobits (62.50 kilobytes) per second, with MFM encoding.
- Track-to-track seek time: 5 ms, plus 35 ms for the head/carriage assembly to stop. The total seek time is therefore the number of tracks to be moved, multiplied by 5, plus 35 ms.



Safety

PERSONAL SAFETY

- The 3725 provides ac and dc power. When the motor is turning, ac voltages are present on the motor terminals and on the motor capacitor.
- The motor and solenoid cases become hot after continuous use; let the parts cool before servicing them.


DISKETTE DRIVE SAFETY

- The diskette drive may be damaged if it is not operated or serviced correctly. Warning notices in this manual are machine safety precautions.
- Do not use IBM or any other cleaning fluid near plastic parts.
- Do not allow your fingers to come into contact with the recording surface through the read/write head slot; fingerprints may cause read/write errors.
- Never use damaged diskettes in a diskette drive. Diskettes that are physically damaged (creased or bent) or contaminated (by pencil marks, finger marks, or cleaning fluid) can cause data errors, equipment errors, or head damage.


DISKETTE SAFETY

Refer to the figure on the right:


Return a diskette to its envelope whenever it is removed from the diskette drive.




Do not use clips or rubber bands on a diskette.




Do not place diskettes near materials that might be magnetized. Data can be lost from a diskette exposed to a magnetic field.




Do not place heavy objects on diskettes.



Do not expose diskettes to heat greater than 51.5° C (125° F) or direct sunlight.




Do not lay diskettes near food, drink, or ashtrays.



Do not touch or clean diskette surfaces. Contaminated diskettes must be discarded.






Do not use hard-tipped writing instruments, and do not write outside the label area on diskettes.




Diskette Drive Support Logic Locations

3725 CONTROLLER - FRAME 01



Diskette Drive Detail Locations




Theory of Operation (Part 1 of 5)

The diskette drive depends on the MOSS for power, commands, and control.

This section contains theory information about the device connections, the data flow, and the operation of the diskette drive.

DISKETTE DRIVE CONTROL CARD AND MMB BOARD CONNECTIONS

The figure below shows the connection lines at connector 01A-A1YR.



Theory of Operation (Part 2 of 5)

INTERCONNECTION LINES DESCRIPTION

Write Data

For each change of the 'write data' signal, the current reverses in the read/write heads, writing the data on the diskette.

+Inner Tracks

The 'inner tracks' line is active from track 44 through track 76. When this line is active, less write current is sent to the read/write head. This is necessary because the inner tracks have a higher bit density, and thus require a lower write current. The same line is also used to increase the read amplifier gain for tracks 44 through 76.

+Write Gate

During a write operation, the 'write gate' line activates the write circuits and deactivates the read circuits. The signal is delayed on the control panel card assembly to prevent bit changes on the diskette surface when the drive is powered on or off.

+Select Head 1

When active, this line selects head 1.

+Erase Gate

The 'erase gate' line activates the tunnel erase circuits during a write operation to erase the edges of the track just recorded. This erasing prevents crosstalk between tracks during later read operations. The signal is delayed on the control panel card assembly to prevent bit changes on the diskette surface when the drive is powered on or off.

+Switch Filter

This line is used in conjunction with the 'inner tracks' signal to correct when bits shift beyond cylinder 60 (for MFM encoding). It is used only during read operations.

+Write/Erase Enabled

When this line is active, either write or erase current has been enabled on the card.

File Data

The 'file data' line is a series of clock and data pulses that together represent the data read from the diskette surface. The VFO circuits supplied by the adapter separate the clock pulses from the data.

+Index


The 'index' line indicates the start of a track. It consists of a 1.5 ms to 3.0 ms pulse occurring every 166.7 ms.

Diskette Sense

When the 'diskette sense' line is activated, it indicates that a diskette type 2 or 2D is in use. The line is not activated by a diskette type 1.

Access Lines 0 and 1

Sequentially activating the access signal lines causes the read/write head to move from one cylinder to the next. The two access line signals (0 and 1) are activated sequentially to move the head inwards (towards the hub) or outwards (away from the hub). The sequence is repeated every 4 cylinders.



+Head Engage

When active, this line causes the read/write heads to load.


MECHANICAL OPERATION

The following figure shows the loading of the two read/write heads of the diskette drive.

1. The diskette is about to be inserted.
2. The diskette is inserted into the diskette guide, closing the knob which clamps the collet (the read/write heads are now much closer to the diskette).
3. The heads are loaded (touching the diskette). The solenoid is activated, the cable pulls the bail, and the bail lowers the head onto the diskette.


The read/write operation takes place. The heads are moved to the desired cylinder of the diskette when the system activates the two stepper motor lines (access lines 0 and 1) in a specific sequence.

4. The heads are released (solenoid deactivated).
5. The operator turns the knob to the open position; the diskette is released and may be removed from the drive.



TYPICAL DEVICE OPERATION

1. The MOSS starts the diskette drive motor.
2. The operator inserts a diskette and turns the operator knob to the closed position. The diskette starts turning as soon as the operator knob is in the closed position. The heads move into position on the diskette surface.
3. Index pulses are sensed once per revolution (166.7 ms). An up level indicates that a diskette is inserted into the drive.
4. The MOSS activates sequentially the two access lines (0 and 1) to move the head/carriage assembly inwards (towards the hub), or outwards (away from the hub) to select the desired cylinder. The two access line states last used to move the carriage remain the same when head movement has stopped.
5. Data from the selected cylinder is valid after 40 ms (minimum time for the head/carriage assembly to come to rest).
6. A head load command can be given before or during a seek to activate the head load solenoid. Data is valid 80 ms after the heads are loaded. The address bytes of the first identifiable ID (identifier) field are then read, thus localizing the heads on the cylinder.
7. Reading or writing may take place 40 ms after seeking to the last cylinder (A) or 80 ms after the heads are loaded.
8. The read/write heads are unloaded after the read or write operation.




Note: Seeking and head loading are not to the index.

Theory of Operation (Part 3 of 5)

READ/WRITE OPERATION PRINCIPLES

Write Data

For each change of the 'write data' signal, the current is switched in the write head, recording the data on the surface of the diskette.




FM Encoding

Frequency modulation (FM) encoding writes data bits 4 us apart. This mode of operation is used on track 00 only, as follows:

Data bit to be recorded	Recorded as:	
	clock bit	data bit
1	1	1
0	1	0

The sequence of bits 0 1 0 1 appears as follows:




MFM Encoding

Modified frequency modulation (MFM) encoding writes data bits 2 us apart. It does not use a constant clock pulse; a clock bit is recorded only when a 0 (no data bit) is immediately followed by another 0. This mode of operation is used on all tracks except track 00, as follows:

Data bit to be recorded	Recorded as:	
	clock bit	data bit
1	0	1
0	(x)	0



Note: (x) is a 0-bit if the preceding bit was a 0-bit, or a 1-bit if the preceding bit was a 1-bit.

The sequence of bits 1 0 1 1 0 0 1 1 appears as follows:




Write Operation

For a write operation, the 'write gate' signal activates the write circuits and deactivates the read circuits. The 'erase gate' signal activates the tunnel erase circuits during a write operation to erase the edges of the data track (E) just recorded. This erasing process prevents crosstalk between tracks during later read operations.



Format Write Operation

The format write operation writes a full track, changing all the ID (identifier) fields, data fields, and gaps. The index to the first ID field gap is 79 eight-bit bytes.




The 'write gate' signal is activated any time between the leading edge of the index pulse (G) and 100 bytes after the leading edge of the index pulse. The 'write gate' signal is deactivated approximately 102 bytes after the leading edge of the next index pulse (H).

The 'erase gate' signal is activated at the same time as the 'write gate' signal. However, the 'erase gate' signal is deactivated 537 us after the 'write gate' signal is deactivated (J).

Record (Update) Write Operation

The record write operation is done only on the data field and its VFO sync field. The ID fields and the gaps are not written.



The 'write gate' signal is activated 316 us after the last ID character is read (K). The 'write gate' signal is deactivated 5 us after the last clock of the 2-bit pad is written (L).

The 'erase gate' signal is activated (M) 221 us after the 'write gate' signal, and is deactivated (N) 537 us after the 'write gate' signal is deactivated.

The writing of the new VFO sync field starts when the 'write gate' line is activated (P).

Read Data

The 'read data' signal is the FM or MFM encoded read head signal; it can be observed at TPAMP 1 and TPAMP 2.

Typical measurements for FM encoding are:

- 125 kHz: 120 to 300 mV (all 0's)
- 250 kHz: 100 to 250 mV (all 1's)

The voltage is higher at the outer tracks because of the higher track speed and the lower bit density.

An all 0's pattern has a higher amplitude and half the frequency of an all 1's pattern.

Typical MFM encoding measurements for the drive are:

- 125 kHz: 120 to 300 mV (alternating 0's and 1's, typical measurements)
- 250 kHz: 100 to 250 mV (all 0's or all 1's, typical measurements)


For MFM, an alternating 0's and 1's pattern has a higher amplitude and has half the frequency of an all 0's or an all 1's pattern.

FILE DATA

The 'file data' signal is a series of clock and data pulses that represent the read data. They are from 150 to 500 ns long, and can be observed at TPH01. The VFO circuits, supplied by the DAC card, separate the clock pulses from the data pulses.

Theory of Operation (Part 4 of 5)

READ DATA: FM ENCODED




Scope Setup

Note: Use Tektronix 453, 454, or similar oscilloscope with x10 probes.

Channel A sweep mode	Normal
Channel A level	+
Channel A coupling	DC
Channel A slope	+
Channel A source	External
Trigger Mode	Normal
Channel 1 volts/division	Add
Channel 2 volts/division	5 mV/cm
Channel 1 input	5 mV/cm
Channel 2 input	AC
Invert	AC
Times per division	Pull out
Connect channel 1 to	2 ms/cm
Connect channel 2 to	TPAMP1
Connect trigger to	TPAMP2
	+Index test pin

Note: The amplitude of the read signal should be from 100 to 250 mV.

FILE DATA SIGNAL




Scope Setup

Note: Use Tektronix 453, 454, or similar oscilloscope with x10 probes.

Channel A sweep mode	Normal
Channel A level	+
Channel A coupling	DC
Channel A slope	+
Channel A source	External
Trigger Mode	Normal
Channel 1 volts/division	Channel 1
Channel 1 input	0.2 V/cm
Times per division	DC
Connect channel 1 to	2 μs/cm
Connect trigger to	+File data
	+Index test pin

Note: Clock pulses every 4 μs. Pulse duration should be between 100 and 500 ns. Pulse amplitude should be between 2.4 and 4.2 volts.

READ DATA: MFM ENCODED




Scope Setup

Note: Use Tektronix 453, 454, or similar oscilloscope with x10 probes.

Channel A sweep mode	Normal
Channel A level	+
Channel A coupling	DC
Channel A slope	+
Channel A source	External
Trigger Mode	Normal
Channel 1 volts/division	Add
Channel 2 volts/division	5 mV/cm
Channel 1 input	5 mV/cm
Channel 2 input	AC
Invert	AC
Times per division	Pull out
Connect channel 1 to	2 ms/cm
Connect channel 2 to	TPAMP1
Connect trigger to	TPAMP2
	+Index test pin

Note: The amplitude of the read signal should be from 100 to 250 mV.

MFM FILE DATA



Scope Setup


Note: Use Tektronix 453, 454, or similar oscilloscope with x10 probes.

Channel A sweep mode	Normal
Channel A level	+
Channel A coupling	DC
Channel A slope	+
Channel A source	External
Trigger Mode	Normal
Channel 1 volts/division	Channel 1
Channel 1 input	0.1 V/cm
Times per division	DC
Connect Channel 1 to	2 μs/cm
Connect trigger to	+File data
	+Index test pin

Note: Clock or data pulses every 2 to 4 μs. Pulse duration should be between 100 and 500 ns. Pulse amplitude should be between 2.4 and 4.2 volts.

Theory of Operation (Part 5 of 5)

DISKETTE DRIVE TEST PINS




DISKETTE DRIVE CONTROL CARD CABLE

Test Points	Line Names
THA01	Diff Read B
THA02	No Pin
THA03	Diff Read A
THA04	-High Gain
THA05	-Disable Stepper Motor
THA06	+14V
THA07	Access Clamp Voltage
THA08	Oscillator

Test Points	Line Names
TPB07	D1 PTX
TPC01	+Access 0
TPC02	+Inner Tracks
TPC03	-5 Vdc
TPD01	+Access 1
TPD02	+Switch Filter
TPE01	+Index
TPF01	+Diskette Sense
TPG01	+Write/Erase Enabled
TPH01	+File Data
TPLD2	D2 LED Voltage
TPLD1	D1 LED Voltage
TPAMP2	Preamp IP2
TPAMP1	Preamp IP1
TPCT0	Center Tap Head 0
TPCT1	Center Tap Head 1

Test Points	Line Names
TPA01	MC-3
TPA02	MC-1
TPA03	MC-2
TPA04	MC-0
TPA05	Ground
TPA06	+Erase Gate
TPA07	Ground
TPA08	-Head Load
TPA09	+5 Vdc
TPA10	D2 PTX
TPB01	+24 Vdc
TPB02	Ground
TPB03	+Select Head 1
TPB04	+Write Gate
TPB05	+Head Engage
TPB06	Write Data

DISKETTE DRIVE CONTROL CARD



PTXCP PTX Connector Pins
 I/O CP I/O Connector Pins 01C-J1
 LEDCP LED Connector Pins
 SCP Solenoid Connector Pins
 HCP Head Connector Pins
 SMCP Stepper Motor Connector Pins

On/Off and Replacement Procedures

DISKETTE DRIVE AC POWER ON/OFF

1. Remove the controller or service diskette from the diskette drive.
2. Turn off CP5 (1). When CP5 is off, relay K5 turns the 220 V ac to the diskette drive motor off. The dc voltages are not cut.

To turn on diskette drive ac power, turn on CP5.

DISKETTE DRIVE AC/DC POWER OFF

1. Remove the controller or service diskette from the diskette drive.
2. Turn off CP5 (1).
3. Unplug the drive motor cable (4).
4. Remove the attachment cable (2) from the diskette drive control card.

DISKETTE DRIVE AC/DC POWER ON


1. Plug the attachment cable (2) to the diskette drive control card.
2. Plug the drive motor cable (5).
3. Turn on CP5 (1).

DISKETTE DRIVE REMOVAL/REPLACEMENT



1. Remove the controller or service diskette from the diskette drive.
2. Turn off CP5 (1).
3. Unplug the diskette drive motor cable (4).
4. Remove the attachment cable (2) from the diskette drive control card.

At this point of this procedure, ac and dc power voltages to the diskette drive are off.

5. Remove the screws holding the diskette drive, and lift out the drive.
6. Put the new diskette drive in place and fasten the screws to hold it in place.
7. Plug the attachment cable (2) into its socket on the diskette drive control card.
8. Plug the drive motor cable (4).
9. Turn on CP5 (1).



AC and DC Voltage Distribution to Diskette



Diskette Drive Service Check

LED, PTX, AND DRIVE CONTROL CARD VERIFICATION OF CORRECT OPERATION

1. With power on, insert a diskette backwards, but do not close the diskette engaging lever.
2. Connect the negative lead of the multimeter to test point TPA07.
3. Connect the positive lead of the multimeter to test point (4) and then to test point (5). Each of these points should be less than 1 Vdc.
4. Very slowly, pull out the diskette to approximately 25mm (1 in.). The meter reading should change to 2.5 Vdc or more. Repeat the test, if necessary.
5. If the result of this test is correct, the LED, PTX, and drive control card are operating correctly. If the result is not good, check the LED and the control card as follows.

LED SERVICE CHECK

1. Connect the positive lead of the multimeter to test point (6), and then to test point (7). Each of these test points should be between 1 Vdc and 2 Vdc. Any other reading indicates a failing LED.
2. If the LED is failing, replace it (see page 7-140).



DISKETTE DRIVE CONTROL CARD SERVICE CHECK

1. Switch off the ac/dc power from the diskette drive (page 7-060), and disconnect the PTX connector (9).
2. Connect the multimeter, as shown, to measure the positive voltage at test point (4). It should be less than 1 Vdc.
3. Connect one end of a jumper to test point (3). Touch the other end of the jumper, alternately, to test points (2) and (1), several times. The meter reading should now be 2.5 Vdc or more at test point (4) when test point (2) and test point (1) are touched.
4. If the voltage is less than +2.5 Vdc on these test points, the control card should be replaced. To replace the control card, see this page.

5. If the voltage is correct, connect the PTX connector (9).
6. Switch on ac/dc power to the diskette drive.


PTX SERVICE CHECK

If the LED and the Diskette Drive Control Card Service Checks have correct results, but the verification of correct operation for the LED, PTX, and Drive Control Card has bad results, replace the PTX (see page 7-140).



REMOVAL AND REPLACEMENT OF THE DISKETTE DRIVE CONTROL CARD

1. Switch off the ac/dc power from the diskette drive (page 7-060).
2. Remove the six connectors (1) from the control card.
3. Loosen the two retainer screws (2) and turn the two retainers (3) outward until they are no longer in the path of the control card.
4. Remove the control card (4).
5. Install a control card in place of the removed one.
6. Turn the two retainers inward slightly until they prevent the card from moving.
7. Tighten the two retainer screws.
8. Reinstall the six connectors on the control card.
9. Power on the system.



Stepper Motor Removal/Replacement

STEPPER MOTOR REMOVAL

1. Switch off the ac power from the diskette drive, and open diskette drive gate (see page 7-030).
2. Remove the head signal cable connector (2) and the head cable guide (8).
3. Remove the stepper motor connector (1).

Warning: The drive band can be easily damaged.

4. Remove the drive band (14) by removing:

- Screws (15), (11), and (12)
- Clamps (16) and (9)


5. Measure (using feeler gauge) the gap (6) between the stepper motor pulley and the casting. Record this figure here:

GAP (6) is _____

6. Now remove:

- Clamp screw (7)
- Stepper motor pulley clamp (13)
- Stepper motor pulley (5)

7. Remove the stepper motor mounting screws (4), then remove the stepper motor (3).




STEPPER MOTOR REPLACEMENT

1. When you place the motor on the casting, locate the motor cable toward the control card.
2. Use the clamp (13) to reinstall the stepper motor pulley (5), with a gap (6) between the pulley and the casting. This gap was recorded in a preceding step.
3. Carefully install the drive band (14) so that you do not damage it. Install the drive band parallel to the carriage bracket (10) (do not tighten screws (11), (12), and (15) yet).

ADJUSTMENTS AFTER STEPPER MOTOR INSTALLATION

To complete the stepper motor installation:


1. Adjust the stepper drive band (see page 7-070).
2. Adjust the head/carriage (see page 7-090).



Drive Band Replacement and Adjustment

DRIVE BAND SERVICE CHECK

Power off ac power from the diskette drive (page 7-060). Move manually the head/carriage within its total range of travel. Check the band movement to ensure that it remains parallel to the edge of the pulley (1).



DRIVE BAND REPLACEMENT

1. Power off the ac/dc power from the diskette drive (page 7-060), and open the diskette drive gate.
2. Remove the head cable connector and the head cable guide, and note the cable routing for replacement later.
3. Remove the drive band (9) by removing:
 - Screws (10), (4), and (6)
 - Clamps (11) and (2)


WARNING

The drive band can be easily damaged. Be very careful to avoid damaging the band when you are removing and installing it.

4. Be sure that the band is reinstalled parallel to the pulley (1) and the carriage bracket (3). Do not tighten screw (6) yet.

DRIVE BAND AND HEAD/CARRIAGE ADJUSTMENT



1. Power off the ac/dc power from the diskette drive (page 7-060) remove the head cable connector and cable guide, and note the cable routing for replacement later.
2. Insert a strip of clean paper between the read/write heads to prevent damage to the heads.



Note: If the band does not remain parallel while you are following the procedures for tightening screws (4), (6), and (10), loosen the screws (4), (6), and (10) and begin again.

3. Loosen screws (4), (6), and (10).
4. Block the head/carriage approximately 25 mm (1 inch) from the casting as shown (12) (you can use a screwdriver handle for this).
5. Pull on the loose end of the band at (7) with a force of 1.1 ± 0.11 kg (2.5 ± 0.25 pounds) and tighten screw (10) (use a force gauge, part 460870). Check to be sure that the band remains parallel to the edge of the pulley (1).
6. Move manually the head/carriage to mid-range (insert the timing pin (8) into the timing hole in the casting to align the head/carriage (5) at track 40). Tighten screw (6). Check that the band remains parallel to the edge of the pulley (1).
7. Move manually the head/carriage to track 0 and tighten the screw (4). Check that the drive band remains parallel to the pulley (1).

Perform the head/carriage adjustment (page 7-090).









Head/Carriage Service Check

1. Power off the ac power from the diskette drive, and open the diskette drive gate (see page 7-060).
2. Remove the head cable guide (1) (note the head cable routing, for reference later).
3. Remove the timing pin from its storage location B (see page 7-040). Install a jumper (6) between TPA05 and THA05 to disable the stepper motor
4. Manually move the head/carriage (8) to approximately align the timing pointer (12) with the timing block.
5. Insert the timing pin (2) through the pulley (3) and into the timing hole in the casting and then remove the timing pin.
6. Install a jumper between (7) and (5) to cause the stepper motor to move the carriage to cylinder 40.
7. Remove and insert the timing pin (2) to ensure that it passes freely into the timing hole in the casting. If it does not, adjust the head/carriage (see page 7-090).
8. Remove the timing pin (2). Move the end of the jumper at (5) to (4). This moves the head to cylinder 39. Verify the cylinder 39 position by checking for 'no gap' (10) between the timing pointer (12) and the timing block.

9. Move the jumper from (4) to (5). DO NOT use a timing pin. Use a dental mirror to ensure the alignment of the timing holes in the pulley and the casting. When these holes are aligned the motor and pulley are at cylinder 40
- Note:** Because of the torque characteristics of the stepper motor, you can do the following service checks only once. If you are not sure of the results of the following checks, start again at the beginning of this service check to ensure correct results.
10. To verify that the head/carriage is correctly positioned for cylinder 40:
 - a. Visually check the head/carriage (for no movement), as you insert a 0.483 mm (0.019 in) thickness gauge (9).
 - b. Visually check for slight movement of the head/carriage, as you insert a 0.553 mm (0.021 in) thickness gauge (9).

If the results of the two preceding checks are not correct, adjust the head/carriage (see page 7-090).
 11. If adjustment is not needed, install the head cable guide (1) and ensure that the head/carriage moves freely.
 12. Remove all jumpers installed for this service check.
 13. Return the timing pin to its storage location (see page 7-040).
 14. If you replaced the head/carriage, perform the bail and solenoid service check (page 7-110).

Diskette Drive Control




Head/Carriage Adjustment



This adjustment synchronizes the movement of the head/carriage with the stepper motor.

1. Power off the ac power from the diskette drive, and open the diskette drive gate (see page 7-060). Install a jumper (8) to disable the stepper motor.
2. Remove the head cable guide (1) (note the head cable routing, for reference later), and measure (using feeler gauge) the gap (6) between the stepper motor pulley 5 and the casting. Record this figure here:




GAP (6) is _____
3. Insert the timing pin (4) (using the straight end) through the pulley (5) and into the timing hole in the casting (move the head/carriage, as necessary, to do this).
4. Install a jumper between (9) and (7) to electrically lock the stepper motor to move to track 40.
5. Adjust the pulley-to-casting gap (6) (as recorded in a previous step) and tighten the clamp screw (3). When tightening the screw (3), ensure that the outer edge of the clamp is approximately even with the end of the stepper motor shaft.



6. Ensure that the timing pin (4) passes freely through the pulley and into the timing hole in the casting. Remove the timing-pin (4).
7. Loosen the screws (13).
8. Insert a 0.50 mm (0.020 in.) thickness gauge at (12) and secure with clip (11).
9. Use the carriage pressure spring (10) to push the head/carriage lightly against the thickness gauge.
10. Tighten the clamp screw (13).
11. Remove the thickness gauge and move the end of the jumper from (7) to (6) (to cause the stepper motor to move to track 39). Verify the track 39 position by checking for a 'no gap' (14) between the timing pointer (15) and the timing block.
12. Power off the dc drive power and remove all jumpers (see page 7-060).
13. Manually move the head/carriage all the way, in both directions, to check the drive band (2). If the drive band does not remain parallel to the edge of the pulley, begin with the drive band adjustment described on page 7-070.



Note: Ensure that the stepper motor clamp is fully on the stepper motor shaft before it is tightened.



Head/Carriage Replacement

1. Power off the ac/dc power from the diskette drive and open the diskette drive gate (see page 7-060).
2. Remove the diskette drive (see page 7-060).
3. Remove the head signal cable connector (2).

Caution

The drive band can be easily damaged or beat.

4. Remove the cable guide (1).
5. Remove the drive band (8) by removing screws (4), (7), and (9). Notice the position of the band and clamp for proper replacement.
6. Remove the carriage bracket (3) by removing screws (6).
7. Insert clean paper between the read/write heads to prevent damaging them.
8. Remove the guide rod (5).
9. Carefully lift and turn the head/carriage to remove it from the remaining guide rod (do not let the read/write heads hit each other).



Replacement Notes:

While replacing the head/carriage, ensure that:

1. A strip of clean paper is inserted between the heads to prevent damaging them.
2. The guide rod holding screws are aligned with the notches in the guide rods.

Additional procedures needed:

- 'Drive Band Replacement', page 7-070.
- 'Drive Band Adjustment', page 7-070.
- 'Head/Carriage Adjustment', page 7-090.



Bail and Solenoid Checks and Adjustments


SERVICE CHECK

1. Power off the ac power from the diskette drive, and open the diskette drive gate (see page 7-060).
2. Insert a diskette and close the diskette engaging lever (1).
3. Install jumper (2) to activate the head load solenoid and jumper (3) to deactivate the stepper motor, and power on the ac power.

Caution


The solenoid case becomes hot after continuous use.

4. Check bail gap (6). Move the head/carriage from one end of the bail to the other and check the gap at both ends of the bail.
5. If the gap (6) is not correct, adjust the head gap.
6. Remove the jumpers (2) and (3), open the diskette engaging lever again, remove the diskette, and close the diskette engaging lever again.
7. Visually check the gap (4) between the head surfaces. If the gap is not correct, adjust it.
8. If both the bail gap and the head gap are correct, open the diskette engaging lever and close the diskette drive gate.



HEAD GAP ADJUSTMENT

1. Power off the ac/dc power (see page 7-060) and remove diskette from the diskette drive, and loosen the bail lever screw (7) enough to allow the lever (8) to move. Close the diskette engaging lever.
2. While looking into the diskette insertion slot, move lever (8) until the heads just touch.
3. If the lever has location marks, notice the relative position of the marks and the alignment edge (9). Then move the lever (8) one space clockwise and tighten the lever screw (7). Check the gap (4) and repeat the adjustment as necessary.
4. If the lever does not have location marks, move the lever until gap (4) is correct. Check visually.
5. Perform the bail adjustment.



BAIL ADJUSTMENT



1. Power off the ac power (see page 7-060) from the diskette drive, insert a diskette, and turn the diskette engaging lever (1) to close.
2. Install jumpers (2) and (3), and power on the ac power.

Caution


The solenoid case becomes hot after continuous use.

3. Loosen solenoid locking screw (5), and turn the solenoid in the mounting bracket to adjust the bail gap (6) between the head load arm and the bail (do not allow the plunger and cable to twist).
4. Tighten the solenoid locking screw, and check the bail gap (6) with the head/carriage at each end of the bail. If it is not correct, adjust it again.
5. Remove the diskette from the diskette drive.
6. Power off the ac/dc power from the diskette drive, and remove jumpers (2) and (3).


Head Load Solenoid Deactivated



Head Load Solenoid Activated




Head Load Arm



Bail and Solenoid Replacement

Do this before replacing the bail or solenoid:

1. Power off the ac/dc power from the diskette drive (page 7-060), and insert a strip of clean paper between the read/write heads (9) to prevent damage to the heads.



2. Slightly push in on bail (6) and disconnect eyelet (10) from the hook.
3. Loosen, but do not remove, screw (4) (some models have a nut that falls into the diskette drive if the screw is removed).
4. Notice the position of the spring (7), then remove the pivot rod (5) (the rod is held by a screw (4)).
5. Slide the bail (6) out from under the head load arm (8).


Warning:

Be careful to avoid letting the heads hit together; this can DAMAGE THEM.

6. When you install the bail (6), ensure that:
 - a. The cable eyelet crimp (11) is facing out.
 - b. The bail return spring is in position.
 - c. The bail mounting screw (4) is tightened.



TO REPLACE the solenoid:

1. Remove the drive belt (3).
2. Remove the solenoid signal cable connector (2).
3. Remove the solenoid, bracket, and cable as one unit.
4. Loosen the solenoid locking screw (1) and unscrew the solenoid from the bracket.
5. When you replace the assembly, ensure that:
 - a. The solenoid is connected to the diskette drive control card.
 - b. The drive belt is installed.
 - c. The cable eyelet crimp (10) is facing out.
 - d. The cable is on the solenoid idler.
6. Perform the 'bail and solenoid service check', page 7-110.



Collet/Flat Spring Replacement and Adjustment

1. Power off the ac/dc power from the diskette drive (see page 7-060).
2. Insert a strip of clean paper between read/write heads (1) to protect the heads.
3. Turn the diskette engaging level (13) to the closed position.



Note: When you install the collet/flat spring (2), ENSURE that:




- The cable eyelet crimp (10) is facing out.
- The bail return spring (8) is in position.
- The bail mounting screw (4) is tightened.

4. Push in slightly on the bail (7) and disconnect the eyelet (5) from the hook.
5. Loosen, but do not remove, screw (4) (some models have a nut that falls into the diskette drive if the screw is removed).
6. Note the position of the spring (8), then remove the pivot rod (6) (the rod is held by screw (4)).
7. Slide the bail (7) out from under the head load arm (9).

Warning: Be careful to avoid letting the heads hit together; this can DAMAGE THEM.

8. Slide the rollers (3) off the actuator rod.
9. Remove the collet/flat spring assembly (2).
10. Bend the flat spring at (11) to adjust the collet position.

Warning: Too much binding will damage the spring.



LED and PTX Replacement

LED (LIGHT EMITTING DIODE) REPLACEMENT

1. Power off the ac/dc power from the diskette drive (see page 7-060).
2. Remove LED mounting screw (1).
3. Disconnect LED connector (2). Notice the LED cable routing and pull the connector back through the cable routing holes to remove the LED assembly.

PTX (PHOTOTRANSISTOR) REPLACEMENT

1. Ensure that the diskette drive ac/dc power is switched off. See page 7-060.
2. Remove the six signal cable connectors attached to the control board (3).
3. Loosen the control retainer screws (4), turn the retainers and remove the board.
4. Push the bail (10) inward, slightly, and remove the cable eyelet (9) from the hook.
5. Insert a trip of clean paper between the read/write heads to protect the heads.
6. Remove the diskette guide mounting screws (8).
7. Remove the diskette guide (5) by lifting it up and carefully sliding the bail (10) from under the head load arm (11).



Caution: Do not allow the heads to hit together, causing damage.

8. Remove the PTX mounting screws (7) and remove the PTX assembly (6).

PTX INSTALLATION NOTES

When you install a phototransistor (PTX), ensure that:

1. The cable eyelet crimp (9) is facing out.
2. The cable is on the solenoid idler.
3. All signal cable connectors are connected and seated.



Drive Motor Removal/Replacement

DRIVE MOTOR REMOVAL

1. Power off the ac power from the diskette drive (page 7-060),
2. Open the diskette drive gate and disconnect the drive motor cable (1).
3. Remove the drive belt (9).
4. Loosen the setscrew (8) and remove the pulley.
5. Remove the motor mounting screws and washers (11), then remove the motor.

DRIVE MOTOR INSTALLATION

1. Hold the ac drive motor in place and loosely install the mounting screws and washers (11).
2. Use the drive motor pulley (7), to center the motor shaft in the casting hole, and tighten the motor mounting screws.
3. Slide the drive motor pulley out of the casting hole and tighten the pulley setscrew (8) (locate the pulley so that the wrench is against the casting when you tighten the setscrew).

DISKETTE DRIVE MOTOR FAN


If the motor has a fan, place the fan and the pulley on the motor shaft so that there is a 0.5 ± 0.1 mm clearance between the fan and face of the motor (at the shaft).

CAPACITOR REPLACEMENT

1. Power off the ac power from the diskette drive (page 7-060).
2. Disconnect ac motor power cable (1).
3. Remove insulator cap from capacitor terminals (6).


Warning: High voltage may be present at the capacitor's terminals.

4. Discharge the capacitor (4) by shorting both terminals together using a large screwdriver with an insulated handle.
5. Remove capacitor leads (5) from capacitor terminals.
6. Remove screw and capacitor bracket assembly (2).
7. Reinstall new capacitor (2) with the red dot positioned (5) at the top.
8. Reinstall motor capacitor leads on capacitor (lead 2 and 3 on top terminals and lead 1 on the bottom terminal).
9. Reinstall insulator caps (6) on capacitor terminals.
10. Replug ac motor power cable (1).
11. Restore ac power to the diskette drive (page 7-060).



Diskette Drive Connectors (Part 1 of 2)

DISKETTE DRIVE CONTROL CARD



Legend:
 PTXCP PTX Connector Pins
 I/O CP I/O Connector Pins 01C-J1
 LEDCP LED Connector Pins
 SCP Solenoid Connector Pins
 HCP Head Connector Pins
 SMCP Stepper Motor Connector Pins

DISKETTE DRIVE CONTROL CARD CONNECTORS

(1)	PTX Connector
A01	Diskette 1 Coll (+5Vdc)
A02	Blank
A03	Diskette 1 PTX Emitter
A04	Diskette 2,2D PTX Emitter
A05	Diskette 2,2D Coll (+5Vdc)

(2)	Attachment Connector J1 (I/O CP)
A01	-5 Vdc
A02	Power Supply Ground
A03)
through) Ground
A18)
B01	+5 Vdc
B02	Blank
B03	+24 Vdc
B04	+Index
B05	+Diskette Sense
B06	+Write/Erase Enabled
B07	+File Data
B08	+Inner Tracks
B09	+Erase Gate
B10	+Access 0
B11	+Select Head 1
B12	NC
B13	+Access 1
B14	+Write Gate
B15	+Head Engage
B16	+Switch Filter
B17	Write Data
B18	NC


(3)	LED Connector
A01	Diskette 2,2D Ground
A02	Blank
A03	Diskette 2,2D Ground
A04	Blank
A05	Diskette 1 Ground
A06	Diskette 1 Anode

(4)	Solenoid Head Load Connector
A01	NC
A02	Blank
A03	+Head Load
A04	-Head Load

(5)	Head Connector
A01	NC
A02	Blank
A03	Head 0 Read/Write Coil
A04	Head 0 Center Tap
A05	Head 0 Read/Write Coil
A06	Head 0 Erase
A07	Head 0 Erase Common
A08	Ground
A09	Ground
A10	Head 1 Erase Common
A11	Head 1 Erase
A12	Head 1 Read/Write Coil
A13	Head 1 Center Tap
A14	Head 1 Read/Write Coil

(6)	Stepper Motor Connector
A01	+24 Vdc
A02	Blank
A03	MC-3
A04	MC-2
A05	MC-1
A06	MC-0

Test Points	Line Names
TPA01	MC-3
TPA02	MC-1
TPA03	MC-2
TPA04	MC-0
TPA05	Ground
TPA06	+Erase Gate
TPA07	Ground
TPA08	-Head Load
TPA09	+5 Vdc
TPA10	D2 PTX
TPB01	+24 Vdc
TPB02	Ground
TPB03	+Select Head 1
TPB04	+Write Gate
TPB05	+Head Engage
TPB06	Write Data
TPB07	D1 PTX
TPC01	+Access 0
TPC02	+Inner Tracks
TPC03	-5 Vdc
TPC04	+Access 1
TPD01	+Switch Filter
TPE01	+Index
TPF01	+Diskette Sense
TPG01	+Write/Erase Enabled
TPH01	+File Data
TPLD1	D1 LED Voltage
TPLD2	D2 LED Voltage
TPAMP1	Preamp TP1
TPAMP2	Preamp TP2
TPCT0	Center Tap Head 0
TPCT1	Center Tap Head 1
THA01	Diff Read B
THA02	No Pin
THA03	Diff Read A
THA04	-High Gain
THA05	-Disable Stepper Motor
THA06	+14 Vdc
THA07	Access Clamp Voltage
THA08	Oscillator



Diskette Drive Connectors (Part 2 of 2)

MMB CABLE CONNECTOR TEST PROCEDURE

Use the following table to check the continuity of the signal cable attaching the MOSS board to the diskette drive control card.

To locate pins on diskette, MMB board connector, and DAC card, see diagram on page 7-050.

	MMB		Diskette		Note 1
	01A-A1YR		01C-J1		Wire No
Note 3	D03		B01		1 (+5 V)
		D11		A01	2 (-5 V)
		D08 Note 2		A02 Note 2	3 (Gnd)
	B04		B04		4
		Bus		A04	T4
	D04		B05		5
		Bus		A05	T5
	B05		B06		6
		Bus		A06	T6
	D05		B07		7
		Bus		A07	T7
	B06		B08		8
		Bus		A08	T8
	D06		B09		9
		Bus		A09	T9
	B07		B10		10
		Bus		A10	T10
D07		B11		11	
	Bus		A11	T11	
B08		B13		12	
	Bus		A13	T12	
B09		B14		13	
	Bus		A14	T13	
D09		B15		14	
	Bus		A15	T14	
B10		B16		15	
	Bus		A16	T15	
D10		B17		16	
	Bus		A17	T16	
Note 4			B03		17

Notes:

1. For signal names, see signal tables in Chapter 4 (cable 15).
2. The cable wires connecting to A02 through A11 and A13 through A17 are terminated at the ground bus located on the connector at 01A-A1YRD08.
3. Cable to MMB socket 01A-A1YR. Refer to page 4-020 for MMB board pin assignments, and to page 7-030 for socket location.
4. Single wire carrying +24 Vdc from primary power box 01N-J1-1.

Diskette Drive Testing

The diskette drive logic and hardware are tested during MOSS IML.

1. Power off the ac power from the diskette drive (page 7-060), and wait at least 10 seconds.
2. Set Function Select switch to MOSS IML, then power on the diskette drive and note the hexadecimal display on the control panel.
3. If the controller initialization is not completed, and a hexadecimal display code is displayed or not, go back to the MIM Part 2, START entries.
4. Wait for the completion of IML (if IML is successfully completed, the diskette drive is operating correctly).
5. If intermittent diskette drive failures are suspected, use the MIM Part 2 main troubleshooting procedure 2 (Chapter 2).



Contents

CHAPTER 8. B/M INSTALLATION AND PREVENTIVE MAINTENANCE

B/M Installation	8-010
Hardware EC/MES Installation	
Microcode and Diagnostic EC Installation	
Preventive Maintenance	8-020
LIC or ICC Move from One Board to Another	8-030
Introduction	
Description of the LIC or ICC Move Phases	
Phase One (Before Moving)	
Phase Two	
Phase Three (Housekeeping/Bring-up)	
Physical Representation of LIC Move	8-035
3725 Model 1	
3726	
3725 Model 2	
Before Moving the LIC(s) or the ICC(s)	8-040
Recording the Machine Configuration	
Testing the Machine Before the LIC or ICC Move	
LIC Move Procedure (Part 1 of 3)	8-045
Step A. DCE Cable Moving	
Step B. Flat Cable Removal	
LIC Move Procedure (Part 2 of 3)	8-050
Step C. LIC Card Move	
Step D. Flat Cable Installation	
Tailgate Connector Installation	
Power On	
Updating the Configuration Data File (CDF) for the LIC	
LIC Move Procedure (Part 3 of 3)	8-055
ICC Move Procedure	8-060
ICC Removal/Installation	
Power On After ICC Card Move	
Updating the Configuration Data File (CDF) for ICC	
Housekeeping (Part 1 of 2)	8-065
Running TSS Diagnostics After LIC or ICC Move Procedure	
Diskette Swap	
Housekeeping (Part 2 of 2)	8-070
General IPL	


B/M Installation

HARDWARE EC/MES INSTALLATION

The following flowchart shows which actions must be performed to install a new EC or an MES.

When you have to install a "Record Purpose Only MES" with specify code 5000, concerning a LIC or ICC move, go to page 8-030.


ECs that require long machine down times are split into several parts. Each of these sequential parts can be installed in less than 2 hours.



MICROCODE AND DIAGNOSTIC EC INSTALLATION

Each EC is installed via a new diskette.

The following flowchart shows which actions must be performed to install a new EC on microcode or diagnostic programs:



Note: The new diskette is probably the cause of the IML error.

Preventive Maintenance

The only preventive maintenance for the 3725/3726 is the following:

Frequency	Check
Six months after installation	Tighten all the screw type connectors of the power system.
As required by the operating environment (six months is recommended in most cases)	Check cooling fans. Check air filters and replace as necessary.
Every 12 months	Check line cord, plugs, terminals, and grounding.

LIC or ICC Move from One Board to Another

INTRODUCTION

- The following installation instruction is to be used only in accordance with a "Record Purpose Only MES Order" specify code 5000. This MES is furnished by IBM for the specific machine type and serial number. It concerns the moving of a hardware part from one place to another (no hardware parts are necessary).
- Before starting, the customer must provide you with the Graphic Configuration File (GCF), described in the Operator's Guide, GA33-0044, under the heading "GCF Printout." This configuration determines the card location and the line address(es) to be removed. The IBM representative may also give you a printout of the new HONE configuration (see 3725 Model 1 Communication Controller, Configuration Guide, SA33-0012, or 3725 Model 2 Communication Controller, Configuration Guide, SA33-0022).
- Normal safety precautions should be observed. Before any physical rework is done make sure that CB1 is turned off on the 3725 and on the 3726, if present. If status 3 machine, see "CE General Safety" guidelines in this manual.
- Reporting: Use reporting code 31.

DESCRIPTION OF THE LIC OR ICC MOVE PHASES

Phase One (Before Moving)

- Record the actual LIC or ICC configuration. The boards to where the LIC(s) or ICC(s) may be moved are:

Machine	Board Location	Board Type	Scanner Number	
			LAB A	LAB B
3725 Model 1	01A-A3	CLAB1	1	
	01B-A2	CLAB2	3	
	01B-A1	LAB		5
	02A-A3	LAB		7
	02A-A2	LAB		9
	02A-A1	LAB		11
	02B-A3	LAB		13
	02B-A2	LAB		15
3725 Model 2	01A-A3	C2LB	1 (for LIC move only)	
	01B-A2	C2LB2	3	
	01B-A1	LAB		5

- With the help of the CDF, the GCF, and HONE configurator, fill in the "From-To" table.
- Run the appropriate diagnostics, to check that the machine operates properly.

Phase Two

WHEN MOVING LICs

See the corresponding "LIC Move Procedure" for detailed instructions on moving LIC cards.

- Record the positions of the card(s), flat cables, and dummy connectors to be moved ("From-To" table).
- Move the flat cables between the LIC(s) and the tailgate connector(s).
- Move the LIC card(s) from one board to another.
- Also move the DCE or direct attached terminal cable(s) on the tailgate.
- Check that, except for LIC2, there is an ICC card on the receiving board, if needed.
- Update the CDF.

WHEN MOVING ICCs

See the corresponding "ICC Move Procedure" for detailed instructions on moving ICC cards.

- Record the position of the card(s) to be moved ("From-To" table).
- Move the ICC card(s) from one board to another.
- On the emptied location(s):
 - Install spacer(s)
 - Remove the clock signal distribution jumpers.
- On the filled location(s):
 - Install the clock signal distribution jumpers.
- Update the CDF.

Phase Three (Housekeeping/Bring-up)


- Run the appropriate diagnostics to check that the machine operates properly again.
- Diskette Swap (update the GCF).
- IPL the machine.

Physical Representation of LIC Move

3725 MODEL 1

3726

3725 MODEL 2



Before Moving the LIC(s) or the ICC(s)

RECORDING THE MACHINE CONFIGURATION

Display the present machine configuration to verify and aid in determining physical position for moving the LIC(s) or ICC(s).
Follow the sequence below:

1. Open machine covers.
 2. Mount the normal service diskette.
 3. On the control panel:
 - Disable all channels: ALL CHANNEL ADAPTERS DISABLED light must be on.
 - Note the position of the POWER CONTROL switch, then turn it to LOCAL.
 - Turn FUNCTION SELECT switch to MOSS IML
 - Press FUNCTION START switch.
 - Wait until "FEF" is displayed on control panel.
 4. On the 3727 operator console, to display the CDF:
 - For a LIC move,
 - Select "UTILITY PGM": Enter "U", press Send
 - Select "CDF": Enter "5", press Send
 - Select "DISPLAY": Enter "3", press Send
 - Select "LAB/CAB": Enter "3", press Send
 - Record the "LIC/Line Installed" portion of the frame; it will be used after CDF update to compare with new configuration.
 - Explanation of the hexadecimal presentation: no hex value = no LIC installed
hex value of '0' thru 'F' = LIC installed
 - For an ICC move,
 - Select "UTILITY PGM": Enter "U", press Send
 - Select "CDF": Enter "5", press Send
 - Select "DISPLAY": Enter "3", press Send
 - Select "LAB/CAB": Enter "3", press Send
 - Select "SCANNER": Enter "5", press Send
 - Enter the scan. numb. Enter "*", press Send
- Refer to "Phase One (Before Moving)" page 8-030.
- Verify on the CDF that the ICC feature is installed. ICC-1 or ICC-2 = 10 (type 1) or 11 (type 2).
 - Explanation of the hexadecimal presentation: See page 2-403.

5. Use CDF display. Compare the CDF with GCF printout and with HONE configuration, to ensure that the proposed LIC or ICC position exists (From), and that the receiving position (To) is empty. Copy the "From - To" table below and fill in the table according to the information collected from this step.

	Board Type (C2LB, or CLAB CLAB or LAB)	Tailgate	Scanner	Board	Card
From					
To					

6. To terminate: press SELN AREA, enter "T", and press SEND.

TESTING THE MACHINE BEFORE THE LIC OR ICC MOVE

Run the diagnostics on the 3727 operator console:

- Select "DIAGNOSTICS": enter "D", press SEND
- Select "TSS", then scanner number:

Enter DIAG=='5', ADP#=='*', press SEND.

(*)= scanner number determined on page 8-030, "Phase One". If LAB B, there are two scanners to test.

If no error found:

- For LIC move follow the "LIC Move Procedure" page 8-045
- For ICC move follow the "ICC Move Procedure" page 8-060

If any error, go to chapter R-3 "Repair Action Code (RAC) Index" in MIM-2 and follow the appropriate procedure.

To terminate: press SELN AREA, enter "T", and press SEND.

LIC Move Procedure (Part 1 of 3)

STEP A. DCE CABLE MOVING

1. Operate the POWER OFF switch of the 3725.

CAUTION

Switch off CB1 in the 3725 and 3726, if present.

2. To remove an external DCE cable:


- Determine the address, and the tailgate connector involved, to disconnect the existing external DCE cable(s).
- Label and unplug the external DCE cable(s) from the tailgate. For one LIC card to be removed, 1 to 4 ports have to be deleted.

1. Remove the cover and the two clamps (part 2194940) from the board.
2. Remove both insulators (part 5729007).
3. Unplug the cable connectors from the top of the LIC card to be removed.
4. Remove the cables from the raceway.
5. Reinstall the clamps and the insulators. Tighten the screws.
6. If some tailgate connectors are installed between the retainer and the LIC position to be moved, label and disconnect the external DCE cables from the tailgate.

STEP B. FLAT CABLE REMOVAL

Using the following table, select the YZ page you need.

3725 Model 1		3725 Model 2	
Board	YZ Page 3725 Vol B01	Board	YZ Page 3725 Vol B01
CLAB1	YZ026	C2LB2	YZ031
CLAB2	YZ031		YZ036
LAB pos 3 A	YZ036		YZ041
LAB pos 3 B	YZ041	LAB pos 3 B	YZ041
3726			
Board	YZ Page 3726 Vol A01		
LAB pos 4-8 A	YZ321		
LAB pos 4-8 B	YZ326		



7. Loosen the two screws (part 1673984) holding the retainer (part 1736746) from the selected tailgate (From), and remove the retainer. Then slide out the tailgate connectors in use and the dummy connectors, if any.
8. Remove the LIC flat cables involved from the tailgate.
9. From the receiving tailgate (To), loosen the two screws (part 1673984) holding the retainer (part 1736746) and remove the retainer. Then slide out the dummy connectors and the tailgate connector, if any.

Note: If some tailgate connectors are installed between the retainer and the LIC position to be installed, label and disconnect the external DCE cables from the tailgate.
10. Install on the same tailgate the tailgate connectors removed in step 7 in the position given by the "From-To" table, and reinstall the tailgate and dummy connectors if previously removed.
11. Install on the "From" tailgate, in place of the tailgate connector removed, the dummy connectors (see "From-To" table), and reinstall the tailgate and dummy connectors if previously removed.
12. Reinstall the retainers (part 1736746) on both tailgates, and tighten the two screws (part 1673984).

LIC Move Procedure (Part 2 of 3)

STEP C. LIC CARD MOVE


- Remove spacer (part 819632, dummy card) from the receiving location (To).
- Remove the LIC card from the location involved (From).
 - Plug spacer part 819632 (dummy card) into this location.
 - If an internal clock circuit was used with this LIC, plug the jumper corresponding to this LIC position to the initial factory plugging (U07 to S09). Refer to page 4-270 for details.
 - Connect the external DCE cables, if disconnected.
 - Close the board cover.
- Plug the LIC card in the new location (To).
- Plug the ICC card, if a direct attachment clock circuit is needed.
 - To select a clock for the line attached to a LIC, plug a jumper from the selected clock pin to the LIC input clock pin (board pin side).
 - Check with the customer or marketing representative for requirements.
Note: This jumper is already installed if ICC feature is present.
 - See the following table for jumper position.

ICC local clock	ICC clock bus on LIC card	LIC input clock pin
2400BPS	U06	S09
4800BPS	U09	S09
9600BPS	U07	S09
19200BPS	S07	S09
245760BPS	M12	S09

These jumpers provide clock signals to terminals attached to the communication controller without modems (direct attached terminals). On the boards, ICC position 1 distributes the clock signals to LIC positions 1 through 4, and ICC position 2 distributes clock signals to LIC positions 5 through 8.

STEP D. FLAT CABLE INSTALLATION

- Remove the two clamps (part 2194940) from the board, and remove the insulators.
- Plug the cable connectors on top of the LIC card (the positioning depends on the LIC type).
- Install the flat cable assemblies in the raceway in their proper order (see page 8-035).
- Wrap the insulator (part 5729007) around all cables.
- Secure each of the two flat cables on gate side with clamp (part 2194940) and with two screws (part 322551) on both places.



TAILGATE CONNECTOR INSTALLATION

Refer to the corresponding YZ page (see "Flat Cable Removal").

- Loosen the two screws (part 1673184); remove the retainer (part 1736746) from the tailgate.
- Locate tailgate connector positions.
- If some tailgate connectors are used in front of LIC position to be installed, label and disconnect external data set cables from tail gate connectors to be moved; then slide out these tail gate connectors from tail gate.
- Remove the dummy tailgate connectors from the positions to be used.
- Install the tailgate connectors in place of the dummy connectors removed.
- Reinstall the tailgate connectors if moved at step 3.
- Reinstall the retainer (part 1736746); tighten the two screws (part 1673984).
- Re-plug the external dataset cable(s) previously removed. For each LIC installed, the ports will be defined according to the line addresses; if necessary see "CDF Display/Update," page 2-402).

POWER ON

Ensure that the normal service diskette is mounted.

On control panel:

- Verify that the FUNCTION SELECT switch is on MOSS IML position.
- Switch on CB1 in the base of the 3725 (and 3726).
- Operate the POWER ON switch.
- Wait until "FEF" is displayed.

UPDATING THE CONFIGURATION DATA FILE (CDF) FOR THE LIC

- On the 3727 operator console:

```
Select "UTILITY PGM":   Enter "U", press SEND
Select "CDF":           Enter "5", press SEND
Select "VERIFY":       Enter "2", press SEND
```

Update the vacant fields where card(s) were installed.

The first screen updates the LIC type (an example follows):

```
CDF - VERIFY OPTION IN PROGRESS.
SCANNER          01
LIC POS          01
DIFFERENCE BETWEEN THE MACHINE AND THE DISKETTE
VALUE FROM THE MACHINE : 00
VALUE FROM THE DISKETTE : 01
TO UPDATE DISKETTE WITH MACHINE VALUE ENTER Y,
OTHERWISE ENTER N
```

If the scanner and the LIC position is the MES position involved: enter "Y"

The second screen updates the cable information (an example follows):

```
CDF - VERIFY OPTION IN PROGRESS.
SCANNER          01
LIC POS          01
CABLE ID
DIFFERENCE BETWEEN THE MACHINE AND THE DISKETTE
VALUE FROM THE MACHINE : 0000
VALUE FROM THE DISKETTE : 1511
TO UPDATE DISKETTE WITH MACHINE VALUE ENTER Y,
OTHERWISE ENTER N
```

If the scanner and the LIC position is the MES position involved: enter "Y"

LIC Move Procedure (Part 3 of 3)

1. At end of verify: CDF is completed and updated on the diskette.
2. If no internally clocked or direct attached lines are installed, skip to step 5.
3. When there are internally clocked or direct attached lines installed:

- Select "CDF": Enter "5" press SEND
Select "DISPLAY/UPDATE": Enter "3" press SEND
Select "SCANNER": Enter "5" press SEND
Enter "SCANNER NUMBER": (selected at step 7 of Machine Configuration Record).

The LIC information is displayed (see pages 2-402 and 2-403).

- To update: press PF1

Move cursor under the installed LIC position, under "C" position of ports which are internally clocked or direct attached, enter:

enter: "1" for internal clock
(business machine clock)

or "3" for direct attachment

continue on all ports of this LIC.

See clock information (C) on various clock types:

0: not defined clock
1: business machine clock
2: external clock
(default for installed cable)
3: direct attachment

- To file, press SEND.

Note: If terminate function is selected before filing updates, the modifications entered are lost.

4. Compare new and old configuration

- Display CDF:

Select CDF: Enter "5", press SEND
Select DISPLAY: Enter "3", press SEND
Select LAB/CAB: Enter "3", press SEND

- Compare with configuration at step 5 of "Machine Configuration Record". A new LIC type installed must appear on "LIC/Line Installed" chart. The hexadecimal value, under L (pos. installed), indicates the ports in use. The hex value is "0" with no external cables installed in any position of the LIC. With external cables installed, the value will vary from "1" thru "F" depending on the number and position of the installed cables. Go to page 8-065 to end the LIC move procedure (Run TSS Diags, Diskette swap, and IPL the machine).

ICC Move Procedure

ICC REMOVAL/INSTALLATION

Using the following table, select the YZ page you need, and determine the ICC "From-To" locations.

3725 Model 1		3725 Model 2	
Board	YZ Page 3725 Vol B01	Board	YZ Page 3725 Vol B01
CLAB1	YZ026	C2LB2	YZ031
CLAB2	YZ031		
LAB pos 3 A	YZ036		
LAB pos 3 B	YZ041	LAB pos 3 A	YZ036
		LAB pos 3 B	YZ041
3726			
Board	YZ Page 3726 Vol A01		
LAB pos 4-8 A	YZ321		
LAB pos 4-8 B	YZ326		

- Operate the POWER OFF switch of the 3725.

CAUTION

Switch off CB1 in the 3725 and 3726, if the 3726 is present.

- Open the board covers.
- Remove the two ICC cards from the location determined above.
- At the "To" location remove the two dummy cards, and plug in the ICC cards previously removed.
- Install the dummy cards in place of the removed ICC cards.
- Remove the jumpers which distribute the clock signals to the LICs (if internal clock distribution), from the emptied ICC position. Then install them into the new position (see "From-To" table).
For speed selection see the table below:

ICC local clock	ICC clock bus on ICC card	ICC input clock pin
2400BPS	U06	S09
4800BPS	U09	S09
9600BPS	U07	S09
19200BPS	S07	S09
245760BPS	M12	S09

See "Clock Select Jumper", page 4-270, if necessary.

- Close the board covers.

POWER ON AFTER ICC CARD MOVE

Ensure that the normal service diskette is mounted.

On control panel:

- Verify that the FUNCTION SELECT switch is on MOSS IML position.
- Switch on CB1 in the base of the 3725 (and 3726).
- Operate the POWER ON switch.
- Wait until "FEF" is displayed.

UPDATING THE CONFIGURATION DATA FILE (CDF) FOR ICC

To update the appropriate fields where ICC cards have been removed/installed, you will use the verify option of the CDF.

- On the 3727 operator console:
Select "UTILITY PGM": Enter "U", press SEND
Select "CDF": Enter "5", press SEND
Select "VERIFY": Enter "2", press SEND

An example of screen that may appear is the following:

```

CDF - VERIFY OPTION IN PROGRESS.
SCANNER          03
ICC-1 TYPE
DIFFERENCE BETWEEN THE MACHINE AND THE DISKETTE

VALUE FROM THE MACHINE : 11
VALUE FROM THE DISKETTE : 00

-TO UPDATE DISKETTE WITH MACHINE VALUE ENTER Y
==>
OTHERWISE ENTER N

```

If the scanner and the ICC position is the MES position involved: enter "Y".
After entering "Y" you will be prompted automatically by the next screen.

```

CDF - VERIFY OPTION IN PROGRESS.
SCANNER          03
ICC-2 TYPE
DIFFERENCE BETWEEN THE MACHINE AND THE DISKETTE

VALUE FROM THE MACHINE : 11
VALUE FROM THE DISKETTE : 00

-TO UPDATE DISKETTE WITH MACHINE VALUE ENTER Y
==>
OTHERWISE ENTER N

```

If the scanner and the ICC position is the MES position involved: enter "Y".
After entering "Y" you will be prompted automatically by the next screen.

```

CDF - VERIFY OPTION IN PROGRESS.
SCANNER          05
ICC-1 TYPE
DIFFERENCE BETWEEN THE MACHINE AND THE DISKETTE

VALUE FROM THE MACHINE : 00
VALUE FROM THE DISKETTE : 11

```

-TO UPDATE DISKETTE WITH MACHINE VALUE ENTER Y
==>
OTHERWISE ENTER N

If the scanner and the ICC position is the MES position involved: enter "Y".
After entering "Y" you will be prompted automatically by the next screen.

```

CDF - VERIFY OPTION IN PROGRESS.
SCANNER          06
ICC-2 TYPE
DIFFERENCE BETWEEN THE MACHINE AND THE DISKETTE

VALUE FROM THE MACHINE : 00
VALUE FROM THE DISKETTE : 11

```

-TO UPDATE DISKETTE WITH MACHINE VALUE ENTER Y
==>
OTHERWISE ENTER N

If the scanner and the ICC position is the MES position involved: enter "Y".
At end of verify: CDF is completed and updated on the diskette.

- Compare new and old configuration: On the 3727 operator console display the CDF:

```

Select "CDF":          Enter "5" press SEND
Select "DISPLAY/UPDATE": Enter "3" press SEND
Select "SCANNER":      Enter "5" press SEND
Select "ALL SCANNERS": Enter "0" press SEND

```

- Compare with the "From-To" table. The ICCs installed must appear on the scanner screen.

To quit press "PF3", then terminate.

To end the ICC removal/installation procedure continue next page.

Housekeeping (Part 1 of 2)

RUNNING TSS DIAGNOSTICS AFTER LIC OR ICC MOVE PROCEDURE

1. Run TSS Diagnostics:
 - For the scanner in which the card(s) are now installed.
 - For the scanner from where the card(s) were removed.
2. On the 3727 operator console:
Select "DIAGNOSTICS":
Enter "D", press "SEND"
Select "TSS", then the scanner number:
Enter DIAG=="5", ADP#=="*", press "SEND"

(*)= scanner number determined in page 8-030 "Phase One".
3. If any error, go to Chapter R-3 "Repair Action Code (RAC) Index" in MIM-2 and follow the appropriate procedure.
4. If no error found, terminate. Press "SELN AREA, enter "T", and press "SEND"

DISKETTE SWAP

Note: Once you have been requested to change diskettes, and until you return to the original diskette, you must not terminate the function. If for any reason you do not want to continue the function, do the following:

- Mount the original diskette.
- Turn FUNCTION SELECT switch to MOSS IML.
- Operate FUNCTION START switch.
- Wait until 'FEF' is displayed in hex display panel.
- Restart the particular diskette swap in progress from the beginning.

1. Copy the normal service diskette onto the spare controller diskette:

- On the 3727 operator console:

Select "UTILITY PGM": Enter "U", press SEND
Select "DISKETTE SWAP": Enter "7", press SEND
Select "SERVICE TO CONTROLLER DISKETTE":
Enter "3", press SEND

The following files will be copied:

MLT ==> Y
CDF ==> Y

- Mount the spare controller diskette; when "CHANGE DISKETTE" is displayed, press SEND.
 - When "MOUNT ORIGINAL DISKETTE" is displayed: mount the normal service diskette (to complete the swap).
 - press "SEND".
 - screen displays: "SWAP COMPLETED"
 - Remove the normal service diskette; put it in the right-hand cover box.
 - Mount the spare controller diskette, and press the FUNCTION START switch.
2. The graphic configuration file (GCF) must be updated by the customer before continuing with the diskette updating procedures.

Refer to 3725 Problem Determination and Extended Services, Chapter 12.

Update the GCF on the spare controller diskette.

Note: If the new installed line is to be used as an IPL port, the IPL ports have to be updated accordingly.

3. Copy the spare controller diskette onto the spare service diskette.

- On the control panel:

- Verify that FUNCTION SELECT switch is on position MOSS IML.
- Press FUNCTION START switch.

- On the 3727 operator console:

Select "MAINTENANCE": Enter "M", press SEND
Select "UTILITY PGM": Enter "U", press SEND
Select "DISKETTE SWAP": Enter "7", press SEND
Select "CONTROLLER TO SERVICE DISKETTE":
Enter "2", press SEND

BER(s) saved on service diskette may be erased. To confirm selection, enter "Y"; else enter "N"==>. Enter "Y" to continue the procedure.

- The following files will be copied:

MLT ==> Y
CDF ==> Y
BER FILE ==> Y
LIC MOVE PROCEDURE (PART 4 OF 4)

- Mount the spare service diskette.

When "CHANGE DISKETTE" is displayed press Send.

When "MOUNT ORIGINAL DISKETTE" is displayed:

Remove the spare service diskette, put it in the right-hand cover box. Mount the spare controller diskette (to complete the swap), and press "SEND".

The screen displays: "SWAP COMPLETED"

4. Copy the spare controller diskette onto the normal controller diskette.

- On the 3727 operator console:

Select "DISKETTE SWAP": Enter "7", press SEND
Select "CONTROLLER TO CONTROLLER DISKETTE":
Enter "1", press SEND

Select the files to be copied:

MLT ==> Y
CDF ==> Y
BER file ==> N
GCF ==> Y
IPL ports ==> N (Y if the IPL ports were updated)
CNTRL PGM PROC ==> N
LDF ==> N
Port swap file ==> N

Press SEND.

Housekeeping (Part 2 of 2)

- Mount the normal controller diskette.
 - Press "SEND"
 - When "MOUNT ORIGINAL DISKETTE" is displayed: mount the spare controller diskette (to complete the swap), and press SEND; the screen displays: "SWAP COMPLETED".
 - Terminate.
- Remove the spare controller diskette; put it in the right-hand cover box.

GENERAL IPL

1. Mount the normal controller diskette.
2. Close machine covers.
3. On the control panel:
 - Turn Function SELECT switch to position NORMAL.
 - Enable all channel interfaces to be used.
 - Operate FUNCTION START switch; observe the 3727 screen:

The screen will display "IPL PHASE 1", "IPL PHASE 2", "IPL PHASE 3".

At phase 3 time, "ALL CHANNEL ADAPTERS DISABLED" light must be off.

When "IPL PHASE 4" is displayed on the 3727, the control panel will display 'FF4'.

The machine will stay in phase 4 until the control program is loaded from the host.
 - If possible, ask the customer to load the control program for this machine.

When "IPL COMPLETE" is displayed on the 3727, the 3725 is operational. The control panel will display '000'.
 - Return the POWER CONTROL switch to its original position.

Note: A new GCF may be printed when NCP/EP is loaded through the host.

Contents

CHAPTER 9. SYSTEM OPERATIONS

System Interrupts	9-010
Examples	
Interrupt Levels	
Message Exchanges	9-030
NSC Address With NCP	
Message Format	
Exchange Sequence	
ESC Address With EP	
Message Format	
Exchange Sequence	
CCU/Scanner Exchanges	9-040
Normal Mode	
Character Mode	
Burst Mode	
Protocol Handling	9-050



System Interrupts

The following figure shows the interrupts raised in the CCU, MOSS, CSP, or TRA.





Examples

1. A PCI condition in the CCU interrupts the CCU itself at level 2, 3, or 4.
2. A 'MOSS Inoperative' condition in the MOSS raises a level 1 interrupt to the CCU.
3. A 'Service to MOSS' condition in the CSP raises a level 4 interrupt to the MOSS.

INTERRUPT LEVELS



Interrupt Levels



Message Exchanges

NSC ADDRESS WITH NCP


Message Format

The channel used is either a byte or block multiplex, or a selector channel. Every message uses a unique address, which is the NSC address. The message format identifier (FID) depends on the environment: FID0 for non-SNA, FID1 for SNA, and FID4 for SNA4.

These messages can be exchanged only if the 3725 control program is NCP, and:

- Between the host and the 3725 on the channel interface
- Between intermediate network nodes (INN) such as 3725 to 3725, or 3725 to 370X.

The message format is as follows:




The FIDx contains the physical unit address to which the data must be sent.

Exchange Sequence

In the following, the host is assumed to initiate an exchange operation with the 3725.

A complete message makes a path information unit (PIU) of the SNA protocol. On the host, the transmit buffers have a defined length and a PIU may need several buffers. Data chaining (DC) points to the next PIU buffer in sequence. Command chaining points to the next write PIU command.



PIU sent from the host

Host	CA	CCU
Write start --->		--> Initial select level 3 <-- Ready
Write PIU1 --->	CE, DE <-----	If NCP/EP wants to send data to host <-- Attention is sent
Write PIU2 --->		
Write break --->		
Read start --->		<-- Status ready
Read NOP --->		

PIU received by the host

Host	CA	CCU
Read Start --->		<-- Attention
Read PIU1 --->		<-- PIU1
Read PIU2 --->		<-- PIU2
Read No-op --->	<----- CE, DE	--- Status ready

A write break indicates a transmit operation end; a No-op indicates a receive operation end. The number of read commands depends on the host buffer resources. There is one read command per buffer, and command chaining between read commands.

ESC ADDRESS WITH EP

Message Format

The channel used must be a byte channel. There is one ESC address for each line. Exchanges are up to 4 bytes. Only data is exchanged, but it can be either control or data characters as all the line controls are performed from the host.


Exchange Sequence

The sequences used depend on the line protocols, the terminal attached, and the code used. The protocols controlled by the access method (BTAM) can be:



- BSC multipoint, point-to-point with contention, and point-to-point switched contention
- Start-stop

Each time a data or control character is to be sent to a particular line, a start I/O command passes the selected line to the EP. The message contents are transparent to EP. In the following example, ESC1 = 7D and ESC2 = 7F.

SIO to 7D



SIO to 7F



CCU/Scanner Exchanges


Each telecommunication line has a transmit and a receive interface. A parameter and status area (PSA) is assigned to each line interface. The PSA is divided into two areas:

- A parameter area (16 bytes) to transfer data from the CCU to the scanner
- A status area (12 bytes) to transfer data from the scanner to the CCU

Exchanges between the CCU and scanners are performed either in normal mode or in character mode.

NORMAL MODE

Normal mode is used for BSC and SDLC. The following figure shows how the PSA is used, and the sequence of actions performed by the CCU and the scanner when a start line or start line initial instruction is issued for a particular line.



CHARACTER MODE

Character mode is used only for start-stop and BSC operations. Performance is degraded as data is exchanged on a character basis. Interrupt processing is necessary between every character.

The sequence of operation is exactly the same as in normal mode except that the parameter area holds the character to be sent on the line, and the status area holds the character received from the line.

BURST MODE

Burst mode is used only for start-stop operations. Data is exchanged by bursts of up to four characters.

Protocol Handling

	Host	CCU
NCP	Access Method: VTAM/TCAM -Transmits PIUs with single command -Receives PIU in one or more commands based on PIU length -Does not directly control polling -One subchannel per NCP -Any type of channel	-Controls polling and link scheduling -Transmits PIUs as single chain of buffers via CSP -Receives PIU in a single buffer chain with intermediate buffer allocation -Passes data to host only when PIU is fully received -Handles ERPs
EP	Access Method: BTAM/ERTAM/TCAM -Controls polling and link scheduling -Transmits data in line code with all control characters -Receives all characters in line code -Handles ERPs -One subchannel per line -Byte multiplex channel only	In Start-Stop: - Exchanges 4 bytes at a time with host - Exchanges one byte at a time with CSP In BSC: - Exchanges one buffer at a time with host and CSP - Reports line hardware errors

		CCU	CSP Microrocode	F E S Modem Change Management Driver Check Survey Serialization/Deserialization
SS	Xmit	Exchange byte per byte		Start-stop bit generation -Underrun management
	Receive	Exchange byte per byte		Start-stop bit deletion Stop check reporting to CSP code -Overrun management
BSC	Xmit	NCP	Control polling Provide chain of buffers to CSP	Generation of control characters Translate if needed Exchange at message level
		EP	Relay data to CSP, one buffer at time With control characters	Exchange at message level
	Receive	NCP	Receive block in a chain of buffers Without control characters	Deletion of control characters Exchange at message level Translate if needed
		EP	Receive data from CSP, one buffer at a time With all control characters	Exchange at message level
SDLC	Xmit	NCP ONLY Control polling Send PIU in a chain of buffers	Insertion of flag: Address and control (FAC) Exchange at frame level	CRC accumulation and SEND NRZI function No ZI function -Underrun management
	Receive	NCP ONLY Receive control frame and information frame in buffer chain Allocate more buffers if needed	Separation of address from control in checking of address Exchange at frame level	CRC accumulation and checking NRZI function Zero deletion function Flag: Abort idle processing

Abbreviations and Glossary

A	ampere	CCMD	current command (storage)	DSx	digit signal 2 to power x		or terminal)
ABEND	abnormal end of task	CCN	communications controller node	DSC	distant station connected	IOC	input/output control
ac, AC	(1) alternating current (2) abandon call (signal) (3) address compare	CCR	compare character register (instruction)	DSR	data set ready (signal)	IOCB	input/output control bus
ACB	adapter control block	CCU	central control unit	DSRS	data signaling rate selection (signal)	IOCS	input/output control system
ACF	Advanced Communication Function	CCUB	CCU board	DTE	data terminal equipment	IOH	adapter input/output halfword (instruction)
ACK	affirmative acknowledgment (BSC)	CCW	channel control word	DTR	data terminal ready (signal)	IOHI	adapter input/output halfword immediate (instruction)
ACLK	adapter clock (card)	CDF	configuration data file	DVB	asynchronous-devices (SNA)	IOIRR	input/output interrupt request register
ACR	add character register (instruction)	CDS	configuration data set (NCP/EP)	DX	duplex (full-duplex)	IML	initial microcode load
ACU	automatic calling unit	CE	(1) customer engineer (WTC term for FE) (2) channel end (channel status)	EBCDIC	extended binary-coded decimal interchange code	INN	intermediate network node
AE	address exception	CELIA	CE latched indicator analytic (card)	EC	engineering change	IPF	instruction pre-fetch
AEK	address exception key			ECC	error checking and correction (card)	IPL	initial program load(er)
AGC	automatic gain control (signal)	CHCW	channel control word	EDE	elementary data exchange	IPR	isolated pacing response (SNA)
AHR	add halfword register (instruction)	CHIN	channel interface (card)	EIA	Electronic Industries Association enquiry (BSC)	IRR	interrupt request removed
AIO	adapter-initiated operation	CHR	compare halfword register (instruction)	ENQ	end of transmission (BSC)	ITB	intermediate text block (BSC)
AIT	average instruction time	CLAB	channel and line attachment board	EOT	emulation program	IVT	isolation verification tests
ALU	arithmetic and logic unit	CLDP	controller load/dump program	EP	emulation program	K	1024 (bytes or words)
AR	(1) add register (instruction) (2) amplifier	CNM	communication network management interface	EPO	emergency power off	KBD	keyboard
ARC1	auto-restart card in unit 01	CNMI	communication network management interface	ERC	error reference code	kbps	kilobits per second
ARC2	auto-restart card in unit 02	CNSL	console	ERP	environmental recording, editing, and printing (program)	kg	kilogram
ARI	add register immediate (instruction)	CP	command processor, control program	EREP	error recovery procedure	kHz	kilohertz
ASCTI	American National Standard Code for Information Interchange	CPA	control panel adapter (card)	ESC	emulation subchannel	ko	not ok
ATTN	attention (3727 operator console key)	CPIT	control program information table	ESCH	emulation subchannel high	L	load (instruction)
		CPM	connection point manager	ESCL	emulation subchannel low	LA	load address (instruction)
		CPT	checkpoint trace	ESD	(1) electrostatic discharge (2) external symbol dictionary	LAB	line attachment board
		CR	(1) compare register (instruction) (2) call request (signal)	ETB	end-of-transmission block character (BSC)	LABA	line attachment board type A
		CRC	cyclic redundancy check	ETX	end-of-text character (BSC)	LABB	line attachment board type B
		CRI	compare register immediate (instruction)	EXP	expected	LABC	line attachment board type C
B	branch (instruction)	CRP	check record pool	FAC	flag address control	LAN	local area network
BAL	branch and link (instruction)	CS	(1) cycle steal (2) communication scanner	FCC	Federal Communications Commission	LAR	lagging address register
BALR	branch and link register (instruction)	CSCW	cycle steal control word	FCPS	final call progress signals (X.21)	LCB	line control block (storage)
BB	branch on bit (instruction)	CSG	cycle steal grant	FES	front-end scanner (card)	LCD	line control definer (storage)
BCC	block check character (BSC)	CSGH	cycle steal grant high	FIC	FRU isolation code	LCOR	load character with offset register (instruction)
BCCW	bit clock control word	CSGL	cycle steal grant low	FM	frequency modulation	LCR	load character register (instruction)
BCL	branch on C latch (instruction)	CSM	communication scanner memory (card)	FNCTN	function (CCU FNCTN) (3727 operator console key)	LCS	line communication status (storage)
BCLC	branch on count (instruction)	CSP	communication scanner processor	FPS	FES parameter/status	LDF	line description file
BCT	branch on count (instruction)	CSP1	communication scanner processor (card) type 1	FRU	field-replaceable unit	LED	light-emitting diode
BER	box error record	CSP2	communication scanner processor (card) type 2	ft	foot	LH	load halfword (instruction)
BG	background	CSR	cycle steal request	GCF	graphic configuration file	LHOR	load halfword with offset register (instruction)
B/M	bill of material	CSRH	cycle steal request high	GPR	general purpose register	LHR	load halfword register (instruction)
bps	bits per second	CSRL	cycle steal request low	GPT	generalized PIU trace	LIB	line interface buffer
BSC	binary synchronous communication	CSS	control subsystem	GTF	generalized trace facility	LIC	line interface coupler
BSM	basic storage module	CSW	channel status word	HDX	half-duplex	LIC1	line interface coupler type 1 (card)
BSMI	basic storage module interconnection (card)	CTS	clear to send (signal)	HDR1	header 1 (diskette)	LIC2	line interface coupler type 2 (card)
BT	branch trace	CTL1	control type 1 (card)	HLIR	high level interface request	LIC3	line interface coupler type 3 (card)
BTAC	branch trace/address compare (card)	CTL2	control type 2 (card)	HSC	high speed channel	LIC4A	line interface coupler type 4A (card)
BTAM	basic telecommunication access method	CVTL	card vendor transistor logic	HW	hardware	LIC4B	line interface coupler type 4B (card)
BUSTERM	IOC bus terminator (card)	CZ	Carry/zero (latch)	HZ	Hertz	LID	line identification
BZL	branch on Z latch (instruction)	C2LB	CLAB in 3725 Model 2	IAR	instruction address register	LLIR	low level interrupt request
C	(1) Celsius (2) control (X.21 signal)	DAC	diskette adapter card	IC	insert character (instruction)	LL2	link level 2 test
CA	channel adapter	DAF	destination address field (SNA)	ICA	integrated communication adapter	LNVT	line vector table (storage)
CAB	channel adapter board	DB	data byte (signal)	ICB	interface control block (storage)	LOGREC	error logging program of access method
CAC	common adapter code	dc, DC	(1) direct current (2) data chaining (channel status)	ICC	internal clock control	LOR	load with offset register (instruction)
CADR	channel adapter driver receiver (card)	DCE	data circuit-terminating equipment	ICT	insert character and count (instruction)	LPDA	link problem determination aid
CADRUk	channel adapter driver receiver type UK (card)	DCF	diagnostic control facility	ICW	interface control word	LR	load register (instruction)
CB	circuit breaker	DCM	diagnostic control monitor	ID	identifier (diskette)	LRC	longitudinal redundancy check
CCA	communication common adapter (card)	DE	device end (channel status)	IFT	internal function test	LRI	load register immediate (instruction)
CCIN	channel-to-CCU interface (card)	DFlx	data flow type x (card) (where x = 1, 4, or 5)	IMB	in mailbox (MOSS)		
CCITT	Comite Consultatif International Telegraphie et Telephone	DIFF	differentiator	IML	initial microcode load(er)		
CCLK	CCU clock (card)	DLO	data line occupied (signal)	in.	inch		
		DMA	direct memory access	IN	input (instruction)		
		DP	digit present (signal)	INN	intermediate network node		
				INOP	inoperative (line, modem, or terminal)		

LSAR	local storage address register	oc	overcurrent	RECFMS	record formatted maintenance statistics	STH	store halfword (instruction)
LSI	large scale integration	OCR	OR character register (instruction)	RECMS	record maintenance statistics	STG	storage
LSR	local storage register (CSP)	OEM	original equipment manufacturer information	REQMS	request for maintenance statistics	STX	start of text (BSC)
LSSD	level sensitive scan design	OEMI	original equipment manufacturer's information	RFS	ready for sending (signal) (or clear to send CTS)	SVC	supervisor call
m	meter	OHR	OR halfword register (instruction)	RI	register to immediate operand (instruction)	SYN	synchronous idle (BSC)
MAC	medium access control	OLTEP	online test execution program	RIM	request initialization mode	SYSGEN	system generation
MAP	maintenance analysis-procedure	OLTSEP	online test standalone execution program	RJK	read-only key	TA	time address
MCPC	machine check/program check	OLTS	online test system	ROS	read-only storage	TAP	trace analysis program
MCC	MOSS control card	OLTT	online terminal test	ROSAR	read-only storage address register	TAR	temporary address register
MCT	machine configuration table	OMB	out mailbox	rpm	revolutions per minute	TC	time command
MDOR	MOSS data operand register	OP	operation decode	RPO	remote power off	TCAM	telecommunications access method
MDR	miscellaneous data recorder	OR	OR register (instruction)	RPQ	request for price quotation	TCB	task control block
MEM	memory (card)	ORI	OR register immediate (instruction)	RR	register to register (instruction)	TCC	trace correlation counter (storage)
MES	miscellaneous equipment specifications	OUT	output (instruction)	RS	register to storage (instruction)	TCP	test connector pin
MFM	modified frequency modulation	ov	overvoltage	RSA	register to storage with addition (instruction)	TCS	two channel switch (see TPS)
MHz	megahertz	PCF	primary control field (storage)	RT	branch (instruction)	TD	time data
MICB	MOSS interface control block	PCI	program-controlled interrupt	RTC	retry count (X.21)	TERMA1	terminator type A in unit 01 (card)
MIM	maintenance information manual	PCR	power check reset	RTM	retry timer (X.21)	TERMB1	terminator type B in unit 01 (card)
MIO	MOSS input/output	PCW	processor control word	RTS	request to send	TERM2	terminator in unit 02 (card)
MIOB	MOSS input/output halfword	PDF	parallel data field (storage)	RVI	reverse interrupt (BSC)	TG	transmission group (NCP line trace)
MIOHI	MOSS input/output halfword immediate	PEP	partitioned emulation program	R/W	read/write	TIC	token ring interface coupler card
MLC	machine level control	PF	program function (3727 operator console keys)	s	second	TICB	trace interface control block
MLT	machine load table (diskette)	PFAR	prefetch address register	SALT	stand-alone link test	TIO	test I/O
mm	millimeter	PH1-x	phase control power block x unit 01	SAR	storage address register	TPS	two-processor switch (feature) (also referred to as ICS)
MMB	memory and MOSS board	PH2-x	phase control power block x in unit 02	SCB	(1) scanner control block (storage) (2) system control block	TPSA	trace parameter status area
MMC	MOSS memory card	PH4-x	phase control power block x in unit 02	SCF	secondary control field (storage)	TRA	token ring interface adapter
MMM8	MOSS memory module 8K	PIO	program initiated operation	SCR	(1) subtract character register (instruction) (2) silicon-controlled rectifier	TRM	test register under mask (instruction)
MMM24	MOSS memory module 24K	PIRR	program interrupt request register	SCTL	storage control (card)	TRM	token ring interface multiplexor card
MMM32	MOSS memory module 32K	PN	part number	SDF	serial data field (storage)	TRSS	token ring subsystem
mn	minute	POPR	prefetch operation register	SDLC	synchronous data link control (SNA)	TRU	trace record unit
MOD	modifier	POR	power-on reset	SE	system engineer	TSET	transmitter signal element timing
MOSS	maintenance and operator subsystem	PS	power supply	SELN	selection (3727 operator console key)	TSS	transmission subsystem
MPC	MOSS processor card	PSA	parameter/status area (storage)	SES	secondary status (storage)	TTA	translate table area
ms	millisecond	PSW	program status word	SHR	subtract halfword register (instruction)	TTD	temporary text delay (BSC)
MSA	machine status area (console)	PTT	post, telephone and telegraph (agency)	SIM	set initialization mode	UA	unnumbered acknowledgment
MSD	machine status display	PTX	phototransistor	SIO	start input/output	UCW	unit control word
mV	millivolt	PV	parity valid (signal)	SIT	scanner interface trace	UE	unit exception (channel status)
NAK	negative acknowledgment (BSC)	PWB1	power board unit 01	SKA	storage key address	UEPO	unit emergency power off
NCCF	network communication control facility (CNM)	PWB2	power board in unit 02	SKDR	storage-protect key data register	UK	United Kingdom
NCP	network control program	PWCA1	power-control analog in unit 01 (card)	SNRM	set normal response mode	UKA	user key address
NCR	AND character register (instruction)	PWCA2	power-control analog in unit 02 (card)	SOH	start of heading (BSC)	UKP	user key program
NEO	network expansion option	PWCL1	power-control logic in unit 01 (card)	SP	storage protect	UKDR	user key data register
NHR	AND halfword register (instruction)	PWCL2	power-control logic in unit 02 (card)	SPAE	storage protect/ address exception	UKL	user key level interrupt
NLDM	network logical data management	PWRC	power resistor card	SPK	storage protect key	USASCII	(see ASCII)
NOSP	network operation support program (VTAM)	RA	register to immediate address (instruction)	SR	subtract register (instruction)	us	microsecond
NPDA	network problem determination application (CNM)	RAC	repair action code	SRI	subtract register immediate (instruction)	uv	undervoltage
NR	AND register (instruction)	RAM	random access memory	SRL	shift left register	V	volt
NRI	AND register immediate (instruction)	RAS	reliability, availability, and serviceability	SS	start-stop	VB	valid byte (signal)
NRZI	non return-to-zero inverted	RCAM	RC access method	SSB	system status block	Vac	volts, alternating current
ns	nanosecond	RCV	receive	SSP	system support programs	Vdc	volts, direct current
NSC	native subchannel	RD	receive data (signal)	ST	store (instruction)	VFO	variable frequency oscillator
NTO	network terminal option	RDV	redrive (card)	STC	store character (instruction)	VH	valid halfword (signal)
NTRI	NCP Token Ring Interconnection	RDVAD	redrive adapter (card)	STCT	store character and count (instruction)	VRC	vertical redundancy check
NTT	Nippon Telegraph Telephone		register external (instruction)			VTAM	virtual telecommunication access method

W watt
WACK wait before transmit positive
acknowledgment (BSC)
WB wrap back (signal)
WKR working register
WSDR working storage data register

XID exchange identification
XCR exclusive OR character register
(instruction)
XHR exclusive OR halfword register
(instruction)
XOR exclusive OR
XR exclusive OR register
(instruction)
XREG external registers
XRI exclusive OR register immediate
(instruction)
X.21 CCITT X.21 recommendation
YZxxx Wiring diagram

ZAP control program modifier function
ZI zero insert
ZREG Z register
50PH1 50-Hz phase control in unit 01
(card)
50PH2 50-Hz phase control in unit 02
(card)
60PH1 60-Hz phase control in unit 01
(card)
60PH2 60-Hz phase control in unit 02
(card)

This glossary defines all new terms used in this manual. It also includes terms and definitions from the IBM Vocabulary for Data Processing Telecommunications, and Office Systems, GC20-1699.

A

access line:

In the diskette drive, a line that transmits pulses to turn the stepper motor.

adapter-initiated operation (AIO):

A transfer of up to 256 bytes between an adapter (channel or scanner) and the CCU storage. The transfer is initiated by an IOH/IOHI instruction, and is performed in cycle stealing via the IOC bus.

addressing:

A technique where the control station selects, among the DTEs that share a transmission line, the DTE to which it is going to send a message.

alcohol pad:

A pad soaked with iso-propyl alcohol.

alternate cylinder:

In the diskette drive, the area containing sectors that can be assigned in place of sectors that are not usable.

alternate track:

In the diskette drive, a track designated to contain data in place of a defective primary track.

asynchronous transmission:

Transmission in which each character is individually synchronized, usually by the use of start and stop elements. The start-stop link protocol, for example, uses asynchronous transmission contrast with 'synchronous transmission.'

auto-answer:

A machine feature that allows a DCE to respond automatically to a call that it receives over a switched line.

auto-call:

A machine feature that allows a DCE to initiate a call automatically over a switched line.

availability:

The degree to which a system or resource is ready when needed to process data.

B

bail assembly:

In the diskette drive, a mechanical arm that operates under control of the head load-solenoid to load or release the read/write head load arm.

belt clearance slots:

In the diskette drive, grooves in the fan enclosure that permit the ac motor belt to turn without rubbing against the fan enclosure.

binary synchronous communication (BSC):

A uniform procedure, using standardized set of control characters and character sequences, for synchronous transmission of binary-coded data between stations.

box error record (BER):

Information about an error detected by the controller. It is recorded on the diskette and can be displayed on the operator console for error analysis.

C

carriage:

In the diskette drive, the part that carries the read/write head under control of the stepper motor drive.

central control unit (CCU):

In the 3725, the controller hardware unit that contains the circuits and data flow paths needed to execute instructions and to control its storage and the attached adapters.

channel adapter (CA):

A communication controller hardware unit used to attach the controller to a host processor.

channel interface:

The interface between the controller and the host processors.

channel and line attachment base (CLAB):

A board that includes the first CAB and LAB of the controller.

collet:

In the diskette drive, the part that centers and holds the diskette to the drive hub.

common carrier:

In the USA and Canada, a government regulated private company that furnishes the general public with telecommunication service facilities. For example, a telephone or telegraph company (see also "post telephone and telegraph" for countries outside the USA and Canada).

communication controller:

A communication control unit that is controlled by a program stored and executed in the unit. Examples are the IBM 3705 and IBM 3725/3726.

Communication Network Management (CNM):

An IBM product program that assists the user in identifying network problems from a control point. It is stored in the host processor and comprises the network problem determination application (NPDA) and the network communication control facility (NCCF).

communication scanner:

See 'scanner'.

communication scanner processor (CSP):

The processor of a scanner.

configuration data file (CDF):

A file of the diskette that contains a description of all the hardware features (presence, type, address, and characteristics).

control panel:

A panel on the 3725 that contains switches and indicators for the use of the customer's operator and service personnel.

control subsystem (CSS):

The part of the controller that stores and executes the control program, and monitors the data transfers over the channel and transmission interfaces.

customer engineer (CE):

An individual who provides field services for IBM products.

cooling fan:

In the diskette drive, a fan that cools the stepper motor.

crosstalk:

In the diskette drive, data bits sensed from one track of the diskette while the read/write head is reading another track.

cyclic redundancy check (CRC):

A method of error checking performed at the receiving station after a block check character has been received.

D

data circuit-terminating equipment (DCE):

The equipment installed at the user's premises that provides all the functions required to establish, maintain, and terminate a connection, and the signal conversion and coding between the data terminal equipment (DTE) and the line. For example, a modem is a DCE (see "modem".)

Note: The DCE may be separate equipment or an integral part of other equipment.

data terminal equipment (DTE):

That part of a data station that serves as a data source, data sink, or both, and provides for the data communication control function according to protocols. In the 3725/3726, the DTE function is achieved by the FES with the associated LIC.

differentiator-amplifier:

An electronic circuit whose output signal is a function of the time rate of change of the input signal.

direct attachment:

The attachment of a DTE to the controller without a DCE.

diskette:

A thin, flexible magnetic disk, and its protective jacket, that records the 3725 microcode, diagnostics, error logs, and monitored data.

diskette 2D:

A diskette used for storing data on both surfaces with twice the usual bit density.

diskette drive:

A mechanism that reads and writes diskettes.

drive band:

In the diskette drive, a metal band connected to the stepper motor pulley and the head carriage assembly.

drive hub:

In the diskette drive, a continuously running part that turns the diskette at 360 rpm.

duplex transmission:

Data transmission in both directions at the same time. Contrast with 'half duplex.'

E

emulation program (EP):

The function of a network control program to perform activities equivalent to those of an IBM 2701 Data Adapter Unit, an IBM 2702 Transmission Control, or an IBM 2703 Transmission Control.

enclosure:

The diskette drive motor cooling fan safety cover.

error recovery procedure (ERP):

A procedure designed to help isolate and, where possible, to recover from errors in equipment. The procedures are often used in conjunction with programs that record the statistics of machine malfunctions.

F

front-end scanner (FES):

A circuit that scans the transmission lines, serializes and deserializes the transmitted characters, and manages the line services. It is part of the scanner.

H

half-duplex:

Data transmission in either direction, one direction at a time. Contrast with 'duplex.'

Note: The functional unit using the data circuit determines the choice of direction.

head/carriage:

In the diskette drive, the unit that contains the read/write head.

host processor:

(1) A processor that controls all or part of a user application network. (2) In a network, the processing unit in which the access method for the network resides. (3) In an SNA network, the processing unit that contains a system services control point (SSCP). (4) A processing unit that executes the access method for attached communication controllers. Also called 'host'

I

identifier:

In the diskette drive, a character or group of characters used to identify or name an item of data and possibly used to indicate some properties of that data.

initial microcode load (IML):

The process of loading the microcode into a scanner or into MOSS.

initial program load (IPL):

The initialization procedure that causes 3725 control program to commence operation.

input/output control (IOC):

The circuit that controls the input/output from/to the channel adapters and scanners via the IOC bus.

internal clock circuit (ICC):

An optional circuit that provides, through the LICs, the clock control to the DCEs or DTEs that need it.

internal function test (IFT):

A set of diagnostic programs designed and organized to detect and isolate a malfunction.

J

jacket:

A permanently attached cover that protects the diskette surface.

L

line:

See 'transmission line'.

line attachment base (LAB):

The unit of modularity of the transmission subsystem. It corresponds to one board and includes mainly the scanners and the line interface couplers.

line interface coupler (LIC):

A circuit that attaches up to four transmission cables to the controller.

Link Problem Determination Aid (LPDA):

A set of test facilities resident in the IBM 386X modems and activated from the control program in the controller.

link protocol:

The set of rules by which a logical data link is established, maintained, and terminated, and by which data is transferred across the link.

longitudinal redundancy check (LRC):

A system of error checking performed at the receiving station after a block check character has been accumulated.

M

maintenance and operator subsystem (MOSS):

The part of the controller that provides operating and servicing facilities to the customer's operator and customer engineer.

microcode:

A program, that is loaded in a processor (for example, the MOSS processor) to replace a hardware function. The microcode is not accessible to the customer.

modem (MOdulator-DEModulator):

A functional unit that transforms logical signals from a DTE into analog signals suitable for transmission over telephone lines (modulation), and conversely (demodulation). A modem is a DCE. It may be integrated in the DTE.

MOSS input/output control (MIOC):

The circuit that controls the input/output from/to the MOSS.

multiplexing:

The division of a transmission facility into two or more channels by allotting the common channel to several different channels, one at a time.

multipoint connection:

A connection established among more than two data stations for data transmission. The connection may include switching facilities.

N

network:

See 'user application network'.

Network Control Program (NCP):

A program, generated by the user from a library of IBM-supplied modules, that controls the operation of a communication controller.

nonswitched line:

A permanent dedicated transmission line that connects two or more DTEs. The connection can be point-to-point or multi-point. The line can be leased or private. Contrast with 'switched line.'

O

online tests:

Testing of a remote data station concurrently with the execution of the user's programs (that is, with only minimal effect on the user's normal operation).

operator console:

The IBM 3727 Operator Console that is used to operate and service the 3725 through the MOSS. A primary operator console must be located within 5 m (16 ft) of the 3725. Optionally an alternate operator console may be installed up to 150 m (492 ft) from the 3725.

P

partitioned emulation programming (PEP):

A feature of NCP that permits some lines to operate in network control mode while simultaneously operating others in emulation mode.

phototransistor:

An electronic part used to sense the light of a light-emitting diode.

point-to-point connection:

A connection established between two data stations for data transmission. The connection may include switching facilities.

polling:

The process whereby stations are invited, one at a time, to transmit.

post telephone and telegraph (PTT):

A generic term for the government-operated common carriers in countries other than the USA and Canada. Examples of the PTT are the Post Office Corporation in the United Kingdom, the Deutsche Bundespost in Germany, and the Nippon Telephone and Telegraph Public Corporation in Japan.

program-initiated operation (PIO):

A transfer of four bytes between a general register in the CCU and an adapter (channel or scanner). The transfer is initiated by IOH/IOHI instruction and is executed via the IOC bus.

R

redrive card:

A card that repowers the IOC bus signals at board entry. It also has logical and checking functions.

reliability:

The ability of a functional unit to perform its intended function under stated conditions, for a stated period of time.

S

scanner:

A device that scans and controls the transmission lines. It is composed of one communication scanner processor (CSP) and one front-end scanner (FES).

services:

A set of functions designed to facilitate the maintenance of a device or system.

serviceability:

The capability to perform effective problem determination, diagnosis, and repair on a data processing system.

solenoid plunger:

In the diskette drive, a moving part of the solenoid that operates the bail assembly to load and release the read/write head load arm.

start-stop:

A data transmission system in which each character is preceded by a start signal and is followed by a stop signal.

stepper motor:

In the diskette drive, the motor that steps the head carriage assembly from track to track.

switched line:

A transmission line with which the connections are established by dialing, only when data transmission is needed. The connection is point-to-point and uses a different transmission line each time it is established. Contrast with 'non-switched line.'

synchronous data link control (SDLC):

A discipline for managing synchronous, code-transparent, serial-by-bit information transfer over a link connection. Transmission exchanges may be duplex or half-duplex over switched or nonswitched links. The configuration of the link connection may be point-to-point, multi-point, or loop. SDLC conforms to subsets of the Advanced Data Communication Control Procedures of the American National Standards Institute and High-level Data Link Control (HDLC) of the International Standards Organization.

synchronous transmission:

Data transmission in which the sending and receiving instruments are operating continuously at substantially the same frequency and are maintained, by means of correction, in a desired phase relationship. Contrast with 'asynchronous transmission.'

systems network architecture (SNA):

The description of the logical structure, formats, protocols, and operational sequences for transmitting information through a user application network. The structure of SNA allows the users to be independent of specific telecommunication facilities.

T

timeout:

The time interval allotted for certain operations to occur.

transmission interface:

The interface between the controller and the user application network.

transmission line:

The physical means for connecting two or more DTEs (via DCEs). It can be nonswitched or switched. Also called a 'line.'

transmission subsystem (TSS):

The part of the controller that controls the data transfers over the transmission interface.

tunnel erase circuit:

In the diskette drive, an electronic circuit that is used to erase the edge of the track just recorded during a write operation. This erasing prevents crosstalk between track during later read operations.

two-processor switch (TPS):

A feature of the channel adapter that connects a second channel to the same adapter.

U

user application network:

A configuration of data processing products, such as processors, controllers, and terminals, for the purpose of data processing and information exchange. This configuration may use circuit-switched, packet-switched, and leased-circuit services provided by carriers or PTT. Also called a 'user network.'

V

variable frequency oscillator:

An electronic circuit that is used to synchronize the MOSS reading circuits with the diskette drive when it is performing a read operation.

vertical redundancy check (VRC):

An odd parity check performed on each character of a block as the block is received.

W

write/erase:

Writing data to and erasing from a diskette.

Index

A

A/B data buffer diag mode 12-040
abnormal conditions during controller initialization 6-100
AC HIT, MSA 2-351
ac voltage adjustment 5-060
accessing channel adapter registers 12-015
ACF/TCAM environment 2-031
ACF/VTAM environment 2-030
activation of traces (NTRI) 2-034
adapter input/output instruction 10-150
adapter return codes 2-290
additional BER information 1-070
address compare error bit 12-055
address compare function 14-050
address compare function, MSA 2-351
address compare, scanner 2-377
address exception 10-250
address formats on IOC bus 11-040
address in tag 12-140
address look-up table 2-040
address out tag 12-140
addressing, line group 11-050
addressing, redrive 11-070
adjusting the video element 6-031
AIO mode 10-020
AIO operation 11-030, 11-031, 11-032, 11-033
AIO operation sequence, CSCW transfer 11-031
AIO operation sequence, data transfer in read 11-032
AIO operation sequence, data transfer in write 11-032
AIO operation sequence, initialization 11-030
AIO operation sequence, storage address transfer 11-031
AIO operation, cycle stealing 11-030
AIO operation, IOC control logic 11-030
AIO operations, CSCW contents 11-040
AIO read timing 11-033
AIO write timing 11-033
alarm/alert list 2-050
alarms 1-023, 2-050
alerts 1-023, 2-050
all channel adapters disabled lamp 6-010, 12-800
alter ZAP 2-396
analysis of a BER ALARM ALERT Sequence 2-251
anti-glare filter feature 6-034
apply ZAP 2-396
ARC 2-290
arithmetic and logic unit 10-030
ASTAT, adapter error 2-300
ASTAT, adapter exception status 2-300
automatic MOSS dump 2-440
automatic scanner dump 2-440
automatic IIC dump 2-440
autoselection scoping routine, CA 12-807
autoselection signal routing, CA 12-804
autoselection signals description, CA 12-065, 12-803
autoselection timing, CA 12-806
autoselection troubleshooting, CA 12-803

B

B instruction 10-190
B/M installation 8-010
BALR instruction 10-120, 10-150
basic telecommunications access method 1-023
BB instruction 10-190
BCC in BSC receive (RAM C) 13-532
BCC in BSC transmit (RAM C) 13-533
BCC in SDLC receive (RAM C) 13-530
BCC in SDLC transmit (RAM C) 13-531
BCL instruction 10-190
BCT instruction 10-190
BER (type 14) IOC 2-230
BER alarm alert mechanism 2-250, 2-251
BER CCU (type 13) 2-220
BER common fields in header lines 2-181
BER decode/hex display 3-030
BER detail display 2-181
BER display 2-170
BER display from MOSS storage 3-030
BER display procedure 2-172, 3-030
BER display sample sequence 2-172
BER display screens 2-180
BER field, IOC bus/addressing 2-182
BER field, redrive address and error register 2-182
BER file erasure 2-170
BER file printing 2-466
BER flag updating 2-173
BER format 2-170
BER generation 2-170
BER handling tools 2-171
BER layout on diskette 2-340, 2-341, 2-342
BER list 2-173, 2-180
BER list display 2-180
BER purge 2-410
BER recovery procedures 2-800
BER recovery procedures, CCU 2-800, 2-802
BER recovery procedures, IOC bus and adapters 2-804
BER recovery procedures, MOSS 2-800
BER recovery procedures, MOSS storage errors 2-801
BER recovery procedures, multiple BERs 2-801
BER recovery procedures, RDV address and error register 2-80
BER recovery procedures, storage double bit errors 2-803
BER save 2-409
BER storage on diskette 2-170
BER storage when diskette is not operational 2-170
BER structure 2-171
BER summary display 2-180
BER that are not machine error 2-171
BER thresholds 2-171
BER type 01 2-240, 2-241, 2-242
BER type 01 ID 00 2-260
BER type 01 ID 00 field explanation 2-260
BER type 01 ID 01 2-270
BER type 01 ID 01 field explanation 2-270
BER type 01 ID 02 2-280, 2-281

BER type 01 ID 01 1B 1F 90 92 93 94 95 96 98 99 9C 9E 9F 2-192
BER type 01 ID 02 field explanation 2-280
BER type 01 ID 03 2-290
BER type 01 ID 03 field explanation 2-290
BER type 01 ID 04 2-300
BER type 01 ID 04 field explanation 2-300
BER type 01 ID 05 2-310
BER type 01 ID 05 field explanation 2-311
BER type 01 ID 06 2-320, 2-324
BER type 01 ID 06 field explanation 2-320
BER type 01 ID 07 2-325
BER type 01 ID 91 B3 C1 C2 2-330
BER type 01 ID 91, B3, C1, C2 2-330
BER type 01 ID 91, B3, C1, C2 field explanation 2-330
BER type 10 (CA) 2-190, 2-191
BER type 10 field explanation 2-193
BER type 10 ID 14 16 91 9A 2-192
BER type 10 ID 18 1C 1E 97 9B 2-192
BER type 10 ID 33, 34, 35, B1, B2, B5, B6 2-192
BER type 11 2-200, 2-201
BER type 11 (TSS) ID 14, 16, 91, 92, 93 2-201
BER type 11 field explanation 2-203
BER type 11 ID A1 2-201
BER type 11 ID A2 2-202
BER type 11 ID B1 2-202
BER type 11 ID 1C 2-202
BER type 11 ID 1E 1F 95 96 99 9A 9B 2-201
BER type 11 ID 18 1B 97 98 9C 2-201
BER type 12 (NCP/EP) 2-210
BER type 12 field explanation 2-210
BER type 12 ID 11 through 19 2-210
BER type 12 ID 21 2-210
BER type 13 2-220
BER type 13 field explanation 2-221
BER type 13 ID C1 thru C6 2-221
BER type 13 ID 32, B1 2-221
BER type 13 ID 91 thru 95 2-221
BER type 14 2-230
BER type 14 field explanation 2-230
BER type 14 ID 91, 92, 93, 95 2-230
BER type 15 2-231
BER type 15 field explanation 2-232, 2-233
BER type 15 ID AC 2-232
BER type 15 ID AF 2-232
BER type 15 ID A3, A5, A7, A8 2-231
BER type 15 ID B2 2-232
BER type 15 ID B3, B4, B5, B6 2-232
BER type 15 ID 14, 16, 91, 92 93 2-231
BER type 15 ID 18, 97, 98, 9C 2-231
BER type 15 ID 96, 99, 9A, 9B 2-231
BER updating 2-173
BER/ALARM/ALERT sequence analysis 2-251
blank display checks 14-820
block multiplex channel 12-092, 12-200

block multiplex mode 12-215
 board characteristics 1-050
 board characteristics, channel adapter 1-041
 board disabled by jumper 11-090
 board layout, C2LB2 4-020
 board layout, LAB 4-020
 board layout, MMB 4-020
 board pin assignments 4-020
 board pin assignments, MMB, C2LB, C2LB2, CLAB, LAB, CAB 4-020
 board voltage plan 4-040
 box error record (BER) description 1-070
 branch and link register instruction 10-150
 branch instruction 10-190
 branch on C latch instruction 10-190
 branch on count instruction 10-190
 branch on Z latch instruction 10-190
 branch trace buffer 14-050
 branch trace extra records 14-050
 branch trace function 14-050
 branch trace function, MSA 2-351
 branch trace level control register 14-051
 branch trace register 14-050
 BSC receive 13-532
 BSC transmit 13-533
 BSC/SS device or line errors 3-050
 BSC/SS station statistics 3-053
 BSTAT 2-300
 buffer content, trace 2-030
 buffer trace 2-031
 buffer use trace 2-030
 buffers trace, location (map) 13-550
 burst length jumper 4-283
 burst mode 1-051, 9-040, 12-205
 bus in check bit 12-055
 BUSTERM diagram 4-095
 BYP-IOC-CHK, MSA 2-351
 byte multiplex channel 12-092, 12-210
 BZL instruction 10-190

C

C REQ 2-322
 CA address compare error 12-080
 CA autoselect timing 12-806
 CA autoselection 12-065
 CA autoselection signal routing 12-804
 CA autoselection troubleshooting 12-803
 CA autoselection, scoping routine 12-807
 CA broadcast commands 12-016
 CA cable removal 4-110
 CA cable routing 4-110
 CA card descriptions 12-005
 CA card socket location 12-005
 CA CCU interface card check 12-080
 CA channel interface card check 12-080
 CA connection details 4-113
 CA control character recognition 12-070
 CA cycle steal operations 12-809
 CA cycle steal signal routing 12-810
 CA cycle steal timing 12-820
 CA cycle steal troubleshooting 12-809
 CA cycle steal, scoping 12-820
 CA data flow 12-095
 CA data transfer in AIO mode (cycle stealing) 12-090
 CA data transfer in PIO mode 12-091
 CA data transfer methods 12-015

CA data transfer sequences 12-090
 CA data transfer state 12-015
 CA disabled state 12-015
 CA enabled bit 12-045
 CA enabling/disabling 12-070
 CA error conditions 12-080
 CA final status transfer/sense 12-100
 CA force error bit 12-040
 CA functional partitioning and selection 12-065
 CA hardware status register 12-025
 CA inbound data transfer sequence in AIO mode 12-090
 CA inbound data transfer sequence in PIO mode 12-092
 CA initial selection 12-085
 CA initial selection state 12-015
 CA initial status transfer 12-085
 CA input/output immediate instruction 12-065
 CA input/output instruction failure scoping 12-820
 CA interface enabled bit 12-045
 CA internal bus parity error 12-080
 CA interrupt request level 1 12-015, 12-070
 CA interrupt request level 3 12-015, 12-070
 CA introduction 12-005
 CA IOC bus parity error 12-080
 CA IOH instructions 12-015
 CA IOH registers 12-020
 CA IOHI instructions 12-016
 CA level 1 interrupt requests 12-015, 12-070
 CA level 3 interrupt requests 12-015, 12-070
 CA local store contents 12-020
 CA modes of operation 12-010
 CA outbound data transfer sequence in AIO mode 12-090
 CA outbound data transfer sequence in PIO mode 12-091
 CA output exception check 12-080
 CA ready state 12-015
 CA scoping routine for autoselect mechanism 12-807
 CA scoping routine for cycle steal mechanism 12-830
 CA stacked initial status 12-085
 CA status transfer state 12-015
 CA switched to interface A bit 12-040
 CA switched to interface B bit 12-040
 CA transfer termination 12-092
 CAB address jumpers 4-270
 CAB board card location 4-063
 CAB board layout 4-020
 cable to ACU 4-160
 cable, CA cable routing in frame 02 4-111
 cable, CAB to LAB position 8 4-091
 cable, MOSS to control panel 4-083
 cable, primary IOC 4-080
 cable, storage cables 4-081
 cables from CCU board to CAB 4-090
 cabling between boards 4-070
 cabling, general view 4-070
 CADR card 12-005
 CADR card check bit 12-055
 CADR card plugging 5-042
 CADR card removal 5-042
 CADR card replacement 5-042
 card and board organization 4-050
 card and connector assignments, CCU board 4-022
 card and connector assignments, power board 4-020
 card assignments, MMB, C2LB, C2LB2, CLAB, LAB, CAB 4-020
 card locations 4-060
 card module information 5-030
 card pin assignments 4-020
 card pin assignments, CCU board 4-022
 card replacement 5-040
 card vendor transistor logic 12-005
 card, BSMI 10-040

card, BTAC 10-040
 card, CCLK 10-040
 card, CTL1 10-040
 card, CTL2 10-040
 card, DFL123 10-040
 card, DFL4 10-040
 card, DFL5 10-040
 card, ECC 10-050
 card, indicator 3-011
 card, internal clock 13-013
 card, LIC 1-052
 card, MCC 14-011
 card, MIOC 14-020
 card, redrive 11-060
 CCA basic status register 14-090
 CCA card 14-090
 CCA card test 6-110
 CCIN card 1-041, 12-005
 CCIN card check bit 12-055
 CCITT signal names 4-130
 CCU BER (type 13) 2-220
 CCU board layout 4-022
 CCU board packaging 10-040
 CCU board replacement 5-010
 CCU card replacement 5-041
 CCU cards 10-040
 CCU characteristics 10-040
 CCU check mode 2-350
 CCU circuit description 10-030
 CCU clock 1-040, 5-050
 CCU connectors 10-040
 CCU control program/MOSS communications 14-140
 CCU cycle 10-040
 CCU data flow 10-020
 CCU description 9-02
 CCU hardcheck 2-250
 CCU in 3725 data flow 10-010
 CCU instruction address register 10-030
 CCU instruction CCU-to-scanner input output 13-121
 CCU interrupt levels 10-040
 CCU isolation 10-800
 CCU level 2 interrupt requests 11-050
 CCU loading support 6-090
 CCU L1 and L2 interrupts scoping 11-808
 CCU main storage 10-040
 CCU mode 2-350
 CCU operation 10-031
 CCU packaging 10-040
 CCU program level priorities 10-080
 CCU read-only storage 10-030
 CCU record printing 2-461
 CCU rollout area 6-090
 CCU ROS 10-031
 CCU status 2-351
 CCU storage refresh timing 10-810
 CCU timers 10-260
 CCU to MOSS communication 14-140
 CCU to MOSS status A register (X'11') 14-040
 CCU to MOSS status B register (X'06') 14-040
 CCU to MOSS status C register (X'07') 14-040
 CCU to MOSS status D register (X'0f') 14-040
 CCU to MOSS status E register (X'01') 14-040
 CCU to MOSS status F register (X'05') 14-040
 CCU to storage bus scoping 10-830, 10-831, 10-832, 10-833
 CCU to storage bus, signal tables 4-081
 CCU to storage internal bus scoping routine 10-830
 CCU troubleshooting 10-800
 CCU X'71' output register 2-351
 CCU X'72' output register 2-352
 CCU 100 ms interval timer 10-260
 CCU/scanner exchanges 9-040

CCU/scanner IPL information 2-353
CCU/storage clocking 10-800
CDF (3725) create 2-400
CDF (3725) verify 2-401
CDF change warning 11-800
CDF data organisation 2-461
CDF display/update 2-402
CDF file printing 2-461
CDF information 2-405
CDF recording before LIC or ICC move 8-040
CDF select and create 2-400
CDF update after LIC or ICC move 8-050
CDF verify 2-401
CDS range definition card layout 2-153
CELIA card 13-011, 13-800
CELIA card data flow 3-011
CELIA LED testing 3-011
central control unit, description 1-040
channel adapter 1-041
channel adapter address bits 12-060
channel adapter addressing 1-041, 11-055
channel adapter and MOSS control 6-010
channel adapter autoselection 12-065
channel adapter block multiplex mode 12-215
channel adapter burst mode 12-205
channel adapter cables 4-084
channel adapter card description 12-005
channel adapter card location 5-042, 12-005
channel adapter channel enabling 12-070
channel adapter condition register 12-045
channel adapter control character recognition 12-070
channel adapter control register 12-045
channel adapter description 12-005
channel adapter device addresses 12-015
channel adapter driver receiver card 1-040, 12-005
channel adapter driver-receiver 1-041
channel adapter enable switches 6-010
channel adapter error register 12-055
channel adapter input X'B' instruction 12-021, 12-050
channel adapter input X'C' instruction 12-021, 12-022, 12-050
channel adapter input X'D' instruction 12-022, 12-055
channel adapter input X'E' instruction 12-022, 12-060
channel adapter input X'F' instruction 12-022, 12-060
channel adapter input X'0' instruction 12-020, 12-025
channel adapter input X'1' instruction 12-020, 12-025
channel adapter input X'2' instruction 12-020, 12-030, 12-031, 12-032
channel adapter input X'3' instruction 12-020, 12-035
channel adapter input X'4' instruction 12-021, 12-035
channel adapter input X'5' instruction 12-021, 12-035
channel adapter input X'6' instruction 12-021, 12-040
channel adapter input X'7' instruction 12-021, 12-045, 12-046
channel adapter interrupt requests 12-015
channel adapter level 1 interrupt requests register 12-070
channel adapter level 3 interrupt requests register 12-070
channel adapter location 1-041
channel adapter mode of operation 12-010
channel adapter modularity 1-041
channel adapter multiplex mode 12-210
channel adapter OLT responder 2-152
channel adapter OLTs 2-152
channel adapter operating environment 12-005
channel adapter output X'B' instruction 12-021, 12-050
channel adapter output X'C' instruction 12-021, 12-050
channel adapter output X'D' instruction 12-022, 12-055
channel adapter output X'E' instruction 12-022, 12-060
channel adapter output X'F' instruction 12-022, 12-060
channel adapter output X'0' instruction 12-020, 12-025
channel adapter output X'1' instruction 12-020, 12-025
channel adapter output X'2' instruction 12-020, 12-030
channel adapter output X'3' instruction 12-020, 12-035
channel adapter output X'4' instruction 12-021, 12-035
channel adapter output X'5' instruction 12-021, 12-035
channel adapter output X'6' instruction 12-021, 12-040
channel adapter output X'7' instruction 12-021, 12-045
channel adapter packaging 1-041
channel adapter record printing 2-462
channel adapter registers 12-015
channel adapter reset bit 12-046
channel adapter reset warning 11-800
channel adapter scoping 11-809
channel adapter selection bits 12-045, 12-065
channel adapter selector mode 12-200
channel adapter states 12-015
channel adapter TPS 12-075
channel adapter troubleshooting 12-750, 12-800
channel bus in check 12-080
channel bus out check 12-025, 12-030
channel enabling/disabling checks 12-800
channel end presented bit 12-030
channel interface 1-010, 1-041
channel interface card 12-005
channel interface scoping 12-820
channel link attached controller 1-011
channel loader dump program final status/sense information 12-101
channel multiplex mode 12-210
channel operation, channel adapter 1-041
channel stop bit 12-030
channel tag line definitions 12-140
channel to CCU interface 1-041
character mode 1-051, 9-040
character mode (contrast with normal mode) 9-040
character mode command status 13-351
check the checkers bit 12-040
checkpoint trace 2-378
CHGDMP 14-081
CHIN card 12-005
CHIN card check bit 12-055
CLAB board layout 4-020
CLAB1 card location 4-061
CLAB1 line information 4-123
CLAB2 1-041
CLAB2 line information 4-122
CLDP 14-081
clock cable routing 4-100, 5-051
clock pulse timing 14-070
clock scope points 4-100
clock scoping 5-050, 4-100, 5-051, 5-052, 5-053, 5-054
clock signal relationship 5-050
clock, high speed, distribution 4-100
command out tag 12-140
commands (CP) to IIC 15-171
communication controller 1-010
communication function trace 2-042
communication interface 4-130
communication scanner 1-051
communication scanner processor 1-050, 13-010
communication scanner processor, packaging 1-050
communication scanner storage packaging 1-050
communication scanner, functions 1-051
communication scanner, modularity 1-051
communication scanner, performance 1-051
communication wrap block 3-012
communication wrap cable 3-012
compatibility, LIC-ICC 1-052
component location 4-010
concurrent maintenance 1-070
condition codes 2-260
configuration data file 2-400, 2-461
configuration, example of scanner 13-261
configurations 1-020
CONNECTED, MSA 2-352
console functions 2-010
console link test 6-031
console signal testing 14-831
console switch 6-010
console wrap block 3-013
control block relationship 13-210
control in start-stop receive (RAM C) 13-534
control in start-stop transmit (RAM C) 13-534
control panel 6-011
control panel card voltage pins 4-043
control panel connections 6-020
control panel, location 1-060
control storage addressing in RAM A receive 13-510, 13-511
control subsystem 1-020, 1-040
control subsystem, description 1-040
controller diskette 1-060, 2-020
controller diskette, primary menu 2-020
controller general description 1-020
controller initialization 6-060
controller initialization flow 6-080
controller initialization request handling 6-130
controller initialization sequence 6-070
controller initialization, phase description 6-090
controller IPL 6-090
controller organization 1-020
controller re-IPL 6-090
controller reset and MOSS IML 6-090
controller resets 6-050
controlling the channel adapter 12-015
conversion rules 2-470
copy ZAPs on a spare diskette 2-399
copying a diskette, MD to MD 2-459
correlating line trace and SIT 2-035
CP commands to TIC 15-171
CP LOADED, MSA 2-353
CPT records 2-036
create, CDF 2-400
creating a ZAP 2-394, 2-398
CS (scanner errors) 2-323
CSCW 12-022, 12-025
CSM, packaging 1-050
CSP 1-050
CSP clock 13-010
CSP components 13-010
CSP control storage 13-010
CSP data flow 13-010
CSP external registers 13-011
CSP hardstop 13-012
CSP internal errors 13-321
CSP IOC bus errors 13-340
CSP IOC bus interface errors 13-321
CSP local storage 13-010
CSP modularity 1-050
CSP packaging 1-050
CSP packaging 13-010
CSP processor characteristics 13-010
CSP purpose 13-010
CSP read only storage 13-010
CSP storage refresh 13-800
CSP timing chart in cycle steal mode 13-800
CSP troubleshooting 13-800
CSP/FES errors 13-321

CSP/IOC bus errors 13-321
 CSS description 1-040
 CSTAT 2-310
 CU forced burst mode 12-205
 current error counter 2-260
 CVTL card 12-005
 cycle counter operation 10-260
 cycle sequence tables 10-171
 cycle steal (AIO) halt remember latch bit 12-055
 cycle steal autoselection 13-820
 cycle steal autoselection (TRM) 15-820
 cycle steal CA, scoping 12-820
 cycle steal halt remember 12-080
 cycle steal mechanism 1-040
 cycle steal mode control register 12-050
 cycle steal preselection 13-820
 cycle steal priority structure (TRM) 15-820
 cycle steal priority structure 13-820
 cycle steal requests 11-050
 cycle steal requests to the CCU 13-820
 cycle steal sequence description (TRM) 15-130
 cycle steal signal routing, CA 12-810
 cycle steal timing 11-813
 cycle stealing 10-040
 C2LB line information 4-120
 C2LB 1-041
 C2LB address jumpers 4-270
 C2LB board card location 4-064
 C2LB board layout 4-020
 C2LB2 line information 4-120
 C2LB2 1-041
 C2LB2 board card location 4-064
 C2LB2 board layout 4-020

D

DAC card replacement 5-040
 data buffer register 12-035
 data circuit-terminating interface 1-011
 data flow 1-030
 data flow for IOH instruction 10-150
 data flow for IOHI instruction 10-120, 10-130
 data flow for output instruction 10-211
 data flow for RE input instruction 10-210
 data flow for RI instruction 10-130
 data flow for RR instruction 10-140
 data flow for RS instruction on character 10-160
 data flow for RS instructions 10-170
 data flow for RSA instruction 10-180
 data flow, channel adapter 12-095
 data flow, communication controller 1-030
 data flow, LIC 13-013
 data in tag 12-140
 data in/out jumper 4-282
 data link escape (DLE) in RAM B transmit 13-521
 data out tag 12-140
 data terminal equipment interface 1-011
 data/status control register 12-030, 12-031
 DC voltage adjustment 5-060
 DC voltages and tolerances 11-600
 DCE cable moving 8-040
 DCF translate table array. 14-135
 deactivating scanner address compare 2-377
 delete ZAP 2-396
 detection of MOSS errors 14-160
 device addresses, channel adapter 12-015
 diagnostics, IOC bus IFT 11-802

diagnostics, TSS group FES IFTs 2-044
 direct attachment clock select jumper 4-270
 disable autoselection bit 12-045
 disable board by jumpers 11-090
 disconnect function (TRSS) 15-150
 disconnecting storage 10-800
 disconnecting the RDV from the IOC bus 3-020
 DISCTD-GO, MSA 2-352
 DISCTD-STOP, MSA 2-352
 DISK (diskette errors) 2-322
 disk adapter ROS tests 14-860
 disk bootstrap 6-110
 diskette adapter status register 14-080
 diskette BERS 3-030
 diskette commands 14-070
 diskette description 7-010
 diskette drive, ac/dc power on/off 7-054, 7-060
 diskette drive, access lines 7-051
 diskette drive, bail adjustment 7-120
 diskette drive, bail and solenoid replacement 7-120
 diskette drive, bail and solenoid check 7-110
 diskette drive, bail checks and adjustments 7-090
 diskette drive, band replacement 7-070
 diskette drive, cable connector test procedure 7-161
 diskette drive, characteristics 7-011
 diskette drive, collet/flat spring replacement 7-130
 diskette drive, connectors 7-160, 7-161
 diskette drive, control board 7-160
 diskette drive, control board connections 7-050
 diskette drive, control board connectors 7-160
 diskette drive, control card 7-054
 diskette drive, control card cable 7-054
 diskette drive, control card interface 7-050
 diskette drive, diskette sense line 7-051
 diskette drive, drive band adjustment 7-070
 diskette drive, drive band replacement and adjustment 7-070
 diskette drive, drive band service check 7-070
 diskette drive, erase gate line 7-051
 diskette drive, file data line 7-051
 diskette drive, file data signal 7-053
 diskette drive, FM encoding 7-052
 diskette drive, general description 7-010
 diskette drive, head engage line 7-051
 diskette drive, head gap adjustment 7-090
 diskette drive, head/carriage adjustment 7-090
 diskette drive, head/carriage replacement 7-100
 diskette drive, head/carriage service check 7-080
 diskette drive, index line 7-051
 diskette drive, inner tracks line 7-051
 diskette drive, interface lines description 7-051
 diskette drive, LED and PTX replacement 7-140
 diskette drive, locations 7-040
 diskette drive, maintenance 7-010
 diskette drive, mechanical operation 7-051
 diskette drive, MFM encoding 7-052, 7-053
 diskette drive, motor capacitor replacement 7-150
 diskette drive, motor fan 7-150
 diskette drive, motor installation 7-150
 diskette drive, motor removal/replacement 7-150
 diskette drive, power on/off procedures 7-060
 diskette drive, PTX service check 7-061
 diskette drive, read/write operation principles 7-052
 diskette drive, removal/replacement 7-060, 7-061
 diskette drive, safety 7-020
 diskette drive, select head 1 line 7-051
 diskette drive, service check 7-061
 diskette drive, special tools 7-011
 diskette drive, stepper motor removal replacement 7-062

diskette drive, support logic locations 7-030
 diskette drive, switch filter line 7-051
 diskette drive, test pins 7-054
 diskette drive, testing 7-170
 diskette drive, theory of operation 7-050
 diskette drive, typical device operation 7-051
 diskette drive, write data line 7-051
 diskette drive, write gate line 7-051
 diskette drive, write/erase enabled line 7-051
 diskette format write operation 7-052
 diskette functional characteristics 7-011
 diskette internal bus error indications 14-860
 diskette mapping 14-081
 diskette read data 7-052, 7-053
 diskette record write operation 7-052
 diskette safety 7-020
 diskette sense byte 14-081
 diskette swap 2-408, 8-065
 diskette testing 6-110
 diskette tools 3-012
 diskette use 7-010
 diskette write operation 7-052
 dispatcher subtask trace 2-031
 display all CDF (3725) 2-402
 display CCU/MOSS 2-402
 display channel adapters 2-403
 display C2LB/LAB 2-402
 display is other than X'F01' 14-821
 display LAB/CAB 2-402
 display module 2-393
 display MOSS storage 2-393
 display scanners/TRAS 2-403
 display SCB, SSB and parameter block, TRA 2-385
 display storage, scanner 2-373
 display TIC storage, TRA 2-383
 display token-ring status, TRA 2-386
 display/alter blocks, scanner 2-375
 display/alter LSR and Xrer, scanner 2-376
 display/alter store, scanner 2-373
 display/alter TIC interrupt register, TRA 2-382
 display/alter TRM registers, TRA 2-381
 display/update menu, CDF 2-402
 display, hexadecimal 6-010
 DLE remember latch bit 12-050
 DPLY/ALT blocks, scanner 2-375
 driver/receiver card check 12-080
 dump delete MOSS, scanner or TRSS 2-392
 dump display MOSS, scanner or TRSS 2-391, 2-392
 dump exchange mechanism 6-140, 6-150
 dump exchange over link part 6-180
 dump scanner 2-371
 dump transfer 2-450, 6-190
 dump, scanner, MOSS, TRSS/TIC 2-440

E

EBCDIC monitor control latch bit 12-050
 EC/MES installation, hardware/microcode 8-010
 ECC card 10-050
 ECC control command 10-060
 ECC mechanism 10-050
 EIA card 14-090
 EIA card test 6-110
 element removal and replacement procedures 6-032
 element, 3727, video, logic and keyboard 6-030
 emulation program 1-023
 enable autoselection bit 12-045
 EP channel commands 12-125

EP communication with MOSS 14-140
EP ending status 12-130
EP final status information 12-130
EP line trace 2-034
EP sense information 12-135
EPO switch, control panel 6-011
erase ZAP 2-394, 2-397
EREP unit check records 3-070
error checking circuits 10-020
error control program error area 13-551
error detection (box error in 3725/26) 1-071
error detection (3725/3726 attached network) 1-071
error detection during PIO 13-380
error detection in CSP/IOC bus interface 13-321
error detection on 3725/3726 site 1-071
error log function 2-050, 2-170
error reporting path to host 1-071
error reporting to CCU during PIO 13-330
error status description 13-350
error status type hardstop 13-351
ERROR-EXT 2-322
error, Exx type 3-030
error, no FRU isolated 1-070
errors during AIO 13-330
errors during PIO 13-330
ESC address and status byte register 12-035
ESC address with EP 9-030
ESC final status transfer 12-100
ESC mode 12-005, 12-010
ESC operation bit 12-025, 12-030
ESC stacked final status 12-101
ESC test I/O address and status register 12-050
ESD 5-020
exceptions to RR instructions 10-150
execute output on addressed channel adapter bit 12-046
exit instruction 10-200
extended problem analysis tools 3-040
extended troubleshooting using BERs chapter 2, section 2
external register functions 10-220

F

FES 13-130
FES commands for 13-131
FES data flow 13-020
FES data transfer operation 13-260
FES functions 13-021
FES general reset 13-021
FES modularity 1-051
FES operation 13-260
FES packaging 1-051
FES packaging and components 13-020
FES parameter status 13-130
FES parameter transfer operation 13-260
FES parameter/status transfer mechanism 13-260
FES programmed reset 13-013
FES purpose 13-020
FES scanning operation 13-260
FES scheduler 13-013
FES storage 13-021
FES throughput 13-020
field description for BER list screen 2-180
field description for BER summary screen 2-180
fields common to many BER detail screens 2-182
file a ZAP in ZAP area 2-398

file data 7-052, 7-053
file data signal 7-053
file deletion 2-392
file printing 2-460
file printing, BER list 2-466
file printing, CDF 2-461
file printing, MLT file 2-460
file printing, MOSS dump 2-467, 2-468
file printing, ZAP history table 2-465
file transfer to host 2-042, 2-450 - 2-459
final status stacked bit 12-030
flag (BER) updating 2-173
flat cable extractor 3-013
flat cable installation 8-050
flat cable removal 8-045
frame 01 component location 4-011
frame 02 component location 4-012
front end layer 13-013
front end scanner 1-051, 13-020
front end scanner, packaging 1-051
function data exchange 2-351, 2-352
function registers 10-030
function select switch 6-010
function start switch 6-010
functional organization 1-040
functions called from the host 2-030

G

general IPL after LIC or ICC move 8-070
general PIO operations 15-100
general purpose tools 3-010
generation, control program 1-023
get command completion (TRM) 15-120
get error status instruction operation 13-230
get line identification (GLI) instruction 13-123
get line identification instruction operation 13-231
ground fault 12-080
ground fault error bit 12-055
group address, RDV 11-055

H

HARDSTOP, MSA 2-351
hardware error 2-250
hardware reset function (TRA) 15-155
hex display 6-010
hex display, BER decode 3-030
hexadecimal/decimal conversion 2-470
high-level command status 13-351
high-speed clock distribution 4-100
high/low resolution timer 10-260
host NLDM trace 2-032
host trace, environment-independent 2-032
host traces in an ACF/TCAM environment 2-031
host traces in an ACF/VTAM environment 2-030

I

I/O connections 14-090
I/O MOSS 14-090
I/O selection and interrupt mechanism 6-110
IAR 10-030
IC instruction 10-160
ICB (interface control block) location (map) 13-550
ICB (interface control/PSA block) description 13-554
ICC characteristics 1-052
ICC data flow 13-040
ICC jumpering 13-040
ICC modularity 1-052
ICC move 8-030
ICC or LIC, before moving 8-040
ICC packaging and components 13-040
ICC register 13-040, 13-541
ICC, packaging 1-050
ICT instruction 10-180
IML error flag 2-323
IML scanner 2-371
IML, MOSS 3-030
IML, steps 6-120
inbound data transfer sequence bit 12-030
indicator card 3-011
indicator card data flow 3-011
indicator card functions 3-011
initial selection 12-085, 12-086
initial selection address and command register 12-025
initial selection control register 12-025
initial selection interrupt 12-025
initial status byte stacked bit 12-025, 12-085
initialization of a channel-attached 3725 6-060
initialization of link-attached 3725 6-060
initialization request handling 6-130
initialization requests 6-060
initialization, controller 6-060
INITIALIZED, MSA 2-352
initiate service latch ungated bit 12-055
INOPERATIVE, MSA 2-352
input instruction 10-210
input registers 10-220
input X'7x' register bits 10-230, 10-231
input X'70' scoping 10-820
input/output (IOH) 11-055, 12-015, 12-065
input/output (IOHI) 11-055, 12-016, 12-065
insert ZAP 2-396
inserting the diskette 7-010
installation, microcode EC 8-010
instruction address register 10-030
instruction decoding 10-090, 10-110
instruction formats 10-100
instruction get error status 13-123
instruction operations 13-230
instruction RR (BALR, IOH, IOHI) 10-150
instruction set 10-040
instruction set LNVT high/low 13-123
instruction start line 13-123
instruction, address exception 10-250
instruction, B 10-190
instruction, BB 10-190
instruction, BCL 10-190
instruction, BCT 10-190
instruction, BZL 10-190
instruction, exit 10-200
instruction, IC 10-160
instruction, RE 10-210
instruction, register and storage with addition 10-180

- instruction, register to register 10-140
 instruction, RS 10-170
 instruction, RS on character 10-160
 interchange circuits 4-141
 interface disconnection 12-025
 interface, DCE 1-010
 interface, DTE 1-010
 interface, storage 10-050
 interface, transmission 1-010
 intermittent error, tentative repair action 1-070
 internal bus parity error bit 12-055
 internal clock card 1-052, 13-040
 internal clock card, packaging 1-050
 interrupt (level1) request 11-814
 interrupt (level2) test 11-814
 interrupt (level3) request 11-814
 interrupt (scanner) request to the MOSS 11-814
 interrupt autoselection 13-810
 interrupt autoselection (TRA) 15-810
 interrupt level 1/2 (TRM) 15-135
 interrupt level, MOSS 14-110
 interrupt levels 9-010
 interrupt mechanism 10-080
 interrupt operations (TRA) 15-060
 interrupt preselection 13-810
 interrupt preselection (TRA) 15-810
 interrupt priority structure 13-810
 interrupt priority structure (TRA) 15-810
 interrupt request in RAM A receive 13-510
 interrupt request in RAM A transmit 13-511
 interrupt request sources 10-081
 interrupt request to CCU (TRA) 15-810
 interrupt requests to CCU 13-810
 interrupt requests, resetting 10-080
 interrupt system 1-040
 interrupts autoselection 13-810
 interrupts, CCU 10-040
 invalid input instructions 10-210
 invalid output instructions 10-211
 IOC BER (type 14) 2-230
 IOC bus adapter interrupts 11-814
 IOC bus address format 11-040
 IOC bus address/command formats 11-040
 IOC bus command description 11-040
 IOC bus command format 11-040
 IOC bus configuration 11-801
 IOC bus connection 11-060
 IOC bus continuity plugs 4-290
 IOC bus data flow 11-010
 IOC bus error bit 12-055
 IOC bus error reporting 11-811
 IOC bus errors (CSP) 13-340
 IOC bus IFT diagnostics 11-802
 IOC bus interface 15-050
 IOC bus interface control (TIC) 15-041
 IOC bus interface errors (CSP) 13-321
 IOC bus interface signal lines summary (TRM) 15-050
 IOC bus isolation 11-803
 IOC bus lines 11-015
 IOC bus RDV states 11-801
 IOC bus shortening 11-803
 IOC bus structure 11-015, 11-016
 IOC bus terminator jumpers 4-290
 IOC bus terminator power warning 11-800
 IOC bus troubleshooting 11-800
 IOC check 2-351
 IOC control logic 10-090, 11-015
 IOC control logic, PIO operation 11-015
 IOC internal status table 10-231
 IOC registers 10-030
 IOC wire continuity 4-090
 IOH instruction 10-150, 11-055, 13-121
 IOHI instructions 10-120, 11-055
 IOIR scope points 14-850
 IPL CCU/TSS 2-365
 IPL CHECK, MSA 2-353
 IPL COMPLETE+ERRORS, MSA 2-353
 IPL exchange mechanism 6-140
 IPL exchanges over link IPL port 6-160
 IPL menu/selection 2-365
 IPL REQ 2-322
 Isolation, problem 2-171
- J**
- jumper pin removal/replacement 5-030
 jumpers installed on boards 4-270
 jumpers on IOC bus 4-290
 jumpers, ESC address range 4-282
 jumpers, installed on cards 4-280
 jumpers, summary table 4-260
- K**
- key, read only 10-250
 key, storage protect 10-250
 keyboard element replacement 6-032
 keyboard palm rest feature 6-034
 keyboard palm rest, installation and removal 6-034
- L**
- LA instruction 10-120
 LAB address 11-040
 LAB address jumpers 4-270
 LAB board layout 4-020
 LAB locations 4-011
 LAB numbering 1-050
 LAB position 3 line information 4-124
 LAB position 4 line information 4-125
 LAB position 5 line information 4-126
 LAB position 6 line information 4-127
 LAB position 7 line information 4-128
 LAB position 8 line information 4-129
 LAB type C 15-031
 LABA board card location 4-062
 LABB board card location 4-062
 LABC board card location 4-063
 lagging address register 10-030
 LAR 10-030
 last MOSS check code 2-351
 LCB (line control block) description 13-553
 LCB (line control block) location (map) 13-550
 LED replacement 7-140
 LIB (line interface buffer) description 13-555
 LIB (line interface buffers) location (map) 13-550
 LIC card move 8-050
 LIC card move from one board to another 8-030
 LIC card replacement 5-041
 LIC driver check 13-331
 LIC general reset 13-031
 LIC modularity 1-052
 LIC move physical representation 8-035
 LIC move procedure 8-030
 LIC or ICC, before moving 8-040
 LIC packaging 1-050
 LIC packaging and components 13-030
 LIC purpose 13-030
 LIC registers 13-030
 LIC to DCE interface scoping 13-820
 LIC type 1 1-053
 LIC type 1 autocal unit interface 4-160
 LIC type 1 DCE interface 4-140
 LIC type 2 1-053
 LIC type 3 1-053
 LIC type 4A 1-053
 LIC type 4A, 4B jumpers 4-282
 LIC type 4B 1-053
 LIC weight 1-052
 LIC/ICC compatibility 1-052
 LIC/ICC register description 13-540
 LIC1 autocal 4-160
 LIC1 DCE interface (Japan) 4-150, 4-151
 LIC1 direct attachment 4-170
 LIC1 registers 13-540
 LIC2 type 2 DCE interface 4-180
 LIC3 DCE interface 4-190
 LIC3 direct attachment 4-200
 LIC3 registers 13-541
 LIC4 registers 13-541
 LIC4A DCE interface 4-210
 LIC4A direct attachment 4-220
 LIC4B DCE interface (except France) 4-230
 LIC4B DCE interface (France only-transmix) 4-232
 LIC4B direct attachment 4-240
 line addressing 11-050
 line and IOH trace (NTRI) 2-034
 line attachment board address 11-050
 line character trace (BSC) 2-037
 line character trace (SDLC) 2-037
 line character trace (start/stop) 2-037
 line disabled/no-operation 13-013
 line error trace 2-037
 line group 11-050
 line ID loading (TRA) 15-137
 line identification (line ID) generation (TRA) 15-135
 line information, LAB position 3 4-124
 line information, LAB position 7 4-128
 line interface address 11-050
 line interface buffer See LIB
 line interface card 1-052, 13-030
 line interface card, packaging 1-050
 line operating character mode 13-111
 line operating modes 1-051
 line operating normal mode 13-111
 line operating service mode 13-111
 line reset 13-013
 line trace of remote load 6-171
 line trace of remote NCPabend 6-190
 line vector table, see LNVT
 LNVT definition 13-120
 LNVT pointer to 13-552
 load and start CLDP in CCU 6-090
 local storage 1-041
 local storage component location 4-010

location 4-010
location, diskette drive 7-040
location, local storage component 4-010
location, thermal switch 4-013
lock/unlock NCP buffers jumper 4-283
logic element replacement 6-033
logic partitioning 10-040
LOGREC 2-042
low-speed clock scoping 5-051
LSSD 10-090
LSSD bit identification 2-404
LSSD display 2-404
LSSD operation 14-070
LSSD operations 10-090
LSSD operations (from MOSS) 2-404, 14-071
LSSD register 14-071
LSSD testing circuit 14-070

M

machine clocks (other than high speed) 5-050
machine instructions 1-040
machine internal communications (TRA) 15-060
machine load table 2-407
machine status area 2-350 - 2-354
mailbox commands 14-141
mailbox description 14-140
mailbox exchange procedure 14-140
mailbox exchange timeouts 14-141
mailbox MOSS 13-552
mailbox status 14-141
main storage 1-040
main storage data flow 10-050
main storage description 10-050
main storage protection states 10-250
maintenance and operator subsystem 1-020, 1-060, 14-010
maintenance data operand register 10-030
Maintenance Device 2-450
Maintenance Device 2 3-040
maintenance operation screen 2-020
maintenance philosophy 1-070
maintenance, preventive 8-020
manual MOSS dump 2-440
manual routine B001 2-803
manual scanner dump 2-440
manual step switch, control panel 6-011
manual TIC dump 2-440
mask in BSC receive (RAM C) 13-532
mask in BSC transmit (RAM C) 13-533
mask in SDLC receive (RAM C) 13-530
mask in SDLC transmit (RAM C) 13-531
mask in start-stop receive (RAM C) 13-534
mask in start-stop transmit (RAM C) 13-534
MCC card test 6-110
MCC status register 14-030
MEF status byte 2-260
MEM card replacement 5-040
MEMx card 10-050, 10-070
message directory 2-480, 2-490, 2-491, 2-492
message exchanges 9-030
message format, system operation 9-030
messages, TRSS functions 2-520
messages, TSS functions 2-510
messages, utility program 2-500
microcode checkpoint trace 2-040

microcode data flow, general 13-110
microcode EC installation 8-010
microcode functions 13-110
microcode interaction with control program 13-120
microcode interaction with FES 13-130
microcode interaction with MOSS 13-140
microcode level 13-111
MIOC bus signal tables 4-082
MIOC control logic 10-090
MIOC data flow 10-090
MIOC direct operations 10-090
MIOC indirect operations 10-090
MLT 2-407
MLT file printing 2-460
MMB board layout 4-020
MMC card 14-011, 14-012
MMC card replacement 5-040
mode (TRSS) 2-387
mode control register A 14-051
mode control, scanner 2-372
mode, line operating 13-111
modem change detection 13-261
modem interface test set 3-040
modem line management 13-261
modify ZAP 2-396
module display 2-393
module extractor/aligner 3-013
MOSS adapter read command timing chart 14-840
MOSS adapter write command timing chart 14-840
MOSS adapters 1-060
MOSS address compare register 14-051
MOSS buses signal tables 4-083
MOSS card interconnection 14-012
MOSS card organization 14-010, 14-012, 4-060
MOSS changes of state 14-101
MOSS check code 2-351
MOSS clocking 14-810
MOSS command completion 13-352
MOSS command status 13-352
MOSS communication between MOSS and NCP/EP 14-140
MOSS completely down 14-820
MOSS connection to control panel 6-020
MOSS console connections 14-090
MOSS control 6-010
MOSS control panel connections 14-090
MOSS data flow 14-010
MOSS description 14-010
MOSS diskette adapter 1-060
MOSS diskette drive 14-080
MOSS dump 2-440
MOSS dump file printing 2-467, 2-468
MOSS error area 13-552
MOSS error detection 14-160
MOSS error status register 15-108
MOSS functions 14-010
MOSS hardware checking 14-160
MOSS IML 6-070
MOSS IML step description 6-110
MOSS indirect operation register 14-040
MOSS initialization 6-120
MOSS inoperative lamp 6-010
MOSS interrupt levels 14-110
MOSS IOC bus testing 6-110
MOSS isolation 14-810
MOSS loop on error 14-831
MOSS LSSD register 14-071
MOSS mailbox protocol 14-140
MOSS message lamp 6-010
MOSS microcode 14-100

MOSS or scanner dump delete 2-392
MOSS or scanner dump display 2-391
MOSS PIO bus and internal signal routing 14-835
MOSS PIO bus protocol 14-012
MOSS processor 14-011
MOSS processor checkout 6-110
MOSS processor storage and microcode 1-060
MOSS record printing 2-462
MOSS reduced configuration 14-830
MOSS register MAP 14-141
MOSS register space allocation 14-120
MOSS reset 6-110
MOSS scanner and TRSS dump display/delete 2-391
MOSS scanner communication 14-150
MOSS sense codes 14-110
MOSS software checking 14-160
MOSS states 14-100
MOSS status 2-350
MOSS storage address test 14-840
MOSS storage errors 2-801
MOSS storage map 14-011
MOSS storages 14-011
MOSS store and module display 2-393
MOSS timing charts 14-840
MOSS to CCU adapter 1-060
MOSS to CCU communication 14-020, 14-140
MOSS to CCU internal bus scoping routine 14-883
MOSS to CCU internal bus, physical 14-880
MOSS to CCU internal bus, read operation 14-882
MOSS to CCU internal bus, write operation 14-881
MOSS to CCU interrupt registers 14-040
MOSS to CCU operations 14-020, 14-140
MOSS to CCU status registers 14-040, 14-051
MOSS to control panel cable 4-083
MOSS to diskette cable 4-083
MOSS troubleshooting 14-800
MPC card 14-011, 14-012
MPC card replacement 5-040
MROS card replacement 5-040
MSA, BYP-CCU-CHK 2-350
MSA, BYP-IOC-CHK 2-351
MSA, CCU/scanner IPL 2-353
MSA, CCU/scanner IPL information 2-350, 2-353
MSA, HARDCHK 2-351
MSA, HARDSTOP 2-351
MSA, I-STEP 2-350
MSA, IPL-REQ 2-351
MSA, LAST MCHK;xxx 2-351
MSA, MOSS-ALONE 2-350
MSA, MOSS-OFFLINE 2-350
MSA, MOSS-ONLINE 2-350
MSA, PROCESS 2-350
MSA, RESET 2-351
MSA, RUN 2-351
MSA, scanner information 2-350, 2-352
MSA, SERVICE-MODE 2-350
MSA, STOP-AC 2-351
MSA, STOP-BT 2-351
MSA, STOP-CCU-CHK 2-350
MSA, STOP-IOC-CHK 2-351
MSA, STOP-PGM 2-351
MSA, with TRA/TIC information 2-350, 2-354
multiple interrupt requests on same level 10-080
multiplex mode 12-210
multiplexer channel 12-210
multistation access unit 8228 15-022

N

NCCF 1-023, 2-032
 NCP address trace 2-034
 NCP branch trace 2-033
 NCP channel adapter trace 2-033
 NCP channel commands information 12-110
 NCP generalized PIU trace 2-033
 NCP line trace 2-034
 NCP scanner interface trace 2-035
 NCP sense information 12-120
 NCP session trace 2-033
 NCP SIT 2-035
 NCP SIT record units 2-036
 NCP status information 12-115
 NCP transmission group trace 2-034
 NCP/EP command status 13-351
 net list, example 4-030
 network configuration changes 1-023
 network control program 1-023
 network problem determination application 1-023
 NLDM 1-023, 2-032
 NLDM users 2-032
 no FRU isolated 1-070
 normal mode 1-051
 normal mode (contrast with character mode) 9-040
 normal operation screen 2-020
 NPDA messages 2-050
 NSC address 9-030
 NSC address active bit 12-045
 NSC address jumpers 4-281
 NSC final status transfer 12-100
 NSC initial status chart 12-086
 NSC mode 12-005, 12-010
 NSC stacked final status 12-100
 NSC status/control register 12-040
 NSC, initial status chart 12-086
 NTO 1-023
 NTRI traces 2-034

O

OLT (CA responder) 2-152
 OLT (CA) 2-152
 OLT CDS for the 3725 2-153
 OLT procedure 2-151
 OLT routine list 2-152
 OLT running restrictions 2-152
 online test group 2-150
 OP register 10-030
 operation register 10-030
 operation, ROS 10-031
 operational in tag 12-140
 operational out tag 12-140
 operator console adapter 1-060
 operator console anti-glare feature 6-034
 operator console interface, wrap block 6-040
 operator console keyboard rest feature 6-034
 operator console sharing 6-040
 operator console test 6-031
 operator console, elements 6-030
 operator console, keyboard element replacement 6-032
 operator console, logic element replacement 6-033
 operator console, test switch 6-030

operator console, video element adjustment 6-031
 operator console, video element replacement 6-032
 operator console, video element testing 6-031
 outbound data transfer bit 12-030
 output exception check bit 12-055
 output instruction 10-211
 output registers 10-230
 output X'7x' register bits 10-240
 output X'71' instruction 2-351
 output X'72' instruction 2-352
 output X'74' instruction 10-825
 overview token-ring network 15-020

P

packaging, CLAB 1-050
 packaging, C2LB 1-050
 packaging, C2LB2 1-050
 packaging, LAB 1-050
 packaging, MOSS 1-060
 packaging, storage 10-050
 packaging, TSS 1-050
 packaging, 3725 model2 1-041
 packaging, 3725/3726 1-041
 parallel data field (PDF) in RAM A 13-510, 13-511
 parallel data field (PDF) in RAM B 13-521, 13-520
 parameter status area, see PSA
 part location, diskette drive 7-040
 partitioned emulation programming extension 1-023
 PCI level3 interrupt scoping 11-809
 PCW 2-281
 permanent BSC/SS device errors 3-050
 permanent BSC/SS line error, RECMS decoding 3-050
 permanent interrupt after reset 14-850
 permanent SDLC line error 3-056
 PF keys 2-373
 PF keys on BER list screen 2-180
 PFAR register 10-030
 physical LIC move 8-035
 pin addressing 4-030
 pin list, example 4-030
 pin lists 4-030
 ping/pong buffers 13-012
 PIO bus protocol 11-015
 PIO bus read timing 11-812
 PIO bus write timing 11-812
 PIO format and types (TRA) 15-105
 PIO format at TA time (TRA) 15-105
 PIO halt remember latch bit 12-055, 12-080
 PIO initiated by the CCU 11-020
 PIO initiated by the MOSS 11-020
 PIO mode 10-020
 PIO mode bit 12-045
 PIO operation 11-020, 11-021, 11-022
 PIO operation sequence 11-020
 PIO operation sequence, data transfer 11-021
 PIO operation sequence, initialization 11-021
 PIO read sequence (TRA) 15-110
 PIO read timing 11-022
 PIO scoping routine for IOC bus 11-805, 11-806
 PIO scoping, channel adapters 11-809
 PIO scoping, scanners 11-808
 PIO scoping, TRAs 11-809
 PIO types (TRA) 15-105
 PIO types for IIC 15-105
 PIO write sequence (TRA) 15-110
 PIO write timing 11-022
 PIO-MMIO operations 15-060
 PIO-MMIO hand-shaking mechanism (TRM) 15-115
 PIO-MMIO read (TRM) 15-115
 PIO-MMIO write (TRM) 15-115
 PIU trace 2-031
 POPR register 10-030
 power board layout 4-021
 power control 6-011
 power jumpers 4-300
 power mode switch 6-011
 power on checks 14-820
 power on lamp, control panel 6-011
 power on lamp, operator console 6-030
 power on/off switch, control panel 6-011
 power on/off switch, operator console 6-030
 power service area, control panel 6-011
 power supply adjustments 5-060
 power terminator cards 4-300
 pre-fetch address register 10-030
 pre-fetch operation register 10-030
 preselection mechanism (TRA) 15-810
 preventive maintenance 8-020
 primary control field (PCF) in RAM B receive 13-520
 primary control field (PCF) in RAM B transmit 13-521
 primary IOC cables 4-080
 primary menu 2-020
 primary redrive address 11-070
 printing general scanner configuration frame 2-462
 printing scanner detailed information records 2-463
 printing the BER list 2-466
 printing the CDF 2-461
 printing the configuration data file 2-461
 printing ZAP history tables 2-465
 priority outbound service bit 12-031, 12-032
 program generation 1-023
 program requested interrupt bit 12-030
 program wait lamp 6-010
 program-initiated operation 12-035
 programmed input/output operations (TRA) 15-100
 programmed reset function (TRA) 15-155
 programmed reset TRM 15-120
 programming support for the host 1-023
 protocol handling 9-050
 PSA area 13-120
 PSA data buffers 13-121
 PSW condition codes and page pointer 2-260
 PT-2 channel monitor 3-040
 PT-2 high-speed trace programs 3-040
 PT-2 SNA edit and display program 3-040
 PT-2 tool 3-040
 PT-2 TP exercise program 3-040
 PT-2 TP line monitor 3-040
 PTX replacement 7-140
 purge BER 2-409
 purpose of ICC 13-040
 purpose of the token-ring network 15-020
 PWB1 board card location 4-063
 PWB2 board card location 4-064

R

RA instructions 10-120
 RAM A 13-130
 RAM A description 13-510
 RAM A receive 13-510
 RAM A transmit 13-511
 RAM B description 13-520
 RAM B receive 13-520
 RAM B transmit 13-521
 RAM C 13-131
 RAM C BSC receive 13-532
 RAM C BSC transmit 13-533
 RAM C description 13-530
 RAM C SDLC receive 13-530
 RAM C SDLC transmit 13-531
 RAS 1-023
 RDV card replacement 5-042
 RDV card scoping 11-807
 RDV clocking 11-804
 RDV disconnection 11-803
 RDV in 3725 data flow 11-010
 RE instruction 10-210, 10-211
 re-IML, MOSS 3-030
 read computed line ID by MOSS (TRA) 15-120
 read CSCW (TRA) 15-120
 read load line ID base (TRA) 15-120
 read only key 10-250
 read storage size command 10-060
 read storage timing 10-832
 read/modify/write storage timing 10-833
 receive and transmit commands for FES 13-131
 receiving a file, data base to MD 2-452 to 2-457
 receiving a file, MD to MD 2-458
 RECMS record formats 3-050
 redrive, addressing on boards 11-070
 redrive, card implementation 11-060
 redrive, card scoping 11-807
 redrive, cards 11-060
 redrive, channel adapter 1-041
 redrive, commands 11-100, 11-101, 11-070
 redrive, diagnostic read command 11-101
 redrive, diagnostic write command 11-101
 redrive, disable driver command 11-101
 redrive, disable jumper 11-090, 11-803
 redrive, disconnection 11-803
 redrive, enable driver command 11-101
 redrive, error register 11-080
 redrive, functions 11-080
 redrive, group address 11-070
 redrive, group address 11-070
 redrive, IOC bus 11-015
 redrive, numbering 11-070
 redrive, poll command 11-100
 redrive, read error register command 11-100
 redrive, record printing 2-462
 redrive, reset 11-080
 redrive, reset redrive command 11-101
 redrive, state definitions 11-090
 redrive, states 11-801
 redrive, write error register command 11-100
 refresh 10-060
 register and immediate address instructions 10-120
 register and storage with addition instructions 10-180
 register description 13-420
 register external instructions 10-210
 register immediate instructions 10-130
 register in X'76' 11-811

register to register instructions 10-140
 register to storage on character instruction 10-160
 register X'B' 12-021, 12-050
 register X'C' 12-021, 12-050
 register X'D' 12-022, 12-055
 register X'E' 12-022, 12-060
 register X'F' 12-022, 12-060
 register X'1' 12-020, 12-025
 register X'2' 12-020, 12-030, 12-031
 register X'3' 12-020, 12-035
 register X'4' 12-021, 12-035
 register X'5' 12-021, 12-035
 register X'6' 12-040
 register X'7' 12-021, 12-045, 12-046
 register, branch trace 14-050
 register, definition of external 10-220
 register, diskette adapter status 14-080
 register, MDOR 10-030
 register, MOSS/CCU interrupt 14-040
 register, pre-fetch operation 10-030
 register, storage address 10-030
 register, X'0' 12-025
 registers, CSP FES 13-010
 reliability, 1-023
 remote power off (RPO) 6-050
 removal, CADR card 3-020
 removal, CCU board 5-010
 removal, RDV card 3-020
 removing the CADR card from the host channel
 interface 3-020
 removing the diskette 7-010
 repair action in case of solid error 1-070
 replacement, CCU board 5-010
 replacement, operator console elements 6-032
 replacement, redrive card 5-042
 replacements, chapter 5
 request byte count bit 12-032, 12-050
 request in tag 12-140
 reserved scanner storage areas 13-121
 reset CCU/LSSD 2-360, 2-361
 reset channel adapter level 1 checks bit 12-046
 reset data status control bit 12-031
 reset functions 6-060
 reset ICC 13-040
 reset initial selection bit 12-031
 reset initial selection register 12-025
 reset line path 6-050
 reset of FES 13-021
 reset of LIC 13-031
 reset redrive 11-080
 reset system reset/NSC address active bit 12-046
 reset TIC function 15-155
 reset to neutral state bit 12-040
 reset/freeze command for FES 13-131
 RESET, MSA 2-351, 2-352
 resets, controller 6-050
 residual byte count bits 12-031, 12-050
 restore ZAP 2-396
 RI instructions 10-130
 ring interface electrical characteristics 4-131, 15-600
 ring transmitter/receiver 15-600
 ROS operation 10-031
 RR instruction on character 10-140
 RR instruction on halfword and word 10-140
 RR instructions (except BALR, IOH, IOHI) 10-140
 RS instructions on character 10-160
 RS instructions on halfword and word 10-170, 10-171
 RSA instructions 10-180
 RT instructions 10-190

S

SALT 3-045
 save area mail box 13-552
 save BER 2-409
 scan ZAP 2-397
 scanner addressing 11-050
 scanner and TRA modularity 1-051
 scanner base control in RAM A transmit 13-511
 scanner base control in RAM A receive 13-510
 scanner base layer 13-013
 scanner board information 4-120, 4-121, 4-122
 scanner board information LAB 6 4-127
 scanner board information LAB 7 4-128
 scanner board information LAB 8 4-129
 scanner board information, CLAB1 4-122
 scanner board information, CLAB2 4-123
 scanner board information, C2LB 4-120
 scanner board information, C2LB2 4-121
 scanner board information, LAB position 3 4-124
 scanner board information, LAB position 4 4-125
 scanner board information, LAB position 5 4-126
 scanner commands 13-013
 scanner configuration 13-261
 scanner connection 13-013
 scanner control block (SCB) description 13-551
 scanner display/alter store 2-373
 scanner dump 2-430, 2-440
 scanner dump, MSA 2-352
 scanner errors without BERs 2-806
 scanner IML 6-090
 scanner IML principle 6-120
 scanner IML step description 6-120
 scanner IML, MSA 2-352
 scanner in RAM A transmit 13-512
 scanner initialization 13-013
 scanner interrupt request to the MOSS 11-814
 scanner microcode sequence of operation 2-040
 scanner performance 1-051
 scanner pre-autoselection 11-050
 scanner reserved storage areas 13-121
 scanner scanning sequence 13-261
 scanner state 13-013
 scanner storage map 13-550
 scanner/MOSS communication 14-150
 SCB 2-323
 scenario for IOC level 1 error recovery (TRM) 15-135
 scope point references 5-050
 scope points 5-051, 5-052
 scoping, high speed clock 5-051
 screen layouts 2-020
 SCTL card 10-050
 SCTL function 10-070
 SDLC line error 3-056
 SDLC receive 13-530
 SDLC transmit 13-531
 secondary bus enabling warning 11-800
 secondary control field (SCF) in RAM A transmit 13-511
 secondary control field (SCF) in RAM B receive 13-520
 secondary in RAM B transmit 13-521
 secondary IOC cables 4-085
 secondary redrive address 11-070
 select addressed channel adapter bit 12-045
 select in tag 12-141
 select out priority jumpers 4-280
 select out tag 12-141
 select/release scanner 2-370
 select, CDF 2-400

selected CA data/status level 3 interrupt bit 12-060
 selected CA initial select level 3 interrupt bit 12-060
 selection of utility programs 2-390
 selective reset 12-025
 selective reset bit 12-030
 selector channel timing 12-200
 selector mode 12-200
 serial data field (SDF)
 serial in RAM B receive 13-520
 serial in RAM B transmit 13-521
 service diskette 1-060
 service diskette, primary menu 2-020
 service in tag 12-141
 service mode 1-051
 service out tag 12-141
 service procedures, chapter 2
 serviceability 1-023
 set allow channel interface enable/disable bit 12-046
 set command (TRM) 15-120
 set ESC command free bit 12-046
 set ESC operational bit 12-046
 set force A busy bit 12-040
 set force B busy bit 12-040
 set mode in BSC receive (RAM C) 13-532
 set mode in BSC transmit (RAM C) 13-533
 set mode in SDLC receive (RAM C) 13-530
 set mode in SDLC transmit (RAM C) 13-531
 set monitor for circle B bit 12-032
 set monitor for 2848 ETX bit 12-032
 set NSC status byte
 set program requested interrupt bit 12-046
 set reset outbound transfer sequence bit 12-031
 set suppress out monitor bit 12-046
 set suppressible status bit 12-032
 set/get TIC control register 15-106
 set/get TRM control register 15-106
 set/reset diag storage mode 12-040
 set/reset ESC operation bit 12-031
 set/reset inbound data transfer sequence bit 12-031
 set/reset PIO mode bit 12-031
 set/reset status transfer sequence 12-031
 setting interrupt requests 10-080
 shift register latch 14-040
 shipping group tools 3-010
 signal name abbreviations 4-130
 signal routing documentation 4-030
 signal routing, CA autoselection 12-804
 signal routing, cycle steal CA 12-810
 signal tables 4-080
 single-frame configuration 1-021
 SIT trace records 2-036
 SNA link permanent errors 3-054
 SNA station permanent errors 3-055
 software error, software or hardware detected 2-250
 spare diskette, update 2-399
 speed mixing on LIC 1-052
 SSP 1-023
 stand-alone link test 3-045
 start line initial (SLI) instruction 13-122
 start line initial instruction operation 13-230
 start line instruction commands 13-124
 start-stop receive (in RAM C) 13-534
 start-stop transmit (in RAM C) 13-534
 STAT(system status) 2-322
 status byte cleared bit 12-025
 status in tag 12-141
 status transfer operation, FES 13-260
 status transfer sequence bit 12-030, 12-031
 STCT instruction 10-180

STOP-BT, MSA 2-351
 STOP-IOC-CHK, MSA 2-351
 STOP-X70, MSA 2-351
 storage address register 10-030
 storage addressing 10-050
 storage buses 10-050
 storage cables 4-081
 storage cards 10-050
 storage configurations 10-070
 storage control out tag 10-825
 storage data flow 10-070
 storage double bit errors 2-803
 storage FES 13-130
 storage location 1-040
 storage mapping, DCF 14-135
 storage mapping, MOSS 14-130
 storage operation timing 10-060
 storage operations 10-050
 storage partitioning 10-070
 storage protect 10-250
 storage protect error handling 10-250
 storage protect instructions 10-250
 storage protect key 10-250
 storage signal routing 10-841
 storage size, CCU 1-040
 storage troubleshooting 10-800
 storage word 10-050
 storage, address exception 10-250
 storage, display LSRs 2-376
 storage, display storage 2-373
 storage, MOSS 1-060
 storage, refresh 10-060
 suppress out bit 12-030
 suppress out monitor interrupt bit 12-030
 suppress out tag 12-141
 SYN monitor latch bit 12-050
 synchronization in RAM B receive 13-520
 synchronization in RAM B transmit 13-521
 SYSREC 2-042
 system interrupts 9-010
 system message exchange sequence 9-030
 system operations, chapter 9
 system reset 12-025
 system tests 2-160

T

tailgate connector installation 8-050
 tailgate level wrap test 2-048
 TCAM alert messages 2-050
 telecommunications access method 1-023
 terminator card diagram 4-095
 test/normal switch, operator console 6-030
 test/operate switch 4-151
 testing the indicators 3-011
 testing the LEDs 3-011
 testing the machine before the LIC move 8-040
 thermal switch locations 4-013
 thermal switch type airflow detector 4-013
 thread wrap block (part 147440, Japan only) 4-160
 thresholds 2-171
 TIC adapter check register 15-137
 TIC adapter check register decoding 15-138
 TIC bring-up error code (test = 1) 15-170
 TIC bus interface 15-051
 TIC bus signal lines 15-051

TIC bus signal lines summary 15-051
 TIC card data flow 15-040
 TIC data flow 15-040
 TIC dump 2-440
 TIC dump storage, TRA 2-384
 TIC initialization 15-170
 TIC interface management by the TRM 15-115
 TIC internal RAM format, TRA 12-383
 TIC internal trace 2-034
 TIC interrupt scenario 15-136
 TIC interrupts 15-136
 TIC read interrupt register (initialize) 15-170
 TIC receive operation 15-042
 TIC transmit operation 15-042
 tightly-coupled alternate path host operations 12-075
 tightly-coupled host operations 12-075
 timer in RAM A receive 13-511
 timer in RAM A transmit 13-511
 timer operation 10-260
 timer, 100 ms interval 10-260
 timing, CCU 10-040
 token-ring access control protocol 15-021
 token-ring adapter 15-020, 1-054
 token-ring adapter isolation (3725/3726) 15-800
 token-ring adapter, functions 1-054
 token-ring adapter, limitations 1-054
 token-ring adapter, modularity 1-054
 token-ring bridges 15-022
 token-ring cabling system (ring) 15-020
 token-ring encoding 15-021
 token-ring front end 15-041
 token-ring general frame format 15-021
 token-ring interface adapters 15-021
 token-ring interface coupler card (TIC) 15-040
 token-ring interface coupler card, weight 1-054
 token-ring interface coupler card, type 1-054
 token-ring interface electrical characteristics 4-131, 15-600
 token-ring LID general description 15-135
 token-ring major system components 15-021
 token-ring message processor 15-041
 token-ring MOSS error register 15-108
 token-ring multiplexer card 1-054
 token-ring network definition 15-020
 token-ring network overview 15-020
 token-ring network purpose 15-020
 token-ring nodes 15-021
 token-ring protocol handler 15-041
 token-ring receiver 15-600
 token-ring subsystem 1-020, 1-050
 token-ring subsystem data flow 15-030
 token-ring subsystem in the 3725 15-031
 token-ring subsystem, board characteristics 1-050
 token-ring subsystem, packaging 1-050
 token-ring transmission media 15-020
 token-ring transmitter 15-600
 token-ring typical multi-floor wiring 15-022
 token-ring wrap test 2-044
 tool, wrap block 3-012
 tools and test equipment 3-013
 tools, chapter 3
 tools, diskette drive (special) 7-011
 torque screwdriver 3-012
 TPS installed bit 12-060
 TPS, effect of selective reset 12-076
 TPS, effect of system reset 12-076
 TPS, loosely-coupled 12-075
 TPS, presentation of CA status 12-076
 TPS, selective reset over interface having allegiance 12-076

TPS, selective reset over interface not having allegiance 12-076
 TPS, system reset over interface having allegiance 12-076
 TPS, system reset over interface not having allegiance 12-076
 TPS, system reset when the CA is in the neutral state 12-076
 TPS, tightly-coupled 12-075
 TRA addressing 11-050
 TRA DC voltages and tolerances at board pin level 15-600
 TRA initialization error code (test = 0) 15-170
 TRA interaction with control program 15-170
 TRA reset operations 15-155
 TRA select, connect/disconnect 2-380
 trace, comparison 2-042
 trace, extended buffer 2-031
 trace, high speed trace limitations for NCP SIT 2-035
 trace, NCP line trace 2-035
 trace, objectives (NCP SIT) 2-035
 trace, record unit formats 2-036
 trace, save area 13-550
 trace, scanner interface 2-035
 trace, summary 2-042
 tracing in an ACF/VTAM environment 2-030
 tracing on the 3725 2-030
 transferring a file: MD to VM or MD to MD 2-451
 transmission interface 1-011
 transmission subsystem 1-020, 1-050
 transmission subsystem clocking 13-800
 transmission subsystem isolation 13-800
 transmission subsystem troubleshooting 13-800
 transmission subsystem, redrive 1-050
 transmix (France) 4-232
 TRM arbitration mechanism 15-051
 TRM AS/DS checker (timer) 15-160
 TRM buffer and extended buffer 15-106
 TRM card description 15-050
 TRM card scoping 11-809
 TRM cycle steal operations 15-130
 TRM cycle steal preselection (TRM) 15-820
 TRM cycle steal requests to CCU (TRM) 15-820
 TRM data strobe checker 15-160
 TRM direct long and indirect operation for normal cycle steal 15-130
 TRM direct short operation for error cycle steal operation 15-130
 TRM disconnect operation scenario 15-135
 TRM DTACK checker (timer) 15-160
 TRM error detection and reporting 15-160
 TRM hardware checkers placement 15-160
 TRM idle checker of the IIC address/data bus 15-160
 TRM idle checker of the IIC bus tags 15-160
 TRM internal parity checker 15-160
 TRM interrupt operations 15-135
 TRM interrupt scenario 15-136
 TRM interrupt to MOSS general operation 15-138
 TRM interrupt to MOSS scenario 15-138
 TRM invalid PIO checker 15-160
 TRM level 1 interrupt 15-135
 TRM level 1/2 error status register 15-107
 TRM level 1/2 interrupt 15-135
 TRM mapping of DMA to cycle steal 15-130
 TRM mapping of PIO to MMIO 15-115
 TRM parity checker to the IOC bus 15-160
 TRM PIO command description 15-120
 TRM PIO functional description 15-110
 TRM PIO get line identification 15-120
 TRM PIO initialization 15-110
 TRM PIO management 15-110

TRM PIO operation 15-100
 TRM selection 15-110
 troubleshooting techniques, CCU and storage 10-750, 10-751
 troubleshooting, token-ring subsystem 15-800
 troubleshooting, transmission subsystem 13-800
 TRSS BER processing 2-805
 TRSS clocking 15-800
 TRSS connect function 15-150
 TRSS CS-DMA operations 15-060
 TRSS diagnostics organisation 15-800
 TRSS dump delete 2-392
 TRSS dump display 2-391
 TRSS extended troubleshooting techniques 15-750
 TRSS function messages 2-520
 TRSS impact on NCP level 1 code 15-060
 TRSS mode 2-387
 TRSS PIO-MMIO operation 15-060
 TRSS, disconnect/connect function 15-150
 TRU formats 2-036
 TSS BER processing 2-805
 TSS clocking 13-800
 TSS diagnostics after LIC Move 8-065
 TSS error detection 13-320
 TSS function messages 2-510
 TSS function, alter external registers 2-376
 TSS function, alter LSRs 2-376
 TSS function, alter scanner blocks 2-375
 TSS function, display external registers 2-376
 TSS function, display LSRs 2-376
 TSS function, display scanner blocks 2-375
 TSS function, display storage 2-373
 TSS function, IML a scanner 2-371
 TSS function, modify scanner mode 2-372
 TSS function, PF keys for display or alter storage 2-373
 TSS function, scanner address compare 2-377
 TSS function, select a scanner 2-370
 TSS functions 2-370
 TSS functions, selection from controller diskette 2-370
 TSS functions, selection from the service diskette 2-370
 TSS hardware error in data flow 13-320
 TSS in 3725 data flow 13-005
 TSS, error reporting to the CCU, CSP/FES interface 13-330
 TSS, error reporting to the CCU, detected by microcode 13-331
 TSS, error reporting to the MOSS, CSP IOC bus interface 13-340
 TSS, error reporting to the MOSS, detected by hardware 13-340
 TSS, error status description 13-350
 TSS, errors during AIO 13-340
 TSS, errors during PIO 13-340
 TSS, redrive 1-050
 TSS, reporting errors to the CCU 13-330
 TSS, reporting errors to the MOSS 13-340
 TTA table 2-260
 TTA test 6-110
 two-frame configuration 1-022
 two-processor switch 1-041
 two-processor switch (tightly coupled hosts) 12-075
 two-processor switch, loosely coupled hosts 12-075
 typical multi-floor wiring 15-022

U

UCW definition 12-005
 unexpected CCU interrupt processing 10-850
 UNKNOWN-MODE, MSA 2-352
 unresolved interrupts 2-171, 2-807
 update spare diskette 2-399
 USASCII monitor control latch bit 12-050
 use of PF keys on BER detail screen 2-181
 user application network 1-010
 using CCU functions during initialization 6-100
 utility program, 2-390, 2-500
 utility program, alter ZAP record 2-395
 utility program, CDF (3725) display or update 2-402
 utility program, copy ZAPs 2-399
 utility program, create-ZAP 2-397
 utility program, delete ZAP record 2-395
 utility program, display all CDF (3725) 2-402
 utility program, display CCU/MOSS 2-402
 utility program, display channel adapters 2-403
 utility program, display channel adapters (3725 Model2) 2-403
 utility program, display C2LB/LAB 2-402
 utility program, display LAB/CAB 2-402
 utility program, display LSSD 2-404
 utility program, display scanners 2-403
 utility program, display/delete dump 2-391
 utility program, insert ZAP record 2-395
 utility program, machine load table 2-407
 utility program, messages 2-480
 utility program, scan ZAP 2-395
 utility program, selection 2-390

V

V.24 (CCITT) 4-140
 verify, CDF 2-401
 video element replacement 6-032
 voltage pin assignments 4-020
 voltage plan, all boards except CCU 4-040
 voltage plan, CCU board 4-022
 voltage plan, G and J pins 4-041
 voltage plan, M and P pins 4-042
 voltage plan, S and U pins 4-043
 VTAM alerts messages 2-050
 VTAM I/O trace 2-030
 VTAM internal trace 2-030

W

working registers 10-030
 wrap block (part 1733977) 4-150, 4-160, 4-170,
 4-180, 4-210, 4-220, 4-230, 4-232, 4-240
 wrap test (token-ring) 2-044
 wrap test at tailgate 2-044, 2-046, 2-048
 wrap test controlled from the MOSS 2-046
 wrap test start screen 2-048
 wrap tests 2-044
 write diskette 7-052
 write IPL request handling on the MOSS side 6-130
 write storage data register 10-030
 write/read interrupt request and bus request
 register 15-106
 WSDR 10-030

X

X'00' (IOC bus control 1) 13-430
 X'00' (IOC bus control 1), external register 13-430
 X'02' (IOC bus service), external register 13-430
 X'04' (miscellaneous/adaptor address) 13-431
 X'04', external register 13-431
 X'07' (synchro/configuration data set) 13-431
 X'07', external register 13-431
 X'1A' (current CSP interrupt level) 13-433
 X'1A', external register 13-433
 X'1C' (address compare byte 0) 13-434
 X'1C', external register 13-434
 X'1E' (CSP interrupt masks) 13-434
 X'1E', external register 13-434
 X'10' (extended interrupt request) 13-432
 X'10', external register 13-432
 X'13' (line interface address (read/write) 13-432
 X'13', external register 13-432
 X'15' (asynchronous operation command) 13-432
 X'15', external register 13-432
 X'17' (FES general commands) 13-433
 X'17', external register 13-433

Z

Z register 10-030
 ZAP 2-394
 ZAP, creating 2-394
 ZAP, erasing 2-394
 ZAP, fonction selection 2-395
 ZAP, history table 2-407
 ZAP, history table file printing 2-465
 ZAP, identification 2-394

0

01L voltage pins 4-043

3

3725 alarm messages 2-050
 3725 CDS card and storage layout 2-153
 3725 control program trace 2-033
 3725 data flow 10-005
 3725 model 1 block diagram 1-021
 3725 model 1/3726 block diagram 1-022
 3725 model 2 block diagram 1-020
 3725 trace 2-033
 3727 operator console 6-030
 3727 operator console interface 6-040
 3727 operator console, controls and locations 6-030

5

5 volt power supply jumpers 4-300
 51TD control card 7-054
 51TD control card cable 7-054
 51TD test pins 7-054

READER'S
COMMENT
FORM

3725/3726 Communication Controller and Expansion
Maintenance Information Manual (MIM) Part 1 Volume 1
Order No. SY33-2018-7

This manual is part of a library that serves as a reference source for customer engineers. You may use this form to communicate your comments about this publication, its organization, or subject matter, with the understanding that IBM may use or distribute whatever information you supply in any way it believes appropriate without incurring any obligation to you.

Your comments will be sent to the author's department for whatever review and action, if any, are deemed appropriate. Comments may be written in your own language: English is not required.

Note: Copies of IBM publications are not stocked at the location to which this form is addressed. Please direct any requests for copies of publications, or for assistance in using your IBM system, to your IBM representative or to the branch office serving your locality.

Possible topics for comments are:

Clarity Accuracy Completeness Organization Coding Retrieval Legibility

If you wish a reply, give your name, company, mailing address, and date:

.....
.....
.....
.....

What is your occupation?

Number of latest Newsletter associated with this publication:

Thank you for your cooperation. No postage stamp necessary if mailed in the USA. (Elsewhere, an IBM office or representative will be happy to forward your comments or you may mail directly to the address in the Edition Notice on the back of the title page.)

Note: Staples can cause problems with automated mail sorting equipment.
Please use pressure sensitive or other gummed tape to seal this form.

READER'S
COMMENT
FORM

3725/3726 Communication Controller and Expansion
Maintenance Information Manual (MIM) Part 1 Volume 1
Order No. SY33-2018-7

This manual is part of a library that serves as a reference source for customer engineers. You may use this form to communicate your comments about this publication, its organization, or subject matter, with the understanding that IBM may use or distribute whatever information you supply in any way it believes appropriate without incurring any obligation to you.

Your comments will be sent to the author's department for whatever review and action, if any, are deemed appropriate. Comments may be written in your own language: English is not required.

Note: Copies of IBM publications are not stocked at the location to which this form is addressed. Please direct any requests for copies of publications, or for assistance in using your IBM system, to your IBM representative or to the branch office serving your locality.

Possible topics for comments are:

Clarity Accuracy Completeness Organization Coding Retrieval Legibility

If you wish a reply, give your name, company, mailing address, and date:

.....
.....
.....
.....

What is your occupation?

Number of latest Newsletter associated with this publication:

Thank you for your cooperation. No postage stamp necessary if mailed in the USA. (Elsewhere, an IBM office or representative will be happy to forward your comments or you may mail directly to the address in the Edition Notice on the back of the title page.)

Note: Staples can cause problems with automated mail sorting equipment.
Please use pressure sensitive or other gummed tape to seal this form.



Reader's Comment Form

Reader's Comment Form

Fold and tape

Please Do Not Staple

Fold and tape

Fold and tape

Please Do Not Staple

Fold and tape



NO POSTAGE
NECESSARY
IF MAILED
IN THE
UNITED STATES

NO POSTAGE
NECESSARY
IF MAILED
IN THE
UNITED STATES

BUSINESS REPLY MAIL
FIRST CLASS PERMIT NO. 40 ARMONK, N.Y.

BUSINESS REPLY MAIL
FIRST CLASS PERMIT NO. 40 ARMONK, N.Y.

POSTAGE WILL BE PAID BY ADDRESSEE:

POSTAGE WILL BE PAID BY ADDRESSEE:

International Business Machines Corporation
Department 6R1LG
180 Kost Road
Mechanicsburg
PA 17055

International Business Machines Corporation
Department 6R1LG
180 Kost Road
Mechanicsburg
PA 17055

Fold and tape


Please Do Not Staple

Fold and tape


Fold and tape


Please Do Not Staple

Fold and tape









SY33-2018-07

