

HEWLETT-PACKARD


OWNER'S MANUAL

7942

*and*

7946

*DISC/TAPE DRIVES*





# Owner's Manual

## 7942 and 7946 Disc/Tape Drives

Manual part no. 07942-90901

Printed: February 1985  
Printed in U.S.A.

07942-90901  
E0285

### OPTIONS COVERED

In addition to the standard models, this manual covers the following options: 015 and 550.

### FOR U.S.A. ONLY

The Federal Communications Commission (in 47 CFR 15.805) has specified that the following notice be brought to the attention of the users of this product.

#### FEDERAL COMMUNICATIONS COMMISSION RADIO FREQUENCY INTERFERENCE STATEMENT

Warning: This equipment generates and uses radio frequency energy and if not installed and used properly, that is, in strict accordance with the manufacturer's instructions, may cause interference to radio and television reception. It has been type tested and found to comply with the limits for a Class B computing device in accordance with the specifications in Subpart J of Part 15 of FCC Rules, which are designed to provide reasonable protection against such interference in a residential installation. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures: reorient the receiving antenna; relocate the computer with respect to the receiver; move the computer away from the receiver; plug the computer into a different branch circuit. If necessary, the user should consult the dealer or authorized field service representative for additional suggestions. The user may find the following booklet prepared by the Federal Communications Commission helpful: "How to Identify and Resolve Radio-TV Interference Problems." This booklet is available from the U.S. Government Printing Office, Washington, DC 20402. Stock No. 004-000-0035-4.

## Printing History

New editions incorporate all update material since the previous edition. Updating Supplements, which are issued between editions, contain additional and revised information to be incorporated into the manual by the user. The date on the title page changes only when a new edition is published.

First Edition ..... February 1985

### Notice

The information contained in this document is subject to change without notice.

**HEWLETT-PACKARD MAKES NO WARRANTY OF ANY KIND WITH REGARD TO THIS MATERIAL, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE.** Hewlett-Packard shall not be liable for errors contained herein or for incidental or consequential damages in connection with the furnishing, performance or use of this material.

This document contains proprietary information which is protected by copyright. All rights are reserved. No part of this document may be photocopied or reproduced without the prior written consent of Hewlett-Packard Company.

# Table of Contents

## Chapter 1: General Description

Introduction .....	1
Accessories .....	2
Options .....	2
Supporting Documentation .....	2
Characteristics .....	2

## Chapter 2: Installation

Introduction .....	5
Unpacking Your Drive .....	5
Equipment Supplied .....	6
Power Requirements .....	7
Configuring Power .....	7
Setting the VOLTAGE SELECTOR Switch .....	7
Checking the FUSE Value .....	7
Installing the Power Cord .....	8
Interfacing the Drive to Your System .....	8
Connecting the HP-IB Cable .....	10
Setting the HP-IB Device Address .....	11
Cabling Check .....	12
Warranty Label .....	12

## Chapter 3: Operation

Introduction .....	13
Warnings and Precautions .....	13
Environmental Limits .....	15
Connectors, Switches, and Indicators .....	15
Disc/Tape Drive .....	15
LINE~ Switch .....	15
~AC LINE Connector .....	15
FUSE .....	16
VOLTAGE SELECTOR Switch .....	16
SELF TEST Switch .....	16
Self Test Display .....	16
DISPLAY RESULTS Switch .....	18
HP-IB Connector .....	19
ADDRESS Switch .....	19
Disc Drive .....	19
FAULT/ON LINE Indicator .....	19
Tape Drive .....	20
TO TAPE Pushbutton .....	20
FROM TAPE Pushbutton .....	20
UNLOAD Pushbutton .....	21
Eject Pushbutton .....	21
BUSY Indicator .....	21
PROTECT Indicator .....	21



## Table of Contents (continued)

FAULT Indicator .....	21
Tape Cartridge Slot .....	22
Line Voltage Application .....	22
Tape Cartridge .....	22
Tape Cartridge Loading .....	24
Tape Cartridge Unloading .....	26
Disc-to-Tape Back-Up .....	27
Tape-to-Disc Restore .....	28
Line Voltage Removal .....	28
<b>Chapter 4: Maintenance and Service</b>	
Serial Number .....	29
Shipping .....	29
Disc Drive Maintenance .....	29
Tape Drive Maintenance .....	29
Cleaning Supplies .....	30
Wiping Materials .....	31
Cleaning the Tape Head and Capstan .....	31
Cleaning the Case .....	32
Warranty .....	33
Appendix A: Installation on RTE-A Systems .....	A-1
Appendix B: Installation on HP 9000 Systems .....	B-1

## Illustrations

Figure 1. Controls and Connectors .....	4
Figure 2. Packaging Details .....	6
Figure 3. Power Cord Sets .....	9
Figure 4. HP-IB Cable .....	10
Figure 5. ADDRESS Switch .....	12
Figure 6. Rear Panel Self-Test Display .....	17
Figure 7. Front Panel Self-Test Display .....	20
Figure 8. Tape Cartridge .....	23
Figure 9. Tape Cartridge Loading .....	25
Figure 10. Tape Head and Capstan Cleaning .....	32

## Tables

Table 1. Disc/Tape Drive Characteristics .....	3
--	---

# Chapter 1

## General Description

### Introduction

The HP 7942 and HP 7946 Disc/Tape Drives are medium performance, random access, data storage devices designed for use with small and medium sized computer systems. The HP 7942 consists of a 24-megabyte disc drive and a tape drive combined in a single desktop cabinet to form an integrated disc/tape drive. The HP 7946 consists of a 55-megabyte disc drive and a tape drive combined in a similar manner. In this manual, unless otherwise specified, “drive” refers to both the HP 7942 and HP 7946.

The 24- and 55-megabyte disc drives employ two and four nonremovable 130-millimetre (5.12-inch) discs, respectively, for storage media. Each disc surface employs one movable head to service its data tracks. The bottom surface of the lowest disc in the stack contains continuous pre-recorded servo data which is used to ensure the precise positioning of the read/write heads.

Head positioning is performed by a rotary actuator and closed-loop servo positioning system. Mechanical and contamination protection for the discs, heads, and the rotary actuator is provided by a sealed head-disc module. The head-disc module includes a self-contained air filtration system which supplies clean air and temperature equalization throughout the module.

The tape drive is a data storage device utilizing a removable 1/4-inch tape cartridge. Two tape lengths are available: 150 feet (16.7 megabyte) and 600 feet (67 megabyte). The tape drive acts as a back-up device for the disc drive. The data transfer rate for back-up is approximately two megabytes per minute. The actual data transfer rate is host dependent. Included in the tape drive is a read-after-write capability for data verification, as well as data recovery and automatic sparing. The tape drive is compatible with existing 1/4-inch tape drives contained in other HP disc/tape drives.

The drive also includes a Hewlett-Packard Interface Bus (HP-IB)\* controller and a power supply.

The drive contains internal self-test diagnostics and a fault-finding system which exercise key functions of the drive. Self test is performed automatically at power on and can also be initiated by the host or by a switch on the rear panel of the drive. Go/no-go test results are indicated by green and red indicators on the front panel. If a failure occurs, information on the cause of the failure can be determined by viewing a 2-digit hexadecimal display on the rear panel.

The drive is packaged in a stand-alone desktop cabinet. Accessories available include a desk-height stand-alone cabinet designed to hold the drive and other desktop stack modules. A kit for rack mounting the unit in a standard EIA equipment rack is also available.

\* HP-IB: Not just IEEE-488, but the hardware, documentation and support that delivers the shortest path to a computation system.

This manual provides all of the information needed to install and operate the drive. Details of the control functions provided by the computer are described in the installation documentation provided with the computer.

## Accessories

- HP 92211A Cabinet. A desk-height stand-alone cabinet for the drive and other desktop stackable peripherals and systems.
- HP 19501A Rack Mounting Kit. Allows the drive to be mounted in a stand-alone, 19-inch EIA equipment rack.
- HP 88140SC Tape Cartridge, 150-foot (16.7-megabyte), formatted and certified. Box of 5.
- HP 88140LC Tape Cartridge, 600-foot (67-megabyte), formatted and certified. Box of 5.
- HP 92193H Magnetic Head Cleaning Kit. The kit contains two 2-oz bottles of tape head cleaner, 50 lint-free wipes, 10 foam swabs, and one easy-pour dispensing cap.
- 9300-0757 Foam Swabs. 50 per package.
- HP 92193X Tape Head Cleaner. Six 4-oz bottles.

## Options

- Option 015. For non-U.S. shipments. Voltage Selector switch set for 230 Vac operation.
- Option 550. Deletion of the HP 10833A HP-IB Interface Cable Assembly.

## Supporting Documentation

The following documentation may be ordered from a Hewlett-Packard Sales and Support Office:

- *HP 7942 and HP 7946 Disc/Tape Drives Service Manual*, part no. 07942-90903.
- *CS/80 Instruction Set Programming Manual*, part no. 5955-3442.
- *CS/80 External Exerciser Manual*, part no. 5955-3462.

## Characteristics

Characteristics of the drive, including physical dimensions and power requirements, are listed in Table 1, Disc/Tape Drive Characteristics. Detailed specifications for the drive, including environmental requirements, are listed in the *Site Environmental Requirements for Disc/Tape Drives Manual*, part no. 5955-3456. This publication is supplied with the drive.



Table 1. Disc/Tape Drive Characteristics

## Safety

Meets all applicable safety standards of IEC 380 and IEC 435.

UL recognized to UL 114 and UL 478.

CSA certified to CSA C22.2 No. 154.

## Power Requirements

Specified source (selected by rear panel VOLTAGE SELECTOR switch)

Voltage (true RMS): 115V range; 100V, 115V, 120V, single phase  
(inclusive tolerance range is 90V to 132V).

230V range; 220V, 240V, single phase  
(inclusive tolerance range is 180V to 264V)

Frequency: 47.5 to 66 Hz

Typical current: 115V range; 1.50 A (true rms at 115V, 60 Hz)  
230V range; 0.80 A (true rms at 230V, 50 Hz)

Typical power: 115V range; 173 V-A at 115V, 60 Hz  
230V range; 184 V-A at 230V, 50 Hz

## Size/Weight

Height: 208 mm (8.2 in.)

Width: 325 mm (12.8 in.)

Depth: 285 mm (11.2 in.)

Net weight: 15.8 kg (34.8 lb)

Shipping weight: 19.6 kg (43.3 lb)






Figure 1. Controls and Connectors

# Chapter 2

## Installation

**NOTICE: BEFORE CONNECTING POWER, READ THESE INSTRUCTIONS CAREFULLY.**

### Introduction

This chapter provides instructions on how to place your drive in operation. These instructions include unpacking instructions, a check of equipment supplied, and how to connect the drive to a line voltage source and the Hewlett-Packard Interface Bus (HP-IB).

---

#### Note

Refer to Figure 1, Controls and Connectors, for the locations of the controls and connectors identified by numbers (for example: LINE ~ switch **1**), in the text.

---

### Unpacking Your Disc Drive

---

#### CAUTION

THE DRIVE IS DELICATE AND SHOULD BE HANDLED WITH CARE. ALSO, THE DRIVE IS HEAVIER (15.8 KILOGRAMS/34.8 POUNDS) THAN ITS SIZE WOULD INDICATE.

---

The drive is shipped in a reusable shipping container. (See Figure 2, Packaging Details.) When the shipment arrives, ensure that the container has been received as specified by the carrier's bill of lading. Inspect the shipping container immediately upon receipt for evidence of mishandling during transit. If the container is damaged or water stained, request that the carrier's agent be present when the container is unpacked.

Remove the drive from the shipping container and inspect the drive for any mechanical damage that may have occurred during shipment. If any damage is observed, you should immediately notify your dealer or Hewlett-Packard Sales and Support Office and file a claim with any carriers involved. A list of Hewlett-Packard Sales and Support Offices is provided at the back of this manual.

---

#### Note

An envelope containing the drive warranty label is attached to the outside of the shipping container. It is important that this label be removed from the envelope and placed on the rear panel of the drive. Refer to the Warranty Label paragraph at the end of this chapter for instructions.

---




Figure 2. Packaging Details

## Equipment Supplied

Check to ensure that all of the standard equipment supplied with the drive has been received. This equipment is listed below.

- Power Cable (part number depends on location).
- *Site Environmental Requirements for Disc/Tape Drives Manual*, part no. 5955-3456.
- *7942 and 7946 Disc/Tape Drive Owner's Manual*, part no. 07942-90901.
- HP 10833A HP-IB Interface Cable Assembly, part no. 8120-3445.
- Tape Cartridge, 67-megabyte, formatted and certified. Quantity: 1.
- Fuse, 5-ampere, 250-volt, nontime delay, part no. 2110-0010. Quantity: 2.
- Head Cleaner, part no. 8500-3440. 1-oz bottle.
- Foam Swabs. Package of 10.
- Warranty Label Envelope.

If any items are missing, contact your dealer or Hewlett-Packard Sales and Support Office.

## Power Requirements

Refer to Table 1, Disc/Tape Drive Characteristics.

## Configuring Power

The following instructions should be followed to ensure that your drive is properly adjusted to operate on the line voltage available in your area.

### Setting the VOLTAGE SELECTOR Switch

---

#### CAUTION

MAKE SURE THAT THE POWER CORD IS DISCONNECTED FROM THE DRIVE ~ AC LINE CONNECTOR **2** BEFORE CHANGING THE VOLTAGE SELECTOR SWITCH **4** SETTING. FAILURE TO DISCONNECT THE POWER CORD COULD RESULT IN DAMAGE TO THE DRIVE.

---

Your drive should already be adjusted to operate on the line voltage available in your area. Check that the VOLTAGE SELECTOR switch **4** is set to this voltage level (115V or 230V). To change the switch setting, disconnect the power cord from the ~ AC LINE connector **2**. Then, place the tip of a small flat-blade screwdriver in the slot on the switch and slide the switch sideways to the proper setting.

### Checking the FUSE Value

---

#### WARNING

MAKE SURE THAT THE POWER CORD IS DISCONNECTED FROM THE DRIVE BEFORE INSTALLING OR REPLACING THE FUSE **3**. FAILURE TO DISCONNECT THE POWER CORD COULD RESULT IN ELECTRICAL SHOCK OR DAMAGE TO THE DRIVE.

---

---

#### WARNING

FOR CONTINUED PROTECTION AGAINST FIRE HAZARD, REPLACE ONLY WITH THE SAME TYPE AND RATING OF FUSE AS SPECIFIED.

---



The value of the FUSE **3** is the same for both settings of the VOLTAGE SELECTOR switch **4**. The correct rating for the fuse is 5-ampere, 250-volt, nontime delay. The HP part number for the fuse is 2110-0010.

To check the value of the FUSE **3**, first ensure that the power cord is disconnected from the ~ AC LINE connector **2**. Then, using a small flat-blade screwdriver, turn the fuseholder cap counterclockwise until the cap releases. Remove the fuse from the cap and check that the fuse is of the correct value. Replace the fuse in the cap — either end of the fuse can be installed in the cap. Next, install the fuse and fuseholder cap in the fuseholder by pressing the cap inward and then turning it clockwise until it locks in place.

## Installing the Power Cord

---

### CAUTION

- USE UL/CSA APPROVED POWER CORD, SVT TYPE, RATED FOR SUITABLE VOLTAGE AND CURRENT. (SEE FIGURE 3, POWER CORD SETS.)
  - CHECK THE INPUT AC VOLTAGE, THE VALUE OF THE FUSE **3**, AND THE SETTING OF THE VOLTAGE SELECTOR SWITCH **4** BEFORE PROCEEDING WITH THE POWER CORD INSTALLATION. THE DRIVE IS SUPPLIED WITH AN APPROPRIATE POWER CORD. THE VARIOUS POWER CORDS AVAILABLE ARE SHOWN IN FIGURE 3, POWER CORD SETS.
  - DO NOT ATTEMPT TO OPERATE THE DRIVE CONFIGURED FOR 115 VAC ON 230 VAC, OR VICE VERSA. DAMAGE TO THE DRIVE MAY RESULT.
- 

- a. Set the LINE ~ switch **1** to the 0 (out) position.
- b. Plug the female end of the power cord into the ~ AC LINE connector **2** at the rear of the drive.

## Interfacing the Drive to Your System

The drive is connected to the system host via an HP-IB cable attached to the HP-IB connector **8** on the rear panel of the drive. It is also necessary to set the ADDRESS switch **9** to the HP-IB device address selected for the drive. Details of these two operations are provided in the following paragraphs.


**OPTION 903 120V STANDARD**

MALE NEMA (MOLDED)

BROWN OR BLACK (L)  
GREEN/YELLOW (E)  
LIGHT BLUE OR WHITE (N)



FEMALE CEE




(L) BROWN OR BLACK  
(E) GREEN/YELLOW  
(N) LIGHT BLUE OR WHITE

(8120-1378 [GRAY, 2.3m])


**OPTION 905 240V**

MALE CEE

BROWN OR BLACK (L)  
GREEN/YELLOW (E)  
LIGHT BLUE OR WHITE (N)



FEMALE CEE




(L) BROWN OR BLACK  
(E) GREEN/YELLOW  
(N) LIGHT BLUE OR WHITE

8120-1860 (1.5m)  
8120-1575 (0.7m)


**OPTION 906 240V**

MALE SEV

BLUE (N)  
GREEN/YELLOW (E)  
BROWN (L)



FEMALE CEE




(L) BROWN  
(E) GREEN/YELLOW  
(N) LIGHT BLUE

8120-2104 (2.0m)


**OPTION 902 240V**

MALE SCHUKO

LIGHT BLUE (N)  
GREEN/YELLOW (E)  
BROWN (L)



FEMALE CEE



(L) BROWN  
(E) GREEN/YELLOW  
(N) BLUE


NOTE: THE LIGHT BLUE (N) AND BROWN (L) WIRES TO THE MALE SCHUKO CONNECTOR MAY BE CONNECTED OPPOSITE TO THAT SHOWN.

8120-1689 (2.0m)


**OPTION 901 240V**

MALE ASC-112

LIGHT BLUE OR BLACK (N)  
GREEN/YELLOW (E)  
LIGHT BROWN OR RED (L)



FEMALE CEE




(L) LIGHT BROWN OR RED  
(E) GREEN/YELLOW  
(N) LIGHT BLUE OR BLACK

8120-1369 (2.0m)


**OPTION 900 240V**

MALE BS 1363

LIGHT BLUE (N)  
GREEN/YELLOW (E)  
LIGHT BROWN (L)



FEMALE CEE




(L) LIGHT BROWN  
(E) GREEN/YELLOW  
(N) LIGHT BLUE


8120-1351 (2.3m)

**OPTION 912 220V MALE DANISH 90 DEG MDPP**

GREEN/YELLOW (N)  
BLUE (E)  
BROWN (L)



FEMALE CEE



(L) BROWN  
(E) GREEN/YELLOW  
(N) BLUE

8120-2956 (2.0m)

E EARTH OR SAFETY GROUND  
N NEUTRAL OR IDENTIFIED CONDUCTOR  
L LINE OR ACTIVE CONDUCTOR

Figure 3. Power Cord Sets

---

### Note

The drive must be connected to the system host by a shielded HP 10833 Series HP-IB Cable Assembly, or its equivalent.

---

## Connecting the HP-IB Cable

---

### CAUTION

ENSURE THAT THE LINE~ SWITCHES ON ALL UNITS OF YOUR SYSTEM ARE SET TO THE 0 (OUT) POSITION BEFORE CONNECTING (OR DISCONNECTING) HP-IB CABLES.

---



Figure 4. HP-IB Cable

A 1-metre (3.3-foot) HP-IB cable assembly is supplied with the drive. (See Figure 4, HP-IB Cable.) Before using this cable to connect the drive to the system host, ensure that the proposed cabling conforms to the following HP-IB cabling standards:

- Cabling is limited to 1 metre per HP-IB load. Typically, the central processing unit (CPU) is seven equivalent loads and the drive is one equivalent load. Refer to the host configuration guide for specific information regarding the CPU equivalent load.
- The CPU adheres to an HP standard which allows 7 metres of HP-IB cable between the CPU and the nearest device connected to it, and 1 metre of cable connected between each additional device.



- The maximum is eight devices (excluding the CPU) per HP-IB channel or a maximum of 15 metres or 15 equivalent loads.
  - The maximum number of devices which can be connected to a single HP-IB channel is host dependent. This information is provided in the appropriate host configuration guide.
  - There are no restrictions on how the devices can be connected together on the HP-IB channel. However, do not connect more than three cable connectors to the HP-IB connector on a device. Additional cable connectors could result in enough force being exerted on the HP-IB connector to damage it.
- a. Set the LINE~ switch **1** to the 0 (out) position.
  - b. Connect one end of the HP-IB cable to the HP-IB connector **8** on the rear panel of the drive. Tighten the two securing screws on the connector.
  - c. Connect the other end of the HP-IB cable to the HP-IB data bus on the CPU.

## Setting the HP-IB Device Address

Each device in a Hewlett-Packard Interface Bus (HP-IB) system requires a unique device address. A small 4-segment ADDRESS switch **9** on the rear panel of the drive is provided for this purpose. The switch can be set to any one of eight addresses, ranging from decimal 0 through 7.

---

### CAUTION

ENSURE THAT THE DRIVE LINE~ SWITCH **1** IS SET TO THE 0 (OUT) POSITION BEFORE CHANGING THE ADDRESS SWITCH **9** SETTINGS. FAILURE TO OBSERVE THIS PRECAUTION MAY RESULT IN LOSS OF DATA OR NO SYSTEM RESPONSE.

---

- a. Set the LINE~ switch **1** to the 0 (out) position.
- b. Set the ADDRESS switch **9** on the rear panel to the desired HP-IB device address using the coding scheme marked on the panel. Disregard any markings on the switch itself. Use the tip of a ballpoint pen or similar object to operate the switches. Figure 5, ADDRESS Switch, shows the ADDRESS switch **9** settings for HP-IB addresses 0 through 7.

---

### Note

During normal operation of the drive, the selected HP-IB address is shown on the rear panel Self Test display **6**.

---






Figure 5. ADDRESS Switch

## Cabling Check

After the drive has been connected to the operating system, visually inspect the installation. Ensure that all cabling is correctly connected and the desired HP-IB channel address has been selected. Before applying line voltage to the drive, read the description of the drive operating controls and line voltage connection instructions contained in the OPERATION chapter of this manual.

## Warranty Label

Remove the warranty label from the sealed envelope on the side of the shipping container. (See Figure 2, Packaging Details.) Remove the paper backing from the label. Attach the label to the left-hand side of the rear panel in the space marked "Place warranty label here."

# Chapter 3

## Operation

### Introduction

This chapter contains operating instructions for the drive. Included are operating precautions, a description of the operating controls, self-test information, and line voltage application and removal procedures.

### Warnings and Precautions

---

#### WARNING

**OBSERVE ALL WARNINGS AND CAUTIONS IN THIS MANUAL AND AFFIXED TO THE EQUIPMENT.**

---

#### CAUTION

- DO NOT TURN THE LINE ~ SWITCH **I** ON OR OFF WHEN YOUR SYSTEM IS TRANSFERRING DATA ON THE HEWLETT-PACKARD INTERFACE BUS (HP-IB).
- DO NOT CYCLE THE LINE ~ SWITCH **I** ON AND OFF UNNECESSARILY.
- DO NOT CONNECT OR DISCONNECT THE HP-IB CABLE(S) FROM THE DRIVE WHEN YOUR SYSTEM IS TRANSFERRING DATA ON THE HP-IB.
- DO NOT TOUCH THE TAPE OR ATTEMPT TO CLEAN THE TAPE OR TAPE GUIDES WITHIN THE TAPE CARTRIDGE.
- DO NOT ATTEMPT TO REMOVE THE TAPE CARTRIDGE FROM THE DRIVE BEFORE THE UNLOADING SEQUENCE HAS BEEN COMPLETED. IF YOU LOSE POWER WITH THE TAPE CARTRIDGE INSERTED IN THE DRIVE (BETWEEN OPERATIONS),

THE CARTRIDGE IS LOCKED IN THE DRIVE UNTIL POWER IS RESTORED AND THE UNLOAD SEQUENCE IS COMPLETED.

- DO NOT USE EXCESSIVE FORCE ON THE TAPE CARTRIDGE EJECT PUSHBUTTON **14**. THE PUSHBUTTON WILL NOT OPERATE WHEN THE BUSY INDICATOR **15** IS ILLUMINATED, THE UNLOAD OPERATION IS IN PROGRESS, OR THE POWER IS OFF.
- DO NOT CLEAN THE TAPE DRIVE CAPSTAN OR HEAD WITH ANY TYPE OF CLEANING MATERIALS OR TOOLS OTHER THAN THOSE SPECIFIED IN THE MAINTENANCE AND SERVICE CHAPTER OF THIS MANUAL.
- DO NOT LEAVE TAPE CARTRIDGES IN EXCESSIVELY WARM, DRY, OR HUMID LOCATIONS; IN DIRECT SUNLIGHT; OR IN AREAS WHERE MAGNETIC FIELDS ARE PRESENT (FOR EXAMPLE, ADJACENT TO TRANSFORMERS AND MOTORS).
- DO NOT USE TAPE CARTRIDGES AT TEMPERATURES BELOW 10°C (50°F) OR ABOVE 40°C (104°F).
- DO NOT STORE THE TAPE CARTRIDGES AT TEMPERATURES BELOW -40°C (-40°F) OR ABOVE 60°C (140°F).
- DO NOT DROP THE TAPE CARTRIDGES OR SUBJECT THEM TO ROUGH HANDLING.
- TO PREVENT OVERWRITING DATA STORED ON A TAPE, SET THE WRITE PROTECT SWITCH ON THE TAPE CARTRIDGE TO THE SAFE MARKING BEFORE INSTALLING THE CARTRIDGE IN THE DRIVE. THIS PROTECTS THE CARTRIDGE FROM ALL WRITE OPERATIONS. YOU CAN ONLY READ FROM THE CARTRIDGE. INSTRUCTIONS ON HOW TO SET THE WRITE PROTECT SWITCH ARE PROVIDED IN THE TAPE CARTRIDGE PARAGRAPH IN THIS CHAPTER.

- REMOVE THE TAPE CARTRIDGE FROM THE DRIVE WHEN THE CARTRIDGE IS NOT IN USE AND STORE IT IN ITS PROTECTIVE PLASTIC CASE. IF THE TAPE CARTRIDGE IS LEFT UNUSED IN THE DRIVE, IT MAY DEFORM THE CAPSTAN AND COLLECT EXCESSIVE AMOUNTS OF DUST AND DIRT.
  - STORE TAPE CARTRIDGES IN A CLEAN ENVIRONMENT AT ALL TIMES. EXPOSURE TO SMOKE, DUST, AND OTHER CONTAMINANTS DEGRADES TAPE RELIABILITY.
- 

## Environmental Limits

To ensure proper operation, the drive must be operated within the environmental limits specified in the *Site Environmental Requirements for Disc/Tape Drives Manual*, part no. 5955-3456. This publication is supplied with the drive.

## Connectors, Switches, and Indicators

Figure 1, Controls and Connectors, shows the location of the connectors, switches, and indicators on the front and rear panels of the drive. The functions of these components are described in the following paragraphs.

---

### Note

The controls and connectors listed under the heading Disc/Tape Drive are common to both the disc drive and the tape drive. The remaining controls and connectors, listed under the headings Disc Drive and Tape Drive, are applicable to the disc drive and the tape drive, respectively.

---

## Disc/Tape Drive

### Line ~ Switch

The LINE ~ switch **1** controls the application of line voltage to the drive.

### ~ AC LINE Connector

The ~ AC LINE connector **2** allows the drive to be connected to a line voltage source.



## FUSE

The FUSE **3** protects the drive from a line voltage overload. The fuse is the same value (5A, 250-volt, nontime delay) for both 115 and 230 Vac operation.

## VOLTAGE SELECTOR Switch

The VOLTAGE SELECTOR switch **4** is a 2-position slide switch which selects a line voltage of 115 or 230 Vac for the drive.

## SELF TEST Switch

The SELF TEST switch **5** is a momentary contact pushbutton switch which initiates the drive internal self-test diagnostic routines. The switch is recessed behind the rear panel and can be activated by the tip of a ballpoint pen or similar object. The self-test routines initiated by the switch are the same as those initiated by a host-issued diagnostic command. Both of these routines are similar to the power on self-test routines.


## Self Test Display

The Self Test display **6** consists of a 2-digit 7-segment hexadecimal display which reports the results of the internal self-test and diagnostic routines. The Self Test display **6** also shows the HP-IB address selected by the ADDRESS switch **9**.

Whenever self test is initiated, either by operation of the SELF TEST switch **5** or when line voltage is applied to the drive, the display will first show an **8.8.** readout to test that all segments of the display are functioning. The display will then go blank until self test is completed. (See Figure 6, Rear Panel Self Test Display.)

When the SELF TEST switch **5** is pressed, release from the host is requested. If release is granted, the Self Test display **6** is blanked to indicate that the self test is ready to start. When the switch is released, self-test commands are issued to the drive. One of the first tests is one that causes the **8.8.** display to appear. The display is then blanked until self test is completed. If release is not granted, an **r.d.** (release denied) display will appear. This message will continue to be displayed until the SELF TEST switch **5** is released, at which time the display will show the previous pass/fail result.

When self test has been completed on the units of the drive (controller, disc drive, tape drive, and power supply), the display will show a **P.x.** (pass) or an **F.x.** (fail) result. The numeral **x.** is the HP-IB address set by the ADDRESS switch **9**. If the self-test command is sent to a single unit (disc drive or tape drive), the pass result will only be displayed if the unit passes self test and the controller and the other unit have passed their most recent self tests.



DISPLAY	MESSAGE	
8.8.	DISPLAY TEST	] <b>GO/NO-GO TEST RESULT.</b> * = HP-IB ADDRESS
P.*	SELF TEST PASS	
F.*	SELF TEST FAIL	
r.d.	RELEASE DENIED	] <b>UNIT FAILED</b>
U.2.	HOST DEPENDENT CONTROLLER	
U.0.	DISC DRIVE	
U.1.	TAPE DRIVE	

- A.1. DISC DRIVE ASSY
  - A.2. DEVICE DEPENDENT CONTROLLER
  - A.4. POWER SUPPLY
  - A.5. HOST DEPENDENT CONTROLLER
  - A.6. CONNECTORS
- DISC DRIVE FRA FAILED.**
- 0.0. ] **DISC DRIVE SELF-TEST SUBTEST FAILED.**
  - ...
  - 6.8. Refer to DISC/TAPE DRIVE SERVICE MANUAL, part no. 07942-90903, for details.
  - 8.8. ]

- A.0. Not discernible. An assembly failed and it tested as good.
  - A.1. DRIVE MECHANISM (includes CAPSTAN MOTOR and HEAD STEPPER MOTOR)
  - A.2. DEVICE DEPENDENT CONTROLLER
  - A.3. READ/WRITE ASSY
  - A.4. DIRTY HEAD
  - A.5. CONTROLLER
  - A.7. SERVO ASSY
  - A.8. HEAD STEPPER MOTOR
  - A.9. CAPSTAN MOTOR (includes TACHOMETER)
- TAPE DRIVE FRA FAILED.**
- 0.0. ] **TAPE DRIVE SELF-TEST SUBTEST FAILED.**
  - ...
  - 8.8. ] Refer to DISC/TAPE DRIVE SERVICE MANUAL, part no. 07942-90903, for details.

Figure 6. Rear Panel Self-Test Display

---

### Note

The decimal points in the display are energized by dc voltage supplied to the controller and act as indicators for this voltage. The decimal points should remain illuminated at all times during self test and normal operation of the drive.

---

## DISPLAY RESULTS Switch

The DISPLAY RESULTS switch **7** is a momentary contact pushbutton switch which causes self-test results to be displayed on the Self Test display **6**. When the switch is pressed, a request for release is generated. The switch must be pressed and held down until release is granted or denied. If release is granted the display will become blank until the switch is released. If release is denied, an **r.d.** (release denied) message will be displayed. When the switch is released, the previous pass/fail result is restored to the display.

---

### Note

In the event of a self-test failure, the failed unit will have requested release to update the error logs. If the unit is not operating correctly, this may take some time to complete. During this period, the DISPLAY RESULTS switch **7** will be inactive. This means that the DISPLAY RESULTS switch **7** may have to be pressed for a longer than normal period of time or pressed after the update operation has been completed.

---

Following release, pressing the switch a number of times will display a sequence of test failure information. The information displayed for a failure will be, in order, unit failed, field replaceable assembly (FRA) failed, and subtest failed. The failing unit is indicated by the display **U.x.** where numeral **x.** identifies the unit. The failing FRA is indicated by **A.x.** where numeral **x.** identifies the FRA. A subtest failed is indicated by a 2-digit hexadecimal number. It is possible for a failing unit to have multiple failing FRA's. These will be listed in descending order of most probable failure. If a unit has no failures to report, it will display only the unit number. Refer to Figure 6, Rear Panel Self-Test Display, for a listing of unit, FRA, and subtest failure numbers.

---

### Note

When sequencing test results *all* of the results must be displayed before the drive will go back on line (return from release). After the last result has been displayed, the display will return to the **P.x.** (pass) or **F.x.** (fail) readout.

---



---

### Note

A controller self-test failure is a special type of failure. When the controller fails self test, the drive will enter into an infinite loop, monitoring the DISPLAY RESULTS switch 7. The only function the drive can perform under this condition is to present the controller self-test results. The drive will not respond to any commands from the host computer. Exit from the loop can only be achieved by powering down the drive.

---

## HP-IB Connector

The HP-IB connector 8 allows the drive to be connected to the host computer via an HP-IB cable assembly. Connection instructions are given in the INSTALLATION chapter.

## ADDRESS Switch

The ADDRESS switch 9 is a 4-segment switch which programs the drive HP-IB device address. One segment of the switch is not used. Operating instructions are given in the INSTALLATION chapter.

## Disc Drive

### FAULT/ON LINE Indicator

The FAULT/ON LINE indicator 10 is a red/green display which signals the operating status of the disc drive. (See Figure 7, Front Panel Self-Test Display.) When line voltage is applied to the disc drive, the FAULT (red) and ON LINE (green) portions of the display will illuminate for one second to test that the display is functioning. Next, the green portion will flash during the time that the disc drive is executing its internal self-test routines. Self test takes between six and 12 seconds to complete. If the disc drive passes self test, the display will change to a solid green. If the disc drive fails self test, the display will change to a solid red with a flashing green indicating that the self-test routines are still accomplishing some “housekeeping” tasks. When these tasks are complete, the green indicator will extinguish, indicating that the disc drive is ready to accept host commands such as diagnostics. The green indicator will flash again when the disc drive attempts to respond to these commands. A solid red and green display indicates that the host dependent controller (unit 2) has failed self test.

After a successful self test, a solid green display indicates that the disc drive is idle and a flashing green indicates that the disc drive is active.






Figure 7. Front Panel Self-Test Display

## Tape Drive

### TO TAPE Pushbutton

The TO TAPE pushbutton **11** is a momentary contact switch which initiates a disc-to-tape back-up operation. Pressing the pushbutton once causes the BUSY indicator **15** to flash for 2.5 seconds. During this period, pressing the TO TAPE pushbutton **11** once more will initiate the back-up. Details of the back-up operation are provided in the Disc-To-Tape Back-Up paragraph in this chapter.

### FROM TAPE Pushbutton

The FROM TAPE pushbutton **12** is a momentary contact switch which initiates a tape-to-disc restore operation. Pressing the pushbutton once will cause the BUSY indicator **15** to flash for 2.5 seconds. During this period, pressing the FROM TAPE pushbutton **12** once more will initiate the restore. Details of the restore operation are provided in the Tape-To-Disc Restore paragraph in this chapter.

## UNLOAD Pushbutton

The UNLOAD pushbutton **13** is a momentary contact switch which initiates a tape cartridge unload operation. If the tape drive is active, the operation in progress (seek, read, write) is completed before the unload request is sent to the host computer. In conjunction with local operation, the host computer must also allow the unload request. The computer may deny the unload request, depending on the current operation in progress. A description of the unload operation is provided in the Tape Cartridge Unloading paragraph.

## Eject Pushbutton

The Eject pushbutton **14** unloads the tape cartridge from the tape drive. The pushbutton remains locked until the completion of the unload operation. If there is a power failure or the drive is powered down, the tape cartridge will remain locked in the tape drive. To get the tape cartridge out, apply power, wait for the BUSY indicator **15** to extinguish, and then press the UNLOAD pushbutton **13**. After a delay of approximately 1½ minutes, press the Eject pushbutton **14**.

## BUSY Indicator

The BUSY indicator **15** is illuminated when the tape drive is performing certain functions. These functions are: self test, tape cartridge loading, tape cartridge unloading, seek, read, and write. The Eject pushbutton is locked when the BUSY indicator **15** is illuminated. (The Eject pushbutton is not necessarily unlocked when the BUSY indicator **15** is extinguished.)

## PROTECT Indicator

The PROTECT indicator **16** is illuminated when a write-protected tape cartridge is inserted into the tape drive or is residing in the tape drive. When the indicator is illuminated, you can only read data from the cartridge; you cannot write data to the cartridge. How to make a cartridge “write protected” is described in the Tape Cartridge paragraph. The PROTECT indicator **16** is extinguished when the tape cartridge is unloaded.

The PROTECT indicator **16** also acts as a recording medium indicator. If the PROTECT indicator **16** starts to flash after the BUSY indicator **15** is extinguished at the end of the unload operation, this is a warning that *the tape is approaching the end of its useful life*. The data on the tape cartridge needs to be copied and the cartridge discarded. In this instance, the PROTECT indicator **16** will flash until the tape cartridge is removed from the disc/tape drive. Refer to the Tape Cartridge Unloading paragraph for additional information.

## FAULT Indicator

The FAULT indicator **17** is illuminated when a tape drive or tape cartridge self-test failure occurs.

## Tape Cartridge Slot

The tape cartridge slot **18** allows a tape cartridge to be loaded into the tape drive transport mechanism.

## Line Voltage Application

- a. Set the LINE~ switch **1** to the 1 (in) position and observe the action of the FAULT/ON LINE indicator **10**. A normal sequence of events on the indicator will be a momentary red and green display (display test), followed by a flashing green (self test in progress), and finally a solid green (self test passed). If the sequence ends with a solid red and green display (controller failed self test) or a solid red display (self test failed), the malfunctioning circuitry may be identified as follows:
  - (1) Observe the Self Test display **6** on the rear panel of the drive.
  - (2) The display should show an **F.x.** (self test fail) message.
  - (3) Using the tip of a ballpoint pen or a similar object, press the DISPLAY RESULTS switch **7** a number of times, noting each message until the display returns to the **F.x.** message.
  - (4) Using the messages noted, consult Figure 6, Rear Panel Self-Test Display, to determine the failed unit, field replaceable assembly (FRA), and subtest. There may be multiple FRA failures.

## Tape Cartridge

### CAUTION

DO NOT DEGAUSS OR BULK ERASE THE TAPE CARTRIDGE. THIS WILL ERASE FORMATTING INFORMATION RECORDED ON THE TAPE AT THE FACTORY. ONCE THIS PRERECORDED FORMATTING INFORMATION IS ERASED, THE TAPE CARTRIDGE CANNOT BE USED IN THE DRIVE.

The removable recording medium used in the tape drive is a 1/4-inch tape cartridge. (See Figure 8, Tape Cartridge.) Two versions of the tape cartridge are available:

- HP 88140SC Tape Cartridge, 150-foot (16.7-megabyte), formatted and certified. Box of 5.
- HP 88140LC Tape Cartridge, 600-foot (67-megabyte), formatted and certified. Box of 5.

A single formatted and certified 600-foot (67-megabyte) tape cartridge is supplied with your drive.






Figure 8. Tape Cartridge

Each tape cartridge is packaged in a hard plastic case, sealed with a clear plastic wrapping. You must remove both the wrapping and the plastic case before the cartridge can be used. Between uses, store the cartridge in the plastic case.

Formatting (a factory process) divides the tape into block sections. Each block contains beginning and ending markings magnetically recorded on the tape. Certifying is a process which ensures that all of the sections of the tape that are to be used are good sections.

Tape cartridges must be initialized by your computer before they can be used for the first time. You *must* initialize each tape. This is done using a command from your computer. Initializing prepares the cartridge for use by setting up preliminary information (volume name and file directory) on the tape. Once initialized, and after data is stored on the cartridge, another initialization will erase all the stored data (but not the prerecorded formatting information). Do not re-initialize the tape unless you want to remove all stored data from the tape.



---

## CAUTION

WHEN CHANGING THE WRITE PROTECT SWITCH TO OR FROM THE SAFE MARKING, BE SURE TO TURN THE SWITCH UNTIL IT CATCHES (THE DETENT ENGAGES) WITH THE ARROW POINTING DIRECTLY TOWARD THE SAFE MARKING OR DIRECTLY AWAY FROM IT. IF THE SWITCH IS NOT PLACED IN THE DETENT POSITION, IT CAN LOCK AROUND THE RECEIVING PORTION INSIDE THE TAPE DRIVE AND JAM. IF THIS HAPPENS, THE TAPE CARTRIDGE CANNOT BE REMOVED WITHOUT DISASSEMBLING THE DRIVE.

---

The tape cartridge has a Write Protect switch. (See Figure 8, Tape Cartridge.) Use a small screwdriver or the edge of a coin to turn the switch. When the arrow on the switch is pointing toward the SAFE marking, the cartridge is write protected. This means that only read operations are allowed. You cannot accidentally write over existing data with the Write Protect switch in the SAFE position. With a write-protected cartridge in the drive, the WRITE PROTECT indicator **16** on the front panel will be illuminated. Typical reasons for using write protect include safeguarding important data and programs, and protecting your master back-up copy.

If you decide to perform write operations with a write-protected cartridge in the drive, press the UNLOAD pushbutton **13** to initiate the unload operation. You can now remove the cartridge, change the setting of the Write Protect switch, re-insert the cartridge, and initiate the load operation.

## Tape Cartridge Loading

- a. Remove the tape cartridge from its protective plastic case.
- b. Set the tape cartridge Write Protect switch to the desired position.
- c. Position the tape cartridge adjacent to the tape cartridge slot **18**. (See Figure 9, Tape Cartridge Loading.)
- d. Insert the tape cartridge into the slot and push the cartridge in until a click is heard. This indicates that the cartridge is properly installed.
- e. The tape drive will now begin a series of automatic routines which prepare the tape for operation. The BUSY indicator **15** is illuminated during this procedure.




Figure 9. Tape Cartridge Loading

---

### Note

If the FAULT indicator **17** is illuminated and the Eject push-button **14** unlocks, this indicates that the tape cartridge may be defective. If the tape cartridge is the most likely item that failed, the rear panel Self Test display **6** will show a **P.x.** (pass) result even though the FAULT indicator **17** is illuminated. Try another tape cartridge.

---

First, the read circuitry is tested. Next, the tape is wound to its end (End of Tape EOT). This action should require almost no time to complete because the tape should have been wound to EOT when it was last unloaded from the drive. The tape is now run in a reverse/forward pattern. This is used to calibrate tape speed (internal friction varies from cartridge to cartridge). The automatic gain control for the read electronics is set next. This allows the tape drive to read weak signals from older tapes. The tape is now wound to its beginning (Beginning of Tape BOT). Here, the BUSY indicator **15** is briefly extinguished. At this point the tape drive determines:

- Capacity of the tape (16.7 Mbyte or 67 Mbyte)
- Address information for any bad sections on the tape
- Address information for available spare blocks

Next, a write/read test is performed at a special location on the tape. After writing some data, the read-after-write function is performed. This read-after-write function is the error determination mechanism of the tape drive. Once this data is read, the BUSY indicator **15** is extinguished and the tape is ready for use. The entire operation takes approximately one minute for the 16.7-Mbyte tape and under two minutes for the 67-Mbyte tape.

## Tape Cartridge Unloading

---

### CAUTION

DO NOT ATTEMPT TO REMOVE THE TAPE CARTRIDGE FROM THE DRIVE BEFORE THE UNLOAD OPERATION HAS BEEN COMPLETED. THE OPERATION IS COMPLETE WHEN THE BUSY INDICATOR **15** IS EXTINGUISHED.

---

- a. Press the UNLOAD switch **13**. The tape drive will now begin an automatic unload operation. The BUSY indicator **15** is illuminated during this time.

First, the tape is wound to its beginning (BOT) where information regarding the errors which were accrued during the session are recorded. Next, the tape is wound to its end (EOT) where the number of sessions and tape life information is updated. After the updating, the BUSY indicator **15** is extinguished. The Eject pushbutton **14** is now unlocked, allowing the tape cartridge to be removed from the drive.

- b. If the PROTECT indicator **16** starts to flash after the BUSY indicator **15** is extinguished, this is a warning that the tape is approaching the end of its useful life.

Tape life information is determined by a media monitor circuit incorporated in the tape drive. The circuit monitors two parameters:

- Number of cartridge loads
- Number of data blocks accessed

Every time the tape cartridge is unloaded, the two numbers are updated in a designated area of EOT (only if the cartridge is not write protected). When a cartridge exceeds either of the following numbers, the monitor circuit causes the PROTECT indicator **16** to flash.

- 2000 cartridge loads
- 800 Mbytes accessed (600-foot cartridge) or 200 Mbytes accessed (150-foot cartridge)

- c. Press the Eject pushbutton **14** and remove the tape cartridge from the tape cartridge slot **18**.
- d. Check that the Write Protect switch on the tape cartridge is set to the desired position.
- e. Place the tape cartridge in its protective plastic container, and store it in a suitable location.



## Disc-To-Tape Back-Up

- a. Load a tape cartridge into the drive as described in the Tape Cartridge Loading paragraph. Ensure that the tape cartridge has sufficient capacity (16.7 or 67 megabytes) to store the disc volume and that the arrow on the Write Protect switch is pointing away from the SAFE marking.
- b. Ensure that the BUSY indicator **15** is extinguished.
- c. Press the TO TAPE pushbutton **11** once. When the BUSY indicator **15** flashes, press the TO TAPE pushbutton **11** once more to begin the disc-to-tape back-up (data transfer) operation.

The data transfer will start from logical block 0 on the disc and tape, and proceed until the disc volume has been completely transferred. When the last block is written on the tape, a file mark is written on the next block (assuming that a tape cartridge of sufficient capacity is being used). No multiple tape cartridge operations are supported.

When the data transfer has been successfully completed, the tape cartridge is automatically unloaded from the tape drive. Simultaneously, the disc drive FAULT/ON LINE indicator **10** will change from a flashing green to a solid green and the tape drive BUSY indicator **15** will be extinguished.

---

### Note

If a disc drive uncorrectable data error occurs during the data transfer, a best guess is sent. A disc drive fault will halt the data transfer. Both conditions (data error/disc drive fault) will cause the disc drive FAULT/ON LINE indicator **10** to turn red. The tape cartridge is not unloaded.

If a tape drive fault occurs, the data transfer will be halted and the tape drive FAULT indicator **17** will be illuminated. Again, the tape cartridge is not unloaded.

Press the UNLOAD pushbutton **13** to clear the fault and unload the tape cartridge.

---

- d. Press the Eject pushbutton **14** and remove the tape cartridge from the tape cartridge slot **18**.
- e. Set the arrow on the tape cartridge Write Protect switch to the SAFE marking.



## Tape-To-Disc Restore

- a. Load the back-up tape cartridge into the drive as described in the Tape Cartridge Loading paragraph.
- b. Ensure that the BUSY indicator **15** is extinguished.
- c. Press the FROM TAPE pushbutton **12** and when the BUSY indicator **15** begins flashing, press the FROM TAPE pushbutton **12** once more to begin the tape-to-disc restore (data transfer) operation. The data transfer will start from logical block 0 on the tape and proceed until the tape volume has been completely transferred.

When the data transfer has been successfully completed, the tape cartridge is automatically unloaded from the tape drive. Simultaneously, the disc drive FAULT/ON LINE indicator **15** will change from a flashing green to a solid green and the tape drive BUSY indicator **15** will be extinguished.

---

### Note

If a tape drive uncorrectable data error occurs during the data transfer, a best guess is sent. A tape drive fault will halt the data transfer. Both conditions (data error/tape drive fault) will cause the tape drive FAULT indicator **17** to be illuminated. The tape cartridge is not unloaded.

If a disc drive fault occurs, the data transfer will be halted and the disc drive FAULT/ON LINE indicator **10** will be a solid red. Again, the tape cartridge is not unloaded.

Press the UNLOAD pushbutton **13** to clear the fault and unload the tape cartridge.

---

- d. Press the Eject pushbutton **14** and remove the tape cartridge from the tape cartridge slot **18**.

## Line Voltage Removal

- a. Unload the tape cartridge (if installed) from the drive following the instructions given in the Tape Cartridge Unloading paragraph.
- b. Set the LINE~ switch **1** to the 0 (out) position.

# Chapter 4

## Maintenance and Service

### Serial Number

Each drive carries an individual serial number recorded on the rear panel. It is a good idea to keep a record of this serial number. Should your drive be stolen or lost, the serial number is often necessary for tracing and recovery, as well as any insurance claims. Hewlett-Packard does not maintain cross-reference records of customer names and drive serial numbers.

### Shipping

When the drive requires repackaging for shipment, use the original container and packaging material supplied with the drive. Pack the drive as shown in Figure 1, Packaging Details. Seal the container securely with strapping tape. If the original container is not available, consult your local dealer or Hewlett-Packard Sales and Support Office for information on how to obtain replacement packaging material.

Before shipment, the container should have an attached tag identifying the owner and the service or repair needed. Include the equipment model number and full serial number. The shipping weight of the drive is 19.6 kilograms (43.3 pounds). Also, we recommend that all shipments be insured.

### Disc Drive Maintenance

No regularly scheduled preventive maintenance is required for the disc drive.

### Tape Drive Maintenance

The tape drive needs a minimum of maintenance to keep it in proper working order. However, the tape head requires regular cleaning. The tape head must be cleaned each week and after using a new tape cartridge for the first time. Also, head cleaning is recommended after every three to five back-up operations requiring the use of the 600-foot tape cartridge. It is important that the tape head be cleaned any time data errors are encountered. Tape head cleaning instructions are given in the Cleaning the Tape Head and Capstan paragraph.

## Cleaning Supplies

---

### WARNING

**ALL PRODUCTS WHICH UTILIZE TAPE HEAD CLEANER ARE SHIPPED WITH A MATERIAL SAFETY DATA SHEET (MSDS). FOLLOW THE APPLICABLE SAFETY PRECAUTIONS WHEN USING THE TAPE HEAD CLEANER.**

---

A supply of cleaning material should be kept on hand at all times. The following products are recommended for use with the drive.

- HP 92193X Tape Head Cleaner. Six 4-oz bottles.
- 9300-0767 Foam Swabs. 50 per package.
- HP 92193H Magnetic Head Cleaning Kit. Included in the kit are two 4-oz bottles of tape head cleaner, 50 lint-free wipes, 10 foam swabs, and one easy-pour dispensing cap.

---

### CAUTION

- DO NOT USE CLEANING SOLUTIONS WHICH CONTAIN LUBRICANTS. THESE SOLUTIONS DEPOSIT LUBRICANTS ON THE TAPE HEAD AND DEGRADE PERFORMANCE.
  - DO NOT USE SOAP AND WATER ON THE TAPE PATH. SOAP LEAVES A THICK FILM AND WATER MAY DAMAGE ELECTRONIC PARTS.
  - DO NOT USE STANDARD HUB CLEANERS OR STRONG ALCOHOLIC SOLUTIONS (GREATER THAN 20 PERCENT). THESE SOLUTIONS WILL DAMAGE THE TAPE GUIDES AND CAPSTAN.
  - DO NOT USE AEROSOL CLEANERS, EVEN IF THEY CONTAIN FREON TF. THE SPRAY IS DIFFICULT TO CONTROL AND MAY CONTAIN METALLIC PARTICLES WHICH WILL DAMAGE THE TAPE HEAD.
- 

Hewlett-Packard supports *only* the use of *liquid* Freon TF (trichlorotrifluorethane) as a tape path cleaning solution. Liquid Freon TF cuts oil and grease, evaporates quickly, leaves no residue, and will not damage the tape transport. If the user employs a source other than Hewlett-Packard for this product, make sure that the fluid is a high-quality solution of 80 percent Freon TF and 20 percent isopropyl alcohol. Avoid solutions of Freon TF mixed with other solvents.



## Wiping Materials

---

DO NOT USE FACIAL TISSUES OR COTTON-TIPPED SWABS. ALTHOUGH SEEMINGLY EFFECTIVE, THEY CAN INTRODUCE HIGHLY ABRASIVE LINT INTO THE TAPE PATH.

---

Use only the foam swabs listed in the Cleaning Supplies paragraph. The wiping materials must be discarded after use. Even if they appear to be clean, they contain contamination.

## Cleaning the Tape Head and Capstan

---

- DO NOT TOUCH THE TAPE OR ATTEMPT TO CLEAN THE TAPE OR TAPE GUIDES IN THE TAPE CARTRIDGE.
  - USE ONLY THE CLEANING MATERIALS LISTED IN THE CLEANING SUPPLIES PARAGRAPH. USE OF UNAUTHORIZED MATERIALS COULD RESULT IN LOSS OF DATA.
- 

The tape head and capstan can be reached for easy cleaning. To do this, the drive must be powered on. Then, reach in through the tape cartridge slot with a cleaning swab and depress the Cartridge-In switch. (See Figure 10, Tape Head and Capstan Cleaning.) The Cartridge-In switch is the lower of the two switches located at the left rear of the tape cartridge cavity. Press the switch for approximately 1 second and then release it. This will cause the tape head to rise. It will be necessary to press the Cartridge-In switch twice to raise the head up far enough to fully clean it. Pressing the switch for longer than 3 seconds will cause the tape drive to think that a cartridge has been loaded and a load sequence will begin. If this happens, cycle the power off and on again and repeat the head raising procedure.

After power is removed, clean the tape head and capstan as follows:

- a. Set the LINE~ switch **1** to the 0 (out) position and disconnect the power cord from the ~ AC LINE connector **2**.

---

### CAUTION

FREON TF DISSOLVES WAX. IF A WAXED PAPER CUP IS USED, THE WAX WILL BE TRANSFERRED TO THE TAPE PATH, RESULTING IN THE POSSIBLE LOSS OF DATA.

---

- b. Pour a small amount of tape head cleaner into a small *unwaxed* paper cup.






Figure 10. Tape Head and Capstan Cleaning

- c. Moisten the cleaning swabs with the tape head cleaner in the paper cup, as required.
- d. While applying pressure in the direction of the tape path, clean the tape head and capstan as shown in figure 10. Be sure to clean the tape head with a side-to-side motion of the cleaning swab.

## Cleaning the Case

### CAUTION

- CHEMICAL SPRAY-ON CLEANERS USED FOR APPLIANCES AND OTHER HOUSEHOLD AND INDUSTRIAL APPLICATIONS MAY DAMAGE THE FINISH ON THE CASE. THESE, OR OTHER CHEMICAL CLEANERS, SHOULD NOT BE USED.
- DO NOT CLEAN THE CASE WITH DETERGENTS THAT CONTAIN AMMONIA, BENZENES, CHLORIDES, OR ABRASIVES.

The drive front panel is made of a colored plastic and is not painted. The cover and rear panel are painted with a durable, long-lasting, nontoxic paint. This will preserve the appearance of your drive for many years. When you want to clean the case, follow the instructions given below. If the finish on the painted portions of the case should become damaged, consult your local Hewlett-Packard Sales and Support Office or dealer for touchup paints that are available.

- a. Set the LINE~ switch **1** to the 0 (out) position and disconnect the power cord from the ~AC LINE connector **2**.
- b. Disconnect the HP-IB cable from the HP-IB connector **8**.
- c. Dampen a clean, lint-free cloth in a solution of water and mild soap and wipe the soiled areas of the case. Ensure that no cleaning solution gets inside the case.
- d. Wipe the cleaned areas with a clean, lint-free cloth moistened in clean water. Dry the case with a clean cloth. Remove any pen and ink marks with a nonabrasive eraser.

## Warranty

The drive is covered by a standard Hewlett-Packard warranty. However, this warranty is voided if the sealed head-disc assembly is opened or otherwise tampered with.

# Appendix A

## Installation on RTE-A Systems

### Overview

This appendix describes how to prepare an RTE-A operating system which will support the use of the HP 7942 and HP 7946 Disc/Tape Drives on Model A600, A700, and A900 computer systems running standard RTE-A operating systems.

The purpose of this appendix is to complement the installation and generation of the HP 7942 and HP 7946 on A-Series computers prior to the next system document update cycle, and the A.85 software release cycle from Data Systems Division.

### Support

The HP 7942 and HP 7946 are supported as a “system disc” or “add-on disc” on RTE-A systems. Operating systems can be installed by doing a pushbutton restore (tape-to-disc copy), or by using the RTE-A utility INSTL, and copying system files to the disc.

The HP 7942 and HP 7946 require the RTE-A CS/80 disc driver DD.33, revision 2326 or later.

Up to four (4) HP 7942/HP 7946's are supported on a single 12009A HP-IB interface card. The HP 7942 and HP 7946 can be “daisy chained” to any other CS/80 disc drive provided the total number of CS/80 disc drives do not exceed the four disc drives per interface requirement.

### Preparing for the Disc Layout

To optimize the disc storage capacity of the HP 7942 and HP 7946 Disc/Tape Drives on RTE-A, the user should define the driver parameters which specify LU sizes and starting block location (DP3, DP4, DP5, DP6, DP7). There are no default generation records contained in the current RTE-A operating system for the HP 7942 and HP 7946.

The HP 7942 and HP 7946 have 92,928 and 216,831 disc blocks of usable formatted capacity, respectively.

---

#### Note

One disc block equals 256 bytes or 128 words.

---



To do the generation, the user should have available the following RTE-A manuals:

- *RTE-A System Generation and Installation Manual*, part no. 92077-90034 ..... (required)
- *RTE-A User's Manual*, part no. 92077-90002 ..... (if needed)
- *RTE-A Utilities Manual*, part no. 92077-90004 ..... (if needed)
- *RTE-A Driver Reference Manual*, part no. 92077-90011 ..... (if needed)

A procedure to configure an HP 7942 or HP 7946 is described below. Each step in the procedure is accompanied by an example showing how the generation is done.

## Considerations

The simplest way to configure the disc drive is to use the default disc configuration for the HP 7911 and HP 7912 Disc Drives and then modify the last LU to fully utilize the capacity of the disc drive. The following example illustrates this approach.

There are several benefits to using this approach:

- (1) Most LU's will be the same size as other CS/80 disc default LU sizes.
- (2) These LU sizes will be the same size as the default disc configuration which will be included for the generation records for the HP 7942 and HP 7946 in the A.85 software release. Therefore, the system generation will not be affected when the software update is provided by Data Systems Division.

If you desire to configure your disc drives in a way other than that shown in the example, refer to pages C-8 through C-13 in the *RTE-A System Generation and Installation Manual* on configuring a CS/80 disc subsystem.

## Disc Layout

Most of the disc and CTD layout to be used will be the same as the RTE-A default sizes for the HP 7911 and HP 7912 Disc Drives. LU 22 is reconfigured to utilize the disc capacity for the HP 7942 example. LU 29 is reconfigured to utilize the capacity of the HP 7946. (Refer to the *RTE-A System Generation and Installation Manual*, Appendix C and E, for more information.)

## HP 7942 Disc Drive Layout Example

A sample disc layout for the HP 7942 is shown below. The example uses the RTE-A default disc configuration for the HP 7911. However, LU 22 has been made smaller since the HP 7942 is smaller in capacity than the HP 7911. (Refer to the *RTE-A System Generation and Installation Manual*, page C-12.)

	LU	16	17	18	19	20	22	Range
DP1	HP-IB addr.	0	0	0	0	0	0	0-7
DP2	UNIT / VOL.	0	0	0	0	0	0	0
DP3	Starting	0	0	0	0	0	0	0
DP4	Block	0	0	0	0	0	0	0-1
DP5	Number	0	19200	29472	43872	54144	64750	0-65536
DP6	# Tracks	400	214	300	214	215	587	1-1936
DP7	Sect/Track	48	48	48	48	48	48	48
DP8	Reserved	0	0	0	0	0	0	0

## HP 7946 Disc Drive Layout Example

A sample disc layout for an HP 7946 is shown below. Note that the first seven LU numbers (LU's 16-23) are the same as the RTE-A default disc configuration for an HP 7912. (Refer to the *RTE-A System Generation and Installation Manual*, page C-12, for more information.)

	LU	16	17	18	19	20	22	23	29	Range
DP1	0	0	0	0	0	0	0	0	0	0-7
DP2	0	0	0	0	0	0	0	0	0	0
DP3	0	0	0	0	0	0	0	0	0	0
DP4	0	0	0	0	0	0	0	1	1	0-3
DP5	0	19200	29472	43872	54144	64750	44286	64640	64640	0-64750
DP6	400	214	300	214	215	939	424	1805	1805	1-4517
DP7	48	48	48	48	48	48	48	48	48	48
DP8	0	0	0	0	0	0	0	0	0	0

## Disc Cache Layout Example for the HP 7942 and HP 7946

The disc cache is an area reserved on the disc for improving the 1/4-inch tape drive performance when copying files between the disc and tape. For more information on the disc cache refer to page C-8 in the *RTE-A System Generation and Installation Manual* and page 2-80 in the *RTE-A Driver Reference Manual*. The example shown below is applicable for the HP 7942 and HP 7946.

	LU	24
DP1	HP-IB addr.	0
DP2	UNIT / VOL.	400B
DP3	Cache Bit, Disc U/V	100000B
DP4	Starting Block	0
DP5	Number	64464
DP6	Addr. of Disc	0
DP7	Cache Block	0
DP8	Reserved	0

## EDIT the Answer File

Now that the disc configuration has been determined, the answer file must be modified to include the HP 7942 or HP 7946. EDIT your answer file to include the following requirements.

### Driver Partition Section

Modify the driver partition to include the interface driver (%ID.37::cartridge number) and the CS/80 disc device driver (%DD.33::cartridge number). If these drivers are already genned into your system, skip this step, and proceed to the TABLE GENERATION.

Example:

```
*  
RE,%ID.37::17  
RE,%DD.33::17  
END  
*
```

### Table Generation

- a. Add an IFT command for the HP-IB interface where the HP 7942 or HP 7946 will be placed.

---

#### Note

This command *will not* be required if the HP 7942 or HP 7946 is going to be placed on an existing CS/80 disc channel. (Refer to the *RTE-A System Generation and Installation Manual*, page 6-8, for more information.)

---

Example:

```
*  
IFT,%ID.37::17,SC:27B  
*
```

Add a DVT command for the device table *immediately* after the IFT command.

---

#### Note

This command *will not* be required if the HP 7942 or HP 7946 is being added to an existing CS/80 disc channel. (Refer to page 6-12 in the *RTE-A System Generation and Installation Manual* for more information on this command.)

---

Example:

```
*  
DVT,,,LU:9,TO:2000,DT:77B,TX:0,DX:1,DP:1:36B,PR:0  
*
```



- b. Add a comment before the section of driver parameters for the HP 7942 or HP 7946 noting that it is an HP 7942/HP 7946 disc drive.

Example:

```
*
* HP 7946 Disc Drive (LU's 16-20,22,23,24,29) with integrated cartridge tape drive
* specifying model number as HP 7912
* HP-IB address of disc is 0
*
```

- c. Add the HP 7942 or HP 7946 parameters that have been determined in the DISC LAYOUT paragraph.

If you do not want to specify a disc model number, you can specify the device type as 33B (i.e., DT:33B). (Refer to the DVT command description on page 6-12 of the *RTE-A System Generation and Installation Manual*.)

Example: "Table Generation" section for an HP 7946 disc drive

```
*
DVT,%DD.33::17,M7912__LF:0,LU:16,DP:1:0
DVT,%DD.33::17,M7912__LF:1,LU:17,DP:1:0
DVT,%DD.33::17,M7912__LF:2,LU:18,DP:1:0
DVT,%DD.33::17,M7912__LF:3,LU:19,DP:1:0
DVT,%DD.33::17,M7912__LF:4,LU:20,DP:1:0
DVT,%DD.33::17,M7912__LF:5,LU:22,DP:1:0
DVT,%DD.33::17,M7912__LF:6,LU:23,DP:1:0
DVT,%DD.33::17,M7912__LF:7,LU:29,DP:1:0:0,DP:3:0:1:64640:1805,DP:7:48:0
*
```

## The Node List

Modify the node list to include the LU numbers which are contained on the HP 7942/HP 7946.

Example:

```
*
* NINE 7946 DISC LU'S including cartridge tape drive
node,16,17,18,19,20,22,23,24,29
*
```

## Generation

Run RTAGN to do the system generation. (Refer to the *RTE-A System Generation and Installation Manual*, page 2-1.) Provided the correct parameters are specified in the answer file, the generation should complete with 0 errors.

You should now have a bootable operating system which will allow you to use the HP 7942/HP 7946 to its full capacity. (Refer to the *RTE-A System Generation and Installation Manual*, page 8-1, for installing a disc-based system).

Connect the HP-IB cable to the disc/tape drive.

Set the HP-IB address on the disc/tape drive which is specified in Driver Parameter one (DPI). (Refer to the paragraph titled SETTING THE HP-IB DEVICE ADDRESS in Chapter 2 of this manual for information on setting the address.)

Power on the drive. The disc drive and tape drive will go through a self-test process.

## Booting the New System

Boot the new operating system which includes the HP 7942 or HP 7946.

The HP 7942 or HP 7946 Disc/Tape Drive should now be ready for use.

Mount CI and/or Initialize and mount FMGR cartridges. (Refer to the *RTE-A User's Manual*, page 6-27.)

If the operating system is to be installed on the HP 7942 or HP 7946, refer to the *RTE-A System Generation and Installation Manual* to install an operating system on the disc drive.

## Back-up

Back-up for files and data which are stored on the HP 7942 and HP 7946 can be accomplished by the use of many RTE-A Utilities or by doing a pushbutton save, and to many types of media.

### The Media

Files can be backed up to the integrated 1/4-inch tape drive (16.7 Mbyte or 67 Mbyte tape capacity). If desired, files can also be backed up on another disc drive (integrated or stand-alone), an 800 or 1600 BPI tape drive, or even floppy disc (integrated floppies in Micro-1000's or stand-alone).

The medium chosen depends on the devices which are available to the user, and the amount of data which needs to be copied. Floppy discs should be used only where small amounts of data need to be backed up.

### RTE-A Back-Up Utilities

File back-up can be accomplished with the HP 7942 and HP 7946 using RTE-A utilities such as:

- a. TF (tape filer)
- b. FC (file copy)

An image backup can be accomplished by using utilities such as:

- a. ASAVE and ARSTR

Refer to page 2-1 of the *RTE-A Utilities Manual* to determine which utility is best suited for your application and back-up strategy.

## Rack Mounting

To rack mount the HP 7942 or HP 7946 in a 19-inch equipment rack, a 19501A Rack Mounting Kit is required. The kit can be purchased through your HP sales representative. Installation instructions are supplied with the kit.

Consult your local HP Customer Engineer for assistance.

## Additional Help

If you require further assistance on installing an HP 7942 or HP 7946 Disc/Tape Drive on your RTE-A system, please contact your local Hewlett-Packard Customer Engineer.



# Appendix B

## Installation on HP 9000 Systems

### Overview

The HP 7942 and HP 7946 Disc/Tape Drives are CS/80 disc products with an integrated cartridge tape drive. They should be configured on HP 9000 systems according to the instructions provided with each operating system for using CS/80 disc drives.

The following HP 9000 systems support the HP 7942 and HP 7946, both as system discs and as add-on discs:

- Series 200

- BASIC 3.0

- Pascal 3.0

- Modify CONFIG:CTABLE,TEXT disc template to include:

- CS80id := 7942; nvols := 23; mp.tpm := 3\*968;

- mp.bpt := 32\*256 {7942}

- CS80id := 7946; nvols := 30; mp.tpm := 7\*968;

- mp.bpt := 32\*256 {7946}

- HPUX 2.1

- When installing HPUX 2.1 on the 7942 or 7946, /etc/s4sinstall will prompt you for the number of blocks on your disc. The following chart assumes a swap size of 2,000 blocks and should be used for your reply:

CS/80 DISC	SIZE	BLOCKS
HP 7942	23.8 Mb	21232
HP 7946	55.5 Mb	52208

- Series 500 — requires loader Rev. B to boot system from HP 7942 or HP 7946

- BASIC 2.0

- HPUX 4.0

### Additional Help

If you require further assistance on how to configure an HP 7942 or HP 7946 Disc/Tape Drive on your particular system, contact your local Hewlett-Packard Customer Engineer.

# SALES & SUPPORT OFFICES

Arranged alphabetically by country



## Product Line Sales/Support Key

Key Product Line

**A** Analytical

**CM** Components

**C** Computer Systems Sales only

**CH** Computer Systems Hardware Sales and Services

**CS** Computer Systems Software Sales and Services

**E** Electronic Instruments & Measurement Systems

**M** Medical Products

**P** Personal Computation Products

\* Sales only for specific product line

\*\* Support only for specific product line

**IMPORTANT:** These symbols designate general product line capability. They do not insure sales or support availability for all products within a line, at all locations. Contact your local sales office for information regarding locations where HP support is available for specific products.

*HP distributors are printed in italics.*

## HEADQUARTERS OFFICES

If there is no sales office listed for your area, contact one of these headquarters offices.

### AFRICA AND MIDDLE EAST

Hewlett-Packard S.A.  
Mediterranean and Middle East Operations

Atrina Centre

32 Kifissias Ave.

Paradissos-Amarousion, **ATHENS**

Greece

Tel: 682 88 11

Telex: 21-6588 HPAT GR

Cable: HEWPACKSA Athens

### NORTH/CENTRAL AFRICA

Hewlett-Packard S.A.  
7, Rue du Bois-du-Lan

CH-1217 **MEYRIN** 2, Switzerland

Tel: (022) 83 12 12

Telex: 27835 hpse

Cable: HEWPACKSA Geneve

### ASIA

Hewlett-Packard Asia Ltd.

47/F, 26 Harbour Rd.,

Wanchai, **HONG KONG**

G.P.O. Box 863, Hong Kong

Tel: 5-8330833

Telex: 76793 HPA HX

Cable: HPASIAL TD

### CANADA

Hewlett-Packard (Canada) Ltd.

6877 Goreway Drive

**MISSISSAUGA**, Ontario L4V 1M8

Tel: (416) 678-9430

Telex: 610-492-4246

### EASTERN EUROPE

Hewlett-Packard Ges.m.b.h.

Liebigasse 1

P.O.Box 72

A-1222 **VIENNA**, Austria

Tel: (222) 2365110

Telex: 13 4425 HEPA A

### NORTHERN EUROPE

Hewlett-Packard S.A.

Uilenstede 475

P.O.Box 999

NL-1180 **AZ AMSTELVEEN**

The Netherlands

Tel: 20 437771

### SOUTH EAST EUROPE

Hewlett-Packard S.A.

World Trade Center

110 Avenue Louis Carol

1215 Cointrin, **GENEVA**, Switzerland

Tel: (022) 98 96 51

Telex: 27225 hpse.

### EASTERN USA

Hewlett-Packard Co.

4 Choke Cherry Road

**ROCKVILLE**, MD 20850

Tel: (301) 258-2000

### MIDWESTERN USA

Hewlett-Packard Co.

5201 Tollview Drive

**ROLLING MEADOWS**, IL 60008

Tel: (312) 255-9800

### SOUTHERN USA

Hewlett-Packard Co.

2000 South Park Place

P.O. Box 105005

**ATLANTA**, GA 30348

Tel: (404) 955-1500

### WESTERN USA

Hewlett-Packard Co.

3939 Lankershim Blvd.

P.O. Box 3919

**LOS ANGELES**, CA 91604

Tel: (213) 506-3700

### OTHER INTERNATIONAL AREAS

Hewlett-Packard Co.

Intercontinental Headquarters

3495 Deer Creek Road

**PALO ALTO**, CA 94304

Tel: (415) 857-1501

Telex: 034-8300

Cable: HEWPACK

### ANGOLA

Telectra

Empresa TAecnica de Equipamentos

R. Barbosa Rodrigues, 41-I DT.

Caixa Postal 6487

**LUANDA**

Tel: 35515,35516

E,P

### ARGENTINA

Hewlett-Packard Argentina S.A.

Avenida Santa Fe 2035

Martinez 1640 **BUENOS AIRES**

Tel: 798-5735, 792-1293

Cable: HEWPACKARG

A,E,CH,CS,P

### AUSTRALIA

#### Adelaide, South Australia Office

Hewlett-Packard Australia Ltd.

153 Greenhill Road

**PARKSIDE**, S.A. 5063

Tel: 272-5911

Telex: 82536

Cable: HEWPARD Adelaide

A\*,CH,CM,CS,E,M,P

#### Brisbane, Queensland Office

Hewlett-Packard Australia Ltd.

10 Payne Road

**THE GAP**, Queensland 4061

Tel: 30-4133

Telex: 42133

Cable: HEWPARD Brisbane

A,CH,CS,CM,E,M,P

#### Canberra, Australia

##### Capital Territory Office

Hewlett-Packard Australia Ltd.

121 Wollongong Street

**FYSHWICK**, A.C.T. 2609

Tel: 80 4244

Telex: 62650

Cable: HEWPARD Canberra

C,CH,CM,CS,E,P

#### Melbourne, Victoria

##### Office

Hewlett-Packard Australia Ltd.

31-41 Joseph Street

**BLACKBURN**, Victoria 3130

Tel: 895-2895

Telex: 31-024

Cable: HEWPARD Melbourne

A,CH,CM,CS,E,M,P

#### Perth, Western Australia

##### Office

Hewlett-Packard Australia Ltd.

261 Stirling Highway

**CLAREMONT**, W.A. 6010

Tel: 383-2188

Telex: 93859

Cable: HEWPARD Perth

A,CH,CM,CS,E,M,P

#### Sydney, New South

##### Wales Office

Hewlett-Packard Australia Ltd.

17-23 Talavera Road

P.O. Box 308

**NORTH RYDE**, N.S.W. 2113

Tel: 888-4444

Telex: 21561

Cable: HEWPARD Sydney

A,CH,CM,CS,E,M,P

### AUSTRIA

Hewlett-Packard Ges.m.b.h.

Grottenhofstrasse 94

A-8052 **GRAZ**

Tel: (0316) 291 5 66

Telex: 32375

CH,E

Hewlett-Packard Ges.m.b.h.

Liebigasse 1

P.O. Box 72

A-1222 **VIENNA**

Tel: (0222) 23 65 11-0

Telex: 134425 HEPA A

A,CH,CM,CS,E,M,P

### BAHRAIN

Green Salon

P.O. Box 557

Manama

**BAHRAIN**

Tel: 255503-255950

Telex: 84419

P

Wael Pharmacy

P.O. Box 648

**BAHRAIN**

Tel: 256123

Telex: 8550 WAEL BN

E,M

### BELGIUM

Hewlett-Packard Belgium S.A./N.V.

Blvd de la Woluwe, 100

Woluwedal

B-1200 **BRUSSELS**

Tel: (02) 762-32-00

Telex: 23-494 paloben bru

A,CH,CM,CS,E,M,P

### BERMUDA

Applied Computer Technologies

Atlantic House Building

Par-La-Ville Road

Hamilton 5

Tel: 295-1616

P

### BRAZIL

Hewlett-Packard do Brasil

I.e.C. Ltda.

Alameda Rio Negro, 750

Alphaville

06400 **BARUERI SP**

Tel: (011) 421.1311

Telex: (011) 33872 HPBR-BR

Cable: HEWPACK Sao Paulo

A,CH,CM,CS,E,M,P





# SALES & SUPPORT OFFICES

Arranged alphabetically by country

## BRAZIL (Cont'd)

Hewlett-Packard do Brasil  
i.e.C. Ltda.  
Avenida Epitacio Pessoa, 4664  
22471 RIO DE JANEIRO-RJ  
Tel: (021) 286.0237  
Telex: 021-21905 HPBR-BR  
Cable: HEWPACK Rio de Janeiro  
A,CH,CM,E,M,P\*  
*Convex/Van Den*  
*Rua Jose Bonifacio*  
*458 Todos Os Santos*  
*CEP 20771*  
**RIO DE JANEIRO, RJ**  
Tel: 249-7121, 591-4946  
Telex: 33487  
*ANAMED I.C.E.I. Ltda.*  
*Rua Bage, 103*  
**04012 SAO PAULO**  
Tel: (011) 570-5726  
Telex: 021-21905 HPBR-BR  
M

## CANADA

### Alberta

Hewlett-Packard (Canada) Ltd.  
3030 3rd Avenue N.E.  
**CALGARY, Alberta T2A 6T7**  
Tel: (403) 235-3100  
A,CH,CM,E\*,M,P\*  
Hewlett-Packard (Canada) Ltd.  
11120-178th Street  
**EDMONTON, Alberta T5S 1P2**  
Tel: (403) 486-6666  
A,CH,CM,CS,E,M,P

### British Columbia

Hewlett-Packard (Canada) Ltd.  
10691 Shellbridge Way  
**RICHMOND,**  
British Columbia V6X 2W7  
Tel: (604) 270-2277  
Telex: 610-922-5059  
A,CH,CM,CS,E\*,M,P\*  
Hewlett-Packard (Canada) Ltd.  
121 - 3350 Douglas Street  
**VICTORIA, British Columbia V8Z 3L1**  
Tel: (604) 381-6616  
CH,CS

### Manitoba

Hewlett-Packard (Canada) Ltd.  
1825 Inkster Blvd.  
**WINNIPEG, Manitoba R3H 0Y1**  
Tel: (204) 786-6701  
A,CH,CM,E,M,P\*

### New Brunswick

Hewlett-Packard (Canada) Ltd.  
37 Shediac Road  
**MONCTON, New Brunswick E1A 2R6**  
Tel: (506) 855-2841  
CH,CS

### Nova Scotia

Hewlett-Packard (Canada) Ltd.  
Suite 111  
900 Windmill Road  
**DARTMOUTH, Nova Scotia B2Y 3Z6**  
Tel: (902) 469-7820  
CH,CM,CS,E\*,M,P\*

## Ontario

Hewlett-Packard (Canada) Ltd.  
3325 N. Service Rd., Unit 6  
**BURLINGTON, Ontario P3A 2A3**  
Tel: (416) 335-8644  
CS,M\*  
Hewlett-Packard (Canada) Ltd.  
496 Days Road  
**KINGSTON, Ontario K7M 5R4**  
Tel: (613) 384-2088  
CH,CS  
Hewlett-Packard (Canada) Ltd.  
552 Newbold Street  
**LONDON, Ontario N6E 2S5**  
Tel: (519) 686-9181  
A,CH,CM,E\*,M,P\*  
Hewlett-Packard (Canada) Ltd.  
6877 Goreway Drive  
**MISSISSAUGA, Ontario L4V 1M8**  
Tel: (416) 678-9430  
A,CH,CM,CS,E,M,P  
Hewlett-Packard (Canada) Ltd.  
2670 Queensview Dr.  
**OTTAWA, Ontario K2B 8K1**  
Tel: (613) 820-6483  
A,CH,CM,CS,E\*,MS,P\*  
Hewlett-Packard (Canada) Ltd.  
1855 Lasalle Boulevard  
**SUDBURY, Ontario, P3A 2A3**  
Tel: (705) 560-5450  
CH  
Hewlett-Packard (Canada) Ltd.  
220 Yorkland Blvd. Unit #11  
**WILLOWDALE, Ontario M2J 1R5**  
Tel: (416) 499-9333  
CH  
**Quebec**  
Hewlett-Packard (Canada) Ltd.  
17500 South Service Road  
Trans-Canada Highway  
**KIRKLAND, Quebec H9J 2M5**  
Tel: (514) 697-4232  
A,CH,CM,CS,E,M,P\*  
Hewlett-Packard (Canada) Ltd.  
1150 Rue Claire Fontaine  
**QUEBEC CITY, Quebec G1R 5G4**  
Tel: (418) 648-0726  
CH,CS  
Hewlett-Packard (Canada) Ltd.  
#7-130 Robin Crescent  
**SASKATOON, Saskatchewan S7L 6M7**  
Tel: (306) 242-3702  
CH,CS  
**CHILE**  
*ASC Ltda.*  
*Austria 2041*  
**SANTIAGO**  
Tel: 223-5946, 223-6148  
Telex: 340192 ASC CK  
P,C  
*Jorge Calcagni y Cia. Ltda.*  
*Av. Italia 634 Santiago*  
*Casilla 16475*  
**SANTIAGO 9**  
Tel: 222-0222  
Telex: 440283 JCYCL CZ  
CM,E,M

## Metrolab S.A.

*Monjitas 454 of. 206*  
**SANTIAGO**  
Tel: 395752, 398296  
Telex: 340866 METLAB CK  
A  
*Olympia (Chile) Ltda.*  
*Av. Rodrigo de Araya 1045*  
*Casilla 256-V*  
**SANTIAGO 21**  
Tel: 225-5044  
Telex: 340892 OLYMP  
Cable: Olympiachile Santiagochile  
CH,CS,P

## CHINA, People's Republic of

China Hewlett-Packard Co., Ltd.  
6th Floor, Sun Hung Kai Centre  
30 Harbour Road  
**HONG KONG**  
Tel: 5-8323211  
Telex: 36678 HEWPA HX  
A,C,CH,CS,E,M,P  
*China Hewlett-Packard Rep. Office*  
*P.O. Box 418*  
*1A Lane 2, Luchang St.*  
*Beiwei Rd., Xuanwu District*  
**BEIJING**  
Tel: 33-1947, 33-7426  
Telex: 22601 CTSHP CN  
Cable: 1920  
A,CH,CM,CS,E,P

## COLOMBIA

*InstrumentaciAO n*  
*H. A. Langebaek & Kier S.A.*  
*Carrera 4A No. 52A-26*  
*Apartado Aereo 6287*  
**BOGOTA 1, D.E.**  
Tel: 212-1466  
Telex: 44400 INST CO  
Cable: AARIS Bogota  
CM,E,M  
*Nefromedicas Ltda.*  
*Calle 123 No. 9B-31*  
*Apartado Aereo 100-958*  
**BOGOTA D.E., 10**  
Tel: 213-5267, 213-1615  
Telex: 43415 HEGAS CO  
A  
*Procesa, S.A.*  
*CRA 7 No. 24-89 Piso 25*  
*Torre Colpatría*  
*Apartado Aereo No. 49667*  
**BOGOTA D.E.**  
Tel: 2344925, 2344958, 2344742  
Telex: 43127 COVER CO  
C,P  
*Compumundo*  
*Avenida 15 # 107-80*  
**BOGOTA D.E.**  
Tel: 214-4458  
Telex: 45466 MARICO  
P

## COSTA RICA

*Cientifica Costarricense S.A.*  
*Avenida 2, Calle 5*  
*San Pedro de Montes de Oca*  
*Apartado 10159*  
**SAN JOSÉ**  
Tel: 24-38-20, 24-08-19  
Telex: 2367 GALGUR CR  
CM,E,M

## CYPRUS

*Telerexa Ltd.*  
*P.O. Box 4809*  
*14C Stassinou Avenue*  
**NICOSIA**  
Tel: 62698  
Telex: 2894 LEVIDO CY  
E,M,P

## DENMARK

Hewlett-Packard A/S  
Datavej 52  
DK-3460 BIRKEROD  
Tel: (02) 81-66-40  
A,CH,CM,CS,E,M,P  
Hewlett-Packard A/S  
Rølhedsvej 32  
DK-8240 RISSKOV, Aarhus  
Tel: (06) 17-60-00  
Telex: 37409 hpas dk  
CH,E

## DOMINICAN REPUBLIC

*Microprog S.A.*  
*Juan Tomás Mejía y Cotes No. 60*  
*Arroyo Hondo*  
**SANTO DOMINGO**  
Tel: 565-6268  
Telex: 4510 ARENTA DR (RCA)  
P

## ECUADOR

*CYEDE Cia. Ltda.*  
*Avenida Eloy Alfaro 1749*  
*y Belgica*  
*Casilla 6423 CCI*  
**QUITO**  
Tel: 450-975, 243-052  
Telex: 2548 CYEDE ED  
CM,E,P  
*Hospitalar S.A.*  
*Robies 625*  
*Casilla 3590*  
**QUITO**  
Tel: 545-250, 545-122  
Telex: 2485 HOSPTL ED  
Cable: HOSPITALAR-Quito  
M  
**QUITO**  
Tel: 2-238-951  
Telex: 2298 ECUAME ED

## EGYPT

*Egyptian International*  
*Office for Foreign Trade*  
*P.O. Box 2558*  
*42 El-Zahraa Street*  
**Dokki, CAIRO,**  
Tel: 712230  
Telex: 93337 EGPOR UN  
Cable: EGYPOR  
P,A



# SALES & SUPPORT OFFICES

Arranged alphabetically by country

3



## EGYPT (Cont'd)

### INFORMATIC FOR SYSTEMS

22 Talaat Harb Street

#### CAIRO,

Tel: 759006

Telex: 93697 SAFLM UN

CS

International Engineering Associates

24 Hussein Hegazi Street

Kasr-el-Aini

#### CAIRO,

Tel: 23829, 21641

Telex: 93830 IEA UN

Cable: INTEGASSO

E

S.S.C. Medical

40 Gezerat El Arab Street

Mohandessin

#### CAIRO,

Tel: 803844, 805998, 810263

Telex: 20503 SSC UN

M\*

## EL SALVADOR

IPESA de El Salvador S.A.

29 Avenida Norte 1216

#### SAN SALVADOR

Tel: 26-6858, 26-6868

Telex: 20539 IPESASAL

A,CH,CM,CS,E,P

## FINLAND

Hewlett-Packard Oy

Piispankalliontie 17

02200 ESPOO

Tel: 00358-0-88721

Telex: 121563 HEWPA SF

CH,CM,SS,P

Hewlett-Packard Oy

(Olarinluoma 7)

PL 24

02101 ESPOO 10

Tel: (90) 4521022

A,E,M

Hewlett-Packard Oy

Aatoksenkatu 10-C

SF-40720-72 JYVASKYLA

Tel: (941) 216318

CH

Hewlett-Packard Oy

Kainvuntie 1-C

SF-90140-14 OULU

Tel: (981) 338785

CH

## FRANCE

Hewlett-Packard France

Z.I. Mercure B

Rue Berthelot

F-13763 Les Milles Cedex

#### AIX-EN-PROVENCE

Tel: (42) 59-41-02

Telex: 410770F

A,CH,E,M,P\*

Hewlett-Packard France

64, rue Marchand Saillant

F-61000 ALENCON

Tel: (33) 29 04 42

Hewlett-Packard France

Boite Postale 503

F-25026 BESANCON

28 rue de la Republique

F-25000 BESANCON

Tel: (81) 83-16-22

Telex: 361157

CH,M

Hewlett-Packard France

13, Place Napoleon III

F-29000 BREST

Tel: (98) 03-38-35

Hewlett-Packard France

Chemin des Mouilles

Boite Postale 162

F-69130 ECULLY Cedex (Lyon)

Tel: (78) 833-81-25

Telex: 310617F

A,CH,CS,E,M

Hewlett-Packard France

Parc d'Activite du Bois Briard

Ave. du Lac

F-91040 EVRY Cedex

Tel: 6 077-8383

Telex: 692315F

E

Hewlett-Packard France

5, Avenue Raymond Chanas

F-38320 EYBENS (Grenoble)

Tel: (76) 62-67-98

Telex: 980124 HP GRENOB EYBE

CH

Hewlett-Packard France

Centre d'Affaire Paris-Nord

Bâtiment Ampère 5 étage

Rue de la Commune de Paris

Boite Postale 300

F-93153 LE BLANC MESNIL

Tel: (1) 865-44-52

Telex: 211032F

CH,CS,E,M

Hewlett-Packard France

Parc d'Activités Cadere

Quartier Jean Mermoz

Avenue du Président JF Kennedy

F-33700 MERIGNAC (Bordeaux)

Tel: (56) 34-00-84

Telex: 550105F

CH,E,M

Hewlett-Packard France

Immeuble "Les 3 B"

Nouveau Chemin de la Garde

ZAC de Bois Briard

F-44085 NANTES Cedex

Tel: (40) 50-32-22

Telex: 711085F

CH\*\*

Hewlett-Packard France

125, rue du Faubourg Banner

F-45000 ORLEANS

Tel: (38) 68 01 63

Telex: 600048F

A,CH,CM,CS,E,M,P

Hewlett-Packard France

Zone Industrielle de Courtaboeuf

Avenue des Tropiques

F-91947 Les Ulis Cedex ORSAY

Tel: (6) 907-78-25

Telex: 600048F

A,CH,CM,CS,E,M,P

Hewlett-Packard France

Paris Porte-Maillot

15, Avenue de L'Amiral Bruix

F-75782 PARIS CEDEX 16

Tel: (1) 502-12-20

Telex: 613663F

CH,M,P

Hewlett-Packard France

124, Boulevard Tourasse

F-64000 PAU

Tel: (59) 80 38 02

Hewlett-Packard France

2 AllAe de la Bourgonnette

F-35100 RENNES

Tel: (99) 51-42-44

Telex: 740912F

CH,CM,E,M,P\*

Hewlett-Packard France

98 Avenue de Bretagne

F-76100 ROUEN

Tel: (35) 63-57-66

Telex: 770035F

CH\*\* ,CS

Hewlett-Packard France

4 Rue Thomas Mann

Boite Postale 56

F-67033 STRASBOURG Cedex

Tel: (88) 28-56-46

Telex: 890141F

CH,E,M,P\*

Hewlett-Packard France

Le PAEripole

20, Chemin du Pigeonnier de la

CAEpiGeere

F-31083 TOULOUSE Cedex

Tel: (61) 40-11-12

Telex: 531639F

A,CH,CS,E,P\*

Hewlett-Packard France

9, rue Baudin

F-26000 VALENCE

Tel: (75) 42 76 16

Hewlett-Packard France

Carolor

ZAC de Bois Briard

F-57640 VIGY (Metz)

Tel: (8) 771 20 22

CH

Hewlett-Packard France

Immeuble PEriceentre

F-59658 VILLENEUVE D'ASCQ Cedex

Tel: (20) 91-41-25

Telex: 160124F

CH,E,M,P\*

## GERMAN FEDERAL

### REPUBLIC

Hewlett-Packard GmbH

Geschäftsstelle

Keithstrasse 2-4

D-1000 BERLIN 30

Tel: (030) 24-90-86

Telex: 018 3405 hpbin d

A,CH,E,M,P

Hewlett-Packard GmbH

Geschäftsstelle

Herrenberger Strasse 130

D-7030 BÖBLINGEN

Tel: (7031) 14-0

Telex: 07265739

A,CH,CM,CS,E,M,P

Hewlett-Packard GmbH

Geschäftsstelle

Emanuel-Leutze-Strasse 1

D-4000 DUSSELDORF

Tel: (0211) 5971-1

Telex: 085/86 533 hpdd d

A,CH,CS,E,M,P

Hewlett-Packard GmbH

Geschäftsstelle

Schleefstr. 28a

D-4600 DORTMUND-Aplerbeck

Tel: (0231) 45001

Hewlett-Packard GmbH

Vertriebszentrale Frankfurt

Berner Strasse 117

Postfach 560 140

D-6000 FRANKFURT 56

Tel: (0611) 50-04-1

Telex: 04 13249 hpffm d

A,CH,CM,CS,E,M,P

Hewlett-Packard GmbH

Geschäftsstelle

Aussenstelle Bad Homburg

Louisenstrasse 115

D-6380 BAD HOMBURG

Tel: (06172) 109-0

Hewlett-Packard GmbH

Geschäftsstelle

Kapstadtring 5

D-2000 HAMBURG 60

Tel: (040) 63804-1

Telex: 021 63 032 hpgh d

A,CH,CS,E,M,P

Hewlett-Packard GmbH

Geschäftsstelle

Heidering 37-39

D-3000 HANNOVER 61

Tel: (0511) 5706-0

Telex: 092 3259

A,CH,CM,E,M,P

Hewlett-Packard GmbH

Geschäftsstelle

Rosslauer Weg 2-4

D-6800 MANNHEIM

Tel: (0621) 70050

Telex: 0462105

A,C,E

Hewlett-Packard GmbH

Geschäftsstelle

Messerschmittstrasse 7

D-7910 NEU ULM

Tel: 0731-70241

Telex: 0712816 HP ULM-D

A,C,E\*

Hewlett-Packard GmbH

Geschäftsstelle

Ehhericherstr. 13

D-8500 NÜRNBERG 10

Tel: (0911) 5205-0

Telex: 0623 860

CH,CM,E,M,P

Hewlett-Packard GmbH

Geschäftsstelle

Eschenstrasse 5

D-8028 TAUFKIRCHEN

Tel: (089) 6117-1

Telex: 0524985

A,CH,CM,E,M,P

## GREAT BRITAIN

See United Kingdom

# SALES & SUPPORT OFFICES

Arranged alphabetically by country

## GREECE

Hewlett-Packard A.E.  
178, Kifissias Avenue  
6th Floor  
Halandri-ATHENS  
Greece  
Tel: 647 1673, 647 1543, 6472971  
A,CH,CM\*,CS\*\*,E,M,P

Kostas Karayannis S.A.  
8 Omirou Street  
ATHENS 133

Tel: 32 30 303, 32 37 371  
Telex: 215962 RKAR GR  
A,CH,CM,CS,E,M,P

PLAISIO S.A.  
Eliopoulos Brothers Ltd.  
11854

ATHENS  
Tel: 34-51-911  
Telex: 216286  
P

## GUATEMALA

IPESA  
Avenida Reforma 3-48, Zona 9  
GUATEMALA CITY  
Tel: 316627, 314786  
Telex: 4192 TELTRO GU  
A,CH,CM,CS,E,M,P

## HONG KONG

Hewlett-Packard Hong Kong, Ltd.  
G.P.O. Box 795  
5th Floor, Sun Hung Kai Centre  
30 Harbour Road  
HONG KONG  
Tel: 5-8323211  
Telex: 66678 HEWPA HX  
Cable: HEWPACK HONG KONG  
E,CH,CS,P

CET Ltd.  
10th Floor, Hua Asia  
Bldg. Gloucester  
64-66 Gloucester Road  
HONG KONG

Tel: (5) 200922  
Telex: 85148 CET HX  
CM

Schmidt & Co. (Hong Kong) Ltd.  
18th Floor, Great Eagle Centre  
23 Harbour Road, Wanchai

HONG KONG  
Tel: 5-8330222  
Telex: 74766 SCHMC HX  
A,M

## ICELAND

Elding Trading Company Inc.  
Hafnarnvoli-Tryggvagotu  
P.O. Box 895  
IS-REYKJAVIK  
Tel: 1-58-20, 1-63-03  
M

## INDIA

Computer products are sold through  
Blue Star Ltd. All computer repairs and  
maintenance service is done through  
Computer Maintenance Corp.

Blue Star Ltd.  
Sabri Complex II Floor  
24 Residency Rd.

BANGALORE 560 025  
Tel: 55660  
Telex: 0845-430  
Cable: BLUESTAR  
A,CH\*,CM,CS\*,E

Blue Star Ltd.  
Band Box House  
Prabhadevi

BOMBAY 400 025  
Tel: 422-3101  
Telex: 011-3751  
Cable: BLUESTAR  
A,M

Blue Star Ltd.  
Sahas  
414/2 Vir Savarkar Marg  
Prabhadevi

BOMBAY 400 025  
Tel: 422-6155  
Telex: 011-71193  
Cable: FROSTBLUE  
A,CH\*,CM,CS\*,E,M

Blue Star Ltd.  
Kalyan, 19 Vishwas Colony  
Alkapuri, BORODA, 390 005  
Tel: 65235

Cable: BLUE STAR  
A

Blue Star Ltd.  
7 Hare Street  
CALCUTTA 700 001

Tel: 12-01-31  
Telex: 021-7655  
Cable: BLUESTAR  
A,M

Blue Star Ltd.  
133 Kodambakkam High Road  
MADRAS 600 034

Tel: 82057  
Telex: 041-379  
Cable: BLUESTAR  
A,M

Blue Star Ltd.  
Bhandari House, 7th/8th Floors  
91 Nehru Place

NEW DELHI 110 024  
Tel: 682547  
Telex: 031-2463  
Cable: BLUESTAR  
A,CH\*,CM,CS\*,E,M

Blue Star Ltd.  
15/16:C Wellesley Rd.  
PUNE 411 011

Tel: 22775  
Cable: BLUE STAR  
A

Blue Star Ltd.  
2-2-47/1108 Bolarum Rd.  
SECUNDERABAD 500 003

Tel: 72057  
Telex: 0155-459  
Cable: BLUEFROST  
A,E

Blue Star Ltd.  
T.C. 7/603 Poornima  
Maruthankuzhi  
TRIVANDRUM 695 013

Tel: 65799  
Telex: 0884-259  
Cable: BLUESTAR  
E

Computer Maintenance Corporation Ltd.  
115, Sarojini Devi Road  
SECUNDERABAD 500 003  
Tel: 310-184, 345-774  
Telex: 031-2960  
CH\*\*

## INDONESIA

BERCA Indonesia P.T.  
P.O.Box 496/Jkt.  
Jl. Abdul Muis 62

JAKARTA  
Tel: 21-373009  
Telex: 46748 BERSAL IA  
Cable: BERSAL JAKARTA  
P

BERCA Indonesia P.T.  
P.O.Box 2497/Jkt.  
Antara Bldg., 17th Floor

Jl. Medan Merdeka Selatan 17  
JAKARTA-PUSAT  
Tel: 21-344-181  
Telex: BERSAL IA  
A,CS,E,M

BERCA Indonesia P.T.  
P.O. Box 174/SBY.  
Jl. Kutei No. 11

SURABAYA  
Tel: 68172  
Telex: 31146 BERSAL SB  
Cable: BERSAL-SURABAYA  
A\*,E,M,P

## IRAQ

Hewlett-Packard Trading S.A.  
Service Operation  
Al Mansoor City 9B/3/7

BAGHDAD  
Tel: 551-49-73  
Telex: 212-455 HEPAIRAQ IK  
CH,CS

## IRELAND

Hewlett-Packard Ireland Ltd.  
82/83 Lower Leeson Street  
DUBLIN 2

Tel: 0001 608800  
Telex: 30439  
A,CH,CM,CS,E,M,P

Cardiac Services Ltd.  
Kilmore Road  
Artane

DUBLIN 5  
Tel: (01) 351820  
Telex: 30439  
M

## ISRAEL

Eidan Electronic Instrument Ltd.  
P.O.Box 1270  
JERUSALEM 91000

16, Ohaliav St.  
JERUSALEM 94467  
Tel: 533 221, 553 242  
Telex: 25231 AB/PAKRD IL  
A,M

Computation and Measurement  
Systems (CMS) Ltd.  
11 Masad Street  
67060

TEL-AVIV  
Tel: 388 388  
Telex: 33569 Motil IL  
CH,CM,CS,E,P

## ITALY

Hewlett-Packard Italiana S.p.A  
Traversa 99C  
Via Giulio Petroni, 19

I-70124 BARI  
Tel: (080) 41-07-44  
M,CH

Hewlett-Packard Italiana S.p.A.  
Via Martin Luther King, 38/III  
I-40132 BOLOGNA

Tel: (051) 402394  
Telex: 511630  
CH,CS,E,M

Hewlett-Packard Italiana S.p.A.  
Via Principe Nicola 43G/C  
I-95126 CATANIA

Tel: (095) 37-10-87  
Telex: 970291  
CH

Hewlett-Packard Italiana S.p.A.  
Via G. Di Vittorio 9  
I-20063 CERNUSCO SUL

NAVIGLIO  
(Milano)  
Tel: (02) 923691

Telex: 334632  
A,CH,CM,CS,E,M,P

Hewlett-Packard Italiana S.p.A.  
Via C. Colombo 49  
I-20090 TREZZANO SUL

NAVIGLIO  
(Milano)  
Tel: (02) 4459041

Telex: 322116  
CH,CS

Hewlett-Packard Italiana S.p.A.  
Via Nuova San Rocco a  
Capodimonte, 62/A

I-80131 NAPOLI  
Tel: (081) 7413544  
Telex: 710698

A\*\*,CH,CS,E,M  
Hewlett-Packard Italiana S.p.A.

Viale G. Modugno 33  
I-16156 GENOVA PEGLI  
Tel: (010) 68-37-07

Telex: 215238  
E,C

Hewlett-Packard Italiana S.p.A.  
Via Peizzo 15  
I-35128 PADOVA

Tel: (049) 664888  
Telex: 430315  
A,CH,CS,E,M

Hewlett-Packard Italiana S.p.A.  
Viale C. Pavese 340  
I-00144 ROMA EUR

Tel: (06) 54831  
Telex: 610514  
A,CH,CS,E,M,P\*



# SALES & SUPPORT OFFICES

Arranged alphabetically by country

5



## ITALY (Cont'd)

Hewlett-Packard Italiana S.p.A.  
Via di Casellina 57/C  
I-50018 SCANDICCI-FIRENZE  
Tel: (055) 753863  
CH,E,M

Hewlett-Packard Italiana S.p.A.  
Corso Svizzera, 185  
I-10144 TORINO  
Tel: (011) 74 4044  
Telex: 221079  
A\*,CS,CH,E

## JAPAN

Yokogawa-Hewlett-Packard Ltd.  
152-1, Onna

ATSUGI, Kanagawa, 243  
Tel: (0462) 28-0451  
CM,C\*,E

Yokogawa-Hewlett-Packard Ltd.  
Meiji-Seimei Bldg. 6F  
3-1 Hon Chiba-Cho  
CHIBA, 280  
Tel: 472 25 7701  
E,CH,CS

Yokogawa-Hewlett-Packard Ltd.  
Yasuda-Seimei Hiroshima Bldg.  
6-11, Hon-dori, Naka-ku  
HIROSHIMA, 730  
Tel: 82-241-0611

Yokogawa-Hewlett-Packard Ltd.  
Towa Building  
2-3, Kaigan-dori, 2 Chome Chuo-ku  
KOBE, 650  
Tel: (078) 392-4791  
C,E

Yokogawa-Hewlett-Packard Ltd.  
Kumagaya Asahi 82 Bldg  
3-4 Tsukuba  
KUMAGAYA, Saitama 360  
Tel: (0485) 24-6563  
CH,CM,E

Yokogawa-Hewlett-Packard Ltd.  
Asahi Shinbun Daiichi Seimei Bldg.  
4-7, Hanabata-cho  
KUMAMOTO, 860  
Tel: (0963) 54-7311  
CH,E

Yokogawa-Hewlett-Packard Ltd.  
Shin-Kyoto Center Bldg.  
614, Higashi-Shiokoji-cho  
Karasuma-Nishiiru  
Shiokoji-dori, Shimogyo-ku  
KYOTO, 600  
Tel: 075-343-0921  
CH,E

Yokogawa-Hewlett-Packard Ltd.  
Mito Mitsui Bldg  
4-73, Sanno-maru, 1 Chome  
MITO, Ibaraki 310  
Tel: (0292) 25-7470  
CH,CM,E

Yokogawa-Hewlett-Packard Ltd.  
Meiji-Seimei Kokubun Bldg. 7-8  
Kokubun, 1 Chome, Sendai  
MIYAGI, 980  
Tel: (0222) 25-1011  
Telex:  
C,E

Yokogawa-Hewlett-Packard Ltd.  
Sumitomo Seimei 14-9 Bldg.  
Meieki-Minami, 2 Chome  
Nakamura-ku  
NAGOYA, 450  
Tel: (052) 571-5171  
CH,CM,CS,E,M

Yokogawa-Hewlett-Packard Ltd.  
Chuo Bldg.,  
4-20 Nishinakajima, 5 Chome  
Yodogawa-ku  
OSAKA, 532  
Tel: (06) 304-6021  
Telex: YHPOSA 523-3624  
A,CH,CM,CS,E,M,P\*

Yokogawa-Hewlett-Packard Ltd.  
27-15, Yabe, 1 Chome  
SAGAMIHARA Kanagawa, 229  
Tel: 0427 59-1311

Yokogawa-Hewlett-Packard Ltd.  
Daiichi Seimei Bldg.  
7-1, Nishi Shinjuku, 2 Chome  
Shinjuku-ku, TOKYO 160  
Tel: 03-348-4611  
CH,E

Yokogawa-Hewlett-Packard Ltd.  
29-21 Takaïdo-Higashi, 3 Chome  
Suginami-ku TOKYO 168  
Tel: (03) 331-6111  
Telex: 232-2024 YHPTOK  
A,CH,CM,CS,E,M,P\*

Yokogawa-Hewlett-Packard Ltd.  
Daiichi Asano Building  
2-8, Odori, 5 Chome  
UTSUNOMIYA, Tochigi 320  
Tel: (0286) 25-7155  
CH,CS,E

Yokogawa-Hewlett-Packard Ltd.  
Yasuda Seimei Nishiguchi Bldg.  
30-4 Tsuruya-cho, 3 Chome  
YOKOHAMA 221  
Tel: (045) 312-1252  
CH,CM,E

## JORDAN

Scientific and Medical Supplies Co.  
P.O. Box 1387

## AMMAN

Tel: 24907, 39907  
Telex: 21456 SABCO JO  
CH,E,M,P

## KENYA

ADCOM Ltd., Inc., Kenya  
P.O. Box 30070

## NAIROBI

Tel: 331955  
Telex: 22639  
E,M

## KOREA

Samsung Hewlett-Packard Co. Ltd.  
12 Fl. Kinam Bldg.  
San 75-31, Yeoksam-Dong  
Kangnam-Ku  
YEONGDONG P.O. Box 72  
SEOUL

Tel: 555-7555, 555-5447  
Telex: K27364 SAMSAN  
A,CH,CM,CS,E,M,P

## KUWAIT

Al-Khalidiya Trading & Contracting  
P.O. Box 830

## SAFAT

Tel: 424910, 411726  
Telex: 22481 AREEG KT  
Cable: VISCOUNT  
E,M,A

Photo & Cine Equipment  
P.O. Box 270

## SAFAT

Tel: 2445111  
Telex: 22247 MATIN KT  
Cable: MATIN KUWAIT  
P

W.J. Towell Computer Services  
P.O. Box 75

## SAFAT

Tel: 2462640/1  
Telex: 30336 TOWELL KT  
C

## LEBANON

Computer Information Systems  
P.O. Box 11-6274

## BEIRUT

Tel: 89 40 73  
Telex: 42309  
C,E,M,P

## LUXEMBOURG

Hewlett-Packard Belgium S.A./N.V.  
Blvd de la Woluwe, 100

Woluwedal

B-1200 BRUSSELS

Tel: (02) 762-32-00  
Telex: 23-494 paloben bru  
A,CH,CM,CS,E,M,P

## MALAYSIA

Hewlett-Packard Sales (Malaysia)  
Sdn. Bhd.  
1st Floor, Bangunan British  
American  
Jalan Semantan, Damansara Heights  
KUALA LUMPUR 23-03

Tel: 943022

Telex: MA31011  
A,CH,E,M,P\*

Protel Engineering

P.O. Box 1917  
Lot 6624, Section 64  
23/4 Pending Road  
Kuching, SARAWAK

Tel: 36299  
Telex: MA 70904 PROMAL  
Cable: PROTELENG  
A,E,M

## MALTA

Philip Toledo Ltd.  
Notabile Rd.

## MRIEHEL

Tel: 447 47, 455 66  
Telex: Media MW 649  
E,P,M

## MEXICO

Hewlett-Packard Mexicana, S.A.  
de C.V.

Av. Periferico Sur No. 6501  
Tepepan, Xochimilco  
16020 MEXICO D.F.  
Tel: 6-76-46-00  
Telex: 17-74-507 HEWPACK MEX  
A,CH,CS,E,M,P

Hewlett-Packard Mexicana, S.A.  
de C.V.

Czda. del Valle  
409 Ote. 1 °Piso  
Colonia del Valle  
Municipio de Garza García  
66220 MONTERREY, Nuevo LeAOn  
Tel: 78 42 41  
Telex: 038 410  
CH

Equipos Cientificos de Occidente, S.A.  
Av. Lazaro Cardenas 3540

## GUADALAJARA

Tel: 21-66-91  
Telex: 0684186 ECOMÉ  
A

Infograficas y Sistemas del Noreste, S.A.  
Rio Orinoco #171 Oriente

Despacho 2001

Colonia Del Valle

## MONTERREY

Tel: 782499, 781259A

A

## MOROCCO

Dolbeau

81 rue Karatchi

## CASABLANCA

Tel: 3041-82, 3068-38  
Telex: 23051, 22822  
E

Gerep

2 rue d'Agadir

Boite Postale 156

## CASABLANCA

Tel: 272093, 272095

Telex: 23 739

P

Sema-Maroc

Rue Lapebie

## CASABLANCA

Tel: 26.09.80

CH,CS,P

## NETHERLANDS

Hewlett-Packard Nederland B.V.

Van Heuven Goedhartlaan 121

NL 1181KK AMSTELVEEN

P.O. Box 667

NL 1180 AR AMSTELVEEN

Tel: (020) 47-20-21

Telex: 13 216 HEPAC NL

A,CH,CM,CS,E,M,P

Hewlett-Packard Nederland B.V.

Bongerd 2

NL 2906VK CAPELLE A/D IJSSEL

P.O. Box 41

NL 2900AA CAPELLE A/D IJSSEL

Tel: (10) 51-64-44

Telex: 21261 HEPAC NL

A,CH,CS,E

Hewlett-Packard Nederland B.V.

Pastoor Petersstraat 134-136

NL 5612 LV EINDHOVEN

P.O. Box 2342

NL 5600 CH EINDHOVEN

Tel: (040) 326911

Telex: 51484 hepae nl

A,CH\*\*,E,M

# SALES & SUPPORT OFFICES

Arranged alphabetically by country

## NEW ZEALAND

Hewlett-Packard (N.Z.) Ltd.  
5 Owens Road  
P.O. Box 26-189  
Epsom, **AUCKLAND**  
Tel: 687-159  
Cable: HEWPAK Auckland  
CH,CS,CM,E,P\*

Hewlett-Packard (N.Z.) Ltd.  
4-12 Cruickshank Street  
Kilbirnie, **WELLINGTON 3**  
P.O. Box 9443  
Courtenay Place, **WELLINGTON 3**  
Tel: 877-199  
Cable: HEWPAK Wellington  
CH,CS,CM,E,P

Northrop Instruments & Systems Ltd.  
369 Khyber Pass Road  
P.O. Box 8602  
**AUCKLAND**

Tel: 794-091  
Telex: 60605  
A,M

Northrop Instruments & Systems Ltd.  
110 Mandeville St.  
P.O. Box 8388

## CHRISTCHURCH

Tel: 488-873  
Telex: 4203  
A,M

Northrop Instruments & Systems Ltd.

Sturdee House  
85-87 Ghuznee Street  
P.O. Box 2406

## WELLINGTON

Tel: 850-091  
Telex: NZ 3380  
A,M

## NORTHERN IRELAND

See United Kingdom

## NORWAY

Hewlett-Packard Norge A/S  
Folke Bernadottes vei 50  
P.O. Box 3558  
N-5033 FYLLINGSDALEN (Bergen)  
Tel: 0047/5/16 55 40  
Telex: 16621 hpnas n  
CH,CS,E,M

Hewlett-Packard Norge A/S  
UCOsterndalen 16-18  
P.O. Box 34

## N-1345 OCUSTERÅS

Tel: 0047/2/17 11 80  
Telex: 16621 hpnas n  
A,CH,CM,CS,E,M,P

## OMAN

Khimijil Ramdas  
P.O. Box 19

## MUSCAT

Tel: 722225, 745601  
Telex: 3289 BROKER MB MUSCAT  
P

Suhail & Saud Bahwan  
P.O. Box 169

## MUSCAT

Tel: 734 201-3  
Telex: 3274 BAHWAN MB  
E

## Imtac LLC

P.O. Box 8676  
**MUTRAH**  
Tel: 601695  
Telex: 5741 Tawoos On  
A,C,M

## PAKISTAN

Mushko & Company Ltd.  
House No. 16, Street No. 16  
Sector F-6/3

## ISLAMABAD

Tel: 824545  
Cable: FEMUS Islamabad  
A,E,M,P\*

Mushko & Company Ltd.  
Oosman Chambers

Abdullah Haroon Road  
**KARACHI 0302**

Tel: 524131, 524132  
Telex: 2894 MUSKO PK  
Cable: COOPERATOR Karachi  
A,E,M,P\*

## PANAMA

ElectrOnico Balboa, S.A.  
Calle Samuel Lewis, Ed. Alfa  
Apartado 4929

## PANAMA 5

Tel: 63-6613, 63-6748  
Telex: 3483 ELECTRON PG  
A,CM,E,M,P

## PERU

Cia Electro Médica S.A.  
Los Flamencos 145, San Isidro  
Casilla 1030

## LIMA 1

Tel: 41-4325, 41-3703  
Telex: Pub. Booth 25306  
CM,E,M,P

## SAMS

Rio De La Plata 305

## SAN ISIDRO

Tel: 419928  
Telex: 394 20450 PELIBERTAD  
P

## PHILIPPINES

The Online Advanced Systems  
Corporation  
Rico House, Amorsolo Cor. Herrera  
Street

Legaspi Village, Makati

P.O. Box 1510

## Metro MANILA

Tel: 815-38-11 (up to 16)  
Telex: 63274 Online PN  
A,CH,CS,E,M

Electronic Specialists and  
Proponents Inc.

690-B Epifanio de los Santos

Avenue

## Cubao, QUEZON CITY

P.O. Box 2649 Manila

Tel: 98-96-81, 98-96-82, 98-96-83

Telex: 40018, 42000 ITT GLOBE MAC-  
KAY BOOTH  
P

## PORTUGAL

Mundinter  
Intercambio Mundial de ComAercio  
S.A.R.L.

P.O. Box 2761  
Av. Antonio Augusto de Aguiar 138  
**P-LISBON**

Tel: (19) 53-21-31, 53-21-37

Telex: 16691 munter p

## M

## Soquimica

Av. da Liberdade, 220-2

1298 LISBOA Codex

Tel: 56 21 81/2/3

Telex: 13316 SABASA

## P

Telectra-Empresa Técnica de

Equipmentos Eléctricos S.A.R.L.

Rua Rodrigo da Fonseca 103

P.O. Box 2531

## P-LISBON 1

Tel: (19) 68-60-72

Telex: 12598

## CM,E

## Rarcentro Ltda

R. Costa Cabral 575

4200 PORTO

Tel: 499174/495173

Telex: 26054

## CH,CS

## PUERTO RICO

Hewlett-Packard Puerto Rico

101 MuAnoz Rivera Av

Esu. Calle Ochoa

HATO REY, Puerto Rico 00918

Tel: (809) 754-7800

A,CH,CS,CM,M,E,P

## QATAR

Computer Arabia

P.O. Box 2750

## DOHA

Tel: 883555

Telex: 4806 CHPARB

## P

Nasser Trading & Contracting

P.O. Box 1563

## DOHA

Tel: 422170

Telex: 4439 NASSER DH

## M

## SAUDI ARABIA

Modern Electronic Establishment

Hewlett-Packard Division

P.O. Box 281

Thuobah

## AL-KHOBAR

Tel: 895-1760, 895-1764

Telex: 671 106 HPMEEK SJ

Cable: ELECTA AL-KHOBAR

CH,CS,E,M

Modern Electronic Establishment

Hewlett-Packard Division

P.O. Box 1228

Redec Plaza, 6th Floor

## JEDDAH

Tel: 644 38 48

Telex: 4027 12 FARNAS SJ

Cable: ELECTA JEDDAH

A,CH,CS,CM,E,M,P

## Modern Electronic Establishment

Hewlett-Packard Division

P.O. Box 22015

## RIYADH

Tel: 491-97 15, 491-63 87

Telex: 202049 MEERYD SJ

CH,CS,E,M

Abdul Ghani El Ajou

P.O. Box 78

## RIYADH

Tel: 40 41 717

Telex: 200 932 EL AJOU

## P

## SCOTLAND

See United Kingdom

## SINGAPORE

Hewlett-Packard Singapore (Sales)

Pte. Ltd.

#08-00 Inchcape House

450-2 Alexandra Road

P.O. Box 58 Alexandra Rd. Post

Office

**SINGAPORE, 9115**

Tel: 631788

Telex: HPSGSO RS 34209

Cable: HEWPAK, Singapore

A,CH,CS,E,MS,P

Dynamar International Ltd.

Unit 05-11Block 6

Kolam Ayer Industrial Estate

**SINGAPORE 1334**

Tel: 747-6188

Telex: RS 26283

## CM

## SOUTH AFRICA

Hewlett-Packard So Africa (Pty.) Ltd.

P.O. Box 120

Howard Place **CAPE PROVINCE 7450**

Pine Park Center, Forest Drive, Pine-

lands

**CAPE PROVINCE 7405**

Tel: 53-7954

Telex: 57-20006

A,CH,CM,E,M,P

Hewlett-Packard So Africa (Pty.) Ltd.

P.O. Box 37099

Overport Drive 92

**DURBAN 4067**

Tel: 28-4178

Telex: 6-22954

CH,CM

Hewlett-Packard So Africa (Pty.) Ltd.

6 Linton Arcade

511 Cape Road

Linton Grange

**PORT ELIZABETH 6001**

Tel: 041-301201

CH

Hewlett-Packard So Africa (Pty.) Ltd.

Fountain Center

Kalkden Str.

Monument Park

Ext 2

**PRETORIA 0105**

Tel: 45-5723

Telex: 32163

CH,E



# SALES & SUPPORT OFFICES

Arranged alphabetically by country



## **SOUTH AFRICA (Cont'd)**

Hewlett-Packard So Africa (Pty.) Ltd.  
Private Bag Wendywood  
SANDTON 2144  
Tel: 802-5111, 802-5125  
Telex: 4-20877  
Cable: HEWPACK Johannesburg  
A,CH,CM,CS,E,M,P

## **SPAIN**

Hewlett-Packard Española S.A.  
Calle Entenza, 321  
E-BARCELONA 29  
Tel: 322.24.51, 321.73.54  
Telex: 52603 hpbee  
A,CH,CS,E,M,P

Hewlett-Packard Española S.A.  
Calle San Vicente S/No  
Edificio Albia II 7B  
E-BILBAO 1  
Tel: 423.83.06  
A,CH,E,M

Hewlett-Packard Española S.A.  
C/ta. de la Coruña, Km. 16, 400  
Las Rozas  
E-MADRID  
Tel: (1) 637.00.11  
Telex: 23515 HPE  
CH,CS,M

Hewlett-Packard Española S.A.  
Avda. S. Francisco Javier, S/No  
Planta 10. Edificio Sevilla 2,  
E-SEVILLA 5  
Tel: 64.44.54  
Telex: 72933  
A,CS,M,P

Hewlett-Packard Española S.A.  
C/Isabel La Católica, 8  
E-46004 VALENCIA  
Tel: 0034/6/351 59 44  
CH,P

## **SWEDEN**

Hewlett-Packard Sverige AB  
Sunnanvagen 14K  
S-22226 LUND  
Tel: (046) 13-69-79  
Telex: (854) 17886 (via Spånga  
office)  
CH

Hewlett-Packard Sverige AB  
Östra Tullgatan 3  
S-21128 MALMÖ  
Tel: (040) 70270  
Telex: (854) 17886 (via Spånga  
office)

Hewlett-Packard Sverige AB  
Västra Vintergatan 9  
S-70344 ÖREBRO  
Tel: (19) 10-48-80  
Telex: (854) 17886 (via Spånga  
office)  
CH

Hewlett-Packard Sverige AB  
Skalholtsgatan 9, Kista  
Box 19  
S-16393 SPÅNGA  
Tel: (08) 750-2000  
Telex: (854) 17886  
Telefax: (08) 7527781  
A,CH,CM,CS,E,M,P

Hewlett-Packard Sverige AB  
Frötällsgatan 30  
S-42132 VÄSTRA-FRÖLUNDA  
Tel: (031) 49-09-50  
Telex: (854) 17886 (via Spånga  
office)  
CH,E,P

## **SWITZERLAND**

Hewlett-Packard (Schweiz) AG  
Clarastrasse 12  
CH-4058 BASEL  
Tel: (61) 33-59-20  
A

Hewlett-Packard (Schweiz) AG  
7, rue du Bois-du-Lan  
Case Postale 365  
CH-1217 MEYRIN 2  
Tel: (0041) 22-83-11-11  
Telex: 27333 HPAG CH  
CH,CM,CS

Hewlett-Packard (Schweiz) AG  
Allmend 2  
CH-8967 WIDEN  
Tel: (0041) 57 31 21 11  
Telex: 53933 hpag ch  
Cable: HPAG CH  
A,CH,CM,CS,E,M,P

## **SYRIA**

General Electronic Inc.  
Nuri Basha Ahnaf Ebn Kays Street  
P.O. Box 5781

**DAMASCUS**  
Tel: 33-24-87  
Telex: 411 215  
Cable: ELECTROBOR DAMASCUS  
E

Middle East Electronics  
P.O. Box 2308  
Abu Rummaneh

## **DAMASCUS**

Tel: 33 45 92  
Telex: 411 304  
M

## **TAIWAN**

Hewlett-Packard Taiwan  
Kaohsiung Office  
11/F 456, Chung Hsiao 1st Road  
**KAOHSIUNG**  
Tel: (07) 2412318  
CH,CS,E

Hewlett-Packard Taiwan  
8th Floor Hewlett-Packard Building  
337 Fu Hsing North Road

## **TAIPEI**

Tel: (02) 712-0404  
Telex: 24439 HEWPACK  
Cable: HEWPACK Taipei  
A,CH,CM,CS,E,M,P

Ing Lih Trading Co.  
3rd Floor, 7 Jen-Ai Road, Sec. 2

## **TAIPEI 100**

Tel: (02) 3948191  
Cable: INGLIH TAIPEI  
A

## **THAILAND**

Unimesa  
30 Patpong Ave., Suriwong  
**BANGKOK 5**  
Tel: 235-5727  
Telex: 84439 Simonco TH  
Cable: UNIMESA Bangkok  
A,CH,CS,E,M

Bangkok Business Equipment Ltd.  
5/5-6 Dejo Road  
**BANGKOK**  
Tel: 234-8670, 234-8671  
Telex: 87669-BEQUIPT TH  
Cable: BUSIQUIPT Bangkok  
P

## **TOGO**

Societe Africaine De  
Promotion  
B.P. 12271

## **LOME**

Tel: 21-62-88  
Telex: 5304  
P

## **TRINIDAD & TOBAGO**

Caribbean Telecoms Ltd.  
Corner McAllister Street &  
Eastern Main Road, Laventille  
P.O. Box 732

## **PORT-OF-SPAIN**

Tel: 624-4213  
Telex: 22561 CARTEL WG  
Cable: CARTEL, PORT OF SPAIN  
CM,E,M,P

Computer and Controls Ltd.  
P.O. Box 51  
66 Independence Square

## **PORT-OF-SPAIN**

Tel: 623-4472  
Telex: 3000 POSTLX WG  
P

## **TUNISIA**

Tunisie Electronique  
31 Avenue de la Liberte  
**TUNIS**  
Tel: 280-144  
CH,CS,E,P

Corema  
1 ter. Av. de Carthage

## **TUNIS**

Tel: 253-821  
Telex: 12319 CABAM TN  
M

## **TURKEY**

E.M.A  
Mediha Eldem Sokak No. 41/6  
Yenisehir

## **ANKARA**

Tel: 319175  
Telex: 42321 KTX TR  
Cable: EMATRADE ANKARA  
M

Kurt & Kurt A.S.  
Mithatpasa Caddesi No. 75  
Kat 4 Kizilay

## **ANKARA**

Tel: 318875/6/7/8  
Telex: 42490 MESR TR  
A

Saniva Bilgisayar Sistemleri A.S.  
Buyukdere Caddesi 103/6  
Gayrettepe  
**ISTANBUL**  
Tel: 1673180  
Telex: 26345 SANI TR  
C,P

Teknim Company Ltd.  
Iran Caddesi No. 7  
Kavaklidere  
**ANKARA**  
Tel: 275800  
Telex: 42155 TKNM TR  
E,CM

## **UNITED ARAB EMIRATES**

Emitac Ltd.  
P.O. Box 1641  
**SHARJAH,**  
Tel: 591181  
Telex: 68136 EMITAC EM  
Cable: EMITACH SHARJAH  
E,C,M,P,A

Emitac Ltd.  
P.O. Box 2711

**ABU DHABI,**  
Tel: 820419-20  
Cable: EMITACH ABUDHABI

Emitac Ltd.  
P.O. Box 8391

**DUBAI,**  
Tel: 377951

Emitac Ltd.  
P.O. Box 473  
**RAS AL KHAIMAH,**  
Tel: 28133, 21270

## **UNITED KINGDOM**

### **GREAT BRITAIN**

Hewlett-Packard Ltd.  
Trafalgar House  
Navigation Road  
**ALTRINCHAM**  
Cheshire WA14 1NU  
Tel: 061 928 6422  
Telex: 668068  
A,CH,CS,E,M,M,P

Hewlett-Packard Ltd.  
Miller House  
The Ring, **BRACKNELL**  
Berks RG12 1XN  
Tel: 44344 424898  
Telex: 848733  
E

Hewlett-Packard Ltd.  
Elstree House, Elstree Way  
**BOREHAMWOOD,** Herts WD6 1SG  
Tel: 01 207 5000  
Telex: 8952716  
E,CH,CS,P

Hewlett-Packard Ltd.  
Oakfield House, Oakfield Grove  
Clifton **BRISTOL,** Avon BS8 2BN  
Tel: 0272 736806  
Telex: 444302  
CH,CS,E,P



# SALES & SUPPORT OFFICES

Arranged alphabetically by country

## GREAT BRITAIN (Cont'd)

Hewlett-Packard Ltd.  
Bridewell House  
Bridewell Place  
LONDON EC4V 6BS  
Tel: 01 583 6565  
Telex: 298163  
CH,CS,P

Hewlett-Packard Ltd.  
Fourier House  
257-263 High Street  
LONDON COLNEY  
Herts. AL2 1HA, St. Albans  
Tel: 0727 24400  
Telex: 1-8952716  
CH,CS

Hewlett-Packard Ltd.  
Pontefract Road  
NORMANTON, West Yorkshire WF6 1RN  
Tel: 0924 895566  
Telex: 557355  
CH,CS,P

Hewlett-Packard Ltd.  
The Quadrangle  
106-118 Station Road  
REDHILL, Surrey RH1 1PS  
Tel: 0737 68655  
Telex: 947234  
CH,CS,E,P

Hewlett-Packard Ltd.  
Avon House  
435 Stratford Road  
Shirley, SOLIHULL, West Midlands  
B90 4BL  
Tel: 021 745 8800  
Telex: 339105  
CH,CS,E,P

Hewlett-Packard Ltd.  
West End House  
41 High Street, West End  
SOUTHAMPTON  
Hampshire SO3 3DQ  
Tel: 04218 6767  
Telex: 477138  
CH,CS,P

Hewlett-Packard Ltd.  
King Street Lane  
Winnersh, WOKINGHAM  
Berkshire RG11 5AR  
Tel: 0734 784774  
Telex: 847178  
A,CH,CS,E,M,P

Hewlett-Packard Ltd.  
Nine Mile Ride  
Easthampstead, WOKINGHAM  
Berkshire, RG11 3LL  
Tel: 0344 773100  
Telex: 848805  
CH,CS,E,P

## IRELAND

### NORTHERN IRELAND

Hewlett-Packard Ltd.  
Cardiac Services Building  
95A Finaghy Road South  
BELFAST BT10 0BY  
Tel: 0232 625-566  
Telex: 747626  
CH,CS

## SCOTLAND

Hewlett-Packard Ltd.  
SOUTH QUEENSFERRY  
West Lothian, EH30 9TG  
Tel: 031 331 1188  
Telex: 72682  
CH,CM,CS,E,M,P

## UNITED STATES

### Alabama

Hewlett-Packard Co.  
700 Century Park South, Suite 128  
BIRMINGHAM, AL 35226  
Tel: (205) 822-6802  
C,CH,CS,P\*  
Hewlett-Packard Co.  
420 Wynn Drive  
P.O. Box 7700  
HUNTSVILLE, AL 35807  
Tel: (205) 830-2000  
C,CH,CM,CS,E,M\*

### Alaska

Hewlett-Packard Co.  
3601 C St., Suite 1234  
ANCHORAGE, AK 99503  
Tel: (907) 563-8855  
CH,CS,E

### Arizona

Hewlett-Packard Co.  
8080 Pointe Parkway West  
PHOENIX, AZ 85044  
Tel: (602) 273-8000  
A,CH,CM,CS,E,M

Hewlett-Packard Co.  
2424 East Aragon Road  
TUCSON, AZ 85706  
Tel: (602) 573-7400  
CH,E,M\*\*

### California

Hewlett-Packard Co.  
99 South Hill Dr.  
BRISBANE, CA 94005  
Tel: (415) 330-2500  
CH,CS

Hewlett-Packard Co.  
P.O. Box 7830 (93747)  
5060 E. Clinton Avenue, Suite 102  
FRESNO, CA 93727  
Tel: (209) 252-9652  
CH,CS,M

Hewlett-Packard Co.  
1421 S. Manhattan Av.  
FULLERTON, CA 92631  
Tel: (714) 999-6700  
CH,CM,CS,E,M  
Hewlett-Packard Co.  
320 S. Kellogg, Suite B  
GOLETA, CA 93117  
Tel: (805) 967-3405  
CH

Hewlett-Packard Co.  
5400 W. Rosecrans Blvd.  
LAWDALE, CA 90260  
P.O. Box 92105  
LOS ANGELES, CA 90009  
Tel: (213) 643-7500  
Telex: 910-325-6608  
CH,CM,CS,M

Hewlett-Packard Co.  
3155 Porter Drive  
PALO ALTO, CA 94304  
Tel: (415) 857-8000  
CH,CS,E  
Hewlett-Packard Co.  
4244 So. Market Court, Suite A  
P.O. Box 15976  
SACRAMENTO, CA 95813  
Tel: (916) 929-7222  
A\*,CH,CS,E,M

Hewlett-Packard Co.  
9606 Aero Drive  
P.O. Box 23333  
SAN DIEGO, CA 92123  
Tel: (619) 279-3200  
CH,CM,CS,E,M

Hewlett-Packard Co.  
2305 Camino Ramon 'C'  
SAN RAMON, CA 94583  
Tel: (415) 838-5900  
CH,CS

Hewlett-Packard Co.  
3005 Scott Boulevard  
SANTA CLARA, CA 95050  
Tel: (408) 988-7000  
Telex: 910-338-0586  
A,CH,CM,CS,E,M

Hewlett-Packard Co.  
5703 Corsa Avenue  
WESTLAKE VILLAGE, CA 91362  
Tel: (213) 706-6800  
E\*,CH\*,CS\*

### Colorado

Hewlett-Packard Co.  
24 Inverness Place, East  
ENGLEWOOD, CO 80112  
Tel: (303) 649-5000  
A,CH,CM,CS,E,M

### Connecticut

*Eff. Dec. 1, 1984*  
Hewlett-Packard Co.  
500 Sylvan Av.  
BRIDGEPORT, CT 06606  
Tel: (203) 371-6454  
CH,CS,E

Hewlett-Packard Co.  
47 Barnes Industrial Road South  
P.O. Box 5007  
WALLINGFORD, CT 06492  
Tel: (203) 265-7801  
A,CH,CM,CS,E,M

### Florida

Hewlett-Packard Co.  
2901 N.W. 62nd Street  
P.O. Box 24210  
FORT LAUDERDALE, FL 33307  
Tel: (305) 973-2600  
CH,CS,E,M,P\*

Hewlett-Packard Co.  
4080 Woodcock Drive, Suite 132  
JACKSONVILLE, FL 32207  
Tel: (904) 398-0663  
C\*,CH\*,M\*\*

Hewlett-Packard Co.  
6177 Lake Ellenor Drive  
P.O. Box 13910  
ORLANDO, FL 32859  
Tel: (305) 859-2900  
A,C,CH,CM,CS,E,P\*

Hewlett-Packard Co.  
4700 Bayoue Blvd.  
Building 5  
PENSACOLA, FL 32505  
Tel: (904) 476-8422  
A,C,CH,CM,CS,M

Hewlett-Packard Co.  
5550 Idlewild, #150  
P.O. Box 15200  
TAMPA, FL 33684  
Tel: (813) 884-3282  
A\*,C,CH,CS,E\*,M\*,P\*

### Georgia

Hewlett-Packard Co.  
2000 South Park Place  
P.O. Box 105005  
ATLANTA, GA 30348  
Tel: (404) 955-1500  
Telex: 810-766-4890  
A,C,CH,CM,CS,E,M,P\*

### Illinois

Hewlett-Packard Co.  
304 Eldorado Road  
P.O. Box 1607  
BLOOMINGTON, IL 61701  
Tel: (309) 662-9411  
CH,M\*\*

Hewlett-Packard Co.  
525 W. Monroe, #1300  
CHICAGO, IL 60606  
Tel: (312) 930-0010  
CH,CS

Hewlett-Packard Co.  
1200 Diehl  
NAPEVILLE, IL 60566  
Tel: (312) 357-8800  
CH\*,CS

Hewlett-Packard Co.  
5201 Toltview Drive  
ROLLING MEADOWS, IL 60008  
Tel: (312) 255-9800  
Telex: 910-687-1066  
A,CH,CM,CS,E,M

### Indiana

Hewlett-Packard Co.  
11911 N. Meridian St.  
CARMEL, IN 46032  
Tel: (317) 844-4100  
A,CH,CM,CS,E,M

### Iowa

Hewlett-Packard Co.  
4070 22nd Av. SW  
CEDAR RAPIDS, IA 52404  
Tel: (319) 390-4250  
CH,CS,E,M



# SALES & SUPPORT OFFICES

Arranged alphabetically by country

9



## UNITED STATES (Cont'd)

Hewlett-Packard Co.  
4201 Corporate Dr.  
**WEST DES MOINES, IA 50265**  
Tel: (515) 224-1435  
A\*\*,CH,M\*\*

**Kentucky**  
Hewlett-Packard Co.  
10300 Linn Station Road, #100  
**LOUISVILLE, KY 40223**  
Tel: (502) 426-0100  
A,CH,CS,M

**Louisiana**  
Hewlett-Packard Co.  
160 James Drive East  
**ST. ROSE, LA 70087**  
P.O. Box 1449  
**KENNER, LA 70063**  
Tel: (504) 467-4100  
A,C,CH,E,M,P\*

**Maryland**  
Hewlett-Packard Co.  
3701 Koppers Street  
**BALTIMORE, MD 21227**  
Tel: (301) 644-5800  
Telex: 7 10-862-1943  
A,CH,CM,CS,E,M

Hewlett-Packard Co.  
2 Choke Cherry Road  
**ROCKVILLE, MD 20850**  
Tel: (301) 948-6370  
A,CH,CM,CS,E,M

**Massachusetts**  
Hewlett-Packard Co.  
1775 Minuteman Road  
**ANDOVER, MA 01810**  
Tel: (617) 682-1500  
A,C,CH,CS,CM,E,M,P\*  
Hewlett-Packard Co.  
32 Hartwell Avenue  
**LEXINGTON, MA 02173**  
Tel: (617) 861-8960  
CH,CS,E

**Michigan**  
Hewlett-Packard Co.  
4326 Cascade Road S.E.  
**GRAND RAPIDS, MI 49506**  
Tel: (616) 957-1970  
CH,CS,M

Hewlett-Packard Co.  
39550 Orchard Hill Place Drive  
**NOVI, MI 48050**  
Tel: (313) 349-9200  
A,CH,CS,E,M  
Hewlett-Packard Co.  
1771 W. Big Beaver Road  
**TROY, MI 48084**  
Tel: (313) 643-6474  
CH,CS

**Minnesota**  
Hewlett-Packard Co.  
2025 W. Larpenture Ave.  
**ST. PAUL, MN 55113**  
Tel: (612) 644-1100  
A,CH,CM,CS,E,M

**Missouri**  
Hewlett-Packard Co.  
1001 E. 101st Terrace  
**KANSAS CITY, MO 64131**  
Tel: (816) 941-0411  
A,CH,CM,CS,E,M  
Hewlett-Packard Co.  
13001 Hollenberg Drive  
**BRIDGETON, MO 63044**  
Tel: (314) 344-5100  
A,CH,CS,E,M

**Nebraska**  
Hewlett-Packard  
10824 Old Mill Rd., Suite 3  
**OMAHA, NE 68154**  
Tel: (402) 334-1813  
CM,M

**New Jersey**  
Hewlett-Packard Co.  
120 W. Century Road  
**PARAMUS, NJ 07652**  
Tel: (201) 265-5000  
A,CH,CM,CS,E,M  
Hewlett-Packard Co.  
20 New England Av. West  
**PISCATAWAY, NJ 08854**  
Tel: (201) 981-1199  
A,CH,CM,CS,E

**New Mexico**  
Hewlett-Packard Co.  
11300 Lomas Blvd., N.E.  
P.O. Box 11634  
**ALBUQUERQUE, NM 87112**  
Tel: (505) 292-1330  
CH,CS,E,M

**New York**  
Hewlett-Packard Co.  
5 Computer Drive South  
**ALBANY, NY 12205**  
Tel: (518) 458-1550  
A,CH,E,M  
Hewlett-Packard Co.  
9600 Main Street  
P.O. Box AC  
**CLARENCE, NY 14031**  
Tel: (716) 759-8621  
CH,CS,E

Hewlett-Packard Co.  
200 Cross Keys Office Park  
**FAIRPORT, NY 14450**  
Tel: (716) 223-9950  
A,CH,CM,CS,E,M  
Hewlett-Packard Co.  
7641 Henry Clay Blvd.  
**LIVERPOOL, NY 13088**  
Tel: (315) 451-1820  
A,CH,CM,CS,E,M

Hewlett-Packard Co.  
No. 1 Pennsylvania Plaza  
55th Floor  
34th Street & 8th Avenue  
**MANHATTAN NY 10119**  
Tel: (212) 971-0800  
CH,CS,M\*  
Hewlett-Packard Co.  
15 Myers Corner Rd.  
**WAPPINGER FALLS, NY 12590**  
CM,E

Hewlett-Packard Co.  
250 Westchester Avenue  
**WHITE PLAINS, NY 10604**  
Tel: (914) 684-6100  
CM,CH,CS,E

Hewlett-Packard Co.  
3 Crossways Park West  
**WOODBURY, NY 11797**  
Tel: (516) 921-0300  
A,CH,CM,CS,E,M

**North Carolina**  
Hewlett-Packard Co.  
305 Gregson Dr.  
**CARY, NC 27511**  
Tel: (919) 467-6600  
C,CH,CM,CS,E,M,P\*  
Hewlett-Packard Co.  
9600-H Southern Pine Blvd.  
**CHARLOTTE, NC 28210**  
Tel: (704) 527-8780  
CH\*,CS\*

Hewlett-Packard Co.  
5605 Roanne Way  
P.O. Box 26500  
**GREENSBORO, NC 27420**  
Tel: (919) 852-1800  
A,C,CH,CM,CS,E,M,P\*

**Ohio**  
Hewlett-Packard Co.  
9920 Carver Road  
**CINCINNATI, OH 45242**  
Tel: (513) 891-9870  
CH,CS,M

Hewlett-Packard Co.  
16500 Sprague Road  
**CLEVELAND, OH 44130**  
Tel: (216) 243-7300  
A,CH,CM,CS,E,M  
Hewlett-Packard Co.  
980 Springboro Pike  
**MIAMISBURG, OH 45343**  
Tel: (513) 859-8202  
A,CH,CM,E\*,M  
Hewlett-Packard Co.  
675 Brooksedge Blvd.  
**WESTERVILLE, OH 43081**  
Tel: (614) 436-1041  
CH,CM,CS,E\*

**Oklahoma**  
Hewlett-Packard Co.  
304 N. Meridian, Suite A  
P.O. Box 75609  
**OKLAHOMA CITY, OK 73147**  
Tel: (405) 946-9499  
C,CH,CS,E\*,M  
Hewlett-Packard Co.  
3840 S. 103rd E. Ave., #100  
P.O. Box 35747  
**TULSA, OK 74153**  
Tel: (918) 665-3300  
A\*\*,C,CH,CS,M\*,E,P\*

**Oregon**  
Hewlett-Packard Co.  
9255 S. W. Pioneer Court  
P.O. Box 328  
**WILSONVILLE, OR 97070**  
Tel: (503) 682-8000  
A,CH,CS,E\*,M

**Pennsylvania**  
Hewlett-Packard Co.  
50 Dorchester Rd.  
P.O. Box 6080  
**HARRISBURG, PA 17111**  
Tel: (717) 657-5900  
C

Hewlett-Packard Co.  
111 Zeta Drive  
**PITTSBURGH, PA 15238**  
Tel: (412) 782-0400  
A,CH,CS,E,M  
Hewlett-Packard Co.  
2750 Monroe Boulevard  
P.O. Box 713  
**VALLEY FORGE, PA 19482**  
Tel: (215) 666-9000  
A,CH,CM,CS,E,M

**South Carolina**  
Hewlett-Packard Co.  
Brookside Park, Suite 122  
1 Harbison Way  
P.O. Box 21708  
**COLUMBIA, SC 29221**  
Tel: (803) 732-0400  
A,C,CH,CS,M  
Hewlett-Packard Co.  
100 Executive Cntr. Dr.  
Koger Executive Center  
Chesterfield Bldg., Suite 124  
**GREENVILLE, SC 29615**  
Tel: (803) 297-4120  
C

**Tennessee**  
Hewlett-Packard Co.  
One Energy Centr. #200  
Pellissippi Pkwy.  
P.O. Box 22490  
**KNOXVILLE, TN 37933**  
Tel: (615) 966-4747  
A,C,CH,CS,M

Hewlett-Packard Co.  
3070 Directors Row  
**MEMPHIS, TN 38131**  
Tel: (901) 346-8370  
A,C,M  
Hewlett-Packard Co.  
220 Great Circle Road, Suite 116  
**NASHVILLE, TN 37228**  
Tel: (615) 255-1271  
C,M,P\*

**Texas**  
Hewlett-Packard Co.  
11002-B Metric Boulevard  
**AUSTIN, TX 78758**  
Tel: (512) 835-6771  
C,CM,E,P\*  
Hewlett-Packard Co.  
5700 Cromo Dr  
P.O. Box 12903  
**EL PASO, TX 79913**  
Tel: (915) 833-4400  
CH,E\*,M\*\*



# SALES & SUPPORT OFFICES

Arranged alphabetically by country

## UNITED STATES (Cont'd)

Hewlett-Packard Co.  
3952 Sand Shell St  
**FORT WORTH, TX 76137**  
Tel: (817) 232-9500  
A,C,CH,E,M

Hewlett-Packard Co.  
10535 Harwin Drive  
P.O. Box 42816  
**HOUSTON, TX 77042**  
Tel: (713) 776-6400  
A,C,CH,CS,E,M,P\*

Hewlett-Packard Co.  
511 W. John W. Carpenter Fwy.  
Royal Tech. Center #100  
**IRVINE, TX 75062**  
Tel: (214) 556-1950  
C,CH,CS,E

Hewlett-Packard Co.  
930 E. Campbell Rd.  
P.O. Box 83/1270  
**RICHARDSON, TX 75083-1270**  
Tel: (214) 231-6101  
A,CH,CM,CS,E,M,P\*

Hewlett-Packard Co.  
1020 Central Parkway South  
P.O. Box 32993  
**SAN ANTONIO, TX 78232**  
Tel: (512) 494-9336  
A,C,CH,CS,E,M,P\*

### Utah

Hewlett-Packard Co.  
3530 W. 2100 South  
P.O. Box 26626  
**SALT LAKE CITY, UT 84126**  
Tel: (801) 974-1700  
A,CH,CS,E,M

### Virginia

Hewlett-Packard Co.  
4305 Cox Road  
**GLEN ALLEN, VA 23060**  
P.O. Box 9669  
**RICHMOND, VA 23228**  
Tel: (804) 747-7750  
A,C,CH,CS,E,M,P\*

### Washington

Hewlett-Packard Co.  
15815 S.E. 37th Street  
**BELLEVUE, WA 98006**  
Tel: (206) 643-4000  
A,CH,CM,CS,E,M

Hewlett-Packard Co.  
708 North Argonne Road  
P.O. Box 3808  
**SPOKANE, WA 99220-3808**  
Tel: (509) 922-7000  
CH,CS

### West Virginia

Hewlett-Packard Co.  
4604 MacCorkle Ave.  
**CHARLESTON, WV 25304**  
Tel: (304) 925-0492  
A,M

### Wisconsin

Hewlett-Packard Co.  
275 N. Corporate Dr.  
**BROOKFIELD, WI 53005**  
Tel: (414) 784-8800  
A,CH,CS,E\*,M

### URUGUAY

*Pablo Ferrando S.A.C. e I.*  
*Avenida Italia 2877*  
*Casilla de Correo 370*  
**MONTEVIDEO**  
*Tel: 80-2586*  
*Telex: Public Booth 901*  
A,CM,E,M

*Mini Computadores, Ltda.*  
*Avda. del Libertador Brig*  
*Gral Lavalleja 2071*  
*Local 007*  
**MONTEVIDEO**  
*Tel: 29-55-22*  
*Telex: 901 P BOOTH UY*  
P

*Olympia de Uruguay S.A.*  
*Maquinas de Oficina*  
*Avda. del Libertador 1997*  
*Casilla de Correos 6644*  
**MONTEVIDEO**  
*Tel: 91-1809, 98.-3807*  
*Telex: 6342 OROU UY*  
P

## VENEZUELA

Hewlett-Packard de Venezuela C.A.  
3RA Transversal Los Ruices Norte  
Edificio Segre 1, 2 & 3  
Apartado 50933  
**CARACAS 1071**  
Tel: 239-4133  
Telex: 251046 HEWPACK  
A,CH,CS,E,M,P

Hewlett-Packard de Venezuela C.A.  
Residencias Tia Betty Local 1  
Avenida 3 y con calle 75  
**MARACAIBO, Estado Zulia**  
Apartado 2646  
Tel: (061) 75801-75805-75806-80304  
Telex: 62464 HPMAR  
C,E\*

Hewlett-Packard de Venezuela C.A.  
Urb. Lomas de Este  
Torre Trebol — Piso 11  
**VALENCIA, Estado Carabobo**  
Apartado 3347  
Tel: (041) 222992/223024  
CH,CS,P

*Albis Venezolana S.R.L.*  
*Av. Las Marias, Ota. Alix,*  
*El Pedregal*

*Apartado 81025*  
**CARACAS 1080A**  
*Tel: 747984, 742146*  
*Telex: 24009 ALBIS VC*  
A

*Tecnologica Medica del Caribe, C.A.*  
*Multicentro Empresarial del Este*  
*Ave. Libertador*  
*Edif. Libertador*  
*Nucleo "C" - Oficina 51-52*  
**CARACAS**  
*Tel: 339867/333780*  
M

## CIZUCA

*Cientifica Zulia C.A.*  
*Calle 70, Los Olivos*  
*No. 66-86*  
*Apartado 1843*  
**MARACAIBO**  
*Tel: 54-64-37, 54-63-85, 54-64-94*  
*Telex: 62144*  
A

## YUGOSLAVIA

*Do Hermes*  
*General Zdanova 4*  
**MARACAIBO, Estado Zulia**  
*A,CH,E,P*  
*Hermes*  
*Titova 50*  
*Telex: YU-11000 LJUBLJANA*  
*CH,CS,E,M,P*

*Elektrotehna*  
*Titova 51*  
*Telex: YU-61000 LJUBLJANA*  
CM

## ZAMBIA

R.J. Tilbury (Zambia) Ltd.  
P.O. Box 32792

**LUSAKA**  
Tel: 215590  
Telex: 40128  
E

## ZIMBABWE

*Field Technical Sales*  
*45 Kelvin Road, North*  
*P.B. 3458*  
**SALISBURY**  
*Tel: 705 231*  
*Telex: 4-122 RH*  
E,P

August 1984

*HP distributors are printed in italics.*





HEWLETT  
PACKARD