

**READ ORDERING
INSTRUCTIONS**

LOG LITERATURE LITERATURE
CATALOG LITERATURE CATALOG LI
CATALOG LITERATURE LITERATURE
LITERATURE LITERATURE ERAT
LITERATURE CATALOG LI
CATALOG LITERATURE CATALOG LI
LITERATURE CATALOG LI

**CONTROL DATA
CORPORATION**

CORPORATE HEADQUARTERS

8100 34TH AVENUE SOUTH, MINNEAPOLIS, MINNESOTA

MAILING ADDRESS • BOX 0, MINNEAPOLIS, MINNESOTA 55440

CONTROL DATA

INCORPORATED

July 15, 1975


Dear Customer:

Attached is the July 1975 Literature Catalog. Please read all instructions in the front section of this catalog before placing orders. This catalog obsoletes all previous editions.

Tranex Users Guide, Publication No. 60436500 will not be available under Kronos V2.1. This document will be available under NOS V1.0, but not until 11-15-75.

Batch Users Guide, Publication No. 60436300 will not be available until 10-22-75.

T-S Users Guide, Publication No. 60436400 will not be available until 9-15-75.



G. F. Moore, Manager
Literature & Distribution Services

GFM/sku

**CONTROL DATA CORPORATION
LITERATURE AND DISTRIBUTION SERVICES
8100 34TH AVENUE SOUTH, P.O. BOX O
MINNEAPOLIS, MINNESOTA 55440
TELEPHONE: 612-853-4157
TWX NUMBER 910-576-2978
TELEX NUMBER 290-435**



JULY 1975 EDITION

THIS CATALOG OBSOLETE
ALL PREVIOUS EDITIONS

EXTERNAL CUSTOMER CATALOG
PUBLICATION 90310500

INTRODUCTION

The Literature and Distribution Services Department of Control Data Corporation is responsible for the publishing of this catalog and the distribution of the items contained therein. The purpose of LDS is to provide a central ordering and distribution service for the external sale of literature and coding forms to Control Data customers.

The Customer Catalog will be published twice during 1975, with literature supplements published during the interim months. The monthly supplements reflect the changes which have taken place in the previous month including obsoleted publications, new publications and revision changes.

LDS solicits your comments and requests that verbal or written communication be directed to the Manager of Literature and Distribution Services.

TABLE OF CONTENTS

| | <u>PAGE</u> |
|--|-------------|
| Manual Definition | I-1 - I-2 |
| Procedures For Ordering Manuals | I-3 - I-5 |
| Procedures For Ordering Coding Forms | I-5 |
| Listing Of Coding Forms | I-6 - I-7 |
| Accumulated Literature Change Listings | I-8 - I-27 |
| Obsoleted Publications | I-28 - I-29 |
| Numerical Listing Of Publications | |
| With Page Locations | I-30 I-38 |
| Section I - Hardware Manuals | 1-53 |
| Listed Under Equip. Designator | |
| Section II - Software Manuals | 54-127 |
| Listed Under Product Number | |
| Section III - Software Manuals | 128-155 |
| Listed Under Operating Systems | |
| Table Of Software Abbreviations | 129 |
| Section IV - Miscellaneous Manuals - | 156 |
| Binders, Templates, Etc. | |
| Miscellaneous Manuals | 157-158 |
| Education Manuals | 159 |
| Training Manuals | 159-162 |
| Technical Reports | 162-163 |
| Video Lecture Manuals | 163 |
| SCM Publications | 163-164 |
| Hard Cover Binders | 164-165 |
| Templates | 165 |
| Motor Generator Set Manuals | 165 |
| Refrigeration Manuals | 165 |
| Power Supply Manuals | 165-166 |
| Printed Circuit Manuals | 166 |
| Site Preparation Manuals | 166-167 |
| Vendor Manuals | 167-168 |
| Long Line Transmission For 1604 Type I/O | 168 |
| Miscellaneous Equipment Modifications | 168-169 |
| QSE | 169 |
| Standard Options | 169-171 |
| Special Options | 171-172 |
| Cybernet Publications | 172-179 |

MANUAL DEFINITION

The following general description of manuals, operator guides and handbooks is provided to allow the catalog user to more quickly identify categorically, the type of book he requires. With this information the user can then relate more easily to the section of this catalog which contains the required manual.

Hardware Reference Manual - This manual provides functional and operational descriptions and general programming capability information on Control Data hardware products and systems. This manual is written to the level of a knowledgeable prospective customer, professional programmer, and equipment operator.

Customer Engineering Manual - This manual provides the technical information necessary to maintain Control Data hardware products. Categories of information presented, in one or more volumes, are: General Description, Operation and Programming, Installation and Checkout, Theory of Operation, Diagrams, Maintenance, Maintenance Aids, Parts Data, Wire Lists, and Equation Summary {or equivalent}.

Hardware Reference/Customer Engineering Manual - This combined manual, usually for less complex devices that require minimal programming information, contains the same information as that in separate Reference and Customer Engineering manuals.

Site Preparation Manual - This manual presents technical information with which to plan and prepare sites for computer installation. Three sections make up this manual:

Section I: General Information - Two Section I manuals are available: One for small systems; the other covers large and medium-scale systems.

Section II: System Information - Section II manuals cover site planning information for specific systems; e.g., 3300, 6400, etc.

Section III: Peripheral Equipment - Section III provides site planning data on all Control Data peripheral equipment.

Hardware Diagnostic Reference Manual - This manual provides a functional description and detailed operating instructions for diagnostic programs.

System Operator's Manual - This manual provides operating instructions to the system operator. Instructions in this manual normally include system start-up, message formats, error recovery procedures, and general system information. This manual is written to the level of computer operators who do not have a detailed knowledge of programming.

System Reference Manual - This manual describes the system in terms of function, applications, and capabilities. Provides a configuration of the hardware that makes up the system with a brief description of the system function of each product. May also include a description of the software available with the system. Written to the level of the prospective customer who does not have a detailed knowledge of either the hardware or software.

Software General Information Manual - This manual provides introductory descriptions of functional and operational characteristics of Control Data software products.

Software Reference Manual - This manual provides complete descriptions of external functional and operational characteristics of Control Data software products.

Software Operator's Guide - This manual provides detailed instructions for operating Control Data software systems.

Software Diagnostic Handbook - This manual provides the messages issued by all programs in a software product set, together with the recommended action.

Software Installation Handbook - This manual provides installation and modification instructions for Control Data software products.

Software User's Guide - This manual provides the layman with the instructions on how to use a software product.

Software Instant Manual - This pocket-size manual provides summary information {deck structures, etc.} for system programmers and operators of software systems.

LITERATURE ORDERING POLICY AND PROCEDURES

Please read these policies and procedures prior to ordering to avoid confusion and mistakes and also to expedite the handling of orders.

PURCHASE ORDERS - Orders directed to LDS should include, if possible, a numbered purchase order, a money order or personal check.

ORDER LEAD TIME - All customer orders received will be handled on a priority basis and normally processed within a four working day period. Please keep in mind the transit time required by your order to both get to LDS and for the order to travel to your place of business. Under normal conditions, complete turn around on orders should not exceed fourteen calendar days.

DOMESTIC ORDERS - All purchase orders from domestic customers should be forwarded directly to:

Literature & Distribution Services
Control Data Corporation HQC00C
8100 34th Avenue South, P.O. Box 0
Minneapolis, Minnesota 55440

INTERNATIONAL ORDERS - International customer orders should be directed to the nearest Control Data Sales Office. The Control Data Sales Office will then process your order through LDS.

PRICING - The prices contained in this catalog are subject to change without notice.

FOB - All prices are F.O.B. Minneapolis, Minnesota

TERMS: NET 30 DAYS

SHIPPING REQUIREMENTS - Shipping instructions as given by the customer will be followed whenever possible. However, when the instructions cannot be adhered to, LDS reserves the right to determine the mode of transportation.

PRICE QUOTES - Price quotes are available upon request and are valid for 30 days only.

TELEPHONE ORDERS - LDS will accept telephone orders but each order must reference a purchase order number. A purchase order must follow confirming the phone order, and should be marked 'confirmation, do not duplicate'.

IDENTIFICATION OF MANUALS NEEDED - When ordering, you must specify whether you require a specific revision packet to a manual or if you desire the complete manual with all applicable revision packets updating the publication to its current revision level.

LITERATURE ORDERING POLICY AND PROCEDURES {CONT.}

NOTE: In some cases, the revision packet required is not available. However, the manual itself may have been reprinted through the revision which you require. If the packet is not available and you wish LDS to send you the updated manual, please specify same on your order. If you do not give LDS specific instructions for such a possibility, LDS will return your order and will not arbitrarily send the updated manual in place of the unavailable revision packet.

BACK ORDERS - All out of stock items will be automatically backordered and routed to you upon resupply of the item to stock. Please contact LDS should you not want specific items backordered.

DISCOUNTS - Discounts are given for literature as follows:

- {1} A 10% discount is given when ordering 25 to 99 copies of a single document.
- {2} A 20% discount is given when ordering 100 or more copies of a single document.

RETURNS FOR CREDIT - LDS does not sell literature on a consignment basis but will accept returns to stock if LDS has misfilled or delayed delivery of order so that the manuals are no longer required. Manuals which customers have ordered in excess of their needs may be returned if the publications are still current. IT IS IMPORTANT THAT YOU CONTACT AND RECEIVE FROM LDS WRITTEN APPROVAL BEFORE ANY MANUALS ARE RETURNED TO LDS. The manuals must be unused, in new condition and sent freight prepaid. Complete paperwork must accompany all returns for credit. Complete paperwork would include your original order number and if possible a copy of the order, the date of order and a copy of the LDS generated order invoice. All uncleared return to stock orders which LDS receives will be returned to the originator at the originator's expense.

AUTOMATIC SOFTWARE REVISION PACKET DISTRIBUTION SERVICE - On July 1, 1972, an additional service was made available to CDC customers. This service provides for the free postpaid automatic distribution to eligible customers of software revision packets as the packets become available. The policy holds that all external customer manual orders received directly from the customer by LDS on July 1, 1972 and thereafter will be eligible for automatic revision packet distribution. The customer is requested to return a copy of the shipping document which will be provided by Literature and Distribution and indicate on the document which Software publications they wish to have placed on the A/D service. A cover memo will be sent with each shipment indicating the guidelines you must follow. The packets will then be supplied to the customer in the same quantity as the manuals purchased under the original manual purchase order. The packets will continue to be distributed as long as packets are published or until the customer notifies LDS that the distribution should stop. You must establish eligibility

LITERATURE ORDERING POLICY AND PROCEDURES [CONT.]

by the purchase of a manual as a customer will not be placed on the listing if he purchases only a revision packet. Revision packets for manuals purchased prior to July 1, 1972, must be purchased by the customer and not through a CDC Sales Office. Not all customers will want this service as some manuals are purchased for a short duration use, such as orders by educational institutions for class use. Please indicate on your order if you do not wish this automatic packet distribution service.

GENERAL REVISION PACKET PRICING - All revision packets which support manuals sold to external CDC customers by LDS after July 1, 1972, will be provided free of charge. The packets will be given in the same quantity as the original manual purchase. Software packets will be automatically distributed {see Automatic Software Revision Packet Distribution above} whereas, requests for Hardware and Miscellaneous packets to support previously purchased manuals must be made directly to LDS by the customer. Please state on your order that the packets are in support of previously ordered manuals to avoid a billing for the packets. Quantities of packets which are in excess of the total number of manuals initially purchased by the customer will be charged to the customer.

PROCEDURES FOR ORDERING CODING FORMS

All purchase orders for coding forms from International customers should be directed to the nearest Control Data Sales Office. All purchase orders from Domestic customers should be directed to:

Literature & Distribution Services
Control Data Corporation
8100 34th Avenue South, P.O. Box 0
Minneapolis, Minnesota 55440

The unit price, form number, description and sheets per pad are as shown on the following pages.

Control Data does not offer quantity discounts on Forms sales.

CODING FORMS

| <u>FORM NO.</u> | <u>DESCRIPTION</u> | <u>UNIT PRICE</u> |
|-----------------|---|-------------------|
| AA0138 | OSAS/OSAS-A Coding Form | \$.75/PD |
| *AA0193 | 1604 Assembly Coding Form | |
| *AA0235 | 1604 Octal Card For General Load | |
| *AA0236 | 1604 Decimal Card For General Load | |
| AA0252 | FORTTRAN Coding Form | .84/PD |
| AA0323 | 80 Column Punched Card Layout | .90/PD |
| AA0366 | 3600 COMPASS System Coding Form | 1.00/PD |
| AA0382 | COBOL Coding Form | .86/PD |
| AA0382-1 | COBOL Coding Form | 1.00/PD |
| AA0383 | AUTOCOMM Coding Form | .66/PD |
| AA0540 | 160/160-A Data Processor | .81/PD |
| *AA0543 | 160 G Octal/Decimal Loader Form | |
| AA0649 | Tape Record Layout | 1.02/PD |
| AA1030 | Computer Operating Instructions | 1.33/PD |
| AA1031 | Intercom Program | .87/PD |
| AA1040 | Report and Tape Layout | 2.82/PD |
| AA1053 | Cybernet Tape/Pkt. Lab | .06/EA |
| AA1084 | Obsolete - Use AA5491 | |
| AA1085 | Obsolete - Use AA5492 | |
| AA1086 | Obsolete - Use AA5490 | |
| AA1133 | Obsolete - Use AA5494 | |
| AA1283 | Loadflow Program - Control Information | .73/PD |
| AA1284 | Loadflow Program - Line & Transformer Data | 1.18/PD |
| AA1385 | Software Document | 1.40/PD |
| AA1385-1 | Software Document | 2.75/PD |
| AA1401 | Index To Data Files For System | .99/PD |
| AA1405 | Documentation Charting Form - Large | 4.17/PD |
| AA1457 | 1700 Absolute Programming Sheet | 1.24/PD |
| AA1502 | Element Values LP-DCD Linear Programming Code | .87/PD |
| AA1503 | Row Or Column Name LP-DCD Linear Programming Code | .70/PD |
| AA1529 | Tape Record Format | .97/PD |
| AA1530 | Card Format {S} | .97/PD |
| AA1708 | SIMSCRIPT Report Generator Layout Form | 1.46/PD |
| AA1709 | SIMSCRIPT Initial | 1.48/PD |
| AA1710 | SIMSCRIPT Definition Form | 1.62/PD |
| AA1775 | 6600 ASCENT System Coding Form | .64/PD |
| AA1779 | 80 Column Punched Card Layout | 1.20/PD |
| AA2142 | PERT/TIME Coding Form - Type A Data | 1.36/PD |
| AA2184 | Obsolete - No Replacement | |
| AA2212 | OSAS/OSAS-A TAS 915 Coding Form | 48.60/RM |
| AA2364 | Transfer Request | .64/PD |
| AA2394 | Report Generator Coding Form | .90/PD |
| AA2422 | Multiple Layout Card Form | .78/PD |
| AA2442 | CIVCO Input Data Form | 1.63/PD |
| AA2453 | Pagination Sequence | .98/PD |
| AA2501 | Forecasting Worksheet | 1.44/PD |
| AA2583 | Form Layout Sheet - 8 1/2 x 11 Vertical | 1.57/PD |
| AA2583-1 | Form Layout Sheet - 8 1/2 x 11 Horizontal | 2.00/PD |
| AA2836 | Sample Format and Card | .94/PD |
| AA2986 | Eunas Data Form | 1.02/PD |

*PRICES AVAILABLE UPON REQUEST

CODING FORMS {CONT}

| <u>FORM NO.</u> | <u>DESCRIPTION</u> | <u>UNIT PRICE</u> |
|-----------------|---|--------------------------|
| AA2987 | 6000/7000 Compass Coding Form | \$.76/PD |
| AA3034 | Department Data and Recaps | .84/PD |
| AA3034-1 | Departmental Recap Names | .85/PD |
| AA3168 | SAMIS, Pseudo Instruction Input Data-Form 1 | 1.02/PD |
| AA3169 | SAMIS, Materials Tables Input Data-Form 2 | 1.02/PD |
| AA3170 | SAMIS, Facet and Beam Element Input Data-Form 3 | 1.02/PD |
| AA3171 | SAMIS, Matrix Input Data - Form 4 | 1.02/PD |
| AA3385 | Program Trouble Sheet | .17/EA |
| AA3389 | CDC/MACRAN Coding Form | 1.02/PD |
| AA3422 | STARDYNE Data Form, Prep Data Form 2 | .87/PD |
| AA3423 | STARDYNE Data Form, 10 Digit Decimal Data | .71/PD |
| AA3424 | STARDYNE Data Form, Stardyne Static Loads | .93/PD |
| AA4173 | 3000L Compass System Coding Form | 1.44/PD |
| AA4193 | TELCOM User Master Corrections | .87/PD |
| AA4206 | 6000/7000 Table Form | .91/PD |
| AA4405 | Revision Record | 1.29/PD |
| AA4437 | OPHELIE-LP MPS Data Form | .67/PD |
| AA5490 | DCO/Tranplan Transit NE | 1.12/PD |
| AA5491 | DCO/Tranplan Transit NE | 1.40/PD |
| AA5492 | DCO/Tranplan Transp System | .88/PD |
| AA5493 | DCO/Tranplan Transp PLA | 1.29/PD |
| AA5494 | DBO/Tranplan Transp PLA | 1.53/PD |
| AA6036 | Bridge Analysis Input Data-Card Type 1 | 1.62/PD |
| AA6037 | Bridge Analysis Input Data-Card Types 2, 5, 6 | 1.44/PD |
| AA6038 | Bridge Analysis Input Data-Card Type 3 | 1.62/PD |
| AA6039 | Bridge Analysis Input Data-Card Type 7 | 1.46/PD |
| AA6040 | Bridge Analysis Input Data-Card Type 8 | 1.45/PD |
| AA6041 | Bridge Analysis Input Data-Card Type 9 | 1.46/PD |
| AA6042 | Bridge Analysis Input Data-Card Type 10 | 1.42/PD |
| AA6043 | Bridge Analysis Input Data-Card Type 11 | 1.46/PD |
| AA6044 | Bridge Analysis Input Data-Card Type 12 | 1.35/PD |
| AA6045 | Bridge Analysis Input Data-Card Type 13 | 1.46/PD |
| AA6046 | Bridge Analysis Input Data-Card Type 14 | 1.46/PD |
| AA6047 | Bridge Analysis Input Data-Card Type 15 | 1.46/PD |
| AA6048 | Bridge Analysis Input Data-Card Type 60 | 1.46/PD |
| AA6049 | Bridge Analysis Input Data-Card Type 61 | 1.38/PD |
| AA6050 | Bridge Analysis Input Data-Card Type 62 | 1.62/PD |
| AA6051 | Bridge Analysis Input Data-Card Type 63 | 1.35/PD |
| AA6052 | Bridge Analysis Input Data-Card Type 64 | 1.35/PD |
| AA6053 | Bridge Analysis Input Data-Card Type 65 | 1.46/PD |
| AA6054 | Bridge Analysis Input Data-Control Cards | 1.62/PD |
| MSC015R1 | LGP 30 Coding Form | Forms comprise set, must |
| MSC016R1 | LGP 30 Coding Form | be sold together |
| MSC05710 | LGP 30 Work Format | .99/PD |

All pads contain 50 sheets each
 All reams contain 500 sheets each

ACCUMULATED LITERATURE CHANGE LISTING

This section is an accumulation of all literature revisions, additions and deletions which have taken place since the issuance of the January 1975, Literature Catalog. The manuals are listed numerically by product number.

The legend for columns one through six is as follows:

- 1-New or revised literature published since last edition.
 - A. N-New Publication
 - B. R-Revision in packet form only
 - C. RM-Revision in manual form only
 - D. RMP-Revised manual/packet available
 - E. RO-Revised publication obsoletes all previous editions.
 - 2-Publication number of literature
 - 3-The latest revision level
 - 4-Indicates size of hard cover binder that may be used for manuals
 - 5-Publication division responsible for contents of literature
- *FOR CONTROL DATA USE ONLY

| 1 | TITLE | 2 | 3 | 4 | 5 |
|----|---|----------|---|----|-----|
| *N | 3315B MEMORY SYSTEMS SALES REFERENCE MAN | 10121100 | - | -- | HQW |
| R | FJ601-A {3316-1, 3516-1} MULTIPLEXER CONTROLLER THEORY OF OPERATION, INSTALLATION/CHECKOUT, DIAGS., MAINT., MAINT. AIDS, PARTS DATA AND WIRE LISTS CE MAN | 13796700 | K | 22 | ARH |
| N | 469 COMPUTER SYSTEM 462-01A AND 462-02A TELETYPE CONTROLLER HARDWARE REF/CE MANUAL | 14060200 | - | 22 | MSP |
| N | 469 COMPUTER SYSTEM 461-01B/02A PUNCHED TAPE MEMORY LOADER/TAPE PUNCH HARDWARE REFERENCE/CE MANUAL | 14060300 | A | 22 | GSD |
| N | MP-60 COMPUTER SYSTEM COMPASS REFERENCE MAN | 14061300 | B | 22 | GSD |
| N | MP-60 COMPUTER SYSTEM COSY REFERENCE MANUAL | 14062100 | A | 22 | GSD |
| N | MP-60 COMPUTER SYSTEM PRELIB REFERENCE MAN | 14062200 | A | 22 | GSD |
| N | 469 COMPUTER SYSTEM PROGRAMMING REF MANUAL | 14065300 | B | 22 | GSD |
| N | 469 COMPUTER SYSTEM ASSEMBLER V 1.2 REF MAN | 14077300 | C | 22 | GSD |
| N | 469 COMPUTER SYSTEM SIMULATOR V 1.0B REF MAN | 14082100 | D | 22 | GSD |
| N | 469 COMPUTER SYSTEM BASIC ARITHMETIC SUB-ROUTINES REFERENCE MANUAL | 14082200 | B | 22 | GSD |
| RO | 5600 COMPUTER SERIES MPP REFERENCE MANUAL | 14232000 | A | 22 | GSD |
| N | MP-60 COMPUTER SYSTEM REFERENCE MANUAL | 14306500 | A | 22 | GSD |
| N | 33159 MONOLITHIC MAIN MEMORY SYSTEMS SALES REFERENCE GUIDE | 15001100 | - | -- | HQW |
| R | 6000 COMPUTER SYSTEMS CONTINUOUS SYSTEM SIMULATION LANGUAGE III USERS GUIDE VERSION I | 17304400 | F | 22 | SVL |
| N | 6000/CYBER 70 MODELS 72/73/74 COMP SYSTEM DIGITAL DISPLAY SYSTEM {DDS} VER 3 REFERENCE MANUAL | 17318900 | A | 22 | SVL |
| RO | 6000/CYBER 70 MODELS 72, 73, 74 COMP SYSTEM ??? INTERACTIVE GRAPHICS SYSTEM VER 2 OPERATORS GUIDE | 17322600 | B | 22 | SVL |
| RO | 6000/CYBER 70 MODELS 72, 73, 74 LCGT/IGS VERSION 1 G.I.M. | 17322700 | B | 3 | SVL |
| RO | CYBER 70 COMPUTER SYSTEMS MODELS 72, 73, 74 LOW COST GRAPHICS TERMINAL {LCGT} INTERACTIVE GRAPHICS SYSTEM {IGS} VERSION 1.1 REFERENCE MANUAL | 17322800 | B | 22 | SVL |
| N | ??? THREE DIMENSIONAL INTERACTIVE GRAPHICS SYSTEM {3-D IGS} VER 1 REF MAN CONTROL DATA 6000 CYBER 70 MODELS 72, 73, 74 COMPUTER SYSTEMS | 17326500 | A | 22 | SVL |
| R | 6000/CYBER 70 MODELS 72, 73, 74 COMPUTER SYS 3000L TO CYBER 70 CONVERSION AIDS SYSTEM VER 1.0 FORTRAN CONVERSION FOR SCOPE 3.4 | 19980600 | C | 22 | TTO |

CONT.

| 1 | TITLE | 2 | 3 | 4 | 5 |
|-----|--|----------|-----|----|-----|
| R | 6000/CYBER 70 MODELS 72,73,74 COMPUTER SYS 3000L TO CYBER 70 CONVERSION AIDS SYSTEM VER 1.0 COBOL CONVERSION FOR SCOPE 3.4 | 19980700 | B | 22 | TTO |
| R | 6000/CYBER 70 MODELS 72,73,74 COMPUTER SYS 3000L TO CYBER 70 CONVERSION AIDS SYSTEM VER 1.0 LANGUAGE CONVERSION USERS GUIDE FOR SCOPE 3.4 | 19980900 | B | 22 | TTO |
| RO | CYBER 170-MODELS 172/173/174 SYSTEMS DATA SITE PREPARATION MANUAL | 19981400 | A | 22 | ARH |
| N | CYBER 170 MODELS 172,173,174 CENTRAL PRO- CESSOR UNIT THEORY OF OPERATION, DIAGS, HARDWARE MAINT. MANUAL VOLUME 1 OF 2 {PRELIMINARY ED.} | 19981800 | 01 | 22 | TTO |
| N | CYBER 70/CYBER 170/6000 SERIES COMPUTER SYS COBOL VERSION 5.0 GIM | 19984100 | A | 22 | TTO |
| N | FF525 PRINTER SUBSYSTEM CENTRAL CONTROL UNIT LOGIC DIAGRAMS | 22272500 | A | 34 | PLY |
| N | 28211-21 PRINTER SUBSYSTEM LOGIC DIAGRAMS | 22273100 | A-G | 34 | PLY |
| RO | 1538 {FL301A} HIGH-SPEED, HIGH LEVEL ANALOG INPUT CONTROLLER | 39074500 | D | 22 | LJL |
| N | 1700 A/Q {DC220/221-A} DSA ADAPTERS GEN DESC., OPER AND PROGRAMMING, INSTALLA- TION AND CHECKOUT, THEORY OF OPER., DIAGS, MAINT, MAINT. AIDS, PARTS DATA, WIRE LISTS, HDWE/REF/CE MANUAL | 39392700 | C | 22 | LJL |
| RO | 1700 COMPUTER SYSTEMS MS05 4 FILE MANAGER VERSION 1 SOFTWARE REFERENCE MANUAL | 39520600 | B | 22 | LJL |
| N | 1700 COMPUTER SYSTEMS 1700 MS05 4.1 FORTRAN 3.2 A/B, AND TIMESHARE 2.0 RELEASE BULLETIN | 39520800 | A | 22 | LJL |
| N | 1700 COMPUTER SYSTEMS MS05 VERSION 4 ORDER- ING BULLETIN | 39521900 | B | 22 | LJL |
| RO | 1700 COMPUTER SYSTEMS MS05 4 G.I.M. | 39522400 | B | 22 | LJL |
| R | GH107-B/ED301-E MULTIPLEXER {MX-7A} GENERAL DESC., DIAGRAMS, WIRE LISTS, PARTS DATA CE MANUAL | 39660400 | B | 22 | LJL |
| N | BG504A-H DRUM MEMORY SUBSYSTEM HARDWARE REFERENCE/CE MANUAL | 39731700 | C | 22 | LJL |
| RO | DK605-A {1595-10/11} SERIAL I/O UNIT REF CE MANUAL | 39909507 | B | 22 | LJL |
| N | 1590-3 {DN124-A,FJ124-A} REMOTE COMPUTER INTERFACE SUBSYSTEM HARDWARE REF/CE MANUAL | 39909513 | A | 22 | LJL |
| RO | BE102 {608} MAGNETIC TAPE TRANSPORT PARTS LIST CE MANUAL | 40864100 | G | 22 | VFD |
| R | FJ103-A/B/C/D/E {1748-2} MULTIPLEXER CON- TROLLER THEORY OF OPERATION, INSTALLA- TION CHECKOUT, DIAGS., MAINT., MAINT. AIDS, PARTS DATA CE MANUAL | 41601700 | J | 22 | ARH |
| RMP | DJ110-A {311-2} DATA SET ADAPTER THEORY OF OPERATION, INSTALLATION/CHECKOUT, DIAGS., MAINT., MAINT. AIDS, PARTS DATA CE MANUAL | 41603200 | C | 22 | ARH |
| R | FJ103-A/B/C/D/E {1748-2} MULTIPLEXER CONTROLLER CARD PLACEMENT, LOGIC WIRING, WIRE LISTS EQUATION SUMMARY CE MANUAL | 41603300 | E | 22 | ARH |

CONT.

| 1 | TITLE | 2 | 3 | 4 | 5 |
|----|---|----------|------|----|-----|
| R | 361-5 {DJ144-A} COMMUNICATIONS ADAPTER REFERENCE MANUAL | 41611800 | C | 22 | ARH |
| RO | 1700/SC1700 COMPUTER SYSTEMS DRAFT VERSION 5.1 OCR REFERENCE MANUAL | 48143900 | F | 22 | ROK |
| RO | CJ122 DIAGRAMS VOLUME 2, PART 3, CE MANUAL | 48430045 | B | 22 | ROK |
| RO | CJ122 PAGE AND DOCUMENT READER MODELS C-K VOLUME 1 HARDWARE MAINTENANCE MANUAL | 48430080 | C | 22 | ROK |
| RO | BE406 {659-1} MAGNETIC TAPE TRANSPORT GEN. DESC., THEO OF OPER., MAINT. CE MAN | 49750600 | G | 22 | VFD |
| N | 34201 MAGNETIC TAPE TRANSPORT OPERATORS MANUAL | 49752300 | A | 3 | VFD |
| RO | 415 CARD PUNCH DIAGRAMS, THEORY OF OPERATION, GEN. DESC., CE/REFERENCE MANUAL | 49755300 | C | 22 | VFD |
| RO | BE482 {9525} MAGNETIC TAPE TRANSPORT DIAGS. CE MANUAL | 49755800 | C | 22 | VFD |
| N | CH102-A/B CARD PUNCH PART IDENTIFICATION MANUAL | 49762400 | A | 22 | VFD |
| RO | BE103 {657-1} MAGNETIC TAPE TRANSPORT PARTS LIST CE MANUAL | 49815000 | G | 22 | VFD |
| N | 3000 COMPUTER SYSTEM BROKERAGE CONTROL SYS VER 4.0 REF MAN | 59159000 | A | 22 | ARH |
| N | 3000 COMPUTER SYSTEMS BROKERAGE CONTROL SYS VER 4.0 OPERATORS GUIDE | 59159100 | A | 22 | ARH |
| N | EXTENDED CORE STORAGE DATA PATH AND STACK SELECT MAINTENANCE AID CHART | 59304600 | - | -- | ARH |
| N | 14031 TRAIN PRINTER GEN DESC., INSTALLATION & CHECKOUT, OPER AND PROGRAMMING, PRINCIPLES OF OPERATION, MAINT, MAINT AIDS CE MANUAL VOLUME I | 59708200 | A-01 | 22 | RHT |
| N | 14031 TRAIN PRINTER DIAGRAMS & WIRE LIST CE MANUAL VOLUME 2 | 59708300 | A-01 | 22 | RHT |
| N | 14031 TRAIN PRINTER VOLUME 3 PARTS DATA CE MANUAL | 59708400 | A-01 | 22 | RHT |
| RO | SINGER BUSINESS MACHINES LINE PRINTER EQUIPMENT MODELS 53,54,55 AND 56 PARTS MAN | 59708700 | D | 3 | RHT |
| RO | 9322 SINGER FIELD SERVICE MANUAL VOLUME 2 PRINTED CIRCUIT MANUALS CORDWOOD MANUAL VOLUMES 1,2,3 | 59709000 | B-01 | 34 | RHT |
| R | 3200 COMPUTER SYSTEM CE DIAGRAMS | 60042700 | AY | 22 | ARH |
| R | 3100/3150/3170/3200/3300/3500 COMPUTER SYS MASTER/MSOS/RTS MASS STORAGE FORTRAN VERSION 3 AND 4 REFERENCE MANUAL | 60049400 | AY | 22 | ARH |
| R | 3228-A/B MAGNETIC TAPE CONTROLLER CE MANUAL | 60057600 | G | 22 | ARH |
| R | 6000 COMPUTER SYSTEMS REFERENCE MANUAL | 60093700 | V | 22 | ARH |
| R | 3104/3114-A/B COMPUTER DIAGRAMS CE MANUAL | 60100000 | AE | 22 | ARH |
| R | 3000L SYSTEM MAINTENANCE MONITOR REF MANUAL VOLUME 1 AND 2 | 60111100 | BE | 22 | ARH |
| R | DC211-A {6684-A} DATA CHANNEL CONVERTER CE MANUAL | 60118600 | M | 22 | ARH |
| R | 6411-A/6416-A AUGMENTED I/O BUFFER CONTROL DIAGRAMS AND CIRCUIT DESCRIPTION | 60125000 | AZ | 22 | ARH |
| R | 3104-A/B, 3114-A/B COMPUTER CARD PLACEMENT, EQUATION SUMMARY CE MANUAL | 60146200 | U | 22 | AR |
| R | 3104-A/B, 3114-A/B COMPUTER WIRE LIST {TERM} CE MANUAL | 60152500 | AD | 22 | ARH |
| R | 3458-A LINE PRINTER CONTROLLER DIAGS CIRC. DESC., MAINT AND PARTS LIST | 60152600 | AA | 22 | ARH |
| R | 1700 COMPUTER SYSTEM CODES | 60158200 | Z | 22 | ARH |
| RO | | 60163500 | H | 6 | LJL |

CONT.

| 1 | TITLE | 2 | 3 | 4 | 5 |
|----|---|----------|----|----|-----|
| R | 1706-A BUFFERED DATA CHANNEL DIAGS., CIRCUIT DESC., MAINTENANCE, PARTS LISTS CE MANUAL | 60165700 | L | 22 | LJL |
| R | 1700 COMPUTER SYSTEM INPUT/OUTPUT SPECIFICATIONS MANUAL | 60165800 | H | 22 | LJL |
| R | 6400/6500-A/B/C CENTRAL COMPUTER CABLE TABS {FOR 6404-A, 6414/6514-A/B/C {ONLY}} | 60166000 | M | 22 | ARH |
| R | 6400/6500-A/B/C CENTRAL COMPUTERS CHASSIS 3 CHASSIS TABS | 60166300 | AR | 22 | ARH |
| R | 1738-A/B/C DISK DRIVE CONTROLLER CE MANUAL | 60167700 | U | 22 | LJL |
| R | 3234-A/B MASS STORAGE CONTROLLER DIAGRAMS CE MANUAL | 60167900 | AD | 22 | ARH |
| R | 6400/6500-A/B/C CENTRAL COMPUTERS CABLE TABS {FOR 6405-A, 6415-A/B/C ONLY} | 60169700 | M | 22 | ARH |
| R | 6400/6500-A/B/C CENTRAL COMPUTERS MAINT. AND COMMAND TIMING | 60182100 | J | 22 | ARH |
| R | 1716-A COUPLING DATA CHANNEL CE MANUAL | 60182800 | N | 22 | LJL |
| RO | 1708-A {BB310-A/BB311-A/BB312-A} STORAGE INCREMENT CE MANUAL | 60182900 | G | 22 | LJL |
| R | SMM17 REFERENCE MANUAL VOLUME 1 AND 2 | 60182000 | M | 22 | ARH |
| R | FF511-A/B {1742} LINE PRINTER CONTROLLER CE MANUAL {INCLUDES PMI/PMP} | 60183000 | H | 22 | LJL |
| R | 3300 COMPUTER SYSTEMS INSTRUCTION CODES | 60186900 | D | -- | ARH |
| R | 6400/6500-A/B/C CENTRAL COMPUTERS CHASSIS 8 CHASSIS TABS | 60187700 | V | 22 | ARH |
| R | 6400/6500-A/B/C CENTRAL COMPUTER CABLE TABS {FOR 6413/6513-A/B/C ONLY} | 60188900 | G | 22 | ARH |
| R | 3458-A LINE PRINTER CONTROLLER CARD PLACEMENT, EQUATION SUMMARY, WIRE LIST CE MANUAL | 60197000 | S | 22 | ARH |
| R | 3104-C/3114-C COMPUTER CARD PLACEMENT, EQUATION SUMMARY CE MANUAL | 60197900 | S | 22 | ARH |
| R | 3104-C/3114-C COMPUTER WIRE LIST {TERM} CE MANUAL | 60198000 | M | 22 | ARH |
| R | 6673/6674 DATA SET CONTROLLER CARD PLACEMENT EQUATION SUMMARY CE MANUAL | 60201500 | N | 22 | ARH |
| R | 6673/6674 DATA SET CONTROLLER WIRE LISTS CE MANUAL | 60205400 | L | 22 | ARH |
| RM | 1732-A/B MAGNETIC TAPE CONTROLLER CE MANUAL | 60208200 | L | 22 | LJL |
| R | BB319-A {6634-C} EXTENDED CORE STORAGE ASSEMBLY DIAGRAMS, CIRC. DESC., WIRE LIST CE MANUAL | 60209600 | W | 22 | ARH |
| R | BB313-A {3502} STORAGE MODULE CE MANUAL | 60210200 | AC | 22 | ARH |
| R | BB323-A {6635-C} EXTENDED CORE STORAGE ASSEMBLY DIAGRAMS, CIRC. DESC., PARTS LIST, CARD PLACEMENT CE MANUAL | 60212200 | W | 22 | ARH |
| R | FJ411-A/B {6671} DATA SET CONTROLLER DIAGS. CIRCUIT DESC., PARTS LIST, CARD PLACEMENT, EQUATION SUMMARY, WIRE LISTS CE MANUAL | 60217400 | W | 22 | ARH |
| RO | SMM17 PROGRAM LISTINGS - MEM | 60220100 | F | 22 | ARH |
| RO | SMM17 PROGRAM LISTINGS - COM | 60220200 | E | 22 | ARH |
| RO | SMM17 PROGRAM LISTINGS - PTP | 60220300 | E | 22 | ARH |
| RO | SMM17 PROGRAM LISTINGS - PTR | 60220400 | E | 22 | ARH |
| RO | SMM17 PROGRAM LISTINGS - TTY | 60220500 | F | 22 | ARH |
| RO | SMM17 PROGRAM LISTINGS - CR1 | 60220600 | D | 22 | ARH |
| RO | SMM17 PROGRAM LISTINGS - MT1 | 60220700 | E | 22 | ARH |
| RO | SMM17 PROGRAM LISTINGS - DP1 | 60220800 | F | 22 | NRM |

CONT.

| 1 | TITLE | 2 | 3 | 4 | 5 |
|-----|---|----------|----|----|-----|
| R0 | SMM17 PROGRAM LISTINGS - RPT | 60220900 | F | 22 | ARH |
| R0 | SMM17 PROGRAM LISTINGS - SC1 | 60221100 | F | 22 | ARH |
| R0 | SMM17 PROGRAM LISTINGS - LP1 | 60221200 | F | 22 | ARH |
| R0 | SMM17 PROGRAM LISTINGS - MT2 | 60221300 | E | 22 | ARH |
| R0 | SMM17 - PROGRAM LISTINGS - MT3 | 60221700 | G | 22 | ARH |
| R0 | FF516-A {1740} LINE PRINTER CONTROLLER CE MANUAL | 60223800 | J | 22 | LJL |
| R | BB323-A {6635-C} EXTENDED CORE STORAGE ASSEMBLY CHASSIS/CABLE TABS CE MANUAL | 60230300 | S | 22 | ARH |
| R | 6000 COMPUTER SYSTEMS SIMULA REFERENCE MAN | 60234800 | F | 22 | SVL |
| R | 6613-D COMPUTER SYSTEM CENTRAL MEMORY CLOCK, ECS COUPLER, POWER DIAGRAMS CE MANUAL | 60246600 | U | 22 | ARH |
| R | 6400/6500-D CENTRAL COMPUTERS CPU, CENTRAL MEMORY, CLOCK, ECS COUPLER AND POWER DIAGRAMS | 60246800 | AG | 22 | ARH |
| R | 6400/6500-D CENTRAL COMPUTERS CHASSIS 1 CHASSIS CABLE TABS | 60246900 | S | 22 | ARH |
| R | 6613-D COMPUTER SYSTEM CHASSIS 4 CHASSIS/ CABLE TABS CE MANUAL | 60247000 | R | 22 | ARH |
| R | 6613-D COMPUTER SYSTEM CHASSIS 8 CHASSIS/ CABLE TABS CE MANUAL | 60247400 | J | 22 | ARH |
| R | 6614-D COMPUTER SYSTEM CHASSIS 9 CHASSIS/ CABLE TABS CE MANUAL | 60247600 | P | 22 | ARH |
| R | 6400/6500-D CENTRAL COMPUTER CHASSIS 3 CHASSIS/CABLE TABS | 60248500 | U | 22 | ARH |
| R | 6400/6500-D CENTRAL COMPUTER CHASSIS 6 CHASSIS/CABLE {FOR 6415-D ONLY} | 60249000 | K | 22 | ARH |
| R | 6400/6500-D CENTRAL COMPUTER CHASSIS 8 CHASSIS/CABLE TABS | 60249100 | S | 22 | ARH |
| RMP | ACTIVE EXPERIMENT NETWORKS | 60250500 | C | 3 | CDI |
| N | 6000 COMPUTER SYSTEMS SCOPE USERS GUIDE VERSION 3.3 | 60252700 | C | 22 | CYB |
| R | FA704-A/B {3553-2} MASS STORAGE CONTROLLER CE MANUAL | 60266000 | AE | 22 | ARH |
| R | SMM17 INSTANT ERROR CODES | 60266200 | G | | ARH |
| R | REFRIGERATION THEORY MAINTENANCE MANUAL | 60268100 | H | 22 | ARH |
| R | 3234-A/B MASS STORAGE CONTROLLER WIRE LIST, EQUATION SUMMARY CE MANUAL | 60268900 | P | 22 | ARH |
| R | AT131-A {10169, 10173-3/4/5, 10174-1/2} CENTRAL MEMORY ACCESS PRIORITY REFER- ENCE CE MANUAL | 60270900 | H | 22 | ARH |
| R0 | SMM17 PROGRAM LISTINGS {CRP} 1728/430 CARD READER/PUNCH CE MANUAL | 60271300 | F | 22 | ARH |
| R0 | SMM17 PROGRAM LISTINGS {CR3} 1729-2/411 CARD READER | 60271400 | F | 22 | ARH |
| R0 | SMM17 PROGRAM LISTINGS {CR2} 1726/405 CARD READER | 60271500 | E | 22 | ARH |
| R0 | SMM17 PROGRAM LISTINGS - 1735/915 OCR OPTICAL CHARACTER READER CE MANUAL | 60271700 | F | 22 | ARH |
| R | AT129-A {10169, 10173-6/7/8/9/10} CENTRAL MEMORY ACCESS PRIORITY OPTION FOR 64/6500 A/B/C REFERENCE/CE MANUAL | 60272700 | G | 22 | ARH |
| R0 | SMM17 DDC 1745/1746/210 DATA DISPLAY CE MAN | 60273200 | E | 22 | ARH |
| R | SECTION 3 PERIPHERAL EQUIPMENT DATA SITE PREPARATION MANUAL | 60275300 | 06 | 22 | ARH |
| R0 | 7700 SYSTEMS DATA SITE PREPARATION MANUAL | 60277800 | B | 22 | ARH |
| R | 1706-A BUFFERED DATA CHANNEL CROSS TABS CE MANUAL | 60284000 | B | 22 | LJL |

CONT.

| 1 | TITLE | 2 | 3 | 4 | 5 |
|----|---|----------|----|----|-----|
| R | AA103-A CENTRAL COMPUTER {6414-E} PERIPHERAL PROCESSOR UNIT DIAGRAMS CE MANUAL | 60284100 | U | 22 | ARH |
| R | 1770/SC-1700 SYSTEM CONTROLLER I/O SPECIFICATIONS | 60285200 | 04 | 22 | LJL |
| R | AA103-A CENTRAL COMPUTER {6614-E} CHASSIS 1 CHASSIS/CABLE TABS CE MANUAL | 60285300 | AD | 22 | ARH |
| R | AA105-A CENTRAL COMPUTER {6414-E} CHASSIS 3 CHASSIS/CABLE TABS CE MANUAL | 60285500 | Z | 22 | ARH |
| R | AA103-A CENTRAL COMPUTER {6614-E} CPW/FUNCTIONAL UNIT DIAGRAMS CE MANUAL | 60287300 | T | 22 | ARH |
| R | BB319-A {6634-C} EXTENDED CORE STORAGE ASSEMBLY, MAINTENANCE, MAINTENANCE AIDS, CE MANUAL | 60289200 | K | 22 | ARH |
| R | FA705-A {3553-1} MASS STORAGE CONTROLLER CE MANUAL | 60290000 | R | 22 | ARH |
| R | FJ427-A {6671-1} DATA SET CONTROLLER INSTALLATION/CHECKOUT, DIAGS, PARTS DATA, WIRE LISTS, EQ SUMMARY CE MANUAL | 60294500 | K | 22 | ARH |
| R | AA103-A CENTRAL COMPUTER {6614-E} CHASSIS 8 CHASSIS/CABLE TABS CE MANUAL | 60294900 | F | 22 | ARH |
| R | DT122-A {7683-1} REMOTE CHANNEL COUPLER REFERENCE/CE MANUAL | 60296200 | H | 22 | ARH |
| R | AA102-A {7601-1} CENTRAL COMPUTER THEORY OF OPERATION, DIAGRAMS, MAINT. AIDS | 60297600 | AC | 22 | ARH |
| RO | SMM3L PROGRAM LISTINGS {MM2} 3300 MEMORY | 60300400 | G | 22 | ARH |
| RO | SMM3L PROGRAM LISTINGS {COM} | 60300600 | E | 22 | ARH |
| RO | SMM3L PROGRAM LISTINGS {FPT} FLOATING POINT TEST | 60300700 | E | 22 | ARH |
| RO | SMM17 PROGRAM LISTINGS - CH2 | 60301500 | G | 22 | ARH |
| RO | SMM3L PROGRAM LISTINGS {MS1} | 60301900 | G | 22 | ARH |
| RO | SMM3L PROGRAM LISTINGS {DVN} EXECUTIVE MODE MONITOR | 60303000 | F | 22 | ARH |
| RO | SMM3L PROGRAM LISTINGS 3L00 QUICK LOOK MEMORY TEST | 60303700 | B | 22 | ARH |
| RO | SMM3L PROGRAM LISTINGS 3L00 QUICK LOOK COMMAND TEST | 60303800 | C | 22 | ARH |
| RO | SMM3L PROGRAM LISTINGS 3200 EXTERNAL EQUIPMENT | 60303900 | E | 22 | ARH |
| RO | SMM3L PROGRAM LISTINGS - RFT | 60304000 | B | 22 | ARH |
| RO | SMM3L PROGRAM LISTINGS MMX INTERRUPT PROC | 60304100 | E | 22 | ARH |
| RO | SMM3L PROGRAM LISTINGS - SIMULATED RANDOM INSTR TEST | 60304500 | B | 22 | ARH |
| RO | SMM3L PROGRAM LISTINGS - 3316 CONTROLLER {CEN} | 60304600 | C | 22 | ARH |
| R | 6000/7000/CYBER 70/CYBER 170 COMPUTER SYS FORTRAN EXTENDED REF/MANUAL VERSION 4 | 60305600 | G | 22 | SVL |
| R | 6000/7000/CYBER 70/CYBER 170 COMPUTER SYS CYBER RECORD MANAGER VERSION 1, 7000 RECORD MANAGER REFERENCE MANUAL | 60307300 | G | 22 | SVL |
| R | 6000/CYBER 70 MODELS 72/73/74 COMPUTER SYS SCOPE INSTALLATION HANDBOOK VERSION 3.4.3 | 60307400 | V | 22 | SVL |
| RO | SMM17 PROGRAM LISTINGS - 0C3 - FF406 TEST CE MANUAL | 60309200 | E | 22 | ARH |
| R | AA105-A CENTRAL COMPUTER {6414-E} DIAGRAMS CE MANUAL | 60316200 | Z | 22 | ARH |
| RO | SMM17 PROGRAM LISTINGS - MTS | 60325800 | E | 22 | ARH |
| RO | SMM17 PROGRAM LISTINGS - 0C4 | 60326400 | D | 22 | ARH |

CONT.

| 1 | TITLE | 2 | 3 | 4 | 5 |
|-----|--|----------|----|----|-----|
| R | 6000/CYBER 70 MODELS 72,73,74 COMPUTER SYS SYMPL REFERENCE MANUAL VERSION 1 | 60328800 | C | 22 | SVL |
| R | FV218-A/B {733-10} HSB SUBSYSTEM TERMINAL CONTROLLER CE MANUAL | 60329700 | V | 22 | ARH |
| R | 1742-A/B {CL309-A/B, FF511-A/B} LINE PRINTER WITH CONTROLLER REFERENCE MANUAL | 60331300 | B | 22 | LJL |
| R | 3248-A/B CARD READER CONTROLLER REF MANUAL | 60332300 | D | 22 | ARH |
| R | 3458-A LINE PRINTER CONTROLLER REF MANUAL | 60332800 | B | 22 | ARH |
| RO | 6681-B/C/D DATA CHANNEL CONVERTOR REF MANUAL | 60334400 | G | 22 | ARH |
| R | 6673/6674 DATA SET CONTROLLER REFERENCE MAN | 60334500 | B | 22 | ARH |
| R | AA105-A CENTRAL COMPUTER {6414-E} CHASSIS & CHASSIS/CABLE TABS CE MANUAL | 60336400 | L | 22 | ARH |
| R | SMM3L PROGRAM LISTINGS - BDP TESTS 3312-A | 60336500 | D | 22 | ARH |
| R | SMM3L PROGRAM LISTINGS - BDP TESTS 3514 | 60336800 | D | 22 | NRM |
| R | SMM3L PROGRAM LISTINGS - 33/3500 PAGE FILE TEST - PFT | 60336900 | D | 22 | ARH |
| RO | SMM3L PROGRAM LISTINGS - 3553-2/821 MS4 | 60337100 | D | 22 | ARH |
| RO | 6000/7600/CYBER 70/CYBER 170 COMPUTER SYS LOADER REF MANUAL | 60344200 | G | 22 | ARH |
| RO | 7600/CYBER 70 MODEL 76 SCOPE 2.1 INSTANT | 60344300 | B | 6 | ARH |
| R | MODEL 72 SYSTEM DESCRIPTION/PROGRAMMING INFO VOLUME 1 | 60347000 | H | 22 | ARH |
| R | MODEL 73 SYSTEM DESC/PROGRAMMING INFO VOLUME 1 | 60347200 | E | 22 | ARH |
| R | MODEL 72/73/74 INSTRUCTION DESC VOLUME 2 | 60347300 | J | 22 | ARH |
| R | MODEL 74 SYSTEMS DESC/PROGRAMMING INFO VOLUME 1 | 60347400 | K | 22 | ARH |
| RO | AF104-A {1ST OP 10256} 3200 BUSINESS DATA PROCESSOR INTERFACE CE MANUAL | 60347600 | C | 22 | PLY |
| RO | 10256 {AF101-C, AF104-A} 3200 BDP OPTION REFERENCE MANUAL | 60347700 | B | 22 | PLY |
| R | AC113-A CENTRAL COMPUTER THEORY OF OPERATION DIAGRAMS, MAINTENANCE CE MANUAL | 60348000 | AB | 22 | ARH |
| R | AC113-A CENTRAL COMPUTER LCM STACK WIRE LIST CE MANUAL | 60349600 | D | 22 | ARH |
| R | AA115-A {72-XX, 73-XX} BASIC UNIFIED PROCESSOR CHASSIS 1,3,11 WIRE LIST CE MAN | 60350200 | R | 22 | ARH |
| R | AA115-A {72-XX, 73-XX} BASIC UNIFIED PROCESSOR CHASSIS 2,6 WIRE LIST CE MANUAL | 60350300 | V | 22 | ARH |
| RMP | AA115-A {72-XX, 73XX} BASIC UNIFIED PROCESSOR CHASSIS 3 WIRE LIST CE MANUAL | 60350400 | L | 22 | ARH |
| R | AA115-A {72-XX, 73-XX} BASIC UNIFIED PROCESSOR CHASSIS 4 WIRE LIST CE MANUAL | 60350500 | AC | 22 | ARH |
| R | AA115-A {72-XX, 73-XX} BASIC UNIFIED PROCESSOR CHASSIS 7 WIRE LIST CE MANUAL | 60350800 | K | 22 | ARH |
| R | AA115-A {72-XX, 73-XX} BASIC UNIFIED PROCESSOR CHASSIS 8 WIRE LIST CE MANUAL | 60350900 | R | 22 | ARH |
| R | AA117-A {74-XX} PARALLEL PROCESSOR CHASSIS 12 WIRE LIST CE MANUAL | 60351300 | L | 22 | ARH |
| RO | PASSIVE ELECTRONICS STUDENT MANUAL | 60354500 | G | 3 | CDI |
| R | DK518-A {7681-1} DATA CHANNEL CONVERTER CE MANUAL | 60355900 | F | 22 | ARH |
| RO | 6000/CYBER 70 MODELS 72,73,74 COMPUTER SYS SCOPE VERSION 3.3 TO SCOPE VERSION 3.4 CONVERSION AIDS PROGRAMMING SYSTEMS BULLETIN | 60358200 | D | 22 | SVL |
| R | 6000/CYBER 70 MODELS 72,73,74 COMPUTER SYS DATA DESCRIPTION | 60359000 | B | 22 | SVL |

CONT.

| 1 | TITLE | 2 | 3 | 4 | 5 |
|-----|---|----------|---|----|-----|
| RO | 6000/CYBER 70 COMPUTER SYSTEMS DDL FOR THE QUERY UPDATE SUBSCHEMA {QUIDDL} REFERENCE MANUAL | 60359200 | C | 22 | SVL |
| R | 6000/CYBER 70/CYBER 170 COMPUTER SYSTEMS & BIT SUBROUTINES REF MANUAL VER 1.0 | 60359400 | C | 22 | SVL |
| RO | 1700 COMPUTER SYSTEMS MSOS VERSION 4 REFERENCE MANUAL | 60361500 | D | 22 | LJL |
| R | 1700 COMPUTER SYSTEMS MSOS DIAGNOSTIC HANDBOOK VERSION 4 | 60361800 | D | -- | LJL |
| R | 1700 COMPUTER SYSTEMS 1700 MSOS 4 MS FORTRAN 3A/B REFERENCE MANUAL | 60362000 | D | 22 | LJL |
| R | 7054-1 {DT209-C, FA710-A-F, FA719-A-D, MA710-A/B} OPERATION AND PROGRAMMING MANUAL | 60363900 | J | 22 | ARH |
| R | DT209-C {7054-1/2} 6000 COUPLER REF/CE MAN | 60364100 | R | 22 | ARH |
| RO | 7054-1 {DT209-C, FA710-A/B/C/D/E/F, FA719- A/B/C/D/MA710-A/B} GEN INFO MANUAL | 60364400 | D | 22 | ARH |
| R | FA710-A/B/C/D {7054-1} DISK CONTROLLER HARDWARE REFERENCE MANUAL | 60364500 | G | 22 | ARH |
| RMP | 7600/CYBER 70 MODEL 76 COMPUTER SYSTEMS HARDWARE REFERENCE MANUAL | 60367200 | C | 22 | ARH |
| R | GH 214-B 10-TON CONDENSING UNIT REFRIGERA- TION CE MANUAL | 60367300 | G | 22 | ARH |
| R | DC135-A {6642-1, 7030-XX} DISTRIBUTIVE DATA PATH CE MANUAL | 60369400 | D | 22 | ARH |
| R | AA115-A {72-XX, 73-XX} BASIC UNIFIED PRO- CESSOR CHASSIS 1,3,11 DIAGRAMS CE MAN | 60369700 | R | 22 | ARH |
| R | AA115-A {72-XX, 73-XX} BASIC UNIFIED PRO- CESSOR CHASSIS 4 DIAGRAMS CE MANUAL | 60370100 | Z | 22 | ARH |
| R | AA115-A {72-XX, 73-XX} BASIC UNIFIED PRO- CESSOR CHASSIS 3 DIAGRAMS CE MANUAL | 60370200 | M | 22 | ARH |
| R | AT145-A/B/C {10173} ADDITIONAL PPU CHASSIS FOR 6000 COMPUTERS {INCR TO 20 PPU'S} CE MANUAL | 60370600 | K | 22 | ARH |
| R | AA117-A {74-XX} PARALLEL PROCESSOR CHASSIS 4,5,6,7,8 DIAGRAMS MANUAL | 60370800 | R | 22 | ARH |
| R | AA117-A {74-XX} PARALLEL PROCESSOR CHASSIS 9 DIAGRAMS MANUAL | 60370900 | P | 22 | ARH |
| R | AE116-D {74-2X} SECOND CENTRAL PROCESSOR CHASSIS 2 WIRE LIST CE MANUAL | 60371000 | J | 22 | ARH |
| R | AA117-A {74-XX} PARALLEL PROCESSOR CHASSIS 4 WIRE LIST CE MANUAL | 60371100 | K | 22 | ARH |
| R | AA117-A {74-XX} PARALLEL PROCESSOR CHASSIS WIRE LIST CE MANUAL | 60371200 | S | 22 | ARH |
| R | 3100/3150/3170/3200/3300/3500 COMPUTER SYS MASTER/MSOS ALGOL VERSION 1 REF MANUAL | 60371800 | C | 22 | ARH |
| RO | 6000/7600/CYBER/CYBER 170 COMPUTER SYSTEMS LOADER INSTANT | 60372200 | B | | ARH |
| R | SMM V 3 OPERATORS GUIDE | 60373800 | C | 22 | ARH |
| RO | CYBER 76 SMM V3 REFERENCE MANUAL | 60373900 | C | 22 | ARH |
| R | AE116-B {10174-X} SECOND CENTRAL PROCESSOR CONVERTS A 6600-A/B/C WITH SPIGOTS TO A 6700-A/B/C DIAGRAMS, WIRE LIST CE MANUAL {CH. 12} | 60374800 | D | 22 | ARH |
| R | AA115-A {72-XX, 73-XX} BASIC UNIFIED PRO- CESSOR CHASSIS 5 DIAGRAMS CE MANUAL | 60377200 | G | 22 | ARH |
| RMP | AA115-A {72-XX, 73-XX} BASIC UNIFIED PRO- CESSOR CHASSIS 8 DIAGRAMS CE MANUAL | 60377300 | L | 22 | ARH |

CONT.

| 1 | TITLE | 2 | 3 | 4 | 5 |
|----|---|----------|---|----|-----|
| R | 3100 SOFTWARE STUDENT MANUAL | 60380400 | A | 3 | CDI |
| R | AT154-A {10173-X} ADDITIONAL MEMORY ACCESS FOR 6613-A/B/C CHASSIS 5 WIRE LIST CE MANUAL | 60380800 | G | 22 | ARH |
| R | AA115-A {72-XX,73-XX} BASIC UNIFIED PRO- CESSOR REFRIGERATION SYSTEM CE MANUAL | 60382300 | C | 22 | ARH |
| R | AA117-A {74-XX} PARALLEL PROCESSOR CHASSIS 10 DIAGRAMS MANUAL | 60382600 | D | 22 | ARH |
| R | AA117-A {74-XX} PARALLEL PROCESSOR CHASSIS 11 DIAGRAMS MANUAL | 60382700 | C | 22 | ARH |
| R | AA117-A {74-XX} PARALLEL PROCESSOR CHASSIS 12 DIAGRAMS MANUAL | 60382800 | H | 22 | ARH |
| R | 6000/7600/CYBER 70 MODELS 72,73,74,76 COM- PUTER SYSTEMS ALGOL REF MAN VER 4 | 60384700 | C | 22 | SVL |
| R | 6000/CYBER 70 MODELS 72,73,74 COMPUTER SYSTEMS QUERY UPDATE VERSION 2 | 60384900 | D | 22 | SVL |
| R | 6000/CYBER 70 MODELS 72/73/74 COMPUTER SYS QUERY UPDATE MINI USER GUIDE VER 2 | 60385500 | C | 22 | SVL |
| RO | 6000/7600/CYBER 70 MODELS 72/73/74 COMPUTER SYSTEMS FORTRAN COMMON LIBRARY | 60387900 | B | 22 | SVL |
| R | MATHEMATICAL ROUTINES | | | | |
| R | 6682-A SATELLITE COUPLER CE MANUAL | 60390100 | E | 22 | ARH |
| R | AT153-A {10173-4/5,10174-2} ADDITIONAL CENTRAL MEMORY ACCESS FOR 6614-A/B/C COMPUTER SYSTEM CHASSIS 5 WIRE LISTS CE MANUAL | 60391900 | D | 22 | ARH |
| R | AT251-A {CYBER 72,73,74} EXTERNAL DATA CHANNEL | 60392700 | F | 22 | ARH |
| R | FA705-B {3553-1} MASS STORAGE CONTROLLER CE MANUAL | 60394600 | D | 22 | ARH |
| R | FA705-C {3053-2} MASS STORAGE CONTROLLER CE MANUAL | 60394700 | H | 22 | ARH |
| R | 3234-D/E MASS STORAGE CONTROLLER CE MANUAL | 60394800 | D | 22 | ARH |
| R | AA121-A {7700} CENTRAL COMPUTER CHANNEL TABS WIRE LISTS CE MANUAL | 60398200 | B | 22 | ARH |
| R | AD102-A {7700} ADJUNCT PROCESSOR CHANNEL TABS, WIRE LISTS CE MANUAL | 60399200 | B | 22 | ARH |
| R | 6671-3 {FJ440-A} DATA SET CONTROLLER HARDWARE REFERENCE MANUAL | 60399900 | B | 22 | ARH |
| R | FA102-A {1733-1} DISK STORAGE CONTROLLER CE MANUAL | 60400100 | F | 22 | LJL |
| R | AT194-A {6500-D OR 6500-E WITH ECS. CAPABILITY FOR 6400-D WITH AT198-A CHASSIS 2,6,3,8 DIAGRAMS WIRE LIST CE MANUAL | 60401200 | G | 22 | ARH |
| R | FA401-A/B {7021-1} 1X8 MAG TAPE CONTROLLER CE MANUAL | 60404100 | G | 22 | ARH |
| R | 7600/CYBER 70 MODEL 76 COMPUTER SYSTEMS SCOPE 2.1 ON-LINE MAINT PROGRAMS REFERENCE MANUAL | 60406200 | D | 22 | ARH |
| R | 6000/CYBER 70 MODELS 72,73,74 COMPUTER SYSTEMS KRONOS 2.1 REFERENCE MANUAL | 60407000 | C | 22 | ARH |
| R | 6000/CYBER 70 MODELS 72,73,74 COMPUTER SYS KRONOS 2.1 INSTALLATION HANDBOOK | 60407500 | K | 22 | ARH |
| R | 6000/CYBER 70 MODELS 72,73,74 COMPUTER SYS KRONOS 2.1 TIMESHARING USERS REF MAN | 60407600 | C | 22 | ARH |

CONT.

| 1 | TITLE | 2 | 3 | 4 | 5 |
|----|--|----------|----|----|-----|
| R | 6000/CYBER 70 MODELS 72,73,74 COMPUTER SYS KRONOS 2.1 OPERATORS GUIDE | 60407700 | D | 22 | ARH |
| R | 3100/3150/3170/3200/3300/3500 COMPUTER SYS MSOS VERSION 5 OPERATING SYSTEM REFERENCE MANUAL | 60410600 | C | 22 | ARH |
| RO | 3100/3150/3170/3200/3300/3500 COMPUTER SYS MSOS VERSION 5 OPERATORS GUIDE | 60410700 | B | 22 | ARH |
| R | 3100/3150/3170/3200/3300/3500 COMPUTER SYS MSOS VERSION 5 INSTALLATION HANDBOOK | 60410800 | D | 22 | ARH |
| R | 3100/3150/3170/3200/3300/3500 COMPUTER SYS MSOS VERSION 5 DIAGNOSTIC HANDBOOK | 60410900 | C | 22 | ARH |
| N | 3100/3150/3170/3200/3300/3500 COMPUTER SYS MSOS VERSION 5 INSTANT | 60411000 | A | | ARH |
| RO | SMM17 PROGRAM LISTINGS - DMP | 60411500 | C | 22 | ARH |
| RO | SMM17 PROGRAM LISTINGS - AQM | 60412100 | C | 22 | ARH |
| RO | SMM17 PROGRAM LISTINGS - LST | 60412200 | C | 22 | ARH |
| RO | SMM17 PROGRAM LISTINGS - MCC | 60412400 | C | 22 | ARH |
| RO | SMM17 PROGRAM LISTINGS - CDD | 60412700 | C | 22 | ARH |
| RO | SMM17 PROGRAM LISTINGS - DRM | 60412800 | D | 22 | ARH |
| RO | SMM17 PROGRAM LISTINGS - IOM | 60413100 | C | 22 | ARH |
| RO | SMM17 PROGRAM LISTINGS - DP3 | 60413900 | D | 22 | ARH |
| RO | SMM17 PROGRAM LISTINGS - EDT | 60414700 | C | 22 | ARH |
| R | 3170/3300/3500 COMPUTER SYSTEMS MASTER VERSION 4.0 INSTALLATION HANDBOOK | 60415100 | C | 22 | ARH |
| R | 3170/3300/3500 COMPUTER SYSTEMS MASTER VERSION 4.0 REFERENCE MANUAL | 60415400 | C | 22 | ARH |
| R | 3170/3300/3500 COMPUTER SYSTEMS MASTER VERSION 4.0 LIBRARY GENERATION AND MAINTENANCE MANUAL | 60415500 | C | 22 | ARH |
| R | 3170/3300/3500 COMPUTER SYSTEMS MASTER VERSION 4.0 DIAGNOSTIC HANDBOOK | 60415800 | C | 22 | ARH |
| R | AT149-A {ST.OP.10173} ADDITIONAL MEMORY ACCESS OPTION FOR 6414-A/B/C, 6514- A/B/C CABLE TABS {AT149-A ONLY} CE MANUAL | 60416000 | E | 22 | ARH |
| R | AE116-D {74-2X} SECOND CENTRAL PROCESSOR CHASSIS 2 DIAGRAMS CE MANUAL | 60416700 | G | 22 | ARH |
| R | 6500-D WITH ECS CAPABILITY AT198-A/6500-D CONVERSION AND DT143-A ECS KIT DT 205-- A ECS INTERFACE LOGIC, AT194-A 6500 ECS CONVERSION THEORY OF INSTALLATION, DIAGRAMS, MAINT AIDS, WIRE LISTS CE MANUAL | 60417600 | A | 34 | ARH |
| N | STANDARD OPTIONS 10309-1 AND 10309-2 GO MODE SDL FOR THE AC104-A AND AC106-A/B CE MANUAL | 60420100 | A | 22 | ARH |
| RO | CYBER 170-MODEL 175 SYSTEMS DATA SITE PREPARATION MANUAL | 60420600 | D1 | 22 | ARH |
| N | CYBER 170 MODEL 175 CENTRAL COMPUTER AND ALL OPTIONS MAINTENANCE, PARTS DATA HARDWARE MAINTENANCE MANUAL | 60420700 | A | 22 | ARH |
| N | CYBER 170 MODEL 175 POWER DISTRIBUTION AND WARNING SYSTEM GEN DESC., OPERATION, THEORY OF OPER., DIAGS, APPENDIX AND WIRE LIST HARDWARE MAINTENANCE MANUAL | 60421400 | C | 22 | ARH |
| R | AC113-B CENTRAL COMPUTER CHASSIS 6 WIRE LIST CE MANUAL | 60421500 | C | 22 | ARH |
| R | AC113-B CENTRAL COMPUTER CHASSIS 7 WIRE LIST CE MANUAL | | | | |

CONT.

| 1 | TITLE | 2 | 3 | 4 | 5 |
|----|---|----------|---|----|-----|
| R | AC113-B CENTRAL COMPUTER CHASSIS 8 WIRE LIST CE MANUAL | 60421600 | D | 22 | ARH |
| R | AC113-B CENTRAL COMPUTER CHASSIS 9 WIRE LIST CE MANUAL | 60421700 | B | 22 | ARH |
| R | AC113-B CENTRAL COMPUTER CHASSIS 10 WIRE LIST CE MANUAL | 60421800 | C | 22 | ARH |
| R | AC113-B CENTRAL COMPUTER CHASSIS 12 WIRE LIST CE MANUAL | 60422000 | C | 22 | ARH |
| R | AC113-B CENTRAL COMPUTER CHASSIS 13 WIRE LIST CE MANUAL | 60422100 | B | 22 | ARH |
| RO | SMM17 PROGRAM LISTINGS - MY2 | 60422300 | C | 22 | ARH |
| RO | SMM17 PROGRAM LISTINGS - MY1 | 60422400 | C | 22 | ARH |
| RO | SMM17 PROGRAM LISTINGS - DP5 | 60422900 | C | 22 | ARH |
| R | FE202-A/B {415-30} CARD PUNCH CONTROLLER REFERENCE/CE MANUAL | 60425600 | C | 22 | ARH |
| N | DC145-A/B DISTRIBUTIVE DATA PATH/DT221-A REGISTER GEN DESC, OPERATION, INSTALLATION, AND CHECKOUT, THEORY OF OPERATION DIAGRAMS, MAINT., PARTS DATA, WIRE LISTS CABLE TABS HARDWARE MAINT MAN | 60425800 | A | 22 | ARH |
| N | CYBER 70 MODEL 76 {AA106-A} CYBER 170 MODEL 175 REFRIGERATION SYSTEM, GEN DESC., OPERATION, INSTALLATION AND CHECKOUT, THEORY OF OPERATION, DIAGRAMS, MAINT., PARTS DATA, APPENDIX, WIRE LISTS, HARDWARE MAINTENANCE MANUAL | 60427800 | A | 22 | ARH |
| R | FA722-A/B {7054-21/22/41/42} DISK STORAGE CONTROLLER HARDWARE MAINTENANCE MANUAL | 60428500 | J | 22 | ARH |
| N | AA106-A CENTRAL COMPUTER/AB101-A, AB102-A/B, AT174-A PERIPHERAL PROCESSOR UNIT MAINTENANCE CE MANUAL | 60429900 | A | 22 | ARH |
| N | GH506-A/B POWER DISTRIBUTION UNIT USED WITH POWER DISTRIBUTION AND WARNING SYSTEM | 60433400 | A | 22 | ARH |
| N | AA106-A CENTRAL COMPUTER A/B102-A/B I/O STATION CABINET/GK171-A I/O STATION CABINET MODIFICATION KIT CE MAN | 60433600 | A | 22 | ARH |
| N | AA106-A {BS101/2-A, BB360-B, AT311/312-A} CENTRAL COMPUTER INSTALLATION AND CHECKOUT, THEORY OF OPERATION, DIAGS., MAINT. AIDS, PARTS DATA VOLUMES 1-3 CE MANUAL | 60433700 | A | 22 | ARH |
| N | AA106-A {BS101/2-A, BB360-B, AT311/312-A} CENTRAL COMPUTER | 60433800 | A | 22 | ARH |
| N | CHASSIS 7 WIRE LISTS CE MANUAL | 60433900 | A | 22 | ARH |
| N | CHASSIS 8 WIRE LISTS CE MANUAL | 60434700 | A | 22 | ARH |
| N | CHASSIS 9 WIRE LISTS CE MANUAL | 60434800 | A | 22 | ARH |
| N | CHASSIS 2 WIRE LISTS CE MANUAL | 60434900 | A | 22 | ARH |
| N | CHASSIS 3 WIRE LISTS CE MANUAL | 60435000 | A | 22 | ARH |
| N | CHASSIS 4 WIRE LISTS CE MANUAL | 60435100 | A | 22 | ARH |
| N | CHASSIS 5 WIRE LISTS CE MANUAL | 60436600 | A | 22 | ARH |
| N | CHASSIS 6 WIRE LISTS CE MANUAL | | | | |
| N | 6000/CYBER 70/CYBER 170/COMPUTER SYSTEMS ON LINE MAINTENANCE SOFTWARE REFERENCE MANUAL, KRONOS 2.1-X/NO5 V1.0.0 | 60436600 | A | 22 | ARH |
| N | SYSTEM 17 SERIES MINI COMPUTER SYSTEMS SITE PREPARATION MAN SECTION 1, GEN SITE REQUIREMENT | 60437000 | A | 22 | ARH |

CONT.

| 1 | TITLE | 2 | 3 | 4 | 5 |
|----|---|----------|-----|----|-----|
| N | SYSTEM 17 SERIES MINI COMPUTER SYSTEMS SITE PREPARATION MAN SECTION 2 - SYSTEM DATA | 60437100 | A | 22 | ARH |
| N | SYSTEM 17 SERIES MINI COMPUTER SYSTEMS SITE PREPARATION SECTION 3 - PERIPHERAL EQUIPMENT DATA | 60437200 | A | 22 | ARH |
| RO | SMM17 PROGRAM LISTINGS {GT0} | 60437400 | B | 22 | ARH |
| RO | SMM17 PROGRAM LISTINGS {GT1} | 60437500 | B | 22 | ARH |
| RO | SMM17 PROGRAM LISTINGS - GT2 | 60437600 | B | 22 | ARH |
| RO | SMM17 PROGRAM LISTINGS - GT3 | 60437700 | B | 22 | ARH |
| RO | SMM17 PROGRAM LISTINGS - GT5 | 60437900 | B | 22 | ARH |
| RO | SMM17 PROGRAM LISTINGS - GT6 | 60438000 | B | 22 | ARH |
| RO | SMM17 PROGRAM LISTINGS - LP5 | 60438100 | B | 22 | ARH |
| RO | SMM17 PROGRAM LISTINGS - KEY | 60438400 | B | 22 | ARH |
| N | FA444-A/B, FF445-A/B MAGNETIC TAPE CONTROLLER MB434-A CONTROLWARE INSTALLATION AND CHECKOUT, MAINTENANCE, DIAGS, GEN DESC., OPERATION, THEORY OF OPER., PARTS DATA, WIRE LISTS, LEVEL 2 HARDWARE MAINTENANCE MANUAL VOLUMES 1-3 | 60438500 | A | 22 | ARH |
| RO | SMM17 PROGRAM LISTINGS - MDC | 60438600 | B | 22 | ARH |
| R | 6640-D EXTENDED CORE STORAGE CONTROLLER GEN. DESC., OPER., THEORY OF OPER., INSTALLATION AND CHECKOUT, MAINT., DIAGS, PARTS DATA, APPENDIX AND WIRE LISTS CE MANUAL | 60440500 | B | 22 | ARH |
| N | 6681-F DATA CHANNEL CONVERTER GEN DESC., OPERATION, INSTALLATION AND CHECKOUT, THEORY OF OPER., DIAGS., MAINT., PARTS DATA, WIRE LIST, CE MANUAL | 60440800 | A | 22 | ARH |
| N | 6000/CYBER 70 MODELS 72,73,74 COMPUTER SYS AUTOMATED INTEGRATED DESIGN SYSTEM, SEMIAUTOMATIC ARTWORK GENERATION {SAAG} USERS GUIDE | 60441000 | A | 22 | ARH |
| N | 6000/CYBER 70 MODELS 72,73,74 COMPUTER SYS AUTOMATED INTEGRATED DESIGN SYSTEM GENERAL PURPOSE WIRE WRAP {GPWW} USERS GUIDE | 60443100 | A | 22 | ARH |
| N | SMM17 PROGRAM LISTINGS - DPC | 60446100 | A | 22 | ARH |
| N | SMM17 PROGRAM LISTINGS - MTX | 60446200 | A | 22 | ARH |
| N | SMM17 PROGRAM LISTINGS - PET | 60446300 | A | 22 | ARH |
| N | SMM17 PROGRAM LISTINGS - PAD | 60446400 | A | 22 | ARH |
| N | SMM17 PROGRAM LISTINGS - BDL | 60446500 | A | 22 | ARH |
| N | SMM17 PROGRAM LISTINGS - REP | 60446600 | A | 22 | ARH |
| N | SMM17 PROGRAM LISTINGS - INS | 60446700 | A | 22 | ARH |
| N | SMM17 PROGRAM LISTINGS - CMD | 60446800 | A | 22 | ARH |
| N | SMM17 PROGRAM LISTINGS - CPY | 60447700 | A | 22 | ARH |
| RO | 6000/CYBER 170/CYBER 70 MODELS 72,73,74 COMPUTER SYSTEMS CYBER RECORD MANAGER VERSION 1.1 MULTIPLE INDEX PROCESSOR PROGRAMMING SYSTEMS BULLETIN | 60492900 | B | 22 | SVL |
| N | 6000/7600/CYBER 70/CYBER 170 COMPUTER SYS CYBER COMMON UTILITIES REF MANUAL | 60493300 | A | 3 | SVL |
| N | 6000/CYBER 70 MODELS 72,73,74 COMPUTER SYS SCOPE INTEGRATED SCHEDULER TUNING GUIDE PROGRAMMING SYSTEMS BULLETIN | 60493500 | A | 22 | SVL |
| N | HOSPITAL COMMUNICATIONS SYSTEM DIGISCRIBE OPTION OPERATORS GUIDE {QSE 10892} | 62995800 | A-0 | | LJL |

CONT.

| 1 | TITLE | 2 | 3 | 4 | 5 |
|----|---|----------|-----|----|-----|
| N | CV403-A {10892} HOSPITAL COMMUNICATIONS SYSTEM DIGISCRIBE OPTION ON-ISTE MAINTENANCE MANUAL | 62995900 | A-0 | 22 | LJL |
| N | CV403-A DIGISCRIBE OPTION REPAIR CENTER CE MANUAL | 62996000 | A-0 | 22 | LJL |
| N | AN/UJK-25{V} DATA PROCESSING SET INCLUDING CP1201{V}/UJK-25 {V} DIGITAL DATA COMPUTER {5601 SERIES} MU/618/UJK-25 {V} CORE MEMORY UNIT {5604 SERIES} REFERENCE MANUAL | 69651800 | | 22 | MSP |
| RO | CJ112 PAGE READER G-H {CS/N151-200} DIAGRAMS CE MANUAL | 70601700 | E | 22 | ROK |
| RO | 33301/33302 SUBSYSTEMS ON-LINE DIAGNOSTICS MANUAL {COLDS} | 70602900 | D | 22 | NRM |
| N | BR281 DISK STORAGE UNIT DIAGRAMS AND WIRE LISTS CE MANUAL | 70607900 | D | 22 | NRM |
| RO | 33301 MULTIPLE DISK SYSTEM INSTALLATION CE MANUAL | 70608100 | G | 22 | NRM |
| R | 33301 MULTIPLE DISK SYSTEM TROUBLESHOOTING MANUAL | 70608200 | C | 22 | NRM |
| R | BR1A9-B VOICE COIL DRIVE PARTS DATA B01 AND ABOVE CE MANUAL | 70609300 | J | 22 | NRM |
| R | BR281 DISK STORAGE UNIT MAINTENANCE MANUAL | 70612500 | C | 3 | NRM |
| R | TB301-A/B FIELD TEST EXERCISER MAINTENANCE MANUAL | 70612800 | G | 3 | NRM |
| R | FA7A4-A/B PLUG COMPATIBLE CONTROLLER MAINT CE MANUAL | 70613800 | G | 22 | NRM |
| R | BR2A1-D DISK STORAGE UNIT MAINTENANCE MANUAL | 70616300 | C | 22 | NRM |
| R | BR2A1-L DISK STORAGE UNIT DIAGRAMS CE MANUAL | 70616400 | F | 22 | NRM |
| R | BR1A9 DISK STORAGE UNIT DIAGRAMS, WIRE LISTS, MAINT. AIDS {MODS B03 AND ABOVE} | 70617100 | H | 22 | NRM |
| R | BR5A1 DISK STORAGE UNIT MAINTENANCE MANUAL | 70617800 | E | 22 | NRM |
| R | BR5A1 DISK STORAGE UNIT PARTS DATA CE MANUAL | 70618000 | P | 22 | NRM |
| R | BR1B3 DISK STORAGE UNIT PARTS DATA CE MANUAL | 70620600 | G | 22 | NRM |
| R | FR113-A {731-10/12-732-10/12} BUFFER CONTROLLER MAINTENANCE CE MANUAL | 70621400 | F | 22 | NRM |
| R | BR2A7 DISK STORAGE UNIT DIAGRAMS AND WIRE LIST | 70622200 | L | 22 | NRM |
| RM | BR2A8 DISK STORAGE UNIT DIAGRAMS AND WIRE LISTS CE MANUAL | 70622300 | M | 22 | NRM |
| R | BR2A8 DISK STORAGE UNIT MAINTENANCE CE MAN | 70622400 | G | 22 | NRM |
| R | BR2A7 DISK STORAGE UNIT PARTS DATA CE MANUAL | 70622500 | M | 22 | NRM |
| R | BR2A6-B DISK STORAGE UNIT MAINT. CE MANUAL | 70622600 | H | 22 | NRM |
| R | BR2A6-B DISK STORAGE UNIT PARTS DATA CE MAN | 70622800 | N | 22 | NRM |
| R | BR5A2 DISK STORAGE UNIT MAINTENANCE MANUAL | 70624500 | G | 22 | NRM |
| R | BR5A2 DISK STORAGE UNIT PARTA DATA CE MANUAL | 70624700 | J | 22 | NRM |
| R | BR304 DISK STORAGE UNIT MAINTENANCE CE MAN | 70627900 | D | 22 | NRM |
| R | BR304 DISK STORAGE UNIT GENERAL DESCRIPTION, OPERATION, THEORY OF OPERATION, KEY TO LOGIC, INTEGRATED/DISCRETE CIRCUITS CE MANUAL | 70628000 | C | 22 | NRM |
| R | BR304 DISK STORAGE UNIT PARTS DATA CE MANUAL | 70628100 | C | 22 | NRM |
| R | BR3B4 DISK STORAGE UNIT MAINTENANCE MANUAL | 70628200 | L | 3 | NRM |
| R | BR3B4 DISK STORAGE UNIT MAINTENANCE MANUAL | 70628400 | G | 3 | NRM |
| N | BR5A3 DISK STORAGE UNIT GEN DESC., OPER., INSTALLATION/CHECKOUT, THEORY OF OPER., MAINTENANCE CE MANUAL | 70628500 | B | 22 | NRM |
| N | BR5A3 DISK STORAGE UNIT DIAGRAMS AND WIRE LISTS CE MANUAL | 70628600 | D | 22 | NRM |

CONT.

| 1 | TITLE | 2 | 3 | 4 | 5 |
|-----|--|----------|---|----|-----|
| R | BR501 DISK STORAGE UNIT GENERAL DESCRIPTION, OPERATION, THEORY OF OPERATION CE MANUAL | 70629200 | F | 22 | NRM |
| RMP | BR501 DISK STORAGE UNIT PREVENTIVE AND CORRECTIVE MAINTENANCE DIAGRAMS AND WIRE LISTS CE MANUAL | 70629300 | M | 22 | NRM |
| R | BR501 DISK STORAGE UNIT PARTS DATA CE MANUAL | 70629400 | K | 22 | NRM |
| R | BR303 DISK STORAGE UNIT GENERAL DESCRIPTION, OPERATION, THEORY OF OPERATION CE MAN | 70629500 | C | 22 | NRM |
| R | BR303 DISK STORAGE UNIT INSTALLATION/CHECK-OUT, PREVENTIVE/CORRECTIVE MAINT, DIAGRAMS WIRE LIST, CE MANUAL | 70629600 | H | 22 | NRM |
| R | BR303 DISK STORAGE UNIT PARTS DATA CE MANUAL | 70629700 | J | 22 | NRM |
| N | BR3B5 DISK STORAGE UNIT PARTS DATA MANUAL | 70630500 | F | 3 | NRM |
| R | BJ5XX STORAGE MODULE DRIVE MAINTENANCE MAN | 70630900 | K | 3 | NRM |
| R | BJ5XX STORAGE MODULE DRIVE PARTS DATA CE MAN | 70631100 | L | 3 | NRM |
| N | BR2B2/3 DISK STORAGE UNIT GEN. DESC., MAINTENANCE CE MANUAL | 70631300 | D | 22 | NRM |
| R | BR2B2/3 DISK STORAGE UNIT DIAGRAMS AND WIRE LISTS CE MANUAL | 70631400 | F | 22 | NRM |
| R | BR2B2/3 DISK STORAGE UNIT PARTS DATA CE MAN | 70631500 | G | 22 | NRM |
| N | CYBER 1000 {FA101-A, DY128-A} DISK PACK CONTROLLER HARDWARE MAINTENANCE MANUAL | 73361200 | B | 22 | STA |
| N | CYBER 1000 MAGNETIC TAPE CONTROLLER DY120-A, FA419-A HARDWARE MAINTENANCE MANUAL | 74607500 | | 22 | STA |
| N | CYBER 1000/3000 SERIES CONTROLLER-ADAPTER {DY122-A} HARDWARE MAINTENANCE MANUAL | 74660300 | A | 22 | STA |
| N | CYBER 1000 {DY127-A} HIGH-SPEED LINE CONTROLLER HARDWARE MAINTENANCE MANUAL | 74664300 | A | 22 | STA |
| N | CYBER 1000/1700 SERIES {DY123-A} CONTROLLER ADAPTER HARDWARE MAINTENANCE MANUAL | 74675500 | A | 22 | STA |
| N | DY121-A {CYBER 1000} FAST DISK CONTROLLER HARDWARE MAINTENANCE MANUAL | 74691800 | A | 22 | STA |
| N | DW110-A {CYBER 1000} TWO BAY EXCHANGE UNIT HARDWARE MAINTENANCE MANUAL | 74717600 | A | 22 | STA |
| N | DW105-A/DW111-A {CYBER 1000} THREE BAY EXCHANGE UNIT HARDWARE MAINTENANCE MAN | 74720400 | A | 22 | STA |
| N | DY124-A/DY129-A {CYBER 1000} CONTROLLER EXTENSION CABINETS HARDWARE MAINT MAN | 74720500 | A | 22 | STA |
| N | DY107-110-A {CYBER 1000} LINE MODULE EXTENSION CABINET HARDWARE MAINT MANUAL | 74724500 | A | 22 | STA |
| N | 6000/CYBER 70 MODELS 72,73,74 COMPUTER SYSTEMS MARS VI REF MANUAL FOR PARTIAL INVERSION KRONOS 2.1 USAGE | 76070100 | | 3 | CYB |
| N | 6000 CYBER 70 MODELS 72,73,74 COMPUTER SYS TOTAL-CDC REFERENCE MANUAL VERSION 1 | 76070300 | | 3 | CYB |
| N | 1FMS-INTERACTIVE FINANCIAL MODELING SYSTEM USER INFORMATION MANUAL | 76070400 | | 3 | CYB |
| N | SYSCAP-II - SYSTEM OF CIRCUIT ANALYSIS PROGRAMS U.I.M. | 76070600 | | 3 | CYB |
| R | CC-TEGAS3-TEST GENERATION AND SIMULATION SYSTEM USER INFORMATION MANUAL | 76070700 | A | 3 | CYB |
| N | SYSTEMS PROFESSIONAL PROGRAMS COST GUIDE USER COST GUIDE | 76070800 | | 3 | CYB |
| N | ANSYS - ENGINEERING ANALYSIS SYSTEM EXAMPLES MANUAL | 76070900 | | 3 | CYB |
| N | XEDIT-EXTENDED KRONOS TEXT EDITOR U.I.M. | 76071000 | | 3 | CYB |
| N | FASTIME/LOADFLOW-POWER SYSTEM ANALYSIS USER INFORMATION MANUAL | 76071200 | | 3 | CYB |

CONT.

| 1 | TITLE | 2 | 3 | 4 | 5 |
|----|--|----------|---|----|-----|
| N | ATHENA/ON-LINE INTERACTIVE RETRIEVAL UPDATE LANGUATE USER INFORMATION MANUAL | 76071400 | A | 3 | CYB |
| N | CYBERNET CYBER 70/MODEL 76 {PRELIMINARY} TERMINAL USERS GUIDE | 76072700 | | 3 | CYB |
| N | SYSTEM 2000 LEVEL 2-A MULTI-PURPOSE DATA MANAGEMENT SYSTEM USER INFORMATION MANUAL | 76074000 | | 3 | CYB |
| N | SYSTEM 2000 LEVEL 2-A MULTI-PURPOSE DATA MANAGEMENT SYSTEM DIAGNOSTIC MESSAGE SUPPLEMENT | 76074300 | | 3 | CYB |
| N | SYSTEM 2000 LEVEL 2-A MULTI-PURPOSE DATA MANAGEMENT SYSTEM IMMEDIATE ACCESS FEATURE SUPPLEMENT | 76074400 | | 3 | CYB |
| N | SYSTEM 2000 LEVEL 2-A MULTI-PURPOSE DATA MANAGEMENT SYSTEM FORTRAN PROCEDURAL LANGUAGE SUPPLEMENT | 76074600 | | 3 | CYB |
| N | SYSTEM 2000 LEVEL 2-A MULTI-PURPOSE DATA MANAGEMENT SYSTEM REPORT WRITER FEATURE SUPPLEMENT | 76074700 | | 3 | CYB |
| R | PUNCH CARD EQUIPMENT STUDENT MANUAL | 76360001 | C | 3 | CDI |
| R | BR3B8 DISK STORAGE UNIT MAINTENANCE CE MAN | 83301000 | K | 3 | NRM |
| R | BR3B8-DISK STORAGE UNIT REFERENCE MANUAL | 83301100 | C | 3 | NRM |
| R | BR3B8 DISK STORAGE UNIT PARTS DATA CE MANUAL | 83301200 | K | 3 | NRM |
| R | 3330/DISK MEMORY SUBSYSTEM SITE PLANNING KIT | 83301400 | C | 22 | NRM |
| R | 33302 DISK MEMORY SUBSYSTEM REFERENCE MANUAL | 83301500 | B | 22 | NRM |
| R | 33302 DISK MEMORY SUBSYSTEM INSTALLATION CE MANUAL | 83301600 | D | 22 | NRM |
| R | FA721 STORAGE CONTROL HARDWARE REFERENCE CE MANUAL | 83301800 | B | 22 | NRM |
| R | FA721 STORAGE CONTROL PREVENTIVE/CORRECTIVE MAINT. W/L CE MANUAL | 83301900 | E | 22 | NRM |
| R | FA721 STORAGE CONTROL DIAGRAMS VOLUME 2 CE MANUAL | 83302000 | R | 22 | NRM |
| R | FA721 STORAGE CONTROL EIGHT VOLUME CAU FUNCTIONAL MICROPROGRAM CE MANUAL | 83302100 | E | 22 | NRM |
| RO | BR5A5 DISK STORAGE UNIT GEN DESC., OPERATION, INSTALLATION AND CHECKOUT, THEORY OF OPERATION AND MAINTENANCE CE MANUAL | 83302300 | D | 22 | NRM |
| R | BR5A5 DISK STORAGE UNIT DIAGRAMS, MAINT. AIDS, WIRE LISTS CE MANUAL | 83302400 | C | 22 | NRM |
| RO | BR5A5 DISK STORAGE UNIT PARTS DATA CE MANUAL | 83302500 | E | 22 | NRM |
| R | BR502/4 DISK STORAGE UNIT PREVENTIVE CORRECTIVE MAINTENANCE, DIAGS., WIRE LIST, CE MANUAL | 83302600 | G | 22 | NRM |
| R | BR502/4 DISK STORAGE UNIT PARTS DATA CE MAN | 83302800 | F | 22 | NRM |
| R | BR305 DISK STORAGE UNIT - PREVENTIVE CORRECTIVE MAINTENANCE, DIAGS, WIRE LISTS CE MANUAL | 83303100 | B | 22 | NRM |
| R | BR305 DISK STORAGE UNIT PARTS DATA CE MANUAL | 83303300 | C | 22 | NRM |
| R | BR3D1-DISK STORAGE UNIT MAINTENANCE MANUAL | 83305700 | E | 3 | NRM |
| R | BR3D1-B DISK STORAGE UNIT REFERENCE MANUAL | 83305800 | C | 3 | NRM |
| R | BR3D1-B DISK STORAGE UNIT PARTS DATA MANUAL | 83305900 | E | 3 | NRM |
| N | FA721 STORAGE CONTROL PARTS DATA CE MANUAL | 83306000 | F | 22 | NRM |
| RO | FV605 CONTROLLER ADAPTER UNIT GEN. DESC., THEORY OF OPERATION, | 83306100 | B | 22 | NRM |
| RO | FV605 CONTROLLER ADAPTER UNIT PARTS DATA CE MANUAL | 83306300 | C | 22 | NRM |
| N | TB207-A FIELD TEST UNIT MAINTENANCE MANUAL | 83307900 | B | 3 | NRM |

CONT.

| 1 | TITLE | 2 | 3 | 4 | 5 |
|-----|--|----------|---|----|-----|
| N | BJ7XX STORAGE MODULE DRIVE MAINTENANCE MAN | 83308400 | A | 3 | NRM |
| N | BJ7XX STORAGE MODULE DRIVE REFERENCE MANUAL | 83308500 | A | 3 | NRM |
| N | BJ7XX STORAGE MODULE DRIVE PARTS DATA MANUAL | 83308600 | A | 3 | NRM |
| R | BR306/7 DISK STORAGE UNIT PREVENTIVE CORRECTIVE MAINT., DIAGRAMS AND WIRE LISTS | 83308700 | C | 22 | NRM |
| R | BR306/7 DISK STORAGE UNIT REFERENCE MANUAL | 83308800 | B | 22 | NRM |
| R | BR306/7 DISK STORAGE UNIT PARTS DATA CE MAN | 83308900 | C | 22 | NRM |
| R | BR306 DISK STORAGE UNIT MAINTENANCE CE MANUAL | 83309300 | C | 3 | NRM |
| R | BR306 DISK STORAGE UNIT REFERENCE MANUAL | 83309400 | B | 22 | NRM |
| R | BR306 DISK STORAGE UNIT PARTS DATA CE MANUAL | 83309500 | C | 3 | NRM |
| R | BJ6XX STORAGE MODULE DRIVE MAINTENANCE MAN | 83310800 | C | 3 | NRM |
| R | BJ6XX STORAGE MODULE DRIVE REFERENCE MANUAL | 83310900 | B | 3 | NRM |
| N | BR21D {S/C 19 AND ABOVE} DISK STORAGE UNIT PARTS DATA CE MANUAL | 83311400 | A | 22 | NRM |
| N | BR3D3-A/B DISK STORAGE UNIT MAINTENANCE MAN | 83311600 | A | 22 | NRM |
| N | BR3D3-A/B DISK STORAGE UNIT REFERENCE MANUAL | 83311700 | A | 3 | NRM |
| R | FA721 STORAGE CONTROL 16 VOL CAU FUNCTIONAL MICROPROGRAM MANUAL | 83311900 | E | 22 | NRM |
| RO | FA721 STORAGE CONTROL IN-LINE DIAGNOSTICS MICROPROGRAM CE MANUAL | 83312000 | E | 22 | NRM |
| RO | FA721 STORAGE CONTROL STANDARD DIAGNOSTICS MICROPROGRAM CE MANUAL | 83312100 | C | 22 | NRM |
| N | TB4A1-A FIELD TEST UNIT MAINTENANCE MANUAL | 83312300 | A | 3 | NRM |
| N | BR3D4 DISK STORAGE UNIT MAINTENANCE MANUAL | 83313100 | A | 3 | NRM |
| N | BR3D4 DISK STORAGE UNIT REFERENCE MANUAL | 83313200 | A | 3 | NRM |
| N | BR3D4 DISK STORAGE UNIT PARTS LIST MANUAL | 83313300 | A | 3 | NRM |
| N | BR5A6 DISK STORAGE UNIT MAINTENANCE MANUAL | 83313400 | B | 3 | NRM |
| N | BR5A6 DISK STORAGE UNIT REFERENCE MANUAL | 83313500 | B | 3 | NRM |
| N | BR5A6 DISK STORAGE UNIT PARTS DATA MANUAL | 83313600 | A | 3 | NRM |
| N | BR306/BR307-D,E DISK STORAGE UNIT PREVEN- TIVE/CORRECTIVE MAINTENANCE, DIAGRAMS, AND WIRE LISTS CE MANUAL | 83314000 | A | 22 | NRM |
| N | FV605-D-G CONTROLLER ADAPTER UNIT PREVEN- TIVE/CORRECTIVE MAINT. DIAGRAMS, WIRE LISTS CE MANUAL | 83315400 | A | 22 | NRM |
| N | FA203 CONTROLLER MICRODIAGNOSTIC USERS CE MANUAL | 83315600 | A | 22 | NRM |
| N | FA203 CONTROLLER FLEXIBLE DISK DRIVE CE MANUAL | 83315700 | A | 22 | NRM |
| N | FA203 CONTROLLER MICRODIAGNOSTIC CE MANUAL | 83315800 | A | 22 | NRM |
| N | FA203 CONTROLLER THEORY OF OPERATION CE MAN | 83316100 | A | 22 | NRM |
| N | FA203 CONTROLLER PARTS DATA CE MANUAL | 83316200 | A | 22 | NRM |
| N | FA203 CONTROLLER HARDCORE MICROPROGRAM CE MANUAL | 83316300 | A | 22 | NRM |
| N | FA203 CONTROLLER DIAGNOSTIC MICROPROGRAM CE MANUAL | 83316400 | A | 22 | NRM |
| N | FA203 CONTROLLER DUAL ACCESS FEATURE MICRO- PROGRAM CE MANUAL | 83316600 | A | 22 | NRM |
| RMP | CYBERNET/KRONOS 2.1 TIME-SHARING FORTRAN REFERENCE MANUAL | 84001700 | B | 3 | CYB |
| R | EAC/EASE-2 USER INFORMATION/THEORHETICAL MANUAL | 84002700 | A | 3 | CYB |
| RO | CYBERNET/PROSE SYSTEM GUIDE | 84002900 | A | 3 | CYB |
| RO | GPSS V/GENERAL PURPOSE SIMULATION SYSTEM V/6000 GENERAL INFORMATION MANUAL | 84003900 | A | 3 | CYB |
| N | MODIFIED PCA FLAT PLATE, FLAT SLAB, WAFFLE SLAB, AND FRAME ANALYSIS AND DESIGN, WORKING OR ULTIMATE STRENGTH 1971 AC1 USERS GUIDE | 84009400 | | 3 | CYB |

CONT.

| 1 | TITLE | 2 | 3 | 4 | 5 |
|-----|--|----------|----|----|-----|
| N | FAAST-FLUID ANALYSIS AND SIMULATION TECHNIQUE U.I.M. | 84009800 | | 3 | CYB |
| R | SYSTEM 2000 DATA MANAGEMENT SYSTEM USER INFORMATION MANUAL LEVEL II | 86604500 | J | 3 | CYB |
| RMP | CYBERNET/KRONOS LIBRARY PROGRAMS | 86605900 | D | 3 | CYB |
| RO | STRU-PAK PROGRAM ABSTRACTS | 86608700 | B | 3 | CYB |
| RO | E/CUBE ENERGY ANALYSIS CYBERNET SERVICE GUIDELINES | 86608900 | C | 3 | CYB |
| RO | SYSTEM 2000 LEVEL 2-A MULTI-PURPOSE DATA MANAGEMENT SYSTEM MINI MANUAL | 86615600 | B | | CYB |
| RO | CYBERLOAN GENERAL INFORMATION MANUAL | 86616100 | A | 3 | CYB |
| R | NASTRAN APPLICATIONS MANUAL | 86616700 | I | 3 | CYB |
| N | CJ127 HARDWARE REFERENCE/CE MANUAL | 87906700 | A | 22 | ROK |
| N | CJ520 DOCUMENT READER LOGIC RACK HARDWARE MAINTENANCE MANUAL VOLUME 1 | 87911800 | A | 22 | ROK |
| N | CJ127 OCR DOCUMENT READER DIAGRAMS VOLUME 2 HARDWARE REFERENCE/CE MANUAL | 87971600 | | 22 | ROK |
| N | CJ127 OCR DOCUMENT READER PARTS DATA VOLUME 3 HARDWARE REFERENCE/CE MANUAL | 87971700 | 01 | 22 | ROK |
| RO | 929 DRIVE {1784 COMP. SYST.} OCR SOFTWARE REFERENCE MANUAL | 87971800 | B | 22 | ROK |
| N | 1700 COMPUTER SYSTEMS TOTES OPERATORS GUIDE | 88818500 | A | 22 | LJL |
| N | 1700 COMPUTER SYSTEMS TOTES FILE MANAGER UTILITY PROGRAM REFERENCE MANUAL | 88947900 | A | 22 | LJL |
| N | 1700 COMPUTER SYSTEMS REDUCED CORE OPERATING SYSTEM REFERENCE MANUAL V2 | 88948500 | A | 22 | LJL |
| N | 1700 COMPUTER SYSTEMS TIMESHARE 2.0 REF MAN | 88964000 | A | 22 | LJL |
| N | 1576 {FV4A3,498} STALL ALARM UNIT HARDWARE REFERENCE/CE MANUAL | 88981000 | A | 22 | LJL |
| N | EB3A1-A/D FOUR CHANNEL DIGITAL-TO-ANALOG CONVERTER HARDWARE REFERENCE/CE MANUAL | 88981100 | A | 22 | LJL |
| N | KEY TO LOGIC SYMBOLS G.I.M. | 88981500 | B | 22 | LJL |
| N | 6000/CYBER 170/CYBER 70 MODELS 72,73,74 C COMPUTER SYSTEMS CCP SUPPORT SOFTWARE 1 REFERENCE MANUAL | 88988400 | A | 22 | LJL |
| N | 6000/CYBER 170/CYBER 70 MODELS 72,73,74 COMPUTER SYSTEMS CCP SUPPORT SOFTWARE PASCAL COMPILER REFERENCE MANUAL | 88988500 | A | 22 | LJL |
| N | 6000/CYBER 170/CYBER 70 MODELS 72,73,74 COMPUTER SYSTEMS CCP SUPPORT SOFTWARE 1 GENERAL INFORMATION MANUAL | 88988600 | A | 22 | LJL |
| N | 6000/CYBER 170/CYBER 70 MODELS 72,73,74 COMPUTER SYSTEMS CCP SUPPORT SOFTWARE 1 DIAGNOSTIC HANDBOOK | 88988700 | A | 22 | LJL |
| N | 6000/CYBER 170/CYBER 70 MODELS 72,73,74 COMPUTER SYSTEMS CCP SUPPORT SOFTWARE 1 MICRO ASSEMBLER REFERENCE MANUAL | 88988800 | A | 22 | LJL |
| N | 6000/CYBER 170/CYBER 70 MODELS 72,73,74 COMPUTER SYSTEMS CCP SUPPORT SOFTWARE 1 MACRO ASSEMBLER REFERENCE MANUAL | 88988900 | A | 22 | LJL |
| N | SYSTEM 17 INSTALLATION MANUAL | 88996000 | A | 22 | LJL |
| N | 1700 COMPUTER SYSTEMS 1700 RCOS 2 ASSEMBLER REFERENCE MANUAL | 88997600 | A | 22 | LJL |
| R | 1784-1/2 COMPUTER SYSTEM CE MANUAL | 89633300 | 04 | 22 | LJL |
| N | FF524-A LINE PRINTER CONTROLLER | 89637300 | 04 | 22 | LJL |
| N | FE119-A CARD READER CONTROLLER HARDWARE REFERENCE/CE MANUAL | 89637500 | 03 | 22 | LJL |
| N | 1732-2 {SYSTEM 17} MAGNETIC TAPE TRANSPORT CONTROLLER REFERENCE MANUAL | 89637600 | 03 | 22 | LJL |

CONT.

| 1 | TITLE | 2 | 3 | 4 | 5 |
|-----|---|----------|------|----|-----|
| N | FA442-A NRZI MAGNETIC TAPE TRANSPORT CONTROLLER GEN. DESC., OPER AND PROGRAMMING, INSTALLATION/CHECKOUT, THEORY OF OPERATION, DIAGS., MAINT., MAINT. AIDS, P/L, W/L, GLOSSARY | 89637700 | 02 | 22 | LJL |
| N | FA716-A CARTRIDGE DISK DRIVE CONTROLLER CE MANUAL | 89638100 | 02 | 22 | LJL |
| N | DJ81-A SYNCHRONOUS COMMUNICATIONS CONTROLLER AND DISTRIBUTION PANEL CE MANUAL | 89638300 | 02 | 22 | LJL |
| N | FJ606-A SYNCHRONOUS COMMUNICATIONS CONTROLLER (SCC) AND DISTRIBUTION PANEL CE MANUAL | 89638500 | 01 | 22 | LJL |
| N | SYSTEM 17 REAL TIME CLOCK PRELIMINARY REFERENCE MANUAL | 89638800 | 01 | 22 | LJL |
| R | 1784 (SYSTEM 17) COMPUTER SYSTEM INPUT/OUTPUT SPECIFICATIONS | 89673100 | 02 | 22 | LJL |
| N | SYSTEM 17 KEY TO LOGIC SYMBOLS | 89723700 | | 22 | LJL |
| N | AT310-A TTL A/Q-DSA BUS EXPANDER HARDWARE REFERENCE/CE MANUAL | 89758600 | 01 | 22 | LJL |
| N | 1732-3 (SYSTEM 17) MAGNETIC TAPE TRANSPORT CONTROLLER REFERENCE MANUAL | 89769400 | 01 | 22 | LJL |
| N | FA446-A NRZI-LCTT MAGNETIC TAPE TRANSPORT CONTROLLER CE MANUAL | 89769500 | 01 | 22 | LJL |
| N | FV497-A, FV618-A PHASE ENCODING FORMATTER CE MANUAL | 89796100 | 01 | 22 | LJL |
| N | 929 DOCUMENT READER OCR MEDIA MANUAL | 91604300 | A | 22 | ROK |
| R | 955/959 PAGE AND DOCUMENT READER OCR MEDIA MANUAL | 91604500 | B | 22 | ROK |
| N | 1700/SC1700 COMPUTER SYSTEMS ASSEMBLER OCR SOFTWARE REFERENCE MANUAL | 91634000 | A | 22 | ROK |
| R | 595 PRINT CARTRIDGE TYPE D MANUAL | 91860100 | A | 22 | RHT |
| N | 915/8092 COMPUTER SYSTEMS GRASP OCR SOFTWARE INSTALLATION HANDBOOK | 91661300 | | | ROK |
| N | CW195 OCR-B PLUGGABLE FONT OPTION GEN. DESC. INSTALLATION/CHECKOUT, DIAGRAMS HARDWARE REFERENCE/CE MANUAL | 91662900 | A | 22 | ROK |
| N | 959 PAGE AND DOCUMENT READER SYSTEM OPERATORS GUIDE | 91669100 | A | 22 | ROK |
| N | 915/919-1700 SERIES & 955/959 1700 SERIES COMPUTER SYSTEMS PAGE READER SETUP-SOURCE EDIT TAPE UPDATE PROGRAM OCR SOFTWARE REFERENCE MANUAL | 91674400 | A | 22 | ROK |
| N | 8092 COMPUTER SYSTEM 921 MONITOR OCR REFERENCE MANUAL V.1 | 91681100 | A | 22 | ROK |
| N | 580 LINE PRINTER EQUIPMENT INTRODUCTION, OPERATING INSTRUCTIONS, PRINCIPLES OF OPERATION REFERENCE MANUAL | 91858600 | B | 22 | RHT |
| N | 580 LINE PRINTER EQUIPMENT INSTALLATION/CHECKOUT/PREVENTIVE MAINTENANCE CORRECTIVE MAINT., PARTS REPLACEMENT FIELD SERVICE MANUAL VOLUME I | 91858700 | B | 22 | RHT |
| NMP | 580 LINE PRINTER EQUIPMENT FIELD SERVICE MANUAL VOLUME II | 91858800 | B-01 | 22 | RHT |
| N | CW207 HANDPRINT UNIT MODEL A01 HARDWARE MAINTENANCE MANUAL VOLUME I | 91558900 | A | 22 | ROK |
| N | 580 PRINT CARTRIDGE GEN DESC., OPER, AND PROGRAMMING, THEORY OF OPERATION, MAINTENANCE, PARTS DATA HARDWARE REFERENCE/CE MANUAL | 91559000 | C | 22 | RHT |

CONT.

| 1 | TITLE | 2 | 3 | 4 | 5 |
|-----|--|----------|---|----|-----|
| RO | 9322 LINE PRINTER EQUIPMENT INTERCONNECTION PRINT HEAD LOGIC/CONTROLLER LOGIC/ TIMING DIAGRAMS, FSM VOLUME II | 91859200 | B | 34 | RHT |
| R | 595 PRINT CARTRIDGE TYPE D MANUAL | 91860100 | A | 22 | RHT |
| N | 580 LINE PRINTER EQUIPMENT CONTROLS AND INDICATORS, OPERATING PROCEDURES, OPERATOR MAINTENANCE OPERATOR HANDBOOK | 91860400 | B | 22 | RHT |
| N | 1700 COMPUTER SYSTEM TOTES G.I.M. | 96716700 | A | 22 | LJL |
| R | AF107-A {ST.OPT.10287-4} 3100 ENHANCED BLOCK CONTROL AND BDP INTERFACE CE MAN | 97402300 | B | 22 | PLY |
| N | 10287-1 {AF105-A, BT193-A, CD124-A} 3200 ENHANCED BLOCK CONTROL OPTION REF MAN | 97402400 | A | 22 | PLY |
| N | AF105-A {ST.OPT.10287-1} 3200 ENHANCED BLOCK CONTROL MODIFICATION CE MANUAL | 97402500 | A | 22 | PLY |
| N | AT146-A {10287-3} MEMORY INCREMENT 3200 CE MANUAL | 97402700 | A | 22 | PLY |
| *RO | MASTER OPERATING SYSTEM - DATA SHEET | 10035700 | - | -- | ADV |
| *RO | 9427H DOUBLE-DENSITY CART DISK DRIVE - DATA SHEET | 20028300 | B | -- | ADV |
| *RO | CYBERNET: PDS/MAGEN - DATA SHEET | 20032100 | C | -- | ADV |
| *RO | CYBERNET: QA-PAK-QUESTIONNAIRE | 20057000 | A | -- | ADV |
| *RO | CYBERNET: PIPEFLEX - DATA SHEET | 20057100 | A | -- | ADV |
| *RO | CYBERNET: SYSCAP II - DATA SHEET | 20057200 | B | -- | ADV |
| *RO | CYBERNET: MAP FEB. 1975 - DATA SHEET | 20059700 | D | -- | ADV |
| *RO | MILITARY DISK STORAGE UNIT - DATA SHEET | 20063100 | B | -- | ADV |
| *RO | REPORT ON SOCIAL RESPONSIBILITY - BROCHURE | 20067200 | - | -- | ADV |
| *RO | 669 MAG TAPE TRANSPORTS - DATA SHEET | 20067300 | - | -- | ADV |
| *RO | 667 MAG TAPE TRANSPORTS - DATA SHEET | 20067500 | - | -- | ADV |
| *RO | BRIDGE ANALYSIS & RATING SYSTEM - DATA SHEET | 20070200 | B | -- | ADV |
| *RO | 9760 & 9762 STORAGE MOD DRIVES - DATA SHEET | 20070400 | E | -- | ADV |
| *RO | CONSULTING SERVICES FOR DATA COMM SYSTEM - BROCHURE | 20071500 | B | -- | ADV |
| *RO | PERIPHERAL PRODUCTS CATALOG - BROCHURE | 20083800 | A | -- | ADV |
| *RO | 33158 MONOLITHIC MAIN MEMORY - DATA SHEET | 20085700 | - | -- | ADV |
| *RO | MULTIPARTITION MSOS 5 - DATA SHEET | 20087100 | - | -- | ADV |
| *RO | 1987 CABINET - DATA SHEET | 20089200 | A | -- | ADV |
| *RO | MODEL 77-2 CYBER GRAPHICS TERMINAL - DATA SHEET | 20090300 | - | -- | ADV |
| *RO | 844-21 MASS STORAGE SUBSYSTEM - DATA SHEET | 20101200 | - | -- | ADV |
| *N | 1743 COMMUNICATIONS CONTROL - DATA SHEET | 20106000 | - | -- | ADV |
| *R | CYBER 170 PRESENTATION GUIDE | 20106200 | A | 22 | LDS |
| *RO | SYSTEM 2000 G-P DATA BASE MGMT - BROCHURE | 20108400 | A | -- | ADV |
| *RO | 2570-1 LINE PRINTER & 2571-1 CONTROLLER - DATA SHEET | 20108500 | A | -- | ADV |
| *RO | 2570-2 LINE PRINTER & 2571-1 CONTROLLER - DATA SHEET | 20108600 | A | -- | ADV |
| *RO | 2572-1/2572-2 CARD READER & 2571-1 CONTROLLER - DATA SHEET | 20108700 | A | -- | ADV |
| *N | CYBERNATA KEY ENTRY SYSTEM - BROCHURE | 20109600 | - | -- | ADV |
| *RO | COMPUTERS IN EDUCATION | 20114000 | A | -- | ADV |
| *N | CORPORATE PHOTOGRAPHY CATALOG | 20114600 | - | 22 | HQN |
| *N | 1732-3/616 MAG TAPE SUBSYSTEM - DATA SHEET | 20116100 | - | -- | ADV |
| *N | 1566-20/21/22/23 DIGITAL-TO-ANALOG CONVERTERS - DATA SHEET | 20116500 | - | -- | ADV |
| *N | 1590-3 REMOTE COMPUTER INTERFACE SUBSYSTEM SUBSYSTEM - DATA SHEET | 20116000 | - | -- | ADV |
| *N | MPP/CONTROLLER FOR 9760 STORAGE MODULE DRIVE - DATA SHEET | 20116700 | - | -- | ADV |

CONT.

| 1 | TITLE | 2 | 3 | 4 | 5 |
|-----|---|----------|---|----|-----|
| *R0 | 9747 DISK STORAGE UNIT - DATA SHEET | 20116900 | - | -- | ADV |
| *N | 2550-100 EMULATION MODULE | 20117300 | - | -- | ADV |
| *N | MU-602 {V} UYK EXTENDED CORE MEMORY UNIT - DATA SHEET | 20117400 | - | -- | ADV |
| *N | M80 SYSTEMS & SERVICES COMPANY - BROCHURE | 20117800 | - | -- | ADV |
| *N | M80 MARKETING COMPANY - BROCHURE | 20117900 | - | -- | ADV |
| *N | M80 CORPORATE STAFF - BROCHURE | 20118000 | - | -- | ADV |
| *N | CYBERNET - CYBER 76 SERVICE - DATA SHEET | 20118200 | - | -- | ADV |
| *N | GRAPHICALLY ORIENTED DESIGN AND ANALYSIS SYSTEM - DATA SHEET | 20118300 | - | -- | ADV |
| *N | 777 CYBER GRAPHICS TERMINAL - DATA SHEET | 20118400 | - | -- | ADV |
| *N | FAST-TIME/LOAD FLOW - BROCHURE | 20118600 | - | -- | ADV |
| *N | CYBERNET: IS/ATHENA - DATA SHEET | 20118700 | - | -- | ADV |
| *N | CYBERNET: SPOTLIGHT OVERVIEW - BROCHURE | 20118800 | - | -- | ADV |
| *N | 882 DISK PACK - DATA SHEET | 20118900 | - | -- | ADV |
| *N | 469 LARGE-PLANE COMPUTER SYSTEM | 20119000 | - | -- | ADV |
| *N | BUSINESS PRODUCTS - LEADERS IN THEIR FIELD | 20119100 | - | -- | ADV |
| *N | 94200 CORE MEMORY - DATA SHEET | 20119400 | - | -- | ADV |
| *N | DATA MASS STORAGE SYSTEM FOR IBM 370 - DATA SHEET | 20119800 | - | -- | ADV |
| *N | MASS STORAGE TAPE CARTRIDGE-DATA SHEET | 20119900 | - | -- | ADV |
| *N | 1700 REDUCED-CORE OPER. SYSTEM VER 2 - DATA SHEET | 20120200 | - | -- | ADV |
| *N | 1974 CCC ANNUAL REPORT | 20120300 | - | -- | ADV |
| *N | CYBERNET: IFMS | 20120400 | - | -- | ADV |
| *N | 1700 MASS STORAGE FORTRAN V3 A/B DATA SHEET | 20120500 | - | -- | ADV |
| *N | CYBERNET: FAAS - DATA SHEET | 20122300 | - | -- | ADV |
| *N | CYBERNET: CC-TEGAS 3 - DATA SHEET | 20122400 | - | -- | ADV |
| *N | 1974 ANNUAL REPORT | 20122500 | - | -- | ADV |
| *N | CYBERNET: GPSS V/6000 - DATA SHEET | 20122700 | - | -- | ADV |
| *N | CYBERNET: APEX III MATH PROG SYSTEM - DATA SHEET | 20122800 | - | -- | ADV |
| *N | 3373 MAG CORE STORAGE MEMORY SYSTEM - DATA SHEET | 20123200 | - | -- | ADV |
| *N | 3000 COMPUTER SYSTEMS - BROCHURE | 20123300 | - | -- | ADV |
| *N | 92451 STAND-ALONE DISPLAY TERMINAL - DATA SHEET | 20124000 | - | -- | ADV |
| *N | ISP 00001 SUPPORT PACKAGE - DATA SHEET | 20124600 | - | -- | ADV |
| *N | ISP 00005 SUPPORT PACKAGE - DATA SHEET | 20124700 | - | -- | ADV |
| *N | ISP 20002 SUPPORT PACKAGE - DATA SHEET | 20124800 | - | -- | ADV |
| *N | ISP 00006 SUPPORT PACKAGE - DATA SHEET | 20124900 | - | -- | ADV |
| *N | ISP 00004 SUPPORT PACKAGE - DATA SHEET | 20125000 | - | -- | ADV |
| *N | ISP 20001 SUPPORT PACKAGE - DATA SHEET | 20125100 | - | -- | ADV |
| *N | ISP 00002 SUPPORT PACKAGE - DATA SHEET | 20125200 | - | -- | ADV |

OBSOLETE PUBLICATIONS

This section lists publications which have become obsolete since the January 1975 Catalog. The publications which replaces the obsolete items are also shown and if no manual replaces an obsoleted item, the replacement is listed as "none".

| <u>TITLE</u> | <u>PUB. NO.</u> | <u>REPLACEMENT</u> |
|---|-----------------|--------------------|
| 657-1 MAG TAPE DATA SHEET | 10038400 | NONE |
| 3400 DATA SHEET | 10039400 | NONE |
| 3800 DATA SHEET | 10039600 | NONE |
| 659-1 DATA SHEET | 10042200 | NONE |
| 1700 COMP SYS BROCHURE | 10042500 | NONE |
| COMPUTER SITE ENGINEERING | 10047200 | NONE |
| 1750 DCB TERMINATOR-DATA SHEET | 10044200 | NONE |
| 1797 DATA SHEET | 10044300 | NONE |
| 1739-1 DATA SHEET | 10045800 | NONE |
| 1717-1 DATA SHEET | 10050600 | NONE |
| 9280 DATA SHEET | 10051900 | NONE |
| CORPORATE PHOTOGRAPHY CATALOG | 10056900 | 20114600 |
| 8194 DATA SHEET | 10059000 | NONE |
| DIS DATA SHEET | 10063200 | NONE |
| LOW LEVEL ANALOG - D.S. | 10063300 | NONE |
| 1558 DATA SHEET | 10063500 | NONE |
| 1547 EVENT COUNTER SUB SYS DATA SHEET | 10063600 | NONE |
| 1549 DATA SHEET | 10063700 | NONE |
| 1577 STALL ALARM DATA SHEET | 10063800 | NONE |
| 1571 DATA SHEET | 10064000 | NONE |
| 3520 DATA SHEET | 10068000 | NONE |
| 9540 DATA SHEET | 10071000 | NONE |
| 9525 DATA SHEET | 10071200 | NONE |
| 9250 DATA SHEET | 10071400 | NONE |
| 9433 DATA SHEET | 10071700 | NONE |
| 9432 DATA SHEET | 10071800 | NONE |
| 1581 DATA SHEET | 10073000 | NONE |
| 1587 DATA SHEET | 10073300 | NONE |
| EXTERNAL REGISTER DATA SHEET | 10073400 | NONE |
| 9720 DATA SHEET | 10076500 | NONE |
| 9200 DATA SHEET | 10076900 | NONE |
| 1534,1535 DATA SHEET | 10084600 | NONE |
| 3400 BROCHURE | 10089200 | NONE |
| 657-2 DATA SHEET | 10091900 | NONE |
| 657-4 DATA SHEET | 10092100 | NONE |
| 659-3 DATA SHEET | 10092300 | NONE |
| 659-4 DATA SHEET | 10092400 | NONE |
| 90100 DATA SHEET | 10092800 | NONE |
| 90120 DATA SHEET | 10092900 | NONE |
| 1604 BROCHURE | 10093000 | NONE |
| 1572 PROG SAMPLE DATA SHEET | 10093400 | NONE |
| 9486/9487 DATA SHEET | 10093700 | NONE |
| APPL. REPORT COMPUTERS BOOST COLUMBIA RIVER POWER | 20001900 | NONE |
| THROUGHPUT-FEEDBACK FOLDER | 20006800 | NONE |
| 3400 DATA SHEET | 20007600 | NONE |
| 9463 DATA SHEET | 20010800 | NONE |
| 9736/9737 DATA SHEET | 20012100 | NONE |
| 3200 BROCHURE | 20015500 | NONE |
| 92413 CRT DISPLAY D.S. | 20035500 | 20085600 |
| A LEASING PROGRAM STRUCTURED TO FIT YOUR NEEDS | 20035700 | NONE |
| APPL. REPORT-AT DELTA AIRLINES COMMUNICATIONS RATES SEPARATE COMPUTER | 20040100 | NONE |
| 3000 SERIES CASH | 20040900 | NONE |

| <u>OBSOLETE PUBLICATIONS CONT.</u> | <u>PUB. NO.</u> | <u>REPLACEMENT</u> |
|---|-----------------|---|
| 731 LOW SPEED TERMINAL D.S. | 20041300 | NONE |
| APPL. REPORT-VICTORIAN TAB SUCCESSFUL IN OTB AUTOMATION | 20044200 | NONE |
| 1739-1 DATA SHEET | 20045800 | NONE |
| COMPUTER MAINT FOLDER | 20049201 | NONE |
| THE READY RESPONSE PLAN | 20049300 | NONE |
| THE TIME CRITICAL PLAN | 20049400 | NONE |
| THE DO IT YOURSELF PLAN | 20049500 | NONE |
| THE CALL US WHEN YOU NEED US PLAN | 20049600 | NONE |
| THE SPECIAL PLAN ARRANGEMENT | 20049700 | NONE |
| FLIP CHART NOTEBOOK | 20049900 | NONE |
| 1971 ANNUAL REPORT | 20051900 | NONE |
| ELECTRICAL ENGINEERING BROCHURE | 20057800 | NONE |
| OPERATIONS RESEARCH BROCHURE | 20058000 | NONE |
| 33145 MONOLITHIC MAIN MEMORY | 20069900 | NONE |
| TOTAL SERVICES MARKETING | 20073700 | NONE |
| CYBERNET MEMBER CERTIFICATE | 20059800 | NONE |
| 1732-2/615 DATA SHEET | 20081500 | NONE |
| 33145 MONOLITHIC MAIN MEMORY | 20086500 | NONE |
| APPL. REPORT-BRIEF DATA RETRIEVAL SYSTEM SPEEDS TAX SERVICE | 20094300 | NONE |
| COMMERCIAL TERM LEASING PLAN | 20094400 | NONE |
| APPL. BRIEF FOR SKYLAB PROJECT | 20097900 | NONE |
| CDC PIONEERS GIANT DATA STORAGE | | |
| APPL. REPORT-AT AERONAUTICAL RADIO ELECTRONIC SWITCHING DIRECTS MESSAGE TRAFFIC | 20098100 | NONE |
| C-810 TRG SERIES D.S. | 20099000 | NONE |
| C-910 TRG SERIES DATA SHEET | 20102000 | NONE |
| 9315 DATA SHEET | 20105200 | NONE |
| 1973 REAL/TIME VOL 10 NO. 2 | 00015600 | NONE |
| 469 COMPUTER SYSTEMS CE MANUAL | 14176000 | NONE |
| EL101-A (1750-1) COMPUTER INTERFACE UNIT REF/CE | 39909501 | 88980100 |
| 1576 (FV4A3/498) STALL ALARM UNIT REF/CE MANUAL | 39909510 | 88981000 |
| KEY TO LOGIC SYMBOLS G.I.M. | 39909515 | 88981500 |
| 501 HIGH SPEED REF MANUAL | 40805000 | NONE |
| 501 HIGH SPEED REF MANUAL | 40815200 | NONE |
| 9464 DISK STORAGE DRIVE DIAGS. & WIRE LIST | 41248700 | NONE |
| PROFITS INFORMATION MANUAL | 59157700 | NONE |
| 1700 MSOS 4 G.I.M. | 60171400 | 39522400 |
| 955 PAGE AND DOCUMENT READER OCR MEDIA MANUAL | 60216102 | NONE |
| 3000 TAPE SORT/MERGE G.I.M. | 60227900 | 60282100 |
| 1700 COSY REFERENCE V1 | 60237100 | 60361500 |
| PAPER TAPE EQUIPMENT TRAINING MAN | 60238600 | NONE |
| 6000 SCOPE USERS GD 6000 V3.3 | 60252700 | NONE |
| 1700 SYSTEM CHECKOUT VI | 60281800 | 60361500 |
| 1700 CONFIGURATOR VI | 60282300 | 60361500 |
| MSOS VERSION 3 REF MANUAL | 60282600 | 60361500 |
| LOGIC ANALYSIS STUDENT MANUAL | 60313300 | NONE |
| COBOL STUDENT MANUAL | 60314600 | NONE |
| SCIENTIFIC PROGRAMMING STUDENT MAN | 60315000 | NONE |
| 6000/CYBER 70/RECORD MGR REF MAN | 60385400 | 60307300 |
| I/LOGIC CYBERNET U.I.M. | 84000200 | NONE |
| CSM O/P CYBERNET U.I.M. | 84000300 | NONE |
| 1700 REAL/TIME MAINT SYSTEM | 84542000 | 60361500 |
| I/CAP CYBERNET U.I.M. | 86602500 | NONE |
| SYSTEM 2000 G.I.M. | 86604400 | 76074100 |
| SYSTEM 2000 U.I.M. | 86604500 | INDIVIDUAL MANUALS |
| COP U.I.M. | 86605500 | NONE |
| COP DATA CARD DIGEST | 86612400 | NONE |
| I/TRAC CYBERNET U.I.M. | 86616400 | NONE |
| APEX II USERS GUIDE | 97401400 | NONE |
| 28211/14031 & 28211-21 PRINTER SYSTEMS OPERATING GUIDE | 97403300 | 22265500 (AVAILABLE FROM BOB HED-PLYOP3) |

PUBLICATION NUMERICAL SEQUENCE PAGE LISTING

This section contains a complete listing of all catalog publications by numerical sequence along with the page numbers on which each publication can be found. Note that some publications are found on more than one page.

| PUB. NO. | PG. | PUB. NO. | PG. | PUB. NO. | PG. | PUB. NO. | PG. | PUB. NO. | PG. | PUB. NO. | PG. |
|----------|-----|----------|-----|-------------|---------|----------|---------|----------|-----|----------|-----|
| AE05571 | 57 | 13791400 | 87 | 13799800 | 50 | 17322800 | 145 | 31620099 | 92 | 36822900 | 112 |
| AET01621 | 57 | 13791500 | 93 | 14060200 | 66 | | 147 149 | 31620199 | 92 | 36823200 | 70 |
| AET05611 | 167 | 13791600 | 93 | 14061300 | 130 | 17325100 | 149 | 31620200 | 92 | 36823300 | 70 |
| AET05613 | 57 | 13791700 | 112 | 14062100 | 131 | 17326500 | 149 | 31620300 | 92 | 36823400 | 115 |
| AET09611 | 57 | 13791800 | 112 | 14062200 | 131 | 19980300 | 145 | 32501300 | 95 | 36823500 | 114 |
| APT45910 | 167 | 13791900 | 112 | 14065300 | 131 | 19980400 | 145 | 32503300 | 95 | 36823700 | 114 |
| BER11621 | 57 | 13792000 | 59 | 14077300 | 131 | 19980600 | 141 | 35110900 | 89 | 36823800 | 113 |
| BER56250 | 57 | 13792100 | 92 | 14082100 | 131 | | 148 150 | 36810100 | 112 | 36824400 | 64 |
| BPT36210 | 130 | 13792200 | 92 | 14082200 | 131 | 19980700 | 148 | 36810200 | 112 | 36824500 | 74 |
| ESD10400 | 58 | 13792400 | 87 | 14091600 | 115 | | 150 | 36810300 | 59 | 36824700 | 64 |
| ESD10501 | 58 | 13792500 | 87 | 14091700 | 115 | 19980900 | 148 | 36810500 | 113 | 36824800 | 64 |
| ESD10504 | 167 | 13792700 | 87 | 14091800 | 115 | | 151 | 36810600 | 113 | 36825600 | 115 |
| ESD10505 | 58 | 13792800 | 59 | 14091900 | 115 | 19981400 | 166 | 36810700 | 113 | 36825800 | 93 |
| ESD10600 | 58 | 13792900 | 74 | 14092000 | 115 | 19981400 | 166 | 36810800 | 113 | 36825900 | 93 |
| PED20030 | 68 | 13793000 | 74 | 14093500 | 115 | 19983600 | 56 | 36810900 | 113 | 36826000 | 93 |
| PED20080 | 69 | 13793100 | 87 | 14094700 | 115 | 19983800 | 4 | 36811000 | 112 | 36826500 | 74 |
| PED22140 | 69 | 13793200 | 91 | 14123800 | 157 | 20114600 | 157 | 36811300 | 114 | 36826600 | 115 |
| PED22160 | 69 | 13793300 | 87 | 14142900 | 157 | 22003300 | 69 | 36811500 | 114 | 36826700 | 115 |
| PP118100 | 130 | 13793400 | 87 | 14143700 | 157 | 22006500 | 159 | 36811600 | 114 | 36827000 | 85 |
| PSBAG010 | 130 | 13793500 | 97 | 14143800 | 157 | 22006600 | 159 | 36811700 | 112 | 36827100 | 85 |
| PSBAG020 | 130 | 13793600 | 91 | 14155000 | 157 | 22006700 | 159 | 36812500 | 115 | 36827800 | 114 |
| PSBAG030 | 130 | 13793900 | 93 | 14163300 | 102 | 22006900 | 159 | 36812600 | 112 | 36827900 | 114 |
| PSBAG040 | 130 | 13794100 | 92 | 14166700 | 102 | 22008200 | 159 | 36812700 | 115 | 36828100 | 93 |
| PSBAG050 | 130 | 13794400 | 85 | 14166800 | 102 | 22261700 | 51 | 36812800 | 171 | 36828200 | 114 |
| PSBAG060 | 130 | 13794600 | 86 | 14167100 | 102 | 22261900 | 157 | 36813100 | 115 | 36828300 | 114 |
| PSBAG070 | 130 | 13794700 | 86 | 14232000 | 101 | 22262100 | 157 | 36813300 | 114 | 36828600 | 74 |
| PSBAG090 | 130 | 13794800 | 86 | 14237500 | 158 | 22262200 | 157 | 36813700 | 115 | 36828700 | 74 |
| PSBAG110 | 130 | 13794900 | 59 | 14247900 | 102 | 22263500 | 124 | 36814000 | 112 | 36828900 | 116 |
| PSBAG120 | 130 | 13795000 | 79 | 14306500 | 130 | 22263600 | 157 | 36814100 | 115 | 36829000 | 64 |
| SB001700 | 142 | 13795100 | 114 | 15000300 | 123 | 22263800 | 125 | 36814200 | 115 | 36829100 | 85 |
| SC000100 | 58 | 13795300 | 114 | 15002900 | 158 | 22263900 | 124 | 36814300 | 70 | 36829400 | 158 |
| SC057600 | 58 | 13795400 | 158 | 17302500 | 152 | 22264000 | 124 | 36814400 | 115 | 36829500 | 87 |
| SC063300 | 58 | 13795500 | 158 | 17303100 | 151 | 22264500 | 157 | 36814500 | 115 | 36829600 | 89 |
| SC200000 | 58 | 13795600 | 158 | | 152 | 22264600 | 157 | 36814700 | 116 | 36829700 | 89 |
| SC200100 | 58 | 13795700 | 158 | 17303600 | 152 | 22264700 | 157 | 36814800 | 116 | 36829900 | 108 |
| SC400600 | 58 | 13795900 | 43 | 17304200 | 153 | 22264800 | 124 | 36815000 | 116 | 36829900 | 79 |
| 00000200 | 158 | 13796000 | 114 | 17304400 | 149 | 22265400 | 124 | 36816000 | 116 | 36829900 | 79 |
| 00002100 | 162 | 13796100 | 64 | | 151 | 22265500 | 123 | 36816200 | 93 | 36829900 | 172 |
| 00004600 | 165 | 13796200 | 86 | 17305100 | 150 | 22267100 | 157 | 36816300 | 112 | 36829900 | 108 |
| 00006000 | 163 | 13796300 | 168 | | 152 | 22267200 | 157 | 36816400 | 112 | 36829900 | 108 |
| 00006100 | 163 | 13796400 | 64 | 17307300 | 149 | 22267300 | 157 | 36816600 | 113 | 36829900 | 108 |
| 00006300 | 158 | 13796500 | 38 | | 151 153 | 22272400 | 46 | 36816700 | 111 | 36829900 | 108 |
| 00007300 | 141 | 13796800 | 95 | 17308100 | 152 | 22272500 | 46 | 36817300 | 115 | 39070800 | 75 |
| 00007500 | 157 | 13796900 | 114 | 17308300 | 152 | 22273000 | 123 | 36817400 | 70 | 39070900 | 76 |
| 00015000 | 158 | 13797000 | 116 | 17309500 | 174 | 22273100 | 123 | 36817500 | 112 | 39071100 | 85 |
| 00015100 | 173 | 13797300 | 116 | 17309700 | 153 | 22285300 | 125 | 36817600 | 86 | 39071300 | 76 |
| 01306700 | 160 | 13797400 | 64 | 17310100 | 149 | 22285400 | 125 | 36817700 | 74 | 39071400 | 76 |
| 04036700 | 162 | 13797500 | 158 | 17311600 | 174 | 22285500 | 125 | 36817900 | 74 | 39071500 | 76 |
| 04256700 | 162 | 13797700 | 74 | 17311700 | 174 | 22285600 | 124 | 36818000 | 74 | 39071900 | 76 |
| 04266700 | 160 | 13797800 | 83 | 17313000 | 150 | 22285700 | 125 | 13618100 | 74 | 39072200 | 79 |
| 07046700 | 161 | 13797900 | 47 | | 152 153 | 24107700 | 60 | 36818200 | 74 | 39072400 | 79 |
| 082966A0 | 161 | 13798100 | 47 | 17313200 | 147 | 24140300 | 113 | 36818300 | 58 | 39072500 | 60 |
| 083066A0 | 159 | 13798400 | 64 | | 149 | 31600200 | 98 | 36818500 | 58 | 39072600 | 76 |
| 13790100 | 87 | 13798500 | 64 | 17313600 | 147 | 31600800 | 99 | 36819100 | 114 | 39072900 | 85 |
| 13790200 | 87 | 13798600 | 64 | 149 151 154 | | 31601100 | 99 | 36819900 | 112 | 39073100 | 76 |
| 13790300 | 87 | 13798700 | 64 | 17317200 | 152 | 31602300 | 100 | 36820000 | 86 | 39073300 | 75 |
| 13790400 | 91 | 13798800 | 47 | 17317400 | 149 | 31602900 | 100 | 36820100 | 87 | 39073400 | 75 |
| 13790500 | 86 | 13798900 | 159 | 17318900 | 149 | 31603800 | 101 | 36820200 | 87 | 39073500 | 75 |
| 13790700 | 87 | 13799000 | 85 | 17321800 | 149 | 31605400 | 98 | 36820300 | 87 | 39073600 | 75 |
| 13790800 | 87 | 13799100 | 47 | 17322100 | 152 | 31605600 | 99 | 36820400 | 86 | 39073700 | 75 |
| 13791100 | 115 | 13799200 | 47 | 17322500 | 149 | 31605700 | 99 | 36820600 | 74 | 39073800 | 75 |
| 13791200 | 116 | 13799300 | 64 | 17322600 | 149 | 31606100 | 100 | 36822500 | 111 | 39073900 | 75 |
| 13791300 | 87 | 13799700 | 116 | 17322700 | 145 | 31606600 | 101 | 36822700 | 115 | 39074100 | 75 |
| | | | | | 147 149 | | | | | | |

| PUB. NO. | PG. | PUB. NO. | PG. | PUB. NO. | PG. | PUB. NO. | PG. | PUB. NO. | PG. | PUB. NO. | PG. |
|----------|-----|----------|-----|----------|-----|----------|-----|----------|-----|----------|-----|
| 39074200 | 75 | 40807200 | 67 | 40821700 | 117 | 40862700 | 67 | 41246000 | 120 | 41610700 | 98 |
| 39074300 | 75 | 40807700 | 69 | 40821800 | 117 | 40862900 | 72 | 41246100 | 121 | 41610900 | 66 |
| 39074400 | 75 | 40807800 | 69 | 40821900 | 22 | 40863100 | 120 | 41246200 | 121 | 41611000 | 38 |
| 39074500 | 75 | 40707900 | 69 | 40822000 | 69 | 40863200 | 33 | 41246800 | 120 | 41611200 | 38 |
| 39074700 | 63 | 40808100 | 118 | 40822100 | 116 | 40863300 | 71 | 41246900 | 121 | 41611300 | 92 |
| 39074900 | 66 | 40808200 | 23 | 40822200 | 69 | 40863600 | 117 | 41247100 | 121 | 41611700 | 38 |
| 39075000 | 75 | 40808300 | 63 | 40822300 | 116 | 40863900 | 72 | 41247200 | 121 | 41611800 | 65 |
| 39075200 | 76 | 40808400 | 117 | 40822400 | 68 | 40864000 | 32 | 41247300 | 71 | 41611900 | 38 |
| 39075300 | 76 | 40808500 | 117 | 40822500 | 68 | 40864100 | 21 | 41247400 | 72 | 41612000 | 65 |
| 39083500 | 141 | 40808600 | 24 | 40822600 | 69 | 40864400 | 120 | 41247500 | 120 | 41612100 | 38 |
| 39150100 | 74 | 40809100 | 69 | 40822800 | 69 | 40864600 | 117 | 41247600 | 120 | 41612200 | 65 |
| 39153300 | 75 | 40809300 | 66 | 40823000 | 68 | 40864800 | 32 | 41247700 | 120 | 41612300 | 38 |
| 39153400 | 75 | 40809500 | 70 | 40823100 | 71 | 40864900 | 66 | 41247800 | 121 | 41612400 | 65 |
| 39185900 | 79 | 40809600 | 111 | 40823200 | 72 | 40865000 | 117 | 41248400 | 121 | 41612500 | 66 |
| 39201800 | 133 | 40810800 | 68 | 40823400 | 71 | 40865100 | 117 | 41248800 | 121 | 41612600 | 38 |
| 39216600 | 85 | 40811200 | 69 | 40823600 | 117 | 40865200 | 71 | 41248900 | 26 | 41612700 | 66 |
| 39222600 | 42 | 40811400 | 68 | 40823700 | 117 | 40865500 | 121 | 41249000 | 26 | 41612800 | 38 |
| 39230300 | 74 | 40811500 | 68 | 40813600 | 117 | 40865800 | 122 | 41249200 | 25 | 41613200 | 37 |
| 39231200 | 47 | 40811700 | 116 | 40823900 | 66 | 40866400 | 120 | 41249300 | 25 | 41613400 | 37 |
| 39260700 | 134 | 40811800 | 68 | 40824000 | 69 | 40866500 | 120 | 41249400 | 25 | 41614300 | 51 |
| 39268100 | 133 | 40811900 | 68 | 40824200 | 23 | 40867100 | 121 | 41249500 | 25 | 41614400 | 140 |
| 39278700 | 75 | 40812000 | 68 | 40824300 | 71 | 40867300 | 53 | 41249600 | 25 | 41614500 | 140 |
| 39308000 | 79 | 40812300 | 157 | 40824600 | 116 | 40867600 | 121 | 41249700 | 25 | 41614600 | 140 |
| 39359900 | 76 | 40812400 | 67 | 40824800 | 71 | 40867700 | 53 | 41249800 | 25 | 41614700 | 140 |
| | 50 | 40812500 | 68 | 40824900 | 72 | 40867800 | 122 | 41600000 | 134 | 41614800 | 140 |
| 39368600 | 49 | 40812600 | 68 | 40825000 | 71 | 40868100 | 117 | 41600300 | 95 | 41614900 | 140 |
| 39392700 | 37 | 40812700 | 69 | 40825100 | 71 | 40868400 | 121 | | 47 | 41615000 | 140 |
| 39412900 | 79 | 40812800 | 59 | 40825200 | 66 | 40868500 | 121 | 41600500 | 64 | 41615100 | 140 |
| 39415100 | 79 | 40813100 | 65 | 40825400 | 117 | 40868700 | 22 | 41600600 | 37 | 41615200 | 140 |
| 39473200 | 41 | 40813300 | 117 | 40825600 | 71 | 40869500 | 166 | 41600700 | 101 | 41615300 | 140 |
| 39519800 | 132 | 40814200 | 69 | 40826200 | 117 | 40869600 | 26 | 41600900 | 170 | 44016000 | 159 |
| 39519900 | 132 | 40814300 | 70 | 40826300 | 71 | 40869700 | 22 | 41601000 | 50 | 44016800 | 159 |
| 39520200 | 133 | 40814400 | 59 | 40826400 | 72 | 40869901 | 22 | 41601500 | 85 | 44020300 | 159 |
| 39520500 | 132 | 40814500 | 70 | 40826500 | 120 | 41240000 | 21 | 41601600 | 85 | 44020500 | 159 |
| 39520600 | 132 | 40814600 | 70 | 40826600 | 116 | 41240100 | 69 | 41601700 | 46 | 44610400 | 153 |
| 39520900 | 132 | 40814800 | 68 | 40826700 | 166 | 41240200 | 172 | 41601800 | 65 | 44616700 | 152 |
| 39521700 | 133 | 40814900 | 116 | 40826800 | 120 | 41240300 | 121 | 41601900 | 37 | 44623700 | 158 |
| 39521900 | 133 | 40815100 | 68 | 40826900 | 120 | 41240400 | 121 | 41602200 | 46 | 44629200 | 153 |
| 39522400 | 132 | 40815200 | 67 | 40827000 | 121 | 41240500 | 121 | 41602400 | 64 | 44629300 | 152 |
| 39524000 | 37 | 40815300 | 67 | 40827300 | 120 | 41240600 | 53 | 41602500 | 50 | 44855500 | 34 |
| 39534900 | 31 | 40815400 | 68 | 40827500 | 71 | 41240800 | 117 | 41602600 | 97 | 44855600 | 35 |
| 39644500 | 133 | 40815500 | 68 | 40827600 | 33 | 41240900 | 71 | 41602700 | 97 | 44855700 | 34 |
| 39660400 | 51 | 40815600 | 68 | 40827900 | 166 | 41241000 | 72 | 41602800 | 97 | 44855800 | 67 |
| 39677500 | 133 | 40815700 | 117 | 40828200 | 121 | 41241400 | 33 | 41602900 | 50 | 44895600 | 34 |
| 39690100 | 51 | 40816000 | 70 | 40828700 | 120 | 41241500 | 31 | 41603000 | 170 | 44895700 | 34 |
| 39731700 | 24 | 40816100 | 111 | 40828900 | 120 | 41241600 | 120 | 41603100 | 38 | 44895800 | 34 |
| 39744900 | 41 | 40816200 | 158 | 40829000 | 120 | 41241700 | 25 | 41603200 | 37 | 44895900 | 119 |
| 39771300 | 174 | 40816500 | 68 | 40829100 | 120 | 41241900 | 33 | 41603300 | 46 | 44896400 | 114 |
| 39909502 | 35 | 40816800 | 68 | 40829300 | 122 | 41242100 | 22 | 41603500 | 115 | 44896500 | 89 |
| 39909503 | 36 | 40816900 | 120 | 40829400 | 66 | 41242200 | 24 | 41605200 | 157 | 44976700 | 34 |
| 39909504 | 42 | 40817000 | 116 | 40829700 | 166 | 41242300 | 24 | 41605300 | 65 | 44977000 | 119 |
| 39909505 | 50 | 40817200 | 69 | 40829900 | 117 | 41242400 | 24 | 41605400 | 37 | | 172 |
| 39909506 | 41 | 40817400 | 23 | 40860000 | 157 | 41243200 | 31 | 41605600 | 47 | 44977600 | 119 |
| 39909507 | 39 | 40818700 | 117 | 40860100 | 117 | 41243500 | 26 | 41605900 | 58 | 44977700 | 119 |
| 39909508 | 48 | 40818800 | 116 | 40860200 | 121 | 41243600 | 26 | 41606100 | 113 | 44978800 | 34 |
| 39909509 | 37 | 40818900 | 117 | 40860400 | 72 | 41243700 | 26 | 41606200 | 65 | 44980100 | 34 |
| 39909513 | 76 | 40819300 | 33 | 40860500 | 72 | 41243800 | 22 | 41606300 | 37 | 44980700 | 35 |
| 40801800 | 22 | 40819400 | 68 | 40860700 | 21 | 41243900 | 26 | 41606400 | 46 | 44980800 | 35 |
| 40802000 | 31 | 40819500 | 68 | 40860800 | 21 | 41244100 | 71 | 41606500 | 93 | 44980900 | 35 |
| 40802100 | 116 | 40819700 | 117 | 40860900 | 23 | 41244200 | 72 | 41606600 | 141 | 44981600 | 119 |
| 40803200 | 70 | 40819800 | 117 | 40861000 | 23 | 41244300 | 120 | 41607100 | 65 | 44982700 | 119 |
| 40803400 | 70 | 40819900 | 23 | 40861700 | 67 | 41244400 | 120 | 41607400 | 114 | 44983100 | 119 |
| 40803900 | 116 | 40820000 | 71 | 40861800 | 67 | 41244500 | 121 | 41607700 | 172 | 44983200 | 119 |
| 40804800 | 31 | 40820100 | 112 | 40861900 | 65 | 41244600 | 121 | 41608100 | 37 | 47500700 | 89 |
| 40805000 | 67 | 40820200 | 66 | 40862000 | 67 | 41244700 | 121 | 41608500 | 48 | 47966500 | 114 |
| 40805200 | 117 | 40820300 | 68 | 40862100 | 67 | 41245200 | 120 | 41608700 | 168 | 47966600 | 114 |
| 40805300 | 116 | 40820400 | 117 | 40862200 | 67 | 41245500 | 121 | 41609000 | 64 | 47966700 | 34 |
| 40806600 | 111 | 40820500 | 67 | 40862300 | 117 | 41245600 | 166 | 41609600 | 65 | 47967000 | 34 |
| 40806700 | 116 | 40820800 | 67 | 40862400 | 72 | 41245700 | 71 | 41609700 | 37 | | 58 |
| 40806800 | 117 | 40821000 | 68 | 40862500 | 71 | 41245800 | 72 | 41610400 | 39 | 48143900 | 133 |
| 40807100 | 117 | 40821200 | 68 | 40862600 | 69 | 41245900 | 120 | 41610500 | 66 | 48143910 | 72 |

| PUB. NO. | PG. | PUB. NO. | PG. | PUB. NO. | PG. | PUB. NO. | PG. | PUB. NO. | PG. | PUB. NO. | PG. |
|----------|-----|-----------|-----|----------|-----|----------|-----|----------|-----|----------|-----|
| 48143981 | 35 | 49752300 | 124 | 59150800 | 146 | 60007200 | 59 | 60026200 | 60 | 60052900 | 132 |
| 48299700 | 158 | 49754900 | 31 | 59151000 | 146 | 60007300 | 60 | 60026500 | 60 | 60053300 | 143 |
| 48299727 | 158 | 49755100 | 31 | 59151300 | 146 | 60007400 | 61 | 60026700 | 73 | 60053400 | 143 |
| 48402800 | 165 | 49755200 | 31 | 59151600 | 146 | 60007500 | 61 | 60026800 | 60 | | 144 |
| 48430000 | 134 | 49755300 | 66 | 59152000 | 146 | 60007600 | 61 | 60026900 | 60 | 60053500 | 132 |
| 48430010 | 134 | 49755400 | 66 | 59152100 | 146 | 60007700 | 61 | 60027000 | 61 | 60053900 | 132 |
| 48430045 | 33 | 49755500 | 66 | 59153200 | 140 | 60007800 | 61 | 60027100 | 73 | 60054000 | 130 |
| 48430050 | 74 | 49755600 | 21 | 59153300 | 140 | 60007900 | 61 | 60027200 | 78 | 60054100 | 130 |
| 48430070 | 74 | 49755700 | 22 | 59155100 | 134 | 60008300 | 167 | 60027400 | 73 | 60054200 | 130 |
| 48430080 | 33 | 49755800 | 22 | 59155600 | 134 | 60008400 | 131 | 60027500 | 73 | 60054400 | 130 |
| 48430087 | 33 | 49755900 | 66 | | 141 | 60009800 | 78 | 60027600 | 78 | 60054500 | 130 |
| 48430090 | 33 | 49757500 | 68 | 59156000 | 158 | 60010200 | 168 | 60028100 | 77 | 60054600 | 130 |
| 48430100 | 133 | 49757600 | 68 | 59156600 | 146 | 60010600 | 78 | 60028200 | 95 | 60055000 | 138 |
| 48430170 | 72 | 49762400 | 33 | 59156800 | 151 | 60010700 | 78 | 60029100 | 60 | | 139 |
| 48643305 | 74 | 49800300 | 23 | 59156900 | 151 | 60013600 | 168 | 60029200 | 78 | 60055100 | 138 |
| 48704601 | 155 | 49803700 | 52 | 59157000 | 151 | 60013700 | 73 | 60029300 | 73 | 60055200 | 135 |
| 48704702 | 72 | 49803800 | 52 | 59157900 | 154 | 60013900 | 61 | 60041400 | 60 | 137 | 138 |
| 48704800 | 155 | 49815000 | 21 | 59158000 | 148 | 60014000 | 60 | 60041600 | 166 | 60055400 | 138 |
| 48704810 | 74 | 49815100 | 22 | | 154 | 60014100 | 60 | 60041700 | 98 | 60055500 | 141 |
| 48704850 | 74 | 49815200 | 24 | 59158100 | 148 | 60014200 | 60 | 60041800 | 99 | | 142 |
| 48704901 | 155 | 49815300 | 23 | | 154 | 60014300 | 60 | 60041900 | 99 | 60055600 | 142 |
| 48706101 | 155 | 498159200 | 23 | 59158200 | 158 | 60014400 | 62 | 60042000 | 99 | 60055700 | 141 |
| 48706201 | 155 | 498159300 | 23 | 59158300 | 158 | 60016400 | 77 | 60042100 | 99 | | 142 |
| 48707800 | 155 | 498159400 | 22 | 59158800 | 141 | 60016500 | 77 | | 172 | 60055800 | 137 |
| 48707900 | 155 | 49932700 | 23 | 59158900 | 141 | 60016600 | 77 | 60042200 | 100 | | 139 |
| 48708000 | 72 | 49973600 | 31 | 59159000 | 140 | 60016700 | 77 | 60042300 | 101 | 60055900 | 142 |
| 48781100 | 74 | 50577600 | 118 | 59159100 | 140 | 60016800 | 73 | 60042400 | 101 | 60056100 | 132 |
| 48814000 | 155 | 50577700 | 35 | 59159400 | 158 | 60017000 | 73 | 60042500 | 100 | 60056300 | 135 |
| 48883700 | 33 | 50577800 | 118 | 59159600 | 141 | 60017100 | 73 | 60042600 | 98 | 137 | 138 |
| 48911900 | 35 | 50577900 | 118 | 59159700 | 153 | 60017300 | 73 | 60042700 | 166 | 60056400 | 143 |
| 48948100 | 33 | 50578100 | 34 | 59159800 | 155 | 60017800 | 78 | 60042800 | 58 | | 144 |
| 48948200 | 33 | 50578500 | 34 | 59304600 | 158 | 60017900 | 78 | 60042900 | 166 | 60056500 | 144 |
| 48991800 | 35 | | 120 | 59349900 | 24 | 60018200 | 132 | 60043000 | 89 | 60056800 | 140 |
| 48996300 | 35 | 50578700 | 168 | 59577900 | 120 | 60018400 | 59 | 60043300 | 99 | 60056900 | 140 |
| 48996600 | | 50579100 | 119 | 59578000 | 120 | 60018500 | 59 | 60043400 | 98 | 60057100 | 140 |
| | 155 | 50579600 | 119 | 59578100 | 120 | 60018600 | 159 | 60043500 | 100 | 60057200 | 141 |
| 48997900 | 33 | 50580500 | 119 | 59578800 | 120 | 60018700 | 59 | 60043800 | 92 | | 142 |
| 49484600 | 23 | 50580900 | 52 | 59578900 | 120 | 60018800 | 78 | 60044400 | 98 | 60057400 | 141 |
| 49486400 | 21 | 50581000 | 119 | 59579200 | 118 | 60018900 | 78 | 60044800 | 73 | 142 | 143 |
| 49487000 | 23 | 50581200 | 168 | 59579300 | 118 | 60019100 | 131 | 60044900 | 78 | 60057500 | 141 |
| 49487100 | 23 | 50581300 | 119 | 59579400 | 119 | 60019400 | 61 | 60047600 | 99 | | 142 |
| 49487200 | 22 | 50581400 | 119 | 59579500 | 119 | 60019500 | 61 | 60047700 | 100 | 60057600 | 134 |
| 49487300 | 22 | 50581500 | 168 | 59707800 | 119 | 60020900 | 59 | 60047900 | 89 | 135 | 136 |
| 49487400 | 22 | 50581600 | 67 | 59708000 | 119 | 60021300 | 98 | 60048300 | 101 | 138 | 139 |
| 49487500 | 22 | 50581800 | 34 | 59708200 | 123 | 60021400 | 78 | 60048400 | 100 | 60057800 | 142 |
| 49487600 | 23 | 50581900 | 120 | 59708300 | 123 | 60021500 | 78 | 60048600 | 158 | 60057900 | 141 |
| 49487700 | 23 | 50582000 | 52 | 59708400 | 123 | 60021600 | 62 | 60048800 | 87 | 60058200 | 155 |
| 49487800 | 21 | 50582200 | 67 | 59708500 | 167 | 60021700 | 62 | 60048900 | 73 | 60058300 | 142 |
| 49487900 | 21 | 50582300 | 35 | 59708600 | 167 | 60021800 | 62 | 60049100 | 63 | 60058500 | 143 |
| 49488000 | 23 | 50582400 | 35 | 59708700 | 167 | 60021900 | 62 | 60049400 | 92 | | 144 |
| 49488100 | 23 | 50582500 | 119 | 59709000 | 167 | 60022000 | 61 | 60049800 | 100 | 60058600 | 143 |
| 49488200 | 21 | 50583100 | 34 | 59709100 | 118 | 60022200 | 61 | 60050100 | 131 | | 144 |
| 49488300 | 23 | 50583200 | 34 | 60001500 | 77 | | 62 | 60050300 | 131 | 60058700 | 142 |
| 49488400 | 23 | 50583300 | 34 | 60001800 | 132 | 60022300 | 62 | 60050500 | 131 | 60058900 | 141 |
| 49488600 | 23 | 50583400 | 34 | 60002000 | 76 | 60022400 | 62 | 60050600 | 132 | | 142 |
| 49591900 | 32 | 50583500 | 52 | 60002300 | 59 | 60022500 | 61 | 60050700 | 131 | 60059000 | 142 |
| 49592900 | 32 | 50583600 | 118 | 60002600 | 59 | 60023000 | 60 | 60050800 | 132 | | 143 |
| 49593000 | 32 | 50583700 | 118 | 60003000 | 77 | 60023800 | 62 | 60050900 | 132 | 60059100 | 139 |
| 49593100 | 32 | 50583800 | 118 | 60003200 | 77 | 60023900 | 62 | 60051000 | 132 | | 140 |
| 49596700 | 117 | 50583900 | 35 | | 132 | 60024000 | 62 | 60051100 | 132 | 60059200 | 142 |
| 49596800 | 117 | 50584100 | 52 | 60003300 | 77 | 60024300 | 76 | 60051200 | 131 | 60059300 | 138 |
| 49596900 | 118 | 50584300 | 34 | 60003500 | 77 | 60024400 | 76 | 60051300 | 131 | 60059400 | 141 |
| 49597000 | 32 | 50584400 | 118 | 60003600 | 77 | 60024500 | 76 | 60051500 | 131 | | 142 |
| 49626100 | 31 | 50584500 | 118 | 60003700 | 77 | 60024900 | 59 | 60051600 | 132 | 60059500 | 141 |
| 49750300 | 22 | 50584600 | 118 | 60004100 | 77 | 60025000 | 59 | 60051900 | 131 | | 142 |
| 49750400 | 22 | 50583700 | 120 | 60004400 | 77 | 60025100 | 131 | 60052000 | 132 | 60059800 | 141 |
| 49750600 | 24 | 50584800 | 119 | 60006600 | 77 | 60025600 | 77 | 60052100 | 132 | | 142 |
| 49750700 | 24 | 59150500 | 144 | 60006800 | 59 | 60025700 | 76 | 60052200 | 132 | 60059900 | 155 |
| 49750900 | 66 | | 145 | 60006900 | 59 | 60025800 | 60 | 60052500 | 143 | 60060100 | 130 |
| 49751400 | 69 | 59150600 | 146 | 60007000 | 59 | 60026000 | 60 | | 144 | 60060200 | 130 |
| 49751600 | 158 | 59150700 | 146 | 60007100 | 59 | 60026100 | 60 | 60052600 | 132 | 60060300 | 130 |

| PUB. NO. | PG. | PUB. NO. | PG. | PUB. NO. | PG. | PUB. NO. | PG. | PUB. NO. | PG. | PUB. NO. | PG. |
|----------|-----|----------|-----|----------|-----|----------|-------------|----------|-----|----------|-----|
| 60060400 | 130 | 60083800 | 144 | 60100700 | 99 | 60123900 | 61 | 60134100 | 134 | 60150200 | 87 |
| 60060500 | 130 | 60084000 | 132 | 60100800 | 102 | 60124000 | 61 | | 135 | 60150300 | 95 |
| 60060600 | 130 | 60084100 | 131 | 60100900 | 92 | 60124100 | 60 | 60134200 | 142 | 60150700 | 99 |
| 60060700 | 130 | 60084200 | 130 | 60101100 | 92 | 60124300 | 61 | 60134300 | 138 | 60150800 | 105 |
| 60060800 | 130 | 60084400 | 142 | 60101400 | 89 | 60124400 | 113 | 60134600 | 143 | 60150900 | 59 |
| 60061000 | 57 | 60084900 | 141 | 60101900 | 113 | 60124600 | 57 | | 144 | 60151000 | 78 |
| 60061200 | 130 | 60085300 | 165 | 60102000 | 113 | 60124800 | 101 | 60134700 | 138 | 60151200 | 62 |
| 60061300 | 56 | 60086000 | 164 | 60102300 | 95 | 60125000 | 36 | | 139 | 60151500 | 61 |
| 60061400 | 57 | 60086100 | 164 | 60102500 | 61 | 60125400 | 101 | 60134900 | 134 | 60151700 | 63 |
| 60061500 | 130 | 60086900 | 164 | 60103900 | 60 | 60126400 | 95 | | 139 | 60151800 | 61 |
| 60061600 | 130 | 60087000 | 164 | 60104200 | 60 | 60126500 | 101 | 60135900 | 137 | 60152100 | 167 |
| 60061700 | 57 | 60087200 | 164 | 60104300 | 61 | 60126800 | 77 | | 138 | 60152300 | 94 |
| 60061800 | 57 | 60087400 | 164 | 60104400 | 61 | 60127000 | 106 | 60137000 | 142 | 60152500 | 90 |
| 60061900 | 130 | 60087500 | 164 | 60104500 | 57 | 60127500 | 78 | 60137100 | 141 | 60152600 | 90 |
| 60062000 | 130 | 60087600 | 164 | 60104600 | 60 | 60127800 | 112 | | 142 | 60152700 | 81 |
| 60062100 | 130 | 60088500 | 164 | 60104700 | 60 | 60129300 | 61 | 60137200 | 142 | 60153000 | 102 |
| 60062200 | 130 | 60088600 | 164 | 60104900 | 101 | 60129400 | 58 | 60137300 | 142 | 60153100 | 79 |
| 60062300 | 56 | 60088700 | 165 | 60105100 | 93 | 60130000 | 137 | 60137500 | 143 | 60153500 | 130 |
| 60062400 | 57 | 60088800 | 164 | 60105400 | 60 | | 138 139 | 60137600 | 138 | 60153600 | 130 |
| 60062500 | 57 | 60089100 | 164 | 60107100 | 78 | 60130100 | 140 | | 139 | 60153800 | 130 |
| 60062600 | 57 | | 179 | 60107300 | 165 | 60130200 | 138 | 60137700 | 153 | 60153900 | 94 |
| 60062700 | 130 | 60089200 | 164 | 60107400 | 101 | | 139 140 | 60137900 | 143 | 60154000 | 94 |
| 60062900 | 57 | | 179 | 60108100 | 96 | 60130400 | 137 | 60138000 | 131 | 60154100 | 94 |
| 60063000 | 57 | 60089300 | 164 | 60108400 | 89 | | 138 139 | 60138100 | 131 | 60154500 | 102 |
| 60063100 | 57 | | 179 | 60109800 | 61 | 60130500 | 143 | 60138200 | 143 | 60156000 | 141 |
| 60063200 | 57 | 60089400 | 179 | 60110100 | 76 | | 144 | 60138300 | 138 | 60156900 | 165 |
| 60063400 | 57 | 60089800 | 112 | 60110400 | 87 | 60130600 | 143 | 60138400 | 144 | 60157000 | 93 |
| 60063500 | 58 | 60090200 | 62 | 60110900 | 92 | 60130900 | 155 | 60138800 | 144 | 60157100 | 102 |
| 60063600 | 130 | 60090300 | 73 | 60111000 | 92 | 60131000 | 182 | 60138900 | 144 | 60157200 | 90 |
| 60063700 | 57 | 60090400 | 97 | 60111100 | 89 | 60131100 | 134 | 60139000 | 132 | 60157300 | 98 |
| 60063800 | 57 | 60090500 | 93 | 60111200 | 89 | | 135 139 | 60139100 | 141 | 60157400 | 105 |
| 60064000 | 57 | 60090800 | 77 | 60112400 | 90 | 60131200 | 137 | | 142 | 60157500 | 140 |
| 60064300 | 58 | 60091000 | 113 | 60112700 | 62 | | 138 139 | 60139300 | 141 | 60158200 | 97 |
| 60064400 | 58 | 60091100 | 113 | 60112800 | 60 | 60131400 | 135 | 60139500 | 157 | 60158600 | 158 |
| 60064500 | 58 | 60091200 | 113 | 60113200 | 165 | | 137 138 | 60140400 | 90 | 60158700 | 160 |
| 60064600 | 58 | 60091300 | 112 | 60113300 | 171 | | 139 140 | 60140700 | 113 | 60158800 | 160 |
| 60064700 | 58 | 60091500 | 113 | 60113400 | 87 | 60131500 | 143 | 60140800 | 101 | 60159000 | 102 |
| 60064800 | 57 | 60091600 | 113 | 60113900 | 93 | 60131600 | 142 | 60141200 | 63 | 60159200 | 99 |
| 60064900 | 57 | 60091700 | 78 | 60114200 | 97 | 60131700 | 141 | 60141300 | 62 | 60159300 | 112 |
| 60065000 | 57 | 60091800 | 97 | 60116000 | 76 | | 142 143 | 60141400 | 61 | 60159400 | 112 |
| 60065100 | 130 | 60093100 | 73 | 60116100 | 92 | 60131800 | 143 | 60141500 | 61 | 60159600 | 100 |
| 60070000 | 95 | 60093700 | 92 | 60116200 | 61 | | 144 | 60141600 | 60 | 60159700 | 100 |
| 60070100 | 59 | 60093800 | 99 | 60116300 | 62 | 60131900 | 141 | 60141800 | 93 | 60159900 | 102 |
| 60070200 | 59 | 60093900 | 98 | 60116400 | 61 | 60132000 | 138 | 60141900 | 102 | 60160000 | 102 |
| 60070300 | 73 | 60094100 | 73 | 60116600 | 60 | | 139 | 60142000 | 167 | 60160300 | 91 |
| 60070400 | 76 | 60094200 | 101 | 60116900 | 113 | 60132100 | 137 | 60142100 | 167 | 60160400 | 81 |
| 60070500 | 77 | 60094400 | 101 | | 168 | | 138 139 | 60143100 | 167 | 60160600 | 103 |
| 60070600 | 77 | 60094600 | 74 | 60118600 | 87 | 60132200 | 143 | 60143200 | 167 | 60160700 | 94 |
| 60070700 | 77 | 60094800 | 60 | 60118700 | 76 | 60132300 | 142 | 60143400 | 160 | 60161200 | 157 |
| 60070800 | 163 | 60094900 | 61 | 60118800 | 76 | 60132400 | 142 | 60143600 | 167 | 60161300 | 167 |
| 60070900 | 163 | 60095000 | 61 | 60119100 | 60 | | 143 144 | 60144200 | 168 | 60162300 | 102 |
| 60071000 | 163 | 60095200 | 63 | | 62 | 60132500 | 134 | 60144500 | 78 | 60162600 | 90 |
| 60071100 | 163 | 60095400 | 62 | 60119200 | 61 | | 135 136 | 60145300 | 112 | 60162900 | 95 |
| 60071300 | 163 | 60095500 | 99 | 60119300 | 105 | | 137 138 139 | 60145500 | 95 | 60163500 | 79 |
| 60071400 | 163 | 60095700 | 168 | 60121100 | 62 | 60132800 | 143 | 60145600 | 95 | 60163900 | 112 |
| 60071500 | 158 | 60095800 | 168 | 60121300 | 99 | 60132900 | 141 | 60145700 | 95 | 60164200 | 82 |
| 60075400 | 92 | 60095900 | 167 | 60121400 | 99 | | 142 143 144 | 60145900 | 95 | 60164500 | 102 |
| 60080400 | 132 | 60096700 | 99 | 60121600 | 57 | 60133000 | 143 | 60146000 | 95 | 60164600 | 57 |
| 60081000 | 131 | 60096800 | 98 | 60122600 | 63 | | 144 | 60146100 | 103 | 60164700 | 57 |
| 60081100 | 132 | 60096900 | 95 | 60122700 | 102 | 60133100 | 138 | 60146200 | 103 | 60164800 | 57 |
| 60081300 | 132 | 60097000 | 95 | 60123100 | 113 | | 139 | 60146400 | 131 | 60165000 | 159 |
| 60081500 | 132 | 60097100 | 78 | | 168 | 60133300 | 147 | 60146500 | 131 | 60165100 | 93 |
| 60081900 | 144 | 60097200 | 171 | 60123200 | 113 | | 150 152 | 60146600 | 131 | 60165200 | 93 |
| 60082000 | 144 | 60097900 | 100 | | 168 | 60133500 | 144 | 60147200 | 91 | 60165300 | 92 |
| 60082400 | 144 | 60098200 | 78 | 60123300 | 112 | 60133600 | 145 | 60148100 | 167 | 60165400 | 92 |
| 60082600 | 131 | 60098400 | 71 | 60123400 | 113 | | 146 147 | 60148500 | 77 | 60165700 | 82 |
| 60083400 | 131 | 60099500 | 71 | 60123500 | 113 | | 150 152 | 60148900 | 106 | 60165800 | 79 |
| 60083500 | 144 | 60099800 | 100 | 60123600 | 60 | 60133700 | 141 | 60149600 | 106 | 60166000 | 103 |
| 60083600 | 132 | 60100000 | 102 | 60123700 | 62 | 60133800 | 138 | 60149800 | 113 | 60166100 | 103 |
| 60083700 | 132 | 60100200 | 60 | | 78 | | 139 | 60150000 | 95 | 60166200 | 103 |
| | 152 | 60100400 | 93 | 60123800 | 62 | 60133900 | 132 | 60150100 | 91 | 60166300 | 103 |

| PUB. NO. | PG. | PUB. NO. | PG. | PUB. NO. | PG. | PUB. NO. | PG. | PUB. NO. | PG. | PUB. NO. | PG. | | |
|----------|-----|----------|-----|----------|-----|----------|-----|----------|-----|----------|----------|-----|-----|
| 60166400 | 103 | 60175600 | 162 | 60190500 | 163 | 60213500 | 135 | 60235300 | 163 | 60244800 | 164 | | |
| 60166700 | 160 | 60175700 | 162 | 60190900 | 151 | 60213600 | 136 | 60235400 | 149 | 60244900 | 164 | | |
| 60166800 | 165 | 60176000 | 137 | 60191100 | 136 | 60213700 | 137 | 60235900 | 137 | 60245100 | 164 | | |
| 60166900 | 91 | 60176100 | 137 | | 137 | | 138 | 60236000 | 135 | 60245200 | 164 | | |
| 60167000 | 91 | 60176500 | 132 | 60191300 | 137 | 60214000 | 136 | 60236100 | 138 | 60245300 | 164 | | |
| 60167100 | 112 | 60176700 | 135 | 60191500 | 153 | 60214800 | 143 | 139 | 140 | 142 | 60245400 | 164 | |
| 60167200 | 112 | | 137 | 60191600 | 138 | | 144 | 60236300 | 141 | | 60245500 | 164 | |
| 60167500 | 84 | | 139 | 60191900 | 151 | 60214900 | 142 | 60236400 | 134 | | 60246400 | 106 | |
| 60167700 | 84 | 60177000 | 143 | 60192000 | 134 | 60215200 | 142 | | 135 | | 60246500 | 104 | |
| 60167900 | 93 | 60177200 | 144 | | 135 | 60216101 | 74 | 60236500 | 134 | | 60246600 | 107 | |
| 60169100 | 101 | 60177300 | 143 | 60192100 | 137 | 60216104 | 72 | | 136 | | 60246800 | 104 | |
| 60169500 | 159 | 60177400 | 137 | 60192400 | 163 | 60217400 | 46 | 60236600 | 136 | | 60246900 | 104 | |
| 60169600 | 159 | | 138 | 60192500 | 145 | 60217600 | 18 | 60236700 | 137 | | 60247000 | 107 | |
| 60169700 | 103 | 60177700 | 137 | | 151 | 60220100 | 79 | | 138 | | 60247100 | 107 | |
| 60170100 | 141 | | 138 | 60192600 | 142 | 60220200 | 79 | 60236800 | 134 | | 60247200 | 107 | |
| 60170200 | 138 | 60177800 | 144 | 60192700 | 142 | 60220300 | 79 | | 135 | 136 | 60247300 | 107 | |
| 60170300 | 143 | 60178000 | 141 | 60192800 | 137 | 60220400 | 79 | 138 | 139 | 140 | 60247400 | 107 | |
| | 144 | 60178600 | 136 | 60192900 | 143 | 60220500 | 79 | 60236900 | 134 | | 60247500 | 107 | |
| 60170400 | 143 | 60178800 | 136 | 60193100 | 148 | 60220600 | 79 | 136 | 137 | 135 | 60247600 | 107 | |
| | 144 | 60179000 | 144 | | 151 | 60220700 | 79 | 60237000 | 138 | | 60247700 | 107 | |
| 60170500 | 141 | 60179500 | 144 | 60193600 | 142 | 60220800 | 79 | 60237400 | 153 | | 60247800 | 107 | |
| 142 | 143 | 60179700 | 135 | 60194000 | 133 | 60220900 | 79 | 60237700 | 45 | | 60247900 | 107 | |
| 60170700 | 133 | 60179800 | 135 | 60194400 | 102 | 60221000 | 79 | 60237800 | 84 | | 60248000 | 107 | |
| 60170800 | 143 | 60180000 | 103 | 60194500 | 81 | 60221100 | 79 | 60238000 | 6 | | 60248100 | 107 | |
| | 144 | 60180100 | 103 | 60197000 | 97 | 60221200 | 79 | 60238300 | 162 | | 60248200 | 107 | |
| 60170900 | 141 | 60180200 | 170 | 60197100 | 103 | 60221300 | 79 | 60238400 | 159 | | 60248300 | 107 | |
| 142 | 143 | 60181200 | 101 | 60197200 | 103 | 60221400 | 79 | 60238500 | 159 | | 60248500 | 104 | |
| 60171100 | 131 | 60181300 | 63 | 60197300 | 100 | 60221500 | 79 | 60238700 | 161 | | 60248600 | 104 | |
| | 141 | 60181400 | 63 | 60197400 | 172 | 60221600 | 79 | 60238800 | 162 | | 60248700 | 104 | |
| 60171200 | 139 | 60182000 | 79 | 60197600 | 95 | 60221700 | 79 | 60239200 | 160 | | 60248800 | 104 | |
| | 140 | 60182100 | 103 | 60197700 | 102 | 60222100 | 36 | 60239400 | 162 | | 60248900 | 104 | |
| 60171300 | 143 | 60182400 | 46 | 60197900 | 90 | 60222200 | 133 | 60239500 | 160 | | 60249000 | 104 | |
| 60171500 | 141 | 60182800 | 83 | 60198000 | 90 | 60222400 | 163 | 60239600 | 161 | | 60249100 | 104 | |
| | 142 | 60182900 | 82 | 60198200 | 90 | 60223100 | 132 | 60239700 | 160 | | 60249400 | 160 | |
| 60171600 | 132 | 60183000 | 46 | 60199300 | 102 | 60223300 | 103 | 60240200 | 165 | | 60249900 | 160 | |
| | 133 | 60183300 | 160 | 60199700 | 160 | 60223800 | 46 | 60240300 | 164 | | 60250000 | 160 | |
| 60171800 | 139 | 60183400 | 160 | 60199800 | 169 | 60224000 | 45 | 60240400 | 159 | | 60250100 | 162 | |
| 60171900 | 141 | 60183900 | 160 | 60200300 | 97 | 60224100 | 87 | 60240600 | 159 | | 60250200 | 162 | |
| | 142 | 60184500 | 102 | 60201000 | 166 | 60224200 | 103 | 60240700 | 161 | | 60250300 | 162 | |
| 60172000 | 140 | 60184900 | 159 | 60201300 | 172 | 60224800 | 106 | 60241000 | 159 | | 60250400 | 160 | |
| 60172100 | 146 | 60185500 | 59 | 60201500 | 108 | 60224900 | 100 | 60241200 | 161 | | 60250500 | 160 | |
| | 148 | 60185600 | 93 | 60202000 | 159 | 60225100 | 108 | 60241300 | 160 | | 60250600 | 161 | |
| 60172200 | 144 | 60186000 | 108 | 60202100 | 169 | 60227300 | 108 | 60241400 | 159 | | 60250700 | 161 | |
| 60172300 | 133 | 60186100 | 102 | 60202600 | 91 | 60227400 | 165 | 60241600 | 161 | | 60250800 | 160 | |
| 60172500 | 138 | 60186700 | 95 | 60203200 | 169 | 60227500 | 170 | 60241700 | 161 | | 60250900 | 32 | |
| 60172800 | 135 | 60186900 | 94 | 60203300 | 101 | 60227600 | 135 | 60241800 | 161 | | 60251200 | 107 | |
| | 137 | 60187200 | 103 | 60205400 | 108 | 60227700 | 135 | 60241900 | 164 | | 60251300 | 46 | |
| 60172900 | 137 | 60187500 | 75 | 60206800 | 136 | 60228300 | 163 | 60242000 | 163 | | 60251900 | 145 | |
| 60173000 | 137 | 60187600 | 133 | 60207200 | 137 | 60228500 | 133 | 60242100 | 164 | | 148 | 150 | 152 |
| 60173300 | 141 | 60187700 | 103 | 60207300 | 136 | 60228700 | 9 | 60242200 | 164 | | 60252300 | 163 | |
| | 142 | 60187800 | 103 | | 137 | 60229300 | 135 | 60242300 | 163 | | 60252400 | 163 | |
| 60173400 | 137 | 60187900 | 104 | | 139 | 60229500 | 135 | 60242400 | 164 | | 60252500 | 163 | |
| | 138 | 60188600 | 63 | 60207700 | 167 | 60229700 | 163 | 60242500 | 163 | | 60252600 | 152 | |
| 60173500 | 145 | 60188800 | 69 | 60207800 | 91 | 60229900 | 137 | 60242600 | 164 | | 60252700 | 151 | |
| | 146 | 60188900 | 103 | 60207900 | 159 | 60230200 | 46 | 60242700 | 164 | | 60253000 | 146 | |
| | 150 | 60189000 | 138 | 60208200 | 84 | 60230300 | 19 | 60242800 | 163 | | 151 | 151 | |
| 60173600 | 143 | | 140 | 60208600 | 114 | 60231300 | 98 | 60242900 | 163 | | 60253200 | 107 | |
| | 144 | 60189100 | 149 | 60209600 | 18 | 60232000 | 45 | 60243000 | 163 | | 60253300 | 107 | |
| 60173700 | 132 | | 151 | 60209800 | 95 | 60232200 | 44 | 60243100 | 163 | | 60256700 | 162 | |
| | 133 | 60189300 | 153 | 60210200 | 18 | 60232300 | 44 | 60243300 | 163 | | 60257100 | 162 | |
| 60174100 | 137 | 60189500 | 145 | 60210300 | 72 | 60233100 | 6 | 60243400 | 164 | | 60257200 | 160 | |
| 60174200 | 133 | | 149 | 60210400 | 24 | 60233500 | 114 | 60243500 | 164 | | 60257600 | 162 | |
| 60174500 | 146 | 60189600 | 143 | 60210900 | 43 | 60233700 | 131 | 60243600 | 163 | | 60257700 | 160 | |
| | 148 | | 144 | 60211400 | 58 | | 141 | 60243800 | 164 | | 60257800 | 160 | |
| 60174700 | 141 | 60189700 | 137 | 60211500 | 58 | 60234300 | 132 | 60244000 | 164 | | 60257900 | 159 | |
| 60174800 | 143 | 60190000 | 133 | 60211600 | 167 | 60234400 | 163 | 60244100 | 163 | | 60258000 | 160 | |
| 60174900 | 145 | 60190100 | 143 | 60212200 | 18 | 60234500 | 133 | 60244200 | 163 | | 60258100 | 160 | |
| | 146 | 60190200 | 137 | 60212800 | 97 | 60234600 | 151 | 60244300 | 163 | | 60259400 | 134 | |
| 60175000 | 142 | | 138 | 60213100 | 94 | 60234700 | 163 | 60244400 | 163 | | 60259500 | 134 | |
| 60175100 | 139 | 60190300 | 137 | 60213200 | 94 | 60234800 | 145 | 60244500 | 164 | | 60259700 | 134 | |
| 60175300 | 143 | 60190400 | 137 | 60213300 | 106 | | 148 | 60244600 | 163 | | 60265500 | 111 | |
| | 144 | | | | | | 150 | | | | | | |

| PUB. NO. | PG. | PUB. NO. | PG. | PUB. NO. | PG. | PUB. NO. | PG. | PUB. NO. | PG. | PUB. NO. | PG. |
|----------|-----|----------|-----|----------|-----|----------|-----|----------|---------|----------|-----|
| 60266000 | 44 | 60279800 | 153 | 60291400 | 43 | 60304500 | 88 | 60316600 | 51 | 60331400 | 86 |
| 60266200 | 79 | | 154 | 60292600 | 49 | 60304600 | 88 | 60317100 | 168 | 60331500 | 100 |
| 60266300 | 103 | 60279900 | 146 | 60292700 | 49 | 60304700 | 89 | | 169 | 60331600 | 95 |
| 60266400 | 106 | 151 153 | 154 | 60293300 | 2 | 60305100 | 151 | 60317200 | 14 | 60331700 | 92 |
| 60266500 | 106 | 60280000 | 153 | 60293400 | 31 | 60305200 | 151 | 60317300 | 10 | 60331800 | 90 |
| 60267100 | 104 | 60280200 | 136 | 60293500 | 2 | 60305400 | 146 | 60317500 | 94 | 60331900 | 91 |
| 60267200 | 103 | 60280400 | 153 | 60293600 | 3 | | 151 | 60317600 | 10 | 60332000 | 90 |
| 60267300 | 106 | 60280600 | 133 | 60293700 | 2 | 60305600 | 149 | 60317800 | 87 | 60332200 | 93 |
| 60267400 | 107 | 60280700 | 137 | 60293800 | 3 | 60305700 | 132 | 60318100 | 94 | 60332300 | 93 |
| 60268000 | 104 | 60280800 | 135 | 60293900 | 2 | 150 152 | | 60318200 | 89 | 60332400 | 91 |
| 60268100 | 165 | 60281000 | 135 | 60294000 | 3 | 60305800 | 163 | 60318300 | 94 | 60332500 | 93 |
| 60268900 | 93 | 60281100 | 135 | 60294100 | 3 | 60305900 | 151 | 60318500 | 39 | 60332600 | 101 |
| 60269100 | 104 | | 137 | 60294200 | 3 | 60306200 | 149 | 60318600 | 49 | 60332700 | 93 |
| 60269200 | 45 | 60281200 | 153 | 60294300 | 3 | | 151 | 60318700 | 32 | 60332800 | 97 |
| 60270200 | 59 | 60281300 | 135 | 60294500 | 47 | 60307000 | 149 | 60318900 | 14 | 60332900 | 93 |
| 60270600 | 85 | 60281400 | 134 | 60294700 | 2 | 60307100 | 149 | 60319300 | 11 | 60333000 | 101 |
| 60270700 | 74 | 135 136 | 137 | 60294800 | 2 | 60307200 | 148 | 60319800 | 20 | 60333100 | 97 |
| 60270900 | 9 | 60281500 | 137 | 60294900 | 2 | 60307300 | 148 | 60320700 | 102 | 60333200 | 100 |
| 60271300 | 80 | 60281600 | 153 | 60295600 | 167 | | 150 | 60321100 | 43 | 60333300 | 92 |
| 60271400 | 80 | 60281700 | 145 | 60295900 | 14 | 60307400 | 148 | 60321400 | 125 | 60333400 | 101 |
| 60271500 | 80 | 146 147 | 153 | 60296200 | 39 | 60307500 | 147 | 60321500 | 125 | 60333500 | 101 |
| 60271600 | 80 | 60281900 | 136 | 60296500 | 10 | | 150 | 60321600 | 12 | 60333600 | 107 |
| 60271700 | 80 | 60282000 | 136 | 60296900 | 172 | 60307600 | 2 | 60321800 | 47 | 60333700 | 172 |
| 60271800 | 80 | 60282100 | 135 | 60297200 | 164 | 60307700 | 2 | 60323100 | 18 | 60333800 | 172 |
| 60271900 | 80 | 60282200 | 136 | 60297300 | 167 | 60307800 | 2 | 60323400 | 94 | 60334100 | 108 |
| 60272100 | 158 | 60282400 | 134 | 60297600 | 2 | 60307900 | 2 | 60323500 | 18 | 60334200 | 108 |
| 60272200 | 59 | 60282500 | 153 | 60297700 | 2 | 60308000 | 2 | 60324000 | 126 | 60334300 | 109 |
| 60272700 | 9 | 60282800 | 133 | 60297900 | 2 | 60308100 | 2 | 60324600 | 74 | 60334400 | 108 |
| 60273200 | 80 | 60282900 | 146 | 60298100 | 51 | 60308200 | 2 | 60324700 | 46 | 60334500 | 108 |
| 60273300 | 160 | 151 153 | | 60298400 | 51 | 60308300 | 2 | 60325100 | 71 | 60334600 | 108 |
| 60273400 | 159 | 60283000 | 145 | 60298600 | 51 | 60308400 | 2 | 60325600 | 80 | 60335400 | 48 |
| 60273500 | 160 | 146 147 | 153 | 60299500 | 103 | 60308500 | 2 | 60325700 | 80 | 60336400 | 3 |
| 60273600 | 160 | 60283100 | 153 | 60299700 | 113 | 60308600 | 2 | 60325800 | 80 | 60336500 | 89 |
| 60273800 | 162 | 60283200 | 46 | 60299800 | 37 | 60308700 | 2 | 60325900 | 80 | 60336600 | 89 |
| 60273900 | 162 | 60283400 | 8 | 60300000 | 87 | 60308800 | 2 | 60326100 | 80 | 60336700 | 89 |
| 60274100 | 160 | 60283500 | 8 | 60300100 | 87 | 60308900 | 2 | 60326200 | 80 | 60336800 | 89 |
| 60274300 | 160 | 60283600 | 45 | 60300200 | 88 | 60309000 | 2 | 60326300 | 80 | 60336900 | 89 |
| 60274400 | 162 | 60283900 | 81 | 60300300 | 88 | 60309100 | 2 | 60326400 | 80 | 60337000 | 89 |
| 60274900 | 6 | 60284000 | 82 | 60300400 | 88 | 60309200 | 80 | 60327000 | 152 | 60337100 | 89 |
| 60275000 | 48 | 60284100 | 2 | 60300500 | 88 | 60309300 | 80 | 60327200 | 150 | 60341500 | 91 |
| 60275100 | 166 | 60285200 | 85 | 60300600 | 88 | 60309400 | 80 | 60327300 | 148 | 60341600 | 111 |
| 60275200 | 166 | 60285300 | 2 | 60300700 | 88 | 60309500 | 80 | 60327600 | 146 | 60342100 | 155 |
| 60275300 | 167 | 60285400 | 3 | 60300800 | 88 | 60309600 | 103 | | 151 | 60342200 | 154 |
| 60275500 | 166 | 60285500 | 3 | 60300900 | 88 | 60309700 | 49 | 60327800 | 145 | 60342300 | 155 |
| 60275600 | 166 | 60285600 | 3 | 60301000 | 88 | 60309800 | 102 | 147 149 | 153 | 60342400 | 145 |
| 60275900 | 166 | 60285700 | 3 | 60301100 | 88 | 60310500 | 2 | 60327900 | 145 | 148 | 150 |
| 60276100 | 166 | 60286000 | 3 | 60301200 | 88 | 60311200 | 8 | 147 149 | 153 | 60342500 | 146 |
| 60276400 | 166 | | 10 | 60301300 | 88 | 60311500 | 160 | 60328400 | 145 | 150 152 | 153 |
| 60276500 | 166 | 60286100 | 3 | 60301400 | 88 | 60312400 | 6 | 147 149 | 154 | 60342600 | 154 |
| 60276600 | 166 | | 10 | 60301500 | 88 | 60312700 | 161 | 60328800 | 146 | 60342700 | 153 |
| 60277000 | 166 | 60286200 | 32 | 60301600 | 88 | 60313100 | 161 | 148 | 150 | 60342800 | 140 |
| 60277100 | 166 | 60286400 | 164 | 60301700 | 88 | 60313400 | 162 | 60329000 | 145 | 60343000 | 153 |
| 60277200 | 166 | 60286800 | 167 | 60301800 | 88 | 60313500 | 162 | | 151 | 60343300 | 155 |
| 60277300 | 166 | 60287000 | 78 | 60301900 | 88 | 60313600 | 161 | 60329100 | 151 | 60343400 | 145 |
| 60277400 | 166 | 60287100 | 73 | 60302000 | 88 | 60314100 | 159 | 60329400 | 145 | 147 149 | 154 |
| 60277500 | 166 | 60287200 | 45 | 60302200 | 88 | 60314200 | 159 | 147 149 | | 60343500 | 134 |
| 60277600 | 166 | 60287300 | 2 | 60302500 | 88 | 60314300 | 161 | | 151 154 | 135 | |
| 60277700 | 166 | 60287400 | 2 | 60302600 | 88 | 60314400 | 162 | | | 60343600 | 155 |
| 60277800 | 166 | 60287600 | 98 | 60302700 | 88 | 60314800 | 161 | 60329500 | 70 | 60343700 | 155 |
| 60278100 | 6 | 60288100 | 113 | 60302800 | 88 | 60314900 | 160 | 60329700 | 49 | 60343800 | 155 |
| 60278300 | 48 | 60288700 | 163 | 60303000 | 88 | 60315100 | 161 | 60329900 | 94 | 60343900 | 146 |
| 60278400 | 2 | 60289000 | 2 | 60303100 | 88 | 60315200 | 161 | 60330300 | 82 | 148 | 150 |
| 60278500 | 98 | | 107 | 60303200 | 88 | 60315500 | 13 | 60330400 | 83 | 60344000 | 154 |
| 60278800 | 46 | 60289100 | 43 | 60303300 | 88 | 60315600 | 10 | 60330500 | 83 | 60344100 | 154 |
| 60279100 | 63 | 60289200 | 18 | 60303800 | 88 | 60315700 | 10 | 60330600 | 84 | 60344200 | 145 |
| 60279200 | 142 | 60289500 | 6 | 60303900 | 88 | 60315900 | 20 | 60330700 | 84 | 150 | 154 |
| 60279400 | 137 | 60290000 | 44 | 60304000 | 88 | 60316000 | 20 | 60331000 | 84 | 60344300 | 154 |
| 60279500 | 153 | 60290900 | 116 | 60304100 | 88 | 60316100 | 20 | 60331100 | 84 | 60344400 | 145 |
| 60279600 | 153 | 60291000 | 100 | 60304200 | 88 | 60316200 | 3 | 60331200 | 85 | 148 | |
| | 154 | 60291100 | 8 | 60304300 | 88 | 60316500 | 47 | 60331300 | 85 | 60344700 | 38 |
| 60279700 | 153 | 60291200 | 8 | 60304400 | 88 | | | | | | |
| | 154 | | | | | | | | | | |

| PUB. NO. | PG. | PUB. NO. | PG. | PUB. NO. | PG. | PUB. NO. | PG. | PUB. NO. | PG. | PUB. NO. | PG. |
|----------|---------|-------------|---------|----------|---------|-------------|---------|----------|-----|----------|-----|
| 60344800 | 14 | 60358500 | 150 | 60370800 | 5 | 60384700 | 145 | 60401700 | 48 | 60413800 | 81 |
| 60345100 | 153 | | 152 | 60370900 | 5 | 147 148 154 | | 60401800 | 48 | 60413900 | 81 |
| 60346500 | 20 | 60358700 | 148 | 60371000 | 8 | 60384900 | 148 | 60402100 | 48 | 60414000 | 81 |
| 60347000 | 55 | 60358800 | 149 | 60371100 | 5 | | 150 | 60402200 | 48 | 60414100 | 81 |
| 60347100 | 56 | 60359000 | 149 | 60371200 | 5 | 60385200 | 147 | 60402700 | 48 | 60414200 | 81 |
| 60347200 | 55 | 60359200 | 148 | 60371300 | 5 | | 149 150 | 60402900 | 48 | 60414300 | 81 |
| 60347300 | 56 | | 150 | 60371400 | 5 | 60385300 | 150 | 60403900 | 155 | 60414400 | 81 |
| 60347600 | 8 | 60359400 | 146 | 60371800 | 134 | 60385500 | 148 | 60404000 | 42 | 60414500 | 81 |
| 60347700 | 170 | | 148 150 | | 135 136 | | 150 | 60404100 | 42 | 60414600 | 81 |
| 60348000 | 7 | 60359600 | 150 | 60372200 | 154 | 60385600 | 150 | 60404500 | 4 | 60414700 | 81 |
| 60348200 | 6 | 60359700 | 150 | 60372300 | 135 | | 152 | 60404800 | 15 | 60415100 | 134 |
| 60348300 | 6 | | 152 | 60372500 | 135 | 60385700 | 150 | 60404900 | 15 | 60415200 | 134 |
| 60348400 | 6 | 60359800 | 150 | 60372600 | 154 | 60385900 | 150 | 60405100 | 157 | 60415300 | 134 |
| 60348500 | 7 | | 152 | 60372700 | 134 | 60387900 | 145 | 60405200 | 16 | 60415400 | 134 |
| 60348600 | 7 | 60360100 | 155 | | 135 | | 147 149 | 60405400 | 16 | 60415500 | 134 |
| 60348700 | 7 | 60360200 | 146 | 60372800 | 134 | | 154 155 | | 127 | 60415600 | 103 |
| 60348800 | 7 | 148 150 153 | | | 135 | 60389600 | 21 | 60405500 | 45 | 60415800 | 11 |
| 60348900 | 7 | 60360400 | 155 | 60372900 | 153 | 60390100 | 109 | 60406000 | 158 | 60415900 | 11 |
| 60349000 | 7 | 60360500 | 155 | 60373100 | 135 | 60390600 | 16 | 60406100 | 11 | 60416000 | 8 |
| 60349100 | 7 | 60360700 | 154 | 60373400 | 132 | 60391700 | 11 | 60406300 | 171 | 60416400 | 45 |
| 60349200 | 7 | 60360900 | 145 | 60373500 | 157 | 60391800 | 11 | 60407000 | 145 | 60416700 | 14 |
| 60349300 | 7 | | 147 149 | 60373800 | 154 | 60391900 | 11 | 60407100 | 144 | 60417000 | 158 |
| 60349400 | 7 | 60361000 | 145 | 60373900 | 56 | 60392000 | 11 | 60407200 | 145 | 60417300 | 93 |
| 60349500 | 7 | 147 149 154 | | 60374500 | 12 | 60392100 | 11 | 60407500 | 145 | 60417600 | 17 |
| 60349600 | 7 | 60361100 | 140 | 60374800 | 8 | 60392300 | 11 | 60407700 | 145 | 60417800 | 134 |
| 60349700 | 7 | 60361200 | 140 | 60374900 | 5 | 60392400 | 11 | 60407800 | 145 | 60417900 | 136 |
| 60349800 | 7 | 60361500 | 132 | 60375600 | 16 | 60392600 | 37 | 60407900 | 146 | 60418000 | 134 |
| 60350200 | 4 | 60361600 | 132 | 60375700 | 16 | 60392700 | 16 | | 148 | 60418200 | 166 |
| 60350300 | 4 | 60361700 | 145 | 60376300 | 108 | 60393700 | 5 | 60408000 | 146 | 60418500 | 158 |
| 60350400 | 4 | 147 149 154 | | 60377100 | 4 | 60393800 | 5 | | 148 | 60418900 | 134 |
| 60350500 | 4 | 60361800 | 132 | 60377200 | 4 | 60394600 | 44 | 60408100 | 158 | 60419500 | 15 |
| 60350600 | 4 | 60361900 | 133 | 60377300 | 4 | 60394700 | 44 | 60408200 | 145 | 60419600 | 15 |
| 60350700 | 5 | 60362000 | 133 | 60378100 | 161 | 60394800 | 93 | 60408300 | 158 | 60419700 | 15 |
| 60350800 | 4 | 60362100 | 133 | 60378200 | 161 | 60396300 | 111 | 60408400 | 145 | 60419900 | 165 |
| 60350900 | 4 | 60362300 | 133 | 60378300 | 161 | 60396400 | 5 | 60408800 | 146 | 60420000 | 56 |
| 60351000 | 5 | 60362400 | 135 | 60378400 | 161 | 60396500 | 6 | 60408700 | 50 | 60420100 | 166 |
| 60351100 | 5 | 60363300 | 49 | 60378500 | 162 | 60396600 | 5 | 60409200 | 47 | 60420600 | 5 |
| 60351200 | 5 | 60363900 | 110 | 60378600 | 160 | 60396700 | 5 | 60409400 | 18 | 60420700 | 5 |
| 60351300 | 5 | 60364000 | 44 | 60378700 | 162 | 60396800 | 5 | 60410000 | 45 | 60420800 | 165 |
| 60351400 | 5 | 60364100 | 40 | 60378900 | 161 | 60396900 | 5 | 60410100 | 127 | 60420900 | 7 |
| 60352000 | 31 | 60364200 | 40 | 60379000 | 161 | 60397000 | 5 | 60410200 | 127 | 60421000 | 7 |
| 60352300 | 40 | 60364400 | 110 | 60379100 | 162 | 60397100 | 5 | 60410600 | 136 | 60421100 | 7 |
| 60352500 | 56 | 60364500 | 44 | 60379200 | 161 | 60397200 | 5 | 60410700 | 136 | 60421200 | 7 |
| 60353000 | 162 | 60364600 | 110 | 60379300 | 162 | 60397300 | 5 | 60410800 | 136 | 60421300 | 7 |
| 60353100 | 161 | 60364700 | 102 | 60379500 | 162 | 60397400 | 5 | 60410900 | 136 | 60421400 | 7 |
| 60353200 | 162 | 60364800 | 102 | 60380000 | 161 | 60397500 | 5 | 60411000 | 136 | 60421500 | 7 |
| 60353300 | 162 | 60364900 | 83 | 60380100 | 161 | 60397600 | 5 | 60411300 | 80 | 60421600 | 7 |
| 60353500 | 161 | 60365100 | 109 | 60380200 | 162 | 60397700 | 6 | 60411400 | 80 | 60421700 | 7 |
| 60353700 | 161 | 60365200 | 43 | 60380300 | 162 | 60397800 | 6 | 60411500 | 80 | 60421800 | 7 |
| 60354300 | 162 | 60365700 | 48 | 60380400 | 159 | 60397900 | 6 | 60411600 | 80 | 60421900 | 7 |
| 60354500 | 162 | 60366600 | 31 | 60380500 | 159 | 60398000 | 6 | 60411700 | 80 | 60422000 | 7 |
| 60354600 | 159 | 60366700 | 32 | 60380600 | 12 | 60398100 | 6 | 60411800 | 80 | 60422100 | 7 |
| 60354700 | 161 | 60366800 | 6 | 60380700 | 12 | 60398200 | 6 | 60411900 | 80 | 60422200 | 7 |
| 60354900 | 161 | 60367200 | 56 | 60380800 | 12 | 60398300 | 7 | 60412000 | 80 | 60422300 | 81 |
| 60355100 | 162 | 60367300 | 51 | 60380900 | 12 | 60398400 | 8 | 60412100 | 80 | 60422400 | 81 |
| 60355200 | 162 | 60367400 | 48 | 60381000 | 12 | 60398500 | 8 | 60412200 | 80 | 60422500 | 81 |
| 60355300 | 162 | 60368000 | 47 | 60381100 | 12 | 60398600 | 8 | 60412300 | 80 | 60422600 | 81 |
| 60355400 | 162 | 60368500 | 49 | 60381200 | 12 | 60398700 | 8 | 60412400 | 80 | 60422700 | 81 |
| 60355500 | 161 | 60368600 | 84 | 60381300 | 12 | 60398800 | 8 | 60412500 | 80 | 60422800 | 81 |
| 60355700 | 161 | 60368700 | 112 | 60381400 | 12 | 60398900 | 8 | 60412600 | 80 | 60422900 | 81 |
| 60355800 | 161 | 60369400 | 36 | 60382200 | 4 | 60399000 | 8 | 60412700 | 80 | 60423000 | 81 |
| 60355900 | 39 | 60369700 | 4 | 60382300 | 4 | 60399100 | 8 | 60412800 | 80 | 60423100 | 165 |
| 60356000 | 111 | 60369800 | 16 | 60382600 | 5 | 60399200 | 8 | 60412900 | 80 | 60423500 | 17 |
| 60356300 | 39 | 60369900 | 15 | 60382700 | 5 | 60399400 | 110 | 60413000 | 80 | 60425000 | 17 |
| 60357100 | 5 | 60370000 | 4 | 60382800 | 5 | 60399500 | 70 | 60413100 | 80 | 60425100 | 47 |
| 60357900 | 147 | 60370100 | 4 | 60383300 | 87 | 60399900 | 108 | 60413200 | 80 | 60425300 | 152 |
| | 149 154 | 60370200 | 4 | 60384100 | 145 | | | 60413300 | 80 | 60425600 | 45 |
| 60358200 | 148 | 60370300 | 15 | | 147 149 | 60400100 | 42 | 60413400 | 80 | 60425700 | 134 |
| 60358300 | 149 | 60370400 | 16 | 60384200 | 154 | 60401200 | 14 | 60413500 | 80 | 60425800 | 36 |
| | 153 | 60370500 | 16 | 60384300 | 147 | 60401500 | 48 | 60413600 | 80 | 60426000 | 134 |
| 60358400 | 149 | 60370600 | 10 | 60384600 | 150 | 60401600 | 48 | 60413700 | 81 | 60426500 | 152 |
| | 152 | | | | | | | | | | |

| PUB. NO. | PG. | PUB. NO. | PG. | PUB. NO. | PG. | PUB. NO. | PG. | PUB. NO. | PG. | PUB. NO. | PG. |
|----------|-----|----------|-----|----------|-----|----------|-----|----------|---------|----------|-----|
| 60427200 | 165 | 60493500 | 149 | 70603600 | 26 | 70616100 | 70 | 70631000 | 25 | 82128900 | 63 |
| 60427300 | 165 | | 152 | 70603700 | 26 | 70616200 | 70 | 70631100 | 25 | 82129000 | 63 |
| 60427400 | 165 | 62033500 | 127 | 70603900 | 24 | 70616300 | 27 | 70631300 | 28 | 82129700 | 63 |
| 60427500 | 8 | 62034200 | 127 | 70604000 | 53 | 70616400 | 28 | 70631400 | 28 | 82140400 | 31 |
| 60427600 | 42 | 62038000 | 127 | 70604100 | 124 | 70616700 | 44 | 70631500 | 28 | 82140800 | 35 |
| 60427800 | 51 | 62049500 | 127 | 70604200 | 121 | 70616800 | 158 | 73361200 | 41 | 82146800 | 95 |
| 60427900 | 157 | 62056300 | 53 | 70604300 | 25 | 70617000 | 27 | 73443000 | 157 | 82269600 | 165 |
| 60428500 | 45 | 62061700 | 127 | 70604400 | 25 | 70617100 | 27 | 73443100 | 157 | 83096200 | 123 |
| 60429200 | 158 | 62067900 | 118 | 70604500 | 25 | 70617400 | 31 | 73933300 | 157 | 83096300 | 123 |
| 60429900 | 3 | 62068000 | 127 | 70604700 | 25 | 70617800 | 30 | 74606800 | 39 | 83096400 | 123 |
| 60430000 | 110 | 62068100 | 118 | 70605000 | 25 | 70617900 | 30 | 74607500 | 41 | 83301000 | 29 |
| 60433400 | 3 | 62068200 | 127 | 70605300 | 25 | 70618000 | 30 | 74660300 | 41 | 83301100 | 28 |
| 60433600 | 3 | 62068300 | 118 | 70605400 | 71 | 70618400 | 29 | 74664300 | 41 | 83301200 | 28 |
| 60433700 | 3 | 62068400 | 127 | 70605500 | 25 | 70618500 | 29 | 74675500 | 41 | 83301400 | 124 |
| 60433800 | 3 | 62073300 | 127 | 70605800 | 27 | 70618600 | 29 | 74691800 | 41 | 83301500 | 124 |
| 60433900 | 3 | 62073800 | 118 | 70605900 | 53 | 70619100 | 158 | 74717600 | 41 | 83301600 | 124 |
| 60434000 | 3 | 62074000 | 127 | 70606100 | 26 | 70619200 | 27 | 74720400 | 41 | 83301700 | 124 |
| 60434100 | 3 | 62079500 | 116 | 70606500 | 25 | 70619300 | 27 | 74720500 | 41 | 83301800 | 45 |
| 60434200 | 4 | 62088900 | 127 | 70606600 | 123 | 70619400 | 27 | 74724500 | 41 | 83301900 | 45 |
| 60434300 | 4 | 62089100 | 127 | 70606700 | 24 | 70619500 | 26 | 75365100 | 123 | 83302000 | 45 |
| 60434600 | 3 | 62122800 | 127 | 70606800 | 72 | 70619600 | 26 | 75365200 | 124 | 83302300 | 30 |
| 60434700 | 3 | 62122900 | 127 | 70606900 | 24 | 70619700 | 26 | 75368900 | 124 | 83302400 | 30 |
| 60434800 | 3 | 62181600 | 165 | 70607100 | 24 | 70620400 | 27 | 75369000 | 125 | 83302500 | 30 |
| 60434900 | 3 | 62995900 | 35 | 70607200 | 26 | 70620500 | 27 | 75369100 | 124 | 83302600 | 30 |
| 60435000 | 3 | 62996000 | 35 | 70607300 | 26 | 70620600 | 27 | 75369200 | 124 | 83302700 | 30 |
| 60435100 | 3 | 63016700 | 106 | 70607500 | 24 | 70621300 | 123 | 75369600 | 124 | 83302800 | 30 |
| 60435400 | 147 | 63016900 | 105 | 70607700 | 121 | 70621400 | 48 | 75369800 | 124 | 83302900 | 53 |
| 60435500 | 147 | 63017100 | 105 | 70607900 | 28 | 70621500 | 44 | 75372900 | 124 | 83303100 | 29 |
| 60435600 | 147 | 63017200 | 105 | 70608100 | 124 | 70621600 | 44 | 75373000 | 124 | 83303200 | 29 |
| 60435700 | 147 | 63017300 | 105 | 70608200 | 124 | 70621700 | 44 | 75385700 | 124 | 83303300 | 29 |
| 60435800 | 147 | 63017400 | 105 | 70609200 | 27 | 70621800 | 44 | 75387400 | 123 | 83303700 | 53 |
| 60435900 | 147 | 63019200 | 105 | 70609300 | 27 | 70621900 | 44 | 75387500 | 123 | 83305700 | 29 |
| 60436100 | 147 | 63019600 | 105 | 70609400 | 26 | 70622000 | 123 | 75391300 | 124 | 83305800 | 29 |
| 60436200 | 147 | 63019700 | 105 | 70609500 | 27 | 70622100 | 24 | 75400200 | 65 | 83305900 | 29 |
| 60436300 | 147 | 63019800 | 105 | 70609600 | 33 | 70622200 | 28 | 75401000 | 123 | 83306000 | 45 |
| 60436600 | 145 | 63024900 | 106 | 70609700 | 26 | 70622300 | 28 | 75401400 | 124 | 83306100 | 50 |
| 60437000 | 166 | 63025400 | 106 | 70609800 | 27 | 70622400 | 28 | 75401500 | 124 | 83306300 | 50 |
| 60437100 | 166 | 63025500 | 105 | 70609900 | 27 | 70622500 | 28 | 75401700 | 124 | 83307900 | 53 |
| 60437200 | 167 | 63025600 | 105 | 70610100 | 27 | 70622600 | 28 | 75401800 | 124 | 83308000 | 53 |
| 60437300 | 111 | 63033500 | 106 | 70610300 | 28 | 70622700 | 28 | 75402000 | 124 | 83308400 | 25 |
| 60437400 | 81 | 63033600 | 106 | 70610500 | 28 | 70622800 | 28 | 75402100 | 124 | 83308500 | 25 |
| 60437500 | 81 | 63033700 | 106 | 70611000 | 27 | 70623500 | 28 | 76070000 | 145 | 83308600 | 25 |
| 60437600 | 81 | 63033800 | 106 | 70611100 | 27 | 70623600 | 28 | | 148 | 83308700 | 29 |
| 60437700 | 81 | 65631800 | 86 | 70611200 | 27 | 70623700 | 28 | 76070300 | 146 | 83308800 | 29 |
| 60437800 | 81 | 65655800 | 87 | 70611300 | 27 | 70624500 | 30 | | 148 176 | 83308900 | 29 |
| 60437900 | 81 | 65690800 | 87 | 70611500 | 70 | 70624600 | 30 | 76070400 | 174 | 83309300 | 29 |
| 60438000 | 81 | 65692300 | 36 | 70611600 | 70 | 70624700 | 30 | 76070600 | 175 | 83309400 | 29 |
| 60438100 | 81 | 65714900 | 58 | 70611700 | 71 | 70626300 | 29 | 76070700 | 173 | 83309500 | 29 |
| 60438200 | 81 | 65715000 | 58 | 70611800 | 71 | 70626500 | 28 | 76070800 | 178 | 83310800 | 25 |
| 60438300 | 81 | 65715100 | 58 | 70611900 | 71 | 70627400 | 124 | 76070900 | 172 | 83310900 | 25 |
| 60438400 | 81 | 65724900 | 91 | 70612000 | 71 | 70627900 | 29 | 76071000 | 176 | 83311400 | 28 |
| 60438500 | 43 | 65727400 | 87 | 70612200 | 121 | 70628000 | 29 | 76071200 | 174 | 83311600 | 29 |
| 60438600 | 81 | 65739900 | 59 | 70612400 | 124 | 70628100 | 29 | 76071400 | 173 | 83311700 | 29 |
| 60440800 | 109 | 69651800 | 9 | 70612500 | 28 | 70628200 | 28 | 76072700 | 173 | 83311900 | 45 |
| 60441000 | 157 | 70601100 | 71 | 70612600 | 27 | 70628400 | 28 | 76074000 | 176 | 83312000 | 45 |
| 60443100 | 157 | 70601300 | 24 | 70612800 | 53 | 70628500 | 30 | 76074300 | 175 | 83312100 | 45 |
| 60445300 | 147 | 70601400 | 25 | 70612900 | 27 | 70628600 | 30 | 76074400 | 175 | 83312300 | 53 |
| 60446100 | 81 | 70601500 | 25 | 70613000 | 27 | 70629100 | 158 | 76074600 | 175 | 83313100 | 29 |
| 60446200 | 81 | 70601700 | 33 | 70613100 | 27 | 70629200 | 30 | 76074700 | 175 | 83313200 | 29 |
| 60446300 | 81 | 70601900 | 26 | 70613200 | 28 | 70629300 | 30 | 76360001 | 162 | 83313300 | 29 |
| 60446400 | 81 | 70602100 | 33 | 70613300 | 28 | 70629400 | 30 | 76360002 | 161 | 83313400 | 30 |
| 60446500 | 81 | 70602200 | 25 | 70613700 | 123 | 70629500 | 29 | 76360003 | 162 | 83313500 | 30 |
| 60446600 | 81 | 70602300 | 25 | 70613800 | 44 | 70629600 | 29 | 76360010 | 159 | 83313600 | 30 |
| 60446700 | 81 | 70602400 | 26 | 70613900 | 44 | 70629700 | 29 | 76360011 | 161 | 83314000 | 29 |
| 60446800 | 81 | 70602500 | 26 | 70614000 | 44 | 70629800 | 124 | 76360012 | 161 | 83315400 | 50 |
| 60447700 | 81 | 70602900 | 124 | 70614100 | 44 | 70629900 | 124 | 76360015 | 160 | 83315600 | 42 |
| 60448200 | 145 | 70603000 | 26 | 70614200 | 44 | 70630000 | 30 | 76360023 | 161 | 83315700 | 42 |
| 60449200 | 147 | 70603200 | 26 | 70615100 | 28 | 70630100 | 30 | 76360031 | 161 | 83315800 | 42 |
| 60449200 | 145 | 70603300 | 26 | 70615700 | 166 | 70630200 | 30 | 76630900 | 120 | 83316100 | 42 |
| | 148 | 70603400 | 26 | 70615800 | 24 | 70630500 | 28 | 82115700 | 74 | 83316200 | 42 |
| 60493300 | 145 | 70603500 | 26 | 70615900 | 27 | 70630900 | 25 | 82128800 | 63 | 83316300 | 42 |
| | 147 | | | | | | | | | | |

| <u>PUB. NO.</u> | <u>PG.</u> | <u>PUB. NO.</u> | <u>PG.</u> | <u>PUB. NO.</u> | <u>PG.</u> | <u>PUB. NO.</u> | <u>PG.</u> | <u>PUB. NO.</u> | <u>PG.</u> |
|-----------------|------------|-----------------|------------|-----------------|------------|-----------------|------------|-----------------|------------|
| 83316400 | 42 | 84007900 | 177 | 86608900 | 173 | 86618400 | 173 | 91681100 | 155 |
| 83316600 | 42 | 84008000 | 177 | 86609000 | 176 | 86618500 | 173 | 91858500 | 118 |
| 84000000 | 175 | 84008100 | 177 | 86609100 | 176 | 86618900 | 174 | 91858600 | 67 |
| 84000100 | 175 | 84008200 | 177 | 86609200 | 176 | 86619600 | 174 | 91858700 | 67 |
| 84000400 | 175 | 84008300 | 178 | 86609300 | 176 | 86619700 | 174 | 91858800 | 67 |
| 84000500 | 172 | 84008400 | 178 | 86609400 | 176 | 86619900 | 174 | 91859000 | 67 |
| 84000600 | 173 | 84008500 | 178 | 86609500 | 176 | 86811400 | 25 | 91859100 | 118 |
| 84000700 | 175 | 84008600 | 178 | 86609600 | 176 | 87829800 | 33 | 91859200 | 118 |
| 84000800 | 173 | 84008700 | 178 | 86609700 | 176 | 87900200 | 72 | 91860100 | 67 |
| 84000900 | 172 | 84008800 | 178 | 86609800 | 176 | 87906700 | 33 | 91860200 | 49 |
| 84001000 | 173 | 84008900 | 178 | 86609900 | 176 | 87911800 | 33 | 91860300 | 52 |
| 84001100 | 176 | 84009000 | 178 | 86610000 | 176 | 87951000 | 33 | 91860400 | 67 |
| 84001200 | 173 | 84009100 | 178 | 86610100 | 176 | 87971600 | 33 | 96716700 | 133 |
| 84001300 | 173 | 84009200 | 178 | 86610200 | 176 | 87971700 | 33 | 97400200 | 154 |
| 84001400 | 173 | 84009300 | 178 | 86610300 | 176 | 87976600 | 155 | 97400300 | 152 |
| 84001500 | 173 | 84009400 | 178 | 86610400 | 176 | 87976700 | 155 | 97401500 | 157 |
| 84001700 | 173 | 84009600 | 175 | 86610500 | 176 | 87976800 | 155 | 97401600 | 157 |
| 84001800 | 173 | 84009800 | 174 | 86610600 | 176 | 87978800 | 74 | 97401700 | 158 |
| 84001900 | 173 | 84009900 | 175 | 86610700 | 176 | 88762000 | 133 | 97401800 | 170 |
| 84002000 | 173 | 84763300 | 140 | 86610800 | 176 | 88762100 | 133 | 97401900 | 9 |
| 84002100 | 173 | 84781600 | 76 | 86610900 | 176 | 88762200 | 133 | 97402000 | 171 |
| 84002400 | 175 | 84785000 | 158 | 86611000 | 176 | 88818500 | 133 | 97402100 | 9 |
| 84002500 | 174 | 84797500 | 133 | 86611100 | 177 | 88947900 | 133 | 97402200 | 171 |
| 84002600 | 173 | 84837900 | 75 | 86611200 | 177 | 88948500 | 133 | 97402300 | 9 |
| 84002700 | 173 | 84851100 | 76 | 86611300 | 177 | 88964000 | 133 | 97402400 | 9 |
| 84002800 | 174 | 84894200 | 74 | 86611400 | 177 | 88980100 | 42 | 97402500 | 171 |
| 84002900 | 173 | 84937300 | 75 | 86611500 | 177 | 88981000 | 76 | 97402600 | 9 |
| 84003000 | 173 | 84942200 | 43 | 86611600 | 177 | 88981100 | 41 | 97402700 | 170 |
| 84003100 | 173 | 84970400 | 79 | 86611700 | 177 | 88981500 | 150 | 97402700 | 8 |
| 84003200 | 173 | 86601600 | 175 | 86611800 | 177 | 88988400 | 149 | 97403500 | 123 |
| 84003700 | 173 | 86601700 | 175 | 86611900 | 177 | 88988500 | 149 | 97403600 | 158 |
| 84003800 | 175 | 86601800 | 172 | 86612000 | 177 | 88988600 | 149 | 97404600 | 123 |
| 84003900 | 145 | 86602000 | 174 | 86612100 | 174 | 88988700 | 149 | 97404700 | 152 |
| 84004000 | 178 | 86602300 | 174 | 86612300 | 173 | 88988800 | 149 | 97404800 | 152 |
| 84004100 | 178 | 86602800 | 172 | 86612500 | 173 | 88988900 | 149 | 97404900 | 152 |
| 84004200 | 178 | 86602900 | 173 | 86612600 | 174 | 88997600 | 133 | 97405000 | 152 |
| 84004300 | 178 | 86603000 | 173 | 86613500 | 173 | 89633300 | 86 | 97405100 | 152 |
| 84004400 | 178 | 86603100 | 173 | 86613600 | 174 | 89633400 | 86 | 97405200 | 152 |
| 84004500 | 178 | 86603200 | 173 | 86613700 | 174 | 89637200 | 85 | 97405500 | 152 |
| 84004600 | 178 | 86603300 | 173 | 86613800 | 174 | 89637300 | 46 | | |
| 84004700 | 178 | 86603500 | 174 | 86614000 | 177 | 89637400 | 84 | | |
| 84004800 | 178 | 86603700 | 173 | 86614100 | 174 | 89637700 | 43 | | |
| 84004900 | 178 | 86604000 | 175 | 86614200 | 175 | 89638100 | 44 | | |
| 84005000 | 178 | 86604100 | 175 | 86614300 | 174 | 89638200 | 85 | | |
| 84005100 | 178 | 86604200 | 175 | 86614600 | 177 | 89638300 | 38 | | |
| 84005200 | 178 | 86604300 | 175 | 86614900 | 177 | 89638400 | 85 | | |
| 84005300 | 178 | 86604600 | 174 | 86615000 | 174 | 89638500 | 47 | | |
| 84005400 | 178 | 86604700 | 174 | 86615100 | 175 | 89638800 | 171 | | |
| 84005500 | 178 | 86604800 | 174 | 86615500 | 175 | 89673100 | 6 | | |
| 84005600 | 178 | 86604900 | 174 | 86615600 | 177 | | 86 | | |
| 84005700 | 178 | 86605600 | 173 | 86615700 | 173 | 89723700 | 158 | | |
| 84005800 | 178 | 86605700 | 177 | 86615800 | 174 | 89758600 | 17 | | |
| 84005900 | 178 | 86605900 | 172 | 86615900 | 176 | 89769400 | 84 | | |
| 84006000 | 178 | 86606100 | 174 | 86616100 | 173 | 89769500 | 44 | | |
| 84006200 | 178 | 86606200 | 175 | 86616300 | 174 | 89796100 | 49 | | |
| 84006300 | 178 | 86607000 | 175 | 86616600 | 174 | 91503500 | 169 | | |
| 84006700 | 174 | 86607100 | 173 | 86616700 | 174 | 91556200 | 133 | | |
| 84006800 | 177 | 86607200 | 173 | 86616800 | 172 | 91558900 | 35 | | |
| 84006900 | 177 | 86607500 | 175 | 86616900 | 173 | 91566700 | 72 | | |
| 84007000 | 177 | 86607700 | 172 | 86617100 | 175 | 91604200 | 74 | | |
| 84007100 | 177 | 86607800 | 174 | 86617200 | 175 | 91604300 | 74 | | |
| 84007200 | 177 | 86607900 | 174 | 86617300 | 175 | 91604400 | 74 | | |
| 84007300 | 177 | 86608000 | 175 | 86617400 | 175 | 91604500 | 74 | | |
| 84007400 | 177 | 86608100 | 175 | 86617500 | 175 | 91628700 | 52 | | |
| 84007500 | 177 | 86608400 | 175 | 86617700 | 175 | 91649500 | 155 | | |
| 84007600 | 177 | 86608500 | 175 | 86618000 | 172 | 91661300 | 155 | | |
| 84007700 | 177 | 86608600 | 176 | 86618200 | 176 | 91662900 | 35 | | |
| 84007800 | 177 | 86608700 | 176 | 86618300 | 175 | 91669100 | 33 | | |

SECTION 1

This section contains Hardware Manuals for individual equipments arranged in equipment designator sequence. Product numbers are included in parenthesis after the equipment designator. Additional manuals may be found in Section 2 by looking up the Product Number.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|----|----|-------|
| INDIVIDUAL EQUIPMENT MANUALS | | | | |
| AA101-A/B COMPUTER (USE 1704-A/B, CAT. SEC. 2) | | | | |
| AA102-A (7601-1) CENTRAL COMPUTER | | | | |
| PARTS DATA CE MANUAL | 60297700 | B | 22 | 12.35 |
| CHANNEL TABS WIRE LIST CE MANUAL | 60351900 | C | 22 | 06.25 |
| THEORY OF OPERATION, DIAGRAMS, MAINT. AIDS | 60297600 | AC | 22 | 46.50 |
| CHASSIS 1 WIRE LIST CE MANUAL | 60307600 | D | 22 | 05.10 |
| CHASSIS 2 WIRE LIST CE MANUAL | 60307700 | D | 22 | 04.60 |
| CHASSIS 3 WIRE LIST CE MANUAL | 60307800 | E | 22 | 06.70 |
| CHASSIS 4 WIRE LIST CE MANUAL | 60307900 | E | 22 | 04.50 |
| CHASSIS 5 WIRE LIST CE MANUAL | 60308000 | C | 22 | 04.15 |
| CHASSIS 6 WIRE LIST CE MANUAL | 60308100 | J | 22 | 05.70 |
| CHASSIS 7 WIRE LIST CE MANUAL | 60308200 | N | 22 | 05.50 |
| CHASSIS 8 WIRE LIST CE MANUAL | 60308300 | J | 22 | 09.70 |
| CHASSIS 9 WIRE LIST CE MANUAL | 60308400 | C | 22 | 05.05 |
| CHASSIS 10 WIRE LIST CE MANUAL | 60308500 | E | 22 | 05.05 |
| CHASSIS 11 WIRE LIST CE MANUAL | 60308600 | C | 22 | 05.00 |
| CHASSIS 12 WIRE LIST CE MANUAL | 60308700 | C | 22 | 04.80 |
| CHASSIS 13 WIRE LIST CE MANUAL | 60308800 | G | 22 | 07.00 |
| CHASSIS 14 WIRE LIST CE MANUAL | 60308900 | G | 22 | 06.15 |
| LGM STACK WIRE LIST CE MANUAL | 60309000 | D | 22 | 03.75 |
| POWER AND REFERENCE WIRE LISTS CE MANUAL | 60309100 | E | 22 | 04.30 |
| MAINTENANCE MANUAL | 60297900 | E | 22 | 15.00 |
| REFRIGERATION INFO (USE GH214-A/B) | | | | |
| (THE FOLLOWING MANUALS FOR THE ABOVE EQUIP. ARE AVAILABLE FROM D. VESTAL, ARHOPS (X3258) H2720C, H2720D SCANNER SYSTEMS SERVICE MANUAL PRICE AVAILABLE UPON REQUEST | 60298500 | | | |
| AA102-C () CENTRAL COMPUTER CE INFO (USE AC113-A) | | | | |
| AA103-A CENTRAL COMPUTER (6614-E) | | | | |
| CPU/FUNCTIONAL UNIT DIAGRAMS CE MANUAL | 60287300 | T | 22 | 13.60 |
| DEPIPH PROC UNIT DIAGRAMS CE MANUAL | 60284100 | U | 22 | 05.50 |
| CENTRAL MEMORY, CLOCK, ECS COUPLER AND POWER DIAGRAMS CE MANUAL | 60287400 | L | 22 | 09.35 |
| MAINTENANCE AID-CLOCK TIMING | 60289000 | B | 22 | 01.80 |
| CHASSIS 1 CHASSIS/CABLE TABS CE MANUAL | 60285300 | AD | 22 | 18.40 |
| CHASSIS 4 CHASSIS/CABLE TABS CE MANUAL | 60310500 | J | 22 | 19.75 |
| CHASSIS 5 CHASSIS/CABLE TABS CE MANUAL | 60293300 | S | 22 | 19.20 |
| CHASSIS 6 CHASSIS/CABLE TABS CE MANUAL | 60294700 | F | 22 | 20.60 |
| CHASSIS 7 CHASSIS/CABLE TABS CE MANUAL | 60294800 | C | 22 | 20.00 |
| CHASSIS 8 CHASSIS/CABLE TABS CE MANUAL | 60294900 | F | 22 | 21.70 |
| CHASSIS 9 CHASSIS/CABLE TABS CE MANUAL | 60278400 | P | 22 | 16.50 |
| CHASSIS 10 CHASSIS/CABLE TABS CE MANUAL | 60293500 | G | 22 | 08.75 |
| CHASSIS 11 CHASSIS/CABLE TABS CE MANUAL | 60293700 | F | 22 | 08.30 |
| CHASSIS 12 CHASSIS/CABLE TABS CE MANUAL | 60293900 | H | 22 | 09.80 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|---|----|-------|
| AA104-A CENTRAL COMPUTER (6613-E) | | | | |
| CPU/FUNCTIONAL UNIT DIAGRAMS (USE AA103-A) | | | | |
| PERIP PROC UNIT DIAGRAMS (USE AA103-A) | | | | |
| CENTRAL MEMORY, CLOCK, ECS COUPLER, AND POWER DIAGRAMS (USE AA103-A) | | | | |
| MAINTENANCE AID-CLOCK TIMING (USE AA103-A) | | | | |
| CHASSIS 1 CHASSIS/CABLE TABS (USE AA103-A) | | | | |
| CHASSIS 4 CHASSIS/CABLE TABS (USE AA103-A) | | | | |
| CHASSIS 5 CHASSIS/CABLE TABS (USE AA103-A) | | | | |
| CHASSIS 6 CHASSIS/CABLE TABS (USE AA103-A) | | | | |
| CHASSIS 7 CHASSIS/CABLE TABS (USE AA103-A) | | | | |
| CHASSIS 8 CHASSIS/CABLE TABS (USE AA103-A) | | | | |
| CHASSIS 9 CHASSIS/CABLE TABS (USE AA103-A) | | | | |
| CHASSIS 10 CHASSIS/CABLE TABS | 60293600 | F | 22 | 09.50 |
| CHASSIS 11 AND 15 TABS CE MANUAL | 60293800 | F | 22 | 09.00 |
| CHASSIS 12 CHASSIS/CABLE TABS CE MANUAL | 60294000 | E | 22 | 08.45 |
| CHASSIS 13 CHASSIS/CABLE TABS CE MANUAL | 60294100 | D | 22 | 10.75 |
| CHASSIS 14 CHASSIS/CABLE TABS CE MANUAL | 60294200 | D | 22 | 08.50 |
| CHASSIS 16 CHASSIS/CABLE TABS CE MANUAL | 60294300 | E | 22 | 05.00 |
| AA105-A CENTRAL COMPUTER (6414-E) | | | | |
| DIAGRAMS CE MANUAL | 60316200 | Z | 22 | 24.50 |
| PERIPH PROC UNIT DIAGRAMS (USE AA103-A) | | | | |
| CHASSIS 1 CHASSIS/CABLE TABS (USE AA103-A) | | | | |
| CHASSIS 2 CHASSIS/CABLE TABS CE MANUAL | 60285400 | M | 22 | 20.00 |
| CHASSIS 3 CHASSIS/CABLE TABS CE MANUAL | 60285500 | Z | 22 | 12.65 |
| CHASSIS 4 CHASSIS/CABLE TABS CE MANUAL | 60285600 | E | 22 | 09.85 |
| CHASSIS 5 CHASSIS/CABLE TABS CE MANUAL | 60285700 | G | 22 | 09.85 |
| CHASSIS 8 CHASSIS/CABLE TABS CE MANUAL | 60336400 | L | 22 | 13.30 |
| AA105-A, AT141-A CHASSIS 9 AND 11 CARD PLACE- MENT. WIRE LIST, CE MANUAL | 60286000 | F | 22 | 07.95 |
| CHASSIS 10 AND 12 CARD PLACEMENT, WIRE LISTS CE MANUAL | 60286100 | G | 22 | 10.65 |
| AA106-A (76-XXX) CENTRAL COMPUTER | | | | |
| INSTALLATION/CHECKOUT, THEORY OF OP, DIAGRAMS, MAINT AIDS, PARTS DATA CE MANUAL | 60433600 | A | 22 | 65.00 |
| POWER DISTRIBUTION/WARNING SYSTEM CE MANUAL | 60433400 | A | 22 | 17.50 |
| REFRIGERATION SYSTEM INFO (USE GH223-A) | | | | |
| MAINTENANCE CE MANUAL | 60429900 | A | 22 | 25.90 |
| CHASSIS 1 WIRE LIST CE MANUAL | 60434600 | A | 22 | |
| CHASSIS 2 WIRE LIST CE MANUAL | 60434700 | A | 22 | 23.05 |
| CHASSIS 3 WIRE LIST CE MANUAL | 60434800 | A | 22 | 26.05 |
| CHASSIS 4 WIRE LIST CE MANUAL | 60434900 | A | 22 | 19.70 |
| CHASSIS 5 WIRE LIST CE MANUAL | 60435000 | A | 22 | 20.00 |
| CHASSIS 6 WIRE LIST CE MANUAL | 60435100 | A | 22 | 23.10 |
| CHASSIS 7 WIRE LIST CE MANUAL | 60433700 | A | 22 | 22.20 |
| CHASSIS 8 WIRE LIST CE MANUAL | 60433800 | A | 22 | 24.55 |
| CHASSIS 9 WIRE LIST CE MANUAL | 60433900 | A | 22 | 22.50 |
| CHASSIS 10 WIRE LIST CE MANUAL | 60434000 | A | 22 | |
| CHASSIS 11 WIRE LIST CE MANUAL | 60434100 | A | 22 | |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|----|----|-------|
| CHASSIS 13 WIRE LIST CE MANUAL | 60434200 | A | 22 | |
| CHASSIS 14 WIRE LIST CE MANUAL | 60434300 | A | 22 | |
| CABLE WIRE LIST CE MANUAL | 60434400 | A | 22 | |
| AA107-A (172-X,173-X,174-X) REFRIGERATION SYST GEN. DESC., OPERATION, THEORY OF OPERATION, INSTALLATION/CHECKOUT, MAINTENANCE, PARTS DATA HARDWARE MAINTENANCE MANUAL | 19983800 | 01 | 22 | 03.45 |
| AA108-A CENTRAL COMPUTER (6415-E) PERIPH PROC UNIT DIAGRAMS (USE AA103-A) CHASSIS 1 CHASSIS/CABLE TABS (USE AA103-A) CHASSIS 2,3,4,5 AND 8 CHASSIS/CABLE TABS CE MANUALS (USE AA105-A) | | | | |
| AA108-B (PROD 6415-9) CENTRAL COMPUTER PERIPH PROC UNIT DIAGRAMS (USE AA103-A) CHASSIS 1 CHASSIS/CABLE TABS (USE AA103-A) CHASSIS 2,3,4,5 AND 8 CHASSIS/CABLE TABS CE MANUALS (USE AA105-A) CHASSIS 11 CHASSIS/CABLE TABS (USE AA103-A) | | | | |
| AA108-C (PROD 6415-8) CENTRAL COMPUTER PERIPH PROC UNIT DIAGRAMS (USE AA103-A) CHASSIS 2,3,4,5 AND 8 CHASSIS/CABLE TABS CE MANUALS (USE AA105-A) | | | | |
| AA108-D (PROD 6415-7) CENTRAL COMPUTER PERIPH PROC UNIT DIAGRAMS (USE AA103-A) CHASSIS 1 CHASSIS/CABLE TABS (USE AA103-A) CHASSIS 2,3,4,5 AND 8 CHASSIS/CABLE TABS CE MANUALS (USE AA105-A) | | | | |
| AA115-A (72-XX, 73-XX) BASIC UNIFIED PROCESSOR COMMAND TIMING CE MANUAL | 60404500 | A | 22 | 15.15 |
| REFRIGERATION SYSTEMS CE MANUAL | 60382300 | C | 22 | 03.30 |
| POWER DISTRIBUTION/WARNING SYSTEM CE MANUAL | 60382200 | F | 22 | 04.60 |
| CHASSIS 1,3,11 DIAGRAMS CE MANUAL | 60369700 | R | 22 | 16.55 |
| CHASSIS 2,6 DIAGRAMS CE MANUAL | 60370000 | T | 22 | 10.75 |
| CHASSIS 3 DIAGRAMS CE MANUAL | 60370200 | M | 22 | 01.20 |
| CHASSIS 4 DIAGRAMS CE MANUAL | 60370100 | Z | 22 | 16.00 |
| CHASSIS 5 DIAGRAMS CE MANUAL | 60377200 | G | 22 | 02.50 |
| CHASSIS 7 DIAGRAMS CE MANUAL | 60377100 | F | 22 | 05.90 |
| CHASSIS 8 DIAGRAMS CE MANUAL | 60377300 | L | 22 | 06.70 |
| CHASSIS 1,3,11 WIRE LIST CE MANUAL | 60350200 | R | 22 | 39.50 |
| CHASSIS 2,6 WIRE LIST CE MANUAL | 60350300 | V | 22 | 34.00 |
| CHASSIS 3 WIRE LIST CE MANUAL | 60350400 | L | 22 | 26.75 |
| CHASSIS 4 WIRE LIST CE MANUAL | 60350500 | AC | 22 | 27.75 |
| CHASSIS 5 WIRE LIST CE MANUAL | 60350600 | D | 22 | 37.35 |
| CHASSIS 7 WIRE LIST CE MANUAL | 60350800 | K | 22 | 17.60 |
| CHASSIS 8 WIRE LIST CE MANUAL | 60350900 | R | 22 | 30.45 |
| AA116-A (1714) COMPUTER 65K | | | | |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.

4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|----|----|-------|
| GEN DESC, OPER AND PROG, INSTAL, CHKOUT THEO OF OP, DIAGRAMS, MAINT CE MANUAL | 60357100 | C | 22 | 09.10 |
| PARTS DATA CE MANUAL | 60393700 | A | 22 | 06.85 |
| CROSS TABS CE MANUAL | 60393800 | B | 22 | 05.30 |
| REFRIGERATION SYSTEMS CE INFO (USE AA115-A) | | | | |
| COMMAND TIMING CE MANUAL | 60374900 | B | 22 | 05.50 |
| AA117-A (74-XX) PARALLEL PROCESSOR | | | | |
| POWER DIST - WARNING SYSTEM INFO (USE AA115) | | | | |
| CHASSIS 1 CE INFO USE AA115-A | | | | |
| CHASSIS 4 WIRE LIST CE MANUAL | 60371100 | K | 22 | 27.80 |
| CHASSIS 5 WIRE LIST CE MANUAL | 60371200 | S | 22 | 32.90 |
| CHASSIS 6 WIRE LIST CE MANUAL | 60350700 | E | 22 | 27.30 |
| CHASSIS 7 WIRE LIST CE MANUAL | 60371300 | E | 22 | 32.05 |
| CHASSIS 8 WIRE LIST CE MANUAL | 60371400 | E | 22 | 31.20 |
| CHASSIS 9 WIRE LIST CE MANUAL | 60351000 | P | 22 | 20.20 |
| CHASSIS 10 WIRE LIST CE MANUAL | 60351100 | D | 22 | 19.10 |
| CHASSIS 11 WIRE LIST CE MANUAL | 60351200 | F | 22 | 20.60 |
| CHASSIS 12 WIRE LIST CE MANUAL | 60351300 | L | 22 | 20.40 |
| CHASSIS 13 AND 15, 14 AND 16 USE AT237-A | | | | |
| CHASSIS 4,5,6,7,8 DIAGRAMS MANUAL | 60370800 | R | 22 | 36.70 |
| CHASSIS 9 DIAGRAMS MANUAL | 60370900 | P | 22 | 09.95 |
| CHASSIS 10 DIAGRAMS MANUAL | 60382600 | D | 22 | 03.90 |
| CHASSIS 11 DIAGRAMS MANUAL | 60382700 | C | 22 | 04.15 |
| CHASSIS 12 DIAGRAMS MANUAL | 60382800 | H | 22 | 02.35 |
| AA119-A/B/C/D (1714) COMPUTER 65K CE INFO (USE AA116-A) | | | | |
| AA120-A (175-XX) CENTRAL COMPUTER | | | | |
| REFRIGERATION SYSTEM INFO (USE GH223-A) | | | | |
| MAINTENANCE, PARTS DATA HOWE MAINT MANUAL (INCLUDES INFO FOR ALL OPTIONS) | 60420600 | 01 | 22 | 08.70 |
| POWER DISTRIBUTION/WARNING SYSTEM MANUAL | 60420700 | A | 22 | 09.90 |
| CENTRAL PROCESSOR THEORY, DIAGRAMS MANUAL | 60420300 | | 22 | |
| CENTRAL PROCESSOR (CH 5-7) WIRE LIST MANUAL | 60420400 | | 22 | |
| CABLE WIRE LIST MANUAL | 60420200 | | 22 | |
| INSTALLATION/CHECKOUT MANUAL | 60420500 | | 22 | |
| AA121-A (7700) CENTRAL COMPUTER | | | | |
| INSTALLATION/CHECKOUT, THEORY OF OP, DIAGRAMS, MAINT AIDS, PARTS DATA CE MANUAL | 60396400 | A | 22 | 34.10 |
| CHASSIS 1 WIRE LISTS CE MANUAL | 60396600 | A | 22 | 08.05 |
| CHASSIS 2 WIRE LISTS CE MANUAL | 60396700 | A | 22 | 07.40 |
| CHASSIS 3 WIRE LISTS CE MANUAL | 60396800 | A | 22 | 08.85 |
| CHASSIS 4 WIRE LISTS CE MANUAL | 60396900 | A | 22 | 07.80 |
| CHASSIS 5 WIRE LISTS CE MANUAL | 60397000 | A | 22 | 07.80 |
| CHASSIS 6 WIRE LISTS CE MANUAL | 60397100 | A | 22 | 05.60 |
| CHASSIS 8 WIRE LISTS CE MANUAL | 60397300 | A | 22 | 10.40 |
| CHASSIS 7 WIRE LISTS CE MANUAL | 60397200 | A | 22 | 09.60 |
| CHASSIS 9 WIRE LISTS CE MANUAL | 60397400 | A | 22 | 11.20 |
| CHASSIS 10 WIRE LISTS CE MANUAL | 60397500 | A | 22 | 11.30 |
| CHASSIS 11 WIRE LISTS CE MANUAL | 60397600 | A | 22 | 10.10 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------|----|----|-------|
| CHASSIS 12 WIRE LISTS CE MANUAL | 60397700 | A | 22 | 08.25 |
| CHASSIS 13 WIRE LISTS CE MANUAL | 60397800 | A | 22 | 10.50 |
| CHASSIS 14 WIRE LISTS CE MANUAL | 60397900 | A | 22 | 10.25 |
| CHASSIS 15 WIRE LISTS CE MANUAL | 60398000 | A | 22 | 04.95 |
| LCM STACK CABLES WIRE LIST C.E.MANUAL | 60398100 | A | 22 | 09.65 |
| CHANNEL TABS WIRE LISTS CE MANUAL | 60398200 | B | 22 | 14.15 |
| POWER AND REFERENCE WIRE LISTS CE MANUAL | 60396500 | A | 22 | 11.10 |
| ** SEE ALSO AB101-A, AD102-A MANUALS ** | | | | |
| AB101-A (7601-1, 7611-1/2) PERIPHERAL PROC. THEO OF OPERATION, INSTALLATION/CHECKOUT, DIAGRAMS, MAINTENANCE AIDS, PARTS DATA. WIRE LISTS CE MANUAL | 60274900 | P | 22 | 09.40 |
| AB102-A/B (7611-1/2) PERIPHERAL PROCESSOR CAB. INSTALLATION/CHECKOUT, THEORY OF OPERATION, DIAGRAMS, MAINTENANCE AIDS, PARTS DATA, WIRE LISTS CE MANUAL (USE AB101-A) REFRIGERATION INFO (USE GH214-A IF AB102-A OR GH214-B IF AB102-B) POWER DISTRIBUTION/WARNING SYSTEM (USE GH105-A/B/C IF AB102-A OR GH105-D IF AB102B | | | | |
| AB103-A (90104) COMPUTE MODULE CE MANUAL | 60278100 | AW | 22 | 07.75 |
| PARTS LIST CE MANUAL | 60366800 | E | 22 | 16.20 |
| AB107/AB108 INPUT/OUTPUT SPECIFICATIONS | 89673100 | 01 | 22 | 04.30 |
| AC104-A (3504-1) CENTRAL COMPUTER GENERAL DESCRIPTION, DIAGRAMS, CABLE TABS CE MANUAL | 60181000 | AW | 34 | 49.00 |
| PROCESSOR (USE 3304-B, CATALOG SECTION 2) MAINT. AIDS; COMMAND TIMING CHARTS CE MANUAL | 60238000 | B | 22 | 07.85 |
| PARTS DATA CE MANUAL | 60233100 | AG | 22 | 10.80 |
| AC105-B (3174-1/2/3/4, 3304, 3304-2/3) CENTRAL PROCESSOR (USE 3304.B, CATALOG, SECTION 2) | | | | |
| AC106-A (3514-1/2/3/4) CENTRAL PROCESSOR GENERAL DESC., DIAGRAMS, CABLE TABS CE MAN | 60289500 | AU | 34 | 88.60 |
| MAINT. AIDS, COMMAND TIMING CHARTS CE MANUAL | 60312400 | A | 22 | 21.90 |
| PARTS DATA (USE AC104-A) | | | | |
| AC109-A (1774-1) SYSTEM CONTROLLER CE INFO (USE AB103-A) | | | | |
| AC113-A () CENTRAL COMPUTER CHASSIS 1 WIRE LIST CE MANUAL | 60348200 | A | 22 | 05.70 |
| CHASSIS 2 WIRE LIST CE MANUAL | 60348300 | A | 22 | 06.45 |
| CHASSIS 3 WIRE LIST CE MANUAL | 60348400 | A | 22 | 04.30 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------|----|----|-------|
| CHASSIS 4 WIRE LIST CE MANUAL | 60348500 | C | 22 | 06.30 |
| CHASSIS 5 WIRE LIST CE MANUAL | 60348600 | B | 22 | 06.15 |
| CHASSIS 6 WIRE LIST CE MANUAL | 60348700 | H | 22 | 06.85 |
| CHASSIS 7 WIRE LIST CE MANUAL | 60348800 | H | 22 | 07.00 |
| CHASSIS 8 WIRE LIST CE MANUAL | 60348900 | C | 22 | 06.95 |
| CHASSIS 9 WIRE LIST CE MANUAL | 60349000 | B | 22 | 06.75 |
| CHASSIS 10 WIRE LIST CE MANUAL | 60349100 | B | 22 | 07.90 |
| CHASSIS 12 WIRE LIST CE MANUAL | 60349300 | B | 22 | 06.40 |
| CHASSIS 11 WIRE LIST CE MANUAL | 60349200 | B | 22 | 06.90 |
| CHASSIS 13 WIRE LIST CE MANUAL | 60349400 | E | 22 | 06.15 |
| CHASSIS 14 WIRE LIST CE MANUAL | 60349500 | C | 22 | 05.80 |
| THEO OF OPERATION, DIAGRAMS, MAINT. CE MAN | 60348000 | AB | 22 | 29.95 |
| LCM STACK WIRE LIST CE MANUAL | 60349600 | D | 22 | 08.00 |
| POWER AND REFERENCE WIRE LIST CE MANUAL | 60349700 | E | 22 | 08.35 |
| CHANNEL TABS WIRE LIST CE MANUAL | 60349800 | E | 22 | 09.55 |
| REFRIGERATION MANUAL (USE GH214-B) | | | | |
| POWER DISTRIBUTION/WARNING SYSTEM (USE GH105-D) | | | | |
| AC113-B () CENTRAL COMPUTER | | | | |
| CHASSIS 1 WIRE LIST CE MANUAL | 60420900 | A | 22 | 18.60 |
| CHASSIS 2 WIRE LIST CE MANUAL | 60421000 | A | 22 | 20.70 |
| CHASSIS 3 WIRE LIST CE MANUAL | 60421100 | A | 22 | 19.20 |
| CHASSIS 4 WIRE LIST CE MANUAL | 60421200 | A | 22 | 14.60 |
| CHASSIS 5 WIRE LIST CE MANUAL | 60421300 | A | 22 | 15.20 |
| CHASSIS 6 WIRE LIST CE MANUAL | 60421400 | C | 22 | 20.10 |
| CHASSIS 7 WIRE LIST CE MANUAL | 60421500 | C | 22 | 21.05 |
| CHASSIS 8 WIRE LIST CE MANUAL | 60421600 | D | 22 | 17.85 |
| CHASSIS 9 WIRE LIST CE MANUAL | 60421700 | B | 22 | 18.60 |
| CHASSIS 10 WIRE LIST CE MANUAL | 60421800 | C | 22 | 15.80 |
| CHASSIS 11 WIRE LIST CE MANUAL | 60421900 | A | 22 | 17.84 |
| CHASSIS 12 WIRE LIST CE MANUAL | 60422000 | C | 22 | 16.55 |
| CHASSIS 13 WIRE LIST CE MANUAL | 60422100 | B | 22 | 18.00 |
| CHASSIS 14 WIRE LIST CE MANUAL | 60422200 | A | 22 | 14.75 |
| INSTALLATION/CHECKOUT, THEORY OF OP, DIAGRAMS, MAINT AIDS, PARTS DATA INFO (USE AC113-A) | | | | |
| MAINTENANCE INFO (USE AA102-A) | | | | |
| LCM STACK WIRE LIST INFO (USE AC113-A) | | | | |
| POWER AND REFERENCE WIRE LIST INFO (USE AC113-A) | | | | |
| CHANNEL TABS WIRE LIST INFO (USE AC113-A) | | | | |
| REFRIGERATION INFO (USE GH214-B) | | | | |
| POWER DISTRIBUTION AND WARNING SYSTEM INFO (USE GH105-D) | | | | |
| AC115-A/B/C (1774-1) BASIC PROCESSOR CE INFO (USE AB103-A) | | | | |
| AD102-A (7700) ADJUNCT PROCESSOR INSTALLATION/CHECKOUT, THEORY OF OPERATION, DIAGRAMS (USE AA121-A) | | | | |
| CHASSIS 6 WIRE LISTS CE MANUAL | 60398300 | A | 22 | 06.45 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|---|----|-------|
| CHASSIS 7 WIRE LISTS CE MANUAL | 60398400 | A | 22 | 07.20 |
| CHASSIS 8 WIRE LISTS CE MANUAL | 60398500 | A | 22 | 09.65 |
| CHASSIS 9 WIRE LISTS CE MANUAL | 60398600 | A | 22 | 10.30 |
| CHASSIS 10 WIRE LISTS CE MANUAL | 60398700 | A | 22 | 11.50 |
| CHASSIS 11 WIRE LISTS CE MANUAL | 60398800 | A | 22 | 08.80 |
| CHASSIS 12 WIRE LISTS CE MANUAL | 60398900 | A | 22 | 09.70 |
| CHASSIS 13 WIRE LISTS CE MANUAL | 60399000 | A | 22 | 08.35 |
| CHASSIS 14 WIRE LISTS CE MANUAL | 60399100 | A | 22 | 09.60 |
| CHANNEL TABS WIRE LISTS CE MANUAL | 60399200 | B | 22 | 09.80 |
| POWER AND REFERENCE WIRE LISTS CE MANUAL | 60427500 | A | 22 | 05.95 |
| AE116-B (10174-X) SECOND CENTRAL PROCESSOR CONVERTS A 6600-A/R/C WITH SPIGOTS TO A 6700-A/R/C. DIAGRAMS, WIRE LIST CE MANUAL (CH.12) (FOR CONSOLE DISPLAY CONTROLLER DOCUMENTS USE FR114-A) | 60374800 | D | 22 | 26.90 |
| AE116-C (10174-X) SECOND CENTRAL PROCESSOR CONVERTS A 6600-D/E WITH SPIGOTS TO A 6700-D/F. DIAGRAMS, WIRE LIST INFO (CH.2) (USE AE116-B) | | | | |
| AE116-D (74-2X) SECOND CENTRAL PROCESSOR CHASSIS 2 WIRE LIST CE MANUAL | 60371000 | J | 22 | 26.00 |
| CHASSIS 2 DIAGRAMS CE MANUAL | 60416000 | E | 22 | 11.10 |
| AF101-A (3304-2) BUSINESS DATA PROCESSOR (USE 3312-A, CATALOG SFC. 2) | | | | |
| AF101-B (3174-3/4, 3304-3, ST.OP.10256-1/2/ 3/4) BUSINESS DATA PROCESSOR MAINTENANCE - PMI/PMP (USE 3304-A) PARTS LIST (USE 3304-A) WIRE LIST (TERM LIST, HAND TABS) CE MANUAL | 60291200 | L | 22 | 10.10 |
| MAINTENANCE COMMAND TIMING CHARTS CE MANUAL | 60283500 | J | 22 | 17.30 |
| EQUATION SUMMARY, CARD PLACEMENT CE MANUAL | 60291100 | L | 22 | 11.90 |
| DIAGRAMS CE MANUAL | 60283400 | M | 22 | 06.65 |
| AF102-A (3514-2/4) BUSINESS DATA PROCESSOR MAINT. AIDS, COMMAND TIMING CHARTS (USE AC106-A) GENERAL DESCRIPTION, DIAGRAMS, CABLE TABS CE MANUAL | 60311200 | P | 22 | 08.60 |
| AF104-A/AT146-A OR AF105-A/AT165-A 3200 ENHANCED BLOCK CONTROL MODIFICATION (OPTION 10287) AND 3200 BUSINESS DATA PROCESSOR INTERFACE (OPTION 10256) CE MANUAL | 97402700 | A | 22 | 33.90 |
| AF104-A (ST.OP.10256-1) 3200 BUSINESS DATA PROCESSOR INTERFACE CE MANUAL | 60347600 | C | 22 | 19.30 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------|---|----|-------|
| AF104-B (ST.OP.10256-2) 3100 BDP INTERFACE OPT CE MANUAL | 97401900 | A | 22 | 09.70 |
| AF105-A (ST.OP.10287-1) 3200 ENHANCED BLOCK CONTROL MODIFICATION CE MANUAL | 97402500 | A | 22 | 24.70 |
| REF MANUAL | 97402400 | A | 22 | 03.60 |
| AF106-A (ST.OP.10287-2) 3100 ENHANCED BLOCK CONTROL MODIFICATION CE MANUAL | 97402100 | A | 22 | 14.60 |
| AF107-A (ST.OP.10287-4) 3100 ENHANCED BLOCK CONTROL AND BDP INTERFACE CE MANUAL | 97402300 | B | 22 | 20.95 |
| AN/UYS-25 (V) DATA PROCESSING SET - REF MAN | 69651800 | | 22 | 08.90 |
| AT105-A (ST. OPT. 10121) ACCESS CHANNEL CE INFO (USE BB313-A) | | | | |
| AT106-A (ST. OPT.10123) MEMORY PROTECT - 3100 REF/CE MANUAL | 60228700 | D | 22 | 04.15 |
| AT115-A (ST. OPT.10123) MEMORY PROTECT - 3200 (USE AT106-A) | | | | |
| AT124-A (3514-3/4) RELOCATION PAGE FILE DIAGRAMS (USE AC106-A) COMMAND TIMING CHARTS (USE AC104-A) | | | | |
| AT129-A (10169, 10173-6/7/8/9/10) CENTRAL MEMORY ACCESS PRIORITY OPTION FOR 64/6500-ABC REF/CE MANUAL | 60272700 | G | 22 | 08.15 |
| AT130-A (10169, 10173-3/4/5/6/7/8/10, 10174-1 CENTRAL MEMORY ACCESS CE INFO (USE AA103-A PPU DIAGRAMS AND CH.1 WIRE LISTS CE MANUALS) | | | | |
| AT131-A (10169, 10173-3/4/5, 10174-1/2) CENTRAL MEMORY ACCESS PRIORITY REF/CE MANUAL | 60270900 | H | 22 | 12.30 |
| AT137-A (10173-6/7/8/9) CENTRAL MEMORY ACCESS (AT130-A MUST BE INSTALLED) FOR ADDITIONAL PPU S - APPLICABLE TO A 6413-D CENTRAL COMPUTER (USE AA105-A) REF INFO (USE 6000 COMPUTER SYSTEMS REF MAN) | | | | |
| AT139-A (10173-7/9/10, 10178-2) CENTRAL MEMORY ACCESS FOR ADDITIONAL PPU S - APPLICABLE TO A | | | | |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------|-----|----|-------|
| 6414-D CENTRAL COMPUTER (USE AA105-A) (AT130-A MUST BE INSTALLED) | | | | |
| AT140-A (6413-E, ST.OP.10119) 65K MEMORY INCREMENT FOR AA105-A | | | | |
| CHASSIS 9 AND 11 WIRE LIST CE MANUAL | 60286000 | B | 22 | 07.95 |
| CHASSIS 10 AND 12 WIRE LIST CE MANUAL FOR AN AA105-A/AT141-A COMPUTER SYSTEM | 60286100 | C | 22 | 10.65 |
| AT140-B (ST.OP. 10178-1) 32K MEMORY INCREMENT REFERENCE/CE MANUAL | 60315600 | D | 22 | 09.50 |
| AT140-E (ST.OP. 10119) MEMORY INCREMENT TO 131K FOR 6413-A/B/C AND 6513-A/B/C COMPUTERS (USE 6414/6514-A) | | | | |
| AT140-F (PROD ST OPT 10178-1) 32K MEMORY INCR. FOR AN 6414/6514-A/B/C CENTRAL COMPUTER REFERENCE/CE MANUAL | 60317300 | C | 22 | 10.35 |
| AT140-G (10119) 65K MEMORY INCREMENT TO 131K FOR 6400/6500-D, USE 6413-D/6513-D. NOTE IF INSTALLED ON 6414-A/B/C OR 6500-A/B/C COMPUTERS ORDER ONLY THE FOLLOWING MANUALS. | | | | |
| 6413-D CHASSIS 9/11 CHASSIS TABS (60248800) | | | | |
| 6413-A/B/C CABLE TABS (60188900) | | | | |
| 6413-D CHASSIS 10/12 CHASSIS TABS (60248900) | | | | |
| 6413-D DIAGRAMS (USE ONLY CHASSIS 9 THROUGH 12 DIAGRAMS) (60246800) | | | | |
| AT140-H (PROD ST OPT 10178-1) 32K MEMORY INCR FOR AN 6414/6514-D CENTRAL COMPUTER REF/CE MANUAL | 60296500 | B,C | 22 | 05.05 |
| AT141-A (6500-E) SECOND CPU FOR AA105-A USE MANUALS LISTED UNDER AA105-A UNLESS DT143-A OR AT194-A ARE INSTALLED IN WHICH CASE USE MANUALS LISTED UNDER AT194-A. | | | | |
| AT142-F (PROD ST OPT 10177-1) 16K MEMORY INCR FOR A 6415-A/B/C CENTRAL COMPUTER REF/CE MANUAL | 60317600 | C | 22 | 03.05 |
| AT142-H (PROD ST OPT 10177-1) 16K MEMORY INCR FOR A 6415-D CENTRAL COMPUTER REFERENCE/CE MANUAL | 60315700 | B | 22 | 02.90 |
| AT145-A/B/C (10173) ADDITIONAL PPU CHASSIS FOR 6000 COMPUTERS (INCR TO 20 PPU S) CE MANUAL (ALSO REQUIRES AT177-A/B/C CE MANUAL) | 60370600 | K | 22 | 22.50 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|---|----|-------|
| AT146-A (10287-3) MEMORY INCREMENT - 3200 CE MANUAL (USE AF104-A) | | | | |
| AT147-A (ST.OP. 10180) MEMORY INCREMENT 6600-A/B/C MACHINES 98K TO 131K (USE 6613-A/B/C) | | | | |
| AT147-B (ST.OPT. 10180) MEMORY INCREMENT 6600-D MACHINES 98K TO 131K (USE 6613-D) | | | | |
| AT147-C (ST.OPT. 10180) MEMORY INCREMENT 6600-E MACHINES 98K TO 131K (USE AA103-A) | | | | |
| AT149-A (ST.OP.10173) ADDITIONAL MEMORY ACCESS OPTION FOR 6414-A/B/C, 6514-A/B/C DIAGRAMS, W/L, C/P CE MANUAL | 60406100 | B | 22 | 01.80 |
| CABLE TABS (AT149-A ONLY) CE MANUAL | 60415800 | C | 22 | 18.15 |
| ALSO REQUIRES THE FOLLOWING AA105-A MANUALS DIAGRAMS CE MANUAL 60316200 CH 2 WIRE LISTS CE MANUAL 60285400 CH 3 WIRE LISTS CE MANUAL 60285500 | | | | |
| AT151-A (10256-4) 3100 BDP OPTION CE INFO (USE AF107-A) | | | | |
| AT152-A (ST.OP.10173) ADDITIONAL MEMORY ACCESS OPTION FOR 6413-A/B/C, 6513-A/B/C CABLE TABS CE MANUAL | 60415900 | C | 22 | 30.85 |
| DIAGRAMS, WIRE LIST INFO (USE AT149-A) | | | | |
| AT153-A (10173-4/5, 10174-2) ADDITIONAL CENTRAL MEMORY ACCESS FOR 6614-A/B/C COMPUTER SYSTEMS. GEN.DESC. AND DIAGRAMS | 60392300 | E | 22 | 03.40 |
| CHASSIS 2 WIRE LISTS CE MANUAL | 60391700 | A | 22 | 31.65 |
| CHASSIS 3 WIRE LISTS (USE AA103-A, CH 9) | | | | |
| CHASSIS 3 ECS COUPLER DIAGRAMS (USE AA103-A ECS COUPLER DIAGRAMS) | | | | |
| CHASSIS 4 WIRE LISTS CE MANUAL | 60391800 | B | 22 | 19.00 |
| CHASSIS 5 WIRE LISTS CE MANUAL | 60391900 | D | 22 | 31.30 |
| CHASSIS 9 WIRE LISTS CE MANUAL | 60392000 | B | 22 | 17.40 |
| CHASSIS 10 WIRE LISTS CE MANUAL | 60392100 | A | 22 | 21.25 |
| CABLE TABS CE MANUAL | 60392400 | B | 22 | 19.30 |
| AT154-A (10173-X) ADDITIONAL MEMORY ACCESS FOR 6613-A/B/C DIAGRAMS (EXCEPT CH.1,3,12) CE MANUAL | 60319300 | P | 22 | 04.60 |
| CHASSIS 1 DIAGRAMS, WIRE LIST CE MANUAL (USE ONLY IF AT145-A/AT176-A IS NOT INSTALLED) | 60423300 | | 22 | |
| DIAGRAMS, WIRE LIST CH.3 (USE AA103-A CH.9) | | | | |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | | | | 1 | 2 | 3 | 4 |
|---|-----------------|-------------------|----------------------|----------|---|----|-------|
| DIAGRAMS, WIRE LIST CH.12 (USE AE116-B) | | | | 60380600 | B | 22 | 26.50 |
| CHASSIS 2 WIRE LIST CE MANUAL | | | | 60380700 | B | 22 | 16.25 |
| CHASSIS 4 WIRE LIST CE MANUAL | | | | 60380800 | G | 22 | 25.90 |
| CHASSIS 5 WIRE LIST CE MANUAL | | | | 60380900 | B | 22 | 19.70 |
| CHASSIS 9 WIRE LIST CE MANUAL | | | | 60381000 | C | 22 | 12.10 |
| CHASSIS 10 WIRE LIST CE MANUAL | | | | 60381100 | C | 22 | 11.30 |
| CHASSIS 13 WIRE LIST CE MANUAL | | | | 60381200 | D | 22 | 11.25 |
| CHASSIS 14 WIRE LIST CE MANUAL | | | | 60381300 | C | 22 | 10.35 |
| CHASSIS 15 WIRE LIST CE MANUAL | | | | 60381400 | C | 22 | 11.80 |
| CHASSIS 16 WIRE LIST CE MANUAL | | | | 60321600 | G | 22 | 20.25 |
| CABLE TABS CE MANUAL | | | | | | | |
| AT155-A (10173-4/5, 10174-2) ADDITIONAL MEMORY ACCESS FOR 6614-D | | | | | | | |
| CHASSIS 9 (ONLY) DIAGRAMS, W/L, C/P CE MAN. | | | | 60374500 | B | 22 | 15.10 |
| CHASSIS NO. | USE MANUALS FOR | DIAGRAMS PUB. NO. | CHASSIS TABS PUB.NO. | | | | |
| **** 1 | AA103-A | *60284100 | **60285300 | | | | |
| 4 | 6614-D | 60224800 | 60247000 | | | | |
| 5 | AA103-A | ***60287300 | 60293300 | | | | |
| 6 | 6614-D | 60224800 | 60247200 | | | | |
| 7 | 6614-D | 60224800 | 60247300 | | | | |
| 8 | 6614-D | 60224800 | 60247400 | | | | |
| 10 | AA103-A | 60287400 | 60293500 | | | | |
| 11 | AA103-A | 60287400 | 60293700 | | | | |
| 12 | AA103-A | 60287400 | 60293900 | | | | |
| * FOR 20 PPU S USE THIS MANUAL PLUS DIFFERENCE PAGES FROM AT176-A/AT145 MANUAL, PUB.NO. 60370600 | | | | | | | |
| ** FOR 20 PPU S COMPLETE CHASSIS 1 AND 3 TABS ARE INCLUDED IN AT176-A/AT145 MANUAL, PUB.NO. 60370600 | | | | | | | |
| *** USE ONLY CHASSIS 5 PORTION OF THIS MANUAL. | | | | | | | |
| **** THIS DOCUMENTATION SHOULD BE USED INSTEAD OF 6600-D CHASSIS 1 PLUS AT130-A OPTION MANUAL WHICH IS OBSOLETE | | | | | | | |
| AT156-A (10173-3/4, 10174-1) ADDITIONAL MEMORY ACCESS FOR 6613-D | | | | | | | |
| CHASSIS 9 (USE AT155-A) | | | | | | | |
| CHASSIS NO. | USE MANUALS FOR | DIAGRAMS PUB. NO. | CHASSIS TABS PUB.NO. | | | | |
| **** 1 | AA104-A | *60284100 | **60285300 | | | | |
| 4 | 6613-D | 60224800 | 60247000 | | | | |
| 5 | AA104-A | ***60287300 | 60293300 | | | | |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

| TITLE | | | | 1 | 2 | 3 | 4 |
|---|---------|----------|----------|----------|---|----|-------|
| 6 | 6613-D | 60224800 | 60247200 | | | | |
| 7 | 6613-D | 60224800 | 60247300 | | | | |
| 8 | 6613-D | 60224800 | 60247400 | | | | |
| 10 | AA104-A | 60287400 | 60293600 | | | | |
| 11/15 | AA104-A | 60287400 | 60293800 | | | | |
| 12 | AA104-A | 60287400 | 60294000 | | | | |
| 13 | AA104-A | 60287400 | 60294100 | | | | |
| 14 | AA104-A | 60287400 | 60294200 | | | | |
| 16 | AA104-A | 60287400 | 60294300 | | | | |
| <p>* FOR 20 PPU S USE THIS MANUAL PLUS DIFFERENCE PAGES FROM AT176-A/AT145 MANUAL, PUB.NO. 60370600.</p> <p>** FOR 20 PPU S COMPLETE CHASSIS 1 AND 3 TABS ARE INCLUDED IN AT176-A/AT145 MANUAL, PUB.NO. 60370600.</p> <p>*** USE ONLY CHASSIS 5 PORTION OF THIS MANUAL.</p> <p>**** THIS DOCUMENTATION SHOULD BE USED INSTEAD OF 6600-D CHASSIS 1 PLUS AT130-A OPTION MANUAL.</p> <p>AT160-A (ST.OP.10173) REQUIRED WHEN A 6500-A/B/C HAS AN ADDITIONAL MEMORY ACCESS ADDED (AT149-A OR AT152-A) CE INFO (USE AT141-A)</p> <p>AT162-A ADDITIONAL PPU (USE AA108-A OR 6400-D MANUALS)</p> <p>AT163-A ADDITIONAL PPU (USE AA108-A OR 6400-D MANUALS)</p> <p>AT164-A ADDITIONAL PPU (USE AA108-A OR 6400-D MANUALS)</p> <p>AT165-A (10256-3) 3200 BDP OPTION CE INFO (USE AT146-A)</p> <p>AT168-A (ST.OP. 10105) MEMORY INCREMENT TO 131K FOR 6614-E/6714 COMPUTER SYSTEMS (USE AA103-A)</p> <p>AT168-R (ST.OP.10180-1) 32K MEMORY INCR TO 98K FOR AA103-A COMPUTER REFERENCE/CE MANUAL ALSO ORDER MANUALS LISTED FOR CHASSIS 10, 11,12,13,14,15,16 FOR AA104-A</p> <p>AT168-C (ST.OP. 10105) MEMORY INCREMENT TO 131K FOR 6614-A/B/C WITH AT153-A (USE AT154-A)</p> | | | | | | | |
| | | | | 60315500 | A | 22 | 07.15 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------|---|----|-------|
| AT168-F (ST.OP. 10105-A) MEMORY INCREMENT TO 131K FOR 6614-A COMPUTER SYSTEM (USE 6613-A/B/C) | | | | |
| AT168-F (ST.OP. 10105-B) MEMORY INCREMENT TO 131K FOR 6614-B/C COMPUTER SYSTEM (USE 6613-A/B/C) | | | | |
| AT168-G (ST.OP. 10180-1) 32K MEMORY INCREMENT FOR 6614-A/B/C REF/CE MANUAL | 60317200 | A | 22 | 08.15 |
| AT168-J (ST.OP.10180-1) 32K MEMORY INCR TO 98K FOR 6614-D CENTRAL COMPUTER REFERENCE/CE MANUAL ALSO ORDER MANUALS LISTED FOR CHASSIS 9, | 60295900 | A | 22 | 5.30 |
| AT174-A () PERIPHERAL PROCESSOR CE INFO (USE AA106-A) | | | | |
| AT176-A (10173) ADDITIONAL PPU CHASSIS FOR 6000 COMPUTERS (INCREMENT TO 20 PPU S) CE INFO (USE AT145-A/B/C) | | | | |
| AT177-A/B/C (10173) EXTERNAL DATA CHANNEL CE MANUAL | 60318900 | F | 22 | 16.05 |
| AT194-A (6500-D OR 6500-E WITH ECS) ECS CAPABILITY FOR AA105-A WITH AT141-A OR ECS CAPABILITY FOR 6400-D WITH AT198-A | | | | |
| FOR 6500-0 CHASSIS 3 DIAGRAMS, WIRE LIST CE MANUAL CHASSIS 2 AND 6 DIAGRAMS, WIRE LIST INFO (IDENTICAL TO 6500-C WITH ECS - SEE AT195-A) CHASSIS 8 DIAGRAMS, WIRE LIST INFO (IDENTICAL TO 6500-E WITH ECS - SEE NEXT ENTRY BELOW) | 60416700 | G | 22 | 04.30 |
| FOR 6500-E CHASSIS 2/6,3,8 DIAGRAMS, WIRE LIST CE MAN | 60401200 | G | 22 | 10.20 |
| AT195-A (6500-A/B/C WITH ECS) ECS CAPABILITY FOR 6500-A/B/C CHASSIS 2,3,8 DIAGRAMS, WIRE LIST CE MANUAL | 60344800 | F | 22 | 17.10 |
| AT196-A (6500-A/B/C) SECOND CPU FOR 641X-A/B/C USE 6400-A/B/C UNLESS DT117-A OR AT195-A ARE INSTALLED IN WHICH CASE USE MANUALS LISTED UNDER AT195-A. | | | | |
| AT197-A (6500-A) SECOND CPU FOR 6404-A MAKES A 6514-A (SEE AT195-A) | | | | |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|---|----|-------|
| AT198-A (6500-D) SECOND CPU FOR 641X-D USE 6400-D UNLESS AT194-A IS INSTALLED IN WHICH CASE USE MANUALS LISTED UNDER AT194-A. | | | | |
| AT217-A (6200-E, 6014, 6015) CPU CONVERSION FOR AA108-A/B/C/D OR AA105-A DIAGRAMS, WIRE LISTS CE MANUAL (CHASSIS 8) | 60404900 | A | 22 | 31.40 |
| DIAGRAMS, WIRE LISTS CE MANUAL (CHASSIS 2) | 60404800 | B | 22 | 24.65 |
| AT217-A () CPU CONVERSION FOR 6415-D OR 6414-D DIAGRAMS CE MANUAL | 60419500 | D | 22 | 15.35 |
| CHASSIS 2 WIRE LISTS CE MANUAL | 60419600 | C | 22 | 33.15 |
| CHASSIS 8 WIRE LISTS CE MANUAL | 60419700 | B | 22 | 18.20 |
| AT219-A (CYBER 74-XX) ECS COUPLER ENABLE CE INFO (INCLUDED IN AA117-A, CHASSIS 9 MANUALS) | | | | |
| AT224-A (10267-1) 64 BIT INCREMENT TO 128 BITS FOR INTERLOCK REGISTER CE INFO (USE AA115-A, CHASSIS 3) | | | | |
| AT226-A (73-XX, 10270-2, 10272-1/2) SPEED INCREMENT FOR AA115-A BASIC UNIFIED PROCESSOR AND AT227-A SECOND BASIC UNIFIED PROCESSOR CHASSIS 2 AND 6 WIRE LISTS CE MANUAL | 60370300 | T | 22 | 43.60 |
| CHASSIS 2 AND 6 DIAGRAMS CE MANUAL (DIFFERENCE PAGES ONLY, ALSO ORDER AA115-A CHASSIS 2 AND 6 DIAGRAMS) COMMAND TIMING INFO (USE AA115-A) | 60369900 | N | 22 | 04.20 |
| AT227-A (72-XX, 73-XX) SECOND BASIC UNIFIED PROCESSOR (CHASSIS 6) CE INFO (USE AT226-A) | | | | |
| AT231-A (72-XX, 73-XX) 16K INCREMENT TO 65K CE INFO (USE AA115-A) | | | | |
| AT232-A (72-XX, 73-XX) 16K INCREMENT TO 49K CE INFO (USE AA115-A) | | | | |
| AT233-A (10268-3, 10269-3) 3 PPU INCR TO 20 PPU S FOR AA115-A OR AA117-A CE INFO (USE AA115-A, CHASSIS 1) | | | | |
| AT234-A () 4 PPU INCREMENT TO 14 PPU S FOR AA117-A CE INFO (USE AA115-A, CHASSIS 1) | | | | |
| AT235-A (10268-2, 10269-2) 3 PPU INCR TO 17 PPU S FOR AA115-A OR AA117-A | | | | |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|---|----|-------|
| CE INFO (USE AA115-A, CHASSIS 1) | | | | |
| AT236-A (72-XX, 73-XX, 74-XX, 10265-4, 10264-4 32K INCR TO 131K FOR AA115-A OR AA117-A CE INFO (USE AT237-A) | | | | |
| AT237-A (72-XX, 73-XX, 74-XX, 10264-3, 10265-3) 32K INCREMENT TO 98K FOR AA115-A OR AA117-A. | | | | |
| CHASSIS 13 AND 15 WIRE LISTS CE MANUAL | 60370400 | J | 22 | 24.20 |
| CHASSIS 13 AND 15 DIAGRAMS CE MANUAL | 60369800 | E | 22 | 06.10 |
| CHASSIS 14 AND 16 WIRE LISTS CE MANUAL | 60370500 | G | 22 | 24.75 |
| CHASSIS 14 AND 16 DIAGRAMS CE MANUAL | 60390600 | F | 22 | 05.95 |
| AT239-A (CYBER 74-XX) 32K TO 49K INCREMENT CE INFO (INCLUDED IN AA117-A, CHASSIS 9, 10, 11 AND 12 MANUALS) | | | | |
| AT247-A (7030) ECS INTERFACE LOGIC CE INFO (USE AA115-A, CHASSIS 8) | | | | |
| AT248-A (10276-1) AUTO-RESTART OPTION CE INFO (USE AA116-A) | | | | |
| AT249-A (7030-XX) ECS COUPLER ENABLE DIAGRAMS INFO (USE AA117-A) | | | | |
| AT250-A () 4 PPU INCREMENT TO 14 PPU S FOR AA115-A CE INFO (USE AA115-A, CHASSIS 1) | | | | |
| AT251-A (CYBER 72/73/74) EXTERNAL DATA CHANNEL CE MANUAL | 60392700 | F | 22 | 25.40 |
| AT259-A () REGISTER FILE PARITY - ABNORMAL INTERRUPT EXPANSION REF/CE MANUAL | 60375600 | G | 22 | 07.75 |
| AT260-A () PAGE FILE PARITY REFERENCE/CE MANUAL | 60375700 | D | 22 | 03.95 |
| AT265-A/B () ADDITIONAL PPU CHASSIS FOR 6000 COMPUTERS (INCREMENT TO 20 PPU S) CE INFO (USE AT145-A/B/C) | | | | |
| AT267-A (CYBER 72/73) COMPARE/MOVE LOGIC CE INFO (USE AA115-A, CHASSIS 4) | | | | |
| AT269-A (7611-11) SERVICE STATION CLOCK CF MANUAL | 60405200 | A | 22 | 03.30 |
| AT270-A (7611-11) SERVICE STATION ENABLE CE INFO (USE AT269-A) | | | | |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|----|----|-------|
| AT271-A (7700) LCM FLAG REGISTER INCREMENT CE INFO (USE AA121-A) | | | | |
| AT281-A (SP.OP. 65102) AC105/3304 BUS PARITY CE MANUAL | 60425000 | A | 22 | 19.74 |
| AT282-A (SP.OP. 65102) BDP BUS PARITY CE INFO (USE AT281-A) | | | | |
| AT283-A (SP.OP. 65102) PAGE FILE BUS PARITY CE INFO (USE AT281-A) | | | | |
| AT284-A (SP.OP. 65102) 3316 MULTIPLEXER BUS PARITY CE INFO (USE AT281-A) | | | | |
| AT285-A (SP.OP. 65102) BB316/BR105-A/3302 BUS PARITY CE INFO (USE AT281-A) | | | | |
| AT286-A (SP.OP. 65102) BB351/BB105-B BUS PARITY CE INFO (USE AT281-A) | | | | |
| AT289-A (ST.OP.10309-1/2) GO MODE FROM INTERRUPT FOR THE AC104-A AND AC106-A/B C.E. MANUAL | 60417600 | A | 34 | 05.10 |
| AT292-A (ST.OP. 10308-2) GO MODE FROM INTERRUPT CE MANUAL | 60423500 | A | 22 | 03.10 |
| AT293-A (ST.OP. 10308-2) SDL EXECUTION IN PROGRAM STATE CE INFO (USE AT292-A) | | | | |
| AT294-A (ST.OP.10309-1) EXECUTE SDL IN PROGRAM STATE FOR AC104-A CE INFO (USE AT289-A) | | | | |
| AT295-A (ST.OP.10309-2) EXECUTE SDL IN PROGRAM STATE FOR AC106-A/B CE INFO (USE AT289-A) | | | | |
| AT303-A () ADJUNCT PPU REFRIGERATION INFO (USE GH223-A) | | | | |
| AT310-A TTL AQ-DSA CE MANUAL | 89758600 | 01 | 22 | 03.40 |
| AT311-A (76-XXX, ST.OP.10348-1) I/O MUX CHANNEL CE INFO (USE AA106-A) | | | | |
| AT312-A (ST.OP.10348-2) I/O MUX CHANNEL | | | | |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|----|----|-------|
| CE INFO (USE AA106-A) | | | | |
| AU102-A (7700) MEMORY SHARING UNIT CE INFO (USE AA121-A AND AD102-A) | | | | |
| BB104-A () STORAGE MODULE CE MANUAL | 60323500 | C | 22 | 02.00 |
| BB105-A (3172) MAGNETIC CORE STORAGE CE INFO (USE 3304-B, CATALOG SECTION 2) CARD PLACEMENT, EQ SUM, WIRE LISTS CE MANUAL | 60323100 | A | 22 | 12.00 |
| BB105-A () STORAGE MODULE CE MANUAL OPERATION/PROGRAMMING INFO (USE 3100 COMPUTER SYSTEM REF MANUAL OR 3150 COMPUTER SYSTEM REF MANUAL OR 3200 COMPUTER SYSTEM REF MANUAL INSTALLATION/CHECKOUT INFO (USE 3000 SERIES SITE PREPARATION MANUAL) | 60409400 | A | 22 | 22.00 |
| BB107-A () STORAGE MODULE CE AND REF INFO (SEE BB106-A) | | | | |
| BB201-A (7700) SCM INCREMENT CE INFO (USE AA121-A AND AD102-A) | | | | |
| BB310-A (1708) STORAGE INCREMENT | | | | |
| BB311-A (1708) STORAGE INCREMENT | | | | |
| BB312-A (1708) STORAGE INCREMENT | | | | |
| BB313-A (3502) STORAGE MODULE CE MANUAL | 60210200 | AC | 22 | 22.80 |
| BB314-A (3502) STORAGE MODULE CE INFO (USE BB313-A) | | | | |
| BB316-A STORAGE MODULE (USE 3302-A, CATALOG SEC. 2) | | | | |
| BB319-A (6634-C) EXTENDED CORE STORAGE ASSEMBLY DIAGRAMS, CIRC. DESC., WIRE LIST CE MANUAL | 60209600 | W | 22 | 08.40 |
| STACK ASSEMBLY-DIAGRAMS, CIRC DESC, MAINT CE MANUALS (DESCRIBES STACK ONLY) | 60217600 | D | 22 | 16.05 |
| MAINTENANCE, MAINTENANCE AIDS CE MANUAL | 60289200 | K | 22 | 10.00 |
| BB319-B (6634-D) EXTENDED CORE STORAGE ASSEMBLY (USE MANUALS UNDER BB319-A) | | | | |
| BB323-A (6635-C) EXTENDED CORE STORAGE ASSEMBLY DIAGRAMS, CIRC. DESC., PARTS LIST, CARD | 60212200 | W | 22 | 05.00 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------|---|----|-------|
| PLACEMENT CE MANUAL STACK ASSEMBLY CE MANUAL (USE MANUAL LISTED UNDER BB319-A) CHASSIS TABS, CABLE TABS CE MANUAL MAINTENANCE, MAINTENANCE AIDS (USE BB319-A) | 60230300 | S | 22 | 46.15 |
| BB323-B (6635-D) EXTEND CORE STORAGE ASSEMBLY (USE BB323-A MANUALS) | | | | |
| BB324-B (6636-D) EXTENDED CORE STORAGE ASSEMBLY (USE BB323-A MANUALS) | | | | |
| BB325-A (6633-C) EXTENDED CORE STORAGE ASSEMBLY (USE BB319-A MANUALS) | | | | |
| BB325-B (6633-D) EXTENDED CORE STORAGE ASSEMBLY (USE BB319-A MANUALS) | | | | |
| BB328-A (1772-1, 90104, 90108-2) MEM INCREMENT CE INFO (USE AB103-A) | | | | |
| BB329-A (1772-2, 90104, 90108-1) MEM INCREMENT CE INFO (USE AB103-A) | | | | |
| BB343-B (ST.OP. 10178) MEMORY INCREMENT 98K TO 131K FOR 6414/6514-D REFERENCE AT140-G/H 6414-D PRIOR TO OPT (USE 6413-D) NOT FOR USE WITH AT139 OR AT137 (USE BB343-C INSTEAD | | | | |
| BB343-C (ST. OP. 10178) MEMORY INCREMENT 98K TO 131K FOR AT140-A/B 6414-E (INCLUDED IN AA105-A MANUALS) ALSO APPLIES TO 6414/6514-D WITH SPIGOT | | | | |
| BB346-A (SP.OP. 60058-A) MEMORY INCREMENT 32K TO 65K FOR 6605/6615-A (USE 6604/14-A) | | | | |
| BB349-A (ST.OP. 10177) MEMORY INCREMENT 49K TO 65K FOR 6415-C (USE 6414-A/B/C) | | | | |
| BB349-B (ST.OP. 10177) MEMORY INCREMENT 49K TO 65K FOR 6415-D (USE 6414-D) | | | | |
| BB349-C (ST.OP. 10177) MEMORY INCREMENT 49K TO 65K FOR 6415-E (AA108-A) (USE AA105-A) | | | | |
| BB351-A () STORAGE MODULE | | | | |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------|---|----|-------|
| CE MANUAL | 60316100 | C | 22 | 15.10 |
| BB353-A () STORAGE MODULE CE INFO (USE BB104-A) | | | | |
| BB354-A () STORAGE INCREMENT CE INFO (USE GH408-A/B) | | | | |
| BB355-A () STORAGE INCREMENT CE INFO (USE GH408-A/B) | | | | |
| BB360-A () LARGE CORE MEMORY INCREMENT CE INFO (USE AC113-A) | | | | |
| BB360-B (76-XXX) LARGE CORE MEMORY INCREMENT CE INFO (USE AA106-A OR AC113-A) | | | | |
| BB361-A () SMALL CORE MEMORY INCREMENT CE INFO (USE AC113-A) | | | | |
| BB365-A (ST.OP. 10179-1) 16K INCREMENT TO 49K REF/CE MANUAL | 60316000 | B | 22 | 06.00 |
| BB365-B (ST. OPT. 10179-1) 16K MEMORY INCR. FOR 6615-D CENTRAL COMPUTER REFERENCE/CE MANUAL | 60315900 | B | 22 | 05.65 |
| BB366-A () 32K INCREMENT TO 65K FOR AA103-A USE AA103-A MANUALS | | | | |
| BB367-A () 16K INCREMENT TO 65K FOR AA103-A USE AA103-A MANUALS | | | | |
| BB370-A () MEM MODIFICATION FOR 6600 REFERENCE/CE MANUAL | 60319800 | B | 22 | 06.80 |
| BB372-A (731-XX, 732-XX, 730-100) 750 NANO- SECOND CORE STORAGE MODULE CE MANUAL | 60346500 | C | 22 | 02.85 |
| BB377-A (733-140, 10274-1) 4K INCREMENT CE INFO (USE FV156-A) | | | | |
| BB381-A (1772-2, 90108-3) MEMORY INCREMENT CE INFO (USE AB103-A) | | | | |
| BB382-A (1772-2, 90108-3) MEMORY MODULE CE INFO (USE AB103-A) | | | | |
| BB385-A/B (1772-2) MEMORY MODULE CE INFO (USE AB103-A) | | | | |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.

4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------------------------------|-------------|----|-------------------------|
| BB386-A (1772-1) STORAGE INCREMENT CE INFO (USE AB103-A) | | | | |
| BB387-A () MEMORY MODULE CE INFO (USE AB103-A) | | | | |
| BB393-A (7030-4/8/16) EXTENDED CORE STORAGE CE INFO (USE BB323-A) | | | | |
| BB394-A (7030-2) EXTENDED CORE STORAGE CE INFO (USE BB319-A) | | | | |
| BB395-A (7030-1) EXTENDED CORE STORAGE CE INFO (USE BB319-A) | | | | |
| BB397-A (CYBER 74-XX) 65K TO 32K DECREMENT CE INFO (INCLUDED IN AA117-A, CHASSIS 9, 10, 11 AND 12 MANUALS) | | | | |
| BB399-A (10273-2) MEMORY INCREMENT MODULE CE INFO (USE AA116-A) | | | | |
| BB400-A (10273-3) MEMORY INCREMENT MODULE CE INFO (USE AA116-A) | | | | |
| BB402-A () CORE STORAGE MODULE CE MANUAL | 60389600 | A | 22 | 02.85 |
| BB405-A (7700) LCM INCREMENT CE INFO (USE AA121-A) | | | | |
| BE1A2 (9545-14) MAGNETIC TAPE TRANSPORT PARTS LIST (A01-A02 AND ABOVE) CE MANUAL REF/CE MANUAL (EXCEPT PARTS LIST) | 49487900 49487800 | B A | 22 | 04.00 09.40 |
| BE1A3 (9525-14) MAGNETIC TAPE TRANSPORT PARTS LIST (A01 AND ABOVE) CE MANUAL REF/CE MANUAL (EXCEPT PARTS LIST) | 49488200 49486400 | C A | 22 | 04.00 09.50 |
| BE101 (604-2) MAGNETIC TAPE TRANSPORT GENERAL DESCRIPTION, DIAGRAMS CE MANUAL PARTS LIST (A04-07 B04 AND ABOVE, C02 AND ABOVE) CE MANUAL | 49755600 41240000 | A E | 22 | 08.55 04.20 |
| BE102 (608) MAGNETIC TAPE TRANSPORT THEORY OF OPERATION, DIAGRAMS, WIRE LIST CE MANUAL DESCRIPTION, OPERATION, INSTALLATION, CHECKOUT, MAINTENANCE CE MANUAL PARTS LIST CE MANUAL | 40860800 40860700 40864100 | J E G | 22 | 01.50 04.75 02.95 |
| BE103 (657-1) MAGNETIC TAPE TRANSPORT PARTS LIST CE MANUAL | 49815000 | G | 22 | 05.70 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|---|----|-------|
| GEN DESC., THEO OF OPER, MAINT. CE MANUAL | 49750300 | F | 22 | 05.45 |
| DIAGRAMS CE MANUAL | 49750400 | D | 34 | 04.05 |
| BE104 (657-2) MAGNETIC TAPE TRANSPORT CE INFO (USE BE103) | | | | |
| BE2A1 (9568) MAGNETIC TAPE TRANSPORT PARTS LIST (A01 AND ABOVE) CE MANUAL | 41243800 | B | 22 | 01.65 |
| REF/CE MANUAL (EXCEPT PARTS LIST) | 40869700 | D | 22 | 04.40 |
| BE2A2 (9585-14) MAGNETIC TAPE TRANSPORT PARTS LIST (A01 AND ABOVE) CE MANUAL | 49487300 | B | 22 | 04.00 |
| REF/CE MANUAL (EXCEPT PARTS LIST) | 49487200 | A | 22 | 09.60 |
| BE2A3-A (9565-14) MAGNETIC TAPE TRANSPORT PARTS LIST (A01 AND ABOVE) CE MANUAL | 49487500 | C | 22 | 04.00 |
| REF/CE MANUAL (EXCEPT PARTS LIST) | 49487400 | A | 22 | 09.60 |
| BE222 (607-2) MAGNETIC TAPE TRANSPORT REFERENCE/CE MANUAL (INCLUDES BE423) (INCLUDES PMI/PMO) PARTS LIST CE INFO. (USE BE101) | 40869901 | C | 22 | 04.60 |
| BE223 (657-3) MAGNETIC TAPE TRANSPORT CE INFO (USE BE103) PARTS LIST CE MANUAL | 49815100 | F | 22 | 02.10 |
| BE224 (657-4) MAGNETIC TAPE TRANSPORT CE INFO (USE BE103) | | | | |
| BE4A1 (9560) MAGNETIC TAPE TRANSPORT REF/CE MANUAL (EXCEPT PARTS LIST) | 40868700 | C | 22 | 05.70 |
| PARTS LIST CE MANUAL | 41242100 | C | 22 | 01.70 |
| BE4A1/BT103 (9560 WITH SPO 68024) MAGNETIC TAPE TRANSPORT CE MANUAL | 49859400 | A | 22 | 10.35 |
| BE4A2 (9565) GEN DESC. THEO OF OPER, MAINT. CE MANUAL | 49755700 | B | 22 | 09.75 |
| PARTS LIST CE INFO. (USE BE4A1) | | | | |
| BE4A9 (9585) MAGNETIC TAPE TRANSPORT GEN DESC, THEO OF OPER, MAINT. CE MANUAL | 49755700 | B | 22 | 09.75 |
| PARTS LIST (A01, B01 AND ABOVE) CE MANUAL | 40801800 | D | 22 | 03.90 |
| BE4B1 (9545) MAGNETIC TAPE TRANSPORT GEN DESC, THEO OF OPER, MAINT. CE MANUAL | 49755700 | B | 22 | 09.75 |
| PARTS LIST (A02, B02 AND ABOVE) CE MANUAL | 40821900 | E | 22 | 04.00 |
| BE4B2 (9525) MAGNETIC TAPE TRANSPORT GEN DESC, THEO OF OPER, MAINT. CE MANUAL | 49755700 | B | 22 | 09.75 |
| DIAGRAMS CE MANUAL | 49755800 | C | 22 | 09.00 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------------------------------|-------------|----------------|-------------------------|
| BE4B3 (9540) MAGNETIC TAPE TRANSPORT PARTS LIST (A04, B04 AND ABOVE) CE INFO. (USE BE4B1) REF/CE MANUAL (EXCEPT PARTS LIST) | 40817400 | B | 22 | 05.60 |
| BE4B3/BT115 (9540 WITH SPO 68025) MAGNETIC TAPE TRANSPORT REF/CE MANUAL | 49859100 | A | 22 | 09.80 |
| BE4B4 (9580) MAGNETIC TAPE TRANSPORT REF/CE MANUAL (EXCEPT PARTS LIST) PARTS LIST CE INFO. (USE BE4A9) | 40824200 | A | 22 | 12.20 |
| BE4B4 WITH BT116 (9580 WITH SPO.68023) | 49859200 | B | 22 | 10.20 |
| BE4B5 (9520) MAGNETIC TAPE TRANSPORT PARTS LIST (A01, B01 AND ABOVE) CE INFO. (USE BE4B2) DIAGRAMS, WIRE LIST CE MANUAL REF/CE MANUAL (EXCEPT PARTS LIST) PARTS LIST | 49859300 40808200 40819900 | A B C | 22 22 22 | 10.05 05.60 04.10 |
| BE4B8 (9585-11) MAGNETIC TAPE TRANSPORT PARTS LIST (A01 AND ABOVE) CE MANUAL REF/CE MANUAL | 49800300 49484600 | C B | 22 22 | 02.55 08.50 |
| BE4B9 (9525-13) MAGNETIC TAPE TRANSPORT REF/CE MANUAL (EXCEPT PARTS LIST) PARTS LIST (A01 AND ABOVE) CE MANUAL | 49488300 49488400 | A C | 22 22 | 08.90 04.00 |
| BE4C1 (9545-13) MAGNETIC TAPE TRANSPORT REF/CE MANUAL (EXCEPT PARTS LIST) PARTS LIST CE MANUAL | 49488000 49488100 | A B | 22 22 | 09.25 03.50 |
| BE4C2 (9565-13) MAGNETIC TAPE TRANSPORT REF/CE MANUAL (EXCEPT PARTS LIST) PARTS LIST (A01 AND ABOVE) CE MANUAL | 49487600 49487700 | A C | 22 22 | 09.25 03.40 |
| BE4C3 (9585-13) MAGNETIC TAPE TRANSPORT REF/CE MANUAL (EXCEPT PARTS LIST) PARTS LIST (A01 AND ABOVE) CE MANUAL | 49487000 49487100 | A B | 22 22 | 09.25 04.00 |
| BE4C4 (9519) MAGNETIC TAPE TRANSPORT PARTS LIST CE MANUAL SPECIAL CARD MANUAL | 49488600 49932700 | E A | 22 22 | 05.80 01.50 |
| BE4D1 (609) MAGNETIC TAPE TRANSPORT THEORY OF OPERATION, DIAGRAMS, WIRE LIST CE MANUAL DESCRIPTION, OPERATION, INSTALLATION CHECKOUT, MAINTENANCE CE MANUAL PARTS LIST CE INFO. (USE BE102) | 40861000 40860900 | H E | 22 22 | 02.40 05.55 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------------------------------|-------------|----------------|-------------------------|
| BE406 (659-1) MAGNETIC TAPE TRANSPORT GEN DESC., THEO OF OPER, MAINT CE MANUAL DIAGRAMS CE MANUAL PARTS LIST CE MANUAL | 49750600 49750700 49815200 | G G H | 22 34 22 | 09.10 04.90 02.20 |
| BE407 (659-2) MAGNETIC TAPE TRANSPORT CE INFO (USE BE406) | | | | |
| BE408 (659-3) MAGNETIC TAPE TRANSPORT CE INFO (USE BE406) PARTS LIST CE MANUAL | 70603900 | J | 22 | 02.30 |
| BE409 (659-4) MAGNETIC TAPE TRANSPORT CE INFO (USE BE406) PARTS LIST (A01, B01 AND ABOVE) CE INFO. (USE BE408) | | | | |
| BE423 () NINE TRACK OPTION (SEE BE222) | | | | |
| BG105-A/B DRUM STORAGE UNITS,DIAGS, CIRC DESC, MAINT,P/L,C/P, EQ SUM, W/L | 60210400 | C | 22 | 13.55 |
| BG108-C/D/863-C DRUM STORAGE UNIT CE MAN. | 70606700 | A | 22 | 09.50 |
| BG111-A/C MICRO DRUM CE MANUAL | 40808600 | B | 22 | 01.30 |
| BG111D-G MICRO DRUM GEN DESC., OPER., PARTS DATA, MAINT., THEO. OF OPER., CE MANUAL | 70622100 | B | 22 | 03.25 |
| BG113 DRUM STORAGE UNIT GEN DESC,MAINT AIDS, EQ SUM, W/L DIAGS CE MANUAL | 70607500 | B | 22 | 16.25 |
| BG504 A-H DRUM MEMORY SUBSYSTEM HARDWARE REF/CE MANUAL | 39731700 | C | 22 | 03.00 |
| BH1A9/BH2A1 DISK FILE THEORY OF DIAGRAMS, WIRE LIST CE MANUAL | 70607100 | A | 22 | 07.80 |
| BH2A1 DISK FILE SYSTEM PARTS DATA | 70606900 | B | 22 | 02.30 |
| BH405 DISK FILE CLOCK WRITER/EXERCISER CE MANUAL TROUBLESHOOTING GUIDE | 70615800 59349900 | B A | 22 22 | 05.90 15.90 |
| BH405-C DISK FILE GEN DESC.,OPER.,INSTAL., CHECKOUT, MAINTENANCE PRELIM.ED. CE MANUAL THEO OF OPER., DIAGS., WIRE LIST CE MANUAL PARTS DATA CE MANUAL | 41242300 41242200 41242400 | B F C | 22 22 22 | 08.45 06.35 05.10 |
| BH408/410 DISK FILE GENERAL DESCRIPTION | 70601300 | B | 22 | 06.20 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|---|----|-------|
| OPER., INSTALL. AND CHECKOUT, MAINT. CE MAN. PARTS LIST MOD A07,A08 AND ABOVE CE MANUAL | 70601500 | D | 22 | 02.20 |
| THEORY, DIAGRAMS AND WIRE LIST MANUAL | 70601400 | G | 22 | 06.20 |
| TROUBLE SHOOTING GUIDE CE MANUAL | 86811400 | A | 22 | 08.80 |
| BJ1A7 DISK STORAGE DRIVE--ALSO LISTED AS 9451 DIAGRAMS AND WIRE LIST CE MANUAL | 41241700 | B | 22 | 06.40 |
| BJ1A9 PARTS LIST MOD A13,B13 ABOVE CE MANUAL | 70605300 | C | 22 | 02.15 |
| BJ103 DISK STORAGE DRIVE PARTS LIST | 70605000 | C | 22 | 02.85 |
| BJ104-A/B DISK STORAGE DRIVE DIAGS AND WIRE LIST CE MANUAL | 70604400 | E | 22 | 02.90 |
| PARTS LIST MODS A13, B13 AND ABOVE MAINTENANCE CE MANUAL | 70604500 | C | 22 | 02.85 |
| | 70604300 | C | 22 | 06.70 |
| BJ2A2 DISK STORAGE DRIVE DIAGS. AND W/L MAINTENANCE MANUAL | 41249700 | D | 22 | 04.55 |
| PARTS DATA CE MANUAL | 41249600 | B | 22 | 05.75 |
| | 41249800 | B | 22 | 01.80 |
| BJ3A1 DISK STORAGE DRIVE A12 ABOVE, B12 ABOVE PARTS LIST | 41249500 | C | 22 | 03.70 |
| DIAGS, CIRC DESC., C/P, W/L, CE MANUAL | 41249400 | D | 22 | 02.15 |
| BJ3A1-A/B DISK STORAGE DRIVE MAINT.CE MANUAL | 41249300 | C | 22 | 12.70 |
| BJ3A3 DISK STORAGE DRIVE-DUAL DISK DRIVE PARTS | 70606500 | B | 22 | 02.00 |
| BJ5XX STORAGE MODULE DRIVE PARTS DATA CE MANUAL | 70631100 | L | 3 | 02.80 |
| REFERENCE MANUAL | 70631000 | D | 3 | 09.35 |
| MAINTENANCE MANUAL | 70630900 | K | 3 | 09.60 |
| BJ6XX STORAGE MODULE DRIVE MAINTENANCE MANUAL | 83310800 | C | 3 | 05.70 |
| REFERENCE MANUAL | 83310900 | B | 3 | 05.40 |
| BJ7XX STORAGE MODULE DRIVE MAINTENANCE MANUAL | 83308400 | A | 3 | 10.50 |
| REFERENCE MANUAL | 83308500 | A | 3 | 12.40 |
| PARTS DATA MANUAL | 83308600 | A | 3 | 04.10 |
| BK3A1 DUAL DISK DRIVE PARTS LIST CE MANUAL | 70604700 | D | 22 | 03.45 |
| BM1A1/BM1A3 MULTIPLE DISK DRIVE DIAGS, W/L CE | 41249200 | A | 22 | 07.20 |
| BM1A1,2,3,4 PARTS DATA CE MANUAL | 70605500 | D | 22 | 06.10 |
| BM1A2-A/B/BM1A4-A/B MULTIPLE DISK DRIVE DIAGS, WIRE LIST CE MANUAL | 70602300 | A | 22 | 07.10 |
| MAINTENANCE CE MANUAL | 70602200 | A | 22 | 03.65 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|---|----|-------|
| BM1A5/BM1A6 MULT. DISK DR MOD B01/ABOVE PARTS | 70601900 | K | 22 | 05.95 |
| BM1A5/BM1A7 MULTIPLE DISK DRIVE THEORY OF OPER DIAGRAMS, MAINTENANCE AIDS, WIRE LISTS | 70602500 | H | 22 | 08.20 |
| GENERAL DESCRIPTION, OPERATION, INSTALLATION AND CHECKOUT, MAINTENANCE CE MANUAL | 70602400 | G | 22 | 08.00 |
| BM1A6/BM1A8 MULTIPLE DISK DR. GEN. DESC., OPER. INST.CHKOUT,MAINT, CE MAN | 41243900 | E | 22 | 03.80 |
| BM1B1/3-A/B GENERAL DESCRIPTION MANUAL OP., DIAGRAMS, MAINT. | 70603300 | G | 22 | 05.10 |
| THEORY OF OPER. DIAGS, MAINT AIDS, WIRE LIST CE MANUAL | 70603400 | H | 22 | 11.40 |
| BM1B1,2,3,4 AND A02,B02 AND ABOVE, MULT DK DR | 70603500 | H | 22 | 03.90 |
| BM1B2-A/B, BM1B4-A/B MULT. DISK DR GEN DESC. OPER., INST., AND CHKOUT MAINT. MAN. | 70603600 | D | 22 | 03.70 |
| THEO OF OP,DIAG,MAINT AIDS,WIRE LIST CE MAN | 70603700 | D | 22 | 20.15 |
| BM1B5-B/BM1B6-B GEN DESC.,OPER.,INST. AND CHECKOUT, MAINT. CE MANUAL PARTS LIST | 40869600 | J | 22 | 02.00 |
| BM1B7 MULTIPLE DISK DRIVE PARTS LIST CE MANUAL | 70603200 | A | 22 | 02.10 |
| BM1B7-A MULTIPLE DISK DRIVE MAINTENANCE CE | 70603000 | A | 22 | 03.60 |
| BM1B8-B/BM1B9-B MULT. DISK DRIVE MAINT., GEN. DESC., CE MANUAL | 70607300 | E | 22 | 01.00 |
| DIAG, WIRE LIST, MAINT, CE MANUAL | 70607200 | G | 22 | 05.90 |
| BM1C1-B/BM1C2-B MULTIPLE DISK DRIVE GEN DESC. THEORY OF OPER, CE MANUAL | 70619500 | C | 22 | 04.95 |
| DIAGRAMS CE MANUAL | 70619600 | B | 22 | 11.80 |
| PARTS DATA CE MANUAL | 70619700 | C | 22 | 04.30 |
| BM101/103 MULTIPLE DISK DRIVE GEN DESC., OPER., INSTAL. CKOUT., MAINT. CE MAN | 41248900 | J | 22 | 02.95 |
| THEO OF OPER., DIAGRAMS, MAINT. AIDS CE LISTS CE MANUAL | 41249000 | J | 22 | 07.70 |
| PARTS DATA CE MANUAL | 41243700 | L | 22 | 16.90 |
| BM102/104-A/3 MULTIPLE DISK DRIVE GEN. DESC., OPER.,INSTL.CHKOUT,MAINT. CE MANUAL | 41243500 | H | 22 | 04.35 |
| THEO OF OPER., DIAGRAMS, MAINT AIDS, WIRE LISTS CE MAN. | 41243600 | J | 22 | 22.10 |
| PARTS DATA INFO (USE BM101/103) | | | | |
| BM2A2/4 MULTIPLE DISK DRIVE MAINT, CE MANUAL | 70606100 | B | 22 | 04.35 |
| BM2A7/8 MULTIPLE DISK DRIVE MAINT. CE MANUAL | 70609400 | B | 22 | 04.80 |
| PARTS DATA CE MANUAL | 70609700 | F | 22 | 04.30 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|---|----|-------|
| THEORY OF OPER, DIAGRAMS, W/L, MAINT.AIDS CE | 70609500 | B | 22 | 09.80 |
| BM2B1 MULTIPLE DISK DRIVE | | | | |
| GEN DESC, CHKOUT, MAINT. CE MANUAL | 70611000 | A | 22 | 04.00 |
| THEO OF OPER, MAINT AIDS, DIAGRAMS, W/L CE | 70611100 | B | 22 | 14.90 |
| BM2B2 MULTIPLE DISK DRIVE | | | | |
| GEN DESC, CHECKOUT, MAINTENANCE CE MANUAL | 70611300 | D | 22 | 09.25 |
| PARTS DATA CE MANUAL | 70611200 | H | 22 | 03.05 |
| BM2B2-C/D MULTIPLE DISK DRIVE | | | | |
| DIAGRAMS CE MANUAL | 70615900 | D | 22 | 07.70 |
| BM3A? MULTIPLE DISK DRIVE PARTS DATA CE MAN | 70609200 | D | 22 | 02.10 |
| BP2A3 DISK STORAGE UNIT A01 ABOVE PARTS DATA CE MANUAL | 70605800 | B | 22 | 02.20 |
| BR1A1 DISK STORAGE UNIT | | | | |
| GEN DESC, OPER, INSTAL/CHECKOUT, THEORY OF | 70609800 | D | 22 | 14.00 |
| DIAGRAMS, MAINT AIDS, WIRE LISTS CE MANUAL | 70609900 | C | 22 | 02.50 |
| PARTS DATA CE MANUAL | 70610100 | J | 22 | 01.50 |
| DIAGRAMS, MAINT. AIDS, WIRE LIST CE MANUAL | 70617000 | L | 22 | 12.35 |
| (MODS A03, B03 AND C03 AND ABOVE) | | | | |
| BR1A1-E DISK STORAGE UNIT | | | | |
| MAINTENANCE MANUAL | 70619200 | F | 22 | 12.25 |
| DIAGRAMS AND WIRE LIST | 70619300 | H | 22 | 10.50 |
| PARTS DATA CE MANUAL | 70619400 | H | 22 | 02.10 |
| BR1A3 DISK STORAGE UNIT | | | | |
| PARTS DATA CE MANUAL | 70613100 | B | 22 | 03.10 |
| GEN DESC, OPER, INS0ALLATION/CHECKOUT, THEO | 70612900 | A | 22 | 04.90 |
| OF OP, MAINT CE MANUAL | | | | |
| DIAGRAMS CE MANUAL | 70613000 | B | 22 | 05.35 |
| BR1A9 DISK STORAGE UNIT | | | | |
| DIAGS, W/L, MAINT AIDS (MODS B03 AND ABOVE) | 70617100 | H | 22 | 04.50 |
| CE MANUAL | | | | |
| BR1A9-B VOICE COIL DRIVE | | | | |
| PARTS DATA(B01 AND ABOVE) CE MANUAL | 70609300 | J | 22 | 03.80 |
| BR1B3 DISK STORAGE UNIT DIAGRAMS AND WIRE LIST | 70620500 | F | 22 | 02.85 |
| CE MANUAL | | | | |
| GEN DESC., THEORY OF OPER., INSTL/CHECKOUT, | 70620400 | C | 22 | 06.15 |
| MAINTENANCE CE MANUAL | | | | |
| PARTS DATA CE MANUAL | 70620600 | G | 22 | 02.25 |
| BR2A1-D DISK STORAGE UNIT | | | | |
| MAINTENANCE MANUAL | 70616300 | C | 22 | 04.30 |
| PARTS DATA CE MANUAL | 70612600 | C | 22 | 01.65 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|---|----|-------|
| BR2A1-D (SC19 AND ABOVE) DISK STORAGE UNIT PARTS DATA CE MANUAL | 83311400 | A | 22 | 05.05 |
| BR2A1-1 DISK STORAGE UNIT DIAGRAMS CE MANUAL | 70616400 | F | 22 | 07.20 |
| BR2A7 DISK STORAGE UNIT PARTS DATA CE MANUAL | 70615100 | A | 22 | 04.15 |
| BR2A6-B DISK STORAGE UNIT DIAGRAMS AND W/L PARTS DATA CE MANUAL | 70622700 | K | 22 | 03.55 |
| MAINTENANCE CE MANUAL | 70622800 | N | 22 | 03.15 |
| | 70622600 | H | 22 | 05.30 |
| BR2A7 DISK STORAGE UNIT DIAGRAMS AND WIRE LIST PARTS DATA CE MANUAL | 70622200 | L | 22 | 03.45 |
| | 70622500 | M | 22 | 07.65 |
| BR2A8 DISK STORAGE UNIT DIAGRAMS AND WIPE LISTS CE MANUAL | 70622300 | M | 22 | 06.10 |
| MAINTENANCE CE MANUAL | 70622400 | G | 22 | 05.05 |
| BR2B1 DISK STORAGE UNIT MAINTENANCE MANUAL | 70612500 | C | 22 | 13.40 |
| DIAGRAMS AND WIRE LISTS | 70607900 | D | 22 | 07.60 |
| BR2B2/3 DISK STORAGE UNIT GENERAL DESCRIPTION, MAINTENANCE CE MANUAL | 70631300 | D | 22 | 08.45 |
| DIAGRAMS, WIRE LISTS CE MANUAL | 70631400 | F | 22 | 06.30 |
| PARTS DATA CE MANUAL | 70631500 | G | 22 | 04.35 |
| BR3A1-G DISK STORAGE UNIT MAINTENANCE AIDS DIAGRAMS AND WIRE LIST CE MANUAL | 70613300 | F | 22 | 06.50 |
| MAINTENANCE CE MANUAL | 70613200 | F | 22 | 10.30 |
| PARTS DATA (SC 07 AND ABOVE) | 70626500 | C | 22 | 04.50 |
| BR3A4 DISK STORAGE UNIT GEN DESC., THEO OF OPER., MAINTENANCE CE MANUAL | 70610300 | D | 22 | 12.75 |
| DIAGRAMS CE MANUAL | 70610500 | F | 22 | 06.25 |
| BR3A5 DISK STORAGE UNIT PARTS DATA CE MANUAL DIAGRAMS AND WIRE LIST CE MANUAL | 70623700 | B | 22 | 03.40 |
| MAINTENANCE CE MANUAL | 70623600 | C | 22 | 06.10 |
| | 70623500 | A | 22 | 07.60 |
| BR3B4 DISK STORAGE UNIT MAINTENANCE MANUAL PARTS DATA MANUAL | 70628200 | L | 3 | 05.89 |
| | 70628400 | G | 3 | 02.35 |
| BR3B5 DISK STORAGE UNIT PARTS DATA MANUAL | 70630500 | F | 3 | 05.90 |
| BR3B8 DISK STORAGE UNIT PARTS DATA CE MANUAL | 83301200 | K | 3 | 03.85 |
| REFERENCE MANUAL | 83301100 | C | 3 | 04.90 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.

4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|---|----|-------|
| MAINTENANCE CE MANUAL | 83301000 | K | 3 | 07.90 |
| BR306 DISK STORAGE UNIT REFERENCE MANUAL | 83309400 | B | 3 | 07.05 |
| MAINTENANCE CE MANUAL | 83309300 | C | 3 | 08.70 |
| PARTS DATA | 83309500 | C | 3 | 04.85 |
| BR301R DISK STORAGE UNIT | | | | |
| MAINTENANCE MANUAL | 83305700 | E | 3 | 10.20 |
| REFERENCE MANUAL | 83305800 | C | 3 | 05.75 |
| PARTS DATA MANUAL | 83305900 | E | 3 | 03.00 |
| BR303-A/B DISK STORAGE UNIT | | | | |
| MAINTENANCE MANUAL | 83311600 | A | 22 | 16.90 |
| REFERENCE MANUAL | 83311700 | A | 3 | 10.00 |
| BR304 DISK STORAGE UNIT | | | | |
| MAINTENANCE MANUAL | 83313100 | A | 3 | 20.30 |
| REFERENCE MANUAL | 83313200 | A | 3 | 17.55 |
| PARTS LIST | 83313300 | A | 3 | 04.65 |
| BR302 DISK STORAGE UNIT | | | | |
| DIAGRAMS AND WIRE LIST CE MANUAL | 70618500 | J | 22 | 05.70 |
| MAINTENANCE CE MANUAL | 70618400 | F | 22 | 24.25 |
| PARTS DATA CE MANUAL | 70618600 | E | 22 | 02.95 |
| PARTS DATA CE MANUAL (S/C 09 AND ABOVE) | 70626300 | D | 22 | 03.40 |
| BR303 DISK STORAGE UNIT | | | | |
| INSTALLATION/CHECKOUT, PREVENTIVE/CORRECTIVE | 70629600 | H | 22 | 07.10 |
| MAINTENANCE, DIAGRAMS, W/L, CE MANUAL | | | | |
| PARTS DATA CE MANUAL | 70629700 | J | 22 | 03.30 |
| GEN DESC., OPER., THEORY OF OPERATION CE MAN | 70629500 | C | 22 | 03.45 |
| BR304 DISK STORAGE UNIT | | | | |
| PARTS DATA CE MANUAL | 70628100 | C | 22 | 01.95 |
| MAINTENANCE CE MANUAL | 70627900 | D | 22 | 11.30 |
| GENERAL DESCRIPTION, OPERATION, THEORY OF | 70628000 | C | 22 | 06.90 |
| OPERATION, KEY TO LOGIC, INTEGRATED CIRCUIT | | | | |
| DISCRETE CIRCUITS CE MANUAL | | | | |
| BR305 DISK STORAGE UNIT | | | | |
| PARTS DATA CE MANUAL | 83303300 | C | 22 | 04.50 |
| REFERENCE MANUAL | 83303200 | A | 22 | 06.90 |
| PREVENTIVE/CORRECTIVE MAINTENANCE, DIAGRAMS, | 83303100 | B | 22 | 20.05 |
| WIRE LISTS CE MANUAL | | | | |
| BR306/7 DISK STORAGE UNIT | | | | |
| PARTS DATA CE MANUAL | 83308900 | C | 22 | 04.60 |
| PREVENTIVE/CORRECTIVE MATNT., DIAGS, W/L | 83308700 | C | 22 | 18.55 |
| REFERENCE MANUAL | 83308800 | B | 22 | 14.50 |
| BR306/7-D/E DISK STORAGE UNIT | | | | |
| PREVENTIVE/CORRECTIVE MAINTENANCE, DIAGRAMS, | 83314000 | A | 22 | 13.05 |
| WIRE LISTS CE MANUAL | | | | |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------|---|----|-------|
| BR5A1 DISK STORAGE UNIT MAINTENANCE MANUAL | 70617800 | E | 22 | 04.50 |
| PARTS DATA CE MANUAL | 70618000 | P | 22 | 02.50 |
| DIAGRAMS AND WIRE LIST CE MANUAL | 70617900 | J | 22 | 03.45 |
| BR5A2 DISK STORAGE UNIT MAINTENANCE MANUAL | 70624500 | G | 22 | 05.90 |
| DIAGRAMS CE MANUAL | 70624600 | J | 22 | 04.45 |
| PARTS DATA MANUAL | 70624700 | J | 22 | 02.85 |
| BR5A3 DISK STORAGE UNIT GEN. DESC., OPER., INSTALLATION AND CHECKOUT THEORY OF OPERATION, MAINTENANCE CE MANUAL | 70628500 | B | 22 | 06.25 |
| DIAGRAMS AND WIRE LISTS CE MANUAL | 70628600 | D | 22 | 05.40 |
| BR5A4 DISK STORAGE UNIT MAINTENANCE MANUAL | 70630000 | B | 3 | 18.75 |
| PARTS DATA CE MANUAL | 70630200 | C | 3 | 07.80 |
| DIAGRAMS CE MANUAL | 70630100 | C | 22 | 10.90 |
| BR5A5 DISK STORAGE UNIT GEN. DESC., OPERATION, INSTALLATION/CHECKOUT THEORY OF OPERATION AND MAINT CE MANUAL | 83302300 | D | 22 | 11.05 |
| DIAGRAMS, MAINT. AIDS, WIRE LIST CE MANUAL | 83302400 | C | 22 | 08.40 |
| PARTS DATA CE MANUAL | 83302500 | E | 22 | 05.35 |
| BR5A6 DISK STORAGE UNIT MAINTENANCE MANUAL | 83313400 | B | 3 | 10.50 |
| REFERENCE MANUAL | 83313500 | B | 3 | 12.20 |
| PARTS DATA MANUAL | 83313600 | A | 3 | 03.75 |
| BR501 DISK STORAGE UNIT PREVENTIVE AND CORRECTIVE MAINTENANCE, DIAGRAMS, WIRE LISTS, CE MANUAL | 70629300 | M | 22 | 09.75 |
| GENERAL DESCRIPTION, OPERATION, THEORY OF OPERATION CE MANUAL | 70629200 | F | 22 | 03.70 |
| PARTS DATA CE MANUAL | 70629400 | K | 22 | 04.60 |
| BR502/4 DISK STORAGE UNIT REFERENCE MANUAL | 83302700 | D | 22 | 06.25 |
| PARTS DATA CE MANUAL | 83302800 | F | 22 | 02.65 |
| PREVENTIVE/CORRECTIVE MAINTENANCE, DIAGRAMS, WIRE LIST CE MANUAL | 83302600 | G | 22 | 07.95 |
| BS101-A (76-XXX) CENTRAL MEMORY INCREMENTS CE INFO (USE AA106-A) | | | | |
| BS102-A (76-XXX) CENTRAL MEMORY INCREMENT CE INFO (USE AA106-A) | | | | |
| BT116 (SPO 63023) DUAL MODE OPTION (SEE BF4B4) | | | | |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------------------|---------|----|----------------|
| BT118 (SPO 68106) NINE TRACK OPTION (SEE BE101) | | | | |
| BT128-A () STORAGE MODULE CE INFO (USE B8351-A) | | | | |
| BT150-A/B (1714) MEMORY EXPANSION MODULE CE INFO (USE AA116-A) | | | | |
| BU104 MAGNETIC TAPE CERTIFIER PARTS DATA CE MANUAL | 70617400 | A | 22 | 04.80 |
| CA101-A, CA102-A HDWR REF/CE MAN | 82140400 | A00 | 22 | 01.25 |
| CC514-A/B (7601-1) STATION CONSOLE | | | | |
| CC521-A () SECOND CONSOLE DISPLAY FOR 6000-D/E COMPUTER SYSTEMS (USE 6602/6612) | | | | |
| CC533-A DATA ACQUISITION/CONTROLLER CONSOLE GEN DESC., DIAGS, W/L, MAINT CE MANUAL | 39534900 | A | 22 | 02.30 |
| CE1A5 (9200) CARD READER REF/CE MANUAL (EXCEPT PARTS LIST) | 49626100 | D | 22 | 10.70 |
| CE120 (1729-2) CARD READER PARTS LIST (A01, B01 AND ABOVE) CE MANUAL REF/CE MANUAL (EXCEPT PARTS LIST) | 40804800 40802000 | A C | 22 | 01.85 05.30 |
| CE123-A/B PARTS LIST CE MANUAL DIAGRAMS, WIRE LIST, MAINTENANCE CE MANUAL | 49755100 49755200 | 02 B | 22 | 01.45 14.95 |
| CE124 (410) PL10 CARD READER GEN DESC., DIAGS, THEORY OF OPERATION REF/CE MANUAL | 49754900 | B | 22 | 06.70 |
| CE149 (407) CARD READER REF/CE MANUAL (EXCEPT PARTS LIST) | 49973600 | B | 22 | 11.00 |
| CE152 (224) CARD READER REF/CE INFO (USE CE1A5) PARTS DATA CE MANUAL | 60352000 | D | 22 | 01.05 |
| CE155-A/B () CARD READER REFERENCE/CE MANUAL | 60366600 | A | 22 | 16.65 |
| CE304 (224-2) CARD READER REF/CE MANUAL (EXCEPT PARTS LIST) PARTS LIST CE MANUAL | 41243200 41241500 | D H | 22 | 03.55 02.50 |
| CE305-A/B (1777-1/2, 90121-1, 90122-1) PAPER TAPE READER CE MANUAL | 60293400 | N | 22 | 03.40 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|----|----|-------|
| ** REFER ALSO TO CATALOG SEC. 2 FOR 370 PAPER TAPE READER MANUALS | | | | |
| CE306 (224-2A) CARD READER REF/CE MANUAL (EXCEPT PARTS LIST) | 49593000 | C | 22 | 06.40 |
| PARTS LIST (A01/B01 AND ABOVE) CE MANUAL | 49593100 | C | 22 | 02.95 |
| CE601-A (SP. OPT. 60031) 3447 CARD READER MODIF REFERENCE/CE MANUAL (45 COLUMN CARDS) | 60250900 | A | 22 | 03.15 |
| CE602-A (SP. OPT. 60031) 3649 CARD READER MODIF REF/CE INFO (USE CE601-A) (45 COLUMN CARDS) CE601-A | | | | |
| CF104-A (1777-1/2, 90123-1, 90124-1) PAPER TAPE PUNCH - STEEL CE INFO (USE CE305-A/B) ** REFER ALSO TO VENDOR MANUALS, CATALOG SEC. 4 FOR NCR EM-B3 MANUALS | | | | |
| CF105 (226-1) CARD PUNCH REF/CE MANUAL (EXCEPT PARTS LIST) | 49591900 | D | 22 | 10.80 |
| PARTS LIST CE MANUAL | 49592900 | C | 22 | 06.65 |
| CF106-A (90123-2, 90124-2) PAPER TAPE PUNCH - TUNGSTEN CARBIDE CE INFO (USE CE305-A/B) ** REFER ALSO TO VENDOR MANUALS, CATALOG SEC. 4 FOR NCR EM-B3 MANUALS | | | | |
| CF109-A/B () CARD PUNCH CE MANUAL | 60366700 | 01 | 22 | 11.70 |
| CF5A5-A/B/C (90125-1) PAPER TAPE STATION - COMMON CONTROL | | | | |
| CF504 (430) CARD READER/PUNCH REF/CE MANUAL (EXCEPT PARTS LIST) (INCLUDES PMI/PMP) | 40864000 | G | 22 | 07.35 |
| PARTS LIST CE MANUAL | 40864800 | E | 22 | 05.95 |
| CF507-A/B (9230) CARD READER/PUNCH REF/CE MANUAL (EXCEPT PARTS LIST) VOLS I-II | 60286200 | F | 22 | 12.05 |
| PARTS LIST CE MANUAL | 49597000 | E | 22 | 10.95 |
| CF508-A/B/C (1777-1/2) COMMON CONTROL CE INFO (USE CE305-A/B) | | | | |
| CF511-A/B CARD READER/PUNCH CE MANUAL | 60318700 | A | 22 | 16.85 |
| CF8A1-A (90126-1) ENCLOSURE KIT | | | | |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------|----|----|-------|
| CF801-A () PAPER TAPE PUNCH - TUNGSTEN CARBIDE OPTION CE INFO (USE CE305-A/B) | | | | |
| CH102-A/B CARD PUNCH PART IDENTIFICATION MANUAL | 49762400 | A | 22 | 12.35 |
| CJ1A5 OCR DOCUMENT READER DIAGRAMS VOL 2 HARDWARE REF/CE MANUAL | 87951000 | | 22 | 04.80 |
| CJ103-A/CW146-A OCR DOCUMENT READER WIRE LIST CE MANUAL (CJ103-A ONLY) | 70609600 | A | 22 | 21.80 |
| GEN.DESC., OPER., MAINT., MAINT. AIDS | 40827600 | A | 22 | 06.55 |
| THEORY OF OPERATION DIAGRAMS CE MANUAL | 41241900 | B | 3 | 14.70 |
| PARTS DATA CE MANUAL | 40863200 | B | 22 | 04.15 |
| CJ112 PAGE READER G-H (CS/N151-200) PARTS LIST CE MANUAL | 41241400 | B | 3 | 10.35 |
| DIAGRAMS OF MANUAL | 70601700 | E | 22 | 17.85 |
| PAGE READER REFERENCE CE MANUAL | 40819300 | A | 22 | 10.35 |
| WIRE LISTS (LOGIC W/L) VOL.4 CE MANUAL | 70602100 | C | 22 | 20.90 |
| CJ115, CJ1A4 OCR DOCUMENT READER GEN DESC., OPER., THEO OF OPER., MAINTENANCE CE MANUAL | 48883700 | A | 3 | 15.90 |
| CJ119 PAGE READER DIAGRAMS VOL 2 HARD.REF/CE | 48997900 | B | 22 | 07.15 |
| CJ122 MAINTENANCE CE MANUAL | 48430080 | C | 3 | 21.30 |
| DIAGRAMS VOLUME 2, PART 3, CE MANUAL | 48430045 | B | 22 | 18.30 |
| PARTS DATA VOLUME 3 CE MANUAL | 48430090 | B | 3 | 06.60 |
| PARTS DATA S/N 103-129 VOL 38 REF/CE MANUAL | 48430087 | D | 3 | 08.55 |
| PAGE READER VOL 2 CE MANUAL | 48948100 | B | 3 | 19.95 |
| 959 PAGE AND DOCUMENT READER SYST. OP. GUIDE | 91669100 | A | 22 | 02.75 |
| CJ122 PAGE AND DOCUMENT READER (S/N 151-175) DIAGRAMS, RECOGNITION RACK, HARDWARE REF/ CE MANUAL (VOL II, PART II) | 48948200 | B | 3 | 05.20 |
| CJ127 OCR DOCUMENT READER DIAGS. HR/CE MAN V2 | 87971600 | 01 | 22 | 02.75 |
| PARTS DATA HARDWARE/CE MANUAL VOL 3 | 87971700 | 01 | 22 | 02.65 |
| HARDWARE REFERENCE/C.E.MANUAL | 87906700 | A | 22 | 01.90 |
| SYSTEMS OPERATORS GUIDE (SEE 929 DOC. READER | | | | |
| CJ508-A ANST OCR-A AND E13-B CHARACTER SET DPT RECOGNITION LOGIC, DIAGRAMS, ASSERT-NEGATE DIAGRAMS AND PARTS DATA CE MANUAL | 87829800 | A | 3 | 05.50 |
| CJ520 OCR DOCUMENT READER LOGIC RACK HARDWARE MAINTENANCE MANUAL VOL I | 87911800 | A | 22 | 13.30 |
| CK501-A/B (1711-3, 90111-1) TELETYPEWRITER | | | | |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------------------------------|----------------|----|-------------------------|
| CE INFO (USE AB103-A) ** REFER ALSO TO VENDOR MANUALS, CATALOG SEC. 4 FOR TELETYPE MANUALS (35KSR) | | | | |
| CK502-A/B (1713-3, 90113-1) TELETYPEWRITER CE INFO (USE AB103-A) ** REFER ALSO TO VENDOR MANUALS, CATALOG SEC. 4 FOR TELETYPE MANUALS (35ASR) | | | | |
| CL106A/B ELECTRONICS EQUIP., CL107A/B PRINT HEAD EQUIPMENT | 44976700 | B | 22 | 02.00 |
| CL308A/B LINE PRINTER EQUIP PARTS DATA CE MAN. PRINTER EQUIPMENT CE MANUAL | 44895600 47967000 | A F | 22 | 02.45 08.25 |
| CL309 A/B LINE PRINTER EQUIP PARTS DATA PRINTER EQUIPMENT CE MAN. (USE CL308-A/B) | 44895700 | A | 22 | 02.70 |
| CL320 MEDIUM SPEED BATCH TERMINAL LINE PRINTER EQUIPMENT OPERATION REFERENCE MANUAL DIAGRAMS AND WIRE LIST FIELD SERVICE MANUAL PARTS IDENTIFICATION MANUAL | 50583100 50583200 50584300 | A B B | 22 | 01.55 04.35 03.55 |
| CL4B4-A/B/C/D USE 9322 LINE PRINTER | | | | |
| CL401-A/B, CL402-A/B (222) LINE PRINTER CONTROLLER REF/CE MANUAL PARTS DATA CE MANUAL PRINTER EQUIPMENT CE MAN. (USE CL308-A/B) | 47966700 44895800 | E A | 22 | 04.95 02.00 |
| CL403A/B AND CL4044/B LINE PRINTER CONT EQ MAN PRINTER EQUIPMENT CE MAN. (USE CL308-A/B) | 44978800 | A | 22 | 03.10 |
| CL408-A/B USE 9322 LINE PRINTER | | | | |
| CL503 LINE PRINTER EQUIPMENT HSBT PARTS IDENTIFICATION MANUAL GENERAL DESCRIPTION, INSTALLATION AND CHECKOUT, MAINT./MAINT AIDS REF MANUAL DIAGRAMS AND WIRE LIST VOL II CE MANUAL | 50583400 50581800 50583300 | 01 01 01 | 22 | 05.40 05.10 04.35 |
| CL6A1 (9360) LINE PRINTER PARTS DATA CE INFO - SERIES A/C23-A/C28 | 50578500 | A | 22 | 05.00 |
| CL601 (512) LINE PRINTER EQUIPMENT REF/CE MANUAL DIAGRAMS AND WIRE LIST - SERIES A23-A28, B23-B28, C23-C28, D23-D28 | 44980100 50578100 | D A | 22 | 01.70 03.45 |
| CL601, CL6A1A LINE PRINTER EQUIP DIAGRAMS AND WIRE LIST DIAGRAMS, WIRE LIST MOD A01-A07 CE MANUAL | 44855700 44855500 | C D | 22 | 02.50 05.80 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------------------|------------|----|----------------|
| PARTS DATA CE MANUAL - SERIES A08-A22 | 44855600 | C | 22 | 04.35 |
| PARTS DATA CE MANUAL - SERIES A/D23-A/D28 | 50577700 | A | 22 | 10.10 |
| CL835 LINE PRINTER EQUIP. PARTS DATA CE MAN. REF/CE MANUAL | 44980900 44980700 | C C | 22 | 03.40 03.00 |
| CL835 LINE PRINTER EQUIPMENT CE MANUAL | 44980800 | C | 22 | 02.25 |
| CL896 LOW SPEED BATCH TERMINAL LINE PRINTER EQUIPMENT REFERENCE MANUAL | 50582300 | B | 22 | 01.85 |
| DIAGRAMS, WIRE LIST FIELD SERVICE MANUAL | 50582400 | B | 22 | 03.15 |
| PARTS IDENTIFICATION MANUAL | 50583900 | B | 22 | 02.70 |
| CR105-A (3504-1) DESK CONSOLE GENERAL DESCRIPTION, DIAGRAMS (USE AC104-A) MAINT. AIDS; 50-PAK STRIP TABS/MAPS (USE AC104-A) PARTS DATA (USE AC104-A) | | | | |
| CR106-A (3514-1/2/3/4) DESK CONSOLE GENERAL DESCRIPTION, DIAGRAMS (USE AC106-A) PARTS DATA (USE AC104-A) | | | | |
| CV403-A DIGISCRIBE OPTION (10892) REPAIR CENTER CE MANUAL ON SITE MAINTENANCE MANUAL | 62996000 62995900 | A-0 A-0 | 22 | 04.10 03.20 |
| CW120-A/121-A LINE PRINTER ADAPTER KIT REF/CE | 82140800 | A01 | 34 | 03.00 |
| CW123-A (1777-2, 90127-1) PUNCH VALIDATION FEATURE CE INFO (USE CE305-A/B) | | | | |
| CW126-E/F HANDPRINT UNIT HARDWARE REF/CE MANUAL | 48991800 | A | 3 | 34.80 |
| DIAGRAMS VOL 2 HARDWARE REFERENCE MANUAL | 48143981 | B | 3 | 30.15 |
| DIAGRAMS VOL 2B HARDWARE REFERENCE MANUAL | 48911900 | A | 3 | 13.80 |
| CW140-A ISO-OCR-B NUMERICS FONT OPTION GEN. | 48996300 | A | 3 | 02.95 |
| CW195 OCR-B PLUGGABLE FONT OPTION GENERAL DESCRIPTION, INSTALLATION AND CKOUT DIAGRAMS HARDWARE REF/CE MANUAL | 91662900 | A | 22 | 06.15 |
| CW207 HANDPRINT UNIT MODEL A01 HARDWARE MAINTENANCE MANUAL VOLUME 1 | 91558900 | A | 22 | 44.40 |
| DA101-A (1544-2) DIGITAL INPUT UNIT REF/CE MANUAL | 39909502 | B | 22 | 03.35 |
| DA101-B (1544-1) DIGITAL INPUT UNIT REF/CE INFO (USE DA101-A) | | | | |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|----|----|-------|
| DA401-A (1544-4) DIGITAL INPUT UNIT REF/CE INFO (USE DA101-A) | | | | |
| DA401-B (1544-3) DIGITAL INPUT UNIT REF/CE INFO (USE DA101-A) | | | | |
| DA502-E () DIGITAL OUTPUT UNIT REF/CE MANUAL DESC., DTAGS, W/L, PARTS DATA CE MANUAL | 39909503 | B | 22 | 03.00 |
| DC110-A (6641-A) ECS/MASS STORAGE ADAPTER CE MANUAL | 60222100 | K | 22 | 06.00 |
| DC111-A (3507-1) COMMUNICATION CHANNEL GENERAL DESCRIPTION, DIAGRAMS ** USE AC104-A IF 3504 COMPUTER SYSTEM ** USE AC106-A IF 3514 COMPUTER SYSTEM PARTS DATA (USE AC104-A) MAINT. AIDS 50-PAK STRIP TABS/MAPS (USE AC104-A) | | | | |
| DC118-A (1775-1, 90105-1) A/Q INTERRUPT CHAN. CE INFO (USE AB103-A) | | | | |
| DC119-A (1779-1, 90109-1) CHARACTER HANDLING CE INFO (USE AB103-A) | | | | |
| DC120-A (1773-1, 90106-1) DIRECT STORAGE ACCESS CHANNEL CE INFO (USE AB103-A) | | | | |
| DC135-A (6642-1, 7030-XX) DISTRIBUTIVE DATA PATH CE MANUAL | 60369400 | D | 22 | 11.95 |
| DC136-A (1773-1) DIRECT STORAGE ACCESS CHANNEL CE INFO (USE AB103-A) | | | | |
| DC137-A (1775-1) A/Q INTERRUPT DATA CHANNEL CE INFO (USE AB103-A) | | | | |
| DC145-A/B (6642-2) DISTRIBUTIVE DATA PATH HARDWARE MAINT. MANUAL | 60425800 | A | 22 | 62.75 |
| DC211-A (6684-A) DATA CHANNEL CONVERTER CE MANUAL | 60125000 | AZ | 22 | 04.70 |
| DC212-A (6684-2) CODE CONVERSION FOR 6684-1 CE INFO (USE DC211-A) REF INFO (USE 6681-R/C/D) | | | | |
| DC215-A/B DATA TRANSFER BUFFER GEN.DESC,OPER AND PROG,INSTALL,CHKOUT,THEO,OF OPER,DIAGS, | 65692300 | A | 22 | 06.00 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------|---|----|-------|
| DIAGNOSTIC, MAINT AIDS, P/L, W/L, EQ SUM, REF/CE | | | | |
| DC216-A (SP. OP. 60128) DATA CHANNEL CONVERTER REF/CE MANUAL | 60299902 | C | 22 | 02.20 |
| DC220/DC221-A 1700 A/Q DSA ADAPTERS HARDWARE REFERENCE/CE MANUAL | 39392700 | C | 22 | 07.30 |
| DC401-A (SP.OP.65075) MASS STORAGE EXTENDER CE MANUAL | 60392600 | C | 22 | 08.80 |
| DE101-A MULTIPLEX DATA CHANNEL GEN DESC, THEORY OF CP, DIAGS, MAINT CE MAN. | 39524000 | A | 22 | 14.35 |
| DF3A1-A (1555-1/4) RELAY OUTPUT UNIT REF/CE MANUAL | 39909509 | A | 22 | 03.25 |
| DJ101-A, DJ115-A DATA SET ADAPTERS CE MANUAL | 41600600 | B | 22 | 02.45 |
| DJ110-A (311-2) DATA SET ADAPTER THEORY OF OPERATION, INSTALLATION/CHECKOUT DIAGRAMS, MAINT., MAINT. AIDS, PARTS DATA, CE MANUAL | 41603200 | C | 22 | 11.05 |
| WIRE LIST, EQ SUMMARY CE MANUAL | 41608100 | A | 22 | 05.85 |
| DJ111-A (311-2) DATA SET ADAPTER CE INFO (USE DJ110-A) | | | | |
| DJ112-A-B TRANSCEIVER CE MANUAL | 41605400 | B | 22 | 03.30 |
| DJ113-A/B (358-2) TRANSCEIVER CE MANUAL (INCLUDES PMI/PMP) | 41606300 | E | 22 | 04.40 |
| DJ114-A/B/C/D (358-3/4) TRANSCEIVER CE MANUAL | 41601900 | E | 22 | 04.90 |
| DJ115-A (327-2) DATA SET ADAPTER CE INFO (USE DJ101-A) | | | | |
| DJ122-A (361-4) COMMUNICATIONS ADAPTER CE MANUAL | 41609700 | F | 22 | 11.55 |
| DJ130-A (792-10) AUTOMATIC CALLING ADAPTER CE INFO (USE FJ424-A/B/C) | | | | |
| DJ140-A/B (124-1) SYNCHRONOUS MODEM CE MANUAL | 41613400 | F | 22 | 01.50 |
| DJ141-A (101-1) SYNCHRONOUS MODEM CE MANUAL | 41613200 | E | 22 | 01.40 |
| DJ142-A (361-1/3) COMMUNICATIONS ADAPTER REF INFO (USE 361-1) | | | | |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------|----|----|-------|
| CE MANUAL | 41612100 | H | 22 | 03.30 |
| DJ143-A (361-1/2) COMMUNICATIONS ADAPTER REF INFO (USE 361-1) CF INFO (USE DJ142-A) | | | | |
| DJ144-A (361-5) COMMUNICATIONS ADAPTER CE MANUAL | 41611700 | J | 22 | 12.75 |
| DJ145-A (361-6) SYNCHRONOUS COMMUNICATIONS ADAPTER CE MANUAL | 41611900 | M | 22 | 05.35 |
| DJ146-A (361-7) COMMUNICATIONS ADAPTER CE MANUAL | 41612300 | A | 22 | 03.20 |
| DJ151-A DATA SET ADAPTER REFERENCE/CE MANUAL | 60344700 | A | 22 | 05.85 |
| DJ152-A DATA SET ADAPTER REF/CF INFO (USE DJ151-A) | | | | |
| DJ604-A (792-2) DATA SET ADAPTER CF INFO (USE FJ424-A/B/C) | | | | |
| DJ605-A (792-3) DATA SET ADAPTER CF INFO (USE FJ424-A/B/C) | | | | |
| DJ607-A (792-1) DATA SET ADAPTER CF INFO (USE FJ424-A/B/C) | | | | |
| DJ805-A/B (304-1) COMMUNICATIONS MULTIPLEXER CE MANUAL | 13796500 | G | 22 | 04.30 |
| DJ808-A (364-1/2) COMMUNICATIONS MULTIPLEXER CE MANUAL | 41611000 | J | 22 | 02.35 |
| DJ813-A (364-3) COMMUNICATIONS MULTIPLEXER CE MANUAL | 41612600 | 02 | 22 | 04.80 |
| DJ814-A (364-4/5) COMMUNICATIONS MULTIPLEXER CE MANUAL | 41612800 | F | 22 | 07.10 |
| DJ815-A ASYNCHRONOUS COMMUNICATIONS CONTROLLER AND DISTRIBUTION PANEL CE MANUAL | 89638300 | 02 | 22 | 05.35 |
| DK501-A (ST. OPT. 10128) DUAL MODE OPTION CE MANUAL | 41603100 | D | 22 | 03.00 |
| DK502-A (ST. OPT. 10127) EXPANDED MEMORY OPTION CE MANUAL | 41611200 | D | 22 | 03.00 |
| DK509-A (362-1/2) TELEGRAPHIC LEVEL CONVERTER | | | | |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------|---|----|-------|
| CE MANUAL | 41610400 | G | 22 | 04.10 |
| DK516-A (7700) MUX INCREMENT-1 CE INFO (USE AC113-A/B OR AA121-A AND AD102-A) | | | | |
| DK518-A (7681-1) DATA CHANNEL CONVERTER CE MANUAL | 60355900 | F | 22 | 06.35 |
| DK520-A (7700) MUX INCREMENT-2 CE INFO (USE AC113-A/B OR AA121-A AND AD102-A) | | | | |
| DK526-A (CYBER 1000) MEDIUM SPEED LINE CONTROLLER HARDWARE REFERENCE MANUAL | 74606800 | A | 22 | 09.70 |
| DK605-A (1595-10/11) SERIAL I/O UNIT REF/CE MANUAL | 39909507 | B | 22 | 03.90 |
| DK605-B (1595-20/21) SERIAL I/O UNIT REF/CE INFO (USE DK605-A) | | | | |
| DN124-A USE 1590-3 | | | | |
| DT117-A (6500-A/B/C WITH ECS) ADDS ECS CAPABILITY TO 6500-A/B/C (USE AT195-A MANUAL) | | | | |
| DT122-A (7683-1) REMOTE CHANNEL COUPLER REF/CE MANUAL | 60296200 | H | 22 | 04.60 |
| DT137-A (791-1/3/4) NORMAL OUTPUT CHANNEL CE INFO (USE FJ424-A/B/C) | | | | |
| DT138-A (791-1/3/4) NORMAL INPUT CHANNEL CE INFO (USE FJ424-A/B/C) | | | | |
| DT139-A (791-1) CHANNEL EXPANDER RECEIVERS AND TRANSMITTERS CE INFO (USE FJ424-A/B/C) | | | | |
| DT141-A () 1700 A/Q COUPLER CE INFO (USE FF104-A) | | | | |
| DT143-A () ADDS ECS CAPABILITY TO AA105-A OR 641X-D. (USE MANUALS UNDER AT194-A) | | | | |
| DT158-A (7611-10) PL COUPLER CE MANUAL | 60356300 | D | 22 | 05.00 |
| DT160-A () TERMINAL COUPLER CE MANUAL | 60318500 | A | 22 | 08.65 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------|---|----|-------|
| DT174-A (ST.OP.10266-1/2/3, 10280-1/2/3) DOP REGISTER INCREMENT (2,3 OR 4 PORT) CE INFO (USE DC135-A) | | | | |
| DT175-A/B (7077-1) 6000 PL SAC COUPLER CE MANUAL | 60352300 | C | 22 | 05.90 |
| DT194-A (ST.OP. 10293-1) CHANNEL MODIFICATION | | | | |
| DT196-A (ST.OP. 10293-1/2) CHANNEL MODIFICATON | | | | |
| DT204-A (SP.OP. 60081-A) ECS INTERFACE LOGIC FOR 6400-A/B/C CENTRAL COMPUTER OR AUGMENTED I/O BUFFER AND CONTROLLER TO 6640 ECS USE 6400-A/B/C UNLESS AT197-A AND AT195-A OR AT196-A AND AT195-A ARE INSTALLED, IF SO SEE AT195-A. | | | | |
| DT205-A (SP.OP. 60081-B) ECS INTERFACE LOGIC MAY BE INSTALLED IN 6400-D OR AA105. USE STANDARD MANUALS FOR THAT SYSTEM UNLESS AT194-A IS INSTALLED. IN THIS CASE SEE MANUALS LISTED UNDER AT194-A | | | | |
| DT208-A (7611-10) PL COUPLER CE INFO (USE DT158-A) | | | | |
| DT209-C (7054-1/2) 6000 COUPLER REF/CE MANUAL | 60364100 | R | 22 | 16.10 |
| DT209-D (7021-1/2) 6000 COUPLER | | | | |
| DT210-A (7654-1) 7000 COUPLER REF/CE MANUAL | 60364200 | C | 22 | 24.40 |
| DT210-B (7622-1/2) 7000 COUPLER REF/CE INFO (USE DT210-A) | | | | |
| DT220-A (7054-2, ST.OP 10285-1) DUAL ACCESS OPTION REF/CE INFO (USE DT209-C) | | | | |
| DT220-B (7054-2) DUAL ACCESS OPTION REF/CE INFO (USE FA719-A/B/C/D COUPLER MAN) | | | | |
| DT220-C (7054-22/42) SECOND CHANNEL FEATURE REF/CE INFO (USE FA722-A/B) | | | | |
| DT221-A () REGISTER CE INFO (USE DC145-A/B) | | | | |
| DT716-A (7054-41) DOUBLE DENSITY OPTION | | | | |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------|---|----|-------|
| CE INFO (USE FA722-A/B) | | | | |
| DW105-A (CYBER 1000) THREE-BAY EXCHANGE UNIT HARDWARE MAINTENANCE MANUAL | 74720400 | A | 22 | 09.00 |
| DW110-A (CYBER 1000) TWO-BAY EXCHANGE UNIT HARDWARE MAINTENANCE MANUAL | 74717600 | A | 22 | 09.15 |
| DW111-A USE DW105-A | | | | |
| DY107/8/9/10-A (CYBER 1000) LINE MODULE EXTENSION CABINET HARDWARE MAINTENANCE MANUAL | 74724500 | A | 22 | 06.40 |
| DY120-A (CYBER 1000) MAGNETIC TAPE CONTROLLER HARDWARE MAINTENANCE MANUAL | 74607500 | B | 22 | 08.95 |
| DY121-A (CYBER 1000) FAST DISK CONTROLLER HARDWARE MAINTENANCE MANUAL | 74691800 | A | 22 | 09.00 |
| DY122-A (CYBER 1000) 3000 SERIES CONTROLLER- ADAPTER HARDWARE MAINTENANCE MANUAL | 74660300 | A | 22 | 08.75 |
| DY123-A (CYBER 1000) 1700 SERIES CONTROLLER- ADAPTER HARDWARE MAINTENANCE MANUAL | 74675500 | A | 22 | 05.35 |
| DY124-A (CYBER 1000) CONTROLLER EXTENSION CAB. HARDWARE MAINTENANCE MANUAL | 74720500 | A | 22 | 05.05 |
| DY127-A (CYBER 1000) HIGH-SPEED LINE CONTROL HARDWARE MAINTENANCE MANUAL | 74664300 | A | 22 | 10.80 |
| DY128-A (CYBER 1000) DISK PACK CONTROLLER HARDWARE MAINTENANCE MANUAL | 73361200 | B | 22 | 07.15 |
| DY129-A USE DY124-A | | | | |
| EA102-A (1525-2) ANALOG TO DIGITAL CONVERTER GEN DESC, DIAGS, W/L, MAINT CE MANUAL | 39473200 | A | 22 | 04.40 |
| EA309-A (1525-3) ANALOG TO DIGITAL CONVERTER REF/CE MANUAL | 39909506 | B | 22 | 04.00 |
| EB201-A/EB202-A (DA-1) THIRTY TWO CHANNEL ELEVEN BIT DAC GEN DESC, INSTALLATION/CHECKOUT, DIAGS, W/L, MAINTENANCE, PARTS DATA, REF/CE MANUAL | 39744900 | A | 22 | 03.90 |
| EB301-A/D FOUR CHANNEL DIGITAL-TO-ANALOG CONVERTER GEN.DESC.,OP AND PROGRAMMING,INSTALLATION | 88981100 | A | 22 | 03.90 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------------------|--------|----------|----------------|
| AND CHECKOUT, THEORY OF OPERATIONS, DIAGRAMS, MAINTENANCE, MAINT. AIDS, PARTS DATA HARDWARE REFERENCE/CE MANUAL | | | | |
| ED105-A (1501-10) ANALOG INPUT MULTIPLEXER REF/CE MANUAL | 39909504 | B | 22 | 06.35 |
| ED106-A (1501-11) ANALOG INPUT MULTIPLEXER EXPANDER REF/CE INFO (USE ED105-A) | | | | |
| EE601-A TAPE CONTR AND MONITOR UNIT (TCM) HARDWARE REFERENCE/CE MANUAL | 39222600 | A | 22 | 04.90 |
| EL101-A (1750-1) COMPUTER INTERFACE UNIT REF/CE MANUAL | 88980100 | C | 22 | |
| EL102-A (1750-2) COMPUTER INTERFACE EXPANDER REF/CE INFO (USE EL101-A) | | | | |
| FA102-A (1733-1) DISK STORAGE CONTROLLER CE MANUAL | 60400100 | F | 22 | 18.10 |
| FA103-A (7639-2) MASS STORAGE CONTROLLER HARDWARE MAINTENANCE MANUAL | 60427600 | B | 22 | 47.45 |
| FA202-A (7639-1/2) MASS STORAGE CONTROLLER HDWE MAINT INFO (USE FA103-A) | | | | |
| FA203 CONTROLLER | | | | |
| MTCPODIAGNOSTICS USERS CE MANUAL | 83315600 | A | 22 | 07.60 |
| FLEXIBLE DISK DRIVE CE MANUAL | 83315700 | A | 22 | 04.50 |
| MICRODIAGNOSTIC DESCRIPTIONS CE MANUAL | 83315800 | A | 22 | 03.85 |
| THEORY OF OPERATION CE MANUAL | 83316100 | A | 22 | 14.25 |
| PARTS DATA CE MANUAL | 83316200 | A | 22 | 08.75 |
| HARDWARE MICROPROGRAM CE MANUAL | 83316300 | A | 22 | 07.30 |
| DIAGNOSTIC MICROPROGRAM CE MANUAL | 83316400 | A | 22 | 18.70 |
| DUAL ACCESS FEATURE MICROPROGRAM CE MANUAL | 83316600 | A | 22 | 18.60 |
| FA401-A/B (7021-1) 1X8 MAG TAPE CONTROLLER HARDWARE REFERENCE MANUAL CE MANUAL - VOL 1 | 60404000 60404100 | C G | 22 22 | 03.75 37.90 |
| FA402-A/B (7021-2) 2X8 MAG TAPE CONTROLLER HARDWARE REF INFO (USE FA401-A/B) | | | | |
| FA403-A/B (7622-1) 1X8 MAG TAPE CONTROLLER HARDWARE REF INFO (USE FA401-A/B) | | | | |
| FA404-A/B (7622-2) 2X8 MAG TAPE CONTROLLER HARDWARE REF INFO (USE FA401-A/B) | | | | |
| FA405-A/B (8194) MAGNETIC TAPE CONTROLLER | | | | |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|-----|----|-------|
| CE MANUAL | 13795900 | G | 22 | 05.05 |
| FA407-A7 OR 9 TRACK MAGNETIC TAPE CONTROLLER, OPER., MAINT. INSTR. MANUAL | 84942200 | | 22 | 05.10 |
| FA414-A/B (3121-A/B) MAGNETIC TAPE CONTROLLER CE MANUAL ** REFER ALSO TO CATALOG SEC. 2 FOR 609 TAPE TRANSPORT CE MANUALS | 60210900 | K,L | 22 | 06.25 |
| FA416-B (3518-1/2/3) MAG TAPE CONTROLLER CE MANUAL | 60289100 | BG | 22 | 16.80 |
| FA417-B (3518-2/3, 3528-2/3) MAGNETIC TAPE CONTROLLER CE INFO (USE FA416-B) | | | | |
| FA418-A (3528-1/2/3) MAGNETIC TAPE CONTROLLER CE INFO (USE FA416-B) | | | | |
| FA419-A (CYBER 1000) SEE DY120-A | | | | |
| FA420-B (3518-3, 3528-3) MAG TAPE CONTROLLER CE INFO (USE FA416-B) | | | | |
| FA423-A () MAGNETIC TAPE CONTROLLER REF/CE MANUAL (INCLUDES PMI/PMP) ** REFER ALSO TO CATALOG SECTION 2 FOR 604 AND 607 MAG TAPE TRANSPORT MANUALS | 60291400 | F | 22 | 10.05 |
| FA428-A (7618-1, 7629-1) 1X8 MAGNETIC TAPE CONTROLLER CE MANUAL | 60321100 | U | 22 | 37.60 |
| FA429-A (7628-1, 7629-2) 2X8 MAGNETIC TAPE CONTROLLER CE INFO (USE FA428-A) | | | | |
| FA434-A/B (7622-1, 7021-1) 1X8 MAG TAPE CONTROL CE MANUAL HARDWARE REF INFO (USE FA401-A/B) | 60365200 | D | 22 | 23.40 |
| FA438-A/B (7622-2, 7021-2) 2X8 MAG TAPE CONTROL CE INFO (USE FA434-A/B) HARDWARE REF INFO (USE FA401-A/B) | | | | |
| FA442 MAGNETIC TAPE CONTROLLER CE MANUAL | 89637700 | 02 | 22 | 10.05 |
| FA444-A/B (7021-21) MAG TAPE CONTROLLER HOWE MAINT. MANUAL | 60438500 | A | 22 | 41.50 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|----|----|-------|
| FA445-A/B (7021-2?) MAG TAPE CONTROLLER MAINT INFO (USE FA444-A/B) | | | | |
| FA446-A MTT (LCTT) CE MANUAL | 89769500 | 01 | 22 | 06.40 |
| FA601-A INTERIM DRUM CONTROLLER REF/CE MANUAL | 60232300 | B | 22 | 05.60 |
| FA7A3-A (OEM 9008-1) DISK CONTROLLER REF/CE INFO (USE 9008-1 CATALOG SEC 2) | | | | |
| FA7A4-A/B PLUG COMPATABLE CONTROLLER MICROPROGRAM CE MANUAL | 70614100 | D | 22 | 09.80 |
| WIRE LIST CE MANUAL | 70614000 | E | 22 | 11.55 |
| DIAGRAMS CE MANUAL | 70613900 | H | 22 | 05.40 |
| THEORY OF OPERATION | 70616700 | A | 22 | 04.50 |
| MAINTENANCE CE MANUAL | 70613800 | G | 22 | 05.10 |
| FA7A4-C/D, FV1A1-A TWO CHANNEL PLUG COMPATABLE CONTROLLER CE MANUAL | 70614200 | B | 22 | 06.25 |
| FA7A5-A/B/C/D PLUG COMPATABLE CONTROLLER MICRO PROGRAM CE MANUAL | 70621800 | B | 22 | 08.95 |
| DIAGRAMS CE MANUAL (INCLUDES FV1A4-A) | 70621600 | G | 22 | 07.25 |
| THEORY OF OPERATIONS CE MANUAL | 70621500 | A | 22 | 08.05 |
| WIRE LISTS CE MANUAL | 70621700 | D | 22 | 21.70 |
| GENERAL DESCRIPTION, INSTALLATION AND CHECK- OUT THEO OF OPER., WIRE LIST CE MANUAL | 70621900 | A | 22 | 15.50 |
| FA701-A CONTROLLER 7600 INTERIM DISK FILE SYS | 60232200 | D | 22 | 05.15 |
| FA704-A/B (3553-2) MASS STORAGE CONTROLLER CE MANUAL | 60266000 | AE | 22 | 20.35 |
| FA704-C (3553-2) MASS STORAGE CONTROLLER CE MANUAL | 60394700 | H | 22 | 36.50 |
| FA705-A (3553-1) MASS STORAGE CONTROLLER CE MANUAL | 60290000 | R | 22 | 12.05 |
| FA705-B (3553-1) MASS STORAGE CONTROLLER CE MANUAL | 60394600 | D | 22 | 35.95 |
| FA710-A/B/C/D (7054-1) DISK CONTROLLER HARDWARE REFERENCE MANUAL | 60364500 | G | 22 | 04.00 |
| CE MANUAL - VOL 1 AND 2 | 60364000 | N | 22 | 36.15 |
| FA710-E/F (7054-1) DISK CONTROLLER CE INFO (USE FA719-A CE MANUAL - 60405500) | | | | |
| FA716 CARTRIDGE DISK CONTROLLER CE MANUAL | 89638100 | 02 | 22 | 05.65 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|--|--------------------------------------|--|--|
| FA719-A/B/C/D (7054-1/2) DISK STORAGE CONTROLLER CE MANUAL (6000 COUPLER) CE MANUAL VOLS 1 AND 2 | 60416400 60405500 | E G | 22 22 | 11.50 32.60 |
| FA720-A/B/C/D (7654-1) DISK STORAGE CONTROLLER CE MANUAL (ALSO USE FA719-A MANUAL - 60405500) | 60410000 | B | 22 | 11.00 |
| FA721 STORAGE CONTROL EIGHT VOLUME CAU FUNCTIONAL MICROPROGRAM CE MANUAL PREVENTIVE/CORRECTIVE MAINT, W/L, CE MAN V-2 DIAGRAMS VOLUME 2 CE MANUAL STANDARD DIAGNOSTICS MICROPROGRAM CE MANUAL INLINE DIAGNOSTICS MICROPROGRAM CE MANUAL 16 VOL. CAU FUNCTIONAL MICROPROGRAM MANUAL HARDWARE REFERENCE CE MANUAL PARTS DATA CE MANUAL | 83302100 83301900 83302000 83312100 83312000 83311900 83301800 83306000 | E E R C E E B F | 22 22 22 22 22 22 22 22 | 18.70 07.95 27.85 25.75 18.25 18.45 06.90 03.85 |
| FA722-A/B (7054-21/22/41/42) DISK STORAGE CONTROLLER HARDWARE MAINTENANCE MANUAL | 60428500 | J | 22 | 28.00 |
| FA802-A (7601-1, 7638-1) DISK/DRUM CONTROLLER REF INFO (USE 7638-1, CATALOG SECTION 2) CE MANUAL ** REFER ALSO TO BH405 MANUALS FOR DISK FILE DOCUMENTATION | 60287200 | N | 22 | 08.80 |
| FE107-A (1726-1) CARD READER CONTROLLER CE MANUAL | 60232000 | B | 22 | 07.80 |
| FE110-A (1729-2) CARD READER CONTROLLER CE MANUAL | 60269200 | G | 22 | 04.50 |
| FE119 CARD READER CE MANUAL | 89637500 | 03 | 22 | 03.15 |
| FE201-A (417-1) CARD PUNCH CONTROLLER REFERENCE/CE MANUAL | 60283600 | B | 22 | 06.95 |
| FE202-A/B (415-30) CARD PUNCH CONTROLLER REF/CE MANUAL | 60425600 | C | 22 | 20.90 |
| FE304-A (1728-A/B) CARD READER/PUNCH CONTROLLER CE MANUAL | 60224000 | M | 22 | 03.75 |
| FF103-A (1735) PAGE READER CONTROLLER CE MANUAL | 60237700 | H | 22 | 08.95 |
| FF104-A (955-1) PAGE AND DOCUMENT READER CONTROLLER | | | | |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|-----|----|-------|
| CE MANUAL | 60324700 | A | 22 | 12.10 |
| FF307-B (3555-1) LINE PRINTER CONTROLLER CE MANUAL | 60278800 | S | 22 | 20.40 |
| FF406-A/B/C (1736-1) UNIT RECORD READER CONTROLLER CE MANUAL | 60230200 | 06 | 22 | 08.80 |
| GEN DESC, FLOW CHARTS, PROGRAM LISTINGS CE MANUAL | 60283200 | A | 22 | 09.80 |
| FF510-A/B (3254) LINE PRINTER CONTROLLER CE MANUAL (INCLUDES PMI-PMP) | 60182400 | J | 22 | 11.00 |
| FF511-A/B (1742) LINE PRINTER CONTROLLER CE MANUAL (INCLUDES PMI/PMP) | 60183000 | H | 22 | 04.80 |
| FF516-A (1740) LINE PRINTER CONTROLLER CE MANUAL | 60223800 | J | 22 | 23.80 |
| FF524-A LINE PRINTER CONTROLLER GEN. DESC., OPERATION AND PROGRAMMING, INSTALL- ATION AND CHECKOUT, THEORY OF OPERATION, DIAGRAMS, MAINTENANCE, PARTS DATA, WIRE LISTS CE MANUAL | 89637300 | 04 | 22 | 03.00 |
| FF525 PRINTER SUBSYSTEM CENTRAL CONTROL UNIT LOGIC DIAGRAMS THEORY OF OPERATIONS | 22272500 | A | 34 | 09.55 |
| | 22272400 | A | 3 | 12.90 |
| FJ101-A (1717-1) 1700 AUTODIN INTERFACE THEORY OF OPERATION, INSTALLATION/CHECKOUT DIAGRAMS, MAINT., MAINT. AIDS, PARTS DATA, CE MANUAL | 41602200 | B | 22 | 03.95 |
| CARD PLACEMENT, EXPRESSION FILE, UNIVERSAL WIRE DATA LISTS, WIRE LISTS CE MANUAL | 41606400 | B,C | 22 | 04.85 |
| FJ103-A/B/C/D/E (1748-2) MULTIPLEXER CONTROLER THEORY OF OPERATION, INSTALLATION CHECKOUT, DIAGRAMS, MAINT., MAINT. AIDS, PARTS DATA, CE MANUAL | 41601700 | J | 22 | 04.35 |
| CARD PLACEMENT, LOGIC WIRING, WIRE LISTS, EQUATION SUMMARY CE MANUAL | 41603300 | E | 22 | 08.05 |
| FJ124-A USE 1590-3 | | | | |
| FJ411-A/B (6671) DATA SET CONTROLLER DIAGRAMS, CIRCUIT DESCRIPTION, PARTS LIST, CARD PLACEMENT, EQUATION SUMMARY, WIRE LISTS CE MANUAL | 60217400 | W | 22 | 27.00 |
| MAINTENANCE, MAINTENANCE AIDS CE MANUAL (INCLUDES PMI/PMP) | 60251300 | E | 22 | 16.25 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|-----|----|-------|
| FJ412-A/B/C (1747) DATA SET CONTROLLER THEORY OF OPERATION, INSTALLATION CHECKOUT DIAGRAMS, MAINTENANCE, MAINT. AIDS, PARTS DATA CE MANUAL | 13799100 | E | 22 | 04.05 |
| WIRE LISTS, EQUATION SUMMARY CE MANUAL | 13799200 | E | 22 | 03.40 |
| FJ413-A (313, 314, 317, 318) RECEIVE CONTROL UNIT REF INFO (SEE APPROPRIATE PRODUCT, CATALOG SECTION 2) CE MANUAL | 13798100 | G | 22 | 03.80 |
| FJ414-A (313, 314, 317, 318) SEND CONTROL UNIT REF INFO (SEE APPROPRIATE PRODUCT, CATALOG SECTION 2) CE INFO (USE FJ413-A) INSTRUCTION CARD | 60368000 | B | | 01.00 |
| FJ415-A (1717-1) AUTODIN INTERFACE UNIT THEORY OF OPERATION, INSTALLATION/CHECKOUT DIAGRAMS, MAINTENANCE, MAINT. AIDS, PARTS DATA CE MANUAL | 13797900 | B-E | 22 | 05.45 |
| CARD PLACEMENT, EXPRESSION FILE, UNIVERSAL WIRE DATA LIST, WIRE LISTS CE MANUAL | 41605600 | C | 22 | 10.30 |
| FJ424-A/B/C (791-1) LOCAL COMMUNICATIONS CONTROLLER CE MANUAL | 60321800 | T | 22 | 23.50 |
| FJ427-A (6671-1) DATA SET CONTROLLER MAINTENANCE, MAINT. AIDS CE INFO (USE FJ411-A/B) INSTALLATION/CHECKOUT, DIAGRAMS, PARTS DATA, WIRE LISTS, EQ. SUMMARY CE MANUAL | 60294500 | K | 22 | 11.90 |
| FJ430-A/B (7077-1) STORAGE ACCESS CONTROLLER CE MANUAL | 60316500 | D | 22 | 24.75 |
| FJ440-A (6671-3) DATA SET CONTROLLER CE MANUAL - VOLUME 1 | 60409200 | B | 22 | 34.15 |
| MAINTENANCE, MAINTENANCE AIDS CE MAN. VOL 2 | 60425100 | A | 22 | 18.55 |
| FJ601-A (3316-1, 3516-1) MULTIPLEXER CONTROLLER THEORY OF OPERATION, INSTALLATION/CHECKOUT DIAGRAMS, MAINTENANCE, MAINT. AIDS, PARTS DATA, WIRE LISTS CE MANUAL | 13796700 | K | 22 | 06.15 |
| CROSS TABS, LOGIC WIRING, EQ SUMMARY CE MAN. | 13798800 | H | 22 | 06.20 |
| TEST ROUTINE CE MANUAL | 41600300 | A | 22 | 01.35 |
| FJ605-A SYNCHRONOUS COMMUNICATIONS CONTROLLER AND DISTRIBUTION PANEL CE MANUAL | 89638500 | 01 | 22 | 04.20 |
| FL303-A TAGGED DATA BUS OUTPUT INTERFACES TDB/ | 39231200 | A | 22 | 02.05 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|---|----|-------|
| DSA INTERFERE-TDI TOB/DAC INTERFACE DAI HOWE REFERENC/CE MANUAL | | | | |
| FR101-B () BUFFER CONTROLLER REFERENCE MANUAL | 60275000 | C | 22 | 01.00 |
| CE MANUAL | 60278300 | H | 22 | 06.55 |
| FR113-A (731-10/12, 732-10/12) BUFFER CONTROLLER | | | | |
| CE MANUAL | 60335400 | M | 22 | 08.70 |
| DIAGNOSTIC REFERENCE MANUAL - VOLS 1/2/3 | 60400300 | D | 22 | 25.00 |
| MAINTENANCE CE MANUAL | 70621400 | F | 22 | 06.10 |
| IBM 360 BUFFER CONTROLLER DIAGNOSTIC LISTING | 60401600 | A | 22 | 02.80 |
| 23141/23142 MADCOP CE MANUAL | | | | |
| IBM 360 BUFFER CONTROLLER DIAGNOSTIC LISTING | 60401500 | A | 22 | 28.15 |
| 23141/23142 FODDER CE MANUAL | | | | |
| BUFFER CONTROLLER DIAGNOSTIC LISTINGS - | | | | |
| HSB 512 LINE PRINTER TEST (LP1) CE MANUAL | 60401700 | B | 22 | 03.95 |
| HSR 80X16 DRUM/DISPLAY TEST (DD2) CE MAN. | 60401800 | A | 22 | 09.45 |
| 200 NSEC MEMORY TEST (MY1) CE MANUAL | 60402100 | A | 22 | 01.20 |
| 200 NSEC MEMORY TEST (MY2) CE MANUAL | 60402200 | A | 22 | 01.00 |
| LSRT/MSRT DISPLAY/KEYBOARD/OPERATOR | 60402700 | C | 22 | 05.65 |
| CONSOLE TEST (DD6) CE MANUAL | | | | |
| 200 NSEC MEMORY TEST (BCM) CE MANUAL | 60402900 | A | 22 | 01.30 |
| FR114-A () CONSOLE DISPLAY CONTROLLER GEN DESC, DIAGRAMS, WIRE LISTS CE MANUAL | 60365700 | A | 22 | 09.60 |
| FT1A1-A (1547-1) EVENTS COUNTER UNIT REF/CE MANUAL | 39909508 | A | 22 | 05.35 |
| FT1A1-B (1547-2) EVENTS COUNTER UNIT REF/CE INFO (USE FT1A1-A) | | | | |
| FT103-A/B TRANSFER SWITCH CONTROLLER REF/CE INFO (USE 8271 - CATALOG SEC 2) | | | | |
| FT104-A TRANSFER SWITCH CONTROLLER REF/CE INFO (USE 8271 - CATALOG SEC 2) | | | | |
| FT111-A () POWER FAULT DETECTOR CE MANUAL | 60367400 | A | 22 | 05.05 |
| FV129-A (3516-1) MULTIPLEXER CONTROLLER ADAPTER UNIT CE MANUAL | 41608500 | C | 22 | 03.00 |
| FV138-A DISPLAY STATION ADAPTER KIT (EDIT) REF/CE INFO (USE FV135-A) | | | | |
| FV149-A (ST. OPT. 10194-2) ASCII HOLLERITH TO BCD CONVERSION KIT FOR THE 3447-B CARD READER CONTROLLER | | | | |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.

4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|-----|----|-------|
| REF INFO (USE 3248-A REF MAN, CATALOG SEC 2) CE MANUAL | 60292600 | D | 22 | 07.65 |
| FV150-A (ST. OPT. 10194-1) INTERNAL BCD TO ASCII HOLLERITH CONVERSION KIT FOR THE 3446-A/B CARD PUNCH CONTROLLER REF INFO (USE 3446-A/B REF MAN, CAT. SEC 2) CE MANUAL | 60292700 | C | 22 | 02.50 |
| FV156-A () 4K MEMORY CE MANUAL | 60309700 | B-G | 22 | 07.35 |
| FV165-A (791-2) EXPANSION UNIT CE INFO (USE FJ424-A/B/C) | | | | |
| FV216A SWITCH UNIT HARDWARE/REF CE MANUAL | 39368600 | A | 22 | 05.65 |
| FV217-A () INTERIM MEDIUM SPEED BATCH SUBSYSTEM CE INFO (USE DT160-A) | | | | |
| FV218-A/B (733-10) HSB SUBSYSTEM/TERMINAL CONTROLLER CE MANUAL | 60329700 | V | 22 | 23.20 |
| FV227-A/B (1739-1) CARTRIDGE DISK DRIVE CONTROLLER CE MANUAL | 60368500 | B | 22 | 07.50 |
| FV4A3 (1576) STALL ALARM UNIT | | | | |
| FV409-A (7611-10) DRUM AND DISPLAY LOGIC REFERENCE/CE MANUAL | 60318600 | D | 22 | 07.30 |
| FV410-A (7611-10) DRUM AND DISPLAY LOGIC REF/CE INFO (USE FV409-A) | | | | |
| FV433-A, FV434-A, FV435-A, FV436-A DRUM AND DISPLAY LOGIC REF/CE MANUAL | 60363300 | L | 22 | 05.45 |
| FV437-A (733-1XX) HSB SUBSYSTEM/TERMINAL RECEIVER/TRANSMITTER OPTION CE INFO (USE FV218-A) | | | | |
| FV444-A () POWER REGULATOR MODULE CE INFO (USE BB372-A) | | | | |
| FV497-A/FV613-A PHASE ENCODING FORMATTER CE MANUAL | 89796100 | 01 | 22 | 06.60 |
| FV498 (1576) STALL ALARM UNIT CII PRINT CARTRIDGE HARDWARE REFERENCE MAN | 91860200 | A | 22 | 01.65 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|---|----|-------|
| FV605 CONTROLLER ADAPTER UNIT | | | | |
| PARTS DATA CE MANUAL | 83306300 | C | 22 | 03.65 |
| GENERAL DESCRIPTION, THEORY OF OPERATION | 83306100 | B | 22 | 04.95 |
| PREVENTIVE/CORRECTIVE MAINTENANCE, DIAGRAMS, WIRE LISTS CE MANUAL | 83315400 | A | 22 | 21.10 |
| FV618-A CE INFO USE FV497 | | | | |
| GA103-A/B/C (ST. OPT. 10126) INTERVAL TIMER | | | | |
| THEORY OF OPERATION, INSTALLATION/CHECKOUT DIAGRAMS, MAINTENANCE, MAINT. AIDS, PARTS DATA CE MANUAL | 41601000 | C | 22 | 04.00 |
| WIRE LISTS, EQUATION SUMMARY CE MANUAL | 41602500 | C | 22 | 04.00 |
| GA104-A/B (ST. OPT. 10126) TIME OF DAY CLOCK CE MANUAL | 41602900 | B | 22 | 04.90 |
| GA107 LINE SYNCHRONIZED TIMING GENERATOR HARDWARE/REFERENCE MANUAL | 39359900 | A | 22 | 01.95 |
| GA128-A (1572-1) SAMPLE TIMING UNIT REF/CE MANUAL | 39909505 | C | 22 | 03.15 |
| GD104-A (90115-1) POWER SUPPLY - 400HZ CE INFO (USE AB103-A) | | | | |
| GD105-A (90115-1) POWER SUPPLY - 50HZ CE INFO (USE AB103-A) | | | | |
| GD106-A (90115-1) POWER SUPPLY - 60HZ CE INFO (USE AB103-A) | | | | |
| GD108-A/B (60130-1) LOOP CURRENT POWER SUPPLY REF/CE INFO (USE GH407-A/B) | | | | |
| GD306-A/B (364-1/4, 10193-1) POWER SUPPLY REF/CE INFO (USE GH407-A/B) | | | | |
| GE210-A/B (90115-4) FREQUENCY CONVERTER | | | | |
| GE226-A (7601-1) FREQUENCY CONVERTER CE INFO (USE MOTOR GENERATOR CE MANUAL - SEE MOTOR GENERATOR SETS, CATALOG SECTION 4) | | | | |
| GE232-A (7601-1, 7611-1/2) FREQUENCY CONVERTER CE INFO (USE MOTOR GENERATOR CE MANUAL - SEE MOTOR GENERATOR SETS, CATALOG SECTION 4) | | | | |
| GG105-A (303-1) COMMUNICATIONS EXPANSION UNIT CE MANUAL | 13799800 | B | 22 | 06.40 |
| GH104-A (350?) POWER MODULE | | | | |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|---|----|-------|
| CE INFO (USE BB313-A) | | | | |
| GH105-A/B/C (76XX) POWER DISTRIBUTION AND WARNING SYSTEM CE MANUAL | 60298400 | G | 22 | 05.25 |
| GH105-D (76XX) POWER DISTRIBUTION UNIT CE MANUAL | 60298600 | L | 22 | 10.30 |
| GH107-B/FD301-E MULTIPLEXER (MX-7A) GEN DESC, DIAGS, W/L, PARTS DATA CE MANUAL | 39660400 | B | 22 | 03.30 |
| GH107/ED301-F ANALOG MULTIPLEXER GEN DESC, W/L, PARTS DATA CE MANUAL | 39690100 | A | 22 | 04.50 |
| GH110-A/B () 2-TON CONDENSING UNIT ** REFER ALSO TO VENDOR MANUALS, CATALOG REFRIGERATION INFO (USE GH214-B) | | | | |
| GH214-A (7601-1,) TEN TON REFRIGERATION UNIT (WATER COOLED) CE MANUAL | 60298100 | F | 22 | 06.60 |
| GH214-B () 10-TON CONDENSING UNIT REFRIGERATION CE MANUAL | 60367300 | G | 22 | 09.35 |
| GH216-A (7611-1/2) 2 TON REFRIGERATION UNIT (AIR COOLED) CE INFO (USE GH214-A) | | | | |
| GH218-A (7611-1/2) 2 TON REFRIGERATION UNIT (WATER COOLED) CE INFO (USE GH214-A) | | | | |
| GH223-A (76-XXX) CONDENSING UNIT CE MANUAL | 60427800 | A | 22 | 10.30 |
| GH401-A (90114-1) CABINETY CE INFO (USE AB103-A) | | | | |
| GH407-A/B (362-1, 364-1, 364-4) GENERAL PURPOSE CABINET REFERENCE/CE MANUAL | 41614300 | E | 22 | 02.85 |
| GH408-A/B (7077-1) CENTRAL STORAGE CABINET CE MANUAL | 60316600 | F | 22 | 13.45 |
| GH417-A/B () CABINETY CE INFO (USE AB103-A) | | | | |
| GH427-A/B DESK CABINET HARDWARE MAINTENANCE MANUAL | 22261700 | A | 3 | 04.00 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|---|----|-------|
| GH428-A (173-X,174-X) USE AA107-A | | | | |
| GH432-A/B DESK CABINET HARDWARE REF/CE MANUAL | 91628700 | A | 22 | 04.30 |
| GH506-A (76-XXX) POWER DISTRIBUTION UNIT 60HZ CE INFO (USE AA106-A) | | | | |
| GH506-B (76-XXX) POWER DISTRIBUTION UNIT 50HZ CE INFO (USE AA106-A) | | | | |
| GJ1A1 (5560) POWERED FORMS STACKER GEN DESC., OPER, DIAGS, MAINT AIDS, PARTS DATA CE MAN. | 50580900 | C | 3 | 02.55 |
| GJ1A1-A/B-CIT POWERED FORMS STACKER REF/CE | 91860300 | A | 22 | 02.35 |
| GJ1A2 (5570) MANUAL FORMS STACKER GEN DESC., OPER, DIAGS, MAINT AIDS, PARTS DATA CE MAN. | 50582000 | C | 22 | 01.00 |
| GJ102-A (1778-1, 90122-1) PAPER TAPE READER HANDLER CE INFO (USE CE305-A/B) ** REFER ALSO TO VENDOR MANUALS, CATALOG SEC. 4 FOR REMEX TAPE SPOOLER CE MANUAL | | | | |
| GJ103-A/B (1778-2, 90124-1/2) PAPER TAPE PUNCH HANDLER CE INFO (USE CE305-A/B) SEC. 4 FOR NCR EM-B3 TAPE TRANSPORT CE MANUAL | | | | |
| GJ104 MANUAL FORMS STACKER GEN DESC, OPERATION DIAGRAMS, MAINTENANCE, PARTS DATA CE MAN | 50584100 | B | 22 | 01.35 |
| GJ105A/B POWERED FORMS STACKER GEN DESC., OPER, DIAGS, MAINT, MAINT AIDS, PARTS DATA CE MAN | 50583500 | C | 22 | 02.95 |
| GK102 (673) TAPE EXERCISER REF/CE MANUAL | 49803700 | A | 22 | 03.40 |
| GK111 (SP. OPT 65006) TAPE EXERCISER REF/CE MANUAL | 49803800 | A | 22 | 03.30 |
| GK153-A () DATA CHANNEL LONG LINE DRIVER CE INFO (USE AB103-A) | | | | |
| GK154-A () DATA CHANNEL LONG LINE DRIVER CE INFO (USE AB103-A) | | | | |
| GK181-A (76XX) I/O STATION CABINET MODIFICATION KIT CE INFO (USE GH105-D) | | | | |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------|---|----|-------|
| GL102 (686) MAGNETIC TAPE CERTIFIER GENERAL DESCRIPTION, OPERATION, INSTALLATION CHECKOUT, MAINT. CE MANUAL (INCLUDES PMI/PMP) | 40867500 | C | 22 | 14.40 |
| THEORY OF OPERATION, DIAGRAMS, W/L CE MANUAL | 40867700 | G | 22 | 06.45 |
| PARTS LIST (A04, B04 AND ABOVE) CE MANUAL | 41240600 | C | 22 | 02.95 |
| OPERATORS CE MANUAL | 70605900 | A | 22 | 02.10 |
| GL112-A (90107-1) CONSOLE CE INFO (USE AB103-A) | | | | |
| MB434-A CONTROLWARE (6000) (USE FA401-A/B CE MANUAL VOL 1 OR FA444-A/B) | | | | |
| MB435-A CONTROLWARE (7000) (USE FA401-A/B CE MANUAL VOL 1) | | | | |
| SD101 SOURCE DATA COLLECTION TERMINAL HARDWARE PROGRAMMING MANUAL | 62056300 | A | 22 | 01.35 |
| TB101 PERIPHERAL EXERCISER--LISTED AS 9910 | | | | |
| TB101-B/9910-B PERIPHERAL EXERCISER | | | | |
| TB115-A FEILD TEST UNIT DIAGRAMS, WIRE LISTS, PARTS DATA, GEN. DESC, OPERATIONS CE MANUAL | 70604000 | A | 22 | 04.90 |
| TB204 FEILD TEST EXERCISER CE MANUAL | 83302900 | B | 22 | 03.10 |
| TB207-A FIELD TEST UNIT MAINTENANCE MANUAL | 83307900 | B | 3 | 04.65 |
| TB301-A/B FIELD TEST EXERCISER MAINT. MANUAL | 70612800 | G | 3 | 05.00 |
| TB3A1 FEILD TEST UNIT GEN DESC., INSTALLATION AND OPERATION, THEO. OF OPERATION, MAINT., DIAGRAMS AND W/L, PART DATA CE MANUAL | 83303700 | B | 22 | 05.35 |
| TB302 FIELD TEST UNIT CE MANUAL | 83308000 | B | 22 | 06.75 |
| TB4A1-A FIELD TEST UNIT MAINTENANCE MANUAL | 83312300 | A | 3 | 12.15 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

SECTION 2

The manuals in this section are listed by Product or System Number. Many entries include a product to equipment cross reference; e.g. 1742 {CL309-A/B, FF511-A/B}. Since Hardware Manuals for equipment developed after November, 1967 are categorized by equipment designator, always look up the equipment designator in Section 1 as well as the Product Number.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------------------|--------|----------|----------------|
| CYBER 72/73/74 72-12 (6681-D, AA115-A, CC538-A/B) 72-13 (6681-D, AA115-A, AT232-A, CC538-A/B) 72-14 (6681-D, AA115-A, AT231-A, AT232-A, CC538-A/B) 72-16 (6681-D, AA115-A, AT231-A, AT232-A, AT237-A, CC538-A/B) 72-18 (6681-D, AA115-A, AT231-A, AT232-A, AT236-A, AT237-A, CC538-A/B) 72-24 (6681-D, AA115-A, AT227-A, AT231-A, AT232-A, CC538-A/B) 72-26 (6681-D, AA115-A, AT227-A, AT231-A, AT232-A, AT237-A, CC538-A/B) 72-28 (6681-D, AA115-A, AT227-A, AT231-A, AT232-A, AT236-A, AT237-A, CC538-A/B) 73-12 (6681-D, AA115-A, AT226-A, CC538-A/B) 73-13 (6681-D, AA115-A, AT226-A, AT232-A, CC538-A/B) 73-14 (6681-D, AA115-A, AT226-A, AT231-A, AT232-A, CC538-A/B) 73-16 (6681-D, AA115-A, AT226-A, AT231-A, AT232-A, AT237-A, CC538-A/B) 73-18 (6681-D, AA115-A, AT226-A, AT231-A, AT232-A, AT236-A, AT237-A, CC538-A/B) 73-24 (6681-D, AA115-A, AT226-A, AT227-A, AT231-A, AT232-A, CC538-A/B) 73-26 (6681-D, AA115-A, AT226-A, AT227-A, AT231-A, AT232-A, AT237-A, CC538-A/B) 73-28 (6681-D, AA115-A, AT226-A, AT227-A, AT231-A, AT232-A, AT236-A, AT237-A, CC538-A/B) 74-12 (6681-D, AA117-A, BR397-A, CC538-A/B) 74-13 (6681-D, AA117-A, AT239-A, BB397-A, CC538-A/B) 74-14 (6681-D, AA117-A, CC538-A/B) 74-16 (6681-D, AA117-A, AT237-A, CC538-A/B) 74-18 (6681-D, AA117-A, AT236-A, AT237-A, CC538-A/B) 74-24 (6681-D, AA117-A, AE116-D, CC538-A/B) 74-26 (6681-D, AA117-A, AE116-D, AT237-A, CC538-A/B) 74-28 (6681-D, AA117-A, AE116-D, AT236-A, AT237-A, CC538-A/B) | | | | |
| REFERENCE MANUALS (HARDWARE) ORDER VOL.2 AND APPROPRIATE VOL 1 FOR A COMPLETE REFERENCE MANUAL. ORDER VOL.3 IF SYSTEM CONTAINS FCS. | | | | |
| MODEL 72 SYS DESC/PROGRAMMING INFO-VOL 1 MODEL 73 SYS DESC/PROGRAMMING INFO-VOL 1 | 60347000 60347200 | H E | 22 22 | 01.05 01.20 |

1-Publication number of literature.
 2-The latest revision level.

3-Indicates size of hard cover
 binder that may be used for
 manuals.
 4-Publication division responsi-
 ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|----|-------|-------|
| MODEL 74 SYS DESC/PROGRAMMING INFO-VOL I | 60347400 | K | 22 | 02.05 |
| MODEL 72/73/74 INSTRUCTION DESC. VOL 2 | 60347300 | J | 22 | 01.25 |
| MODEL 72/73/74 ECS DESC/PROGRAMMING VOL 3 | 60347100 | D | 22 | 01.00 |
| MODEL 72/73/74 INPUT/OUTPUT SPECIFICATIONS (INCLUDES 6000) | 60352500 | E | 22 | 01.00 |
| CYBER 76 | | | | |
| 76-111 (AA106-A, AB101-A, GH506-A/B, GE226-A/B, GH214-C/D, CC522-A/B, CE149-A/B AT311-A) | | | | |
| 76-112 (AA106-A, AB101-A, GH506-A/B, GE226-A/B, GH214-C/D, CC522-A/B, CE149-A/B AT311-A, BB360-B) | | | | |
| 76-121 (AA106-A, AB101-A, GH506-A/B, GE226-A/B, GH214-C/D, CC522-A/B, CE149-A/B AT311-A, BS101-A) | | | | |
| 76-122 (AA106-A, AB101-A, GH506-A/B, GE226-A/B, GH214-C/D, CC522-A/B, CE149-A/B AT311-A, BS101-A, BB360-B) | | | | |
| 76-142 (AA106-A, AB101-A, GH506-A/B, GE226-A/B, GH223-A, CC522-A/B, CE149-A/B, BS101-A, BS102-A, BB360-B, AT311-A) | | | | |
| REF MANUAL (HARDWARE) | 60367200 | C | 22 | 06.70 |
| SMMV3 REFERENCE MANUAL VOLS 1,2,3 (INC.7600) | 60373900 | C | 22 | 45.00 |
| I/O SPECIFICATIONS (INCLUDES 7600) | 60408700 | B | 22 | 01.00 |
| CYBER 172/173/174 COMPUTER SYSTEMS | | | | |
| INPUT/OUTPUT SPECIFICATIONS MANUAL (INCLUDES MODEL 175) | 19983600 | | 02 22 | 00.70 |
| CYBER 175 | | | | |
| 175-4 (AA120-A, GE258-A/B, CC545-A/B, GH223-A) | | | | |
| 175-6 (AA120-A, GE258-A/B, CC545-A/B, GH223-A, BS110-A) | | | | |
| 175-8 (AA120-A, GE258-A/B, CC545-A/B, GH223-A, BS107-A) | | | | |
| 175-12 (AA120-A, GE258-A/B, CC545-A/B, GH223-A, BS107-A) | | | | |
| 175-16 (AA120-A, GE258-A/B, CC545-A/B, GH223-A, BS107-A) | | | | |
| HARDWARE REFERENCE MANUAL INPUT/OUTPUT SPECS (SEE CYBER 172/173/174) | 60420000 | 03 | 22 | 01.70 |
| CYBER 1000 HARDWARE SEE DW105-A, DY121/122/123 124/127/129 | | | | |
| G-15 COMPUTER REFERENCE MANUALS | | | | |
| DIGITAL COMPUTER SYSTEM MANUAL | 60061300 | | | 02.00 |
| INTERCOM 1000 INSTRUCTION CAPD (G-15) | 60062300 | | | 00.50 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|---|----|-------|
| OPERATION MANUAL | 60062400 | | | 02.20 |
| PA-3 GRAPH PLOTTER REFERENCE | 60181800 | | | 03.00 |
| PROGRAMMING MANUAL | 60062500 | | | 07.00 |
| REFERENCE CARD (PAPER STOCK) (G-15) | 60062600 | | | 00.50 |
| REFERENCE CARD (PLASTIC STOCK) (G15) | 60062600 | | | 00.75 |
| CUSTOMER ENGINEERING MANUALS | | | | |
| PARTS MANUAL | 60061400 | | | 04.30 |
| CE DIAGRAMS | 60063000 | A | | 03.60 |
| CA-2 CARD ACCESSORY (AET-01631) | 60063100 | A | | 08.00 |
| AN-1 ALPHANUMERIC ACCESSORY MANUAL | 60064000 | | | 03.50 |
| DA-1 DIFFERENTIAL ANALYZER | 60064800 | | | 05.00 |
| DIAPER (DIAGNOSTIC ROUTINES) | 60064900 | | | 10.00 |
| ANC-2 ALPHANUMERIC COUPLER | 60065000 | | | 03.20 |
| PA-3 GRAPH PLOTTER | 60104500 | | | 04.20 |
| THEORY OF OPERATION AND SIMPLIFIED DRAWINGS | 60121600 | | 22 | 12.75 |
| DIGITAL MAGNETIC TAPE HANDLER (POTTER MODEL MTA) (902) INSTRUCTION MANUAL INCLUDING MTA-2 PARTS LIST | 60124600 | | | 01.20 |
| MTA-2 MAGNETIC TAPE UNIT ACCESSORY | AEG05571 | | 22 | 03.45 |
| PR-2 PHOTOELECTRIC TAPE READER | AET01621 | A | | 06.60 |
| MTA-2 MAGNETIC TAPE ACCESSORY | AET05613 | | | 03.50 |
| PTP-1 PAPER TAPE PUNCH | AET09611 | | | 05.40 |
| ANC-1 (OUTLINE, DISCUSSION, INSTALLATION AND DRAWINGS) | | | | |
| (THE FOLLOWING MANUALS FOR THE ABOVE G-15 COMPUTER PRODUCT LINE ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES. ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY. PRICE AVAILABLE UPON REQUEST | | | | |
| SERVICE MANUAL MTA-3 (AET-5611) | 60164600 | | | |
| SERVICE MANUAL MTA-4 (AET-10621) | 60164700 | | | |
| OPERATORS MANUAL MTA-4 (AEG-10621) | 60164800 | | | |
| G-20 COMPUTER REFERENCE MANUALS | | | | |
| CONTROL BUFFER/MACHINE LANGUAGE (CB-11) | 60061800 | | | 05.20 |
| GENERAL REFERENCE MANUAL | 60061000 | A | 22 | 08.00 |
| OPERATING MANUAL | 60061700 | | | 12.20 |
| REFERENCE CARD (G-20) | | | | |
| CUSTOMER ENGINEERING MANUALS | | | | |
| 88 SERVICE MANUAL | BER05625 | | | 07.00 |
| 1402 CARD READER/PUNCH REFR/INSTRUCTION | 60063200 | | | 08.50 |
| LP-12 HIGH SPEED PRINTER (INCL. DIAGRAMS) | 60062900 | | | 10.00 |
| PC-10 CARD PRINTER COUPLER SERVICE | BER11621 | | 22 | 10.05 |
| CB-11 BUFFER CONTROL CE DIAGRAMS | 60063400 | A | 34 | 03.25 |
| CB-11 CONTROL BUFFER/SERVICE MANUAL VOL 1 | 60063700 | | | 10.00 |
| CB-11 CONTROL BUFFER/SERVICE MANUAL VOL 2 | 60063800 | | | 05.00 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------------------|--------|----------|----------------|
| ENGINEERING DESIGN HANDBOOK FOR THE G-20 PT-10 SERVICE MANUAL (8ER07621) | 60129400 60042800 | | 22 | 04.50 04.60 |
| (THE FOLLOWING MANUALS FOR THE ABOVE G-20 COMPUTER PRODUCT LINE ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES. ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY. PRICE AVAILABLE UPON REQUEST | | | | |
| MT-10 DIAGRAMS | 60063500 | | | |
| MM-10 DIAGRAMS | 60064400 | | | |
| LP-10 DIAGRAMS | 60064500 | | | |
| PC-10 DIAGRAMS | 60064300 | | | |
| PT-10 DIAGRAMS | 60064600 | | | |
| CC-10 DIAGRAMS | 60064700 | | | |
| G-20 CENTRAL PROC. SERVICE MANUAL VOL. 1 (8ER-10622) | 60211400 | | | |
| G-20 CENTRAL PROC. SERVICE MANUAL VOL. 2 | 60211500 | | | |
| LINE PRINTER EQUIPMENT (1742,3010,3254,8130 PRODUCT) CE MANUAL | 47967000 | F | 22 | 08.25 |
| LGP 21 COMPUTER SYSTEM | | | | |
| MAINTENANCE AND TRAINING MANUAL (INCLUDES TALLY TAPE READER, TALLY TAPE PERFORATOR AND MODEL 101 VISUAL OSCILLOSCOPE DISPLAY) | ESD10600 | - | 22 | 07.00 |
| PROGRAMMING MANUAL | SC200100 | | | 03.00 |
| REFERENCE MANUAL | SC2000 | | | 02.55 |
| LGP 30 COMPUTER SYSTEM | | | | |
| MAINTENANCE MANUAL | ESD10400 | | 3 | 06.35 |
| OPERATIONS MANUAL | SC0633 | | | 01.00 |
| PROGRAMMING CLASS NOTES | SC0001 | | | 02.00 |
| PROGRAMMING MANUAL | SC0576 | | | 06.00 |
| RPC 4000 MAINTENANCE AND TRAINING MANUAL MANUAL (INCLUDES RPC 4010 AND RPC 4500) REFERENCE MANUAL | ESD10501 | | | 12.00 |
| | SC4006 | | | 12.00 |
| RPC 4290 TRANSLATOR MAINT AND TRAINING MANUAL (INCLUDES RPC 4410,4435,4440,180 AND 891) | ESD10505 | | | 15.75 |
| SCM-M-120 PRINTER AND 1095-D PRINTER ADAPTER REF/CE MANUAL | 41605900 | C | 22 | 04.25 |
| 0101 BADGE READER AND ADAPTER REFERENCE MAN. CE DIAGRAMS | 36818300 36818500 | B C | 22 22 | 01.75 02.00 |
| 0101-R/D BADGE READER 2010 BADGE READER ADAPTER DIAGRAMS | 65715000 | B | 22 | 01.40 |
| ILLUSTRATED PARTS MANUAL | 65715100 | B | 22 | 01.60 |
| MAINTENANCE MANUAL | 65714900 | A | 22 | 01.80 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.

4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|--|----------------------|------------------------|--|
| 0101-C/0107-B BADGE READER REFERENCE MANUAL CE MANUAL | 13792800 13792000 | A H | 22 | 01.10 02.25 |
| 0120-C SCALE ADAPTER REFERENCE/CE MANUAL | 13794900 | A | 22 | 03.50 |
| 0202 REMOTE TERMINAL HARDWARE REF/CE MANUAL | 65739900 | B | 22 | 10.00 |
| 101-1 (DJ141-A) SYNCHRONOUS MODEM | | | | |
| 124-1 (DJ140-A/B) SYNCHRONOUS MODEM | | | | |
| 150-A CARD TESTER (THE FOLLOWING MANUAL FOR THE 150-A CARD TESTER IS AVAILABLF ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES. ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.) PRICE AVAILABLE UPON REQUEST REFERENCE/INSTRUCTION AND DIAGRAMS MANUAL | 60002600 | | | |
| 151-A CARD TESTER INSTRUCTION MANUAL | 60018400 | B | | 15.45 |
| 152 CARD TESTER MOD A CE MAINTFNANCE MANUAL ILLUSTRATED PARTS LIST, MOD A (6/65) | 40814400 40812800 | A | 22 | 09.75 03.50 |
| 160-B COMPUTER (FORMERLY 160 COMPUTER) REFERENCE MAN COMPUTER SYSTEM COMPUTING CENTER OPERATION DESCRIPTION AND OPERATION VOL 1 INSTALLATION MAN INSTRUCTION CARD (PLASTIC) SATELLITE PROGRAMMING MAN | 60002300 60020900 60006800 60007200 60070100 60018700 | C B | 22 | 03.75 03.25 07.75 03.25 00.75 02.40 |
| CUSTOMER ENGINEERING MANUALS | | | | |
| CARD PLACEMENT AND EQUATION SUMMARY | 60007100 | C | 22 | 04.75 |
| CARD PLACEMENT AND EQUATIONS (SERIALS 0-33) | 60185500 | A | 22 | 04.90 |
| CE DIAGRAMS | 60007000 | F | 34 | 03.00 |
| CE DIAGRAMS (SERIALS 0-30) | 60150900 | A | 34 | 02.20 |
| VOL 2 MAINTENANCE | 60006900 | B | | 06.00 |
| PERIPHERAL EQUIPMENT CODES | 60024900 | | | 01.35 |
| STAND ALONE DIAGNOSTIC SYSTEM REFERENCE MAN. | 60270200 | A | 22 | 07.30 |
| 160-A COMPUTER PROGRAMMING PRIMER OF MESSAGE SWITCHING SYSTEMS 160-A INSTRUCTION CARDS REFERENCE MANUAL (COMPUTER) SPECIFICATION (I/O) STAND ALONE DIAGNOSTIC SYSTEM (SAD) VOLS. I, II, III REFERENCE MANUAL INSTALLATION MANUAL | 36810300 60070200 60014500 60002500 60272200 60018500 | A G F A | 22 22 22 | 01.75 00.75 01.65 02.00 30.00 02.70 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|-----|----|-------|
| CUSTOMER ENGINEERING MANUALS | | | | |
| 160-A WIRE LISTS | 24107700 | E | 22 | 07.80 |
| 160-A CHANNEL ADAPTER OPERATION AND MAINT. | 39072500 | | | 01.60 |
| BUFFER CHANNEL LONG LINE DRIVE CE MANUAL | 60123600 | A | | 01.00 |
| CARD PLACEMENT AND EQUATION SUMMARY | 60014300 | L | 22 | 05.80 |
| CE INSTRUCTION MANUAL-PART 1, THEO OF OPER | 60014000 | E | 22 | 14.10 |
| CE DIAGRAMS | 60014200 | R | 22 | 02.40 |
| DESC, OPERATION, MAINT.(PARTS LIST) CE MAN. | 60014100 | D | 22 | 03.25 |
| MASTER CONTROL SYSTEM MAINT MONITOR VOL 1 | 60104600 | D | 22 | 12.00 |
| MASTER CONTROL SYSTEM MAINT MONITOR VOL 2 | 60104700 | C | 22 | 04.90 |
| MASTER CONTROL SYSTEM MAINT MONITOR PROGRAM | 60112800 | G | 22 | 45.00 |
| LISTINGS VOLS 1 AND 2 | | | | |
| CHECKING PULSE WIDTHS ON 160-A/169 CLOCKED | 60119100 | | | 01.50 |
| INVERTER CARDS | | | | |
| 161-A/B ON-LINE INPUT/OUTPUT TYPEWRITER | | | | |
| REFERENCE/INSTRUCTION MANUAL | 60007300 | S | | 02.60 |
| CARD PLACEMENT AND EQUATION SUMMARY | 60103900 | F,G | 22 | 02.00 |
| CE DIAGRAMS (WITHOUT ECM 10) MANUAL | 60105400 | A | 22 | 01.00 |
| LONG LINE DRIVERS FOR 161 TYPEWRITER | 60124100 | B | 22 | 01.00 |
| WIRE LIST | 60116600 | C | 22 | 01.25 |
| 161-F ON LINE I/O FLEXOWRITER | | | | |
| REFERENCE/INSTRUCTION MANUAL | 60029100 | C | 22 | 02.40 |
| CARD PLACEMENT AND EQUATION SUMMARY | 60041400 | B | 22 | 02.80 |
| 161-G TYPEWRITER | | | | |
| REFERENCE/INSTRUCTION MANUAL | 60094800 | B | | 03.00 |
| (THE FOLLOWING MANUAL FOR THE 161-G IS AVAIL- ABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES. ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.) PRICE AVAILABLE UPON REQUEST | | | | |
| CARD PLACEMENT AND EQUATION SUMMARY | 60141600 | C | 22 | |
| 162 MAGNETIC TAPE SYNCHRONIZERS | | | | |
| REFERENCE MANUALS | | | | |
| 162(S) REFERENCE MANUAL | 60023000 | | | 02.25 |
| 162-1/162-2 REFERENCE MANUAL | 60025800 | E | 22 | 04.25 |
| 162-1B/162-2B/162-3B REF/INST MANUAL | 60100200 | B | 22 | 06.25 |
| CUSTOMER ENGINEERING MANUALS | | | | |
| 162(S) CE DIAGRAMS | 60026000 | E | 34 | 03.00 |
| 162(S) CE MANUAL | 60026500 | | 22 | 03.00 |
| 162(S) CARD PLACEMENT AND EQUATION SUMMARY | 60026800 | E | 22 | 03.60 |
| 162-1 DIAGRAMS | 60026100 | M | 22 | 03.05 |
| 162-1-A CARD PLACEMENT AND EQUATION SUMMARY | 60026900 | L | 22 | 05.25 |
| 162-1-P CE DIAGRAMS | 60104200 | J | 34 | 03.00 |
| 162-2 DIAGRAMS | 60026200 | M | 34 | 01.50 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------|---|----|-------|
| 162-2 CARD PLACEMENT AND EQUATION SUMMARY | 60027000 | K | 22 | 03.40 |
| 162-2-A/H WIRE LIST | 60151800 | G | 22 | 05.00 |
| 162-2-B/G CE DIAGRAMS | 60104300 | H | 34 | 02.10 |
| 162-1-H/162-2-H REF/CE MANUAL DESCRIPTION OPERATION, PROGRAMMING, DIAGRAMS AND P/L | 60095000 | K | 22 | 08.00 |
| 162-3-B/G CE DIAGRAMS | 60104400 | K | 34 | 03.85 |
| 162-1,2,3-B/G CARD PLACEMENT AND EQUATION SUMMARY | 60129300 | K | 22 | 05.30 |
| NORMAL CHANNEL LONG LINE DRIVERS | 60123900 | A | 22 | 01.50 |
| (THE FOLLOWING MANUALS FOR THE 162 PRODUCT LINE ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES. ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.) PRICE AVAILABLE UPON REQUEST | | | | |
| 162-2-H CARD PLACEMENT AND EQUATION SUMMARY | 60141500 | H | 22 | |
| CARD PLACEMENT AND EQUATION SUMMARY | 60022200 | B | | |
| 163-A MAGNETIC TAPE SYSTEM | | | | |
| VOL I REFERENCE/INSTRUCTION MANUAL | 60007400 | C | 22 | 07.25 |
| 163 CE DIAGRAMS | 60007500 | F | 34 | 05.00 |
| CARD PLACEMENT AND EQUATION SUMMARY | 60007600 | D | 22 | 05.35 |
| CROSS TABS | 60116200 | | 22 | 07.60 |
| 164-A MAGNETIC TAPE SYSTEM | | | | |
| CE DIAGRAMS | 60007800 | C | 34 | 04.75 |
| VOL I DESCRIPTION, OPERATION AND MAINTENANCE | 60007700 | A | | 03.00 |
| CARD PLACEMENT AND EQUATION SUMMARY | 60007900 | A | 22 | 04.90 |
| 165/165-2 INCREMENTAL PLOTTER | | | | |
| INSTRUCTION MANUAL | 60013900 | D | | 02.60 |
| CARD PLACEMENT AND EQUATION SUMMARY | 60119200 | A | 22 | 01.50 |
| WIRE LIST, 165-B/G | 60151500 | C | 22 | 03.00 |
| 165-G INCREMENTAL PLOTTER | | | | |
| REFERENCE/INSTRUCTION MANUAL | 60094900 | B | | 03.80 |
| CARD PLACEMENT AND EQUATION SUMMARY | 60141400 | A | 22 | 01.70 |
| WIRE LIST (SEE 165/165-2) | | | | |
| 166-2 LINE PRINTER | | | | |
| NORMAL CHANNEL LONG LINE DRIVERS CE MANUAL | 60124000 | A | 22 | 01.00 |
| REFERENCE/INSTRUCTION MANUAL | 60019500 | F | 22 | 10.25 |
| CE DIAGRAMS | 60022500 | R | 34 | 01.30 |
| CARD PLACEMENT AND EQUATION SUMMARY | 60102500 | J | 22 | 04.00 |
| WIRE LISTS, CROSS TABS | 60116400 | C | 22 | 03.90 |
| H207 LINE PRINTER REFERENCE/INSTRUCTION MAN. | 60109800 | B | 22 | 04.80 |
| 167-1 CARD READER REFERENCE/INSTRUCTION | 60019400 | E | 22 | 04.00 |
| 167-2-A CARD READER REFERENCE/INSTRUCTION AND DIAGRAMS MANUAL | 60022000 | D | 22 | 06.50 |
| CARD READER LONG LINE DRIVERS | 60124300 | C | 22 | 01.00 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.

4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|---|----|-------|
| (THE FOLLOWING MANUAL FOR THE 167-2-A CARD READER IS AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES. ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.) PRICE AVAILABLE UPON REQUEST CARD PLACEMENT AND EQUATION SUMMARY | 60022200 | B | | |
| 168-1-A AUXILIARY ARITHMETIC UNIT VOL.1, DESCRIPTION, OPERATION AND MAINTENANCE MANUAL | 60021600 | A | | 04.00 |
| CARD PLACEMENT AND EQUATION SUMMARY | 60021700 | A | 22 | 04.20 |
| CROSS TABS | 60112700 | | 22 | 05.80 |
| 168-2-A AUXILIARY ARITHMETIC UNIT REFERENCE/INSTRUCTION MANUAL | 60023800 | D | 22 | 03.40 |
| VOL 2 DIAGRAMS | 60023900 | B | 34 | 04.00 |
| AUX. ARITH. UNIT CARD PLCMT. AND EQ. SUMMARY | 60024000 | A | 22 | 04.50 |
| 169-A AUXILIARY MEMORY UNIT REFERENCE/INSTRUCTION MANUAL | 60014400 | D | 22 | 07.00 |
| CE DIAGRAMS | 60022300 | H | 22 | 04.70 |
| CARD PLACEMENT AND EQUATION SUMMARY | 60022400 | F | 22 | 05.80 |
| CROSS TABS | 60116300 | A | 22 | 08.30 |
| CHECKING PULSE WIDTHS ON 160-A/169 CARDS | 60119100 | | 22 | 01.50 |
| EXTERNAL BUFFER CHANNEL LONG LINE DRIVERS CE MANUAL | 60123800 | A | 22 | 01.00 |
| 170-A CARD PUNCH CONTROLLER REFERENCE/INSTRUCTION MANUAL | 60021800 | A | 22 | 02.65 |
| CARD PLACEMENT AND EQUATION SUMMARY | 60090200 | D | 22 | 03.70 |
| CE DIAGRAMS MANUAL | 60021900 | E | 34 | 04.80 |
| CROSS TABS, 170-B/G | 60151200 | D | 22 | 03.55 |
| (THE FOLLOWING MANUAL FOR THE 170-A CARD PUNCH CONTR. IS AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES. ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY) PRICE AVAILABLE UPON REQUEST CARD PUNCH CONTROLLER LONG LINE DRIVERS | 60123700 | A | | |
| 170-G CARD PUNCH CONTROLLER REFERENCE/INSTRUCTION MANUAL | 60095400 | E | 22 | 04.00 |
| CROSS TABS (SEE 170-A) | | | | |
| (THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES. ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.) CARD PLACEMENT AND EQUATION SUMMARY | 60141300 | G | 22 | |
| 174-G PAPER TAPE READER/PUNCH CE MANUAL | 60121100 | H | 22 | 02.95 |
| 177-A/R CARD READER CONTROLLER | | | | |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.

4-Publication division responsible for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------|-----|----|-------|
| REFERENCE/INSTRUCTION MANUAL | 60049100 | D | 22 | 01.50 |
| CARD PLACEMENT AND EQUATION SUMMARY | 60122600 | A | 22 | 02.50 |
| SUMMARY | | | | |
| WIRE LIST AND CABLE TABS, 177-8/G | 60151700 | B | 22 | 02.00 |
| 177-G CARD READER CONTROLLER | | | | |
| REFERENCE INSTRUCTION MANUAL | 60095200 | E | | 04.25 |
| WIRE LIST AND CABLE TABS (SEE 177-A/B) | | | | |
| (THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT | | | | |
| ARE AVAILABLE ON A SPECIAL ORDER BASIS IN | | | | |
| MAX. QTY OF 2 COPIES.ALLOW AT LEAST 3-4 | | | | |
| WEEKS FOR PROCESSING AND DELIVERY.) | | | | |
| CARD PLACEMENT AND EQUATION SUMMARY | 60141200 | A | 22 | |
| 180 DATA COLLECTOR | | | | |
| DIAGRAMS AND WIRE LIST CE MANUAL | 40808300 | | 22 | 02.00 |
| 210 ANALOG TO DIGITAL CONVERTER | | | | |
| OPERATIONS AND MAINT INSTRUCTION MANUAL | 39074700 | | 3 | 01.45 |
| 217-2/FC11-B | | | | |
| DISPLAY STATION FOR USE WITH 217-2 EQUIPMENT | 82128800 | A00 | 22 | 01.00 |
| CONTROLLER PARTS DATA BOOK (INCLUDES INFO O | | | | |
| CC505-A, CC505-B) | | | | |
| 218-1 TYPEWRITER STATION PARTS DATA BOOK | 82128900 | A00 | 22 | 01.00 |
| (INCLUDES INFO ON CK105-A AND CK105-B) | | | | |
| 222 (CL401-A/B, CL402-A/B) LINE PRINTER | | | | |
| CONTROLLER | | | | |
| 224 (CE152) CARD READER | | | | |
| 224-2 (CE304) CARD READER | | | | |
| 224-2A (CE306) CARD READER | | | | |
| 225-1 (CF105) CARD PUNCH | | | | |
| 250-2 DISPLAY SUBSYSTEM HARDWARE REF. MANUAL | 82129000 | A00 | 22 | 03.80 |
| 252-2 DISPLAY CONSOLE (REV. 0-3) | 82129700 | A00 | | 04.40 |
| 271 DIGIGRAPHICS CONTROLLER REFERENCE MANUAL | 60181400 | | | 05.75 |
| 273 DIGIGRAPHIC CONSOLE REFERENCE/CE MANUAL | 60188600 | A | 22 | 08.00 |
| 274 DIGIGRAPHIC CONSOLE GEN DESC, THEO OF OP, | 60279100 | A | 22 | 04.95 |
| DIAGS, MAINT, P/L REFERENCE/CE MANUAL | | | | |
| 275 DIGIGRAPHIC SYSTEM | | | | |
| DIGIGRAPHIC MAN-MACHINE SYSTEMS 275 BUFFER | 60181300 | A | 22 | 03.75 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------|---|----|-------|
| MEMORY REFERENCE MANUAL | | | | |
| 302 COMMUNICATIONS EXPANSION MOD REF/CE MAN | 13796100 | A | 22 | 02.70 |
| 303-1 (GG105-A) COMMUNICATIONS EXPANSION UNIT REFERENCE MANUAL | 13797400 | A | 22 | 01.20 |
| 304-1 (DJ805-A/B) COMMUNICATIONS MULTIPLEXER REFERENCE MANUAL | 13796400 | D | 22 | 01.00 |
| 311-B DATA SET ADAPTER EQUATION FILE AND WIRE LIST CE MANUAL | 36824400 | B | 22 | 04.55 |
| 311-2 (DJ110-A/DJ111-A) DATA SET ADAPTER REFERENCE MANUAL | 41602400 | A | 22 | 01.00 |
| 311-3 COMMUNICATIONS ADAPTER REF INFO (USE 361-5) | | | | |
| 312-2 DATA SET ADAPTER REFERENCE MANUAL | 41609000 | A | 22 | 02.70 |
| 313 (8536-C/8537-C/FJ413-A/FJ414-A) DATA SET ADAPTER REFERENCE MANUAL | 13798400 | A | 22 | 01.00 |
| 314 (8536-C/8537-C/FJ413-A/FJ414-A) DATA SET ADAPTER REFERENCE MANUAL | 13798500 | A | 22 | 01.00 |
| 317 (8536-D/8537-D/FJ413-A/FJ414-A) DATA SET ADAPTER REFERENCE MANUAL | 13798600 | B | 22 | 01.00 |
| 318 (8536-D/8537-D/FJ413-A/FJ414-A) DATA SET ADAPTER REFERENCE MANUAL | 13798700 | B | 22 | 04.30 |
| 321 (8518-C/8519-D) TELETYPEWRITER TERMINAL UNIT REFERENCE MANUAL | 13799300 | A | 22 | 03.50 |
| 323 (8518-C/8519-D) TELETYPEWRITER TERMINAL UNIT (USE 321 REFERENCE MANUAL) | | | | |
| 326-C TRUNK LINE ADAPTER THEORY OF OPERATION, MAINTENANCE, PROGRAMMING, CARD PLACEMENT, PARTS LISTS, DIAGRAMS REFERENCE/CE MANUAL | 36829000 | A | 22 | 02.25 |
| OPERATION, INSTALLATION, MAINTENANCE CE MAN | 36824800 | A | 22 | 01.50 |
| 327 DATA SET ADAPTER CE MANUAL | 36824700 | A | 22 | 07.05 |
| 327-2 (DJ101-A, DJ115-A) DATA SET ADAPTER REFERENCE MANUAL | 41600500 | A | 22 | 01.00 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|--|----------------------|----------------------|---|
| 330 (8536-D/8537-D) DATA SET ADAPTER REFERENCE MANUAL | 13798300 | B | 22 | 01.00 |
| 331 (8536-/8537-E) DATA SET ADAPTER REFERENCE MANUAL | 41607100 | A | 22 | 01.00 |
| 332-1 (8536-C/8537-C) DATA SET ADAPTER REFERENCE MANUAL | 13798200 | A | 22 | 01.00 |
| 350 PAPER TAPE READER/REFERENCE MANUAL MOD C-G REFERENCE MANUAL MOD A AND B DIAGRAMS AND WIRE LIST, MOD J,K,L,M MAINTENANCE MANUAL MOD J,K,L,M,N,P,R,S,T,U PARTS LIST (MOD A THRU U) | 40801200 PED 108A 40808000 40813100 40861900 | A B B B | 22 22 22 22 | 01.25 01.60 01.50 01.90 02.00 |
| 358-1 (DJ112-A/B) TRANSCEIVER REF MANUAL | 41605300 | B | 22 | 01.00 |
| 358-2 (DJ113-A/B) TRANSCEIVER REF MANUAL | 41606200 | B | 22 | 01.00 |
| 358-3 (DJ114-A/B) TRANSCEIVER REFERENCE MANUAL | 41601800 | C | 22 | 01.00 |
| 360-65+/67+ MEMORY SYSTEM DIAGNOSTIC PACKAGE USERS GUIDE | 75400200 | A | 3 | 17.25 |
| 358-4 (DJ114-C/D) TRANSCEIVER REF INFO (USE 358-3) | | | | |
| 361-1 (DJ142-A, DJ143-A) COMMUNICATIONS ADAPTER REFERENCE MANUAL | 41612200 | C | 22 | 01.00 |
| 361-2 (DJ143-A) COMMUNICATIONS ADAPTER REF INFO (USE 361-1) | | | | |
| 361-3 (DJ142-A) COMMUNICATIONS ADAPTER REF INFO (USE 361-1) | | | | |
| 361-4 (DJ122-A) COMMUNICATIONS ADAPTER REFERENCE MANUAL | 41609600 | A | 22 | 03.40 |
| 361-5 (DJ144-A) COMMUNICATIONS ADAPTER REFERENCE MANUAL | 41611800 | C | 22 | 02.65 |
| 361-6 (DJ145-A) COMMUNICATIONS ADAPTER REFERENCE MANUAL | 41612000 | B | 22 | 01.60 |
| 361-7 (DJ146-A) COMMUNICATIONS ADAPTER REFERENCE MANUAL | 41612400 | A | 22 | 01.00 |
| 362-1 (GH407-A/B, DK509-A/B) TELEGRAPHIC LEVEL CONVERTER | | | | |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------------------------------|-------------|----------------|-------------------------|
| REFERENCE MANUAL | 41610500 | A | 22 | 01.00 |
| 362-2 (DK509-A/B) TELEGRAPHIC LEVEL CONVERTER REF INFO (USE 362-1) | | | | |
| 364-1/2 (DJ808-A, GD306-A/B, GH407-A/B) COMMUNICATIONS MULTIPLEXER REFERENCE MANUAL | 41610900 | A | 22 | 01.00 |
| 364-3 (DJ813-A) COMMUNICATIONS MULTIPLEXER REFERENCE MANUAL | 41612500 | A | 22 | 01.00 |
| 364-4 (DJ814-A, GD306-A/B, GH407-A/B) COMMUNICATION MULTIPLEXER REFERENCE MANUAL | 41612700 | B | 22 | 01.00 |
| 364-5 (DJ814-A) COMMUNICATION MULTIPLEXER REF INFO (USE 364-4) | | | | |
| 370 PAPER TAPE READER DIAGRAMS, C/P, W/L, MODS A01-B01 AND ABOVE MAINTENANCE MANUAL MOD A AND B (6166) PARTS LIST MOD A AND B | 40864900 40823900 40829400 | B A D | 22 22 22 | 01.00 01.25 01.50 |
| 402M ANALOG MULTIPLEXER OPER AND MAINT INSTR | 39074900 | | | 01.65 |
| 405 HIGH SPEED CARD READER REFERENCE MANUAL A/B APENDIX FOR C, D, J AND K PARTS LIST MOD A THRU D SUPPLEMENTAL MANUAL (MOD D) | 40809300 40825200 49750900 | J L B | 22 22 22 | 02.25 03.40 02.35 |
| 405 PL-10 CARD READER CE156 PARTS DATA CE MAN | 49755400 | A | 22 | 04.50 |
| 407 (CE149) CARD READER | | | | |
| 415 CARD PUNCH ILLUSTRATED PARTS LIST MOD A AND B DIAGRAMS, THEO OF OPER., GEN DESC CE/REF MAN | 40820200 49755300 | G C | 22 22 | 02.50 11.15 |
| 415-PL-10 CARD PUNCH (CF109) PARTS DATA CE MAN | 49755500 | A | 22 | 04.75 |
| 415-30 (CH102-A/B, FE202-A/B) CARD PUNCH AND CONTROLLER | | | | |
| 417-1 (CF108-A/B, FE201-A) CARD PUNCH WITH CONTROLLER | | | | |
| 430 (CF504) CARD READ-PUNCH | | | | |
| 430 PL-10 CARD READER-PUNCH (CF511) PARTS DATA | 49755900 | 01 | 22 | 04.90 |
| 469 COMPUTER SYSTEM 462-01A/02A TELETYPE CONTROLLERS | 14060200 | | 22 | 08.60 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------|-----|----|-------|
| 501 AND 505 HIGH SPEED LINE PRINTER | | | | |
| 501 REFERENCE MANUAL MOD A AND B | 40805000 | | 22 | 02.50 |
| ILLUSTRATED PARTS LIST (501 MODS C/D, 505 MODS A/B) | 50581600 | A | 22 | 02.35 |
| 501 HIGH SPEED LINE PRINTER REFERENCE MANUAL (MOD C AND D) | 40807200 | | 22 | 01.45 |
| 505 HIGH SPEED LINE PRINTER REF. MOD A/B | 40820800 | A | 22 | 02.50 |
| CUSTOMER ENGINEERING MANUALS | | | | |
| ILLUSTRATED PARTS LIST, MOD A AND B (501) | 40815200 | A | 34 | 04.70 |
| DIAGRAMS AND C/P (501 MOD C07-C14/D01-D08, 505 MOD A07-A14/B01-B07) | 40861700 | B | 22 | 01.80 |
| DIAGRAMS AND C/P (501 MOD C01-C06, 505 MOD A01-A06) | 40861800 | A | | 02.10 |
| DIAGRAMS AND C/P (501 MOD A01-A07, B01-B06) | 40862000 | A | 22 | 01.45 |
| DIAGRAMS AND C/P (501 MOD A08-A09, B07 AND B08) | 40862100 | B | 22 | 02.50 |
| DIAGRAMS AND CARD PLACEMENT (501 MOD A10-A11 B09-B10) | 40862200 | A | 22 | 01.40 |
| 512 (CL601) LINE PRINTER | | | | |
| 517 (CL835) LINE PRINTER | | | | |
| 580 LINE PRINTER EQUIPMENT | | | | |
| INTRODUCTION, ASSEMBLY PARTS LIST, PRINTED CIRCUIT CARDS, USED-ON INDEX PART I.D. MAN. CONTROLS AND INDICATORS, OPERATING PROCEDURE | 91858900 | A | 22 | 08.10 |
| OPERATOR MAINTENANCE OPERATORS HANDBOOK GEN. DESC., OPERATION AND PROGRAMMING, THEORY OF OPERATION, MAINTENANCE, PARTS DATA CE MAN | 91860400 | B | 22 | 01.55 |
| INTRODUCTION, OPERATING INSTRUCTIONS, PRINCIPLES OF OPERATIONS REFERENCE MANUAL | 91859000 | C | 22 | 02.35 |
| INSTALLATION AND CHECKOUT, PREVENTIVE/CORRECTIVE MAINTENANCE, PARTS REPLACEMENT FIELD SERVICE MANUAL VOL.1 | 91858600 | B | 22 | 08.90 |
| FIELD SERVICE MANUAL VOLUME II | 91858700 | B | 22 | 13.35 |
| 595 PRINT CARTRIDGE HARDWARE REFERENCE/CE MAN. GEN. DESC., THEO OF OPER., MAINT., PARTS DATA CE MANUAL | 91858800 | B01 | 22 | |
| TYPE D MANUAL | 44855800 | C | 22 | 01.00 |
| | 50582200 | D | 22 | 01.00 |
| | 91860100 | A | 22 | 01.75 |
| 599 DRUM PRINTER TESTER MAINTENANCE MANUAL | 40820500 | | 22 | 04.05 |
| 601 MAGNETIC TAPE TRANSPORT | | | | |
| DIAGRAMS AND WIRE LIST MOD A-B | 40812400 | B | 22 | 02.15 |
| MAINTENANCE MANUAL, MOD A AND B | 40815300 | G | 22 | 02.40 |
| PARTS LIST, MOD A, B AND C (4167) | 40862700 | A | 22 | 01.85 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------|----|----|-------|
| 602 MAGNETIC TAPE TRANSPORT | | | | |
| MAINTENANCE MANUAL, MOD A AND B (11/65) | 40815500 | A | 22 | 06.25 |
| DIAGRAMS AND WIRE LIST, MOD A AND B | 40815600 | A | 22 | 02.50 |
| 603 MAGNETIC TAPE TRANSPORT | | | | |
| ILLUSTRATED PARTS LIST, MOD F, G, H AND J | 40812700 | D | 22 | 06.80 |
| ILLUSTRATED PARTS LIST | PED2003 | A | 22 | 05.00 |
| MAINTENANCE MANUAL MODS A,B,C,D AND E (ECN21) | 40814800 | C | | 03.60 |
| MAINTENANCE MANUAL MOD F,G,H AND J (5165) | 40812600 | C | 22 | 02.40 |
| DIAGRAMS AND WIPE LIST, MOD A01-A04 (4/66) | 40823000 | B | | 03.00 |
| DIAGRAMS AND WIRE LIST, MOD B-E (12/65) | 40820300 | B | 22 | 02.35 |
| DIAGRAMS AND WIRE LIST, MOD F-J (9/66) | 40819400 | B | 22 | 02.80 |
| 604,606,607 MAGNETIC TAPE TRANSPORTS | | | | |
| ILLUSTRATED PARTS LIST | 40810800 | | | 11.20 |
| DIAGRAMS AND WIRE LIST, MODS A,B,C,D AND E | 40811500 | B | 22 | 09.60 |
| MAINTENANCE MANUAL MODS A,B,C,D AND E | 40812500 | C | 22 | 10.25 |
| 604-2 (8E101) MAGNETIC TAPE TRANSPORT | | | | |
| 605 MAGNETIC TAPE TRANSPORT | | | | |
| MAINTENANCE MANUAL, MOD G (8/65) | 40811800 | 1 | 22 | 04.00 |
| ILLUSTRATED PARTS LIST MOD G | 40811900 | | 3 | 03.50 |
| DIAGRAMS AND WIPE LIST, MOD G (8/65) | 40815400 | B | 22 | 05.30 |
| 606 MAGNETIC TAPE TRANSPORT | | | | |
| CE MAINTENANCE MANUAL, MOD G,H,J,K,L | 40811400 | 03 | | 01.50 |
| DIAGRAMS AND WIRE LIST, MOD G-L | 40812000 | C | 22 | 02.60 |
| MAINTENANCE MANUAL, MOD C AND E (11/65) | 40816500 | 1 | 22 | 03.00 |
| MAINTENANCE MANUAL MOD B AND N (2/66) | 40816800 | 1 | 22 | 03.00 |
| DIAGRAMS AND WIRE LIST, MOD C-E (12/65) | 40821200 | B | 22 | 04.00 |
| DIAGRAMS AND WIRE LIST, MOD 1 AND 2 (2/66) | 40822400 | B | 22 | 03.30 |
| DIAGRAMS AND WIRE LIST, MOD N03-N05 (2/66) | 40822500 | B | 22 | 03.30 |
| 607 MAGNETIC TAPE TRANSPORT | | | | |
| MAINTENANCE MANUAL MODS A,B,C,D,E AND F | 40815100 | D | 22 | 02.95 |
| DIAGRAMS AND WIRE LIST MANUAL, MOD A-F | 40821000 | E | 22 | 02.85 |
| DIAGRAMS, WIPE LIST, CIRC. DESC., C/P CE MAN | 49757600 | A | 22 | 01.95 |
| 607-2 (8E222) MAGNETIC TAPE TRANSPORT | | | | |
| 607 R MAGNETIC TAPE TRANSPORT MAINT CE MANUAL | 49757500 | A | 22 | 04.00 |
| 608 (8E102) MAGNETIC TAPE TRANSPORT | | | | |
| 609 (8E401) MAGNETIC TAPE TRANSPORT | | | | |
| 612 MAGNETIC TAPE TRANSPORT | | | | |
| MAINTENANCE MANUAL | 40819500 | 1 | 22 | 04.80 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|--|-----------------------|----------------------------|---|
| 626 MAGNETIC TAPE TRANSPORT ILLUSTRATED PARTS LIST, MOD B REFERENCE MANUAL, MOD B DIAGRAMS AND WIRE LIST MOD B,C,D,F,G (5/66) | PED2008 PED2214 40824000 | | 3 22 C 22 | 04.50 05.00 05.00 |
| 627 MAGNETIC TAPE TRANSPORT ILLUSTRATED PARTS LIST, MOD A REFERENCE MANUAL, MOD A DIAGRAMS AND WIRE LIST MOD A01 AND ABOVE | 40807700 40807800 40811200 | 01 3 E | 3 3 22 | 03.50 08.00 04.00 |
| 636 COMPUTER PROGRAMMING MANUAL | 22003300 | | | 04.00 |
| 657-1 (BE103) MAGNETIC TAPE TRANSPORT | | | | |
| 657-2 (BE104) MAGNETIC TAPE TRANSPORT | | | | |
| 657-3 (BE223) MAGNETIC TAPE TRANSPORT | | | | |
| 657-4 (BF224) MAGNETIC TAPE TRANSPORT | | | | |
| 659-1 (BF406) MAGNETIC TAPE TRANSPORT | | | | |
| 659-3 (BE408) MAGNETIC TAPE TRANSPORT | | | | |
| 659-4 (BE409) MAGNETIC TAPE TRANSPORT | | | | |
| 66X PSDG FIELD SERVICE MANUAL | 49751400 | E | 22 | 11.60 |
| 671 MAGNETIC TAPE TRANSPORT EXERCISER REFERENCE MANUAL DIAGRAMS, C/P, WIRE LIST MOD A01 AND ABOVE PARTS LIST MOD A | 40814200 40817200 40822000 | A C A | 22 22 22 | 01.50 01.00 01.25 |
| 673 (GK102) TAPE EXERCISER | | | | |
| 680 MAGNETIC TAPE CERTIFIER DIAGRAMS AND WIRE LIST MODS A,B DIAGS AND WIRE LIST MODS E-F MAINTENANCE MANUAL FOR MODS A THUR H PARTS LIST MODS A-D PARTS LIST MODS E-H | 40822800 40862600 40822200 60188800 41240100 | E E D B B | 22 22 22 22 22 | 04.60 05.00 02.90 02.90 10.95 |
| 680,685,690 MAGNETIC TAPE CERTIFIERS TECHNICAL INFORMATION MANUAL | 40822600 | | | 02.40 |
| 686 (GL102) TAPE CERTIFIER | | | | |
| 688 CLOSED LOOP AIR DUCT SYSTEM REFERENCE AND ILLUSTRATED PARTS LIST MANUAL | PED2216 | | | 04.50 |
| 689 TRANSPORT CHANNEL SWITCH/REFERENCE MOD A DIAGRAMS AND WIRE LIST, MOD A (1/65) | 40807900 40809100 | A A | 22 22 | 02.00 02.00 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------|---|----|-------|
| 690 MAGNETIC TAPE CERTIFIER TECHNICAL INFO MAN REFERENCE MANUAL, MOD B, C, D AND E | 40803400 | | | 02.50 |
| DIAGRAM AND WIRE LIST, MOD D AND E (7/65) | 40816000 | A | 22 | 10.00 |
| PARTS LIST, MODS B01-B03, C01-C03, D01-D04, E01-E04, F01-F04, G01-G04 | 40814600 | C | 22 | 04.15 |
| | 40814300 | C | 22 | 05.90 |
| 699 TAPE TRANSPORT EXERCISER/REFERENCE (MOD C) DIAGRAMS AND WIRE LIST MOD A, B AND F | 40803200 | | | 04.25 |
| MAINTENANCE MANUAL MODS A, B AND F | 40809500 | B | 22 | 01.50 |
| | 40814500 | A | 22 | 01.00 |
| 720 DIGITAL COMMUNICATIONS TERMINAL CONTROL UNIT REFERENCE MANUAL | 36814300 | | | 01.50 |
| DIAGRAMS CE MANUAL | 36823200 | | 34 | 01.75 |
| EQUATION FILE, CARD PLACEMENT, WIRE TABS, CABLE TABS, MAINTENANCE CE MANUAL | 36817400 | C | 22 | 02.50 |
| 720-G DIGITAL COMMUNICATION TERMINAL CONTROL DIAGRAMS CE MANUAL | 36823300 | | 34 | 01.75 |
| 730-100 (B8372-A) MEMORY EXPANSION FOR MEDIUM AND SLOW SPEED BATCH STATIONS | | | | |
| 733-10 (CE125-A/B, CL503-A/B, DT208-A, FV218-A/B, FV433-A, FV435-A) HIGH SPEED BATCH SUBSYSTEM/TERMINAL FUNCTIONAL CHARACTERISTICS AND PROGRAMMING OPERATORS MANUAL | 60329500 | B | 22 | 05.15 |
| FOR BUFFER CONTROLLER DIAGNOSTIC LISTINGS SEE FR113-A - CATALOG SECTION 1 | 60399500 | B | 22 | 07.00 |
| 733-101 (CF111-A/B, FV437-A) CARD PUNCH | | | | |
| 733-110 (CL503-A/B, FV437-A) TERMINAL LINE PRINTER | | | | |
| 733-120 (CE125-A/B, FV437-A) TERMINAL CARD READER | | | | |
| 733-130 (DJ152-A) TERMINAL ADAPTOR | | | | |
| 733-140 (B8377-A) MEMORY INCREMENT | | | | |
| 733-150 (CA115-A, CC102-A/B, FV434-A, FV436-A) KEYBOARD-DISPLAY | | | | |
| 733-152 (CA115-A, CC102-A/B, FV434-A/B) KEYBOARD-DISPLAY | | | | |
| 781 MAGNETIC TAPE CLEANER - GEN DESC., THEORY OF OP., DIAGRAMS, MAINT. CE MANUAL | 70611600 | A | 22 | 01.65 |
| OPERATORS MANUAL | 70611500 | A | 22 | 01.00 |
| CE MANUAL | 70616100 | A | 22 | 01.20 |
| OPERATORS GUIDE | 70616200 | A | 22 | 01.00 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|---|----|-------|
| 782 MAGNETIC TAPE CLEANER - GEN DESC., THEORY OF OP., DIAGRAMS, MAINT. CE MANUAL OPERATORS MANUAL | 70611800 | A | 22 | 04.30 |
| | 70611700 | A | 22 | 01.00 |
| 783 MAGNETIC TAPE CLEANER - GEN DESC., THEORY OF OP., DIAGRAMS, MAINT. CE MANUAL OPERATORS MANUAL | 70612000 | A | 22 | 02.00 |
| | 70611900 | A | 22 | 01.20 |
| 791-1 (DT137-A, DT138-A, DT139-A, FJ424-A/B/C) COMMUNICATIONS SUBSYSTEM REFERENCE MANUAL | 60325100 | B | 22 | 03.35 |
| 807/808 DISK FILES--ALSO LISTED AS BH411/BH412 DIAGRAMS AND W/L MODS A01-A08, B02-B08 DIAGS AND WIRE LIST MODS A09 AND ABOVE MAINTENANCE MOD A PARTS LIST MOD A | 40862500 | R | 22 | 12.90 |
| | 70605400 | B | 22 | 06.40 |
| | 40823400 | D | 22 | 09.20 |
| | 40824300 | B | 22 | 03.40 |
| 813/814 DISK FILE DIAGRAMS,C/P,WIRE LIST MODS A01-A05,B01-B05 DIAGRAMS AND WIRE LIST MODS A06, B06 MAINTENANCE MANUAL MODS A AND B PARTS LIST THEO OF OPERATION MAINTENANCE AIDS | 40827500 | J | 22 | 04.10 |
| | 70601100 | D | 22 | 06.75 |
| | 40824800 | E | 22 | 07.30 |
| | 40863300 | B | 22 | 03.75 |
| | 40865200 | B | 22 | 02.50 |
| 817 DISK FILE--LISTED AS BH405 | | | | |
| 821 DISK FILE--LISTED AS BH408 AND BH410 | | | | |
| 828 DISK FILE CE INSTRUCTION MANUAL CE DIAGRAMS | 60099400 | | 22 | 05.80 |
| | 60099500 | | 34 | 04.50 |
| 841 MULTIPLE DISK DRIVE REFER TO BM101, BM102, BM103, BM104 | | | | |
| 844-2 () DISK STORAGE UNIT GENERAL INFO (USE 7054-1) OPERATION AND PROGRAMMING (USE 7054-1) | | | | |
| 852 DISK STORAGE DRIVE MAINTENANCE MANUAL MOD A/B PARTS LIST MOD A AND B DIAGRAMS AND WIRE LISTS MOD A AND B | 40820000 | B | 22 | 06.00 |
| | 40825000 | B | | 02.00 |
| | 40825100 | H | 22 | 05.40 |
| 853 DISK STORAGE DRIVE DIAGS AND W/L MODS A01-A09,B01-B09 DIAGS,CIR DES,C/P,W/L, MODS A10-A11,B10-B11 MAINTENANCE MANUAL MOD A,B MAINTENANCE MANUAL MODS A12, B12 AND ABOVE PARTS LIST MODS A01-A11,B01-B11 DIAGRAMS,CIPC DESC., C/P, W/L MODS A12 PARTS LIST MODS A12 ABOVE B12 ABOVE | 40825600 | P | 22 | 03.15 |
| | 41240900 | F | 22 | 02.50 |
| | 40823100 | E | 22 | 05.60 |
| | 41245700 | C | 22 | 05.50 |
| | 40826300 | D | 22 | 02.30 |
| | 41247300 | E | 22 | 02.50 |
| | 41244100 | D | 22 | 02.40 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------|----|----|-------|
| ABOVE, B12 AND ABOVE | | | | |
| 854 DISK STORAGE DRIVE | | | | |
| DIAGRAMS AND WIRE LISTS MANUAL MODS A,B | 40824900 | W | 22 | 01.95 |
| DIAGS, CIRC., DESC. C/P, W/L MODS A10-A11, B10-B1 | 41241000 | F | 22 | 02.10 |
| DIAGS, AND WIRE LIST MODS A12, B12 | 41247400 | F | 22 | 02.00 |
| J12, K12 | | | | |
| MAINTENANCE MANUAL MODS A, B | 40823200 | E | 22 | 02.10 |
| MAINT. MAN. MOD A12, B12, AND ABOVE | 41245800 | E | 22 | 03.80 |
| PARTS LIST MOD A AND B | 40826400 | D | 22 | 07.35 |
| PARTS LIST MODS A12 AND ABOVE AND B12 ABOVE | 41244200 | E | 22 | 01.80 |
| 857 DISK STORAGE DRIVE--LISTED AS BJ104 | | | | |
| 861/863/865 DRUM STORAGE UNIT REFERENCE MANUAL (SEE 3000 PER EQUIP REF MANUAL REV J) | | | | |
| 861-B/863-B, 863-C/BG108-C DRUM STORAGE UNITS | 60210300 | D | 22 | 10.10 |
| DIAGS, CIRC DESC, MAINT, C/P, EQ SUMMARY W/L | | | | |
| PARTS LIST | 70606800 | A | 22 | 02.30 |
| 863-C DRUM STORAGE UNIT (USE BG108-C/D) | | | | |
| 865 DRUM STORAGE UNIT--LISTED AS BG113 | | | | |
| 897 DISK FILE CLOCK/TRACK VERIFICATION ADDRESS | 40862400 | B | 22 | 08.40 |
| WRITER GEN. DESC. INST. AND CHKOUT. OPERATION | | | | |
| DIAG. MAINT, MAINT P/DATA W/L CE MANUAL | | | | |
| 898 DISK STORAGE DRIVE EXERCISER CE MANUAL | 40860400 | C | 22 | 06.70 |
| MOD A AND B | | | | |
| 899 DISK STORAGE DR EXERCISER MAINT MANUAL | 40860500 | C | 22 | 05.90 |
| 915 PAGE READER | | | | |
| GRASP II (GENERALIZED READ AND SIMULATE | 48704702 | 04 | 3 | 02.35 |
| PROGRAM) A GENERALIZED DATA CAPTURING SYS. | | | | |
| FOR 915 OCR PAGE READING SYSTEMS OPERATOR | | | | |
| INFORMATION MANUAL | | | | |
| GRASP - 8090/160-A OCR SOFTWARE REF MAN. | 48996600 | A | 3 | 03.65 |
| THEORY OF OPERATION MANUAL | 48430170 | A | 3 | 01.20 |
| PARTS LIST MODS C, D, E, F | 40862900 | B | 22 | 05.00 |
| PARTS LIST A/B SUPPLEMENT | 40863900 | A | 22 | 04.00 |
| 915/919 OCR MEDIA MANUAL | 91566700 | | 3 | 06.50 |
| 915/1700 PAGE READER SETUP SOFTWARE REF MAN | 48143910 | 02 | | 01.30 |
| 921 DOCUMENT READER OCR MEDIA MANUAL | 60216104 | C | 3 | 02.20 |
| THEORY OF OPERATION | 48780800 | 02 | 3 | 01.15 |
| 921/8092 OCR DOCUMENT READER | 87900200 | | | 10.55 |
| SYSTEM OPERATING AND PROGRAMMING GUIDE | | | | |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------------------|-----|----|----------------|
| 924-A COMPUTER REFERENCE MANUALS | | | | |
| PERIPHERAL EQUIPMENT CODES | 60026700 | | | 01.50 |
| I/O SPECIFICATION AND INSTALLATION REFERENCE MANUAL | 60027100 60027400 | | | 03.00 03.75 |
| INSTRUCTION CARD | 60070300 | | | 00.75 |
| CUSTOMER ENGINEERING MANUALS | | | | |
| CE DIAGRAMS | 60027500 | S | 34 | 09.60 |
| CE INSTRUCTION MANUAL | 60094100 | A | 22 | 03.30 |
| PARTS LIST CE MANUAL | 60017300 | | 22 | 06.70 |
| 924-B COMPUTER REFERENCE MANUALS | | | | |
| I/O SPECIFICATION AND INSTALLATION REFERENCE MANUAL | 60013700 60016800 | | 22 | 03.75 06.00 |
| CUSTOMER ENGINEERING MANUALS | | | | |
| CE MAINT/INSTRUCTION MANUAL | 60017000 | B | 22 | 08.85 |
| CE DIAGRAMS | 60017100 | F | 34 | 10.00 |
| 925-A MAGNETIC TAPE CONTROLLER REFERENCE MANUAL | 60029300 | B | | 03.00 |
| DIAGRAMS | 60048900 | G,H | 34 | 01.75 |
| CE INSTRUCTION MANUAL | 60090300 | A | 22 | 04.65 |
| CARD PLACEMENT, EQUATION SUMMARY | 60287100 | B | 22 | 08.20 |
| (THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES. ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.) | | | | |
| CARD PLACEMENT, CHASSIS 33 100 | 24105200 | D | | |
| CARD PLACEMENT, CHASSIS 33 200 | 24105300 | | | |
| EQUATION SUMMARY | 24106100 | G | | |
| 925-S MAGNETIC TAPE SYNCHRONIZER CE INSTRUCTION AND REFERENCE MANUAL (REFER TO 925-A) | | | | |
| (THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES. ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.) | | | | |
| CARD PLACEMENT | 24345000 | A | | |
| CE DIAGRAMS | 60106300 | C | 34 | |
| 926-A MAGNETIC TAPE CONTROLLER PRELIMINARY REFERENCE MANUAL | 60044800 | A | | 02.80 |
| CE DIAGRAMS | 60093100 | E | 34 | 03.00 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|-----|----|-------|
| CE INSTRUCTION MANUAL | 60094600 | | 22 | 02.40 |
| 929 OCR DOCUMENT READER THEORY OF OPERATION | 91604200 | | | 01.50 |
| MEDIA MANUAL | 91604300 | A | 22 | 03.40 |
| SYSTEMS OPERATORS GUIDE | 87978800 | A | 22 | 02.60 |
| 935 OCR DOCUMENT READER SYSTEM REF/OPERATIONS MANUAL | 60270700 | 01 | 22 | 06.50 |
| 935 SETUP REFERENCE MANUAL | 48704810 | 04 | 3 | 03.00 |
| OCR MEDIA MANUAL | 60216101 | 02 | 3 | 03.15 |
| OCR DOCUMENT READER THEORY OF OPERATIONS | 48704850 | 02 | 3 | 03.60 |
| DITO (DOCUMENT IN-TAPE OUT) OCR 1700/SC1700 COMPILER SYSTEMS SOFTWARE REF MAN | 48781100 | 02 | 3 | 02.55 |
| 955 PAGE AND DOCUMENT READER CONTROLLER REFERENCE MANUAL | 60324600 | C | 22 | 06.55 |
| THEORY OF OPERATIONS | 48430070 | A | 3 | 01.00 |
| SYSTEMS OPERATORS GUIDE VOL.2 | 48643305 | 02 | 3 | 06.00 |
| SETUP SOFTWARE REFERENCE MANUAL | 48430050 | 03 | 3 | 01.80 |
| 955/959 PAGE AND DOCUMENT READER THEORY OF OPERATION | 91604400 | | | 01.50 |
| OCR MEDIA MANUAL | 91604500 | B | 22 | 01.20 |
| 1010 INPUT STATION REFERENCE MANUAL | 36817700 | A | 22 | 02.50 |
| CE DIAGRAMS MANUAL | 36817900 | B | 34 | 01.50 |
| SUPPLEMENT TO DIAGRAMS MANUAL 36817900 | 65699100 | | 34 | 01.00 |
| ILLUSTRATED PARTS LIST | 36820500 | | 22 | 03.75 |
| 1020 INPUT STATION REFERENCE MANUAL | 36818000 | C | 22 | 03.50 |
| MAINTENANCE MANUAL | 36818100 | D | 22 | 03.00 |
| SUPPLEMENT I TO MAINTENANCE MAN - 36818100 | 36828600 | | | 01.00 |
| DIAGRAMS | 36818200 | K | 34 | 12.15 |
| PARTS LIST | 36820600 | D | 22 | 02.30 |
| MULTI-WIRE SEARCH UNIT SUPPLEMENT | 36824500 | | 22 | 01.00 |
| DIAGRAMS AND WIRE LIST SUPPLEMENT TO 1020/1021 | 36828700 | B | 34 | 02.85 |
| 1022/1023/2022 DATA COLLECTOR CONTR. REFERENCE | 36826500 | | 22 | 01.00 |
| 1025-E INPUT STATION REFERENCE MANUAL | 13792900 | B | 22 | 01.00 |
| CE MAINTENANCE CE MANUAL | 13793000 | D | 22 | 03.00 |
| ILLUSTRATED PARTS MANUAL | 13797700 | H | 22 | 02.90 |
| QSE 1257-A,B PRINTER STATION REF/CE MANUAL | 82115700 | 800 | 22 | 01.00 |
| 1500 INPUT/OUTPUT EQUIPMENT MANUALS | | | | |
| DATA AND CONTROL TERMINAL (DCT 30) HARDWARE REFERENCE/CE MANUAL | 84894200 | A | 22 | 07.00 |
| PERIPHERAL EQUIPMENT SITE PREPARATION MAN. | 39230300 | C | 22 | 05.25 |
| REMOTE I/O SUBSYSTEM HDWF REF/CE MANUAL | 39150100 | | 22 | 10.35 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|---|----|-------|
| TELEMETRY CONTROL CHANNEL/TELEMETRY DATA FORMATTER(TCC/TDF)OPER AND MAINT INSTR MAN | 84837900 | | 22 | 11.50 |
| EB306 +128V (+100V) 15- BIT MULTIPLYING DIGITAL TO ANALOG CONVERTER HARDWARE REF./CE MANUAL | 84937300 | A | 22 | 04.35 |
| ED101-A, ED102-A, ED103-A HIGH LEVEL ANALOG MULTIPLEXER HOWE REF./CE MANUAL | 39278700 | A | 3 | 01.20 |
| 1500 SERIES CONFIGURATOR | 60187500 | | | 01.25 |
| 1501-10 (ED105-A) ANALOG INPUT MULTIPLEXER | | | | |
| 1501-11 (ED106-A) ANALOG INPUT MUX EXPANDER | | | | |
| 1525-2 (EA102-A) ANALOG TO DIGITAL CONVERTER | | | | |
| 1525-3 (EA309-A) ANALOG TO DIGITAL CONVERTER | | | | |
| 1530 ANALOG INPUT INTERFACE HRDW/REF/CE MAN | 39153300 | B | 22 | 03.50 |
| 1530/1534 ANALOG INPUT CONTROLLER OPER AND MAINTENANCE INSTRUCTION | 39073900 | A | | 02.40 |
| 1531 MERCURY-WETTED RELAY MULTIPLEXER INCLUDING 1563 SIGNAL CONDITIONER HARDWARE REFERENCE/CUSTOMER ENGINEERING MANUAL | 39074100 | A | 22 | 01.85 |
| 1533/1535/1563 RELAY MULTIPLEXER AND SIGNAL CONDITIONING UNIT | 39074200 | A | 3 | 08.30 |
| 1534 ANALOG INPUT INTERFACE HARDWARE/REF. CE MANUAL | 39153400 | B | 22 | 10.00 |
| 1538 HIGH SPEED, HIGH LEVEL ANALOG INPUT INTERFACE OPERATION AND MAINTENANCE | 39074500 | D | 3 | 13.35 |
| 1544-1 (DA101-B) DIGITAL INPUT UNIT | | | | |
| 1544-2 (DA101-A) DIGITAL INPUT UNIT | | | | |
| 1544-3 (DA401-B) DIGITAL INPUT UNIT | | | | |
| 1544-4 (DA401-A) DIGITAL INPUT UNIT | | | | |
| 1544/1545/1564 DIGITAL INPUT SUBSYSTEM OPERATION AND MAINTENANCE | 39073300 | D | 3 | 09.60 |
| 1546/1547 EVENT COUNTER SUBSYSTEM OPER AND MAINT INSTRUCTION | 39070800 | B | | 03.70 |
| 1547-1 (FT1A1-A) EVENTS COUNTER UNIT | | | | |
| 1547-2 (FT1A1-B) EVENTS COUNTER UNIT | | | | |
| 1548/1549 EXTERNAL INTERRUPT SUBSYSTEM OPER AND MAINTENANCE | 39073400 | C | 22 | 06.75 |
| 1553/1554 EXTERNAL REGISTER OUTPUT SUBSYSTEM OPER AND MAINTENANCE | 39073500 | C | 3 | 08.80 |
| 1555 POWER DRIVE OUTPUT UNIT AND RELAY OUTPUT UNIT | 39073600 | B | 22 | 02.65 |
| 1555-1 (DF3A1-A) RELAY OUTPUT UNIT | | | | |
| 1555-2 (DF3A1-B) RELAY OUTPUT UNIT | | | | |
| 1555-4 (DF3A1-A) RFLAY OUTPUT UNIT | | | | |
| 1556 ANALOG (DAC) OUTPUT UNIT OPER AND MAINT INSTRUCTION | 39074300 | A | 22 | 02.00 |
| 1558 LATCHING RELAY OUTPUT INTERFACE OPER AND MAINT. INSTRUCTION | 39073700 | | 22 | 06.70 |
| 1559 LATCHING RELAY CONTACT OUTPUT UNIT OPER AND MAINT INSTRUCTION | 39073800 | A | | 01.35 |
| 1560 LATCHING RELAY ANALOG (DAC) OUTPUT UNIT OPER AND MAINT INSTRUCTION | 39074400 | | 3 | 02.30 |
| 1561 ANALOG OUTPUT INTERFACE OPER AND MAINT INSTRUCTION | 39075000 | A | 22 | 01.90 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|---|----|-------|
| 1567, ADSE 3005 AND ADSE 3014 SIMULTANEOUS SAMPLE AND HOLD MODS OPER AND MAINT INSTR | 84851100 | | 22 | 04.50 |
| 1567 SIMULTANEOUS SAMPLE AND HOLD UNIT OPER, MAINT INSTR MANUAL | 39071400 | | 22 | 01.45 |
| 1568/420C ANALOK ANALOG MEMORY OUTPUT UNITS OPER AND MAINT INSTRUCTION | 39071500 | A | | 02.65 |
| 1570 SERIES TERMINATION PANELS/OPERATION AND MAINTENANCE | 39071900 | C | 22 | 06.00 |
| 1571 CHAINING BUFFER CHANNEL OPERATION AND MAINTENANCE INSTRUCTION MANUAL | 39073100 | B | 22 | 18.70 |
| 1572 PROGRAMMABLE SAMPLE RATE UNIT OPERATION AND MAINT INSTRUCTION | 39070900 | C | 22 | 01.55 |
| GENERAL DESCRIPTION, OPERATION AND PROG., THEORY OF OPERATION, MAINTENANCE, DIAGRAMS PARTS LIST AND WIRE LISTS CE MANUAL | 39359900 | B | 22 | 01.50 |
| 1572-1 (GA128-A) SAMPLE TIMING UNIT | | | | |
| 1576 (FV4A3/498) STALL ALARM UNIT REF/CE MAN | 88981000 | A | 22 | 03.70 |
| 1577 STALL ALARM HARDWARE REF/CE MANUAL | 84781600 | B | 3 | 05.30 |
| 1581 LOGGING TYPEWRITER INTERFACE OP/MAINT CE MANUAL | 39075200 | A | 22 | 02.80 |
| 1583 I/O TYPEWRITER INTERFACE HARDWARE/REF. CE MANUAL | 39075300 | A | 22 | 02.25 |
| 1585 INCREMENTAL PLOTTER CONTROLLER HARDWARE REFERENCE CE MANUAL | 39072600 | B | 22 | 01.90 |
| 1587/1557 MONITOR AND CONTROL PANELS OPER AND MAINTENANCE INSTRUCTION MANUAL | 39071300 | B | 22 | 02.50 |
| 1590-3 REMOTE COMPUTER INTERFACE SUBSYSTEM HARDWARE REFERENCE CE MANUAL | 39909513 | A | 22 | 21.00 |
| 1595-10 (DK605-A) SERIAL I/O UNIT | | | | |
| 1595-11 (DK605-A) SERIAL I/O UNIT | | | | |
| 1595-20 (DK605-B) SERIAL I/O UNIT | | | | |
| 1595-21 (DK605-B) SERIAL I/O UNIT | | | | |
| 1604-A COMPUTER | | | | |
| INSTALLATION MAN | 60002000 | E | | 03.00 |
| PERIPHERAL EQUIPMENT CODES | 60025700 | B | | 01.00 |
| PROGRAM CARD (SA185C) | 60070400 | | | .75 |
| REFERENCE MANUAL | 60024500 | | | 03.50 |
| SPECIFICATIONS (I/O) | 60024400 | E | | 03.25 |
| CUSTOMER ENGINEERING MANUALS | | | | |
| CE DIAGRAMS | 60024300 | J | 34 | 12.00 |
| CE INSTRUCTION MANUAL PART 1, THEORY OF OPERATION | 60118700 | A | 22 | 05.75 |
| CE INSTRUCTION MANUAL PART 2, MAINTENANCE EQUATION SUMMARY | 60118800 | A | 22 | 04.40 |
| | 60116000 | A | 34 | 20.00 |
| 1604-B COMPUTER | | | | |
| REFERENCE MANUALS | | | | |
| I/O SPECIFICATIONS | 60110100 | B | 22 | 05.10 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|---|----|-------|
| CUSTOMER ENGINEERING MANUALS | | | | |
| CE DIAGRAMS (STANDARD OPTION 10003) | 60090800 | R | 34 | 10.00 |
| CE INSTRUCTION MANUAL, PART 2, MAINTENANCE CHASSIS MAPS (SEE 1604-C) | 60126800 | | 22 | 05.75 |
| 1604-C/1604-A COMPUTER (PREVIOUSLY 1604/1604-A) | | | | |
| PROGRAMMING TRAINING MANUAL | 60001500 | A | 22 | 10.40 |
| REFERENCE MANUAL | 60016700 | F | 22 | 04.60 |
| SPECIFICATIONS (I/O) | 60003000 | C | | 02.00 |
| CUSTOMER ENGINEERING MANUALS | | | | |
| PRINCIPLES OF OPERATION INSTR. BOOK | 60003200 | B | | 02.00 |
| PART 3 MAINTENANCE | 60003300 | B | | 05.80 |
| CE DIAGRAMS | 60003500 | S | 34 | 14.00 |
| MAINTENANCE LIBRARY | 60006600 | A | | 03.70 |
| CHASSIS MAPS, 1604-B | 60025600 | D | 22 | 10.00 |
| TROUBLE SHOOTING AIDS | 60028100 | B | 22 | 02.30 |
| EQUATION SUMMARY, PART 1 | 60070500 | C | 22 | 14.00 |
| EQUATION SUMMARY, PART 2 | 60070600 | A | 22 | 12.50 |
| EQUATION SUMMARY, PART 3 | 60070700 | A | 22 | 13.00 |
| 1605-A ADAPTER | | | | |
| (THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES.ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.) | | | | |
| DESCRIPTION, OPERATION AND MAINTENANCE VOL 1 | 60003600 | B | | |
| 1606-A PRINT CONTROL UNIT | | | | |
| THEO OF OPER, DIAGS, C/P, EQ SUM, W/L, WIRE TABS, CABLE TABS, REFERENCE/CE MANUAL | 60004400 | A | 22 | 08.30 |
| 1607-A MAGNETIC TAPE SYSTEM (PREVIOUSLY 1607) | | | | |
| DESCRIPTION, OPERATION AND MAINTENANCE | 60003700 | A | 22 | 08.70 |
| CE DIAGRAMS | 60014700 | S | 22 | 02.00 |
| EQUATION SUMMARY, CARD PLACEMENT | 60014800 | E | 22 | 08.40 |
| (THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES.ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.) | | | | |
| CHARACTERISTICS | 60004100 | A | | |
| 1608 CONTROL UNIT | | | | |
| VOL.1, DESCRIPTION, OPERATION AND MAINTENANCE | 60016400 | | | 04.25 |
| CE DIAGRAMS | 60016500 | A | 22 | 01.60 |
| CARD PLACEMENT AND EQUATION SUMMARY | 60016600 | A | 22 | 07.95 |
| WIRE LIST, WIRE TABS (1608-A) | 60148500 | A | 22 | 03.40 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------------------------------|-------------------|----------------|-------------------------|
| 1609-A CARD READ AND PUNCH UNIT VOL. 1, DESCRIPTION AND OPERATION MAINTENANCE, VOLUME 2 VOL.3 DIAGRAMS CE MANUAL | 60017800 60017900 60018900 | A | 22 34 | 03.25 05.60 01.65 |
| 1610-A CONTROL UNIT VOL 1 DESCRIPTION AND OPERATION VOL. 2 MAINTENANCE CE DIAGRAMS | 60010600 60010700 60018800 | A A A | 22 22 34 | 04.50 10.80 07.00 |
| 1611-A LINE PRINTER CONTROLLER REFERENCE/CE MANUAL | 60127500 | F,G | 22 | 07.60 |
| 1612-A HIGH SPEED LINE PRINTER OPERATION AND MAINTENANCE MANUAL | 60009800 | B | 22 | 18.50 |
| 1612G LINE PRINTER CE MANUAL 1612-G LINE PRINTER AND OFF LINE BUFFER EQUATION SUMMARY MANUAL 1612-B CROSS TABS AND 1612-G WIRE LIST 1612 TESTS (REFER TO 1612-A) | 60098200 60145100 60151000 | H,J D,E D,E | 22 22 22 | 10.50 05.00 04.00 |
| 1614-A CARD READER CONTROLLER REFERENCE/INSTRUCTION MANUAL CARD PLACEMENT AND EQUATION SUMMARY | 60091700 60287000 | D A | 22 | 03.75 02.00 |
| 1615/160 CHANNEL LONG LINE DRIVERS CE MANUAL | 60123700 | A | | 00.75 |
| 1615-A MAGNETIC TAPE CONTROLLER REFERENCE MANUAL DIAGRAMS PRELIMINARY CE MANUAL | 60027200 60027600 60097100 | A E A | 3 22 22 | 03.00 03.70 05.90 |
| 1617-A CARD READER (THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES.ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.) VOL 1 DESCRIPTION,OPERATION,PROGRAMMING VOL.2, MAINTENANCE PARTS LIST | 60021400 60021500 | A B | 22 | |
| 1619-A MAGNETIC DISK FILE CONTROLLER REFERENCE MANUAL CE DIAGRAMS CE INSTRUCTION MANUAL (THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES.ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.) WIRE TABS | 60044900 60029200 60107100 | C | 34 22 | 03.00 03.50 03.90 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------|---|----|-------|
| CHASSIS 1 | 22914000 | G | | |
| CHASSIS 2 | 22913900 | J | | |
| CHASSTS 3 | 22913800 | F | | |
| CHASSIS 2 TO 3 | 22913700 | H | | |
| CABLE TABS | | | | |
| CHASSIS 1 | 22914200 | J | | |
| CHASSIS 2 | 22914300 | F | | |
| CHASSIS 3 | 22914400 | K | | |
| 1631 DATA CHANNEL CONVERTER | | | | |
| REFERENCE MANUAL-DESC, OPERATION, PROGRAMMING | 38704400 | B | 22 | 01.55 |
| DIAGS, P/L, C/P, EQ SUM, W/L CE MANUAL | 38704500 | D | 22 | 06.00 |
| 1700 COMPUTER SYSTEM | | | | |
| COMMUNICATIONS AND EQUIPMENT REFERENCE MAN. | 13795000 | B | 22 | 03.10 |
| COMPUTER SYSTEM REFERENCE MANUAL | 60153100 | F | 22 | 01.50 |
| COMPUTER SYSTEMS CODES | 60163500 | H | 6 | 01.35 |
| INPUT/OUTPUT SPECIFICATIONS MANUAL | 60165800 | H | 22 | 01.35 |
| SMM17 ERROR CODES INSTANT | 60266200 | G | | 06.00 |
| SMM17 REFERENCE MANUAL - VOLUMES 1 AND 2 | 60182000 | M | 22 | 50.80 |
| SYSTEM 17 INSTALLATION MANUAL | 88996000 | A | 22 | 12.30 |
| CUSTOMER ENGINEERING MANUALS | | | | |
| 6VDC POWER SUPPLY HARDWARE/REF/CE MAN | 39072400 | | | 01.00 |
| 24VDC POWER SUPPLY HDWE REFERENCE/CE MANUAL | 39072200 | | 3 | 01.00 |
| AT171A, B THREE-PORT A/Q AND INTERRUPT SWITCH | 39412900 | A | 22 | 04.65 |
| HDWR/REF CE | | | | |
| AT172A THREE-PORT DSA SWITCH HDWR/REF MAN. | 39415100 | A | 22 | 05.70 |
| ADSE 8013 21- TRACK MAGNETIC TAPE CONTROLLER | 84970400 | | 22 | 17.00 |
| (MTC) HARDWARE REF./CE MANUAL | | | | |
| DC115B BUFFERED INPUT/OUTPUT INTERFACE | 39308000 | A | 3 | 05.50 |
| HARDWARE REFERENCE CE MANUAL | | | | |
| SEISMIC DECOMMUTATION CHANNEL/WORD ASSEMBLY | 39185900 | | 22 | 05.60 |
| CONTROL HARDWARE REFERENCE/CE MANUAL | | | | |
| SMM17 PROGRAM LISTINGS - MEM | 60220100 | F | 22 | 07.35 |
| SMM17 PROGRAM LISTINGS - COM | 60220200 | E | 22 | 07.10 |
| SMM17 PROGRAM LISTINGS - PTP | 60220300 | E | 22 | 07.60 |
| SMM17 PROGRAM LISTINGS - PTR | 60220400 | E | 22 | 05.10 |
| SMM17 PROGRAM LISTINGS - TTY | 60220500 | F | 22 | 04.85 |
| SMM17 PROGRAM LISTINGS - CR1 | 60220600 | D | 22 | 06.20 |
| SMM17 PROGRAM LISTINGS - MT1 | 60220700 | E | 22 | 08.90 |
| SMM17 PROGRAM LISTINGS - DP1 | 60220800 | F | 22 | 08.90 |
| SMM17 PROGRAM LISTINGS - RPT | 60220900 | F | 22 | 01.95 |
| SMM17 PROGRAM LISTINGS - BD1 | 60221000 | D | 22 | 05.90 |
| SMM17 PROGRAM LISTINGS - SC1 | 60221100 | F | 22 | 10.50 |
| SMM17 PROGRAM LISTINGS - LP1 | 60221200 | F | 22 | 08.05 |
| SMM17 PROGRAM LISTINGS - MT2 | 60221300 | E | 22 | 06.75 |
| SMM17 PROGRAM LISTINGS - BD2 | 60221400 | D | 22 | 10.60 |
| SMM17 PROGRAM LISTINGS - BTB | 60221500 | C | 22 | 03.90 |
| SMM17 PROGRAM LISTINGS - DSC | 60221600 | E | 22 | 01.70 |
| SMM17 PROGRAM LISTINGS - MT3 | 60221700 | G | 22 | 09.35 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------|---|----|-------|
| SMM17 PROGRAM LISTINGS - CRP 1728/430 CARD READER/PUNCH CE MANUAL | 60271300 | F | 22 | 13.20 |
| SMM17 PROGRAM LISTINGS - (CR3) 1729-2/411 CARD READER | 60271400 | F | 22 | 10.65 |
| SMM17 PROGRAM LISTINGS - (CR2)1726/405 CARD READER | 60271500 | E | 22 | 08.65 |
| SMM17 PROGRAM LISTINGS - (DS1) 1747 DATA SET CONTROLLER | 60271600 | D | 22 | 04.40 |
| SMM17 PROGRAM LISTINGS - 1735/915 OCR OPTICAL CHARACTER READER CE MANUAL | 60271700 | F | 22 | 20.70 |
| SMM17 PROGRAM LISTINGS (CLK) 10126 INTERVAL TIMER CE MANUAL | 60271800 | C | 22 | 03.40 |
| SMM17 PROGRAM LISTINGS (CTC) 1749/321-311B COMMUNICATIONS TERMINAL CONTROLLER | 60271900 | D | 22 | 09.25 |
| SMM17 DDC 1745/1746/210 DATA DISPLAY CE MAN | 60273200 | E | 22 | 12.55 |
| SMM17 PROGRAM LISTINGS - OC3 FF406 TEST CE | 60309200 | E | 22 | 18.65 |
| SMM17 PROGRAM LISTINGS (FFT) FAST FOURIER TRANSFORM | 60309300 | B | 22 | 09.25 |
| SMM17 PROGRAM LISTINGS (CR4) 405/DTB TEST | 60309400 | C | 22 | 02.75 |
| SMM17 PROGRAM LISTINGS (DAD) DUAL ACCESS DISK TEST CE MANUAL | 60309500 | B | 22 | 05.45 |
| SMM17 PROGRAM LISTINGS - CAR | 60325600 | C | 22 | 01.00 |
| SMM17 PROGRAM LISTINGS - DDT | 60325700 | C | 22 | 02.80 |
| SMM17 PROGRAM LISTINGS - MTS | 60325800 | E | 22 | 04.05 |
| SMM17 PROGRAM LISTINGS - D1G | 60325900 | C | 22 | 05.20 |
| SMM17 PROGRAM LISTINGS - OC2 | 60326100 | C | 22 | 05.10 |
| SMM17 PROGRAM LISTINGS - BC1 | 60326200 | C | 22 | 03.70 |
| SMM17 PROGRAM LISTING - AC4 | 60326300 | A | 22 | 06.20 |
| SMM17 PROGRAM LISTINGS - OC4 | 60326400 | D | 22 | 13.40 |
| SMM17 PROGRAM LISTINGS - QL | 60411300 | C | 22 | 04.95 |
| SMM17 PROGRAM LISTINGS - SMM | 60411400 | C | 22 | 10.80 |
| SMM17 PROGRAM LISTINGS - DMP | 60411500 | C | 22 | 03.10 |
| SMM17 PROGRAM LISTING - PNY | 60411600 | A | 22 | 06.45 |
| SMM17 PROGRAM LISTINGS - UD3 | 60411700 | B | 22 | 02.05 |
| SMM17 PROGRAM LISTINGS - RX1 | 60411800 | C | 22 | 05.90 |
| SMM17 PROGRAM LISTINGS - LDR/RX3 | 60411900 | C | 22 | 08.40 |
| SMM17 PROGRAM LISTINGS - RX4 | 60412000 | C | 22 | 10.20 |
| SMM17 PROGRAM LISTINGS - AQM | 60412100 | C | 22 | 15.25 |
| SMM17 PROGRAM LISTINGS - LST | 60412200 | C | 22 | 03.85 |
| SMM17 PROGRAM LISTINGS - SAS | 60412300 | B | 22 | 03.85 |
| SMM17 PROGRAM LISTINGS - MCC | 60412400 | C | 22 | 21.55 |
| SMM17 PROGRAM LISTINGS - LPX | 60412500 | B | 22 | 04.65 |
| SMM17 PROGRAM LISTING - DG4 | 60412600 | B | 22 | 04.45 |
| SMM17 PROGRAM LISTINGS - CDD | 60412700 | C | 22 | 17.85 |
| SMM17 PROGRAM LISTINGS - DRM | 60412800 | D | 22 | 11.40 |
| SMM17 PROGRAM LISTINGS - GTR | 60412900 | C | 22 | 10.35 |
| SMM17 PROGRAM LISTINGS - D10 | 60413000 | B | 22 | 02.05 |
| SMM17 PROGRAM LISTINGS - IOM | 60413100 | C | 22 | 11.65 |
| SMM17 PROGRAM LISTING - RMT | 60413200 | A | 22 | 02.70 |
| SMM17 PROGRAM LISTING - RD3 | 60413300 | A | 22 | 02.60 |
| SMM17 PROGRAM LISTING - CP1 | 60413400 | A | 22 | 02.20 |
| SMM17 PROGRAM LISTING - CP2 | 60413500 | A | 22 | 02.35 |
| SMM17 PROGRAM LISTING - HCA | 60413600 | A | 22 | 03.75 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|---|----|-------|
| SMM17 PROGRAM LISTING - DP2 | 60413700 | A | 22 | 03.75 |
| SMM17 PROGRAM LISTING - RD4 | 60413800 | A | 22 | 04.05 |
| SMM17 PROGRAM LISTINGS - DP3 | 60413900 | D | 22 | 15.60 |
| SMM17 PROGRAM LISTING - DP4 | 60414000 | A | 22 | 03.00 |
| SMM17 PROGRAM LISTING - BD5 | 60414100 | A | 22 | 02.20 |
| SMM17 PROGRAM LISTING - PLT | 60414200 | A | 22 | 01.35 |
| SMM17 PROGRAM LISTING - QOB | 60414300 | A | 22 | 01.70 |
| SMM17 PROGRAM LISTING - CTU | 60414400 | A | 22 | 04.05 |
| SMM17 PROGRAM LISTING - CTT | 60414500 | A | 22 | 02.00 |
| SMM17 PROGRAM LISTING - DDD | 60414600 | A | 22 | 03.25 |
| SMM17 PROGRAM LISTINGS - EDT | 60414700 | C | 22 | 11.10 |
| SMM17 PROGRAM LISTINGS - MYZ | 60422300 | C | 22 | 08.40 |
| SMM17 PROGRAM LISTINGS - MY1 | 60422400 | C | 22 | 08.70 |
| SMM17 PROGRAM LISTINGS - UD1 | 60422500 | B | 22 | 02.00 |
| SMM17 PROGRAM LISTINGS - UD2 | 60422600 | B | 22 | 02.05 |
| SMM17 PROGRAM LISTINGS - RC3 | 60422700 | B | 22 | 11.05 |
| SMM17 PROGRAM LISTING - RC2 | 60422800 | B | 22 | 19.10 |
| SMM17 PROGRAM LISTINGS - DP5 | 60422900 | C | 22 | 05.65 |
| SMM17 PROGRAM LISTING - CP4 | 60423000 | A | 22 | 02.75 |
| SMM17 PROGRAM LISTINGS - GT0 | 60437400 | B | 22 | 09.65 |
| SMM17 PROGRAM LISTINGS - GT1 | 60437500 | B | 22 | 20.65 |
| SMM17 PROGRAM LISTINGS - GT2 | 60437600 | B | 22 | 19.10 |
| SMM17 PROGRAM LISTINGS - GT3 | 60437700 | B | 22 | 14.10 |
| SMM17 PROGRAM LISTING - GT4 | 60437800 | A | 22 | 04.05 |
| SMM17 PROGRAM LISTINGS - GT5 | 60437900 | B | 22 | 10.05 |
| SMM17 PROGRAM LISTINGS - GT6 | 60438000 | B | 22 | 17.75 |
| SMM17 PROGRAM LISTINGS - LP5 | 60438100 | B | 22 | 16.75 |
| SMM17 PROGRAM LISTING - HOR | 60438200 | A | 22 | 10.05 |
| SMM17 PROGRAM LISTING - VSD | 60438300 | A | 22 | 02.10 |
| SMM17 PROGRAM LISTINGS - KEY | 60438400 | B | 22 | 09.55 |
| SMM17 PROGRAM LISTINGS - MDC | 60438600 | B | 22 | 23.05 |
| SMM17 PROGRAM LISTING - DPC | 60446100 | A | 22 | 04.05 |
| SMM17 PROGRAM LISTING - MTX | 60446200 | A | 22 | 13.80 |
| SMM17 PROGRAM LISTING - PET | 60446300 | A | 22 | 06.90 |
| SMM17 PROGRAM LISTING - PAD | 60446400 | A | 22 | 05.65 |
| SMM17 PROGRAM LISTING - BDL | 60446500 | A | 22 | 06.10 |
| SMM17 PROGRAM LISTING - REP | 60446600 | A | 22 | 08.20 |
| SMM17 PROGRAM LISTING - INS | 60446700 | A | 22 | 06.65 |
| SMM17 PROGRAM LISTING - CMD | 60446800 | A | 22 | 05.70 |
| SMM17 PROGRAM LISTING - CPY | 60447700 | A | 22 | 02.25 |
| 1703-A STORAGE INCREMENT | | | | |
| REF INFO (USE 1700 COMPUTER SYSTEM REF MAN.) | | | | |
| MAINT., PARTS LIST (USE 1704-A/B) | | | | |
| DIAGRAMS, CIRCUIT DESC., C/P (USE 1704-A/B) | | | | |
| 1704-A/B COMPUTER | | | | |
| REF INFO (USE 1700 COMPUTER SYSTEM REF MAN.) | | | | |
| DIAGRAMS, CIRCUIT DESCRIPTION, CARD | | | | |
| PLACEMENT OF MANUAL (INCLUDES PMI/PMP) | | | | |
| MAINTENANCE, PARTS LIST OF MANUAL | | | | |
| MAINTENANCE, COMMAND TIMING CHARTS OF MANUAL | | | | |
| CROSS TABS OF MANUAL | | | | |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|----|----|-------|
| 1705-A INTERRUPT DATA CHANNEL REF INFO (USE 1700 COMPUTER SYSTEM REF MAN.) DIAGRAMS, CIRCUIT DESCRIPTION, CARD PLACEMENT (USE 1704-A/B) MAINTENANCE, PARTS LIST (USE 1704-A/B) | | | | |
| 1706-A BUFFERED DATA CHANNEL REFERENCE MANUAL | 60330300 | C | 22 | 01.00 |
| DIAGRAMS, CIRCUIT DESCRIPTION, MAINTENANCE, PARTS LIST CE MANUAL | 60165700 | L | 22 | 02.00 |
| CROSS TABS CE MANUAL | 60284000 | B | 22 | 03.10 |
| 1708-A/BB310-A/BB311-A/BB312-A STORAGE INCREMENT REF INFO (USE 1700 COMPUTER SYSTEM REF MAN.) DIAGRAMS, CIRCUIT DESCRIPTION, CARD PLACEMENT (USE 1704-A/B) CE MANUAL | 60182900 | G | 22 | 05.95 |
| 1709-A STORAGE INCREMENT REF INFO (USE 1700 COMPUTER SYSTEM REF MAN.) MAINTENANCE, PARTS LIST (USE 1704-A/B) DIAGRAMS, CIRCUIT DESCRIPTION, CARD PLACEMENT (USE 1704-A/B) | | | | |
| 1711-A/B TELETYPEWRITER REF INFO (FOR 1704-A/B USE 1700 SYSTEM REF. MANUAL) REF INFO (FOR 1714 USE 1714 SYSTEM REF. MANUAL) DIAGRAMS, CIRCUIT DESCRIPTION, MAINTENANCE PARTS LIST, C/P, WIRE LISTS CE MANUAL ** REFER TO VENDOR MANUALS SECTION FOR TELETYPE MANUALS (35KSR) | 60164200 | AF | 22 | 21.75 |
| 1711-3 (CK501-A/B) TELETYPEWRITER (35KSR) REF INFO (USE 1770 REFERENCE MANUAL) | | | | |
| 1712-A TELETYPEWRITER REF INFO (USE 1700 COMPUTER SYSTEM REF MAN.) CE INFO (USE 1711-A/B) ** REFER TO VENDOR MANUALS SECTION FOR TELETYPE MANUALS (35KSR) | | | | |
| 1713-A/B TELETYPEWRITER REF INFO (USE 1700 COMPUTER SYSTEM REF MAN.) CE INFO (USE 1711-A/B) ** REFER TO VENDOR MANUALS SECTION FOR TELETYPE MANUALS (35ASR) | | | | |
| 1713-3 (CK502-A/B) TELETYPEWRITER (35ASR) REF INFO (USE 1770 REF MAN) | | | | |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------------------|--------|----------|----------------|
| 1714 (AA116-A, AA119-A/B/C/D, BT150-A/B) BASIC PROCESSOR REFERENCE MANUAL | 60364900 | B | 22 | 01.75 |
| 1716-A COUPLING DATA CHANNEL REFERENCE MANUAL CE MANUAL | 60330400 60182800 | B N | 22 22 | 01.00 01.85 |
| 1717-1 (FJ101-A, FJ415-A) DATA SET CONTROLLER REFERENCE MANUAL | 13797800 | B | 22 | 03.40 |
| 1718-A SATELLITE COUPLER REFERENCE MANUAL ** REFER ALSO TO 370 PAPER TAPE READER ** REFER ALSO TO VENDOR MANUALS SECTION FOR REMX TAPE SPOOLER CE MANUAL | 60330500 | A | 22 | 01.00 |
| 1721-A/B PAPER TAPE READER REF INFO (USE 1700 COMPUTER SYSTEM REF MAN.) CE INFO (USE 1711-A/B) ** REFER ALSO TO 350 PAPER TAPE READER FOR ADDITIONAL DOCUMENTATION | | | | |
| 1721-C/D PAPER TAPE READER REF INFO (USE 1700 COMPUTER SYSTEM REF MAN.) CE INFO (USE 1711-A/B) ** REFER ALSO TO 370 PAPER TAPE READER FOR ADDITIONAL DOCUMENTATION | | | | |
| 1722-A/B PAPER TAPE READER REF INFO (USE 1700 COMPUTER SYSTEM REF MAN.) CE INFO (USE 1711-A/B) MAINTENANCE, PARTS LIST (USE 1704-A/B) | | | | |
| 1723-A/B PAPER TAPE PUNCH REF INFO (USE 1700 COMPUTER SYSTEM REF MAN.) CE INFO (USE 1711-A/B) ** REFER TO VENDOR MANUALS SECTION FOR NCR EM-B1 PAPER TAPE PUNCH CE MANUAL | | | | |
| 1724-A/B PAPER TAPE PUNCH REF INFO (USE 1700 COMPUTER SYSTEM REF MAN.) CE INFO (USE 1711-A/B) ** REFER TO VENDOR MANUAL SECTION FOR NCR EM-B1 PAPER TAPE PUNCH AND NCR EM-B2 TAPE HANDLER CE MANUALS | | | | |
| 1726-1 (FE107-A) CARD READER CONTROLLER REFERENCE MANUAL | 60330900 | A | 22 | 01.00 |
| 1728-A/B (CF504, FE304-A) CARD READER/PUNCH WITH CONTROLLER | | | | |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------------------|--------|----------|----------------|
| REFERENCE MANUAL CE INFO FOR READER/PUNCH (USE CF504) CE INFO FOR CONTROLLER (USE FE304-A, CATALOG SECTION 1) | 60331000 | A | 22 | 01.25 |
| 1729-2 (CE120-A/B, FE110-A) CARD READER WITH CONTROLLER REFERENCE MANUAL | 60331100 | A | 22 | 01.00 |
| 1729-3 CARD READER CONTROLLER REFERENCE MANUAL | 89637400 | 02 | 22 | 01.15 |
| 1729-A/B CARD READER REF INFO (USE 1700 REF MAN) CE INFO (USE 1711-A/B) | | | | |
| 1731-A/B MAGNETIC TAPE CONTROLLER REFERENCE MANUAL CE MANUAL | 60330700 60167500 | A M | 22 22 | 01.00 06.20 |
| 1732-A/B MAGNETIC TAPE CONTROLLER REFERENCE MANUAL CE MANUAL | 60330800 60208200 | A L | 22 22 | 01.50 22.20 |
| 1732-2 (SYSTEM 17) MAGNETIC TAPE TRANSPORT CONTROLLER REFERENCE MANUAL | 89637600 | 03 | 22 | 02.25 |
| 1732-3 (SYSTEM 17) MAGNETIC TAPE TRANSPORT CONTROLLER REFERENCE MANUAL | 89769400 | 01 | 22 | 02.95 |
| 1733-1 (FA102-A) DISK STORAGE CONTROLLER REFERENCE MANUAL | 60400200 | A | 22 | 01.30 |
| 1733-2 CARTRIDGE DISK DRIVE CONTROLLER REFERENCE MANUAL | 89638000 | 03 | 22 | 01.65 |
| 1735 (FF103-A) PAGE READER CONTROLLER REFERENCE MANUAL | 60237800 | D | 22 | 01.80 |
| 1736-1 (FF406-A/B/C) UNIT RECORD READER CONTROLLER REF INFO (USE 935 OCR SYSTEM REF/OPERATORS MANUAL) | | | | |
| 1738-A/B/C DISK DRIVE CONTROLLER REFERENCE MANUAL CE MANUAL | 60330600 60167700 | B U | 22 22 | 05.10 05.35 |
| 1739-1 (BR401-A/B, FV227-A/B, GD121-A, GH421-A) CARTRIDGE DISK DRIVE REFERENCE MANUAL | 60368600 | B | 22 | 03.25 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------------------------------|-------------|----------------|-------------------------|
| 1740 (FF516-A) LINE PRINTER CONTROLLER REFERENCE MANUAL | 60331200 | A | 22 | 01.00 |
| 1742-A/B (CL309-A/B, FF511-A/B) LINE PRINTER WITH CONTROLLER REFERENCE MANUAL CE INFO FOR PRINTER (USE CL309-A/B, CATALOG SECTION 1) CE INFO FOR CONTROLLER (USE FF511-A/B) | 60331300 | B | 22 | 01.40 |
| 1742-30/120 LINE PRINTER CONTROLLER REF MAN | 89637200 | 02 | 22 | 01.10 |
| 1743-1 SYNCHRONOUS COMMUNICATION CONTROLLER AND DISTRIBUTION PANEL REFERENCE MANUAL | 89638400 | 02 | 22 | 01.90 |
| 1743-2 ASYNCHRONOUS COMMUNICATION CONTROLLER AND DISTRIBUTION PANEL REFERENCE MANUAL | 89638200 | 02 | 22 | 01.45 |
| 1747 (FJ412-A/B/C) DATA SET CONTROLLER REFERENCE MANUAL | 13799000 | C | 22 | 01.65 |
| 1748 MULTIPLEXER CONTROLLER C/P, LOGIC WIRING, WIRE LTSTS, EQ SUM CE MAN | 41601500 | 01 | 22 | 15.75 |
| 1748 MULTIPLEXER CONTROLLER REFERENCE MANUAL | 13794400 | A | 22 | 03.90 |
| 1748-2 (FJ103-A/B) MULTIPLEXER CONTROLLER REFERENCE MANUAL | 41601600 | A | 22 | 03.70 |
| 1749-A/B COMMUNICATION TERMINAL CONTROLLER REFERENCE MANUAL THEORY OF OPERATION, MAINT., INSTALLATION, PARTS LIST, DIAGRAMS, CARD PLACEMENT CE MAN WIRE LISTS, EQ SUMMARY, MAINT. AIDS CE MAN | 36827100 36827000 36829100 | D H G | 22 22 22 | 01.25 02.00 09.25 |
| 1750 DATA AND CONTROL TERMINAL (DCT) OPERATION AND MAINTENANCE INSTRUCTION MANUAL | 39072900 | E | 22 | 07.15 |
| 1750-1 (EL101-A) COMPUTER INTERFACE UNIT | | | | |
| 1750-2 (EL102-A) COMPUTER INTERFACE EXPANDER | | | | |
| 1751 DRUM INTERFACE AND STORAGE UNIT OPER AND INSTRUCTION MANUAL DRUM STORAGE UNIT HDR. REF./CE MANUAL | 39071100 39216600 | 003 | 22 22 | 03.10 03.40 |
| 1770/SC-1700 SYSTEM CONTROLLER REFERENCE MANUAL COMPUTER SYSTEM CODES (USE 1700) I/O SPECIFICATIONS MANUAL | 60270600 60285200 | B 04 | 22 22 | 01.90 01.00 |
| 1772-1 (BB328-A) MEMORY INCREMENT MODULE REF INFO (USE 1770 REF MAN) | | | | |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|----|----|-------|
| 1772-2 (BB329-A) MEMORY EXPANSION UNIT REF INFO (USE 1770 REF MAN) | | | | |
| 1773-1 (DC120-A) DIRECT ACCESS STORAGE MODULE REF INFO (USE 1770 REF MAN) | | | | |
| 1774-1 (AC109-A/B/C) COMPUTE MODULE REF INFO (USE 1770 REF MAN) | | | | |
| 1775-1 (DC118-A) A/O INTERRUPT DATA CHANNEL REF INFO (USE 1770 REF MAN) | | | | |
| 1777-1 (CE305-A/B, CF104-A, CF508-A/B) PAPER TAPE STATION REFERENCE MANUAL | 60331400 | B | 22 | 01.00 |
| 1777-2 (CE305-A/B, CF104-A, CF508-A/B, CW123-A) PAPER TAPE STATION W/VALIDATION OPT. REF INFO (USE 1777-1 REF MAN) | | | | |
| 1778-1 (GJ102-A) PAPER TAPE READER HANDLER REF INFO (USE 1777-1 REF MAN) | | | | |
| 1778-2 (GJ103-A/B) PAPER TAPE PUNCH HANDLER REF INFO (USE 1777-1 REF MAN) | | | | |
| 1779-1 (DC119-A) CHARACTER HANDLING REF INFO (USE 1770 REF MAN) | | | | |
| 1784 (SYSTEM 17) COMPUTER SYSTEM INPUT/OUTPUT SPECIFICATIONS | 89673100 | 02 | 22 | 04.40 |
| 1784-1/2 () COMPUTER SYSTEM REFERENCE MANUAL | 89633400 | A | 22 | 02.25 |
| CE MANUAL | 89633300 | 04 | 22 | 22.50 |
| 2013-A BADGE READER ADAPTER CE/REF MANUAL | 13790500 | D | 22 | 05.50 |
| 2014-A TIME EMITTER CE MANUAL VOL 2 EQ FILE AND WIRE LIST MANUAL | 13794700 | C | 22 | 02.25 |
| REFERENCE/CE MANUAL | 13794600 | B | 22 | 01.70 |
| 2014-B TIME EMITTER REFERENCE/CE MANUAL | 13794800 | A | 22 | 01.00 |
| 2020 COMPILER CE MANUAL - DIAGRAMS | 36820000 | F | 22 | 03.05 |
| ILLUSTRATED PARTS MANUAL (TRANSACTION SYSTEM) | 65631800 | A | 22 | 01.05 |
| TRANSACTION SYSTEM REFERENCE MANUAL | 36817600 | A | 22 | 03.25 |
| INSTALLATION MANUAL | 36820400 | B | 22 | 02.00 |
| 2022-P DATA COLLECTOR CONTROLLER CE MANUAL | 13796200 | B | | 02.40 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------|-----|----|-------|
| 2025-1/2 MAGNETIC TAPE COMPILER SYSTEM USERS MANUAL | 65690800 | B | 22 | 06.05 |
| SFTWR. DESC., SYS. DESC., SYSTEM REF.MAN. | 65655800 | B | 22 | 06.15 |
| SOFTWARE INSTALLATION MANUAL | 65727400 | A | 22 | 01.25 |
| 2040 AUTOMATIC SHUNT CE DIAGRAMS MANUAL | 36820100 | C | 34 | 02.00 |
| 2070-A CONCENTRATOR CE DIAGRAMS MANUAL | 36820200 | A | 34 | 02.75 |
| 2070-B/2075-B CONCENTRATOR CONVERTER CE MANUAL-THEO OF OPER,DIAGS,P/L,C/P,W/L | 36829800 | C | 22 | 03.60 |
| 2075-A CONVERTER CE DIAGRAMS MANUAL | 36820300 | A | 34 | 01.75 |
| 2077/2078/2079 CONCENTRATOR TERMINAL REF. MAN. | 13790300 | B | 22 | 01.25 |
| CE MANUAL VOL I THEO OF OPER,MAINT,DIAG, P/L | 13790100 | G | 22 | 13.90 |
| CE MANUAL VOL II OF 4 (INCL EQ FILE, W/L) | 13790200 | D | 22 | 10.00 |
| CE MANUAL VOL III EQ FILE, LOGIC WIRING,W/L | 13791300 | D | 22 | 15.35 |
| 2079 CONCENTRATOR TERM. CE MANUAL VOL 4 OF 4 | 13791400 | D | 22 | 02.85 |
| 2085-A/2086-A TRUNK LINE CONTROLLER REF MANUAL | 13790700 | A | | 01.00 |
| LOGIC WIRING, W/L, EQ. FILE, C/P, VOL II CE MANUAL | 13790800 | D | 22 | 07.65 |
| CE MANUAL VOL 1 AND 2 | 36829500 | F | 22 | 02.50 |
| 2086-B TRUNK LINE CONTROLLER REFERENCE MANUAL | 13792500 | D | 22 | 01.00 |
| OPER,MAINT,DIAGRAMS AND PARTS LIST CE MANUAL | 13792400 | I | 22 | 03.40 |
| CE MANUAL VOL 2 (INC WIRE LIST,EQ FILE) | 13792700 | E | 22 | 02.85 |
| 3000 SERIES COMPUTER SYSTEM | | | | |
| INPUT/OUT SPECIFICATIONS | 60048800 | M | 22 | 02.30 |
| INSTRUCTION CODES (3100/3200) | 60150200 | B | | 01.35 |
| PERIPHERAL EQUIPMENT CODES | 60113400 | J | | 01.65 |
| SITE PREPARATION AND INSTALLATION MANUAL | 60110400 | M-N | 22 | 04.00 |
| CUSTOMER ENGINEERING MANUALS | | | | |
| PERIPHERAL CONTROLLER CABINETS CE MANUAL | 60224100 | Z | 22 | 02.20 |
| INFORMATION (1700/3000/6000) SOLID FRONT STYLE | | | | |
| 3000L SYSTEM MAINT. MONITOR REF MAN VOL 1+2 | 60118600 | M | 22 | 20.00 |
| PM1/PMP MAINT SERIES CONTROLLER (3000) | 60317800 | A | 22 | 01.00 |
| REAL TIME SYSTEMS EXECUTIVE TEST ROUTINES (3100/3200/3300) | 13793100 | A | 22 | 02.15 |
| 3100/3200/3300 COMPUTER MEMORY PATTERN TEST | 13793300 | | 22 | 01.00 |
| 3100/3200/3300 COMPUTER UTILITY ROUTINE | 13793400 | | 22 | 01.50 |
| IBM 360/370 SMM CE MANUAL | 60383300 | 04 | 22 | 04.70 |
| SMM3L PROGRAM LISTINGS MONITOR | 60300000 | F | 22 | 07.20 |
| SMM3L PROGRAM LISTINGS (SPV) SERVICE ROUTINE CE MANUAL | 60300100 | C | 22 | 02.10 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------|---|----|-------|
| SMM3L PROGRAM LISTINGS (MEM) MEMORY TEST FOR 3200 | 60300200 | B | 22 | 02.25 |
| SMM3L PROGRAM LISTINGS (MM1) 2DP MEMORY CE | 60300300 | D | 22 | 03.25 |
| SMM3L PROGRAM LISTINGS (MM2) 3300 MEMORY | 60300400 | G | 22 | 08.95 |
| SMM3L PROGRAM LISTINGS (LOG) 3L00 LOGIC | 60300500 | E | 22 | 05.65 |
| SMM3L PROGRAM LISTINGS (COM) | 60300600 | E | 22 | 24.95 |
| SMM3L PROGRAM LISTINGS (FPT) FLOATING POINT TEST | 60300700 | E | 22 | 07.00 |
| SMM3L PPROGRAM LISTINGS (MOE) MOVE TEST | 60300800 | B | 22 | 01.00 |
| SMM3L PROGRAM LISTINGS (RAN) RANDOM INSTR. | 60300900 | C | 22 | 04.10 |
| SMM3C PROGRAM LISTINGS 322X MAG TAPE (MT1) | 60301000 | C | 22 | 04.25 |
| SMM3L PROGRAM LISTINGS (MT6) 3127/601 MAG TAPE TEST | 60301100 | C | 22 | 02.65 |
| SMM3L PROGRAM LISTINGS (MT0) 3600/322X/60X TAPE | 60301300 | E | 22 | 04.15 |
| SMM3L PROGRAM LISTINGS (CH1) 3207/6 CHANNEL TEST | 60301400 | D | 22 | 02.40 |
| SMM3L PROGRAM LISTINGS (CH2) CHANNEL TEST 3234 853/854, 813/814 CE MANUAL | 60301500 | G | 22 | 11.30 |
| SMM3L PROGRAM LISTINGS (LP2) 501 LINE PRINT- | 60301600 | B | 22 | 01.30 |
| SMM3L PROGRAM LISTINGS (TP1) CONSOLE TYPEWRITER | 60301700 | B | 22 | 01.60 |
| SMM3L PROGRAM LISTINGS (OP4) DISK PACK TEST | 60301800 | C | 22 | 03.25 |
| SMM3L PROGRAM LISTINGS (MS1) | 60301900 | G | 22 | 21.65 |
| SMM3L PPROGRAM LISTINGS DM19DM29 3235 DRUM 3236/3237/861 DRUM CE MANUAL | 60302000 | C | 22 | 02.30 |
| SMM3L PROGRAM LISTINGS (OD5) 3290C DISPLAY | 60302200 | C | 22 | 02.75 |
| SMM3L PROGRAM LISTINGS MEMORY INTERRUPT TEST FOR 3300 | 60302500 | B | 22 | 01.80 |
| SMM3L PROGRAM LISTINGS (FX2) EXECUTIVE MODE | 60302600 | F | 22 | 03.05 |
| SMM3L PROGRAM LISTINGS (SPS) 3300 SELECTIVE PROTECT SWITCH TEST | 60302700 | C | 22 | 02.30 |
| SMM3L PROGRAM LISTINGS (PF1) 3300 PAGE FILE ILLEGAL WRITE TEST | 60302800 | C | 22 | 01.10 |
| SMM3L PROGRAM LISTINGS (OVN) EXECUTIVE MODE MONITOR | 60303000 | F | 22 | 09.15 |
| SMM3L PROGRAM LISTINGS (CP4) 3446/3644 CARD PUNCH CONTROLLER | 60303100 | D | 22 | 02.60 |
| SMM3L PROGRAM LISTINGS (CR4) 3248/3447/3649 CARD READER CONTROLLER | 60303200 | D | 22 | 03.55 |
| SMM3L PROGRAM LISTINGS 3L00 QUICK LOOK MEMORY TEST | 60303700 | B | 22 | 02.90 |
| SMM3L PROGRAM LISTINGS 3L00 QUICK LOOK COMMAND TEST | 60303800 | C | 22 | 08.85 |
| SMM3L PROGRAM LISTINGS 3200 EXTERNAL EQUIP. | 60303900 | E | 22 | 07.35 |
| SMM3L PROGRAM LISTINGS - RFT | 60304000 | B | 22 | 01.70 |
| SMM3L PROGRAM LISTINGS MMX ITERRUPT PROC. | 60304100 | E | 22 | 07.40 |
| SMM3L PROGRAM LISTINGS MS3 | 60304200 | B | 22 | 06.00 |
| SMM3L PROGRAM LISTINGS LOADING | 60304300 | B | 22 | 04.50 |
| SMM3L PROGRAM LISTINGS DCP 17 | 60304400 | E | 22 | 05.60 |
| SMM3L PROGRAM LISTINGS SIMULATED RANDOM INSTR. TEST | 60304500 | B | 22 | 12.70 |
| SMM3L PROGRAM LISTINGS-3316 CONTROLLER CEN | 60304600 | C | 22 | 21.40 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------|----|----|-------|
| SMM3L PROGRAM LISTINGS MM4 | 60304700 | B | 22 | 03.80 |
| SMM3L PROGRAM LISTINGS-BDP TESTS 3312-A | 60336500 | D | 22 | 17.60 |
| SMM3L PROGRAM LISTINGS - BDP TESTS 3504 | 60336600 | C | 22 | 17.75 |
| SMM3L PROGRAM LISTINGS-BDP TESTS 3312-B | 60336700 | C | 22 | 14.55 |
| SMM3L PROGRAM LISTINGS - BDP TESTS 3514 | 60336800 | D | 22 | 18.10 |
| SMM3L PROGRAM LISTINGS - 3300/3500 PAGE FILE TEST - PFT | 60336900 | D | 22 | 10.50 |
| SMM3L PROGRAM LISTINGS - 3266 COMMUNICATIONS CONTROLLER (CTC) | 60337000 | B | 22 | 04.30 |
| SMM3L PROGRAM LISTINGS-3553-2/ 821 MS4 | 60337100 | D | 22 | 25.75 |
| SMM3L PROGRAM LISTINGS - (PFR) PAGE READER | 60337200 | B | 22 | 05.05 |
| 3010 LINE PRINTER EQUIPMENT | | | | |
| CE MANUAL PARTS DATA | 44896500 | A | 22 | 02.50 |
| REFERENCE CE MANUAL | 47500700 | D | 22 | 03.50 |
| PRINTER EQUIPMENT CE MAN. (USE CL308-A/B) | | | | |
| 3020-A ALPHANUMERIC INPUT TERMINAL | | | | |
| REFERENCE/CE MANUAL | 36829600 | D | 22 | 01.95 |
| EQUATION SUMMARY, LOGIC WIRING CE MANUAL | 36829700 | C | 22 | 03.70 |
| 3100 COMPUTER SYSTEM | | | | |
| REFERENCE MANUALS | | | | |
| COMPUTER SYSTEM REFERENCE MANUAL | 60108400 | D | 22 | 06.70 |
| INSTRUCTION CARD (3100/3200) | 60043000 | B | | 00.75 |
| CUSTOMER ENGINEERING MANUALS | | | | |
| OPTIONAL ARITH. CIRCUIT DESC (3100/3200) CE MANUAL | 60101400 | B | 22 | 12.45 |
| PMI/PMP CE MANUAL | 60318200 | A | 22 | 01.00 |
| 3101-A/B/C CONSOLE | | | | |
| REF INFO (USE 3100 COMPUTER SYSTEM REF MAN) | | | | |
| PARTS LIST (USE 3104-A/B) | | | | |
| DIAGRAMS (USE 3104-A/B/C) | | | | |
| ** SEE 3192-A/B/C ALSO FOR TYPEWRITER MANUAL | | | | |
| 3103-A STORAGE MODULE | | | | |
| DIAGRAMS (USE 3104-A/B) | | | | |
| REF INFO (USE 3100 COMPUTER SYSTEM REF MAN) | | | | |
| PARTS LIST (USE 3104-A/B) | | | | |
| CARD PLACEMENT, EQ SUMMARY, WIRE LIST CE MAN (INCLUDES PREVIOUS PUB NO.S 35111000 AND 35111100) (ALSO INCLUDES 3113-A/B INFO) | 35110900 | C | 22 | 08.20 |
| 3104-A/B, 3114-A/B COMPUTER | | | | |
| REF INFO (USE 3100 COMPUTER SYSTEM REF MAN) | | | | |
| CIRCUIT DESCRIPTION CE MANUAL | 60111200 | A | 22 | 03.50 |
| DIAGRAMS CE MANUAL | 60111100 | BE | 22 | 08.00 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------|----|----|-------|
| MAINTENANCE COMMAND TIMING CHARTS CE MANUAL | 60112400 | A | 22 | 05.00 |
| PARTS LIST CE MANUAL | 60157200 | C | 22 | 06.05 |
| CARD PLACEMENT, EQUATION SUMMARY CE MANUAL | 60152500 | AD | 22 | 30.00 |
| WIRE LIST (TERM) CE MANUAL | 60152600 | AA | 22 | 16.55 |
| WIRE LIST (HAND TABS) CE MANUAL | 60162600 | J | 22 | 06.30 |
| 3104-C/3114-C COMPUTER | | | | |
| REF INFO (USE 3100 COMPUTER SYSTEM REF MAN) | | | | |
| CIRCUIT DESCRIPTION (USE 3104-A/B) | | | | |
| DIAGRAMS (USE 3104-A/B) | | | | |
| MAINT. COMMAND TIMING CHARTS (USE 3104-A/B) | | | | |
| PARTS LIST (USE 3104-A/B) | | | | |
| CARD PLACEMENT, EQUATION SUMMARY CE MANUAL | 60197900 | S | 22 | 26.00 |
| WIRE LIST (TERM) CE MANUAL | 60198000 | M | 22 | 15.10 |
| WIRE LIST (HAND TABS) CE MANUAL | 60198200 | D | 22 | 09.10 |
| 3106-A/B DATA CHANNEL | | | | |
| REF INFO (USE 3100 COMPUTER SYSTEM REF MAN) | | | | |
| CE INFO (USE 3104-A/B) | | | | |
| 3107-A/B DATA CHANNEL | | | | |
| REF INFO (USE 3100 COMPUTER SYSTEM REF MAN) | | | | |
| DIAGRAMS (USE 3104-A/B) | | | | |
| PARTS LIST (USE 3104-A/B) | | | | |
| CARD PLACEMENT, EQUATION SUMMARY | | | | |
| ** USE 3104-A/B FOR 3104-A/B, 3114-A/B SYSTEMS | | | | |
| ** USE 3104-C FOR 3104-C, 3114-C SYSTEMS | | | | |
| WIRE LISTS (SAME AS CARD PLACEMENT ABOVE) | | | | |
| 3108-A MEMORY EXPANSION UNIT | | | | |
| REF INFO (USE 3100 COMPUTER SYSTEM REF MAN) | | | | |
| CE INFO (USE 3104-A/B) | | | | |
| 3109-A/B MEMORY MODULE | | | | |
| REF INFO (USE 3100 COMPUTER SYSTEM REF MAN) | | | | |
| DIAGRAMS (USE 3104-A/B) | | | | |
| PARTS LIST (USE 3104-A/B) | | | | |
| CARD PLACEMENT, EQ SUMMARY | | | | |
| ** USE 3104-A/B FOR 3104-A/B, 3114-A/B SYSTEMS | | | | |
| ** USE 3104-C FOR 3104-C, 3114-C SYSTEMS | | | | |
| WIRE LISTS (SAME AS CARD PLACEMENT ABOVE) | | | | |
| 3113-A/B STORAGE MODULE | | | | |
| CARD PLACEMENT, EQ SUMMARY, WIRE LISTS (USE 3103-A) | | | | |
| 3121-A/B (FA414-A/B) MAGNETIC TAPE CONTROLLER REFERENCE MANUAL | | | | |
| | 60332000 | A | 22 | 01.10 |
| 3127-A/B MAGNETIC TAPE CONTROLLER CE MANUAL REFERENCE MANUAL | | | | |
| | 60140400 | R | 22 | 17.90 |
| | 60331800 | B | 22 | 03.50 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|---|----|-------|
| 3127/3228/3329 MAG TAPE CONTROLLER AND 60X MAG TAPE TRANSPORT TEST ROUTINE | 13790400 | | 22 | 02.30 |
| 3128-A/B MAGNETIC TAPE CONTROLLER CE MANUAL | 60202600 | K | 22 | 09.65 |
| REFERENCE MANUAL | 60331900 | A | 22 | 01.35 |
| 3142-A/B CARD READER AND CONTROLLER CE MANUAL | 60160300 | G | 22 | 05.55 |
| REFERENCE MANUAL | 60332400 | A | 22 | 01.20 |
| 3150 DATA PROCESSING SYSTEM | | | | |
| REFERENCE MANUAL | 60207800 | A | 22 | 02.55 |
| SOURCE DATA COLLECTION SYS SOFTWARE DESC. | 65724900 | | 3 | 01.00 |
| 3152-A/B LINE PRINTER CONTROLLER | | | | |
| CIRCUIT DESCRIPTION, DIAGRAMS, MAINT, PARTS LIST, CARD PLACEMENT, EQ SUMMARY CE MANUAL | 60108100 | F | 22 | 22.65 |
| CROSS TABS OF MANUAL | 60147200 | B | 22 | 04.00 |
| TEST ROUTINE | 13793200 | | 22 | 01.05 |
| 3170 COMPUTER SYSTEM | | | | |
| REFERENCE MANUAL | 60341500 | C | 22 | 10.00 |
| I/O SPECIFICATIONS (USE 3000 I/O) | | | | |
| 3172 (8B105-A) MAGNETIC CORE STORAGE | | | | |
| REF INFO (USE 3170) | | | | |
| 3174-1 (AC105-B, 3301-A, 3311-A) BASIC PROCESSOR | | | | |
| REF INFO (USE 3170) | | | | |
| 3174-2 (AC105-B, 3301-A, 3310-A, 3311-A) SCIENTIFIC PROCESSOR | | | | |
| REF INFO (USE 3170) | | | | |
| 3174-3 (AC105-B, 3301-A, 3311-A, AF101-B) BUSINESS DATA PROCESSOR | | | | |
| REF INFO (USE 3170) | | | | |
| 3174-4 (AC105-B, 3301-A, 3310-A, 3311-A, AF101-B) GENERAL PROCESSOR | | | | |
| REF INFO (USE 3170) | | | | |
| 3177 (3306-C, 3307-A) COMMUNICATIONS CHANNEL | | | | |
| REF INFO (USE 3170) | | | | |
| 3192-A/B/C/D ON-LINE MONITOR TYPEWRITER | | | | |
| CE MANUAL | 60150100 | J | 22 | 06.45 |
| TEST ROUTINE | 13793600 | | 22 | 01.05 |
| 3195-A PAGE READER CONTROLLER | | | | |
| REFERENCE MANUAL | 60166900 | D | 22 | 02.00 |
| CE MANUAL | 60167000 | D | 22 | 08.00 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|----|----|-------|
| 3200 COMPUTER SYSTEM | | | | |
| REFERENCE MANUAL COMPUTER SYSTEM | 60043800 | J | 22 | 02.30 |
| CUSTOMER ENGINEERING MANUALS (INCLUDE INFO ON 3203-A, 3204A/B, 3205A/B, 3206 3207A/B, 3209-A, 3210-A/B, 3215-A/B) | | | | |
| CARD PLACEMENTS | 31620199 | AK | 34 | 05.50 |
| EQUATION SUMMARY, VOLUME 1 AND 2 | 31620099 | Y | 34 | 19.05 |
| WIRE LIST, TERM LIST | 31620200 | AD | 22 | 17.95 |
| WIRE LIST, HAND TABS | 31620300 | P | | 08.25 |
| CE DIAGRAMS | 60049400 | AY | 22 | 13.40 |
| PARTS LIST | 60075400 | D | 22 | 07.45 |
| CE MANUAL CIRC DESC., COMPUTATION SECT. | 60100900 | C | 22 | 09.80 |
| MAINTENANCE COMMAND TIMING CHARTS | 60101100 | B | 22 | 15.00 |
| 3203 DISK DIAGNOSTIC TEST ROUTINE MANUAL | 41611300 | A | 22 | 04.50 |
| 3216 REAL TIME COMMUNICATION MODULE | | | | |
| CE MANUAL | 13792100 | A | 22 | 01.20 |
| CE DIAGRAMS MANUAL | 13792200 | B | 34 | 02.00 |
| 3217 REAL TIME COMMUNICATION MODULE AND B.A.T.E. EXCHANGE TEST ROUTINES | 13794100 | A | 22 | 02.85 |
| 3218-A PROGRAMMED DATA CHANNEL REF/CE MANUAL | 60116100 | E | 22 | 07.00 |
| (THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES. ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.) | | | | |
| EQUATION SUMMARY | 60115900 | | | |
| WIRE TABS | 24146700 | | | |
| 3228-A/B MAGNETIC TAPE CONTROLLER | | | | |
| REFERENCE MANUAL | 60331700 | C | 22 | 01.40 |
| CE MANUAL | 60093700 | V | 22 | 07.05 |
| 3229-A/B MAGNETIC TAPE CONTROLLER (USE 3228-A) REF INFO (USE 3228-A/B) | | | | |
| 3231-A DISK PACK CONTROLLER | | | | |
| REFERENCE MANUAL | 60110900 | C | 22 | 01.75 |
| CE MANUAL | 60111000 | B | 22 | 06.00 |
| 3232-A/B DISK DRIVE CONTROLLER | | | | |
| REFERENCE MANUAL | 60165300 | 01 | 22 | 02.50 |
| CE MANUAL | 60165400 | E | 22 | 21.60 |
| 3234-A/B MASS STORAGE CONTROLLER | | | | |
| REFERENCE MANUAL | 60333300 | B | 22 | 02.20 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------|-----|----|-------|
| DIAGRAMS CE MANUAL | 60167900 | AD | 22 | 08.50 |
| WIPE LIST, EQUATION SUMMARY CE MANUAL | 60268900 | P | 22 | 10.00 |
| TEST ROUTINE (SEE ALSO SPECIAL OPTION 60076-A) | 41606500 | A | 22 | 02.00 |
| 3234-D/E MASS STORAGE CONTROLLER CE MANUAL | 60394800 | D | 22 | 12.75 |
| 3235-A DRUM STORAGE SUBSYSTEM REFERENCE MANUAL | 60165100 | 01 | | 02.75 |
| CE MANUAL | 60165200 | 01 | 22 | 09.50 |
| 3245-A CARD PUNCH CONTROLLER REFERENCE MANUAL | 60332200 | A | 22 | 01.25 |
| CE MANUAL | 60105100 | J,K | 22 | 08.00 |
| 3248-A/B CARD READER CONTROLLER REFERENCE MANUAL | 60332300 | D | 22 | 02.85 |
| CE MANUAL | 60100400 | R | 22 | 03.05 |
| 3248/405 TEST ROUTINE | 13793800 | | 22 | 01.60 |
| 3254 (CL308-A, FF510-A/B) LINE PRINTER WITH CONTROLLER REFERENCE MANUAL | 60332900 | A | 22 | 01.00 |
| 3256-A/B/C LINE PRINTER CONTROLLER REFERENCE MANUAL | 60332500 | A | 22 | 01.25 |
| CE MANUAL | 60113900 | AC | 22 | 05.70 |
| 3256/3659 TEST ROUTINE | 13793900 | | 22 | 01.10 |
| 3266-B COMM TERMINAL CONTROLLER THEO OF OPER INSTAL., MAINT., AND PARTS LIST | 36825800 | J | 22 | 01.50 |
| MAINTENANCE AIDS MANUAL | 36825900 | J | 22 | 03.25 |
| DIAGRAMS MANUAL | 36826000 | H | 34 | 03.00 |
| REFERENCE MANUAL | 36828100 | D | 22 | 01.00 |
| 3270-A/B TRANSFER SWITCH CONTROLLER REF/CE MANUAL | 60417300 | A | 22 | 09.05 |
| 3275-C DATA SET CONTROLLER REFERENCE MANUAL | 13791500 | A | 22 | 01.20 |
| CE MANUAL | 13791600 | | 22 | 01.00 |
| 3276 COMMUNICATION TERMINAL CONTROLLER MAINTENANCE MANUAL | 36816200 | A | 22 | 03.50 |
| 3293-A/B INCREMENTAL PLOTTER REFERENCE MANUAL | 60332700 | B | 22 | 01.00 |
| CE MANUAL | 60090500 | N | 22 | 03.85 |
| 3300 COMPUTER SYSTEM REFERENCE MANUAL | 60157000 | N | 22 | 04.50 |
| COMMAND TIMING CHARTS CE MANUAL | 60185600 | B | 22 | 08.50 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|----|----|-------|
| INSTRUCTION CODES (POCKET-SIZE) (INCLUDES 3500) | 60186900 | D | | 00.75 |
| ON-LINE DIAGNOSTICS (33/3500 MASTER) GIM | 60329900 | A | 22 | 01.00 |
| ON-LINE DIAGNOSTICS (33/3500 MASTER) REF MAN | 60323400 | 04 | 22 | 14.70 |
| 3301-A (3174-1/2/3/4, 3304-2/3) DESK CONSOLE REF INFO (USE 3170 OR 3300) CIRCUIT DESCRIPTION, DIAGRAMS, MAINTENANCE (USE 3304-A) MAINTENANCE - PMI/PMP (USE 3304-A) PARTS LIST (USE 3304-A) | | | | |
| 3302-A/BB316-A STORAGE MODULE REF INFO (USE 3300 COMPUTER SYSTEM REF MAN) CIRCUIT DESCRIPTION, DIAGRAMS, MAINTENANCE (USE 3304-A) WIRE LIST; HAND TABS (USE 3304-A) MAINTENANCE - PMI/PMP (USE 3304-A) EQUATION SUMMARY (USE 3304-A) CARD PLACEMENT (USE 3304-A) WIPE LIST (TERM LIST) (USE 3304-A) PARTS LIST (USE 3304-A) | | | | |
| 3304-A CENTRAL PROCESSOR CIRCUIT DESCRIPTION, DIAGRAMS, MAINT CE MAN REF INFO (USE 3300 COMPUTER SYSTEM REF MAN) WIRE LIST; HAND TABS CE MANUAL MAINTENANCE - PMI/PMP CE MANUAL EQUATION SUMMARY CE MANUAL CARD PLACEMENT CE MANUAL WIRE LIST (TERM LIST) CE MANUAL PARTS LIST CE MANUAL | 60152300 | DT | 22 | 10.15 |
| | 60317500 | B | 22 | 26.00 |
| | 60318300 | A | 22 | 01.00 |
| | 60153900 | BA | 22 | 20.00 |
| | 60154000 | AZ | 34 | 06.05 |
| | 60154100 | BC | 22 | 14.95 |
| | 60160700 | E | 22 | 10.00 |
| 3304-B/AC105-B (3304, 3304-2/3) CENTRAL PROC. REF INFO (USE 3300 COMPUTER SYSTEM REF MAN) CIRCUIT DESCRIPTION, DIAGRAMS, MAINTENANCE (USE 3304-A) WIRE LIST; HAND TABS (USE 3304-A) MAINTENANCE - PMI/PMP (USE 3304-A) EQUATION SUMMARY, CARD PLACEMENT CE MANUAL ** 3304-3/AC105-B, 3310-A, STD. OPT. 10099-B ONLY. ORDER 3304-A EQUATION SUMMARY IF INFORMATION REQUIRED FOR 3311-A, 3309-A, 3302-A, 3306-A/B/C, 3307-A. WIRE LIST (TERM LIST) CE MANUAL ** 3304-3/AC105-B, 3310-A, ST.OP.10099-B ONLY. ORDER 3304-A WIRE LIST IF INFORMATION REQUIRED FOR 3311-A, 3309-A, 3302-A, 3306-A/B/C, 3307-A PARTS LIST (USE 3304-A) | 60213100 | H | 22 | 23.00 |
| | 60213200 | F | 22 | 15.50 |
| 3304-2 (AC105-B, AF101-A, 3301-A) BUSINESS | | | | |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.

4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|--|------------------|----------------------|----------------------------------|
| DATA PROCESSOR REF INFO (USE 3300 COMPUTER SYSTEM REF MAN) CE INFO (SEE APPROPRIATE EQUIPMENT) | | | | |
| 3304-3 (AC105-B, AF101-B, 3301-A) BUSINESS DATA PROCESSOR REF INFO (USE 3300 COMPUTER SYSTEM REF MAN) CE INFO (SEE APPROPRIATE EQUIPMENT) | | | | |
| 3306-A/B/C COMMUNICATION CHANNELS REF INFO (USE 3300 COMPUTER SYSTEM REF MAN) CE INFO (USE 3304-A) | | | | |
| 3307-A COMMUNICATION CHANNEL REF INFO (USE 3300 COMPUTER SYSTEM REF MAN) CE INFO (USE 3304-A) | | | | |
| 3309-A STORAGE MODULE REF INFO (USE 3300 COMPUTER SYSTEM REF MAN) CE INFO (USE 3304-A) | | | | |
| 3310-A (3174-2/4) FLOATING POINT MODULE REF INFO (USE 3170 OR 3300) CE INFO EXCEPT WIRE LIST, EQ SUM (USE 3304-A WIRE LIST/EQ SUMMARY (USE 3304-A OR 3304-B FOR 3300 SYSTEMS) (USE ONLY 3304-B FOR 3170 SYSTEMS) | | | | |
| 3311-A (3174-2/4) MULTIPROGRAMMING MODULE REF INFO (USE 3170 OR 3300) CE INFO (USE 3304-A FOR 3300 SYSTEMS) (USE 3304-B FOR 3170 SYSTEMS) | | | | |
| 3312-A/AF101-A (3304-2) BUSINESS DATA PROCESSOR REF INFO (USE 3300 COMPUTER SYSTEM REF MAN) MAINTENANCE - PMI/PMP (USE 3304-A) PARTS LIST (USE 3304-A) WIRE LIST (TERM LIST, HAND TABS) CE MANUAL EQUATION SUMMARY, CARD PLACEMENT CE MANUAL DIAGRAMS CE MANUAL MAINTENANCE COMMAND TIMING CHARTS | 60197600 60186700 60162900 60209800 | P P T H | 22 22 22 22 | 07.05 13.50 05.15 11.80 |
| 3312-B/AF101-B (3304-3) BUSINESS DATA PROCESSOR REF INFO (USE 3300 COMPUTER SYSTEM REF MAN) | | | | |
| 3316-1 (FJ601-A) MULTIPLEXER CONTROLLER REFERENCE MANUAL TEST ROUTINE MANUAL | 13796800 41600300 | F A | 22 22 | 05.00 01.35 |
| 3344 DIGIGRAPHIC CONTROLLER HDWR REF/CE MAN. | 82146800 | A00 | 22 | 05.15 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|-----|----|-------|
| 3400 COMPUTER SYSTEM | | | | |
| INSTRUCTION CARD | 60070000 | | | 00.75 |
| INSTRUCTION CODES (3400) | 60150300 | | | 00.75 |
| REFERENCE MANUAL | 60028200 | P | 22 | 02.95 |
| CUSTOMER ENGINEERING MANUALS | | | | |
| CE DIAGRAMS | 60096900 | AF | 22 | 15.00 |
| CE INST/PART 1 THEORY OF OPERATION | 60097000 | C | 22 | 13.20 |
| MAINTENANCE MONITOR (SMM34) VOLS 1 AND 2 | 60126400 | D | 22 | 25.00 |
| COMMAND TIMING CHARTS | 60141800 | COE | 22 | 08.35 |
| WIRE TABS, CABLE TABS AND CROSS TABS | 60146000 | K | 34 | 22.70 |
| (THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES.ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.) | | | | |
| PARTS LIST | 60149900 | A | 22 | |
| 3401 CONSOLE TYPEWRITER CONTROL CARD PLMT, EQUATION SUMMARY,WIRE TABS,CABLE TABS,CROSS TABS | 60145500 | A | 34 | 06.00 |
| 3404-A BASIC 16K COMPUTER CARD PLMTS AND EQUATION SUMMARY VOL 1 AND 2 | 60145900 | J | 22 | 24.10 |
| WIRE TABS, CABLE TABS AND CROSS TABS | 60146000 | K | 22 | 22.70 |
| 3406-A STANDARD I/O CHANNEL CARD PLACEMENTS, EQUATION SUMMARY,WIRE TABS,CABLE TABS,CROSS | 60145600 | C,D | 34 | 15.00 |
| 3409-A 32K STORAGE OPTION CARD PLACEMENTS, EQUATION SUMMARY,WIRE,CABLE AND CROSS TABS | 60145700 | B | 22 | 09.30 |
| 3410-A FLOATING POINT OPTION C/P, EQ SUMMARY, WIRE LIST CE MANUAL (INCLUDES PREVIOUS PUB NO.S 32501400 AND 32501500) | 32501300 | B | 22 | 06.50 |
| 3416-A STANDARD I/O CHANNEL CARD PLACEMENT, EQUATION SUMMARY, WIRE LIST CE MANUAL (INCLUDES INFO FOR PREVIOUS PUB NO.S 32503400 AND 32503500 - ALSO INCLUDES 3417-A INFO FOR PREVIOUS PUB NO.S 32503700, 32503800 AND 32503900) | 32503300 | E | 22 | 28.70 |
| 3417-A DIRECT ACCESS CHANNEL CE INFO (SEE 3416-A) | | | | |
| 3421-A/B/3422-A/B/3423-A/B MAG TAPE CONTROLLER THEO OF OPER, MAINT, PARTS LIST, DIAGRAMS MAN REFERENCE MANUAL | 60102300 | U | 22 | 06.30 |
| | 60331600 | D | 22 | 01.30 |
| 342X-A/B MAG TAPE CONTROLLER CARD PLACEMENT, | 60150000 | N | 34 | 13.30 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------|-----|----|-------|
| EQ. SUMMARY, WIRE TABS CE MANUAL | | | | |
| 3436-A DRUM CONTROLLER REFERENCE MANUAL | 60333100 | A | 22 | 01.45 |
| CE MANUAL | 60114200 | M,N | 22 | 07.30 |
| TEST ROUTINE | 13793500 | | 22 | 01.00 |
| 3446-A/B CARD PUNCH CONTROLLER REFERENCE MANUAL | 60332100 | B | 22 | 01.20 |
| CE MANUAL | 60090400 | Y | 22 | 03.75 |
| TEST ROUTINES - 3446, 3644/415/523/544 | 41602600 | A | 22 | 02.50 |
| PUNCH/READER CARD PATTERNS FOR 3446-3644/ 415/523/544 CARD PUNCH TEST AND 3447-3649/ 405 CARD READER TEST | 41602800 | | 22 | 09.40 |
| 3447-A CARD READER CONTROLLER REF INFO (USE 3248-A REF MAN) | 60091800 | AB | 22 | 02.65 |
| CE MANUAL | 41602700 | A | 22 | 01.30 |
| TEST ROUTINES - 3447, 3649/405 | | | | |
| 3447-B CARD READER CONTROLLER REF INFO (USE 3248-A REF MAN) | 60212800 | M | 22 | 03.60 |
| CE MANUAL | | | | |
| TEST ROUTINES (USE 3447-A) | | | | |
| 3458-A LINE PRINTER CONTROLLER REFERENCE MANUAL | 60332800 | B | 22 | 01.90 |
| DIAGRAMS, CIRC. DESC., MAINT AND PARTS LIST | 60158200 | Z | 22 | 07.75 |
| CARD PLACEMENT, EQ SUMMARY, WIRE LIST CE MAN | 60197000 | S | 22 | 24.50 |
| 3500 COMPUTER SYSTEM COMPUTER SYSTEM REFERENCE MANUAL | 60200300 | D | 22 | 05.15 |
| INSTRUCTION CODES (USE 3300) | | | | |
| SMM REF INFO (USE 3300) | | | | |
| HARDWARE MAINT FEATURES (3500 MASTER) GENERAL INFORMATION MANUAL (USE 3300) | | | | |
| 3502 (BB313-A, BB314-A, GH104-A) SYSTEM STORAGE REF INFO (USE 3500 REF MAN) | | | | |
| 3504-1 (AC104-A, CR105-A) PROCESSOR REF INFO (USE 3500 COMPUTER SYSTEM REF MAN.) | | | | |
| 3507-1 (DC111-A) DATA CHANNEL REF INFO (USE 3500 COMPUTER SYSTEM REF MAN.) | | | | |
| 3514-1 (AC106-A, CR106-A) BASIC PROCESSOR REF INFO (USE 3500 COMPUTER SYSTEM REF MAN) | | | | |
| 3514-2 (AC106-A, AF102-A, CR106-A) BUSINESS DATA PROCESSOR REF INFO (USE 3500 COMPUTER SYSTEM REF MAN) | | | | |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------|---|----|-------|
| 3514-3 (AC106-A, AT124-A, CR106-A) MULTI-PROGRAMMING PROCESSOR REF INFO (USE 3500 COMPUTER SYSTEM REF MAN) | | | | |
| 3514-4 (AC106-A, AF102-A, AT124-A, CR106-A) GENERAL PURPOSE PROCESSOR REF INFO (USE 3500 COMPUTER SYSTEM REF MAN) | | | | |
| 3516-1 (FJ601-A, FV129-A) MULTIPLEXER CONTROLLER REFERENCE MANUAL | 41610700 | A | 22 | 01.00 |
| 3518 (FA416-B, FA417-B, FA420-B) MAGNETIC TAPE CONTROLLER REFERENCE MANUAL | 60287600 | P | 22 | 03.80 |
| 3522 (AT122-A, AT123-A) REAL TIME INTERRUPT REF INFO (USE 3500 COMPUTER SYSTEM REF MAN.) | | | | |
| 3528 (FA417-B, FA418-A, FA420-B) MAGNETIC TAPE CONTROLLER REF INFO (USE 3518) | | | | |
| 3553-1 (FA705-A/B) MASS STORAGE CONTROLLER REFERENCE MANUAL | 60278500 | B | 22 | 02.40 |
| 3553-2 (FA704-A/B/C) MASS STORAGE CONTROLLER REF INFO (USE 3553-1) | | | | |
| 3555-1 (FF307-B) LINE PRINTER CONTROLLER REFERENCE MANUAL | 60231300 | C | 22 | 01.00 |
| 3600 COMPUTER SYSTEM REFERENCE MANUAL | 60021300 | N | 22 | 03.30 |
| INSTRUCTION CODES 3600/3800 | 60044400 | C | | 03.00 |
| CUSTOMER ENGINEERING MANUALS | | | | |
| SYSTEM MAINT. MONITOR REF MANUAL | 60093900 | H | 22 | 57.50 |
| PARTS LIST | 60157300 | C | 22 | 05.80 |
| (THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES. ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.) | | | | |
| CARD TESTER REFERENCE/INSTRUCTION | 60096800 | | 22 | |
| 3601 CONSOLE DIAGRAMS | 60042600 | J | 22 | 06.35 |
| CARD PLACEMENT AND EQUATION SUM. CE MANUAL | 31605400 | A | 22 | 02.25 |
| CE INSTRUCTION MANUAL | 60043400 | B | 22 | 08.75 |
| WIRE TABS | 31600200 | C | 22 | 01.50 |
| 3602-A/3802-1 COMMUNICATIONS MOD CE DIAGRAMS | 60041700 | J | 34 | 01.60 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------------------|--------|----------|----------------|
| COMMUNICATION MOD INSTRUCTION/CE MANUAL C/P, EQ SUMMARY, W/L CE MANUAL (INCLUDES PREVIOUS PUB NO. 31605500) | 60096700 31600500 | E B | 22 22 | 03.50 12.85 |
| 3604-A/B COMPUTATION MODULE CE DIAGRAMS VOLS 1 AND 2 | 60042100 | AV | 34 | 08.45 |
| CE INSTRUCTION/CIRCUIT DESCRIPTION | 60047600 | | 22 | 18.00 |
| PRELIMINARY COMMAND TIMING CHARTS | 60093800 | | 22 | 14.70 |
| ARITHMETIC COMMAND TIMING CHARTS | 60100700 | | 22 | 06.45 |
| CARD PLACEMENT, EQ SUMMARY CE MANUAL | 31605600 | S | 22 | 42.35 |
| WIRE LIST CE MANUAL | 31600800 | P | 22 | 45.70 |
| 3604-B COMPUTATION MODULE WIRE LIST CARD PLACEMENT AND EQUATION SUM. VOLS. 1,2 | 17804500 60150700 | K L | 22 34 | 35.00 43.50 |
| 3606-A BI-DIRECTIONAL DATA CHAN CE DIAGRAMS CE INSTRUCTION MANUAL | 60041800 60043300 | F D | 34 22 | 01.25 07.45 |
| CHASSIS MAPS AND SUMMARY | 31605700 | D | 34 | 05.70 |
| WIRE TABS | 31601100 | D | 22 | 03.50 |
| 3607-A 24 BIT DATA CHANNEL CE DIAGRAMS | 60041900 | D | 34 | 03.30 |
| (THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES.ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.) | | | | |
| WIRE TABS | 31601400 | | | |
| CHASSIS MAPS AND SUMMARY | 31605800 | | | |
| 3608-A 48 BIT DATA CHANNEL CE DIAGRAMS | 60047900 | C | 34 | 03.10 |
| (THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES.ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.) | | | | |
| WIRE LIST | 31601700 | C | | |
| CHASSIS MAPS AND SUMMARY | 31605900 | B | | |
| 3609-A STORAGE MODULE CE DIAGRAMS CE INSTRUCTION MANUAL | 60042000 60095500 | R E | 34 22 | 03.75 05.95 |
| CARD PLACEMENTS, EQ SUMMARY AND WIRE TABS | 60159200 | B | 34 | 21.85 |
| 3610-A/3810-A COMMUNICATIONS MOD CE DIAGRAMS CE INSTRUCTION MANUAL | 60121400 60121300 | C D | 22 | 01.00 05.00 |
| (THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES.ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.) | | | | |
| CARD PLACEMENT, EQUATION SUMMARY | 31605200 | | | |
| WIRE LIST | 31605300 | | | |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------|----|----|-------|
| 3613 SIDEWAYS ALOGRITHM BOX | 60047700 | B | 22 | 03.00 |
| 362X-A MAGNETIC TAPE CONTROLLER REFERENCE MANUAL | 60331500 | C | 22 | 01.30 |
| CE DIAGRAMS MANUAL | 60042200 | AF | 34 | 10.00 |
| REFERENCE/INSTRUCTION MANUAL | 60043500 | J | 22 | 09.50 |
| CARD PLACEMENTS AND EQUATION SUMMARY | 31606100 | L | 34 | 37.00 |
| WIRE LIST CE MANUAL | 31602300 | P | 22 | 17.65 |
| 362X-B MAGNETIC TAPE CONTROLLER REF INFO (USE 362X-A) | | | | |
| CARD PLACEMENT AND EQUATION | 60159600 | J | 34 | 34.00 |
| WIRE LISTS CE MANUAL | 60159700 | J | 22 | 24.00 |
| 363X-A DTSK FILE CONTROLLER REFERENCE MANUAL | 60333200 | A | 22 | 01.55 |
| CIRCUIT DESC., MAINT., PARTS LIST, CARD PLACEMENT, EQUATION SUMMARY CE MANUAL | 60099800 | D | 22 | 22.55 |
| WIRE LISTS CE MANUAL | 60197300 | C | 22 | 10.00 |
| 3637-A DRUM STORAGE CONTROLLER REF/CE INFO (USE 3436-A) | | | | |
| 3637-B/C DRUM STORAGE CONTROLLER CE MANUAL | 60224900 | H | 22 | 07.50 |
| 3641-A CARD READER CONTROLLER CARD PLACEMENTS AND EQUATION SUMMARY | 31606200 | | 34 | 03.20 |
| (THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES.ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.) | | | | |
| REFERENCE/INSTRUCTION MANUAL | 60107200 | | | |
| WIRE TABS | 31602600 | | 22 | |
| 3643 CARD READ WIRE TABS CE MANUAL | 31602900 | | | 02.90 |
| 3644-A CARD PUNCH CONTROLLER REF INFO (USE 3446-A/B REF MAN) CE MANUAL | 60048400 | Z | 22 | 09.50 |
| TEST ROUTINES (USE 3446-A) | | | | |
| 3649-A CARD READER CONTROLLER REF INFO (USE 3248-A REF MAN) REFERENCE/INSTRUCTION MANUAL | 60097900 | B | 22 | 02.50 |
| CE MANUAL | 60049800 | W | 22 | 04.30 |
| TEST ROUTINES (USE 3447-A) | | | | |
| 3655-A LINE PRINTER ADAPTER EQ. SUM., CARD PLACEMENT, WIRE LIST CE MANUAL | 60291000 | A | 22 | 03.80 |
| CE DIAGRAMS MANUAL | 60042500 | E | 34 | 03.20 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|--|----------------------|----------------------|----------------------------------|
| 3659-A/B/C LINE PRINTER CONTROLLER REF INFO (USE 3256-A/B/C) DIAGRAMS CE MANUAL CIRCUIT DESCRIPTION, MAINT., PARTS LIST, CARD PLACEMENT, EQ SUMMARY, WIRE LIST CE MANUAL TEST ROUTINES (USE 3256-A) | 60094200 60126500 | S M | 22 22 | 02.70 10.95 |
| 3681-A DATA CHANNEL CONVERTER CE MANUAL REFERENCE MANUAL SYSTEM MAINTENANCE MONITOR REFERENCE SYSTEMS MAINT. MONITOR PROG. LISTINGS | 60042300 60333400 60169100 60181200 | F A B B | 22 22 22 22 | 13.05 01.00 07.50 10.60 |
| 3682-A/B/C SATELLITE CONTROLLER CE MANUAL REFERENCE MANUAL TEST ROUTINE | 60042400 60333500 41600700 | H A A | 22 22 22 | 03.00 01.00 01.00 |
| 3691-A PAPER TAPE READER/PUNCH REFERENCE MANUAL PAPER TAPE READER PUNCH WIRE TABS REFERENCE INSTRUCTION AND DIAGRAMS MANUAL | 60333000 60140800 60048300 | B D F | 22 22 22 | 01.00 01.50 03.40 |
| 3691-B/C/D/E PAPER TAPE READ/PUNCH CE MANUAL REF INFO (USE 3691-A) | 60124800 | T | 22 | 08.00 |
| 3692-A PROGRAM CONTROLLED I/O TYPEWRITER REFERENCE MANUAL CE DIAGRAMS WIRE TABS CHASSIS MAPS AND SUMMARY | 60332600 60094400 31603800 31606600 | A E C C | 22 34 22 34 | 01.00 02.50 01.75 05.50 |
| 3694-A PAPER TAPE READER/PUNCH DIAGRAMS REFERENCE MANUAL (THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES. ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.) PRICE AVAILABLE UPON REQUEST CARD PLACEMENT EQUATION SUMMARY | 60104900 60107400 31554400 31554300 | A A | 22 22 | 01.30 03.80 |
| 3694-C/D PAPER TAPE READER/PUNCH CE MANUAL REFERENCE MANUAL (THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES. ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.) PRICE AVAILABLE UPON REQUEST CARD PLACEMENT EQUATION SUMMARY | 60125400 60203300 31646700 60149700 | S A E M | 22 22 | 04.20 01.50 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------|----|----|-------|
| 3800 COMPUTER SYSTEM REFERENCE MANUAL | 60162300 | C | 22 | 04.70 |
| CUSTOMER ENGINEERING MANUALS | | | | |
| MAINTENANCE COMMAND TIMING CHARTS | 60160000 | A | 22 | 22.30 |
| CE MANUAL-POWER DIAGRAMS | 60194400 | A | 22 | 01.00 |
| PARTS LIST CE MANUAL | 60197700 | A | 22 | 08.60 |
| 3801-A CONSOLE DIAGRAMS,C/P,EQ SUMMARY,W/L AND TERM LIST CIRCUIT DESCRIPTION AND MAINTENANCE | 60159000 | B | | 02.40 |
| | 60199300 | A | 22 | 07.80 |
| 3802-A COMMUNICATION MODULF (USE 3602-A MANUAL | | | | |
| 3803-B STORAGE MOD DIAG,CIR DES,MAINT,C/P,W/L | 60184500 | C | 22 | 06.50 |
| 3804-A/3811-A COMPUTATION MOD AND RELOCATION UNIT DIAGRAMS AND CIRCUIT DESCRIPTION CARD PLACEMENT, EQUATION SUMMARY WIRE AND TERM LISTS, HAND TABS | 60154500 | R | 22 | 17.55 |
| | 60159900 | K | 34 | 30.30 |
| | 60186100 | J | 22 | 19.75 |
| 3806-A DATA CHANNEL CE MANUAL CE INSTRUCTION MANUAL | 60122700 | D | 22 | 09.25 |
| | 60100800 | B | 22 | 04.75 |
| 3810-A COMMUNICATION MODULE (USE 3610-A MANUAL | | | | |
| 3816 PRIORITY DATA CHANNEL CE DIAGRAM,CIRC DESC,P/L,CP,EQ SUM,W/L REFERENCE MANUAL | 60153000 | B | 22 | 16.05 |
| | 60157100 | A | 22 | 02.20 |
| 5100 CUSTOMER ENGINEERING MANUAL VOLS. 1 AND 2 | 14163300 | A | 22 | 12.00 |
| MIMIC SOFTWARE REFERENCE MANUAL | 14166700 | | | 01.35 |
| COMPASS ASSEMBLER SOFTWARE REF MAN | 14196600 | | | 03.90 |
| COMPASS SOFTWARE REFERENCE MANUAL | 14166800 | A | | 04.45 |
| PROGRAM CHECKOUT MONITOR SOFTWARE REF MAN | 14167100 | A | 22 | 01.05 |
| 5600 SERIES MPP REFERENCE MANUAL MAINTENANCE, DIAGS, WIPE LIST CE MANUAL | 14232000 | A | 22 | 07.85 |
| | 14247900 | A | 22 | 07.45 |
| 6000 COMPUTER SYSTEMS (6014, 6015, 6200, 6400, 6500, 6600, 6700) INSTRUCTION CARD | 60164500 | C | | 00.75 |
| INSTRUCTION CODES | 60141900 | F | | 01.00 |
| INPUT/OUTPUT SPECIFICATIONS (USE CYBER 72) 73, 74 I/O SPECIFICATIONS) REFERENCE MANUAL | 60100000 | AE | 22 | 03.50 |
| SCOPE 3.3 ON-LINE DIAGNOSTICS GIM | 60309800 | A | 22 | 01.00 |
| SCOPE 3.4 ON-LINE DIAGNOSTICS GIM | 60364700 | A | 22 | 01.05 |
| SCOPE 3.3 ON-LINE DIAGNOSTICS REFERENCE MAN. | 60320700 | 02 | 22 | 02.20 |
| SCOPE 3.4 ON-LINE DIAGNOSTICS REFERENCE MAN. | 60364800 | D | 22 | 03.15 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|----|----|-------|
| 6000/CYBER OPTIONS GENERAL INSTALLATION PROCEDURES MANUAL | 60415600 | A | 22 | 03.15 |
| CUSTOMER ENGINEERING MANUALS | | | | |
| PERIPHERAL CONTROLLER CABINETS REF/CE MANUAL (1700/3000/6000)(REFER TO 3000 SERIES) | | | | |
| REFRIGERATION MANUALS - (SEE CATALOG SEC 4) | | | | |
| 6014 6000 STATION (AT217-A) REF INFO (PPU AND CPU - USE 6000 SERIES REF MANUAL) (INTERFACE REF INFO - USE 6682 AND DT122-A REF OR REF/CE MANUALS) | | | | |
| 6015-7/8/9 6000 STATION (USE 6014) | | | | |
| 6400/6500-A/B/C CENTRAL COMPUTERS | | | | |
| * THE MANUALS LISTED BELOW ARE USED * | | | | |
| * WITH ALL 6400/6500-A/B/C COMPUTERS * | | | | |
| * UNLESS INDICATED OTHERWISE * | | | | |
| **DIAGRAM MANUALS** | | | | |
| CPU,PPU,CENTRAL MEMORY,CLOCK,ECS COUPLER AND POWER DIAGRAMS | 60146100 | BL | 22 | 15.00 |
| **MAINTENANCE MANUALS** | | | | |
| MAINTENANCE AND COMMAND TIMING | 60182100 | J | 22 | 23.50 |
| INSTANT SMM CODE BOOK (64/65/6600) | 60299500 | D | | 01.00 |
| SYSTEM MAINTENANCE MONITOR REFERENCE MANUAL VOLS 1-5(AVAIL IN SETS ONLY) | 60160600 | 18 | 22 | 31.00 |
| MAINTENANCE PMI/PMP CE MANUAL | 60309600 | G | 22 | 27.15 |
| **PARTS DATA** | | | | |
| PARTS LIST(6404-A,6414-A/B/C ONLY) | 60187200 | C | 22 | 08.60 |
| PARTS LIST(6404-A,6415-A/B/C ONLY) | 60266300 | A | 22 | 10.85 |
| PARTS LIST(6413-C/O ONLY) | 60223300 | C | 22 | 06.00 |
| PARTS LIST(6514-C ONLY) | 60224200 | B | 22 | 04.05 |
| PARTS LIST(6513-C/D ONLY) | 60267200 | A | 22 | 09.70 |
| **WIRE LISTS** | | | | |
| CHASSIS 1 CHASSIS TABS (INCL 6411/16-A/B) | 60166100 | T | 22 | 15.00 |
| CHASSIS 2 CHASSIS TABS (INCL 6400/6500-D) | 60166200 | AA | 22 | 25.30 |
| CHASSIS 3 CHASSIS TABS | 60166300 | AR | 22 | 16.60 |
| CHASSIS 4 CHASSIS TABS | 60180000 | L | 22 | 15.00 |
| CHASSIS 5/7 CHASSIS TABS | 60166400 | M | 22 | 10.00 |
| CHASSIS 8 CHASSIS TABS | 60187700 | V | 22 | 06.85 |
| CHASSIS 9/11 CHASSIS TABS | 60197100 | C | 22 | 10.00 |
| CHASSIS 10/12 CHASSIS TABS | 60197200 | C | 22 | 10.00 |
| CABLE TABS(FOR 6404-A,6414/6514-A/B/C ONLY) | 60166000 | M | 22 | 10.70 |
| CABLE TABS(FOR 6405-A,6415-A/B/C ONLY) | 60169700 | M | 22 | 07.50 |
| CABLE TABS(FOR 6413/6513-A/B/C ONLY) | 60188900 | G | 22 | 14.85 |
| 6411-A,6416-A AUGMENTED I/O BUFFER/CONTROL DIAGRAMS AND CIRCUIT DESCRIPTIONS | | | | |
| CHASSIS 1 CHASSIS TABS(SEE 64/6500-A/B/C) | 60146200 | U | 22 | 05.05 |
| CHASSIS 3 CHASSIS TABS CE MANUAL | 60180100 | H | 22 | 13.80 |
| CHASSIS 4 CHASSIS TABS CE MANUAL | 60187800 | G | 22 | 06.10 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|----|----|-------|
| CABLE TABS CE MANUAL | 60187900 | K | 22 | 07.10 |
| 6400/6500-D CENTRAL COMPUTER | | | | |
| * THE MANUALS LISTED BELOW ARE USED * | | | | |
| * WITH ALL 6400/6500-D COMPUTERS * | | | | |
| * UNLESS INDICATED OTHERWISE * | | | | |
| **DIAGRAM MANUALS** | | | | |
| CPU, CENTRAL MEMORY, CLOCK, ECS COUPLER AND POWER DIAGRAMS | 60246800 | AG | 22 | 27.75 |
| PERIPH PROCESSING UNIT DIAGRAMS | 60246500 | K | 22 | 03.05 |
| **MAINTENANCE MANUALS** | | | | |
| SYSTEM MAINT MONITOR REF(SEE 64/6500-A/B/C) | | | | |
| MAINTENANCE-PMI/PMP (SEE 64/6500-A/B/C) | | | | |
| **PARTS DATA** | | | | |
| PARTS LIST (6414-D ONLY) | 60268000 | B | 22 | 03.50 |
| PARTS LIST(6514-D ONLY) | 60267100 | A | 22 | 03.80 |
| PARTS LIST(6415-D,6513-D,SEE 64/6500-A/B/C) | | | | |
| **WIRE LISTS** | | | | |
| CHASSIS 1 CHASSIS/CABLE TABS | 60246900 | S | 22 | 38.40 |
| CHASSIS 2 CHASSIS TABS(SEE 64/6500-A/B/C) | | | | |
| CHASSIS 3 CHASSIS/CABLE TABS | 60248500 | U | 22 | 12.00 |
| CHASSIS 4 CHASSIS/CABLE TABS | 60248600 | H | 22 | 14.00 |
| CHASSIS 5 CHASSTIS/CABLE TABS CE MANUAL | 60248700 | C | 22 | 13.00 |
| CHASSIS 6 CHASSIS/CABLE (FOR 6415.D ONLY) | 60249000 | K | 22 | 10.60 |
| CHASSIS 8 CHASSIS/CABLE TABS | 60249100 | S | 22 | 13.65 |
| CHASSIS 9/11 CHASSIS/CABLE TABS | 60248800 | E | 22 | 14.30 |
| CHASSIS10/12 CHASSIS/CABLE TABS | 60248900 | F | 22 | 09.20 |
| HAND TABS,SENSE AMP WIRING(FOR 64/65/6600-D) | 60269100 | A | 22 | 02.38 |
| 6413-E (AA105-A WITH AT140-A) | | | | |
| 6414-E (AA105-A) | | | | |
| 6415-E (AA103-A) CENTRAL COMPUTER | | | | |
| 6415-7 (AA103-D) CENTRAL COMPUTER | | | | |
| 6415-8 (AA103-C) CENTRAL COMPUTER | | | | |
| 6415-9 (AA103-B) CENTRAL COMPUTER | | | | |
| 6500-C USE STANDARD 6400-C MANUALS. IF AT196-A/B AND DT117-A OR DT204-A AND AT196-A AND AT195-A ARE INSTALLED USE MANUALS LISTED UNDER AT195-A. | | | | |
| 6500-C WITH ECS CAPABILITY USE MANUALS LISTED UNDER AT195-A | | | | |
| 6500-D USE STANDARD 6400-D MANUALS. IF AT198-A AND DT143-A OR DT205-A AND AT194-A AND AT198-A ARE INSTALLED USE MANUALS LISTED UNDER AT194-A. | | | | |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|----|----|-------|
| 6500-D WITH ECS CAPABILITY USE MANUALS LISTED UNDER AT194-A. | | | | |
| 6500-E USE STANDARD 6400-E MANUALS. IF AT141-A AND DT143-A OR AT141-A AND DT205-A AND AT194-A ARE INSTALLED USE MANUALS LIST UNDER AT194-A. | | | | |
| 6500-E WITH ECS CAPABILITY USE MANUALS LISTED UNDER AT194-A. | | | | |
| 6601-A THROUGH F CENTRAL COMPUTER(SER.1-7) DIAGRAMS AND CIRCUIT DESC(SEE 6601-H/J) CHASSIS 1,6,7,8,13,14,15 AND 16 CHASSIS TABS(SEE 6601-H/J) * THE FOLLOWING MANUALS FOR THE * * ABOVE SYSTEM ARE AVAILABLE ON A * * A SPECIAL ORDER BASIS IN MAX.QTY * * OF 2 COPIES.ALLOW AT LEAST 3-4 * * WEEKS FOR PROC.AND DELIVERY. * PRICE AVAILABLE UPON REQUEST | | | | |
| CHASSIS 2 CHASSIS TABS(INCL 6604-B) | 60161500 | | 22 | |
| CHASSIS 3 CHASSIS TABS | 60161600 | | 22 | |
| CHASSIS 4 CHASSIS TABS | 60161800 | | 22 | |
| CHASSIS 5 CHASSIS TABS(INCL 6604-B) | 60162000 | | ?? | |
| CHASSIS 9 CHASSIS TABS | 60162100 | | 22 | |
| CHASSIS 10 CHASSIS TABS | 60162200 | | 22 | |
| CABLE TABS(SEE 6601-H/J) | | | | |
| 6601-H/J CENTRAL COMPUTER **DIAGRAM MANUALS** | | | | |
| CPU, FUNCTIONAL UNIT, PERIPHERAL PROC. UNIT CLOCK,ECS COUPLER,AND POWER DIAGRAMS **MAINTENANCE AIDS** | 60119300 | DR | 22 | 09.15 |
| SYSTEM MAINT MON.REF(SEE 6400/6500-A/B/C) MAINTENANCE-PMI/PMP(SFE 6400/6500-A/B/C) **PARTS DATA** | | | | |
| PARTS LIST(FOR 6601-H/J,6613-A/B/C ONLY) **WIRE LISTS** | 60157400 | D | 22 | 17.20 |
| CHASSIS 1 CHASSTIS TABS | 63019800 | AD | 22 | 17.35 |
| CHASSIS 2 CHASSIS TABS | 63019700 | AL | 22 | 25.55 |
| CHASSIS 3 (FOR 6601-H/J,6613-A/B/C ONLY) | 63019600 | BD | 22 | 14.30 |
| CHASSIS 4 (FOR 6601-H/J,6613-A/B/C ONLY) | 63019200 | W | 22 | 10.00 |
| CHASSIS 5 CHASSIS TABS | 60150800 | BP | 22 | 16.85 |
| CHASSIS 6 CHASSIS TABS | 63017400 | Z | 22 | 20.00 |
| CHASSIS 7 CHASSIS TABS | 63017300 | P | 22 | 21.10 |
| CHASSIS 8 CHASSIS TABS | 63017200 | AF | 22 | 21.20 |
| CHASSIS 9 (FOR 6601-H/J,6613-A/B/C ONLY) | 63017100 | V | 22 | 10.00 |
| CHASSIS 10 (FOR 6601-H/J,6613-A/B/C ONLY) | 63016900 | S | 22 | 12.30 |
| CHASSIS 12 CHASSIS TABS(SEE 6612-B/E) | | | | |
| CHASSIS 13 (FOR 6601-H/J,6613-A/B/C ONLY) | 63025600 | R | 22 | 09.15 |
| CHASSIS 14 (FOR 6601-H/J,6613-A/B/C ONLY) | 63025500 | P | 22 | 07.80 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------|----|----|-------|
| CHASSIS 15 (FOR 6601-H/J,6613-A/B/C ONLY) | 63025400 | N | 22 | 08.00 |
| CHASSIS 16 (FOR 6601-H/J,6613-A/B/C ONLY) | 63024900 | R | 22 | 07.25 |
| CABLE TABS(FOR 6601-H/J,6613-A/B/C ONLY) | 60148900 | AJ | 22 | 17.05 |
| 6602-A THROUGH E CONSOLE DISPLAY CONTROLLER REFERENCE MANUAL | 60333900 | B | 22 | 01.00 |
| DIAGRAMS (6602-A THRU E, 6612-A THRU E) | 60389800 | A | 22 | 03.05 |
| PARTS LIST CE MANUAL | 60266400 | A | 22 | 01.00 |
| CHASSIS/CABLE TABS CE MANUAL | 63016700 | N | 22 | 32.45 |
| 6603-A/B/C DISK SYSTEM DIAGRAMS, WIRE LISTS CE MANUAL | 60389900 | A | 22 | 06.30 |
| REFERENCE MANUAL | 60334000 | A | 22 | 01.00 |
| SERVICE MANUAL-DIAGRAMS,CIRC DESCRIPTION | 60127000 | C | 22 | 20.70 |
| PARTS LIST CE MANUAL | 60266500 | B | 22 | 01.20 |
| MAINTENANCE-ELECTRONIC TEST PROCEDURES | 60213300 | C | 22 | 02.40 |
| 6604-A/C CENTRAL COMPUTER DIAGRAMS(SEE 6601-H/J) | | | | |
| CHASSIS 1,2,5,6,7,AND 8 CHASSIS TABS(SEE 6601-H/J) | | | | |
| CHASSIS 3 (FOR 6604-A/C,6614-A/B/C ONLY) | 63033800 | BG | 22 | 17.50 |
| CHASSIS 4 (FOR 6604-A/C,6614-A/B/C ONLY) | 63033700 | Z | 22 | 13.00 |
| CHASSIS 9 (FOR 6604-A/C,6614-A/B/C ONLY) | 63033600 | S | 22 | 10.00 |
| CHASSIS 10(FOR 6604-A/C,6614-A/B/C ONLY) | 63033500 | T | 22 | 13.85 |
| CABLE TABS(FOR 6604-A/C,6614-A/B/C ONLY) | 60149600 | AG | 22 | 11.50 |
| PARTS LIST(FOR 6604-A/C,6614-A/B/C ONLY) | 60267300 | A | 22 | 11.00 |
| SYSTEM MAINT MONITOR REFERENCE VOL 1-5(SEE 6601-H/J) | | | | |
| 6604-B COMPUTER SYSTEM(SERIAL 1-7) DIAGRAMS AND CIRCUIT DESC(SEE 6601-H/J) | | | | |
| SYST.MAINTENANCE MONITOR(SEE 6601-H/J) | | | | |
| PARTS LIST (SEE 6604-A) | | | | |
| CHASSIS 1,6,7,AND 8(SEE 6601-H/J) | | | | |
| CHASSIS 2(SEE 6601-A THROUGH F) | | | | |
| CHASSIS 5(SEE 6601-A THROUGH F) | | | | |
| CHASSIS 9 AND 10(SEE 6604-A/C) | | | | |
| 6612-A THROUGH E CONSOLE DISPLAY CONTROLLER REF INFO (USE 6602-A) | | | | |
| DIAGRAMS AND CIRC DESC(SEE 6602-A-E) | | | | |
| PARTS LIST(SEE 6602-A-E) | | | | |
| CHASSIS/CABLE TABS(SEE 6602-A-E) | | | | |
| 6612-F/G CONSOLE DISPLAY CONTROLLER REF INFO (USE 6602-A) | | | | |
| DIAGRAMS, CIRC DESC, CARD PLACMT, WIRE LIST, | 60246400 | K | 22 | 16.20 |
| 6613-A/B/C COMPUTER SYSTEM(SEE 6601-H/J) | | | | |
| 6613-D COMPUTER SYSTEM CPU, FUNCTIONAL UNIT CE DIAGRAMS | 60224800 | W | 22 | 15.00 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------|---|----|-------|
| CENT. MEM, CLOCK, ECS COUPLER, POWER DIAGRAMS PERIPH PROC UNIT DIAGRAMS(SEE 6400/6500-D) | 60246600 | U | 22 | 04.90 |
| PARTS LIST CE MANUAL | 60253300 | C | 22 | 08.65 |
| MAINTENANCE-CLOCK TIMING | 60289000 | B | 22 | 01.80 |
| SYST MAINT MONITOR REF VOL 1-5(SEE 6601-H) | | | | |
| CHASSIS 1 CHASSIS TABS(SEE 64/6500-D) | | | | |
| CHASSIS 4 CHASSIS/CABLE TABS CE MANUAL | 60247000 | R | 22 | 19.55 |
| CHASSIS 5 CHASSIS/CABLE TABS CE MANUAL | 60247100 | Z | 22 | 20.00 |
| CHASSIS 6 CHASSIS/CABLE TABS CE MANUAL | 60247200 | H | 22 | 17.40 |
| CHASSIS 7 CHASSIS/CABLE TABS CE MANUAL | 60247300 | E | 22 | 23.45 |
| CHASSIS 8 CHASSIS/CABLE TABS CE MANUAL | 60247400 | J | 22 | 26.20 |
| CHASSIS 9 CHASSIS/CABLE TABS CE MANUAL | 60247500 | N | 22 | 10.90 |
| CHASSIS 10 CHASSIS/CABLE TABS CE MANUAL | 60247700 | F | 22 | 07.60 |
| CHASSIS 11/15 CHASSIS/CABLE TABS CE MANUAL | 60247900 | C | 22 | 10.20 |
| CHASSIS 12/16 CHASSIS/CABLE TABS CE MANUAL | 60248100 | D | 22 | 12.80 |
| CHASSIS 13/14 CHASSIS/CABLE TABS CE MANUAL | 60248300 | J | 22 | 19.80 |
| HAND TABS-MEMORY SENSE AMP W/L(SEE 6400-D) | | | | |
| 6613-E (AA104-A) | | | | |
| 6614-A/B/C COMPUTER SYSTEM(SEE 6604-A) | | | | |
| 6614-D COMPUTER SYSTEM DIAGRAM MANUALS(SEE 6613-D) | | | | |
| PARTS LIST CE MANUAL | 60267400 | B | 22 | 05.05 |
| MAINTENANCE MANUALS(SEE 6613-D) | | | | |
| CHASSIS 1 CHASSIS/CABLE(SEE 64/6500-D) | | | | |
| CHASSIS 4,6,7,AND 8 TABS(SEE 6613-D) | | | | |
| CHASSIS 5 CHASSIS/CABLE TABS | 60251200 | Y | 22 | 17.45 |
| CHASSIS 9 CHASSIS/CABLE TABS | 60247600 | P | 22 | 14.50 |
| CHASSIS 10 CHASSIS/CABLE TABS | 60247800 | D | 22 | 07.75 |
| CHASSIS 11 CHASSIS/CABLE TABS | 60248000 | E | 22 | 08.75 |
| CHASSIS 12 CHASSIS/CABLE TABS | 60248200 | D | 22 | 12.00 |
| HAND TABS-MEMORY SENSE AMP W/L(SEE 6400-D) | | | | |
| DATA CHANNEL EQUIP CHASSTS TABS(SEE DC211-A) | | | | |
| 6614-E (AA103-A) | | | | |
| 6622-A/B MAGNETIC TAPE CONTROLLER REFERENCE MANUAL | 60333600 | A | 22 | 01.10 |
| DIAGRAMS, WIRE LIST CE MANUAL | 60390000 | A | 22 | |
| (THE FOLLOWING MANUALS MANUALS FOR THE ABOVE PRODUCT ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES ALLOW AT LEAST 3-4 WEEKS FOR DELIVERY) | | | | |
| PARTS LIST CE MANUAL | 60253200 | A | 22 | 01.70 |
| 6633-C (BB325-A) EXTENDED CORE STORAGE ASSEM. | | | | |
| 6633-D (BB325-B) EXTENDED CORE STORAGE ASSEM. | | | | |
| 6634-C (BB319-A) EXTENDED CORE STORAGE ASSEM. | | | | |
| 6634-D (BB319-B) EXTENDED CORE STORAGE ASSEM. | | | | |
| 6635-C (BB323-A) EXTENDED CORE STORAGE ASSEM. | | | | |
| 6635-D (BB323-B) EXTENDED CORE STORAGE ASSEM. | | | | |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|-----|----|-------|
| 6636-C (BB324-A) EXTENDED CORE STORAGE ASSEM. 6636-D (BB324-B) EXTENDED CORE STORAGE ASSEM. EXTENDED CORE STORAGE REFERENCE MANUAL | 60225100 | F,G | 22 | 01.00 |
| 6638 DISK FILE (USE 6639) | | | | |
| 6639 DISK FILE SYSTEM REFERENCE MANUAL | 60334100 | E | 22 | 01.00 |
| DIAGS, CIRC DESC, MAINT, P/L, C/P, W/L, CHASSIS TABS | 60227300 | H | 22 | 04.45 |
| 6640-A/B EXT. CORE STORAGE CONTROLLER DIAGRAMS CIRC. DESC., MAINT., P/L, C/P, AND W/L | 60186000 | AM | 22 | 07.60 |
| 6640-D ECS CONTROLLER HDWE MAINT. MANUAL | 60440500 | B | 22 | 25.20 |
| 6641-A (DC110-A) ECS MASS STORAGE CONTROLLER REFERENCE MANUAL | 60334200 | A | 22 | 01.00 |
| 6642-1 (DC135-A) DISTRIBUTIVE DATA PATH OPERATION AND PROGRAMMING REFERENCE MANUAL | 60376300 | A | 22 | 01.00 |
| 6671-A/B (FJ411-A/B) DATA SET CONTROLLER REFERENCE MANUAL | 60334600 | E | 22 | 02.70 |
| 6671-1 (FJ427-A) DATA SET CONTROLLER REF INFO (USE 6671-A/B) | | | | |
| 6671-3 (FJ440-A) DATA SET CONTROLLER HARDWARE REFERENCE MANUAL | 60399900 | B | 22 | 01.30 |
| 6673/6674 DATA SET CONTROLLER REFERENCE MANUAL | 60334500 | B | 22 | 01.00 |
| CIRCUIT DESCRIPTION, MAINTENANCE, PARTS LIST CARD PLACEMENT, EQ SUMMARY CE MANUAL | 60201500 | N | 22 | 04.25 |
| WIRE LISTS CE MANUAL | 60205400 | L | 22 | 02.35 |
| 6675 DATA SET CONTROLLER CE MANUAL | 38700400 | D | 22 | 01.45 |
| 6676-A TTY MULTIPLEXER REFERENCE MANUAL | 38706000 | C | 22 | 01.20 |
| CE MANUAL | 38708400 | K | 22 | 10.30 |
| 6676-B/C TTY MULTIPLEXER REFERENCE MANUAL | 38707800 | E | 22 | 02.90 |
| CE MANUAL | 38706100 | S | 22 | 23.95 |
| 6681-B/C/D DATA CHANNEL CONVERTER REFERENCE MANUAL | 60334400 | F | 22 | 02.55 |
| CE INFO (USE DC211-A, CATALOG SEC. 1) | | | | |
| 6681-F DATA CHANNEL CONVERTER | | | | |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------------------|--------|----------|----------------|
| CE MANUAL | 60440800 | A | 22 | 17.25 |
| 6682-A SATELLITE COUPLER REFERENCE MANUAL CE MANUAL | 60334300 60390100 | B E | 22 22 | 01.50 02.10 |
| 6683-A SATELLITE COUPLER REF INFO (USE 6682-A) CE INFO (USE 6682-A) | | | | |
| 6684-1 (DC211-A) DATA CHANNEL CONVERTER REF INFO (USE 6681-B/C/D) | | | | |
| 6700 DUAL CENTRAL PROCESSOR REF INFO (USE 6000) 6700-A/B/C (USE AT153-A OR AT154-A AND AE116-B) 6700-D (USE AT155-A OR AT156-A AND AE116-C) 6700-E (USE AE116-C) | | | | |
| 7021-1 (FA434-A/B, DT209-D OR FA401-A/B) MAGNETIC TAPE CONTROLLER GENERAL INFORMATION MANUAL | 60365100 | C | 22 | 01.25 |
| 7021-2 (FA434-A/B, DT209-D OR FA402-A/B) MAGNETIC TAPE CONTROLLER REF INFO (USE 7021-1) | | | | |
| 7030-X ECS REF INFO FOR ECS SYSTEMS (USE CYBER 72/73/74 ECS DESCRIPTION/PROGRAMMING MANUAL - VOL.3 - PUBLICATION NUMBER 60347100) POWER DIST/WARNING SYSTEM INFO (USE AA115-A) | | | | |
| 7030-1 (6640-B, AT247-A, BB395-A, DC135-A) ECS 125K (FOR CYBER 72 OR 73) | | | | |
| 7030-1 (6640-B, AT249-A, BB395-A, DC135-A) ECS 125K (FOR CYBER 74) | | | | |
| 7030-2 (6640-B, AT247-A, BB394-A, DC135-A) ECS 250K (FOR CYBER 72 OR 73) | | | | |
| 7030-2 (6640-B, AT249-A, BB394-A, DC135-A) ECS 250K (FOR CYBER 74) | | | | |
| 7030-4 (6640-B, AT247-A, BB393-A, DC135-A) ECS 500K (FOR CYBER 72 OR 73) | | | | |
| 7030-4 (6640-B, AT249-A, BB393-A, DC135-A) ECS 500K (FOR CYBER 74) | | | | |
| 7030-8 (6640-B, AT247-A, BB393-A, DC135-A) ECS 1000K (FOR CYBER 72 OR 73) | | | | |
| 7030-8 (6640-B, AT249-A, BB393-A, DC135-A) ECS 1000K (FOR CYBER 74) | | | | |
| 7030-16 (6640-B, AT247-A, BB393-A, DC135-A) ECS 2000K (FOR CYBER 72 OR 73) | | | | |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------------------|--------|----------|----------------|
| 7030-16 (6640-B, AT249-A, 9B393-A, DC135-A) ECS 2000K (FOR CYBER 74) | | | | |
| 7030-1XX (CYBER 170) EXTENDED CORE STORAGE SUBSYSTEM HARDWARE REFERENCE MANUAL | 60430000 | B | 22 | 03.25 |
| 7054-1 (DT203-C, FA710-A/B/C/D/E/F, FA719-A/B/C/D, MA710-A/B) GENERAL INFORMATION MANUAL OPERATION AND PROGRAMMING MANUAL | 60364400 60363900 | D J | 22 22 | 02.60 01.65 |
| 7054-2 (DT203-C, DT220-A/B/D, FA710-A/B/C/D, FA719-A/B/C/D, MA710-A, MA720-B) DISK STORAGE CONTROLLER GENERAL INFO (USE 7054-1) OPERATION AND PROGRAMMING (USE 7054-1) | | | | |
| 7054-21 (FA722-A/B, MA710-A) DISK STORAGE CONTROLLER REF INFO (USE 7054-1) | | | | |
| 7054-22 (FA722-A/B, DT220-C, MA710-A) DISK STORAGE CONTROLLER REF INFO (USE 7054-1) | | | | |
| 7054-41 (DT716-A, FA722-A/B, MA710-A) DISK STORAGE CONTROLLER REF INFO (USE 7054-1) | | | | |
| 7054-42 (DT220-C, FA722-A/B, MA710-A) DISK STORAGE CONTROLLER REF INFO (USE 7054-1) | | | | |
| 7077-1 (DT175-A, FJ430-A, GH408-A) COMMUNICATIONS STATION REFERENCE MANUAL | 60364600 | A | 22 | 01.75 |
| 7600 COMPUTER SYSTEM REF INFO (USE CYBER 76 REFERENCE MANUAL) | | | | |
| 7601-1 (AA102-A, AB101-A, GH214-A, CC514-A/B, GE226-A, GE232-A) CENTRAL COMPUTER REF INFO (USE 7600 COMPUTER SYSTEM REF MAN.) | | | | |
| 7611-1/2 (AB101-A, AB102-A/B, GH216-A, GH218-A, GH105-A/B, GE232-A) I/O STATION | | | | |
| 7611-11 () PERIPHERAL COMMUNICATIONS STATION REFERENCE MANUAL | 60399400 | C | 22 | 02.95 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------------------------------|---|----|-------------------------|
| 7618-1 (FA428-A) MAGNETIC TAPE CONTROLLER REFERENCE MANUAL | 60341600 | H | 22 | 02.00 |
| 7622-1 (FA434-A/B, DT210-B OR FA403-A/B) MAGNETIC TAPE CONTROLLER REF INFO (USE 7021-1) | | | | |
| 7622-2 (FA438-A/B, DT210-B OR FA404-A/B) MAGNETIC TAPE CONTROLLER REF INFO (USE 7021-1) | | | | |
| 7628-1 (FA429-A) MAGNETIC TAPE CONTROLLER REF INFO (USE 7618-1) | | | | |
| 7629-1/2 (FA428-A, FA429-A) MAGNETIC TAPE CONTROLLER SUBSYSTEM REF INFO (USE 7618-1) | | | | |
| 7638-1 (BH405-C, FA802-A, GH217-A) DISK STORAGE SUBSYSTEM REFERENCE MANUAL SEE INFO FOR CONTROLLER (USE FA802-A, CATALOG SECTION 1) | 60265500 | D | 22 | 01.00 |
| 7639-1 (FA202-A) MASS STORAGE CONTROLLER HOWE REFERENCE MANUAL | 60437300 | A | 22 | 01.50 |
| 7639-2 (FA103-A, FA202-A) MASS STORAGE CONTROLLER REF INFO (USE 7639-1) | | | | |
| 7654-1 (DT210-A, FA710-A/B/C/D/E/F, FA720-A/B/C/D, MA710-A, MA720-A) DISK STORAGE CONTROLLER GENERAL INFO (USE 7054-1) OPERATION AND PROGRAMMING (USE 7054-1) | | | | |
| 7681 (DK518-A) DATA CHANNEL CONVERTER REFERENCE MANUAL | 60356000 | C | 22 | 01.00 |
| 7683-1 (DT122-A) REMOTE CHANNEL COUPLER | | | | |
| 7700 () DUAL PROCESSOR COMPUTER SYSTEM HARDWARE REFERENCE MANUAL | 60396300 | A | 22 | 12.90 |
| 8010 DATA COLLECTION SYSTEM OF DIAGRAMS MAN USERS MANUAL | 36816700 36822500 | A | | 03.50 01.90 |
| 8011 DATA COLLECTOR/REFERENCE MANUAL ILLUSTRATED PARTS LIST WIRE LIST MOD A | 40806600 40809600 40816100 | | 22 | 03.00 01.75 07.30 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------|----|----|-------|
| ILLUSTRATED PARTS LIST | 40820100 | | | 01.75 |
| 8011-B DATA COLLECTOR DIAGRAMS AND WIRE LIST | 65725100 | A | 22 | 02.70 |
| 8012 REMOTE MULTIPLEXER/8017 LINE MODULE REFERENCE/CUSTOMER ENGINEERING MANUAL | 36816400 | A | | 01.90 |
| 8013 MASTER MULTIPLEXER REFERENCE MANUAL | 36816300 | | 22 | 01.00 |
| 8019-1 (FF106-A) DOCUMENT READER CONTROLLER REFERENCE MANUAL | 60368700 | 01 | 22 | 01.15 |
| 8022-A/B PAGE READER CONTROLLER REFERENCE MANUAL | 60167100 | F | 22 | 06.60 |
| CE MANUAL | 60167200 | J | 22 | 03.65 |
| 8030 RECORD TRANSMISSION TERMINAL USERS MANUAL | 36822900 | | | 01.75 |
| 8041-A/8042-A/8081-A/8082-A CARD PLACEMENT AND EQUATION SUMMARY | 60127800 | P | 22 | 03.00 |
| 8046-A DISK PACK CONTROLLER CE MANUAL | 60163900 | A | 22 | 07.70 |
| 8047-A/B DISK DRIVE CONTROLLER CE MANUAL REFERENCE MANUAL | 60159400 | A | 22 | 10.40 |
| | 60159300 | C | 22 | 03.05 |
| 8050 INFORMATION CONTROL SYSTEM 160-A/8050 COMPUTER MAINTENANCE -CRUCIBLE) | 36811000 | | | 12.15 |
| DIAGRAMS (CRUCIBLE) | 36811700 | | 34 | 03.10 |
| DIAGRAMS (DUPONT) | 36812600 | | | 04.50 |
| 8061 DATA SET CONTROLLER REFERENCE MANUAL (REVISED) | 36810100 | 02 | 22 | 02.40 |
| 8063 DATA SET CONTROLLER REFERENCE/CE MANUAL | 36810200 | D | | 01.75 |
| USERS MANUAL | 36817500 | | | 01.50 |
| 8066-B COMMUNICATIONS TERMINAL CONTROLLER REFERENCE MANUAL | 13791700 | | | 01.00 |
| CE MANUAL VOL. 1 | 13791800 | D | 22 | 01.70 |
| CE MANUAL VOL. 2 | 13791900 | C | 22 | 05.20 |
| 8067 DATA SET CONTROLLER REFERENCE MANUAL | 36814000 | A | | 01.50 |
| USERS MANUAL | 36819900 | | | 01.00 |
| 8070-A/B MAG TAPE SYNCHRONIZER REF/CE MANUAL | 60145300 | H | | 07.85 |
| 8071-A/8072-A MAG TAPE SYNCH CE DIAGRAMS CARD PLACEMENT AND EQUATION SUMMARY | 60091300 | M | 34 | 02.00 |
| | 60089800 | K | 22 | 04.00 |
| NORMAL CHANNEL LONG LINE DRIVERS CE MANUAL | 60123300 | A | 22 | 01.00 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|----|----|-------|
| 8073-A/B PAPER TAPE PUNCH REF INFO (USE 8090 REF MANUAL) | | | | |
| 8075 TALLY PAPER TAPE READER REFERENCE/INSTR | 60116900 | | | 04.60 |
| 8076 COMMUNICATION TERMINAL CONTROLLER CE DIAGRAMS | 36823800 | 1 | 34 | 01.80 |
| CE MAINTENANCE MANUAL | 36816600 | | 22 | 01.80 |
| 8083-A ARITHMETIC UNIT CE DIAGRAMS | 60091100 | | 34 | 02.50 |
| CARD PLACEMENTS AND EQUATION SUMMARY | 60149800 | | 22 | 03.00 |
| LONG LINE DRIVERS CE MANUAL | 60124400 | A | 22 | 01.00 |
| 8084A/8085A AUXILIARY MEMORY CE DIAGRAMS | 60091200 | F | 34 | 02.60 |
| CARD PLACEMENTS AND EQUATION SUMMARY | 60140700 | C | 22 | 03.20 |
| 8090 COMPUTER SYSTEM REFERENCE MANUALS | | | | |
| INPUT/OUTPUT SPECIFICATIONS REFERENCE MANUAL | 60102000 | B | 22 | 01.00 |
| | 60091500 | E | 22 | 08.55 |
| CUSTOMER ENGINEERING MANUALS | | | | |
| CROSS TABS AND CABLE TABS MANUAL | 24140300 | V | 22 | 03.75 |
| CE DIAGRAMS | 60091000 | AC | 34 | 14.05 |
| CE INSTRUCTION MANUAL, PART 1 | 60091600 | E | 22 | 06.00 |
| CE INSTRUCTION, PART 2 MAINTENANCE MANUAL | 60101900 | D | 22 | 26.00 |
| 8090 MCSMM REFERENCE MANUAL VOL 1-2 (SEE 160A SECTION) | | | | |
| 8090 MCSMM PROGRAM LISTINGS, VOL 1-2 (SEE 160-A SECTION) | | | | |
| 8090 NORMAL CHANNEL LONG LINE DRIVERS CE MAN. | 60123200 | A | 22 | 01.00 |
| BUFFER CHANNEL LONG LINE DRIVERS CE MANUAL | 60123100 | A | 22 | 01.00 |
| COMPUTER 1/COMPUTER 2 I/O LONG LINE DRIVER CE MANUAL | 60123500 | A | 22 | 01.00 |
| 8090/8084 EXTERNAL BUFFER CHANNEL LONG LINE DRIVERS CE MANUAL | 60123400 | A | 22 | 01.00 |
| 8092 TELEPROGRAMMER CE MANUAL VOL II OF II, CABLE AND WIRE TABS, WIRE LIST | 41606100 | B | 22 | 02.10 |
| EQUIPMENT DIAGRAMS | 36810900 | J | 34 | 03.00 |
| INPUT/OUTPUT SPECIFICATIONS | 36810500 | A | 22 | 01.70 |
| PROGRAMMING REFERENCE MANUAL | 36810700 | A | | 02.25 |
| MAINTENANCE, INSTALL, TIMING CHARTS, C/P, EO FILFS, PARTS LIST | 36810800 | F | 22 | 02.85 |
| REFERENCE MANUAL | 36810600 | E | 22 | 03.25 |
| SYSTEM MAINT. MONITOR CE MANUAL VOLS 1-3 | 60288100 | F | 22 | 65.00 |
| SMM92 INSTANT ERROR CODES | 60299700 | A | | 01.80 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------|----|----|-------|
| REFERENCE MANUAL (CARD READER CONTROLLER (C813-R813) | 36827800 | A | 22 | 01.60 |
| CE MANUAL (CARD READER CONTROLLER-C813) | 36827900 | D | 22 | 01.40 |
| 8092-B TELEPROGRAMMER - A BASIC LIBRARY SYSTEM | 36823500 | | | 01.00 |
| 8093 TAPE SYNCHRONIZER REFERENCE MANUAL | 36811600 | | | 01.80 |
| 8094 PERIPHERAL EQUIPMENT ADAPTER REFERENCE MANUAL | 36811300 | A | 22 | 01.40 |
| 8095 CONTROL PANEL CE MANUAL | 36811500 | B | 22 | 01.55 |
| 8097 DIGITAL COMMUNICATIONS TERMINAL REFERENCE MANUAL | 36813300 | | | 01.25 |
| 8097/8297 DATA SET CONTROLLER USERS MANUAL | 36819100 | | | 01.30 |
| 8130 CARD READER/LINE PRINTER TERMINAL PROGRAM LISTINGS COMMAND TEST | 60233500 | 01 | 22 | 07.85 |
| 8130 REMOTE TERMINAL REFERENCE MANUAL | 36828000 | B | | 01.80 |
| USERS MANUAL | 36829900 | B | | 01.55 |
| TEST ROUTINE MANUAL | 13796900 | A | | 01.00 |
| 8136 COMMUNICATIONS TERM CONTROLLER CE MANUAL | 13795100 | B | 22 | 01.75 |
| REFERENCE MANUAL | 13795300 | A | 22 | 01.00 |
| 8137 COMMUNICATIONS EXPANSION UNIT REF/CE MAN. | 41607400 | A | 22 | 01.00 |
| 8156 LINE PRINTER PRINTER EQUIPMENT CE MANUAL (USE CL308-A/B) | | | | |
| PRINTER PARTS DATA CE MANUAL | 44896400 | A | 22 | 02.00 |
| CONTROLLER EQUIP. REF/CE MAN SERIES A06 HDWE | 47966500 | E | 22 | 05.25 |
| CONTROLLER EQUIP. REF/CE MAN SERIES A10 HDWE | 47966600 | A | 22 | 03.25 |
| 8170-A/B MAG TAPE CONTROLLER REF/CE MANUAL | 60208600 | D | 22 | 13.80 |
| 8193 MAG TAPE CONTROLLER REFERENCE/CE MANUAL | 36823700 | D | 22 | 03.00 |
| 8194 MAG TAPE SYNCHRONIZER REFERENCE MANUAL | 13796000 | C | 22 | 01.45 |
| 8197 DATA SET CONTROLLER CE MANUAL | 36828200 | G | 22 | 14.25 |
| REFERENCE MANUAL | 36828300 | | | 02.00 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------|---|----|-------|
| 8271-A/B/D TRANSFER SWITCHES AND FT103/FT104 TRANSFER SWITCH CONTROLLERS REF./CE MANUAL | 36822700 | G | 22 | 14.45 |
| 8271-E CHANNEL TRANSFER SWITCH/INDICATOR REF/CE INFO (USE 3270-A/B) | | | | |
| 8404 CONSOLE | | | | |
| (THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES.ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.) PRICE AVAILABLE UPON REQUEST REFERENCE MANUAL | 36816900 | | | |
| 8490 COMPUTER SYSTEM REFERENCE MANUAL | 14091600 | B | 22 | 04.10 |
| DIAGRAMS AND THEORY OF OPERATION | 14091700 | C | 22 | 14.30 |
| SITE PREPARATION AND INSTALLATION MANUAL | 14091800 | A | 22 | 01.90 |
| ADSAS AND FORTRAN OPERATION REFERENCE MANUAL | 14091900 | A | 22 | 02.25 |
| MAINTENANCE AND COMMAND TIMING MANUAL | 14092000 | B | 22 | 08.75 |
| INSTRUCTION CARDS | 14093500 | | | 00.75 |
| SYSTEM MAINTENANCE MONITOR (SMM) REFERENCE/ PROGRAM LISTINGS MANUAL | 14094700 | A | 22 | 11.75 |
| 8508B/8515B INPUT UNIT, 8509B/8519B OUTPUT UNIT REFERENCE/CE MANUAL | 36826700 | A | 22 | 02.85 |
| 8518-C,8519-D CE MANUAL, INSTALL AND CHECKOUT, THEO OF OPEP, DIAG, MAINT AIDS, PARTS DATA W/ | 36826600 | B | 22 | 01.50 |
| 8527 DCU/8065 DCT/8096 INPUT/OUTPUT UNIT REFERENCE MANUAL (8527-A) | 36812700 | A | 22 | 02.95 |
| REFERENCE MANUAL (8527-B) | 36823400 | B | 22 | 03.00 |
| 8528 DIGITAL COMMUNICATIONS TERMINAL CE MANUAL | 36825600 | A | 22 | 04.10 |
| DIAGRAMS MANUAL | 36814200 | 4 | 34 | 02.25 |
| MAINTENANCE AIDS MANUAL | 36817300 | 7 | 22 | 08.00 |
| REFERENCE MANUAL | 36814100 | A | 22 | 01.75 |
| 8528-G DIGITAL COMMUNICATIONS TERMINAL CE DIAGRAMS | 36814500 | 7 | 34 | 02.25 |
| MAINTENANCE MANUAL (USE 8528) | | | | |
| REFERENCE MANUAL | 36814400 | A | 22 | 02.85 |
| 8529-B/C DATA SET CONTROLLER, W/L, EQ. SUMMARY | 41603500 | B | 22 | 01.70 |
| REFERENCE MANUAL | 36813100 | | | 01.25 |
| 8529 DIGITAL COMMUNICATIONS TERMINAL DIAGRAM VOLUME | 36813700 | | 34 | 01.50 |
| CUSTOMER ENGINEERING MANUAL | 36812500 | | 22 | 02.00 |
| 8529-B/C DATA SET CONTROLLER REFERENCE MAN | 13791100 | A | 22 | 01.00 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------|----|----|-------|
| CE MANUAL VOL. I OF II | 13791200 | C | 22 | 02.40 |
| CE MANUAL | | | | |
| 8536-C/D, 8537-C/D INPUT/OUTPUT UNITS CE MANUAL | 13797000 | E | 22 | 07.35 |
| 8601 POWER SUPPLY REFERENCE MANUAL | 36814800 | | | 01.25 |
| 8606 POWER SUPPLY REFERENCE MANUAL | 36815000 | | | 01.30 |
| 8615 DUAL POWER SUPPLY REFERENCE MANUAL | 36814700 | | | 01.00 |
| 8909-C TEST BOARD UNIT REFERENCE MANUAL | 36816000 | A | 22 | 02.00 |
| 8909-G TEST BOARD DRAWER REF/CE MANUAL | 36828900 | A | 22 | 01.50 |
| 8909-H TEST BOARD UNIT REFERENCE MANUAL | 13797300 | B | 22 | 02.30 |
| CE MAN VOL I OF II THEO OF OPER, DIAG, MAINT, MAINT AIDS, PARTS DATA | 13799700 | C | 22 | 01.20 |
| CE MANUAL VOL. II OF II WIRE LISTS | 41600100 | D | 22 | 07.55 |
| 8987 R/O NIP STATION OPERATORS GUIDE | 62079500 | 02 | 22 | 01.00 |
| 9008-1 DUAL ACCESS DISK DRIVE CONTROLLER REFERENCE/CE MANUAL | 60290900 | B | 22 | 09.45 |
| 9081 PLUG COMPATIBLE CONTROLLER--LISTED AS FA7A4, FV1A1 | | | | |
| 9082 (23142) | | | | |
| 9100 MAGNETIC TAPE TRANSPORT MAINT. MANUAL ILLUSTRATED PARTS LIST | 40814900 | | 22 | 04.00 |
| | 40803900 | | 22 | 09.00 |
| 9103 MAGNETIC TAPE TRANSPORT DIAGRAMS AND WIRE LIST, MOD A | 40811700 | | | 02.85 |
| REFERENCE MANUAL, MOD A | 40802100 | C | 22 | 04.60 |
| CE MANUAL - PARTS LIST MOD A | 40805300 | A | 22 | 03.60 |
| 9110 MAG TAPE TRANSPORT DIAGRAM/WIRE LIST MOD B AND C | 40824600 | 2 | 22 | 06.80 |
| REFERENCE MANUAL, MOD B AND C | 40806700 | | 22 | 06.00 |
| 9112 MAGNETIC TAPE TRANSPORT MAINT. MANUAL | 40822300 | B | 22 | 10.00 |
| 9113 MAGNETIC TAPE TRANSPORT DIAGRAMS AND WIRE LIST | 40818800 | 2 | 22 | 03.00 |
| 9114 MAGNETIC TAPE TRANSPORT MAINTENANCE CE MANUAL PARTS LIST | 40817000 | | 22 | 04.00 |
| | 40826600 | | 22 | 01.80 |
| 9115 MAGNETIC TAPE TRANSPORT DIAGS, W/L MOD A | 40822100 | A | 22 | 09.30 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|----|----|-------|
| MAINTENANCE MANUAL | 40819700 | | 22 | 03.50 |
| PARTS LIST | 40829900 | | | 05.70 |
| 9119 MAGNETIC TAPE TRANSPORT MAINTENANCE | 40823800 | 2 | 22 | 04.00 |
| DIAGRAMS AND WIRE LIST | 40823600 | 8 | 22 | 05.00 |
| PARTS LIST, MOD A | 40823700 | B | | 03.95 |
| 9120 MAGNETIC TAPE TRANSPORT MAINTENANCE | 40820400 | | 22 | 04.00 |
| DIAGRAMS AND WIRE LIST | 40815700 | 2 | 22 | 03.20 |
| PARTS LIST | 40868200 | A | 22 | 06.60 |
| 9125 MAGNETIC TAPE TRANSPORT | 40818900 | | 22 | 04.00 |
| DIAGRAMS AND WIRE LIST MOD A | 40821800 | 3 | 22 | 07.05 |
| 9125/9135 MAGNETIC TAPE TRANSPORT PARTS LIST | 40860100 | A | 22 | 10.35 |
| 9130 MAGNETIC TAPE TRANSPORT DIAGRAMS AND | 40825400 | 2 | 22 | 05.80 |
| WIRE LIST MOD A05 AND UP, B01 AND UP | 40806800 | | 3 | 08.00 |
| REFERENCE MANUAL, MOD A AND B | | | | |
| 9131 MAGNETIC TAPE TRANSPORT DIAGRAMS MOD A/B | 40808500 | | 3 | 03.50 |
| REFERENCE MANUAL, MOD A AND B | 40805200 | A | 3 | 06.00 |
| ILLUSTRATED PARTS LIST, MOD A AND B | 40807100 | | 3 | 03.50 |
| WIRE LIST MOD A AND B | 40808400 | | 3 | 03.50 |
| 9135 MAGNETIC TAPE TRANSPORT MAINTENANCE | 40819800 | B | 22 | 13.10 |
| DIAGRAMS AND WIRE LIST | 40821700 | 4 | 22 | 04.00 |
| 9155 MAGNETIC TAPE TRANSPORT CE MAINT MANUAL | 40862300 | A | 22 | 04.30 |
| 9160A/B MAGNETIC TAPE TRANSPORT MAINTENANCE | 40813300 | 2 | 22 | 04.00 |
| 9165 MAGNETIC TAPE TRANSPORT | 40865000 | 02 | 22 | 01.60 |
| MAINTENANCE MANUAL MOD A | | | | |
| 9165/9175 TAPE TRANSPORT PARTS LIST | 40863600 | A | 22 | 05.60 |
| 9170 MAGNETIC TAPE TRANSPORT MAINTENANCE | 40818700 | A | 22 | 04.60 |
| 9175 MAG TAPE TRANSPORT MOD A AND B MAINT MAN. | 40865100 | 2 | 22 | 02.10 |
| 9180 MAGNETIC TAPE TRANSPORT PARTS LIST MOD A | 40868100 | B | 22 | 05.55 |
| CE MAINTENANCE MANUAL MODS A AND B | 40864600 | B | 22 | 13.00 |
| DIAGRAMS, CIRC. DESC., WIRE LIST | 41240800 | A | | 04.60 |
| 9190-B MAG TAPE TRANSPORT DIAGRAM/WIRE LIST | 40826200 | A | 22 | 05.40 |
| 9200 (CE1A5) CARD READER | | | | |
| 9202 CARD READER | | | | |
| GENERAL DESC., OPERATION, INSTALLATION, | 49596700 | B | 22 | 03.00 |
| CHECKOUT, MAINTENANCE CE MANUAL | | | | |
| THEORY OF OPERATION, DIAGRAMS, WIRE LIST | 49596800 | B | 22 | 05.80 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------|-----|----|-------|
| CE MANUAL PARTS LIST CE MANUAL | 49596900 | B | 22 | 09.35 |
| 9236/9244/9286 AIRLINES TERMINAL DISPLAY/ KEYBOARD | | | | |
| HARDWARE PROGRAMMING MANUAL | 62068100 | | 22 | 02.05 |
| RECEIVE ONLY- NON IMPACT OPERATORS GUIDE | 62073800 | | 22 | 01.00 |
| OPERATORS GUIDE | 62067900 | | 22 | 01.00 |
| ON SITE MAINT MANUAL | 62068300 | | 22 | 02.30 |
| 9251 CARD PUNCH SERVICE MANUAL | 40808100 | 7 | | 05.00 |
| 9280-A/B (CF507-A/B) CARD READER/PUNCH SURSYSTEM | | | | |
| 9300 TICKET PRINTER GEN DESC, MAINT, PARTS DATA, WIRE LISTS HARDWARE REF/CE MANUAL | 50577600 | A | 22 | 11.10 |
| 9301 LINE PRINTER CONTROLLER PARTS DATA, DIAGS, W/L, GEN DESC, INSTAL/ CHECKOUT.REF/CE MANUAL | 50577900 | A | 22 | 15.75 |
| 9301 LINE PRINTER EQUIPMENT DIAGRAMS MANUAL | 50577800 | A | | 29.00 |
| 9320 LINE PRINTER PRINCIPLES OF OPERATION REFERENCE MANUAL | 50584400 | A | 22 | 01.25 |
| PARTS IDENTIFICATION MANUAL | 50584600 | A | 22 | 02.15 |
| MAINTENANCE, DIAGRAMS, WIRE LIST CE MANUAL | 50584500 | A | 22 | 04.30 |
| 9322 LINE PRINTER MAINTENANCE, DIAGRAMS AND WIRE LIST FIELD SERVICE MANUAL | 50583700 | C | 22 | 03.70 |
| PARTS LIST PARTS IDENTIFICATION MANUAL | 50583800 | C | 22 | 01.70 |
| PRINCIPLES OF OPERATIONS REFERENCE MANUAL | 50583600 | D | 22 | 01.80 |
| LOGIC SCHEMATICS, CIRCUIT BOARDS, TIMING/ WIRING DIAGRAMS FIELD SERVICE MAN. VOL II | 91859200 | B | 34 | 09.15 |
| 50982602/03 EQUIPMENT TYPE CL484C/CL484D INTRODUCTION, OPERATING INSTRUCTIONS PRINCIPLES OF OPERATION CE MANUAL | | | | |
| INTRODUCTION, ASSEMBLY PARTS LISTS, PARTS IDENTIFICATION CE MANUAL | 59579300 | A | 22 | 02.35 |
| 50982602/03 EQUIPMENT TYPE CL484C/D INSTALL- ATION AND CHECKOUT, MAINT, W/L, DIAGRAMS FSM | 59579200 | 01 | 22 | 15.30 |
| 59690800/01 EQUIPMENT TYPE CL408-A/B INSTALL. AND CHECKOUT, MAINTENANCE, GLOSSARY FIELD SERVICE MANUAL | 91858400 | A | 22 | 02.35 |
| INTRODUCTION, OPERATING INSTRUCTIONS, PRINCIPLES OF OPERATION MANUAL | 59709100 | A | 22 | 04.20 |
| INTRODUCTION, PARTS LIST, USED-ON INDEX CE | 91859100 | A | 22 | 03.20 |
| INTERCONNECTION DIAGS, PRINT HEAD LOGIC DIAG CONTROLLER LOGIC DIAGS, TIMING DIAGS, FSM II | 91858500 | A01 | 34 | 10.40 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------------------|----------|----------|----------------|
| 9340 LINE PRINTER EQUIPMENT PARTS DATA CE MAN. SPECIAL OPTION 68091 INTRO. OPER. PROG. INST. CHKOUT., PRINCIPLES OF OPER, MAINT. DIAGS, W/L, EQ SUM. PARTS DATA CE MANUAL PRINTER EQUIPMENT CE MAN. (USE CL308-A/B) | 44895900 44977000 | A C | 22 22 | 02.00 02.90 |
| 9341 LINE PRINTER W/SPECIAL OPTION 68090 PART 1 CONTROLLER., PART 2 LINE PRINTER EQUIP., PART 3 LINE PRINTER PARTS DATA CE MANUAL | 44975600 | B | 22 | 15.70 |
| 9342 LINE PRINTER EQUIPMENT (CL8P2-A THRU CL8P2-S) INSTALLATION, CHECKOUT, DIAGS, W/L, PARTS DATA, MAINTENANCE CE MANUAL | 50579600 | A01 | 22 | 06.95 |
| 9346E LINE PRINTER PRINT HEAD HDWR REF/CE MAN | 44982700 | B | 22 | 03.70 |
| 9346-F LINE PRINTER HEAD MECHANISM (CL8R5-A/D) OPERATIONS, DIAGRAMS, WIRE LIST, MAINTENANCE, PARTS DATA CE MANUAL | 50582500 | B01 | 22 | 03.85 |
| OPERATIONS, DIAGRAMS, WIRE LIST, MAINTENANCE PARTS DATA CE MANUAL | 50579100 | C | 22 | 05.00 |
| 9350 SERIES LINE PRINTER EQ CE MANUAL PARTS DATA | 44977600 44981600 | A A | 22 22 | 03.40 02.00 |
| 9350 LINE PRINTER EQUIP. MODIFIED FOR MSBT GEN DESC, DIAGS, W/L, MAINT. CE MANUAL PARTS DATA CE MANUAL | 44983100 44983200 | 01 01 | | 06.90 02.85 |
| 9352 LINE PRINTER CONTROLLER EQUIPMENT W/SPEC. OPTIONS CE MANUAL | 44977700 | A | 22 | 05.15 |
| INSTALLATION/CHECKOUT DIAGRAMS, WIRE LIST, PARTS DATA CE MANUAL | 50581300 | C | 22 | 08.35 |
| INSTALLATION/CHECKOUT, MAINT., PARTS DATA W/L, CE MANUAL | 50581000 | B02 | 22 | 08.40 |
| INSTALLATION AND CHECKOUT, DIAGRAMS AND WIRE LISTS, PARTS DATA CE MANUAL | 50581400 | D | 22 | 05.80 |
| DIAGRAMS, WIRE LIST, PARTS DATA CE MANUAL EQUIPMENT MANUAL | 50584800 59579400 | C C | 22 22 | 06.00 03.70 |
| LOGIC SCHEMATICS, CIRCUIT BOARDS, WIRING PRINT HEAD MECHANISM - 96 CHARACTER | 59707800 59579500 | A A | 34 22 | 03.50 03.40 |
| DIAGRAMS, TIMING DIAGRAMS, FIELD SERVICE MANUAL VOLUME II | | | | |
| FOR TOP LEVEL ASSEMBLY 50709515/16 EQUIPMENT TYPE CL4A9-E/CL4A9-F INSTALLATION AND CKOUT OPER., PRIN. OF OPER., POWER SUPPLY, DIAGS, MAINT, W/L, PARTS DATA HARDWARE REF/CE MAN | 59708000 | A | 22 | 09.15 |
| 9355 LINE PRINTER PRINT MECHANISM HARDWARE REF/CE MANUAL | 50580500 | | | 04.50 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|-----|----|-------|
| OPERATIONS, MAINT, DIAGRAMS, PARTS DATA CE | 50581900 | 001 | 22 | 06.25 |
| OPERATIONS, MAINTENANCE, DIAGRAMS, PARTS | 50584700 | A | 22 | 07.90 |
| DATA CE MANUAL | | | | |
| 9360 LINE PRINTER EQUIPMENT PARTS DATA | 50578500 | A | 22 | 05.00 |
| 9361 LINE PRINTER EQUIPMENT PARTS IDENTIFICA- | 59577900 | A | 22 | 04.80 |
| TION MANUAL | | | | |
| GEN DESC., MAINT/MAINT AIDS REFERENCE MANUAL | 59578000 | A | 22 | 04.80 |
| DIAGRAMS AND WIRE LIST FIELD SERVICE MANUAL | 59578100 | A | 22 | 03.90 |
| 9362 PARTS IDENTIFICATION MANUAL | 59578900 | AD4 | 22 | 07.15 |
| FIELD SERVICE MANUAL | 59578800 | A | 22 | 24.30 |
| GII- JT14A TEST BOX OPERATION MANUAL | 76630900 | | 22 | 02.50 |
| 9410-A, 9420-B DUAL DISK STOR DRU. MODS A01-A05 | 40866500 | G | 22 | 03.00 |
| B04-B05 PARTS LIST | | | | |
| GEN DESC, OPER, INSTAL AND CHECKOUT, MAINT MAN | 40864400 | D | 22 | 05.65 |
| THEORY OF OPER, DIAGS, MAINT. AIDS, AND W/L | 40866400 | E | 22 | 05.65 |
| 9421 DUAL DISK DRIVE--LISTED AS BK3A1 | | | | |
| 9431 DISK STORAGE DRIVE DIAG. AND W/L MAN A12B12 | 41247500 | E | 22 | 02.85 |
| MAINTENANCE MANUAL MODS A12, B12 AND ABOVE | 41245900 | C | 22 | 07.30 |
| PARTS LIST MODS A12, B12 AND ABOVE | 41244300 | E | 22 | 01.65 |
| 9432 DISK STORAGE DRIVE | | | | |
| DIAGS AND WIRE LIST MANUAL MODS C, D, G, J, K | 40827300 | J | 22 | 01.50 |
| DIAGS, CIRC DESC, C/P AND WIRE LIST | 41247600 | E | 22 | 02.55 |
| MAINTENANCE MANUAL MODS A, B, C, D, G, H | 40816900 | E | 22 | 06.10 |
| MAINTENANCE MANUAL MODS C12-K12 AND ABOVE | 41246000 | C | 22 | 06.85 |
| PARTS LIST MODS C12 AND ABOVE, D12 AND ABOVE | 41244400 | D | 22 | 02.40 |
| F12 AND ABOVE, G12 AND ABOVE, J12 AND ABOVE | | | | |
| K12 AND ABOVE | | | | |
| PARTS MANUAL MODS C, D, F, G, J, K | 40826500 | C | 22 | 02.10 |
| 9433-A/B/J/K DIAGRAMS AND WIRE LIST MANUAL | 40863100 | H | 22 | 05.80 |
| DIAGRAMS AND WIRE LIST MANUALS MOD A12, B12 | 41247700 | E | 22 | 02.00 |
| J12, K12 | | | | |
| PARTS LIST MANUAL MOD A, B, J, K | 40826800 | D | 22 | 03.20 |
| CE MAINTENANCE MANUAL MODS A THRU G | 40826900 | F | 22 | 04.10 |
| MAINTENANCE MODS RH1A7-A AND B | 41241600 | B | 22 | 08.85 |
| 9460 DISK STORAGE DRIVE | | | | |
| PARTS LIST | 40828700 | B | 22 | 01.30 |
| 9461 DISK STORAGE DRIVE | | | | |
| DIAGRAMS AND WIRE LIST MOD A05/B05 ABOVE | 40828900 | N | 22 | 05.40 |
| PARTS LIST MODS A05-A11/B05-B11 | 40829000 | C | 22 | 06.55 |
| MAINTENANCE MANUAL MODS A-B | 40829100 | F | 22 | 05.55 |
| MAINTENANCE MANUAL MODS A12, B12 AND ABOVE | 41246800 | C | 22 | 04.05 |
| PARTS LIST MODS A12, B12 AND ABOVE | 41245200 | F | 22 | 02.00 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.

4-Publication division responsible for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------|---|----|-------|
| DIAGS AND W/L MODS A12,B12 ABOVE, R35 ABOVE | 41248400 | L | 22 | 01.55 |
| CE MAINTENANCE MANUAL MODS A,B,J,K | 41246100 | C | 22 | 06.00 |
| MAINTENANCE MAN MODS F12,G12,L12,M12,S12, T12 AND ABOVE | 41246200 | B | 22 | 02.00 |
| PARTS LIST MODS A12 ABOVE, R12 ABOVE, J12 ABOVE, K12 ABOVE | 41244500 | D | 22 | 02.00 |
| 9433 DISK STORAGE DRIVE--ALSO LISTED AS BJ1A9 | | | | |
| DIAG AND W/L MODS F/G/S/T 12 AND ABOVE | 41247800 | E | 22 | 02.75 |
| DIAG AND W/L MODS L/M 12 AND ABOVE | 70604200 | D | 22 | 02.20 |
| PARTS LIST MODS F/G/S/T 11 AND BELOW | 40865500 | D | 22 | 01.70 |
| PARTS LIST MODS F/G/L/M/S/T 12 AND ABOVE | 41244600 | D | 22 | 01.80 |
| 9434-A/B DISK STORAGE DRIVE PARTS LIST MOD A,B | 40827000 | B | 22 | 06.50 |
| PARTS LIST MODS A12-R12 AND ABOVE | 41244700 | D | 22 | 02.00 |
| 9441 DISK STORAGE DRIVE | | | | |
| DIAGS,CIRC DESC,C/P AND W/L MODS B0 AND ABOVE | 40828200 | G | 22 | 02.55 |
| DIAGRAMS AND WIRE LIST OF MANUAL | 70607700 | B | 22 | 02.00 |
| 9451 DISK STORAGE DRIVE--ALSO LISTED AS BJ1A7 | | | | |
| PART DATA MANUAL | 70612200 | A | 22 | 01.65 |
| 9462-A/B DISK STORAGE DRIVE | | | | |
| MAINTENANCE MANUAL MODS A12,B12 AND ABOVE | 41246900 | C | 22 | 04.65 |
| 9463 DISK STORAGE DRIVE | | | | |
| DIAGS,CIRC DESC, C/P AND W/L MODS A10 AND ABOVE, B10 ABOVE | 40867100 | C | 22 | 05.00 |
| 9464 DISK STORAGE DRIVE | | | | |
| DIAGRAMS, CIRC DESC, C/P,W/L MODS K09/ABOVE | 40867600 | B | 22 | 06.00 |
| MAINTENANCE MANUAL MODS K09-K11 | 40868400 | D | 22 | 08.70 |
| MAINTENANCE MANUAL MOD A12 AND ABOVE | 41247100 | C | 22 | 07.45 |
| PARTS LIST MOD K | 40868500 | C | 22 | 07.30 |
| PARTS LIST MODS K12 AND ABOVE | 41245500 | D | 22 | 02.00 |
| 9465 DISK STORAGE DRIVE--ALSO LISTED AS BJ3A3 | | | | |
| PARTS LIST MOD P-12 AND ABOVE | 40860200 | D | 22 | 02.05 |
| MAINTENANCE MANUAL MOD P | 41240300 | B | 22 | 09.00 |
| MAINTENANCE MANUAL MOD P12 AND ABOVE | 41247200 | C | 22 | 08.10 |
| DIAGRAMS AND WIRE LIST MODS D09 AND ABOVE | 41240400 | C | 22 | 06.05 |
| PARTS LIST MODS P09-P11 | 41240500 | C | 22 | 04.00 |
| DIAGS,CARD PLACEMENT,W/L MODS P12 AND ABOVE | 41248800 | E | 22 | 02.20 |
| 9468 DISK STORAGE DRIVE--LISTED AS BJ3A1 | | | | |
| 9469 DISK STORAGE DRIVE--LISTED AS BJ2A2 | | | | |
| 9480-1 MULTIPLE DISK DRIVE--LISTED AS BM1A3, BM1A7, BM1B3 | | | | |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|---|----|-------|
| 9480-2 MULTIPLE DISK DRIVE--LISTED AS BM1A1, BM1A5, BM1B1 | | | | |
| 9481-1 MULTIPLE DISK DRIVE--LISTED AS BM1A4, BM1A6, BM1B4 | | | | |
| 9481-2 MULTIPLE DISK DRIVE--LISTED AS BM1A2, BM1B2 | | | | |
| 9482 MULTIPLE DISK DRIVE--LISTED AS BM2A1, BM2A2, BM3A2 | | | | |
| 9482-1 MULTIPLE DISK DRIVE--LISTED AS BM2A7 | | | | |
| 9482-2 MULTIPLE DISK DRIVE--LISTED AS BM2A8, BM2B1, BM2B2 | | | | |
| 9486 DISK STORAGE UNIT--LISTED AS BP2A3, BP3A8 | | | | |
| 9492/9493 DISK FILE SYSTEM MAINTENANCE MANUAL PARTS LIST MODS A | 40829300 | E | 22 | 06.70 |
| | 40867800 | A | 22 | 10.40 |
| 9496/9497 DISK FILE GENERAL DESCRIPTION, OPER, INSTALL, CHECKOUT, MAINT, CE MANUAL | 40865800 | C | 22 | 03.45 |
| 9519 (RE4C4) MAGNETIC TAPE TRANSPORT | | | | |
| 9520 (BE4B5) MAGNETIC TAPE TRANSPORT | | | | |
| 9525 (RE4R2) MAGNETIC TAPE TRANSPORT | | | | |
| 9525-13 (RE4B9) MAGNETIC TAPE TRANSPORT | | | | |
| 9525-14 (RE1A3) MAGNETIC TAPE TRANSPORT | | | | |
| 9540 (RE4B3) MAGNETIC TAPE TRANSPORT | | | | |
| 9545 (RE4B1) MAGNETIC TAPE TRANSPORT | | | | |
| 9545-13 (RE4C1) MAGNETIC TAPE TRANSPORT | | | | |
| 9545-14 (RE1A2) MAGNETIC TAPE TRANSPORT | | | | |
| 9560 (RE4A1) MAGNETIC TAPE TRANSPORT | | | | |
| 9565 (RE4A2) MAGNETIC TAPE TRANSPORT | | | | |
| 9565-13 (RE4C2) MAGNETIC TAPE TRANSPORT | | | | |
| 9565-14 (RE2A3) MAGNETIC TAPE TRANSPORT | | | | |
| 9566 (RE4R7) MAGNETIC TAPE TRANSPORT | | | | |
| 9568 (RE2A1) MAGNETIC TAPE TRANSPORT | | | | |
| 9580 (BE4B4) MAGNETIC TAPE TRANSPORT | | | | |
| 9585 (RE4A9) MAGNETIC TAPE TRANSPORT | | | | |
| 9585-11 (BE4B8) MAGNETIC TAPE TRANSPORT | | | | |
| 9585-13 (BE4C7) MAGNETIC TAPE TRANSPORT | | | | |
| 9585-14 (RE2A2) MAGNETIC TAPE TRANSPORT | | | | |
| 9720 DISK FILE--LISTED AS BH1A9 AND BH2A1 | | | | |
| 9736 DISK STORAGE UNIT--LISTED AS BR1A1/7/9 | | | | |
| 9737 DISK STORAGE UNIT--LISTED AS BR1A8 | | | | |
| 9738 DISK STORAGE UNIT--LISTED AS BR1A3 | | | | |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|-----|----|-------|
| 9739 DISK STORAGE UNIT--LISTED AS BR1A4 | | | | |
| 9740 DISK STORAGE UNIT--LISTED AS BR1A5, BR2A1 | | | | |
| 9741 DISK STORAGE UNIT--LISTED AS BR2A2 | | | | |
| 9910 PERIPHERAL EXERCISER GEN DESC, DIAG, MAINT. CE MANUAL | 70606600 | B | 22 | 03.70 |
| 23022/23030/23040/23050 MEMORY SYSTEM SITE PLANNING KIT | 83096400 | B | | 01.00 |
| 23044 MEMORY SYSTEM SITE PLANNING KIT | 83096300 | | | |
| 23065/67 MODEL 1 MEMORY SYSTEM SITE PLANNING KIT | 83096200 | | | 01.20 |
| 14031 TRAIN PRINTER GEN. DESC., INSTALLATION AND CHECKOUT, OPERA- TION AND PROGRAMMING, PRINCIPLES OF OPERA- TION, MAINT/MAINT AIDS CE MANUAL VOL 1 | 59708200 | A01 | 22 | 09.10 |
| DIAGRAMS AND WIRE LISTS CE MANUAL VOL 2 | 59708300 | A01 | 22 | 07.05 |
| PARTS DATA CE MANUAL VOL 3 | 59708400 | A01 | 22 | 10.50 |
| 23141 (9081) MULTIPLE DISK SYSTEM REFERENCE MANUAL | 70613700 | A | 22 | 01.95 |
| 23142 (9082) MULTIPLE DISK SYSTEM REF MANUAL SYSTEM ANALYSTS GUIDE | 70621300 | A | 22 | 03.85 |
| | 70622000 | A | 22 | 01.30 |
| 28211 PRINTER SYSTEMS FORM DESIGN, RIBBON AND ACCESSORIES USERS MAN PRODUCT INFORMATION MANUAL | 97403500 | A | 22 | 01.00 |
| | 97404600 | A | 22 | 02.15 |
| 28211/14301 AND 28211-21 PRINTER SYSTEMS OPERATORS GUIDE | 22265500 | A | 3 | 03.90 |
| 28211-21 PRINTER SUBSYSTEM LOGIC DIAGRAMS | 22273100 | G | 34 | 02.60 |
| THEORY OF OPERATIONS | 22273000 | G | 3 | 13.75 |
| 33100 MEMORY SYSTEMS FOR THE IBM SYSTEM 370 SALES REFERENCE GUIDE | 15000300 | | 3 | 06.05 |
| 33135 MEMORY SYSTEM SITE PLANNING KIT | 75365100 | B | | 02.40 |
| LOGIC DIAGRAMS | 75387400 | B | 34 | 23.85 |
| THEORY OF OPERATION | 75387500 | | | |
| PRODUCT INFORMATION MANUAL | 75401000 | | | |
| 33145 MEMORY SYSTEM | | | | |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------|----|----|-------|
| SITE PLANNING KIT | 75365200 | B | | 01.00 |
| LOGIC DIAGRAMS | 75372900 | B | 34 | 27.00 |
| THEORY OF OPERATION | 75373000 | B | 3 | 09.85 |
| SERVICE MANUAL | 75369200 | | 3 | 12.90 |
| 33155-5XX MEMORY SYSTEM | | | | |
| SITE PLANNING KIT | 22264000 | B | | 01.15 |
| THEORY OF OPERATION | 75401400 | A | 3 | 15.75 |
| LOGIC DIAGRAMS | 75401500 | A | 34 | 19.00 |
| 33155-6XX MEMORY SYSTEM | | | | |
| SITE PLANNING KIT | 75369100 | B | | 03.35 |
| PRODUCT INFORMATION MANUAL | 22265400 | A | | 01.00 |
| MAINTENANCE MANUAL | 75369600 | A | 3 | 12.75 |
| 33158 -2XX/3XX/4XX MEMORY SYSTEM | | | | |
| SITE PLANNING KIT | 75385700 | A | | 02.00 |
| THEORY OF OPERATION | 75401700 | A | 3 | 15.75 |
| LOGIC DIAGRAMS | 75401800 | A | 34 | 19.00 |
| 33159 MEMORY SYSTEM | | | | |
| SITE PLANNING KIT | 22263900 | C | | 02.15 |
| PRODUCT INFORMATION MANUAL | 22264800 | A | | 01.00 |
| SERVICE MANUAL | 75369800 | | 3 | 15.75 |
| LOGIC DIAGRAMS | 75391300 | B | 34 | 25.75 |
| 33165-5XX MEMORY SYSTEM | | | | |
| THEORY OF OPERATION | 75402000 | A | 3 | 17.25 |
| LOGIC DIAGRAMS | 75402100 | A | 34 | 19.00 |
| SITE PLANNING KIT | 75368900 | | | |
| 33301 MULTIPLE DISK SYSTEM PRODUCT INFOR MAN | 70629800 | | 3 | 00.85 |
| REFERENCE MANUAL | 70629900 | D | 22 | 06.30 |
| GROUP III MICRODIAGNOSTICS DESCRIPTIONS | 70604100 | D | 22 | 06.50 |
| GROUP III MICRODIAGNOSTICS USERS MANUAL | 70612400 | C | 22 | 02.05 |
| TROUBLESHOOTING MANUAL | 70608200 | C | 22 | 03.50 |
| INSTALLATION CE MANUAL | 70608100 | G | 22 | 08.35 |
| 33301 DISK MEMORY SUBSYSTEM SITE PLANNING KIT | 83301400 | C | | 01.00 |
| 33301/33302 SUBSYSTEM | | | | |
| ON-LINE DIAGNOSTICS (COLDS MANUAL) | 70602900 | D | 22 | 16.35 |
| 33302 DISK MEMORY SUBSYSTEM | | | | |
| SITE PLANNING KIT | 70627400 | | 22 | 01.00 |
| REFERENCE MANUAL | 83301500 | B | 22 | 08.00 |
| INSTALLATION CE MANUAL | 83301600 | D | 22 | 03.75 |
| TROUBLESHOOTING MANUAL | 83301700 | 01 | 22 | 08.85 |
| 34201 MAGNETIC TAPE TRANSPORT | | | | |
| OPERATORS MANUAL | 49752300 | A | 3 | 01.10 |
| OPERATORS GUIDE | 22263500 | | 3 | 01.80 |
| MAINTENANCE | 22285600 | | 3 | 22.20 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover binder that may be used for manuals.
4-Publication division responsible for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|--|----------|---|----|-------|
| LOGIC DIAGRAMS SITE PLANNING KIT USE 38031 MAG TAPE SBSYSTEM PRODUCT MANUAL USE 38031 MAG TAPE SUBSYSTEM | 22285700 | | 34 | 06.80 |
| 38031 MAGNETIC TAPE CONTROLLER MAINTENANCE | 22285300 | | 3 | 01.35 |
| LOGIC DIAGRAMS | 22285400 | | 34 | 18.65 |
| TRANSLATOR LISTING | 22285500 | | | 10.70 |
| 38031 MAGNETIC TAPE SUBSYSTEM PRODUCT MANUAL | 22263800 | | 3 | 03.85 |
| SITE PLANNING KIT | 75369000 | | | 01.50 |
| 90100 SYSTEM CONTROLLER COMPUTER SYSTEM REFERENCE MANUAL | 60321400 | A | 22 | 01.40 |
| INPUT/OUTPUT SPECIFICATIONS MANUAL | 60321500 | A | 22 | 01.00 |
| 90104 (AB103-A, BB328-A, BB329-A) COMPUTATION MODULE REF INFO (USE 90100 REF MAN) CE INFO (USE AB103-A, CATALOG SEC. 1) | | | | |
| 90105-1 (DC118-A) DATA CHANNEL REF INFO (USE 90100 REF MAN) CE INFO (USE AB103-A, CATALOG SEC. 1) | | | | |
| 90106-1 (DC120-A) STORAGE CHANNEL REF INFO (USE 90100 REF MAN) CE INFO (USE AB103-A, CATALOG SEC. 1) | | | | |
| 90107-1 (GL112-A) CONSOLE REF INFO (USE 90100 REF MAN) CE INFO (USE AB103-A, CATALOG SEC. 1) | | | | |
| 90108-1 (BB329-A) MEMORY MODULE REF INFO (USE 90100 REF MAN) CE INFO (USE AB103-A, CATALOG SEC. 1) | | | | |
| 90108-2 (BB328-A) STORAGE INCREMENT REF INFO (USE 90100 REF MAN) CE INFO (USE AB103-A, CATALOG SEC. 1) | | | | |
| 90109-1 (DC119-A) CHARACTER HANDLER REF INFO (USE 90100 REF MAN) CE INFO (USE AB103-A, CATALOG SEC. 1) REF INFO (USE 90100 REF MAN) CE INFO (USE AB103-A, CATALOG SEC. 1) ** REFER ALSO TO VENDOR MANUALS SECTION FOR TELETYPE MANUALS (35KSP) | | | | |
| 90113-1 (CK502-A/B) TELETYPEWRITER ** REFER ALSO TO VENDOR MANUALS SECTION FOR TELETYPE MANUALS (35ASR) | | | | |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------|---|----|-------|
| 90114-1 (GH401-A) CABINET REF INFO (USE 90100 REF MAN) CE INFO (USE AB103-A, CATALOG SEC. 1) | | | | |
| 90115-1 (GD104-A, GD105-A, GD106-A) POWER SUPPLY REF INFO (USE 90100 REF MAN) CE INFO (USE AB103-A, CATALOG SEC. 1) | | | | |
| 90115-4 (GE210-A/B) AUXILIARY MOTOR GENERATOR CE INFO (USE 90100 SITE PREPARTION MANUAL - CATALOG SEC. 4) | | | | |
| 90120 PAPER TAPE STATION REFERENCE MANUAL | 60324000 | A | 22 | 01.15 |
| 90121-1 (CE305-A/B) PAPER TAPE READER REF INFO (USE 90120 REF MAN) CE INFO (USE CE305-A/B, CATALOG SEC. 1) ** REFER ALSO TO 370 PAPER TAPE READER MANUALS | | | | |
| 90122-1 (CE305-A/B, GJ102-A) PAPER TAPE READER WITH HANDLER REF INFO (USE 90120 REF MAN) CE INFO (USE CE305-A/B, CATALOG SEC. 1) ** REFER ALSO TO 370 PAPER TAPE READER MANUALS ** REFER ALSO TO VENDOR MANUALS SECTION FOR REMEX PAPER TAPE SPOOLER CE MANUAL | | | | |
| 90123-1 (CF104-A) PAPER TAPE PUNCH REF INFO (USE 90120 REF MAN) CE INFO (USE CE305-A/B, CATALOG SEC. 1) | | | | |
| 90123-2 (CF106-A) PAPER TAPE PUNCH - TUNGSTEN CARBIDE REF INFO (USE 90120 REF MAN) CE INFO (USE CE305-A/B, CATALOG SEC. 1) | | | | |
| 90124-1 (CF104-A, GJ103-A/B) PAPER TAPE PUNCH WITH HANDLER REF INFO (USE 90120 REF MAN) CE INFO (USE CE305-A/B, CATALOG SEC. 1) ** REFER ALSO TO VENDOR MANUALS SECTION FOR REMEX TAPE SPOOLER CE MANUAL | | | | |
| 90124-2 (CF106-A, GJ103-A/B) PAPER TAPE PUNCH -TUNGSTEN CARBIDE- WITH HANDLER REF INFO (USE 90120 REF MAN) CE INFO (USE CE305-A/B, CATALOG SEC. 1) ** REFER ALSO TO VENDOR MANUALS SECTION FOR | | | | |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.

4-Publication division responsi-
ble for contents of literature.

| TITLE | 1 | 2 | 3 | 4 |
|---|----------|----|----|-------|
| REMUX TAPE SPOOLER CE MANUAL | | | | |
| 90125-1 (CF5A5-A/B/C) PAPER TAPE STATION - COMMON CONTROL REF INFO (USE 90120 REF MAN) CE INFO (USE CE305-A/B, CATALOG SEC. 1) | | | | |
| 90126-1 (CF8A1-A) ENCLOSURE KIT FOR 90125-1 REF INFO (USE 90120 REF MAN) CE INFO (USE CE305-A/B, CATALOG SEC. 1) | | | | |
| 90127-1 (CW123-A) PAPER TAPE PUNCH VALIDATION FEATURE REF INFO (USE 90120 REF MAN) CE INFO (USE CE305-A/B, CATALOG SEC. 1) | | | | |
| 92411 CRT DISPLAY TERMINAL OPERATORS GUIDE | 62034200 | 01 | | 01.00 |
| HARDWARE PROGRAMMING MANUAL | 62061700 | 02 | 22 | 01.00 |
| 92412 PRINTER TERMINAL OPERATORS GUIDE | 62049500 | 00 | | 01.00 |
| HARDWARE PROGRAMMING MANUAL (PRELIMINARY) | 62074000 | | 22 | 01.20 |
| 92413 CONVERSATIONAL DISPLAY TERMINAL OPERATORS GUIDE | 62038000 | 00 | | 01.00 |
| HARDWARE PROGRAMMING MANUAL | 62033500 | 02 | 22 | 01.00 |
| 92417/92427 NON-IMPACT PRINTER STATION OPERATORS GUIDE | 62073300 | | | 01.00 |
| READ ONLY PRINTER PROGRAMMING MANUAL (92417) | 62088900 | 01 | 22 | 01.05 |
| READ ONLY PRINTER STATION HARDWARE PROGRAMMING MANUAL (92427) | 62122800 | 01 | 22 | 01.00 |
| ON-SITE MAINTENANCE MANUAL (92417) | 62089100 | 01 | 22 | 01.20 |
| ON-SITE MAINTENANCE MANUAL (92427) | 62122900 | 01 | 22 | 01.05 |
| 92424/92425 AIRLINES TERMINAL DISPLAY/KEYBOARD OPERATORS GUIDE | 62068000 | | | 01.00 |
| ON SITE MAINTENANCE MANUAL | 62068400 | | | 02.30 |
| HARDWARE PROGRAMMING MANUAL | 62068200 | | | 02.05 |
| 94100 () CORE MEMORY PRODUCT DESCRIPTION MANUAL | 60410100 | A | 22 | 01.00 |
| THEORY OF OPERATION MANUAL | 60410200 | | 22 | 02.50 |
| CE MANUAL | 60405400 | A | 22 | 08.95 |

1-Publication number of literature.
2-The latest revision level.

3-Indicates size of hard cover
binder that may be used for
manuals.
4-Publication division responsi-
ble for contents of literature.

SECTION 3

PLEASE NOTE:

A number of Software Manuals are listed in more than one location because of the fact that specific software products will run on various operating systems.

Manuals in this section

The format in this section uses a machine line heading with a listing of manuals for each operating system version and the appropriate product set members printed beneath the heading.

TABLE OF ABBREVIATIONS

All Titles for software manuals have been reviewed and standardized. The following table lists all abbreviations and their full wording.

| | |
|-------------|---|
| ADB | Applications Development Bulletin |
| BIN | Binary |
| BSIPP | Simultaneous Peripheral Processor |
| COMPAT | Compatible |
| COMPARATIVE | Used with FORTRAN, notes the similarities and differences among the FORTRAN for 3000 and 6000 machine lines and USASI |
| EXT | Extended |
| FTN | FORTRAN |
| FUNCT | Functions |
| GENERIC | Algol, applicable to all 3/6 machine line |
| HS | High Speed |
| IMB | Installation Handbook |
| LIB | Library |
| META | Procedure Oriented Source Language Assembler |
| MP | Memory Protect |
| MS | Mass Storage |
| MSIO | Logical Input/Output On Mass Storage |
| REF | Reference |
| OP | Operating System |
| REGINA 1 | Linear Programming Package |
| RESPOND | Multiaccess Subsystem For Remote And/Or Local Ter |
| SAINT | 1401 Simulator And Interpreter |
| SASY | 31/32 Satellite For Standard File Processing-3600 |
| SDPS | Seismic Data Processing System |
| SFP | Standard File Processor |
| SIPP | Simultaneous Peripheral Processor, Batch Execution |
| SMT | Summit |
| TSORT | Tape Sort |
| XLAT | Translator |

| TITLE | 1 | 2 | 3 | 4 | 5 |
|---|------------------|---|----|-------|-----|
| G-15 COMPUTER | | | | | |
| ALGOL/OPERATING MANUAL | 60063600 | | | 01.00 | 36 |
| ALGOL/PROGRAMMING MANUAL | 60060500 | | | 02.05 | 32 |
| ALGOL/TECHNICAL MANUAL | 60060600 | | | 04.50 | 224 |
| ALTRAN/REFERENCE MANUAL | 60060300 | | | 03.00 | 160 |
| AUTOCARD PROGRAMMING MANUAL | 60153500 | | | 03.65 | 68 |
| AUTOPOINT 24 PROGRAMMING MANUAL | PPT18100 | | | 03.05 | 24 |
| BIT OF MEANING (APG-12591-0761) | 60062100 | | 22 | 01.00 | 20 |
| CODING MANUAL | 60060400 | | | 01.00 | 26 |
| FIXED POINT SCALE (G-15) | 60062700 | | | 01.00 | 28 |
| INTERCARD PROGRAMMING MANUAL | 60153600 | A | | 03.30 | 86 |
| INTERCOM 500/PROGRAM MANUAL | 60060700 | | | 01.50 | 72 |
| INTERCOM 1000/PROGRAMMING MANUAL | 60062200 | | | 01.00 | 32 |
| INTERMAP/PROGRAMMING MANUAL | 60060100 | | | 03.00 | 156 |
| G-20 COMPUTER | | | | | |
| GENERAL INFORMATION MANUALS | | | | | |
| BINARY PATCH LOADER (CB-11) | PSB-AG06 | | | 01.00 | 10 |
| BOOTSTRAP CARD PRODUCER VIA CB-11 | PSB-AG05 | | | 01.00 | 4 |
| FILE OPERATIONS SYSTEMS (G-20) | PSB-AG01 | | | 01.00 | 20 |
| INTRODUCTION TO PERT | 60062000 | | | 01.00 | 12 |
| MAGNETIC TAPE MACPOS (G-20) | PSB-AG02 | | | 01.00 | 30 |
| PERT 2 FOR SNAP 11 VOL 1 (G-20) | PSB-AG09 | | | 01.00 | 15 |
| PERT 2 FOR SNAP 11 VOL 2 (G-20) | PSB-AG09 | | | 01.00 | 20 |
| PERT HANDBOOK | 60153800 | | | 01.50 | 76 |
| PIECES OF EIGHT, AN INTRO TO OCTAL SYSTEM | 60061600 | | | 02.00 | 44 |
| REVISIONS TO SPACE PROGRAMMING SYSTEM | PSB-AG04 | | | 01.00 | 16 |
| SATELLITE PACKAGE (CB-11) | PSB-AG07 | | | 01.00 | 48 |
| SPACE SYSTEM ARITHMETIC SUBROUTINES | PSB-AG03 | | | 01.00 | 7 |
| TAPE-TO-MT-10 TAPE TRANSLATOR (603) | PSB-AG12 | | | 01.00 | 56 |
| USE OF TAPES WITH THE SPACE SYSTEM | PSB-AG11 | | | 01.00 | 20 |
| FORTRAN/REFERENCE MANUAL | 60061200 | | | 02.00 | 108 |
| FORTRAN 11/REFERENCE MANUAL | 60054400 | | | 03.00 | 152 |
| FORTPAN-4 (SPD-03) (G-20) | 60084200 | | | 01.50 | 74 |
| LINNEAR PROGRAMMING REF MAN | 60054600 | | | 04.50 | 214 |
| PERIPHERAL EQUIP. MAC LANG | 60065100 | | | 05.35 | 106 |
| SBAP REFERENCE MANUAL | 60061900 | A | | 02.10 | 32 |
| SCIENTIFIC COMPUTING SYSTEM (G-20/G-20-A) | 60054200 | | | 01.00 | 44 |
| SIMULATOR REF MAN (G-20/650) | 60060800 | | | 01.50 | 78 |
| SIMULATOR TECHNICAL MAN (G-20/650) | BPT03621 | | | 02.75 | 50 |
| SNAP 11/REF MANUAL | 60061500 | | | 03.00 | 144 |
| SORT MERGE/GENERATOR/INFORMATION MANUAL | 60054000 | | | 01.50 | 72 |
| SPAR/REFERENCE MANUAL | 60054100 | | | 05.00 | 256 |
| PERT/REFERENCE MANUAL (G-20) | 60054500 | | | 01.50 | 80 |
| MP-60 COMPUTER SYSTEMS | | | | | |
| | REFERENCE MANUAL | | | | |
| | 14306500 | A | 22 | 04.45 | 152 |
| COMPASS | REF MANUAL | | | | |
| | 14061300 | B | 22 | 04.30 | 72 |

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched in manual for use with hard cover ringed binder.

4. Price per manual.
5. Manual page count.

| TITLE | | 1 | 2 | 3 | 4 | 5 |
|---------------|--|----------|---|----|-------|-----|
| | COSY REF MANUAL | 14062100 | A | 22 | 01.00 | 34 |
| | PRELIR REF MANUAL | 14062200 | A | 22 | 01.00 | 44 |
| 160-B | FORMERLY 160 | | | | | |
| | FORTRAN GIM | 60050500 | B | | 01.00 | 28 |
| | REFERENCE MANUAL | 60050300 | | | 02.00 | 104 |
| | OP PROCEDURE FTN-A | 60082500 | | | 01.00 | 8 |
| | OSAS/ASSEMBLY REFERENCE MANUAL | 60050100 | | | 01.50 | 72 |
| 160-A | | | | | | |
| | AUTOCOMM REF MANUAL | 60051900 | A | | 01.50 | 70 |
| | FORTRAN REF MANUAL | 60051300 | B | | 02.50 | 120 |
| | INTERFOR REF MANUAL | 60051200 | | | 02.50 | 114 |
| | OSAS-A ASSEMBLY REF MANUAL (SYSTEM) | 60050700 | C | | 01.00 | 52 |
| | PERIPHERAL PROC REF MANUAL | 60051700 | | | 01.00 | 36 |
| | RT DECODER INST REF MANUAL | 60025100 | A | | 01.00 | 42 |
| | SASY OPERATORS GUIDE | 60171100 | | | 01.00 | 48 |
| | SICOM REF MANUAL | 60051500 | A | | 02.50 | 132 |
| MISCELLANEOUS | | | | | | |
| | SYSTEMS PROGRAMS FOR THE 160 COMPUTER | 60008400 | | 22 | 08.80 | 304 |
| | CHARACTERISTICS OF 160-A | 60019100 | C | | 01.00 | 20 |
| 270 | DIGIGRAPHICS SYSTEM | | | | | |
| | DIGIGRAPHIC SYSTEM 270 FUNCTION CONTROL | 60146400 | | | 01.00 | 56 |
| | PROGRAM SPECIFICATIONS | | | | | |
| | DIGIGRAPHIC SYSTEM 270 FUNCTION CONTROL | 60146500 | | | 01.50 | 84 |
| | PROGRAM SPECIFICATIONS (SUPPLEMENT) | | | | | |
| | DIGIGRAPHIC SUBSYSTEM FOR 3300 GEN.DESC | 60146600 | B | 22 | 01.50 | 74 |
| | SYSTEM OPERATION | | | | | |
| | DIGIGRAPHIC SUBSYSTEM FOR 3300 (STUDY GUIDE) | 60233700 | A | 22 | 01.50 | 78 |
| 469 | COMPUTER SYSTEM | | | | | |
| | ASSEMBLER REF MAN V1.2 | 14077300 | | 22 | 01.50 | 66 |
| | BASIC ARITHMETIC REF MANUAL | 14082200 | B | 22 | 02.00 | 90 |
| | PROGRAMMING REF MANUAL | 14065300 | B | 22 | 03.00 | 150 |
| | SIMULATOR REF MAN V1.0B | 14082100 | D | 22 | 02.00 | 88 |
| | SUBROUTINES | | | | | |
| 924-A | COMPUTER | | | | | |
| | 924 ASSEMBLY PROGRAM FOR PAPER TAPE-CM01 | 60082600 | | | 01.00 | 16 |
| 1604-A | | | | | | |
| | FORTRAN -60 OPERATING GUIDE | 60138100 | | | 01.00 | 48 |
| | SOURCE LANGUAGE (PSB) | 60138000 | | | 02.00 | 88 |
| 1604-C/1604-A | FORMERLY 1604/1604A | | | | | |
| | ALGOL (AE15) GIM | 60083400 | | | 01.00 | 84 |
| | ALGOL (SP002) GIM | 60084100 | | | 02.05 | 44 |
| | CODAP-I (PSBAE10) GIM | 60081000 | | | 01.00 | 8 |

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched in manual for use with hard cover ringed binder.

4. Price per manual.
5. Manual page count.

| TITLE | | 1 | 2 | 3 | 4 | 5 |
|---------------|--|----------|---|----|-------|-----|
| | REF MANUAL | 60051000 | | | 01.00 | 48 |
| COMPATABILITY | | 60083600 | | | 01.00 | 10 |
| COSY ASSEMBLY | PSR | 60081100 | A | | 01.00 | 8 |
| COBOL | REF MANUAL | 60052100 | B | | 06.00 | 222 |
| | INTRODUCTION TO | 60052000 | | | 01.00 | 60 |
| COM2 | REF MANUAL | 60051100 | | | 01.50 | 66 |
| COM3 | REF MANUAL | 60052600 | | | 01.50 | 68 |
| CO-OP MONITOR | REF MANUAL | 60051600 | B | 3 | 02.00 | 94 |
| | INSTANT | 60056100 | | | 01.35 | 36 |
| | OPERATORS GUIDE | 60050900 | | | 02.00 | 92 |
| | PROGRAMMING GUIDE | 60050800 | A | | 03.00 | 150 |
| FTN-60 SP001 | GIM | 60084000 | | | 04.00 | 190 |
| FORTAN II/63 | CONV GUIDE (PSBAE13) | 60081300 | | | 01.00 | 12 |
| FORTAN IV/67 | CONV GUIDE (AE-15) | 60081500 | | | 01.00 | 10 |
| FORTAN 60/62 | CONV GUIDE (PS A505) | 60080500 | | | 01.00 | 28 |
| FORTAN-62 | | 60050600 | A | | 02.50 | 116 |
| FORTAN-63 | | 60052900 | A | 3 | 04.00 | 196 |
| LIBEDIT | | 60080400 | | | 01.00 | 18 |
| PERT | | 60053900 | | | 02.00 | 96 |
| PERT/TIME/FTN | | 60139000 | | | 01.00 | 28 |
| SORT | | 60053500 | | 3 | 01.50 | 86 |
| SORT TIMING | | 60083700 | | | 01.00 | 19 |
| MISCELLANEOUS | | | | | | |
| | CHARACTERISTICS | 60001800 | C | | 02.00 | 104 |
| | COMPUTER CENTER OPERATIONS (MASTER TAPE) | 60018200 | B | | 01.00 | 36 |
| | PROGRAMMING SYSTEMS | 60052200 | | | 01.00 | 8 |
| | PART 2 OPERATION | 60003200 | | | 05.50 | 266 |
| 1700 | ASSEMBLY SYSTEM (4K) | 60133900 | A | | 01.00 | 28 |
| | REFERENCE | 60171600 | | | 01.50 | 70 |
| | INSTANT | 60173700 | | | 01.35 | 28 |
| | ADB | 60176500 | | | 01.00 | 34 |
| 1700 | MSOS | | | | | |
| | REF MAN V2 | 60223100 | C | | 05.00 | 260 |
| | REF MAN V4 | 60361500 | D | 22 | 08.75 | 460 |
| | DIAGNOSTIC HB V4 | 60361800 | D | | 03.65 | 144 |
| | IHR V2.1 | 60234300 | F | 22 | 05.20 | 118 |
| | IHR V4.0 | 60361600 | C | 22 | 06.40 | 328 |
| | OPERATORS GUIDE V4.0 | 60373400 | A | 22 | 01.50 | 74 |
| | SYSTEM CHKOUT REF V2 | 60362200 | A | | 01.00 | 42 |
| | IMPORT (1700) HS REF | 60305700 | A | 22 | 02.00 | 90 |
| MSOS 4 | FILE MANAGER V1 REF | 39520600 | B | 22 | 02.50 | 110 |
| | ASSEMBLER, MACRO GIM | 39519800 | B | 22 | 01.00 | 38 |
| | INSTANT | 39520500 | A | | 02.75 | 82 |
| | GIM | 39522400 | B | 22 | 01.00 | 38 |
| | MS/FORTAN VER3-A/R | 39519900 | A | 22 | 01.00 | 56 |
| | INSTALLATION HANDBOOK | 39520900 | A | 22 | 03.00 | 138 |
| | GENERAL INFO MANUAL | | | | | |

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4. Price per manual.
5. Manual page count.

| TITLE | 1 | 2 | 3 | 4 | 5 |
|---|----------|---|----|-------|-----|
| INSTANT SMALL COMPUTER MAINT. MONITOR V1 | 39521700 | A | | 01.35 | 44 |
| ORDERING BULLETIN V4 | 39521900 | B | 22 | 01.50 | 76 |
| RCOS 2 ASSEMBLER REF MANUAL | 88997600 | A | 22 | 01.50 | 72 |
| RFF MAN V2 | 88948500 | A | 22 | 03.50 | 178 |
| RELEASE BULLETIN | 39520800 | A | 22 | 01.25 | 72 |
| TIME-SHARE REF MAN 2.0 | 88964000 | A | 22 | 04.00 | 198 |
| TOTES FILE MGR UTILITY PROG | 88947900 | A | 22 | 13.65 | 74 |
| OPERATORS GUIDE | 88818500 | A | 22 | 15.85 | 94 |
| GIM | 96716700 | A | 22 | 02.90 | 46 |
| ASSEMBLER, MACRO REF MAN V3 | 60361900 | B | 22 | 02.00 | 88 |
| CONFIGURATION REF MAN V2 | 60362300 | C | 22 | 02.00 | 98 |
| COSY/MSOS REF MANUAL | 60362100 | B | | 01.00 | 28 |
| MS FORTRAN REF MAN V3 | 60362000 | D | 22 | 04.50 | 230 |
| OLYMPUS 1700 DIAGNOSTIC PACKAGE SOFTWARE | 39268100 | D | 22 | 03.90 | 130 |
| SMALL COMPUTER MAINTENANCE MONITOR REF. MAN. | 39520200 | A | 22 | 01.50 | 76 |
| UTOPIA 1700 CONSOLE DEBUGGING PKG. SOFTWARE | 84797500 | C | 3 | 01.50 | 80 |
| 1700 | | | | | |
| REDUCED CORE MONITOR | | | | | |
| REDUCED CORE IHR V1 | 60282800 | A | 22 | 02.50 | 116 |
| REF MAN V1 | 60280600 | A | 22 | 01.50 | 84 |
| 1700 | | | | | |
| UTILITY SYSTEM | | | | | |
| GIM | 60170700 | | 3 | 01.00 | 20 |
| REF MANUAL | 60172300 | | | 02.00 | 90 |
| INSTANT | 60173700 | | | 01.35 | 28 |
| ASSEMBLER | | | | | |
| GIM | 60133900 | A | | 01.00 | 28 |
| REF MANUAL | 60171600 | | | 01.50 | 70 |
| INSTANT | 60173700 | | | 01.35 | 28 |
| TAPE FORTRAN | | | | | |
| REF MANUAL | 60174200 | | 3 | 02.50 | 122 |
| INSTANT | 60173700 | | | 01.35 | 28 |
| I/O DRIVERS | | | | | |
| 17481430 | 60190000 | | | 01.00 | 50 |
| | 60234500 | | | 01.00 | 16 |
| SYSTEM BULLETINS | | | | | |
| SR 8 | 60194000 | | | 02.00 | 88 |
| SR 9 | 60222200 | | | 01.00 | 22 |
| SR 13 | 60228500 | | | 01.00 | 20 |
| MISCELLANEOUS | | | | | |
| SEQ. NO. ONLY | | | | | |
| ANALOG/DIGITAL SYSTEMS GENERAL INFORMATION | 60187600 | | | 02.00 | 92 |
| AUTPAN USERS GUIDE V2.0 | 88762200 | C | 22 | 03.00 | 142 |
| AUTRAN REFERENCE MANUAL V2.0 | 88762000 | B | 22 | 05.50 | 286 |
| AUTRAN IHR V2.0 | 88762100 | B | 22 | 03.00 | 158 |
| AUTRAN DACS SOFTWARE REFERENCE MAN V1 | 39644500 | C | | 07.55 | 280 |
| AUTPAN IT SYSTEMS MAINTENANCE SPECIFICATIONS VOLS 1 AND 2 | 39201800 | A | 22 | 09.00 | 512 |
| CARDIO TEST II SOFTWARE OPERATORS GUIDE | 39677500 | A | | 01.00 | 26 |
| DRAFT (VER. 5.1) OCR REFERENCE MANUAL | 48143900 | F | 3 | 04.50 | 118 |
| 915/919 GRASP (VER. 2.2) OCR SOFTWARE REF MAN | 48430100 | B | 3 | 03.10 | 80 |
| 955 GRASP (VER. 2.3) OCR SOFTWARE INSTALLATION HANDBOOK | 91556200 | | | 02.45 | 22 |

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched in manual for use with hard cover ringed binder.

4. Price per manual.
5. Manual page count.

| TITLE | 1 | 2 | 3 | 4 | 5 |
|--|----------|----|----|-------|-----|
| MEDISCOPE GENERAL INFORMATION MANUAL | 60259500 | | 3 | 01.00 | 34 |
| MESSAGE ENTRY SYSTEM (MENS) SITE PREPARATION MANUAL | 41600000 | C | 22 | 01.50 | 68 |
| PARIMUTUEL WAGERING SYSTEM GIM | 59155600 | 01 | 22 | 01.00 | 42 |
| REMOTE I/O SUBSYSTEM (PRODUCTION CONFIGURA- TION) HDR. REF./OE MANUAL | 39260700 | A | 22 | 08.65 | 482 |
| SETPAN SOFTWARE REFERENCE MANUAL | 60259400 | B | | 01.50 | 60 |
| SHORT OPERATING SYSTEM PROGRAM RULES REF. | 60259700 | A | | 03.50 | 182 |
| SUP-SOFTWARE REFERENCE MANUAL | 91637300 | 01 | 22 | 03.30 | 54 |
| SUP (VER.1.0) SOFTWARE INSTALLATION HANDBOOK | 91602400 | B | | 02.50 | 34 |
| TICKET ISSUING SYSTEM USERS GUIDE | 59155100 | A | | 01.00 | 32 |
| TAPE SCOPE OCR SOFTWARE REF MANUAL | 48430010 | 04 | 3 | 03.00 | 148 |
| 1700/SC1701 ASSEMBLER OCR SOFTWARE REF MAN | 91634000 | A | 22 | 04.00 | 80 |
| 915/919 AN) 955/959 SETUP (VER.1.4) OCR SOFTWARE REFERENCE MANUAL | 91674400 | A | | 01.95 | 30 |
| 955 GRASP (VER.2.3) OCR SOFTWARE REFERENCE | 48430000 | C | 3 | 03.25 | 38 |
| 915/919 GRASP (VER.2.2) OCR SFTWARE INSTALL. | 91529600 | | 3 | 01.00 | 42 |
| 929 DRIVE(1784) SOFTWARE REF MANUAL | 87971800 | B | 22 | 04.05 | 112 |
| ***** | | | | | |
| 3170/3300/3500 COMPUTER SYSTEMS | | | | | |
| * MASTER V4 * | | | | | |
| ***** | | | | | |
| MASTER | | | | | |
| DIAGNOSTIC HANDBOOK | 60415500 | C | 22 | 09.75 | 539 |
| GTM | 60134100 | B | 22 | 01.00 | 34 |
| INSTALLATION HANDBOOK | 60415300 | D | 22 | 08.25 | 458 |
| INSTANT | 60426000 | A | 22 | 01.35 | 102 |
| LTB GEN/MAINT MANUAL (INCLUDES COSY,CUP,GLIB, SYSGEN) | 60415400 | C | 22 | 07.50 | 368 |
| OPERATORS GUIDE | 60415200 | A | 22 | 02.00 | 108 |
| REFERENCE MANUAL | 60415100 | C | 22 | 09.75 | 556 |
| USERS GUIDE | 60425700 | A | 22 | 05.50 | 278 |
| UTILITIES REF MANUAL | 60418900 | B | 22 | 02.00 | 107 |
| REF MANUAL | 60371800 | C | 22 | 04.00 | 190 |
| ALGOL | 60417800 | C | 22 | 06.00 | 305 |
| COBOL, ANSI | 60192000 | B | 22 | 04.00 | 188 |
| COBOL, MS | 60236800 | C | 22 | 06.40 | 314 |
| COMPASS | 60281400 | C | 22 | 04.50 | 214 |
| FORTRAN, ANST | 60236500 | B | 22 | 03.50 | 168 |
| REF MAN V2 | 60057600 | G | 22 | 05.00 | 254 |
| FORTRAN, MS | 60236900 | B | 22 | 02.50 | 122 |
| REF MANUAL | 60343500 | B | 22 | 01.50 | 64 |
| LISA | 60418000 | B | 22 | 01.50 | 91 |
| L-SORT | 60372700 | A | 22 | 07.90 | 416 |
| MS-SORT | 60372800 | A | 22 | 02.50 | 136 |
| REF MANUAL | 60282400 | E | 22 | 03.50 | 172 |
| MARS-III | 60236400 | B | 22 | 03.50 | 164 |
| USERS MANUAL | 60132500 | A | 22 | 01.50 | 78 |
| MOS-III | 60131100 | | 22 | 01.00 | 58 |
| REF MANUAL | | | | | |
| META | | | | | |
| PERT/COST | | | | | |
| REF MANUAL | | | | | |
| PERT/TIME | | | | | |
| REF MANUAL | | | | | |

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4. Price per manual.
5. Manual page count.

| TITLE | 1 | 2 | 3 | 4 | 5 |
|--|----------|---|----|-------|-----|
| RESPOND-EXP/TMP REF MANUAL | 60372300 | B | 22 | 02.00 | 110 |
| TAPE SORT/MERGE REF MANUAL | 60282100 | E | 22 | 02.50 | 118 |
| 3170/3300/3500 COMPUTER SYSTEMS | | | | | |
| ***** | | | | | |
| * MASTER V3 * | | | | | |
| ***** | | | | | |
| MASTER | | | | | |
| DIAGNOSTIC HDBK V3 | 60280800 | F | 22 | 09.40 | 520 |
| GIM | 60134100 | B | 22 | 01.00 | 34 |
| IHB | 60372500 | F | 22 | 08.25 | 460 |
| INSTANT | 60227600 | D | | 01.35 | 34 |
| LIBRARY GEN/MAINT MANUAL (INCLUDES COSY,CUP,GLIB, SYSGFN) | 60373100 | D | 22 | 07.15 | 370 |
| OPERATORS GUIDE V3 | 60281300 | E | 22 | 04.00 | 208 |
| REF MAN V3 | 60281000 | D | 22 | 09.00 | 494 |
| USERS GUIDE V3 | 60371600 | B | 22 | 05.50 | 266 |
| ALGOL | 60134900 | | | 01.35 | 34 |
| INSTANT | 60371800 | C | 22 | 04.00 | 190 |
| REF MANUAL | 60213500 | A | 22 | 01.00 | 52 |
| COBOL, ANSI | 60229500 | B | | 01.35 | 32 |
| INSTANT | 60281100 | F | 22 | 08.25 | 456 |
| REF MANUAL | 60056300 | | 3 | 02.25 | 32 |
| COBOL, MS | 60192000 | B | 22 | 04.00 | 188 |
| GIM | 60176700 | B | | 01.35 | 20 |
| COMPASS | 60236800 | C | 22 | 06.40 | 314 |
| INSTANT | 60229300 | A | | 01.35 | 26 |
| REF MANUAL | 60281400 | C | 22 | 04.50 | 214 |
| FORTRAN, ANSI | 60055200 | C | 22 | 01.00 | 40 |
| REF MAN V2 | 60131400 | E | | 01.35 | 20 |
| FORTRAN, MS | 60057600 | G | 22 | 05.00 | 254 |
| INSTANT | 60236900 | B | 22 | 02.50 | 122 |
| LISA | 60343500 | A | 22 | 01.50 | 64 |
| L-SORT | 60372700 | A | 22 | 07.90 | 416 |
| MAPS | 60372800 | | 22 | 02.50 | 136 |
| REF MAN V2 | 60282400 | E | 22 | 03.50 | 172 |
| USERS GUIDE V2 | 60236000 | A | 22 | 01.00 | 56 |
| MCS III | 60236400 | B | 22 | 03.50 | 164 |
| REF MANUAL | 60362400 | A | 22 | 02.50 | 116 |
| MS SORT | 60130000 | | 22 | 01.00 | 16 |
| REF MAN V3 | 60132500 | A | 22 | 01.50 | 78 |
| PERT COST | 60179800 | | | 01.00 | 20 |
| ADV DEV BULLETIN | 60131100 | | 22 | 01.00 | 58 |
| REF MANUAL | 60179700 | | | 01.00 | 14 |
| APP DEV BULLETIN | 60172800 | | | 01.00 | 22 |
| APP DEV BULLETIN V2 | 60282100 | E | 22 | 02.50 | 118 |
| TAPE SORT/MERGE REF MANUAL | 60372300 | B | 22 | 02.00 | 110 |
| RESPOND EXP/TMP REF MANUAL | 60227700 | A | | 01.35 | 36 |
| INSTANT | | | | | |

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4. Price per manual.
5. Manual page count.

| TITLE | 1 | 2 | 3 | 4 | 5 |
|--|----------|---|----|-------|-----|
| 3170/3300/3500 COMPUTER SYSTEMS | | | | | |
| ***** | | | | | |
| * MASTER V3,V4 (MISC) * | | | | | |
| ***** | | | | | |
| ANSI FORTRAN REF MAN V1 (FOR MASTER V3,V4) | 60236500 | B | 22 | 03.50 | 168 |
| MS SORT V2 (FOR REF MANUAL MASTER V3.0 AND V3.1) | 60282200 | B | 22 | 02.00 | 100 |
| L-SORT V1 (FOR REF MANUAL MASTER V3.0 AND V3.1) | 60280200 | A | 22 | 01.00 | 28 |
| DCP MARK 4 DIGI- REF MANUAL GRAPHICS (ONLY FOR MASTER V3.0) | 60236600 | A | 22 | 03.00 | 156 |
| MAPS REF MAN V1 | 60281900 | B | 22 | 08.25 | 446 |
| USERS GUIDE V1 | 60282000 | B | 22 | 02.50 | 120 |
| 3170/3300/3500 COMPUTER SYSTEMS | | | | | |
| ***** | | | | | |
| * MASTER V2 * | | | | | |
| ***** | | | | | |
| MASTER REF MAN V2 | 60213600 | D | 22 | 07.50 | 388 |
| DIAGNOSTIC HDBK V2 | 60206800 | B | 22 | 04.50 | 214 |
| IHB V2 | 60214000 | G | 22 | 08.65 | 466 |
| OPERATORS GUIDE V2 | 60178600 | B | 22 | 02.50 | 132 |
| COSY REF MANUAL | 60178800 | B | 22 | 01.00 | 36 |
| 3100/3150/3170/3200/3300/3500 COMPUTER SYSTEMS | | | | | |
| ***** | | | | | |
| * MSOS V5 * | | | | | |
| ***** | | | | | |
| MSOS DIAGNOSTIC HANDBOOK | 60410900 | C | 22 | 05.50 | 287 |
| INSTANT | 60411000 | A | | 01.35 | 164 |
| IHB | 60410800 | D | 22 | 06.40 | 326 |
| OPERATORS GUIDE | 60410700 | B | 22 | 01.50 | 108 |
| REF MANUAL | 60410600 | C | 22 | 07.50 | 405 |
| ADAPT REF MANUAL | 60173400 | B | 22 | 02.50 | 134 |
| ALGOL REF MANUAL | 60371800 | C | 22 | 04.00 | 190 |
| COROL, ANSI REF MANUAL | 60417900 | A | 22 | 05.00 | 240 |
| COROL, MS REF MANUAL | 60191100 | C | 22 | 03.50 | 170 |
| COMPASS REF MANUAL | 60236800 | C | 22 | 06.40 | 314 |
| COSY REF MANUAL | 60207300 | C | 22 | 01.00 | 48 |
| FORTRAN, ANSI REF MANUAL | 60281400 | C | 22 | 04.50 | 214 |
| FORTRAN, MS REF MANUAL | 60057600 | G | 22 | 05.00 | 254 |
| LISA/MSTR/MSOS REF MANUAL | 60236900 | B | 22 | 02.50 | 122 |
| REF COST REF MANUAL | 60132500 | A | 22 | 01.50 | 78 |
| REF TIME REF MANUAL | 60131100 | | 22 | 01.00 | 58 |

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4. Price per manual.
5. Manual page count.

| TITLE | | 1 | 2 | 3 | 4 | 5 |
|--|---------------------|----------|---|----|-------|-----|
| SAINT | REF MANUAL | 60213700 | B | 22 | 01.00 | 46 |
| SORT MERGE | REF MANUAL | 60281500 | B | 22 | 03.00 | 158 |
| 3100/3150/3170/3200/3300/3500 COMPUTER SYSTEMS | | | | | | |
| ***** | | | | | | |
| * MSOS V4 * | | | | | | |
| ***** | | | | | | |
| MSOS | DIAGNOSTIC HANDBOOK | 60236700 | D | 22 | 06.75 | 340 |
| | GIM | 60176000 | | 22 | 01.00 | 22 |
| | INSTANT | 60190300 | B | | 01.35 | 44 |
| | IHR | 60280700 | E | 22 | 07.50 | 410 |
| | OPERATORS GUIDE | 60176100 | D | 22 | 04.95 | 168 |
| | REF MANUAL | 60173000 | F | 22 | 06.75 | 358 |
| ADAPT | GIM | 60135900 | | | 01.00 | 20 |
| | REF MANUAL | 60173400 | B | 22 | 02.50 | 134 |
| | INSTANT | 60174900 | | | 01.35 | 34 |
| BSIPP | OPERATORS GUIDE | 60190200 | | | 01.00 | 28 |
| COBOL | GIM | 60056300 | | 3 | 02.25 | 32 |
| | REF MANUAL | 60172900 | | 3 | 03.50 | 176 |
| | INSTANT | 60131200 | A | | 01.35 | 32 |
| | REF MAN V2 | 60281100 | E | 22 | 08.25 | 456 |
| COBOL, ANSI | REF MANUAL | 60191100 | C | 22 | 03.50 | 200 |
| COBOL, MS | REF MANUAL | 60236800 | C | 22 | 06.40 | 314 |
| COMPASS | INSTANT | 60176700 | B | | 01.35 | 20 |
| | REF MANUAL | 60207300 | C | | 01.00 | 48 |
| COSY/MSOS/RTS | GIM | 60055200 | C | | 01.00 | 40 |
| FORTAN | REF MAN V4 | 60057600 | G | 22 | 05.00 | 254 |
| | INSTANT | 60131400 | E | | 01.35 | 20 |
| | REF MAN V2 | 60281400 | C | 22 | 04.50 | 214 |
| FORTAN, ANSI | REF MANUAL | 60236900 | B | 22 | 02.50 | 122 |
| LISA/MSTR/MSOS | ADR | 60192100 | | | 01.00 | 16 |
| MP | GIM | 60189700 | | | 01.00 | 12 |
| MSID | REF MANUAL | 60191300 | B | 3 | 02.00 | 112 |
| | GIM | 60130000 | | | 01.00 | 16 |
| PERT COST | REF MANUAL | 60132500 | A | | 01.50 | 78 |
| | ADR V2 | 60172800 | | | 01.00 | 22 |
| | ADR | 60177700 | | | 01.00 | 22 |
| | REF MANUAL | 60131100 | | | 01.00 | 58 |
| PERT TIME | ADR | 60177400 | | | 01.00 | 20 |
| | GIM | 60190400 | | | 01.00 | 16 |
| RESPOND | REF MANUAL | 60192800 | | | 01.00 | 60 |
| | INSTANT | 60229900 | | | 01.35 | 32 |
| SAINT | GIM | 60132100 | A | | 01.00 | 20 |
| | REF MANUAL | 60213700 | B | | 01.00 | 46 |
| SOPS | REF MANUAL | 60235900 | | | 02.00 | 96 |
| SFP | REF MANUAL | 60207200 | | | 01.00 | 36 |
| SIPP | REF MANUAL | 60130400 | B | | 01.00 | 32 |
| SORT/MERGE | REF MANUAL | 60281500 | B | 22 | 03.00 | 158 |
| SORT | REF MANUAL | 60174100 | A | 3 | 01.50 | 78 |
| TSORT/MERGE | GIM | 60055800 | A | | 01.00 | 20 |
| UTILITY | REF MANUAL | 60279400 | B | 22 | 01.00 | 22 |

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4. Price per manual.
5. Manual page count.

| TITLE | 1 | 2 | 3 | 4 | 5 |
|--|----------|---|----|-------|-----|
| 3100/3150/3170/3200/3300/3500 COMPUTER SYSTEMS | | | | | |
| ***** | | | | | |
| * REAL TIME SCOPE * | | | | | |
| ***** | | | | | |
| REAL TIME SCOPE | | | | | |
| DIAGNOSTIC HANDBOOK | 60236700 | D | 22 | 06.75 | 340 |
| GIM | 60134300 | | 3 | 01.00 | 22 |
| IHB | 60237000 | A | | 03.50 | 180 |
| INSTANT | 60191600 | | | 01.35 | 32 |
| OPERATORS GUIDE | 60170200 | A | 3 | 01.50 | 64 |
| REF MANUAL | 60172500 | | | 03.10 | 86 |
| ADAPT | 60135900 | | | 01.00 | 20 |
| GIM | 60173400 | B | 22 | 02.50 | 134 |
| REF MANUAL | 60190200 | | | 01.00 | 28 |
| BSIPP | 60056300 | | 3 | 02.25 | 32 |
| COBOL | 60132000 | | | 03.00 | 160 |
| GIM | 60131200 | A | | 01.35 | 32 |
| INSTANT | 60137600 | | | 01.00 | 28 |
| ADR V2 | 60055100 | R | | 01.00 | 20 |
| COBOL, GPTD | 60059300 | A | | 01.50 | 66 |
| REF MANUAL | 60236800 | C | 22 | 06.40 | 314 |
| COMPASS | 60176700 | B | | 01.35 | 20 |
| INSTANT | 60055000 | A | | 01.00 | 34 |
| COMPASS 32 | 60207300 | C | | 01.00 | 48 |
| COSY/MSOS/RTS | 60055200 | C | | 01.00 | 40 |
| FORTRAN | 60057600 | G | 22 | 05.00 | 254 |
| REF MANUAL | 60131400 | E | | 01.35 | 20 |
| INSTANT | 60236100 | | | 01.50 | 86 |
| FIN COMPAR 3/6 | 60130000 | | | 01.00 | 16 |
| PERT COST | 60132500 | A | | 01.50 | 78 |
| REF MANUAL | 60177700 | | | 01.00 | 22 |
| ADR | 60172800 | | | 01.00 | 20 |
| ADR V2 | 60131100 | | | 01.00 | 58 |
| PERT TIME | 60177400 | | | 01.00 | 20 |
| REF MANUAL | 60133100 | | | 01.00 | 22 |
| ADR | 60134700 | | | 02.00 | 102 |
| PRT GENERATOR | 60133800 | | | 01.35 | 24 |
| INSTANT | 60132100 | A | | 01.00 | 20 |
| SAINT | 60213700 | R | | 01.00 | 46 |
| GIM | 60130400 | R | | 01.00 | 32 |
| REF MANUAL | 60130200 | | | 01.00 | 26 |
| UTILITY, SCOPE | | | | | |
| 3100/3150/3200 COMPUTER SYSTEMS | | | | | |
| ***** | | | | | |
| * TAPE SCOPE * | | | | | |
| ***** | | | | | |
| TAPE SCOPE | | | | | |
| ADR, RANDOM DISK DR. | 60138300 | | | 01.00 | 32 |
| GIM | 60055400 | A | | 01.00 | 16 |
| INSTANT | 60189000 | A | | 01.35 | 36 |

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched in manual for use with hard cover ringed binder.

4. Price per manual.
5. Manual page count.

| TITLE | | 1 | 2 | 3 | 4 | 5 |
|---------------------------------|-----------------|----------|---|----|-------|-----|
| | OPERATORS GUIDE | 60059100 | | | 01.00 | 32 |
| | REF MANUAL | 60171200 | | | 04.50 | 220 |
| BSIOP | OPERATORS GUIDE | 60190200 | | | 01.00 | 28 |
| COBOL | GTM | 60056300 | | 3 | 02.25 | 32 |
| | REF MANUAL | 60132000 | | | 03.00 | 160 |
| | INSTANT | 60131200 | A | | 01.35 | 32 |
| | ADB 42 | 60137600 | | | 01.00 | 28 |
| COMPASS-32 | GIM | 60055000 | A | | 01.00 | 34 |
| | REF MANUAL | 60236800 | C | 22 | 06.40 | 314 |
| | INSTANT | 60176700 | B | | 01.35 | 20 |
| COSY/MSOS/RTS | REF MANUAL | 60207300 | C | | 01.00 | 48 |
| FORTRAN | GIM | 60055200 | C | | 01.00 | 40 |
| | REF MANUAL | 60057600 | G | 22 | 05.00 | 254 |
| | INSTANT | 60131400 | E | | 01.35 | 20 |
| FTN COMPAR 3/6 | REF MANUAL | 60236100 | | | 01.50 | 84 |
| PERT COST | GIM | 60130000 | | | 01.00 | 16 |
| | REF MANUAL | 60132500 | A | | 01.50 | 78 |
| | ADB V2 | 60172800 | | | 01.00 | 20 |
| | ADB MSOS | 60177700 | | | 01.00 | 22 |
| PERT TIME | GTM | 60130000 | | | 01.00 | 16 |
| | REF MANUAL | 60131100 | | | 01.00 | 58 |
| | ADB/MSOS | 60177400 | | | 01.00 | 20 |
| PEGINA | REF MANUAL | 60171800 | A | 3 | 01.00 | 60 |
| REPORT PROG GEN | GIM | 60133100 | | | 01.00 | 22 |
| | REF MANUAL | 60134700 | | | 02.00 | 102 |
| | INSTANT | 60133800 | | | 01.35 | 24 |
| SAINT | GTM | 60132100 | A | | 01.00 | 20 |
| | REF MANUAL | 60213700 | B | | 01.00 | 46 |
| STP | REF MANUAL | 60130400 | B | | 01.00 | 32 |
| TAPE SORT MERGE | GIM | 60055800 | A | | 01.00 | 20 |
| UTILITY, SCOPE | REF MANUAL | 60130200 | | | 01.00 | 26 |
| 3100/3150/3200 COMPUTER SYSTEMS | | | | | | |
| ***** | | | | | | |
| * BASIC DISK SCOPE * | | | | | | |
| ***** | | | | | | |
| BASIC DISK SCOPE | | | | | | |
| | REF GUIDE ADB | 60175100 | | | 01.00 | 32 |
| COMPASS-32 | GIM | 60055000 | A | | 01.00 | 34 |
| COMPASS | REF MANUAL | 60236800 | C | 22 | 06.40 | 314 |
| | INSTANT | 60176700 | B | | 01.35 | 20 |
| COSY/MSOS/RTS | REF MANUAL | 60207300 | C | | 01.00 | 48 |
| FORTRAN | GTM | 60055200 | C | | 01.00 | 40 |
| | REF MANUAL | 60057600 | G | 22 | 05.00 | 254 |
| | INSTANT | 60131400 | E | | 01.35 | 20 |
| FTN COMPAR 3/6 | REF MANUAL | 60236100 | | | 01.50 | 84 |
| 3100/3150/3200 COMPUTER SYSTEMS | | | | | | |
| ***** | | | | | | |
| * DISK SCOPE * | | | | | | |
| ***** | | | | | | |

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched in manual for use with hard cover ringed binder.

4. Price per manual.
5. Manual page count.

| TITLE | | 1 | 2 | 3 | 4 | 5 |
|--|-----------------|----------|---|----|-------|-----|
| DISK SCOPE | | | | | | |
| | REF MANUAL | 60171200 | | | 04.50 | 220 |
| | OPERATORS GUIDE | 60059100 | | | 01.00 | 32 |
| | INSTANT | 60189000 | A | | 01.35 | 36 |
| COMPASS-32 | GIM | 60055000 | A | | 01.00 | 34 |
| COMPASS | REF MANUAL | 60236800 | C | 22 | 06.40 | 314 |
| | INSTANT | 60176700 | B | | 01.35 | 20 |
| COSY/MSOS/RTS | REF MANUAL | 60207300 | C | | 01.00 | 48 |
| FORTTRAN | GIM | 60055200 | C | | 01.00 | 40 |
| | REF MANUAL | 60057600 | G | 22 | 05.00 | 254 |
| | INSTANT | 60131400 | F | | 01.35 | 18 |
| FTN COMPAR 3/6 | REF MANUAL | 60236100 | | 22 | 01.50 | 84 |
| UTILITY SCOPE | REF MANUAL | 60130200 | | | 01.00 | 26 |
| 3170/3300/3500 COMPUTER SYSTEMS | | | | | | |
| ***** | | | | | | |
| * KRONOS III * | | | | | | |
| ***** | | | | | | |
| KRONOS III | | | | | | |
| | GIM | 41614400 | B | 22 | 01.00 | 26 |
| ASSEMBLE | REF MANUAL | 41614800 | A | | 01.00 | 50 |
| BACKGROUND | REF MANUAL | 41615100 | A | | 01.00 | 22 |
| BASIC | REF MANUAL | 41615000 | | | 02.00 | 104 |
| CAL | REF MANUAL | 60361100 | A | | 02.00 | 100 |
| CENTRAL SITE | OPERATORS GUIDE | 60342800 | A | | 01.00 | 48 |
| DEBUG | REF MANUAL | 41615300 | A | | 01.00 | 36 |
| EDIT | REF MANUAL | 41614900 | A | | 01.00 | 52 |
| FORTTRAN/FTN | REF MANUAL | 41614700 | A | | 03.00 | 140 |
| GENERAL SYSTEM | USFPS MANUAL | 41614600 | B | 22 | 01.00 | 56 |
| GO | REF MANUAL | 41615200 | A | | 02.45 | 28 |
| INSTANT | REF MANUAL | 41614500 | A | | 01.35 | 82 |
| NFLIAC | REF MANUAL | 60361200 | A | | 02.15 | 60 |
| 3100/3150/3170/3200/3300/3500 COMPUTER SYSTEMS | | | | | | |
| ***** | | | | | | |
| * MISCELLANEOUS | | | | | | |
| ***** | | | | | | |
| ANALOG MAINT MONITOR (AMM30) SOFTWARE USERS MANUAL | | 84763300 | | | 03.00 | 138 |
| AUTOLOAD UTILITY (3000L) REFERENCE | | 60130100 | | | 01.00 | 30 |
| BASIC ASSEMBLER REFERENCE (3100/3200/3300) | | 60057100 | | | 01.50 | 64 |
| BASIC ASSEMBLY PROG GENERAL REFERENCE MAN | | 60056800 | | | 01.00 | 20 |
| BASIC FORTTRAN REFERENCE MANUAL | | 60172000 | | | 02.50 | 116 |
| BASIC SYSTEM GENERAL INFORMATION | | 60056800 | | | 01.00 | 20 |
| BASIC II FORTTRAN INSTANT (TAPE/SCOPE) | | 60189000 | A | | 01.35 | 36 |
| BASIC II FORTTRAN REFERENCE MANUAL | | 60056900 | | 22 | 01.00 | 56 |
| BROKERAGE CONTROL OPERATORS GUIDE | | 59153300 | A | 22 | 03.00 | 148 |
| BROKERAGE CONTROL OPERATORS GUIDE V4.0 | | 59159100 | A | 22 | 03.00 | 162 |
| BROKERAGE CONTROL REFERENCE MANUAL | | 59153200 | A | 22 | 01.50 | 80 |
| BROKERAGE CONTROL REFERENCE MANUAL V4.0 | | 59159000 | A | 22 | 02.00 | 88 |
| BOP EQUIPMENT BULLETIN | | 60157500 | | | 01.00 | 28 |

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched in manual for use with hard cover ringed binder.

4. Price per manual.
5. Manual page count.

| TITLE | 1 | 2 | 3 | 4 | 5 |
|---|----------|----|----|-------|-----|
| DIGIGRAPHIC SUBSYSTEM FOR 3000 (STUDY) | 60233700 | A | 22 | 01.50 | 78 |
| ILP1/INTEGER LINNEAR PROGRAMMING | 60084900 | A | | 01.00 | 32 |
| MASTER/PROFITS 1.0 INSTALLATION PROCEDURES | 97400100 | A | 22 | 01.00 | 24 |
| MASTER/OCS MANUAL | 59158900 | A | 22 | 04.15 | 154 |
| MASTER USERS UTILITIES REFERENCE MANUAL | 00007300 | A | 22 | 01.50 | 76 |
| MSOS ON-LINE CONTROL SUBSYSTEM (OCS) REF MAN | 59158800 | A | 22 | 06.25 | 214 |
| MSOS/PROFITS 1.0 INSTALLATION PROCEDURES | 59159600 | A | 22 | 01.00 | 22 |
| PARIMUTUEL WAGERING SYSTEM GIM | 59155600 | 01 | 22 | 01.00 | 42 |
| SASY/SATELLITE (3000L) OPERATORS REFERENCE | 60133700 | | | 01.00 | 52 |
| SASY/SATELLITE (3600) OPERATORS REFERENCE | 60171100 | | | 01.00 | 48 |
| TIME SHARING EQUIPMENT BULLETIN | 60156000 | | | 01.00 | 40 |
| 3000L COMMUNICATIONS SYS AND EQUIP REF 1 | 41606600 | 01 | 22 | 02.00 | 108 |
| 3000L TO CYBER 70 - CONVERSION AIDS SYSTEM VERSION 1.0 - FORTRAN CONVERSION FOR SCOPE 3.4 | 19980600 | B | 22 | 03.00 | 140 |
| 31/32/3300 SYSTEM BULLETIN 61 | 60236300 | | 3 | 01.00 | 16 |
| 31/32/33/3500 PRELIM MSOS APPLICATIONS BULL. | 60174700 | | 3 | 01.00 | 340 |
| 31/33/3500 HYBRID LINKAGE SYSTEM SOFTWARE USERS MANUAL | 39083500 | | 22 | 01.00 | 12 |
| 31/32/33/3500 REGINA I | 60178000 | | | 01.00 | 7 |
| 3200 SASY OPERATORS GUIDE | 60133700 | | | 01.00 | 52 |
| 3200 SCOPE/EXECUTION INTERROGATION PROG | 60139300 | A | 3 | 01.00 | 22 |
| 3400/3600/3800 COMPUTER SYSTEMS | | | | | |
| ***** | | | | | |
| * 3400 DRUM SCOPE * | | | | | |
| ***** | | | | | |
| DRUM SCOPE | | | | | |
| GIM | 60131900 | | | 01.00 | 32 |
| REF MANUAL | 60170100 | | | 04.00 | 196 |
| OPERATORS GUIDE | 60171900 | | | 01.00 | 52 |
| ALGOL INSTANT | 60131700 | | | 01.35 | 24 |
| ALGOL-60 GIM | 60173300 | | | 01.00 | 20 |
| COBOL GIM | 60170900 | | | 01.00 | 40 |
| REF MANUAL | 60170500 | A | | 05.00 | 239 |
| INSTANT | 60057400 | A | | 01.35 | 28 |
| COMPASS GIM | 60055700 | A | | 01.00 | 32 |
| 3400 BASIC REFERENCE MANUAL | 60057900 | | | 03.00 | 144 |
| FORTRAN GIM | 60055500 | A | | 01.00 | 36 |
| REF MANUAL | 60132900 | A | | 04.50 | 220 |
| INSTANT | 60057500 | B | | 01.35 | 24 |
| FTN LIB FUNCT REF MANUAL | 60057200 | | | 02.00 | 98 |
| GPTA GIM | 60058900 | | | 01.00 | 16 |
| REF MANUAL | 60059400 | A | | 01.00 | 44 |
| PERT TIME/COST REF MANUAL | 60059500 | | | 02.50 | 118 |
| TAB (EXTENSION) | 60139100 | | | 01.00 | 20 |
| SORT III REF MANUAL | 60059800 | A | | 01.50 | 72 |
| UTILITY PACKAGE ADR | 60137100 | | | 01.00 | 26 |
| UTILITY COSY ADR | 60171500 | | | 01.00 | 12 |
| ***** | | | | | |

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4. Price per manual.
5. Manual page count.

| TITLE | | 1 | 2 | 3 | 4 | 5 |
|--------------------------|-----------------------|----------|---|----|-------|-----|
| * 3400 TAPE SCOPE * | | | | | | |
| ***** | | | | | | |
| TAPE SCOPE | | | | | | |
| | GIM | 60055600 | B | | 01.00 | 34 |
| | REF MANUAL | 60057800 | | | 04.50 | 228 |
| | OPERATING GUIDE V3 | 60134200 | | | 01.00 | 56 |
| | INSTANT | 60059000 | A | | 01.35 | 36 |
| | ADB (ADDITION TO REF) | 60137200 | | | 01.00 | 20 |
| | ADR (LIB PREPARATION) | 60137300 | | | 01.00 | 16 |
| ALGOL | INSTANT | 60131700 | | | 01.35 | 24 |
| | ADB | 60084800 | A | | 01.50 | 86 |
| ALGOL-60 | GIM | 60173300 | | | 01.00 | 20 |
| CEM-4 | REF MANUAL | 60132300 | A | | 03.35 | 112 |
| COBOL | GTM | 60170900 | | | 01.00 | 40 |
| | REF MANUAL | 60170500 | A | 22 | 05.00 | 239 |
| | INSTANT | 60057400 | A | | 01.35 | 28 |
| COMPASS | GIM | 60055700 | A | | 01.00 | 32 |
| | REF MANUAL | 60057800 | A | | 04.50 | 228 |
| | ADR (ADDITION TO REF) | 60137200 | | | 01.00 | 20 |
| COMPASS/FTN | MIXED DECKS (PSB) | 60137000 | | | 01.00 | 20 |
| FORTRAN | GIM | 60055500 | A | | 01.00 | 36 |
| | REF MANUAL | 60132900 | A | | 04.50 | 220 |
| | REF MANUAL (GENERIC) | 60214900 | A | | 03.50 | 186 |
| | INSTANT | 60057500 | B | | 01.35 | 24 |
| FTN COMPAR 3/6 | REF MANUAL | 60236100 | | | 01.50 | 84 |
| FTN LIB FUNCT | REF MANUAL | 60057200 | | | 02.00 | 98 |
| GRI0 | GTM | 60058900 | | | 01.00 | 16 |
| | REF MANUAL | 60059400 | A | | 01.00 | 44 |
| INFOL | GIM | 60132400 | | | 01.00 | 16 |
| PERT TIME/COST | REF MANUAL | 60059500 | | | 02.50 | 118 |
| | TAR (EXTENSIONS) | 60139100 | | | 01.00 | 20 |
| SORT III | REF MANUAL | 60059800 | A | | 01.50 | 72 |
| SORT MERGE | GTM | 60058700 | | | 01.00 | 16 |
| UTILITY PACKAGE | ADB | 60137100 | | | 01.00 | 26 |
| UTILITY COSY | ADR | 60171500 | | | 01.00 | 12 |
| | SB 24 (3400) | 60192600 | | | 01.00 | 12 |
| | SB 48 (36/3800) | SB001700 | | | 02.65 | 76 |
| | SB 50 (36/3800) | 60192700 | | | 01.00 | 12 |
| | SP 51 (36/3800) | 60193600 | | | 01.00 | 38 |
| | SR 52 (36/3800) | 60215200 | | | 01.00 | 60 |
| | SR 54 (36/3800) | 60279200 | | | 01.00 | 24 |
| 3400 SYSTEM | GTM | 60058300 | | | 01.00 | 28 |
| * * * * * | | | | | | |
| * 3600/3800 DRUM SCOPE * | | | | | | |
| * * * * * | | | | | | |
| DRUM SCOPE | | | | | | |
| | GIM | 60131000 | | | 01.00 | 28 |
| | REF MANUAL | 60059200 | B | 22 | 04.50 | 222 |
| | OPERATORS GUIDE V1 | 60171900 | | | 01.00 | 52 |
| | OPERATORS GUIDE | 60175000 | A | | 01.00 | 54 |
| | INSTANT | 60131600 | A | | 01.35 | 36 |

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched in manual for use with hard cover ringed binder.

4. Price per manual.
5. Manual page count.

| TITLE | | 1 | 2 | 3 | 4 | 5 |
|--------------------------|-----------------------|----------|---|---|-------|-----|
| | ADB (BACKGROUND PRG) | 60137900 | | | 02.60 | 26 |
| | ADB (DRUM/TAPE SCOPE) | 60137500 | | | 01.00 | 16 |
| ALGOL | INSTANT | 60131700 | | | 01.35 | 24 |
| ALGOL-60 | GIM | 60173300 | | | 01.00 | 20 |
| APT | GIM | 60131500 | | | 01.00 | 20 |
| | REF MANUAL | 60132800 | A | | 05.00 | 244 |
| | ADB | 60190100 | | | 01.00 | 34 |
| | SUPPLEMENT | 60192900 | | | 01.50 | 84 |
| CDC KWIC | ADB | 60175300 | | | 01.00 | 32 |
| COM-4 | REF MANUAL | 60177000 | | | 02.00 | 108 |
| COBOL | GIM | 60170900 | | | 01.00 | 40 |
| | REF MANUAL | 60170500 | A | | 05.00 | 239 |
| | INSTANT | 60057400 | A | | 01.35 | 28 |
| COMPASS | GIM | 60131800 | | | 01.00 | 36 |
| | REF MANUAL | 60052500 | C | | 02.00 | 102 |
| DISK SORT | GIM | 60177300 | | | 01.00 | 16 |
| | REF MANUAL | 60189600 | | | 01.00 | 48 |
| FORTTRAN | GIM | 60053400 | | | 01.00 | 52 |
| | REF MANUAL | 60132900 | A | | 04.50 | 220 |
| | OPERATING GUIDE (PSB) | 60138200 | | | 01.00 | 46 |
| | INSTANT | 60057500 | B | | 01.35 | 24 |
| FTN LIB FUNCT | REF MANUAL | 60056400 | B | | 02.50 | 118 |
| FORTTRAN | GIM | 60132400 | | | 01.00 | 16 |
| | 34/38 INFO MAN | 60170300 | | | 03.00 | 140 |
| | INSTANT | 60173600 | | | 01.35 | 20 |
| FTN COMPAR 3/6 | REF MANUAL | 60236100 | | | 01.50 | 84 |
| GPIO | REF MANUAL | 60130600 | | | 02.15 | 40 |
| MSIO | REF MANUAL | 60174800 | A | | 01.00 | 60 |
| NETWORK FLOW | REF MANUAL | 60130500 | | | 01.00 | 52 |
| PERT COST | REF MANUAL | 60214800 | | | 02.00 | 92 |
| PERT TIME | REF MANUAL | 60170800 | | | 01.50 | 74 |
| PERT TIME/COST | GIM | 60170400 | | | 01.00 | 16 |
| SIMSCRIPT | GIM | 60133000 | | | 01.00 | 28 |
| | REF MANUAL | 60134600 | | | 03.00 | 162 |
| | INSTANT | 60133500 | | | 01.35 | 28 |
| SOPT II | GIM | 60058600 | | | 01.00 | 20 |
| | REF MANUAL | 60058500 | D | | 01.50 | 78 |
| ***** | | | | | | |
| * 3600/3800 TAPE SCOPE * | | | | | | |
| ***** | | | | | | |
| | TAPE SCOPE | | | | | |
| | GIM | 60132200 | A | | 01.00 | 20 |
| | REF MANUAL | 60053300 | B | | 05.50 | 280 |
| | INSTANT | 60059000 | A | | 01.35 | 36 |
| | ADB | 60171300 | A | | 01.00 | 20 |
| ALGOL | INSTANT | 60131700 | | | 01.35 | 24 |
| ALGOL-60 | GIM | 60173300 | | | 01.00 | 20 |
| APT | GIM | 60131500 | | | 01.00 | 20 |
| | REF MANUAL | 60132800 | A | | 05.00 | 244 |
| | ADB | 60190100 | | | 01.00 | 34 |
| | SUPPLEMENT | 60192900 | | | 01.50 | 84 |

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched in manual for use with hard cover ringed binder.

4. Price per manual.
5. Manual page count.

| TITLE | | 1 | 2 | 3 | 4 | 5 |
|--|------------------------|----------|---|----|-------|-----|
| CDC KWIC | ADB | 60175300 | | | 01.00 | 32 |
| CEM-4 | REF MANUAL | 60132300 | A | | 02.00 | 112 |
| COBOL | GIM | 60170900 | | | 01.00 | 40 |
| | REF MANUAL | 60170500 | A | | 05.00 | 239 |
| | REV A FOR 36/38 ONLY | | | | | |
| | INSTANT | 60057400 | A | | 01.35 | 28 |
| | EXTENSIONS V2 (PSB) | 60138400 | | | 01.00 | 12 |
| | BIN ARITH 3600 COBOL | 60083800 | | | 01.00 | 8 |
| COMPASS | GIM | 60131800 | | | 01.00 | 36 |
| | REF MANUAL | 60052500 | C | | 02.00 | 102 |
| | INSTANT | 60056500 | A | | 01.35 | 32 |
| DISK SORT | REF MANUAL | 60189600 | | | 01.00 | 48 |
| FORTRAN | GIM | 60053400 | | | 01.00 | 52 |
| | REF MANUAL | 60132900 | A | | 04.50 | 220 |
| | 36/38 INFO REF MAN | 60170300 | | | 03.00 | 140 |
| | INSTANT | 60173600 | | | 01.35 | 20 |
| | INSTANT | 60057500 | B | | 01.35 | 24 |
| FORTRAN II/3600 | CONVERSION GUIDE | 60081900 | A | | 01.00 | 16 |
| FORTRAN 63 | CONVERSION GUIDE (PSB) | 60082000 | | | 01.00 | 16 |
| FTN LIB FUNCT | REF MANUAL | 60056400 | B | | 02.50 | 118 |
| INFOL | GIM | 60132400 | | | 01.00 | 16 |
| | INSTANT | 60173600 | | | 01.35 | 20 |
| NETWORK FLOW | REF MANUAL | 60130500 | | | 01.00 | 52 |
| OPHELIE | ADB | 60172200 | | | 02.00 | 96 |
| PERT COST | REF MANUAL | 60214800 | | | 02.00 | 92 |
| PERT TIME | REF MANUAL | 60170800 | | | 01.50 | 74 |
| PERT TIME/COST | GTM | 60170400 | | | 01.00 | 16 |
| SIMSCRIPT | GIM | 60133000 | | | 01.00 | 28 |
| | REF MANUAL | 60134600 | | | 03.00 | 162 |
| | INSTANT | 60133500 | | | 01.35 | 28 |
| SORT II | GIM | 60058600 | | | 01.00 | 20 |
| | REF MANUAL | 60058500 | D | | 01.50 | 78 |
| MISCELLANEOUS | | | | | | |
| LIBRARY PREPARATION AND MAINTENANCE FOR 3600 (CA-11) | | 60083500 | | | 01.00 | 24 |
| OSAS-A MASTER TAPE (7681) | | 60138900 | | | 01.00 | 24 |
| SCOPE MESSAGES AND DIAGNOSTICS (CA-03A) | | 60082400 | A | 3 | 01.00 | 44 |
| SCOPE OPERATING GUIDE VERSION 2.0 | | 60138800 | | | 01.00 | 28 |
| SUMMIT-NRL 3600 SYSTEM | | | | | | |
| COM-4 | ADB | 60179000 | | | 02.00 | 106 |
| COMPASS | ADB | 60177800 | | | 02.00 | 100 |
| DEPEND SYS | ADB | 60179500 | | | 01.00 | 28 |
| FORTRAN | REF MANUAL | 60177200 | | 22 | 03.25 | 100 |
| 6000 SERIES OR CYBER 70 MODELS 72,73,74 | | | | | | |
| ***** | | | | | | |
| * KRONOS V2.1 * | | | | | | |
| ***** | | | | | | |
| KRONOS | | | | | | |
| | EXPORT/IMPORT REF MAN | 59150500 | D | 22 | 01.00 | 32 |
| | GTM | 60407100 | A | 22 | 01.00 | 20 |

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched in manual for use with hard cover ringed binder.

4. Price per manual.
5. Manual page count.

| TITLE | | 1 | 2 | 3 | 4 | 5 |
|-----------------------|--|----------|---|----|-------|-----|
| | IHB | 60407500 | K | 22 | 09.40 | 531 |
| | INSTANT | 60407200 | A | | 01.35 | 208 |
| | OPERATORS GUIDE | 60407700 | D | 22 | 05.00 | 216 |
| | REF MAN VOL.1 (FOR APPLICATION ANALYST) | 60407000 | D | 22 | 10.75 | 618 |
| | REF MAN VOL.2 (FOR SYSTEM ANALYST) | 60448200 | D | 22 | | |
| | TERMINAL USER INSTANT | 60407800 | A | | 01.35 | 50 |
| | TEXT EDITOR REF MAN | 60408200 | B | 22 | 01.50 | 70 |
| | T-S USERS REF MAN | 60407600 | C | 22 | 03.00 | 148 |
| ALGOL | INSTANT V3 | 60192500 | A | | 01.35 | 28 |
| | REF MAN V3 | 60329000 | D | 22 | 05.00 | 240 |
| | REF MAN V4 | 60384700 | A | 22 | 05.00 | 246 |
| APEX III | REF MANUAL | 76070000 | | 22 | 03.50 | 244 |
| APL* CYBER | REF MANUAL | 19980400 | C | 22 | 04.50 | 204 |
| BASIC | REF MANUAL | 19980300 | B | 22 | 04.50 | 232 |
| COBOL | GTM V4 | 60327800 | A | 22 | 01.00 | 52 |
| | INSTANT V4 | 60328400 | B | | 01.35 | 50 |
| | REF MAN V4 | 60384100 | E | 22 | 06.00 | 598 |
| COMMON UTILITIES | REF MANUAL | 60493300 | A | 3 | 01.00 | 32 |
| COMPASS | GTM V3 | 60343400 | A | 22 | 01.00 | 52 |
| | INSTANT V3 | 60361000 | B | | 01.35 | 104 |
| | INSTR CARD V3 | 60361700 | B | | 00.50 | 2 |
| | REF MAN V3 | 60360900 | E | 22 | 06.75 | 356 |
| CYBERLINK INTERCHANGE | | | | | | |
| | REF MAN V1 | 60373300 | B | 22 | 01.50 | 82 |
| | OPERATORS GUIDE | 60408400 | B | 22 | 01.00 | 58 |
| EXPORT/IMPORT | REF MANUAL | 59150500 | D | 22 | 01.00 | 32 |
| FORTPAN | INSTANT V2.3 | 60189500 | E | | 01.35 | 32 |
| | REF MAN V2.3 | 60174900 | F | 22 | 04.50 | 218 |
| FORTPAN EXT | GTM V4 | 60327900 | A | 22 | 01.00 | 46 |
| | INSTANT V4 | 60357900 | B | | 01.35 | 56 |
| | REF MAN V4 | 60305600 | G | 22 | 09.00 | 508 |
| | DEBUG GUIDE V4 | 60329400 | B | 22 | 02.00 | 106 |
| | COMMON LIBRARY MANUAL | 60387900 | B | 22 | 03.50 | 166 |
| GPSS V/6000 | GTM | 84003900 | A | 3 | 01.00 | 94 |
| IGS | LGGT V1 GIM | 17322700 | B | 22 | 01.20 | 28 |
| | LGGT V1 REF | 17322800 | B | 22 | 03.00 | 40 |
| LOADER | INSTANT | 60372200 | B | | 01.35 | 56 |
| | REF MANUAL | 60344200 | G | 22 | 04.50 | 214 |
| MODIFY | INSTANT | 60283000 | B | | 01.35 | 42 |
| | REF MANUAL | 60281700 | D | 22 | 01.50 | 78 |
| ON-LINE MAINT | REFERENCE MANUAL | 60436600 | A | 22 | 02.50 | 116 |
| PERT/TIME | REF MAN V1.2 | 60133600 | D | 22 | 01.50 | 76 |
| RECORD MANAGER | CYBER MULTIPLE INDEX PROCESSOR (PSB) | 60492900 | B | 22 | 01.00 | 52 |
| | REF MANUAL | 60307300 | G | 22 | 05.00 | 254 |
| SIMSRIPT | GTM V3 | 60173500 | A | 22 | 01.00 | 24 |
| | REF MAN V3 | 60358500 | E | 22 | 04.00 | 198 |
| STIMULA | GTM V1 | 60251900 | A | 22 | 01.00 | 30 |
| | REF MAN V1 | 60234800 | F | 22 | 05.00 | 242 |
| SORT/MERGE | GTM V4 | 60342400 | A | 22 | 01.00 | 18 |
| | INSTANT V4 | 60344400 | B | | 01.35 | 60 |

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4. Price per manual.
5. Manual page count.

| TITLE | | 1 | 2 | 3 | 4 | 5 |
|---|-----------------------|----------|----|----|-------|-----|
| | REF MANUAL | 60343900 | G | 22 | 03.00 | 146 |
| SYMPL | REF MANUAL | 60328800 | C | 22 | 03.00 | 172 |
| TOTAL | REF MANUAL | 76070300 | | 3 | 03.50 | 180 |
| TRANSACTION SUBSYSTEM | | | | | | |
| | OPERATORS GUIDE | 60408000 | B | 22 | 01.00 | 36 |
| | REF MANUAL | 60407900 | B | 22 | 04.00 | 200 |
| | TRANEX USERS GUIDE | 60436500 | A | 22 | | 24 |
| T-S FORTRAN | REF MANUAL | 60408600 | B | 22 | 03.00 | 144 |
| UPDATE | INSTANT | 60360200 | A | 22 | 01.35 | 44 |
| | REF MANUAL | 60342500 | E | 22 | 02.00 | 102 |
| 8-BIT SUBROUTINE | REF MANUAL | 60359400 | C | 22 | 03.00 | 158 |
| 6000 SERIES OR CYBER 70 MODELS 72,73,74 | | | | | | |
| ***** | | | | | | |
| * KRONOS V2.0 * | | | | | | |
| ***** | | | | | | |
| KRONOS | | | | | | |
| | EXPORT/IMPORT REF MAN | 59150500 | D | | 01.00 | 32 |
| | GIM | 59156600 | 01 | | 01.00 | 36 |
| | INSTANT | 59152100 | 01 | | 01.35 | 12 |
| | OPERATORS GUIDE | 59151600 | A | | 03.50 | 186 |
| | REF MANUAL | 59150600 | C | | 09.40 | 514 |
| | TERMINAL USER INSTANT | 59152000 | B | | 01.35 | 24 |
| | TEXT EDITOR REF MAN | 59150700 | B | | 01.00 | 30 |
| | T-S USERS REF MAN | 59151300 | B | | 02.00 | 94 |
| ALGOL | INSTANT V2 | 60192500 | A | | 01.35 | 28 |
| APT | GIM V2.2 | 60172100 | | | 01.00 | 20 |
| | REF MAN V2.2 | 60174500 | C | | 05.50 | 270 |
| COBOL | REF MAN V3 | 60253000 | F | | 07.50 | 402 |
| | INSTANT V3 | 60327600 | A | | 01.35 | 44 |
| COMPASS | REF MAN V2 | 60279900 | D | 22 | 06.75 | 354 |
| | INSTANT | 60282900 | B | | 01.35 | 96 |
| FORTRAN | REF MAN V2.3 | 60174900 | F | 22 | 04.50 | 218 |
| | INSTANT V2.3 | 60189500 | E | | 01.35 | 32 |
| FORTRAN EXT | INSTANT V3 | 60305900 | | | 01.35 | 40 |
| FORTPAN TRANSLT | REF MANUAL | 59151000 | B | 22 | 01.00 | 26 |
| MODIFY | INSTANT | 60283000 | B | | 01.35 | 42 |
| | REF MANUAL | 60281700 | D | 22 | 01.50 | 78 |
| PERT/TIME | REF MAN V1.2 | 60133600 | D | 22 | 01.50 | 76 |
| SCOPE | INDEXED SEQUENTIAL RM | 60305400 | E | 22 | 02.50 | 134 |
| SIMSCRIPT | GIM V2 | 60173500 | A | 22 | 01.00 | 24 |
| SIMULA | GIM V1 | 60251900 | A | 22 | 01.00 | 30 |
| | REF MAN V1 | 60234800 | F | 22 | 05.00 | 242 |
| SORT/MERGE | REF MAN V3 | 60252600 | D | 22 | 03.00 | 146 |
| T-S BASIC | REF MANUAL | 59150800 | C | 22 | 02.00 | 90 |
| T-S FORTRAN | REF MANUAL | 60408600 | B | 22 | 03.00 | 144 |
| 6000 SERIES OR CYBER 70 MODEL 72/73/74 | | | | | | |
| CYBER 170 MODELS 172,173,174,175 | | | | | | |
| ***** | | | | | | |

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4.Price per manual.
5. Manual page count.

| TITLE | | 1 | 2 | 3 | 4 | 5 |
|------------------|-----------------------|----------|---|----|-------|-----|
| * NOS V1.0 * | | | | | | |
| ***** | | | | | | |
| NOS | APPLICATIONS PROGRAM- | 60436000 | A | | | |
| | MFRS INSTANT | | | | | |
| | BATCH USERS GUIDE | 60436300 | A | 22 | | |
| | EXPORT/IMPORT REF | 60436200 | A | 22 | 01.00 | 36 |
| | GIM | 60435900 | A | 22 | 01.00 | 24 |
| | IHB | 60435700 | A | 22 | | |
| | OPERATORS GUIDE | 60435600 | A | 22 | | |
| | REF MAN VOL.1 (FOR | 60435400 | A | 22 | | |
| | APPLICATION ANALYST) | | | | | |
| | REF MAN VOL.2 (FOR | 60445300 | A | 22 | | |
| | SYSTEM ANALYST) | | | | | |
| | SYSTEMS PROGRAMMERS | 60449200 | A | | | |
| | INSTANT | | | | | |
| | TERMINAL USER INSTANT | 60435800 | A | | | |
| | TEXT EDITOR REF | 60436100 | A | 22 | 01.50 | 68 |
| | T-S REF | 60435500 | A | 22 | | |
| | T-S USERS GUIDE | 60436400 | A | 22 | | |
| ALGOL | REF MAN V4 | 60384700 | A | 22 | 05.00 | 246 |
| APL*CYBER | REFERENCE MANUAL | 19980400 | | | | |
| APT IV | GIM | 17313200 | C | 22 | 01.00 | 20 |
| | REF MANUAL | 17313600 | C | 22 | 05.50 | 286 |
| BASIC | REFERENCE MANUAL | 19983900 | | | | |
| COROL | GIM | 60327800 | A | 22 | 01.00 | 52 |
| | INSTANT | 60328400 | B | | 01.35 | 50 |
| | REF MAN V4 | 60384100 | E | 22 | 10.50 | 598 |
| COMMON UTILITIES | REF MANUAL | 60493300 | A | 3 | 01.00 | 32 |
| COMPASS | GIM | 60343400 | A | 22 | 01.00 | 52 |
| | INSTANT | 60361000 | B | | 01.35 | 104 |
| | INSTRUCTION CARD | 60361700 | B | | 00.50 | 2 |
| | REF MAN V3 | 60360900 | E | 22 | 06.75 | 356 |
| DOL | REF MANUAL | 60359000 | B | 22 | 03.50 | 182 |
| | USERS GUIDE | 60384300 | A | 22 | 02.00 | 110 |
| FORTRAN EXT | GIM | 60327900 | A | 22 | 01.00 | 46 |
| | GUIDE FOR USERS OF | 60385200 | A | 22 | 02.50 | 136 |
| | FORTRAN EXTENDED | | | | | |
| | INSTANT | 60357900 | B | | 01.35 | 56 |
| | REF MAN V4 | 60305600 | G | 22 | 09.00 | 508 |
| | DEBUG USER GUIDE | 60329400 | B | 22 | 02.00 | 106 |
| | COMMON LIBRARY MANUAL | 60387900 | B | 22 | 03.50 | 166 |
| GPSS V/6000 | GIM | 84003900 | A | | 01.00 | 94 |
| IGS | LOGT V1 GIM | 17322700 | A | 22 | 01.00 | 28 |
| | LOGT V1 REF | 17322800 | B | 22 | 03.00 | 40 |
| LOADER | INSTANT | 60372200 | B | | 01.35 | 56 |
| | REF MANUAL | 60344200 | G | 22 | 04.50 | 214 |
| MODIFY | INSTANT | 60283000 | B | | 01.35 | 42 |
| | REF MANUAL | 60281700 | D | 22 | 01.50 | 78 |
| ON-LINE MAINT | REFERENCE MANUAL | 60436600 | A | 22 | 02.50 | 116 |
| PEPT/TIME | GIM | 60133300 | | 22 | 01.00 | 16 |
| | REF MANUAL | 60133600 | D | 22 | 01.50 | 76 |
| QUERY UPDATE | REF MANUAL | 60307500 | D | 22 | 02.00 | 94 |

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4. Price per manual.
5. Manual page count.

| TITLE | | 1 | 2 | 3 | 4 | 5 |
|--|----------------------|----------|---|----|-------|-----|
| | REF MANUAL V2 | 60384900 | D | 22 | 06.40 | 290 |
| QU DDL | MINI USERS GUIDE | 60385500 | C | | 01.35 | 73 |
| | DATA DEFINITION | | | | | |
| | LANGUAGE FOR THE | | | | | |
| | QUERY UPDATE | | | | | |
| | SUB-SCHEMA | | | | | |
| | REFERENCE MANUAL | 60359200 | C | 22 | 02.00 | 112 |
| RECORD MANAGER | REF MANUAL | 60307300 | G | 22 | 05.00 | 254 |
| | CYBER MULTIPLE INDEX | 60492900 | B | 22 | 01.00 | 52 |
| | PROCESSOR (PSB) | | | | | |
| SIMSCRIPT | GIM | 60173500 | A | 22 | 01.00 | 24 |
| | REF MAN V3 | 60358500 | E | 22 | 04.00 | 198 |
| SIMULA | GIM | 60251900 | A | 22 | 01.00 | 30 |
| | REF MANUAL | 60234800 | F | 22 | 05.00 | 242 |
| SORT MERGE | GIM | 60342400 | A | 22 | 01.00 | 18 |
| | REF MANUAL | 60343900 | G | 22 | 03.00 | 146 |
| | INSTANT V4 | 60344400 | B | | 01.35 | 60 |
| SYMPL | REF MANUAL | 60328800 | C | 22 | 03.00 | 156 |
| TOTAL | REF MANUAL | 76070300 | | 3 | 03.50 | 180 |
| TRANSACTION SUBSYSTEM | | | | | | |
| | OPERATORS GUIDE | 60408000 | B | 22 | 01.00 | 36 |
| | REF MANUAL | 60407900 | B | 22 | 04.00 | 200 |
| | TRANEX USERS GUIDE | 60436500 | A | 22 | | 24 |
| UPDATE | INSTANT | 60360200 | A | | 01.35 | 44 |
| | REF MANUAL | 60342500 | E | 22 | 02.00 | 102 |
| 8-BIT SUBROUTINE | REF MANUAL | 60359400 | C | 22 | 03.00 | 158 |
| 3001L TO CYBER | CONVERSION AIDS | | | | | |
| 70 | SYSTEM 1.2 FORTRAN | 19980600 | C | 22 | 03.00 | 140 |
| | SYSTEM 1.2 COBOL | 19980700 | B | 22 | 05.50 | 264 |
| | SYSTEM 1.2 LANGUAGE | 19980900 | B | 22 | 03.50 | 178 |
| | CONVERSION USERS | | | | | |
| | GUIDE | | | | | |
| 6000 SERIES OR CYBER 70 MODEL 72,73,74 | | | | | | |
| ***** | | | | | | |
| * SCOPE V3.4 * | | | | | | |
| ***** | | | | | | |
| | SCOPE | | | | | |
| | IHR | 60307400 | V | 22 | 07.15 | 230 |
| | REF MANUAL | 60307200 | H | 22 | 09.00 | 462 |
| | OPERATORS GUIDE | 60327300 | F | 22 | 06.40 | 320 |
| | CONV AIDS PSB | 60358200 | D | 22 | 01.50 | 68 |
| | USERS GUIDE | 60358700 | A | 22 | 06.40 | 320 |
| ALGOL | REF MAN V3 | 60329000 | D | 22 | 05.00 | 240 |
| | REF MAN V4 | 60384700 | C | 22 | 05.00 | 246 |
| APEX T | REF MANUAL | 59158000 | C | 22 | 03.50 | 172 |
| APEX II | REF MANUAL | 59158100 | B | 22 | 06.40 | 318 |
| APEX III | REF MANUAL | 76070000 | | 22 | 03.50 | 244 |
| APT | GTM | 60172100 | | 22 | 01.00 | 20 |
| | INSTANT | 60193100 | | | 01.35 | 40 |
| | REF MANUAL | 60174500 | C | 22 | 05.50 | 270 |

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4.Price per manual.
5. Manual page count.

| TITLE | | 1 | 2 | 3 | 4 | 5 |
|------------------------|---|----------|---|----|-------|-----|
| APT IV | GTM | 17313200 | C | 22 | 01.00 | 20 |
| | REF MANUAL | 17313600 | C | 22 | 05.50 | 286 |
| BASIC | REF MANUAL | 19980300 | B | 22 | 04.50 | 232 |
| | REF MANUAL | 60306200 | C | 22 | 02.00 | 108 |
| CCP SUPPORT SOFTWARE 1 | REF MAN | 88988400 | A | 22 | 01.00 | 48 |
| | DIAGNOSTIC HANDBOOK | 88988700 | A | 22 | 01.00 | 30 |
| | GTM | 88988600 | A | 22 | 01.00 | 34 |
| | MACRO ASSEMBLER REF | 88988900 | A | 22 | 02.00 | 102 |
| | MICRO ASSEMBLER REF | 88988800 | A | 22 | 02.00 | 102 |
| | PASCAL COMPILER REF | 88988500 | A | 22 | 01.50 | 82 |
| | GIM | 60327800 | A | 22 | 01.00 | 52 |
| COBOL | INSTANT | 60328400 | B | | 01.35 | 50 |
| | REF MAN V4 | 60384100 | E | 22 | 06.00 | 598 |
| COMMON UTILITIES | REF MANUAL | 60493300 | A | 3 | 01.00 | 32 |
| COMPASS | GIM | 60343400 | A | 22 | 01.00 | 52 |
| | INSTANT | 60361000 | B | | 01.35 | 104 |
| | INSTRUCTION CARD | 60361700 | B | | 00.50 | 2 |
| | REF MAN V3 | 60360900 | E | 22 | 06.75 | 356 |
| DDL | REF MANUAL | 60359000 | B | 22 | 03.50 | 182 |
| | USERS GUIDE | 60384300 | A | 22 | 02.00 | 110 |
| DDS | REF MAN V3 | 17318900 | A | 22 | 01.50 | 76 |
| EXPORT/IMPORT | HS REF MAN | 60235400 | D | 22 | 02.00 | 106 |
| | 8231 REF MAN | 60189100 | A | 22 | 01.00 | 48 |
| FORM | REF MANUAL | 60307000 | F | 22 | 02.50 | 122 |
| FORTRAN | INSTANT | 60189500 | E | | 01.35 | 32 |
| | REF MAN V2.3 | 60174900 | F | 22 | 04.50 | 218 |
| FORTRAN EXT | GIM | 60327900 | A | 22 | 01.00 | 46 |
| | GUIDE FOR USERS OF FORTRAN EXTENDED | 60385200 | A | 22 | 02.50 | 136 |
| | INSTANT | 60357900 | B | | 01.35 | 56 |
| | REF MAN V4 | 60305600 | G | 22 | 09.00 | 508 |
| | DEBUG USER GUIDE | 60329400 | B | 22 | 02.00 | 106 |
| | STFT PSB | 60358400 | A | | 01.00 | 26 |
| | COMMON LIBRARY MANUAL | 60387900 | B | 22 | 03.50 | 166 |
| | 240 SERIES REF MAN | 17307300 | E | 22 | 02.50 | 122 |
| | 274 SERIES OG | 60359800 | C | 22 | 02.00 | 88 |
| | 777 VER 2.0 USERS GUIDE/TRAINING MAN | 17322500 | A | 22 | 02.00 | 100 |
| TGS | 777 VER.2 OPERATORS GUIDE | 17322600 | B | 22 | 01.00 | 40 |
| | 777 V2 QUICK DRAW PACKAGE REFERENCE | 17325100 | A | 22 | 01.00 | 48 |
| | 274 SERIES REF MAN | 60358800 | C | 22 | 03.50 | 172 |
| | LOGT V1 GIM | 17322700 | B | 22 | 01.20 | 28 |
| | LOGT V1 REF | 17322800 | B | 22 | 03.00 | 40 |
| | 777 3-D V1 REFERENCE | 17326500 | A | 22 | 02.00 | 90 |
| | CSSL III REFERENCE | 17304400 | F | 22 | 04.50 | 228 |
| | APT/IGS V1 REFERENCE | 17310100 | B | 22 | 06.75 | 354 |
| | APT/IGS V1 G.I.M. | 17317400 | B | 22 | 01.00 | 20 |
| | 777 IGS V2 REFERENCE | 17321800 | A | 22 | 05.00 | 254 |
| INTERCOM | REF MANUAL | 60307100 | E | 22 | 04.00 | 208 |
| | MUJ PSB | 60358300 | C | 22 | 01.00 | 36 |

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4.Price per manual.
5. Manual page count.

| TITLE | | 1 | 2 | 3 | 4 | 5 |
|------------------|--|----------|---|----|-------|-----|
| | INTERACTIVE COMMAND SUMMARY | 60384600 | D | | 00.50 | 2 |
| | INTERACTIVE INTERCOM GUIDE FOR USERS OF FORTRAN EXTENDED | 60359700 | B | 22 | 03.50 | 174 |
| | INTERACTIVE PROCEDURE GUIDE | 60385600 | B | | 01.35 | 15 |
| | INTERACTIVE INTERCOM GUIDE FOR USERS OF COBOL | 60385700 | C | 22 | 03.50 | 166 |
| | REMOTE BATCH COMMAND SUMMARY | 60387400 | A | | 00.50 | 2 |
| LOADER | INSTANT | 60372200 | B | | 01.35 | 72 |
| | REF MANUAL | 60344200 | G | 22 | 04.50 | 222 |
| MARS VI | REF MAN (FULL INV) | 17313000 | A | 22 | 05.00 | 262 |
| | REF MAN (PART INV) | 60385900 | A | 22 | 04.50 | 226 |
| | REF MANUAL | 17305100 | A | 22 | 03.00 | 156 |
| PERT/TIME | GIM | 60133300 | | 22 | 01.00 | 16 |
| | REF MANUAL | 60133600 | D | 22 | 01.50 | 76 |
| QUERY UPDATE | REF MANUAL | 60307500 | D | 22 | 02.00 | 94 |
| | REF MAN V2 | 60384900 | D | 22 | 06.40 | 290 |
| | MTNI USERS GUIDE | 60385500 | C | | 01.35 | 73 |
| QUIDDL | REF MANUAL | 60327200 | D | 22 | 02.00 | 92 |
| QU DDL | DATA DEFINITION LANGUAGE FOR THE QUERY UPDATE SUB-SCHEMA | | | | | |
| | REFERENCE MANUAL | 60359200 | C | 22 | 02.00 | 112 |
| RECORD MANAGER | REF MANUAL | 60307300 | G | 22 | 05.00 | 254 |
| | USERS GUIDE | 60359600 | C | 22 | 07.50 | 428 |
| | GUIDE FOR USERS OF FORTRAN EXTENDED | 60385200 | A | 22 | 02.50 | 136 |
| | GUIDE FOR COBOL USERS | 60385300 | A | 22 | 03.00 | 150 |
| | CYBER MULTIPLE INDEX PROCESSOR (PSB) | 60492900 | B | 22 | 01.00 | 52 |
| STIMSCRIPT | GIM | 60173500 | A | 22 | 01.00 | 24 |
| | REF MAN V3 | 60358500 | E | 22 | 04.00 | 198 |
| STIMULA | GIM | 60251900 | A | 22 | 01.00 | 30 |
| | REF MANUAL | 60234800 | F | 22 | 05.00 | 242 |
| SORT MERGE | GIM | 60342400 | A | 22 | 01.00 | 18 |
| | REF MANUAL | 60343900 | G | 22 | 03.00 | 146 |
| SYMPL | REF MANUAL | 60328800 | C | 22 | 03.00 | 156 |
| UPDATE | INSTANT | 60360200 | A | | 01.35 | 44 |
| | REF MANUAL | 60342500 | E | 22 | 02.00 | 102 |
| 8 BIT SUBROUTINE | REF MANUAL | 60359400 | C | 22 | 03.00 | 158 |
| 1700 MSOS | OPERATORS GUIDE | 60359800 | C | 22 | 02.00 | 88 |
| | EXPORT/IMPORT REF MANUAL | 60305700 | A | 22 | 02.00 | 90 |
| 3000L TO CYBER | CONVERSION AIDS | 19980600 | C | 22 | 03.00 | 140 |
| 70 | SYSTEM 1.0 FORTRAN CONVERSION FOR SCOPE 3.4 | | | | | |
| | CONVERSION AIDS | 19980700 | B | 22 | 05.50 | 264 |
| | SYSTEM 1.0 COBOL | | | | | |

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched in manual for use with hard cover ringed binder.

4. Price per manual.
5. Manual page count.

| TITLE | 1 | 2 | 3 | 4 | 5 | |
|---|--------------------|----------|----|-------|-------|-----|
| CONVERSION FOR SCOPE 3.4 CONVERSION AIDS SYSTEM 1.0 LANGUAGE CONVERSION USER GUIDE | 19980900 | B | 22 | 03.50 | 178 | |
| 6000 SERIES OR CYBER 70 MODEL 72,73,74 | | | | | | |
| ***** | | | | | | |
| * SCOPE V3.3 * | | | | | | |
| ***** | | | | | | |
| SCOPE | | | | | | |
| IHR | 60305100 | AC | 22 | 09.00 | 506 | |
| INDEXED SEQ REF MAN | 60305400 | E | 22 | 02.50 | 134 | |
| OPERATORS GUIDE | 60306400 | F | 22 | 03.50 | 174 | |
| OPHELIE GIM V1 | 59156800 | A | 22 | 01.00 | 48 | |
| OPHELIE REF V1 | 59156900 | C | 22 | 05.50 | 270 | |
| OPHELTE/MIXED REF V1 | 59157000 | B | 22 | 01.50 | 80 | |
| REF MANUAL | 60305200 | F | 22 | 07.15 | 376 | |
| USERS GUIDE | 60252700 | C | 22 | 06.00 | 302 | |
| ALGOL | INSTANT | 60192500 | A | 01.35 | 28 | |
| | REF MAN V3 | 60329000 | D | 22 | 05.00 | 240 |
| APT | APP DEV BULLETIN | 60193100 | | 01.00 | 40 | |
| | GIM | 60172100 | 22 | 01.00 | 20 | |
| | REF MANUAL | 60174500 | C | 22 | 05.50 | 270 |
| APT IV | REF MANUAL | 17313600 | C | 22 | 05.50 | 286 |
| BASIC | REF MANUAL | 60306200 | C | 22 | 02.00 | 108 |
| COBOL | INSTANT | 60327600 | A | 01.35 | 44 | |
| | REF MANUAL | 60253000 | E | 22 | 07.50 | 402 |
| COMPASS | GIM | 60174400 | C | 22 | 01.00 | 16 |
| | INSTANT | 60191900 | B | 01.35 | 26 | |
| | INSTANT V2 | 60282900 | B | 01.35 | 96 | |
| | REF MANUAL | 60190900 | C | 22 | 04.00 | 196 |
| | REF MAN V2 | 60279900 | D | 22 | 06.75 | 354 |
| CSSL3 | USERS GUIDE | 17304400 | F | 22 | 04.50 | 228 |
| (CONTINUOUS SYSTEM SIMULATION LANGUAGE III) | | | | | | |
| EXPORT/IMPORT | HS REF MAN | 60235400 | D | 22 | 02.00 | 106 |
| | HS OG | 17303100 | A | 22 | 01.50 | 72 |
| | 200 REF MAN | 60234600 | B | 22 | 01.50 | 86 |
| | 8231 REF MAN | 60189100 | A | 22 | 01.00 | 48 |
| FORTPAN | INSTANT | 60189500 | E | 01.35 | 32 | |
| | REF MANUAL | 60174900 | F | 22 | 04.50 | 218 |
| FORTPAN EXTENDED | INSTANT | 60305900 | A | 01.35 | 40 | |
| | REF MANUAL | 60329100 | D | 22 | 05.00 | 258 |
| | DEBUG USERS GUIDE | 60329400 | B | 22 | 02.00 | 106 |
| TGS | 240 SERIES REF MAN | 17307300 | F | 22 | 02.50 | 122 |

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched in manual for use with hard cover ringed binder.

4. Price per manual.
5. Manual page count.

| TITLE | | 1 | 2 | 3 | 4 | 5 |
|---|-----------------------|----------|----|----|-------|-----|
| (INTERACTIVE GRAPHICS SYSTEM) | 274 SERIES OG | 17303100 | A | 22 | 01.50 | 72 |
| | 274 SERIES GIM | 44616700 | A | 22 | 01.00 | 46 |
| | 274 SERIES USER GUIDE | 44629300 | E | 22 | 03.50 | 182 |
| | 274 SERIES REF MAN | 17303600 | F | 22 | 04.50 | 218 |
| INTERCOM | REF MAN V3 | 60252800 | C | 22 | 03.50 | 184 |
| JOVIAL | REF MANUAL | 17302500 | A | 22 | 06.00 | 300 |
| MARS VI | REF MAN (FULL INV) | 17313000 | A | 22 | 05.00 | 262 |
| PERT | GIM | 60133300 | | 22 | 01.00 | 16 |
| PERT/TIME | REF MANUAL | 60133600 | D | 22 | 01.50 | 76 |
| SIFT | PROGRAM SYSTEM BULL. | 60358400 | A | | 01.00 | 26 |
| SIMSCRIPT | GIM | 60173500 | A | 22 | 01.00 | 24 |
| | REF MAN V3 | 60358500 | E | 22 | 04.00 | 198 |
| SIMULA | GIM | 60251900 | A | 22 | 01.00 | 30 |
| | REF MANUAL | 60234800 | F | 22 | 05.00 | 242 |
| SORT/MERGE | REF MANUAL | 60252600 | E | 22 | 03.00 | 146 |
| UPDATE | REF MANUAL | 60342500 | E | 22 | 02.00 | 102 |
| 1700 MSOS | EXPORT/IMPORT | 60305700 | A | 22 | 02.00 | 90 |
| MISCELLANEOUS | | | | | | |
| CYBER 70 COMPUTER SERIES NUCLEAR CODES MAN | | 20085400 | | 3 | 01.20 | 73 |
| CYBER 70 COMPUTER SYSTEM MODELS 72,73,74 | | 60359800 | C | 22 | 02.00 | 88 |
| 6000/1700 COMPUTER SYSTEM 274 INTERACTIVE GRAPHICS SYSTEM OPERATORS GUIDE MODELS 72, 73,74 VERSION 2/6000 V2, MSOS IMPORT HIGH SPEED OPERATORS GUIDE 1700 VERSION 1 | | | | | | |
| 6000/CYBER 70 COMPUTER SYSTEMS INTERACTIVE INTERCOM GUIDE FOR USERS OF FORTRAN EXT. | | 60359700 | A | 22 | 03.50 | 174 |
| COROL 35 REFERENCE MANUAL | | 17308300 | A | 22 | 05.50 | 270 |
| COMMAND GENERAL INFORMATION 6000/CYBER 70 | | 97400300 | A | 22 | 01.00 | 32 |
| DATA HANDLER VERSION 1 REFERENCE MANUAL | | 17322100 | A | 22 | 01.50 | 63 |
| GRAPHICALLY ORIENTED DESIGN AND ANALYSIS SYSTEM (GODAS) V2 REFERENCE MANUAL | | 17317200 | C | 22 | 04.00 | 204 |
| GIM | | 17326600 | A | 22 | 01.00 | 40 |
| INTERACTIVE GRAPHICS REF MANUAL V1 | | 44616800 | D | 22 | 03.50 | 186 |
| INTERACTIVE GRAPHICS 274 SYSTEM USERS GUIDE | | 44629300 | D | 22 | 03.50 | 182 |
| INTERCOM INTERACTIVE PROCEDURE GUIDE | | 60385600 | B | | 01.35 | 15 |
| JOVIAL COMPILER REFERENCE MANUAL | | 17302500 | A | 22 | 06.40 | 328 |
| KRONOS WORKSHOP REFERENCE MANUAL V2.1 | | 97404700 | B | 22 | 13.65 | 810 |
| MARS V1 PART-INVERSION REF MANUAL | | 17305100 | A | | 03.00 | 156 |
| MARS V1 PART-INVERSION USERS GUIDE | | 17308100 | A | 22 | 02.50 | 134 |
| PLATO SUBSYSTEM AUTHORS GUIDE | | 97404900 | 01 | 22 | 01.50 | 56 |
| OPERATING GUIDE | | 97405200 | 01 | 22 | 03.60 | 117 |
| TUTOR REFERENCE MANUAL | | 97405100 | 01 | 22 | 04.50 | 204 |
| USERS GUIDE | | 97404800 | 01 | 22 | 01.00 | 15 |
| INSTALLATION HANDBOOK | | 97405000 | 01 | 22 | 01.00 | 22 |
| SCOPE INTEGRATED SCHEDULER TUNING GUIDE PSB (CYBER 71/6000 SERIES) | | 60493500 | A | 22 | 01.50 | 66 |
| SCOPE OPERATING SYSTEM SALES HANDBOOK V3.4.1 | | 60425300 | | 22 | 02.80 | 155 |
| SCOPE 3.2/3.3 PERM FILE PRESERVATION BULL. | | 60327000 | A | | 01.00 | 26 |
| SORT TIMING PROGRAM | | 60083700 | | | 01.00 | 19 |
| TRAFFIC GENERAL INFORMATION MANUAL | | 97405500 | B | 22 | 01.50 | 120 |

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched in manual for use with hard cover ringed binder.

4. Price per manual.
5. Manual page count.

| TITLE | 1 | 2 | 3 | 4 | 5 |
|---|----------|----|----|-------|-----|
| 6000/CYBER 70 COMMAND BILL OF MATERIAL REFERENCE MANUAL | 59159700 | B | 22 | 02.50 | 114 |
| 6000/CYBER 70 COMPUTER SYSTEM MULTI-ACCESS RETRIEVAL SYSTEM MARS VT FOR FULL INVERSION REFERENCE MANUAL VERSION 2.1 | 17313000 | A | 22 | 05.00 | 262 |
| 6000/CYBER 70 INTERCOM MULTI-USER JOB CAPABILITY PROGRAMMING SYSTEM BULLETIN FOR TIME-CRITICAL APPLICATIONS GIM | 60358300 | C | 22 | 01.00 | 36 |
| 6000/CYBER 70 SERIES HIGH-PERFORMANCE SYSTEM | 17309700 | A | 22 | 02.50 | 116 |
| 6000/CYBER 70 SERIES TIME-CRITICAL SIMULA- TION SYSTEMS GIM MODELS 72/73/74 V3-6000 V4 | 44629200 | C | 22 | 02.00 | 98 |
| 6000 INTERCOM MULTIUSER JOB CAPABILITY PSB VERSION 3 | 60327400 | D | 22 | 01.00 | 34 |
| 6000/240 SERIES INTERACTIVE GRAPHICS SYSTEM REFERENCE MANUAL | 17307300 | F | 22 | 02.50 | 122 |
| 6000 KWIC APPLICATIONS DEV. BULLETIN | 60137700 | | | 02.65 | 28 |
| 6000 MIMTC SIMULATION LANGUAGE REFERENCE | 44610400 | E | 22 | 05.75 | 152 |
| 6000 SCOPE OPERATING SYSTEM TIME CRITICAL MODULE REF V2 (SCOPE 3.3 TC) | 17304200 | A | 22 | 01.00 | 42 |
| 6000 SEISMIC DATA PROC. SYSTEM REF MANUAL | 60342700 | | 22 | 01.50 | 66 |
| 6000 SEISMIC DATA PROC. SYSTEM IHB | 60343000 | A | 22 | 01.00 | 30 |
| 64/6500 ASSIST USERS GUIDE | 60345100 | 03 | 22 | 02.50 | 132 |
| 64/65/6600 TTY RESPOND REF MAN | 60199300 | B | 22 | 02.00 | 112 |
| 64/65/6600 TTY RESPOND INSTANT | 60191500 | | | 01.35 | 28 |
| 7600 | | | | | |
| ***** | | | | | |
| * SCOPE V1.1 * | | | | | |
| ***** | | | | | |
| SCOPE | | | | | |
| GIM | 60280000 | A | 22 | 01.00 | 62 |
| IHR | 60282500 | A | 22 | 05.50 | 286 |
| INSTANT | 60343100 | A | | 01.35 | 128 |
| REF MANUAL | 60281200 | B | 22 | 05.00 | 254 |
| COMPASS REF MAN V2 | 60279900 | D | 22 | 06.75 | 354 |
| GIM V2 | 60279600 | A | 22 | 01.00 | 40 |
| OPU CARD V2 | 60279700 | B | | 00.50 | 2 |
| PPU CARD V2 | 60279800 | B | | 00.50 | 2 |
| INSTANT V2 | 60282900 | B | | 01.35 | 96 |
| FORTRAN EXT REF MANUAL | 60329100 | D | 22 | 05.00 | 258 |
| FOPTRAN RUN REF MANUAL | 60280400 | A | 22 | 03.50 | 172 |
| GIM | 60279500 | | 22 | 01.00 | 36 |
| MODIFY REF MANUAL | 60281700 | D | 22 | 01.50 | 78 |
| INSTANT | 60283000 | B | | 01.35 | 42 |
| MOX REF MANUAL | 60237400 | A | 22 | 01.00 | 56 |
| SOM/MCM OPERATORS GUIDE/REF | 60372900 | A | 22 | 01.50 | 72 |
| UPDATE INSTANT | 60360200 | A | | 01.35 | 44 |
| REF MANUAL | 60342500 | E | 22 | 02.00 | 102 |
| ***** | | | | | |
| * SCOPE V1.1 STATIONS * | | | | | |
| ***** | | | | | |
| 7611-1 I/O STN OG/REF | 60281600 | A | 22 | 02.50 | 134 |
| 7611-1 I/O STN INSTNT | 60283100 | | | 01.35 | 38 |

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4. Price per manual.
5. Manual page count.

| TITLE | 1 | 2 | 3 | 4 | 5 |
|-----------------------------|----------|---|----|-------|-----|
| CYBER 70/MODEL 76 OR 7600 | | | | | |
| ***** | | | | | |
| * SCOPE V2.1 * | | | | | |
| ***** | | | | | |
| SCOPE | | | | | |
| REF MANUAL | 60342600 | H | 22 | 06.40 | 322 |
| USERS GUIDE | 60372600 | C | 22 | 07.15 | 366 |
| DIAGNOSTIC HNOBK | 60344100 | E | 22 | 02.00 | 106 |
| GIM | 60342200 | B | 22 | 11.00 | 36 |
| IHR V2.0 | 60344000 | C | 22 | 07.90 | 424 |
| IHR V2.1 | 60426100 | C | 22 | 09.40 | 518 |
| INSTANT | 60344300 | B | 6 | 01.35 | 108 |
| ALGOL REF MANUAL | 60384700 | C | 22 | 05.00 | 246 |
| APEX I REF MANUAL | 59158000 | C | 22 | 03.50 | 172 |
| APEX II REF MANUAL | 59158100 | B | 22 | 06.40 | 318 |
| GIM | 59157900 | A | 22 | 01.00 | 26 |
| APEX III REF MANUAL | 76070000 | | 22 | 03.50 | 244 |
| APT IV REF MANUAL | 17313600 | C | 22 | 05.50 | 286 |
| COBOL REF MAN V2 | 60384200 | B | 22 | 09.40 | 522 |
| GIM | 60327800 | A | 22 | 01.00 | 52 |
| INSTANT | 60328400 | B | | 01.35 | 50 |
| COMMON UTILITIES REF MANUAL | 60493300 | A | 3 | 01.00 | 32 |
| COMPASS REF MAN V2 | 60279900 | D | 22 | 16.75 | 354 |
| GIM V2 | 60279600 | A | 22 | 01.00 | 40 |
| CPU CARD V2 | 60279700 | B | | 00.50 | 2 |
| PPU CARD V2 | 60279800 | B | | 00.50 | 2 |
| INSTANT V2 | 60282900 | B | | 01.35 | 96 |
| REF MAN V3 | 60360900 | E | 22 | 06.75 | 356 |
| GIM V3 | 60343400 | A | 22 | 01.00 | 52 |
| INST CARD | 60361700 | B | | 00.50 | 2 |
| INSTANT V3 | 60361000 | B | | 01.35 | 104 |
| FORTRAN EXT REF MAN V4.1 | 60305600 | G | 22 | 09.00 | 508 |
| GIM | 60327900 | A | 22 | 01.00 | 46 |
| INSTANT | 60357900 | B | | 01.35 | 56 |
| DEBUG USERS GUIDE | 60329400 | B | 22 | 02.00 | 106 |
| COMMON LIBRARY MANUAL | 60387900 | A | 22 | 03.00 | 166 |
| FORTRAN RUN REF MAN V2 | 60360700 | C | 22 | 04.00 | 210 |
| LOADER REF MANUAL | 60344200 | G | 22 | 04.50 | 222 |
| INSTANT | 60372200 | B | | 01.35 | 22 |
| ON-LINE MAINT. | | | | | |
| REF MANUAL | 60406200 | D | 22 | 01.50 | 70 |
| RECORD MANAGER REF MANUAL | 60307300 | G | 22 | 05.00 | 254 |
| SIMSRIPT 1.5 REF MAN V3 | 97400200 | | 22 | 04.50 | 214 |
| SAM OPERATORS GUIDE V2 | 60361400 | A | 22 | 01.50 | 80 |
| OPERATORS GUIDE V3 | 60373800 | C | 22 | 02.00 | 94 |
| SORT/MERGE REF MANUAL | 60343900 | G | 22 | 03.00 | 146 |
| GIM | 60342400 | A | 22 | 01.00 | 18 |
| INSTANT | 60344400 | B | | 01.35 | 60 |
| SYMPOL REF MANUAL | 60328800 | C | 22 | 03.00 | 156 |
| UPDATE REF MANUAL | 60342500 | E | 22 | 02.00 | 102 |
| INSTANT | 60360200 | A | | 01.35 | 44 |
| ***** | | | | | |

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4.Price per manual.
5. Manual page count.

| TITLE | 1 | 2 | 3 | 4 | 5 |
|--|----------|---|----|-------|-----|
| * SCOPE V2 STATIONS * | | | | | |
| * AND SUBSYSTEMS * | | | | | |
| ***** | | | | | |
| 6000 STN 3.3 OG/REF MAN | 60360400 | A | 22 | 03.50 | 164 |
| 6000 STN 3.4 OG/REF MAN | 60343800 | D | 22 | 02.50 | 122 |
| GTM | 60342100 | A | 22 | 01.00 | 20 |
| INSTANT | 60360500 | A | | 01.35 | 64 |
| 7611-1 I/O STN OG/REF MAN | 60343600 | C | 22 | 03.00 | 156 |
| GTM | 60343300 | A | 22 | 01.00 | 24 |
| INSTANT | 60360100 | A | | 01.35 | 41 |
| 7611-2 MAG TAPE STATION | | | | | |
| OG/REF MAN | 60343700 | B | 22 | 01.50 | 76 |
| GTM | 60342300 | | 22 | 01.00 | 20 |
| MAG TAPE SUBSYSTEM | | | | | |
| REF MANUAL | 60403900 | C | 22 | 02.50 | 114 |
| MISCELLANEOUS | | | | | |
| 6000/CYBER 70 COMMAND REFERENCE MANUAL | 59159800 | A | 22 | 04.00 | 202 |
| FORTPAN COMMON LIBRARY MATHEMATICAL ROUTINES | 60387900 | A | 22 | | 140 |
| 8090 | | | | | |
| OSAS-A REF MANUAL | 60130900 | | | 01.00 | 52 |
| OSAS-ASSEMBLY SYSTEM | 60058200 | | | 01.00 | 46 |
| SIMULTANEOUS PERIPH PROCESS REF | 60059900 | | | 01.00 | 32 |
| 915 GRASP OCR REF MANUAL V2.0 | 48996600 | | | 03.65 | 75 |
| 8092 | | | | | |
| NIMP IHR V2.1 | 87976700 | A | | 06.05 | 54 |
| REF MANUAL V2.1 | 48706201 | B | 3 | 05.50 | 91 |
| TAS IHR V3.0 | 87976800 | A | 22 | 05.75 | 54 |
| REF MANUAL V3.1 | 48704601 | C | 3 | 04.50 | 33 |
| UTILITY ROUTINE REF MAN V1.0 | 48704901 | A | 3 | 03.55 | 56 |
| 915 GRASP IHR V3.0 | 91661300 | A | | 03.25 | 42 |
| REF MAN V2.0 | 48704800 | E | 3 | 02.25 | 32 |
| 915 H/S GRASP PROGRAMMERS REF V1.0 | 48707800 | B | 3 | 05.00 | 70 |
| 915 KEYPUNCH REF MAN V2.1 | 48707900 | E | 3 | 01.70 | 18 |
| SIMULATOR | | | | | |
| 915 LIST PROC. REF MAN V1.0 | 48706101 | C | 3 | 04.50 | 75 |
| 921 DRIVE IHR VER 3.1 | 87976600 | A | | 10.50 | 28 |
| REF MAN V3.1 | 48881400 | D | 3 | 05.25 | 36 |
| 921 MONITOR REF MAN V1.0 | 91681100 | A | 22 | 03.45 | 46 |
| IHR | 91649500 | A | | 14.85 | 42 |

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched in manual for use with hard cover ringed binder.

4. Price per manual.
5. Manual page count.

SECTION 4

| TITLE | 1 | 2 | 3 | 4 | 5 |
|--|----------|---|----|-------|---|
| MISCELLANEOUS MANUALS | | | | | |
| A LIBRARY OF NUCLEAR CODES | 60139500 | | | 01.25 | |
| A STUDY OF METHODS OF ERROR DETECTION DURING TRANSMISSION OF BINARY INFORMATION | 60426500 | A | 22 | 01.65 | |
| AIDS - AUTOMATED INTEGRATED DESIGN SYSTEM GENERAL INFORMATION MANUAL | 60427900 | | | 06.20 | |
| AIDS - GENERAL PURPOSE WIRE WRAP USERS GUIDE | 60443100 | A | 22 | 06.85 | |
| AIDS - SEMIAUTOMATIC ARTWORK GENERATION USERS GUIDE | 60441000 | A | 22 | 03.50 | |
| ALPHA REFERENCE MANUAL | 14142900 | A | 22 | 01.80 | |
| ALPHA 1 COMPUTER SYSTEM - CPU DIAGRAMS MANUAL VOL. IT | 14143700 | A | 34 | 35.00 | |
| ALPHA 1 COMPUTER SYSTEM GROUND SUPPORT EQUIP. DIAGRAMS MAN. VOL. 2 | 14143800 | A | 34 | 26.20 | |
| ALPHA-1 MIMIC SOFTWARE MANUAL | 14155000 | | | 01.20 | |
| ALPHA-1 SOFTWARE REFERENCE MAN-ALPHA COMPASS | 14123800 | A | | 08.50 | |
| A METHOD OF GENERATING UNIFORM RANDOM NUMBERS (AN APP. REPORT BY W.J.WESTLAKE) | 60161200 | | | 01.25 | |
| CARE AND HANDLING OF MAGNETIC TAPE | 40812300 | | | 01.00 | |
| CD CARRIER TRUCKING - ORIENTED TRANSPORTATION APPLICATIONS SOFTWARE GENERAL INFO | 97401600 | A | 22 | 01.40 | |
| CE ILLUSTRATED TOOL CATALOG | 40860000 | C | 22 | | |
| COMMAND SYSTEMS INFORMATION MANUAL | 97401500 | | | 06.15 | |
| COMMUNICATIONS HANDBOOK | 60405100 | A | 22 | 01.70 | |
| COMMUNICATIONS SYSTEMS DIVISION TERMINAL UNIT AND DATA SET CE TECH INFO MANUAL | 41605200 | B | 22 | 03.10 | |
| COMPUTER AIDED MAINTENANCE SCHEDULER (CAMS VERSTON 2) | | | | | |
| CE MANUAL | 60373500 | C | 22 | 02.00 | |
| CORPORATE PHOTOGRAPHY CATALOG | 20114600 | | 22 | | |
| CYBER 1000 DATA COMMUNICATIONS SYSTEM MANUAL | 00007500 | A | | 01.95 | |
| CYBER 1000 DCS GENERAL PROPOSAL TO AIRLINE INDUSTRY | 73443000 | A | | 02.35 | |
| CYBER 1000 DCS GENERAL PROPOSAL TO BANKING INDUSTRY | 73443100 | A | | 02.10 | |
| CYBER 1000 DCS GENERAL PROPOSAL TO MANUFACTURING | 73933300 | A | | 02.35 | |
| CYBERDATA KEY-TO-DISK OPERATORS INSTANT | 22261900 | A | | 08.40 | |
| SUPERVISORS INSTANT REFERENCE MANUAL | 22262100 | A | | 11.14 | |
| 22262200 | | | | | |
| 970-8 REFERENCE MANUAL | 22267300 | A | 3 | 01.20 | |
| 970-8 CE MANUAL | 22264500 | A | 3 | 04.40 | |
| 970-32 REFERENCE MANUAL | 22267200 | A | 3 | 02.10 | |
| 970-32 CE MANUAL | 22264600 | A | 3 | 03.00 | |
| 970-480 CE MANUAL | 22264700 | A | 3 | 04.30 | |
| 970-480 REFERENCE MANUAL | 22267100 | | | | |
| INSTALLATION KIT | 22263600 | | | | |

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched in manual for use with hard cover ringed binder.

4.Price per manual.
5. Manual page count.

| TITLE | 1 | 2 | 3 | 4 | 5 |
|--|----------|---|----|-------|---|
| DIAGNOSTIC CONFIGURATOR/CATALOG | 00015000 | | 3 | | |
| DIAGNOSTIC CONFIGURATOR CATALOG | 60408100 | B | 22 | 01.80 | |
| DISK STORAGE UNIT MAINTENANCE AIDS MANUAL | 70616800 | M | 22 | 07.45 | |
| DISK STORAGE UNIT 84-X,975-X MAINT AIDS CE | 70619100 | J | 22 | 19.45 | |
| DISK STORAGE UNIT 84X,975X-ENHANCED LOGIC CARDS CE MANUAL | 70629100 | G | 22 | 12.70 | |
| DTL INTEBRID LOGIC GENERAL INFO MANUAL | 84785000 | | 3 | 04.50 | |
| ENGINEERING LOG BOOK | 60272100 | | | 05.85 | |
| EXTENDED COPE STORAGE DATA PATH AND STOCK SELECT MAINTENANCE AID CHART | 59304600 | | | | |
| FORMS DESIGN MANUAL | 00000200 | | | 02.40 | |
| FIELD BULLETIN, POWER RECEPTACLE INSTALL | 40816200 | | 22 | 02.00 | |
| HARDWARE DEVELOPMENT GUIDELINES INFORMATION | 60429200 | A | 3 | 03.00 | |
| HOW TO HANDPRINT FOR CONTROL DATA OCR READER | 48299727 | | | 02.25 | |
| KEY TO LOGIC SYMBOLS G.I.M. | 88981500 | B | 22 | 05.40 | |
| KEY TO LOGIC SYMBOLS - SYSTEM 17 | 89723700 | - | 22 | 04.90 | |
| KEY TO LOGIC SYMBOLS - TTL | 60406000 | A | 22 | 01.80 | |
| MAGNETIC TAPE TRANSPORT SINGLE CAPSTON HIGH PERFORMANCE OPERATORS MANUAL | 49751600 | A | 22 | 01.75 | |
| MANAGEMENT GUIDE TO EFFECTIVE SELECTION PROCESS | 60426700 | | | 01.35 | |
| MATH SCIENCE LIBRARY GENERAL INFORMATION MAN | 60328900 | A | | 01.00 | |
| MERCHANT USERS MANUAL | 13797500 | | | 02.15 | |
| MILITARY DISK STORAGE UNIT DESC., THEO OF OPER., DIAGRAMS AND WIRE LIST CE MANUAL | 14237500 | | 22 | 20.40 | |
| PARTS SUPPORT FOR THE OEM CUSTOMER | 15002900 | | | 00.80 | |
| PLANIT AUTHORS GUIDE | 59159400 | | 3 | 08.30 | |
| PLANIT LANGUAGE REFERENCE MANUAL | 97401700 | | | 13.30 | |
| POSTAL SOURCE DATA COLLECTION SYSTEM INSTALLATION MANUAL | 36829400 | C | 22 | 02.55 | |
| POSTAL SOURCE DATA COLLECTION SYSTEM DATA COLLECTION SITE REFERENCE MANUAL | 13795600 | A | 22 | 01.80 | |
| POSTAL SOURCE DATA COLLECTION SYSTEM TELECONCENTRATOR SITE REFERENCE MANUAL | 13795700 | A | 22 | 01.00 | |
| POSTAL SOURCE DATA COLLECTION SYSTEM DATA PROCESSING CENTER SITE REF MANUAL | 13795500 | A | 22 | 02.00 | |
| POSTAL SOURCE DATA SYSTEM REF MANUAL | 13795400 | C | 22 | 01.00 | |
| PRODUCT TO EQUIPMENT CROSS REFERENCE MANUAL | 60071500 | R | 3 | 05.70 | |
| PROFITS REFERENCE MANUAL | 59158200 | B | 22 | 16.25 | |
| PROFITS OPERATORS GUIDE 3000 PROFITS CRT | 59158300 | A | 22 | 02.70 | |
| PROFITS AN ON-LINE REAL-TIME ENG/MANUF. SYS | 59156000 | | | 03.90 | |
| PROGRAM MANAGEMENT HANDBOOK | 60408300 | | | 20.90 | |
| PROGRAMMING REFERENCE AIDS (CONTAINS CONVERSION TABLES, CONSTANTS, POWERS AND HEXADECIMAL INFORMATION) | 60158600 | | | 04.00 | |
| REVOLUTION IN PROGRAMMING | 60417000 | | | 02.80 | |
| SCOPE 3.1.5 | 00006300 | | 3 | 04.85 | |
| SOFTWARE DEVELOPMENT GUIDELINES | 60418500 | | | 02.60 | |
| QUALITY ASSURANCE MANUAL | 60348600 | | | 14.55 | |
| SEISMIC DATA PROCESSING SYSTEM REF. MANUAL | 44623700 | B | 22 | 11.80 | |
| TIME SLOTTED REQUIREMENTS APPLICATION REPORT | 97403600 | | | 01.60 | |
| TYPIING FOR CONTROL DATA OCR PAGE READERS | 48299700 | | | 04.05 | |

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4. Price per manual.
5. Manual page count.

| TITLE | 1 | 2 | 3 | 4 | 5 |
|---|----------|---|----|-------|---|
| EDUCATIONAL MANUALS | | | | | |
| AN INTRODUCTION TO BASIC COMPUTER CONCEPTS | 44016000 | | | 03.70 | |
| AN INTRODUCTION TO INTEGRATED CIRCUITS | 60202000 | | | 02.55 | |
| BIOLOGY-PHYSIOLOGY APPLIED TO DIGITAL COMPUTERS | 22006700 | | | 01.25 | |
| FORTRAN AUTOTESTER JOHN WILFY AND SONS, INC., NEW YORK) | 60018600 | | | 04.75 | |
| FORTRAN TRAINER STUDENT WORKBOOK (BY BRUCE THOMPSON) | 44020500 | | | 05.15 | |
| FORTRAN TRAINER PART 1 TEACHERS EDITION BY THOMPSON) | 44020300 | | | 05.85 | |
| FUNCTIONS, FUNCTION MACHINES AND COMPUTERS BY ROBERT L. ALBRECHT | 44016800 | | | 01.50 | |
| FUNDAMENTAL COMPUTER CONCEPTS BY DR. ROBERT E. SMITH | 22008200 | | | 02.00 | |
| INTRODUCTION TO DATA COMMUNICATIONS (BASIC SYSTEMS AND HARDWARE) | 13798900 | C | 22 | 05.95 | |
| MATHEMATICS OF CHEMISTRY AS APPLIED TO DIGITAL COMPUTERS | 22006500 | | | 01.60 | |
| SECONDARY LEVEL PHYSICS AS APPLIED TO DIGITAL COMPUTERS | 22006600 | | | 01.25 | |
| STATISTICS APPLIED TO DIGITAL COMPUTERS | 22006900 | | | 01.00 | |
| TRAINING MANUALS | | | | | |
| 160-A TRAINING WORKBOOK (FORMERLY 082666) | 60273400 | | | 07.50 | |
| 160-A FORTRAN TRAINING MANUAL | 60165000 | | | 04.50 | |
| 360 ASSEMBLY LANGUAGE TRAINING MANUAL | 60354600 | B | 3 | 03.70 | |
| 546 SUPPLEMENTAL MANUAL (FORMERLY A-095102) | 60238400 | | | 01.40 | |
| 915 PAGE READER-A PROGRAMMED TEXT VOL. I (FORMERLY 020568) | 60241000 | A | | 01.00 | |
| 1500 SERIES SYSTEM CODES | 76360010 | | | 01.90 | |
| 1604 TYPE CARDS | 60314100 | | | 00.75 | |
| 1604 PRINTED CIRCUITS (FORMERLY 010367) | 60240600 | | | 01.40 | |
| 1700 COMPUTER MAINTENANCE TRAINING MANUAL, VOL I, 2ND EDITION | 60169500 | B | | 03.40 | |
| 1700 COMPUTER MAINTENANCE TRAINING MANUAL, VOL II, 2ND EDITION | 60169600 | A | | 05.85 | |
| 1700 COMPUTER MAINTENANCE TRAINING MANUAL, VOL III | 60184900 | | | 01.75 | |
| 1700 PRINTED CIRCUITS MANUAL | 083066A0 | | | 12.00 | |
| 1700 PROGRAMMING TRAINING MANUAL | 60207900 | B | | 07.85 | |
| 1728 CARD READER/PUNCH TRAINING MANUAL (FIRST EDITION) | 60241400 | | | 01.55 | |
| 1738 DISK CONTROLLER TRAINING MANUAL (FORMERLY 010268A) | 60257900 | | | 02.55 | |
| 2013 BADGE READER ADAPTED TRAINING MANUAL, TEST EDITION (FORMERLY 041467) | 60240400 | | | 01.00 | |
| 3000 HARDWARE STUDENT MANUAL | 60380500 | | 3 | 11.85 | |
| 3000 PRINTED CIRCUITS (FORMERLY 092166) | 60238500 | | | 02.25 | |
| 3000 TYPE CARDS | 60314200 | | | 01.00 | |
| 3000 SOFTWARE STUDENT MANUAL | 60380400 | A | 3 | 01.80 | |

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched in manual for use with hard cover ringed binder.

4. Price per manual.
5. Manual page count.

| TITLE | 1 | 2 | 3 | 4 | 5 |
|---|----------|---|----|-------|---|
| 31/32/33/3500 COMPUTER SYSTEM COBOL TRAINING | 60314900 | C | | 05.15 | |
| 31/32/33/3500 FORTRAN TRAINING MANUAL | 60199700 | A | | 06.75 | |
| 3100/3200 TRAINING HANDOUTS (FORMERLY 042767) | 60258100 | | | 03.90 | |
| 3100/3200/3300/3500 COMPASS PROGRAMMING TRAINING MANUAL VOLS 1 AND 2 | 60311500 | A | | 05.40 | |
| 3200 TRAINING MANUAL, VOL I, 2ND EDITION, (FORMERLY 020968) | 60257700 | | | 03.60 | |
| 3200 TRAINING MANUAL VOL 2, 2ND EDITION (FORMERLY 021068) | 60257800 | | | 07.35 | |
| 3200/3300 DIFFERENCE COURSE WORKBOOK | 01306700 | | | 02.20 | |
| 3203/3209 STORAGE MODULE TRAINING MANUAL | 60143400 | | 22 | 03.50 | |
| 3229 MAG TAPE CONTROLLER TRAINING MANUAL, FIRST EDITION (FORMERLY 021268) | 60239200 | A | | 03.00 | |
| 3234-A MASS STORAGE CONTROLLER TRAINING SUPPLEMENT | 60249400 | | | 01.05 | |
| 3300 COMPUTER TRAINING MANUAL VOL 1 | 60158700 | A | | 02.70 | |
| 3300 TRAINING MANUAL, VOL II, 2ND EDITION | 60158800 | | | 07.50 | |
| 3312 BUSINESS DATA PROCESSING TRAINING MAN., VOL I, 2ND EDITION (FORMERLY 091566B) | 60249900 | | | 02.65 | |
| 3312 BDP TRAINING MANUAL VOL II, 2ND EDITION (FORMERLY 020568) | 60250000 | | | 13.40 | |
| 3400/3600/3800 COMPASS TRAINING MANUAL, VOLS I, II, III | 60166700 | B | | 15.65 | |
| 3447-A CARD READER CONTROLLER TRAINING MAN. | 60273500 | | | 03.40 | |
| 3500 BLOCK CONTROL HANDBOOK | 60274300 | | | 01.05 | |
| 3600 COMPUTER MAINTENANCE WORKBOOK | 04266700 | | | 10.50 | |
| 3600/3800 DIFFERENCE TRAINING MANUAL (FORMERLY 032467) | 60273600 | | | 04.35 | |
| 6000 ASCENT/COMPASS PROGRAMMING TRAINING | 60183400 | | | 04.90 | |
| 6000/CYBER 74 COMPUTER MAINTENANCE CHARTS AND DIAGRAMS FOR TRAINING PURPOSES | 60378600 | | 34 | 08.55 | |
| 6000 INTRO. AND PERIPHERAL PROCESSOR TRNG. MANUAL (FORMERLY 020267) | 60250400 | | | 02.00 | |
| 6000 SERIES ASPER/COMPASS PROGRAMMING | 60183300 | | | 03.65 | |
| 6400 CENTRAL PROCESSOR TRAINING MANUAL (FORMERLY 011167) | 60257200 | | | 04.15 | |
| 6600 CENTRAL PROCESSOR TRAINING MANUAL VOL 1 CONTROL AND MEMORY (FORMERLY 020167) | 60241300 | | | 08.65 | |
| 6600 CENTRAL PROCESSOR, VOL II, FUNCTIONAL UNITS (FORMERLY 091466) | 60239700 | | | 05.80 | |
| 6600 COMPUTER WORKBOOK AND TIMING DIAGRAMS (FORMERLY 042167) | 60258000 | | | 03.80 | |
| 6610 STANDARD PERIPHERAL TRAINING MANUAL, TEST EDITION (FORMERLY 092967) | 60239500 | | | 01.00 | |
| 6638 DISK FILE SUBSYSTEM TRAINING SUPPLEMENT | 60250800 | A | | 02.10 | |
| 6639 DISK CONTROLLER TRAINING MANUAL (FORMERLY 092867) | 60273300 | | | 01.05 | |
| 8092 TELEPROGRAMMER TRAINING MANUAL | 60183900 | | | 03.50 | |
| ACTIVE ELECTRONICS STUDENT MANUAL (750 HR) | 76360015 | A | 3 | 06.10 | |
| ACTIVE NETWORKS EXPERIMENTS, REVISED (APL.) (FORMERLY A-012268) | 60250500 | C | 3 | 01.80 | |
| ACTIVE NETWORKS WORKBOOK, VOL. I | 60274100 | | | 05.70 | |

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4. Price per manual.
5. Manual page count.

| TITLE | 1 | 2 | 3 | 4 | 5 |
|---|----------|---|---|-------|---|
| (FORMERLY 082866A) | | | | | |
| ACTIVE NETWORKS WORKBOOK, VOL. II | 082966A0 | | | 03.00 | |
| ACTIVE NETWORKS WORKBOOK, VOL I (REVISED) | 60250600 | | | 04.45 | |
| (FORMERLY A-012368) | | | | | |
| ACTIVE NETWORKS WORKBOOK, VOL II (REVISED) | 60250700 | | | 04.80 | |
| (ARL) (FORMERLY A-012468) | | | | | |
| AN INTRODUCTION TO DIGITAL COMPUTERS, VOL 1 | 60241600 | | | 05.80 | |
| (FORMERLY 081866A) | | | | | |
| AN INTRODUCTION TO DIGITAL COMPUTERS, VOL II | 60241700 | | | 07.15 | |
| (FORMERLY 091266A) | | | | | |
| AN INTRODUCTION TO DIGITAL COMPUTERS, VOL III | 60241800 | | | 03.40 | |
| (FORMERLY 032367) | | | | | |
| ASSEMBLY LANGUAGE TRAINING MANUAL | 60354700 | | 3 | 06.70 | |
| ASSEMBLY LANGUAGE STUDENT MANUAL | 60315100 | | 3 | 02.75 | |
| ASSEMBLY LANGUAGE TRAINING SUPPLEMENT | 60355500 | | | 01.80 | |
| BUSINESS APPLICATIONS STUDENT MANUAL | 60315200 | A | | 01.00 | |
| BUSINESS CONCEPTS STUDENT MANUAL | 60378900 | | 3 | 02.75 | |
| BUSINESS MATH AND ACCOUNTING STUDENT MANUAL | 60355800 | | 3 | 01.00 | |
| CARD EQUIPMENT STUDENT MANUAL | 60313100 | | | 01.00 | |
| CDI CAREER EDUCATION STUDENT HANDBOOK (1975) | 76360031 | | | 01.15 | |
| CENTRAL PROCESSOR SOFTWARE STUDENT MANUAL | 60353700 | | | 02.05 | |
| CENTRAL PROCESSOR HARDWARE STUDENT MANUAL | 60379200 | A | 3 | 12.00 | |
| VOL. I-II | | | | | |
| COMMUNICATIONS AND CUSTOMER RELATIONS | 60378100 | | 3 | 01.00 | |
| STUDENT MANUAL | | | | | |
| COMPASS STUDENT MANUAL BOOK I | 60313600 | | 3 | 01.00 | |
| COMPASS STUDENT MANUAL PART II | 60314300 | | 3 | 01.00 | |
| COMPUTER IN CREDIT STUDENT MANUAL | 60378400 | | 3 | 01.00 | |
| COMPUTER SYSTEMS OPERATIONS STUDENT MANUAL | 76360011 | | 3 | 05.20 | |
| COMPUTER TECHNOLOGY HARDWARE WORKBOOK | 60241200 | A | | 02.70 | |
| COMPUTER TECHNOLOGY STUDENT MANUAL | 60314800 | A | 3 | 01.00 | |
| COMPUTER TECHNOLOGY SOFTWARE TRAINING SUPP. | 60239600 | | | 01.00 | |
| CONTROL DATA INSTITUTE PRODUCT CATALOG | 60379000 | | 3 | 04.05 | |
| CREDIT PRINCIPLES AND PRACTICES I STUDENT | 60378200 | | 3 | 01.00 | |
| MANUAL | | | | | |
| CREDIT PRINCIPLES AND PRACTICES II STUDENT | 60378300 | | 3 | 01.00 | |
| MANUAL | | | | | |
| CYBER 72/73/74 SCOPE SYSTEM MAINTENANCE | 76360012 | | 3 | 05.35 | |
| STUDENT MANUAL | | | | | |
| DATA PROCESSING CONCEPTS STUDENT MANUAL | 60353100 | | | 01.20 | |
| DATA TERMINALS AND COMMUNICATIONS SYSTEMS | 76360023 | | 3 | 10.10 | |
| DIAGNOSTIC ROUTINES WORKBOOK (FORMERLY | 60238700 | | | 01.45 | |
| 042467) | | | | | |
| DIGITAL COMPUTER OPERATOR | 60312700 | | | 01.50 | |
| DIGITAL ELECTRONICS STUDENT MANUAL | 60353500 | C | 3 | 04.10 | |
| DISK DRIVE STUDENT MANUAL | 76360002 | | 3 | 04.35 | |
| ELECTRONICS REVIEW STUDENT MANUAL | 60380100 | | 3 | 02.15 | |
| GLOSSARY FOR INFORMATION PROCESSING | 60240700 | | 3 | 01.60 | |
| (FORMERLY 070367) | | | | | |
| HANDOUTS FOR POSTOFFICE COURSE | 07046700 | | | 01.95 | |
| INTEGRATED CIRCUITS STUDENT MANUAL | 60380000 | | 3 | 01.30 | |
| INTRO TO DATA PROCESSING (DCO) STUDENT MAN | 60354900 | | | 02.55 | |
| INTRODUCTION TO CREDIT STUDENT MANUAL | 60355700 | | 3 | 01.00 | |

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4. Price per manual.
5. Manual page count.

| TITLE | 1 | 2 | 3 | 4 | 5 |
|--|----------|---|----|-------|---|
| LINE PRINTER EQUIP. TRAINING MAN 2ND EDITION (FORMERLY 082166) | 60257100 | C | | 07.15 | |
| LOGIC CIRCUIT EXPERIMENTS | 60238800 | A | | 02.00 | |
| MAGNETIC RECORDING EQUIP.TAPE STUDENT MANUAL | 60314400 | A | | 01.00 | |
| MAGNETIC RECORDING EQUIP. DISK STUDENT MAN | 60354300 | C | 3 | 03.30 | |
| MAGNETIC TAPE-ITS PRINCIPLES AND CERTIF. (FORMERLY 62466) | 60256700 | | | 01.30 | |
| MAGNETIC TAPE STORAGE TRAINING MANUAL (FORMERLY 081766B) | 60239400 | C | | 03.50 | |
| MODEL 33 TELETYPEWRITER TRAINING MANUAL (FORMERLY 060167) | 60273900 | | | 03.35 | |
| MSOS PROGRAMMING TRAINING MANUAL | 60257600 | | | 02.20 | |
| OPTICAL CHARACTER RECOGNITION STUDENT MANUAL | 60355400 | | 3 | 01.00 | |
| PASSIVE ELECTRONICS STUDENT MANUAL | 60354500 | G | 3 | 06.70 | |
| PASSIVE NETWORKS EXPERIMENTS (REVISED ED) (FORMERLY A-010468) | 60250200 | | 22 | 01.15 | |
| PASSIVE NETWORKS WORKBOOK, REVISED, (ARL.) (FORMERLY A-010368 AND 090166B) | 60250100 | | | 04.60 | |
| PASSIVE NETWORKS WORKBOOK TRAINING SUPP. | 60250300 | | | 04.05 | |
| PHASE I PROGRAMMING TECHNOLOGY WORKBOOK | 04036700 | | | 08.70 | |
| PHASE II PROGRAMMING TECHNOLOGY WORKBOOK | 04256700 | | | 05.60 | |
| PROGRAMMING CONCEPTS WORKBOOK | 60274400 | | 3 | 07.50 | |
| PUNCHED CARD EQUIPMENT STUDENT MANUAL | 76360001 | C | 3 | 01.10 | |
| PUNCHED CARD EQUIPMENT TRAINING MANUAL | 60378700 | R | 3 | 05.85 | |
| REPORT PROGRAM GENERATOR STUDENT MANUAL | 60379100 | | 3 | 01.35 | |
| SELECTRIC MAINTENANCE ADMINISTRATION GUIDE | 60380200 | | 3 | 02.50 | |
| SELECTRIC MAINTENANCE STUDENT GUIDE | 60380300 | | 3 | 01.70 | |
| SELECTRIC TYPEWRITER TRAINING MANUAL, SECOND EDITION (FORMERLY 080566B) | 60238300 | | | 02.40 | |
| SMM3L MONITOR COMMAND AND MEMORY TEST LISTINGS (FORMERLY 030767) | 60273800 | | | 01.35 | |
| SYSTEM/360 COMPUTER OPERATION (DCO) STUDENT | 60355200 | | | 01.35 | |
| SYSTEM/360 ASSEMBLY LANGUAGE STUDENT MANUAL | 60353000 | B | 3 | 07.20 | |
| SYSTEM/360 INSTRUCTIONS | 60379300 | | | 00.75 | |
| SYSTEMS CONCEPTS STUDENT MANUAL | 60353300 | | | 01.00 | |
| SYSTEMS DESIGN STUDENT MANUAL | 60379500 | | 3 | 01.25 | |
| UNIT RECORD EQUIPMENT (DCO) STUDENT MANUAL | 60355100 | | | 04.35 | |
| UTILITIES PROGRAMMING STUDENT MANUAL | 60353200 | | | 01.00 | |
| UTILITIES STUDENT MANUAL | 60313500 | A | 3 | 01.00 | |
| VISUAL DISPLAY TRAINING MANUAL | 60355300 | | 3 | 01.20 | |
| VISUAL DISPLAYS / SYSTEMS MAINTENANCE STUDENT MANUAL | 76360003 | | 3 | 01.30 | |
| VISUAL RECORDING EQUIP. STUDENT MANUAL | 60313400 | A | | 01.15 | |
| WORK SIMULATION STUDENT MANUAL | 60378500 | | 3 | 01.00 | |
| TECHNICAL REPORTS | | | | | |
| TER01- SOLVING DESIGN PROBLEMS IN GRAPHICAL DIALOGUE | 00000021 | | | 04.95 | |
| TER02- A GENERALIZED LANGUAGE FOR INFORMAT STORAGE AND RETRIEVAL APPLICATIONS | 60175600 | | | 01.25 | |
| TER03- USE OF INFOL FOR DOCUMENT AND RETRIEVAL APPLICATIONS | 60175700 | | | 01.60 | |

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4.Price per manual.
5. Manual page count.

| TITLE | 1 | 2 | 3 | 4 | 5 |
|--|----------|---|----|-------|---|
| TER04- DISPLAY CODED CHARACTER ARITHMETIC ON THE 6000 SERIES | 60190500 | | | 01.50 | |
| TER05-THE GPL LANGUAGE | 60192400 | | | 04.00 | |
| TER07- CONVERSATIONAL APT | 60222400 | | | 07.65 | |
| TER08-COMPUTER SIMULATION-AN INTRODUCTION | 60228300 | | | 01.70 | |
| TER09- COMPUTERS AND PUBLIC CONCERN | 60229700 | | 3 | 02.90 | |
| TER10-APT/EXPEDITE A CONVERSATIONAL APT SYS FOR THE 6000 COMPUTER WITH 210/211/212 DISPLAY STATION | 60234400 | | 3 | 04.65 | |
| TER-12 PROGRAMMING TECHNICAL REPORT | 60235300 | | | 01.30 | |
| TER11- THE CHART? FLOWCHARTING PROGRAM | 60234700 | | 3 | 01.85 | |
| TER14 FUNDAMENTALS OF BASIC TIME SHARING | 60252300 | | | 01.00 | |
| TER-15 - SIMPL-A SIMULATION PROGRAMMING LANGUAGE. AUTHOR M. MACDOUGALL | 60252400 | | | 02.00 | |
| TER-16 - PACKED DATA IN FORTRAN EXTENDED UNDER 6000 SCOPE 3.AUTHOR JOHN O. NEUHAUS | 60252500 | | | 01.45 | |
| TER-17 PROGRAMMING TECHNICAL REPORT | 60305800 | | | 02.00 | |
| MATHEMATICAL APPROXIMATIONS (TR52) | 60070900 | | | 08.00 | |
| MATRIX ALGEBRA,GAMMA FUNCTION,ERROR FUNCTION BESSEL FUNCTIONS(TR53) | 60071000 | | | 02.50 | |
| BINARY ERROR DETECTION BY GENERALIZED PARITY CHECKING (TR54) | 60071100 | | 22 | 02.75 | |
| ARITHMETIC ERRORS AND SINE APPROXIMATIONS (TR56) | 60071300 | | | 02.20 | |
| LOGIC FOR COMPUTER DESIGNERS AND PROGRAMMERS PART 1 INTRODUCTION TO MATHEMATICAL LOGIC (TR57) | 60071400 | | | 04.30 | |
| CELLS-BASIC STRUCTURAL UNITS OF DESIGN(TR51) | 60070800 | | | 02.00 | |
| VIDEO LECTURE MANUALS | | | | | |
| VIDEO LECTURE (7600 FEATURES) | 00006100 | | | 01.80 | |
| VIDEO LECTURE SCOPE 3.1.6 TCS | 00006000 | | | 05.35 | |
| SCM PUBLICATIONS | | | | | |
| T-330 PROGRAMMING OPER MODE DIAGS,ALIGN PROC POWER SUPPLY SERVICE/INSTR MANUAL | 60244400 | A | 22 | 10.75 | |
| S-550 SERVICE MANUAL | 60242900 | | | 04.05 | |
| 2816 POINT TO POINT PROGRAMMING MANUAL | 60244200 | A | 22 | 03.00 | |
| 2816 POWER SUPPLY INSTRUCTION MANUAL | 60242500 | A | 22 | 01.50 | |
| 2816 SERVICE MANUAL (ADDENDUM D) | 60243000 | A | 22 | 05.00 | |
| 2816/7816 VERTIPUNCH INSTRUCTION MANUAL | 60244600 | A | 22 | 04.60 | |
| 6615 SERVICE MANUAL | 60242000 | A | 22 | 17.20 | |
| 6615-02 POWER SUPPLY MANUAL | 60244300 | A | 22 | 02.00 | |
| 7816 POINT TO POINT PROGRAMMING MANUAL | 60244100 | A | 22 | 02.10 | |
| CONTROL UNIT INSTRUCTION MANUAL | 60242300 | A | 22 | 05.95 | |
| CONTROL UNIT PARTS MANUAL | 60243600 | B | 22 | 05.20 | |
| CONTROL UNIT SERVICE MANUAL | 60243100 | A | 22 | 08.40 | |
| CPI SERVICE AND INSTRUCTION MANUAL | 60242800 | | | 05.00 | |
| DATA PROCESSING PROGRAMMING COURSE | 60238700 | | 3 | 12.25 | |
| I/O TO PUNCH TRANSLATOR SERVICE MANUAL | 60243300 | | | 05.35 | |

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched in manual for use with hard cover ringed binder.

4.Price per manual.
5. Manual page count.

| TITLE | 1 | 2 | 3 | 4 | 5 |
|---|----------|---|----|-------|---|
| I/O UNIT PARTS MANUAL | 60243400 | | | 03.60 | |
| INPUT/OUTPUT INSTRUCTION MANUAL | 60242100 | A | 22 | 03.60 | |
| PROCESSOR INSTRUCTION MANUAL | 60242400 | A | 22 | 10.00 | |
| PROCESSOR POWER SUPPLY INSTRUCTION MANUAL | 60242600 | A | 22 | 01.05 | |
| PROCESSOR SERVICE MANUAL | 60241900 | A | 22 | 06.50 | |
| READER PARTS MANUAL | 60243500 | A | 22 | 02.50 | |
| TCR-30 PARTS MANUAL | 60243800 | | 22 | 02.65 | |
| TCR-30 SERVICE AND INSTRUCTION MANUAL | 60242700 | A | 22 | 08.30 | |
| TOOL LIST | 60244000 | A | 22 | 01.20 | |
| TYPETRONIC 330 PARTS INFORMATION CE MANUAL | 60244900 | A | 22 | 02.10 | |
| TYPETRONIC 2816/7816 AUX. FEATURE CONTROL UNIT, PARTS INFORMATION CE MANUAL | 60286400 | A | 22 | 01.50 | |
| TYPETRONIC 2816/7816 MODEL 02 READER INSTRUCTION MANUAL | 60242200 | A | 22 | 02.10 | |
| TYPETRONIC 7816 PROCESSOR PARTS CE MANUAL | 60244800 | A | 22 | 05.20 | |
| TYPETRONIC VERTIPUNCH PARTS MANUAL | 60240300 | | 22 | 02.65 | |
| VERTIPUNCH SERVICE MANUAL | 60244500 | C | | 02.50 | |
| SCM (OEM) MANUALS | | | | | |
| 024-026 INSTRUCTION MANUAL - IBM | 60245300 | | | 03.60 | |
| 024-026 MAINTENANCE MANUAL - IBM | 60245400 | | | 04.05 | |
| 024-026 PARTS MANUAL - IBM | 60245500 | | | 03.60 | |
| 024-026 REFERENCE MANUAL - IBM | 60245200 | | | 01.00 | |
| CS100 PARTS CATALOG - BULL CE | 60245100 | | | 03.00 | |
| HARD COVER BINDERS AND TEMPLATES | | | | | |
| 34-RING FOR 11 X 17 DIAGRAM MANUALS | | | | | |
| 3/4 IN BINDER | 60086900 | | | 02.85 | |
| 1 1/4 IN BINDER | 60087000 | | | 04.05 | |
| 22-RING FOR 8 1/2 X 11 MANUALS | | | | | |
| 3/4 IN BINDER - DARK BLUE W/CDC LOGO | 60087200 | | | 01.85 | |
| 1 1/4 IN BINDER-DARK BLUE W/CDC LOGO | 60087400 | | | 02.00 | |
| 3-RING FOR 8 1/2 X 11 MANUALS | | | | | |
| 3/4 IN BINDER-DARK BLUE W/CDC LOGO | 60086000 | | | 01.50 | |
| 1 1/2 IN BINDER - DARK BLUE W/CDC LOGO | 60086100 | | | 02.30 | |
| 2 IN BINDER - DARK BLUE W/CDC LOGO | 60087500 | | | 02.50 | |
| CYBER 70 1 1/2 3 RING - BUTTERSCOTCH CDC | 60088800 | | | 02.30 | |
| 1700 SERIES 1 1/4 3 RING- BROWN W/CDC LOGO | 60088600 | | | 03.00 | |
| 3000 SERIES 1 1/4 3 RING- ORANGE W/CDC LOGO | 60087600 | | | 03.00 | |
| 6000 SERIES 1 1/4 3 RING LIGHT BLUE W/CDC LOGO | 60088500 | | | 03.00 | |
| CYBERNET SERVICES-LIGHT BLUE 1 INCH 3 RING | 60089100 | | 3 | 04.00 | |
| CYBERNET SERVICES-LIGHT BLUE 1 1/2 IN 3 RING | 60089200 | | 3 | | |
| CYBERNET SERVICES LIGHT BLUE 2 INCH 3 RING | 60089300 | | 3 | | |
| 7000 SERIES 1 1/2 3 RING- BROWN W/CDC LOGO | 60297200 | | | 02.10 | |

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched in manual for use with hard cover ringed binder.

4. Price per manual.
5. Manual page count.

| TITLE | 1 | 2 | 3 | 4 | 5 |
|--|----------|---|----|-------|---|
| 6-RING 3/4 INCH CODE BOOK BINDER-YELLOW | 60088700 | | 6 | 01.70 | |
| PROGRAMMING REPORT SUMMARY BINDER RUST PRESSBOARD 9 X 5 3/4 (METAL FASTENER) | 00004600 | | | 00.50 | |
| TEMPLATES | | | | | |
| FORM DESIGN AID (915 PAGE READER) | 48402800 | | | 04.35 | |
| LOGIC TEMPLATE | 60085100 | | | 03.20 | |
| LOGIC SYMBOLOGY TEMPLATE | 62181600 | | | 09.25 | |
| LOGIC DRAWING TEMPLATE | 82269600 | | | 06.60 | |
| PROGRAMMING TEMPLATE | 10124300 | | | 01.50 | |
| 6600 LOGIC TEMPLATE | 60113200 | | | 03.60 | |
| MOTOR GENERATOR SETS | | | | | |
| CE MANUAL DES, INSTL, OPR, MAINT AND REF DWGS (ELECTRIC MACH FREQ CONV-SETS PRIOR TO SER 65-1582 EXCEPT SER 65-1557) | 60156900 | C | 22 | 05.10 | |
| CE MAN-DESC, INSTL, OPR, MAINT AND REF DWGS (ELECTRIC MACHINE FREQ CONV-SER 65-1557, 65-1582 AND ABOVE) | 60166800 | B | 22 | 09.85 | |
| CE DIAGRAMS MANUAL | 60423100 | A | 22 | 16.05 | |
| KATO MOTOR GENERATOR SETS (SERIALS 55972 AND ABOVE) | | | | | |
| GEN DESC, OPERATION, INSTALLATION/CHECKOUT, THEORY OF OPERATION, MAINT, PARTS CE MAN. DIAGRAMS MANUAL | 60420800 | A | 22 | 08.30 | |
| | 60419900 | A | 22 | 10.20 | |
| REFRIGERATION MANUALS | | | | | |
| TRANE RECIPROCATING REFRIGERATION MANUAL | 60240200 | | | 09.00 | |
| REFRIGERATION THEORY MAINTENANCE MANUAL | 60268100 | H | 22 | 06.60 | |
| REFRIGERATION UNITS CORDWOOD MODULES PARTS LIST | 60227400 | B | 22 | 01.50 | |
| ** SEE ALSO GH214-A, GH216-A, GH218-A ** | | | | | |
| POWER SUPPLY MANUALS | | | | | |
| AULT POWER SUPPLIES FOR CDC SYSTEMS | 60107300 | D | 22 | 11.00 | |
| CONTROL DATA POWER SUPPLIES APPLICABLE TO ACTIVE 6000/CYBER SERIES COMPUTING EQUIP. DIAGRAMS, THEORY OF OPERATION, MAINTENANCE AND PARTS DATA CE MANUAL | 60427200 | A | 22 | 01.50 | |
| CONTROL DATA POWER SUPPLIES APPLICABLE TO ACTIVE 3000 SERIES COMPUTING EQUIPMENT DIAGRAMS, THEORY OF OPERATION, MAINTENANCE AND PARTS DATA CE MANUAL | 60427300 | A | 22 | 03.35 | |
| CONTROL DATA POWER SUPPLIES APPLICABLE TO INACTIVE COMPUTING EQUIPMENT DIAGRAMS, THEORY OF OPERATION, MAINTENANCE AND PARTS DATA CE MANUAL | 60427400 | A | 22 | 16.05 | |

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4. Price per manual.
5. Manual page count.

| TITLE | 1 | 2 | 3 | 4 | 5 |
|---|----------|-----|-------|-------|---|
| DISK FILE HYDRAULIC | 40869500 | C | 22 | 03.80 | |
| DISK FILE HYDRAULIC POWER SUPPLY GH202-B06 CE MANUAL | 41245600 | D | 22 | 02.35 | |
| DISK FILE HYDRAULIC POWER SUPPLY CE MANUAL | 70615700 | B | 22 | 04.30 | |
| PRINTED CIRCUIT MANUALS | | | | | |
| 1604 DISK FILE LOGIC MANUAL | 40829700 | G | 22 | 17.70 | |
| 1604 SERIES LOGIC MODULES (TAPE TRANSPORT) OEM CF MANUAL | 40827900 | E | 22 | 05.90 | |
| CORDWOOD MANUAL VOLUMES 1,2,3 | 60042700 | AY | 22 | 10.00 | |
| DISK STORAGE DRIVE (OEM) 1604 SERIES LOGIC MODULE CE MANUAL | 40826700 | J | 22 | 07.15 | |
| PRINTED CIRCUIT CARD MODIFICATION PROCEDURES (DRIFT TO MESA) | 60041600 | A | 3 | 01.25 | |
| VOLS. 1,2 AND 3 (1604 AND 3600 TYPES) | 60042900 | U | 22 | 13.10 | |
| INTERRD CIRCUITS MANUAL | 60201000 | A | 22 | 03.15 | |
| SITE PREPARATION MANUALS | | | | | |
| SECTION 1 - GENERAL INFORMATION | | | | | |
| LARGE AND MEDIUM SCALE COMPUTER SYSTEMS INCLUDES INFO FOR 3000, 6000 AND 7000 SYSTEMS | 60275100 | C | 22 | 01.40 | |
| SMALL SCALE COMPUTER SYSTEMS - INCLUDES INFO FOR 160, 160-A, 1700, SC17 (1770), AND 8090 SYSTEMS | 60275200 | R | 22 | 03.35 | |
| MINI COMPUTER SYSTEMS | 60437000 | A | 22 | 02.60 | |
| SECTION 2 SITE PREPARATION AND INSTALLATION INFORMATION (SYSTEM DATA) | | | | | |
| CYBER 70 - MODELS 72/73/74 COMP. SYSTEMS AND CYBER 70 - MODEL 7030 SYSTEMS DATA | 60277700 | A | 22 | 07.00 | |
| CYBER 70 - MODEL 76 SYSTEMS DATA | 60277600 | C | 22 | 02.55 | |
| CYBER 170 - MODELS 172/173/174 SYSTEMS DATA | 19981400 | A | 22 | 04.80 | |
| CYBER 170 - MODEL 175 SYSTEMS DATA | 60420100 | A | 22 | 03.80 | |
| CYBER 1000 MODELS IMX, PMX, CMX SYS DATA MINI COMPUTER SYSTEMS | 60418200 | A | 22 | 01.40 | |
| 60437100 | A | 22 | 04.70 | | |
| SC1700 SYSTEMS DATA SITE PREPARATION MANUAL 732-XX, 733-10, 791-X, 7077-1 AND 7X54/844 SYSTEMS DATA SITE PREPARATION MANUAL | 60277000 | C | 22 | 01.30 | |
| 60277500 | A | 22 | 01.95 | | |
| 8090 SYSTEMS DATA SITE PREPARATION MANUAL | 60275500 | B | 22 | 01.45 | |
| 1700 SYSTEMS DATA SITE PREPARATION MANUAL | 60275600 | D | 22 | 01.60 | |
| 3170 SYSTEMS DATA SITE PREPARATION MANUAL | 60277400 | A | 22 | 01.30 | |
| 3300 SYSTEMS DATA SITE PREPARATION MANUAL | 60275900 | A | 22 | 01.05 | |
| 3500 SYSTEMS DATA SITE PREPARATION MANUAL | 60276100 | C-E | 22 | 01.15 | |
| 6200 SYSTEMS DATA SITE PREPARATION MANUAL | 60277300 | A | 22 | 01.30 | |
| 6400 SYSTEMS DATA SITE PREPARATION MANUAL | 60276400 | B | 22 | 01.00 | |
| 6500 SYSTEMS DATA SITE PREPARATION MANUAL | 60276500 | R | 22 | 01.00 | |
| 6600 SYSTEMS DATA SITE PREPARATION MANUAL | 60276600 | B | 22 | 01.00 | |
| 6700 SYSTEMS DATA SITE PREPARATION MANUAL | 60277100 | A | 22 | 01.10 | |
| 7611-11 SERVICE STATION - SYSTEMS DATA | 60277200 | A | 22 | 03.25 | |
| 2700 SYSTEMS DATA SITE PREPARATION MANUAL | 60277800 | B | 22 | 06.00 | |

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4. Price per manual.
5. Manual page count.

| TITLE | 1 | 2 | 3 | 4 | 5 |
|---|----------|-----|----|-------|---|
| 90100 SYSTEMS DATA SITE PREPARATION MANUAL (INCLUDES PRODUCT SPECIFICATION) | 60286800 | A | 22 | 02.00 | |
| SECTION 3 PERIPHERAL EQUIPMENT DATA SITE PREPARATION MANUAL | 60275300 | 06 | 22 | 02.40 | |
| SECTION 3 MINI COMPUTER SYSTEMS | 60437200 | A | 22 | 05.35 | |
| VENDOR MANUALS | | | | | |
| BENDIX MTA-3 MAGNETIC TAPE ACCESSORY (DRS) | AET05611 | | 3 | 05.55 | |
| BENDIX PROGRAM PREPARATION ROUTINE TECH MAN | APT45910 | | 3 | 03.75 | |
| BRYANT DRUM SERVICE MANUAL | 60194200 | | | | |
| CALCOMP - MODEL 565 PLOTTER INSTRUCTION MANUAL - (SPECIAL ORDER ITEM-60 DAY DELIVERY) CONTAINS DESC., INSTAL., THEORY OF OP., OPERATING INSTRUCTIONS, MAINTENANCE AND PARTS LIST. (JUNE 1969) | 60148100 | | | 30.00 | |
| DATA PRODUCTS 5024/818 DISC FILE REFERENCE (SPECIAL ORDER ITEM-VENDOR COST 47.00) | 60095600 | | | | |
| DIGITRONICS - MODEL R3000 PERFORATED TAPE READER - CONTAINS INSTALLATION, OPERATION, THEORY OF OP., MAINTENANCE, SCHEMATICS AND WIRING DIAGRAMS | 60143200 | | 22 | 09.75 | |
| DIGITRONICS - MODEL B6090 PERFORATED TAPE HANDLER - CONTAINS DESCRIPTION, INSTAL., OPERATION, THEORY OF OP, MAINT., AND SCHEMATICS | 60143100 | | 22 | 02.70 | |
| GENERAL PRECISION 4440 HIGH SPEED PUNCH MAINTENANCE AND TRAINING | ESD10504 | | 3 | 10.20 | |
| TRM MODEL 31 MONITOR TYPEWRITER WITH SOROBAN MODIFICATION - REF/INSTRUCTION MANUAL INCLUDES DESCRIPTION, OPERATION, MAINT. | 60008300 | B | 22 | 07.90 | |
| TRM SELECTRIC SERIES 73 I/O TYPEWRITER REFERENCE MANUAL - INCLUDES MAINT., ADJUSTMENTS, REMOVAL INFO, TIMING CHARTS, WIRING DIAGRAMS, PARTS LIST | 60095900 | B | 22 | 15.95 | |
| TRM 1311 CE INSTRUCTION MANUAL | 60142000 | | | 04.35 | |
| TRM 1311 CE MAINTENANCE MANUAL | 60152100 | | | 03.60 | |
| TRM 1407 CONSOLE INQUIRY CE REFERENCE MANUAL | 60142100 | | 22 | 03.40 | |
| PAPER TAPE PUNCH HANDLER (NCR) CE MANUAL | 60297300 | A | | 05.00 | |
| NCR EM-P3 PAPER TAPE PUNCH | 60295600 | A | 22 | 04.80 | |
| NCR PUNCH MANUAL EM-P2 MX-1027-7 | 60143600 | | | 02.55 | |
| SUPPLEMENT NO.1 TO C.D.C. PAPER TAPE PUNCH (NCR EM-31/B2) (ADDENDUM TO 60143600) | 60211600 | | | 01.00 | |
| NCR CARD EM-02 (PE) CE MANUAL (REV. 12/67) | 60161300 | B | 22 | 05.05 | |
| REMEX PAPER TAPE SPOOLER (MODEL RS0502ARB/ S2R) CE MANUAL | 60207700 | B | 22 | 01.90 | |
| SINGER BUSINESS MACHINES LINE PRINTER EQUIPMENT MODELS 53/54/55/56 FIELD SERVICE MANUAL VOL I | 59708600 | A01 | 3 | 02.50 | |
| FIELD SERVICE MANUAL VOL II | 59709000 | B01 | 34 | 08.25 | |
| REFERENCE MANUAL (TRAINING) | 59708500 | B | 3 | 02.00 | |
| PARTS MANUAL | 59708700 | D | 3 | 11.45 | |

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4. Price per manual.
5. Manual page count.

| TITLE | 1 | 2 | 3 | 4 | 5 |
|---|----------|---|----|-------|---|
| TALLY PAPER TAPE READER, REF INSTRUCTION | 60116900 | | | 04.60 | |
| TELETYPE 147624 BRPE PUNCH INSTALLATION | 13796300 | A | | 01.00 | |
| TELETYPE PAPER TAPE PUNCH TECH MANUAL BRPE 11(BULLETIN 215B) | 60095700 | | | 07.50 | |
| TELETYPE PAPER TAPE PUNCH PARTS MANUAL (BRPE-11) (BULLETIN 1154B) | 60095800 | | | 03.60 | |
| TELETYPE PARTS MANUAL MODELS 32 AND 33 (BULLETIN 1184B) | 60144200 | | | 05.25 | |
| TELETYPE TECH MANUAL TAPE READER SET (BULLETIN 267B) | 41608700 | | | 03.60 | |
| TELEX 5403 TRAIN PRINTER DIAGRAMS, W/L CE MANUAL VOLS 1-3 | 50578700 | B | | 15.30 | |
| DIAGRAMS, W/L, PARTS DATA CL7A2 VOLS 1-3 | 50581200 | B | 22 | 10.65 | |
| 5416 TELEX PRINT CART GEN. DFSC., MAINT., THEO.OF OPER., CE MANUAL | 50581500 | C | 22 | 01.20 | |
| (THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES.ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.) | | | | | |
| AMPEX CDFR-400 TAPE TRANSPORT | 60017400 | | | | |
| AMPEX COTM-2 TAPE TRANSPORT | 60017500 | A | | | |
| LONG LINE TRANSMISSION FOR 1604 TYPE I/O CE MANUAL | | | | | |
| | 60013600 | A | 22 | 01.40 | |
| (THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES.ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.) | | | | | |
| COMPUTER BUFFER CHANNEL LONG LINE DRIVERS | 60123100 | A | 22 | 00.75 | |
| COMPUTER NORMAL CHANNEL LONG LINE DRIVERS | 60123200 | A | 22 | 00.75 | |
| LONG LINE TRANSMISSION FOR 3000 PERIPHERAL CE MANUAL | | | | | |
| | 60317100 | A | 22 | 04.50 | |
| MISCELLANEOUS EQUIPMENT MODIFICATIONS (PRIOR TO STANDARD OPT,SPECIAL OPT AND QSE.) | | | | | |
| NCR COMPUTER VOL III DIAGRAMS MANUAL | 60010200 | A | 24 | 04.60 | |
| (THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES.ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.) | | | | | |
| CONTROL MONITOR C-2539/GTC | 60011400 | | | | |
| DATA SELECT UNIT | 60021100 | | | | |
| DIGITAL DATA TERMINAL | 60105300 | | | | |
| FADE IN DIAGRAMS | 60012000 | | | | |
| FADE IN DIAGRAMS(SERIAL 2) | 60012700 | | | | |
| THOMPSON-RAMO-WOOLDRIDGE CX/IX400 EXCH.UNIT | 60107700 | | | | |

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4.Price per manual.
5. Manual page count.

| TITLE | 1 | 2 | 3 | 4 | 5 |
|--|----------|---|----|-------|---|
| 160-A TEST CONSOLE DIAGRAMS | 60103600 | | | | |
| 162-A TAPE SYNCHRONIZER(PROTOTYPE DIAGRAMS) | 60103800 | | | | |
| 163-A MAGNETIC TAPE SYSTEM (WEBSTER) | 60008600 | | | | |
| 164-A TAPE SIGNAL CONDITIONER | 60025400 | | | | |
| 924-B (SERIAL 3) 77 PASS DIAGRAMS | 60109500 | | | | |
| 924-B (SERIAL 9) BREAKPOINT SWITCH MOD | 60102900 | | | | |
| 924-B ITEK MODIFICATION | 60109600 | | | | |
| 1619X MAGNETIC DISK FILE CONTROLLER DIAG(AIL | 60110300 | | | | |
| QSE | | | | | |
| PUBLICATIONS FOR QSE#S ARE NOT STOCKED.THEY ARE AVAILABLE IN OZALID FORM ONLY. WHEN ORDERING,FURNISH QSE NUMBER AND DESCRIPTION AND ALL AVAILABLE INFO WILL BE SENT. | | | | | |
| STANDARD OPTIONS | | | | | |
| (NOTE 1. INFO FOR THIS OPTION IS INCLUDED IN BASIC MANUALS FOR RESPECTIVE PRODUCT. SEE INDIVIDUAL EQUIPMENT LISTING) | | | | | |
| 955 SEQUENTIAL NUMBERING DEVICE OPTION GEN DESC., THEORY OF OPER., DIAGRAMS AND PARTS DATA OF MANUAL | 91503500 | A | 3 | 03.75 | |
| 10001 EIGHT 603 ON 162-1(MAPE 101) | 60115800 | | | | |
| 10003 1604-B MODIFICATION DIAGRAMS(SEE NOTE 1) | | | | | |
| 10005 160-A INTERFACE FOR 3206 REFERENCE/ INSTRUCTION (MAPE 223)-SEE NOTE 1 | | | | | |
| 10006 924/924-A CORE STOR CONVERS 8K TO 16K SEE NOTE 1 | | | | | |
| 10007 924/924-A CORE STOR CONVERS 16K TO 32K (SEE NOTE 1) | | | | | |
| 10008 924/924-A CORE STOR CONVERS 8K TO 32K (SEE NOTE 1) | | | | | |
| 10009 1604A/B/C CORE STORAGE CONVERSION 16K TO 32K (SEE NOTE 1) | | | | | |
| 10010-A LONG LINE DRIVER | 60317100 | A | 22 | 04.50 | |
| 10012 SPECIAL 501 PRINT DRUM(SLOTTED OH)(SEE NOTE 1) | | | | | |
| 10013 3200 CONSOLE FOR 3100 (SEE NOTE 1) | | | | | |
| 10015 DUAL MOTOR/GENERATOR SET (NO PUBL NEED OR AVAILABLE FOR THIS OPTION) | | | | | |
| 10040-10043 (INFO AVAILABLE IN 1700 DIAGRAMS MANUAL-60152700) | | | | | |
| 10099-A SPEED IMPROVEMENT REF/CE MANUAL REF INFO (USE 3300 COMPUTER SYSTEM REF MAN) OF INFO (SEE 3304-A OR 3304-B) | 60199800 | D | 22 | 02.90 | |
| 10103-A CEJ/MEJ FOR 6400/6500 COMPUTERS OF MANUAL | 60202100 | D | 22 | 01.65 | |
| REF INFO (USE 6000 REFERENCE MANUAL) | | | | | |
| 10104-A/B/C/D CENTRAL AND MONITOR EXCHANGE JUMPS FOR 6600 DESC,OPER,PROG,REF MANUAL | 60203200 | D | 22 | 01.00 | |

- 1.Publication number of literature
- 2.The latest revision level
- 3.Indicates number of holes punched in manual for use with hard cover ringed binder.

- 4.Price per manual.
5. Manual page count.

| TITLE | 1 | 2 | 3 | 4 | 5 |
|---|----------|---|----|-------|---|
| 10104-C/D (CE INFO - USE 6613-D CENTRAL MEMORY CE MANUAL - 60246600) | | | | | |
| 10115-A REFERENCE MANUAL | 60180200 | A | 22 | 02.25 | |
| 10121 (AT105-A) ACCESS CHANNEL REF INFO (USE 3500 REF MANUAL) | | | | | |
| 10123 (AT106-A, AT115-A) MEMORY PROTECT REF/CE INFO (USE AT106-A) | | | | | |
| 10124-A 6603 DISK SPEED INCREASE REFERENCE/CE MANUAL | 60227500 | A | 22 | 01.65 | |
| 10126 (GA103-A/B/C, GA104-A/B) TIME BASE SOURCE REFERENCE MANUAL | 41600900 | B | 22 | 01.50 | |
| 10127 (DK502-A) EXPANDED MEMORY OPTION REF INFO (USE 3316-1 REFERENCE MAN.) | | | | | |
| 10128 (DK501-A) DUAL MODE OPTION REFERENCE MANUAL | 41603000 | A | 22 | 01.00 | |
| 10169 CENTRAL MEMORY ACCESS PRIORITY FOR | | | | | |
| 6400/6500-A/B/C CENTRAL COMP. (USE AT129-A | | | | | |
| 6600 SERIALS 1-47 CENT. COMP. (USE AT131-A | | | | | |
| 6400/6500/6600-D CENT. COMP. (USE AT130-A) | | | | | |
| 10177-1 16K MEMORY INCREMENT FOR | | | | | |
| 6415-A/B/C COMPUTER SYSTEM (USE AT142-F) | | | | | |
| 6415-D COMPUTER SYSTEM (USE AT142-G) | | | | | |
| AA108-A COMPUTER SYSTEM (USE AT142-B) | | | | | |
| 10178-1 32K MEMORY INCREMENT FOR | | | | | |
| 6414/6514-A/B/C COMPUTER SYS (USE AT140-F) | | | | | |
| 6414/6514-D COMPUTER SYSTEM (USE AT140-H) | | | | | |
| AA105-A COMPUTER SYSTEM (USE AT140-B) | | | | | |
| 10179-1 16K MEMORY INCREMENT FOR | | | | | |
| 6615-D COMPUTER SYSTEM (USE RR365-B) | | | | | |
| 10180-1 32K MEMORY INCREMENT FOR | | | | | |
| 6614-A/B/C COMPUTER SYSTEM (USE AT168-G) | | | | | |
| 6614-D COMPUTER SYSTEM (USE AT168-J) | | | | | |
| AA103-A COMPUTER SYSTEM (USE AT168-B) | | | | | |
| 10194-1 (FV150-A) INTERNAL BCD TO ASCII HOLLERITH CONVERSION KIT FOR THE 3446-A/B CARD PUNCH CONTROLLER | | | | | |
| REF INFO (USE 3446-A/B REF MANUAL) | | | | | |
| CE INFO (USE FV150-A) | | | | | |
| 10194-2 (FV149-A) ASCII HOLLERITH TO BCD CONVERSION KIT FOR THE 3447-B CARD READER CONTROLLER | | | | | |
| REF INFO (USE 3248-A REF MANUAL) | | | | | |
| CE INFO (USE FV149-A) | | | | | |
| 10256-1 (AF101-B, AF104-A) 3200 BDP OPTION REFERENCE MANUAL | 60347700 | B | 22 | 09.75 | |
| 10256-1 AND 10287-3 OR 10289-1 AND 10256-3 REFERENCE MANUAL | 97402600 | A | 22 | | |
| CE INFO (USE AT146-A) | | | | | |
| 10256-2 (AF101-B, AF104-B) 3100 BDP INTERFACE OPTION REFERENCE MANUAL | 97401800 | A | 22 | 01.20 | |
| 10256-2 AND 10287-4 OR 10287-2 AND 10256-4 | | | | | |

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched in manual for use with hard cover ringed binder.

4. Price per manual.
5. Manual page count.

| TITLE | 1 | 2 | 3 | 4 | 5 |
|--|----------|----|----|-------|---|
| REFERENCE MANUAL CE INFO (USE AF107-A) 10285-1 () DUAL CHANNEL SWITCH OPTION GENERAL INFO (USE 7054-1) OPERATION AND PROGRAMMING (USE 7054-1) 10287-1 (AF105-A, BT193-A, CD124-A) 3200 ENHANCED BLOCK CONTROL OPTION REFERENCE MANUAL | 97402200 | A | 22 | 03.85 | |
| 10287-2 (3106-A/B, AF106-A, CD124-A) 3100 ENHANCED BLOCK CONTROL OPTION REFERENCE MANUAL | 97402400 | A | 22 | 03.60 | |
| 10293-1/2 (DT194-A, DT196-A) CHANNEL MODIFICATION REF/CF MANUAL | 97402000 | A | 22 | 01.80 | |
| 10308-2 (AT292-A, AT293-A) GO MODE/SDL 10309-1 (AT289-A, AT294-A) GO MODE/SDL-AC104 10309-2 (AT289-A, AT295-A) GO MODE/SDL-AC106 10336-1 (1784) REAL TIME CLOCK REF MANUAL 10339-1 (FA103-A) MASS STORAGE CONTROLLER REF INFO (USE 7639-1) | 60406300 | A | 22 | 17.00 | |
| 10348-1 (AT311-A) DATA CHANNEL CE INFO (USE AA106-A) REF INFO (USE CYBER 76 REF MANUAL PUBLICATION NO. 60367200) | 89638800 | 01 | 22 | 01.65 | |
| 10348-2 (AT312-A) DATA CHANNEL CE INFO (USE AA106-A) REF INFO (USE CYBER 76 REF MANUAL PUBLICATION NO. 60367200) | | | | | |
| (THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES.ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.) 10078-A 3306 TO 160/160-A INTERFACE REF/CE | 60166500 | A | 22 | | |
| SPECIAL OPTIONS | | | | | |
| 60002-A 161-S TYPEWRITER UNIT MANUAL MAPE105 | 60041500 | | | | |
| 60006-A 924 SPEED IMPRV.PKG (MAPE 245) | 60102200 | | | | |
| 60006-A 924-A SPEED IMPROV PKG(MAPE 245) | 60102700 | | | | |
| 60007 3637 DRUM CONTROLLER CE DIAGRAMS | 60184600 | | | | |
| 60008-A 8030 POWER FAILURE INTERRUPT(MAPE345 | 60120400 | | | | |
| 60009-A 3256 ERROR CHECKING REF/DIAGRAMS MAN | 60122800 | | | | |
| 60009-A 3256 LINE PRINTER ECHO CHECK C/P-E/S | 60142300 | | | | |
| 60014-A 165-2 REFERENCE/INSTP(MAPE 112) | 60113300 | | | 02.70 | |
| 60014/15-A (MAPE 111/114) CE DIAGRAMS | 60097200 | | 34 | 03.00 | |
| 60015-A 165-2 REFERENCE/INSTR(MAPE 113) | 60113300 | | | 02.70 | |
| 60016-A 160/160-A EXCHANGE UNIT REF. MANUAL | 36812800 | | 22 | 02.70 | |
| 60016-A 160/160-A CARD PL AND EQ SUMMARY | 36812900 | | | | |
| 60017-A 603/604/606/607 CHAN SWITCH CONSOLE | 60105200 | | | | |
| 60018-A 603/604/606/607 CHAN SWITCH CONSOLE | 60105200 | | | | |
| 60022 DATA CHANNEL CONVERTER | | | | | |

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4.Price per manual.
5. Manual page count.

| TITLE | 1 | 2 | 3 | 4 | 5 |
|--|----------|----|----|-------|---|
| CE MANUAL | 60390200 | | | | |
| 60026 REFERENCE/CE MANUAL | 38705100 | D | 22 | 04.40 | |
| 60028-A/B/C/D/E REFERENCE MANUAL | 60333700 | A | 22 | 01.20 | |
| CE MANUAL | 60390300 | A | | 22 | |
| 60029 405 CARD READER CONTROLLER REF MANUAL | 60333800 | A | 22 | 01.00 | |
| CE MANUAL | 60390400 | A | 22 | | |
| 60031 (CE601-A, CE602-A) 45 COLUMN CARD READ MODIFICATION | | | | | |
| 60032-A 3604 DIAGRAMS PAGE 186 | 60042100 | AT | 34 | 08.45 | |
| 60064-A REFERENCE/CE MANUAL | 60201300 | | | 03.10 | |
| 60076 CE MANUAL (2321 DATA CELL ADAPTOR FOR 3234 MASS STORAGE SUBSYSTEM) | 60197400 | | | 06.45 | |
| 60118 MAGNETIC TAPE TRANSPORT MAINT, DIAGS. | 41240200 | B | 22 | 01.45 | |
| 60126 3000/7000 DATA CHANNEL ADAPTER | 60296900 | A | 22 | 08.40 | |
| 65005 DATA SET ADAPTER MODULE TESTER REF/ CE MANUAL | 41607700 | D | 22 | 04.10 | |
| 65006 (GK111-A) TAPE EXERCISER SPECIAL OPTION 68091 INTRO. OPER. PROG. INSTL. CHKOUT., PRINCIPLES OF OPER., MAINT. DIAGS, W/L EQ SUM. PARTS DATA CE MANUAL | 44977000 | C | 22 | 02.90 | |
| 65075 (DC401-A) MASS STORAGE EXTENDER | | | | | |
| 65102 () BUS PARITY CHECKING CE INFO (USE AT281-A IN SECTION 1) | | | | | |
| (THE FOLLOWING MANUALS FOR THE ABOVE PRODUCT ARE AVAILABLE ON A SPECIAL ORDER BASIS IN MAX. QTY OF 2 COPIES. ALLOW AT LEAST 3-4 WEEKS FOR PROCESSING AND DELIVERY.) | | | | | |
| 60013-A 3200 STORAGE MOD CONNECTOR (MAPE 298) | 35076500 | | | | |
| 60016-B MAINTENANCE SUPPLEMENT | 60196100 | | | | |
| 60022 DATA CHANNEL CONVERTER 170 MODIFICATION REFERENCE MANUAL | 60334700 | A | | | |
| 1612 MODIFICATION REFERENCE MANUAL | 60334800 | A | | | |
| 60028-A/B/C/D/E CE MANUAL | 60390300 | A | | | |
| 60029 405 CARD READER CONTROLLER CE MANUAL | 60390400 | A | | | |
| 60032-A 3604-A/B BILLABLE TIME METER SUPPL | 17632300 | | | | |
| CYBERNET PUBLICATIONS | | | | | |
| 6400 KRONOS LIBRARY PROGRAMS | 86605900 | D | 3 | 07.90 | |
| 6000 CYBERNET SCOPE 3.3 REFERENCE MANUAL | 86618000 | | 3 | 07.15 | |
| 6600 SCOPE 3.3 LIBRARY ROUTINES | 86607700 | A | 3 | 01.00 | |
| ADLPIPE-STATIC-THERMAL-DYNAMIC PIPE STRESS ANALYSIS USER INFORMATION MANUAL | 86602800 | B | 3 | 02.00 | |
| AID 6600 LEARNERS GUIDE SURVY ANALYSIS WITH QA-PAK-CYBERNET SERVICES | 86601800 | | 3 | 01.50 | |
| ANSYS EXAMPLES MANUAL | 76070900 | | 3 | 10.50 | |
| ANSYS INTRODUCTORY MANUAL | 84000900 | | 3 | 01.50 | |
| ANSYS USER INFORMATION MANUAL | 86616800 | C | 3 | 15.30 | |
| APT CYBERNET USER INFORMATION MANUAL | 84000500 | A | 3 | 02.00 | |

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4. Price per manual.
5. Manual page count.

| TITLE | 1 | 2 | 3 | 4 | 5 |
|--|----------|---|---|-------|---|
| APTURNS USER INFORMATION MANUAL | 84002100 | | 3 | 05.00 | |
| ATHENA - ON-LINE INTERACTIVE RETRIEVAL/ UPDATE LANGUAGE U.I.M. | 76071400 | A | 3 | 02.50 | |
| AUTOFLEX USER INFORMATION MANUAL | 84000800 | | 3 | 04.90 | |
| AVAS USER INFORMATION MANUAL | 00015100 | A | 3 | 01.50 | |
| BRIDGE ANALYSIS AND RATING SYSTEM MANUAL | 86618500 | | 3 | 07.50 | |
| CYBERNET SERVICES PROGRAM LIBRARY CATALOG | 86616900 | A | 3 | 02.00 | |
| CC-TEGAS3 - TEST GENERATION AND SIMULATION SYSTEM USER INFORMATION MANUAL | 76070700 | A | 3 | 05.00 | |
| CELS USER INFORMATION MANUAL | 86612300 | B | 3 | 07.15 | |
| CELS PROGRAM ABSTRACTS | 86612500 | | 3 | 01.00 | |
| CENSTAT-CENSUS STATISTICS-GENERAL INFORMATION MANUAL | 86603700 | | 3 | 01.00 | |
| CENSTAT TEMPLATE | 86613500 | | | 00.50 | |
| CIVCO USER INFORMATION MANUAL | 86603000 | B | 3 | 04.00 | |
| CONTROL 2000 DEMONSTRATION SCRIPT | 84003700 | | 3 | 01.00 | |
| CRYSPEAK-CRYSTALLOGRAPHY PACKAGE USER INFO | 86605600 | A | 3 | 04.50 | |
| CYBER 70/MODFL 76 TERMINAL USERS GUIDE | 76072700 | | 3 | 01.00 | |
| CYBERLOAN GENERAL INFORMATION MANUAL | 86616100 | A | 3 | 02.25 | |
| CYBERNET/KRONOS 2.0 TO 2.1 CONVERSION GUIDE | 84002600 | | 3 | 02.00 | |
| CYBERNET/KRONOS 2.1 BASIC PROGRAMMING LANGUAGE REFERENCE MANUAL | 84001900 | A | 3 | 03.00 | |
| CYBERNET/KRONOS 2.1 BATCH AND REMOTE BATCH REFERENCE MANUAL | 84000600 | | 3 | 10.90 | |
| CYBERNET/KRONOS 2.1 TIME-SHARING FORTRAN REFERENCE MANUAL | 84001700 | B | 3 | 03.00 | |
| CYBERNET/KRONOS COMPILER SUBROUTINE AND SYSTEM UTILITY SUPPLEMENT | 84002000 | A | 3 | 01.50 | |
| CYBERNET/KRONOS PROCEDURE FILES REFERENCE | 84001000 | A | 3 | 03.00 | |
| CYBERNET/KRONOS TIME-SHARING USERS REFERENCE | 84001800 | | 3 | 03.00 | |
| CYBERNET/PROSE CALCULUS OPERATIONS MANUAL | 84003200 | A | 3 | 03.50 | |
| CYBERNET/PROSE DEBUGGING OPERATIONS MANUAL | 84003100 | | 3 | 01.00 | |
| CYBERNET/PROSE PROCEDURAL OPERATIONS MANUAL | 84003000 | A | 3 | 02.00 | |
| CYBERNET/PROSE SYSTEM GUIDE | 84002900 | A | 3 | 02.20 | |
| DCO/TRANPLAN USER INFORMATION MANUAL | 86615700 | | 3 | 09.00 | |
| DD-PLOT USER INFORMATION MANUAL | 86618400 | | 3 | 02.50 | |
| DECIDER USER INFORMATION MANUAL | 86602900 | A | 3 | 01.00 | |
| DISSPLA BEGINNERS USER INFORMATION MANUAL | 84001200 | | 3 | 03.50 | |
| DISSPLA CYBERNET SUPPLEMENT | 84001400 | | 3 | 01.00 | |
| DISSPLA INTERMEDIATE USER INFORMATION MANUAL | 84001300 | | 3 | 03.00 | |
| DISSPLA ADVANCED USER INFORMATION MANUAL | 84001500 | | 3 | 06.40 | |
| EAC/EASE-ELASTIC ANALYSIS FOR STRUCTURAL ENGINEERING-GENERAL INFORMATION MANUAL | 86603100 | A | 3 | 01.00 | |
| EAC/EASE-ELASTIC ANALYSIS FOR STRUCTURAL ENGINEERING-USER INFORMATION MANUAL | 86603200 | B | 3 | 02.00 | |
| EAC/EASE-ELASTIC ANALYSIS FOR STRUCTURAL ENGINEERING-DATA CARD DIGEST | 86603300 | A | 3 | 01.00 | |
| EAC/EASE-2 USER INFORMATION/THEORETICAL MAN | 84002700 | A | 3 | 03.50 | |
| E/CUBE ENERGY ANALYSIS CYBERNET SERVICE GUIDELINES | 86608900 | C | 3 | 01.00 | |
| EASE ADDENDUM A-ENGINEERING APPLICATIONS AND PROBLEM SOLUTIONS | 86607100 | | 3 | 02.35 | |
| EASE ADDENDUM B - THEORETICAL REFERENCES | 86607200 | | 3 | 03.90 | |

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4. Price per manual.
5. Manual page count.

| TITLE | 1 | 2 | 3 | 4 | 5 |
|--|----------|---|---|-------|---|
| ELECTRICAL ENGINEERING APPLICATION GUIDE | 86619700 | | 3 | 01.00 | |
| FAAST USER INFORMATION MANUAL | 84009800 | | 3 | 02.50 | |
| FASTIME/LOADFLOW POWER SYSTEM ANALYSIS U.I.M | 76071200 | | 3 | 03.40 | |
| FINITE ELEMENT LEARNERS GUIDE | 86616600 | | 3 | 01.00 | |
| GENERAL ACCOUNTING APPLICATIONS APRIL MINI-MANUAL | 86613800 | | | 01.35 | |
| GENERAL ACCOUNTING APPLICATIONS GENERAL LEDGER SYSTEMS MINI-MANUAL | 86613600 | | | 01.35 | |
| GENERAL ACCOUNTING APPLICATIONS PAYROLL MINI-MANUAL | 86613700 | | | 01.35 | |
| GENERAL PURPOSE SIMULATION SYSTEM GIM | 84003900 | A | 3 | 02.00 | |
| GENSAP USER INFORMATION MANUAL | 86619900 | B | 3 | 02.00 | |
| GINA-GENERATE INPUT FOR CDC/NASTRAN UIM | 84006700 | | 3 | 01.00 | |
| IFMS-INTERACTIVE FINANCIAL MODELING SYST.UIM | 76070400 | | 3 | 01.00 | |
| INIS-INTERACTIVE INTERFACE TO SCOPE USERS GUIDE | 84002800 | | 3 | 01.00 | |
| KRONOS TIME-SHARING TUTORIAL MANUAL | 86615800 | C | 3 | 04.50 | |
| LOADFLOW-POWER SYSTEM PLANNING PROGRAM USER INFORMATION MANUAL | 86604600 | | 3 | 02.00 | |
| MAGEN 6000 USER INFORMATION MANUAL | 86604700 | A | 3 | 02.00 | |
| MARC I SHADOW/SHADE TERMINAL USERS GUIDE | 86607800 | A | 3 | 09.50 | |
| MARC II SHADOW/SHADE TERMINAL USERS GUIDE | 86607900 | | 3 | 09.50 | |
| MARC II TERMINAL-EXPORT/IMPORT TERMINAL USER GUIDE OPERATING SYSTEM REFERENCE LIBRARY | 86606100 | A | 3 | 01.50 | |
| MARC-CDC USER INFORMATION MANUAL VOL 1 | 17309500 | F | 3 | 05.50 | |
| MARC-CDC USER INFORMATION MANUAL VOL II PROGRAM INPUT | 17311600 | E | 3 | 05.50 | |
| MARC-CDC USER INFORMATION MANUAL VOL III DEMONSTRATION PROBLEMS | 17311700 | F | 3 | 05.50 | |
| MARS VI REFERENCE MANUAL | 76070100 | | 3 | 04.50 | |
| MATH PROGRAM GENERAL INFORMATION-CYBERNET SERVICES | 86614100 | | 3 | 01.00 | |
| MATH SCIENCE LIBRARY CYBERNET USER GUIDE | 86612100 | | 3 | 01.00 | |
| MEDISHARP GENERAL INFORMATION MANUAL | 39771300 | A | 3 | 01.50 | |
| MEDISHARP PATIENT ACCOUNTING | 86618900 | | 3 | 03.50 | |
| MTIAS USER INFORMATION MANUAL | 86615000 | A | 3 | 07.50 | |
| MRI/STARDYNE-FINITE ELEMENT DEMONSTRATION PROBLEMS | 84002500 | | 3 | 01.00 | |
| MRI/STARDYNE-DYNAMIC STRUCTURAL ANALYSIS SYSTEM-USER INFORMATION MANUAL | 86603500 | D | 3 | 08.65 | |
| MRI/STARDYNE THEORETICAL MANUAL | 86616300 | A | 3 | 09.75 | |
| NAR/SYSCAP-SYSTEM OF CIRCUIT ANALYSIS PROGRAMS-(DOMESTIC) SOLD IN SETS ONLY | 86602000 | | | 14.00 | |
| NAR/SYSCAP-SYSTEM OF CIRCUIT ANALYSIS PROGRAMS-(INTERNATIONAL)SOLD IN SETS ONLY | 86602300 | | 3 | 13.80 | |
| NASTRAN APPLICATIONS MANUAL - FRONT MATTER | 86616700 | K | 3 | 11.10 | |
| NASTRAN-NASA STRUCTURAL ANALYSIS BASIC TRAINING MANUAL | 86612600 | A | 3 | 02.00 | |
| NASTRAN-GENERAL INFORMATION MANUAL | 86614300 | A | 3 | 01.00 | |
| NASTRAN-TECHNICAL ARTICLES | 86619600 | | 3 | 01.00 | |
| NETFLOW II-NETWORK FLOW ROUTINE U.I.M. | 86604900 | | 3 | 02.75 | |
| PDQ/LP-RAPID LINEAR PROGRAMMING SYSTEM USER INFORMATION MANUAL | 86604800 | | 3 | 01.00 | |

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched in manual for use with hard cover ringed binder.

4. Price per manual.
5. Manual page count.

| TITLE | 1 | 2 | 3 | 4 | 5 |
|--|----------|---|---|-------|---|
| PDS/MAGEN - A GENERAL PURPOSE PROBLEM DESCRIPTOR SYSTEM UIM | 84009900 | A | 3 | 02.50 | |
| PERSONNEL DEMO SCRIPT | 84003800 | | 3 | 01.00 | |
| PIPFLEX USER MANUAL SUPP. CYBERNET SERVICE | 86615100 | | 3 | 01.00 | |
| PMCS USER INFORMATION MANUAL | 86615500 | D | 3 | 04.00 | |
| PPS IV PROJECT PLANNING SYSTEM GENERAL INFORMATION MANUAL | 86608400 | | 3 | 01.00 | |
| PPS IV PROJECT PLANNING SYSTEM USER INFORMATION MANUAL | 86608500 | A | 3 | 03.00 | |
| PIPFLEX-PIPING FLEXIBILITY ANALYSIS-USER INFORMATION MANUAL | 86614200 | | 3 | 01.00 | |
| PIPFLEX-CYBERNET USER INFORMATION MANUAL | 84000100 | A | 3 | 04.00 | |
| PRICE SCHEDULE FOR CYBERNET SERVICE (FOR CDC USE ONLY) | 86608000 | C | 3 | 01.00 | |
| PISCES IDL MANUAL A USER INFORMATION MANUAL | 86617100 | B | 3 | 01.00 | |
| PISCES IDL MANUAL B USER INFORMATION MANUAL | 86617200 | A | 3 | 03.50 | |
| PISCES IDL MANUAL C USER INFORMATION MANUAL | 86617300 | B | 3 | 01.50 | |
| PISCES IDL MANUAL D USER INFORMATION MANUAL | 86617400 | A | 3 | 01.00 | |
| PISCES 2DL MANUAL A USER INFORMATION MANUAL | 86617500 | A | 3 | 01.00 | |
| PISCES 2DL MANUAL B USER INFORMATION MANUAL | 86617600 | A | 3 | 03.50 | |
| PISCES 2DL MANUAL C USER INFORMATION MANUAL | 86617700 | B | 3 | 01.50 | |
| PISCES GEOMETRIC RATIOS USER INFORMATION MAN | 86617900 | | 3 | 02.50 | |
| PI/PLOT-USER INFORMATION MANUAL | 86618300 | | 3 | 01.00 | |
| PLOT 10 TERMINAL CONTROL SYSTEM USER INFO | 84002400 | | 3 | 02.00 | |
| A PRIMER TO QUESTAIRE AND MARKETING RESEARCH DATA PROCESSING TECHNIQUES | 86607500 | A | 3 | 01.00 | |
| QUESTIONNAIRE ANALYSIS PACKAGE-COMPTRAN LEARNERS GUIDE | 86601700 | | 3 | 01.00 | |
| QUESTIONNAIRE ANALYSIS-MARGINAL LEARNERS GUIDE | 86601600 | | 3 | 01.00 | |
| QUESTIONNAIRE ANALYSIS PACKAGE-GENERAL INFORMATION MANUAL | 86604300 | A | 3 | 01.00 | |
| QUESTAIRE II GENERAL INFORMATION MANUAL | 86604100 | A | 3 | 01.00 | |
| QUESTAIRE II USERS INFORMATION MANUAL | 86604200 | C | 3 | 03.00 | |
| RISK ANALYSIS USERS INFORMATION MANUAL | 86604000 | A | 3 | 03.15 | |
| SCOPE VERSION 3.3 TO VERSION 3.4 CONVERSION AIDS | 84000700 | | 3 | 01.50 | |
| SCPLOT USER INFORMATION MANUAL | 84000000 | | 3 | 01.00 | |
| SIMULATORS-1130 (II) SIMULATION OF A MARC II TERMINAL-F/I 200 TERMINAL USER GUIDE | 86606200 | A | 3 | 03.10 | |
| SPECIAL ADDENDUM FOR EASE (ELASTIC ANALYSIS FOR STRUCTURAL ENGINEERING) | 86607000 | | 3 | 01.00 | |
| SPSS/ON LINE KRONOS VER2.1 U.T.M. | 84009600 | | 3 | 01.00 | |
| SYSCAP TUTORIAL INTRODUCTION GUIDE TO BEGINNER USERS | 84000400 | | 3 | 06.00 | |
| SYSCAP II-SYSTEMS OF CIRCUIT ANALYSIS PROGRAMS USER INFORMATION MANUAL | 76070600 | | 3 | 07.15 | |
| SYSTEM 2000 LEVEL 2 - A MULTI-PURPOSE DATA MANAGEMENT SYSTEM | | | | | |
| DIAGNOSTIC MESSAGE SUPPLEMENT | 76074300 | | 3 | 01.50 | |
| FORTRAN PROCEDURAL LANGUAGE SUPPLEMENT | 76074600 | | 3 | 02.00 | |
| IMMEDIATE ACCESS FEATURE SUPPLEMENT | 76074400 | | 3 | 02.00 | |
| REPORT WRITER FEATURE SUPPLEMENT | 76074700 | | 3 | 02.00 | |

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4. Price per manual.
5. Manual page count.

| TITLE | 1 | 2 | 3 | 4 | 5 |
|--|----------|---|---|-------|---|
| USER INFORMATION MANUAL | 76074000 | | 3 | 04.00 | |
| TESS USER INFORMATION MANUAL | 86615900 | | 3 | 05.00 | |
| TESS GENERAL INFORMATION MANUAL | 86618200 | | 3 | 01.00 | |
| TESS-TTY USER INFORMATION MANUAL | 84001100 | | 3 | 01.00 | |
| TOTAL-CDC REFERENCE MANUAL | 76070300 | | 3 | 03.50 | |
| XEDIT - EXTENDED KRONOS TEXT EDITOR U.I.M. | 76071000 | | 3 | 01.50 | |
| ***** | | | | | |
| STRU-PAK - STRUCTURAL ANALYSIS PACKAGE | | | | | |
| MASTER INSTRUCTION GUIDE | 86608600 | C | 3 | 01.00 | |
| PROGRAM ABSTRACTS | 86608700 | B | 3 | 01.00 | |
| ** USER INFORMATION MANUALS | | | | | |
| CENSECT - PLANAR SECTION PROPERTIES OF ARBITRARY CROSS SECTIONS | 86609000 | | 3 | 01.00 | |
| STANSECTP - PLANAR SECTION PROPERTIES OF STANDARD CROSS SECTIONS | 86609100 | | 3 | 01.00 | |
| BEAMCOL - BENDING ANALYSIS OF VARIABLE CROSS-SECTION BEAM COLUMNS | 86609200 | A | 3 | 01.00 | |
| STANBEAM - BENDING ANALYSIS OF VARIABLE CROSS-SECTION BEAMS | 86609400 | A | 3 | 01.00 | |
| MULTISPAN - BENDING ANALYSIS OF MULTISPAN BEAMS | 86609500 | | 3 | 01.00 | |
| ELASTCOL - ELASTIC STABILITY OF END LOADED COLUMNS | 86609300 | A | 3 | 01.00 | |
| INRING - ELASTIC ANALYSIS OF RINGS WITH INPLANE LOADS | 86609600 | A | 3 | 01.00 | |
| OUTRING - ELASTIC ANALYSIS OF RINGS WITH OUT-OF-PLANE LOADS | 86609700 | | 3 | 01.00 | |
| 2DGENFRAME - TWO-DIMENSIONAL GENERAL FRAME ANALYSIS PROGRAM | 86609800 | B | 3 | 01.00 | |
| 2DFSAP-TWO-DIMENSIONAL STRUCTURAL ANALYSIS PROGRAM | 86609900 | B | 3 | 01.00 | |
| 3DFSAP-THREE-DIMENSIONAL STRUCTURAL ANALYSIS PROGRAM | 86610000 | B | 3 | 01.00 | |
| GRIDSAP - GRID STRUCTURAL ANALYSIS PROGRAM | 86610100 | A | 3 | 01.00 | |
| 2DTSAP - TWO-DIMENSIONAL TRUSS STRUCTURAL ANALYSIS PROGRAM | 86610200 | B | 3 | 01.00 | |
| 3DTSAP -THREE-DIMENSIONAL TRUSS STRUCTURAL ANALYSIS PROGRAM | 86610300 | B | 3 | 01.00 | |
| CIRCPLAT - BENDING ANALYSIS OF CIRCULAR PLATES | 86610400 | A | 3 | 01.00 | |
| HUBFLAGI - DESIGN AND ANALYSIS OF BOLTED FLANGE CONNECTIONS-INTEGRAL TYPE | 86610500 | | 3 | 01.00 | |
| STIFSHLL - BUCKLING OF ORTHOTROPIC SHELLS | 86610600 | | 3 | 01.00 | |
| CRITSPEED - CRITICAL SPEEDS ANALYSIS OF ROTATING SHAFTS | 86610700 | | 3 | 01.00 | |
| 2DFMAP - TWO-DIMENSIONAL FRAME MODAL ANALYSIS PROGRAM | 86610800 | B | 3 | 01.00 | |
| 3DFMAP - THREE DIMENSIONAL FRAME MODAL ANALYSIS PROGRAM | 86610900 | C | 3 | 01.00 | |
| GRIDMAP - GRID MODAL ANALYSIS PROGRAM | 86611000 | A | 3 | 01.00 | |

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched
in manual for use with hard cover
ringed binder.

4.Price per manual.
5. Manual page count.

| TITLE | 1 | 2 | 3 | 4 | 5 |
|---|----------|---|---|-------|---|
| 2DTMAP - TWO-DIMENSIONAL TRUSS MODAL ANALYSIS PROGRAM | 86611100 | B | 3 | 01.00 | |
| 3DTMAP - THREE-DIMENSIONAL TRUSS MODAL ANALYSIS PROGRAM | 86611200 | B | 3 | 01.00 | |
| DYNROSS - DYNAMIC RESPONSE OF SIMPLE SYSTEMS | 86611300 | | 3 | 01.00 | |
| SHOCSPEC - SHOCK SPECTRA ANALYSIS OF A SINGLE-DEGREE-OF-FREEDOM SYSTEM | 86611400 | A | 3 | 01.00 | |
| SINSPONS - SINUSOIDAL RESPONSE OF A MULTI-DEGREE-OF-FREEDOM SYSTEM | 86611500 | A | 3 | 01.00 | |
| RELSPRING - DESIGN AND ANALYSIS OF BELLEVILLE SPRINGS | 86611600 | A | 3 | 01.00 | |
| COMSPRING - DESIGN AND ANALYSIS OF HELICAL COMPRESSION SPRINGS | 86611700 | | 3 | 01.00 | |
| TESTRAIN - STRAIN GAGE DATA REDUCTION AND ANALYSIS | 86611800 | | 3 | 01.00 | |
| TORCELL - TORSIONAL ANALYSIS OF SINGLE CELLAR MULTICELLULAR SECTIONS | 86611900 | | 3 | 01.00 | |
| COMPLETE STRU-PAK COLLECTION WITH BINDER AND TABS | 86612000 | | 3 | 21.75 | |
| STRU-PAK PROCESSING COSTS MANUAL | 86614000 | | 3 | 01.00 | |
| SYSTEM 2000 (LEVEL II) MTNI-MANUAL | 86615600 | B | | 01.35 | |
| TRANPLAN II GENERAL INFORMATION MANUAL | 86614400 | | 3 | 02.50 | |
| S-RAY 70-X-RAY SYSTEM OF CRYSTALLOGRAPHIC PROGRAMS USER INFORMATION PROGRAM | 86605700 | | 3 | 04.65 | |
| ZIPTRAN USER INFORMATION MANUAL | 86614600 | | 3 | 03.25 | |
| LIBRARY OF MATH SUBPROGRAMS - USER INFORMATION MANUAL | 86614900 | A | 3 | 02.00 | |
| ***** | | | | | |
| SYSTEMS PROFESSIONAL PACKAGE | | | | | |
| COMPLETE SYSTEMS PROFESSIONAL PACKAGE (INCLUDING BINDER AND TABS) | 84006800 | | 3 | 27.65 | |
| *** USERS GUIDES | | | | | |
| SYSTEMS PROFESSIONAL MASTER USER INFORMATION AND OPERATIONAL INSTRUCTIONS USERS GUIDE | 84006900 | | 3 | 01.00 | |
| CONCRETE COLUMN ULTIMATE STRENGTH DESIGN | 84007000 | | 3 | 01.00 | |
| NON-PRISMATIC CONTINUOUS BEAM DESIGN SERIES | 84007100 | | 3 | 02.50 | |
| RETAINING WALL DESIGN WORKING STRENGTH | 84007200 | | 3 | 01.00 | |
| PRISMATIC CONTINUOUS BEAM DESIGN SERIES | 84007300 | | 3 | 03.00 | |
| PRESTRESSED CONCRETE BEAM DESIGN SERIES | 84007400 | | 3 | 01.00 | |
| FLAT PLATE AND FRAME ANALYSIS AND DESIGN | 84007500 | | 3 | 01.50 | |
| FOOTING DESIGN SERIES-RECTANGULAR OR COMBINED FOOTING DESIGN | 84007600 | | 3 | 01.00 | |
| STEEL COLUMN INVESTIGATION AND DESIGN | 84007700 | | 3 | 01.00 | |
| STEEL BEAM INVESTIGATION AND DESIGN SERIES | 84007800 | | 3 | 01.00 | |
| COMPOSITE STEEL BEAM INVESTIGATION AND D.S. | 84007900 | | 3 | 01.00 | |
| COLUMN BASE PLATE DESIGN | 84008000 | | 3 | 01.00 | |
| WELDED STEEL GIRDER INVESTIGATION AND DESIGN | 84008100 | | 3 | 01.00 | |
| MASONRY, BLOCK OR CONCRETE SHEAR WALL AND PEIP DESIGN | 84008200 | | 3 | 01.00 | |

1.Publication number of literature
2.The latest revision level
3.Indicates number of holes punched in manual for use with hard cover ringed binder.

4.Price per manual.
5. Manual page count.

| TITLE | 1 | 2 | 3 | 4 | 5 |
|--|----------|---|---|-------|---|
| MASONRY, BLOCK OR CONCRETE BEARING WALL DESIGN | 84008300 | | 3 | 01.00 | |
| SAWN TIMBER BEAM DESIGN | 84008400 | | 3 | 01.00 | |
| GLU-LAM TIMBER BEAM DESIGN | 84008500 | | 3 | 01.00 | |
| REGULAR RIGID FRAME ANALYSIS | 84008600 | | 3 | 01.00 | |
| SHEAR WALL-FRAME INTERACTION ANALYSIS | 84008700 | | 3 | 01.00 | |
| MULTI-STORY COLUMN LOAD TAKE-OFF TABULATION | 84008800 | | 3 | 01.00 | |
| SPSTRESS-GENERAL STRUCTURAL SYSTEMS ANALYSIS | 84008900 | | 3 | 02.00 | |
| SIMPLE SPAN BEAM ANALYSIS OPTIONAL CANTILEVR | 84009000 | | 3 | 01.00 | |
| MULTI-STORY WIND OR EARTHQUAKE ROTATIONAL ANALYSIS | 84009100 | | 3 | 02.00 | |
| SMALL RIGID FRAME ANALYSIS | 84009200 | | 3 | 01.00 | |
| DETERMINE TRUSS ANALYSIS | 84009300 | | 3 | 01.00 | |
| THE TWO ITEMS BELOW ARE NOT INCLUDED IN THE COMPLETE PACKAGE AND MUST BE ORDERED SPTLY | | | | | |
| MODIFIED PCA FLAT PLATE, FLAT SLAB, WAFFLE SLAB AND FRAME ANALYSIS AND DESIGN USERS GD | 84009400 | | 3 | 01.50 | |
| SYSTEMS PROFESSIONAL PROGRAMS COST GUIDE USFR COST GUIDE | 76070800 | | 3 | 01.00 | |
| ***** | | | | | |
| LEAHS PRODUCT DESCRIPTION MANUALS | | | | | |
| LEAHS PHASE III OVERVIEW | 84004300 | | 3 | 01.00 | |
| PWR SEQUENCE OVERVIEW | 84004000 | | 3 | 01.00 | |
| BWR SEQUENCE OVERVIEW | 84004200 | | 3 | 01.00 | |
| PWR BENCHMARKING | 84005800 | | 3 | 01.00 | |
| LEAHS INDIVIDUAL CODE MANUALS | | | | | |
| CHEETAH-P | 84004100 | | 3 | 03.00 | |
| NAIHYDRO-B | 84004400 | | 3 | 01.00 | |
| NAIHYDRO-P | 84004500 | | 3 | 01.00 | |
| FIT | 84004600 | | 3 | 01.00 | |
| SHUFFLE | 84004700 | | 3 | 03.25 | |
| INTREGAL | 84004800 | | 3 | 02.00 | |
| EDIT-C | 84004900 | | 3 | 01.00 | |
| EXPAND | 84005000 | | 3 | 01.00 | |
| PUNCHER-P | 84005100 | | 3 | 01.00 | |
| PD07LEAHS | 84005200 | | 3 | 03.35 | |
| MODEL | 84005300 | | 3 | 01.00 | |
| COPC-BLADE | 84005400 | | 3 | 01.00 | |
| NAI LASER | 84005500 | | 3 | 01.00 | |
| COPC-PTN | 84005600 | | 3 | 01.00 | |
| NAI 30-P | 84005700 | | 3 | 02.00 | |
| PUNCHER-B | 84005900 | | 3 | 01.00 | |
| DPFFIT | 84006000 | | 3 | 01.00 | |
| CHEETAH-B | 84006200 | | 3 | 01.00 | |
| NAI 30-B | 84006300 | | 3 | 01.50 | |

1. Publication number of literature
2. The latest revision level
3. Indicates number of holes punched in manual for use with hard cover ringed binder.

4. Price per manual.
5. Manual page count.

| TITLE | 1 | 2 | 3 | 4 | 5 |
|--|--|---|-------------------|----------------------------------|---|
| ***** CYBERNET SERVICES BINDERS 1 INCH,3 RING,CYBERNET,LIGHT BLUE BINDER 1 1/2 INCH,3 RING,CYBERNET,LIGHT BLUE BINDER 2 INCH,3 RING,CYBERNET,LIGHT BLUE BINDER 4 INCH,NYLON POST,RED,SYSTEMS PROFESSIONAL BINDER | 60089100 60089200 60089300 60089400 | | 3 3 3 2P | 04.00 04.40 04.70 06.50 | |

1.Publication number of literature
 2.The latest revision level
 3.Indicates number of holes punched
 in manual for use with hard cover
 ringed binder.

4.Price per manual.
 5. Manual page count.