


# PATHWORKS for VMS

---

digital

Server Master Index



# PATHWORKS for VMS

---

## Server Master Index

Order Number: AA-PF41B-TK

**September 1991**

**Revision/Update Information:** This document supersedes  
Server Master Index, order number  
AA-PF41A-TK.

**Software Version:** PATHWORKS for VMS Version 4.1 or  
higher

**Digital Equipment Corporation  
Maynard, Massachusetts**

---

**First Published, December 1989**  
**Revised, January 1991, September 1991**

The information in this document is subject to change without notice and should not be construed as a commitment by Digital Equipment Corporation. Digital Equipment Corporation assumes no responsibility for any errors that may appear in this document.

The software described in this document is furnished under a license and may be used or copied only in accordance with the terms of such license.

No responsibility is assumed for the use or reliability of software on equipment that is not supplied by Digital Equipment Corporation or its affiliated companies.

Restricted Rights: Use, duplication, or disclosure by the U.S. Government is subject to restrictions as set forth in subparagraph (c)(1)(ii) of the Rights in Technical Data and Computer Software clause at DFARS 252.227-7013.

© Digital Equipment Corporation 1989, 1991.

All rights reserved.  
Printed in U.S.A.

The postpaid Reader's Comments form at the end of this document requests your critical evaluation to assist in preparing future documentation.

The following are trademarks of Digital Equipment Corporation:

DDCMP, DDIF, DEC, DECconnect, DECmate, DECnet, DECnet-DOS, DECrouter, DECserver, DECstation, DECwindows, DECwrite, DELNI, DEMPR, DEPCA, DESTA, DNA, EtherWORKS, LA50, LA75 Companion, LAT, LN03, LN03 PLUS, LN03 ScriptPrinter, METROWAVE, MicroVAX, PATHWORKS, PrintServer, ReGIS, RMS-11, RSX, RSX-11, RT, RT-11, RX33, ThinWire, TK, ULTRIX, VAX, VAX Notes, VAXcluster, VAXmate, VAXserver, VAXshare, VMS, VT, WPS, WPS-PLUS, and the DIGITAL logo.

The following are third-party trademarks:

HP is a registered trademark of Hewlett-Packard Corporation. IBM, Proprinter, and OS/2 are registered trademarks of International Business Machines Corporation. Silentwriter is a registered trademark of NEC Technologies, Incorporated. Epson is a registered trademark of Seiko Epson Corporation.

This document was prepared with VAX DOCUMENT, Version 1.2.

---

**HOW TO ORDER ADDITIONAL DOCUMENTATION  
DIRECT MAIL ORDERS**

**USA\***

Digital Equipment Corporation  
P.O. Box CS2008  
Nashua, New Hampshire 03061

**CANADA**

Digital Equipment  
of Canada Ltd.  
100 Herzberg Road  
Kanata, Ontario K2K 2A6  
Attn: Direct Order Desk

**INTERNATIONAL**

Digital Equipment Corporation  
PSG Business Manager  
c/o Digital's local subsidiary  
or approved distributor

In Continental USA, Alaska, and Hawaii call 800-DIGITAL.

In Canada call 800-267-6215.

\* Any order from Puerto Rico must be placed with the local Digital subsidiary (809-754-7575).

Internal orders should be placed through the Software Distribution Center (SDC), Digital Equipment Corporation, Westminister, Massachusetts 01473.

---



---

# Preface

The *Server Master Index* is a compilation of indexes from the manuals in the PATHWORKS for VMS documentation set. The *Server Master Index* directs you to the manual or manuals that contain the information you are looking for.

To keep entries concise, the names of the manuals are abbreviated, as shown in Table 1.

**Table 1 Manual Names and Abbreviations**

<b>Title of Manual</b>	<b>Abbreviation</b>
<i>Server Installation Guide</i>	<i>ServInstall</i>
<i>Server Administrator's Guide</i>	<i>ServAdmin</i>
<i>Server Administrator's Commands Reference</i>	<i>ServCmds</i>
<i>Server Messages</i>	<i>ServMsgs</i>
<i>Network Troubleshooting Guide</i>	<i>NetTrouble</i>



---

# Master Index

## A

---

- Access control entries (ACEs),
  - ServAdmin*, 3-2
- Access control lists (ACLs), *ServAdmin*, 1-5, 3-2
- Access to files
  - See also* PCDISK utility
  - See also* RMS protection
  - and RMS protection, *ServAdmin*, 1-5
  - in application file services, *ServAdmin*, 3-2
  - in common file services, *ServAdmin*, 3-3
  - in file services, *ServAdmin*, 1-5
  - in virtual disks, *ServAdmin*, 5-17
- Access to services
  - See also* Security
  - changing, *ServAdmin*, 3-18
  - denying, *ServAdmin*, 3-16, 3-18, 3-19
  - disk services, *ServAdmin*, 5-12
  - for disk services, *ServAdmin*, 1-3, 5-2, 5-3
  - for file services, *ServAdmin*, 3-1
  - for printer services, *ServAdmin*, 4-5
  - for users, *ServAdmin*, 1-5, 1-6, 3-19
  - granting, *ServAdmin*, 3-16, 3-18, 3-19
  - group, *ServAdmin*, 1-6, 3-18
  - listing for file services, *ServAdmin*, 3-17
  - modifying, *ServAdmin*, 5-12
  - public, *ServAdmin*, 1-6, 3-17, 3-18
  - restricting with group codes, *ServAdmin*, 7-10
- Access to services (Cont.)
  - with default account, *ServAdmin*, 6-15
- Accounts
  - See* Default account
  - See* VMS accounts
- Actual length, *ServAdmin*, 3-20, A-4
  - term defined, *ServAdmin*, 3-13
- ADA programs
  - creating files compatible with file server, *ServAdmin*, A-5
- Add a Printer Queue option (PCSA Manager Menu), *ServCmds*, 1-20
- ADD GROUP command (PCSA Manager), *ServCmds*, 1-8
- Adding
  - application disk services, *ServAdmin*, 5-3
  - application file services, *ServAdmin*, 3-8
  - common file services, *ServAdmin*, 3-6
  - disk services, *ServAdmin*, 5-7
  - file services, *ServAdmin*, 3-9, 3-11
  - file services with actual length, *ServAdmin*, 3-13
  - file services with RMS stream format, *ServAdmin*, 3-13
  - groups, *ServCmds*, 1-8; *ServAdmin*, 6-17
  - members to groups, *ServCmds*, 1-10; *ServAdmin*, 6-18
  - nodes to databases, *ServCmds*, 1-12; *ServAdmin*, 11-1
  - printer forms, *ServAdmin*, 4-11
  - printer services, *ServCmds*, 1-20; *ServAdmin*, 4-13
  - service to database, *ServCmds*, 1-14



## Adding (Cont.)

- template, *ServCmds*, 1-23
- users, *ServCmds*, 1-25; *ServAdmin*, 6-2
- users to groups, *ServAdmin*, 6-18
- workstations, *ServCmds*, 1-28
- ADD MEMBER command (PCSA Manager), *ServCmds*, 1-10
- ADD NODE command (PCSA Manager), *ServCmds*, 1-12
- ADD SERVICE/DIRECTORY command (PCSA Manager), *ServCmds*, 1-14; *ServAdmin*, 3-12, 3-13, 3-14
- ADD SERVICE/PRINTER command (PCSA Manager), *ServCmds*, 1-20
- ADD TEMPLATE command (PCSA Manager), *ServCmds*, 1-23
- ADD USER command (PCSA Manager), *ServCmds*, 1-25; *ServAdmin*, 6-12
- ADD WORKSTATION command (PCSA Manager), *ServCmds*, 1-28; *ServAdmin*, H-5
- Alias
  - term defined, *ServAdmin*, 3-20
- ALIAS MAXIMUM LINKS (DECnet), *NetTrouble*, 3-42
- Application data files
  - storing, *ServAdmin*, 1-8
- Application disk services
  - See also* Disk services
  - adding, *ServAdmin*, 5-3
  - selecting for user, *ServAdmin*, 6-5
- Application file services
  - See also* File services
  - access to, *ServAdmin*, 3-2
  - adding, *ServAdmin*, 3-8
  - contrasted with application disk services, *ServAdmin*, 1-7
  - contrasted with common file services, *ServAdmin*, 1-4, 1-9, 3-2
  - default access, *ServAdmin*, 3-18
  - default location for, *ServAdmin*, 3-11
  - selecting for user, *ServAdmin*, 6-4
- Applications
  - See also* Application file services

## Applications (Cont.)

- See also* Common file services
  - access by DOS and VMS users, *ServAdmin*, 1-8
  - adding to application file services, *ServAdmin*, 3-8
  - adding to common file services, *ServAdmin*, 3-6
  - adding to disk services, *ServAdmin*, 5-3, 5-7
  - and performance, *ServAdmin*, 8-2
  - and printer services, *ServAdmin*, 3-14, 3-16, 5-4
  - choosing disk or file services for, *ServAdmin*, 1-7
  - default location for, *ServAdmin*, 3-11
  - designed for local hard disk, *ServAdmin*, 1-8
  - guidelines for, *ServAdmin*, 1-7
  - installing, *ServAdmin*, 1-7, 3-14, 5-4
  - limiting users of, *ServAdmin*, 3-20, 5-2
  - program diskette for, *ServAdmin*, 5-5
  - redirecting data files in, *ServAdmin*, 1-8
  - security in, *ServAdmin*, 3-2
  - selecting for user, *ServAdmin*, 6-5
  - selecting languages for PCSA applications, *ServAdmin*, 6-6
  - storing, *ServAdmin*, 1-7
  - using in DOS and VMS, *ServAdmin*, 3-13, A-2, A-7
  - with fixed records, *ServAdmin*, 3-13
  - with licenses, *ServAdmin*, 1-8, 3-12, 5-2
- ARP command
    - DOS, *NetTrouble*, 4-10
    - ULTRIX, *NetTrouble*, 4-7
  - ARP storm
    - causes, *NetTrouble*, 3-19
  - ARP tables
    - inaccurate entries, *NetTrouble*, 6-8
  - Assigning
    - disk service ratings, *ServAdmin*, 5-14

## Assigning (Cont.)

- passwords in VMS accounts,  
*ServAdmin*, 6-3
- passwords to virtual disk, *ServAdmin*,  
5-10
- VMS priority for file server,  
*ServAdmin*, 8-13
- Asterisk, *ServCmds*, 2-5
- Asynchronous DECnet, *NetTrouble*, 3-11
- ATTRIBUTE command (PCDISK utility),  
*ServCmds*, 2-10, 2-12
- AUTHORIZE command (VMS)
  - and passwords, *ServAdmin*, 6-14
  - and UIC groups, *ServAdmin*, 6-17
  - changing passwords, *ServAdmin*,  
6-14, 6-15
- Authorize utility
  - running, *ServInstall*, C-2
- AUTOEXEC.BAT file
  - and GRAPHICS command,  
*ServAdmin*, 6-5
- AUTOGEN procedure (VMS), *ServInstall*,  
3-4; *ServAdmin*, 7-4, 7-8, 8-10,  
8-15, 8-16
- AUTOUSER.BAT file, *ServAdmin*, 6-1,  
6-6
  - and group codes, *ServAdmin*, 7-12
  - changing, *ServAdmin*, 6-7
  - connecting to services, *ServAdmin*,  
6-4
  - customizing editors, *ServAdmin*, 6-6
  - editing, *ServAdmin*, 6-1
  - modifying, *ServAdmin*, 6-6

## B

---

- Babbling device (DECnet), *NetTrouble*,  
3-16
- Backing up
  - disk services, *ServAdmin*, 9-16
  - file services, *ServAdmin*, 9-16
  - PATHWORKS Server 3100 system,  
*ServAdmin*, 12-2
  - system disk, *ServInstall*, 1-4
  - user accounts, *ServAdmin*, 9-16

## Backing up (Cont.)

- using the PCSA Manager Menu,  
*ServAdmin*, 9-16
- using the VMS BACKUP command,  
*ServAdmin*, 9-18
- BACKUP command (VMS), *ServAdmin*,  
9-18
  - incremental backups, *ServAdmin*,  
9-18
- Backup log file
  - printing, *ServAdmin*, 9-17
- Baseband Ethernet
  - configuration guidelines, *NetTrouble*,  
C-1
- BASIC programs
  - creating files compatible with file  
server, *ServAdmin*, A-5
- Binary files
  - using in file services, *ServAdmin*, A-4,  
A-7
- Blank pages
  - preventing on non-PostScript printers,  
*ServAdmin*, 4-20
- Boot database
  - restoring, *ServAdmin*, 11-4
- Booting
  - after installation, *ServInstall*, 3-11
- Bouncing circuit (DECnet), *NetTrouble*,  
3-9
- Breakout boxes, *NetTrouble*, 3-39
- Bridges
  - configuration guidelines, *NetTrouble*,  
C-3
  - LAN Bridge switch settings,  
*NetTrouble*, 3-51
- BROADCAST command (PCSA Manager),  
*ServCmds*, 1-33
- Broadcast storm (DECnet), *NetTrouble*,  
3-19
- Broadcast utility
  - sending messages, *ServAdmin*, 10-1,  
10-2
  - setting up for clients, *ServAdmin*,  
10-2
- Byte-range locking, *ServAdmin*, 9-11

## C

Cache, *ServAdmin*, 8-2

and closing files, *ServAdmin*, 8-8

and stream files, *ServAdmin*, 8-2

availability of, *ServAdmin*, 8-5

buffer size, *ServAdmin*, 8-8

data file for, *ServAdmin*, 8-3, 8-4

increasing on file server, *ServAdmin*,  
8-5, 8-7

on disk server, *ServAdmin*, 8-13

on file server, *ServAdmin*, 8-3, 8-4

open file, *ServAdmin*, 8-2, 8-4, 8-7

size of, *ServAdmin*, 8-7

system parameters required for,  
*ServAdmin*, 8-13, 8-14

term defined, *ServAdmin*, 8-1

Cache hit rate, *ServAdmin*, 8-14

term defined, *ServAdmin*, 8-5

Cache parameters

for disk server, *ServAdmin*, 8-14

for file server, *ServAdmin*, 8-6

Calculating system parameters

for installation, *ServInstall*, E-1

Carriage control information

in DOS, *ServAdmin*, A-1, A-4

in VMS, *ServAdmin*, A-1, A-4, A-7

Carriage return

*See* Carriage control information

Changing

*See also* Modifying

access to file services, *ServAdmin*,  
3-18

disk services, *ServInstall*, 3-11

maximum disk services, *ServInstall*,  
3-10; *ServAdmin*, 7-7

number of clients, *ServInstall*, 3-2;  
*ServAdmin*, 7-4, 9-5

number of connections to file services,  
*ServAdmin*, 9-4

open files, *ServAdmin*, 9-5

RMS protection on files, *ServAdmin*,  
3-6

Changing (Cont.)

timeout on disk server, *ServAdmin*,  
7-9, 9-13

CHANNELCNT parameter, *ServAdmin*,  
F-1, F-6

CHDIR command (PCDISK utility),  
*ServCmds*, 2-10, 2-15

Checklist

for installing, *ServInstall*, 2-1

for postinstallation, *ServInstall*, 3-1

for preinstallation tasks, *ServInstall*,  
1-2

Circuit

bouncing, *NetTrouble*, 3-9

state problems, *NetTrouble*, 3-23

Circuit-id, *ServInstall*, 1-10

Clearing

disk server counters, *ServCmds*, 1-170

Client Loopback Test

for DECnet, *NetTrouble*, 2-64

Client operating systems

listing, *ServAdmin*, 11-4

Clients

*See also* Personal computers

changing number of, *ServAdmin*, 7-3,  
7-4, 9-5

connecting to services at startup,  
*ServAdmin*, 6-4

listing with file service connections,  
*ServAdmin*, 9-2

maintaining, *ServAdmin*, 11-1

on file server, *ServAdmin*, F-5

tuning for DOS, *NetTrouble*, B-1

VAXmate clients, *ServAdmin*, H-1

Version 2.2 DECnet/PCSA Clients,  
*ServAdmin*, H-1

Client-to-Client Loop Test

for DECnet, *NetTrouble*, 2-71

Client-to-Server Loop Test

for DECnet, *NetTrouble*, 2-71

CLOSE FILE\_SERVER FILE command  
(PCSA Manager), *ServCmds*, 1-37;  
*ServAdmin*, 9-4

Closing

## Closing (Cont.)

open files, *ServCmds*, 1-37;  
*ServAdmin*, 9-4

## Clusters, *ServAdmin*, 9-10

and file server priority, *ServAdmin*,  
8-13

database for, *ServAdmin*, 9-11

file server log file and, *ServAdmin*,  
9-11

limiting disk services in, *ServAdmin*,  
5-2, 9-15

managing disk services in, *ServAdmin*,  
9-14

sharing files, *ServAdmin*, 9-10

## COBOL programs

creating files compatible with file  
server, *ServAdmin*, A-5

## Commands (PCSA Manager), *ServCmds*, 1-1

## Common directories

See Common file services

## Common file services

access to, *ServAdmin*, 3-2, 3-5

adding, *ServAdmin*, 3-6

and RMS protection on files,  
*ServAdmin*, 3-9

client connections to, *ServAdmin*, 6-4

contrasted with application file  
services, *ServAdmin*, 1-4, 1-9,  
3-2

default location for, *ServAdmin*, 3-11

security, *ServAdmin*, 3-2

selecting for user, *ServAdmin*, 6-4

## COMMON services

default installation disk, *ServInstall*,  
2-6

## Components

disk space requirements of,  
*ServInstall*, 1-5

VMSINSTAL questions about,  
*ServInstall*, 2-6

## CONFIG command (PCSA Manager), *ServCmds*, 1-35

## Configuration guidelines

baseband Ethernet, *NetTrouble*, C-1

## Configuration guidelines (Cont.)

bridges, *NetTrouble*, C-3

DELNI local area interconnect,  
*NetTrouble*, C-2

DEMPR ThinWire multiport repeaters,  
*NetTrouble*, C-3

DEREP Ethernet repeaters,  
*NetTrouble*, C-3

fiber-optic cable, *NetTrouble*, C-2  
ThinWire Ethernet, *NetTrouble*, C-2

## Configuration utility

log file messages, *ServMsgs*, 6-1

## Configuring

disk server, *ServInstall*, 3-10

disk servers, *ServAdmin*, 7-7

file server, *ServInstall*, 3-2

file servers, *ServAdmin*, 7-2

Local Area System Transport (LAST),  
*ServAdmin*, 7-9

VAXmate clients, *ServAdmin*, H-1

Configuring network devices on TCP/IP  
networks, *NetTrouble*, 6-10, 6-17

## Connecting to services, *ServAdmin*, 1-5

and printer output, *ServAdmin*, 4-24

at client startup, *ServAdmin*, 6-4

granting access to, *ServAdmin*, 1-4,  
3-16, 3-17

to application file services, *ServAdmin*,  
3-14

to common file services, *ServAdmin*,  
3-14

to disk services, *ServAdmin*, 5-4

using default account, *ServAdmin*,  
1-5, 3-5, 3-17

## Connections

allowing file server to accept,  
*ServCmds*, 1-156

limiting for disk services, *ServAdmin*,  
5-2

limiting for file services, *ServAdmin*,  
3-12, 3-20, 9-4

listing file services, *ServAdmin*, 9-2

specifying for client startup,  
*ServAdmin*, 6-4

COPY command (PCDISK utility),  
*ServCmds*, 2-10, 2-17

Counters  
 loop, *NetTrouble*, 1-8  
 zeroing, *NetTrouble*, 1-8

C programs  
 creating files compatible with file  
 server, *ServAdmin*, A-5

CREATE command (PCDISK utility),  
*ServCmds*, 2-10, 2-20

CREATE DISK command (PCSA  
 Manager), *ServCmds*, 1-39;  
*ServAdmin*, 5-8, 5-10, 5-13

Creating  
*See also* Adding  
 forms, *ServAdmin*, 4-11  
 groups, *ServAdmin*, 6-17  
 printer startup file, *ServAdmin*, 4-5  
 virtual disks, *ServCmds*, 1-39;  
*ServAdmin*, 5-7  
 VMS accounts, *ServAdmin*, 6-1

**D**

---

Daisy Chain Segment Test  
 for DECnet, *NetTrouble*, 2-72  
 for TCP/IP, *NetTrouble*, 5-35

Data caching, *ServAdmin*, 8-7

Data files  
 for applications, *ServAdmin*, 1-8

Data set hangup error, *NetTrouble*, 8-19

DCL table, *ServInstall*, E-4

DECnet  
 defining executor pipeline quota,  
*ServInstall*, 1-8  
 defining logical links, *ServInstall*, 1-6  
 DEQRA diagnostics, *NetTrouble*, 2-13  
 determining logical links needed for file  
 server, *ServInstall*, 1-7  
 edit startup procedure, *ServInstall*,  
 1-14  
 hardware and configuration,  
*NetTrouble*, 2-68  
 messages, *NetTrouble*, 3-1  
 PC-based, *NetTrouble*, 3-98

DECnet (Cont.)  
 Network Control Program (NCP),  
*NetTrouble*, 1-1  
 Phase IV addresses, *NetTrouble*, 6-8  
 Problem-Isolation Flowcharts,  
*NetTrouble*, 2-1  
 starting, *ServInstall*, 1-6  
 status while installing, *ServInstall*,  
 2-3  
 Token Ring, *NetTrouble*, D-1  
 troubleshooting tools, *NetTrouble*, 1-1

DECnet address  
 defining on server, *ServAdmin*, 11-1

DECnet area  
 maximum number of areas,  
*NetTrouble*, 3-78  
 maximum number of nodes,  
*NetTrouble*, 3-78

DECnet database, *ServCmds*, 1-12, 1-83  
 adding nodes to, *ServAdmin*, 11-1  
 deleting nodes from, *ServAdmin*, 11-2  
 restoring, *ServAdmin*, 11-4

DECnet nodes  
 defining on server, *ServAdmin*, 11-1  
 displaying on print jobs, *ServAdmin*,  
 4-24

DECservers  
 setting up printers on, *ServAdmin*,  
 4-16

DEC TRNcontroller diagnostics,  
*NetTrouble*, 2-13

Default account, *ServAdmin*, 3-5, 3-17,  
 6-15, 6-18  
 and printer output, *ServAdmin*, 4-24  
 changing name of, *ServAdmin*, 6-16  
 connecting to services, *ServAdmin*,  
 1-5, 1-6, 3-5  
 disabling, *ServAdmin*, 6-15

Default allocation  
 for virtual disks, *ServAdmin*, 5-9

Default locations  
 for file services, *ServAdmin*, 3-11,  
 3-12  
 for virtual disks, *ServAdmin*, 5-7

Default responses, *ServAdmin*, 2-5

- Defining
  - disk server characteristics, *ServCmds*, 1-93
  - file server characteristics, *ServCmds*, 1-98
  - file service characteristics, *ServCmds*, 1-102
  - forms, *ServAdmin*, 4-11
  - group codes for servers, *ServAdmin*, 7-11, 7-12
  - print service characteristics, *ServCmds*, 1-102
  - virtual disk location, *ServAdmin*, 5-7
- DELETE command (PCDISK utility), *ServCmds*, 2-10, 2-24
- DELETE DISK command (PCSA Manager), *ServCmds*, 1-43; *ServAdmin*, 5-16
- Deleting
  - disk services, *ServAdmin*, 5-15
  - file services, *ServAdmin*, 3-21
  - groups, *ServAdmin*, 6-19
  - nodes from database, *ServAdmin*, 11-2
  - remote boot clients, *ServAdmin*, 11-3
  - user accounts, *ServAdmin*, 6-12
  - users from groups, *ServAdmin*, 6-19
  - virtual disks, *ServCmds*, 1-43; *ServAdmin*, 5-16
- Delimiters
  - valid for commands and parameters, *ServCmds*, 2-3
- DELNI local network interconnect
  - configuration guidelines, *NetTrouble*, C-2
- DEMPR Configuration Segment Test
  - for DECnet, *NetTrouble*, 2-73
  - for TCP/IP, *NetTrouble*, 5-36
- DENY/GROUP command (PCSA Manager), *ServCmds*, 1-48
- DENY command (PCSA Manager), *ServCmds*, 1-46
- Denying
  - group access, *ServCmds*, 1-48; *ServAdmin*, 3-18
  - public access, *ServAdmin*, 3-18
- Denying (Cont.)
  - user access, *ServCmds*, 1-46; *ServAdmin*, 3-19
- DEQRA diagnostics, *NetTrouble*, 1-10, 2-13
- DEREP Ethernet repeaters
  - configuration guidelines, *NetTrouble*, C-3
- Destination file for PCDISK utility
  - term defined, *ServCmds*, 2-3
- Device control libraries, *ServAdmin*, 4-8
  - creating, *ServAdmin*, 4-10
  - entries in, *ServAdmin*, 4-8, 4-10
  - for printers listed on menu, *ServAdmin*, 4-14, 4-16
  - merging entries, *ServAdmin*, 4-14
- Device names
  - checking, *ServInstall*, 1-4
- Dialup problems (DECnet), *NetTrouble*, 3-37
- Directory
  - changing to another, *ServCmds*, 2-15
- DIRECTORY command (PCDISK utility), *ServCmds*, 2-10, 2-27
- Disconnecting
  - clients, *ServAdmin*, 9-2
- Disk name
  - COMMON services, *ServInstall*, 2-6
  - PERSONAL accounts, *ServInstall*, 2-6
- Disk quotas
  - and extending files, *ServAdmin*, 8-7, F-3
  - and moving user accounts, *ServAdmin*, 6-7
  - required for installation, *ServInstall*, 1-5
  - SYSTEM account, *ServInstall*, 3-11
- Disk server commands (PCSA Manager)
  - command reference, *ServCmds*, 1-14
- Disk servers, *ServAdmin*, G-5
  - adding to startup file, *ServInstall*, 3-8
  - and maximum disk services on, *ServAdmin*, 7-7
  - changing cache for, *ServAdmin*, 8-13, 8-14

## Disk servers (Cont.)

- changing maximum disk services,  
*ServInstall*, 3–10
- changing timeout, *ServAdmin*, 7–9,  
9–13
- configuring, *ServInstall*, 3–10;  
*ServAdmin*, 7–7
- database for services, *ServAdmin*,  
9–15
- data file for, *ServAdmin*, D–1
- defining maximum disk services,  
*ServInstall*, 3–11
- defining privileges for, *ServAdmin*,  
5–13
- improving performance on,  
*ServAdmin*, 8–13
- modifying startup file, *ServInstall*,  
3–11
- monitoring, *ServAdmin*, 9–12
- parameters at startup, *ServAdmin*,  
7–7, 8–14, D–1
- starting, *ServAdmin*, 9–14
- starting automatically, *ServInstall*,  
3–8
- startup file, *ServInstall*, 3–11
- startup file for, *ServAdmin*, 5–13
- stopping, *ServAdmin*, 9–14
- system parameters required for,  
*ServAdmin*, 7–8, 8–13, 8–14

## Disk services

- See also* Remote boot clients
- See also* Virtual disks
- access to, *ServAdmin*, 1–3, 5–3
- adding applications in, *ServAdmin*,  
5–3
- and /TYPE qualifier, *ServAdmin*, 5–8
- backing up, *ServAdmin*, 9–16
- changing maximum on server,  
*ServInstall*, 3–10
- clients connected to, *ServAdmin*, 9–13
- connections to, *ServAdmin*, 5–2
- contrasted with file services,  
*ServAdmin*, 1–7
- controlling security of, *ServAdmin*,  
1–3, 5–1

## Disk services (Cont.)

- default locations for, *ServAdmin*, 5–8
  - deleting, *ServAdmin*, 5–15
  - dismounting, *ServAdmin*, 5–5
  - DOS client troubleshooting procedure,  
*NetTrouble*, 11–30
  - in clusters, *ServAdmin*, 9–14
  - listing, *ServInstall*, 3–10; *ServAdmin*,  
9–12
  - listing access to, *ServAdmin*, 9–13
  - listing clients, *ServAdmin*, 9–13
  - listing connections to, *ServAdmin*,  
9–13
  - listing ratings, *ServAdmin*, 5–14
  - maximum number of, *ServAdmin*, 7–7
  - modifying access, *ServAdmin*, 5–12
  - mounting, *ServAdmin*, 5–11
  - OS/2 client troubleshooting procedure,  
*NetTrouble*, 11–39
  - passwords for, *ServAdmin*, 5–3, 5–12
  - permanent, *ServAdmin*, 5–11
  - personal, *ServAdmin*, 5–7
  - ratings for, *ServAdmin*, 5–14
  - restoring, *ServAdmin*, 9–18
  - setting maximum, *ServInstall*, 3–11
  - temporary, *ServAdmin*, 5–11
  - term defined, *ServAdmin*, 5–10
  - types of, *ServAdmin*, 5–8
  - VMS server troubleshooting procedure,  
*NetTrouble*, 11–12
- ## Disk space, *ServAdmin*, F–3
- See also* Disk quotas
  - determining requirements, *ServInstall*,  
1–5
  - extending virtual disk size,  
*ServAdmin*, 5–13
  - limiting, *ServAdmin*, 5–9
  - planning use, *ServInstall*, 1–11
  - used by files in file services,  
*ServAdmin*, 8–7, F–3
- ## Disk types
- supported by PCDISK, *ServCmds*, 2–1
- ## Disk usage
- planning, *ServInstall*, 1–11

DISMOUNT DISK command (PCSA Manager), *ServCmds*, 1-50;  
*ServAdmin*, 5-6, 5-16

#### Dismounting

disk, *ServCmds*, 1-50  
disk services, *ServAdmin*, 5-5, 5-16

#### Displaying

*See also* Listing  
active connections to file server,  
*ServCmds*, 1-121  
active DECnet sessions on file server,  
*ServCmds*, 1-139  
client operating systems, *ServCmds*,  
1-105  
disk server characteristics, *ServCmds*,  
1-107  
disk server connection information,  
*ServCmds*, 1-109  
disk server counters, *ServCmds*, 1-111  
disk service information, *ServCmds*,  
1-114  
file server characteristics, *ServCmds*,  
1-119  
file server status information,  
*ServCmds*, 1-141  
group information, *ServCmds*, 1-143  
information about active file services,  
*ServCmds*, 1-129  
information about active print services,  
*ServCmds*, 1-129  
information about granted file services,  
*ServCmds*, 1-132  
information about granted print  
services, *ServCmds*, 1-132  
information about registered file  
services, *ServCmds*, 1-136  
information about registered print  
services, *ServCmds*, 1-136  
open files on file server, *ServCmds*,  
1-127  
performance information on the file  
server, *ServCmds*, 1-124  
registered users, *ServCmds*, 1-148  
templated defined, *ServCmds*, 1-146  
user information, *ServCmds*, 1-143

#### Displaying (Cont.)

version numbers for VMS server  
software, *ServCmds*, 1-150  
workstations configure for remote boot,  
*ServCmds*, 1-152

Domain name services, *NetTrouble*, 5-27

#### DOS

file names, *ServCmds*, 2-4  
virtual disk, *ServCmds*, 2-2

DOS byte-range locking, *ServAdmin*,  
9-11

DOS Client Configuration Procedure  
for LAT, *NetTrouble*, 8-27

DOS Client Disk Services Procedure,  
*NetTrouble*, 11-30

DOS Client File Services Procedure  
for LAST, *NetTrouble*, 11-31

DOS Client LAN Manager Procedure  
for DECnet, *NetTrouble*, 2-48  
for TCP/IP, *NetTrouble*, 5-29

DOS Client Master Procedure  
for DECnet, *NetTrouble*, 2-41  
for LAST, *NetTrouble*, 11-19  
for LAT, *NetTrouble*, 8-26  
for TCP/IP, *NetTrouble*, 5-25

DOS Client Maximum Links/Connections  
Procedure  
for LAT, *NetTrouble*, 8-38

DOS Client Memory Interaction Procedure  
for LAST, *NetTrouble*, 11-25

DOS Client Printer Services Procedure  
for LAST, *NetTrouble*, 11-31  
for LAT, *NetTrouble*, 8-34

DOS Client Remote Printing Procedure  
for DECnet, *NetTrouble*, 2-51  
for TCP/IP, *NetTrouble*, 5-31

DOS Client Required Components  
Procedure  
component load order, *NetTrouble*,  
11-22

for LAST, *NetTrouble*, 11-21

DOS Client Transport Procedure  
for DECnet, *NetTrouble*, 2-42  
for LAST, *NetTrouble*, 11-28  
for LAT, *NetTrouble*, 8-29



DOS Client Transport Procedure (Cont.)  
 for TCP/IP, *NetTrouble*, 5–26

DOS configuration files, *NetTrouble*, 8–27

DOS files  
 and carriage control, *ServAdmin*, A–2  
 backing up using file server,  
   *ServAdmin*, 9–18  
 file version limit in, *ServAdmin*, 6–3  
 in file services, *ServAdmin*, 1–3  
 in VMS FIXED format, *ServAdmin*,  
   A–7  
 in VMS STREAM format, *ServAdmin*,  
   A–7  
 structure of, *ServAdmin*, A–1  
 using in file services, *ServAdmin*, A–1,  
   A–7  
 using in VMS, *ServAdmin*, A–7

DOS operating system  
 listing, *ServAdmin*, 11–4  
 using files with estimated length,  
   *ServAdmin*, A–5

DOS tools (TCP/IP), *NetTrouble*, 4–10

Duplicate Node Definition Procedure  
 for DECnet, *NetTrouble*, 2–69  
 for TCP/IP, *NetTrouble*, 5–33

## E

---

EMS memory  
 DOS client configuration check,  
   *NetTrouble*, 5–27

End-of-file pointer (EOF), *ServAdmin*,  
 A–4, A–5, A–7

Entries, *ServAdmin*, 4–8  
 creating, *ServAdmin*, 4–10  
 merging, *ServAdmin*, 4–14

Epson printers  
 creating printer service for,  
   *ServAdmin*, 4–9  
 creating print queue for, *ServAdmin*,  
 4–9

Error messages  
 See Messages

Error messages and conditions,  
   *ServInstall*, 2–8

Escape key  
 using with EDT editor, *ServAdmin*,  
 4–10  
 using with EVE editor, *ServAdmin*,  
 4–10

ESS\$LAD\_STARTUP.DAT file,  
   *ServInstall*, 3–11; *ServAdmin*, 7–7,  
 8–14, D–1

ESS\$LASTTCP  
 See Local Area System Transport  
 Control Program

ESS\$LASTTCP commands  
 EXIT, *ServCmds*, 3–2  
 HELP, *ServCmds*, 3–5  
 SHOW CIRCUIT COUNTERS,  
   *ServCmds*, 3–7  
 SHOW CLIENTS, *ServCmds*, 3–9  
 SHOW LINE COUNTERS, *ServCmds*,  
 3–11  
 SHOW NODE CHARACTERISTICS,  
   *ServCmds*, 3–14  
 SHOW NODE COUNTERS,  
   *ServCmds*, 3–16  
 SHOW SERVERS, *ServCmds*, 3–18  
 SHOW STATUS, *ServCmds*, 3–20  
 SHOW TRANSPORT COUNTERS,  
   *ServCmds*, 3–22  
 START TRANSPORT, *ServCmds*,  
 3–24  
 STOP TRANSPORT, *ServCmds*, 3–28  
 ZERO COUNTERS, *ServCmds*, 3–30

ESS\$LASTTCP program  
 messages, *ServMsgs*, 4–1

ESS\$LASTDRIVER, *ServCmds*, 3–1

ESS\$LASTDRIVER device driver  
 controlling and diagnosing, *ServCmds*,  
 3–1

ESS\$LAST\_STARTUP.DAT file,  
   *ServAdmin*, 7–9, 7–11, E–1

Estimated length, *ServAdmin*, A–4  
 term defined, *ServAdmin*, 3–13

/etc/ifconfig command, *NetTrouble*, 6–10,  
 6–17

/etc/password file, *NetTrouble*, 6–14

/etc/rc.local file, *NetTrouble*, 6–10, 6–17

Ethernet  
 cabling rules, *NetTrouble*, C-1  
 configuration guidelines, *NetTrouble*,  
 C-1  
 Ethernet addresses, *NetTrouble*, 6-8  
 Ethernet controllers  
 changing on VAXmates, *ServAdmin*,  
 H-3  
 Executor node, *NetTrouble*, 1-3  
 Executor pipeline quota  
 defining, *ServInstall*, 1-8  
 EXIT command (PCDISK utility),  
*ServCmds*, 2-29  
 EXIT command (PCSA Manager),  
*ServCmds*, 1-52  
 Exiting  
 PCSA Manager, *ServCmds*, 1-52  
 PCSA Manager Menu, *ServAdmin*,  
 2-3  
 EXPORT command (PCDISK utility),  
*ServCmds*, 2-10, 2-30  
 Extended LANs, *ServAdmin*, 7-10

## F

Fiber-optic cable  
 configuration guidelines, *NetTrouble*,  
 C-2  
 File access, *ServAdmin*, 3-3, 3-9  
 File compatibility  
 in DOS and VMS, *ServAdmin*, 3-13  
 File extent, *ServAdmin*, 8-7  
 File locking, *ServAdmin*, F-5  
 and cache, *ServAdmin*, 8-8  
 byte-range, *ServAdmin*, 9-11  
 in clusters, *ServAdmin*, 9-10  
 Files  
 access to in application file services,  
*ServAdmin*, 3-2  
 access to in common file services,  
*ServAdmin*, 3-3, 3-9  
 actual length of, *ServAdmin*, 3-13  
 and disk quotas, *ServAdmin*, 8-7, F-3  
 and open file caching, *ServAdmin*, 8-4,  
 8-8

## Files (Cont.)

and private locks, *ServAdmin*, 9-10  
 AUTOEXEC.BAT, *ServAdmin*, 6-5  
 AUTOUSER.BAT, *ServAdmin*, 6-1,  
 6-6  
 byte-range locking, *ServAdmin*, 9-11  
 changing number of, *ServInstall*, 3-2  
 closing open files, *ServAdmin*, 9-4  
 ESS\$LAD\_STARTUP.DAT,  
*ServInstall*, 3-11; *ServAdmin*,  
 7-7, 8-14, D-1  
 ESS\$LAST\_STARTUP.DAT,  
*ServAdmin*, 7-9, 7-11, E-1  
 estimated length of, *ServAdmin*, 3-13  
 fixed format, *ServAdmin*, 3-13  
 fixed length, *ServAdmin*, 3-13  
 in a cluster, *ServAdmin*, 9-10  
 LAD\_STARTUP.COM, *ServAdmin*,  
 5-13  
 listing open files, *ServAdmin*, 9-3  
 MODPARAMS.DAT, *ServAdmin*, 7-8,  
 8-15  
 names in DOS, *ServCmds*, 2-4  
 PCFS\$CACHE\_STATISTICS.TXT,  
*ServAdmin*, 8-4  
 PCFS\$MODPARAMS.DAT,  
*ServAdmin*, 7-8, 8-15  
 PCFS\$MONITOR.LOG, *ServAdmin*,  
 8-4  
 PCFS\$STARTUP.LOG, *ServInstall*,  
 3-7; *ServAdmin*, 7-7, 8-12, 9-10  
 PCFS\$STARTUP\_PARAMS.DAT,  
*ServAdmin*, 7-3, 7-4, 8-9, F-1  
 PCFS\_LOGICALS.COM, *ServAdmin*,  
 3-11  
 PCFS\_PRINT.COM, *ServAdmin*, 4-5  
 PCFS\_SERVER.LOG file, *ServAdmin*,  
 9-6, 9-7, 9-8  
 PCFS\_STARTUP.COM, *ServAdmin*,  
 8-13, 9-6  
 purging, *ServInstall*, 2-5  
 RMS protection in common file services,  
*ServAdmin*, 3-5, 3-9  
 sharing in clusters, *ServAdmin*, 9-10

## Files (Cont.)

- space allocated for and performance, *ServAdmin*, 8-7
- stream format, *ServAdmin*, 3-13
- SYSTARTUP\_V5.COM, *ServAdmin*, 4-5, 4-12
- using files in DOS and VMS, *ServAdmin*, 3-13
- using in actual length file services, *ServAdmin*, A-5
- using in DOS and VMS, *ServAdmin*, 1-3, A-1
- using in estimated length file services, *ServAdmin*, A-5
- version limit for, *ServAdmin*, 6-3, 9-15

## File server commands (PCSA Manager)

- command reference, *ServCmds*, 1-14

- ## File server log file, *ServAdmin*, 9-11
- defining events in, *ServAdmin*, 9-9
  - displaying, *ServAdmin*, 9-7
  - messages in, *ServAdmin*, 9-7
  - name of, *ServAdmin*, 9-7
  - printing, *ServAdmin*, 9-8
  - starting a new file, *ServAdmin*, 9-8
  - term defined, *ServAdmin*, 9-6
  - using, *ServAdmin*, 9-6

## File servers

- adding to startup file, *ServInstall*, 3-8
- allocating space for files in, *ServAdmin*, 8-7
- and carriage control information, *ServAdmin*, A-4
- and locked data, *ServAdmin*, F-5
- and VMS priority, *ServAdmin*, 8-13
- cache and, *ServCmds*, 1-124
- collecting cache data, *ServAdmin*, 8-3
- configuration and performance, *ServAdmin*, 8-1
- configuring, *ServInstall*, 3-2; *ServAdmin*, 7-2
- data file for, *ServAdmin*, F-1
- displaying cache use, *ServAdmin*, 8-4
- limiting clients, *ServAdmin*, 9-5
- limiting open files, *ServAdmin*, 9-5

## File servers (Cont.)

- log file, *ServAdmin*, 9-6, 9-8
- log file messages, *ServMsgs*, 1-1
- messages, *ServMsgs*, 1-1
- monitoring, *ServAdmin*, 9-1
- monitoring security breaches, *ServAdmin*, 9-6
- parameters at startup, *ServAdmin*, 7-3, F-1
- performance, *ServAdmin*, 8-2, 8-13
- performance and packet size, *ServAdmin*, 8-6
- starting, *ServInstall*, 3-7; *ServAdmin*, 7-6, 8-12, 9-10
- starting automatically, *ServInstall*, 3-8
- startup file for, *ServAdmin*, 8-13, 9-6
- stopping, *ServAdmin*, 9-10
- system parameters required for, *ServInstall*, 3-4; *ServAdmin*, 7-4, 8-10

## File services

- access to, *ServAdmin*, 3-2, 3-18, 3-19
- actual length, *ServAdmin*, 3-13, A-4, A-5
- adding, *ServAdmin*, 3-9
- alias for, *ServAdmin*, 3-20
- backing up, *ServAdmin*, 9-16
- common, *ServAdmin*, 3-2
- contrasted with disk services, *ServAdmin*, 1-7
- deleting, *ServAdmin*, 3-21
- estimated length, *ServAdmin*, 3-13, A-4, A-5
- fixed format, *ServAdmin*, A-7
- fixed-length, *ServAdmin*, A-7
- fixed length format, *ServAdmin*, 3-13
- group access to, *ServAdmin*, 3-18
- in a VAXcluster, *ServAdmin*, 9-10
- limiting connections to, *ServAdmin*, 3-12, 3-20, 9-4
- listing, *ServAdmin*, 9-2
- location for, *ServAdmin*, 3-11
- modifying VMS files in, *ServAdmin*, A-2

## File services (Cont.)

- name for, *ServAdmin*, 3-11
- public access to, *ServAdmin*, 3-17, 3-18
- restoring, *ServAdmin*, 9-18
- RMS protection in common services, *ServAdmin*, 3-3
- root directory for, *ServAdmin*, 3-11
- security in, *ServAdmin*, 1-4, 3-1, 3-2
- security of files in, *ServAdmin*, 1-5, 3-9
- stream format, *ServAdmin*, 3-13, A-7
- type of (common or application), *ServAdmin*, 3-11
- user access to, *ServAdmin*, 3-19
- using DOS and VMS files in, *ServAdmin*, A-1
- VMS server troubleshooting procedure for LAST, *NetTrouble*, 11-15
- with carriage control information, *ServAdmin*, A-4
- writing to VMS files in, *ServAdmin*, A-2

## File Transfer Protocol

- error messages, *NetTrouble*, 6-30

## Fixed format, *ServAdmin*, 3-20

## Fixed length files, *ServAdmin*, 3-13

## Fixed length records, *ServAdmin*, 3-13 in VMS files, *ServAdmin*, A-7

## Flowcharts

- for DECnet, *NetTrouble*, 2-1
- for LAST, *NetTrouble*, 11-1
- for LAT, *NetTrouble*, 8-1
- for TCP/IP, *NetTrouble*, 5-1

## FORMAT command (PCDISK utility), *ServCmds*, 2-10, 2-33

## Formatting

- virtual disks, *ServCmds*, 1-39

## Forms, *ServAdmin*, 4-1, 4-8

- adding, *ServAdmin*, 4-11
- default, *ServAdmin*, 4-4
- for printers listed on PCSA Manager Menu, *ServAdmin*, 4-6
- landscape, *ServAdmin*, 1-3, 4-1
- portrait, *ServAdmin*, 1-3, 4-1

## Forms (Cont.)

- term defined, *ServAdmin*, 4-4

## FORTTRAN programs

- creating files compatible with file server, *ServAdmin*, A-5

## G

---

## GBLPAGES system parameter, *ServInstall*, E-4

## GBLSECTIONS system parameter, *ServInstall*, E-6

## Generic queues, *ServAdmin*, 4-8 for printers listed on PCSA Manager Menu, *ServAdmin*, 4-6

- name, *ServAdmin*, 4-4

## GRANT/GROUP command (PCSA Manager), *ServCmds*, 1-56

## GRANT command (PCSA Manager), *ServCmds*, 1-53; *ServAdmin*, 3-21

## Granting

- group access, *ServCmds*, 1-56;  
*ServAdmin*, 1-7, 3-18
- public access, *ServAdmin*, 1-7, 3-18,  
6-18
- user access, *ServCmds*, 1-53;  
*ServAdmin*, 1-7, 3-19

## Group codes

- for clients, *ServAdmin*, 7-12
- for servers, *ServAdmin*, 7-11
- term defined, *ServAdmin*, 7-10
- with remote boot, *ServAdmin*, 7-12

## Groups, *ServAdmin*, 6-16

- adding users to, *ServAdmin*, 6-18
- contrasted with UIC group codes,  
*ServAdmin*, 6-17
- creating, *ServAdmin*, 6-17
- default, *ServAdmin*, 6-18
- defining, *ServAdmin*, 6-16
- deleting, *ServAdmin*, 6-19
- public, *ServAdmin*, 6-18
- removing users, *ServAdmin*, 6-19
- term defined, *ServAdmin*, 6-1
- using, *ServAdmin*, 6-18

## H

---

### Hardware

required before installation,  
*ServInstall*, 1–3

### Help

for PCSA Manager commands,  
*ServAdmin*, 2–9

PCSA Manager, *ServCmds*, 1–60

### HELP command

ESS\$LASTCP program, *ServCmds*,  
3–5

PCDISK utility, *ServCmds*, 2–35

PCSA Manager, *ServCmds*, 1–60

### HP LaserJet printers, *ServAdmin*, 4–3

setting up, *ServAdmin*, B–1

## I

---

### Identifiers, *ServAdmin*, 3–8

in application file services, *ServAdmin*,  
3–2

in common file services, *ServAdmin*,  
3–3

term defined, *ServAdmin*, 3–2

### Illegal PCDISK file names, *ServCmds*, 2–4

### IMPORT command (PCDISK utility), *ServCmds*, 2–10, 2–37

### Installation checklist, *ServInstall*, 2–1

### Installation disk

default name, *ServInstall*, 2–6

### Installation procedure

calculating system parameters for,  
*ServInstall*, E–1

interrupting, *ServInstall*, 2–3

responding to questions, *ServInstall*,  
2–2

starting, *ServInstall*, 2–2, 2–3

### Installation Verification Procedure (IVP), *NetTrouble*, 4–4

running automatically, *ServInstall*,  
2–5, 2–7

running independently, *ServInstall*,  
3–2

Installing applications, *ServAdmin*, 3–14,  
5–4

Intel Above Board Plus, *NetTrouble*, 5–28

Interactive login, *ServAdmin*, 6–3

Isolating DECnet Problems, *NetTrouble*,  
2–1

Isolating Local Area System Transport  
(LAST) Problems, *NetTrouble*, 11–1

Isolating Local Area Transport (LAT)  
Problems, *NetTrouble*, 8–1

Isolating TCP/IP Problems, *NetTrouble*,  
5–1

### IVP

*See* Installation Verification Procedure

## L

---

LABEL command (PCDISK utility),  
*ServCmds*, 2–10, 2–40

### LAD

*See* Virtual disk services

LAD\$KERNEL messages, *ServMsgs*, 4–4

LAD\$KERNEL Messages, *NetTrouble*,  
12–4

### LADDRV.SYS Messages

on DOS, *NetTrouble*, 12–13

on OS/2, *NetTrouble*, 12–20

LAD Log File Messages, *NetTrouble*,  
12–7

LAD Messages, *NetTrouble*, 12–14

LAD\_STARTUP.COM file, *ServAdmin*,  
5–13

### LAN bridges

traffic monitor, *NetTrouble*, 7–4

Landscape forms, *ServAdmin*, 1–3, 4–1

### Languages

selecting for PCSA applications,  
*ServAdmin*, 6–6

### LAN problems

terminal server connection failures,  
*NetTrouble*, 8–62

LANSESS Messages, *NetTrouble*, 12–15

LAN Traffic Monitor, *NetTrouble*, 7–3  
babbling devices, *NetTrouble*, 7–3

## LAN Traffic Monitor (Cont.)

- hardware requirements, *NetTrouble*, 7-4
- listener, *NetTrouble*, 7-4
- privileges required to run, *NetTrouble*, 7-5
- running, *NetTrouble*, 7-5
- software requirements, *NetTrouble*, 7-4
- user interface, *NetTrouble*, 7-4

## LAST

See Local Area System Transport

## LASTCP

See Local Area System Transport Control Program

## LASTTCP program

See ESS\$LASTCP program

## LAST messages, *NetTrouble*, 12-1

## LATCP

See Local Area Transport Control Program

## LAT messages, *NetTrouble*, 9-1

## Limiting

- clients, *ServAdmin*, 7-2, 9-5
- connections to disk services, *ServAdmin*, 5-2
- connections to file services, *ServAdmin*, 3-12, 3-20, 9-4
- maximum disk services, *ServInstall*, 3-11; *ServAdmin*, 7-7
- open files, *ServAdmin*, 9-5
- server access, *ServAdmin*, 7-10

## Listing

- access to file services, *ServAdmin*, 3-17
- client operating systems, *ServAdmin*, 11-4
- clients connected to file services, *ServAdmin*, 9-2
- clients using disk server, *ServAdmin*, 9-13
- connections to disk server, *ServAdmin*, 9-13
- connections to file services, *ServAdmin*, 9-2

## Listing (Cont.)

- disk services, *ServInstall*, 3-10; *ServAdmin*, 9-12, 9-13
- file server cache, *ServAdmin*, 8-4
- file server log file, *ServAdmin*, 9-7
- file services, *ServAdmin*, 9-2
- messages in log file, *ServAdmin*, 9-7
- nodes, *ServAdmin*, 12-8
- open files, *ServAdmin*, 9-3
- remote boot clients, *ServAdmin*, 11-3
- users, *ServAdmin*, 6-12

## Load/Init error messages, *NetTrouble*, 6-24

## Lobe, *NetTrouble*, D-3

## Local area networks (LANs), *ServAdmin*, 7-10

- restricting server access, *ServAdmin*, 7-10

## Local Area System Transport (LAST), *ServAdmin*, 7-10, 8-16

- configuring, *ServAdmin*, 7-9
  - data file for, *ServAdmin*, E-1
  - group codes, *ServAdmin*, 7-11
  - monitoring memory use, *ServAdmin*, 8-16
  - performance, *ServAdmin*, 8-16
- ## Problem-Isolation Flowcharts, *NetTrouble*, 11-1
- starting, *ServAdmin*, 7-9
  - startup parameters for, *ServAdmin*, 7-11, E-1
  - stopping, *ServAdmin*, 7-10
  - tools

- on DOS, *NetTrouble*, 10-9
- on OS2, *NetTrouble*, 10-7
- on VMS, *NetTrouble*, 10-2
- overview, *NetTrouble*, 10-1

## Local Area System Transport Control Program (LASTCP), *ServAdmin*, 7-9, 7-11; *NetTrouble*, 10-1

- explained, *ServCmds*, 3-1
- on OS2, *NetTrouble*, 10-7
- on VMS, *NetTrouble*, 10-2
- start, *ServCmds*, 3-1
- using commands, *ServCmds*, 3-2

- Local Area Transport (LAT)
  - connects to the wrong node, *NetTrouble*, 8-53
  - connects to the wrong service, *NetTrouble*, 8-53
  - displaying error messages, *NetTrouble*, 8-16
  - does not work under an operating environment, *NetTrouble*, 8-61
  - LAT will not load, *NetTrouble*, 8-54
  - loses characters, *NetTrouble*, 8-58
  - loses connections, *NetTrouble*, 8-56
  - print queues
    - fixing a paused queue, *NetTrouble*, 8-18
    - fixing a stalled queue, *NetTrouble*, 8-17
    - job retained on error, *NetTrouble*, 8-23
    - printing incorrectly, *NetTrouble*, 8-22
    - starting a stopped queue, *NetTrouble*, 8-17
  - Problem-Isolation Flowcharts, *NetTrouble*, 8-1
  - tools, *NetTrouble*, 7-1
  - uses too much memory, *NetTrouble*, 8-59
- Local Area Transport Control Program (LATCP), *NetTrouble*, 7-1
  - on DOS, *NetTrouble*, 7-2
  - on OS/2, *NetTrouble*, 7-2
  - on ULTRIX, *NetTrouble*, 7-2
  - on VMS, *NetTrouble*, 7-2
- Local files, *ServAdmin*, 9-3
- Locked data, *ServAdmin*, F-5
- Log files
  - See also* Backup log file
  - See also* File server log file
  - for backup, *ServAdmin*, 9-17
  - for cache collection on file server, *ServAdmin*, 8-4
  - for file server startup, *ServInstall*, 3-7; *ServAdmin*, 7-7, 8-12, 9-10
  - ULTRIX (TCP/IP), *NetTrouble*, 4-10
- Log files (Cont.)
  - VMS (TCP/IP), *NetTrouble*, 4-2
- Logging
  - file server events, *ServCmds*, 1-158
- Logical links
  - defining DECnet links, *ServInstall*, 1-6
  - determining need for file server, *ServInstall*, 1-7
- Logicals
  - for virtual disk locations, *ServAdmin*, 5-7
  - PCFS\$APPLICATION, *ServAdmin*, 3-11
  - PCFS\$COMMON, *ServAdmin*, 3-11
  - PCFS\$LOG\_FILES, *ServAdmin*, 8-4, 9-7
  - PCFS\$SERVICE\_DATABASE, *ServAdmin*, 9-11
  - PCSA\$EDITOR\_COMMAND, *ServAdmin*, 6-6
  - SYS\$SPECIFIC, *ServAdmin*, 9-11
- Login
  - interactive, *ServAdmin*, 6-3
- Lookaside lists
  - term defined, *ServAdmin*, 8-16
- Loopback connector, *NetTrouble*, 1-9
- Loopback test
  - for DECnet, *NetTrouble*, 2-64
- LOOP command, *NetTrouble*, 4-4
- Loop counters, *NetTrouble*, 1-8
- Loop tests
  - for DECnet, *NetTrouble*, 2-71
- Lotus/Intel/Microsoft Expanded Memory Specification (EMS), *NetTrouble*, 5-28
- LPT1, *ServAdmin*, 6-5
- LTM
  - See* LAN Traffic Monitor

## M

### Mail

messages from the server, *ServMsgs*, 5-1

MAKE DIRECTORY command (PCDISK utility), *ServCmds*, 2-10, 2-42

### Managing

default account, *ServAdmin*, 6-15

overview of server tasks, *ServAdmin*, 1-9

MAXBUF system parameter, *ServInstall*, E-7

MAXIMUM LINKS (DECnet), *NetTrouble*, 3-42

Maximum Links/Connections Procedure for DECnet, *NetTrouble*, 2-70  
for TCP/IP, *NetTrouble*, 5-34

### Memory

EMS, *NetTrouble*, 5-28

### Memory allocation

managing, *ServAdmin*, 8-16

MENU command (PCSA Manager), *ServCmds*, 1-63

### Merging entries

in device control library, *ServAdmin*, 4-14

### Messages

DECnet, *NetTrouble*, 3-1

DECnet routing layer, *NetTrouble*, A-1

in the configuration utility log file, *ServMsgs*, 6-1

in the file server log file, *ServMsgs*, 1-1

LAST, *NetTrouble*, 12-1

LAT, *NetTrouble*, 9-1

Mail from the server, *ServMsgs*, 5-1

PCDISK utility, *ServMsgs*, 3-1

PCSA Manager, *ServMsgs*, 2-1

sending to workstations, *ServCmds*, 1-33

TCP/IP, *NetTrouble*, 6-1

### Mirror

### Mirror (Cont.)

used in network testing, *NetTrouble*, 1-9

MKDIR command (PCDISK utility), *ServCmds*, 2-10, 2-42

Modem signals, *NetTrouble*, 3-39

MODIFY DISK command (PCSA Manager), *ServCmds*, 1-65;  
*ServAdmin*, 5-13

### Modifying

AUTOUSER.BAT file, *ServAdmin*, 6-6  
disk server characteristics, *ServCmds*, 1-93

file server characteristics, *ServCmds*, 1-98

file service characteristics, *ServCmds*, 1-102

print service characteristics, *ServCmds*, 1-102

user's AUTOUSER.BAT file, *ServCmds*, 1-68

virtual disk, *ServCmds*, 1-65

virtual disk characteristics, *ServCmds*, 1-95

workstation, *ServCmds*, 1-70

MODIFY USER command (PCSA Manager), *ServCmds*, 1-68

MODIFY WORKSTATION command (PCSA Manager), *ServCmds*, 1-70;  
*ServAdmin*, 11-4, H-3

MODPARAMS.DAT file, *ServAdmin*, 7-8, 8-15

Modules, *ServAdmin*, 4-8, 4-15

defining forms, *ServAdmin*, 4-11

### Monitoring

disk server activity, *ServAdmin*, 9-12

disk server cache, *ServAdmin*, 8-13

file server activity, *ServAdmin*, 9-1

file server cache, *ServAdmin*, 8-4

file server performance, *ServAdmin*, 8-3

lookaside lists, *ServAdmin*, 8-16

MOUNT DISK command (PCSA Manager), *ServCmds*, 1-73;  
*ServAdmin*, 5-10



Mounting  
disk, *ServCmds*, 1-73  
Mounting media, *ServInstall*, 2-4  
Mounting virtual disks, *ServAdmin*, 5-10  
privileges for, *ServAdmin*, 5-10  
Multistation access unit (MAU),  
*NetTrouble*, D-3

## N

---

NCP  
See Network Control Program  
NET ATTRIB command, *ServAdmin*,  
3-11  
NETMBX privilege  
setting, *ServInstall*, C-2  
NETSTAT command  
DOS, *NetTrouble*, 4-11  
ULTRIX, *NetTrouble*, 4-8  
Network boot disk  
device name, *ServInstall*, 2-6  
Network Connection Procedure  
for DECnet, *NetTrouble*, 2-72  
for LAST, *NetTrouble*, 11-40  
for LAT, *NetTrouble*, 8-48  
for TCP/IP, *NetTrouble*, 5-35  
Network Control Program  
area number, *NetTrouble*, 1-3  
commands  
CLEAR, *NetTrouble*, 1-6  
DEFINE, *NetTrouble*, 1-6  
LIST, *NetTrouble*, 1-6  
LOOP, *NetTrouble*, 1-8, 1-9, 4-4  
LOOP CIRCUIT, *NetTrouble*, 1-10  
LOOP NODE, *NetTrouble*, 1-9  
MIRROR, *NetTrouble*, 1-9  
MONITOR LOGGING,  
*NetTrouble*, 1-8  
PURGE, *NetTrouble*, 1-6  
READ LOG, *NetTrouble*, 1-8  
SET, *NetTrouble*, 1-6  
SHOW, *NetTrouble*, 1-6, 1-8  
SHOW CIRCUIT COUNTERS,  
*NetTrouble*, 1-8

Network Control Program  
commands (Cont.)  
SHOW EXECUTOR COUNTERS,  
*NetTrouble*, 1-8  
SHOW LINE COUNTERS,  
*NetTrouble*, 1-8  
TELL, *NetTrouble*, 1-8  
ZERO, *NetTrouble*, 1-8  
ZERO CIRCUIT, *NetTrouble*, 1-8  
ZERO EXECUTOR, *NetTrouble*,  
1-8  
ZERO LINE, *NetTrouble*, 1-8  
command syntax, *NetTrouble*, 1-3  
example configuration, *NetTrouble*,  
1-5  
executor node, *NetTrouble*, 1-3  
Help utility, *NetTrouble*, 1-5  
node address, *NetTrouble*, 1-3  
node-id, *NetTrouble*, 1-3  
objects, *NetTrouble*, 1-3  
on PCs, *NetTrouble*, 1-2  
on VMS, *NetTrouble*, 1-1  
term defined, *NetTrouble*, 1-1  
Network key disks, *ServInstall*, 3-10;  
*ServAdmin*, 7-7, 9-12  
See also Remote boot clients  
adding template for, *ServCmds*, 1-23  
removing template for, *ServCmds*,  
1-87  
Network maintenance errors, *NetTrouble*,  
6-35  
Network Maintenance Facilities (NMF),  
*NetTrouble*, 5-26  
Network Segment Interface Procedure  
for DECnet, *NetTrouble*, 2-76  
for LAST, *NetTrouble*, 11-40  
for LAT, *NetTrouble*, 8-48  
for TCP/IP, *NetTrouble*, 5-39  
NMF  
See Network Maintenance Facilities  
Nodes  
adding, *ServAdmin*, 11-1  
adding to NCP database, *ServCmds*,  
1-12  
deleting, *ServAdmin*, 11-2

## Nodes (Cont.)

- listing, *ServAdmin*, 12-8
- maximum number per DECnet area,  
*NetTrouble*, 3-78
- registered, *ServAdmin*, 11-1
- NPAGEDYN parameter, *ServInstall*,  
3-11; *ServAdmin*, 7-8, G-5
- term defined, *ServAdmin*, 8-14

## O

---

- Object, *NetTrouble*, 1-3
- Open file caching, *ServAdmin*, 8-2, 8-4
  - delay for, *ServAdmin*, 8-8
  - hit rate, *ServAdmin*, 8-4
  - setting, *ServAdmin*, 8-7
- Open file hit rate
  - term defined, *ServAdmin*, 8-4
- Open files
  - closing, *ServAdmin*, 9-4
  - limiting in file services, *ServAdmin*,  
9-5
  - listing, *ServAdmin*, 9-3
- Operating systems
  - See Client operating systems
  - See DOS operating system
  - See VMS operating system
- OPTIONS N parameter, *ServInstall*, 2-3,  
2-4
- OS/2 Client Configuration Procedure
  - for LAT, *NetTrouble*, 8-40
- OS/2 Client Disk Services Procedure,  
*NetTrouble*, 11-39
- OS/2 Client LAN Manager Procedure
  - for DECnet, *NetTrouble*, 2-59
- OS/2 Client Master Procedure
  - for DECnet, *NetTrouble*, 2-53
  - for LAST, *NetTrouble*, 11-33
  - for LAT, *NetTrouble*, 8-39
  - LAST troubleshooting considerations,  
*NetTrouble*, 11-34
- OS/2 Client Remote Printing Procedure
  - for DECnet, *NetTrouble*, 2-62
- OS/2 Client Required Components  
Procedure

## OS/2 Client Required Components

- Procedure (Cont.)
  - component load order, *NetTrouble*,  
11-35
  - for LAST, *NetTrouble*, 11-34
- OS/2 Client Transport Procedure
  - for DECnet, *NetTrouble*, 2-54
  - for LAST, *NetTrouble*, 11-37
  - for LAT, *NetTrouble*, 8-44
- OS/2 files
  - backing up using file server,  
*ServAdmin*, 9-18
  - file version limit in, *ServAdmin*, 6-3
- OS/2 Server LAN Manager Procedure
  - for DECnet, *NetTrouble*, 2-37
- OS/2 Server Master Procedure
  - for DECnet, *NetTrouble*, 2-34
- OS/2 Server Procedure
  - for DECnet, *NetTrouble*, 2-35

## P

---

- Packets
  - and server performance, *ServAdmin*,  
8-6
  - size of, *ServAdmin*, 8-6
- Page file size, *ServAdmin*, G-4
- PCFS\$NUM\_OF\_WORKSTATIONS
  - parameter and, *ServAdmin*, G-4
  - WSMAX parameter and, *ServAdmin*,  
G-4
- PAK
  - See Product Authorization Key
- Parallel printers
  - connected to user's personal computer,  
*ServAdmin*, 4-1
- Parameters
  - See System parameters
- Partial routing update loss
  - See Node out of range packet loss
- Partitioned area (DECnet), *NetTrouble*,  
3-82
- PASCAL programs
  - creating files compatible with file  
server, *ServAdmin*, A-5

Passwords, *NetTrouble*, 6-2  
     changing, *ServAdmin*, 6-14, 6-15  
     defining, *ServAdmin*, 6-3  
     expiration of, *ServAdmin*, 6-14  
     for disk services, *ServAdmin*, 5-3  
     in VMS accounts, *ServAdmin*, 6-14  
     modifying, *NetTrouble*, 3-3  
 PATHWORKS Server 3100  
     backing up, *ServAdmin*, 12-2  
     managing the server, *ServAdmin*,  
         12-1  
     reboot, *ServAdmin*, 12-6  
     restore disk, *ServAdmin*, 12-4  
     shutdown, *ServAdmin*, 12-6  
 Paused LAT print queue, *NetTrouble*,  
     8-18  
 PCCOMMON file service, *ServAdmin*,  
     3-7, 6-4  
 PCDISK utility, *ServCmds*, 2-1;  
     *ServAdmin*, 5-17  
     *See also* PCDISK utility commands  
     and DOS commands, *ServCmds*, 2-3  
     backup capability, *ServCmds*, 2-8  
     command procedures, *ServCmds*, 2-8  
     commands, *ServCmds*, 2-1  
     directory structures, *ServCmds*, 2-5  
     DOS device, *ServCmds*, 2-1, 2-2  
     editing with, *ServCmds*, 2-7  
     exiting from, *ServCmds*, 2-29  
     explained, *ServCmds*, 2-1  
     help with commands, *ServCmds*, 2-35  
     how to run, *ServCmds*, 2-2  
     illegal file names, *ServCmds*, 2-4  
     messages, *ServMsgs*, 3-1  
     naming DOS files, *ServCmds*, 2-4  
     path names, *ServCmds*, 2-5  
     prompt, *ServCmds*, 2-2, 2-3  
     qualifiers, *ServCmds*, 2-3  
     running, *ServCmds*, 2-2  
     supported media, *ServCmds*, 2-1  
     term defined, *ServCmds*, 2-1  
     using wildcards with commands,  
         *ServCmds*, 2-5  
 PCDISK utility commands, *ServCmds*,  
     2-10

PCDISK utility commands (Cont.)  
 ATTRIBUTE, *ServCmds*, 2-10, 2-12  
 CHDIR, *ServCmds*, 2-10, 2-15  
 COPY, *ServCmds*, 2-10, 2-17  
 CREATE, *ServCmds*, 2-10, 2-20  
 DELETE, *ServCmds*, 2-10, 2-24  
 DIRECTORY, *ServCmds*, 2-10, 2-27  
 EXIT, *ServCmds*, 2-10, 2-29  
 EXPORT, *ServCmds*, 2-10, 2-30  
 FORMAT, *ServCmds*, 2-10, 2-33  
 HELP, *ServCmds*, 2-10, 2-35  
 IMPORT, *ServCmds*, 2-10, 2-37  
 information common to, *ServCmds*,  
     2-3  
 LABEL, *ServCmds*, 2-10, 2-40  
 MKDIR, *ServCmds*, 2-10, 2-42  
 REMOVE DIRECTORY, *ServCmds*,  
     2-10  
 RENAME, *ServCmds*, 2-10, 2-46  
 RMDIR, *ServCmds*, 2-10, 2-44  
 SET, *ServCmds*, 2-10  
 SET CONDITION, *ServCmds*, 2-48  
 SET DRIVE, *ServCmds*, 2-50  
 SET FILE, *ServCmds*, 2-52  
 SHOW, *ServCmds*, 2-10  
 SHOW CONNECTIONS, *ServCmds*,  
     2-55  
 SHOW DRIVE, *ServCmds*, 2-57  
 SHOW SERVICE, *ServCmds*, 2-59  
 SHOW VERSION, *ServCmds*, 2-61  
 SPAWN, *ServCmds*, 2-10, 2-63  
 TYPE, *ServCmds*, 2-11, 2-65  
 USE, *ServCmds*, 2-11, 2-67  
 USE drv: /DELETE, *ServCmds*, 2-72  
 USE drv: DOS\_device, *ServCmds*,  
     2-69  
 VOLUME, *ServCmds*, 2-11, 2-74  
 XCOPY, *ServCmds*, 2-11, 2-76  
 PCFS\$ADDITIONAL\_CHANNELS  
     parameter, *ServAdmin*, F-1, G-4  
 PCFS\$APPLICATION logical,  
     *ServAdmin*, 3-11  
 PCFS\$AST\_LIMIT parameter,  
     *ServAdmin*, F-1

PCFS\$BUFFER\_LIMIT parameter, *ServAdmin*, F-1  
 PCFS\$BUFFER\_SIZE parameter, *ServAdmin*, 8-8, F-2  
 PCFS\$CACHE\_OPEN\_FILES parameter, *ServAdmin*, 8-7  
 PCFS\$CACHE\_SIZE parameter, *ServAdmin*, 8-7, F-2, G-3  
 PCFS\$CACHE\_STATISTICS.TXT file, *ServAdmin*, 8-4  
 PCFS\$CLOSE\_DELAY parameter, *ServAdmin*, 8-8, F-2  
 PCFS\$CLUSTER\_ROUTING parameter, *ServAdmin*, F-3  
 PCFS\$COMMON logical, *ServAdmin*, 3-11  
 PCFS\$ENQUEUE\_LIMIT parameter, *ServAdmin*, F-3  
 PCFS\$EXTEND\_BLOCKS parameter, *ServAdmin*, 8-7, F-3  
 PCFS\$EXTENT parameter, *ServAdmin*, F-4  
 PCFS\$FILE\_LIMIT parameter, *ServAdmin*, F-4  
 PCFS\$IO\_BUFFERED parameter, *ServAdmin*, F-4  
 PCFS\$IO\_DIRECT parameter, *ServAdmin*, F-4  
 PCFS\$LOCK\_WAIT parameter, *ServAdmin*, F-5  
 PCFS\$LOG\_DELAY parameter, *ServAdmin*, F-4  
 PCFS\$LOG\_FILES:PCFS\$STARTUP\_PARAMS.DAT file, *ServAdmin*, F-1  
 PCFS\$LOG\_FILES:PCFS\_SERVER.LOG file, *ServAdmin*, 9-7  
 PCFS\$LOG\_FILES logical, *ServAdmin*, 8-4  
 PCFS\$MAXIMUM\_WORKING\_SET parameter, *ServAdmin*, F-5  
 PCFS\$MODPARAMS.DAT file, *ServAdmin*, 7-8, 8-15  
 PCFS\$MONITOR.LOG file, *ServAdmin*, 8-4  
 PCFS\$NUM\_OF\_WORKSTATIONS parameter, *ServAdmin*, 7-3, F-5, G-2, G-4  
 PCFS\$NUM\_OF\_WORKSTATONS parameter, *ServAdmin*, G-2  
 PCFS\$OPEN\_FILES parameter, *ServAdmin*, F-2, G-4  
 PCFS\$OPEN\_FILES\_PER-WKST parameter, *ServAdmin*, F-6  
 PCFS\$PAGE\_FILE parameter, *ServAdmin*, F-6  
 PCFS\$PERCENT\_AVAIL\_MEM parameter, *ServAdmin*, F-6  
 PCFS\$PRIORITY parameter, *ServAdmin*, 8-13  
 PCFS\$QUEUE\_LIMIT parameter, *ServAdmin*, F-7  
 PCFS\$READ identifier, *ServAdmin*, 3-2  
 PCFS\$SERVICE\_DATABASE logical, *ServAdmin*, 9-11  
 PCFS\$SPTREQ parameter, *ServAdmin*, F-7  
 PCFS\$STARTUP.LOG file, *ServInstall*, 3-7; *ServAdmin*, 7-7, 8-12, 9-10  
 PCFS\$STARTUP\_PARAMS.DAT file, *ServAdmin*, 7-3, 7-4, 8-9, F-1  
 VMS system resources and, *ServAdmin*, G-2  
 PCFS\$UPDATE identifier, *ServAdmin*, 3-2  
 PCFS\_LOGICALS.COM file, *ServAdmin*, 3-11  
 PCFS\_PRINT.COM file, *ServAdmin*, 4-5  
 PCFS\_SERVER.LOG file, *ServAdmin*, 9-7  
 PCFS\_STARTUP.COM file, *ServAdmin*, 8-13, 9-6  
 PCSA\$EDITOR\_COMMAND logical, *ServAdmin*, 6-6  
 PCSA applications  
     selecting languages for, *ServAdmin*, 6-6  
 PCSA Manager, *ServCmds*, 1-1  
     messages, *ServMsgs*, 2-1

PCSA Manager commands, *ServCmds*,  
 1-1  
 ADD GROUP, *ServCmds*, 1-8  
 ADD MEMBER, *ServCmds*, 1-10  
 ADD NODE, *ServCmds*, 1-12  
 ADD SERVICE/DIRECTORY,  
*ServCmds*, 1-14; *ServAdmin*,  
 3-12, 3-13, 3-14  
 ADD SERVICE/PRINTER, *ServCmds*,  
 1-20  
 ADD TEMPLATE, *ServCmds*, 1-23  
 ADD USER, *ServCmds*, 1-25;  
*ServAdmin*, 6-12  
 ADD WORKSTATION, *ServCmds*,  
 1-28; *ServAdmin*, H-5  
 BROADCAST, *ServCmds*, 1-33  
 CLOSE FILE\_SERVER FILE,  
*ServCmds*, 1-37  
 CONFIG, *ServCmds*, 1-35  
 CREATE DISK, *ServCmds*, 1-39;  
*ServAdmin*, 5-8, 5-10, 5-13  
 DELETE DISK, *ServCmds*, 1-43;  
*ServAdmin*, 5-16  
 DENY, *ServCmds*, 1-46  
 DENY/GROUP, *ServCmds*, 1-48  
 DISMOUNT DISK, *ServCmds*, 1-50;  
*ServAdmin*, 5-6, 5-16  
 EXIT, *ServCmds*, 1-52  
 GRANT, *ServCmds*, 1-53;  
*ServAdmin*, 3-21  
 GRANT/GROUP, *ServCmds*, 1-56  
 HELP, *ServCmds*, 1-60  
 help for, *ServAdmin*, 2-9  
 MENU, *ServCmds*, 1-63  
 MODIFY DISK, *ServCmds*, 1-65;  
*ServAdmin*, 5-13  
 MODIFY USER, *ServCmds*, 1-68  
 MODIFY WORKSTATION, *ServCmds*,  
 1-70; *ServAdmin*, 11-4, H-3  
 MOUNT DISK, *ServCmds*, 1-73;  
*ServAdmin*, 5-10  
 REMOVE CLIENT\_OS, *ServCmds*,  
 1-77  
 REMOVE GROUP, *ServCmds*, 1-79  
 REMOVE MEMBER, *ServCmds*, 1-81

PCSA Manager commands (Cont.)  
 REMOVE NODE, *ServCmds*, 1-83  
 REMOVE SERVICE, *ServCmds*, 1-85  
 REMOVE TEMPLATE, *ServCmds*,  
 1-87  
 REMOVE USER, *ServCmds*, 1-89  
 REMOVE WORKSTATION,  
*ServCmds*, 1-91  
 running, *ServAdmin*, 2-8  
 SET DISK\_SERVER  
 CHARACTERISTICS,  
*ServCmds*, 1-93; *ServAdmin*, 5-13  
 SET DISK\_SERVER SERVICE,  
*ServCmds*, 1-95; *ServAdmin*,  
 5-12, 5-15  
 SET FILE\_SERVER  
 CHARACTERISTICS,  
*ServCmds*, 1-98; *ServAdmin*, 6-15  
 SET FILE\_SERVER SERVICE,  
*ServCmds*, 1-102  
 SHOW CLIENT\_OS, *ServCmds*, 1-105  
 SHOW DISK\_SERVER  
 CHARACTERISTICS,  
*ServCmds*, 1-107  
 SHOW DISK\_SERVER  
 CONNECTIONS, *ServCmds*,  
 1-109  
 SHOW DISK\_SERVER COUNTER,  
*ServAdmin*, 8-14  
 SHOW DISK\_SERVER COUNTERS,  
*ServCmds*, 1-111  
 SHOW DISK\_SERVER SERVICE,  
*ServAdmin*, 5-14  
 SHOW DISK\_SERVER SERVICES,  
*ServCmds*, 1-114  
 SHOW FILE\_SERVER  
 CHARACTERISTICS,  
*ServCmds*, 1-119  
 SHOW FILE\_SERVER  
 CONNECTIONS, *ServCmds*,  
 1-121  
 SHOW FILE\_SERVER COUNTERS,  
*ServCmds*, 1-124  
 SHOW FILE\_SERVER OPEN\_FILES,  
*ServCmds*, 1-127

PCSA Manager commands (Cont.)

SHOW FILE\_SERVER SERVICES/ACTIVE,  
*ServCmds*, 1-129

SHOW FILE\_SERVER SERVICES/AUTHORIZED,  
*ServCmds*, 1-132

SHOW FILE\_SERVER SERVICES/REGISTERED,  
*ServCmds*, 1-136

SHOW FILE\_SERVER SESSIONS,  
*ServCmds*, 1-139

SHOW FILE\_SERVER STATUS,  
*ServCmds*, 1-141

SHOW GROUP, *ServCmds*, 1-143

SHOW TEMPLATES, *ServCmds*,  
1-146

SHOW USERS, *ServCmds*, 1-148

SHOW VERSION, *ServInstall*,  
3-5, 3-7; *ServCmds*, 1-150;  
*ServAdmin*, 7-5, 7-8, 8-11, 8-15

SHOW WORKSTATIONS, *ServCmds*,  
1-152

START DISK\_SERVER CONNECTIONS, *ServCmds*,  
1-154

START FILE\_SERVER CONNECTIONS, *ServCmds*,  
1-156

START FILE\_SERVER LOGGING,  
*ServCmds*, 1-158

STOP DISK\_SERVER CONNECTIONS  
, *ServCmds*, 1-161; *ServAdmin*,  
8-14

STOP FILE\_SERVER CONNECTIONS,  
*ServCmds*, 1-163

STOP FILE\_SERVER LOGGING,  
*ServCmds*, 1-165

STOP FILE\_SERVER SESSION,  
*ServCmds*, 1-168  
using, *ServAdmin*, 2-1, 2-8

ZERO DISK\_SERVER COUNTERS,  
*ServCmds*, 1-170

PCSA Manager Menu

PCSA Manager Menu (Cont.)

Add a Printer Queue option,  
*ServCmds*, 1-20

default responses to, *ServAdmin*, 2-5

entering, *ServAdmin*, 2-3

exiting, *ServAdmin*, 2-3

moving around in, *ServAdmin*, 2-4

options available in (illus.),  
*ServAdmin*, 2-5

SET FILE\_SERVER CHARACTERISTICS,  
*ServAdmin*, 9-4

tree diagram of (illus.), *ServAdmin*,  
2-5

user profile form, *ServAdmin*, C-1

using, *ServAdmin*, 2-1

Performance

in personal computer applications,  
*ServAdmin*, 8-2

NPAGEDYN and, *ServAdmin*, 8-14

on disk server, *ServAdmin*, 8-13

on file server, *ServAdmin*, 8-2

on Local Area System Transport,  
*ServAdmin*, 8-16

Permanent disk services

term defined, *ServAdmin*, 5-11

PERSONAL accounts

default installation disk, *ServInstall*,  
2-6

Personal computers

and parallel printers, *ServAdmin*, 4-1

Personal disks

creating, *ServAdmin*, 5-7

mounting, *ServAdmin*, 5-10

Physical queues

name for, *ServAdmin*, 4-4, 4-8, 4-14

term defined, *ServAdmin*, 4-8

PING command

DOS, *NetTrouble*, 4-12

ULTRIX, *NetTrouble*, 4-9

PL/I programs

creating files compatible with file  
server, *ServAdmin*, A-5

Portrait forms, *ServAdmin*, 1-3, 4-1

Ports

## Ports (Cont.)

See Printer ports

Postinstallation tasks, *ServInstall*, 3-1

checklist, *ServInstall*, 3-1

system, *ServInstall*, 3-6

Preinstallation tasks

checklist, *ServInstall*, 1-2

DECnet, *ServInstall*, 1-6

Prerequisite hardware, *ServInstall*, 1-3

Prerequisite software, *ServInstall*, 1-3

Printer forms

See Forms

Printer output, *ServAdmin*, 4-24

connecting to services and,

*ServAdmin*, 4-24

Printer ports, *ServAdmin*, 4-9

and printer startup file, *ServAdmin*,  
4-5

## Printers

blank pages and, *ServAdmin*, 4-20

HP LaserJet, *ServAdmin*, B-1

identifying output, *ServAdmin*, 4-24

listed on PCSA Manager Menu,

*ServAdmin*, 4-2, 4-14

not listed on PCSA Manager Menu,

*ServAdmin*, 4-7, 4-13

parallel, *ServAdmin*, 4-1

physical queue, *ServAdmin*, 4-8, 4-14

reset mode, *ServAdmin*, 4-10

selecting for user, *ServAdmin*, 6-5

with DECservers, *ServAdmin*, 4-16

without VMS queues, *ServAdmin*, 4-7

with terminal servers, *ServAdmin*,  
4-16

with VMS queues, *ServAdmin*, 4-13

Printer services, *ServAdmin*, 4-1

access to, *ServAdmin*, 3-19, 4-14

adding, *ServAdmin*, 4-13

adding for printers with terminal  
servers, *ServAdmin*, 4-16

and VMS print queues, *ServAdmin*,  
4-1

default access to, *ServAdmin*, 3-18,  
4-5

denying access, *ServAdmin*, 3-18,  
3-19

## Printer services (Cont.)

for Epson printers, *ServAdmin*, 4-9

for printers listed on PCSA Manager  
Menu, *ServAdmin*, 4-2, 4-14

for printers not listed on PCSA  
Manager Menu, *ServAdmin*, 4-7,  
4-13

for printers without VMS queues,  
*ServAdmin*, 4-2, 4-8

for printers with VMS queues,  
*ServAdmin*, 4-13

granting access, *ServAdmin*, 3-18,  
3-19

identifying printer output, *ServAdmin*,  
4-24

LPT1, *ServAdmin*, 6-5

names for printers listed in menu  
(table), *ServAdmin*, 4-6

privileges for, *ServAdmin*, 4-2

selecting for user, *ServAdmin*, 6-5

subdirectories for printers listed in  
menu (table), *ServAdmin*, 4-6

VMS server troubleshooting procedure  
for LAST, *NetTrouble*, 11-15

## Printer startup file

creating, *ServAdmin*, 4-5

customized, *ServAdmin*, 4-5, 4-12

default, *ServAdmin*, 4-5

name of, *ServAdmin*, 4-5

PCFS\_PRINT.COM, *ServAdmin*, 4-5

term defined, *ServAdmin*, 4-5

## Printers without VMS queues

adding printer services for,  
*ServAdmin*, 4-2

adding printer services for printers  
listed on PCSA Manager Menu,  
*ServAdmin*, 4-2

adding printer services for printers not  
listed on PCSA Manager Menu,  
*ServAdmin*, 4-7

## Printers with VMS queues

adding printer services for,  
*ServAdmin*, 4-13

## Printers with VMS queues (Cont.)

- adding printer services for printers listed on PCSA Manager Menu, *ServAdmin*, 4-14
- adding printer services for printers not listed on PCSA Manager Menu, *ServAdmin*, 4-13

## Printing

- from personal computers, *ServAdmin*, 4-1
- identifying users' output, *ServAdmin*, 4-24
- using printer services, *ServAdmin*, 4-1

## Print jobs

- identifying, *ServAdmin*, 4-24

## Print queues

- adding, *ServAdmin*, 4-2, 4-7
- and printer services, *ServAdmin*, 4-1
- creating, *ServAdmin*, 4-12
- fixing a paused LAT queue, *NetTrouble*, 8-18
- fixing a stalled LAT queue, *NetTrouble*, 8-17
- for printers listed on PCSA Manager Menu (table), *ServAdmin*, 4-6
- generic, *ServAdmin*, 4-8, 4-14
- job retained on error, *NetTrouble*, 8-23
- jobs retained on error, *NetTrouble*, 8-23
- physical, *ServAdmin*, 4-8
- printing incorrectly, *NetTrouble*, 8-22
- starting a stopped queue, *NetTrouble*, 8-17
- states and conditions, *NetTrouble*, 8-16

## Privileged accounts, *NetTrouble*, 3-3, 6-1

- required for troubleshooting, *NetTrouble*, 8-8

## Privileges

- NETMBX, *ServInstall*, C-2
- required for installation, *ServInstall*, 1-4
- setting up user, *ServInstall*, C-2
- TMPMBX, *ServInstall*, C-2

## Process account quotas

## Process account quotas (Cont.)

- required for installation, *ServInstall*, 1-12

## Product Authorization Key (PAK),

*NetTrouble*, 4-4

## Proxy files, *ServAdmin*, 9-3

## Public access

- denying, *ServAdmin*, 3-18
- term defined, *ServAdmin*, 3-17

## Purging files, *ServInstall*, 2-5

## Q

---

## Qualifiers for PCDISK utility, *ServCmds*, 2-3

## Question mark, *ServCmds*, 2-5

## Queues

- See Print queues

## R

---

## Ratings

- assigning to disk services, *ServAdmin*, 5-14
- term defined, *ServAdmin*, 5-14

## Read access

- See also Access to files
- See also Access to services
- for disk services, *ServAdmin*, 5-2

## Recalculating system parameters, *ServInstall*, E-1

## Record attributes

- in VMS files, *ServAdmin*, A-4
- Record Management System (RMS) and carriage control, *ServAdmin*, A-1
- compared to DOS, *ServAdmin*, A-2
- overhead for storing records, *ServAdmin*, A-3

## Registered nodes, *ServAdmin*, 11-1

## Registering workstations

- ADD WORKSTATION command, *ServCmds*, 3-20

## Release notes

- file name, *ServInstall*, 2-5
- OPTIONS N parameter, *ServInstall*, 2-3



## Release notes (Cont.)

ways to view, *ServInstall*, 2-4

## Remote boot

ADD WORKSTATION command,  
*ServCmds*, 3-20

configuring, *ServCmds*, 1-28

creating template for, *ServCmds*, 1-23

displaying workstations, *ServCmds*,  
1-152

enabling services, *ServInstall*, 1-9

removing template for, *ServCmds*,  
1-87

term defined, *ServInstall*, 1-9

using templates for, *ServCmds*, 1-28

## Remote boot clients

and group codes, *ServAdmin*, 7-12

configuring VAXmate clients,  
*ServAdmin*, H-5, H-8

deleting, *ServAdmin*, 11-3

listing, *ServAdmin*, 11-3

## Remote files, *ServAdmin*, 9-3

REMOVE CLIENT\_OS command (PCSA  
Manager), *ServCmds*, 1-77

REMOVE DIRECTORY command  
(PCDISK utility), *ServCmds*, 2-10

REMOVE GROUP command (PCSA  
Manager), *ServCmds*, 1-79

REMOVE MEMBER command (PCSA  
Manager), *ServCmds*, 1-81

REMOVE NODE command (PCSA  
Manager), *ServCmds*, 1-83

REMOVE SERVICE command (PCSA  
Manager), *ServCmds*, 1-85

REMOVE TEMPLATE command (PCSA  
Manager), *ServCmds*, 1-87

REMOVE USER command (PCSA  
Manager), *ServCmds*, 1-89

REMOVE WORKSTATION command  
(PCSA Manager), *ServCmds*, 1-91

## Removing

client operating system, *ServCmds*,  
1-77

directory service, *ServCmds*, 1-85

group, *ServCmds*, 1-79

member, *ServCmds*, 1-81

## Removing (Cont.)

node, *ServCmds*, 1-83

print service, *ServCmds*, 1-85

template, *ServCmds*, 1-87

user, *ServCmds*, 1-89

workstation, *ServCmds*, 1-91

RENAME command (PCDISK utility),  
*ServCmds*, 2-10, 2-46

## Requirements

DOS client components

for LAST, *NetTrouble*, 11-21

DOS component load order

for LAST, *NetTrouble*, 11-22

for troubleshooting LAT, *NetTrouble*,  
8-8

installation, *ServInstall*, 1-3

OS/2 client components

for LAST, *NetTrouble*, 11-34

OS/2 component load order

for LAST, *NetTrouble*, 11-35

Reset mode, *ServAdmin*, 4-10

Reset module

preventing blank pages in,  
*ServAdmin*, 4-20

## Restoring

boot database, *ServAdmin*, 11-4

disk services, *ServAdmin*, 9-18

file services, *ServAdmin*, 9-18

PATHWORKS Server 3100,  
*ServAdmin*, 12-2, 12-4

user accounts, *ServAdmin*, 9-18

## Return key

alternatives to, *ServAdmin*, 2-4

RMDIR command (PCDISK utility),  
*ServCmds*, 2-10, 2-44

## RMS FIXED format

in file services, *ServAdmin*, 3-13

RMS protection, *ServAdmin*, 1-5, 3-5

changing, *ServAdmin*, 3-6

on files in common file services,  
*ServAdmin*, 3-3, 3-9

RMS sequential files, *ServAdmin*, 3-11

## RMS STREAM format

in file services, *ServAdmin*, 3-13

## Routing

## Routing (Cont.)

layer events, *NetTrouble*, A-1

## Run-time parameters

and file server, *ServAdmin*, 7-4, 8-9

## S

---

### Save set

name for, *ServAdmin*, 9-19

### Screaming node, *NetTrouble*, 3-15

### SCSNODE system parameter,

*ServInstall*, E-7

### Security

*See also* Access to services

and default account, *ServAdmin*, 6-15

and user accounts, *ServAdmin*, 1-6

in application file services, *ServAdmin*, 3-2

in common file services, *ServAdmin*, 3-2, 3-9

in common versus application file services, *ServAdmin*, 1-4

in disk services, *ServAdmin*, 1-3, 5-1, 5-10

in file services, *ServAdmin*, 1-4, 3-1

in user accounts, *ServAdmin*, 6-13

monitoring on file server, *ServAdmin*, 9-6

on files in common file service,

*ServAdmin*, 3-5, 3-9

setting up, *ServInstall*, C-1

using file server log file to monitor, *ServAdmin*, 9-6

### Sending messages, *ServAdmin*, 10-1

### Sequential files

term defined, *ServAdmin*, 3-13

### Server-based messages (TCP/IP),

*NetTrouble*, 6-2

### Server-to-Server Loop Test

for DECnet, *NetTrouble*, 2-71

### SET command (PCDISK utility),

*ServCmds*, 2-10

### SET CONDITION command (PCDISK utility), *ServCmds*, 2-48

SET DIRECTORY command, *ServAdmin*, 6-3

### SET DISK\_SERVER CHARACTERISTICS

command (PCSA Manager),

*ServCmds*, 1-93; *ServAdmin*, 5-13

### SET DISK\_SERVER SERVICE command

(PCSA Manager), *ServCmds*, 1-95;

*ServAdmin*, 5-12, 5-15

### SET DRIVE command (PCDISK utility),

*ServCmds*, 2-50

### SET FILE/VERSION\_LIMIT command,

*ServAdmin*, 6-3

### SET FILE command (PCDISK utility),

*ServCmds*, 2-52

### SET FILE\_SERVER CHARACTERISTICS

command (PCSA Manager),

*ServCmds*, 1-98; *ServAdmin*, 6-15, 9-4, 9-5

### SET FILE\_SERVER SERVICE command

(PCSA Manager), *ServCmds*, 1-102

### Setting

cache buffer size, *ServAdmin*, 8-8

cache size, *ServAdmin*, 8-7

delay for open file caching, *ServAdmin*, 8-8

open file caching, *ServAdmin*, 8-7

### SHOW CIRCUIT COUNTERS command

(ESS\$LASTTCP), *ServCmds*, 3-7

### SHOW CLIENTS command

(ESS\$LASTTCP), *ServCmds*, 3-9

### SHOW CLIENT\_OS command (PCSA

Manager), *ServCmds*, 1-105

### SHOW command (PCDISK utility),

*ServCmds*, 2-10

### SHOW CONNECTIONS command

(PCDISK utility), *ServCmds*, 2-55

### SHOW DISK\_SERVER

CHARACTERISTICS command

(PCSA Manager), *ServCmds*, 1-107

### SHOW DISK\_SERVER CONNECTIONS

command (PCSA Manager),

*ServCmds*, 1-109; *ServAdmin*, 9-13

**SHOW DISK\_SERVER COUNTERS**  
 command (PCSA Manager),  
*ServCmds*, 1-111; *ServAdmin*, 8-14

**SHOW DISK\_SERVER SERVICES**  
 command (PCSA Manager),  
*ServCmds*, 1-114; *ServAdmin*, 5-14

**SHOW DRIVE** command (PCDISK utility), *ServCmds*, 2-57

**SHOW FILE\_SERVER CHARACTERISTICS** command (PCSA Manager), *ServCmds*, 1-119

**SHOW FILE\_SERVER** command (PCSA Manager), *ServAdmin*, 9-3

**SHOW FILE\_SERVER CONNECTIONS** command (PCSA Manager), *ServCmds*, 1-121; *ServAdmin*, 9-2

**SHOW FILE\_SERVER COUNTERS** command (PCSA Manager), *ServCmds*, 1-124

**SHOW FILE\_SERVER OPEN\_FILES** command (PCSA Manager), *ServCmds*, 1-127

**SHOW FILE\_SERVER SERVICES/ACTIVE** command (PCSA Manager), *ServCmds*, 1-129

**SHOW FILE\_SERVER SERVICES/AUTHORIZED** command (PCSA Manager), *ServCmds*, 1-132

**SHOW FILE\_SERVER SERVICES/REGISTERED** command (PCSA Manager), *ServCmds*, 1-136

**SHOW FILE\_SERVER SERVICES** command (PCSA Manager), *ServAdmin*, 9-2

**SHOW FILE\_SERVER SESSIONS** command (PCSA Manager), *ServCmds*, 1-139

**SHOW FILE\_SERVER STATUS** command (PCSA Manager), *ServCmds*, 1-141

**SHOW GROUP** command (PCSA Manager), *ServCmds*, 1-143

**SHOW LINE COUNTERS** command (ESS\$LASTCP), *ServCmds*, 3-11

**SHOW NODE CHARACTERISTICS** command (ESS\$LASTCP), *ServCmds*, 3-14

**SHOW NODE COUNTERS** command (ESS\$LASTCP), *ServCmds*, 3-16

**SHOW SERVERS** command (ESS\$LASTCP), *ServCmds*, 3-18

**SHOW SERVICE** command (PCDISK utility), *ServCmds*, 2-59

**SHOW STATUS** command (ESS\$LASTCP), *ServCmds*, 3-20

**SHOW TEMPLATES** command (PCSA Manager), *ServCmds*, 1-146

**SHOW TRANSPORT COUNTERS** command (ESS\$LASTCP), *ServCmds*, 3-22

**SHOW USERS** command (PCSA Manager), *ServCmds*, 1-148

**SHOW VERSION** command (PCDISK utility), *ServCmds*, 2-61

**SHOW VERSION** command (PCSA Manager), *ServInstall*, 3-5, 3-7; *ServCmds*, 1-150; *ServAdmin*, 7-5, 7-8, 8-11, 8-15

**SHOW WORKSTATIONS** command (PCSA Manager), *ServCmds*, 1-152

Software license agreements, *ServAdmin*, 1-8

Source file (PCDISK utility), *ServCmds*, 2-3

Source routing, *NetTrouble*, D-4

**SPAWN** command (PCDISK utility), *ServCmds*, 2-10, 2-63

Spool subdirectory term defined, *ServAdmin*, 4-5

SPTREQ parameters, *ServAdmin*, F-7

**START DISK\_SERVER CONNECTIONS** command (PCSA Manager), *ServCmds*, 1-154

**START FILE\_SERVER CONNECTIONS** command (PCSA Manager), *ServCmds*, 1-156

## START FILE\_SERVER LOGGING

command (PCSA Manager),  
*ServCmds*, 1-158

### Starting

- disk servers, *ServCmds*, 1-154;  
*ServAdmin*, 9-14
- file servers, *ServInstall*, 3-7;  
*ServCmds*, 1-35; *ServAdmin*, 7-6,  
8-12, 9-10
- Local Area System Transport (LAST),  
*ServAdmin*, 7-9, 7-10, 7-12
- logging of file server events,  
*ServCmds*, 1-158
- VMS operating system, *ServInstall*,  
3-4; *ServAdmin*, 7-4, 8-10

## START TRANSPORT command

(ESS\$LASTCP), *ServCmds*, 3-24

### Startup file

- See also AUTOUSER.BAT file
- See also Printer startup file
- adding to, *ServInstall*, 3-8
- for clients, *ServAdmin*, 6-1
- for printer service, *ServAdmin*, 4-5
- for VMS operating system,  
*ServAdmin*, 4-5, 4-12

### Startup parameters

- for disk servers, *ServAdmin*, 7-7, 8-14
- for file servers, *ServAdmin*, 7-3, 7-4,  
8-9, F-1
- for Local Area System Transport  
(LAST), *ServAdmin*, 7-9

### Startup procedure

- DECnet, *ServInstall*, 1-14
- system, *ServInstall*, 3-8

### Star-wired ring, *NetTrouble*, D-3

## STOP DISK\_SERVER CONNECTIONS

command (PCSA Manager),  
*ServCmds*, 1-161; *ServAdmin*, 8-14,  
9-14, 9-18

## STOP FILE\_SERVER CONNECTIONS

command (PCSA Manager),  
*ServCmds*, 1-163; *ServAdmin*, 9-3

## STOP FILE\_SERVER LOGGING

command (PCSA Manager),  
*ServCmds*, 1-165

## STOP FILE\_SERVER SESSION command

(PCSA Manager), *ServCmds*, 1-168;  
*ServAdmin*, 9-2

### Stopping

- connections to file services,  
*ServAdmin*, 9-3
- disk server, *ServCmds*, 1-161;  
*ServAdmin*, 9-14
- file server, *ServAdmin*, 9-10
- file server connections, *ServCmds*,  
1-163
- file server logging, *ServCmds*, 1-165
- Local Area System Transport (LAST),  
*ServAdmin*, 7-10
- workstation session with file server,  
*ServCmds*, 1-168

## STOP TRANSPORT command

(ESS\$LASTCP), *ServCmds*, 3-28

### Storing applications, *ServAdmin*, 1-7

- Stream files, *ServAdmin*, 3-13
- and cache, *ServAdmin*, 8-2
- term defined, *ServAdmin*, 3-13

### Stream format

in VMS files, *ServAdmin*, A-7

## SYS\$SPECIFIC logical

using for file server log file,  
*ServAdmin*, 9-11

SYS\$STARTUP:ESS\$LAD\_STARTUP.DAT  
file, *ServAdmin*, 8-14

SYS\$STARTUP:LAD\_STARTUP.COM file,  
*ServAdmin*, 5-13

SYS\$STARTUP:PCFS\_PRINT.COM file,  
*ServAdmin*, 4-5

SYS\$STARTUP:SYSTARTUP\_V5.COM  
file, *ServAdmin*, 4-5, 4-12

### SYSGEN parameters

- CHANNELCNT, *ServAdmin*, F-1, F-6
- NPAGEDYN, *ServAdmin*, G-5
- NPAGEVIR, *ServAdmin*, G-5
- SPTREQ, *ServAdmin*, F-7
- WSMAX, *ServAdmin*, F-5, F-6

### SYSGEN utility

checking system parameter values  
with, *ServInstall*, E-3

SYSMWCNT system parameter,  
    *ServInstall*, E-9  
SYSTARTUP\_V5.COM file, *ServAdmin*,  
    4-5, 4-12  
    editing, *ServInstall*, 3-8  
SYSTEM account  
    disk quotas, *ServInstall*, 1-5, 3-11  
System backup, *ServInstall*, 2-3  
System disk  
    backing up, *ServInstall*, 1-4  
System parameters, *ServInstall*, 3-4;  
    *ServAdmin*, 7-4, 8-10  
    *See also* AUTOGEN procedure (VMS)  
    *See also* VMS operating system  
    and memory, *ServAdmin*, 8-16  
    checking values with SYSGEN,  
        *ServInstall*, E-3  
    for installation, *ServInstall*, E-1  
    GBLPAGES, *ServInstall*, E-4  
    GBLSECTIONS, *ServInstall*, E-6  
    MAXBUF, *ServInstall*, E-7  
    NPAGEDYN, *ServAdmin*, 7-8, 8-14,  
        G-5  
    SCSNODE, *ServInstall*, E-7  
    SYSMWCNT, *ServInstall*, E-9  
    worksheet of installation, *ServInstall*,  
        E-2  
System resources  
    *See* VMS operating system  
System services  
    and file services, *ServAdmin*, 3-2  
    disk and file, *ServAdmin*, 11-4  
    listing, *ServAdmin*, 11-4  
System startup procedure, *ServInstall*,  
    3-8

## T

TCP/IP  
    Hardware and configuration,  
        *NetTrouble*, 5-33  
    messages, *NetTrouble*, 6-1  
    troubleshooting tools, *NetTrouble*, 4-1  
TCP/IP Problem-Isolation Flowcharts,  
    *NetTrouble*, 5-1  
TCP/IP software  
    verifying, *ServInstall*, 1-11  
Templates  
    for remote boot workstations,  
        *ServCmds*, 1-28  
Temporary disk services  
    term defined, *ServAdmin*, 5-11  
Terminal lines, *ServAdmin*, 4-3  
Terminal server  
    commands, *NetTrouble*, 8-15  
    connection failure, *NetTrouble*, 7-6  
    managing using TSM or NCP,  
        *NetTrouble*, 8-15  
Terminal server connection failures,  
    *NetTrouble*, 8-62  
Terminal Server Manager Software,  
    *NetTrouble*, 7-6  
    entering commands, *NetTrouble*, 7-8  
    online help for, *NetTrouble*, 7-8  
    requirements to run, *NetTrouble*, 7-7  
    running, *NetTrouble*, 7-8  
    uses of, *NetTrouble*, 7-6  
Terminal server problems  
    data set hangup error, *NetTrouble*,  
        8-19  
Terminal servers  
    setting up printers on, *ServAdmin*,  
        4-16  
Text files  
    in DOS and VMS, *ServAdmin*, A-2,  
        A-7  
ThinWire Ethernet  
    configuration guidelines, *NetTrouble*,  
        C-2  
ThinWire multiport repeaters  
    configuration guidelines, *NetTrouble*,  
        C-3  
Timeout  
    changing on disk server, *ServAdmin*,  
        7-9, 9-13  
TMPMBX privilege  
    setting, *ServInstall*, C-2  
Token Ring  
    cabling requirements, *NetTrouble*, D-3  
    diagnostics, *NetTrouble*, 1-10, 2-13

Token Ring (Cont.)  
 term defined, *NetTrouble*, D-1

Tools  
 for troubleshooting DECnet,  
*NetTrouble*, 1-1  
 for troubleshooting LAST, *NetTrouble*,  
 10-1  
 for troubleshooting LAT, *NetTrouble*,  
 7-1  
 for troubleshooting TCP/IP,  
*NetTrouble*, 4-1

TRNcontroller diagnostics, *NetTrouble*,  
 2-13

Troubleshooting  
 DECnet, *NetTrouble*, 2-1  
 Local Area System Transport (LAST),  
*NetTrouble*, 11-1  
 Local Area Transport (LAT),  
*NetTrouble*, 8-1  
 TCP/IP, *NetTrouble*, 5-1

TSM  
*See* Terminal Server Manager Software

Tuning  
*See* Performance

TYPE command (PCDISK utility),  
*ServCmds*, 2-11, 2-65

## U

---

UAF  
*See* User Authorization File (UAF)

ULTRIX files  
 /etc/password, *NetTrouble*, 6-14  
 /etc/rc.local, *NetTrouble*, 6-10, 6-17

ULTRIX File Server Procedure  
 for DECnet, *NetTrouble*, 2-30  
 for TCP/IP, *NetTrouble*, 5-20

ULTRIX log files (TCP/IP), *NetTrouble*,  
 4-10

ULTRIX Remote Printing Procedure  
 for DECnet, *NetTrouble*, 2-32  
 for TCP/IP, *NetTrouble*, 5-22

ULTRIX Server Master Procedure  
 for DECnet, *NetTrouble*, 2-24  
 for LAT, *NetTrouble*, 8-24

ULTRIX Server Master Procedure (Cont.)  
 for TCP/IP, *NetTrouble*, 5-18

ULTRIX Server Transport Procedure  
 for DECnet, *NetTrouble*, 2-25  
 for TCP/IP, *NetTrouble*, 5-19

ULTRIX Tools (TCP/IP), *NetTrouble*, 4-7

USE command, *ServAdmin*, 1-5, 3-3,  
 3-4, 3-14, 5-4

USE command (PCDISK utility),  
*ServCmds*, 2-11, 2-67

USE drv: /DELETE command (PCDISK  
 utility), *ServCmds*, 2-72

USE drv: DOS\_device command (PCDISK  
 utility), *ServCmds*, 2-69

User accounts  
*See also* VMS accounts  
 modifying, *ServAdmin*, 6-6

User Authorization File (UAF),  
*ServInstall*, C-2; *ServAdmin*, 6-13,  
 6-15  
*See also* VMS accounts

User Identification Codes (UIC),  
*ServAdmin*, 1-5, 3-3  
 contrasted with groups, *ServAdmin*,  
 3-3, 6-17

Usernames  
*See* VMS usernames

User passwords, *ServAdmin*, 6-3

User privileges  
 setting up, *ServInstall*, C-1

User profiles  
 and adding a user, *ServAdmin*, 6-2  
 form for, *ServAdmin*, C-1

Users  
*See also* AUTOUSER.BAT file  
*See also* VMS accounts  
 access to disk services, *ServAdmin*,  
 1-3, 5-1  
 access to files, *ServAdmin*, 1-5  
 access to file services, *ServAdmin*, 1-4,  
 1-5  
 access to printer services, *ServAdmin*,  
 1-5  
 accounts for, *ServAdmin*, 6-3  
 adding, *ServAdmin*, 6-2

## Users (Cont.)

- adding to groups, *ServAdmin*, 6-18
- connecting to services, *ServAdmin*, 1-5, 3-16, 3-17
- defining name, *ServAdmin*, 6-3
- defining password, *ServAdmin*, 6-3
- deleting accounts for, *ServAdmin*, 6-12
- denying access to file services, *ServAdmin*, 3-19
- granting access to file services, *ServAdmin*, 3-16, 3-19
- listing, *ServAdmin*, 6-12
- modifying their AUTOUSER.BAT file, *ServAdmin*, 6-6
- removing from groups, *ServAdmin*, 6-19
- specifying connections for client startup, *ServAdmin*, 6-4
- startup file for, *ServAdmin*, 6-1
- username for, *ServAdmin*, 1-5

## V

---

- VAXclusters, *ServAdmin*, 9-10
  - database for services, *ServAdmin*, 9-11
  - file server log file and, *ServAdmin*, 9-11
  - sharing files, *ServAdmin*, 9-10
- VAXmate clients
  - adding for remote boot, *ServAdmin*, H-5
  - changing Ethernet controller and addresses, *ServAdmin*, H-3
  - configuring, *ServAdmin*, H-1
  - configuring with remote boot, *ServAdmin*, H-8
  - reconfiguring on a PATHWORKS for VMS, *ServAdmin*, H-2
- Version limits
  - in VMS files, *ServAdmin*, 6-3
- Virtual disks
  - See also* Disk services
  - See also* Remote boot clients
  - access to, *ServAdmin*, 5-13

## Virtual disks (Cont.)

- allocating space for, *ServAdmin*, 5-9
  - assigning password for, *ServAdmin*, 5-10
  - choosing location for, *ServAdmin*, 5-7
  - creating, *ServAdmin*, 5-7
  - default location for, *ServAdmin*, 5-7
  - default size, *ServAdmin*, 5-9
  - defining access to, *ServAdmin*, 5-13
  - deleting, *ServAdmin*, 5-16
  - directory for, *ServAdmin*, 5-8
  - DOS, *ServCmds*, 2-2
  - extending size of, *ServAdmin*, 5-13
  - location for, *ServAdmin*, 5-7
  - making available to users, *ServAdmin*, 5-7
  - mounting, *ServAdmin*, 5-6, 5-10
  - PCDISK utility, *ServCmds*, 2-1
- ## Virtual disk services
- VMS server troubleshooting procedure, *NetTrouble*, 11-12
- ## VMS/ULTRIX Connection software
- verifying, *ServInstall*, 1-11
- ## VMS accounts, *ServAdmin*, 6-1
- See also* Default account
  - and printer output, *ServAdmin*, 4-24
  - backing up, *ServAdmin*, 9-16
  - creating with PCSA Manager Menu, *ServAdmin*, 6-1
  - default, *ServAdmin*, 6-15, 6-18
  - defining, *ServAdmin*, 6-3
  - deleting, *ServAdmin*, 6-12
  - file version limit in, *ServAdmin*, 6-3
  - moving, *ServAdmin*, 6-7, 6-11
  - passwords for, *ServAdmin*, 6-3, 6-14
  - restoring, *ServAdmin*, 9-18
  - usernames for, *ServAdmin*, 1-5, 6-3
- ## VMS BACKUP command, *ServAdmin*, 9-18
- ## VMS command line editing
- with PCDISK, *ServCmds*, 2-7
- ## VMS directories
- as file service, *ServAdmin*, 1-3
- ## VMS DISKQUOTA utility

## VMS DISKQUOTA utility (Cont.)

- and extending files, *ServAdmin*, 8-7, F-3
- and moving user accounts, *ServAdmin*, 6-7

## VMS files

- and carriage control, *ServAdmin*, A-1
- converting formats of, *ServAdmin*, A-5
- creating for file services, *ServAdmin*, A-5
- in file services, *ServAdmin*, 1-3
- modifying in file services, *ServAdmin*, A-2
- record attributes of, *ServAdmin*, A-4
- structure of, *ServAdmin*, A-1
- using in file services, *ServAdmin*, A-1, A-2
- using programming languages to create, *ServAdmin*, A-5
- with FIXED format, *ServAdmin*, A-7
- without carriage control information, *ServAdmin*, A-7
- with STREAM format, *ServAdmin*, A-7

## VMS File Server Procedure

- for DECnet, *NetTrouble*, 2-18

## VMS identifiers, *ServAdmin*, 3-2

## VMSINSTALL procedure

- components located by, *ServInstall*, 2-6
- description of, *ServInstall*, 2-1
- disk quotas required, *ServInstall*, 1-5
- error messages and conditions, *ServInstall*, 2-8
- interrupting, *ServInstall*, 2-3
- responding to questions, *ServInstall*, 2-2
- starting, *ServInstall*, 2-2, 2-3

## VMS log files (TCP/IP), *NetTrouble*, 4-2

## VMS operating system

- managing memory, *ServAdmin*, 8-16
- priority in, *ServAdmin*, 8-13
- run-time parameters, *ServAdmin*, 7-4, 8-9

## VMS operating system (Cont.)

- starting, *ServInstall*, 3-4; *ServAdmin*, 7-4, 8-10
- system parameters required for disk server, *ServAdmin*, 7-8, 8-13, 8-14
- system parameters required for file server, *ServInstall*, 3-4; *ServAdmin*, 7-4, 8-10

## VMS passwords

- defining, *ServAdmin*, 6-3
- expiration of, *ServAdmin*, 6-14

## VMS priority

- and file server performance, *ServAdmin*, 8-13

## VMS queues

- See Print queues

## VMS Remote Printing Procedure

- for DECnet, *NetTrouble*, 2-22
- for TCP/IP, *NetTrouble*, 5-15

## VMS Server Disk Services Procedure, *NetTrouble*, 11-12

## VMS Server File Services Procedure for LAST, *NetTrouble*, 11-15

## VMS Server LAT Service Procedure for VMS, *NetTrouble*, 8-13

- VMS Server Master Procedure for DECnet, *NetTrouble*, 2-8
- for LAST, *NetTrouble*, 11-9
- for LAT, *NetTrouble*, 8-9
- for TCP/IP, *NetTrouble*, 5-8

## VMS Server Maximum Connections Procedure, *NetTrouble*, 11-17

## VMS Server Maximum Links/Connections Procedure for LAT, *NetTrouble*, 8-14

## VMS Server Remote Printer Services Procedure, *NetTrouble*, 8-15

- VMS Server Transport Procedure for DECnet, *NetTrouble*, 2-9
- for LAST, *NetTrouble*, 11-10
- for LAT, *NetTrouble*, 8-10
- for TCP/IP, *NetTrouble*, 5-9

## VMS startup file, *ServAdmin*, 4-5, 4-12

## VMS tools (TCP/IP), *NetTrouble*, 4-2



VMS usernames, *ServAdmin*, 1-5  
  *See also* VMS accounts  
  and access to files in common file  
  services, *ServAdmin*, 3-4  
  and printer output, *ServAdmin*, 4-24  
  defining, *ServAdmin*, 6-3  
VOLUME command (PCDISK utility),  
  *ServCmds*, 2-11, 2-74

## Zeroing (Cont.)

  disk server counters, *ServCmds*, 1-170

## W

---

WAN problems (DECnet)  
  asynchronous, *NetTrouble*, 3-11  
Wildcards, *ServCmds*, 2-5  
Worksheet  
  for system parameters, *ServInstall*,  
  E-1  
Workstations  
  *See* Clients  
WPS-PLUS  
  using files on DOS and VMS,  
  *ServAdmin*, 3-13  
WPS-PLUS files  
  using in DOS and VMS, *ServAdmin*,  
  A-7  
Write access  
  *See also* Access to files  
  *See also* Access to services  
  for disk services, *ServAdmin*, 5-2  
WSMAX parameter, *ServAdmin*, F-5,  
  F-6

## X

---

XCOPY command (PCDISK utility),  
  *ServCmds*, 2-11, 2-76

## Z

---

ZERO COUNTERS command  
  (ESS\$LASTCP), *ServCmds*, 3-30  
ZERO DISK\_SERVER COUNTERS  
  command (PCSA Manager),  
  *ServCmds*, 1-170  
Zeroing

# Reader's Comments

PATHWORKS for VMS  
Server Master Index

AA-PF41B-TK

---

Your comments and suggestions help us improve the quality of our publications.

**Please rate the manual in the following categories:**

	Excellent	Good	Fair	Poor
Accuracy (product works as described)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Completeness (enough information)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Clarity (easy to understand)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Organization (structure of subject matter)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Figures (useful)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Examples (useful)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Table of contents (ability to find topic)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Index (ability to find topic)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Page design (overall appearance)	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>
Print quality	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>

What I like best about this manual: \_\_\_\_\_  
\_\_\_\_\_

What I like least about this manual: \_\_\_\_\_  
\_\_\_\_\_

Additional comments or suggestions: \_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

I found the following errors in this manual:

Page	Description
_____	_____
_____	_____
_____	_____

For which tasks did you use this manual?

- |  |   |
|--|---|
| <input type="checkbox"/> Installation  | <input type="checkbox"/> Programming                  |
| <input type="checkbox"/> Maintenance   | <input type="checkbox"/> System Management            |
| <input type="checkbox"/> Marketing     | <input type="checkbox"/> Training                     |
| <input type="checkbox"/> Operation/Use | <input type="checkbox"/> Other (please specify) _____ |

Name/Title \_\_\_\_\_

Company \_\_\_\_\_

Address \_\_\_\_\_  
\_\_\_\_\_


Phone \_\_\_\_\_ Date \_\_\_\_\_

Do Not Tear - Fold Here and Tape

**digital**



NO POSTAGE  
NECESSARY  
IF MAILED  
IN THE  
UNITED STATES



**BUSINESS REPLY MAIL**

FIRST CLASS PERMIT NO. 33 MAYNARD MASS.

POSTAGE WILL BE PAID BY ADDRESSEE

**DIGITAL EQUIPMENT CORPORATION  
CORPORATE USER PUBLICATIONS  
PKO3-1/D30  
129 PARKER STREET  
MAYNARD, MA 01754-9975**



Do Not Tear - Fold Here and Tape

**digital**

Order Number:AA-PF41B-TK  
Printed in the U.S.A.