# CUSTOMER SERVICE BULLETIN

**Radio Shack®**
## CUSTOMER SERVICE BULLETIN

400 Atrium—One Tandy Center, Fort Worth, Texas 76102

## Problem

In some unattended modes of operation, it is desirable to have HOST start up without prompting the operator to enable or disable the remote <BREAK> key. Listed below are some optional patches to TRSDOS 4.1 which, when applied, will allow the HOST function to start up without displaying the "Disable remote <BREAK> key (Y/N)" or requiring the operator's reply.

* *   THESE PATCHES ARE <u>OPTIONAL</u>   * *

## Solution

When the first patch is applied, the remote <BREAK> is automatically enabled at start up.  If the second patch is applied instead of the first, HOST starts with the remote <BREAK> key disabled.

To enable the remote <BREAK> key:

PATCH SYSTEM/SYS R=11Ø B=213 F=2158F5ØE C=Ø6ØØ1818

To disable the remote <BREAK> key:

PATCH SYSTEM/SYS R=11Ø B=213 F=2158F5ØE C=Ø6Ø11818

The above patches are for the 64K HOST.