TEKTRONIX

l

ľ

 \bigcirc

E E

ľ

465 OSCILLOSCOPE

SERVICE

INSTRUCTION MANUAL

NOTICE

VERTICAL OUTPUT AMPLIFIER board modifications have been made on all 465's with BO4- serial numbers and up. Information concerning this change can be found at the rear of this manual under Change Information. Sections of this manual affected by this modification include the CIRCUIT DESCRIPTION, CALIBRATION PROCEDURES, DIAGRAMS, ELECTRICAL AND MECHANICAL PARTS LISTS.

M20,159/573

TEKTRONIX®

465 OSCILLOSCOPE

SERVICE

INSTRUCTION MANUAL

Tektronix, Inc. P.O. Box 500 Beaverton, Oregon 97005

Serial Number

070-1330-00

TABLE OF CONTENTS

SECTION 1	465 SPECIFICATIONS	Page
	Introduction	1-1
	Vertical Deflection System	1-1
	Triggering	1-1
	Horizontal Deflection System	1-2
	X-Y Operation	1-3
	Calibrator	1-3
	Z Axis Input	1-3
	Signal Outputs	1-3
	Power Source	1-3
	Cathode-Ray Tube	1-3
	Supplemental Information	
	General	1-3
	Vertical Deflection System	1-3
	Triggering	1-4
	Horizontal Deflection System	1-4
	Calibrator	1-4
	External Z Axis Input	1-4
	Output Signals	1-4
	Cathode-Bay Tube	1.4
		1-4
SECTION 2	OPERATING INFORMATION	
	Introduction	2-1
	Instrument Repackaging	2-1
	Operating Voltage	2-1
	Controls And Connectors	
	General	2-2
	Cathode-Ray Tube (CRT) and Display	2-2
	Vertical Deflection System	2-2
	A and B Triggering	2-4
	A and B Sweep	2-5
	Calibrator and Power	2-6
	Rear Panel	2-6
	Obtaining Basic Displays	
	Introduction	2-6
	Normal Sweep Display	2-6
	Magnified Sween Display	2.7
	Delaved Sween Display	2.7
	Mixed Sween Display	2.7
	X-V Display	2-7 2.7
	χ·ι Display	2-1
SECTION 3	CIRCUIT DESCRIPTION	
	Introduction	3-1
	Digital Logic	3-1
	Block Diagram	
	General	3-1
	Channel 1 Preamp	
	General	3-3
	Input Coupling	3-3
	Input Attenuator	3-4
	Scale-Factor Switching Circuit	3-4
	Source Follower Stage	3-4
	First Cascode Amplifier Stage	3-4
	Second Cascode Amplifier Stage	3-4
	Third Cascode Amplifier Stage	3-5
	Channel 2 Preamp	
	General	3-5
	Second Cascode Amplifier	3-5
	Third Cascode Amplifier	3-6

i

I

I

I

TABLE OF CONTENTS (cont)

SECTION 3

CIRCUIT DESCRIPTION (cont)	Page
Vertical Switching Circuit	-
General	3-6
Diode Gates	3-6
Switching Multivibrator	3-7
Delay-Line Driver	3-8
Reference Feedback Amplifier	3-8
Normal Trigger Pickoff Amplifier	3-8
Vertical Output Amplifier	
General Delas Line	3-8
Delay Line	3-9
Output Amplifier	3-9
A and B I rigger Generators	20
General Trigger Source	3-9
Trigger Coupling	3-9
Input Source Follower	3-9
Paranhasa Amnlifier	3-9
Tunnel Diode Driver	3-5
A And B Sweep Generators	5-10
General	3-10
Disconnect Amplifier	3-10
Sawtooth Sweep Generator	3-11
Output Buffer Amplifier	3-11
Sweep Start Amplifier	3-11
Logic Multivibrator	3-11
B Sweep Generator Differences	3-11
Sweep And Z Axis Logic Circuit	
General	3-11
A Sweep Gate	3-11
B Sweep Gate	3-12
Sweep Control Integrated Circuit	3-12
A Sweep Holdoff Amplifier	3-13
B Sweep Holdoff Amplifier	3-13
A Sweep Z-Axis Gate	3-13
B Sweep Z-Axis Gate	3-13
+A GATE AND +B GATE Emitter Followers	3-13
B Sweep Laten Horizontal Amplifier	3-14
General	2 14
X-Axis Amplifier	3-14 3-14
Input Paraphase Amplifier	3-14
Gain Setting Amplifier	3-15
Output Amplifier	3-15
CRT Circuit	
General	3-15
High-Voltage Oscillator	3-16
High-Voltage Regulator	3-16
High-Voltage Rectifiers and Output	3-17
CRT Control Circuits	3-17
Z-Axis Amplifier	3-17
DC Restorer Circuit	3-17
Calibrator	
General	3-18
IVIUITIVID rator	3-18
Output Amplifier	3-18
A ingger view Amplifier General	• ••
Amplifier	3-18
	3-18

۸ī

TABLE OF CONTENTS (cont)

SECTION 3	CIRCUIT DESCRIPTION (cont) Low-Voltage Power Supply	Page
	General	3-19
	Power Input	3-20
	Secondary Circuit	3-20
	Fan Motor Circuit	
	General	3-20
SECTION A		
SECTION 4	Cabinet Removal	A 1
	Cabillet Relitorance	4-1
	Gonoral	4.1
	Cleaning	4-1
	Lubrication	4-1
	Transistors Checks	4-2
	Pagalibration	4-2
	Corrective Meintenance	4-2
	General	1.2
	Obtaining Banlacement Parts	4-2
	Soldering Techniques	4-2
	Component Benjacement	4.3
	Becalibration After Benair	4-5
	Instrument Benackating	4-5
		40
SECTION 5	CALIBRATION	
	Calibration Interval	5-1
	I EKTRUNIX Field Service	5-1
	Using This Procedure	5-1
	l est Equipment Required	5-1
	Vertical System Charle	FC
	Vertical System Check	D-0 5 1 1
	Horizontal System Check	5-11
	Short Form Calibration	5-13
	Power Supplies And Display	5.16
	Vertical System	5-10
	Tringer System	5-17
	Horizontal System	5.21
	Detailed Calibration	5-21
	Power Supply	5-27
	Disolav & Z-Axis	5-28
	Vertical System	5-30
	Trigger System	5-43
	Horizontal System	5-53
	Calibrator, Gates, & Ext Z-Axis	5-60
SECTION 6	ELECTRICAL PARTS LIST	
SECTION 7	DIAGRAMS & CIRCUIT BOARD ILLUSTRATIONS	
SECTION 8	MECHANICAL PARTS LIST & ILLUSTRATIONS	
CHANGE INF	ORMATION	

P



Fig. 1-1. 465 Oscilloscope.

and the second second

465 SPECIFICATIONS

Introduction

The 465 Oscilloscope is a wide-band, portable oscilloscope designed to operate in a wide range of environmental conditions. The instrument is light in weight and compact of design for ease of transportaion, yet capable of performance necessary for accurate high-frequency measurements. The dual-channel, DC-to-100 megahertz vertical deflection system provides calibrated deflection factors from 5 millivolts to 5 volts/division. The bandwidth limiting switch reduces interference from signals above about 20 megahertz for viewing low-frequency, low-level signals.

The trigger circuits provide stable sweep triggering to beyond the bandwidth of the vertical deflection system. Separate controls are provided to select the desired mode of triggering for the A and B sweeps. The A sweep can be operated in one of three modes: automatic triggering, normal triggering, or single sweep. A variable trigger holdoff control provides the ability for A sweep to trigger stably on aperiodic signals or complex digital words. The horizontal deflection system has calibrated sweep rates from 0.5 second to 0.05 microsecond/division. A X10 magnifier increases each sweep rate by a factor of 10 to provide a maximum sweep rate of 5 nanoseconds/division in the 0.05 μ s position. The delayed and mixed sweep features allow the start of the B sweep to be delayed a selected amount from the start of A sweep to provide accurate relative-time measurements. Calibrated X-Y measurements can be made with Channel 2 providing the vertical deflection and Channel 1 providing the horizontal deflection (TIME/DIV switch fully counterclockwise and VERT MODE switch to CH 2). The regulated DC power supplies ensure that instrument performance is not affected by variations in line voltage and frequency. Maximum power consumption of the instrument is approximately 75 watts.

The following instrument specifications apply over an ambient temperature range of -15° C to $+55^{\circ}$ C unless otherwise specified. Warm-up time for specified accuracies is 20 minutes. The calibration procedure given in section 5, if performed completely, will allow an instrument to meet the electrical characteristics listed below.

VERTICAL DEFLECTION SYSTEM

Deflection Factor

Calibrated range is from 5 millivolts to 5 volts per division in 10 steps in a 1-2-5 sequence. Accuracy is within 3%. Uncalibrated VAR control provides deflection factors continuously variable between the calibrated settings, and extends deflection factor to at least 12.5 volts per division in the 5 volts/div position.

Frequency Response

Bandwidth in both Channel 1 and Channel 2 is DC to at least 100 megahertz. Risetime is 3.5 nanoseconds or less. The AC-coupled lower -3 dB point is 10 hertz or less (1 hertz or less when using a 10X probe). Vertical system bandwidth with the BW LIMIT pushbutton pulled is approximately 20 megahertz.

Chopped Mode Repetition Rate

Approximately 250 kilohertz.

Input Resistance And Capacitance

One megohm within 2% paralleled by approximately 20 picofarads.

Maximum Input Voltage

- DC coupled: 250 V (DC + Peak AC) or 500 V P-P AC at 1 kHz or less.
- AC coupled: 500 V (DC + Peak AC) or 500 V P-P AC at 1 kHz or less.

Cascaded Operation (CH 1 VERT SIGNAL OUT Connected to CH 2 OR Y)

Bandwidth is DC to at least 50 MHz with a sensitivity of at least 1 mV/division.

TRIGGERING

Sensitivity

- DC Coupled: 0.3 division internal or 50 millivolts external from DC to 25 megahertz, increasing to 1.5 divisions internal or 150 millivolts external at 100 megahertz.
- AC Coupled: 0.3 division internal or 50 millivolts external from 60 hertz to 25 megahertz, increasing to 1.5 divisions internal or 150 millivolts external at 100 megahertz. Attenuates all signals below about 60 hertz.

Specifications-465

- LF REJ Coupled: 0.3 division internal or 100 millivolts external from 50 kilohertz to 25 megahertz, increasing to 1.5 divisions internal or 300 millivolts external at 100 megahertz. Blocks DC and attenuates all signals below about 50 kilohertz.
- HF REJ Coupled: 0.3 division internal or 50 millivolts external from 60 hertz to 50 kilohertz. Blocks DC and attenuates all signals below about 60 hertz and above about 50 kilohertz.

Trigger Jitter

0.5 nanosecond or less at 5 nanoseconds/division with 100 megahertz applied (X10 MAG on).

External Trigger Input

Maximum input voltage is $250 \vee DC$ + peak AC or $250 \vee P$ -P AC (1 kilohertz or less). Input resistance is 1 megohm within 10%.

LEVEL Control Range

EXT: At least + and -2 volts, 4 volts peak to peak.

EXT \div 10: At least + and - 20 volts, 40 volts peak to peak.

HORIZONTAL DEFLECTION SYSTEM

Calibrated Sweep Range

- A Sweep: from 0.5 second/division to 0.05 microsecond/division in 22 steps in a 1-2-5 sequence. X10 MAG extends maximum sweep rate to 5 nanoseconds/division.
- B Sweep: from 50 milliseconds/division to 0.05 microsecond/division in 19 steps in a 1-2-5 sequence. X10 MAG extends maximum sweep rate to 5 nanoseconds/division.

Calibrated Sweep Accuracy

Unmagnified sweep accuracy is $\pm 2\%$ from $+20^{\circ}$ C to $+30^{\circ}$ C ($+68^{\circ}$ F to $+86^{\circ}$ F) and $\pm 3\%$ from -15° C to $+20^{\circ}$ C and $+30^{\circ}$ C to $+55^{\circ}$ C ($+5^{\circ}$ F to $+68^{\circ}$ F and $+86^{\circ}$ F to $+131^{\circ}$ F). For the same temperature ranges, magnified sweep accuracy is $\pm 3\%$ and $\pm 4\%$ respectively. Exclude the first and last 50 ns of the 5 ns, 10 ns, and 20 ns magnified sweep rates. Accuracy specifications apply over full ten divisions unless otherwise specified.

Sweep accuracy, over any two or less division portion of the sweep, is $\pm 5\%$. Exclude the first and last magnified divisions of the 5 ns and 10 ns/div magnified sweep rates. Also exclude the first and last 50 ns of the 5, 10, and 20 ns/div magnified sweep rates.

Mixed sweep accuracy is 2% plus the measured A sweep error when viewing the A sweep portion only. The B sweep portion retains its normal accuracy.

A Time/Division Variable Range

Provides continuously variable (uncalibrated) sweep rates between the calibrated settings of the A TIME/DIV switch. Extends the slowest A sweep rate to at least 1.25 seconds/division.

A Trigger Holdoff

Increases A sweep holdoff time by at least a factor of 10.

Delay Time And Differential Time Measurement Accuracy

	+15°C to +35°C (+60°F to +95°F)	-15° C to +55 $^{\circ}$ C (+5 $^{\circ}$ F to +131 $^{\circ}$ F)
Over One Or More Major Dial Division	±1%	±2.5%
Over Less Than One Major Dial Division	±0.01 Major Dial Division	±0.03 Major Dial Division

Delay Time Jitter

Within 0.002% (less than one part in 50,000) of the maximum available delay time when operating on power line frequencies other than 50 Hz.

Within 0.005% (less than one part in 20,000) of the maximum available delay time when operating on 50 Hz power line frequency.

Maximum available delay time is ten times the setting of the A TIME/DIV switch.

Calibrated Delay Time (A VAR set to calibrated position)

Continuous from 5 seconds to 0.2 microsecond.

X-Y OPERATION

Sensitivity

Same as vertical deflection system.

X Axis deflection accuracy within 4%.

Variable Range

Same as vertical deflection system.

X-Axis Bandwidth

DC to at least 4 megahertz.

Y-Axis Bandwidth

Same as vertical deflection system.

Input Resistance

Same as vertical deflection system.

Input Capacitance

Same as vertical deflection system.

Maximum Usable Input Voltage

Same as vertical deflection system.

CALIBRATOR

Output

An approximate 1 kilohertz frequency 30 milliampere (±2%), 300 millivolt (±1%) square-wave signal.

Z AXIS INPUT

Sensitivity

A 5-volt peak to peak signal causes noticeable modulation at normal intensity.

Usable Frequency Range

From DC to 50 megahertz.

SIGNAL OUTPUTS

CH 1 VERT SIGNAL OUT

Output voltage is at least 50 millivolts/division into a 1 megohm load (at least 25 millivolts/division into a 50 ohm load).

Bandwidth is from DC to at least 50 megahertz into a 50 ohm load.

Output DC level is approximately zero volts.

A and B +GATE Outputs

Output voltage is approximately 5.5 volts, positivegoing.

POWER SOURCE

Line Voltages

110, 115, 120, 220, 230, or 240 VAC (all \pm 10%), depending on the settings of the Line Voltage Selector switch and the Regulating Range Selector assembly, with a line frequency of 48 to 440 hertz. Maximum power consumption is 75 watts at 115 VAC, 60 hertz.

CATHODE-RAY TUBE

Graticule Area

Eight by ten centimeters.

Phosphor

 $\mathsf{P31}$ is the standard phosphor with $\mathsf{P11}$ offered as an option.

SUPPLEMENTAL INFORMATION

General

The supplemental information listed here represents limits that, when met, ensure optimum instrument operation. They are, however, not instrument specifications but are intended to be used only as maintenance or operational aids.

VERTICAL DEFLECTION SYSTEM

Low-Frequency Linearity

There should be no more than 0.1 division of compression or expansion of a two-division signal at center screen when the signal is positioned to the upper and lower extremes of the CRT graticule area.

Bandwidth Limiter Bandwidth

The $-3 \, dB$ point should be between 15 and 25 megahertz.

Specifications-465

Step Response Aberrations

There should be less than +3%, -3%, or a total of 3% peak to peak aberration on a positive-going step. Add 2% when checking a negative-going step. Position-effect should not cause total aberrations to be more than +5%, -5%, or a total of 5% peak to peak.

Common-Mode Rejection Ratio

At least 10:1 at 20 megahertz for common mode signals of 6 divisions or less with vertical gain adjusted for best CMRR at 50 kilohertz.

Step Attenuator Balance

Adjustable to 0.2 division or less of trace shift when switching between adjacent deflection factors.

Trace Shift As Variable Is Rotated

Adjustable to one division or less.

INVERT Trace Shift

Two divisions or less when switching from normal to inverted.

Input Gate Current

0.5 nanoampere or less (0.1 division of deflection at 5 mV/div) from $+20^{\circ}$ C to $+30^{\circ}$ C. Four nanoamperes or less (0.8 division of deflection at 5 mV/div) from -15° C to $+55^{\circ}$ C.

Channel Isolation

At least 100:1 at 25 megahertz.

Position Control Range

Twelve divisions up and twelve divisions down from graticule center.

TRIGGERING

External Trigger Input Capacitance

Twenty picofarads within 30%.

HORIZONTAL DEFLECTION SYSTEM

A Sweep Length

10.5 to 11.5 divisions.

Magnifier Registration

There should be 0.2 division or less difference at graticule center when switching from MAG on to MAG off.

Position Control Range

Should be able to position the start of the sweep to the right of graticule center, and the end of the sweep to the left of graticule center.

Phase Difference Between X And Y Axes Amplifiers

Typically 3° or less from DC to 50 kilohertz.

CALIBRATOR

Repetition Rate

Repetition rate accuracy is typically within 25%.

Output Resistance

Approximately 9.4 ohms.

EXTERNAL Z AXIS INPUT

Maximum Input Voltage

Voltages applied to the EXT Z AXIS INPUT connector should be limited to less than 100 volts DC plus peak AC or 100 volts peak to peak AC at 1 kilohertz or less.

OUTPUT SIGNALS

Output Resistance

Output resistance of the CH 1 VERT SIG OUT connector is \approx 50 Ω .

Output resistance of +A and +B GATE outputs is $\approx\!500~\Omega.$

CATHODE-RAY TUBE

Resolution

Typically at least 15 lines per division horizontally and vertically.

Geometry

0.1 division or less of tilt or bowing.

Raster Distortion

0.1 division or less.

Nominal Accelerating Potential

Approximately 18,500 volts.

OPERATING INFORMATION

Introduction

This section of the manual is intended to allow the operator to become familiar with the instrument power requirements, functions of controls and connectors, and how to obtain a few basic displays. For more complete operating information, refer to the 465 Operators Handbook.

Instrument Repackaging

If this instrument is to be shipped for long distances by commercial means of transportation, it is recommended that it be repackaged in the original manner for maximum protection. The original shipping carton can be saved and used for this purpose. Fig. 5 in the Mechanical Parts List illustrates how to repackage the 465 and gives the part number for the packaging components. New shipping cartons can be obtained from Tektronix, Inc. Contact your local TEKTRONIX Field Office or representative.

Operating Voltage



This instrument is designed for operation from a power source with its neutral at or near earth (ground) potential with a separate safety-earth conductor. It is not intended for operation from two phases of a multi-phase system, or across the legs of a single-phase three-wire system.

This instrument can be operated from either a 115-volt or 230-volt nominal line voltage source, 48 to 440 hertz. The Line Voltage Selector switch in the instrument converts the instrument from one nominal operating voltage to the other. The Regulating Range Selector assembly on the instrument rear panel selects one of three regulating ranges for each nominal line voltage; it also contains the line fuse for overload protection. To select the correct nominal line voltage and regulating range, proceed as follows:

1. Disconnect the instrument from the power source.

2. To convert from 115-volts nominal to 230-volts nominal line voltage, set the selector switch to the 230 volts position (toward the rear of the instrument). Change the line-cord plug to match the power source or use a 115-to-230 volt adapter.

NOTE

Color-coding of the cord conductors is as follows (in accordance with National Electrical Code):

Line	Black
Neutral	White
Safety earth (ground)	Green (or green with
	vellow tracer)

3. To change regulating ranges, loosen the two captive screws which hold the cover onto the Regulating Range Selector assembly, then pull to remove the cover.

4. Pull out the range selector switch bar (see Fig. 2-1). Slide the bar to the desired position and plug it back in. Select a range which is centered about the average line voltage to which the instrument is to be connected (see Table 2-1).

TABLE 2-1

Regulating Ranges

Bango Salactor	Regulating Range		
Switch Position	115-Volts Nominal	230-Volts Nominal	
Lo (switch bar in bottom holes)	99 to 121 volts	198 to 242 volts	
M (switch bar in middle holes)	104 to 126 volts	208 to 252 volts	
HI (switch bar in top holes)	108 to 132 volts	216 to 264 volts	



Fig. 2-1. Power supply regulating range selector.

Operating Information-465

5. Re-install the cover and tighten the two captive screws.

6. Before applying power to the instrument, check that the line voltage selector switch and the indicating tab on the Regulating Range Selector assembly are in the correct position for the desired nominal line voltage and regulating range.

CAUTION

This instrument may be damaged if operated with the line voltage selector switch or the Regulating Range Selector assembly set to incorrect positions for the line voltage applied.

The 465 is designed to be used with a three-wire AC power system. If a three-to two-wire adapter is used to connect this instrument to a two-wire AC power system, be sure to connect the ground lead of the adapter to earth (ground). Failure to complete the ground system may allow the chassis of this instrument to be elevated above ground potential and pose a shock hazard.

The feet on the rear panel provide a convenient cord wrap to store the power cord when not in use.

CONTROLS AND CONNECTORS

General

The major controls and connectors for operation of the 465 are located on the front panel of the instrument. A few auxiliary functions are provided on the rear panel. Fig. 2-2 shows the front and rear panels of the 465. A brief description of each control and connector is given here. More detailed operating information is given in the 465 Oscilloscope Operators Handbook.

Cathode-Ray Tube (CRT) and Display

BEAM FIND	Compresses the display to within the graticule area, independently of display position or applied signals.
INTENSITY	Controls brightness of the display.
FOCUS	Provides adjustment for optimum display definition.
SCALE ILLUM	Controls graticule brightness.

ASTIG	Screwdriver adjustment used in conjunction with the FOCUS control to obtain a well-defined display. Does not require readjust- ment in normal use.
TRACE ROTATION	Screwdriver adjustment to align the trace with the horizontal graticule lines.

Vertical Deflection System (Channel 1 & Channel 2)

POSITION	Controls the vertical position of the trace. In the X-Y mode of opera- tion, the CH 2 control positions on the Y-axis (vertically) and the Hori- zontal POSITION control positions on the X-axis (horizontally).
CH 1 OR X	Input connector for Channel 1 de- flection signals or X-axis deflection in the X-Y mode of operation.
CH 2 OR Y	Input connector for Channel 2 de- flection signals or Y-axis deflection in the X-Y mode of operation.
GAIN (Side Panel)	Screwdriver adjustment to set the gain of the Vertical Preamp.
VOLTS/DIV	Selects vertical deflection factor in a 1-2-5 sequence (VAR control must be in the calibrated detent for the indicated deflection factor).
VAR	Provides continuously variable un- calibrated deflection factors between the calibrated settings of the VOLTS/DIV switch.
UNCAL	Light indicates that the VAR con- trol is not in the calibrated position.
Input Coupling (AC-GND-DC)	Selects the method of coupling signal to the input of the Vertical Amplifier.
	 AC: Signal is capacitively coupled to the Vertical Amplifier. DC component of signal is blocked. Low-frequency limit (lower -3 dB point) is about 10 hertz.
	GND: Input signal is removed and the input circuit is grounded. Does not ground the input signal.



A. Front panel.



B. Rear panel.

Fig. 2-2. Front- and rear-panel controls and connectors.

Operating Information-465

DC: All components of the input signal are passed to the Vertical Amplifier.

SOURCE

SLOPE

LEVEL

20 MHz BW/TRIG Dual-purpose switch that, when VIEW pulled out, limits the bandwidth of the complete Vertical Deflection System to approximately 20 MHz, or when pressed causes signal present in A Trigger Generator circuit to be displayed on the CRT.

INVERT Pushbutton switch that inverts the Channel 2 display.

VERT MODE Selects the vertical mode of operation.

CH 1: Displays Channel 1 only.

- ALT: Dual-trace display of signals on both channels. Display is switched between channels at the end of each sweep.
- ADD: Signals applied to the CH 1 OR X and CH 2 OR Y connectors are algebraically added and the sum is displayed on the CRT. The INVERT switch in Channel 2 allows the display to be CH 1 + CH 2 or CH 1 - CH 2.
- CHOP: Dual-trace display of signals on both channels. Display is switched between channels at an approximate repetition rate of 250 kHz.
- CH 2 OR X-Y: Displays Channel 2 only. Must be pushed when operating in X-Y mode.

A and B Triggering (both where applicable)

COUPLING

Determines the method used to couple signal to input of trigger circuits.

- AC: Rejects DC and attenuates signals below about 60 Hz. Accepts signals above about 60 Hz.
- LF REJ: Rejects DC and attenuates signals below about 50 kHz. Accepts signals above about 50 kHz.

- HF REJ: Accepts signals between 60 Hz and 50 kHz. Rejects DC and attenuates all signals outside the above range.
- DC: Accepts all trigger signals from DC to 100 MHz or greater.

Selects source of trigger signal.

- NORM: Internal trigger signal obtained from Vertical Deflection System. Actual source is signal(s) displayed on CRT.
- CH 1: A sample of the signal connected to the CH 1 OR X input connector is used as a trigger signal.
- CH 2: A sample of the signal connected to the CH 2 OR Y input connector is used as a trigger signal.
- EXT: Trigger signal is obtained from signal connected to the External Trigger Input connector.
- EXT ÷10 (A trigger circuit only): External trigger signal is attenuated by a factor of 10.
- STARTS AFTER DELAY (B trigger circuit only): B sweep starts immediately after the delay time selected by the DELAY-TIME POSITION dial and the DELAY-TIME switch.
- LINE (A trigger circuit only): Trigger signal is obtained from a sample of the line voltage applied to the instrument.
- Selects the slope of the trigger signal which starts the sweep.
- +: Sweep can be triggered from the positive-going portion of the trigger signal.
- -: Sweep can be triggered from the negative-going portion of the trigger signal.
- Selects the amplitude point on the trigger signal at which the sweep is triggered.

A TRIG MODE

Determines the operating mode for the A Trigger Circuit.

- AUTO: With the proper trigger control settings, A Sweep can be initiated by signals that have repetition rates above about 20 hertz and are within the frequency range selected by the COUPLING switch. In the absence of an adequate trigger signal or when the trigger controls are misadjusted, the sweep free-runs to produce a reference trace.
- NORM: With the proper trigger control settings, A Sweep can be initiated by signals that are within the frequency range selected by the COUPLING switch. In the absence of an adequate trigger signal or when the trigger controls are misadjusted, there is no trace.
- SING SWP: After a sweep is displayed, further sweeps cannot be presented until the SING SWP pushbutton is pressed again. The display is triggered the same as for NORM operation using the A Triggering controls.

A TRIG HOLDOFF

Provides control of holdoff time between sweeps to obtain stable displays when triggering on aperiodic signals (such as complex digital words). Variable can increase holdoff time up to at least 10 times the holdoff time of the NORM position. In the B ENDS A position (fully clockwise), the A sweep is reset at the end of the B sweep to provide the fastest possible sweep repetition rate for delayed sweep presentations.

External Trigger Input (not labeled) Input connectors for external trigger signals.

A and B Sweep

DELAY-TIME POSITION Provides variable sweep delay between 0.20 and 10.20 times the delay time indicated by the DELAY TIME switch. A AND B TIME/ DIV AND DELAY TIME

VAR

READY

A TIME/DIV switch (clear plastic outer flange) selects the sweep rate of the A sweep circuit and selects the basic delay time (to be multiplied by DELAY-TIME POSITION dial setting) for delayed-sweep operation. B TIME/DIV switch (inner dark knob) selects sweep rate of the B sweep circuit for delayed sweep operation only. VAR control must be in calibrated detent for calibrated A sweep rates.

Provides continuously variable A sweep rates between the calibrated settings of the A TIME/DIV switch. The A sweep rate is calibrated when the VAR control is fully clockwise into the calibrated detent.

- UNCAL Light that indicates when the VAR TIME/DIV control is out of the calibrated detent and the horizontal sweep rate is uncalibrated.
- X10 MAG Indicator Light that indicates when the X10 MAG is turned on.

Light that indicates that A Sweep has been prepared to present a single sweep upon receipt of an adequate trigger signal.

- HORIZ DISPLAY Selects the horizontal mode of operation.
 - A: Horizontal deflection provided by A Sweep. B Sweep inoperative.
 - MIX: The first part of the horizontal sweep is displayed at a rate set by the A TIME/DIV switch and the latter part of the sweep at a rate set by the B TIME/DIV switch. Relative amounts of the display allocated to each of the two rates are determined by the setting of the DELAY-TIME POSITION dial.
 - A INT: Displayed sweep rate determined by the A TIME/DIV switch. An intensified portion appears on the display during the B sweep time. This switch position provides a check of the duration and position of the B sweep (delayed sweep) with respect to the delaying sweep (A).

	B DLYD: Sweep rate determined by the B TIME/DIV switch with the delay time determined by the setting of the DELAY TIME
	(A TIME/DIV) switch and the DELAY-TIME POSITION dial.
Horizontal POSITION	Positions the display horizontally.

X10 MAG Increases the displayed sweep rate by a factor of 10.

Calibrator and Power

- CALIBRATOR A combination current loop and square-wave voltage output device. Provides a 30 mA square-wave current, 300 mV square-wave voltage signal with a repetition rate of approximately 1 kHz.
- POWER Turns instrument power on and off.
- LOW LINE Light that indicates the applied line voltage is below the lower limit of the regulating range selected by the Regulating Range Selector assembly.

Rear Panel

- A +GATE Output connector providing a positive-going rectangular pulse coincident with the A sweep time.
- B +GATE Output connector providing a positive-going rectangular pulse coincident with the B sweep time.
- CH 1 VERT Output connector providing a SIGNAL OUT sample of the signal applied to the CH 1 input connector.
- EXT Z AXIS Input connector for intensity mod-INPUT ulation of the CRT display.
- Regulating Range Selects the regulating range of the Selector internal power supplies (low, medium, high; determined by specific line voltage applied to instrument).

OBTAINING BASIC DISPLAYS

Introduction

The following instructions will allow the operator who is unfamiliar with the operation of the 465 to obtain the basic displays commonly used. Before proceeding with these instructions, preset the instrument controls as follows:

Vertical Controls

VERT MODE Switch	CH 1
VOLTS/DIV Switches	Proper position determined
	by amplitude of signal to
	be applied.
VOLTS/DIV VAR Controls	Calibrated detent
Input Coupling Switches	AC
Vertical POSITION Controls	Midrange
20 MHz BW Switch	Not limited
INVERT Switch	Button out
INTENSITY Control	Fully counterclockwise
FOCUS Control	Midrange
SCALE ILLUM Control	Midrange

Trigger Controls (both A and B if applicable)

SLOPE Switch	+
LEVEL Control	0
SOURCE Switch	NORM
COUPLING Switch	AC
TRIG MODE Switch	AUTO
A TRIG HOLDOFF Control	NORM

Horizontal Sweep Controls

TIME/DIV Switches	Locked together at 1 ms
A TIME/DIV VAR	Calibrated detent
HORIZ DISPLAY Switch	A
X10 MAG Switch	Off (button out)
POSITION Control	Midrange

Normal Sweep Display

1. Set the POWER switch to on (button out). Allow several minutes for instrument warmup.

2. Connect the external signal to the CH 1 input connector.

3. Advance the INTENSITY control until the display is visible. If the display is not visible with the INTENSITY control at midrange, press the BEAM FIND pushbutton and adjust the CH 1 VOLTS/DIV switch until the display is reduced in size vertically. Then, center the compressed display with the vertical and horizontal POSITION controls, and release the BEAM FIND pushbutton. Adjust the FOCUS control for a well-defined display.

4. Set the CH 1 VOLTS/DIV switch and CH 1 POSI-TION control for a display which remains in the display area vertically. 5. Adjust the A Trigger LEVEL control for a stable display.

6. Set the A TIME/DIV switch and the horizontal POSITION control for a display which remains in the display area horizontally.

Magnified Sweep Display

1. Preset the instrument controls and follow steps 1 through 6 for obtaining a Normal Sweep Display.

2. Adjust the horizontal POSITION control to move the area to be magnified to within the center graticule division of the CRT. If necessary, change the TIME/DIV switch setting so the complete area to be magnified is within the center division.

3. Set the X10 MAG switch to the on position (button in) and adjust the horizontal POSITION control for precise positioning of the magnified display.

Delayed Sweep Displays

1. Preset the instrument controls and follow steps 1 through 6 for obtaining a Normal Sweep Display.

2. Set the HORIZ DISPLAY switch to A INT and the B Trigger SOURCE switch to STARTS AFTER DELAY.

3. Pull out the B TIME/DIV switch knob and turn clockwise so the intensified zone on the display is the desired length. Adjust the INTENSITY control to achieve the desired display brightness.

4. Adjust the DELAY-TIME POSITION dial to position the intensified zone to the portion of the display to be delayed.

5. Set the HORIZ DISPLAY switch to B DLYD. The intensified zone on the display noted in step 3 is now being displayed in delay form. The delayed sweep rate is indicated by the dot on the B TIME/DIV switch knob.

6. For a delayed sweep display that will exhibit less jitter, set the B Trigger SOURCE switch to the same position as the A Trigger SOURCE switch and adjust the B Trigger LEVEL control for a stable display. If the A Trigger SOURCE switch is in the LINE position, a sample of the line voltage will have to be supplied to the B Trigger circuit externally.

Mixed Sweep Display

1. Preset the instrument controls and follow steps 1 through 6 for obtaining a Normal Sweep Display.

2. Pull out on the B TIME/DIV switch knob and turn clockwise to the desired sweep rate. Adjust the INTEN-SITY control to achieve the desired display brightness.

3. Set the HORIZ DISPLAY switch to MIX. The CRT display now contains more than one time factor on the horizontal axis. The first portion of the display is at the A Time Base sweep rate and the latter part is at the B Time Base sweep rate. The start of the B Time Base portion of the display can be changed by adjusting the DELAY-TIME POSITION control.

X-Y Display

1. Preset the instrument controls and turn the instrument power on. Allow several minutes for instrument warm-up.

2. Set the TIME/DIV switch to X-Y and the VERT MODE to CH 2. Apply the vertical signal to the CH 2 or Y input connector and the horizontal signal to the CH 1 or X input connector. The CH 2 POSITION control will provide vertical positioning and the Horizontal POSITION control will provide horizontal positioning.

3. Advance the INTENSITY control until the display is visible. If the display is not visible with the INTENSITY control at midrange, press the BEAM FIND pushbutton and adjust the CH 1 and CH 2 VOLTS/DIV switches until the display is reduced in size both vertically and horizontally. Then, center the compressed display with the vertical POSITION controls, and release the BEAM FIND pushbutton. Adjust the FOCUS control for a well-defined display.

CIRCUIT DESCRIPTION

Introduction

This section of the manual contains a description of the circuitry used in the 465 Oscilloscope. The description begins with a discussion of the instrument, using the basic block diagram shown in Fig. 3-1. Then, each circuit is described in detail using detailed block diagrams to show the interconnections between the stages in each major circuit and the relationship of the front panel controls to the individual stages.

A complete block diagram is located in the Diagrams Section at the back of this manual. This block diagram shows the overall relationship between all of the circuits. Complete schematics of each circuit are also given in the Diagrams Section. Refer to these diagrams throughout the following circuit description for electrical values and relationships.

Digital Logic

Digital logic techniques are used to perform many functions within this instrument. The function and operation of the logic circuits are described using logic symbology and terminology. All logic functions are described using the positive logic convention. Positive logic is a system of notation where the more positive of two levels (HI) is called the true or 1 state; the more negative level (LO) is called the false or 0 state. The HI-LO method of notation is used in this logic description. The specific voltages which constitute a HI or LO state vary between individual devices. Typical HI and LO logic levels are shown on the diagrams at the rear of this manual.

It should be noted that not all of the integrated circuit devices in this instrument are digital logic devices. The function of non-digital devices will be described individually using operating waveforms or other techniques to illustrate their function.

BLOCK DIAGRAM

General

The following discussion is provided to aid in understanding the overall concept of the 465 Oscilloscope before the individual circuits are discussed in detail. A basic block diagram of the 465 Oscilloscope is shown in Fig. 3-1. Only the basic interconnections between the individual blocks are shown on this diagram. Each block represents a major circuit within the instrument. The number on each block refers to the complete circuit diagram which is located at the rear of this manual.

Signals to be displayed on the CRT are applied to the CH 1 OR X and/or CH 2 OR Y connectors. The input signals are then amplified by the Preamp circuits. Each Preamp circuit includes separate vertical deflection factor, input coupling, balance, gain, and variable attenuation controls. A trigger pickoff stage in each Vertical Preamp circuit supplies a sample of the channel signals to the Trigger Generator circuit. A sample of the Channel 1 signal is also supplied to the CH1 VERT SIGNAL OUT BNC connector on the instrument rear panel. In the X-Y mode of operation the Channel 1 signal is connected to the input of the Horizontal Amplifier circuit to provide the X-Axis deflection. The Channel 2 Vertical Preamp circuit contains an invert feature to invert the Channel 2 signal as displayed on the CRT. The output of both Vertical Preamp circuits is connected to the Vertical Switching circuit. This circuit selects the channel(s) to be displayed. An output signal from this circuit is connected to the Z Axis Amplifier circuit to blank out the switching transients between channels when in the chopped mode of operation. A trigger pickoff stage at the output of the Vertical Switching circuit provides a sample of the displayed signal(s) to the Trigger Generator circuit.

The output of the Vertical Switching circuit is connected to the Vertical Output Amplifier through the Delay Line. The Vertical Output Amplifier circuit provides the final amplification for the signal before it is connected to the vertical deflection plates of the CRT. This circuit includes the BEAM FIND switch which compresses the vertical and horizontal deflection to within the viewing area to aid in locating an off-screen display.

The A and B Trigger Generator circuits produce an output pulse which initiates the sweep signal produced by the A or B Sweep Generator circuits. The input signal to the A and B Trigger Generator circuits can be individually selected from the Channel 1 signal, Channel 2 signal, the signal(s) displayed on the CRT, a signal connected to the external trigger input connectors, or a sample of the line

Circuit Description-465

voltage applied to the instrument. Each trigger circuit contains level, slope, coupling, and source controls.

The A Sweep Generator circuit, when initiated by the A Trigger Generator circuit, produces a linear sawtooth output signal, the slope of which is controlled by the A TIME/DIV switch. The TRIG MODE switch controls the operating mode of the A Sweep Generator circuit. In the AUTO position, the absence of an adequate trigger signal causes the sweep to free run. In the NORM position, a horizontal sweep is presented only when correctly triggered by an adequate trigger signal. Pushing the SING SWP pushbutton allows one (and only one) sweep to be initiated. The Z Axis Logic circuit produces an unblanking gate signal to unblank the CRT so that the display can be presented. This gate signal is coincident with the sawtooth produced by the A Sweep Generator circuit. A gate signal, which is also coincident with the sawtooth, is available at the A + GATE connector on the instrument rear panel. The Z Axis Logic circuit also produces an alternate sync pulse which is connected to the Vertical Switching circuit. This pulse switches the display between channels at the end of each sweep when the VERT MODE switch is in the ALT position.

The B Sweep Generator circuit is basically the same as the A Sweep Generator circuit. However, this circuit only produces a sawtooth output signal after a delay time determined by the A TIME/DIV switch and the DELAY TIME POSITION dial. If the B Triggering SOURCE switch is set to the STARTS AFTER DELAY position, the B Sweep Generator begins to produce the sweep immediately following the selected delay time. If this switch is in one of the remaining positions, the B Sweep Generator circuit does not produce a sweep until it receives a trigger pulse occurring after the selected delay time.

The output of either the A or B Sweep Generator is amplified by the Horizontal Amplifier circuit to produce horizontal deflection for the CRT except in the fully counterclockwise (X-Y) position of the TIME/DIV switch. This circuit contains a 10X magnifier to increase the sweep rate 10 times in any A or B TIME/DIV switch position. Other horizontal deflection signals can be connected to the horizontal amplifier by using the X-Y mode of operation. When the TIME/DIV switch is set to X-Y, the X signal is connected to the Horizontal Amplifier circuit through the Channel 1 Vertical Preamp circuit.



Fig. 3-1. Basic block diagram of the 465.

The Z Axis Amplifier circuit determines the CRT intensity and blanking. The Z Axis Amplifier circuit sums the current inputs from the INTENSITY control, Vertical Switching circuit (chopped blanking), Z Axis Logic circuit (unblanking), and the external Z AXIS INPUT connector. The output level of the Z Axis Amplifier circuit controls the trace intensity through the CRT Circuit. The CRT circuit provides the voltages and contains the controls necessary for operation of the cathode-ray tube.

The Power Supply circuit provides the low voltage power necessary for operation of this instrument. This voltage is distributed to all of the circuits in the instrument as shown by the Power Distribution Diagram. The Calibrator circuit produces a square-wave output with accurate voltage and current amplitudes which can be used to check the calibration of the instrument and the compensation of probes. The CALIBRATOR current loop provides an accurate current source for calibration of current measuring probe systems.

CHANNEL 1 PREAMP

General

Input signals for vertical deflection on the CRT can be connected to the CH 1 OR X input connector. In the X-Y mode of operation the input signal connected to the CH 1 OR X connector provides the horizontal (X axis) deflection (TIME/DIV switch set to X-Y, VERT MODE switch set to CH 2 OR X-Y). The Channel 1 Preamp circuit provides control of input coupling, vertical deflection factor, gain, and DC balance. Fig. 3-2 shows a detailed block diagram of the Channel 1 Preamp circuit. A schematic of this circuit is shown on Diagram 1 at the rear of the manual.

Input Coupling

Signals applied to the input connector can be AC coupled, DC coupled, or internally disconnected from the input to the Vertical Input Amplifier circuits. When the Input Coupling switch S5 is set for DC coupling, the input signal is coupled directly to the Input Attenuator stage. When AC coupled, the input signal passes through capacitor C3. This capacitor prevents the DC component of the signal



Fig. 3-2. Detailed block diagram of the Channel 1 Preamplifier.

from passing to the amplifier. In the GND position, S5 opens the signal path and connects the input of the amplifier to ground. This provides a ground reference without the need to disconnect the applied signal from the input connector. Resistor R4, connected across the input coupling switch, allows C3 to be pre-charged in the ground position so that the trace remains on screen when switched to the AC position.

Input Attenuator

The effective overall deflection factor of each channel of the 465 is determined by the appropriate VOLT/DIV switch. The basic deflection factor of the Vertical Deflection System is 5 mV/division of CRT deflection. To achieve the deflection factor values indicated on the front panel, precision attenuators are switched in to the circuit and the gain of the First Cascode Amplifier stage is changed.

For the VOLT/DIV switch positions above 5 mV, attenuators are switched in to the circuit, singly or in pairs, to help produce the vertical deflection factors indicated on the front panel. These attenuators are frequency-compensated voltage dividers. In addition to providing constant attenuation at all frequencies within the bandwidth of the instrument, the Input Attenuators are designed to maintain the same input RC characteristics (1 M Ω times approximately 20 pF) for each setting of the VOLT/DIV switch. Each attenuator contains an adjustable series capacitor to provide correct attenuation at high frequencies and an adjustable shunt capacitor to provide correct input capacitance.

NOTE

Each attenuator is a hybrid encapsulated plug-in assembly; therefore, replacement of individual components within the attenuator is not possible. Should defects occur, the attenuator must be replaced as a unit.

Scale-Factor Switching Circuit

The vertical deflection factor for each channel is indicated by back-lighting the appropriate figures imprinted on the flange of the VOLTS/DIV knob. When a X1 probe is connected to the CH 1 OR X input connector, the base level of transistor Q386 is determined by the voltage divider composed of R384, R383 and X10 display factor bulb DS382. Q386 is biased into saturation and conducts current through the X1 indicator DS386. When Q386 conducts, the voltage level at its collector is very close to +5 volts. Therefore, there is insufficient bias at the base of Q382 to cause Q382 to conduct, and the X10 indicator DS382 remains dark.

When a X10 probe with a scale factor switching connector is attached to the CH 1 OR X input connector, the base of Q382 is returned to ground through R381. Q382 is now biased into saturation and conducts current through X10 indicator DS382. The collector level of Q382 is very close to +5 volts; therefore, there is insufficient bias at the base of Q386 to cause it to conduct and X1 indicator DS386 remains dark.

Source Follower Stage

The Channel 1 signal from the Input Attenuator is connected to the Source Follower Stage through R16 and C16. R15 provides the input resistance for this stage. R16 limits the current drive to the gate of Q20A. Diode CR18 protects the circuit by clamping the gate of Q20A at about -8.7 volts if a high amplitude negative-going signal is applied to the CH 1 OR X input connector. Q20B is a relatively constant current source for Q20A.

First Cascode Amplifier Stage

The Paraphase Amplifier Stage composed of Q32 and Q36 converts the single-ended input signal into a push-pull output signal. C33, C34 and CR34 optimize high frequency response through the amplifier stage. R37 and R38 provide thermal balance for the amplifier. C37 and C38 minimize Miller effect through Q32 and Q36. Step Atten Bal adjustment R25 adjusts for no baseline shift of a CRT display when switching between adjacent positions of the VOLTS/DIV switch.

The Common Base Amplifier stage composed of Q42 & Q44 converts the input signal currents into output voltage signals across load resistors R44 and R45. Correct vertical deflection factors are obtained by using a combination of attenuation in the Input Attenuator Stage and changing the gain of the first Cascode Amplifier Stage. For example, when switching from 50 mV/division to 100 mV/division, the input attenuator remains the same but R46 is switched in parallel with R44 and R45. This divides the output load resistance of the Common Base Amplifier Stage by two, thereby reducing the gain of the stage by two. C46, C47, C48, C49, R47 and R48 provide optimum high frequency response through the channel amplifier when operating with reduced gain.

Second Cascode Amplifier

Transistors Q102-Q122 and Q104-Q124 constitute the Second Cascode Amplifier stage of the Channel 1 vertical preamplifier. Gain adjust R118 sets the overall gain of the Channel 1 vertical preamplifier by adjusting the signal current into the emitters of Q122 and Q124. The VAR control R112, when rotated out of the calibrated detent

position, also adjusts the signal currents into Q122 and Q124 to provide uncalibrated deflection factors between the calibrated settings of the VOLTS/DIV switch. Variable balance adjustment R120 adjusts for no baseline shift of a CRT display when rotating the VAR control. Position Centering adjustment R115 centers the range of control of the Channel 1 POSITION control.

Third Cascode Amplifier

Q132 and Q134, in conjunction with Q304 and Q308 in the Vertical Switching Circuit, form the Third Cascode Amplifier stage. Thermistor RT131 (between the emitters of Q132 and Q134) changes in value with changes in temperature. This varies the gain of the Third Cascode Amplifier stage to compensate for changes in total amplifier gain that occur with variations in operating temperature. The push-pull signals picked off in the emitters of Q132 and Q134 are converted to a single-ended signal by Q142 and Q148. This signal is amplified by common-base amplifier stage Q152 and applied to the bases of emitter followers Q162 and Q164. Q164 provides the output signal to the CH 1 VERT SIGNAL OUT connector located on the instrument rear panel. The output signal at the emitter of Q162 is used as the trigger signal source in the CH 1 positions of the Trigger SOURCE switches and as the signal source for emitter follower Q168. Q168 provides the X-axis signal from the Channel 1 Preamplifier to the Horizontal Amplifier in the X-Y mode of operation. CR164, CR165, CR166, and CR167 protect the emitter circuit of Q164 in the event large voltage levels are accidentally connected to the CH 1 VERT SIGNAL OUT connector. R155 adjusts the DC level of the CH 1 trigger source signal.

CHANNEL 2 PREAMP

General

The Channel 2 Preamp circuit is basically the same as the Channel 1 Preamp. Only the specific differences between the two circuits are described here. Portions of this circuit not described in the following description operate in the same manner as for the Channel 1 Preamp. Fig. 3-3 shows a detailed block diagram of the Channel 2 Preamp circuit. A schematic of this circuit is shown on diagram 2 at the rear of this manual.

Second Cascode Amplifier

The Second Cascode Amplifier in Channel 2 is basically the same as the Second Cascode Amplifier in Channel 1 except that the Channel 2 INVERT switching takes place here. For a normal (non-inverted) display, +5 volts is connected to the bases of transistors Q222 and Q224 by INVERT switch S225. The voltage divider comprised or R225 and R226 applies approximately +2.5 volts to the base of Q226 and Q228. Q222 and Q224 are biased on and Q226 and Q228 are biased off, and the signal passes on to the output cascode amplifier stage normally. With the INVERT switch in the INVERT (button in) position, +5 volts is applied to the bases of Q226 and Q228. The voltage divider composed of R225 and R224 applies approximately +2.5 volts to the bases of Q222 and Q224. Q226 and Q228 are now biased on and Q222 and Q224 are biased off. The signal that was normally applied to the base of Q232 is now applied to the base of Q234 through transistor Q228 and the signal that was normally applied to the base of Q234 is now applied to the base of Q232 through transistor Q226.



Fig. 3-3. Detailed block diagram of the Channel 2 Preamplifier.

Circuit Description-465

Third Cascode Amplifier

The trigger pickoff circuit only provides a signal to one emitter follower. This emitter follower (Q262) in turn provides the trigger signal to the Trigger Generator circuits in the CH 2 positions of the SOURCE switches.

VERTICAL SWITCHING CIRCUIT

General

The Vertical Switching Circuit determines whether the Channel 1 or Channel 2 or both signals are connected to the Vertical Output Amplifier Circuit. In the alternate and chopped modes of operation both channels are alternately displayed on a shared time basis. Fig. 3-4 shows a detailed block diagram of the Vertical Switching Circuit. A schematic of this circuit is shown on diagram 3 at the rear of this manual.

Diode Gates

The Diode Gates, consisting of four diodes each, can be thought of as switches which allow either of the Vertical Preamp output signals to be coupled to the Vertical Output Amplifier. CR304, CR305, CR307 and CR308 control the Channel 1 output and CR314, CR315, CR317 and CR318 control the Channel 2 output. These diodes are in turn controlled by the Switching Multivibrator for dual trace displays, or by the VERT MODE switch for single trace displays.

Channel 1 Only Display. When the CH 1 pushbutton is pressed, -8 volts is applied to the junction of CR315-CR317 in the Channel 2 Diode Gate through R367 (see simplified diagram in Fig. 3-5). This forward biases CR315 and CR317 and reverse biases CR314 and CR318. CR314 and CR318 block the Channel 2 signal so it cannot pass to the Delay Line Driver stage. At the same time in the Channel 1 Diode Gate, CR305 and CR307 are connected to +5 volts through R371. CR305 and CR307 are held reverse-biased while CR304 and CR308 are forward biased. Therefore, the Channel 1 signal passes to the Delay Line Driver stage.

Channel 2 Display Only. When the CH 2 pushbutton is pressed, the above conditions are reversed. The junction of CR305-CR307 is connected to -8 volts through R376 and



Fig. 3-4. Detailed block diagram of the Vertical Switching Circuit.

the junction of CR315-CR317 is connected to +5 volts through R361. The Channel 1 Diode Gate blocks the Channel 1 signal and the Channel 2 Diode Gate allows the Channel 2 signal to pass to the Delay Line Driver stage.

Switching Multivibrator

Alternate Trace Display. In this mode of operation, the Switching Multivibrator operates as a bistable multivibrator. When the ALT pushbutton is pressed, --8 volts is applied to the emitter of Alternate Trace Switching Amplifier stage Q352 by the VERT MODE switch. Q352 is forward biased to supply current to the "on" Switching-Multivibrator transistor through R352 and CR368 or CR378. For example, if Q374 is conducting, current is supplied to Q374 through R352 and CR378. The current flow through collector resistor R371 drops the CR305-CR307 cathode level negative so that the Channel 1 Diode Gate is blocked as for Channel 2 Only Operation. The signal passes through the Channel 2 Diode Gate to the Delay-Line Driver stage.

The alternate trace sync pulse is applied to the base of Q352 through C351 at the end of each sweep. This

negative-going sync pulse momentarily interrupts the current through Q352 and both Q364 and Q374 are turned off. When Q352 turns on again after the alternate trace sync pulse, the charge on C368 determines whether Q364 or Q374 conducts. For example, when Q374 was conducting, C368 was charged positive on the CR378 side to the emitter level of Q374 and negatively on the CR368 side toward the negative level at the junction of CR368 and CR378. This charge is stored while Q352 is off and holds the emitter of Q364 more negative than the emitter of Q374. During the time Q364 and Q374 are turned off, the voltages at their bases become approximately equal. Now, when Q352 comes back on, the transistor with the most negative emitter conducts first, the resulting negative movement at its collector holds the other transistor off. The conditions described previously are now reversed: now, the Channel 2 Diode Gate is reverse-biased and the Channel 1 signal passes through the Channel 1 Diode Gate.

Chopped Mode Operation. When the CHOP pushbutton is pressed, the Switching Multivibrator stage free-runs at about a 250 kHz rate. The emitters of Q364 and Q374 are connected to -8 volts through R368, R378, and the primary of transformer T354. At the time of turn-on, one



Fig. 3-5. Effect of Diode Gates on signal path (simplified Vertical Switching diagram). Conditions shown for CH 1 position of VERT MODE switch.

of the transistors begins to conduct; for example, Q374. The negative level at the collector of Q374 forward-biases CR305 and CR307 and back-biases CR304 and CR308 preventing the Channel 1 signal from reaching the Delay-Line Driver stage. Meanwhile, the Channel 2 Diode Gate passes the Channel 2 signal to the Delay-Line Driver stage.

The frequency-determining components in the CHOP mode are C368, R368, R370, and R378. The switching action occurs as follows: when Q374 is on, C368 attempts to charge to -8 volts through R368. The emitter of Q364 slowly goes toward -8 volts as C368 charges. The base of Q364 is held at a point determined by the voltage divider R365 and R374 between -8 volts and the collector level of Q374. When the emitter voltage of Q364 reaches a level slightly more negative than its base, Q364 conducts. Its collector level goes negative and pulls the base of Q374 negative through divider R364-R375 to cut Q374 off. This switches the Diode Gate stages to connect the opposite channel to the Delay-Line Driver stage. Again, C368 begins to charge towards -8 volts but this time through R378. The emitter of Q374 slowly goes negative as C368 charges until Q374 turns on. Q364 is shut off and the cycle begins again.

The Chop Blanking Amplifier stage, Q358, provides an output pulse to the Z Axis Amplifier circuit which blanks out the transition between the Channel 1 and the Channel 2 traces. When the Switching Multivibrator stage changes states, the voltage across T354 momentarily increases. A negative pulse is applied to the base of Q358 to turn it off. The width of the pulse at the base of Q358 is determined by R356 and C356. Q358 is quickly driven in to cutoff and the positive going output pulse, which is coincident with trace switching, is connected to the Z Axis Amplifier circuit through R359.

Added Mode Operation. When the ADD pushbutton is pressed, the following occurs:

1. +5 volts is applied to the cathodes of CR305 and CR307 through R371.

2. +5 volts is applied to the cathodes of CR315 and CR317 through R361.

3. -8 volts is applied to the junction of R321 and R322.

The first two actions enable both of the Channel Diode Gates so that the signal applied to the Delay Line Driver stage is the algebraic sum of the Channel 1 and Channel 2 signals. The -8 volts applied to R321 and R322 provides sufficient current to keep both diode gates turned on without altering the DC levels associated with the Delay Line Driver stage.

Delay-Line Driver

The outputs from the Diode Gate stages are applied to the Delay-Line Driver stage composed of Q322 and Q324. Q322 and Q324 are connected as feedback amplifiers with R325 and R327 providing feedback from the collector to the base of their respective transistors. A sample of the signal in the collector circuit of Q322 is used for triggering in the NORM mode of trigger operation. The BW LIMIT switch S338A connects a pi filter composed of C338, C339, L338, and L339 between the output signal lines of the Delay-Line Driver stage to reduce the upper -3 dB bandwidth limit of the Vertical Amplifier system to approximately 20 MHz. R335 and R336 provide reverse termination for the delay line. The TRIG VIEW switch S338B connects the output of the Trigger View Amplifier to the input of the Delay Line in place of the Delay Driver Stage. This allows viewing the trigger signal present in the A Trigger Generator Circuit.

Reference Feedback Amplifier

Reference Feedback stage Q332 provides common mode voltage feedback from the Delay-Line Driver stage to allow the diode gates to be switched with a minimum amplitude switching signal. The emitter level of Q332 is connected to the junction of the Switching Multivibrator collector resistors, R371 and R361 through CR372 or CR362. The collector level of the "on" Switching Multivibrator transistor is negative and either CR362 or CR372 is forward biased. This clamps the cathode level of the forward biased shunt diodes in the applicable Diode Gate about 0.5 volt more negative than the emitter level of Q332. The level at the emitter of Q332 follows the average voltage level at the emitters of the Delay-Line Driver stage. The shunt diodes are clamped near their switching level and therefore, can be switched very fast with a minimum amplitude switching signal. This maintains about the same current through the Diode Gate shunt diodes so they can be switched with a minimum amplitude switching signal regardless of the deflection signal at the anodes of the shunt diodes.

Normal Trigger Pickoff Amplifier

The trigger signal for NORM trigger operation is obtained from the collector of Q322. Normal Trigger DC Adjustment R340 sets the DC level of the normal trigger output signal so the sweep is triggered at the 0 level of the displayed signal when the Triggering LEVEL control is set to 0. Q344 and Q346 are connected as a feedback amplifier with the signal applied to the non-inverting input and the feedback connected between the output and the inverting input. Gain of the stage is approximately:

R348 + R344 R344

VERTICAL OUTPUT AMPLIFIER

General

The Vertical Output Amplifier circuit provides the final amplification for the vertical deflection signal. This circuit includes the Delay Line and the BEAM FIND pushbutton. The BEAM FIND pushbutton compresses an overscan display to within the viewing area when pressed. A schematic of the Vertical Output Amplifier circuit is shown on diagram 4 at the rear of this manual.

Delay Line

Delay Line DL400 provides approximately 120 ns delay for the vertical signal to allow the Sweep Generator circuits time to initiate a sweep before the vertical signal reaches the vertical deflection plates of the CRT. This allows the instrument to display the leading edge of the signal originating the trigger pulse when using internal triggering.

Output Amplifier

U440 is an integrated circuit amplifier stage that provides the final amplification for the vertical signal. R401 and R411 provide forward termination for the delay line. The components connected between pins 2 and 4 of U440 provide delay-line compensation. Components connected between pins 14 and 15 and pins 7 and 8 of U440 provide thermal compensation for the stage. The BEAM FIND switch, when pressed, reduces the dynamic swing capabilities of the stage, thereby limiting the display to within the display area of the CRT.

A AND B TRIGGER GENERATORS

General

The Trigger Generator circuits produce trigger pulses to start the Sweep Generator circuits. These trigger pulses are derived either from the internal trigger signal from the vertical deflection system, an external signal connected to the external trigger input connectors, or a sample of the line voltage applied to the instrument. Controls are provided in each circuit to select trigger level, slope, coupling, and source. Since the A and B Trigger Generator circuits are virtually the same, only the A Trigger Generator circuit action and the differences between the A and B Trigger Generator circuits are explained. A schematic of these circuits is shown on diagram 5 at the back of this manual.

Trigger Source

The Trigger SOURCE switch S610 selects the source of the trigger signal. The sources available to the A Trigger Generator circuit are the signal(s) being displayed (NORM), Channel 1 (CH 1), Channel 2 (CH 2), LINE, and EXT. The EXT \div 10 (A trigger circuit only) position provides 10 times attenuation for the external trigger signal. The B Trigger SOURCE switch does not have a LINE or an EXT \div 10 position, but has a STARTS AFTER DELAY position. In the LINE mode of triggering, a sample of the power line frequency is obtained from the secondary of power transformer T1501 in the Low Voltage Power Supply circuit. To prevent unwanted attenuation of the trigger signal by the LF REJ circuit, the Trigger COUPLING switches should not be in the LF REJ mode when using line voltage as a trigger source.

Trigger Coupling

The Trigger COUPLING switches offer a means of accepting or rejecting certain components of the trigger signal. In the AC, LF REJ, and HF REJ mode of trigger coupling, the DC component of the trigger signal is blocked by coupling capacitors C612 or C611. Frequency components below about 60 Hz are attenuated when using AC or HF REJ coupling and below about 15 kHz when using LF REJ coupling. The higher frequency components of the trigger signal are passed without attenuation. In the HF REJ mode of trigger coupling, the high frequency components of the trigger signal are passed without attenuation. In the HF REJ mode of trigger signal (above about 50 kHz) are attenuated, while the lower frequency components are passed without attenuation. The DC mode of trigger coupling passes unattenuated all signals from DC to 100 MHz and above.

Input Source Follower

Transistor Q622 is an FET source follower. It provides a high input impedance (set primarily by R616) for the trigger signal and also provides isolation between the Trigger Generator circuit and the trigger signal source. Diode CR617 provides input protection for Q622 if excessively high amplitude negative-going input signals are present. Q624 is a high-impedance, relatively constant, current source for Q622, and provides a measure of temperature compensation for Q622.

Paraphase Amplifier

U640 is a paraphase amplifier stage that converts the single-ended input from Source Follower Q622 into a push-pull output applied to the tunnel diode driver stage. Trigger Level Centering adjustment R635 sets the level at pins 14 and 15 of U640 so that the display is correctly triggered when the LEVEL control is centered. The LEVEL control varies the level at pins 14 and 15 of U640 to select the point on a trigger signal where triggering occurs.

The slope of the input signal that triggers the Sweep Generator circuit is determined by the setting of the SLOPE switch S630. When the SLOPE switch is set to the + position, the output signal present at pin 8 of U640 is in phase with the input signal and the output signal at pin 9 is inverted with respect to the input signal. When the SLOPE switch is set to the - position, the output signal at pin 8 is inverted with respect to the input signal and the output signal at pin 9 is in phase with the input signal.

Tunnel Diode Driver

Q650 and Q652 are common-emitter amplifier stages that provide the signal currents necessary to switch the triggering tunnel diodes. CR650 and CR652 are 4.7 mA tunnel diodes. Quiescently (i.e., after the sweep holdoff period has passed, but before triggering), CR650 and CR652 are biased into their low voltage states. Q650 cannot provide sufficient current to switch CR650 to its high voltage state. Q652, however, can provide sufficient current to bias CR652 into its high voltage state; when Q652 next conducts triggering signal current, the anode of CR652 steps positive to an approximate +0.5 volt level. Since only approximately 1 mA of current is required to maintain CR652 in its high voltage state, this makes approximately 3 mA of current additionally available with which to switch CR650 to its high voltage state. Thus, the next time Q650 conducts signal current, CR650 steps to its high voltage state, sending a positive pulse to the logic circuit to initiate sweep action. A Trigger Sensitivity adjustment R655 adjusts the tunnel diode bias to the proper level that will not allow CR650 to be switched to its high voltage state until CR652 has been switched to its high voltage state. At the end of the sweep time and during holdoff, a negative level is applied to the anode of CR652, thereby resetting both CR650 and CR652 to their low voltage states. The reset level remains during holdoff time to ensure that a sweep gating signal will not be generated until the sweep circuit has returned to its quiescent state.

A AND B SWEEP GENERATORS

General

The A and B Sweep Generators produce sawtooth voltages which are amplified by the Horizontal Amplifier circuit to provide horizontal deflection on the CRT. These sawtooth voltages are produced on command (trigger pulses) from the Trigger Generator circuits. The Sweep Generator circuits also produce gate waveforms that are used by the Z Axis Logic circuit to unblank the CRT during sweep time, and by the Sweep Logic circuit to terminate sweep generation. Fig. 3-6 shows a detailed block diagram of the A Sweep Generator circuit. The B Sweep Generator circuit is very similar to the A Sweep Generator; therefore only the differences in operation associated with the B Sweep Generator will be discussed. A schematic of both circuits is shown on diagram 6 at the rear of this manual.

Disconnect Amplifier

After holdoff but before the next sweep, Disconnect Amplifier Q1024 conducts current through R1024 and the timing resistor R_{+} . This prevents timing current from



Fig. 3-6. Detailed block diagram of the A Sweep Generator.

charging the timing capacitance C_t . The positive-going sweep start gate from Q864 turns off Q1024 and the timing current now begins to charge the timing capacitance.

Sawtooth Sweep Generator

Q1030 and Q1036 compose a Miller Integrator circuit. When the current flow through the Disconnect Amplifier is interrupted, the timing capacitance begins to charge through the timing resistor. The timing resistor and capacitance are selected by the A TIME/DIV switch to provide the various sweep rates listed on the instrument front panel. The output signal at the collector of Q1036 is a negative-going sawtooth waveform.

Output Buffer Amplifier

The Output Buffer Amplifier stage is a common-base amplifier with the signal current-driven into the emitter. It provides the output sawtooth current signal to the Horizontal Amplifier and provides a measure of isolation between the Sawtooth Generator and the Horizontal Amplifier. The HORIZ DISPLAY switch connects to this stage to control the A sawtooth output in the various horizontal modes of operation. In the A and A INTEN modes of operation, the A sweep signal passes through Q1038 to the Horizontal Amplifier. However, in the MIX and B DLY'D modes, -8 volts is connected to zener diode VR1039 which sets the emitter of Q1038 at about -1.8 volts. This biases Q1038 off, preventing the A sawtooth signal from passing to the Horizontal Amplifier.

Sweep Start Amplifier

Just before the sweep starts to run down, the levels at the bases of Q1002 A and B are approximately equal. When the sweep starts to run down, the base of Q1002B goes negative, which increases the forward bias on CR1004. This in turn decreases the forward bias on CR1001, which, very shortly after the start of the sweep, becomes reverse biased to interrupt the current through Q1002A. The circuit remains in this condition until after the sweep retrace is complete. When the circuit returns to guiescence, Q1002A again begins to conduct through R1024. This sets the current through Q1024, which establishes the starting point for the sweep. The Sweep Start adjustment sets the base level of Q1002A. This level is also connected to the base of Q1062A in the B Sweep Generator except in the MIX mode of operation. This ensures that B Sweep starts at the same level as A Sweep.

Logic Multivibrator

Q1012 and Q1014 compose a multivibrator. At quiescence, Q1014 is conducting and Q1012 is turned off. When the sweep starts to run, the negative-going ramp is coupled through the base of Q1002B and CR1004 to the cathode of CR1011. CR1011 becomes forward biased and when the level at the anode of CR1011 falls to about +4 volts Q1012 conducts and Q1014 turns off. The multivibrator remains in this state until the sweep starts to retrace and the voltage level at the anode of CR1011 rises above about +4.5 volts. The resultant pulse at the collector of Q1012 is applied to Sweep Control IC U870 to terminate the sweep. The pulse at the collector of Q1014 is applied to the A Sweep Z Axis Logic Gate to blank the CRT at the end of the sweep.

B Sweep Generator Differences

There are three prime differences between the A and B Sweep Generators. The B Sweep Output Buffer Amplifier is prevented from passing the B Sweep signal to the Horizontal Amplifier in the A and A INTEN positions of the HORIZ DISPLAY switch. There is a transistor stage connected as a constant current source in the emitter circuit of Q1062A and B (corrects for current imbalances side-to-side in Q1062 during MIX mode operation). The Sweep Start Level connected to the base of Q1062A is not always a fixed DC level. During MIX mode operation the A Sweep Sawtooth signal is applied to the base of the amplifier. Now, the DC level at which the B Sweep Generator will start generating its sawtooth waveform is constantly being changed by the A Sweep sawtooth. The output waveform from the B Sweep Generator takes the form of a composite sawtooth waveform, with the first and last parts occurring at a rate determined by the A Sweep Generator and the middle part occurring at a rate determined by the B Sweep Generator.

SWEEP AND Z AXIS LOGIC CIRCUIT

General

The Sweep And Z Axis Logic Circuit derives the logic levels necessary to control the sequence of events associated with sweep generation and CRT unblanking. The +A and +B GATE signals are also generated in this circuit. Positive logic terminologies and symbologies will be used in the following explanation of circuit operation. A schematic of this circuit is shown on diagram 8 at the rear of this manual.

A Sweep Gate

Q862 and Q864 compose the A Sweep Gate Circuit. They form an emitter coupled stage where only one transistor can be conducting at any time. The input signal to the stage is the positive-going trigger signal from the A Fire Trigger TD in the A Trigger Generator Circuit. The

Circuit Description-465

signal at the collector of Q862 is connected to the A Z Axis Gate Circuit to control CRT blanking and to generate the + A GATE signal. The signal at the collector of Q864 is connected to the emitter of the Sweep Disconnect Amplifier stage (Q1024) in the A Sweep Generator Circuit to initiate A Sweep generation.

B Sweep Gate

Q812 and Q814 compose the B Sweep Gate Circuit. They also form an emitter-coupled stage where only one transistor can be conducting at any time. The input signal to the stage is the positive-going trigger signal from the B Fire Trigger TD in the B Trigger Generator Circuit. The signal at the collector of Q812 is connected to the B Z Axis Gate Circuit to control CRT blanking and to generate the + B GATE signal. The signal at the collector of Q814 is connected to the emitter of the Sweep Disconnect Amplifier stage (Q1084) in the B Sweep Generator Circuit to initiate B Sweep generation.

Sweep Control Integrated Circuit

U870 is the Sweep Control Integrated Circuit. Several functions are performed in this stage, depending on the mode of operation of the instrument sweep generators. The following is a brief explanation of the function associated with each pin of the IC.

Pin 1. This is the positive Auto Sense input. The signal connected here comes from the A Fire Trigger TD.

Pin 2. This is the negative Auto Sense input. A fixed DC level established by R871 and R872 is connected here.

Pin 3. This is the + auto gate terminal. In the AUTO mode of operation, if no trigger signals are applied to pin 1 of U870 during the ≈ 100 ms following the end of holdoff the gate level at pin 3 steps LO to turn Q864 on which initiates a sweep.

Pin 4. Not used in this application.

Pin 5. Input terminal for negative voltage supply.

Pin 6. This is the auto gate timing terminal. R879 and C879 determine the amount of time between the end of holdoff and the generation of the auto gate.

Pin 7. This terminal lights the TRIG'D light when a triggered gate has occurred.

Pin 8. This is the holdoff timing terminal. The R/C connected to this terminal (selected by the TIME/DIV switch) determines the length of holdoff time.

Pin 9. Ground terminal.

Pin 10. This is the Holdoff output terminal. The gate level present here is LO during sweep holdoff time and HI otherwise.

Pin 11. This terminal lights the READY light when operating in the single sweep mode.

Pin 12. This is the single sweep mode terminal. When +5 volts is applied to this terminal the sweep operates in the single sweep mode; when the terminal is left open or grounded the sweep operates in the repetitive mode.

Pin 13. Not used in this application.

Pins 14 & 15. Single sweep reset terminals. Pushing the PUSH TO RESET button prepares the single sweep circuitry to respond to the next one triggering event. Also causes the READY light to be lit.

Pin 16. This is the holdoff start input terminal. The HI sweep reset gate pulse from the sweep generators is applied here to initiate sweep holdoff.

Pin 17. This is the sweep disable output terminal. The gate level at this terminal is HI during holdoff and LO otherwise.

Pin 18. Sweep lockout input. +5 volts applied to this terminal disables all sweep action.

Pin 19. Auto mode terminal. Grounding this terminal enables auto sweep operation.

Pin 20. Input terminal for positive voltage supply.

A Sweep Holdoff Amplifier

Q854 is the A Sweep Holdoff Amplifier. The holdoff gate waveform is applied to the base of Q854 through R858 and C858 from pin 17 of U870. When Q854 is turned off (during holdoff time), its collector is LO and CR851 is forward biased, which resets both the Arm and Fire trigger TD's in the A Trigger Generator. When Q854 is turned on (any time other than holdoff time), its collector level is HI and CR851 is reversed biased. This allows the trigger TD's in the A Trigger Generator to respond to the next adequate triggering signal.

B Sweep Holdoff Amplifier

Q804 is the B Sweep Holdoff Amplifier. Its circuit action is identical to that described for the A Sweep Holdoff Amplifier except that there are three gate signal sources that control the state of the stage. The three sources are the holdoff gate from pin 17 of U870 (through CR859), the collector of Q1052 in the Delay Pickoff Comparator, and the collector of Q822 in the B Latch Multivibrator (through CR809). All three gate sources must be in their LO state for B Sweep to be triggerable; any one of the sources in its H1 state will disable the B Trigger Generator TD's.

A Sweep Z-Axis Gate

Q1304 and Q1306 comprise the A Sweep Z-Axis Gate. They form an emitter-coupled stage where only one transistor can be conducting at any time. The controlling signal inputs come from the collector of Q862 in the A Sweep Gate, the blanking signal from Q1014 in the A Sweep Generator, and Q824 in the B Latch Multivibrator (only in the MIX mode of operation). The blanking signal for use in the Z-Axis Amplifier is taken from the collector of Q1306 (through CR1342). The collector signal of Q1304 is applied to the +A GATE Emitter Follower.

In all positions of the HORIZ DISPLAY switch except for B DLY'D, -8 volts is connected to the cathode of CR1341. This pulls the anode of CR1306 down very close to -8 volts, causing CR1306 to be reverse biased, which in turn allows the gate signal at the collector of Q1306 to pass through CR1342. In the B DLY'D position of the HORIZ DISPLAY switch, -8 volts is no longer connected to CR1341. This allows CR1306 to be forward biased, which pulls up on the cathode of CR1342. This reverse-biases CR1342, which blocks the A blanking signal from reaching the Z-Axis Amplifier.

In all positions of the HORIZ DISPLAY switch except MIX, -8 volts is connected to the cathode of CR832. This keeps CR831 reverse biased and prevents the collector signal of Q824 from affecting the A Z-Axis Gate. However,

in the MIX position of the HORIZ DISPLAY switch, -8 volts is no longer connected to CR832. Now, when the B Sweep ends and sets the B Sweep Latch circuit, the collector signal of Q824 (through CR831) switches the A Sweep Z-Axis Gate causing the CRT display to be completely blanked. This prevents any further display of A Sweep in the MIX mode even though A Sweep may still be running.

B Sweep Z-Axis Gate

Q1324 and Q1326 compose the B Sweep Z-Axis Gate. They form an emitter-coupled stage where normally one transistor is on and the other is off. The controlling signal inputs come from the collector of Q812 in the B Sweep Gate and the blanking signal from Q1074 in the B Sweep Generator. The blanking signal for use in the Z-Axis Amplifier is taken from the collector of Q1326 (through CR1344). The collector signal of Q1324 is applied to the +B GATE Emitter Follower.

In the A position of the HORIZ DISPLAY switch, -8 volts is applied to the cathode of CR1347, which causes CR1345 to be back biased. The collector of Q1326 is pulled positive through R1326 and CR1326, which in turn back biases CR1344, preventing the B Sweep Z-Axis Gate from affecting CRT unblanking. In the MIX and A INTEN positions of the HORIZ DISPLAY switch, -8 volts is removed from the cathode of CR1347 and applied to the cathode of CR1327. This forward biases CR1345 and reverse biases CR1326. CR1344 is still reverse biased, but when B Sweep starts, the collector of Q1326 steps negative enough to forward bias CR1344 and add a slight amount of unblanking to the A Sweep unblanking already present. This provides a measure of intensification for the B Sweep portion of an A INTEN or MIX display. In the B DLY'D position of the HORIZ DISPLAY switch, -8 volts is applied to the cathodes of CR1327 and CR1347. This reverse biases both CR1345 and CR1326, which allows the full B Sweep unblanking signal to pass through CR1344. Since the A Sweep Z-Axis Gate output diode CR1342 is held reverse biased, the only unblanking signal present at the input to the Z-Axis Amplifier will be the B Sweep signal.

+A GATE And +B GATE Emitter Followers

Q1314 and Q1334 are emitter followers providing the +A GATE and +B GATE output signals available at the instrument rear panel. The output signals are positive-going rectangular waveforms, approximately 5.5 volts in amplitude. The amplitude is set in the collectors of Q1304 and Q1324. For example, when Q1304 is conducting the base of Q1314 can go no more negative than approximately -0.7 volt (limited by CR1304). When Q1304 is not conducting, the base of Q1314 rises to the decoupled +5 volts power supply level through R1304. CR1315, CR1316,

Circuit Description-465

CR1335, and CR1336 provide protection against accidental application of damaging voltage levels to the +A GATE and +B GATE output connectors.

B Sweep Latch

Q822 and Q828 compose the B Sweep Latch. Quiescently, (before either the A or B Sweeps have reached their maximum amplitudes) both transistors are off. Then, the sweep reset pulse from whichever sweep terminates first will be applied to the base of Q828 (A Sweep reset through CR826; B Sweep reset through CR825). The positive-going reset pulse turns on Q828 and the negative-going movement at its collector turns on Q822. The collector of Q822 in turn pulls up on the base of Q828, holding Q828 on, which causes the circuit to stay in its on or latched state. The HI at the collector of Q822 is applied to the base of the B Sweep Holdoff Amplifier (through CR809) to disable the B Trigger Tunnel Diodes. In the B ENDS A position of the A TRIG HOLDOFF control the HI is also applied to the holdoff start input terminal of the Sweep Control IC through C286. Thus, when B Sweep ends A Sweep ends also.

The B Latch Multivibrator is reset to its quiescent state by the LO Holdoff level Present at pin 10 of the Sweep Control IC during A Sweep holdoff.

HORIZONTAL AMPLIFIER

General

The Horizontal Amplifier circuit provides the output signals to the CRT horizontal deflection plates. The signal applied to the input of the Horizontal Amplifier is determined by the TIME/DIV switch. The signal can be a sawtooth waveform generated within the instrument, or some external signal applied to the CH 1 OR X input connector (X-Y mode of operation). The Horizontal Amplifier also contains the X10 magnifier, horizontal positioning, and some beam finder circuitry. Fig. 3-7 shows a detailed block diagram of the Horizontal Amplifier circuit. A schematic of this circuit is shown on diagram 9 at the rear of this manual.

X-Axis Amplifier

In all positions of the TIME/DIV switches except X-Y, the input signal to the base of Q1224 will be the sawtooth waveforms from the sweep generators. In the X-Y mode however, the sweeps are disabled and the signal applied to Q1224 comes from the Channel 1 Preamp via the X-Axis Amplifier stage. This stage includes Q1214, Q1218, and their associated circuitry.



Fig. 3-7. Detailed block diagram of the Horizontal Amplifier.

Q1214 is connected as a feedback amplifier with R1214 as the feedback element. The input resistance is made up of R1211 and the gain-setting adjustment R1215. When not operating in the X-Y mode, the base of Q1214 rises toward the +15 volt supply but is clamped at approximately +5.7 volts by CR1216. This reverse biases the base-emitter junction of Q1214. The base of Q1218 also rises to approximately +5.7 volts. With the junction of R1202-R1219 sitting at approximately 0 volts, Q1218 is also biased off.

When the TIME/DIV switches are set to the X-Y position (fully counterclockwise), -8 volts is applied to the junction of R1212 and R1217. Also, +5 volts is applied to the emitter circuit of Q1218 through CR1202. This biases the Z-Axis Amplifier circuit into conduction. At the same time, +5 volts is applied to the Channel 1 Scale-Factor Switching Amplifier circuit (through CR1201) and to pin 18 of the Sweep Control Integrated Circuit U870. This enables both scale-factor indicating circuits at the same time and disables sweep generation.

Input Paraphase Amplifier

Q1224 and Q1234 compose the Input Paraphase Amplifier. This is an emitter-coupled amplifier stage that converts the single-ended input signal to a push-pull output signal. The signal at the collector of Q1224 is opposite in phase to the input signal. The signal at the collector of Q1234 is in phase with the input signal. Thermistor resistor RT1230 reduces in value with increases in ambient temperature to increase the gain of the stage. This compensates for changes in amplifier gain that occur as operating temperatures vary. R1205A and R1205B are the Horizontal POSITION and FINE controls, respectively. The FINE control has approximately one tenth the range of the POSITION control and provides fine adjustment of a magnified display.

Gain Setting Amplifier

Q1226 and Q1236 are an emitter coupled push-pull amplifier stage. Q1244 is a constant current supply for the stage. The gain of the Horizontal Amplifier is controlled by adjusting the resistance connected between the emitters of this stage. The X1 Gain adjustment R1237 adjusts unmagnified horizontal gain and the X10 Gain adjustment R1238 adjusts magnified horizontal gain. Magnifier Registration adjustment R1225 balances quiescent DC current in Q1226 and Q1236 so that a center screen display does not change position when the X10 Magnifier is turned on. When the BEAM FIND pushbutton is pressed, R1249 is connected to ground. This reduces the current supplied through Q1244, which has the effect of shifting the operating level at the collector of Q1244 in the positive direction. This causes the Horizontal Amplifier to operate closer to the point where signal limiting occurs, thereby ensuring that an overscanned display will remain within the viewing area of the CRT.

Output Amplifier

The push-pull signal from the Gain Setting Amplifier is connected to the Output Amplifier through CR1253 and CR1273. Each half of the Output Amplifier can be considered as a single-ended feedback amplifier, which amplifies the signal current at the input to produce a voltage output to drive the horizontal deflection plates of the CRT. The amplifiers have a low input impedance and require very little voltage change at the input to produce the desired output change. The Output Amplifiers are limited from overdrive by CR1251, CR1252, CR1253, and CR1273. The input diodes CR1253 and CR1273 become back-biased when the signal level at either input becomes too positive, and the diodes connected back to back between the two signal paths ensure that the signal amplitude side to side will be limited to a maximum of about 0.7 volt.

Transistors Q1254 and Q1274 are inverting amplifier stages whose collector signals drive the emitters of complementary amplifiers Q1262-Q1266 and Q1282-Q1288 respectively. C1256, C1262, and C1282 provide a signal path for fast AC signal currents from one side of the amplifier to the other. R1260-R1261 and R1280-R1281 are the feedback elements in the amplifier with C1261 and C1281 providing high-frequency compensation. The output signal from Q1262-Q1266 drives the right CRT deflection plate, while the signal from Q1282-Q1288 drives the left.

CRT CIRCUIT

General

The CRT Circuit provides the voltage levels and control circuits necessary for operation of the cathode-ray tube (CRT). Fig. 3-8 shows a detailed block diagram of the CRT Circuit. A schematic of this circuit is shown on diagram 10 at the rear of this manual.



Fig. 3-8. Detailed block diagram of the CRT & Z-AXIS Circuits.

High-Voltage Oscillator

Q1418 and associated circuitry compose the high-voltage oscillator that produces the drive for high-voltage transformer T1420. When the instrument is turned on, current through Q1416 provides forward bias for Q1418. Q1418 conducts and the collector current increases, which develops a voltage across the collector winding of T1420. This produces a corresponding voltage increase in the feedback winding of T1420, which is connected to the base of Q1418, and Q1418 conducts even harder. Eventually the rate of collector current increase in Q1418 becomes less than that required to maintain the voltage across the collector winding, and the output voltage drops. This turns off Q1418 by way of the feedback voltage to the base. The voltage waveform at the collector of Q1418 is a sine wave at the resonant frequency of T1420. Q1418 remains off during the negative half cycle while the field collapses in the primary of T1420. When the field is collapsed sufficiently, the base of Q1418 becomes forward biased into conduction again and the cycle begins anew. The amplitude of sustained oscillation depends upon the average current delivered to the base of Q1418. The frequency of oscillation is approximately 50 kilohertz. Fuse F1419 protects the +15 volt supply in the event the High-Voltage Oscillator stage becomes shorted. C1419 and L1419 decouple the +15

3-16

volt supply line and prevent the current changes present in the circuit from affecting the +15 volt regulator.

High-Voltage Regulator

Feedback from the CRT cathode -2450 volt supply is applied to the base of Q1404 through R1431D. Any change in the level at the base of Q1404 produces an error signal at the collector of Q1404, which is amplified by Q1408 and Q1416 and applied to the base of Q1418 through the feedback winding of T1420. Regulation occurs as follows.

If the output voltage at the -2450 volt test point starts to go positive (less negative), this positive-going change is applied to the base of Q1404. Q1404 conducts harder, which in turn causes Q1408 and Q1416 to conduct harder. This results in greater bias current to the base of Q1418 through the feedback winding of T1420. Now, Q1418 is biased closer to its conduction level so that it comes into conduction sooner to produce a larger induced voltage in the secondary of T1420. This increased voltage appears as a more negative voltage at the -2450 volt test point to correct the original positive-going change. By sampling the output from the CRT cathode supply in this manner, the total output of the High-Voltage Supply is held relatively constant.

The output voltage levels of the High-Voltage Supply are controlled by the High Voltage Adjustment R1400 in the base circuit of Q1404. This adjustment sets the conduction of Q1404 to a level that establishes a -2450 volt operating potential at the CRT cathode.

Q1413 and Q1414 compose an overvoltage protection circuit. In the event the regulating action of the circuit should cause the CRT cathode supply to approach approximately -3000 volts, the voltage level at the emitter of Q1416 will be very close to -6 volts. Normally Q1413 and Q1414 are biased off and do not conduct. When the voltage level at the emitter of Q1416 reaches approximately -6volts, Q1413 is biased into conduction which in turn biases Q1414 on. Q1414 now starts to reduce the base drive applied to Q1418 and prevents the amplitude of oscillations from increasing. This prevents the CRT cathode supply from going more negative than approximately -3000 volts.

High-Voltage Rectifiers and Output

The high-voltage transformer T1420 has two output windings. One winding provides filament voltage for the cathode-ray tube. The filament voltage can be supplied from the High-Voltage Supply, since the cathode-ray tube has a very low filament current drain. The cathode and filament of the CRT are connected together to elevate the filament and prevent cathode-to-filament breakdown. One high-voltage winding provides both the negative cathode potential and the positive anode accelerating voltage. The CRT grid bias voltage is derived by a DC restorer circuit that uses a sample of the signal in the high-voltage winding in conjunction with DC levels supplied by the Z-Axis Amplifier and the negative cathode potential.

The positive accelerating potential is supplied by High Voltage Multiplier U1432. Regulated output voltage is approximately +15,500 volts. The negative cathode potential is supplied by half-wave rectifier CR1241. Voltage output is -2450 volts. Voltage variations in this supply are monitored by the High-Voltage Regulator circuit to provide a regulated high-voltage output.

CRT Control Circuits

Focus of the CRT display is controlled by FOCUS control R1430. ASTIG adjustment R1445, which is used in conjunction with the FOCUS control to provide a well-defined display, varies the positive level on the astigmatism grid. Geometry adjustment R1442 varies the positive level

on the horizontal deflection plate shields to control the overall geometry of the display.

Two adjustments control the trace alignment by varying the magnetic field around the CRT. Y Axis adjustment R1446 controls the current through L1446, which affects the CRT beam after vertical deflection, but before horizontal deflection. Therefore, it affects only the vertical (Y) components of the display. TRACE ROTATION adjustment R1440 controls the current through L1440 and affects both vertical and horizontal rotation of the beam.

Z-Axis Amplifier

The Z-Axis Amplifier circuit controls the CRT intensity level from several inputs. The effect of these input signals is to either increase or decrease the trace intensity, or to completely blank portions of the display. The input transistor Q1466 is a current-driven, low input impedance amplifier. It provides termination for the input signals as well as isolation between the input signals and the following stages. The current signals from the various control sources are connected to the emitter of Q1466 and the algebraic sum of the signals determines the collector conduction level.

Q1472, Q1474, and Q1478 compose a feedback amplifier stage; R1468 and R1469 are the feedback elements. C1469 and C1471 provide high frequency compensation. Q1472 is an emitter follower providing drive to complementary amplifier Q1474-Q1478. CR1468, CR1472, and CR1476 provide protection in the event of high-voltage arcing.

In the .1 s, .2 s, .5 s, and X-Y positions of the TIME/DIV switch, +5 volts is connected to the anode of CR1463. This limits the effective range of the INTENSITY control to reduce the unblanking capabilities of the amplifier, thereby reducing the possibility of inadvertently burning the CRT phosphor. When the BEAM FIND pushbutton is pressed, two things occur: First, +15 volts is applied to the anode of CR1465 which lifts the emitter of Q1466 sufficiently positive to ensure there will be no conduction through Q1466. Secondly, R1470 becomes connected to -8 volts through R1477 which establishes a fixed predetermined unblanking level at the output of the amplifier. Thus, the INTENSITY control and all of the input unblanking signals have no control over the intensity level of the CRT display when the BEAM FIND pushbutton is pressed.

DC Restorer Circuit

C1488, C1487, CR1487, CR1488, and R1486 form a DC restorer circuit. All DC levels in this circuit are

Circuit Description-465

referenced to the negative potential of the CRT cathode. The voltage difference across R1486 approximately equals the voltage swing present at the junction of CR1482 and CR1483. The control grid end of R1486 is more negative than the end connected to CR1488. The amplitude of the voltage swings present at the junction of CR1482 and CR1483 is determined by the voltage levels established by the Z-Axis Amplifier and the CRT Bias adjust circuit. CR1483 sets the limit of the positive excursion and CR1482 sets the limit of the negative excursion.

CALIBRATOR

General

The Calibrator circuit produces a square-wave output signal with accurate voltage and current amplitudes. This output is available as a voltage or current at the CALI-BRATOR current loop on the instrument front panel. Fig. 3-9 shows a detailed block diagram of the Calibrator circuit. A schematic of this circuit is shown on diagram 11 at the back of this manual.

Multivibrator

Q1590 and Q1594 along with their associated circuitry compose an astable multivibrator. The basic frequency of the multivibrator is approximately one kilohertz and is essentially determined by the RC combination of C1592, R1591, and R1593. Q1590 and Q1594 alternately conduct, producing a square-wave output signal, which is taken from the collector of Q1594. The amplitude of the square wave is limited in the negative direction by the base-emitter junction of Q1598 and in the positive direction by CR1596.



Fig. 3-9. Detailed block diagram of the Calibrator circuit.

Output Amplifier

The output signal from the Multivibrator overdrives Output Amplifier Q1598 to produce an accurate square wave at the output. When the base of Q1598 goes positive Q1598 is cut off and the collector level drops down to ground. When the base goes negative Q1598 is biased into saturation and the collector of Q1598 rises positive to about +5 volts. Amplitude adjustment R1597 adjusts the resistance between the collector of Q1598 and ground to determine the amount of current allowed to flow, which in turn determines the voltage developed across R1599.

A TRIGGER VIEW AMPLIFIER

General

The A Trigger View Amplifier circuit amplifies a sample of the signal present in the A Trigger Generator circuit and passes it on to the Vertical Output Amplifier for display on the CRT when the TRIG VIEW pushbutton is pressed. This provides a method of making a quick and convenient check of the signal being used to trigger the A Sweep Generator and is intended primarily to be used to check the signal applied to the A External Trigger Input connector. Fig. 3-10 shows a detailed block diagram of the A Trigger View Amplifier circuit. A schematic of this circuit is shown on diagram 11 at the back of this manual.

Amplifier

The amplifier consists of two emitter-coupled push-pull amplifier stages. The emitter source voltage for Q672 and Q682 is switched on and off by the TRIG VIEW pushbutton. With the TRIG VIEW pushbutton not pressed, the emitters of Q672 and Q682 are returned to -8 volts through R691. This reverse-biases the base-emitter junctions of the transistors, preventing any loading of the A Trigger Generator circuit. When the TRIG VIEW pushbutton is pressed, the emitters of Q672 and Q682 are returned to +15 volts through R690. This forward biases



Fig. 3-10. Detailed block diagram of the Trigger View Amplifier.

Q672 and Q682 to allow signal amplification. R675 adjusts for correct DC balance in the circuit.

Normally, the output of the Vertical Switching Amplifier is applied to the input of the Delay Line. When the TRIG VIEW pushbutton is pressed, the signal from the Vertical Switching Amplifier is removed and the output from the A Trigger View Amplifier is applied in its place.

LOW-VOLTAGE POWER SUPPLY

General

The Low-Voltage Power Supply circuit provides the operating power for this instrument from four regulated supplies and one unregulated supply. Electronic regulation is used to provide stable, low-ripple output voltages. Fig. 3-11 shows a detailed block diagram of the Power Supply circuit. A schematic of this circuit is shown at the back of this manual.



Fig. 3-11. Detailed block diagram of the Low Voltage Power Supply.
Power Input

Power is applied to the primary of transformer T1501 through Line Fuse F1501, POWER switch S1501, Thermal Cutout S1502, Line Voltage Selector switch S1503, and the Regulating Range Selector Assembly. Line Voltage Selector switch S1503 connects the split primaries of T1501 in parallel for 115-volt nominal operation, or in series for 230-volt nominal operation. Line Fuse F1501 should be changed to the correct value to provide the correct protection for each nominal line voltage (current rating of fuse for 230-volt operation is one-half the current rating of fuse for 115-volts).

The vacant windings between pins 10, 11, and 12 of T1501 are intended for use with the optional Inverter Circuit Board (Option 7). This allows the instrument to be operated from an external DC power source or an 1106 Power Supply.

Secondary Circuit

The -8 volt, +5 volt, +15 volt, and +55 volt supplies are series-regulated supplies. U1524A and B and U1554A and B are high-gain amplifier cells with differential inputs. These amplifiers monitor voltage variations in the output voltages and generate error signals to maintain relatively constant output voltages. Additionally an unregulated +120 volt supply is derived from the unregulated voltage in the +55 volt supply.

R1515, R1516, VR1515, and Q1514 compose a Crowbar circuit. This circuit provides protection in the event, that the applied line voltage exceeds the upper limit selected by the Regulating Range Selector Assembly. When over-voltage conditions occur, Q1514 is triggered on and starts to conduct. This places a very low impedance directly across the output of CR1511, which now begins to conduct heavily, and eventually causes the line fuse F1501 to blow.

C1510, C1511, and R1511 compose a wave-shaping circuit that provides a sample of the AC voltage present in the secondary of T1501 to the trigger circuitry for use in the LINE positions of the Trigger SOURCE switches. CR1512 provides a relatively fast discharge path for C1542 when instrument power is turned off.

FAN MOTOR CIRCUIT

General

The fan motor used in the 465 is a brushless DC fan motor using Hall Effect devices. The fan motor circuitry varies the rotational speed of the fan with variations in operating temperature. When the ambient temperature increases, the value of thermistor RT1696 reduces. This biases Q1698 on harder to conduct more current through the Hall devices. Higher currents through the Hall devices causes the potential difference across them (for instance, between pins 6 and 8 of the fan) to increase. This potential difference biases one of a pair of transistors on and the other off. For instance, if pin 8 is more positive than pin 6 of the fan, Q1690A will be on and Q1690D will be off. The higher the potential difference between pin 8 and pin 6 the harder the on transistor will be conducting. The harder the transistor is conducting, the faster the fan rotates.

MAINTENANCE

Cabinet Removal



Dangerous potentials exist at several points throughout this instrument. When the instrument is operated with the cover removed, do not touch exposed connections or components. Some transistors may have elevated cases. Disconnect power before cleaning the instrument or replacing parts.

The instrument wrap-around cabinet can be removed in the following manner:

1. Unwrap the power cord from the instrument feet.

2. Remove the six screws indicated in Fig. 4-1 and remove the instrument feet and rear ring assembly from the instrument.

3. Slide the wrap-around cabinet to the rear and remove the oscilloscope.

To replace the instrument in its wrap-around cabinet, reverse the removal procedure. The portable wrap-around cabinet should be installed with the carrying handle pivot points positioned toward the bottom of the instrument.

PREVENTIVE MAINTENANCE

General

Preventive maintenance consists primarily of cleaning and visual inspection. When performed on a regular basis, preventive maintenance can prevent instrument breakdown and will improve the reliability of this instrument. The severity of the environment to which the 465 is subjected will determine the frequency of maintenance. A convenient time to perform preventive maintenance is just prior to recalibration of the instrument.

Cleaning

General. The 465 should be cleaned as often as operating conditions require. Accumulation of dirt in the instrument can cause overheating and component breakdown. Dirt on

components acts as an insulating blanket and prevents efficient heat dissipation. It also provides an electrical conduction path which can result in instrument failure.

The cabinet provides protection against dust in the interior of the instrument. Operation without the cabinet in place necessitates more frequent cleaning. The front cover provides a measure of dust protection for the front panel and the CRT face. The front cover should be installed when storing or transporting the instrument.



Avoid the use of chemical cleaning agents which might damage the plastics used in this instrument. Avoid chemicals which contain benzene, toluene, xylene, acetone or similar solvents. Recommended cleaning agents are isopropyl alcohol or Kelite (1 part Kelite, 20 parts water).

Switch Contacts. Most of the switching in the 465 is accomplished with circuit-board mounted, cam-actuated contacts. Care must be exercised to preserve the highfrequency characteristics of these switches. Seldom is switch maintenance necessary, but if it is required, observe the following precautions.

Cleaning the switch contacts should only be done using isopropyl alcohol or a solution of one part Kelite to 20 parts water. In the absence of these three cleaners it is safe to use petroleum ether, white kerosene, or a solution of 1% Joy detergent and 99% water. Do not use acetone, MEK, MIBK, benzol, toluol, carbon tetrachloride,



Fig. 4-1. Removing wrap-around cabinet.

Maintenance-465

trichlor, trichlene, methyl alcohol, methylene chloride, sulfuric acid, or Freon TC-TE-TF-22-TA-12.

Most spray circuit coolants and contact cleaners contain Freon 12 as a propellant. Because many Freons adversely affect the contacts, check the contents before using a spray cleaner or coolant. An acceptable contact cleaner-restorer is No Noise (Electronic Chemical). The only recommended circuit coolants are dry ice or isopropyl alcohol. There are three recommended switch lubricants. They are Silicone Versilube (General Electric Co.), Rykon R (Standard Oil, and WD-40 (Rocket Chemical Co.).

Exterior. Loose dust accumulated on the outside of the 465 can be removed with a soft cloth or small paint brush. The paint brush is particularly useful for dislodging dirt on and around the front-panel controls. Dirt which remains can be removed with a soft cloth dampened in a mild detergent and water solution. Abrasive cleaners should not be used.

CRT. Clean the blue and clear plastic light filters and the CRT face with a soft, lint-free cloth dampened with denatured alcohol or a mild detergent and water solution. The optional CRT mesh filter can be cleaned in the following manner.

1. Hold the filter in a vertical position and brush lightly with a soft No. 7 watercolor brush to remove light coatings of dust and lint.

2. Greasy residues or dried-on dirt can be removed with a solution of warm water and a neutral pH liquid detergent. Use the brush to lightly scrub the filter.

3. Rinse the filter thoroughly in clean water and allow to air dry.

4. If any lint or dirt remains, use clean low-pressure air to remove. Do not use tweezers or other hard cleaning tools on the filter as the special finish may be damaged.

5. When not in use, store the mesh filter in a lint-free dust-proof container such as a plastic bag.

Interior. Dust in the interior of the instrument should be removed occasionally due to its electrical conductivity under high-humidity conditions. The best way to clean the interior is to blow off the accumulated dust with dry, low-pressure air. Remove any dirt that remains with a soft paint brush or a cloth dampened with a mild detergent and water solution. A cotton-tipped applicator is useful for cleaning in narrow spaces or for cleaning circuit boards.

Lubrication

The fan motor and most of the potentiometers used in the 465 are permanently sealed and generally do not require periodic lubrication. The switches used in the 465, both cam- and lever-type, are installed with proper lubrication applied where necessary and will only rarely require any additional lubrication. It is recommended that a regular periodic lubrication program not be performed on any of the components used in the 465.

Transistor Checks

Periodic checks of the transistors and other semiconductors in the 465 are not recommended. The best check of semiconductor performance is actual operation in the instrument.

Recalibration

To assure accurate measurements, check the calibration of this instrument after each 1000 hours of operation or every six months if used infrequently. In addition, replacement of components may necessitate recalibration of the affected circuits. Complete calibration instructions are given in the Calibration section.

The calibration procedure can also be helpful in localizing certain troubles in the instrument. In some cases, minor troubles may be revealed or corrected by recalibration.

CORRECTIVE MAINTENANCE

General

Corrective maintenance consists of component replacement and instrument repair. Special techniques required to replace components in this instrument are given here.

Obtaining Replacement Parts

Standard Parts. All electrical and mechanical part replacements for the 465 can be obtained through your local TEKTRONIX Field Office or representative. However, many of the standard electronic components can be obtained locally in less time than is required to order them from Tektronix, Inc. Before purchasing or ordering replacement parts, check the parts list for value, tolerance, rating, and description.

NOTE

When selecting replacement parts, it is important to remember that the physical size and shape of a component may affect its performance in the instrument, particularly at high frequencies. All replacement parts should be direct replacements unless it is known that a different component will not adversely affect instrument performance.

Special Parts. In addition to the standard electronic components, some special components are used in the 465. These components are manufactured or selected by Tektronix, Inc. to meet specific performance requirements, or are manufactured for Tektronix, Inc. in accordance with our specifications. These special components are indicated in the Electrical Parts List by an asterisk preceding the part number. Most of the mechanical parts used in this instrument have been manufactured by Tektronix, Inc. Order all special parts directly from your local TEK-TRONIX Field Office or representative.

Ordering Parts. When ordering replacement parts from Tektronix, Inc., it is imperative that all of the following information be included in the order to ensure receiving the proper parts.

1. Instrument type.

2. Instrument serial number.

3. A description of the part (if electrical, include the circuit number).

4. TEKTRONIX Part number.

Soldering Techniques



Always disconnect the instrument from the power source before attempting to solder in the instrument.

Ordinary 60/40 solder and a 35- to 40-watt pencil-type soldering iron can be used to accomplish the majority of the soldering to be done in the 465. If a higher wattagerating soldering iron is used on the etched circuit boards, excessive heat can cause the etched circuit wiring to separate from the board base material.



The Vertical Preamplifier Attenuator circuit boards are made of material easily damaged by excessive heat. When soldering to these boards, do not use a soldering iron with a rating of more than approximately 15 watts. Avoid prolonged applications of heat to circuit-board connections. Use only isopropyl alcohol when cleaning this circuit board.

When soldering to the ceramic strips in the instrument a slightly larger soldering iron can be used. It is recommended that a solder containing about 3% silver be used when soldering to these strips to avoid destroying the bond to the ceramic material. This bond can be broken by repeated use of ordinary tin-lead solder or by the application of too much heat; however, occasional use of ordinary solder will not break the bond if excessive heat is not applied.

If it becomes necessary to solder in the general area of any of the high-frequency contacts in the instrument, clean the contacts immediately upon completion of the soldering. Refer to the section entitled Switch Contacts under PREVENTIVE MAINTENANCE for recommended cleaners and procedures.

Component Replacement

WARNING

Always disconnect the instrument from the power source before attempting to replace components.

Circuit Board Replacement. Occasionally it may be necessary to gain access to the reverse side of a circuit board or to remove one circuit board to gain access to another. The following procedures outline the necessary steps to facilitate instrument disassembly. Most of the connections to the circuit boards in the instrument are made with pin connectors. However, some connections are soldered to the board. Observe the soldering precautions given under Soldering Techniques in this section.

Vertical Preamp Assembly Removal.

1. Remove the instrument wrap-around cabinet in the manner given under Cabinet Removal earlier in this section.

2. Remove the knobs from the VOLTS/DIV switches and from the Input Coupling Switches. The knobs on the VOLTS/DIV switches must have a setscrew in each one loosened (using a 1/16" Allen wrench) before they can be removed, while the knobs on the Input Coupling switches can be pulled off by hand.

3. Disconnect the vertical POSITION control shaft couplers from the vertical POSITION potentiometers (.050" Allen wrench required).

Maintenance-465

4. Remove the two UNCAL light lenses. Pry them away from the front panel with a fingernail and pull them straight out.

5. Disconnect the following cables from the Vertical Preamp circuit board:

a. Nine coaxial cables (five on the front and four on the back). Make note of cable color-codes to insure proper installation during reassembly.

b. A six-wire ribbon cable that connects to the Interface board (P300).

c. The delay-line that connects to the Vertical Output Amplifier.

d. An eight-wire ribbon cable that plugs onto the Vertical Mode Switch circuit board (P390).

6. Remove the covers from the attenuators.

7. Unsolder the leads to both input coupling capacitors. Remove the capacitors by unplugging them from the attenuator circuit boards.

8. Remove the four nuts securing the attenuator chassis to the instrument front casting (1/4" nutdriver required).

9. Remove the circuit board hold down screw on the Vertical Mode Switch circuit board (accessible through a hole in the Vertical Preamp circuit board near the Channel 1 POSITION potentiometer; pozidrive screwdriver required).

10. Remove three circuit board hold down screws from the Vertical Preamp circuit board (two at the rear and one below the Channel 2 POSITION potentiometer).

11. Remove the Vertical Preamp, cam switch assembly, and Vertical Mode Switch circuit board as a unit. Pull the rear of the Vertical Preamp circuit board outward about one or two inches; then slide the whole assembly to the rear until the front-panel control shafts clear the front casting.

To reinstall the Vertical Preamp assembly, reverse the order of the removal steps. To align the VERT MODE switch pushbuttons, hold the assembly in place with a slight forward pressure and use some sort of small tool to reach through the front panel to align the buttons. Install the remaining parts in the reverse order they were removed. Do not tighten the circuit board hold down screws until the securing nuts at the front of the attenuator chassis are tight and the circuit board is aligned properly.

Trigger Circuit Board Removal.

1. Remove the LOW LINE, READY, and TRIG light lenses from the front panel. Pry them away from the front panel with a fingernail and pull straight out.

2. Disconnect the following cables:

a. Eight coaxial cables (five on the front and three on the back; two on the front will have to be unsoldered). Make note of cable color-codes to ensure proper installation during reassembly.

b. Three ribbon cables (two five-wire and one twowire) from the Trigger Generator & Sweep Logic circuit board (P530, P630, and P1040).

3. Unsolder the two wires from the circuit board that run to the A TRIG HOLDOFF control and the two connections to the External Trigger Input connectors. Make note of wire color-codes to ensure proper installation during reassembly.

4. Remove the POWER switch actuator rod from the plastic holder on the switch. Pry the rod out of the holder with a small flat-bladed screwdriver.

5. Remove the POWER switch bracket from the circuit board (1/4" wrench or nutdriver required).

6. Remove five mounting screws from the circuit board (two at rear, two at front, and one at center-top; pozidrive screwdriver required).

7. Unplug the Trigger Generator & Sweep Logic circuit board from the Interface Board by forcing the Trigger board away at the two white interboard connectors at the bottom edge of the Trigger board.

8. Move the Trigger board to the rear until the Trigger switches clear the front casting and then remove the assembly from the instrument. Exercise caution to avoid damaging the connector pins on the Interface Board.

To reinstall the Trigger Generator & Sweep Logic circuit board, reverse the order of the removal steps. If the indexing of the Trigger switches was disturbed, a series of

trial-and-error installation-removal-adjustment steps will be necessary to return them to correct alignment.

Sweep Timing Circuit Board Removal.

1. Remove the Trigger Generator & Sweep Logic circuit board as outlined above.

2. Unsolder four wires from the Timing circuit board. Make note of wire color-codes to ensure proper installation during reassembly.

3. Remove the knobs from the VAR TIME/DIV control and the A AND B TIME/DIV switches (1/16" Allen wrench required). Be careful not to lose the plastic bushing behind the knobs.

4. Remove the X10 MAG and the UNCAL light lenses. Pry them away from the instrument front panel with a fingernail and pull straight out.

5. Remove the four Interface board mounting screws that are nearest the Sweep Timing circuit board.

6. Remove the board mounting screw and the hex rod from the Sweep Timing circuit board (3/16" wrench or nutdriver required).

7. Use a flat blade screwdriver and pry the Timing Board away from the Interface Board. Gently pull away the corner of the Interface Board near the B External Trigger Input connector and simultaneously lift up on the Timing Board near the rear to fully disengage connector pins from the Interface Board.

To reinstall the Timing Board reverse the order of the removal steps.

Power Transformer Replacement. If the power transformer becomes defective, contact your local TEKTRONIX Field Office or representative for a warranty replacement (see warranty note in the front of this manual). Be sure to replace only with a direct replacement TEKTRONIX transformer. After the transformer is replaced check the performance of the complete instrument. The transformer is removed as follows:

1. Unsolder the power cord from the Interface Board, the Regulating Range Selector Assembly, and the solder lug on the rear subpanel. 2. Remove the small blue panel from the rear panel of the instrument. It will be necessary to remove the cover from the Regulating Range Selector Assembly and the two feet from that side of the instrument.

3. Remove the actuating shaft from the POWER switch coupler. Exercise caution so as not to damage the switch coupler.

4. Remove the POWER switch mounting bracket from the Trigger Board.

5. Unsolder the transformer leads from the Interface Board and the solder lug on the rear subpanel. Note the wire color codes to facilitate correct reinstallation.

6. Remove the transformer leads from the Regulating Range Selector Assembly. It will be necessary to use a special pin removing tool available under TEKTRONIX part number 003-0707-00. It is only necessary to use this tool to remove the transformer leads from the Selector Assembly. The leads may be reinstalled by simply pushing them into place. Note wire color codes to facilitate correct reinstallation.

7. Remove the transformer bracket mounting hardware. This includes two screws on the Trigger Board, one screw on the Interface Board, two nuts on the U-channel (one on the transformer side and one on the CRT side), and two screws and nuts on the rear subpanel.

8. Thoroughly loosen the Trigger Board and remove the transformer assembly from the instrument.

9. Remove the thermal cutout and POWER switch from the old transformer and install on the new transformer. Note wire color codes to facilitate correct installation.

10. Install the new transformer assembly in the instrument reversing the order of the removal steps.

Recalibration After Repair

After any electrical component has been replaced, the calibration of that particular circuit should be checked, as well as the calibration of other closely related circuits. Since the power supply affects all circuits, calibration of the entire instrument should be checked if work has been done in the power supply or if the transformer has been replaced.

Instrument Repackaging

If the 465 is to be shipped for long distances by commercial means of transportation, it is recommended that the instrument be repackaged in the original manner for maximum protection. The original shipping carton can

be saved and used for this purpose. The Repackaging illustration in the Mechanical Parts Illustrations shows how to repackage the 465 and gives the part numbers for the repackaging components. New shipping cartons can be obtained from Tektronix, Inc. Contact your local TEK-TRONIX Field Office or representative.

CALIBRATION

Calibration Interval

To assure instrument accuracy, check the calibration of the 465 every 1000 hours of operation, or every six months if used infrequently. Before complete calibration, thoroughly clean and inspect this instrument as outlined in the Maintenance section of the manual.

TEKTRONIX Field Service

Tektronix, Inc. provides complete instrument repair and recalibration at local Field Service Centers and the Factory Service Center. Contact your local TEKTRONIX Field Office or representative for further information.

Using This Procedure

Index. To aid in locating a step in the Performance Check or Calibration procedure, an index is given preceding Part I-Performance Check and Part III-Calibration procedure.

Performance Check. The performance of this instrument can be checked without removing the covers or making internal adjustments, by performing only Part I— Performance Check. This procedure does not check every facet of the instrument's calibration; rather it is concerned primarily with those portions of the instrument essential to measurement accuracy and correct operation.

Short-Form Calibration. A short-form calibration procedure is provided to the technician experienced with the 465 as guidelines for calibration of this instrument, in Part II-Short-Form Calibration.

Calibration Procedure. Completion of each step in Part III-Calibration procedure, ensures that this instrument meets the electrical specifications given in the front of this manual. Where possible, instrument performance is checked before an adjustment is made. For best overall instrument performance when performing a complete calibration procedure, make each adjustment to the exact setting even if the CHECK- is within the allowable tolerance.

Partial Procedures. A partial check or adjustment is often desirable after replacing components or to touch up the adjustment of a portion of the instrument between major recalibrations. To check or adjust only part of the instrument, set the controls as given under the nearest

Control Settings and use the Equipment Required list preceding the desired portion of the step. To prevent unnecessary recalibration of other parts of the instrument, readjust only if the tolerance given in the CHECK- part of the step is not met. If readjustment is necessary, also check the calibration of any steps listed in the INTERACTIONpart of the step.

TEST EQUIPMENT REQUIRED

General

The following test equipment and accessories, or its equivalent, is required for complete calibration of the 465. Specifications given for the test equipment are the minimum necessary for accurate calibration. Therefore, some of the specifications listed here may differ from the actual performance capabilities of the test equipment. All test equipment is assumed to be correctly calibrated and operating within the listed specifications. Detailed operating instructions for the test equipment are not given in this procedure. Refer to the instruction manual for the test equipment if more information is needed.

If only a Performance Check procedure or a Calibration procedure is performed, not all of the listed test equipment will be required. Items used only for the Part III-Calibration procedure are indicated by footnote 1. The remaining pieces of equipment are items common to both a Performance Check procedure and a Calibration procedure.

Special Calibration Fixtures

Special TEKTRONIX calibration fixtures are used only where they facilitate instrument calibration. These special calibration fixtures are available from Tektronix, Inc. Order by part number through your local TEKTRONIX Field Office or representative.

Calibration Equipment Alternatives

All of the listed test equipment is required to completely check and calibrate this instrument. However, complete checking or calibration may not always be necessary or desirable. The user may be satisfied with checking only selected characteristics, thereby reducing the amount of test equipment actually required.

The Performance Check and Calibration procedure are based on the first item of equipment given as an example of applicable equipment. When other equipment is substituted, control settings or calibration setup may need to be altered to meet the requirements of the substitute equipment. If the exact item of test equipment given as an example in the Test Equipment list is not available, first check the Specifications column carefully to see if any

other equipment is available which might suffice. Then check the Usage column to see what this item is used for. If used for a check or adjustment which is of little or no importance to your measurement requirements, the item and corresponding step(s) can be deleted.

TABLE 5-1

Test Equipment Required

Description	Minimum Specifications	Usage	Examples of Applicable Test Equipment
1. Variable Autotransformer ¹	Capable of supplying 120 Volt-Amperes over a range of 103.5 to 126.5 volts.	Power Supply adjustment.	a. General Radio W10MT3W Variac Autotransformer.
2. Precision DC Voltmeter ¹	Range, zero to 100 volts; accuracy, within ±0.05%.	Low voltage power supply check and adjustment.	a. Fluke Model 825A Differential DC Voltmeter.
3. DC Volt- meter (VOM) ¹	Range, zero to 2500 volts; accuracy, within 3%.	High voltage check and adjustment.	a. Triplett Model 630-NA.b. Simpson Model 262.
4. Test Oscillo- scope ¹	Bandwidth, DC to 100 megahertz; minimum deflection factor, five millivolts/division; accuracy, within 3%.	Power supply checks, Z-Axis compensation; Vertical Gain adjustments; A Trigger Holdoff check; A & B Gate checks.	a. TEKTRONIX 454A Oscilloscope with two P6054 probes.
5. Time-Mark Generator	Marker outputs, 5 nanoseconds to 0.5 second; marker accuracy, within 0.1%	CRT geometry; Horizontal deflection system timing checks	a. TEKTRONIX 2901 Time- Mark Generator.
	Within 0.172.		b. TEKTRONIX 184 Time- Mark Generator.
6. Standard Amplitude Calibrator	Amplitude accuracy, within 0.25%; signal amplitude, 5 millivolts to 50 volts; output signal, one-kilohertz square-wave and positive DC voltage.	Vertical deflection system checks. Trigger View deflection factor check.	a. TEKTRONIX calibration fixture Part Number 067-0502-01.
7. Fast-Rise, High-Amplitude Pulse Generator	Risetime, 0.25 nanoseconds or less; repetition rate, 550 to 720 pulses/second; amplitude, variable from 20 millivolts to 10 volts.	Vertical deflection system checks.	a. TEKTRONIX Type 109 Pulse Generator.
8. High- Frequency Con- stant Amplitude Signal Generator	Frequency, 65 megahertz to above 150 megahertz; reference frequency, three megahertz; output amplitude, variable from 0.5 volt to 4 volts; amplitude accuracy, within 1%.	Vertical system bandwidth checks.	a. TEKTRONIX calibration fixture 067-0532-01.
9. Medium- Frequency Con- stant-Amplitude Signal Generator	Frequency, 350 kilohertz to 100 megathertz; reference frequency, 50 kilohertz; output amplitude, variable from 5 millivolts to 5 volts into 50 ohms or 10 volts unterminated; amplitude accuracy within 3%.	Vertical system bandwidth and trigger circuits operation checks. X-Y phasing check.	a. TEKTRONIX 191 Constant-Amplitude Signal Generator. b. General Radio 1211-C with 1263-C Amplitude Regulating Power Supply.

T/	ABL	.E	5-	1 (cont)	
----	-----	----	----	-----	-------	--

Description	Minimum Specifications	Usage	Examples of Applicable Test Equipment
10. Low- Frequency Con- stant-Amplitude Signal Generator	Frequency, 10 hertz to 100 kilohertz; output amplitude, variable from 0.5 volt to 40 volts peak-to-peak; amplitude accuracy, within 3%.	Low Frequency triggering checks.	a. General Radio 1310-A Oscillator.
11. Square- Wave Generator	Frequency, 10 hertz to one megahertz; risetime, one nanosecond or less from fast-rise output; output amplitude, about 120 volts unterminated or 12 volts into 50 ohms.	Vertical deflection system compensation checks.	a. TEKTRONIX Type 106 Square-Wave Generator.
12. Signal Pickoff	Connectors, GR874 thru-signal connectors and BNC signal-pickoff connector.	Trigger system checks and adjustments.	a. TEKTRONIX Part Number 017-0061-00.
13. Cable (two required)	Impedance, 50 ohms; type, RG-58/U; length, 42 inches; connectors, BNC.	Used for signal interconnection.	a. TEKTRONIX Part Number 012-0057-01.
14. Cable	Impedance, 50 ohms; type, RG-58/U; length 18 inches; connectors, BNC.	Used for signal interconnection.	a. TEKTRONIX Part Number 012-0076-00.
15. Cable	Impedance, 50 ohms; type, RG 213; electrical length, 5 nanoseconds; connectors, GR874.	Used for signal interconnection.	a. TEKTRONIX Part Number 017-0502-00.
16. T-Connector	Connectors, BNC.	Used for signal interconnection.	a. TEKTRONIX Part Number 103-0030-00.
17. Dual-Input Coupler (two required)	Connectors, BNC; matched signal transfer to each input.	Used for signal interconnection.	a. TEKTRONIX calibration fixture 067-0525-00.
18. Input Normalizer	RC time constant, 20 picofarads times 1 megaohm.	Standardize input RC time constant.	a. TEKTRONIX Part Number 067-0538-00.
19. Attenuator (two required)	Attenuation ratio, X10; connectors, BNC; impedance, 50 ohms.	Vertical amplifier compensation and trigger checks and adjustments.	a. TEKTRONIX Part Number 011-0059-01.
20. Attenuator	Attenuation ratio, X2; connectors, BNC; impedance, 50 ohms.	Trigger checks and adjustments.	a. TEKTRONIX Part Number 011-0069-01.
21. Adapter	BNC female connector to GR connector.	Used for signal interconnection.	a. TEKTRONIX Part Number 017-0063-00.
22. Termination (two required)	Impedance, 50 ohms; accuracy, within 3%; connectors, BNC.	Bandwidth checks.	a. TEKTRONIX Part Number 011-0049-01.
23. Screwdriver	Three-inch shaft; 3/32-inch bit.	Used throughout procedure to adjust variable resistors.	a. TEKTRONIX Part Number 003-0192-00.
24. Low- Capacitance Screwdriver	1 1/2-inch shaft.	Used throughout procedure to adjust variable capacitors.	a. TEKTRONIX Part Number 003-0000-00.

Preliminary Control Settings

Preset the instrument controls to the settings given below when starting a Performance Check or a Calibration procedure.

Power Controls

Demulation Demos Calenter		(both A	and B if applicable)
Line Voltage Selector POWER	115 V ON	LEVEL SLOPE COUPLING	Fully clockwi + AC

CRT Controls

INTENSITY		
FOCUS		
SCALE ILLUM		
BEAM FIND		

Midrange Midrange Midrange Off (button out)

Vertical Controls (both Channels if applicable)

VOLTS/DIV	
VAR	
POSITION	

5 mV Calibrated detent Midrange

Input Coupling	DC
VERT MODE	CH 1
INVERT	Off
20 MHz BW (Pull)	Off

Triggering Controls *.*...

SOURCE TRIG MODE

ise NORM AUTO

Sweep Controls

HORIZ DISPLAY DELAY TIME POSITION A TIME/DIV **B**TIME/DIV VAR TIME/DIV X10 MAG POSITION FINE A TRIG HOLDOFF

A Fully counterclockwise 1 ms 1 ms Calibrated detent Off (button out) Midrange Midrange NORM

PART I - PERFORMANCE CHECK

Introduction

The following procedure is intended to be used for incoming inspection to determine the acceptability of newly purchased or recently recalibrated instruments. This procedure does not check every facet of the instrument's calibration; rather it is concerned primarily with those portions of the instrument which are essential to measurement accuracy and correct operation. Removing the instrument's dust cover is not necessary to perform this procedure. All checks are made from the front panel.

Index to Part I - Performance Check

VERTICAL SYSTEM CHECK

1. Check Beam Finder Operation	Page 5-6
2. Check Channel 1 and 2 Step Attenuator Balance	Page 5-6
3. Check Channel 1 and 2 Variable Volts/Division Balance	Page 5-6
4. Check Channel 2 Inverted Balance	Page 5-7
5. Check Channel 1 and 2 Position Range	Page 5-7
6. Check Channel 1 and 2 Gain	Page 5-7
7. Check Add Mode Operation	Page 5-7
8. Check Channel 1 and 2 Deflection Accuracy	Page 5-7
9. Check Channel 1 and 2 Variable Volts/Division Range	Page 5-8
10. Check Alternate Mode Operation	Page 5-8
11. Check Chop Mode Operation	Page 5-8
12. Check Low-Frequency Compensation	Page 5-8
13. Check Channel 1 and 2 Volts/ Division Compensation	Page 5-9
14. Check Channel 2 High-Frequency Compensation	Page 5-9
15. Check Channel 1 High-Frequency Compensation	Page 5-9
16. Check Vertical Amplifier Bandwidth	Page 5-10

17. Check Cascaded Gain and Bandwidth Page 5-10

TRIGGER SYSTEM CHECK

18. Check A Triggering	Page 5-11
19. Check B Triggering	Page 5-11
20. Check A Normal Mode Operation	Page 5-12
21. Check Single Sweep Operation	Page 5-12
22. Check Trigger View Operation	Page 5-12
HORIZONTAL SYSTEM CHECK	
23. Check Differential Time Accuracy	Page 5-13
24. Check A Variable Time/Division Range	Page 5-13
25. Check A and B Timing Accuracy	Page 5-13
26. Check Delay Time Accuracy	Page 5-14
27. Check Delay Time Jitter	Page 5-14
28. Check Mixed Sweep Accuracy	Page 5-15
29. Check X Gains	Page 5-15
30. Check X-Y Phasing and Bandwidth	Page 5-15

30. Check X-Y Phasing and Bandwidth Page 5-15

Preliminary Procedure for Performance Check

The performance of this instrument can be checked at any temperature within the $0^{\circ}C$ to $+40^{\circ}C$ ($+32^{\circ}F$ to $+104^{\circ}F$) temperature range unless stated otherwise.

1. Connect the 465 to a power source which meets the voltage and frequency requirements of this instrument.

2. Set the controls as given under Preliminary Control Settings.

3. Allow at least 20 minutes warmup before proceeding.

VERTICAL SYSTEM CHECK

Equipment Required				
1. Standard Amplitude Calibrator	6. 42-Inch 50 Ω BNC cable (two)			
2. Square-Wave Generator (Type 106)	7. GR-to-BNC Female Adapter			
3. High-Frequency Constant-Amplitude Signal Gener- ator (067-0532-01)	8. 50 Ω BNC Termination			
4. Medium-Frequency Constant-Amplitude Signal Gen-	9. 20 Pf RC Input Normalizer			
	10. X10 BNC Attenuator			
5. Fast-Rise High-Amplitude Pulse Generator (Type 109)	11. Dual-Input Coupler			

Control Settings

Preset instrument controls to the settings given under Preliminary Control Settings.

1. Check Beam Finder Operation

a. Position the trace off screen with CH 1 POSITION control.

b. Push the BEAM FIND button and hold it in.

c. CHECK-That the trace is compressed and brought into the CRT viewing area.

d. Release the BEAM FIND button.

2. Check Channel 1 and 2 Step Attenuator Balance

a. Set both VOLTS/DIV switches to 20 mV and both Input Coupling switches to GND.

b. Position the trace to the center horizontal line with the CH 1 POSITION control.

c. CHECK-Rotate the CH 1 VOLTS/DIV switch from 20 mV to 5 mV. Trace should not move more than 0.2 division vertically between adjacent switch positions.

d. Set the VERT MODE switch to CH 2.

e. Position the trace to the center horizontal line with the CH 2 POSITION control.

f. CHECK-Rotate the CH 2 VOLTS/DIV switch from 20 mV to 5 mV. Trace should not move more than 0.2 division vertically between adjacent switch positions.

3. Check Channel 1 and 2 Variable Volts/Division Balance

a. Position the trace to the center horizontal line with the CH 2 POSITION control.

b. Rotate the CH 2 VAR control through its range.

c. CHECK-That the CH 2 UNCAL light comes on when the VAR control is out of the detent position.

d. CHECK-CRT display for 1.0 division or less of vertical trace shift when rotating the CH 2 VAR control through its range.

e. Set the VERT MODE switch to CH 1.

f. Position the trace to the center horizontal line with the CH 1 POSITION control.

g. Rotate the CH 1 VAR control through its range.

h. CHECK-That the CH 1 UNCAL light comes on when the VAR control is out of the detent position.

i. CHECK-CRT display for 1.0 division or less of vertical trace shift when rotating the CH 1 VAR control through its range.

j. Return both VAR controls to the detent position.

4. Check Channel 2 Inverted Balance

a. Set the VERT MODE switch to CH 2, and the CH 2 Input Coupling switch to GND.

b. Position the trace to the center horizontal line with the CH 2 POSITION control.

c. Push the INVERT switch.

d. CHECK-Trace does not vertically shift more than 2 divisions when switching from normal to inverted.

5. Check Channel 1 and 2 Position Range

a. Connect the Standard Amplitude Calibrator output to the CH 1 and CH 2 inputs via a 42-inch 50 Ω BNC cable and a dual input coupler.

b. Set both VOLTS/DIV switches to 20 mV and both Input Coupling switches to AC.

c. Adjust the Standard Amplitude Calibrator for a 500 mV output.

d. CHECK-That the top of the CRT display can be positioned down to 1/2-division above the center horizontal graticule line and the bottom of the display can be positioned up to 1/2-division below the center horizontal graticule line.

e. Set the VERT MODE switch to CH 1.

f. CHECK—That the top of the CRT display can be positioned down to 1/2-division above the center horizontal graticule line and the bottom of the display can be positioned up to 1/2-division below the center horizontal graticule line.

6. Check Channel 1 and 2 Gain

a. Set both VOLTS/DIV switches to 5 mV.

b. Set the Standard Amplitude Calibrator for a 20 mV square-wave output.

c. CHECK–CRT display for four divisions of deflection within 0.12 divisions.

d. Set the VERT MODE switch to CH 2.

e. CHECK-CRT display for four divisions of deflection within 0.12 divisions.

7. Check Add Mode Operation

a. Set both Input Coupling switches to DC.

b. Set the Standard Amplitude Calibrator for a 10 mV output.

c. Set the VERT MODE switch to ADD.

d. CHECK-CRT display for four divisions, ±0.12 division, in amplitude.

8. Check Channel 1 and 2 Deflection Accuracy

a. Set the VERT MODE switch to CH 1.

b. Set the CH 2 Input Coupling switch to GND.

c. CHECK—Using the CH 1 VOLTS/DIV switch and the Standard Amplitude Calibrator settings given in Table 5-2, check that the vertical deflection factor accuracy is within 3% in each position of the CH 1 VOLTS/DIV switch.

TABLE 5-2

Vertical Deflection Accuracy

VOLTS/DIV Switch Setting	Standard Amplitude Calibrator Output	Vertical Deflection in Divisions	Maximum Error for 3% Accuracy
5 m	20 millivolts	4	Previously Checked
 10 m	50 millivolts	5	±0.15 division
20 m	0.1 volt	5	±0.15 division
50 m	0.2 volt	4	±0.12 division
0.1	0.5 volt	5	±0.15 division
0.2	1 volt	5	±0.15 division
0.5	2 volts	4	±0.12 division
1	5 volts	5	±0.15 division
2	10 volts	5	±0.15 division
5	20 volts	4	±0.12 division

d. Set the VERT MODE switch to CH 2.

e. Set the CH 1 Input Coupling switch to GND and the CH 2 Input Coupling switch to DC.

f. CHECK-Using the CH 2 VOLTS/DIV switch and Standard Amplitude Calibrator settings given in Table 5-2, check that the vertical deflection factor accuracy is within 3% in each position of the CH 2 VOLTS/DIV switch.

9. Check Channel 1 and 2 Variable Volts/Division Range

a. Set both VOLTS/DIV switches to 20 mV.

b. Set the Standard Amplitude Calibrator for a 0.1 volt square-wave output.

- c. Rotate the CH 2 VAR control fully counterclockwise.
- d. CHECK-CRT display reduces to less than 2 divisions.
- e. Set the CH 1 Input Coupling switch to DC.
- f. Set the VERT MODE switch to CH 1.
- g. Rotate the CH 1 VAR control fully counterclockwise.
- h. CHECK-CRT display reduces to less than 2 divisions.
- i. Return both VAR controls to the detent position.
- j. Disconnect the test setup.

10. Check Alternate Mode Operation

a. Set the VERT MODE switch to ALT, A LEVEL control fully clockwise, and both Input Coupling switches to GND.

b. Position the traces 2 divisions apart.

c. CHECK-That the sweeps alternate in all settings of the TIME/DIV switch except X-Y.

11. Check Chop Mode Operation

a. Set TIME/DIV switches to 1 $\mu s,$ A SOURCE switch to NORM, A SLOPE switch to +, and VERT MODE switch to CHOP.

b. Position the two traces about 4 divisions apart.

c. Adjust the A LEVEL control for a stable display.

d. CHECK-Duration of each cycle is about four divisions.

e. CHECK-CRT display for complete blanking of switching transients between chopped segments.

12. Check Low Frequency Compensation

a. Set the A TIME/DIV switch to 0.2 ms, the VERT MODE switch to CH 1, CH 1 Input Coupling switch to DC, both VOLTS/DIV switches to 5 mV, and the CH 2 Input Coupling switch to GND.

b. Connect the fast-rise output of the Square-Wave Generator (Type 106) to the CH 1 and CH 2 inputs via a GR-to-BNC adapter, 42-inch 50 Ω BNC cable, X10 BNC attenuator, a 50 Ω BNC termination, and a dual input coupler.

c. Adjust the Square-Wave Generator to maintain a five division display throughout this step.

d. Adjust the Square-Wave Generator for a 1 kHz signal output.

e. Adjust the A LEVEL control for a stable display.

f. CHECK-CRT display for flat-top waveform with no more than 3% overshoot or roll-off on the leading edge.

g. Set the A TIME/DIV switch to $20 \,\mu s$ and adjust the Square-Wave Generator for a 10 kHz signal output.

h. CHECK-CRT display for flat-top waveform with no more than 3% overshoot or roll-off on the leading edge.

i. Set the A TIME/DIV switch to $2\,\mu$ s and adjust the Square-Wave Generator for a 100 kHz signal output.

j. CHECK-CRT display for flat-top waveform with no more than 3% overshoot or roll-off on the leading edge.

13. Check Channel 1 and 2 Volts/Division Compensation

a. Add a 20 pf Normalizer to the test setup between the 50 Ω BNC termination and the dual input coupler.

b. Set both VOLTS/DIV switches to 5 mV.

c. Move the test setup from the fast-rise output to the high-amplitude output of the Square-Wave Generator (Type 106).

d. Adjust the Square-Wave Generator for a five-division display of a one-kilohertz signal. Add or remove attenuators, as necessary, to maintain a five-division display throughout this step.

e. CHECK-CRT display for a flat-top waveform with no more than 3% overshoot or roll-off on the leading edge.

f. Set the CH 1 VOLTS/DIV switch to 50 mV.

g. CHECK-CRT display for a flat-top waveform with no more than 3% overshoot or roll-off on the leading edge.

h. Set the CH 1 VOLTS/DIV switch to 0.5 V.

i. CHECK-CRT display for a flat-top waveform with no more than 3% overshoot or roll-off on the leading edge.

j. Set the CH 1 Input Coupling switch to GND, CH 2 Input Coupling switch to DC, and the VERT MODE switch to CH 2.

k. CHECK-CRT display for a flat-top waveform with no more than 3% overshoot or roll-off on the leading edge.

I. Set the CH 2 VOLTS/DIV switch to 50 mV.

m. CHECK-CRT display for a flat-top waveform with no more than 3% overshoot or roll-off on the leading edge.

n. Set the CH 2 VOLTS/DIV switch to 0.5 V.

o. CHECK-CRT display for a flat-top waveform with no more than 3% overshoot or roll-off on the leading edge.

p. Disconnect the test setup.

14. Check Channel 2 High-Frequency Compensation

a. Set both VOLTS/DIV switches to 5 mV, the A TIME/DIV switch to 0.05 $\mu s,$ and the A SLOPE switch to +.

b. Connect the Fast-Rise High-Amplitude Pulse Generator (Type 109) to the CH 2 input via a GR-to-BNC adapter, 42-inch 50 Ω BNC cable, two X10 BNC attenuators, and a 50 Ω BNC termination.

c. Set the Pulse Generator polarity to + and the voltage range to 50 V.

d. Adjust the Pulse Generator for five divisions of deflection. Remove or add attenuators as necessary to maintain a five division display throughout this step.

e. CHECK-CRT display for risetime of 3.5 nanoseconds or less.

f. CHECK-CRT display for flat-top waveform with 3% or less aberrations.

g. Set the Pulse Generator polarity to - and the 465 A SLOPE switch to $-\!\!\!$.

h. CHECK-CRT display for flat-bottom waveform with 5% or less aberrations.

i. Set the A SLOPE switch to + and Pulse Generator polarity to +.

j. Repeat the high-frequency compensation check procedure, steps 14-e through 14-i, for each setting of the CH 2 VOLTS/DIV switch from 10 mV to 5 V.

15. Check Channel 1 High-Frequency Compensation

a. Set the VERT MODE switch to CH 1, the CH 1 Input Coupling switch to DC, and the A SLOPE switch to +.

b. Move the test signal to the CH 1 input via a GR-to-BNC adapter, 42-inch 50 Ω BNC cable, two X10 BNC attenuators, and a 50 Ω BNC termination.

c. Set the Pulse Generator polarity to +.

d. Adjust the Pulse Generator for five divisions of deflection. Remove or add attenuators as necessary to maintain a five-division display throughout this step.

e. CHECK-CRT display for risetime of 3.5 nanoseconds or less.

f. CHECK-CRT display for flat-top waveform with 3% or less aberrations.

g. Set the Pulse Generator polarity to - and the 465 A SLOPE switch to $-\!\!\!$.

h. CHECK-CRT display for flat-bottom waveform with 5% or less aberrations.

i. Set the A SLOPE switch to + and the Pulse Generator polarity to +.

j. Repeat the high-frequency compensation check procedure, steps 15-e through 15-i, for each setting of the CH 1 VOLTS/DIV switch from 10 mV to 5 V.

k. Disconnect the test setup.

16. Check Vertical Amplifier Bandwidth

a. Set both VOLTS/DIV switches to 5 mV and the A TIME/DIV switch to 0.2 ms.

b. Connect the output of the High-Frequency Constant-Amplitude Signal Generator (067-0532-01) to the CH 1 input via a GR-to-BNC adapter, X10 BNC attenuator, and a 50 Ω BNC termination.

c. Adjust the High-Frequency signal generator output amplitude for a five-division display of a 3 megahertz reference signal.

d. Without changing the output amplitude, increase the output frequency of the High-Frequency signal generator until the display is reduced to 3.5 divisions.

e. CHECK–Output frequency of the signal generator must be at least 100 megahertz (0° C to +40 $^{\circ}$ C).

f. Repeat this bandwidth check procedure, steps 16-c to 16-e, for settings of the CH 1 VOLTS/DIV switch from 10 mV to 2 V.

g. Move the test signal to CH 2.

h. Set the VERT MODE to CH 2.

i. Repeat the above bandwidth check procedure, steps 16-c to 16-e, for settings of the CH 2 VOLTS/DIV switch from 5 mV to 2 V.

j. Disconnect the test setup.

17. Check Cascaded Gain and Bandwidth

a. Set both Input Coupling switches to DC, both VOLTS/DIV switches to 5 mV, and the A TIME/DIV switch to 1 ms.

b. Connect the CH 1 OUT (on the rear panel) to the CH 2 input connector via a 42-inch 50 Ω BNC cable and a 50 Ω BNC termination.

c. Connect the Standard Amplitude Calibrator to the CH 1 input via a 42-inch 50 Ω BNC cable.

d. Adjust the Standard Amplitude Calibrator for a 5 mV output.

e. CHECK-CRT display for at least five divisions of deflection.

f. Remove the test setup from the CH 1 input.

g. Connect the output of the Medium-Frequency Constant-Amplitude Signal Generator (Type 191) to the CH 1 input via a GR-to-BNC adapter, 42-inch 50 Ω BNC cable, X10 BNC attenuator, and a 50 Ω BNC termination.

h. Adjust the Medium-Frequency signal generator for a five-division display of a 50 kilohertz reference signal.

i. Without changing the output amplitude of the signal generator, increase the output frequency until the display is reduced to 3.5 divisions.

j. CHECK—Output frequency of the signal generator must be at least 50 megahertz.

k. Disconnect the test setup.

TRIGGER SYSTEM CHECK

Equipment Required			
1. Medium-Frequency Constant-Amplitude Signal Gener- ator (Type 191)	6. 50 Ω Signal Pickoff Unit (Type CT-3)		
2. Standard Amplitude Calibrator	7. X10 BNC Attenuator		
3. 50 Ω 5 Nanosecond GR Cable	8. X2 BNC Attenuator		
4. 42-Inch 50 Ω BNC Cable	9. 50 Ω BNC Termination (two)		
5. GR-to-BNC Female Adapter	10. Dual-Input Coupler		

Control Settings

Preset instrument controls to the settings given under Preliminary Control Settings except as follows:

both TIME/DIV .05 µs

18. Check A Triggering

a. Connect the output of the Medium-Frequency Constant-Amplitude Signal Generator (Type 191) to the A External Trigger Input via a 50 Ω GR cable, a 50 Ω Signal Pickoff Unit (Type CT-3) thru output, GR-to-BNC adapter, X10 BNC attenuator, X2 BNC attenuator, and a 50 Ω BNC termination.

b. Connect the 10% BNC output connector of the 50 Ω Signal Pickoff Unit (Type CT-3) to the CH 1 and CH 2 inputs via a 50 Ω BNC termination, and a dual input coupler.

c. Adjust the Medium-Frequency signal generator to maintain a 0.3 division display of a 50 kilohertz signal.

d. Rotate the A SLOPE switch between + and -.

e. CHECK-A stable display can be obtained on both the + and - slopes of the displayed waveform in all positions of the A COUPLING switch by adjusting the A LEVEL control.

f. Set the A SOURCE switch to CH 1.

g. Repeat steps 18-d and 18-e.

h. Set the VERT MODE switch to CH 2.

i. Repeat steps 18-d and 18-e.

j. Set the A SOURCE switch to EXT and the CH 2 VOLTS/DIV switch to 20 mV.

k. Adjust the Medium-Frequency signal generator for a five-division display of a 50 kilohertz signal.

I. CHECK-That a stable display can be obtained, by adjusting the A LEVEL control, in both the + and - slopes of the displayed waveform in the AC, HF REJ, and DC positions of the A COUPLING switch.

m. Remove the X2 BNC attenuator from the External Trigger signal test setup.

n. CHECK-That a stable display can be obtained, by adjusting the A LEVEL control, in both the + and - slopes of the displayed waveform in the LF REJ position of the A COUPLING switch.

o. Replace the X2 BNC attenuator and set the A SOURCE switch to EXT \div 10.

p. Remove the X10 BNC attenuator from the External Trigger signal test setup.

q. Repeat steps 18-I through 18-n.

r. Replace both the X10 and X2 BNC attenuators to the External Trigger test setup.

s. Set the A SOURCE switch to NORM.

19. Check B Triggering

a. Move the External Trigger test signal to the B External Trigger input.

b. Adjust the Medium-Frequency signal generator to maintain a 0.3 division display of a 50 kilohertz signal.

c. Rotate the B SLOPE switch between + and -.

d. CHECK-A stable display can be obtained on both the + and - slopes of the displayed waveform in all positions of the B COUPLING switch by adjusting the LEVEL controls.

e. Set the B SOURCE switch to CH 2.

f. Repeat steps 19-c and 19-d.

g. Set the VERT MODE switch to CH 1.

h. Repeat steps 19-c and 19-d.

i. Set the B SOURCE switch to EXT, CH 1 VOLTS/DIV to 20 mV.

j. Adjust the Medium-Frequency signal generator for a five division display of a 50 kilohertz signal.

k. CHECK-That a stable display can be obtained, by adjusting the LEVEL controls, in both the + and - slopes of the displayed waveform in the AC, HF REJ, and DC positions of the B COUPLING switch.

I. Remove the X2 BNC attenuator from the External Trigger signal test setup.

m. CHECK-That a stable display can be obtained, by adjusting the LEVEL controls, in both the + and - slopes of the displayed waveforms in the LF REJ position of the B COUPLING switch.

20. Check A Normal Mode Operation

a. Set the HORIZ DISPLAY switch to A, the A COUPLING switch to AC, the A SOURCE switch to NORM, and the TRIG MODE switch to AUTO.

b. Adjust the Medium-Frequency signal generator for a 50 kilohertz signal.

c. Adjust the A LEVEL control for a triggered display.

d. Switch the TRIG MODE switch to NORM.

e. CHECK-For a stable display.

f. Remove the test signal from the CH 1 input.

g. CHECK—For no trace in the absence of an adequate trigger signal.

21. Check Single Sweep Operation

a. Set the A COUPLING switch to AC, and the TRIG MODE switch to AUTO.

b. Reconnect the test signal from the Medium-Frequency signal generator to the CH 1 input.

c. Adjust the A LEVEL control for a triggered display.

d. Remove the test signal from the CH 1 input.

e. Press the SINGL SWP button.

f. CHECK-READY light comes on when SINGL SWP button is pressed and remains on until the test signal is re-applied.

g. Reconnect the test signal to the CH 1 input.

h. CHECK-READY light is extinguished.

i. Press the SINGL SWP button.

j. CHECK-That a single-sweep display (one sweep only) is presented.

k. Disconnect the test setup.

22. Check Trigger View Operation

a. Set the CH 1 Input Coupling switch to DC, the CH 1 VOLTS/DIV switch to 10 mV, the VERT MODE switch to CH 1, the A COUPLING switch to DC, the A SOURCE switch to EXT, the A SLOPE switch to +, and the A LEVEL control to 0.

b. Connect the output of the Standard Amplitude Calibrator to the A External Trigger Input via a 42-inch 50 Ω BNC cable.

c. Adjust the Standard Amplitude Calibrator for a 200 mV square-wave output.

d. Push the TRIG VIEW button and hold it in.

e. CHECK-For 3.2 to 4.8 divisions of display.

f. Release the TRIG VIEW button.

g. Disconnect the test setup.

HORIZONTAL SYSTEM CHECK

Equipment Required

1. Time-Mark Generator

2. Standard Amplitude Calibrator

3. Medium-Frequency Constant-Amplitude Signal Generator (Type 191)

Control Settings

Preset instrument controls to the settings given under Preliminary Control Settings except as follows:

HORIZ DISPLAY	B DLY'D
A TIME/DIV	1 ms
B TIME/DIV	5 μs
B SOURCE	STARTS AFTER DELAY

23. Check Differential Time Accuracy

a. Connect 1 ms time marks to the CH 1 input from the Time Mark Generator (Type 2901) via a 42-inch 50 Ω BNC cable and a 50 Ω BNC termination.

b. Set the DELAY TIME POSITION dial to position the tenth time marker to the beginning of the sweep.

c. Note the reading on the DELAY TIME POSITION dial.

d. Adjust the DELAY TIME POSITION dial so that the ninth time marker is at the beginning of the sweep.

e. CHECK-DELAY TIME POSITION dial for a reading one division less, within 0.01 division from $+15^{\circ}$ C to $+35^{\circ}$ C; (one division less, within 0.03 division from -15° C to $+55^{\circ}$ C) than the reading noted in step 23-c.

f. Rotate the DELAY TIME POSITION dial to position each successive time marker to the beginning of the sweep.

g. CHECK-DELAY TIME POSITION dial for a reading of one division less, within 0.01 division from $+15^{\circ}$ C to $+35^{\circ}$ C (one division less, within 0.03 division from -15° C to $+55^{\circ}$ C) than the adjacent time marker.

24. Check Variable Time/Division Range

a. Set the HORIZ DISPLAY to A and the A TIME/DIV switch to 2 ms.

b. Select 5 ms time marks from the Time Mark Generator.

4.	42-Inch	50 Ω	BNC	Cable

- 5. 50 Ω BNC Termination
- 6. Dual-Input Coupler

c. CHECK-At least 1 time marker/division can be obtained by adjusting the VAR TIME/DIV control.

d. CHECK-That the UNCAL light comes on when the VAR TIME/DIV control is out of the detent position.

e. Return the VAR TIME/DIV control to the detent position.

25. Check A and B Timing Accuracy

a. CHECK-Using the A TIME/DIV switch and the Time Mark Generator settings given in Table 5-3, check A sweep timing, within 0.2 division, over the first ten divisions of the display.

TABLE 5-3

A and B Timing Accuracy

A and B TIME/DIV Switch Satting	Time-Mark Generator Output	CRT Display (Markers/ Division)
- Switch Setting		1
.05 µs	50 nanosecond	1
.1 µs	0.1 microsecond	1
.2 µs	0.1 microsecond	2
.5 μs	0.5 microsecond	1
1 μs	1 microsecond	1
2 μs	1 microsecond	2
5 µs	5 microsecond	1
10 µs	10 microsecond	1
20 µs	10 microsecond	2
50 μs	50 microsecond	1
.1 ms	0.1 millisecond	1
.2 ms	0.1 millisecond	2
.5 ms	0.5 millisecond	1
1 ms	1 millisecond	1
2 ms	1 millisecond	2
5 ms	5 millisecond	1
10 ms	10 millisecond	1
20 ms	10 millisecond	2
50 ms	50 millisecond	1
	A SWEEP ONLY	
.1 s	0.1 second	1
.2 s	0.1 second	2
.5 s	0.5 second	1

b. Set the HORIZ DISPLAY to B DLY'D.

c. CHECK-Using the B TIME/DIV switch and the Time Mark Generator settings given in Table 5-3, check B sweep timing, within 0.2 division, over the first ten divisions of the display.

26. Check Delay Time Accuracy

a. Set the B SOURCE switch to STARTS AFTER DELAY, the A TIME/DIV switch to $0.2\,\mu$ s, and the B TIME/DIV switch to $0.05\,\mu$ s.

b. CHECK-Using the A TIME/DIV switch, B TIME/ DIV switch, and the Time Mark Generator settings given in Table 5-4, check that the delayed sweep accuracy is within the given tolerance. First set the DELAY TIME POSITION dial to 1.00 and rotate the dial until the sweep starts at the top of the second time marker. Note the control setting and then set the dial to 9.00 and rotate slightly until the sweep starts at the top of the tenth time marker. DELAY TIME POSITION dial setting must be 8.00 divisions higher, ± 8 minor dial divisions.

TABLE 5-4

Delayed Sweep Accuracy

A TIME/ DIV Switch Setting	B TIME/ DIV Switch Setting	Time- Mark Generator Output	Allowable Error for Given Accuracy
.2 μs	.05 µs	.1 microsecond	
.5 μs	.05 µs	.5 microsecond	
1 µs	.1 μs	1 microsecond	
2 μs	.1 μs	1 microsecond	
5 μs	.1 μs	5 microsecond	
10 µs	1 μs	10 microsecond	
20 µs	1 µs	10 microsecond	
50 μs	1 μs	50 microsecond	
.1 ms	10 µs	.1 millisecond	±8 minor
.2 ms	10 µs	.1 millisecond	dial
.5 ms	10 µs	.5 millisecond	divisions
1 ms	.1 ms	1 millisecond	
2 ms	.1 ms	1 millisecond	
5 ms	.1 ms	5 millisecond	
10 ms	1 ms	10 millisecond	
20 ms	1 ms	10 millisecond	
50 ms	1 ms	50 millisecond	
.1 s	10 ms	.1 second	
.2 s	10 ms	.1 second	
.5 s	10 ms	.5 second	

NOTE

The sweep will start at the top of the third time marker at 1.00 and the nineteenth time marker at 9.00 for sweep rates which are multiples of 2 (e.g., 2 μ s, 20 μ s, 0.2 ms, etc.). If in doubt as to the correct setting of the DELAY TIME POSITION dial, set the HORIZ DISPLAY switch to A INTEN and check which time marker is intensified.

27. Check Delay Time Jitter

a. Set the DELAY TIME POSITION dial to 1.00, the HORIZ DISPLAY switch to B DLY'D, the A TIME/DIV switch to 1 ms, and the B TIME/DIV switch to 1 μ s.

b. Position the time marker near the center of the display area with the DELAY TIME POSITION dial.

c. CHECK-Jitter on the leading edge of the time marker does not exceed 0.2 division (0.5 division if operating the instrument on 50 Hz line voltage). Ignore the slow drift.

d. Turn the DELAY TIME POSITION dial to 9.00 and adjust it so the time marker is displayed near the center of the display area.

e. CHECK-Jitter on the leading edge of the time marker does not exceed 0.2 division (0.5 division if operating the instrument on 50 Hz line voltage). Disregard the slow drift.

28. Check Mixed Sweep Accuracy

a. Set the A TIME/DIV switch to 1 ms, the B TIME/DIV switch to 0.5 ms, the HORIZ DISPLAY switch to A, the B SOURCE switch to STARTS AFTER DELAY, and the DELAY TIME POSITION dial fully clockwise.

b. Select 1 ms time-marks from the Time Mark Generator.

c. CHECK-Timing between the second and tenth timemarkers. Note any timing error for use in step 28-e.

d. Set the HORIZ DISPLAY switch to MIX.

e. CHECK-Timing between second and tenth timemarkers is within 0.16 division, \pm the A sweep error noted in step 28-c.

f. Disconnect the test setup.

29. Check X Gain

a. Set the A TIME/DIV switch to X-Y, the VERT MODE switch to CH 2, both VOLTS/DIV switches to 5 mV, and the CH 1 Input Coupling switch to DC.

b. Apply a 20 mV square-wave from the Standard Amplitude Calibrator to the CH 1 or X input through a 42-inch 50 Ω BNC cable.

c. CHECK-CRT display for 4 divisions of deflection, within 4%, between the two displayed dots.

d. Disconnect the test setup.

30. Check X-Y Phasing and Bandwidth

a. Set both VOLTS/DIV switches to 5 mV, and both Input Coupling switches to AC.

b. Connect the output of the Medium-Frequency Constant-Amplitude Signal Generator (Type 191) to the CH 1 and CH 2 inputs through a 42-inch 50 Ω BNC cable, 50 Ω BNC termination, and a dual input coupler.

c. Adjust the Medium-Frequency signal generator for an eight-division horizontal display of a 50 kilohertz signal.

d. Center the display vertically and horizontally with the CH 1 and CH 2 POSITION controls.

e. CHECK-CRT display for an opening at the center horizontal line of 0.4 division or less (see Fig. 5-1).

f. Remove the dual input coupler from the test setup.

g. Reconnect the test signal to the CH 1 input.

h. Adjust the signal generator for a 10-division horizontal display of a 50 kilohertz signal.



Fig. 5-1. Typical CRT display when checking X-Y phasing.

i. Adjust the signal generator frequency until the display is reduced to seven divisions.

j. CHECK-Output frequency of the signal generator is at least 4 megahertz.

k. Disconnect the test setup.

PART II - SHORT-FORM CALIBRATION

Introduction

The following procedure is intended to be used as guidelines for calibration of the 465 by experienced technicians familiar with the instrument. Only essential information is given. Test Equipment Required is the same as that given previously for the Part III - Calibration Procedure.

Preliminary Procedure for Short-Form Calibration

NOTE

This instrument should be adjusted at an ambient temperature of $+25^{\circ}C$ ($\pm 5^{\circ}C$) for best overall accuracy.

1. Remove the dust cover from the 465.

2. Connect the 465 to the autotransformer and set the line voltage to 115 VAC.

3: Set the controls as given under Preliminary Control Settings (given prior to Part I - Performance Check). Allow at least 20 minutes warmup before proceeding.

NOTE

Titles for external controls of this instrument are capitalized in this procedure (e.g., INTENSITY). Internal adjustments are initial capitalized only (e.g., High Voltage).

POWER SUPPLIES AND DISPLAY CALIBRATION

1. Low Voltage Power Supplies

- a. ADJUST-+55 V supply, R1538, ± 0.5%, TP1536
- b. Check-+15 V supply, ±1.5%, TP1548
- c. Check-+5 V supply, ± 1.5%, TP1558
- d. Check--8 V supply, ± 1.5%, TP1568

e. Check-Ripple on all supplies except +55 V supply is 2 mV P-P maximum; +55 V supply ripple is 4 mV P-P maximum.

- f. Check-Regulation between 126.5 V and 103.5 V line.
- g. Check-Low line indicator comes on at 103.5 VAC.

2. High Voltage Power Supply

a. Check--2450 V supply is within ± 49 volts. Test Point is accessible through the hole in the high voltage cover.

b. ADJUST-High Voltage, R1400, for -2450 volts, ± 24.5 volts.

3. Adjust CRT Grid Bias

a. TIME/DIV to X-Y

b. Connect DC Voltmeter to TP1486 and adjust the INTENSITY for a reading of +20 V DC.

c. ADJUST-CRT Grid Bias, R1480, for the dimmest dot that is still visible.

4. Check Display Controls

- a. SCALE ILLUM
- b. FOCUS
- c. INTENSITY

5. Z-Axis Compensation

a. Connect a X10 probe from the Test Oscilloscope to TP1486.

- b. TIME/DIV to 0.05 μ s.
- c. Adjust INTENSITY for a 15 volt P-P signal.

d. ADJUST-C1471, for the best risetime and flat-top waveform.

6. Adjust Trace Alignment

a. Connect time marks to CH 1 input.

b. ADJUST-TRACE ROTATION to align trace with center graticule line.

c. ADJUST-Y Axis Alignment, R1446, to align center time marker with the center vertical graticule line.

d. Check for no more that 0.01 division curvature.

e. ADJUST-Geometry, R1442, for no more than 0.1 division curvature of the time markers.

f. Remove the time markers and check the trace at top and bottom graticule lines, no more than 0.1 division bowing or tilt.

VERTICAL SYSTEM CALIBRATION

7. Adjust Vertical Output Bias

a. Connect 100 MHz sine-wave into CH 1 from the High-Frequency Constant-Amplitude Signal Generator (067-0532-01).

b. ADJUST-Output Bias, R455, for maximum signal deflection.

c. This adjustment will affect vertical risetime, aberration, and position effect, and may be slightly misadjusted for optimum performance of the vertical system.

8. Adjust Vertical Output Centering

a. Connect DC Voltmeter between TP322 and TP324.

b. Adjust CH 1 POSITION for 0 volt reading on the meter.

c. ADJUST-Vertical Output Centering, R429, to position the trace to the center graticule line.

9. Check BEAM FIND Operation

10. Adjust CH 1 Step Attenuator Balance

a. ADJUST-CH 1 Step Atten Bal, R25, for no more than 0.2 division trace shift when switching between 5 mV, 10 mV, and 20 mV.

b. ADJUST-CH 1 Variable Balance, R120, for no more than 1 division trace shift when rotating the CH 1 VAR control through its range.

c. Check CH 1 UNCAL light.

11. Adjust CH 2 Step Attenuator Balance

a. ADJUST-CH 2 Step Atten Bal, R75, for no more than 0.2 division trace shift when switching between 5 mV, 10 mV, and 20 mV.

b. ADJUST-CH 2 Variable Balance, R220, for no more than 1 division trace shift when rotating the CH 2 VAR control through its range.

c. Check CH 2 UNCAL light.

12. Check Probe Indicator Light

a. Connect a X10 probe to CH 1 input.

b. Check that the left light goes out and the right light comes on.

c. Repeat procedure for CH 2.

13. Check CH 1 and 2 INPUT COUPLING switch

14. Adjust CH 1 and 2 Position Centering

a. VOLTS/DIV switches to 20 mV.

INPUT COUPLING to AC

b. Connect a 500 mV signal from the Standard Amplitude Calibrator to the CH 1 input.

c. ADJUST-CH 1 Position Centering, R115, so the top and bottom of the display can be positioned past the center horizontal line.

d. INTERACTION-R115 interacts with R120. Repeat steps 10 and 14 for minimum trace shift.

e. Repeat the above procedure for CH 2, adjusting R215.

f. INTERACTION-R215 interacts with R220. Repeat steps 11 and 14 for minimum trace shift.

15. Check CH 2 Invert Balance and Operation

16. Adjust CH 1 Gain

a. CH 1 VOLTS/DIV to 5 mV.

b. Connect 20 mV signal from Standard Amplitude Calibrator to CH 1 input.

c. ADJUST-CH 1 Gain, R118, for 200 mV push-pull signal between TP322 and TP324.

d. ADJUST-Vertical Output Gain, R400, for exactly 4 divisions of deflection.

e. Check all attenuator ranges for proper deflection, within 3%.

f. Check Variable Range: CH 1 VAR control must reduce a 5 division signal to less than 2 divisions.

17. Adjust CH 2 Gain

a. CH 2 VOLTS/DIV to 5 mV

b. Connect 20 mV signal from Standard Amplitude Calibrator to CH 2 input.

c. ADJUST-CH 2 Gain, R218, for exactly 4 divisions of deflection.

d. Check all attenuator ranges for proper deflection, within 3%.

e. Check Variable Range: CH 2 VAR control must reduce a 5 division signal to less than 2 divisions.

18. Check ADD Operation

a. Both VOLTS/DIV to 5 mV Both INPUT COUPLING switches to DC

b. Connect 10 mV from Standard Amplitude Calibrator to both CH inputs.

c. Set VERT MODE to ADD.

d. CHECK-If CH 1 and CH 2 Gains were adjusted, check for 4 divisions of deflection, within 1% (within 3% if CH 1 and CH 2 Gains were not adjusted).

19. Check Compression and Expansion

a. With 2 division signal, position to top and bottom of graticule.

b. Check for no more than 0.1 division of compression or expansion.

20. Check Vertical ALTernate Operation On All Sweep Speeds

21. Check Vertical CHOP Operation

a. TIME/DIV to 1 μs VERT MODE to CHOP

b. Check for blanking of transients at normal INTEN-SITY level.

c. Check duration of each cycle is about 4 divisions.

22. Adjust Vertical Output Low-Frequency Compensation

a. Connect the fast-rise output of the Square-Wave Generator (Type 106) to CH 1 input.

b. ADJUST-R424, R433, R434 for best flat-top waveform using 1 kHz, 10 kHz, and 100 kHz signals.

23. Adjust VOLTS/DIV Compensation

a. Adjust CH 1 VOLTS/DIV Compensation for no more than 2% aberrations. Use 20 picofarad Normalizer and a 5 division signal.

5 mV	C1
10 mV	Check
20 mV	Check
50 mV	C12, C13
.1 V	Check
.2 V	Check
.5 V	C10, C11
1 V	Check
2 V	Check
5 V	Check

b. Repeat procedure for CH 2.

24. Adjust Vertical Output High-Frequency Compensation

a. VOLTS/DIV to 5 mV

A TIME/DIV to 0.05 µs

b. Adjust for a 5 division display from the Fast-Rise High-Amplitude Pulse Generator (Type 109) to CH 2 input.

c. ADJUST-C77, C83, C205, R205, C249, R249, C403, C442, R442, C443, for no more than 3% aberrations and a 3.5 nanosecond, or less, risetime.

d. Check negative step aberrations, within 5%.

e. CH 2 VOLTS/DIV to 10 mV

f. ADJUST-R97, C97, for aberrations within 3% and 3.5 nanosecond, or less, risetime.

g. Check negative step aberrations, within 5%.

h. CH 2 VOLTS/DIV to 20 mV

i. ADJUST-R98, C98, for aberrations within 3% and 3.5 nanosecond, or less, risetime.

j. Check negative step aberrations, within 5%.

k. Check remaining settings of CH 2 VOLTS/DIV switch for: Positive step aberrations within 3%; risetime of 3.5 nanoseconds, or less; negative step aberrations within 5%.

I. Check position effect: Positive step aberrations within 5%, negative step aberrations within 7%.

25. Adjust CH 1 High-Frequency Compensation

a. Repeat step 24-c with adjustments C27, C33, C105, R105, C122, R122, C149, and R149.

b. Adjust R47, C47 for step 24-f.

c. Adjust R48, C48 for step 24-i.

26. Check Vertical Amplifier Bandwidth

a. Use the High-Frequency Constant-Amplitude Signal Generator (067-0532-01): 5 division display of 3 MHz reference signal.

b. From 5 mV to 5 V settings of both VOLTS/DIV switches, check frequency is at least 100 MHz (0° C to +40°C) when display is reduced to 3.5 division.

27. Check Cascaded Bandwidth and Sensitivity

a. Connect CH 1 OUT to CH 2 input through a terminated cable.

b. Check that the sensitivity is at least 1 mV/division.

c. Check Bandwidth is at least 50 MHz.

28. Check Vertical Channel Isolation and CMRR

a. Channel isolation: at least 100:1 at 25 MHz.

b. CMRR: at least 10:1 at 20 MHz for signals of 6 divisions or less.

29. Check Bandwidth Limit Operation

a. Connect 6 division display of a 50 kHz signal to CH 1 input.

b. Check frequency is 20 MHz, within 4 MHz, when display is reduced to 4.2 divisions.

TRIGGER SYSTEM CALIBRATION

30. Adjust A and B Trigger Sensitivity

a. VOLTS/DIV to 10 mV

both TIME/DIV to $0.05 \,\mu s$

A SOURCE to EXT

A COUPLING to AC

A SLOPE to +

b. Connect the output of the Medium-Frequency Constant-Amplitude Signal Generator (Type 191) to the A and B External Trigger Inputs via a 50 Ω 5 ns GR cable, 50 Ω Signal Pickoff thru output, GR-to-BNC adapter, X10 attenuator, 50 Ω termination, and a dual input coupler.

c. Connect the 10% BNC output connector of the Signal Pickoff Unit to the CH 1 and CH 2 inputs via a terminated dual input coupler.

d. ADJUST-A and B Sensitivity, R655, R555, to just obtain a stable display with a 0.25 division display of 25 MHz signal.

31. Adjust LEVEL and SLOPE Centering

a. Position 0.3 division display of 50 kHz signal to center vertical graticule line.

b. ADJUST-A Level Center, R635, for triggered display.

c. ADJUST-A Slope Center, R645, so trigger point is the same when switching from + to - slope.

d. ADJUST-B Level Center, R535, for triggered display.

e. ADJUST-B Slope Center, R545, so trigger point is the same when switching from + to - slope.

32. Adjust A Trigger DC Levels

a. A COUPLING to DC

A SOURCE to NORM

A LEVEL to 0

b. 0.3 division display centered vertically on the CRT graticule.

c. ADJUST-Normal Trigger DC Level, R340, to obtain stable display in + and - slopes.

d. A SOURCE to CH 1

e. ADJUST-CH 1 Trigger DC Level, R155, to obtain stable display in + and - slopes.

f. VERT MODE to CH 2

A SOURCE to CH 2

g. ADJUST-CH 2 Trigger DC Level, R255, to obtain stable display in + and - slopes.

33. Check B Trigger DC Levels

34. Check Triggering

a. High-frequency triggering

Internal	25 MHz	100 MHz
AC	0.3 div	1.5 div
LF REJ	0.3 div	1.5 div
DC	0.3 div	1.5 div

External		
AC	50 m V	150 m\
LF REJ	100 mV	300 m\
DC	50 m V	150 m\

Multiply by 10 for EXT ÷ 10 sensitivity.

b. HF REJ-Triggers on 0.3 division at 50 kHz; will not trigger at 350 kHz.

c. LF REJ-Triggers on 0.3 division at 50 kHz; will not trigger on 60 Hz.

d. Check single sweep operation and READY light.

e. Check A NORM triggering.

f. Check LINE triggering.

g. Check AUTO recovery time.

35. Check External LEVEL Range

a. EXT: at least + and -2 V for both A and B.

b. EXT \div 10: at least + and – 20 V for A only.

36. Adjust TRIG VIEW Centering

a. ADJUST-Trigger View Centering R675, so trace is at center horizontal line, within 1 division.

b. Connect 200 mV square-wave from Standard Amplitude Calibrator to A External Trigger Input.

c. Check for 3.2 to 4.8 divisions of display with TRIG VIEW in.

HORIZONTAL SYSTEM CALIBRATION

37. Adjust Sweep Start and A Sweep Calibration

a. B SOURCE to STARTS AFTER DELAY

HORIZ DISPLAY to A INTEN

A TIME/DIV to 1 ms

B TIME/DIV to 5 μ s

DELAY TIME POSITION to 1.00

b. Use 1 ms time markers.

c. ADJUST-R1115, to intensify start of the 2nd time marker.

d. DELAY TIME POSITION to 9.00.

e. ADJUST-R1145 to intensify start of 10th time marker.

f. HORIZ DISPLAY to B DLY'D

g. ADJUST-R1145, so 10th time marker starts at the sweep start.

h. DELAY TIME POSITION to 1.00.

i. ADJUST-R1115, so 2nd time marker starts at the sweep start.

j. INTERACTION—There is interaction between R1115 and R1145. Readjust both to minimize interaction.

k. HORIZ DISPLAY to A.

I. ADJUST-R1237 for one time marker/division.

38. Adjust B Sweep Calibration

a. B TIME/DIV to 1 ms HORIZ DISPLAY to B DLY'D

b. ADJUST-R1175, for one time marker/division.

39. Check Differential Time Accuracy

a. Accuracy within 0.01 division between adjacent time markers from +15°C to +35°C.

b. Accuracy within 0.03 division from -15° C to $+55^{\circ}$ C.

- 40. Adjust Horizontal Gain
 - a. HORIZ DISPLAY to A both TIME/DIV to 1 ms
 - b. Use 1 ms time marks.

c. ADJUST-X1 Gain, R1237, for exactly 1 time marker/division.

- d. Use 0.1 ms time marks.
- e. X10 MAG-in.

f. ADJUST-X10 Gain, R1238, for exactly 1 time marker/division.

41. Check Sweep Linearity

42. Adjust Magnifier Registration

a. Use 5 ms time marks.

b. Position the middle magnified time marker to the center vertical graticule line.

c. Turn the X10 MAG off.

d. CHECK-Center time marker should align with the center vertical graticule line, within 0.2 division.

e. ADJUST-Magnifier Registration R1225 to align the center time marker with the center vertical graticule line.

43. Check A Sweep Length

11 divisions, ± 0.5 division.

44. Check VAR TIME/DIV Range

- a. A TIME/DIV to 2 ms HORIZ DISPLAY to A
- b. Use 5 ms time marks.

c. Check for 1 time marker/division by rotating the VAR TIME/DIV control.

d. Check UNCAL light.

45. Check Horizontal POSITION Control Range

46. Adjust High Speed Timing

- a. B SOURCE to STARTS AFTER DELAY
 - A TIME/DIV to $0.5 \,\mu s$
 - B TIME/DIV to 0.05 μ s
 - HORIZ DISPLAY to A INTEN
- b. Use $0.5 \,\mu s$ time marks.
- c. ADJUST–C1137, for 1 time marker/division.
- d. HORIZ DISPLAY to B DLY'D DELAY TIME POSITION to 1.50

e. With horizontal POSITION have time marker cross the center vertical graticule line.

f. DELAY TIME POSITION to 8.50.

g. ADJUST-C1137, so time marker crosses the center vertical graticule line.

h. Repeat procedure for optimum timing.

- i. HORIZ DISPLAY to B DLY'D B SOURCE to NORM
 - A TIME/DIV to $1 \mu s$
 - B TIME/DIV to $0.5 \,\mu s$

DELAY TIME POSITION fully counterclockwise

j. ADJUST-C1167, for 1 time marker/division.

47. Check A and B Timing Accuracy

Within 0.2 division over first 10 divisions of display.

48. Adjust High Speed Magnified Timing

a. X10 MAG-on

A TIME/DIV to $0.05 \,\mu s$

c. ADJUST-Magnified Timing, C1261, C1281, for exactly one cycle/2 divisions. Disregard first and last 10 divisions of sweep length.

49. Check A and B Magnified Timing Accuracy

a. Accuracy within 0.3 division.

b. Exclude the following portions of the sweep:

at 5 ns: Exclude first and last 10 divisions

at 10 ns: Exclude first and last 5 divisions

at 20 ns: Exclude first and last 2.5 divisions

50. Check Delay Time Accuracy

Within 8 minor dial divisions.

51. Check Delay Time Jitter

a. A TIME/DIV to 1 ms B TIME/DIV to 1 μs

HORIZ DISPLAY to B DLY'D

b. Use 1 ms time marks.

c. CHECK-Jitter on the leading edge of the time marker does not exceed 0.2 division (0.5 division if operating the instrument on 50 Hz line voltage). Ignore the slow drift.

52. Check MIX Sweep Accuracy

a. Use 1 ms time marks.

b. Check for proper timing within 0.16 division \pm the A sweep error.

53. Adjust X Gain

a. A TIME/DIV to X-Y both VOLTS/DIV to 5 mV b. Apply 20 mV square wave from Standard Amplitude Calibrator to CH 1 or X input.

c. ADJUST-X Gain, R1215, for 4 divisions of deflection between the dots, within 4%.

54. Check X-Y Phasing and Bandwidth

a. VERT MODE to CH 2

b. Connect an 8 division display of 50 kHz signal from the Medium-Frequency Constant-Amplitude Signal Generator (Type 191) to the CH 1 and 2 inputs.

- c. Check X-Y phase shift is no more than 0.4 division.
- d. Check bandwidth is at least 4 MHz.

55. Check B Ends A Operation

56. Check A Trigger Holdoff

Increases holdoff by at least a factor of 10.

57. Check A and B Gates

- a. A Gate: 5.5 V, within 0.5 V.
- b. B Gate: 5.5 V, within 0.5 V.

58. Check EXT Z-AXIS Operation

a. Connect 5 V square wave to External Trigger Input and EXT Z-AXIS input.

b. Check for noticeable intensity modulation.

PART III - CALIBRATION

Introduction

The following procedure returns the 465 to correct calibration. All limits and tolerances given in this procedure are calibration guides and should not be interpreted as instrument specifications except as specified in the Specifications section of this manual. Where possible, instrument performance is checked before an adjustment is made. For best overall instrument performance when performing a complete calibration procedure, make each adjustment to the exact setting even if the CHECK- is within the allowable tolerance.

Index to Part III - Calibration

POWER SUPPLY CALIBRATION

1. Check Power Supply DC Levels and Ripple	Page 5-27	10 4.1
		18. Adju
2. Adjust High Voltage Supply	Page 5-27	19. Che
DISPLAY and Z-AXIS CALIBRATION		20. Adju
3. Adjust CRT Grid Bias	Page 5-28	
4. Check Display Controls	Page 5-28	21. Adju
5. Adjust Trace Alignment	Page 5-29	22. Che Volts/Divis
6. Adjust Y Axis Alignment	Page 5-29	23. Che
7. Adjust Geometry	Page 5-29	24. Che
8. Adjust Z-Axis Compensation	Page 5-29	25. Cheo
VERTICAL SYSTEM CALIBRATION		26. Ch
9. Adjust Vertical Output Amplifier Bias	Page 5-30	Operation
10. Adjust Vertical Output Centering and Check BEAM FIND	Page 5-30	27. Ad Frequency
11. Adjust Channel 1 Step Attenuator Balance	Page 5-31	28. Adju pensation
12. Adjust Channel 1 Variable Volts/ Division Balance	Page 5-31	29. Adju pensation

13. Check Probe Indicator Lights	Page 5-32
14. Check Channel 1 and 2 INPUT COUPLING Switches	Page 5-32
15. Adjust Channel 1 Position Centering	Page 5-32
16. Adjust Channel 2 Step Attenuator Balance	Page 5-32
17. Adjust Channel 2 Variable Volts/ Division Balance	Page 5-33
18. Adjust Channel 2 Position Range	Page 5-33
19. Check Channel 2 INVERT Balance	Page 5-33
20. Adjust Channel 1 Gain	Page 5-33
21. Adjust Channel 2 Gain	Page 5-34
22. Check Channel 1 and 2 Variable Volts/Division Range	Page 5-35
23. Check Vertical ADD Mode Operation	Page 5-35
24. Check Compression and Expansion	Page 5-35
25. Check Vertical ALT Mode Operation	Page 5-35
26. Check Vertical CHOP Mode Operation	Page 5-36
27. Adjust Vertical Output Low- Frequency Compensation	Page 5-36

28. Adjust Channel 1 VOLTS/DIV Com- Page 5-36 pensation

29. Adjust Channel 2 VOLTS/DIV Com- Page 5-37 pensation

30. Adjust Channel 2 and Vertical Output High-Frequency Compensation	Page 5-38	48. Check B External 25 Megahertz Trig- gering	Page 5-46
31. Check Channel 2 Position Effect	Page 5-39	49. Check A and B External 100 Mega- hertz Triggering	Page 5-47
32. Adjust Channel 1 High-Frequency Compensation	Page 5-39	50. Check B Internal 100 Megahertz Trig- gering	Page 5-47
33. Check Channel 1 Position Effect	Page 5-41	51. Check A Internal 100 Megahertz Trig-	Page 5-48
34. Check Vertical Amplifier Bandwidth	Page 5-41	gering	
35. Check Cascaded Gain and Bandwidth	Page 5-41	52. Check A and B HF REJ Triggering	Page 5-48
36. Check Vertical Channel Isolation	Page 5-42	53. Check B 60 Hertz and LF REJ Triggering	Page 5-49
37. Check Common Mode Rejection Ratio	Page 5-42	54. Check A 60 Hertz and LF REJ Triggering	Page 5-49
38. Check Bandwidth Limit Operation	Page 5-42	55. Check A LEVEL Control External Range	Page 5-50
TRIGGER SYSTEM CALIBRATION			
39. Adjust A Trigger Sensitivity	Page 5-43	56. Check B LEVEL Control External Range	Page 5-50
40. Adjust B Trigger Sensitivity	Page 5-44	57. Check Single Sweep Operation	Page 5-51
41. Adjust B Trigger Slope and Level Centering	Page 5-44	58. Check A Normal Mode Operation	Page 5-51
42. Adjust A Trigger Slope and Level Centering	Page 5-44	59. Check LINE Triggering	Page 5-51
	D 5 44	60. Check Automatic Recovery Time	Page 5-51
43. Adjust A Trigger DC Levels	Page 5-44	61 Adjust Trigger View Centering	Page 5-52
44. Check B Trigger DC Levels	Page 5-45	or. Aujust migger view centering	1 age 5-52
45. Check B Internal 25 Megahertz Trig- gering	Page 5-45	62. Check Trigger View Deflection Factor	Page 5-52
	Dego E 46	HORIZONTAL SYSTEM CALIBRATION	
40. Check A Internal 25 Meganertz Trig- gering	י aye ט-40	63. Adjust Sweep Start and A Sweep Calibration	Page 5-53
47. Check A External 25 Megahertz Trig- gering	Page 5-46	64. Check Differential Time Accuracy	Page 5-53

65. Adjust Horizontal Amplifier Gain	Page 5-54	82. Check B ENDS A Operation	Page 5-59
66. Check Sweep Linearity	Page 5-54	83. Check A TRIG HOLDOFF	Page 5-59
67. Adjust Magnifier Registration	Page 5-54	CALIBRATOR, GATES, & EXT Z-AXIS CALIBRATION	
68. Adjust B Sweep Calibration	Page 5-55	84. Adjust CALIBRATOR Output	Page 5-60
69. Check Sweep Length	Page 5-55	85. Check A and B + GATE	Page 5-60
70. Check VAR TIME/DIV Range	Page 5-55	86. Check EXT Z-AXIS Operation	Page 5-60
71. Check Horizontal POSITION Control Bange	Page 5-55	Preliminary Procedure for Calibration	
Trange		NOTE	
72. Adjust A TIME/DIV High Speed Timing	Page 5-55	This instrument should be adjusted at an temperature of $+25^{\circ}C$ (± $5^{\circ}C$) for best over racy.	ambient rall accu-
73. Adjust B TIME/DIV High Speed Timing	Page 5-56	1. Remove the dust cover from the 465 as outlined the Disassembly Instructions in the Maintenance section	
74. Check A and B TIME/DIV Accuracy	Page 5-56		
75. Adjust High Speed Magnified Timing	Page 5-56	2. Connect the autotransformer to a suitable pow source.	
76. Check A and B Magnified Timing Accuracy	Page 5-57	3. Connect the 465 to the autotransformer output.	
77. Check Delay Time Accuracy	Page 5-57	4. Set the autotransformer output voltage to the center of the voltage range selected by the Line Voltage Selecto	
78. Check Delay Time Jitter	Page 5-58	5. Set the controls as given under Prelimir Settings (given prior to Part I - Performance Cl at least 20 minutes warmup before proceeding.	nary Control heck). Allow
79. Check Mixed Sweep Accuracy	Page 5-58	NOTE	
80. Adjust X Gain	Page 5-58	Titles for external controls of this instru capitalized in this procedure (e.g., INTE	ment are ENSITY).
81. Check X-Y Phasing and Bandwidth	Page 5-58	criternal adjustments are initial capitalized of CRT Grid Bias).	oniy (e.g.,

POWER SUPPLY CALIBRATION

Equipment Required

- 1. Precision DC Voltmeter
- 2. DC Voltmeter
- 3. Test Oscilloscope

Control Settings

Preset instrument controls to the settings given under Preliminary Control Settings.

1. Check Power Supply DC Levels and Ripple

a. Connect the Precision DC Voltmeter between test point (TP) 1536 and GND (negative meter lead to ground) on the Interface board. See Fig. 5-2.

b. CHECK-Meter reading of +55 volts within 0.5% (\pm 27.5 mV).

c. ADJUST-+55 Volt Supply adjustment R1538 (see Fig. 5-2) for a meter reading of +55 volts within 0.1% (0.05 mV).

d. Using the precision DC Voltmeter, measure the DC level of the power supplies given in Table 5-5. Observe proper meter polarity. See Fig. 5-2 for test point locations.

e. Using the Test Oscilloscope, check for correct ripple as given in Table 5-5, while varying the autotransformer between 103.5 VAC to 126.5 VAC.

f. CHECK-For low line indicator to come on when the autotransformer is at 103 volts.



Fig. 5-2. Low-voltage power supply test points and adjustment locations.

- 4. Autotransformer
- 5. Three-inch Screwdriver
- g. Return the line voltage to 115 volts.

TABLE 5-5

Power Supply Tolerance and Ripple

Power Supply	Test Point	Tolerance	Typical Ripple (peak-to-peak)
+55 volt	TP1536	± 0.5%	4 mV
+15 volt	TP1548	± 1.5%	2 mV
+5 volt	TP1558	± 1.5%	2 mV
-8 volt	TP1568	± 1.5%	2 mV

2. Adjust High Voltage Supply

a. Connect the DC Voltmeter between -2450 volt test point and ground (positive meter lead to ground). -2450 test point is accessible through the hole in the high voltage cover. (See Fig. 5-3.)

b. CHECK-Meter for a reading of $-2450\ volts\ \pm\ 49\ volts.$

c. ADJUST-High Voltage adjustment R1400 (see Fig. 5-3) for a meter reading of -2450 volts (± 24.5 volts).



Fig. 5-3. High-voltage test point and adjustment locations.

DISPLAY & Z-AXIS CALIBRATION

Equipment Required	
1. DC Voltmeter	5. 50 Ω BNC Termination
2. Test Oscilloscope	6. X10 Probe
3. Time Mark Generator	7. Three-inch Screwdriver
4. 50 Ω BNC Cable	8. Low Capacitance Screwdriver

Control Settings

Preset instrument controls to the settings given under Preliminary Control Settings except as follows:

A TIME/DIV	X-Y
INTENSITY	Fully Counterclockwise
CH 1 INPUT COUPLING	GND

3. Adjust CRT Grid Bias

a. Connect the DC Voltmeter between TP1486 which is accessible through a hole in the high voltage cover, and ground. (Negative meter lead to ground.) See Fig. 5-4.

b. Set the INTENSITY control for the dimmest, well-defined dot on the CRT.

c. CHECK-Meter for a reading of +20 volts ± 4 volts.

d. ADJUST-INTENSITY control for a meter reading of +20 volts.

e. ADJUST-CRT Grid Bias adjustment, R1480, for the dimmest, well-defined dot visible on the CRT (see Fig. 5-4).

CRT Bias R1480 Warning CRT R1490 Warning CRT R1490 Warning CRT R1490 Warning CRT R1490 Warning CRT R1400 Warning

Fig. 5-4. Location of CRT Grid Bias adjustment and test point 1486.

f. Remove the DC Voltmeter connections.

g. Rotate ASTIG control (front panel screwdriver adjustment) through its range.

h. CHECK—For dot de-focus at both extremes of ASTIG control.

i. Reset the ASTIG control for a well-defined dot.

4. Check Display Controls

a. Rotate SCALE ILLUM control through its range.

b. CHECK-For a smooth increase in illumination.

c. Set TIME/DIV to 1 ms and INTENSITY control to midrange.

d. Rotate FOCUS control through its range.

e. CHECK-For trace de-focus at both extremes of FOCUS control.

f. Rotate INTENSITY control from fully counterclockwise to fully clockwise.

g. CHECK—For trace intensity to increase smoothly from minimum to maximum intensity.

h. Reset INTENSITY and FOCUS controls for a well-defined trace.

5. Adjust Trace Alignment

a. Position the trace to the center horizontal graticule line.

b. CHECK-That the trace is parallel with the center horizontal line.

c. ADJUST-TRACE ROTATION adjustment (front panel adjustment) to make the trace parallel to the center horizontal line.

6. Adjust Y Axis Alignment

a. Connect 0.1 ms time markers from the Time-Mark Generator to the CH 1 input connector via a 42-inch 50 Ω BNC cable and a 50 Ω BNC termination.

b. Set the CH 1 INPUT COUPLING switch to DC and the CH 1 VOLTS/DIV switch to 0.1 V.

c. Adjust the A LEVEL control for a stable display; ASTIG and FOCUS controls for a well-defined display.

d. Adjust the VAR TIME/DIV control for 1 time marker/division.

e. CHECK—For no more than 0.1 division of tilt of the center time marker as compared with the center vertical graticule line.

f. ADJUST-Y Axis Alignment adjustment, R1446, (see Fig. 5-5) to align the center time marker with the center vertical graticule line.

g. INTERACTION-Between Y Axis alignment and TRACE ROTATION adjustments. Readjust until there is no further interaction.



Fig. 5-5. Location of Geometry and Y Axis adjustments.

7. Adjust Geometry

a. CHECK-CRT display for no more than 0.1 division vertical curvature of the markers across the graticule area.

b. ADJUST-Geometry adjustment, R1442, (see Fig. 5-5) for minimum curvature of the markers across the graticule area.

c. Remove the test signal from CH 1 input.

d. CHECK-For no more than 0.1 division of curvature of the trace when positioned from top to bottom of the graticule area.

e. INTERACTION-Between Geometry and Y Axis Alignment adjustments. Adjust both for optimum response.

8. Adjust Z Axis Compensation

a. Set A TIME/DIV to 0.05 μ s.

b. Connect the X10 probe from the Test Oscilloscope to TP1486 (see Fig. 5-6).

c. Adjust the 465 INTENSITY control for a 15 volt display on the Test Oscilloscope.

d. CHECK—Test Oscilloscope display for optimum square corner on the unblanking gate.

e. ADJUST-Z-Axis Compensation adjustment, C1471, using low capacitance screwdriver, (see Fig. 5-6) for optimum square corner on the unblanking gate.

f. Disconnect the test setup.



Fig. 5-6. Location of Z-Axis compensation adjustment and test point 1486.
VERTICAL SYSTEM CALIBRATION

Equipment Required				
1. High-Frequency Constant-Amplitude Signal Gener- ator (067-0532-01)	8. 42-inch 50 Ω BNC Cables (two)			
0. Malian Francisco Oractori Accelitado Circado Ora	9. X10 Probes (two)			
2. Medium-Frequency Constant-Amplitude Signal Gen- erator (Type 191)	10. X10 BNC Attenuators (two)			
3. Fast-Rise High-Amplitude Pulse Generator (Type	11. X10 GR Attenuator			
4. Stee dead Arealizeda Calibratar (007.0500.01)	12. 20 pF Input RC Normalizer			
4. Standard Amplitude Calibrator (067-0502-01)	13. Low-Capacitance Screwdriver			
5. Test Oscilloscope	14. Three-Inch Screwdriver			
6. GR-to-BNC Adapter	15. DC Voltmeter			
7. 50 Ω BNC Termination	16. Square-Wave Generator (Type 106)			

d. INTERACTION—Affects vertical risetime, aberrations, and position effect. This adjustment may be slightly misadjusted for optimum performance of the vertical system.

e. Disconnect the test setup.

10. Adjust Vertical Output Centering and Check BEAM FIND

a. Connect the DC Voltmeter between TP322 and TP324 (see Fig. 5-8).



Fig. 5-8. Location of test points 322 and 324.

Control Settings

Preset instrument controls to the settings given under Preliminary Control Settings except as follows:

CH 1 VOLTS/DIV 0.2 V

9. Adjust Vertical Output Amplifier Bias

a. Connect the High-Frequency Constant-Amplitude Signal Generator (067-0532-01) output to the CH 1 input via a GR-to-BNC female adapter and a 50 Ω BNC termination.

b. Adjust the signal generator for a 100 MHz sinewave output.

c. ADJUST-Vertical Output Bias adjustment, R455, (see Fig. 5-7) for maximum deflection of signal.



Fig. 5-7. Location of Vertical Output Bias adjustment.

b. Adjust the CH 1 POSITION control for a 0 volt reading on the meter.

c. ADJUST-Vertical Output Centering adjustment, R429, (see Fig. 5-9) to position the trace to the center graticule line.

d. Remove the DC Voltmeter lead connections.

e. Position the trace off-screen with the CH 1 POSI-TION and horizontal POSITION controls.

f. Push the BEAM FIND button and hold it in.

g. CHECK-That the trace is brought into the CRT viewing area.

h. Release the BEAM FIND button.

11. Adjust CH 1 Step Attenuator Balance

a. Set the CH 1 VOLTS/DIV switch to 20 mV and the CH 1 INPUT COUPLING switch to GND.

b. Position the trace to the center horizontal graticule line.

c. CHECK-CRT display for 0.2 division or less of trace shift between adjacent switch positions when rotating the CH 1 VOLTS/DIV switch from 20 mV to 5 mV.



Fig. 5-9. Location of Vertical Output Centering adjustment.

d. ADJUST-CH 1 Step Atten Bal adjustment, R25, (see Fig. 5-10) for minimum trace shift when rotating the CH 1 VOLTS/DIV switch from 20 mV to 5 mV.

12. Adjust CH 1 Variable Volts/Division Balance

a. Position the trace to the center horizontal graticule line.

b. CHECK-That the CH 1 UNCAL light comes on when the VAR control is out of the detent position.

c. CHECK-CRT display for 1.0 division or less of trace shift when rotating the CH 1 VAR control through its range.

d. ADJUST-CH 1 Variable Balance adjustment, R120, (see Fig. 5-11) for minimum trace shift when rotating the CH 1 VAR control through its range.

e. Return the CH 1 VAR control to the detent position.



Fig. 5-10. Location of CH 1 Step Atten Bal adjustment.



Fig. 5-11. Location of CH 1 Variable Balance and Position Centering adjustment.

13. Check Probe Indicator Lights

a. Set both VOLTS/DIV switches to 5 mV.

b. Connect a X10 probe with a scale-factor switching connector to the CH 1 input connector.

c. CHECK-Light under 5 mV is extinguished and the light under 50 mV comes on.

d. Set VERT MODE switch to CH 2.

e. Move the probe to the CH 2 input.

f. CHECK—Light under 5 mV is extinguished and the light under 50 mV comes on.

g. Remove the X10 probe.

14. Check INPUT COUPLING Switches

a. Set both INPUT COUPLING switches to DC.

b. Connect the Standard Amplitude Calibrator output to the CH 2 input via a 42-inch 50 Ω BNC cable.

c. Adjust the Standard Amplitude Calibrator for 20 mV output.

d. Position the bottom of the display to the center horizontal graticule line.

e. Set CH 2 INPUT COUPLING switch to GND.

f. CHECK-For no vertical deflection; trace is at center horizontal graticule line.

g. Set CH 2 INPUT COUPLING switch to AC.

h. CHECK-That display is centered about the center horizontal graticule line.

i. Move the test signal to CH 1.

j. Position the bottom of the display to the center horizontal graticule line.

k. Set CH 1 INPUT COUPLING switch to GND.

I. Repeat step 14-f.

m. Set CH 1 INPUT COUPLING switch to AC.

n. Repeat step 14-h.

15. Adjust CH 1 Position Centering

a. Set the CH 1 VOLTS/DIV switch to 20 mV.

b. Adjust the Standard Amplitude Calibrator for 500 mV output.

c. CHECK-That the top of the CRT display can be positioned down to 1/2-division above the center horizontal graticule line, and the bottom of the display can be positioned up to 1/2-division below the center horizontal graticule line.

d. ADJUST-CH 1 Position Centering adjustment, R115, (see Fig. 5-11) so that the top of the CRT display can be positioned down to 1/2-division above the center horizontal graticule line, and the bottom of the display can be positioned up to 1/2-division below the center horizontal graticule line.

e. INTERACTION-Between CH 1 Position Centering and CH 1 Variable Volts/Division Balance adjustments. Re-adjust both until no interaction is visible.

16. Adjust CH 2 Step Attenuator Balance

a. Set the VERT MODE switch to CH 2; CH 2 VOLTS/DIV switch to 20 mV.

b. Position the trace to the center horizontal graticule line.

c. CHECK-CRT display for 0.2 division or less of trace shift between adjacent switch positions when rotating the CH 2 VOLTS/DIV switch from 20 mV to 5 mV.

d. ADJUST-CH 2 Step Atten Bal adjustment, R75, (see Fig. 5-12) for minimum trace shift when rotating the CH 2 VOLTS/DIV switch from 20 mV to 5 mV.

17. Adjust CH 2 Variable Volts/Division Balance

a. CHECK-That the CH 2 UNCAL light comes on when the CH 2 VAR control is out of the detent position.

b. CHECK-CRT display for 1.0 division or less of trace shift when rotating the CH 2 VAR control through its range.

c. ADJUST-CH 2 Variable Balance adjustment, R220, (see Fig. 5-13) for minimum trace shift when rotating the CH 2 VAR control through its range.

d. Return the VAR control to the detent position.

18. Adjust CH 2 Position Centering

a. Move the test signal from CH 1 to the CH 2 input.

b. Set the CH 2 VOLTS/DIV switch to 20 mV; and the VERT MODE switch to CH 2.



Fig. 5-12. Location of CH 2 Step Atten Bal adjustment.



Fig. 5-13. Location of CH 2 Variable Balance and Position Centering adjustments.

c. Adjust the Standard Amplitude Calibrator for a 500 mV output.

d. CHECK-That the top of the CRT display can be positioned down to 1/2-division above the center horizontal graticule line, and the bottom of the display can be positioned up to 1/2-division below the center horizontal graticule line.

e. ADJUST-CH 2 Position Centering adjustment, R215, (see Fig. 5-13) so that the top of the CRT display can be positioned down to 1/2-division above the center horizontal graticule line, and the bottom of the display can be positioned up to 1/2-division below the center horizontal graticule line.

f. INTERACTION-Between CH 2 Position Centering and CH 2 Variable Volts/Division Balance adjustments. Re-adjust both until no interaction is visible.

19. Check CH 2 INVERT Balance

a. Set the CH 2 INPUT COUPLING switch to GND.

b. Position the trace to the center horizontal graticule line.

c. Push the INVERT button.

d. CHECK-For less than 2 division of trace shift when switching from normal to inverted.

20. Adjust CH 1 Gain

a. Set the VERT MODE switch to CH 1, the CH 1 VOLTS/DIV switch to 5 mV, and the CH 1 INPUT COUPLING switch to DC.

b. Move the test signal to the CH 1 input.

c. Adjust the Standard Amplitude Calibrator for a 20 mV output.

d. Set the Test Oscilloscope: Vertical Mode to ADD, Channel 2 to INVERT, and both VOLTS/DIV switches to 5 mV.

e. Connect two X10 probes from the Test Oscilloscope to TP322 and TP324 on the Preamp board of the 465 (see Fig. 5-8).

f. CHECK—The Test Oscilloscope for a 200 mV (peakto-peak) signal between TP322 and TP324.

g. ADJUST-CH 1 Gain adjustment, R118, (see Fig. 5-14) for 200 mV (peak-to-peak) display on the Test Oscilloscope. (NOTE: This is a nominal value for this adjustment and may vary from instrument to instrument.

h. Remove the X10 probes from TP322 and TP324.

i. CHECK–CRT display for 4 divisions of deflection within 3% (0.12 div).

j. ADJUST-Vertical Output Gain adjustment, R400, (see Fig. 5-15) for 4 divisions of deflection.

k. CHECK-Accuracy of CH 1 VOLTS/DIV switch using the settings given in Table 5-6 to see if the deflection factor accuracy for each position is within 3%.



Fig. 5-14. Location of CH 1 Gain adjustment.



Fig. 5-15. Location of Vertical Output Gain adjustment.

21. Adjust CH 2 Gain

a. Set the CH 2 VOLTS/DIV switch to 5 mV, the VERT MODE switch to CH 2, and the CH 2 INPUT COUPLING switch to DC.

b. Move the test signal to CH 2 input connector.

c. Adjust the Standard Amplitude Calibrator for a 20 mV output.

d. CHECK-CRT display for 4 divisions of deflection within 3%.

e. ADJUST-CH 2 Gain adjustment R218 (see Fig. 5-16) for 4 divisions of deflection.

f. CHECK—Accuracy of the CH 2 VOLTS/DIV switch using the settings given in Table 5-6. Deflection factor accuracy to be within 3% in all switch positions.

TABLE 5	-6
---------	----

Vertical Deflection Accuracy

VOLTS/DIV Switch Setting	Standard Amplitude Calibrator Output	Vertical Deflection in Divisions	Maximum Error for 3% Accuracy
5 m	20 millivolts	4	Previously set
10 m	50 millivolts	5	±0.15 division
20 m	0.1 volt	5	±0.15 division
50 m	0.2 volt	4	±0.12 division
.1	0.5 volt	5	±0.15 division
.2	1 volt	5	±0.15 division
.5	2 volts	4	±0.12 division
1	5 volts	5	±0.15 division
2	10 volts	5	±0.15 division
5	20 volts	4	±0.12 division



Fig. 5-16. Location of CH 2 Gain adjustment.

22. Check CH 2 and CH 1 Variable Volts/Division Ranges

a. Adjust the Standard Amplitude Calibrator for 5 divisions of deflection.

- b. Rotate the CH 2 VAR control fully counterclockwise.
- c. CHECK-CRT display reduces to less than 2 divisions.
- d. Move the test signal to the CH 1 input connector.
- e. Set the VERT MODE switch to CH 1.

f. Adjust the Standard Amplitude Calibrator for 5 divisions of deflection.

g. Rotate the CH 1 VAR control fully counterclockwise.

- h. CHECK-CRT display reduces to less than 2 divisions.
- i. Return the VAR controls to the detent positions.

23. Check Vertical ADD Mode Operation

a. Set both VOLTS/DIV switches to 5 mV and both INPUT COUPLING switches to DC.

b. Connect the Standard Amplitude Calibrator output to both channel inputs via a dual input coupler.

c. Adjust the Standard Amplitude Calibrator for a 10 mV output.

d. Set the VERT MODE switch to ADD.

e. CHECK-If CH 1 and CH 2 Gain adjustments were changed, check for 4 divisions of deflection within 1% (within 3% if CH 1 and CH 2 Gain adjustments were not changed).

24. Check Compression and Expansion

a. Set the CH 2 INPUT COUPLING switch to GND and the VERT MODE switch to CH 1.

b. Adjust the CH 1 VAR control for 2 divisions of deflection centered about the center horizontal graticule line.

c. Position the top of the display to the top graticule line.

d. CHECK-CRT display for 0.1 division or less of compression or expansion.

e. Position the bottom of the display to the bottom graticule line.

f. CHECK-CRT display for 0.1 division or less of compression or expansion.

g. Set the CH 1 VAR control to the detent position.

h. Disconnect the test setup.

25. Check Vertical ALT Mode Operation

a. Set the VERT MODE switch to ALT, and the A Trigger LEVEL control fully clockwise.

b. Position the two traces 2 divisions apart.

c. CHECK—That the sweeps alternate at all settings of the A TIME/DIV switch except X-Y.

26. Check Vertical CHOP Mode Operation

a. Set the A TIME/DIV switch to 1 μs , the A SOURCE switch to NORM, the A SLOPE switch to +, the VERT MODE switch to CHOP, and both INPUT COUPLING switches to GND.

b. Position the two traces about 4 divisions apart.

c. Adjust the A LEVEL control for a stable display.

d. CHECK-For complete blanking of switching transients between chopped segments (see Fig. 5-17).

e. CHECK-Duration of each cycle is about four divisions.

27. Adjust Vertical Output Low-Frequency Compensation

a. Set the A TIME/DIV switch to 0.2 ms, the VERT MODE switch to CH 1, both INPUT COUPLING switches to DC, and both VOLTS/DIV switches to 5 mV.

b. Connect the fast-rise output of the Square-Wave Generator (Type 106) to the CH 1 input via a GR-to-BNC adapter, 42-inch 50 Ω BNC cable, X10 BNC attenuator, and a 50 Ω BNC termination.

c. Adjust the Square-Wave Generator to maintain a five division display throughout this step.

d. Adjust the Square-Wave Generator for a 1 kHz signal output.





e. Adjust the A LEVEL control for a stable display.

f. CHECK-CRT display for flat-top waveform with no more than 3% overshoot or roll-off on the leading edge.

g. ADJUST-R424 (see Fig. 5-18) for best flat-top waveform.

h. Set the A TIME/DIV switch to 20 μs and adjust the Square-Wave Generator for a 10 kHz signal output.

i. CHECK-CRT display for flat-top waveform with no more than 3% overshoot or roll-off on the leading edge.

j. ADJUST-R434 (see Fig. 5-18) for best flat-top waveform.

k. Set the A TIME/DIV switch to $2 \mu s$ and adjust the Square-Wave Generator for a 100 kHz signal output.

I. CHECK-CRT display for flat-top waveform with no more than 3% overshoot or roll-off on the leading edge.

m. ADJUST-R433 (see Fig. 5-18) for best flat-top waveform.

n. INTERACTION-Between all adjustments in this step. Re-adjust, if necessary, for total optimum response.

28. Adjust CH 1 VOLTS/DIV Compensation

a. Add a 20 pf Normalizer to the test setup between the 50 Ω BNC termination and the CH 1 input.



Fig. 5-18. Location of Vertical Output Low-Frequency Compensation adjustments.

b. Move the test setup from the fast-rise output to the high-amplitude output of the Square-Wave Generator (Type 106) and adjust the generator for a one-kilohertz output signal.

c. Adjust the Square-Wave Generator for a five division display. Add or remove attenuators as necessary to maintain a five division display throughout this step.

d. CHECK-CRT display for flat-top waveform with no more than 2% overshoot or roll-off on the leading edge.

e. ADJUST-C1 (see Fig. 5-19) with the low-capacitance screwdriver for best flat-top waveform.

f. Set the CH 1 VOLTS/DIV switch to 50 mV.

g. CHECK-CRT display for flat-top waveform with no more than 2% overshoot or roll-off on the leading edge.

h. ADJUST-Channel 1 C13 (see Fig. 5-19) for best flattop waveform, and Channel 1 C12 for the best corner with the low-capacitance screwdriver.

i. CAL AID-Remove the 20 pf Normalizer when adjusting or checking the corner response.

j. INTERACTION-Between Channel 1's C13 and C12. Readjust both for total optimum response.

k. Set the CH 1 VOLTS/DIV switch to 0.5 V.

I. CHECK-CRT display for flat-top waveform with no more than 2% overshoot or roll-off on the leading edge.

m. ADJUST-Channel 1 C11 (see Fig. 5-19) for best flat-top waveform, and Channel 1 C10 for the best corner, with the low-capacitance screwdriver.

n. Set the CH 1 VOLTS/DIV switch to 5 V.

o. CHECK-CRT display for flat-top waveform with no more than 2% overshoot or roll-off on the leading edge.

29. Adjust CH 2 VOLTS/DIV Compensation

a. Set the VERT MODE switch to CH 2 and move the test signal to the CH 2 input.

b. Adjust the Square-Wave Generator (Type 106) for a five-division display. Remove or add attenuators as necessary to maintain a five-division display.

c. CHECK-CRT display for flat-top waveform with no more than 2% overshoot or roll-off on the leading edge.

d. ADJUST-C51 (see Fig. 5-20) with the low-capacitance screwdriver, for best flat-top waveform.

e. Set the CH 2 VOLTS/DIV switch to 50 mV.



Fig. 5-19. Location of CH 1 volts/div compensation adjustments.



Fig. 5-20. Location of CH 2 volts/div compensation adjustments.

f. CHECK--CRT display for flat-top waveform with no more than 2% overshoot or roll-off on the leading edge.

g. ADJUST-Channel 2 C13 (see Fig. 5-20) for best flat-top waveform, and Channel 2 C12 for the best corner, with the low-capacitance screwdriver.

h. CAL AID-Remove the 20 pf Normalizer when adjusting or checking the corner response.

i. INTERACTION-Between Channel 2's C13 and C12. Readjust both for total optimum response.

j. Set the CH 2 VOLTS/DIV switch to 0.5 V.

k. CHECK-CRT display for flat-top waveform with no more than 2% overshoot or roll-off on the leading edge.

I. ADJUST-Channel 2 C11 (see Fig. 5-20) for best flat-top waveform, and Channel 2 C10 for the best corner, with the low-capacitance screwdriver.

m. INTERACTION-Between Channel 2's C11 and C10. Readjust both for optimum response.

n. Set the CH 2 VOLTS/DIV switch to 5 V.

o. CHECK-CRT display for flat-top waveform with no more than 2% overshoot or roll-off on the leading edge.

p. Disconnect the test setup.

30. Adjust Channel 2 and Vertical Output High-Frequency Compensation

a. Set both VOLTS/DIV switches to 5 mV, the VERT MODE switch to CH 2, the A TIME/DIV switch to 0.05 μs , and the A SLOPE to +.

b. Connect the Fast-Rise High-Amplitude Pulse Generator (Type 109) to the CH 2 input via a GR-to-BNC adapter, 42-inch 50 Ω BNC cable, two X10 BNC attenuators, and a 50 Ω BNC termination.

c. Set the Pulse Generator polarity to + and the voltage range to 50 V.

d. Adjust the Pulse Generator for five divisions of deflection. Remove or add attenuators as necessary to maintain a five division display throughout this step.

e. CHECK-CRT display for risetime of 3.5 nanoseconds or less.

f. CHECK-CRT display for flat-top waveform with 3% or less of aberrations.

g. ADJUST-C77, C83, C205, R205, C249, R249, C402, C442, R442, and C443 (see Fig. 5-21 and 5-22) with a low-capacitance screwdriver, for the best flat-top wave-form.

h. Set the Pulse Generator polarity to - and the 465 A SLOPE switch to -.

i. CHECK-CRT display for flat-bottom waveform with 5% or less of aberrations.



Fig. 5-21. Location of part of the CH 2 High-Frequency Compensation adjustments.



Fig. 5-22. Location of Vertical Output High-Frequency Compensation adjustments.

j. CAL AID-The above adjustments also affect the negative-step aberrations. Adjust for optimum response and minimum aberrations on both the positive- and negative-going steps.

k. Set the A SLOPE control to + and the Pulse Generator polarity to +.

I. Set the CH 2 VOLTS/DIV switch to 10 mV.

m. CHECK-CRT display for risetime of 3.5 nanoseconds or less.

n. CHECK-CRT display for flat-top waveform with 3% or less of aberrations.

o. ADJUST-R97 and C97 (see Fig. 5-21) for optimum risetime and aberrations.

p. Set the Pulse Generator polarity to - and the 465 A SLOPE switch to -.

q. CHECK-CRT display for best corner and flatbottom waveform with 5% or less aberrations.

r. Set the CH 2 VOLTS/DIV switch to 20 mV and the A SLOPE switch to +.

s. Set the Pulse Generator polarity to +.

t. CHECK-CRT display for risetime of 3.5 nanoseconds or less.

u. CHECK-CRT display for flat-top waveform with 3% or less of aberrations.

v. ADJUST-R98 and C98 (see Fig. 5-21) for optimum risetime and aberrations.

w. Set the Pulse Generator polarity to - and the 465 A SLOPE switch to -.

x. CHECK-CRT display for flat-bottom waveform with 5% or less of aberrations.

y. Set the CH 2 VOLTS/DIV switch to 50 mV.

z. Set the A SLOPE switch to + and the Pulse Generator polarity to +.

aa. CHECK-CRT display for risetime of 3.5 nano-seconds or less.

ab. CHECK-CRT display for flat-top waveform with 3% or less of aberrations.

ac. Set the Pulse Generator polarity to - and the 465 A SLOPE switch to $-\!\!\!$.

ad. CHECK-CRT display for best corner and flatbottom waveform with 5% or less aberrations.

ae. Repeat step 30-z through 30-ad for each setting of the CH 2 VOLTS/DIV switch from 0.1 V to 5 V.

31. Check CH 2 Position Effect

a. Set the CH 2 VOLTS/DIV switch to 5 mV.

b. Adjust the Pulse Generator (Type 109) for five divisions of display.

c. Adjust the A LEVEL control for a stable display.

d. Position the top of the display to the bottom graticule line.

e. CHECK-CRT display for less than 5% aberrations.

f. Set the Pulse Generator polarity to - and the 465 A SLOPE switch to $-\!\!.$

g. Position the bottom of the display to the top graticule line.

h. CHECK-CRT display for less than 7% aberrations.

32. Adjust CH 1 High-Frequency Compensation

a. Move the test signal from CH 2 to the CH 1 input.

b. Set the A TIME/DIV switch to 0.05 μ s, the A SLOPE switch to +, and the VERT MODE switch to CH 1.

c. Set the Fast-Rise High-Amplitude Pulse Generator (Type 109) to + and adjust the Pulse Generator for five divisions of deflection. Remove or add attenuators as necessary to maintain a five-division display throughout this step.

d. CHECK-CRT display for risetime of 3.5 nano-seconds or less.

e. CHECK-CRT display for flat-top waveform with 3% or less of aberrations.

f. ADJUST-C27, C33, C105, R105, C122, R122, C149, and R149 (see Fig. 5-23) with a low-capacitance screwdriver, for the best flat-top waveform.

g. Set the Pulse Generator polarity to - and the 465 A SLOPE switch to $-\!\!\!$.

h. CHECK-CRT display for flat-bottom waveform with 5% or less of aberrations.

i. CAL AID-The above adjustments also affect the negative-step aberrations. Adjust them for optimum response and minimum aberrations on both the positive- and negative-going steps.

j. Set the A SLOPE control to + and the Pulse Generator polarity to +.

k. Set the CH 1 VOLTS/DIV switch to 10 mV.

I. CHECK-CRT display for risetime of 3.5 nanoseconds or less.



Fig. 5-23. Location of CH 1 High-Frequency Compensation adjustment.

m. CHECK-CRT display for flat-top waveform with 3% or less of aberrations.

n. ADJUST-R47 and C47 (see Fig. 5-23) for optimum risetime and aberrations.

o. Set the Pulse Generator polarity to - and the 465 A SLOPE switch to $-\!\!\!$.

p. CHECK-CRT display for best corner and flatbottom waveform with 5% or less aberrations.

q. Set the CH 1 VOLTS/DIV switch to 20 mV and the A SLOPE switch to +.

r. Set the Pulse Generator polarity to +.

s. CHECK-CRT display for risetime of 3.5 nanoseconds or less.

t. CHECK-CRT display for flat-top waveform with 3% or less of aberrations.

u. ADJUST-R48, and C48 (see Fig. 5-23) for optimum risetime and aberrations.

v. Set the Pulse Generator polarity to - and the 465 A SLOPE switch to -.

w. CHECK-CRT display for flat-bottom waveform with 5% or less of aberrations.

x. Set the CH 1 VOLTS/DIV switch to 50 mV.

y. Set the A SLOPE switch to + and the Pulse Generator polarity to +.

z. CHECK-CRT display for risetime of 3.5 nano-seconds or less.

aa. CHECK-CRT display for flat-top waveform with 3% or less of aberrations.

ab. Set the Pulse Generator polarity to - and the 465 A SLOPE switch to -.

ac. CHECK-CRT display for best corner and flatbottom waveform with 5% or less aberrations.

ad. Repeat step 32-y through 32-ac for each setting of the CH 1 VOLTS/DIV switch from 0.1 V to 5 V.

33. Check CH 1 Position Effect

a. Set the CH 1 VOLTS/DIV switch to 5 mV.

b. Adjust the Pulse Generator (Type 109) for five divisions of display.

c. Adjust the A LEVEL control for a stable display.

d. Position the top of the display to the bottom graticule line.

e. CHECK-CRT display for less than 5% aberrations.

f. Set the Pulse Generator polarity to - and the 465 A SLOPE switch to -.

g. Position the bottom of the display to the top graticule line.

h. CHECK-CRT display for less than 7% aberrations.

i. Disconnect the test setup.

34. Check Vertical Amplifier Bandwidth

a. Connect the output of the High-Frequency Constant-Amplitude Signal Generator (067-0532-01) to the CH 1 input via a GR-to-BNC adapter, X10 BNC attenuator, and a 50 Ω BNC termination.

b. Set the TRIG MODE switch to AUTO, A TIME/DIV switch to 0.2 ms, both VOLTS/DIV switches to 5 mV and the VERT MODE switch to CH 1.

c. Adjust the High-Frequency signal generator output amplitude for a five division display of a 3 megahertz reference signal. d. Without changing the output amplitude, increase the output frequency of the signal generator until the display is reduced to 3.5 divisions.

e. CHECK-Output frequency of the signal generator must be at least 100 megahertz (0° C to +40°C).

f. Repeat this bandwidth check procedure, steps 34-c through 34-e, for settings of the CH 1 VOLTS/DIV switch from 10 mV to 2 V.

g. Move the test signal to CH 2 input, set the VERT MODE switch to CH 2, and the CH 2 INPUT COUPLING switch to DC.

h. Repeat this bandwidth check, step 34-c through 34-e, for settings of the CH 2 VOLTS/DIV switch from 5 mV to 2 V.

i. Disconnect the test setup.

35. Check Cascaded Gain and Bandwidth

a. Set both INPUT COUPLING switches to DC, the VERT MODE switch to CH 2, both VOLTS/DIV switches to 5 mV, and the A TIME/DIV switch to 1 ms.

b. Connect the CH 1 VERT SIGNAL OUT (on the rear panel) to the CH 2 input connector via a 42-inch 50 Ω BNC cable and a 50 Ω BNC termination.

c. Connect the Standard Amplitude Calibrator to the CH 1 input via a 42-inch 50 Ω BNC cable.

d. Adjust the Standard Amplitude Calibrator for a 5 mV output.

e. CHECK-CRT display for at least five divisions of deflection.

f. Remove the test setup from the CH 1 input.

g. Connect the output of the Medium-Frequency Constant-Amplitude Signal Generator (Type 191) to the CH 1 input via a GR-to-BNC adapter, 42-inch 50 Ω BNC cable, X10 BNC attenuator, and a 50 Ω BNC termination.

h. Adjust the Medium-Frequency signal generator for a five-division display of a 50 kilohertz reference signal.

i. Without changing the output amplitude of the signal generator, increase the output frequency until the display is reduced to 3.5 divisions.

j. CHECK-Output frequency of the signal generator must be at least 50 megahertz.

k. Disconnect the test setup.

36. Check Vertical Channel Isolation

a. Move the test signal to the CH 2 input after removing the X10 attenuator.

b. Set CH 2 VOLTS/DIV switch to 0.2 V, CH 1 INPUT COUPLING switch to GND, and VERT MODE switch to CH 2.

c. Adjust the Medium-Frequency signal generator for a 2 division display of a 25 megahertz signal.

d. Set both VOLTS/DIV switches to 20 mV and VERT MODE switch to CH 1.

e. CHECK-CRT display for no more than 0.2 division of deflection.

f. Move the CH 2 input test setup to the CH 1 input.

g. Set the CH 1 INPUT COUPLING switch to DC, CH 2 INPUT COUPLING switch to GND, CH 1 VOLTS/DIV switch to 0.2 V.

h. Adjust the Medium-Frequency signal generator for a 2 division display of a 25 megahertz signal.

i. Set VERT MODE switch to CH 2.

j. CHECK-CRT display for no more than 0.2 division of deflection.

k. Disconnect the test setup.

37. Check Common-Mode Rejection Ratio

a. Set both VOLTS/DIV switches to 5 mV, both INPUT COUPLING switches to DC, the VERT MODE switch to CH 1, and push the CH 2 INVERT switch.

b. Connect the output of the Medium-Frequency Constant-Amplitude Signal Generator (Type 191) to the CH 1 and CH 2 inputs via a GR-to-BNC adapter, 42-inch 50 Ω BNC cable, X10 BNC attenuator, 50 Ω BNC termination, and a dual-input coupler.

c. Adjust the Medium-Frequency Signal Generator for a six-division display of the 50-kilohertz reference signal.

d. Set the VERT MODE switch to ADD and adjust the CH 2 Gain adjust for minimum deflection (best CMRR).

e. Without increasing the output signal amplitude, increase the Type 191 output signal frequency to 20 MHz.

f. CHECK-CRT display for no more than 0.6 division of signal amplitude (indicates CMRR of at least 10:1 at 20 MHz).

g. Release the CH 2 INVERT switch and disconnect the test setup.

38. Check Bandwidth Limit Operation

a. Pull the 20 MHz BW/TRIG VIEW button to BW and set the CH 1 INPUT COUPLING switch to DC.

b. Connect the Medium-Frequency Constant-Amplitude Signal Generator (Type 191) to the CH 1 input via a 42-inch 50 Ω BNC cable and a 50 Ω BNC termination.

c. Adjust the Medium-Frequency signal generator for a six-division display of a 50 kilohertz signal.

d. Increase the output frequency of the signal generator until the display is reduced to 4.2 divisions.

e. CHECK-Output frequency of the signal generator is between 16 and 24 megahertz.

f. Disconnect the test setup.

TRIGGER SYSTEM CALIBRATION

Equipment Required

8. GR-to-BNC Female Adapter

9. X10 BNC Attenuator

10. 50 Ω BNC Termination

11. Dual-Input Coupler (two)

13. 18-inch 50 Ω BNC Cable (two)

12. BNC-T Connector

14. X2 BNC Attenuator

15. 50 Ω 5 ns GR Cable

1. Medium-Frequency Constant-Amplitude Signal Generator (Type 191)

2. Low-Frequency Sine-Wave Generator (General Radio 1310-A)

3. Time-Mark Generator (Type 2901)

4. Standard Amplitude Calibrator

5. 50 Ω Signal Pickoff Unit (Type CT-3)

6. X10 Probe

7. 42-Inch 50 Ω BNC Cable

Control Settings

Preset instrument controls to the settings given under Preliminary Control Settings except as follows:

CH 1 VOLTS/DIV	10 mV
both TIME/DIV	0.05 μs
A TRIGGER	
SOURCE	EXT
COUPLING	AC
SLOPE	+

39. Adjust A Trigger Sensitivity

a. Connect the output of the Medium-Frequency Constant-Amplitude Signal Generator (Type 191) to the A and B External Trigger Inputs via a 50 Ω 5 ns GR cable, 50 Ω Signal Pickoff Unit (Type CT-3) thru output, GR-to-BNC adapter, X10 BNC attenuator, a 50 Ω BNC termination, and a dual input coupler.

b. Connect the 10% BNC output connector of the Signal Pickoff Unit (Type CT-3) to the CH 1 and CH 2 inputs via a 50 Ω BNC termination, and a dual input coupler.

c. Adjust the Medium-Frequency signal generator output for a 3-division display of a 25 megahertz signal.

d. Set the CH 1 VOLTS/DIV switch to 0.1 V.

e. CHECK-That a stable display can just be obtained by rotating the A LEVEL control.

f. Adjust the Medium-Frequency signal generator to reduce the CRT display to 0.25 division.

g. ADJUST-A Trigger Sensitivity adjustment, R655, (see Fig. 5-24) so that a stable display can just be obtained by rotating the A LEVEL control.



Fig. 5-24. Location of A Trigger Sensitivity adjustment.

40. Adjust B Trigger Sensitivity

a. Set the HORIZ DISPLAY switch to B DLY'D, the B COUPLING switch to AC, the B SOURCE switch to EXT, and the B SLOPE to +.

b. Adjust the Medium-Frequency signal generator for a 0.3 division display.

c. CHECK-That a stable display can just be obtained by rotating the B LEVEL control.

d. Adjust the Medium-Frequency signal generator to reduce the CRT display to 0.25 division.

e. ADJUST-B Trigger Sensitivity adjustment, R555, (see Fig. 5-25) so that a stable display can just be obtained by rotating the B LEVEL control.

41. Adjust B Trigger Slope and Level Centering

a. Set both TIME/DIV switches to $10 \,\mu s$, both LEVEL controls to 0, and the CH 1 VOLTS/DIV switch to 10 mV.

b. Adjust the Medium-Frequency signal generator for a 0.3 division display of a 50 kilohertz signal.

c. Vertically center the display about the center vertical graticule line.



Fig. 5-25. Location of B Trigger Sensitivity, Slope Center, and Level Center adjustments.

d. CHECK-CRT display begins at the same vertical point of the signal in both the + and - slope.

e. ADJUST-B Trigger Level Centering adjustment, R535, (see Fig. 5-25) for the trigger point of the display to be at the graticule center, and adjust the B Trigger Slope Centering adjustment, R545, (see Fig. 5-25) so that the trace begins at the graticule center in both the + and - slope.

42. Adjust A Trigger Slope and Level Centering

a. Set the HORIZ DISPLAY switch to A and the A LEVEL control to 0.

b. CHECK-CRT display begins at the same vertical point of the signal in both the + and - slope.

c. ADJUST-A Trigger Level Centering adjustment, R635, (see Fig. 5-26) for the trigger point of the display to be at the graticule center, and adjust the B Trigger Slope Centering adjustment, R645 (see Fig. 5-26) so that the trace begins at the graticule center in both the + and - slope.

43. Adjust A Trigger DC Levels

a. Set the A COUPLING switch to DC, the A SOURCE switch to NORM, and the A LEVEL control to 0.

b. Adjust the Medium-Frequency signal generator for a 0.3 division display.



Fig. 5-26. Location of A Trigger Slope Center and Level Center adjustments.

c. Position the display to the vertical center of the graticule viewing area.

d. CHECK-That a stable display can be obtained on both the + and - slopes of the displayed waveform by rotating the A SLOPE control.

e. ADJUST-Normal Trigger DC Balance adjustment, R340, (see Fig. 5-27) to obtain a stable display on both the + and - slopes of the displayed waveform.

f. Set the A SOURCE switch to CH 1.

g. CHECK-For a stable display on both the + and - slopes of the displayed waveform.

h. ADJUST-CH 1 Trigger DC Balance adjustment, R155, (see Fig. 5-27) to obtain a stable display on both the + and - slopes of the displayed waveform.

i. Set the VERT MODE switch to CH 2.

j. Adjust the CH 2 VOLTS/DIV switch to obtain a 0.3 division display.

k. Position the display to the vertical center of the graticule viewing area.

I. Set the A SOURCE switch to CH 2.



Fig. 5-27. Location of Trigger DC Level adjustments.

m. CHECK-For a stable display on both the + and - slopes of the displayed waveform.

n. ADJUST-CH 2 Trigger DC Balance adjustment, R255, (see Fig. 5-27) to obtain a stable display on both the + and - slopes of the displayed waveform.

44. Check B Trigger DC Levels

a. Set the HORIZ DISPLAY switch to B DLY'D, the B LEVEL control to 0, the B SOURCE switch to NORM, and the B COUPLING switch to DC.

b. CHECK-That a stable display can be obtained on both the + and - slopes of the displayed waveform in the NORM and CH 2 positions of the B SOURCE switch.

c. Set the VERT MODE switch to CH 1.

d. Adjust the CH 1 VOLTS/DIV switch to obtain a 0.3 division display.

e. Position the display to the vertical center of the graticule viewing area.

f. CHECK—That a stable display can be obtained on both the + and — slopes of the displayed waveform in the NORM and CH 1 positions of the B SOURCE switch.

45. Check B Internal 25 Megahertz Triggering

a. Set the DELAY TIME POSITION dial fully counterclockwise, both TIME/DIV switches to $0.05\,\mu$ s, both VOLTS/DIV switches to 10 mV, and both SOURCE switches to NORM.

b. Adjust the Medium-Frequency signal generator to maintain a 0.3 division display of a 25 megahertz signal throughout this step.

c. Rotate the B SLOPE switch between + and -.

d. CHECK-A stable display can be obtained on both the + and - slopes of the displayed waveform in the AC, LF REJ, and DC positions of the B COUPLING switch (adjust the B LEVEL control).

e. Set the B SOURCE switch to CH 1.

f. Repeat steps 45-c and 45-d.

g. Set the VERT MODE switch to CH 2.

h. CHECK-That a stable display cannot be obtained with the B SOURCE switch set to CH 1.

i. Repeat steps 45-c and 45-d for NORM and CH 2 positions of the B SOURCE switch.

46. Check A Internal 25 Megahertz Triggering

a. Set the HORIZ DISPLAY switch to A.

b. Adjust the Medium-Frequency signal generator to maintain a 0.3 division display of a 25 megahertz signal throughout this step.

c. Rotate the A SLOPE switch between + and -.

d. CHECK-A stable display can be obtained on both the + and - slopes of the displayed waveform in the AC, LF REJ, and DC positions of the A COUPLING switch (adjust the A LEVEL control).

e. Set the A SOURCE switch to CH 1.

- f. Repeat steps 46-c and 46-d.
- g. Set the VERT MODE switch to CH 1.

h. CHECK-That a stable display cannot be obtained with the A SOURCE switch set to CH 2.

i. Repeat steps 46-c and 46-d for NORM and CH 1 positions of the A SOURCE switch.

47. Check A External 25 Megahertz Triggering

a. Set the HORIZ DISPLAY switch to A, the A SOURCE switch to EXT, the B SOURCE switch to NORM, and the CH 1 VOLTS/DIV switch to 20 mV.

b. Adjust the Medium-Frequency signal generator for a 5 division display.

c. Add a X2 BNC attenuator to the test setup between the X10 BNC attenuator and the 50 Ω BNC termination.

d. CHECK-That a stable display can be obtained, by adjusting the A LEVEL control, in both the + and - slopes of the displayed waveform in the AC and DC positions of the A COUPLING switch.

e. Remove the X2 BNC attenuator from the External Trigger signal test setup.

f. CHECK-That a stable display can be obtained, by adjusting the A LEVEL control, in both the + and - slopes of the displayed waveform in the LF REJ position of the A COUPLING switch.

g. Replace the X2 BNC attenuator to the test setup and set the A SOURCE switch to EXT \div 10.

h. Remove the X10 BNC attenuator from the test setup.

i. CHECK—That a stable display can be obtained, by adjusting the A LEVEL control, in both the + and — slopes of the displayed waveform in the AC and DC positions of the A COUPLING switch.

j. Remove the X2 BNC attenuator from the test setup.

k. CHECK-That a stable display can be obtained, by adjusting the A LEVEL control, in both the + and - slopes of the displayed waveform in the LF REJ position of the A COUPLING switch.

I. Replace both the X10 and X2 BNC attenuators to the test setup.

48. Check B External 25 Megahertz Triggering

a. Set the HORIZ DISPLAY switch to B DLY'D, the B SOURCE switch to EXT, and the A SOURCE switch to NORM.

b. Adjust the Medium-Frequency signal generator for a five division display.

c. CHECK-That a stable display can be obtained, by adjusting the LEVEL controls, in both the + and - slopes of the displayed waveform in the AC and DC positions of the B COUPLING switch.

d. Remove the X2 BNC attenuator from the test setup.

e. CHECK-That a stable display can be obtained, by adjusting the LEVEL controls, in both the + and - slopes of the displayed waveform in the LF REJ position of the B COUPLING switch.

f. Replace the X2 BNC attenuator to the test setup.

49. Check A and B External 100 Megahertz Triggering

a. Set the A TIME/DIV switch to 50 μ s, the TRIG MODE to AUTO, the X10 MAG button in, both VOLTS/DIV switches to 50 mV, the VERT MODE switch to CH 1, and the A SOURCE switch to EXT \div 10.

b. Adjust the Medium-Frequency signal generator for a three-division display of a 25-megahertz reference signal.

c. Set the A TIME/DIV switch to $0.05 \,\mu s$.

d. Adjust the signal generator for a 100 megahertz output frequency.

e. CHECK-That a stable display, with no more than 0.1 division of jitter, can be obtained in both the + and - slopes of the displayed waveform, by adjusting the A LEVEL control, in the AC and DC positions of the A COUPLING switch.

f. Remove the X2 BNC attenuator.

g. CHECK-That a stable display, with no more than 0.1 division of jitter, can be obtained in both the + and - slopes of the displayed waveform, by adjusting the A LEVEL control, in the LF REJ position of the A COUPLING switch.

h. Replace the X10 and X2 BNC attenuators to the test setup.

i. Set the A SOURCE switch to EXT.

j. Repeat the 100-megahertz triggering check procedure, steps 49-e through 49-g.

k. Replace the X2 BNC attenuator to the test setup.

I. Set the HORIZ DISPLAY switch to B DLY'D, the B SOURCE switch to EXT, and the A SOURCE switch to NORM.

m. CHECK—That a stable display, with no more than 0.1 division of jitter, can be obtained in both the + and - slopes of the displayed waveform, by adjusting both LEVEL controls, in the AC and DC positions of the B COUPLING switch.

n. Remove the X2 BNC attenuator.

o. CHECK-That a stable display, with no more than 0.1 division of jitter, can be obtained in both the + and - slopes of the displayed waveform, by adjusting both LEVEL controls, in the LF REJ position of the B COUPLING switch.

50. Check B Internal 100 Megahertz Triggering

a. Set the B SOURCE switch to NORM and both VOLTS/DIV switches to 10 mV.

b. Adjust the Medium-Frequency signal generator for a 1.5-division display of 100-megahertz signal.

c. CHECK-That a stable display, with no more than 0.1 division of jitter, can be obtained in both the + and - slopes of the displayed waveform, by adjusting both LEVEL controls, in the AC, LF REJ, and DC positions of the B COUPLING switch.

d. Set the B SOURCE switch to CH 1.

e. Repeat step 50-c.

f. Set the B SOURCE switch to CH 2.

g. CHECK-That a stable display cannot be obtained in any position of the B COUPLING switch.

h. Set the VERT MODE switch to CH 2.

i. Repeat step 50-c.

j. Set the B SOURCE switch to NORM.

k. Repeat step 50-c.

I. Set the B SOURCE switch to CH 1.

m. Repeat step 50-g.

51. Check A Internal 100 Megahertz Triggering

a. Set the HORIZ DISPLAY switch to A.

b. CHECK-That a stable display, with no more than 0.1 division of jitter, can be obtained in both the + and - slopes of the displayed waveform, by adjusting the A LEVEL control, in the AC, LF REJ, and DC positions of the A COUPLING switch.

c. Set the A SOURCE switch to CH 2.

- d. Repeat step 51-b.
- e. Set the A SOURCE switch to CH 1.

f. CHECK-That a stable display cannot be obtained in any position of the A COUPLING switch.

g. Set the VERT MODE switch to CH 1.

- h. Repeat step 51-b.
- i. Set the A SOURCE switch to NORM.
- j. Repeat step 51-b.
- k. Set the A SOURCE switch to CH 2.
- I. Repeat step 51-f.

m. Disconnect the test setup.

52. Check A and B HF REJ Triggering

a. Set the HORIZ DISPLAY to A, the TIME/DIV switches to $5\,\mu$ s, the TRIG MODE switch to AUTO, both COUPLING switches to HF REJ, and both SOURCE switches to NORM.

b. Connect the output of the Medium-Frequency Constant-Amplitude Signal Generator (Type 191) to the CH 1 input via a 50 Ω 5 ns GR cable, a 50 Ω Signal Pickoff Unit (Type CT-3) thru output, a GR-to-BNC adapter and an 18-inch 50 Ω BNC cable.

c. Connect the 10% output of the Signal Pickoff Unit to the A External Trigger Input via an 18-inch 50 Ω BNC cable and a 50 Ω BNC termination.

d. Adjust the Medium-Frequency signal generator for a 0.5-volt output and adjust the CH 1 VOLTS/DIV switch for a 0.3-division display of a 50-kilohertz signal.

e. CHECK-That a stable display can be obtained in both the + and - slopes of the displayed waveform, in all positions of the A COUPLING switch, by adjusting the A LEVEL control.

f. Increase the output of the Medium-Frequency signal generator to 1 megahertz.

g. CHECK—That a stable display cannot be obtained in the HF REJ position of the A COUPLING switch.

h. Set the A SOURCE switch to EXT.

i. CHECK—That a stable display cannot be obtained in the HF REJ position of the A COUPLING switch.

j. Reduce the Medium-Frequency signal generator output frequency to 50 kilohertz.

k. CHECK-That a stable display can be obtained in both the + and - slopes of the displayed waveform, in all positions of the A COUPLING switch, by adjusting the A LEVEL control.

1. Move the External Trigger signal to the B External Trigger input.

m. CHECK—That a stable display can be obtained in both the + and — slopes of the displayed waveform, in all positions of the B COUPLING switch, by adjusting the LEVEL controls.

n. Increase the output of the Medium-Frequency signal generator to 1 meaghertz.

o. CHECK-That a stable display cannot be obtained in the HF REJ position of the B COUPLING switch.

p. Set the B SOURCE switch to EXT.

q. CHECK-That a stable display cannot be obtained in the HF REJ position of the B COUPLING switch.

r. Reduce the Medium-Frequency signal generator output frequency to 50 kilohertz.

s. CHECK—That a stable display can be obtained in both the + and — slopes of the displayed waveform, in all positions of the B COUPLING switch, by adjusting the LEVEL controls.

t. Disconnect the test setup.

53. Check B 60 Hertz and LF REJ Triggering

a. Set the B TIME/DIV switch to 5 ms, the HORIZ DISPLAY switch to B DLY'D, both SOURCE switches to NORM, and both VOLTS/DIV switches to 0.1 V.

b. Connect the Low-Frequency Sine-Wave Generator (General Radio 1310-A) to the CH 1 input via a 42-inch 50 Ω BNC cable, a BNC-T connector, and an 18-inch 50 Ω BNC cable. Connect the other side of the BNC-T connector to the B External Trigger input via a X10 BNC attenuator and a 50 Ω BNC termination.

c. Adjust the Sine-Wave Generator for a 0.3-division display of a 60-hertz signal.

d. CHECK-That a stable display can be obtained in both the + and - slopes of the displayed waveform, in the AC, HF REJ, and DC positions of the B COUPLING switch, by adjusting the LEVEL controls.

e. CHECK-That a stable display cannot be obtained in the LF REJ position of the B COUPLING switch.

f. Set the B SOURCE switch to CH 1.

g. CHECK-That a stable display can be obtained in both the + and - slopes of the displayed waveform, in the AC, HF REJ, and DC positions of the B COUPLING switch, by adjusting the LEVEL controls.

h. CHECK-That a stable display cannot be obtained in the LF REJ position of the B COUPLING switch.

i. Set the B SOURCE switch to CH 2.

k. Move the test signal from CH 1 to the CH 2 input.

I. Adjust the Sine-Wave Generator for a 0.3-division display of a 60-hertz signal.

m. CHECK—That a stable display can be obtained in both the + and — slopes of the displayed waveform, in the AC, HF REJ, and DC positions of the B COUPLING switch, by adjusting the LEVEL controls.

n. CHECK—That a stable display cannot be obtained in the LF REJ position of the B COUPLING switch.

o. Set the B SOURCE switch to EXT.

p. CHECK-That a stable display can be obtained in both the + and - slopes of the displayed waveform, in the AC, HF REJ, and DC positions of the B COUPLING switch, by adjusting the LEVEL controls.

q. CHECK-That a stable display cannot be obtained in the LF REJ position of the B COUPLING switch.

54. Check A 60 Hertz and LF REJ Triggering

a. Set the HORIZ DISPLAY switch to A.

b. Move the signal from the B External Trigger input to the A External Trigger input.

c. CHECK—That a stable display can be obtained in both the + and — slopes of the displayed waveform, in the AC, HF REJ, and DC positions of the A COUPLING switch, by adjusting the A LEVEL control.

d. CHECK-That a stable display cannot be obtained in the LF REJ position of the A COUPLING switch.

e. Set the A SOURCE switch to CH 2.

f. CHECK—That a stable display can be obtained in both the + and — slopes of the displayed waveform, in the AC, HF REJ, and DC positions of the A COUPLING switch, by adjusting the A LEVEL control.

g. Set the A SOURCE switch to CH 1.

h. CHECK-That a stable display cannot be obtained in any position of the A COUPLING switch.

i. Move the test signal from CH 2 to the CH 1 input.

j. Adjust the Sine-Wave Generator for a 0.3-division display of a 60-hertz signal.

k. CHECK-That a stable display can be obtained in both the + and - slopes of the displayed waveform, in the AC, HF REJ, and DC positions of the A COUPLING switch, by adjusting the A LEVEL control.

I. CHECK—That a stable display cannot be obtained in the LF REJ position of the A COUPLING switch.

m. Set the A SOURCE switch to EXT.

n. CHECK-That a stable display can be obtained in both the + and - slopes of the displayed waveform, in the AC, HF REJ, and DC positions of the A COUPLING switch, by adjusting the A LEVEL control.

o. CHECK—That a stable display cannot be obtained in the LF REJ position of the A COUPLING switch.

p. Disconnect the test setup.

55. Check A LEVEL Control External Range

a. Set both SOURCE switches to EXT, the CH 1 VOLTS/DIV switch to 1 V, and the A SLOPE switch to +.

b. Connect the output of the Low-Frequency Sine-Wave Generator (General Radio 1310-A) to the CH 1 input and the A External Trigger input through a BNC-T Connector and two 42-inch 50 Ω BNC cables.

c. Adjust the Sine-Wave Generator for a four-division display of a 1-kilohertz signal.

d. CHECK-That the display can be triggered at any point along the positive slope of the waveform when rotating the A LEVEL control throughout its range.

e. CHECK-Display is not triggered at either extreme of rotation.

f. Set the A SLOPE switch to -.

g. CHECK-That the display can be triggered at any point along the negative slope of the waveform when rotating the A LEVEL control throughout its range.

h. CHECK-Display is not triggered at either extreme of rotation.

i. Set the CH 1 VOLTS/DIV switch to 10 V and the A SOURCE switch to EXT \div 10.

j. Adjust the Sine-Wave Generator for a four-division display of a 1-kilohertz signal.

k. CHECK-That the display can be triggered at any point along the negative slope of the waveform when rotating the A LEVEL control throughout its range.

I. CHECK-Display is not triggered at either extreme of rotation.

m. Set the A SLOPE switch to +.

n. CHECK-That the display can be triggered at any point along the positive slope of the waveform when rotating the A LEVEL control throughout its range.

o. CHECK-Display is not triggered at either extreme of rotation.

56. Check B LEVEL Control External Range

a. Set the HORIZ DISPLAY switch to B DLY'D.

b. Move the External Trigger signal to the B External Trigger input.

c. Set the A SOURCE switch to NORM, the B SLOPE switch to +, and the CH 1 VOLTS/DIV switch to 1 V.

d. Adjust the Sine-Wave Generator for a four-division display of a 1-kilohertz signal.

e. CHECK-That the display can be triggered at any point along the positive slope of the waveform when rotating the B LEVEL control throughout its range.

f. CHECK-Display is not triggered at either extreme of rotation.

g. Set the B SLOPE switch to -.

h. CHECK-That the display can be triggered at any point along the negative slope of the waveform when rotating the B LEVEL control throughout its range.

i. CHECK-Display is not triggered at either extreme of rotation.

57. CHECK Single Sweep Operation

a. Set the HORIZ DISPLAY switch to A, and the A COUPLING switch to AC.

b. Adjust the Low-Frequency Sine-Wave Generator for a 50-kilohertz signal output.

c. Adjust the A LEVEL control for a triggered display.

d. Disconnect the test signal from the CH 1 input.

e. Press the SINGL SWP button of the TRIG MODE switch.

f. CHECK-READY light comes on when SINGL SWP button is pressed and remains on until the test signal is re-applied.

g. Reconnect the test signal to the CH 1 input.

h. CHECK-READY light is extinguished.

i. Press the SINGL SWP button.

j. CHECK—That a single-sweep display (one sweep only) is presented.

58. Check A Normal Mode Operation

a. Set the A SOURCE switch to NORM, and the TRIG MODE switch to AUTO.

b. Adjust the Sine-Wave Generator for a 50-kilohertz signal.

c. Adjust the A LEVEL control for a triggered display.

d. Switch the TRIG MODE switch to NORM.

e. CHECK-For a stable display.

f. Remove the test signal from the CH 1 input.

g. CHECK—For no trace in the absence of an adequate trigger signal.

59. Check LINE Triggering

a. Set the HORIZ DISPLAY switch to A, the TRIG MODE switch to AUTO, the A SOURCE switch to LINE, and the A COUPLING switch to AC.

b. Connect a X10 probe from the CH 1 input to a line voltage source.

c. Set the CH 1 VOLTS/DIV switch to display four divisions of deflection.

d. Rotate the A SLOPE switch between + and -.

e. CHECK-Sweep starts on the slope selected by the A SLOPE switch.

f. Disconnect the test setup.

60. Check Automatic Recovery Time

a. Set the A TIME/DIV switch to 50 ms, the A SLOPE switch to +, and the A SOURCE switch to NORM.

b. Connect 50 ms time marks from the Time Mark Generator (Type 2901) to the CH 1 input via a 42-inch 50 Ω BNC cable and a 50 Ω BNC termination.

c. CHECK-That a stable display can be obtained by adjusting the A LEVEL control. Time marker must be at the start of the sweep.

d. Disconnect the test setup.

61. Adjust Trigger View Centering

a. Set the VERT MODE switch to CH 1, CH 1 INPUT COUPLING switch to DC, the CH 1 VOLTS/DIV switch to 10 mV, the A COUPLING switch to DC, the A SOURCE switch to EXT, the A SLOPE switch to +, and the A LEVEL control to 0.

b. Push the TRIG VIEW button and hold it in.

c. CHECK-That the trace is within 1 division of the center horizontal graticule line.

d. ADJUST-Trigger View Centering adjustment, R675, (see Fig. 5-28) so that the trace is at the center horizontal line.

e. Release the TRIG VIEW button.

f. Disconnect the test setup.

62. Check Trigger View Deflection Factor

a. Connect the output of the Standard Amplitude Calibrator to the A External Trigger input via a 42-inch 50 Ω BNC cable.

b. Adjust the Standard Amplitude Calibrator for a 200 mV square-wave output.



Fig. 5-28. Location of Trigger View Centering adjustment.

- c. Push the TRIG VIEW button and hold in.
- d. CHECK-For 3.2 to 4.8 divisions of display.
- e. Release the TRIG VIEW button.
- f. Disconnect the test setup.

HORIZONTAL SYSTEM CALIBRATION

Equipment Required				
 Medium-Frequency Constant-Amplitude Signal Gen- erator (Type 191). 	5. Dual-Input Coupler			
	6. 42-inch 50 Ω BNC Cable			
2. Test Oscilloscope	7. 50 Ω BNC Termination			
3. Time Mark Generator	8. Three-Inch Screwdriver			
4. Standard Amplitude Calibrator	9. Low-Capacitance Screwdriver			

Control Settings

Preset instrument controls to the settings given under Preliminary Control Settings except as follows:

A TIME/DIV	1 ms
B TIME/DIV	5 µs
B TRIGGER	
SOURCE	STARTS AFTER DELAY
HORIZ DISPLAY	A INTEN
DELAY-TIME POSITION	1.00

63. Adjust Sweep Start and A Sweep Calibration

a. Connect 1 ms time marks to the CH 1 input from the Time Mark Generator via a 42-inch 50 Ω BNC cable and a 50 Ω BNC termination.

b. CHECK-Intensified portion of the sweep begins at the second time marker.

c. ADJUST-Sweep Start adjustment, R1115, (see Fig. 5-29) so the intensified portion of the sweep begins at the start of the second time marker.

d. Set the DELAY TIME POSITION dial to 9.00.

e. CHECK-Intensified portion of the sweep begins at the tenth time marker.

f. ADJUST-A Sweep Calibration adjustment, R1145, (see Fig. 5-29) so the intensified portion of the sweep begins at the start of the tenth time marker.

g. Set the HORIZ DISPLAY switch to B DLY'D.

h. Set the DELAY TIME POSITION dial to 1.00.

i. CHECK-Displayed pulse starts at the beginning of the sweep.

j. ADJUST-Sweep Start adjustment, R1115, so the displayed pulse starts at the beginning of the sweep.

k. Set the DELAY TIME POSITION dial to 9.00.

I. CHECK-Displayed pulse starts at the beginning of the sweep.

m. ADJUST-A Sweep Calibration adjustment, R1145, so the displayed pulse starts at the beginning of the sweep.

n. INTERACTION—Between Sweep Start and A Sweep Cal adjustment. Repeat both for no visible interaction.

64. Check Differential Time Accuracy

a. Set the DELAY TIME POSITION dial to position the tenth time marker to the beginning of the sweep.



Fig. 5-29. Location of Sweep Start and A Sweep Cal adjustments.

b. Note the reading on the DELAY TIME POSITION dial.

c. Adjust the DELAY TIME POSITION dial so the ninth time marker is at the beginning of the sweep.

d. CHECK-DELAY TIME POSITION dial for a reading one division less, within 0.01 division from $+15^{\circ}$ C to $+35^{\circ}$ C; one division less, within 0.03 division from -15° C to $+55^{\circ}$ C, than the reading noted in step 64-b.

e. Rotate the DELAY TIME POSITION dial to position each successive time marker to the beginning of the sweep.

f. CHECK–DELAY TIME POSITION dial for a reading of one division less, within 0.01 division from $+15^{\circ}$ C to $+35^{\circ}$ C; one division less, within 0.03 division from -15° C to $+55^{\circ}$ C, than the adjacent time marker.

65. Adjust Horizontal Amplifier Gain

a. Set the HORIZ DISPLAY switch to A, both TIME/ DIV switches to 1 ms, and the VERT MODE switch to CH 1.

b. Select 1 ms time marks from the Time Mark Generator.

c. ADJUST-X1 Gain adjustment, R1237, (see Fig. 5-30) for exactly one time marker/division.



Fig. 5-30. Location of Horizontal Gain and Magnifier Registration adjustments.

d. Select 0.1 ms time marks from the Time Mark Generator.

e. Push the X10 MAG button.

f. CHECK-X10 MAG light is on when the X10 MAG button is in.

g. ADJUST-X10 Gain adjustment, R1238, (see Fig. 5-30) for exactly one time marker/division.

66. Check Sweep Linearity

a. CHECK-Sweep accuracy over any 2 division portion of 10 division sweep to be within 0.1 division.

b. Release the X10 MAG.

c. Select 1 ms time marks from the Time Mark Generator.

d. CHECK-Linearity over any 2 divisions of the sweep to be within 0.1 division of accurate timing.

67. Adjust Magnifier Registration

a. Push the X10 MAG button in.

b. Select 5 ms time markers from the Time Mark Generator.

c. Position the middle time marker to the center vertical graticule line.

d. Release the X10 MAG.

e. CHECK-Middle time marker is within 0.2 division of the center vertical graticule line.

f. ADJUST-Magnifier Registration adjustment, R1225, (see Fig. 5-30) to position the middle time marker to the center vertical graticule line.

g. CAL AID-Repeat the above procedure until no shift occurs between positions of the X10 MAG switch.

68. Adjust B Sweep Calibration

a. Set the DELAY TIME POSITION dial fully counterclockwise; the HORIZ DISPLAY switch to B DLY'D; B TIME/DIV switch to 1 ms; B TRIGGER; COUPLING switch to AC, SOURCE switch to NORM.

b. Select 1 ms time marks from the Time Mark Generator.

c. CHECK-CRT display for 1 time marker/division.

d. ADJUST-B Sweep Calibration adjustment, R1175, (see Fig. 5-31) for 1 time marker/division.

69. Check Sweep Length

a. Set the A TIME/DIV switch to 1 ms, the B TIME/ DIV switch to 1 ms, and the HORIZ DISPLAY switch to A.

b. Select 1 ms and 0.1 ms time marks from the Time Mark Generator.

c. CHECK-A sweep length is 11 divisions, within 0.5 division.

70. Check VAR TIME/DIV Range

a. Set the A TIME/DIV switch to 2 ms.

b. Select 5 ms time marks from the Time Mark Generator.



Fig. 5-31. Location of High Speed Timing and B Sweep Cal adjustments.

c. CHECK-At least 1 time marker/division can be obtained by adjusting the VAR TIME/DIV control.

d. CHECK-That the UNCAL light comes on when the VAR TIME/DIV control is out of the detent position.

e. Return the VAR $\mathsf{TIME}/\mathsf{DIV}$ control to the detent position.

71. Check Horizontal POSITION Control Range

a. Set the horizontal FINE position control to midrange and the A TIME/DIV switch to 2 ms.

b. Turn the horizontal POSITION control fully clockwise.

c. CHECK-Start of sweep is to the right of the center vertical graticule line.

d. Turn the horizontal POSITION control fully counterclockwise.

e. CHECK-End of sweep is to the left of the center vertical graticule line.

f. Rotate the horizontal FINE position control.

g. CHECK-That the FINE position control will position the sweep between one and two divisions.

72. Adjust A TIME/DIV High Speed Timing

a. Set the DELAY TIME POSITION dial to 1.50, the B SOURCE switch to STARTS AFTER DELAY, the A TIME/DIV switch to 0.5 μ s, and the B TIME/DIV switch to 0.05 μ s.

b. Select $0.5\,\mu s$ time marks from the Time Mark Generator.

c. CHECK-CRT display for one time marker/division.

d. ADJUST-A High Speed Timing adjustment, C1137, (see Fig. 5-31) with the low-capacitance screwdriver, for one time marker/division.

e. Switch the HORIZ DISPLAY switch to B DLY'D.

f. Set the horizontal POSITION control so the displayed time marker crosses the center vertical graticule line.

g. Set the DELAY TIME POSITION dial to 8.50.

h. CHECK-That the displayed time marker crosses the center vertical graticule line.

i. ADJUST-A High Speed Timing adjustment, C1137, so the displayed time marker crosses the center vertical graticule line.

j. INTERACTION-There is interaction, when adjusting C1137, between the two positions of the DELAY-TIME POSITION dial. Compromise the adjustments as necessary to achieve optimum timing.

73. Adjust B TIME/DIV High Speed Timing

a. Set the DELAY TIME POSITION dial fully counterclockwise, the HORIZ DISPLAY switch to B DLY'D, B SOURCE switch to NORM, A TIME/DIV switch to $1 \mu s$, and the B TIME/DIV switch to $0.5 \mu s$.

b. Select $0.5\,\mu s$ time marks from the Time Mark Generator.

c. Adjust the A and B LEVEL controls for a stable display.

d. CHECK-CRT display for one time marker/division.

e. ADJUST-B High Speed Timing adjustment, C1167, (see Fig. 5-31) for one time marker/division.

74. Check A and B TIME/DIV Accuracy

a. CHECK-Using the B TIME/DIV switch and the Time Mark Generator settings given in Table 5-7, check B sweep timing, within 0.2 division, over the first ten divisions of the display.

b. Set the HORIZ DISPLAY to A.

c. CHECK-Using the A TIME/DIV switch and the Time Mark Generator settings given in Table 5-7, check A sweep timing, within 0.2 division, over the first ten divisions of the display.

TABLE 5-7

A and B Timing Accuracy

A and B TIME/DIV Switch Setting	Time-Mark Generator Output	CRT Display (Markers/ Division)
.05 µs	50 nanosecond	1
.1 μs	0.1 microsecond	1
.2 μs	0.1 microsecond	2
.5 μs	0.5 microsecond	1
1 µs	1 microsecond	1
2 µs	1 microsecond	2
5 µs	5 microsecond	1
10 µs	10 microsecond	1
20 µs	10 microsecond	2
50 µs	50 microsecond	1
.1 ms	0.1 millisecond	1
.2 ms	0.1 millisecond	2
.5 ms	0.5 millisecond	1
1 ms	1 millisecond	1
2 ms	1 millisecond	2
5 ms	5 millisecond	1
10 ms	10 millisecond	1
20 ms	10 millisecond	2
50 ms	50 millisecond	1
	A SWEEP ONLY	
.1 s	0.1 second	1
.2 s	0.1 second	2
.5 s	0.5 second	1

75. Adjust High Speed Magnified Timing

a. Set the X10 MAG on, the Horizontal POSITION control to midrange, and the A TIME/DIV switch to 0.05 $\mu s.$

b. Select 10 ns sine-wave output from the Time Mark Generator.



Fig. 5-32. Location of Magnified Timing adjustment.

c. CHECK-CRT display for one cycle/two divisions, within 0.3 division over the full ten horizontal graticule divisions. Disregard the first and last ten divisions of sweep length. See Table 5-8.

d. ADJUST—Magnifier Timing adjustments, C1261 and C1281 (see Fig. 5-32), with the low-capacitance screwdriver for one cycle/two divisions. Disregard the first and last ten divisions of sweep length.

76. Check A and B Magnified Timing Accuracy

a. CHECK-Using the A TIME/DIV switch and the Time Mark Generator settings given in Table 5-8, check A magnified sweep timing, within 0.3 division over the center ten divisions of the magnified display. Note the portions of the total magnified sweep length to be excluded from the measurement.

TABLE 5-8

A and B Magnified Accuracy

			Portions of
A and B	l ime-	CRI	total magnified
TIME/	Mark	Display	sweep length
	Generator	(Mark-	to exclude
Switch	Output	ers/	trom
Setting		Division)	measurement
.05 µs	5 nanosecond	1	First and last
			10 divisions
.1 μs	10 nanosecond	1	First and last
			5 divisions
.2 μs	10 nanosecond	2	First and last
			2 1/2 divisions
.5 μs	50 nanosecond	1	
1 μs	0.1 microsecond	1	
2 μs	0.1 microsecond	2	
5 µs	0.5 microsecond	1	
10 µs	1 microsecond	1	
20 µs	1 microsecond	2	
50 µs	5 microsecond	1	
.1 ms	10 microsecond	1	
.2 ms	10 microsecond	2	
.5 ms	50 microsecond	1	
1 ms	0.1 millisecond	1	
2 ms	0.1 millisecond	2	
5 ms	0.5 millisecond	1	
10 ms	1 millisecond	1	
20 ms	1 millisecond	2	
50 ms	5 millisecond	1	
	A SWEE	PONLY	
.1 s	10 millisecond	1	
.2 s	10 millisecond	2	· · · · · · · · · · · · · · · · · · ·
.5 s	50 millisecond	1	

b. Set the HORIZ DISPLAY switch to B DLY'D.

c. CHECK-Using the B TIME/DIV switch and the Time Mark Generator settings given in Table 5-8, check B magnified sweep timing, within 0.3 division over the center ten divisions of the magnified display. Note the portions of the total magnified sweep length to be excluded from the measurement.

d. Release the X10 MAG.

77. Check Delay Time Accuracy

a. Set the B SOURCE switch to STARTS AFTER DELAY, the A TIME/DIV switch to $0.2\,\mu$ s, and the B TIME/DIV switch to $0.05\,\mu$ s.

b. CHECK-Using the A TIME/DIV switch, B TIME/ DIV switch and the Time Mark Generator settings given in Table 5-9, check delayed sweep accuracy is within the given tolerance. First set the DELAY TIME POSITION dial to 1.00 and rotate the dial until the sweep starts at the top of

TABLE 5-9

Delayed Sweep Accuracy

	A TIME/ DIV	B TIME/ DIV	Time- Mark	Allowable
	Switch Setting	Switch Setting	Generator	Error for Given
=				
	.2 µs	.05 µs	.1 microsecond	
	.5 µs	.05 µs	.5 microsecond	
	1 μs	.1 μs	1 microsecond	
	2 µs	.1 μs	1 microsecond	
	5 µs	.1 μs	5 microsecond	
	10 µs	1 µs	10 microsecond	
_	20 µs	1 µs	10 microsecond	
	50 µs	1 µs	50 microsecond	
	.1 ms	10 µs	.1 millisecond	±8 minor
	.2 ms	10 µs	.1 millisecond	dial
	.5 ms	10 µs	.5 millisecond	unisions
	1 ms	.1 ms	1 millisecond	
	2 ms	.1 ms	1 millisecond	
	5 ms	.1 ms	5 millisecond	
	10 ms	1 ms	10 millisecond	•
	20 ms	1 ms	10 millisecond	
	50 ms	1 ms	50 millisecond	
-	.1 s	10 ms	.1 second	
	.2 s	10 ms	.1 second	
	.5 s	10 ms	.5 second	

the second time marker. Note the control setting and then set the dial to 9.00 and rotate it slightly until the sweep starts at the top of the tenth time marker. DELAY TIME POSITION dial setting must be 8.00 divisions higher, \pm 0.08 divisions.

NOTE

Sweep will start at top of the third time marker at 1.00 and at the top of the nineteenth time marker at 9.00 for sweep rates which are multiples of 2 (e.g., 2 μ s, 20 μ s, 0.2 ms, etc.). If in doubt as to the correct setting of the DELAY TIME POSITION dial, set the HORIZ DISPLAY switch to A INTEN and check which marker is intensified.

78. Check Delay Time Jitter

a. Set the DELAY TIME POSITION dial to 1.00, the HORIZ DISPLAY switch to B DLY'D, the A TIME/DIV switch to 1 ms, and the B TIME/DIV switch to 1 μ s.

b. Position the time marker near the center of the display area with the DELAY TIME POSITION dial.

c. CHECK-Jitter on the leading edge of the time marker should not exceed 0.2 division (0.5 division if the instrument is being operated on a 50 Hz line voltage). Disregard the slow drift.

d. Turn the DELAY TIME POSITION dial to 9.00 and adjust it so the time marker is displayed near the center of the display area.

e. CHECK-Jitter on the leading edge of the time marker should not exceed 0.2 divisions (0.5 division if the instrument is being operated on a 50 Hz line voltage). Disregard the slow drift.

79. Check Mixed Sweep Accuracy

a. Set the A TIME/DIV switch to 1 ms, the B TIME/ DIV switch to 0.5 ms, the HORIZ DISPLAY switch to A, the B SOURCE switch to STARTS AFTER DELAY, and the DELAY TIME POSITION dial fully clockwise.

b. Select 1 ms time marks from the Time Mark Generator.

c. CHECK-Timing between the second and tenth time markers. Note any timing error for use in step 79-e.

d. Set the HORIZ DISPLAY switch to MIX.

e. CHECK-The timing between second and tenth time markers is within 0.16 division, \pm the A sweep error noted in step 79-c.

f. Disconnect the test setup.

80. Adjust X Gain

a. Set the A TIME/DIV switch to X-Y, the VERT MODE switch to CH 2, both VOLTS/DIV switches to 5 mV, and the CH 1 INPUT COUPLING switch to DC.

b. Apply a 20 mV square-wave from the Standard Amplitude Calibrator to the CH 1 or X input through a 42-inch 50 Ω BNC cable.

c. CHECK-CRT display for 4 divisions of deflection, $\pm 4\%$, between the two displayed dots.

d. ADJUST-X-Gain adjustment R1215 (see Fig. 5-33) for exactly four divisions of deflection between the two dots displayed on the CRT.

e. Disconnect the test setup.

81. Check X-Y Phasing and Bandwidth

a. Set both VOLTS/DIV switches to 5 mV, and both INPUT COUPLING switches to AC.



Fig. 5-33. Location of X-Gain adjustment.

b. Connect the output of the Medium-Frequency Constant-Amplitude Signal Generator (Type 191) to the CH 1 and CH 2 inputs through a 42-inch 50 Ω BNC cable, 50 Ω BNC termination, and a dual input coupler.

c. Adjust the Medium-Frequency signal generator for an eight division horizontal display of 50 kilohertz.

d. Center the display vertically and horizontally with the CH 1 and CH 2 POSITION controls.

e. CHECK-CRT display for an opening at the center horizontal line of 0.4 division or less (see Fig. 5-34).

f. Remove the dual input coupler from the test setup.

g. Reconnect the test signal to the CH 1 input.

h. Adjust the signal generator for a 10-division horizontal display of 50 kilohertz.

i. Adjust the signal generator frequency until the display is reduced to seven divisions.



Fig. 5-34. Typical CRT display when checking X-Y phasing.

j. CHECK-Output frequency of the signal generator is at least 4 megahertz.

k. Disconnect the test setup.

82. Check B Ends A Operation

a. Set the HORIZ DISPLAY switch to A INTEN, the A TIME/DIV switch to 1 ms, the B TIME/DIV switch to 0.1 ms, and the A TRIG HOLDOFF control to B ENDS A.

b. Adjust the INTENSITY control so that the A sweep is visible.

c. Rotate the DELAY TIME POSITION dial through its range.

d. CHECK-A sweep ends after the intensified portion at all settings of the DELAY TIME POSITION dial.

83. Check A TRIGGER HOLDOFF

a. Set the HORIZ DISPLAY to A, the A TIME/DIV switch to 50 μ s, the A TRIG HOLDOFF control fully counterclockwise, and the A TRIG LEVEL control fully clockwise.

b. Connect the A GATE output signal to the Test Oscilloscope via a 42-inch 50 Ω BNC cable.

c. Set the Test Oscilloscope TIME/DIV switch so that the bottom portion of the waveform (holdoff time of the A GATE) is slightly less than one division in length.

d. Rotate the A TRIG HOLDOFF control clockwise.

e. CHECK—For at least ten times increase in the holdoff time of the A GATE.

f. Set the A TRIG HOLDOFF control fully counterclockwise. CALIBRATOR, GATES, & EXT Z-AXIS CALIBRATION

Equipment Required

- 1. Precision DC Voltmeter
- 2. Test Oscilloscope
- 3. Standard Amplitude Calibrator

4. 42-Inch 50 Ω BNC Cable

Control Settings

Preset instrument controls to the settings given under Preliminary Control Settings.

84. Adjust CALIBRATOR Output

a. Connect the Precision DC Voltmeter between the CALIBRATION loop and ground.

b. Install short circuit between the emitter of Q1594 and the collector of Q1590.

c. CHECK-For a meter reading of +0.3 volt $\pm\,0.003$ volt.

d. ADJUST-Calibrator Amplitude adjustment, R1597, (see Fig. 5-35) for 0.3 volt, within 1% from 0°C to $+40^{\circ}$ C; for 0.3 volt, within 1.5% from -15° C to $+55^{\circ}$ C.

e. Remove the Precision DC Voltmeter connections.

f. Remove the short circuit installed in step b.



Fig. 5-35. Location of CALIBRATOR Amplitude adjustment.

6. 15-inch 50 Ω BNC Cable (two)

7. Three-Inch Screwdriver

85. Check A and B + GATES

a. Set the DELAY TIME POSITION dial fully counterclockwise, the HORIZ DISPLAY switch to B DLY'D, the B SOURCE switch to STARTS AFTER DELAY, B TIME/ DIV switch to 50 μ s, and the TRIG MODE to AUTO.

b. Connect the B + GATE signal to the Test Oscilloscope via a 42-inch 50 Ω BNC cable.

c. CHECK-Test Oscilloscope for a positive-going pulse of +5.5 V in amplitude (within 0.5 V).

d. Remove the B + GATE signal and connect the A + GATE signal to the Test Oscilloscope via a 42-inch 50 Ω BNC cable.

e. CHECK-Test Oscilloscope for a positive-going pulse of +5.5 V in amplitude (within 0.5 V).

f. Disconnect the test setup.

86. Check EXT Z-AXIS Operation

a. Set HORIZ DISPLAY switch to A, A TIME/DIV switch to 0.2 ms, and the A SOURCE switch to EXT.

b. Set the INTENSITY control for a normal level.

c. Connect the Standard Amplitude Calibrator to the A External Trigger Input and the EXT Z-AXIS input via a 42-inch 50 Ω BNC cable, a BNC-T connector, and two 18-inch 50 Ω BNC cables.

d. Adjust the Standard Amplitude Calibrator for a 5 V output.

e. CHECK-CRT display for noticeable intensity modulation.

f. Disconnect the test setup.

ELECTRICAL PARTS LIST

Replacement parts should be ordered from the Tektronix Field Office or Representative in your area. Changes to Tektronix products give you the benefit of improved circuits and components. Please include the instrument type number and serial number with each order for parts or service.

ABBREVIATIONS AND REFERENCE DESIGNATORS

A	Assembly, separable or	FL	Filter	PTM	paper or plastic, tubular
	repairable	н	Heat dissipating device		molded
AT	Attenuator, fixed or variable		(heat sink, etc.)	R	Resistor, fixed or variable
В	Motor	HR	Heater	RT	Thermistor
BT	Battery	J	Connector, stationary portion	S	Switch
С	Capacitor, fixed or variable	κ	Relay	Т	Transformer
Cer	Ceramic	L	Inductor, fixed or variable	TP	Test point
CR	Diode, signal or rectifier	LR	Inductor/resistor combination	U	Assembly, inseparable or
CRT	cathode-ray tube	M	Meter		non-repairable
DL	Delay line	Q	Transistor or silicon-	V	Electron tube
DS	Indicating device (lamp)		controlled rectifier	Var	Variable
Elect.	Electrolytic	Ρ	Connector, movable portion	VR	Voltage regulator (zener diode,
EMC	electrolytic, metal cased	PMC	Paper, metal cased		etc.)
EMT	electrolytic, metal tubular	PT	paper, tubular	WW	wire-wound
F	Fuse			Y	Crystal

Ckt. No.	Tektronix Part No.	Serial/Model Eff	No. Disc	Description
ASSEMBLIES				
Al	670-2434-00)		CH 1 ATTEN Circuit Board Assembly
A2	670-2434-00)		CH 2 ATTEN Circuit Board Assembly
A3	670-2237-00)		VERT PREAMP. Circuit Board Assembly
A4	670-2236-00			VERT MODE Circuit Board Assembly
A5	670-2238-00	B010100 1	B039999	VERT OUTPUT Circuit Board Assembly
A5	670-0323-00	B040000		VERT OUTPUT Circuit Board Assembly
A6	670-2245-00)		FAN MOTOR Circuit Board Assembly
A7	670-2235-00	B010100 1	B010155	TIMING Circuit Board Assembly
A7	670-2235-01	. B010156		TIMING Circuit Board Assembly
A8	670-2234-00)		TRIG GEN & SWP LOGIC Circuit Board Assembly
A9	670-2233-00	B010100 1	B010155	INTERFACE Circuit Board Assembly
A9	670-2233-01	B010156		INTERFACE Circuit Board Assembly
A10	670-2279-00			GRATICULE ILLUM Circuit Board Assembly
A11	670-2520-00)		TRIG VIEW Circuit Board Assembly
MOTOR				
B1690	147-0035-00)		Motor, DC brushless, 10-15 VDC, 145 mA
CAPACITORS				
C1	281-0064-00)		0.25-1.5 pF, Var, Tub., 600 V
C2	281-0627-00			l pF, (nominal value), selected
C3	285-0816-01			0.019 uF, Plastic, 600 V, 10%
C6	283-0000-00			0.001 uF, Cer, 500 V, +100%-0%
C7	283-0000-00			0.001 uF, Cer, 500 V, +100%-0%
C10 (2)	307-1014-00	B010100 1	B019999	Attenuator strip, 100X
C10] (2) C11]	307-1014-01	. B020000 I	B029999	Attenuator strip, 100X

.

Ckt. No.	Tektronix Part No.	Serial/Model No. Eff Disc	Description
CAPACITORS C10 (2)	(cont) 307-1014-02	B030000	Attenuator strip, 100X
C11) C12 (2)	307-1013-00	B010100 B019999	Attenuator strip, 10X
C12 (2)	307-1013-01	в020000	Attenuator strip, 10X
C16	283-0001-00		0.005 uF, Cer, 500 V
C18	281-0593-00		3.9 pF, Cer, 10%
C21	283-0081-00	B010100 B010349	0.1 uF, Cer, 25 V, +80%-20%
C21	283-0004-00	B010350	0.02 uF, Cer, 150 V
C22	283-0087-00	1	300 pF, Cer, 100 V, 10%
C23	290-0517-00)	6.8 uF, Elect., 35 V, 20%
C25	283-0004-00		0.02 uF, Cer, 150 V
C27	281-0184-00	XB010250	2-18 pF, Var, Plastic
C33	281-0178-00		1-4 pF, Var, Plastic, 500 V
C34	283-0139-00		150 pF, Cer, 50 V, 20%
C36	283-0004-00	XB030000	0.02 uF, Cer, 150 V
C37	281-0536-00)	1000 pF, Cer, 500 V, 10%
C38	281-0536-00)	1000 pF, Cer, 500 V, 10%
C39	283-0004-00)	0.02 uF, Cer, 150 V
C42	283-0004-00)	0.02 uF, Cer, 150 V
C46	281-0626-00)	3.3 pF, Cer, 500 V, 5%
C47	281-0184-00)	2-18 pF, Var, Plastic, 500 V
C48	280-0184-00		2-18 pF, Var, Plastic, 500 V
C49	283-0136-00	D B010100 B010249	10 pr, Cer, 50 V, 58
C49	281-0621-00) B010250	12 pr, Cer, 500 V, 18
051	281-0064-00)	0.25-1.5 pr, var, 105., 000 v
C52	281-0627-00)	1 pF, (nominal value), selected
C53	285-0816-01		0.019 uF, Plastic, 600 V, 10%
C56	283-0000-00		0.001 uF, Cer, 500 V, $+100$ %-0%
C57	283-0000-00)	0.001 ur, Cer, 500 V, +1008-08
C66	283-0001-00]	3.9 pF Cer, $300 v$
C08	283-0081-00	, B010100 B010349	0.1 uF. Cer. 25 V. +808-208
C71	283-0004-00	B010350	0.02 uF, Cer, 150 V
C72	283-0087-00)	300 pF, Cer, 1000 V, 10%
C73	290-0517-00)	6.8 uF, Elect., 35 V, 20%
C75	283-0004-00)	0.02 uF, Cer, 150 V
C77	281-0504-00	B010100 B010249	10 pF, (nominal value), selected
C77	281-0184-00	B010250	2-8 pF, Var, Plastic, 500 V
C82	290-0517-00	XB010152	6.8 uF, Elect., 35 V, 20%
C83	281-0184-00	2	2-10 pr, var, Plastic, 500 V
C84	283-0139-00		1000 pF, Cer, 50 V, 208
C87	281-0536-00		1000 pr, Cer, 500 V, 106 1000 pr, Cer, 500 V, 109
CSS	201-0230-00	J	1000 br, cer, 200 v, 100

Electrical Parts List-465

Ckt. No.	Tektronix Part No.	Serial/Model No. Eff Disc	Description
CAPACITORS C92 C96 C97 C98 C99 C99 C101 C102 C103	(cont) 283-0004-00 281-0626-00 281-0184-00 281-0184-00 283-0136-00 281-0626-00 281-0628-00 290-0517-00 281-0604-00	B010100 B010249 B010250 XB010250	0.02 uF, Cer, 150 V 3.3 pF, Cer, 500 V, 5% 2-18 pF, Var, Plastic, 500 V 2-18 pF, Var, Plastic, 500 V 10 pF, Cer, 50 V, 5% 12 pF, Cer, 500 V, 1% 15 pF, Cer, 600 V, 5% 6.8 uF, Elect., 35 V, 20% 2.2 pF, Cer, 500 V, ±0.25 pF
C105 C107 C109 C122 C122 C125 C135 C137 C142	281-0184-00 281-0536-00 281-0536-00 281-0572-00 281-0184-00 290-0517-00 281-0525-00 281-0525-00 283-0003-00	XB010250 B010349 B010350	<pre>2-18 pF, Var, Plastic, 500 V 1000 pF, Cer, 500 V, 10% 1000 pF, Cer, 500 V, 10% 6-8 pF, Cer, 500 V, ±0.5 pF 2-18 pF, Var, Plastic, 500 V 6.8 uF, Elect., 35 V, 20% 470 pF, Cer, 500 V, 20% 470 pF, Cer, 500 V, 20% 0.01 uF, Cer, 150 V, +80%-20%</pre>
C144 C149 C151 C161 C162 C164 C201 C202 C203	281-0625-00 281-0184-00 281-0525-00 290-0517-00 281-0512-00 290-0517-00 281-0628-00 283-0004-00 281-0604-00	XB010250	<pre>35 pF, Cer, 500 V, 5% 2-18 pF, Var, Plastic, 500 V 470 pF, Cer, 500 V, 20% 6.8 uF, Elect., 35 V, 20% 27 pF, Cer, 500 V, 10% 6.8 uF, Elect., 35 V, 20% 15 pF, Cer, 500 V, 5% 0.02 uF, Cer, 150 V 2.2 pF, Cer, 50 V, ±0.25 pF</pre>
C205 C207 C209 C225 C229 C229 C229 C235 C237 C242	281-0184-00 281-0536-00 281-0536-00 283-0004-00 283-0004-00 290-0517-00 281-0525-00 281-0525-00 283-0003-00	XB010211 B010349 B010350	<pre>2-18 pF, Var, Plastic, 500 V 1000 pF, Cer, 500 V, 10% 1000 pF, Cer, 500 V, 10% 0.02 uF, (nominal value), selected 0.02 uF, Cer, 150 V 6.8 uF, Elect., 35 V, 20% 470 pF, Cer, 500 V, 20% 470 pF, Cer, 500 V, 20% 0.01 uF, Cer, 150 V, +80%-20%</pre>
C245 C249 C251 C253 C261 C262 C302 C321 C334	281-0628-00 281-0184-00 281-0525-00 283-0000-00 290-0517-00 281-0519-00 290-0517-00 283-0004-00 283-0004-00)))))	<pre>15 pF, Cer, 600 V, 5% 2-18 pF, Var, Plastic, 500 V 470 pF, Cer, 500 V, 20% 0.001 uF, Cer, 500 V, +100%-0% 6.8 uF, Elect., 35 V, 20% 47 pF, Cer, 500 V, 10% 6.8 uF, Elect., 35 V, 20% 0.02 uF, Cer, 150 V 0.02 uF, Cer, 150 V</pre>

¹Added if necessary.

₿

Ckt. No.	Tektronix Part No.	Serial/Model Eff	No. Disc	Description
CAPACITORS C338 C339 C345 C346 C347 C349 C351 C352 C354	(cont) 281-0579-00 283-0644-00 283-0004-00 290-0517-00 281-0508-00 281-0578-00 281-0549-00 290-0517-00 290-0517-00	XB010250		21 pF, Cer, 500 V, 5% 150 pF, Mica, 500 V, 1% 0.02 uF, Cer, 150 V 6.8 uF, Elect., 35 V, 20% 12 pF, Cer, 500 V, ±0.6 pF 18 pF, Cer, 500 V, 5% 68 pF, Cer, 500 V, 10% 6.8 uF, Elect., 35 V, 20%
C356 C358 C361 C362 C363 C364 C368 C374 C375	281-0549-00 290-0517-00 290-0517-00 290-0517-00 290-0517-00 281-0504-00 283-0058-00 281-0504-00 283-0004-00	XB010350 XB010350 XB010250		<pre>68 pF, Cer, 500 V, 10% 6.8 uF, Elect., 35 V, 20% 10 pF, Cer, 500 V, 10% 0.027 uF, Cer, 100 V, 10% 10 pF, Cer, 500 V, 10% 0.02 uF, Cer, 150 V</pre>
C381 C391 C402 C403 C407 C412 C417 C422 C423	283-0000-00 283-000-00 283-0032-00 281-0089-00 283-0081-00 283-0032-00 283-0081-00 281-0139-00 283-0180-00	XB040000 B010100 XB040000 B010100 XB040000 B010100 B010100	B039999X B039999X B039999X B039999X B039999X	0.001 uF, Cer, 500 V, +100%-0% 0.001 uF, Cer, 500 V, +100%-0% 470 pF, Cer, 500 V, 5% 2-8 pF, Var, Cer 0.1 uF, Cer, 25 V, +80%-20% 470 pF, Cer, 500 V, 5% 0.1 uF, Cer, 25 V, +80%-20% 2.5-9 pF, Var, Cer, 100 V 5600 pF, Cer, 200 V, 20%
C424 C424 C425 C426 C427 C430 C432 C433 C434	283-0167-00 283-0198-00 281-0638-00 281-0580-00 281-0524-00 283-0000-00 283-0065-00 283-0119-00 283-0187-00	B010100 B010895 XB040000 XB040000 XB040000 XB040000 XB040000 B010100 B010100	B010894 B039999X B039999X B039999X B029999	0.1 uF, Cer, 100 V, 10% 0.22 uF, Cer, 50 V, 20% 240 pF, Cer, 500 V, 5% 470 pF, Cer, 500 V, 10% 150 pF, Cer, 500 V, 20% 0.001 uF, Cer, 500 V, +100%-0% 0.001 uF, Cer, 100 V, 5% 2200 pF, Cer, 200 V, 5% 0.047 uF, Cer, 400 V, 10%
C434 C437 C438 C439 C441 C442 C442 C443 C443	283-0341-00 281-0629-00 281-0123-00 281-0617-00 283-0636-00 281-0089-00 283-0065-00 281-0096-00 281-0602-00	B030000 XB040000 XB040000 B010100 B010100 B040000 B010100 B010100	B039999X B039999X B039999 B039999 B039999X B039999	0.047 uF, Cer, 100 V, 10% 33 pF, Cer, 600 V, 5% 5-25 pF, Var, Cer, 100 V 15 pF, Cer, 200 V, 10% 36 pF, Mica, 100 V, ±0.5 pF 2-8 pF, Var, Cer 0.001 uF, Cer, 100 V, 5% 5.5-18 pF, Var, Air 68 pF, Cer, 500 V, 5%

ľ

Ckt. No.	Tektronix Part No.	Serial/Mode Eff	el No. Disc	Description
CAPACITORS	(cont)			
C444	281-0651-00	B040000		47 pF_{-} Cer. 200 V. 58
C445	283-0660-00	B010100	B039999X	510 pF. Mica. $500 V$. 28
C451	283-0144-00	B010100	B039999X	33 pF. Cer. 500 V. 18
C453	283-0000-00	B010100	B039999X	0.001 uF. Cer. 500 V. $\pm 1008-08$
C457	283-0010-00	B010100	B039999X	0.05 uF. Cer. 50 V
C458	283-0081-00	B010100	B039999X	0.1 uF, Cer. 25 V. +808-208
C459	283-0023-00	B010100	B039999X	0.1 uF, Cer, $10 V$, $+808-208$
C464.	283-0178-00	B010100	B039999	0.1 uF, Cer, 100 V, +80%-20%
C464 ¹		B040000		
C469	281-0500-00	XB040000		2.2 pF, Cer, 500 V, ±0.5 pF
C471,	283-0178-00	B010100	B039999X	0.1 uF, Cer, 100 V, +80%-20%
C474⊥		XB040000		
C481	283-0032-00	XB040000		470 pF, Cer, 500 V, 5%
C482	283-0000-00	XB040000		0.001 uF, Cer, 500 V, +100%-0%
C485	283-0003-00	XB040000		0.01 uF, Cer, 150 V, +80%-20%
C491	283-0032-00	XB040000		470 pF, Cer, 500 V, 5%
C492	283-0000-00	XB040000		0.001 uF, Cer, 500 V, +100%-0%
C498	290-0523-00	XB040000		2.2 uF, Elect., 20 V, 20%
C499	290-0523-00	XB040000		2.2 uF, Elect., 20 V, 20%
C502	281-0579-00			21 pF, Cer, 500 V, 5%
C503	281-0651-00			47 pF, Cer, 200 V, 5%
C511	281-0523-00			100 pF, Cer, 350 V, 20%
C512	283-0004-00			0.02 uF, Cer, 150 V
C515	281-0511-00			22 pF, Cer, 500 V, 10%
C522	283-0003-00			0.01 uF, Cer, 150 V, +80%-20%
C525	283-0003-00			0.01 uF, Cer, 150 V, +80%-20%
C528	281-0511-00			22 pF, Cer, 500 V, 10%
C531	283-0003-00			0.01 uF, Cer, 150 V, +80%-20%
C549	283-0003-00			0.01 uF, Cer, 150 V, +80%-20%
C601	283-0003-00	B010100	B010399	0.01 uF, Cer, 150 V, +80%-20%
C601	283-0167-00	B010400		0.1 uF, Cer, 100 V, 10%
C603	281-0670-00			1.8 pF, Cer, 500 V, ± 0.1 pF
C604	281-0523-00			100 pF, Cer, 350 V, 20%
C606	281-0628-00			15 pF, Cer, 600 V, 5%
C607	281-0515-00			27 pF, Cer, 500 V, ±1.35 pF
C611	281-0523-00			100 pF, Cer, 250 V, 20%
C612	283-0004-00			0.02 uF, Cer, 150 V
C615	281-0511-00			22 pF, Cer, 500 V, 10%
C622	283-0003-00			0.01 uF, Cer, 150 V, +80%-20%
C625	283-0003-00			U.UL uF, Cer, 150 V, +80%-20%
C628	281-0511-00			22 pr, Cer, 500 V, 10%
C631	283-0003-00			U.UL UF, CET, ISU V, +808-208
C649		DOIO100	D0100044	U.UI UF, CEF, IDU V, +808-208 47 mF Com 500 V 209
0674	201 0201 00	BUTUTUO	DUIU804X	47 pr, Cer, 300 v, 208
C674	281-0201-00	YROTI700		4./ pr, cer, buu v, ii pr

¹Part of Circuit Board.

₿

18 P.

₩îv F

4
Ckt. No. Part No. Eff Disc Description CAPACITORS (cont) CG76 281-0540-00 B010805 51 pF, (nominal value), selected C676 281-0540-00 B010100 B010824 3.3 pF, Cer, 500 V, 5% C680 283-0081-00 B010100 B010352 0.1 uF, Cer, 25 V, +808-20% C697 283-0081-00 B010100 B010352 0.1 uF, Cer, 25 V, +808-20% C697 283-0081-00 B0101052 0.1 uF, Cer, 10 V, +808-20% C699 283-0081-00 B0101052 0.1 uF, Cer, 10 V, +808-20% C699 283-0081-00 B0101052 0.1 uF, Cer, 10 V, +808-20% C699 283-0081-00 B010353 0.1 uF, Cer, 10 V, +808-20% C699 283-0081-00 B010353 0.1 uF, Cer, 10 V, +808-20% C805 290-0527-00 15 uF, Elect., 20 V, 20% C834 C814 281-0511-00 22 pF, Cer, 500 V, 10% C834 290-0527-00 15 uF, Elect., 20 V, 20% C837 290-0527-00 15 uF, Elect., 20 V, 20% C837 283-0024-00 0.1 uF, Cer, 500 V, 20%		Tektronix	Serial/Model No.	
CAPACITORS (cont) C676 281-0646-00 B010805 B010804 S8 pF, Cer, 500 V, 5% C676 281-0646-00 B010805 S1 pF, (nominal value), selected C684 281-0626-00 B010100 B010832 0.1 uF, Cer, 30 V, +80%-20% C690 283-0081-00 B010353 0.1 uF, Cer, 30 V, +80%-20% C697 283-0081-00 B010353 0.1 uF, Cer, 25 V, +80%-20% C697 283-0081-00 B010353 0.1 uF, Cer, 10 V, +80%-20% C699 283-0023-00 B010353 0.1 uF, Cer, 10 V, +80%-20% C608 281-0517-00 14 uF, Cer, 500 V, 20% C808 281-0517-00 15 uF, Elect., 20 V, 20% C826 281-0523-00 100 pF, Cer, 350 V, 20% C835 290-0527-00 15 uF, Elect., 20 V, 20% C836 290-0527-00 15 uF, Elect., 20 V, 20% C837 281-0524-00 100 uF, Elect., 20 V, 20% C839 290-0536-00 10 uF, Elect., 20 V, 20% C839 290-0527-00 15 uF, Elect., 20 V, 20% C837 281-0524-00 10 uF, Elect., 20 V, 20% C839 290-0527-00 15 uF, Elect., 20 V, 20% C1002 283-0178-00 0.1 uF, Cer, 150 V C1003 281-0629-00 33 pF, Cer, 500 V, 5% C1007 281-0511-00 0.02 uF, Cer, 150 V, 20% C1032 281-0629-00 18 uF, Cer, 500 V, 5% C1032 281-0629-00 33 PF, Cer, 500 V, 5% C1033 281-0637-00 91 P	Ckt. No.	Part No.	Eff Disc	Description
C676 281-0646-00 B010805 S1 pF, (nominal value), selected C676 281-0626-00 B010805 S1 pF, (nominal value), selected C680 283-0024-00 B010100 B010852 O.1 uF, Cer, 350 V, +808-208 C690 283-0024-00 B010353 O.1 uF, Cer, 35 V, +808-208 C697 283-0023-00 B010353 O.1 uF, Cer, 25 V, +808-208 C699 283-0023-00 B010353 O.1 uF, Cer, 25 V, +808-208 C699 283-0023-00 B010353 O.1 uF, Cer, 25 V, +808-208 C699 283-0023-00 B010353 O.1 uF, Cer, 25 V, +808-208 C699 283-0023-00 B010353 O.1 uF, Cer, 50 V, 58 C808 281-0577-00 14 pF, Cer, 500 V, 58 C824 281-0523-00 100 pF, Cer, 350 V, 208 C829 290-0527-00 15 uF, Elect., 20 V, 208 C836 290-0527-00 15 uF, Elect., 20 V, 208 C837 281-0524-00 10 uF, Cer, 500 V, 58 C838 281-0577-00 15 uF, Elect., 20 V, 208 C837 290-0527-00 15 uF, Elect., 20 V, 208 C837 290-0527-00 15 uF, Elect., 20	CAPACITORS	(cont)		
C676 281-0540-00 B01000 S1 pF, (nominal value), selected C664 281-0626-00 B010100 B010352 0.1 uF, Cer, 25 V, +808-208 C690 283-0024-00 B010100 B010353 0.1 uF, Cer, 25 V, +808-208 C697 283-0023-00 B010100 B010353 0.1 uF, Cer, 10 V, +808-208 C697 283-0023-00 B010105 B010353 0.1 uF, Cer, 10 V, +808-208 C699 283-0023-00 B010105 B010353 0.1 uF, Cer, 10 V, +808-208 C605 290-0527-00 15 uF, Elect., 20 V, 208 282 C806 281-0577-00 14 pF, Cer, 500 V, 5% 208 C826 281-0527-00 15 uF, Elect., 20 V, 208 208 C826 281-0527-00 15 uF, Elect., 20 V, 208 208 C833 290-0527-00 15 uF, Elect., 20 V, 208 208 C834 290-0527-00 15 uF, Elect., 20 V, 208 208 C835 290-0527-00 15 uF, Elect., 20 V, 208 208 C836 281-0527-00 14 pF, Cer, 500 V, 208 208	C676	281-0646-00	B010100 B010804	88 pF, Cer, 500 V, 5%
C684 281-0626-00 B010100 B0108103 2.3 pF, Cer, 500 V, 5% C690 283-0024-00 B010352 0.1 uF, Cer, 35 V, +80%-20% C697 283-0024-00 B010353 0.1 uF, Cer, 35 V, +80%-20% C697 283-0023-00 B010353 0.1 uF, Cer, 25 V, +80%-20% C697 283-0023-00 B010353 0.1 uF, Cer, 25 V, +80%-20% C699 283-0023-00 B010353 0.1 uF, Cer, 25 V, +80%-20% C699 283-0023-00 B010353 0.1 uF, Cer, 50 V, 5% C808 281-0577-00 14 pF, Cer, 500 V, 5% C808 281-0523-00 100 pF, Cer, 350 V, 20% C829 290-0527-00 15 uF, Elect., 20 V, 20% C835 290-0527-00 15 uF, Elect., 20 V, 20% C836 281-0577-00 15 uF, Elect., 20 V, 20% C837 281-0524-00 10 uF, Cer, 500 V, 20% C838 281-0577-00 15 uF, Elect., 20 V, 20% C853 290-0527-00 15 uF, Elect., 20 V, 20% C854 281-0577-00 14 pF, Cer, 500 V, 50% C857 290-05	C676	281-0540-00	B010805	51 pF, (nominal value), selected
CCS0 283-0081-00 BOI0352 0.1 UP, Cer, 25 V, +808-208 CG00 283-0024-00 BOI0353 0.1 UP, Cer, 25 V, +808-208 CG07 283-0081-00 BOI0100 BOI0353 0.1 UP, Cer, 25 V, +808-208 CG97 283-0023-00 BOI01353 0.1 UP, Cer, 25 V, +808-208 CG99 283-0023-00 BOI01353 0.1 UP, Cer, 10 V, +808-208 C699 283-0023-00 BOI0353 0.1 UP, Cer, 350 V, 208 C805 290-0527-00 15 UP, Elect., 20 V, 208 288 C824 281-0511-00 22 PF, Cer, 530 V, 108 C826 281-0527-00 15 UP, Elect., 20 V, 208 C826 281-0527-00 15 UP, Elect., 20 V, 208 C833 290-0527-00 15 UP, Elect., 20 V, 208 C835 290-0527-00 15 UP, Elect., 20 V, 208 C837 281-0524-00 0.1 UF, Cer, 500 V, 208 C833 290-0527-00 15 UP, Elect., 20 V, 208 C833 290-0527-00 15 UP, Elect., 20 V, 208 C877 281-0528-0	C684	281-0626-00	B010100 B010804X	3.3 pF. Cer. 500 V. 5%
C600 283-0024-00 B010353 C0.1 UF, Cer, 30 V, +808-208 C697 283-0023-00 B010100 B010352 C1 UF, Cer, 10 V, +808-208 C699 283-0023-00 B010100 B010353 C1 UF, Cer, 10 V, +808-208 C699 283-0023-00 B0101353 C1 UF, Cer, 10 V, +808-208 C699 283-0023-00 B010353 C1 UF, Cer, 10 V, +808-208 C805 290-0527-00 15 uF, Elect., 20 V, 208 C824 C824 281-0511-00 22 pF, Cer, 500 V, 10% C825 290-0527-00 15 uF, Elect., 20 V, 208 C834 290-0527-00 15 uF, Elect., 20 V, 208 C835 290-0527-00 15 uF, Elect., 20 V, 208 C835 290-0527-00 15 uF, Elect., 20 V, 208 C835 290-0527-00 15 uF, Elect., 20 V, 208 C837 281-0521-00 15 uF, Elect., 20 V, 208 C837 281-0527-00 15 uF, Elect., 20 V, 208 C877 290-0527-00 15 uF, Elect., 20 V, 208 C873 290-0527-00 <th< td=""><td>C690</td><td>283-0081-00</td><td>B010100 B010352</td><td>0.1 uF. Cer. 25 V. +80%-20%</td></th<>	C690	283-0081-00	B010100 B010352	0.1 uF. Cer. 25 V. +80%-20%
C630 283-0081-00 B0101352 0.1 uF, Cer, 25 V, +808-208 C697 283-0023-00 B0100353 0.1 uF, Cer, 10 V, +808-208 C699 283-0023-00 B0100353 0.1 uF, Cer, 25 V, +808-208 C699 283-0023-00 B0100353 0.1 uF, Cer, 10 V, +808-208 C699 283-0023-00 B010353 0.1 uF, Cer, 10 V, +808-208 C805 290-0527-00 14 uF, Cer, 500 V, 5% C804 281-0511-00 22 pF, Cer, 500 V, 10% C824 281-0522-00 47 uF, Elect., 20 V, 208 C825 290-0527-00 15 uF, Elect., 20 V, 20% C834 290-0527-00 15 uF, Elect., 20 V, 20% C835 290-0527-00 15 uF, Elect., 20 V, 20% C836 290-0527-00 15 uF, Elect., 20 V, 20% C837 281-0524-00 150 pF, Cer, 500 V, 20% C838 281-0577-00 14 uF, Elect., 20 V, 20% C858 290-0527-00 15 uF, Elect., 20 V, 20% C857 281-0577-00 14 pF, Cer, 500 V, 5% C874 290-0527-00 15 uF, Elect., 20 V, 20% C877 281-058-00 12 pF, Cer, 500 V, 20%	6690	203 0001 00	P010253	0.1 wF Cor $30 \text{ W} \pm 909 - 209$
C697 223-0023-00 BO10352 0.1 UF, Cer, 10 V, +808-208 C699 283-0023-00 BO10353 0.1 UF, Cer, 10 V, +808-208 C699 283-0023-00 BO10353 0.1 UF, Cer, 10 V, +808-208 C609 283-0023-00 BO10353 0.1 UF, Cer, 10 V, +808-208 C805 290-0527-00 15 UF, Elect., 20 V, 208 C824 281-0511-00 22 DF, Cer, 500 V, 108 C825 290-0527-00 15 UF, Elect., 20 V, 208 C835 290-0527-00 15 UF, Elect., 20 V, 208 C835 290-0527-00 15 UF, Elect., 20 V, 208 C836 290-0527-00 15 UF, Elect., 20 V, 208 C837 281-0577-00 15 UF, Elect., 20 V, 208 C838 281-0577-00 14 MF, Cer, 500 V, 5% C847 290-0527-00 15 UF, Elect., 20 V, 208 C858 281-0577-00 14 MF, Cer, 500 V, 5% C877 290-0527-00 15 UF, Elect., 20 V, 208 C877 290-0527-00 15 UF, Elect., 20 V, 208		203-0024-00	D010333	0.1 ur, Cer, 50 v, +008-208
C697 283-0023-00 B010353 D.1 UF, Cer, 10 V, +808-208 C699 283-0023-00 B010353 D.1 UF, Cer, 10 V, +808-208 C699 283-0023-00 B010353 D.1 UF, Cer, 10 V, +808-208 C805 290-0527-00 14 µF, Cer, 500 V, 5% C824 281-0511-00 22 µF, Cer, 500 V, 10% C826 281-0523-00 40 µF, Elect., 20 V, 20% C826 281-0527-00 15 uF, Elect., 20 V, 20% C834 290-0527-00 15 uF, Elect., 20 V, 20% C835 290-0527-00 15 uF, Elect., 20 V, 20% C836 290-0527-00 15 uF, Elect., 20 V, 20% C837 281-0524-00 10 uF, Elect., 20 V, 20% C838 280-0527-00 15 uF, Elect., 20 V, 20% C853 290-0527-00 15 uF, Elect., 20 V, 20% C854 281-0577-00 14 µF, Cer, 500 V, 20% C857 290-0527-00 15 uF, Elect., 20 V, 20% C858 281-0577-00 15 uF, Elect., 20 V, 20% C877 281-0508-00 12 µF, Cer, 500 V, 20% C891 290-0527-00	0697	283-0081-00	B010100 B010352	0.1 ur, Cer, 25 v, +808-208
C699 283-0081-00 B010100 B010353 0.1 uF, Cer, 25 V, +80%-20% C699 283-0023-00 B010353 0.1 uF, Cer, 10 V, +80%-20% C805 290-0527-00 15 uF, Elect., 20 V, 20% C824 281-0577-00 14 pF, Cer, 500 V, 5% C824 281-0523-00 100 pF, Cer, 350 V, 20% C829 290-0527-00 15 uF, Elect., 20 V, 20% C835 290-0527-00 15 uF, Elect., 20 V, 20% C836 290-0527-00 15 uF, Elect., 20 V, 20% C837 281-0524-00 150 pF, Cer, 500 V, 5% C838 290-0527-00 15 uF, Elect., 20 V, 20% C837 281-0524-00 10 uF, Elect., 20 V, 20% C858 281-0577-00 15 uF, Elect., 20 V, 20% C855 290-0527-00 15 uF, Elect., 20 V, 20% C874 290-0527-00 12 uF, Cer, 500 V, 5% C879 290-0527-00 12 uF, Elect., 20 V, 20% C879 290-0527-00 12 uF, Elect., 20 V, 20% C879 290-0527-00 15 uF, Elect., 20 V, 20% C891 290-0527-00 15 uF, Elect., 20 V, 20% C893 290-0527-00	C697	283-0023-00	B010353	0.1 ur, Cer, 10 V, +808-208
C699 283-0023-00 B010353 0.1 uF, Cer, 10 V, +808-20% C805 290-0527-00 15 uF, Elect., 20 V, 20% C806 281-0511-00 22 pF, Cer, 500 V, 10% C826 281-0523-00 100 pF, Cer, 350 V, 20% C828 290-0523-00 47 uF, Elect., 20 V, 20% C834 290-0527-00 15 uF, Elect., 20 V, 20% C835 290-0527-00 15 uF, Elect., 20 V, 20% C836 290-0527-00 15 uF, Elect., 20 V, 20% C837 281-0524-00 150 pF, Cer, 300 V, 480%-20% C839 290-0536-00 10 uF, Elect., 25 V, 20% C839 290-0527-00 15 uF, Elect., 20 V, 20% C858 281-0577-00 15 uF, Elect., 20 V, 20% C877 281-0508-00 12 uF, Cer, 500 V, 20% C877 290-0527-00 15 uF, Elect., 20 V, 20% C879 290-0527-00 15 uF, Elect., 20 V, 20% C891 290-0527-00 15 uF, Elect., 20 V, 20% C893 290-0527-00 15 uF, Elect., 20 V, 20% C894 290-0527-00 15 uF, Elect., 20 V, 20% C895 290-0527-00 15 uF, Elect., 20 V, 20% <	C699	283-0081-00	B010100 B010352	0.1 uF, Cer, 25 V, +80%-20%
C805 290-0527-00 15 uF, Elect., 20 V, 20% C808 281-0511-00 22 pF, Cer, 500 V, 10% C824 281-0511-00 22 pF, Cer, 350 V, 20% C826 281-0523-00 100 pF, Cer, 350 V, 20% C827 290-0529-00 47 uF, Elect., 20 V, 20% C835 290-0527-00 15 uF, Elect., 20 V, 20% C836 290-0527-00 15 uF, Elect., 20 V, 20% C837 281-0524-00 150 pF, Cer, 300 V, 480%-20% C838 281-057-00 15 uF, Elect., 20 V, 20% C839 290-0536-00 10 uF, Elect., 20 V, 20% C839 290-0527-00 15 uF, Cer, 500 V, 20% C855 290-0527-00 15 uF, Elect., 20 V, 20% C874 290-0527-00 15 uF, Elect., 20 V, 20% C877 281-0570 15 uF, Elect., 20 V, 20% C879 290-0527-00 15 uF, Elect., 20 V, 20% C879 290-0527-00 15 uF, Elect., 20 V, 20% C893 290-0527-00 15 uF, Elect., 20 V, 20% C893 290-0527-00 15 uF, Elect., 20 V, 20% C897	C699	283-0023-00	B010353	0.1 uF, Cer, 10 V, +80%-20%
C808 281-0577-00 14 pF, Cer, 500 V, 5% C824 281-0523-00 20 pF, Cer, 500 V, 20% C829 290-0527-00 15 uF, Elect., 20 V, 20% C835 290-0527-00 15 uF, Elect., 20 V, 20% C836 290-0527-00 15 uF, Elect., 20 V, 20% C837 281-0527-00 15 uF, Elect., 20 V, 20% C837 281-0527-00 15 uF, Elect., 20 V, 20% C837 281-0527-00 15 uF, Elect., 20 V, 20% C839 290-0536-00 10 uF, Cer, 500 V, 20% C853 283-0024-00 0.1 uF, Cer, 30 V, 48%-20% C855 290-0527-00 15 uF, Elect., 20 V, 20% C858 281-0577-00 14 pF, Cer, 500 V, 20% C874 290-0527-00 15 uF, Elect., 20 V, 20% C877 281-0508-00 12 pF, Cer, 500 V, 20% C879 290-0527-00 15 uF, Elect., 20 V, 20% C891 290-0527-00 15 uF, Elect., 20 V, 20% C892 290-0527-00 15 uF, Elect., 20 V, 20% C893 290-0527-00 15 uF, Elect., 20 V, 20% C1002 283-0044-00 0.02 uF, Cer, 150 V C1003	C805	290-0527-00	1	15 uF, Elect., 20 V, 20%
C824 281-0511-00 22 pF, Cer, 500 V, 10% C826 281-0523-00 100 pF, Cer, 350 V, 20% C834 290-0527-00 15 uF, Elect., 20 V, 20% C834 290-0527-00 15 uF, Elect., 20 V, 20% C835 290-0527-00 15 uF, Elect., 20 V, 20% C836 290-0527-00 15 uF, Elect., 20 V, 20% C837 281-0524-00 15 uF, Elect., 20 V, 20% C839 290-0536-00 10 uF, Elect., 25 V, 20% C835 290-0527-00 15 uF, Elect., 20 V, 20% C858 281-0577-00 15 uF, Elect., 20 V, 20% C858 281-0577-00 15 uF, Elect., 20 V, 20% C877 281-0508-00 12 pF, Cer, 500 V, 20% C879 290-0527-00 15 uF, Elect., 20 V, 20% C891 290-0527-00 15 uF, Elect., 20 V, 20% C896 290-0527-00 15 uF, Elect., 20 V, 20% C1002 283-0178-00 0.1 uF, Cer, 100 V, +80%-20% C1002 283-0178-00 0.1 uF, Cer, 100 V, +80%-20% C1003 281-0627-00 15 uF, Elect., 20 V, 20% C1004 0.03 20-0527-00 15 uF, Elect., 20 V, 20%	C808	281-0577-00	I	14 pF, Cer, 500 V, 5%
C826 281-0523-00 100 pr. Cer, 350 V, 20% C829 290-0529-00 47 uF, Elect., 20 V, 20% C834 290-0527-00 15 uF, Elect., 20 V, 20% C835 290-0527-00 15 uF, Elect., 20 V, 20% C836 290-0527-00 15 uF, Elect., 20 V, 20% C837 281-0524-00 15 uF, Elect., 20 V, 20% C838 283-0024-00 0.1 uF, Cer, 500 V, 20% C855 290-0527-00 15 uF, Elect., 20 V, 20% C858 281-0577-00 15 uF, Elect., 20 V, 20% C858 281-0577-00 15 uF, Elect., 20 V, 20% C874 290-0527-00 15 uF, Elect., 50 V, 20% C874 290-0527-00 15 uF, Elect., 50 V, 20% C879 290-0527-00 15 uF, Elect., 20 V, 20% C891 290-0527-00 15 uF, Elect., 20 V, 20% C897 290-0527-00 15 uF, Elect., 20 V, 20% C1002 283-0024-00 0.0 2 uF, Cer, 150 V C1002 283-0027-00 15 uF, Elect., 20 V, 20% C1002 283-0027-00 15 uF, Elect., 20 V, 20% C1002 283-0027-00 15 uF, Elect., 20 V, 20% C10	C824	281-0511-00		22 pF, Cer, 500 V, 10%
C829 200-0529-00 47 uF, Elect., 20 V, 20% C834 290-0527-00 15 uF, Elect., 20 V, 20% C835 290-0527-00 15 uF, Elect., 20 V, 20% C836 290-0527-00 15 uF, Elect., 20 V, 20% C837 281-0524-00 15 uF, Elect., 20 V, 20% C839 290-0536-00 10 uF, Elect., 20 V, 20% C839 290-0527-00 15 uF, Elect., 20 V, 20% C858 281-0577-00 15 uF, Elect., 20 V, 20% C858 281-0577-00 15 uF, Elect., 20 V, 20% C877 281-0527-00 15 uF, Elect., 20 V, 20% C879 290-0527-00 15 uF, Elect., 20 V, 20% C879 290-0527-00 15 uF, Elect., 20 V, 20% C891 290-0527-00 15 uF, Elect., 20 V, 20% C893 290-0527-00 15 uF, Elect., 20 V, 20% C1000 283-004-00 0.02 uF, Cer, 150 V C1001 283-004-00 0.1 uF, Cer, 100 V, +80%-20% C1002 283-004-00 0.1 uF, Cer, 100 V, +80%-20% C1003 281-0637-00 91 pF, Cer, 350 V, 20% C1005 281-0629-00 33 pF, Cer, 600 V, 5% C	C826	281-0523-00	1	100 pF, Cer, 350 V, 20%
C834290-0527-0015 uF, Elect., 20 V, 20%C835290-0527-0015 uF, Elect., 20 V, 20%C837281-0524-0015 uF, Elect., 20 V, 20%C837281-0524-00150 pF, Cer, 500 V, 20%C839290-0527-0015 uF, Elect., 25 V, 20%C853283-0024-000.1 uF, Cer, 30 V, +80%-20%C855290-0527-0015 uF, Elect., 20 V, 20%C858281-0577-0014 pF, Cer, 500 V, 5%C874290-0527-0015 uF, Elect., 20 V, 20%C875290-0527-0012 pF, Cer, 500 V, 20%C876290-0527-0012 uF, Elect., 20 V, 20%C891290-0527-0015 uF, Elect., 20 V, 20%C893290-0527-0015 uF, Elect., 20 V, 20%C894290-0527-0015 uF, Elect., 20 V, 20%C895290-0527-0015 uF, Elect., 20 V, 20%C1002283-0178-000.1 uF, Cer, 100 V, +80%-20%C1003281-0629-0033 pF, Cer, 500 V, 5%C1005281-0629-0033 pF, Cer, 500 V, 5%C1017281-0511-0022 pF, Cer, 500 V, 10%C1024290-0527-0015 uF, Elect., 20 V, 20%C1031283-0004-000.02 uF, Cer, 150 VC1032283-0023-0018 pF, Cer, 500 V, 5%C1033281-0678-0018 pF, Cer, 500 V, 5%C1034290-0527-0015 uF, Elect., 20 V, 20%C1035281-0678-0018 pF, Cer, 100 V, +80%-20%C1036281-0578-0018 pF, Cer, 100 V, 5%C1038290-0527-0015 uF, Elect., 20 V, 20%C1038<	C829	290-0529-00	1	47 uF. Elect., 20 V. 20%
C834290-0527-0015 uF, Elect., 20 V, 20%C836290-0527-0015 uF, Elect., 20 V, 20%C837281-0524-00150 pF, Cer, 500 V, 20%C839290-0536-0010 uF, Elect., 25 V, 20%C853283-0024-000.1 uF, Cer, 30 V, 480%-20%C855290-0527-0015 uF, Elect., 20 V, 20%C858281-0577-0014 pF, Cer, 500 V, 5%C874290-0527-0015 uF, Elect., 20 V, 20%C879290-0527-0015 uF, Elect., 20 V, 20%C891290-0527-0015 uF, Elect., 20 V, 20%C893290-0527-0015 uF, Elect., 20 V, 20%C894290-0527-0015 uF, Elect., 20 V, 20%C895290-0527-0015 uF, Elect., 20 V, 20%C896290-0527-0015 uF, Elect., 20 V, 20%C1000283-0004-000.02 uF, Cer, 150 VC1002283-0178-000.1 uF, Cer, 100 V, +80%-20%C1005281-0629-0033 pF, Cer, 600 V, 5%C1005281-0629-0033 pF, Cer, 100 V, +80%-20%C1024290-0527-0015 uF, Elect., 20 V, 20%C1024290-0527-0015 uF, Elect., 20 V, 20%C1025281-0629-0033 pF, Cer, 500 V, 5%C1031283-004-000.02 uF, Cer, 150 VC1032281-0578-0018 pF, Cer, 500 V, 5%C1033290-0527-0015 uF, Elect., 20 V, 20%C1034290-0527-0015 uF, Elect., 20 V, 20%C1035281-0678-0018 pF, Cer, 100 V, +80%-20%C1036281-0578-0018 pF, Cer, 100 V, 5%C1038<	C834	290-0527-00		15 ur, Elect, 20 V, 20%
C 833250-0527-0015 uF, Elect., 20 V, 20%C 837281-0524-00150 pF, Cer, 500 V, 20%C 837281-0524-00150 pF, Cer, 500 V, 20%C 853283-0024-000.1 uF, Elect., 25 V, 20%C 853283-0024-000.1 uF, Cer, 30 V, +80%-20%C 855290-0527-0015 uF, Elect., 20 V, 20%C 856281-0577-0014 pF, Cer, 500 V, 20%C 877281-0508-0012 pF, Cer, 500 V, 20%C 879290-0527-0015 uF, Elect., 20 V, 20%C 893290-0527-0015 uF, Elect., 20 V, 20%C 893290-0527-0015 uF, Elect., 20 V, 20%C 896290-0527-0015 uF, Elect., 20 V, 20%C 897290-0527-0015 uF, Elect., 20 V, 20%C 896290-0527-0015 uF, Elect., 20 V, 20%C 1000283-004-000.02 uF, Cer, 150 VC 1002283-0178-000.1 uF, Cer, 100 V, +80%-20%C 1017281-0637-0031 pF, Cer, 500 V, 5%C 1017281-0511-0022 pF, Cer, 500 V, 10%C 1024290-0527-0015 uF, Elect., 20 V, 20%C 1025281-0623-000.02 uF, Cer, 150 VC 1026281-0523-00100 pF, Cer, 350 V, 20%C 1038290-0527-0015 uF, Elect., 20 V, 20%C 1036281-0578-0018 pF, Cer, 500 V, 5%C 1038290-0527-0015 uF, Elect., 20 V, 20%C 1036281-0578-0018 pF, Cer, 10 V, +80%-20%C 1038290-0527-0015 uF, Elect., 20 V, 20%C 1036281-0637-0091 pF, Cer, 500 V, 5% </td <td>C035</td> <td>290-0527-00</td> <td></td> <td>15 ur, $11 ecc.$, $20 v$, 200</td>	C035	290-0527-00		15 ur, $11 ecc.$, $20 v$, 200
C835 290-0527-00 15 UF, Elect., 20 V, 20% C837 281-0524-00 150 pF, Cer, 500 V, 20% C839 290-0536-00 0.1 UF, Elect., 25 V, 20% C853 283-0024-00 0.1 UF, Cer, 30 V, +80%-20% C855 290-0527-00 15 UF, Elect., 20 V, 20% C874 290-0527-00 15 UF, Elect., 20 V, 20% C877 281-0508-00 12 pF, Cer, 500 V, 20% C879 290-0527-00 15 UF, Elect., 20 V, 20% C891 290-0527-00 15 UF, Elect., 20 V, 20% C893 290-0527-00 15 UF, Elect., 20 V, 20% C893 290-0527-00 15 UF, Elect., 20 V, 20% C893 290-0527-00 15 UF, Elect., 20 V, 20% C894 290-0527-00 15 UF, Elect., 20 V, 20% C1000 283-0178-00 0.1 UF, Cer, 100 V, +80%-20% C1001 283-0178-00 0.1 UF, Cer, 500 V, 5% C1002 283-0178-00 3 pF, Cer, 500 V, 10% C1017 281-0511-00 22 pF, Cer, 500 V, 10% C1024 290-0527-00 15 UF, Elect., 20 V, 20% C1031 283-0004-00 0.02 UF, Cer, 150 V C1	0000	290-0527-00		15 ur, Elect., 20 v, 208
C837 281-0524-00 150 pF, CeF, 500 V, 20% C839 290-0536-00 10 uF, Elect., 25 V, 20% C853 283-0024-00 0.1 uF, Cer, 30 V, +80%-20% C855 290-0527-00 15 uF, Elect., 20 V, 20% C874 290-0527-00 15 uF, Elect., 20 V, 20% C877 281-0508-00 12 pF, Cer, 500 V, 20% C879 290-0527-00 15 uF, Elect., 20 V, 20% C891 290-0527-00 15 uF, Elect., 20 V, 20% C893 290-0527-00 15 uF, Elect., 20 V, 20% C894 290-0527-00 15 uF, Elect., 20 V, 20% C895 290-0527-00 15 uF, Elect., 20 V, 20% C896 290-0527-00 15 uF, Elect., 20 V, 20% C1000 283-004-00 0.02 uF, Cer, 150 V C1001 281-0637-00 91 pF, Cer, 500 V, 5% C1003 281-0637-00 10 uF, Elect., 20 V, 20% C1024 290-0527-00 15 uF, Elect., 20 V, 20% C1025 281-0523-00 0.02 uF, Cer, 150 V C1026 281-0523-00 100 pF, Cer, 350 V, 20% C1036 281-0578-00 18 pF, Cer, 500 V, 5% C1038	0836	290-0527-00		15 uF, Elect., 20 V, 208
C839 290-0536-00 10 uF, Elect., 25 V, 20% C853 283-0024-00 0.1 uF, Cer, 30 V, +80%-20% C855 290-0527-00 15 uF, Elect., 20 V, 20% C858 281-0577-00 14 pF, Cer, 500 V, 2% C874 290-0527-00 15 uF, Elect., 20 V, 20% C877 281-0508-00 12 pF, Cer, 500 V, 20% C879 290-0527-00 15 uF, Elect., 20 V, 20% C891 290-0527-00 15 uF, Elect., 20 V, 20% C893 290-0527-00 15 uF, Elect., 20 V, 20% C893 290-0527-00 15 uF, Elect., 20 V, 20% C894 290-0527-00 15 uF, Elect., 20 V, 20% C1000 283-004-00 0.02 uF, Cer, 150 V C1001 283-004-00 0.1 uF, Cer, 500 V, 5% C1002 283-004-00 0.2 uF, Cer, 150 V C1021 283-004-00 0.02 uF, Cer, 150 V C1024 290-0527-00 15 uF, Elect., 20 V, 20% C1024 281-0578-00 18 pF, Cer, 500 V, 10% C1025 281-0523-00 100 pF, Cer, 350 V, 20% C1026 281-0578-00 18 pF, Cer, 500 V, 5% C1026 28	0837	281-0524-00		150 pr, Cer, 500 V, 20%
C853283-0024-000.1 uF, Cer, 30 V, +80%-20%C855290-0527-0015 uF, Elect., 20 V, 20%C858281-0577-0014 pF, Cer, 500 V, 5%C874290-0527-0015 uF, Elect., 20 V, 20%C877281-0508-0012 pF, Cer, 500 V, 20%C879290-0527-001 uF, Elect., 20 V, 20%C891290-0527-0015 uF, Elect., 20 V, 20%C893290-0527-0015 uF, Elect., 20 V, 20%C894290-0527-0015 uF, Elect., 20 V, 20%C895290-0527-0015 uF, Elect., 20 V, 20%C896290-0527-0015 uF, Elect., 20 V, 20%C1000283-004-000.02 uF, Cer, 150 VC1001283-0178-000.1 uF, Cer, 100 V, +80%-20%C1003281-0637-0031 pF, Cer, 500 V, 5%C1005281-0629-0033 pF, Cer, 600 V, 5%C1017281-0511-0022 pF, Cer, 350 V, 20%C1031283-004-000.02 uF, Cer, 150 VC1032281-0578-0015 uF, Elect., 20 V, 20%C1033281-0578-0015 uF, Elect., 20 V, 20%C1034290-0527-0015 uF, Elect., 20 V, 20%C1035281-0578-0018 pF, Cer, 500 V, 5%C1036281-0578-0015 uF, Elect., 20 V, 20%C1039283-0023-000.1 uF, Cer, 100 V, +80%-20%C1062283-0178-000.1 uF, Cer, 100 V, +80%-20%C1063281-0637-0091 pF, Cer, 500 V, 5%C1063281-0637-0091 pF, Cer, 500 V, 5%C1064290-0527-0033 pF, Cer, 600 V, 5%C1065 <t< td=""><td>C839</td><td>290-0536-00</td><td>1</td><td>10 uF, Elect., 25 V, 20%</td></t<>	C839	290-0536-00	1	10 uF, Elect., 25 V, 20%
C855 290-0527-00 15 uF, Elect., 20 V, 20% C858 281-0577-00 14 pF, Cer, 500 V, 5% C874 290-0527-00 15 uF, Elect., 20 V, 20% C877 281-0508-00 12 pF, Cer, 500 V, 20% C879 290-0527-00 1 uF, Elect., 20 V, 20% C891 290-0527-00 15 uF, Elect., 20 V, 20% C893 290-0527-00 15 uF, Elect., 20 V, 20% C896 290-0527-00 15 uF, Elect., 20 V, 20% C897 290-0527-00 15 uF, Elect., 20 V, 20% C1000 283-004-00 0.02 uF, Cer, 150 V C1001 281-0637-00 91 pF, Cer, 500 V, 5% C1002 281-0629-00 33 pF, Cer, 600 V, 5% C1003 281-0629-00 33 pF, Cer, 500 V, 10% C1021 283-004-00 0.02 uF, Cer, 150 V C1024 290-0527-00 15 uF, Elect., 20 V, 20% C1031 283-004-00 0.02 uF, Cer, 150 V C1032 281-0523-00 100 pF, Cer, 350 V, 20% C1034 290-0527-00 15 uF, Elect., 20 V, 20% C1035 281-0523-00 100 pF, Cer, 150 V C1038 290-0527-	C853	283-0024-00	1	0.1 uF, Cer, 30 V, +80%-20%
C858 281-0577-00 14 pF, Cer, 500 V, 5% C874 290-0527-00 15 uF, Elect., 20 V, 20% C877 281-0508-00 12 pF, Cer, 500 V, 20% C879 290-0522-00 1 uF, Elect., 50 V, 20% C891 290-0527-00 15 uF, Elect., 20 V, 20% C893 290-0527-00 15 uF, Elect., 20 V, 20% C896 290-0527-00 15 uF, Elect., 20 V, 20% C1000 283-004-00 0.02 uF, Cer, 150 V C1001 283-0178-00 0.1 uF, Cer, 100 V, +80%-20% C1002 283-0178-00 0.1 uF, Cer, 500 V, 5% C1003 281-0637-00 91 pF, Cer, 500 V, 5% C1005 281-0637-00 91 pF, Cer, 500 V, 10% C1017 281-0511-00 22 pF, Cer, 500 V, 10% C1024 290-0527-00 15 uF, Elect., 20 V, 20% C1031 283-0004-00 0.02 uF, Cer, 150 V C1034 290-0527-00 15 uF, Elect., 20 V, 20% C1035 281-0578-00 18 pF, Cer, 500 V, 5% C1036 281-0578-00 18 pF, Cer, 100 V, +80%-20% C1038 290-0527-00 15 uF, Elect., 20 V, 20% C1038	C855	290-0527-00	1	15 uF, Elect., 20 V, 20%
C874 290-0527-00 15 uF, Elect., 20 V, 20% C877 281-0508-00 12 pF, Cer, 500 V, 20% C879 290-0522-00 1 uF, Elect., 50 V, 20% C891 290-0527-00 15 uF, Elect., 20 V, 20% C893 290-0527-00 15 uF, Elect., 20 V, 20% C896 290-0527-00 15 uF, Elect., 20 V, 20% C897 290-0527-00 15 uF, Elect., 20 V, 20% C1000 283-004-00 0.02 uF, Cer, 150 V C1001 283-0178-00 0.1 uF, Cer, 100 V, +80%-20% C1003 281-0637-00 91 pF, Cer, 500 V, 5% C1005 281-0629-00 33 pF, Cer, 600 V, 5% C1007 283-0004-00 0.02 uF, Cer, 150 V C1017 281-0511-00 22 pF, Cer, 500 V, 10% C1024 290-0527-00 15 uF, Elect., 20 V, 20% C1031 283-0004-00 0.02 uF, Cer, 150 V C1032 281-0523-00 100 pF, Cer, 350 V, 20% C1033 281-0578-00 18 pF, Cer, 500 V, 5% C1036 281-0578-00 18 pF, Cer, 100 V, +80%-20% C1038 290-0527-00 15 uF, Elect., 20 V, 20% C1039	C858	281-0577-00		14 pF. Cer. $500 V. 58$
C877281-0508-0012 pF, Cer, 500 V, 20%C879290-0522-001 uF, Elect., 50 V, 20%C891290-0527-0015 uF, Elect., 20 V, 20%C893290-0527-0015 uF, Elect., 20 V, 20%C896290-0527-0015 uF, Elect., 20 V, 20%C897290-0527-0015 uF, Elect., 20 V, 20%C1000283-0004-000.02 uF, Cer, 150 VC1002283-0178-000.1 uF, Cer, 100 V, +80%-20%C1003281-0637-0091 pF, Cer, 500 V, 5%C1017281-0511-0022 pF, Cer, 500 V, 10%C1021283-0004-000.02 uF, Cer, 150 VC1024290-0527-0015 uF, Elect., 20 V, 20%C1025281-0523-00100 pF, Cer, 350 V, 20%C1026281-0523-00100 pF, Cer, 350 V, 20%C1038290-0527-0015 uF, Elect., 20 V, 20%C1039283-0023-000.1 uF, Cer, 150 VC1039283-0023-000.1 uF, Cer, 100 V, +80%-20%C1062283-0178-000.1 uF, Cer, 100 V, +80%-20%C1063281-0637-0091 pF, Cer, 500 V, 5%C1065281-0637-0091 pF, Cer, 600 V, 5%C1065281-0637-0033 pF, Cer, 600 V, 5%C1065281-0637-0032 pF, Cer, 500 V, 5%	C874	290-0527-00		15 uF, Elect, 20 V, 208
C877281-0308-0012 pr, Cer, 500 V, 20%C879290-0522-001 uF, Elect., 50 V, 20%C891290-0527-0015 uF, Elect., 20 V, 20%C893290-0527-0015 uF, Elect., 20 V, 20%C896290-0527-0015 uF, Elect., 20 V, 20%C1000283-0004-000.02 uF, Cer, 150 VC1002283-0178-000.1 uF, Cer, 100 V, +80%-20%C1003281-0637-0091 pF, Cer, 500 V, 5%C1005281-0629-0033 pF, Cer, 600 V, 5%C1017281-0511-0022 pF, Cer, 150 VC1024290-0527-0015 uF, Elect., 20 V, 20%C1035281-0523-00100 pF, Cer, 350 V, 20%C1036281-0523-00100 pF, Cer, 350 V, 20%C1038290-0527-0015 uF, Elect., 20 V, 20%C1038290-0527-0015 uF, Cer, 150 VC1039283-0023-000.1 uF, Cer, 100 V, +80%-20%C1062283-0178-000.1 uF, Cer, 100 V, +80%-20%C1063281-0637-0091 pF, Cer, 500 V, 5%C1065281-0629-0033 pF, Cer, 600 V, 5%C1065281-0637-0091 pF, Cer, 500 V, 5%C1065281-0637-0091 pF, Cer, 500 V, 5%C1065281-0637-0091 pF, Cer, 500 V, 5%C1065281-0629-0033 pF, Cer, 600 V, 5%C1065281-0511-0022 pF, Cer, 500 V, 10%	C074	291-0509-00		12 pF Cor 500 V 208
C879290-0527-001 ur, Elect., 50 V, 20%C891290-0527-0015 ur, Elect., 20 V, 20%C893290-0527-0015 ur, Elect., 20 V, 20%C896290-0527-0015 ur, Elect., 20 V, 20%C1000283-004-000.02 ur, Cer, 150 VC1002283-0178-000.1 ur, Cer, 100 V, +80%-20%C1003281-0637-0091 pr, Cer, 500 V, 5%C1005281-0629-0033 pr, Cer, 600 V, 5%C1017281-0511-0022 pr, Cer, 150 VC1024290-0527-0015 ur, Elect., 20 V, 20%C1025281-0523-000.02 ur, Cer, 150 VC1026281-0523-00100 pr, Cer, 350 V, 20%C1036281-0578-0018 pr, Cer, 500 V, 5%C1038290-0527-0015 ur, Elect., 20 V, 20%C1039283-0023-000.1 ur, Cer, 10 V, +80%-20%C1062283-0178-000.1 ur, Cer, 10 V, +80%-20%C1063281-0637-0091 pr, Cer, 500 V, 5%C1065281-0629-0033 pr, Cer, 600 V, 5%C1065281-0637-0091 pr, Cer, 500 V, 5%C1065281-0637-0091 pr, Cer, 500 V, 5%C1065281-0637-0091 pr, Cer, 500 V, 5%C1065281-0637-0091 pr, Cer, 600 V, 5%C1065281-0637-0091 pr, Cer, 500 V, 5%C1065281-0637-0091 pr, Cer, 500 V, 5%C1065281-0637-0091 pr, Cer, 500 V, 5%C1065281-0511-0022 pr. Cer, 600 V, 5%	0070	281-0308-00		12 pr, Cer, 500 v, 208
C891 $290-0527-00$ 15 uF, Elect., 20 V, 20%C893 $290-0527-00$ 15 uF, Elect., 20 V, 20%C896 $290-0527-00$ 15 uF, Elect., 20 V, 20%C1000 $283-0004-00$ 0.02 uF, Cer, 150 VC1002 $283-0178-00$ 0.1 uF, Cer, 100 V, $480\%-20\%$ C1003 $281-0637-00$ 91 pF, Cer, 500 V, 5%C1005 $281-0637-00$ 33 pF, Cer, 600 V, 5%C1005 $281-0637-00$ 22 pF, Cer, 500 V, 10%C1021 $283-0004-00$ 0.02 uF, Cer, 150 VC1024 $290-0527-00$ 15 uF, Elect., 20 V, 20%C1026 $281-0523-00$ 100 pF, Cer, 350 V, 20%C1036 $281-0523-00$ 100 pF, Cer, 150 VC1036 $281-0578-00$ 18 pF, Cer, 500 V, 5%C1038 $290-0527-00$ 15 uF, Elect., 20 V, 20%C1039 $283-0023-00$ 0.1 uF, Cer, 10 V, $480\%-20\%$ C1062 $283-0178-00$ 0.1 uF, Cer, 100 V, $480\%-20\%$ C1063 $281-0637-00$ 91 pF, Cer, 500 V, 5%C1065 $281-0629-00$ 33 pF, Cer, 600 V, 5%C1065 $281-0629-00$ 33 pF, Cer, 500 V, 5%C1065 $281-0637-00$ 91 pF, Cer, 500 V, 5%C1065 $281-0629-00$ 33 pF, Cer, 500 V, 5%C1065 $281-0637-00$ 22 pF, Cer, 500 V, 10%	C8/9			1 ur, Elect., 50 V, 208
C893 290-0527-00 15 uF, Elect., 20 V, 20% C896 290-0527-00 15 uF, Elect., 20 V, 20% C1000 283-0004-00 0.02 uF, Cer, 150 V C1002 283-0178-00 0.1 uF, Cer, 100 V, +80%-20% C1003 281-0637-00 91 pF, Cer, 500 V, 5% C1005 281-0637-00 91 pF, Cer, 600 V, 5% C1007 281-0511-00 22 pF, Cer, 500 V, 10% C1024 290-0527-00 15 uF, Elect., 20 V, 20% C1026 281-0523-00 0.02 uF, Cer, 150 V C1026 281-0523-00 100 pF, Cer, 350 V, 20% C1031 283-0004-00 0.02 uF, Cer, 150 V C1038 290-0527-00 15 uF, Elect., 20 V, 20% C1039 283-0023-00 100 pF, Cer, 500 V, 5% C1039 283-0023-00 0.1 uF, Cer, 10 V, +80%-20% C1062 283-0178-00 0.1 uF, Cer, 100 V, +80%-20% C1063 281-0637-00 91 pF, Cer, 500 V, 5% C1063 281-0637-00 91 pF, Cer, 500 V, 5% C1065 281-0637-00 91 pF, Cer, 600 V, 5% C1065 281-0637-00 33 pF, Cer, 600 V, 5% C1065	0891	290-0527-00		15 uF, Elect., 20 V, 208
C896290-0527-0015 uF, Elect., 20 V, 20%C897290-0527-0015 uF, Elect., 20 V, 20%C1000283-0004-000.02 uF, Cer, 150 VC1002283-0178-000.1 uF, Cer, 100 V, +80%-20%C1003281-0637-0091 pF, Cer, 500 V, 5%C1005281-0629-0033 pF, Cer, 600 V, 5%C1017281-0511-0022 pF, Cer, 500 V, 10%C1024290-0527-0015 uF, Elect., 20 V, 20%C1026281-0523-00100 pF, Cer, 350 V, 20%C1031283-0004-000.02 uF, Cer, 150 VC1036281-0578-0018 pF, Cer, 500 V, 5%C1039283-0023-000.1 uF, Cer, 10 V, +80%-20%C1062283-0178-000.1 uF, Cer, 100 V, +80%-20%C1063281-0637-0091 pF, Cer, 500 V, 5%C1065281-0629-0033 pF, Cer, 600 V, 5%C1065281-0629-0033 pF, Cer, 500 V, 5%C1065281-0529-0033 pF, Cer, 500 V, 5%C1065281-0529-0033 pF, Cer, 500 V, 5%C1065281-0529-0032 pF, Cer, 500 V, 5%C1065281-0529-0033 pF, Cer, 500 V, 5%C1065281-0529-0032 pF, Cer, 500 V, 5%	C893	290-0527-00		15 uF, Elect., 20 V, 20%
C897 290-0527-00 15 uF, Elect., 20 V, 20% C1000 283-0004-00 0.02 uF, Cer, 150 V C1002 283-0178-00 0.1 uF, Cer, 100 V, +80%-20% C1003 281-0637-00 91 pF, Cer, 500 V, 5% C1005 281-0629-00 33 pF, Cer, 600 V, 5% C1017 281-0511-00 22 pF, Cer, 500 V, 10% C1024 290-0527-00 15 uF, Elect., 20 V, 20% C1031 283-0004-00 0.02 uF, Cer, 150 V C1036 281-0578-00 100 pF, Cer, 350 V, 20% C1038 290-0527-00 15 uF, Elect., 20 V, 20% C1039 283-0023-00 100 pF, Cer, 100 V, +80%-20% C1062 283-0178-00 15 uF, Cer, 100 V, 480%-20% C1063 281-0637-00 91 pF, Cer, 500 V, 5% C1063 281-0637-00 91 pF, Cer, 500 V, 5% C1065 281-0629-00 33 pF, Cer, 600 V, 5% C1065 281-0629-00 33 pF, Cer, 500 V, 5%	C896	290-0527-00)	15 uF, Elect., 20 V, 20%
C1000283-0004-000.02 uF, Cer, 150 VC1002283-0178-000.1 uF, Cer, 100 V, +80%-20%C1003281-0637-0091 pF, Cer, 500 V, 5%C1005281-0629-0033 pF, Cer, 600 V, 5%C1017281-0511-0022 pF, Cer, 500 V, 10%C1021283-0004-000.02 uF, Cer, 150 VC1024290-0527-0015 uF, Elect., 20 V, 20%C1031283-0004-000.02 uF, Cer, 150 VC1036281-0578-0018 pF, Cer, 500 V, 5%C1038290-0527-0015 uF, Elect., 20 V, 20%C1039283-0023-000.1 uF, Cer, 10 V, +80%-20%C1062283-0178-000.1 uF, Cer, 100 V, +80%-20%C1063281-0637-0091 pF, Cer, 500 V, 5%C1065281-0637-0091 pF, Cer, 600 V, 5%C1065281-0629-0033 pF, Cer, 600 V, 5%	C897	290-0527-00		15 uF, Elect., 20 V, 20%
C1002283-0178-000.1 uF, Cer, 100 V, +80%-20%C1003281-0637-0091 pF, Cer, 500 V, 5%C1005281-0629-0033 pF, Cer, 600 V, 5%C1017281-0511-0022 pF, Cer, 500 V, 10%C1021283-0004-000.02 uF, Cer, 150 VC1024290-0527-0015 uF, Elect., 20 V, 20%C1031283-0004-000.02 uF, Cer, 150 VC1036281-0578-0018 pF, Cer, 500 V, 5%C1038290-0527-0015 uF, Elect., 20 V, 20%C1039283-0023-000.1 uF, Cer, 10 V, +80%-20%C1062283-0178-000.1 uF, Cer, 100 V, +80%-20%C1063281-0637-0091 pF, Cer, 500 V, 5%C1065281-0629-0033 pF, Cer, 600 V, 5%C1065281-0629-0033 pF, Cer, 500 V, 5%	C1000	283-0004-00		0.02 uF, Cer, 150 V
C1003281-0637-0091 pF, Cer, 500 V, 5%C1005281-0629-0033 pF, Cer, 600 V, 5%C1017281-0511-0022 pF, Cer, 500 V, 10%C1021283-0004-000.02 uF, Cer, 150 VC1024290-0527-0015 uF, Elect., 20 V, 20%C1026281-0523-000.02 uF, Cer, 350 V, 20%C1031283-0004-000.02 uF, Cer, 150 VC1036281-0578-0018 pF, Cer, 500 V, 5%C1038290-0527-0015 uF, Elect., 20 V, 20%C1039283-0023-000.1 uF, Cer, 10 V, +80%-20%C1062283-0178-000.1 uF, Cer, 100 V, +80%-20%C1063281-0637-0091 pF, Cer, 500 V, 5%C1065281-0629-0033 pF, Cer, 600 V, 5%C1077281-0511-0022 pF. Cer, 500 V, 10%	C1002	283-0178-00		0.1 uF, Cer, 100 V, +80%-20%
C1005 281-0629-00 33 pF, Cer, 600 V, 5% C1017 281-0511-00 22 pF, Cer, 500 V, 10% C1021 283-0004-00 0.02 uF, Cer, 150 V C1024 290-0527-00 15 uF, Elect., 20 V, 20% C1026 281-0523-00 100 pF, Cer, 350 V, 20% C1031 283-0004-00 0.02 uF, Cer, 150 V C1036 281-0578-00 18 pF, Cer, 500 V, 5% C1038 290-0527-00 15 uF, Elect., 20 V, 20% C1039 283-0023-00 0.1 uF, Cer, 10 V, +80%-20% C1062 283-0178-00 0.1 uF, Cer, 100 V, +80%-20% C1063 281-0637-00 91 pF, Cer, 500 V, 5% C1065 281-0629-00 33 pF, Cer, 600 V, 5% C1077 281-0511-00 22 pF. Cer. 500 V, 10%	C1003	281-0637-00		91 pF, Cer, 500 V, 5%
C1017 281-0511-00 22 pF, Cer, 500 V, 10% C1021 283-0004-00 0.02 uF, Cer, 150 V C1024 290-0527-00 15 uF, Elect., 20 V, 20% C1031 283-0004-00 0.02 uF, Cer, 350 V, 20% C1036 281-0578-00 100 pF, Cer, 350 V, 20% C1038 290-0527-00 18 pF, Cer, 500 V, 5% C1039 283-0023-00 0.1 uF, Cer, 10 V, +80%-20% C1062 283-0178-00 0.1 uF, Cer, 100 V, +80%-20% C1063 281-0637-00 91 pF, Cer, 500 V, 5% C1065 281-0511-00 22 pF. Cer, 500 V, 5%	C1005	281-0629-00		33 pF, Cer, 600 V, 5%
C1021 283-0004-00 0.02 uF, Cer, 150 V C1024 290-0527-00 15 uF, Elect., 20 V, 20% C1026 281-0523-00 100 pF, Cer, 350 V, 20% C1031 283-0004-00 0.02 uF, Cer, 150 V C1036 281-0578-00 18 pF, Cer, 500 V, 5% C1039 283-0023-00 0.1 uF, Cer, 10 V, +80%-20% C1062 283-0178-00 0.1 uF, Cer, 100 V, +80%-20% C1063 281-0637-00 91 pF, Cer, 500 V, 5% C1065 281-0629-00 33 pF, Cer, 600 V, 5% C1077 281-0511-00 22 pF. Cer, 500 V, 10%	C1017	281-0511-00		22 pF. Cer. 500 V. 10%
C1021 203-0004-00 0.02 uf, Cef, 130 v C1024 290-0527-00 15 uF, Elect., 20 V, 20% C1026 281-0523-00 100 pF, Cer, 350 V, 20% C1031 283-0004-00 0.02 uF, Cer, 150 V C1036 281-0578-00 18 pF, Cer, 500 V, 5% C1038 290-0527-00 15 uF, Elect., 20 V, 20% C1039 283-0023-00 0.1 uF, Cer, 10 V, +80%-20% C1062 283-0178-00 0.1 uF, Cer, 100 V, +80%-20% C1063 281-0637-00 91 pF, Cer, 500 V, 5% C1065 281-0629-00 33 pF, Cer, 600 V, 5% C1077 281-0511-00 22 pF. Cer. 500 V, 10%	C1021	283-0004-00		0.02 yF Cer 150 V
C1024 290-0527-00 15 uF, Elect., 20 V, 200 C1026 281-0523-00 100 pF, Cer, 350 V, 20% C1031 283-0004-00 0.02 uF, Cer, 150 V C1036 281-0578-00 18 pF, Cer, 500 V, 5% C1038 290-0527-00 15 uF, Elect., 20 V, 20% C1039 283-0023-00 0.1 uF, Cer, 10 V, +80%-20% C1062 283-0178-00 0.1 uF, Cer, 100 V, +80%-20% C1063 281-0637-00 91 pF, Cer, 500 V, 5% C1065 281-0629-00 33 pF, Cer, 600 V, 5% C1077 281-0511-00 22 pF. Cer. 500 V, 10%	C1021	203-0004-00		15 wr Floct 20 V 209
C1026 281-0523-00 100 pF, Cer, 350 V, 20% C1031 283-0004-00 0.02 uF, Cer, 150 V C1036 281-0578-00 18 pF, Cer, 500 V, 5% C1038 290-0527-00 15 uF, Elect., 20 V, 20% C1039 283-0023-00 0.1 uF, Cer, 10 V, +80%-20% C1062 283-0178-00 0.1 uF, Cer, 100 V, +80%-20% C1063 281-0637-00 91 pF, Cer, 500 V, 5% C1065 281-0629-00 33 pF, Cer, 600 V, 5% C1077 281-0511-00 22 pF. Cer. 500 V, 10%	C1024	290-0527-00	,	15 ur, Elect., 20 V, 200
C1031 283-0004-00 0.02 uF, Cer, 150 V C1036 281-0578-00 18 pF, Cer, 500 V, 5% C1038 290-0527-00 15 uF, Elect., 20 V, 20% C1039 283-0023-00 0.1 uF, Cer, 10 V, +80%-20% C1062 283-0178-00 0.1 uF, Cer, 100 V, +80%-20% C1063 281-0637-00 91 pF, Cer, 500 V, 5% C1065 281-0629-00 33 pF, Cer, 600 V, 5% C1077 281-0511-00 22 pF. Cer. 500 V, 10%	C1026	281-0523-00)	100 pF, Cer, 350 V, 20%
C1036 281-0578-00 18 pF, Cer, 500 V, 5% C1038 290-0527-00 15 uF, Elect., 20 V, 20% C1039 283-0023-00 0.1 uF, Cer, 10 V, +80%-20% C1062 283-0178-00 0.1 uF, Cer, 100 V, +80%-20% C1063 281-0637-00 91 pF, Cer, 500 V, 5% C1065 281-0629-00 33 pF, Cer, 600 V, 5% C1077 281-0511-00 22 pF. Cer, 500 V, 10%	C1031	283-0004-00)	0.02 uF, Cer, 150 V
C1038 290-0527-00 15 uF, Elect., 20 V, 20% C1039 283-0023-00 0.1 uF, Cer, 10 V, +80%-20% C1062 283-0178-00 0.1 uF, Cer, 100 V, +80%-20% C1063 281-0637-00 91 pF, Cer, 500 V, 5% C1065 281-0629-00 33 pF, Cer, 600 V, 5% C1077 281-0511-00 22 pF. Cer. 500 V, 10%	C1036	281-0578-00)	18 pF, Cer, 500 V, 5%
C1039283-0023-000.1 uF, Cer, 10 V, +80%-20%C1062283-0178-000.1 uF, Cer, 100 V, +80%-20%C1063281-0637-0091 pF, Cer, 500 V, 5%C1065281-0629-0033 pF, Cer, 600 V, 5%C1077281-0511-0022 pF. Cer, 500 V, 10%	C1038	290-0527-00)	15 uF, Elect., 20 V, 20%
C1062 283-0178-00 0.1 uF, Cer, 100 V, +80%-20% C1063 281-0637-00 91 pF, Cer, 500 V, 5% C1065 281-0629-00 33 pF, Cer, 600 V, 5% C1077 281-0511-00 22 pF. Cer, 500 V, 10%	C1039	283-0023-00)	0.1 uF, Cer, 10 V, +80%-20%
C1063 281-0637-00 91 pF, Cer, 500 V, 5% C1065 281-0629-00 33 pF, Cer, 600 V, 5% C1077 281-0511-00 22 pF. Cer, 500 V, 10%	C1062	283-0178-00)	0.1 uF. Cer. 100 V. +80%-20%
C1065 $281-0629-00$ 33 pF, Cer, 600 V, 5% C1077 $281-0511-00$ 22 pF. Cer, 500 V, 10%	C1063	281-0637-00		91 pF. Cer. 500 V. 58
C1077 281-0511-00 22 pF. Cer. 500 V. 10%	C1065	281-0620-00		33 pF. Cer. 600 V. 5%
	C1077	281-0511-00		22 pF. Cer. 500 V. 10%

j

₿

CAPACITORS (cont) 0.02 uF, Cer, 150 V C1081 283-004-00 0.02 uF, Cer, 150 V C1086 281-0523-00 100 pF, Cer, 350 V, 20% C1096 281-0578-00 18 pF, Cer, 150 V C1097 283-0080-00 0.02 uF, Cer, 150 V C1113 290-0519-00 100 uF, Cer, 10 V, 480*-20% C1117 283-0080-00 0.022 uF, Cer, 25 V, +80*-20% C1131 295-0160-00 0.1 uF, Timing capacitor C1133 295-0160-00 0.01 uF, C1134 283-0268-00 0.01 uF, C1152 290-0245-00 1.5 uF, Elect., 10 V, 10% C1153 283-0645-00 1.5 uF, Cer, 10 V, 10% C1161 250-0157-00 0.1 uF, C1161 290-0245-00 2-8 pF, Var, Cer C1161 290-0245-00 0.1 uF, Cer, 10 V, 10% C1163 283-0045-00 0.02 uF, Cer, 150 V C1201 283-0045-00 0.02 uF, Cer, 150 V C1202 283-0040 0.02 uF, Cer, 150 V C1203 283-0040 0.02 uF, Cer, 150 V	Ckt. No.	Tektronix Part No.	Serial/Model Eff	No. Disc	Description
Ci081 283-0004-00 0.02 µF, Cer, 150 V C1084 280-0527-00 150 µF, Elect., 20 V, 20% C1091 283-0023-00 100 µF, Cer, 530 V, 5% C1092 283-0023-00 0.1 µF, Cer, 150 V C1113 200-0519-00 100 µF, Cer, 150 V C1113 200-0519-00 0.1 µF, Cer, 100 V, 4808-20% C1113 200-0519-00 0.022 µF, Cer, 25 V, +808-20% C1131 205-0160-00 0.1 µF, Timing capacitor C1133 295-0160-00 0.1 µF, Timing capacitor C1134 283-0031-00 43 pF, Cer, 100 V, 2% C1151 283-0268-00 0.01 µF, Timing capacitor C1152 290-0245-00 1.5 µF, Elect., 10 V, 10% C1153 283-0645-00 790 pF, Mica, 100 V, 1% C1161 295-0157-00 0.1 µF, Cer, 100 V, 2% C1161 295-0157-00 0.1 µF, Cer, 10 V, 1% C1162 283-031-00 43 pF, Cer, 100 V, 2% C1202 290-0650-00 0.1 µF, Cer, 10 V, 480*-20% C1203 283-003-00 0.1 µF, Cer, 150 V C1204 283-004-00 0.02 µF, Cer, 150 V C1205	CAPACITORS	(cont)			
$ \begin{array}{cccccccccccccccccccccccccccccccccccc$	C1081	283-0004-00)		0.02 uF, Cer, 150 V
$ \begin{array}{cccccccccccccccccccccccccccccccccccc$	C1084	290-0527-00)		15 uF, Elect., 20 V, 20%
$ \begin{array}{cccccccccccccccccccccccccccccccccccc$	C1086	281-0523-00)		100 pF, Cer, 350 V, 20%
C1096 221-0578-00 18 pF, car 500 v, 58 C1099 283-0023-00 0.1 uF, Car, 10 V, +808-208 C1113 290-0519-00 100 uF, Elect., 20 V, 208 C1131 295-0160-00 0.022 uF, Cer, 25 V, +808-208 C1131 295-0160-00 0.1 uF, Timing capacitor C1135 281-0089-00 2-8 pF, Var, Cer C1136 283-031-00 43 pF, Cer, 100 V, 28 C1151 283-0268-00 0.015 uF, Cer, 50 V, 108 C1152 290-0245-00 1.5 uF, Elect., 10 V, 108 C1163 283-0645-00 0.1 uF, Timing capacitor C1161 1 uF, 1 uF, 10 UF, C1161 295-0157-00 0.1 uF, Cer, 100 V, 28 C1162 283-0023-00 0.01 uF, C1163 283-0023-00 0.1 uF, Cer, 100 V, 480*-208 C1209 283-004-00 0.02 uF, Cer, 150 V C1209 283-004-00 0.02 uF, Cer, 150 V C1209 283-004-00 0.1 uF, Cer, 100 V, +80*-208 C1210 283-0024-00 0.1 uF, Cer, 100 V, +80*-208 C1220	C1091	283-0004-00)		0.02 uF, Cer, 150 V
C1099 283-0023-00 0.1 uF, Cer, 10 V, +808-20% C1113 290-0519-00 100 uF, Elect., 20 V, 20% C1131 290-0519-00 0.022 uF, Cer, 25 V, +808-20% C1131 295-0160-00 0.1 uF, Timing capacitor C1133 21-0089-00 2-8 pF, Var, Cer C1137 281-0089-00 2-8 pF, Var, Cer C1138 283-028-00 0.015 uF, Cer, 50 V, 10% C1152 290-0245-00 1.5 uF, Elect., 10 V, 10% C1163 295-0157-00 0.1 uF, Timing capacitor C1161 1 0.001 uF, C1164 281-0089-00 2-8 pF, Var, Cer C1165 281-0089-00 2-8 pF, Var, Cer C1161 1 0.1 uF, C1162 281-0089-00 2-8 pF, Var, Cer C1163 283-0040-00 0.02 uF, Cer, 100 V, 1808-208 C1209 283-0040-00 0.02 uF, Cer, 150 V C1210 283-0040-00 0.02 uF, Cer, 150 V C1220 290-0650-00 1000 uF, Elect., 10 V, 4808-208 C1220 283-0024-00 0.1 uF, Cer, 30 V, +808-208 C1221 281-0024-00 0.01 uF, Cer,	C1096	281-0578-00)		18 pF. Cer. 500 V. 5%
C1013 290-0519-00 100 uF, Elect., 20 v, 20% C1117 283-0080-00 0.022 uF, Cer, 25 v, 480%-20% C1131 295-0160-00 0.10 uF, Cer, 25 v, 480%-20% C1135 281-0089-00 2-8 pF, Var, Cer C1137 281-0089-00 2-8 pF, Var, Cer C1138 283-0331-00 43 pF, Cer, 100 v, 2% C1151 283-0248-00 0.015 uF, Cer, 50 v, 10% C1152 290-0245-00 1.5 uF, Elect., 10 V, 10% C1153 283-0645-00 790 pF, Mica, 100 v, 1% C1161 295-0157-00 0.1 uF, Timing capacitor C1165 0.001 uF, 0.001 uF, C1166 283-0024-00 0.1 uF, Cer, 100 V, 2% C1201 283-0024-00 0.1 uF, Cer, 100 V, 2% C1202 290-0650-00 0.1 uF, Cer, 100 V, 480%-20% C1220 290-0650-00 0.1 uF, Cer, 100 V, 480%-20% C1220 290-0650-00 0.1 uF, Cer, 100 V, 480%-20% C1221 280-0024-00 0.02 uF, Cer, 150 V C1220 290-0650-00 0.1 uF, Cer, 150 V C1221 280-0024-00 0.01 uF, Cer, 150 V C1226	C1099	283-0023-00			0.1 uF. Cer. 10 V. +808-208
C1117 283-0080-00 0.022 uF, Cer, 25 v, +808-208 C1131 295-0160-00 0.1 uF, C1133 295-0160-00 0.1 uF, C1135 281-0089-00 2-8 pF, Var, Cer C1137 283-0268-00 43 pF, Cer, 100 v, 28 C1151 283-0645-00 1.5 uF, Elect., 10 v, 108 C1163 295-0157-00 0.1 uF, Cer, 100 v, 18 C1161 295-0157-00 0.1 uF, Cer, 100 v, 28 C1164 295-0157-00 0.1 uF, Cer, 100 v, 28 C1165 281-0089-00 2-8 pF, Var, Cer C1166 295-0157-00 0.1 uF, Cer, 100 v, 28 C1167 281-0089-00 2-8 pF, Var, Cer C1168 283-0014-00 0.02 uF, Cer, 100 v, 28 C1200 283-0004-00 0.02 uF, Cer, 150 v C1220 290-0650-00 1000 uF, Elect., 10 v, 208 C1221 283-0024-00 0.1 uF, Cer, 30 v, +808-208 C1225 283-0178-00 0.1 uF, Cer, 100 v, 4808-208 C1226 283-0024-00 0.03 uF, Cer, 150 v C1226 283-0024-00 0.01 uF, Cer, 150 v, +808-208 C1262 283-0023-00	C1113	290-0519-00			100 uF, Elect., 20 V. 20%
C111; 295-0160-00 0.001 uF, CF, 15 V, 160 FN C1131 1 295-0160-00 0.1 uF, Timing capacitor C1135 281-0089-00 2-8 pF, Var, Cer C1136 283-0331-00 43 pF, Cer, 100 V, 2% C1151 295-0160-00 0.015 uF, Cer, 50 V, 10% C1152 290-0245-00 1.5 uF, Elect., 10 V, 10% C1163 295-0157-00 0.1 uF, Timing capacitor C11651 295-0157-00 0.1 uF, Timing capacitor C11651 295-0157-00 0.1 uF, Cer, 100 V, 2% C1165 283-004-00 2-8 pF, Var, Cer C1201 283-0024-00 0.02 uF, Cer, 100 V, 2% C1202 283-0004-00 0.02 uF, Cer, 150 V C1220 283-0004-00 0.02 uF, Cer, 150 V C1220 283-0004-00 0.1 uF, Cer, 100 V, +80%-20% C1223 283-0004-00 0.1 uF, Cer, 100 V, +80%-20% C1224 283-0004-00 0.1 uF, Cer, 100 V, +80%-20% C1225 283-0003-00 0.1 uF, Cer, 100 V, +80%-20% C1226 283-0003-00 0.01 uF, Cer, 150 V, 480%-20% C1261 281-0064-00 0.25-1.5 pF, Var, Tub., 600 V </td <td>C1117</td> <td>293-0080-00</td> <td>,</td> <td></td> <td>0.022 uF. Cor. 25 V. +808-208</td>	C1117	293-0080-00	,		0.022 uF. Cor. 25 V. +808-208
C1131 C1133 C1133 C1135 10 uF, 0.1 uF, Timing capacitor 0.001 uF, C28 pF, Var, Cer C38 283-0331-00 28 pF, Var, Cer C418 283-0268-00 C1151 283-0268-00 0.015 uF, Cer, 100 V, 2% 0.015 uF, Cer, 50 V, 10% C1152 290-0245-00 1.5 uF, Elect., 10 V, 10% C1163 283-0645-00 790 pF, Mica, 100 V, 1% C1161 1 295-0157-00 0.1 uF, Timing capacitor 0.001 uF, C1163 281-0089-00 2-8 pF, Var, Cer C1164 283-0023-00 0.1 uF, Cer, 100 V, 2% C1201 283-0023-00 0.1 uF, Cer, 100 V, 2% C1202 280-004-00 0.02 uF, Cer, 150 V C1203 283-0004-00 0.02 uF, Cer, 150 V C1204 283-0004-00 0.1 uF, Cer, 100 V, 480*-20% C1220 290-0650-00 1000 uF, Elect., 10 V, 20% C1235 283-0024-00 0.1 uF, Cer, 150 V C1261 281-0064-00 0.25-1.5 pF, Var, Tub., 600 V C1262 283-0003-00 0.01 uF, Cer, 150 V C1263 283-0003-00 0.01 uF, Cer, 150 V, 480*-20% C1264 281-0064-00 0.25-1.5 pF, Var, Tub., 600 V C1263 283-0003-00 0.01 uF, Cer, 150 V,	CIII/	285-0080-00	,		
C1133 295-0160-00 0.1 uF, Timing capacitor C1135 0.001 uF, C1137 281-0089-00 2-8 pF, Var, Cer C1138 283-02331-00 43 pF, Cer, 100 V, 2% C1151 283-0245-00 1.5 uF, Elect., 10 V, 10% C1152 290-0245-00 1.5 uF, Elect., 10 V, 10% C1163 295-0157-00 0.1 uF, Timing capacitor C1163 295-0157-00 0.1 uF, Cer, 100 V, 2% C1164 295-0157-00 0.1 uF, Cer, 100 V, 2% C1165 0.010 uF, Cer, 100 V, 480%-20% C1201 283-0031-00 43 pF, Cer, 100 V, 480%-20% C1202 290-0650-00 0.02 uF, Cer, 150 V C1203 283-0044-00 0.02 uF, Cer, 150 V C1225 283-0044-00 0.1 uF, Cer, 30 V, +80%-20% C1261 281-0064-00 0.25-15 pF, Var, Tub., 600 V C1262 283-0023-00 0.01 uF, Cer, 150 V C1262 283-003-00 0.01 uF, Cer, 150 V, +80%-20% C1263 283-003-00 0.01 uF, Cer, 150 V, +80%-20% C1264 283-003-00 0.01 uF, Cer, 150 V, +80%-20% C1262 283-0032-00 0.	C1131),				10 uF,
C11351 0.001 uF, C11351 281-0089-00 2-8 pF, Var, Cer C11351 283-0231-00 0.015 uF, Cer, 50 V, 10% C1152 290-0245-00 1.5 uF, Elect., 10 V, 10% C1153 283-0645-00 790 pF, Mica, 100 V, 1% C1161 1 uF, 1 uF, C1163 295-0157-00 0.1 uF, Timing capacitor C1164 295-0157-00 0.1 uF, Cer, 100 V, 2% C1165 0.001 uF, Cer, 100 V, 2% C1166 295-0157-00 0.1 uF, Cer, 100 V, 2% C1167 281-0089-00 2-8 pF, Var, Cer C1168 283-0023-00 0.1 uF, Cer, 10 V, +80%-20% C1201 283-0024-00 0.02 uF, Cer, 150 V C1220 283-0024-00 0.02 uF, Cer, 150 V C1220 283-0024-00 0.1 uF, Cer, 100 V, +80%-20% C1249 283-0024-00 0.1 uF, Cer, 150 V C1261 281-0064-00 0.21 uF, Cer, 150 V C1262 283-0003-00 0.01 uF, Cer, 150 V, +80%-20% C1263 283-0003-00 0.01 uF, Cer, 150 V, +80%-20% C1264 283-0003-00 0.01 uF, Cer, 150 V, +80%-20%	C1133	295-0160-00)		0.1 uF, Timing capacitor
C1137 281-0089-00 2-8 pF, Var, Cer C1138 283-0331-00 43 pF, Cer, 100 V, 2% C1151 283-0268-00 1.5 uF, Elect., 10 V, 10% C1152 290-0245-00 1.5 uF, Elect., 10 V, 10% C1151 283-065-00 790 pF, Mica, 100 V, 1% C1161 1 295-0157-00 0.1 uF, Timing capacitor C1165 0.001 uF, 2-8 pF, Var, Cer C1166 283-0031-00 2-8 pF, Var, Cer, 10 V, 2% C1201 283-0024-00 0.1 uF, Cer, 10 V, 2% C1202 283-004-00 0.02 uF, Cer, 150 V C1220 290-0650-00 1000 uF, Elect., 10 V, 20% C1223 283-004-00 0.1 uF, Cer, 30 V, +80%-20% C1224 283-004-00 0.1 uF, Cer, 150 V C1225 283-004-00 0.1 uF, Cer, 10 V, +80%-20% C1226 283-0024-00 0.1 uF, Cer, 150 V C1226 283-0023-00 0.01 uF, Cer, 150 V, +80%-20% C1226	C1135)				0.001 uF,
C1138 283-0331-00 43 pF, Cer, 100 V, 2% C1151 283-0268-00 0.015 uF, Cer, 50 V, 10% C1152 290-0245-00 1.5 uF, Elect., 10 V, 10% C1153 283-0645-00 790 pF, Mica, 100 V, 1% C1161 1 uF, 1 uF, C1163 295-0157-00 0.1 uF, Timing capacitor C1164 281-0089-00 2-8 pF, Var, Cer C1165 283-0023-00 0.1 uF, Cer, 100 V, 2% C1201 283-0023-00 0.1 uF, Cer, 10 V, +80%-20% C1202 290-0650-00 0.02 uF, Cer, 150 V C1220 290-0650-00 1000 uF, Elect., 10 V, +80%-20% C1235 283-004-00 0.2 uF, Cer, 150 V C1249 283-0024-00 0.1 uF, Cer, 30 V, +80%-20% C1261 281-0064-00 0.25-1.5 pF, Var, Tub., 600 V C1262 283-003-00 0.01 uF, Cer, 150 V, +80%-20% C1263 283-003-00 0.01 uF, Cer, 150 V, +80%-20% C1264 283-003-00 0.01 uF, Cer, 150 V, +80%-20% C1263 283-003-00 0.01 uF, Cer, 150 V, +80%-20% C1264 283-003-00 0.01 uF, Cer, 150 V, +80%-20%	C1137	281-0089-00)		2-8 pF, Var, Cer
C1151 283-0268-00 0.015 uF, Cer, 50 V, 10% C1152 290-0245-00 1.5 uF, Elect., 10 V, 10% C1153 283-0645-00 790 pF, Mica, 100 V, 1% C1161 295-0157-00 0.1 uF, Timing capacitor C1163 295-0157-00 2-8 pF, Var, Cer C1164 283-0023-00 0.1 uF, Cer, 100 V, 2% C1208 283-0004-00 0.02 uF, Cer, 150 V C1209 283-0004-00 0.02 uF, Cer, 150 V C1220 290-06550-00 1000 uF, Elect., 10 V, 480%-20% C1223 283-004-00 0.1 uF, Cer, 30 V, +80%-20% C1261 283-0024-00 0.1 uF, Cer, 150 V C1262 283-0024-00 0.1 uF, Cer, 150 V C1263 283-003-00 0.01 uF, Cer, 150 V, +80%-20% C1263 283-003-00 0.01 uF, Cer, 150 V, +80%-20% C1263 283-003-00 0.01 uF, Cer, 150 V, +80%-20% C1282 283-003-00 0.01 uF, Cer, 150 V, +80%-20% C1282 283-003-00 0.01 uF, Cer, 150 V, +80%-20% C1282 283-0003-00 0.01 uF, Cer, 150 V, +80%-20% C1282 283-0003-00 0.01 uF, Cer, 150 V, +80%-20%	C1138	283-0331-00)		43 pF, Cer, 100 V, 2%
Cl152 $290-0245-00$ 1.5 uF, Elect., $10 V$, 10% Cl161 $283-0645-00$ $790 pF$, Mica, $100 V$, 1% Cl161 $1 uF$, $0.1 uF$, Timing capacitorCl165 $0.001 uF$,Cl167 $281-0089-00$ $2-8 pF$, Var , CerCl168 $283-0331-00$ $43 pF$, Cer, $100 V$, 2% Cl201 $283-0023-00$ $0.1 uF$, Cer, $10 V$, $480\%-20\%$ Cl202 $283-0004-00$ $0.02 uF$, Cer, $150 V$ Cl203 $283-0004-00$ $0.02 uF$, Cer, $150 V$ Cl204 $290-0650-00$ $1000 uF$, Elect., $10 V$, $28\%-20\%$ Cl225 $283-0024-00$ $0.1 uF$, Cer, $150 V$ Cl262 $283-0024-00$ $0.1 uF$, Cer, $150 V$ Cl262 $283-0024-00$ $0.2 uF$, Cer, $150 V$ Cl263 $283-003-00$ $0.01 uF$, Cer, $200 V$, $+80\%-20\%$ Cl264 $281-0064-00$ $0.25-1.5 pF$, Var, Tub., $600 V$ Cl265 $283-003-00$ $0.01 uF$, Cer, $150 V$, $+80\%-20\%$ Cl269 $283-003-00$ $0.01 uF$, Cer, $150 V$, $+80\%-20\%$ Cl281 $281-0064-00$ $0.25-1.5 pF$, Var, Tub., $600 V$ Cl282 $283-003-00$ $0.01 uF$, Cer, $150 V$, $+80\%-20\%$ Cl283 $283-003-00$ $0.01 uF$, Cer, $150 V$, $480\%-20\%$ Cl284 $283-003-00$ $0.01 uF$, Cer, $150 V$, $480\%-20\%$ Cl285 $283-003-00$ $0.01 uF$, Cer, $150 V$, $480\%-20\%$ Cl286 $283-003-00$ $0.01 uF$, Cer, $150 V$, $480\%-20\%$ Cl287 $283-0023-00$ $0.01 uF$, Cer, $150 V$, $480\%-20\%$ Cl288 $283-0023-00$ $0.01 uF$, Cer, $150 V$, 480	C1151	283-0268-00)		0.015 uF, Cer, 50 V, 10%
C1153 283-0645-00 790 pF, Mica, 100 V, 1% C1161 1 295-0157-00 0.1 uF, Timing capacitor C1165 0.001 uF, 0.001 uF, C1166 283-0331-00 43 pF, Cer, 100 V, 2% C1201 283-0023-00 0.1 uF, Cer, 10 V, +80%-20% C1202 290-0650-00 0.02 uF, Cer, 150 V C1220 290-0650-00 0.01 uF, Cer, 100 V, +80%-20% C1235 283-004-00 0.2 uF, Cer, 150 V C1249 283-004-00 0.1 uF, Cer, 100 V, +80%-20% C1242 283-004-00 0.1 uF, Cer, 150 V C1261 281-0064-00 0.2 uF, Cer, 150 V C1262 283-0022-00 0.1 uF, Cer, 150 V C1262 283-0032-00 0.1 uF, Cer, 150 V C1262 283-0003-00 0.01 uF, Cer, 150 V C1263 283-0003-00 0.01 uF, Cer, 150 V, +80%-20% C1281 281-0064-00 0.25-1.5 pF, Var, Tub., 600 V C1262 283-0003-00 0.01 uF, Cer, 150 V, +80%-20% C1281 281-0064-00 0.25-1.5 pF, Var, Tub., 600 V C1282 283-0003-00 0.01 uF, Cer, 150 V, +80%-20%	C1152	290-0245-00)		1.5 uF, Elect., 10 V, 10%
C1161 C1163 C1165 1 295-0157-00 1 uF, 0.1 uF, 0.001 uF, 0.001 0.01 uF, 0.001 0.01 uF, C1167 281-0089-00 2-8 pF, Var, Cer 0.01 uF, Cer, 100 V, 2% C1201 283-0004-00 0.1 uF, Cer, 100 V, 2% 0.1 uF, Cer, 150 V C1209 283-0004-00 0.02 uF, Cer, 150 V 0.1 uF, Cer, 150 V C1220 290-0650-00 1000 uF, Cer, 150 V 0.1 uF, Cer, 100 V, 480%-20% C1235 283-0004-00 0.1 uF, Cer, 150 V 0.1 uF, Cer, 150 V C1261 281-0064-00 0.1 uF, Cer, 150 V 0.25-1.5 pF, Var, Tub., 600 V C1262 283-003-00 0.01 uF, Cer, 150 V, 480%-20% 0.01 uF, Cer, 150 V, 480%-20% C1261 281-0064-00 0.25-1.5 pF, Var, Tub., 600 V 0.25-1.5 pF, Var, Tub., 600 V C1262 283-003-00 0.01 uF, Cer, 150 V, 480%-20% 0.01 uF, Cer, 150	C1153	283-0645-00)		790 pF, Mica, 100 V, 1%
C1163 1 295-0157-00 0.1 uF, Timing capacitor C1165 0.001 uF, 0.1 uF, Cer, 100 V, 2% C1201 283-0023-00 0.1 uF, Cer, 100 V, 2% C1208 283-004-00 0.02 uF, Cer, 150 V C1209 283-004-00 0.02 uF, Cer, 150 V C1202 290-0650-00 1000 uF, Elect., 10 V, 20% C1225 283-004-00 0.1 uF, Cer, 150 V C1226 283-004-00 0.1 uF, Cer, 150 V C1226 283-004-00 0.1 uF, Cer, 150 V C1226 283-004-00 0.1 uF, Cer, 150 V C1261 281-004-00 0.1 uF, Cer, 150 V C1262 283-0003-00 0.1 uF, Cer, 150 V, +80%-20% C1263 283-0003-00 0.01 uF, Cer, 150 V, +80%-20% C1281 281-0064-00 0.25-1.5 pF, Var, Tub., 600 V C1282 283-0003-00 0.01 uF, Cer, 150 V, +80%-20% C1282 283-0003-00 0.01 uF, Cer, 150 V, +80%-20% C1282 283-0003-00 0.01 uF, Cer, 150 V, +80%-20% C1282 283-0003-00 0.01 uF, Cer, 150 V C1282 283-0003-00 0.01 uF, Cer, 150 V <	C1161),				1 uF,
C11650.001 uF,C1167 $281-0089-00$ $2-8$ pF, Var, CerC1168 $283-0331-00$ 43 pF, Cer, 100 V, 2%C1201 $283-0023-00$ 0.1 uF, Cer, 10 V, $+80\%-20\%$ C1208 $283-0004-00$ 0.02 uF, Cer, 150 VC1209 $283-0004-00$ 0.02 uF, Cer, 150 VC1220 $290-0650-00$ 1000 uF, Elect., 10 V, 20% C1235 $283-0178-00$ 0.1 uF, Cer, 150 VC1256 $283-0024-00$ 0.1 uF, Cer, 30 V, $+80\%-20\%$ C1261 $281-0064-00$ $0.25-1.5$ pF, Var, Tub., 600 VC1262 $283-003-00$ 0.01 uF, Cer, 150 V, $+80\%-20\%$ C1263 $283-003-00$ 0.01 uF, Cer, 150 V, $+80\%-20\%$ C1264 $283-003-00$ 0.01 uF, Cer, 150 V, $+80\%-20\%$ C1265 $283-003-00$ 0.01 uF, Cer, 150 V, $+80\%-20\%$ C1266 $283-003-00$ 0.01 uF, Cer, 150 V, $+80\%-20\%$ C1267 $283-003-00$ 0.01 uF, Cer, 150 V, $+80\%-20\%$ C1288 $283-003-00$ 0.01 uF, Cer, 150 V, $+80\%-20\%$ C1288 $283-003-00$ 0.01 uF, Cer, 150 V, $+80\%-20\%$ C127 $281-0501-00$ 4.7 pF, Cer, 500 V, ± 1 pFC139 $283-0023-00$ 0.1 uF, Cer, 10 V, $\pm80\%-20\%$ C139 $283-0023-00$ 0.1 uF, Cer, 10 V, $\pm80\%-20\%$ C1349 $283-0023-00$ 0.1 uF, Cer, 10 V, $\pm80\%-20\%$ C1349 $283-0023-00$ 0.1 uF, Cer, 10 V, $\pm80\%-20\%$ C1349 $283-0023-00$ 0.1 uF, Cer, 10 V, $\pm80\%-20\%$ C1403 $283-0198-00$ 0.22 uF, Cer, 50 V, 20\%C1	C1163	295-0157-00)		0.1 uF, Timing capacitor
C1167281-0089-002-8 pF, Var, CerC1168283-0331-0043 pF, Cer, 100 V, 2%C1201283-0023-000.1 uF, Cer, 10 V, +80%-20%C1208283-0004-000.02 uF, Cer, 150 VC1209283-0004-000.02 uF, Cer, 150 VC1220290-0650-001000 uF, Elect., 10 V, +80%-20%C1235283-0078-000.1 uF, Cer, 100 V, +80%-20%C1249283-0004-000.02 uF, Cer, 150 VC1256283-0024-000.1 uF, Cer, 30 V, +80%-20%C1261281-0064-000.25-1.5 pF, Var, Tub., 600 VC1262283-0092-000.03 uF, Cer, 200 V, +80%-20%C1263283-003-000.01 uF, Cer, 150 V, +80%-20%C1264283-003-000.01 uF, Cer, 150 V, +80%-20%C1265283-003-000.01 uF, Cer, 150 V, +80%-20%C1281281-0064-000.25-1.5 pF, Var, Tub., 600 VC1282283-003-000.01 uF, Cer, 150 V, +80%-20%C1283283-003-000.01 uF, Cer, 150 V, +80%-20%C1284283-003-000.01 uF, Cer, 150 V, +80%-20%C1285283-0003-000.01 uF, Cer, 150 V, +80%-20%C1286283-0003-000.01 uF, Cer, 150 V, +80%-20%C1307281-0501-004.7 pF, Cer, 500 V, ±1 pFC1329283-0023-000.1 uF, Cer, 10 V, +80%-20%C1349283-0023-000.1 uF, Cer, 10 V, +80%-20%C1349283-0023-000.1 uF, Cer, 10 V, +80%-20%C1349283-0023-000.1 uF, Cer, 10 V, +80%-20%C1403283-0128-000.22 uF, Cer, 50 V, 20%C1	C1165				0.001 uF,
C1168 283-0331-00 43 pF, Cer, 100 V, 2% C1201 283-0023-00 0.1 uF, Cer, 10 V, +80%-20% C1208 283-0004-00 0.02 uF, Cer, 150 V C1209 283-0004-00 0.02 uF, Cer, 150 V C1220 290-0650-00 1000 uF, Elect., 10 V, 20% C1235 283-0024-00 0.1 uF, Cer, 100 V, +80%-20% C1249 283-0024-00 0.1 uF, Cer, 150 V C1256 283-0024-00 0.1 uF, Cer, 150 V C1261 281-0064-00 0.25-1.5 pF, Var, Tub., 600 V C1263 283-003-00 0.01 uF, Cer, 150 V, +80%-20% C1263 283-003-00 0.01 uF, Cer, 150 V, +80%-20% C1264 283-003-00 0.01 uF, Cer, 150 V, +80%-20% C1263 283-003-00 0.01 uF, Cer, 150 V, +80%-20% C1281 281-0064-00 0.25-1.5 pF, Var, Tub., 600 V C1282 283-0003-00 0.01 uF, Cer, 150 V, +80%-20% C1283 283-0003-00 0.01 uF, Cer, 150 V, +80%-20% C1283 283-0003-00 0.01 uF, Cer, 150 V, +80%-20% C1283 283-0023-00 0.1 uF, Cer, 10 V, +80%-20% C1307 281-0501-00 4.7 pF, Cer,	C1167	281-0089-00)		2-8 pF, Var, Cer
C1201283-0023-000.1 uF, Cer, 10 V, +80%-20%C1208283-0004-000.02 uF, Cer, 150 VC1209283-0004-000.02 uF, Cer, 150 VC1220290-0650-001000 uF, Elect., 10 V, 20%C1235283-0178-000.1 uF, Cer, 100 V, +80%-20%C1249283-0024-000.1 uF, Cer, 150 VC1256283-0024-000.1 uF, Cer, 150 VC1261281-0064-000.25-1.5 pF, Var, Tub., 600 VC1262283-003-000.01 uF, Cer, 150 V, +80%-20%C1263283-003-000.01 uF, Cer, 150 V, +80%-20%C1269283-0003-000.01 uF, Cer, 150 V, +80%-20%C1281281-0064-000.25-1.5 pF, Var, Tub., 600 VC1282283-0003-000.01 uF, Cer, 150 V, +80%-20%C1283283-0003-000.01 uF, Cer, 150 V, +80%-20%C1288283-0003-000.01 uF, Cer, 150 V, +80%-20%C1288283-0003-000.01 uF, Cer, 150 V, +80%-20%C1288283-0003-000.01 uF, Cer, 150 V, +80%-20%C1307281-0501-004.7 pF, Cer, 500 V, ±1 pFC1327281-0501-004.7 pF, Cer, 10 V, +80%-20%C1348283-0023-000.1 uF, Cer, 10 V, ±80%-20%C1349283-0023-000.1 uF, Cer, 10 V, ±80%-20%C1349283-0023-000.1 uF, Cer, 10 V, ±80%-20%C1403283-0198-000.22 uF, Cer, 50 V, 20%C1412290-0536-0010 uF, Elect., 25 V, 20%	C1168	283-0331-00)		43 pF. Cer, 100 V, 2%
C1208 283-0004-00 0.02 uF, Cer, 150 V C1209 283-0004-00 0.02 uF, Cer, 150 V C1220 290-0650-00 1000 uF, Elect., 10 V, 20% C1235 283-0178-00 0.1 uF, Cer, 100 V, +80%-20% C1261 281-0064-00 0.25-1.5 pF, Var, Tub., 600 V C1262 283-003-00 0.01 uF, Cer, 150 V, +80%-20% C1263 283-003-00 0.01 uF, Cer, 150 V, +80%-20% C1264 281-0064-00 0.25-1.5 pF, Var, Tub., 600 V C1262 283-003-00 0.01 uF, Cer, 150 V, +80%-20% C1281 281-0064-00 0.25-1.5 pF, Var, Tub., 600 V C1282 283-003-00 0.01 uF, Cer, 150 V, +80%-20% C1282 283-003-00 0.01 uF, Cer, 150 V, +80%-20% C1283 283-003-00 0.01 uF, Cer, 150 V, +80%-20% C1284 283-003-00 0.01 uF, Cer, 150 V, +80%-20% C1283 283-003-00 0.01 uF, Cer, 150 V, +80%-20% C1284 283-0023-00 0.1 uF, Cer, 10 V, +80%-20% C1307 281-0501-00 4.7 pF, Cer, 500 V, ±1 pF C1327 281-0501-00 4.7 pF, Cer, 10 V, +80%-20% C1348 283-0023-00	C1201	283-0023-00			0.1 uF. Cer, 10 V. +80%-20%
C1209283-0004-000.02 uF, Cer, 150 VC1220290-0650-001000 uF, Elect., 10 V, 20%C1235283-0178-000.1 uF, Cer, 100 V, +80%-20%C1249283-0004-000.02 uF, Cer, 150 VC1256283-0024-000.1 uF, Cer, 30 V, +80%-20%C1261281-0064-000.25-1.5 pF, Var, Tub., 600 VC1262283-0092-000.03 uF, Cer, 150 V, +80%-20%C1263283-0003-000.01 uF, Cer, 150 V, +80%-20%C1269283-0003-000.01 uF, Cer, 150 V, +80%-20%C1281281-0064-000.25-1.5 pF, Var, Tub., 600 VC1282283-0092-000.03 uF, Cer, 200 V, +80%-20%C1283283-0003-000.01 uF, Cer, 150 V, +80%-20%C1284283-0003-000.01 uF, Cer, 150 V, +80%-20%C1288283-0003-000.01 uF, Cer, 150 V, +80%-20%C1289283-0003-000.01 uF, Cer, 150 V, +80%-20%C1307281-0501-004.7 pF, Cer, 500 V, ±1 pFC1339283-0023-000.1 uF, Cer, 10 V, +80%-20%C1348283-0023-000.1 uF, Cer, 10 V, +80%-20%C1349283-0023-000.1 uF, Cer, 10 V, +80%-20%C1403283-0188-000.22 uF, Cer, 50 V, 20%C1404290-0159-002 uF, Elect., 150 VC1412290-0536-0010 uF, Elect., 25 V, 20%	C1201	283-0004-00			0.02 uF. Cer. 150 V
C1220290-0650-001000 uF, Elect., 10 V, 20%C1235283-0178-000.1 uF, Cer, 100 V, +80%-20%C1249283-0004-000.02 uF, Cer, 150 VC1256283-0024-000.1 uF, Cer, 30 V, +80%-20%C1261281-0064-000.25-1.5 pF, Var, Tub., 600 VC1262283-003-000.03 uF, Cer, 200 V, +80%-20%C1269283-003-000.01 uF, Cer, 150 V, +80%-20%C1281281-0064-000.25-1.5 pF, Var, Tub., 600 VC1282283-003-000.01 uF, Cer, 150 V, +80%-20%C1283283-003-000.01 uF, Cer, 150 V, +80%-20%C1284283-003-000.01 uF, Cer, 150 V, +80%-20%C1288283-003-000.01 uF, Cer, 150 V, +80%-20%C1289283-003-000.01 uF, Cer, 150 V, +80%-20%C1307281-0501-004.7 pF, Cer, 500 V, ±1 pFC1327281-0501-004.7 pF, Cer, 10 V, +80%-20%C1348283-0023-000.1 uF, Cer, 10 V, +80%-20%C1349283-0023-000.1 uF, Cer, 10 V, +80%-20%C1349283-0023-000.1 uF, Cer, 10 V, +80%-20%C1403283-0198-000.22 uF, Cer, 50 V, 20%C1404290-0159-002 uF, Elect., 150 VC1412290-0536-0010 uF, Elect., 25 V, 20%	C1200	283-0004-00			0.02 uF. Cer. 150 V
C1220 $230-003-00$ 1000 ur, 110 , 100 v, $4808-208$ C1235 $283-0178-00$ 0.1 uF, Cer, 100 V, $4808-208$ C1249 $283-0024-00$ 0.1 uF, Cer, 30 V, $4808-208$ C1261 $281-0064-00$ $0.25-1.5$ pF, Var, Tub., 600 VC1262 $283-0092-00$ 0.01 uF, Cer, 150 V, $4808-208$ C1263 $283-0003-00$ 0.01 uF, Cer, 150 V, $4808-208$ C1269 $283-0003-00$ 0.01 uF, Cer, 150 V, $4808-208$ C1281 $281-0064-00$ $0.25-1.5$ pF, Var, Tub., 600 VC1282 $283-0003-00$ 0.01 uF, Cer, 150 V, $4808-208$ C1283 $283-0003-00$ 0.01 uF, Cer, 150 V, $4808-208$ C1284 $283-0003-00$ 0.01 uF, Cer, 150 V, $4808-208$ C1285 $283-0003-00$ 0.01 uF, Cer, 150 V, $4808-208$ C1286 $283-0003-00$ 0.01 uF, Cer, 150 V, $4808-208$ C1287 $281-0501-00$ 4.7 pF, Cer, 500 V, 41 pFC1327 $281-0501-00$ 4.7 pF, Cer, 10 V, $4808-208$ C1348 $283-0023-00$ 0.1 uF, Cer, 10 V, $4808-208$ C1349 $283-0023-00$ 0.1 uF, Cer, 10 V, $4808-208$ C1349 $283-0023-00$ 0.1 uF, Cer, 10 V, $4808-208$ C1403 $283-0198-00$ 0.22 uF, Cer, 50 V, 208 C1404 $290-0159-00$ 2 uF, Elect., 25 V, 208	C1209	200-0650-00	,)		1000 uF, Elect, 10 V, 208
C1249283-0004-000.02 uF, Cer, 150 VC1256283-0024-000.1 uF, Cer, 30 V, +80%-20%C1261281-0064-000.25-1.5 pF, Var, Tub., 600 VC1262283-0092-000.03 uF, Cer, 200 V, +80%-20%C1263283-0003-000.01 uF, Cer, 150 V, +80%-20%C1269283-0003-000.01 uF, Cer, 150 V, +80%-20%C1281281-0064-000.25-1.5 pF, Var, Tub., 600 VC1282283-0003-000.01 uF, Cer, 150 V, +80%-20%C1283283-0003-000.01 uF, Cer, 150 V, +80%-20%C1288283-0003-000.01 uF, Cer, 150 V, +80%-20%C1288283-0003-000.01 uF, Cer, 150 V, +80%-20%C1299283-0004-000.02 uF, Cer, 150 V, +80%-20%C1307281-0501-004.7 pF, Cer, 500 V, ±1 pFC1327281-0501-004.7 pF, Cer, 10 V, +80%-20%C1348283-0023-000.1 uF, Cer, 10 V, +80%-20%C1349283-0023-000.1 uF, Cer, 10 V, +80%-20%C1403283-018-000.22 uF, Cer, 50 V, 20%C1404290-0159-002 uF, Elect., 150 VC1412290-0536-0010 uF, Elect., 25 V, 20%	C1235	283-0178-00)		0.1 uF, Cer, 100 V, +80%-20%
C1249203 0024 000.1 uF, Cer, 30 V, +80%-20%C1261281-0064-000.25-1.5 pF, Var, Tub., 600 VC1262283-0092-000.03 uF, Cer, 200 V, +80%-20%C1263283-0003-000.01 uF, Cer, 150 V, +80%-20%C1269283-0003-000.01 uF, Cer, 150 V, +80%-20%C1281281-0064-000.25-1.5 pF, Var, Tub., 600 VC1282283-0092-000.03 uF, Cer, 200 V, +80%-20%C1283283-0003-000.01 uF, Cer, 150 V, +80%-20%C1288283-0003-000.01 uF, Cer, 150 V, +80%-20%C1299283-0003-000.01 uF, Cer, 150 V, +80%-20%C1299283-0004-000.02 uF, Cer, 150 V, +80%-20%C1207281-0501-004.7 pF, Cer, 500 V, ±1 pFC1307281-0501-004.7 pF, Cer, 10 V, +80%-20%C1348283-0023-000.1 uF, Cer, 10 V, +80%-20%C1349283-0023-000.1 uF, Cer, 10 V, +80%-20%C1403283-0198-000.22 uF, Cer, 50 V, 20%C1404290-0159-002 uF, Elect., 150 VC1412290-0536-0010 uF, Elect., 25 V, 20%	C1249	283-0004-00	h		0.02 uF. Cer. 150 V
C1250283-0024-000.1 uf, Cer, 150 V, 100.8 100 VC1261281-0064-000.25-1.5 pF, Var, Tub., 600 VC1262283-003-000.01 uF, Cer, 200 V, +808-208C1269283-0003-000.01 uF, Cer, 150 V, +808-208C1281281-0064-000.25-1.5 pF, Var, Tub., 600 VC1282283-0092-000.03 uF, Cer, 200 V, +808-208C1283283-0003-000.01 uF, Cer, 150 V, +808-208C1288283-0003-000.01 uF, Cer, 150 V, +808-208C1299283-0003-000.01 uF, Cer, 150 V, +808-208C1299283-0004-000.02 uF, Cer, 150 V, +808-208C1299283-0003-000.01 uF, Cer, 150 V, +808-208C1307281-0501-004.7 pF, Cer, 500 V, ±1 pFC1327281-0501-004.7 pF, Cer, 10 V, +808-208C1348283-0023-000.1 uF, Cer, 10 V, +808-208C1349283-0023-000.1 uF, Cer, 10 V, +808-208C1403283-0198-000.22 uF, Cer, 50 V, 208C1404290-0159-002 uF, Elect., 150 VC1412290-0536-0010 uF, Elect., 25 V, 208	C1249	203 0004 00	,)		0.1 uF, Cer. 30 V. +808-208
C1261281-0084-000.25 fr.5 pr, var, fab., 00 vC1262283-0092-000.03 uF, Cer, 200 V, +808-208C1263283-0003-000.01 uF, Cer, 150 V, +808-208C1281281-0064-000.25-1.5 pF, Var, Tub., 600 VC1282283-0092-000.03 uF, Cer, 200 V, +808-208C1283283-0003-000.01 uF, Cer, 150 V, +808-208C1288283-0003-000.01 uF, Cer, 150 V, +808-208C1299283-0003-000.01 uF, Cer, 150 V, +808-208C1299283-0004-000.02 uF, Cer, 150 V, +808-208C1307281-0501-004.7 pF, Cer, 500 V, ±1 pFC1327281-0501-004.7 pF, Cer, 10 V, +808-208C1339283-0023-000.1 uF, Cer, 10 V, +808-208C1348283-0023-000.1 uF, Cer, 10 V, +808-208C1403283-0198-000.22 uF, Cer, 50 V, 208C1404290-0159-002 uF, Elect., 150 VC1412290-0536-0010 uF, Elect., 25 V, 208	01250	203-0024-00)		0.25 = 1.5 pF Var. Tub. 600 V
C1262 283-0092-00 0.00 uF, Cer, 150 V, 1808-208 C1269 283-0003-00 0.01 uF, Cer, 150 V, 1808-208 C1281 281-0064-00 0.25-1.5 pF, Var, Tub., 600 V C1282 283-0003-00 0.01 uF, Cer, 200 V, 1808-208 C1283 283-0003-00 0.01 uF, Cer, 200 V, 1808-208 C1284 283-0003-00 0.01 uF, Cer, 150 V, 1808-208 C1285 283-0003-00 0.01 uF, Cer, 150 V, 1808-208 C1286 283-0003-00 0.01 uF, Cer, 150 V, 1808-208 C1287 281-0501-00 4.7 pF, Cer, 500 V, 11 pF C1307 281-0501-00 4.7 pF, Cer, 500 V, 11 pF C1339 283-0023-00 0.1 uF, Cer, 10 V, 1808-208 C1348 283-0023-00 0.1 uF, Cer, 10 V, 1808-208 C1349 283-0023-00 0.1 uF, Cer, 10 V, 1808-208 C1403 283-0198-00 0.22 uF, Cer, 10 V, 1808-208 C1403 283-0198-00 0.22 uF, Cer, 50 V, 208 C1404 290-0159-00 2 uF, Elect., 150 V C1412 290-0536-00 10 uF, Elect., 25 V, 208	01261	201-0004-00			0.03 uF Cor. 200 V. $\pm 808-208$
C1263283-0003-000.01 uF, Cer, 150 V, 480%-20%C1281281-0064-000.25-1.5 pF, Var, Tub., 600 VC1282283-0092-000.03 uF, Cer, 200 V, 480%-20%C1283283-0003-000.01 uF, Cer, 150 V, 480%-20%C1288283-0003-000.01 uF, Cer, 150 V, 480%-20%C1299283-0004-000.02 uF, Cer, 150 V, 480%-20%C1307281-0501-004.7 pF, Cer, 500 V, ±1 pFC1327281-0501-004.7 pF, Cer, 500 V, ±1 pFC1339283-0023-000.1 uF, Cer, 10 V, 480%-20%C1348283-0023-000.1 uF, Cer, 10 V, 480%-20%C1349283-0023-000.1 uF, Cer, 50 V, 20%C1404290-0159-002 uF, Elect., 150 VC1412290-0536-0010 uF, Elect., 25 V, 20%	C1202)		0.03 ur (cer) 200 V) $+808-208$
C1269283-0003-000.01 uF, Cer, 150 V, 4808-208C1281281-0064-000.25-1.5 pF, Var, Tub., 600 VC1282283-0092-000.03 uF, Cer, 200 V, 4808-208C1283283-0003-000.01 uF, Cer, 150 V, 4808-208C1288283-0003-000.01 uF, Cer, 150 V, 4808-208C1299283-0004-000.02 uF, Cer, 150 VC1307281-0501-004.7 pF, Cer, 500 V, ±1 pFC1327281-0501-004.7 pF, Cer, 500 V, ±1 pFC1339283-0023-000.1 uF, Cer, 10 V, 4808-208C1348283-0023-000.1 uF, Cer, 10 V, 4808-208C1349283-0023-000.1 uF, Cer, 10 V, 4808-208C1403283-0198-000.22 uF, Cer, 50 V, 208C1404290-0159-002 uF, Elect., 150 VC1412290-0536-0010 uF, Elect., 25 V, 208	C1263				0.01 ur, Cer, 150 V, $+008 - 208$
C1281281-0064-000.23-1.3 pr, var, 1uB., 600 vC1282283-0092-000.03 uF, Cer, 200 V, +80%-20%C1283283-0003-000.01 uF, Cer, 150 V, +80%-20%C1288283-0003-000.01 uF, Cer, 150 VC1299283-0004-000.02 uF, Cer, 150 VC1307281-0501-004.7 pF, Cer, 500 V, ±1 pFC1327281-0501-004.7 pF, Cer, 500 V, ±1 pFC1339283-0023-000.1 uF, Cer, 10 V, +80%-20%C1348283-0023-000.1 uF, Cer, 10 V, +80%-20%C1349283-0023-000.1 uF, Cer, 10 V, +80%-20%C1403283-0198-000.22 uF, Cer, 50 V, 20%C1404290-0159-002 uF, Elect., 150 VC1412290-0536-0010 uF, Elect., 25 V, 20%	C1269				0.01 ur, Cer, 150 V, +008-208
$C1282$ $283-0092-00$ 0.03 uF , Cer , 200 V , $+808-208$ $C1283$ $283-0003-00$ 0.01 uF , Cer , 150 V , $+808-208$ $C1288$ $283-0003-00$ 0.01 uF , Cer , 150 V , $+808-208$ $C1299$ $283-0004-00$ 0.02 uF , Cer , 150 V $C1307$ $281-0501-00$ 4.7 pF , Cer , 500 V , $\pm 1 \text{ pF}$ $C1327$ $281-0501-00$ 4.7 pF , Cer , 500 V , $\pm 1 \text{ pF}$ $C1339$ $283-0023-00$ 0.1 uF , Cer , 10 V , $+808-208$ $C1348$ $283-0023-00$ 0.1 uF , Cer , 10 V , $+808-208$ $C1349$ $283-0023-00$ 0.1 uF , Cer , 10 V , $+808-208$ $C1403$ $283-0198-00$ 0.22 uF , Cer , 50 V , 208 $C1404$ $290-0159-00$ 2 uF , $Elect.$, 150 V $C1412$ $290-0536-00$ 10 uF , $Elect.$, 25 V , 208	C1281	281-0064-00			0.23 - 1.5 pr, var, 100., 000 v
C1283 $283-0003-00$ 0.01 uF, Cer, 150 V, $+808-208$ C1288 $283-0003-00$ 0.01 uF, Cer, 150 VC1299 $283-0004-00$ 0.02 uF, Cer, 150 VC1307 $281-0501-00$ 4.7 pF, Cer, 500 V, ± 1 pFC1327 $281-0501-00$ 4.7 pF, Cer, 500 V, ± 1 pFC1339 $283-0023-00$ 0.1 uF, Cer, 10 V, $\pm 808-208$ C1348 $283-0023-00$ 0.1 uF, Cer, 10 V, $\pm 808-208$ C1349 $283-0023-00$ 0.1 uF, Cer, 10 V, $\pm 808-208$ C1349 $283-0023-00$ 0.1 uF, Cer, 10 V, $\pm 808-208$ C1403 $283-0198-00$ 0.22 uF, Cer, 50 V, 208C1404 $290-0159-00$ 2 uF, Elect., 150 VC1412 $290-0536-00$ 10 uF, Elect., 25 V, 208	C1282	283-0092-00			0.03 ur, Cer, 200 v, +808-208
C1288283-0003-000.01 uF, Cer, 150 V, +80%-20%C1299283-0004-000.02 uF, Cer, 150 VC1307281-0501-004.7 pF, Cer, 500 V, ±1 pFC1327281-0501-004.7 pF, Cer, 500 V, ±1 pFC1339283-0023-000.1 uF, Cer, 10 V, +80%-20%C1348283-0023-000.1 uF, Cer, 10 V, +80%-20%C1349283-0023-000.1 uF, Cer, 10 V, +80%-20%C1349283-0198-000.22 uF, Cer, 50 V, 20%C1404290-0159-002 uF, Elect., 150 VC1412290-0536-0010 uF, Elect., 25 V, 20%	C1283	283-0003-00)		0.01 ur, Cer, 150 V, +808-208
C1299283-0004-000.02 uF, Cer, 150 VC1307281-0501-004.7 pF, Cer, 500 V, ±1 pFC1327281-0501-004.7 pF, Cer, 500 V, ±1 pFC1339283-0023-000.1 uF, Cer, 10 V, +80%-20%C1348283-0023-000.1 uF, Cer, 10 V, +80%-20%C1349283-0023-000.1 uF, Cer, 10 V, +80%-20%C1403283-0198-000.22 uF, Cer, 50 V, 20%C1404290-0159-002 uF, Elect., 150 VC1412290-0536-0010 uF, Elect., 25 V, 20%	C1288	283-0003-00)		0.01 uF, Cer, 150 V, +80%-20%
C1307281-0501-004.7 pF, Cer, 500 V, ±1 pFC1327281-0501-004.7 pF, Cer, 500 V, ±1 pFC1339283-0023-000.1 uF, Cer, 10 V, +80%-20%C1348283-0023-000.1 uF, Cer, 10 V, +80%-20%C1349283-0023-000.1 uF, Cer, 10 V, +80%-20%C1403283-0198-000.22 uF, Cer, 50 V, 20%C1404290-0159-002 uF, Elect., 150 VC1412290-0536-0010 uF, Elect., 25 V, 20%	C1299	283-0004-00)		0.02 uF, Cer, 150 V
C1327281-0501-004.7 pF, Cer, 500 V, ±1 pFC1339283-0023-000.1 uF, Cer, 10 V, +80%-20%C1348283-0023-000.1 uF, Cer, 10 V, +80%-20%C1349283-0023-000.1 uF, Cer, 10 V, +80%-20%C1403283-0198-000.22 uF, Cer, 50 V, 20%C1404290-0159-002 uF, Elect., 150 VC1412290-0536-0010 uF, Elect., 25 V, 20%	C1307	281-0501-00)		4.7 pF, Cer, 500 V, ±1 pF
C1339283-0023-000.1 uF, Cer, 10 V, +80%-20%C1348283-0023-000.1 uF, Cer, 10 V, +80%-20%C1349283-0023-000.1 uF, Cer, 10 V, +80%-20%C1403283-0198-000.22 uF, Cer, 50 V, 20%C1404290-0159-002 uF, Elect., 150 VC1412290-0536-0010 uF, Elect., 25 V, 20%	C1327	281-0501-00)		4.7 pF, Cer, 500 V, ±1 pF
C1348283-0023-000.1 uF, Cer, 10 V, +80%-20%C1349283-0023-000.1 uF, Cer, 10 V, +80%-20%C1403283-0198-000.22 uF, Cer, 50 V, 20%C1404290-0159-002 uF, Elect., 150 VC1412290-0536-0010 uF, Elect., 25 V, 20%	C1339	283-0023-00)		0.1 uF, Cer, 10 V, +80%-20%
C1349283-0023-000.1 uF, Cer, 10 V, +80%-20%C1403283-0198-000.22 uF, Cer, 50 V, 20%C1404290-0159-002 uF, Elect., 150 VC1412290-0536-0010 uF, Elect., 25 V, 20%	C1348	283-0023-00)		0.1 uF, Cer, 10 V, +80%-20%
C1403283-0198-000.22 uF, Cer, 50 V, 20%C1404290-0159-002 uF, Elect., 150 VC1412290-0536-0010 uF, Elect., 25 V, 20%	C1349	283-0023-00)		0.1 uF, Cer, 10 V, +80%-20%
C1404290-0159-002 uF, Elect., 150 VC1412290-0536-0010 uF, Elect., 25 V, 20%	C1403	283-0198-00)		0.22 uF, Cer, 50 V, 20%
C1412 290-0536-00 10 uF, Elect., 25 V, 20%	C1404	290-0159-00)		2 uF, Elect., 150 V
	C1412	290-0536-00)		10 uF, Elect., 25 V, 20%

Individual timing capacitors in this assembly must be ordered by the 9 digit part number, letter suffix and tolerance printed on the timing capacitor to be replaced. Example:

The letter suffix and the tolerance should be the same for all of the timing capacitors in the assembly.

Ckt. No.	Tektronix Part No.	Serial/Model Eff	No. Disc	Description
CAPACITORS	(cont)			
C1416	283-0203-00	1		0 47 uF. Cer. 50 V. 20%
C1410	200-0560-00			47 uF Float 25 V 209
C1419	290-0500-00			47 mF Cor 500 W 19
C1420				47 pr, cer, 500 V, 18 0 0069 wF Com 5000 W 1908-308
C1421	283-00/1-00			0.0068 uF, Cer, 5000 V, $+808-308$
CI422	283-00/1-00			0.0068 uF, Cer, 5000 V, $+808-308$
C1423	283-0071-00			0.0068 uF, Cer, 5000 V, $+808-308$
C1424	285-1040-00			0.0012 uF, Plastic, 4000 V, 10%
C1430	285-1040-00			0.0012 uF, Plastic, 4000 V, 10%
C1434	283-0005-00			0.01 uF, Cer, $250 V$, $\pm 100\% - 0\%$
C1442	283-0003-00)		0.01 uF, Cer, 150 V, +80%-20%
C1445	283-0003-00)		0.01 uF, Cer, 150 V, +80%-20%
C1447	283-0003-00			0.01 uF, Cer, 150 V, +80%-20%
C1449	283-0003-00)		0.01 uF, Cer, 150 V, +80%-20%
C1452	281-0580-00)		470 pF, Cer, 500 V, 10%
C1469	281-0661-00)		0.8 pF, Cer, 500 V, ±0.1 pF
C1471	281-0064-00)		0.25-1.5 pF, Var, Tub., 600 V
C1474	283-0111-00)		0.1 uF, Cer, 50 V
C1475	283-0000-00)		0.001 uF, Cer, 500 V, +100%-0%
C1476	283-0057-00)		0.1 uF, Cer, 200 V, +80%-20%
C1481	290-0164-00)		l uF, Elect., 150 V
C1484	283-0178-00)		0.1 uF, Cer, 100 V, +80%-20%
C1487	283-0101-00)		4700 pF, Cer, 6000 V, +80%-20%
C1488	285-1040-00)		0.0012 uF, Plastic, 4000 V, 10%
C1510	283-0057-00	B010100	B010399	0.1 uF. Cer. 200 V. +808-208
C1510	283-0167-00	B010400		0.1 uF, Cer. 100 V. 10%
C1511	281-0536-00	B010300	BU10399	100 pF. Cer. 500 V. 10%
C1511	281-0580-00	B010400		470 pF Cer. 500 V. 10%
CIJII	281-0580-00	B010400		4/0 pr, cer, 500 v, 100
C1512	290-0639-00)		300 uF, Elect., 80 V, +75%-10%
C1513	290-0638-00)		1200 uF, Elect., 100 V, +75%-10%
C1522	283-0004-00)		0.02 uF, Cer, 150 V
C1525	283-0178-00) XB011052		0.1 uF, Cer, 100 V, +80%-20%
C1534	290-0305-00) .		3 uF, Elect., 150 V, 20%
C1537	281-0550-00)		120 pF, Cer, 500 V, 10%
C1542	290-0584-00)		5500 uF, Elect., 30 V, +100%-10%
C1549	290-0536-00)		10 uF, Elect., 25 V, 20%
C1552	290-0571-00			500 uF, Elect., 25 V, +100%-10%
C1559	290-0535-00)		33 uF, Elect., 10 V, 20%
C1562	290-0583-00	0		3000 uF, Elect., 35 V, +100%-10%
C1569	290-0535-0	2		33 uF, Elect., 10 V, 20%
C1587	290-0523-00)		2.2 uF, Elect., 20 V, 20%
C1592	285-0686-0	0		0.068 uF, PTM, 100 V, 10%
C1593	281-0551-0	C		390 pF, Cer, 500 V, 10%
C1596	290-0532-00	2		150 uF, Elect., 6 V, 20%
C1597	281-0513-0	5		27 pF, Cer, 500 V, 20%
C1698	290-0536-0	C		10 uF, Elect., 25 V, 20%

	Tektronix	Serial/Mode	el No.	
Ckt. No.	Part No.	Eff	Disc	Description
DIODES				
CR18	152-0323-0	0		Silicon, SE365
CR31	152-0141-0	2		Silicon, 1N4152
CR32	152-0141-0	2		Silicon, 1N4152
CR34	152-0271-0	0		Voltage variable capacitance, V10E
CR39	152-0460-0	0		Silicon, JFET, 1 mA constant current, 1N5297
CR68	152-0323-0	0		Silicon, SE365
CR81	152-0141-0	2		Silicon, IN4152
CR82	152-0141-0	2		Silicon, IN4152
CR84	152-0271-0	ō		Voltage variable capacitance, V10E
CR152	152-0141-0	2		Silicon, 1N4152
CR164	152-0141-0	2		Silicon, 1N4152
CR165	152-0141-0	2		Silicon, 1N4152
CR166	152-0141-0	2		Silicon, 1N4152
CR167	152 - 0141 - 0	2		Silicon, 1N4152
CR252	152 - 0141 - 0	2		Silicon, 1N4152
CP304	152-0153-0	0		Silicon, FD7003 or CD5574
CR304	152-0153-0	0		Silicon ED7003 or CD5574
CR305	152-0153-0	0		Silicon $FD7003$ or $CD5574$
CR307	152-0153-0	U		STICON, FD/005 OF CD55/4
CR308	152-0153-0	0		Silicon, FD7003 or CD5574
CR314	152-0153-0	0		Silicon, FD7003 or CD5574
CR315	152-0153-0	0		Silicon, FD7003 or CD5574
CR317	152-0153-0	0		Silicon, FD7003 or CD5574
CR318	152-0153-0	0		Silicon, FD7003 or CD5574
CR342	152-0141-0	2		Silicon, 1N4152
CR362	152-0141-0	2		Silicon, 1N4152
CR368	152-0141-0	2		Silicon, 1N4152
CR372	152-0141-0	2		Silicon, 1N4152
CR378	152-0141-0	2		Silicon, 1N4152
CR421	152-0269-0	0 B010100	B039999X	Silicon, selected from 1N3182
CR422	152-0269-0	0 B010100	B039999X	Silicon, selected from 1N3182
CR434	152-0422-0	0 XB040000		Silicon, voltage variable capacitancce, PE1084
CR451	152-0141-0	2 XB040000		Silicon, 1N4152
CR452	152-0141-0	2 XB040000		Silicon, 1N4152
CR517	152-0246-0	0		Silicon, CD12676 or CD3375
CR550	152-0125-0	0		Tunnel, 4.7 mA, 15 pF
CR552	152-0125-0	0		Tunnel, 4.7 mA, 15 pF
CR553	152-0141-0	2		Silicon, 1N4152
CR554	152-0141-0	2		Silicon, IN4152
CR617	152-0246-0	0		Silicon, CD12676 or FD3375
CR650	152-0125-0	0		Tunnel, 4.7 mA, 15 pF
CR652	152-0125-0	0		Tunnel, 4.7 mA, 15 pF
CR801	152-0322-0	0		Silicon, All08
CR809	152-0141-0	2		Silicon, 1N4152
CR818	152-0141-0	2		Silicon, 1N4152
CR822	152-0141-0	2		Silicon, 1N4152

Ckt. No.	Tektronix Part No.	Serial/Model Eff	No. Disc		Description	
DIODES (cont)						
CR825	152-0141-02			Silicon.	1N4152	
CR826	152-0141-02			Silicon.	1N4152	
CR831	152-0141-02			Silicon.	1N4152	
CR832	152-0141-02			Silicon.	1N4152	
CR838	152-0141-02			Silicon.	1N4152	
CR851	152-0322-00)		Silicon,	A1108	
CR859	152-0141-02			Silicon,	1N4152	
CR863	152-0141-02	XB010600		Silicon,	1N4152	
CR879	152-0141-02	2		Silicon,	lN4152	
CR1001	152-0141-02	!		Silicon,	1N4152	
CR1004	152-0141-02	2		Silicon,	1N4152	
CR1011	152-0141-02	2		Silicon,	1N4152	
CR1024	152-0141-02	2		Silicon,	1N4152	
CR1035	152-0141-02			Silicon,	1N4152	
CR1042	152-0141-02			Silicon,	1N4152	
CR1043	152-0141-02	2		Silicon,	1N4152	
CR1061	152-0141-02	2		Silicon,	1N4152	
CR1064	152-0141-02	2		Silicon,	1N4152	
CR1071	152-0141-02	2		Silicon,	1N4152	
CR1095	152-0141-02	2		Silicon,	1N4152	
CR1101	152-0141-02			Silicon,	1N4152	
CR1102	152-0141-02			Silicon,	1N4152	
CRII55	152-0333-00			Silicon,	FDH6012	
CRI201	152-0141-02			Silicon,	1N4152	
CRI202	152-0141-02	2		Silicon,		
CR1216	152-0141-02	2		Silicon,	1N4152	
CRI248	152-0141-02	2		Silicon,	1N4152	
CR1251	152-0153-00)		Silicon,	FD7003 or CD5574	
CR1252	152-0153-00)		Silicon,	FD7003 or CD5574	
CR1253	152-0322-00)		Silicon,	A1108	
CR1255	152-0141-02			Silicon,	1N4152	
CR1273	152-0322-00)		Silicon,	A1108	
CR1275		2		Silicon,		
CR1286		2		Silicon,		
CR1304	152-0141-02			Silicon,		
CRISUO	152-0141-02	2		sificon,	1114132	
CR1309	152-0141-02	2		Silicon,	1N4152	
CR1315	152-0141-02	2		Silicon,	1N4152	
CR1316	152-0141-02	2		Silicon,	1N4152	
CR1325	152-0141-02	2		Silicon,	1N4152	
CR1326	152-0141-02	2		Silicon,	1N4152	
CR1327	152-0141-02	2		Silicon,	1N4152	
CR1334	152-0141-02			Silicon,	1N4152	
CR1335	152-0141-02	2		Silicon,		
CR1336	152-0141-02	2		Silicon,	1N4152	

₿

	Tektronix	Serial/Model	No.	•				
Ckt. No.	Part No.	Eff	Disc		Descri	ption		
DIODES (cont)								
CR1341	152-0141-02	,		Silicon.	1N4152			
CR1342	152-0141-02			Silicon.	1N4152			
	152-0141-02			Silicon	1N4152			
	152-0141-02			Silicon,	1N4152			
CR1345				Silicon,	1114152			
CRI 34 /	152-0141-02			Silicon,				
CR1404	152-0333-00			Silicon,				
CR1408	152-0141-02			Silicon,	1114152			
CR1412	152-0141-02			Silicon,	1N4152			
CR1413	152-0141-02			Silicon,	1N4152			
CR1414	152-0141-02	:		Silicon,	1N4152			
CR1416	152-0333-00			Silicon,	FDH6012			
CR1421	152-0409-00)		Silicon,	VG-12X			
CR1461	152-0141-02			Silicon,	1N4152			
CR1462	152-0141-02			Silicon,	1N4152			
CR1463	152-0141-02			Silicon,	1N4152			
CR1464	152-0153-00			Silicon.	FD7003 or	CD5574		
CR1465	152-0141-02			Silicon.	1N4152			
CR1468	152-0141-02			Silicon,	1N4152			
CD1472	152-0061-00			Silicon	CD8393 or	FDH2161		
CR1472	152-0001-00			Silicon,	CD8393 Or	FDU2161		
CR14/6	152-0061-00			Silicon,	CD8393 OI			
CR1482	152-0061-00			Silicon,	CD8393 01			
CR1483	152-0061-00			Silicon,		rDH2101		
CR1487	152-0242-00			Silicon,	CDI2691			
CR1488	152-0242-00			Silicon,	CDI2691		~ .	200 11
CR1511	152-0488-00			Silicon,	full wave	briage, 1	5 A,	200 V
CR1512	151-0107-00			Silicon,	T160 or 10	164/	~	
CR1513	152-0066-00)		Silicon,	diffused,	selected	from	1N3194
CR1514	152-0066-00)		Silicon,	diffused,	selected	from	1N3194
CR1524	152-0141-02			Silicon,	1N4152			
CR1532	152-0061-00			Silicon,	CD8393 or	FDH2161		
CR1533	152-0141-02			Silicon,	1N4152			
CR1534	152-0066-00)		Silicon,	diffused,	selected	from	1N3194
CR1535	152-0066-00)		Silicon,	diffused,	selected	from	1N3194
CR1536	152-0141-02			Silicon,	1N4152			
CR1541	152-0462-00			Silicon,	MDA960-3			
CR1549	152-0066-00)		Silicon,	diffused,	selected	from	1N3194
CR1551	152-0488-00)		Silicon.	full wave	bridge, 1	.5 A.	~200 V
CP1556	152 - 0141 - 02			Silicon.	1N4152			
CD1550	152-0066-00			Silicon	diffused.	selected	from	1N3194
CRISSS	152-0400-00			Silicon	full wave	bridge. 1	.5 A.	200 V
CRIDOL	152-01/1-02)		Silicon	1N4152	~++~~y~, 1	,	v
CR1504	152-0141-02			Silicon	diffused	selected	from	1N3194
CB1202	152-0000-00			Silicon	1N4152	JUTIC LEU	Om	
CR1590	152-0141-02	•		Silicon	1N4152			
CRIDJI	152-0141-02	•		Silicon	1N4152			
CKIDYZ	192-0141-02				- 117 - J &			

· · · ·

	Tektronix	Serial/Model	No.	
Ckt. No.	Part No.	Eff	Disc	Description
DTODES (cont)				
CR1694	152 - 0141 - 02			Silicon, 1N4152
CR1696	152 - 0141 - 02			Silicon, IN4152
CR1690	152-0141-02			Silicon, IN4152
VD 21	152-0141-02	н на		Zonor low impedance selected from 1N753A
VRZI VD71	152-0166-00			Zener, low impedance, selected from 1N753A
	152-0100-00			Zener, low impedance, selected from 1N753A
VRIZJ	152-0166-00			Zener, low impedance, selected from 1N753A
VR229	152-0166-00			Zener, low impedance, selected from iN755A
VR464	152-0195-00	XB040000		Zener, selected from in/SIA, 0.4 w, 5.1 V, 5
VR481	152-0395-00	XB060000		Zener, IN/49A, U.4 W, 4.3 V, 5%
VR491	152-0395-00	XB060000		Zener, 1N749A, 0.4 W, 4.3 V, 5%
VR875	152-0278-00			Zener, 1N5372A, 0.4 W, 3 V, 5%
VR896	152-0227-00			Zener, low noise, selected from 1N753A
VR1039	152-0166-00)		Zener, low impedance, selected from 1N753A
VR1099	152-0166-00)		Zener, low impedance, selected from 1N753A
VR1145	152-0395-00)		Zener, 1N749A, 0.4 W, 4.3 V, 5%
VR1146	152-0166-00)		Zener, low impedance, selected from 1N753A
VR1155	152-0278-00)		Zener, 1N4372Å, 0.4 W, 3 V, 5%
VR1289	152-0166-00)		Zener, low impedance, selected from 1N753A
VD1434	152-0247-00	h		Zener, $1N989B$, 0.4 W, 150 V, 58
VR1441	152-0283-00			Zener, $1N976V$, 0.4 W, 43 V, 5%
	152-0286-00)		Zener, $1N982B$, 0.4 W, 75 V, 58
VA1404 VD1515	152-0280-00	,)		Zener, $1N983$ 0 4 W 82 V 18
VRIJIJ	152-0302-00	,)		$\frac{1}{2000} = \frac{1}{1000} = \frac{1}{1000} = \frac{1}{100} = \frac{1}{1000} = \frac{1}$
VRIDZZ	152-0411-00)		Zener, $1N957$, 0.25 W, 5 V, 5
VRLD24 VD1525	152-0304-00		-	2 ener, 1 N976P, 0.4 W, 20 V, 58
VRISZS				2 ener, 1 N 9 / 0 D, 0.4 W, 43 V, 58 $7 ener, 1 N 9 / 0 D, 0.4 W, 20 W, 58$
VRID33	152-0304-00)		Zener, IN966B, 0.4 W, 20 V, 5%
DELAY LINE				
DF338	119-0387-00)		Delay line
BULBS				
DS382	150-0130-00)		Incandescent, 14 V, 80 mA, red dome lens
DS386	150-0130-00)		Incandescent, 14 V, 80 mA, red dome lens
DS388	150-0035-00) .		Neon, AID-T, 0.3 mA
DS389	150-0035-00)		Neon, AID-T, 0.3 mA
DS392	150-0130-00)		Incandescent, 14 V, 80 mA, red dome lens
DS396	150-0130-00)		Incandescent, 14 V, 80 mA, red dome lens
DS834	150-0130-00)		Incandescent, 14 V, 80 mA, red dome lens
DS836	150-0130-00)		Incandescent, 14 V, 80 mA, red dome lens
DS1140	150-0035-00)		Neon, AID-T, 0.3 mA
DS1239	150-0035-00	ט		Neon, AID-T, 0.3 mA
DS1425	150-0002-00)		Neon, NE2
DS1426	150-0002-00)		Neon, NE2
DS1570	150-0129-00	כ		Incandescent, 2112, 6.3 V, 200 mA
DS1571	150-0129-00	0		Incandescent, 2112, 6.3 V, 200 mA
DS1588	150-0130-00	0		Incandescent, 14 V, 80 mA, red dome lens

<u>۽</u>

3

Ckt. No.	Tektronix Part No.	Serial/Mode Eff	el No. Disc		Description	
FUSES						
F1419	159-0016-0	0		Cartridge.	1.5 A, 3AG, fast-	blo
F1501	159-0016-0	0		Cartridge,	1.5 A, 3AG, fast-	blo
CONNECTORS	126 0400 1				had 14 contract	
JI	136-0499-1	.4		Socket, CKt	brd, 14 contact	
J2	136-0499-1	.0		Socket, CKt	brd, 10 contact	
J 3	136-0499-0	4		Socket, CKt	bra, 4 contact	2
J4	131-06/9-0	0		Receptacie,	electrical, BNC,	3 contact
J5	136-0499-1	.0		Socket, ckt	brd, 10 contact	
J6	136-0499-1	.4		Socket, ckt	brd, 14 contact	.
J54	131-0679-0	0		Receptacle,	electrical, BNC,	3 contact
J162	131-1003-0	0		Receptacle,	coaxial cable	
J164	131-1003-0	0		Receptacle,	coaxial cable	
J165	131-0955-0	0		Receptacle,	electrical, BNC,	female
J168	131-1003-0	0		Receptacle,	coaxial cable	
J262	131-1003-0	0		Receptacle,	coaxial cable	
J338	131-1003-0	0		Receptacle,	coaxial cable	
J339	131-1003-0	0		Receptacle,	coaxial cable	
J349	131-1003-0	0		Receptacle,	coaxial cable	
J351	131-1003-0	0		Receptacle,	coaxial cable	
J359	131-1003-0	0		Receptacle,	coaxial cable	
J500	131-0955-0	0		Receptacle,	electrical, BNC,	female
J507	131-1003-0	0		Receptacle,	coaxial cable	
J508	131-1003-0	0		Receptacle,	coaxial cable	
J509	131-1003-0	0		Receptacle,	coaxial cable	
J600	131-0955-0	0		Receptacle,	electrical, BNC,	female
J1317	131-1003-0	0		Receptacle,	coaxial cable	
J1318	131-0955-0	0		Receptacle,	electrical, BNC,	female
J1319	131-1003-0	0		Receptacle,	coaxial cable	
J1337	131-1003-0	0		Receptacle,	coaxial cable	
J1338	131-0955-0	0		Receptacle,	electrical, BNC,	female
J1450	131-0955-0	0		Receptacle,	electrical, BNC,	female
INDUCTORS						
L122	108-0181-0	1 XB010400		0.2 uH		
L149	108-0181-0	1		0.2 uH		
L249	108-0181-0)		0.2 uH		
L338	108-0182-0	0		0.3 uH		
L339	108-0182-0	0		0.3 uH		
L440	108-0370-0	0 B010100	B039999X	0.14 uH		
L442	108-0370-0	00 B010100	B039999X	0.14 uH		
L461	108-0740-0	о во10100	в039999х	230 nH		
L464	108-0570-0	0 XB040000		75 uH		
L471	108-0740-0	0 B010100	B039999X	230 nH		
L474	108-0570-0	0 XB040000		75 uH		
T.A QQ	108 - 0440 - 0	0 XB040000		8 uH		

Ckt. No.	Tektronix Part No.	Serial/Mode Eff	el No. Disc	Description
INDUCTORS	(cont)			
L499	108-0440-00	XB040000		8 uH
L546	108-0370-00)		0.14 uH
L547	108-0370-00)		0.14 uH
L646	108-0370-00)		0.14 uH
1.647	108-0370-00	5		0.14 11H
T.874	108-0538-00			2.7 mH
T.891	108-0538-00			2.7 11H
T.893	108-0538-00			2.7 uH
T.897	108-0538-00			2.7 un
1007	100 0000 00	•		
L1419	108-0422-00)		80 uH
L1440	108-0713-00)		Trace rotation
L1446	108-0714-00)		Y axis alignment
L1596	108-0245-00)		3.9 uH
LR122	108-0282-00) XB010250	B010379X	0.13 uH (wound on a 30 ohm, 1/8 W, 5%,
LR461	108-0284-00	в010100	в039999х	100 nH
LR471	108-0284-00) B010100	B039999X	100 nH
LR483	108-0328-00	XB040000		0.3 uH
LR493	108-0328-00	XB040000		0.3 uH
TRANSISTORS				
020A.B	151-1032-00)		Silicon, JFET, N channel, 2N5911, dual
032	151-0259-00)		Silicon, NPN, selected from 2N3563
036	151-0259-00)		Silicon, NPN, selected from 2N3563
042	151-0221-00)		Silicon, PNP, 2N4258
õ44	151-0221-00)		Silicon, PNP, 2N4258
O70A,B	151-1032-00)		Silicon, JFET, N channel, 2N5911, dual
082	151-0259-00)		Silicon, NPN, selected from 2N3563
086	151-0259-00)		Silicon, NPN, selected from 2N3563
Q92	151-0221-00)		Silicon, PNP, 2N4258
094	151-0221-00)		Silicon, PNP, 2N4258
õ102	151-0259-00	B010100	B010349	Silicon, NPN, selected from 2N3563
0102	151-0427-00	B010350	2020012	Silicon, NPN, selected from 2N3563
Q104	151-0259-00	B010100	B010349	Silcion, NPN, selected from 2N3563
Q104	151-0427-00	B010350		Silicon, NPN, selected from 2N3563
Q122	151-0198-00)		Silicon, NPN, MPS918
Q124	151-0198-00)		Silicon, NPN, MPS918
Q132,	151-0271-00	в010100	B010199	Silicon, PNP, SAB4113
Q132 [⊥]	153-0609-00) B010200		Silicon, PNP, selected from 151-0271-00
				matched pair
Q134.	151-0271-00	в010100	B010199	Silicon, PNP, SAB4113
Q134 [⊥]	153-0609-00	B010200		Silicon, PNP, selected from 151-0271-00
				matched pair
Q142	151-0271-00)		Silicon, PNP, SAB4113
Q148	151-0271-00)		Silicon, PNP, SAB4113
Q152	151-0221-00)		Silicon, PNP, 2N4258

¹Furnished as a matched pair.

Ckt. No.	Tektronix Part No.	Serial/Model Eff	No. Disc	-		Description
TRANSTSTORS	(cont)					
0162	151-0221-00	1		Silicon	DND	2N4258
0164	151-0221-00			Silicon,	DND	2N4250
0169	151-0120-01			Silicon,	NDN	$2N32001 \circ \pi \pi 32001$
0202	151-0190-01		010240	Silicon,	NDN	an and from 2N2562
0202	151-0239-00	B010100 F	5010349	Silicon,	NDN	selected from 2N3563
0202	151-0427-00	B010350	010340	Silicon,	NDN	sologtod from 2N3563
0204	151-0427-00	B010100 E	5010349	Silicon,	NDN	sologtod from 2N3563
0204	152-0547-00	B010330		Silicon,	NDN	selected from 151-0198-00
Q224	122-0241-00			matched	pair	serected from 151-0198-00
Q226	153-0547-00	I		Silicon,	NPN,	selected from 151-0198-00
Q228				matched	pair	
Q232	151-0271-00	B010100 E	3010199	Silicon,	PNP,	SAB4113
Q232+	153-0609-00	B010200		Silicon,	PNP,	selected from 151-0271-00
				matched	pair	
Q234	151-0271-00	B010100 E	3010199	Silicon,	PNP,	SAB4113
Q234 -	153-0609-00	B010200		Silicon,	PNP,	selected from 151-0271-00
Q242	151-0271-00			matched Silicon,	paır PNP,	SAB4113
Q248	151-0271-00			Silicon,	PNP,	SAB4113
Q252	151-0221-00			Silicon,	PNP,	2N4258
Q262	151-0221-00			Silicon,	PNP,	2N4258
Q304	151-0221-00			Silicon,	PNP,	2N4258
Q308	151-0221-00			Silicon,	PNP,	2N4258
Q314	151-0221-00			Silicon,	PNP,	2N4258
Q318	151-0221-00			Silicon,	PNP,	2N4258
Q322	151-0269-00			Silicon,	NPN,	SE3005
Q324	151-0269-00			Silicon,	NPN,	SE3005
Q332	151-0188-00			Silicon,	PNP,	2N3906
Q344	151-0367-00			Silicon,	NPN,	SKA6516
Q346	151-0221-00			Silicon,	PNP,	2N4258
Q352	151-0223-00			Silicon,	NPN,	2N4275
Q358	151-0223-00			Silicon,	NPN,	2N4275
Q364	151-0190-01			Silicon,	NPN,	2N3904 or TE3904
Q374	151-0190-01			Silicon,	NPN,	2N3904 or TE3904
Q382	151-0219-00			Silicon,	PNP,	2N4250
Q386	151-0219-00			Silicon,	PNP,	2N4250
Q392	151-0219-00			Silicon,	PNP,	2N4250
Q396	151-0219-00			Silicon,	PNP,	2N4250
Q402	151-0212-00	XB040000		Silicon,	NPN,	selected from A485
Q406	151-0212-00	XB040000		Silicon,	NPN,	selected from A485
Q412	151-0212-00	XB040000		Silicon,	NPN,	selected from A485
Q416	151-0212-00	XB040000		Silicon,	NPN,	selected from A485
Q432	151-0212-00	XB040000		Silicon,	NPN,	selected from A485
Q442	151-0212-00	XB040000		Silicon,	NPN,	selected from A485
Q462	151-0434-00	XB040000		Silicon,	PNP,	2N4261

.

.

¹Furnished as a matched pair.

2000

ļ

	Tektronix	Serial/Model No.	
Ckt. No.	Part No.	Eff Disc	Description
TRANSISTORS	(cont)		
0468	151-0222-00	XB040000	Silicon, NPN, selected from 2N4217
0472	151-0434-00	XB040000	Silicon, PNP, 2N4261
0478	151-0222-00	XB040000	Silicon, NPN, selected from 2N4217
0482	151-0446-00	XB040000	Silicon, NPN, 2N3866
0492	151-0446-00	XB040000	Silicon, NPN, 2N3866
05221	151-1042-00		Silicon, JFET, N channel, 2N5245, pair
0524	202 2012 00		
0550	151-0221-00		Silicon, PNP, 2N4258
0552	151-0221-00		Silicon, PNP, 2N4258
2002	101 0001 00		
06221	151-1042-00		Silicon, JFET, N channel, 2N5245, pair
0624			
0650	151-0221-00		Silicon, PNP, 2N4258
0652	151-0221-00		Silicon, PNP, 2N4258
0672	151-0369-00	B010100 B010359	Silicon, PNP, replaceable by 151-0271-00
0672^{1}	151-0221-00	B010360 B010399	Silicon, PNP, 2N4258
0672	153-0597-00	B010400	Silicon, PNP, 2N4258
0678	151-0367-00		Silicon, NPN, SKA6516
0682	151-0369-00	B010100 B010359	Silicon, PNP, replaceable by 151-0271-00
2001	101 0000 00		
0682	151-0221-00	B010360 B010399	Silicon, PNP, 2N4258
0682 ¹	153-0597-00	B010400	Silicon, PNP, 2N4258
0688	151-0367-00		Silicon, NPN, SKA6516
0804	151-0220-00		Silicon, PNP, 2N4122
0812	151-0220-00		Silicon, PNP, 2N4122
0814	151-0220-00		Silicon, PNP, 2N4122
0822	151-0220-00		Silicon, PNP, 2N4122
õ824	151-0220-00		Silicon, PNP, 2N4122
0828	151-0190-01		Silicon, NPN, 2N3904 or TE3904
~			
Q854	151-0220-00		Silicon, PNP, 2N4122
Q862	151-0220-00		Silicon, PNP, 2N4122
Q864	151-0220-00		Silicon, PNP, 2N4122
Q1002	151-0354-00	•	Silicon, PNP, QD400
Q1012	151-0220-00)	Silicon, PNP, 2N4122
Q1014	151-0220-00)	Silicon, PNP, 2N4122
Q1024	151-0283-00		Silicon, NPN, selected from 2N3933
Q1030	151-1025-00		Silicon, JFET, N channel similar to KE4416
Q1036	151-0127-00		Silicon, NPN, selected from 2N2369
01020	151 0100 00		Cilicon DND 2N2006
Q1038	151-0188-00		Silicon, PNP, 2N3906
Q1042A,B	151-0232-00	1	SILLCON, NPN, REPLACEABLE DY ZNZYLY, dual
Q1044	T2T-0T30-0T		SILICON, NPN, 2N3304 OF TE3304 Silicon DND 2N4122
Q1052	151-0220-00		SILICON, MNF, 2N4122 Silicon DND 2N4122
Q1054	151-0220-00		SILICON, PNF, 2N4122 Cilicon DND OD400
01002			SILICON, FNF, UD400 Cilicon DND 2N2006
OT063	121-0188-00		SILICON, FNF, 2N3900 Silicon DND 2N4122
01072	121-0220-00		SILICON, FNF, 2N4122 Silicon DND 2N4122
Q10/4	121-0220-00)	DIIICON, PNP, ZN4IZZ

¹Furnished as a matched pair.

.

	Tektronix	Serial/Model	No.	•			
Ckt. No.	Part No.	Eff	Disc			Description	
TRANSISTORS	(cont)						
01084	151-0283-00)		Silicon,	NPN,	selected from 2N3933	
01090	151-1025-00)		Silicon.	JFET	N channel, similar to KE	4416
01096	151-0127-00)		Silicon.	NPN.	selected from 2N2369	
01090	151-0188-00			Silicon	DND	2N3906	
01140	151-0100-00	,)		Silicon	NDN	2112200	
01140	151-0302-00			Silicon,	MEN,	2N2222A 2N2222A	
	151-0302-00			Silicon,	DND	2N2222A	
Q1214	151-0220-00			Silicon,	PNP,		
Q1218	151-0216-00			Silicon,	PNP,	MP56523	
Q1224	151-0190-02	2		Silicon,	NPN,	2N3904	
Q1226	151-0188-00)		Silicon,	PNP,	2N3906	
01234	151-0190-02			Silicon,	NPN,	2N3904	
õ1236	151-0188-00)		Silicon,	PNP,	2N3906	
01244	151-0302-00)		Silicon,	NPN,	2N2222A	
01254	151-0301-00			Silicon.	PNP.	2N2907	
01262	151-0406-00			Silicon.	PNP.	selected from 2N3495	
01266	151-0407-00	,)		Silicon,	NPN.	Tek Spec	
01274	151-0407-00			Silicon	NDN	2N22222	
Q1274	151-0302-00			Silicon,	DND	coloctod from 2N3495	
Q1282	151-0406-00)		sificon,	PNP,	Selected from 2N3495	
Q1286	151-0407-00)		Silicon,	NPN,	Tek Spec	
Q1304	151-0190-01	-		Silicon,	NPN,	2N3940 or TE3904	
Q1306	151-0190-01			Silicon,	NPN,	2N3904 or TE3904	
Q1314	151-0220-00)		Silicon,	PNP,	2N4122	
Q1324	151-0190-01	L		Silicon,	NPN,	2N3904 or TE3904	
01326	151-0190-01	L		Silicon,	NPN,	2N3904 or TE3904	
õ1334	151-0220-00)		Silicon,	PNP,	2N4122	
01404	151-0126-00)		Silicon,	NPN,	2N2484	
Q1408	151-0301-00)		Silicon,	PNP,	2N2907	
01413	151-0188-00	1		Silicon,	PNP,	2N3906	
01414	151-0190-01			Silicon.	NPN.	2N3904 or TE3904	
01414	151-0136-00	L 1		Silicon.	NPN.	2N3053	
01410	151-0140-00			Silicon.	NPN.	selected from 2N3055	
01410	151-0140-00			Silicon	NPN	2N4275	
Q1400	151-0223-00			Silicon	DND	2N3906	
Q14/2	151-0188-00			Silicon,	INF,	Tok Spog	
Q1474	151-0407-00			Silicon,	DND	rek opec	
Q1478	151-0406-00)		Silicon,	PNP,	Selected from 2N3495	
Q1514	151-0506-00)		SCR, 200	V, 4.	A, C106B2	
Q1532	151-0347-00	0		Silicon,	NPN,	2N5551	
Q1534	151-0349-00)		Silicon,	NPN,	replaceable by MJE2801	
Q1536	151-0347-00)		Silicon,	NPN,	2N5551	
Q1544	151-0302-00	0		Silicon,	NPN,	2N2222A	
Q1546	151-0349-00	0		Silicon,	NPN,	replaceable by MJE2801	
Q1548	151-0302-00	0		Silicon,	NPN,	2N2222A	
01556	151-0390-00	0		Silicon,	NPN,	Darlington, MPSU45	
õ1558	151-0302-00	0		Silicon,	NPN,	2N2222A	
õ1564	151-0302-00	0		Silicon,	NPN,	2N2222A	

. .

100

No.

States -

an and

Server an

1.2.

and the second

Ckt. No.	Tektronix Part No.	Serial/Mode Eff	l No. Disc	Description
TRANSISTORS Q1566 Q1570 Q1582 Q1588 Q1590 Q1594 Q1598 Q1698	(cont) 151-0349-00 151-0302-00 151-0302-00 151-0302-00 151-0342-00 151-0342-00 151-0164-00 151-0301-00			Silicon, NPN, replaceable by MJE2801 Silicon, NPN, 2N2222A Silicon, NPN, Darlington, MPSU45 Silicon, NPN, 2N2222A Silicon, NPN, 2N2222A Silicon, PNP, 2N4249 Silicon, PNP, 2N4249 Silicon, PNP, 2N5447 or 2N3702 Silicon, PNP, 2N2907
RESISTORS R1 R3 R4 R6 R6 R15 R16 R18	315-0510-00 307-0110-00 317-0047-00 316-0105-00 316-0101-00 317-0101-00 321-0481-00 316-0474-00 315-0331-00	B010100 B011072 B010100 B010300	B011071 B010299	51 ohm, 1/4 W, 5% 3 ohm, 1/4 W, 5% 4.7 ohm, 1/8 W, 5% 1M ohm, 1/4 W, 10% 100 ohm, 1/4 W, 10% 100 ohm, 1/8 W, 5% 1M ohm, 1/8 W, 1% 470K ohm, 1/4 W, 10% 330 ohm, 1/4 W, 5%
R21 R22 R23 R25 R26 R27 R32 R33 R34	315-0151-00 321-0030-02 321-0030-02 311-1227-00 315-0123-00 315-0151-00 321-0208-00 321-0097-00 315-0434-00	B010100	B039999X	150 ohm, 1/4 W, 5% 20 ohm, 1/8 W, 1/2% 20 ohm, 1/8 W, 1/2% 5K ohm, Var 12K ohm, 1/4 W, 5% 150 ohm, 1/4 W, 5% 1.43K ohm, 1/8 W, 1% 100 ohm, 1/8 W, 1% 430K ohm, 1/4 W, 5%
R35 R36 R37 R38 R39 RT39 R41 R42 R43	315-0104-00 321-0208-00 315-0621-00 315-0621-00 316-0101-00 307-0124-00 321-0190-00 316-0101-00 321-0190-00			100K ohm, 1/4 W, 5% 1.43K ohm, 1/8 W, 1% 620 ohm, 1/4 W, 5% 620 ohm, 1/4 W, 5% 100 ohm, 1/4 W, 10% 5K ohm, Thermal 931 ohm, 1/8 W, 1% 100 ohm, 1/4 W, 10% 931 ohm, 1/8 W, 1%
R44 R45 R46 R47 R48 R49 R49 R51	321-0098-01 321-0098-01 321-0126-01 311-0635-00 311-0635-00 321-0080-00 321-0080-01 315-0510-00	B010100 B010800	в010799	102 ohm, 1/8 W, 1/2% 102 ohm, 1/8 W, 1/2% 200 ohm, 1/8 W, 1/2% 1K ohm, Var 1K ohm, Var 66.5 ohm, 1/8 W, 1% 66.5 ohm, 1/8 W, 1/2% 51 ohm, 1/4 W, 5%

Ckt. No.	Tektronix Part No.	Serial/Mode Eff	el No. Disc	Description
RESISTORS	(cont)			
R53	307-0110-00	B010100	B011071	3 ohm. 1/4 W. 5%
R53	317-0047-00	B011072	20110/1	4.7 obm, 1/8 W, 5%
D5/	316-0105-00			1M ohm 1/4 W 109
NJ4 D56	316-0101-00	, B010100	B010299	100 obm $1/4 W$ 108
R J O		B010100	D010233	100 ohm $1/4 W$ 59
RJU DCE	317-0101-00) B010300		1000000000000000000000000000000000000
ROD	321-0481-00			1^{M} Olding 1/0 W, 13 170^{M} obm 1/4 W 109
ROD	316-04/4-00			4/0K Offill, 1/4 W, 106
ROS	315-0331-00			150 ohm 1/4 W 55
R/1	315-0151-00)		150 Onm, 1/4 W, 58
R72	321-0030-02	:		20 ohm, 1/8 W, 1/2%
R73	321-0030-02			20 ohm, 1/8 W, 1/2%
R75	311-1227-00			5K ohm, Var
R76	315-0123-00)		12K ohm, 1/4 W, 5%
R77	315-0151-00			150 ohm, 1/4 W, 5%
R82	321-0208-00)		1.43K ohm, 1/8 W, 1%
R83	321-0097-00)		100 ohm, 1/8 W, 1%
R84	315-0434-00	B010100	B039999X	430K ohm, 1/4 W, 5%
R85	315-0104-00)		100K ohm, 1/4 W, 5%
R86	321-0208-00)		1.43K ohm, 1/8 W, 1%
R 87	315-0621-00)		620 ohm, 1/4 W, 5%
R88	315-0621-00)		620 ohm, 1/4 W, 5%
R91	321-0190-00)		931 ohm, 1/8 W, 1%
R92	316-0101-00)		100 ohm, 1/4 W, 10%
R93	321-0190-00)		931 ohm, 1/8 W, 1%
R94	321-0098-01			102 ohm, 1/8 W, 1/2%
R95	321-0098-01			102 ohm, 1/8 W, 1/2%
R96	321-0126-01	-		200 ohm, 1/8 W, 1/2%
R97	311-0635-00)		lK ohm, Var
R98	311-0635-00)		lK ohm, Var
R99	321-0080-00	B010100	B010799	66.5 ohm, 1/8 W, 1%
R99	321-0080-01	B010800		66.5 ohm, 1/8 W, 1/2%
R101	315-0682-00)		6.8K ohm, 1/4 W, 5%
R102	321-0204-00)		1.3K ohm, 1/8 W, 1%
R103	321-0087-00)		78.7 ohm, 1/8 W, 1%
P10/	321-0204-00			1.3K ohm. 1/8 W. 1%
D105	311-1225-00	, B010100	B010264	lK ohm. Var
K105	511-1225 00	BOIDIOU	0010204	
R105	311-1226-00	B010265		2.5K ohm, Var
R106	315-0301-00)		300 ohm, 1/4 W, 5%
R107	315-0270-00)		27 ohm, 1/4 W, 5%
R108	315-0301-00)		300 ohm, 1/4 W, 5%
R109	315-0270-00)		27 ohm, 1/4 W, 5%
RIII,	321-0026-00)		18.2 ohm, 1/8 W, 1%
R112	311-1371-00	B010100	B010399	lK ohm, Var
R112⊥	311-1364-00	B010400		lK ohm, Var
R113	321-0026-00)		18.2 ohm, 1/8 W, 1%

¹Furnished as a unit with S112.

∰² 1

Ckt. No.	Tektronix Part No.	Serial/Model Eff	No. Disc	Description
RESISTORS	(cont)			
R114	315-0103-00			10K ohm. 1/4 W. 5%
P115	311-1228-00			10K ohm, Var
P117	321-0085-00			75 obm = 1/8 W = 18
D118	311-1225-00			IK obm. Var
D110	321-0085-00			75 obm 1/8 W 19
P120.	311-1007-00	YB010200		$\frac{1}{20} \text{ obm}, \text{ Var}$
P121	321-0064-00	ABOTOZOO		45.3 obm = 1/8 W = 18
R121	311-0634-00	XB010250		500 obm. Var
R123	321-0064-00	B010100 F	3010199	45.3 ohm, 1/8 W, 1%
		5010200		
K123	321-0033-00	POT0200		100 obm 1/4 W 109
R125	316-0101-00			100 Omm, 1/4 W, 106
RIZ/	321-0122-00			102 Ofm, 1/0 W, 16
R128	321-0122-00			102 OIIII, 1/0 W, 16 267 obm, 1/9 W, 19
RIJU DMJJJ	321-0138-00			20/ Ollil, 1/0 W, 15
RTIJI	221-0124-00	1		$\frac{1}{2} \sum_{i=1}^{2} \sum_{j=1}^{2} \sum_{i=1}^{2} \sum_{j=1}^$
R132	321-0190-00			1.13K Office, $1/6$ W, 1.6
RL33	321-0097-00			1/9 W 19
RI34	321-0198-00	•		1.15K OHM, 1/6 W, 1%
R135	316-0101-00	1		100 ohm, 1/4 W, 10%
R136	315-0621-00			620 ohm, 1/4 W, 5%
R137	316-0101-00			100 ohm, 1/4 W, 10%
R138	315-0621-00			620 ohm, 1/4 W, 5%
R141	316-0390-00			39 ohm, 1/4 W, 10%
R142	315-0391-00			390 ohm, 1/4 W, 5%
R143	321-0200-00)	-	1.18K ohm, 1/8 W, 1%
R144	321-0084-00)		73.2 ohm, 1/8 W, 1%
R145	315-0100-00)		10 ohm, 1/4 W, 5%
R146	321-0200-00)		1.18K ohm, 1/8 W, 1%
R147	316-0390-00)		39 ohm, 1/4 W, 10%
R149	311-1225-00)		lK ohm, Var
R151	315-0331-00)		330 ohm, 1/4 W, 5%
R152	321-0160-00)		453 ohm, 1/8 W, 1%
R154	321-0201-00)		1.21K ohm, 1/8 W, 1%
R155	311-1224-00)		500 ohm, Var
R161	315-0331-00)		330 ohm, 1/4 W, 5%
R162	321-0064-00)		45.3 Ohm, 1/8 W, 1%
R164	315-0751-00)		750 ohm, 1/4 W, 5%
R168	321-0064-00)		45.3 ohm, 1/8 W, 1%
R169	316-0101-00)		100 ohm, 1/4 W, 10%
R201	315-0562-00)		5.6K Ohm, 1/4 W, 58
R202	321-0204-00)		1.3K Ohm, 1/8 W, 18
R203	321-0087-00)		78.7 Onm, 1/8 W, 18
R204	321-0204-00		1	1.3K Onm, 1/8 W, 18
R205	311-1225-00) B010100 (B010264	LK ONM, VAR
R205	311-1226-00	B010265		2.5K Ohm, Var

I

Electrical Parts List-465

Ckt. No.	Tektronix Part No.	Serial/Model No Eff Dis	o. sc	. Description
DECTOMODE	(cont)			
RESISIONS	315-0301-00			300 obm 1/4 W 59
P207	315-0270-00			$27 \text{ obm} \frac{1}{4} \text{ W} 59$
R207	315-0301-00			300 obm 1/4 W 59
R200	315-0270-00			27 obm, $1/4 W$ 58
R209	321-0026-00			18.2 obm, 1/8 W, 18
R2121	311-1371-00	B010100 B010	0399	lK obm. Var
R2121	311-1364-00	B010100 D010	0000	lK ohm, Var
R213	321-0026-00	2010100		18.2K obm, 1/8 W, 18
R214	315-0103-00			10K ohm, 1/4 W, 5%
1.211	515 0105 00			
R215	311-1228-00			10K ohm, Var
R217	321-0085-00			75 ohm, 1/8 W, 1%
R218	311-1225-00			lK ohm, Var
R219	321-0085-00			75 ohm, 1/8 W, 1%
R220	311-1007-00	XB010200		20 ohm, Var
R221	321-0064-00			45.3 ohm, 1/8 W, 1%
R222	316-0101-00			100 ohm, 1/4 W, 10%
R223	321-0064-00	B010100 B010	0199	45.3 ohm, 1/8 W, 1%
R223	321-0055-00	B010200		36.5 ohm, 1/8 W, 1%
R224	316-0103-00			10K ohm, 1/4 W, 10%
R225	316-0103-00			10K ohm, 1/4 W, 10%
R226	316-0103-00			10K ohm, 1/4 W, 10%
R227	321-0122-00			182 ohm, 1/8 W, 1%
R228	321-0122-00			182 ohm, 1/8 W, 1%
R229	316-0101-00			100 ohm, 1/4 W, 10%
R230	321-0138-00			267 Ohm, 1/8 W, 1%
RT231	307-0124-00			5K ohm, Thermal
R232	321-0198-00			1.13K Onm, 1/8 W, 1%
R233	321-0097-00			100 ohm, 1/8 W, 1%
R234	321-0198-00			1.13K ohm, 1/8 W, 1%
R235	316-0101-00			100 ohm, 1/4 W, 10%
R236	315-0621-00			620 ohm, 1/4 W, 5%
R237	316-0101-00			100 ohm, 1/4 W, 10%
R238	315-0621-00			620 ohm, 1/4 W, 5%
R241	316-0390-00			39 Ohm, 1/4 W, 10%
R242	315-0391-00			390 ohm, 1/4 W, 5%
R243	321-0200-00			1.18K ohm, 1/8 W, 1%
R244	321-0084-00			73.2 ohm, 1/8 W, 1%
R245	315-0270-00			2/ onm, 1/4 W, 5%
R246	321-0200-00			1.10K ONM, $1/8$ W, 18 20 obm $1/4$ W 108
R247	310-0390-00			JY OINN, I/4 W, IU3 IK obm. Var
R249	311-1225-00			$\frac{1}{330} \text{ obm } \frac{1}{4} \text{ W} 59$
KZDI DOEO	371-0160-00			453 obm, $1/8 W$, 18
R232 D351	321-0201-00			1.21K ohm. $1/8$ W. 18
R234 D955	311-1004-00			500 ohm. Var
RZ J J	JTT-T224-00			ovo osany tak

¹Furnished as a unit with S212.

₿

495

	Tektronix	Serial/Model	No.	
Ckt. No.	Part No.	Eff	Disc	Description
RESISTORS	(cont)			
R261	315-0751-00			750 ohm. 1/4 W. 5%
R262	321-0064-00			45.3 obm = 1/8 W = 18
D301	311-1311-00			1K ohm Var
R301	221-0226-00			$\frac{1}{2} \frac{9}{4} \frac{1}{2} \frac{1}$
R302 D211	211-1211-00			2.0K Oldi, 1/0 W, 10
ROTT	311-1311-00			$\frac{1}{2} \frac{1}{2} \frac{1}$
RSIZ	321-0236-00			2.0K OIIII, 1/0 W, 16
R321	321-0186-00			845 Onm, 1/8 W, 18
R322	321-0186-00			845 Onm, 1/8 W, 18
R323	321-0157-00			422 Ohm, 1/8 W, 1%
R324	321-0157-00			422 ohm, 1/8 W, 1%
R325	321-0114-00			150 ohm, 1/8 W, 1%
R326	323-0175-00			649 ohm, 1/2 W, 1%
R327	321-0114-00			150 ohm, 1/8 W, 1%
R331	323-0124-00			191 ohm, 1/2 W, 1%
R332	316-0221-00	1		220 ohm, 1/4 W, 10%
R334	316-0391-00	I.		390 ohm, 1/4 W, 10%
R335	321-0065-00	ан сайтаан ал ал ан ал ан		46.4 obm, 1/8 W, 18
R336	321-0065-00	I.		46.4 ohm, 1/8 W, 1%
P340	311-1222-00			100 ohm Var
D2/1	323-0168-00			540 obm 1/2 W 19
N341	323-0108-00			26 l obm 1/9 W 19
R342 D2/2	321-0041-00			100 obm 1/4 M 59
R343	313-0101-00			100 Old, 1/4 W, 55
R344 D345	321-0093-00			$1 \ 1 \ chm \ 1 \ 0 \ W$
R345	321-0197-00			1.11 OIIII, 1/0 W, 16
R340	321-0164-00			499 OIIII, 1/0 W, 16 05 2 obm 1/0 W 19
R34/	321-0095-00			95.5 Offin, $1/6$ W, 16
R348	321-0114-00			150 Onm, 1/8 W, 18
R349	321-0068-00	1		49.9 ohm, 1/8 W, 1%
R351	315-0752-00			7.5K ohm, $1/4$ W, 5%
R352	321-0089-00			82.5 ohm, 1/8 W, 1%
R356	315-0683-00			68K ohm, 1/4 W, 5%
R357	316-0101-00			100 ohm, 1/4 W, 10%
R358	315-0202-00)		2K ohm, 1/4 W, 5%
R359	315-0272-00			2.7K ohm, 1/4 W, 5%
R361	321-0193-00	l .		1K ohm, 1/8 W, 1%
R362	321-0158-00)		432 ohm, 1/8 W, 1%
R364	321-0212-00)		1.58K ohm, 1/8 W, 1%
R365	321-0229-00)		2.37K ohm, 1/8 W, 1%
R367	315-0201-00			200 ohm, 1/4 W, 5%
R368	321-0122-00			182 ohm, 1/8 W, 1%
R370	315-0123-00	XB010350		12K ohm, 1/4 W, 5%
R371	321-0193-00)		1K ohm, 1/8 W, 1%
R372	321-0158-00)		432 ohm, 1/8 W, 1%
R374	321-0212-00)		1.58K ohm, 1/8 W, 1%
R375	321-0229-00)		2.37K ohm, 1/8 W, 1%

Electrical	Parts	List-	-465
------------	-------	-------	------

	Tektronix	Serial/Mod	el No.	
Ckt. No.	Part No.	Eff	Disc	Description
DRATCHORG	(rent)			
RESISTORS				200 obs 1/4 M = 59
R376	315-0201-00			200 Onm, 1/4 W, 58
R3/8	321-0122-00			182 Onm, 1/8 W, 18
R381	316-0152-00			1.5K Onm, 1/4 W, 10%
R383	316-0222-00			2.2K ohm, 1/4 W, 10%
R384	316-0822-00			8.2K ohm, 1/4 W, 10%
R386	316-0223-00			22K ohm, 1/4 W, 10%
R388	316-0154-00			150K ohm, 1/4 w, 10%
R389	316-0154-00			150K ohm, 1/4 W, 10%
R391	316-0152-00			1.5K ohm, 1/4 W, 10%
R393	316-0222-00			2.2K ohm, 1/4 W, 10%
R394	316-0822-00			8.2K ohm, 1/4 W, 10%
R396	316-0223-00			22K ohm, 1/4 W, 10%
R400	311-1139-00	B010100	B039999X	500 ohm. Var
R400	321-0068-00	2020200	20022222	49.9 obm, 1/8 W, 18
P/02	321-0104-00	B010100	BU39999	$118 \text{ obm}_{-} 1/8 \text{ W}_{-} 18$
R402 D/02	315-0221-00	B010100		220 ohm, $1/4 W$, 5%
R402 D402	215-0221-00	B040000	BU30000	39 obm = 1/4 W = 58
R405	312-0330-00	BOIDIOO		55 Olday 1/4 Wy 56
R403	321-0097-00	B040000		100 ohm, 1/8 W, 1%
R404	321-0070-00	B010100	B039999	52.3 ohm, 1/8 W, 1%
R404	321-0097-00	B040000		100 ohm, 1/8 W, 1%
R405	321-0187-00	B010100	B039999X	866 ohm, 1/8 W, 1%
R406	315-0242-00	XB040000		2.4K ohm, 1/4 W, 5%
R407	321-0175-00	B010100	в039999х	649 ohm, 1/8 W, 1%
R408	321-0121-00	XB040000		178 ohm, 1/8 W, 1%
R409	321-0178-00	B010100	B039999	698 ohm, 1/8 W, 1%
R409	321-0189-00	B040000		909 ohm, 1/8 W, 1%
R411	321-0068-00			49.9 ohm, 1/8 W, 1%
R412	315-0221-00	XB040000		220 ohm, 1/4 W, 5%
R413	321-0097-00	XB040000		100 ohm, 1/8 W, 1%
R414	321-0070-00	B010100	в039999	52.3 ohm, 1/8 W, 1%
R414	321-0097-00	B040000		100 ohm, 1/8 W, 1%
R415	315-0100-00	B010100	B039999X	10 ohm, 1/4 W, 5%
R416	315-0242-00	XB040000		2.4K ohm, 1/4 W, 5%
R417	321-0175-00	B010100	B039999X	649 ohm, 1/8 W, 1%
R418	311-1237-00	XB040000		lK ohm, Var
R419	323-0071-00	B010100	в039999	53.6 ohm, 1/2 W, 1%
R419	321-0189-00	B040000		909 ohm, 1/8 W, 1%
R421	315-0620-00	B010100	в039999	62 ohm, 1/4 W, 5%
R421	321-0089-00	B040000		82.5 ohm, 1/8 W, 1%
R422	311-1278-00	XB040000		250 ohm, Var
RT422	307-0181-00	B010100	B039999X	100K ohm, Thermal
R423	315-0471-00	B010100	B010894	470 ohm, 1/4 W, 5%
R423	315-0391-00	B010895	B011199	390 ohm, (nominal value), selected
R423	311-0609-00	B011200	B039999	2K ohm, Var
R423	315-0101-00	B040000		100 ohm, 1/4 W, 5%

.

.

Ckt. No.	Tektronix Part No.	Serial/Mode Eff	el No. Disc	Description
RESISTORS	(cont)			
R424	311-1239-00	B010100	B039999	2.5K ohm, Var
R424	315-0101-00	B040000	2000000	100 obm, 1/4 W, 5%
R425	311-1238-00	XB040000		5K ohm. Var
D/26	321-0423-00	B010100	BU30000	249K obm 1/8 W 19
R420 D426	311-1229-00	B010100	B039999	10K ohm Var
D/27	222-0159-00	B040000	B010210	122 obm 1/2 W 19
R44/ D/27	323-0158-00		B010210	452 OHH, $1/2$ W, 18 200 ohm $1/2$ W 19
R42/	223-0144-00		D039999	$\frac{1}{2} = \frac{1}{2} = \frac{1}$
R42/	311-1225-00	B040000	D010010	1K Originary Var
R428	323-0158-00	BOIDIOD	8010210	432 Onm, 1/2 W, 18
R428	323-0144-00	B010211	в039999х	309 ohm, 1/2 W, 1%
R429	311-1236-00	XB010211	B039999X	250 ohm, Var
R430	323-0159-00	XB040000		442 ohm, 1/2 W, 1%
R431	317-0220-00	XB040000		22 ohm, 1/8 W, 1%
R432	315-0131-00	XB040000		130 ohm. 1/4 W. 5%
R433	311-1138-00	B010100	B039999	1K ohm. Var
R433	323-0118-00	B040000		165 ohm. 1/2 W. 1%
R434	311-1138-00	B010100	B039999	lK ohm. Var
R434	315-0100-00	B040000	2000000	10 ohm, 1/4 W, 5%
R435	321-0059-00	XB040000		40.2 ohm, 1/8 W, 1%
R436	317-0100-00) XB040000		10 ohm, 1/8 W, 1%
R437	323-0158-00) B010100	B039999	432 ohm, 1/2 W, 1%
R437	317-0561-00	B040000		560 ohm, 1/8 W, 1%
R438	323-0158-00) B010100	B039999	432 ohm, 1/2 W, 1%
R438	311-1260-00) B040000		250 ohm, Var
R440	321-0080-00) B010100	B039999	66.5 ohm, 1/8 W, 1%
R440	323-0159-00) B040000		442 ohm, 1/2 W, 1%
R441	321-0064-00) B010100	B039999	45.3 ohm, 1/8 W, 1%
P441	317-0220-00	B040000		22 Ohm. 1/8 W. 18
P442	311-1139-00	B010100	BU30000	500 obm. Var
D// 2	315-0131-00	B040000		130 ohm 1/4 W 59
D//3	321-0193-00	B010100	BU30000	150 Ohm 1/4 W 19
R443	323-0133-00	B010100	B033333	165 obm 1/2 W 19
D///	315-0302-00	B040000	BU30000	3K obm 1/4 W 59
P///	315-0100-00	B010100	0000000	10 obm, 1/4 W, 58
R445	315-0472-00	B010100	B039999	4.7K obm, 1/4 W, 5%
R445	321-0059-00	B010100	000000	40.2 obm, $1/8 W$, 18
11445	521 0055 00			
R446	321-0070-00	B010100	B039999X	52.3 ohm, 1/8 W, 1%
R447	321-0070-00	B010100	B039999X	52.3 ohm, 1/8 W, 1%
R448	322-0662-00	B010100	B039999	334 ohm, 1/4 W, 1/2%
R448	315-0622-00	B040000		6.2K ohm, 1/4 W, 5%
RT448	307-0181-00	XB040000		100K ohm, Thermal
R449	322-0180-00) B010100	B039999	732 ohm, 1/4 W, 5%
R449	317-0102-00	B040000		1K ohm, 1/8 W, 5%
R451	321-0196-00) B010100	B039999	1.07K ohm, 1/8 W, 1%
R451	315-0820-00	B040000		82 ohm, 1/4 W, 5%

Ckt. No.	Tektronix Part No.	Serial/Mod Eff	el No. Disc	Description
	(acat)			
RESISIONS	215-0101-00	B010100	PU30000	100 obm 1/4 W 59
R452 D452	315-0301-00	B010100	8039999	300 obm 1/4 W 59
R4J2 D452	313-0301-00	B040000	DU30000	2.05K obm 1/9 W 19
R41JJ	321-0223-00	B010100	D039999	1/2 obm 1/2 W 19
R455 D454	323-0157-00	B040000	PUSOOOA	422 Office, $1/2$ W, $15A99 obm 1/8 W 19$
R4 J4 D455	321-0104-00	B010100	D030000V	ly ohm Var
R433	215-0201-00	B010100	B03333333	200 obm 1/4 W 59
R437	313-0201-00	B010100	D030000	100 obm $1/9 W$ 59
R401 D462	321-0205-00	VB040000	DUJJJJJ	1 33K ohm 1/8 W 19
R402		XB040000		1.55K OHM, 1/6 W, 1%
R463	321-0219-00	XB040000		1.87K ohm, 1/8 W, 1%
R464	310-0700-00	B010100	B039999	430K ohm, 4 W, WW, 1%
R464	321-0093-00	в040000		90.9 ohm, 1/8 W, 1%
R465	321-0126-00	XB040000		200 ohm, 1/8 W, 1%
R466	311-1226-00	XB040000		2.5K ohm, Var
R468	321-0031-00	XB040000		20.5 ohm, 1/8 W, 1%
R469	323-0072-00	XB040000		54.9 ohm, 1/2 W, 1%
R471	317-0101-00	B010100	B039999X	100 ohm, 1/8 W, 5%
R474	310-0700-00	B010100	B039999	430K ohm, 4 W, WW, 1%
R474	321-0093-00	в040000		90.9 ohm, 1/8 W, 1%
R475	321-0126-00	XB040000		200 ohm, 1/8 W, 1%
R478	321-0031-00	XB040000		20.5 ohm, 1/8 W, 1%
R480	315-0100-00	XB040000		10 ohm, 1/4 W, 5%
R481	315-0820-00	XB040000		82 ohm, 1/4 W, 5%
R482	315-0820-00	XB040000		82 ohm, 1/4 W, 5%
R483	310-0700-00	XB040000		430 ohm, 4 W, WW, 1%
R485	301-0100-00	XB040000		10 ohm, 1/2 W, 5%
R491	315-0820-00	XB040000		82 ohm, 1/4 W, 5%
R492	315-0820-00	XB040000		82 ohm, 1/4 W, 5%
R493	310-0700-00	XB040000		430 ohm, 4 W, WW, 1%
R498	315-0100-00	XB040000		10 ohm, 1/4 W, 5%
R499	315-0100-00	XB040000		10 ohm, 1/4 W, 5%
R502	315-0754-00			750K ohm, 1/4 W, 5%
R503	315-0334-00			330K ohm, $1/4$ W, 5%
R507	321-0068-00			49.9 ohm, 1/8 W, 1%
R508	321-0068-00			49.9 ohm, 1/8 W, 1%
R509	321-0068-00			49.9 ohm, 1/8 W, 1%
הבס	316-0104-00			100K ohm, 1/4 W, 10%
R512	316-0563-00			56K ohm, 1/4 W, 10%
R516	316-0105-00			1M ohm, 1/4 W, 10%
R517	316-0101-00			100 ohm, 1/4 W, 10%
R518	316-0101-00			100 ohm, 1/4 W, 10%
R522	316-0101-00			100 ohm, 1/4 W, 10%
R522	316-0150-00			15 ohm, 1/4 W, 10%
R524	316-0150-00			15 ohm, 1/4 W, 10%
R525	316-0101-00			100 ohm, 1/4 W, 10%

.

营

権的によ

修 1

345- 244

Ckt. No.	Tektronix Part No.	Serial/Model Eff	No. Disc	Description
RESISTORS	(cont)			
R527	321-0209-00)		1.47K ohm, 1/8 W, 1%
R528	315-0390-00)		39 ohm. 1/4 W. 5%
R520	321-0209-00			1.47K obm. $1/8$ W. 18
R5201	211-1102-00	י ר		10K ohm Var
R550				$\frac{100}{100} = \frac{1}{4} = \frac{100}{100}$
RSSI	310-0081-00			$\frac{1}{4} \text{ W}_{1} = \frac{1}{4} \text{ W}_{1} = \frac{1}{4} \text{ W}_{2} = \frac{1}$
R535	311-1230-00			20K Onm, Var
R536	315-0202-00)		2K Ohm, 1/4 W, 5%
R537	315-0560-00	כ		56 ohm, 1/4 W, 5%
R538	315-0362-00	0		3.6K ohm, 1/4 W, 5%
R539	316-0222-00	D		2.2K ohm, 1/4 W, 10%
R540	316-0222-00	0		2.2K ohm, 1/4 W, 10%
R541	316-0682-00	0		6.8K ohm, 1/4 W, 10%
R542	316-0182-00	0		1.8K ohm, 1/4 W, 10%
R544	316-0103-00	C		10K ohm, 1/4 W, 10%
R545	311-1230-00	0		20K ohm, Var
R546	315-0101-00	5		100 ohm, 1/4 W, 5%
R547	315-0101-00	- n		100 ohm, 1/4 W, 5%
R549	315-0331-00	ĥ		330 ohm, 1/4 W, 5%
1(34)	515 0551 0	5		550 Offic, 1/4 (1) 50
R550	316-0330-00	0		33 ohm, 1/4 W, 10%
R551	323-0305-00	D		14.7K ohm, 1/2 W, 1%
R552	316-0330-00	0		33 ohm, 1/4 W, 10%
R553	316-0153-00	0		15K ohm, 1/4 W, 10%
R554	316-0104-0	0		100K ohm, 1/4 W, 10%
R555	311-1230-00	0		20K ohm. Var
R556	316-0562-00	n		5.6K obm, 1/4 W, 108
R550 R557	317-0101-0	0 B010100	B010724	100 obm, $1/8 W$, 5%
D557	321-0097-0	0 B010100	DOTOILA	100 obm 1/8 W 19
K557	521-0097-00	0 0010725		
RT557	307-0124-0	0 XB010725		5K ohm, Thermal
R558	321-0258-0	0		4.75K ohm, 1/8 W, 1%
R602	316-0470-0	0		47 ohm, 1/4 W, 10%
R603	325-0073-0	0		3.57M ohm, 1/2 W, 1%
R604	321-0385-0	0		100K ohm, 1/8 W, 1%
R606	323-0480-0	0		976K ohm, 1/2 W, 1%
R607	321-0451-0	0		487K ohm, 1/8 W, 1%
R609	316-0102-0	0 B010100	B010399	1K ohm, 1/4 W, 10%
R609	316-0274-0	0 B010400		270K ohm, 1/4 W, 10%
R611	316-0104-0	0		100K ohm, 1/4 W, 10%
R612	316-0563-0	Ō		56K ohm, 1/4 W, 10%
R616	321-0481-0	0		1M ohm, 1/8 W, 18
DE17	316-0101-0	n n		$100 \text{ obm} \ 1/4 \text{ W} \ 109$
DE10		n n		100 obm 1/4 W 109
R010	316-0101-0	0		100 obm 1/4 W 109
R022	21C 01E0 0	0		16 obm 1/4 W 106
R023	310-0120-0	0		15 ohm 1/4 W, 105
R624	310-0120-0	0		15 Onm, 1/4 W, 10%
R625	310-0101-0	U		LUU ONM, L/4 W, LUX

 ${}^{\rm l}{\rm Furnished}$ as a unit with S530.

₿

	Tektronix	Serial/Mod	el No.	
Ckt. No.	Part No.	Eff	Disc	Description
RESISTORS	(cont)			
R627	321-0209-00			1.47K ohm, 1/8 W, 1%
R628	315-0390-00			39 ohm, 1/4 W, 5%
R629	321-0209-00			1.47K ohm, 1/8 W, 1%
R6301	311-1192-00			10K ohm. Var
R631	316-0681-00			680 obm, 1/4 W, 10%
P635	311-1230-00			20K obm. Var
D636	315-0202-00			2K ohm, $1/4 W$, 58
R030	315-0560-00			56 ohm 1/4 W 58
R037	315-0362-00			3 6 K obm 1/4 W 59
R030	315-0302-00			5.0K Olma, 1/4 W, 58
R639	316-0222-00			2.2K ohm, 1/4 W, 10%
R640	316-0222-00			2.2K ohm, 1/4 W, 10%
R641	316-0682-00			6.8K ohm, 1/4 W, 10%
R642	316-0182-00			1.8K ohm, 1/4 W, 10%
R644	316-0103-00			10K ohm, 1/4 W, 10%
R645	311-1230-00			20K ohm, Var
R646	315-0101-00			100 ohm, 1/4 W, 5%
R647	315-0101-00			100 ohm, 1/4 W, 5%
R649	315-0331-00			330 ohm, 1/4 W, 5%
R650	316-0330-00			33 ohm. 1/4 W. 10%
R651	323-0305-00			14.7K obm. $1/2$ W. 18
D652	316-0330-00			33 obm, 1/4 W, 10%
D655	311-1230-00			20K ohm. Var
DEEE	316-0562-00			5.6K obm, 1/4 W, 108
R050	317-0101-00	B010100	B010724	100 obm = 1/8 W = 58
R057	317-0101-00	B010100	D010724	100 obm $1/8 W$ 18
	321-009/-00	VB010725		5K ohm Thermal
RTOD/	307-0124-00	ABUI0725		A 75K obm 1/8 W 18
R658	321-0258-00			4.75K OHM, 170 W, 18
R671	316-0100-00			10 ohm, 1/4 W, 10%
R672	315-0680-00			68 ohm, 1/4 W, 5%
R674	316-0100-00	B010100	B010804X	10 ohm, 1/4 W, 10%
R674	315-0470-00	XB011200		47 ohm, 1/4 W, 5%
R675	311-1259-00			100 ohm, Var
R676	315-0430-00			43 ohm, 1/4 W, 5%
R677	315-0102-00			1K ohm, 1/4 W, 5%
R678	315-0510-00			51 ohm, 1/4 W, 5%
R679	315-0120-00			12 ohm, 1/4 W, 5%
R681	316-0100-00			10 ohm, 1/4 W, 10%
R682	315-0680-00			68 ohm, 1/4 W, 5%
R683	315-0471-00			470 ohm, 1/4 W, 5%
R684	316-0101-00	B010100	B010804X	100 ohm, 1/4 W, 10%
R687	315-0102-00			1K ohm, 1/4 W, 5%
R688	315-0510-00			51 ohm, 1/4 W, 5%
R689	315-0120-00			12 ohm, 1/4 W, 5%
R690	316-0100-00			10 ohm, 1/4 W, 10%
R691	316-0104-00			100K ohm, 1/4 W, 10%

 1 Furnished as a unit with the S630.

· 1110

ŝţ.

19. 19.

の高度

	Tektronix	Serial/Model	No.		
Ckt. No.	Part No.	Eff	Disc	Description	
RESISTORS	(cont)				
R692	315-0152-00			1.5K ohm, 1/4 W, 5%	
R694	315-0431-00			430 ohm, 1/4 W, 5%	
R697	316-0100-00			10 ohm, $1/4 W$, $10%$	
R699	316-0100-00			10 ohm, 1/4 W, 108	
R803	315-0391-00			390 obm, 1/4 W, 58	
R804	321-0186-00			845 obm, 1/8 W, 18	
R805	316-0220-00			$22 \text{ ohm} \cdot 1/4 \text{ W} \cdot 108$	
R005 R807	321-0243-00			3 32 mm, $1/8$ W, 18	
D808	321-0206-00			1.37K obm, 1/8 W 18	
NOOO	521 0200 00				
R809	315-0132-00			1.3K ohm, 1/4 W, 5%	
R 811	315-0390-00	l ·		39 ohm, 1/4 W, 5%	
R812	321-0211-00	I		1.54K ohm, 1/8 W, 1%	
R814	315-0332-00	1		3.3K ohm, 1/4 W, 5%	
R815	315-0151-00	I		150 ohm, 1/4 W, 5%	
R 817	315-0681-00	I		680 ohm, 1/4 W, 5%	
R818	315-0681-00)		680 ohm, 1/4 W, 5%	
R822	315-0102-00	B010100 H	3010599	1K ohm, 1/4 W, 5%	
R822	315-0103-00	B010600		10K ohm, 1/4 W, 5%	
R823	315-0153-00	1		15K ohm. 1/4 W. 5%	
R824	315-0103-00			10K obm, 1/4 W, 5%	
R827	315-0102-00			16000000000000000000000000000000000000	
R828	315-0102-00			1K ohm = 1/4 W = 5%	
R829	316-0220-00			22 obm = 1/4 W = 108	
D831	315-0102-00			1K obm 1/4 W 59	
D831	315-0100-00			10 obm 1/4 W 58	
R836	315-0100-00			$10 \text{ obm}_{1} 1/4 \text{ W}_{2} 58$	
R838	316-0101-00			100 obm, 1/4 W, 108	
1050	510 0101 00	·			
R853	315-0471-00)		470 ohm, 1/4 W, 5%	
R854	321-0200-00			1.18K ohm, 1/8 W, 1%	
R855	316-0220-00)		22 ohm, 1/4 W, 10%	
R 856	316-0270-00)		27 ohm, 1/4 W, 10%	
R857	321-0243-00)		3.32K ohm, 1/8 W, 1%	
R858	321-0201-00)		1.21K ohm, 1/8 W, 1%	
R859	315-0132-00)		1.3K ohm, 1/4 W, 5%	
R861	315-0390-00)		39 ohm, 1/4 W, 5%	
R862	321-0211-00) B010100 I	B010599	1.54K ohm, 1/8 W, 1%	
R862	321-0209-00	B010600		1.47K ohm, 1/8 W, 1%	
R863	315-0103-00	XB010600		10K ohm, $1/4 W$, 5%	
R864	315-0332-00)		3.3K ohm, 1/4 W, 5%	
R865	315-0151-00)		150 ohm, 1/4 W, 5%	
RRAA	315-0471-00)		470 ohm. 1/4 W. 5%	
R871	315-0472-00)		4.7K ohm. 1/4 W. 5%	
R872	315-0241-00)		240 ohm, 1/4 W, 5%	
R877	315-0102-00)		1K ohm, 1/4 W, 5%	
R879	315-0274-00)		270K ohm, 1/4 W, 5%	
NOT 2	515 02/3 00	•			

Į

1. 7

	Electrical	Parts	List-4	165
--	------------	-------	--------	-----

	Tektronix	Serial/Model	No.	
Ckt. No.	Part No.	Eff	Disc	Description
RESISTORS	(cont)			
R1001	315-0360-00	1		36 ohm, 1/4 W, 5%
R1002	303-0432-00			4.3K ohm. 1 W. 5%
R1003	316-0101-00			100 ohm, 1/4 W, 10%
R1004	315-0360-00			36 obm, $1/4 W$, 58
R1005	316-0220-00			$22 \text{ ohm} \cdot 1/4 \text{ W} \cdot 10\%$
R1005	308-0421-00			3K ohm, $3W$, WW , $5%$
R1000	316-0103-00			10K ohm, $1/4 W$, 108
P1012	321-0164-00			499 ohm = 1/8 W = 18
D1012	321-0228-00			2.32K ohm. $1/8$ W. 18
KT012	521 0220 00			
R1016	321-0195-00			1.05K ohm, 1/8 W, 1%
R1017	321-0250-00			3.92K ohm, 1/8 W, 1%
R 102 1	321-0193-00			1K ohm, 1/8 W, 1%
R1022	321-0193-00			1K ohm, 1/8 W, 1%
R1024	321-0165-00	ł		511 ohm, 1/8 W, 1%
R1026	316-0181-00			180 ohm, 1/4 W, 10%
R1029	316-0101-00)		100 ohm, 1/4 W, 10%
R1031	316-0470-00	1		47 ohm, 1/4 W, 10%
R1032	316-0101-00	1		100 ohm, 1/4 W, 10%
B1033	321-0256-00			4.53K ohm, 1/8 W, 1%
P1035	316-0101-00			100 obm, $1/4 W$, 108
P1037	321-0251-01			4.02K ohm. $1/8$ W. $1/2$ %
R1038	316-0470-00			47 ohm, $1/4 W$, $10%$
P1039	321-0228-00			2.32K ohm. 1/8 W. 1%
R1035	316-0101-00			100 ohm, 1/4 W, 10%
P1044	321-0227-00			2.26K ohm, 1/8 W, 1%
D1045	316-0101-00			100 ohm, 1/4 W, 10%
R1045	316-0562-00	B010100 E	3010599	5.6K ohm, 1/4 W, 10%
R1046	301-0562-00	B010600		5.6K ohm, 1/2 W, 5%
R1047	316-0681-00	B010100 E	3010599	680 ohm, 1/4 W, 10%
R1047	315-0681-00	B010600		680 ohm, 1/4 W, 5%
R1048	315-0752-00			7.5K ohm, 1/4 W, 5%
R1049	316-0681-00	B010100 F	3010599	680 ohm, 1/4 W, 10%
R1049	315-0681-00	B010600		680 ohm, 1/4 W, 5%
R1052	315-0561-00			560 ohm, 1/4 W, 5%
R1053	315-0622-00	B010100 E	3010599	6.2K ohm, 1/4 W, 5%
R1053	301-0622-00	B010600		6.2K ohm, 1/2 W, 5%
R1054	316-0102-00	B010100 F	3010599	1K ohm, 1/4 W, 10%
R1054	315-0102-00	B010600		1K ohm, 1/4 W, 5%
R1057	316-0562-00	B010100 B	3010599	5.6K ohm, 1/4 W, 10%
R1057	315-0562-00	B010600		5.6K ohm, 1/4 W, 5%
R1061	315-0360-00)		36 ohm, 1/4 W, 5%
R1062	301-0432-00)		4.3K ohm, 1/2 W, 5%
R1063	316-0101-00)		100 ohm, 1/4 W, 10%
R1064	315-0360-00)		36 ohm, 1/4 W, 5%
R1065	316-0220-00)		22 ohm, 1/4 W, 10%

and the second

F

1.12 A

2

- 2 -

Ckt. No. Part No. Eff Disc Description RESISTORS (cont) 308-0421-00 3K ohm, 3 W, WW, 5% 3K ohm, 1/8 W, 16% R1071 316-0103-00 10K ohm, 1/4 W, 10% 3K ohm, 1/8 W, 18 R1073 321-0228-00 2.32K ohm, 1/8 W, 18 3K ohm, 1/8 W, 18 R1077 321-0250-00 3.92K ohm, 1/8 W, 18 3K ohm, 1/8 W, 18 R1081 321-0195-00 1K ohm, 1/8 W, 18 3K ohm, 1/8 W, 18 R1082 321-0195-00 1K ohm, 1/8 W, 18 3K ohm, 1/8 W, 18 R1083 321-0195-00 1K ohm, 1/4 W, 108 3K ohm, 1/8 W, 18 R1084 321-0195-00 1K ohm, 1/4 W, 108 3K ohm, 1/8 W, 18 R1086 316-0181-00 180 ohm, 1/4 W, 108 3K ohm, 1/8 W, 18 R1093 321-0256-00 4.53K ohm, 1/4 W, 108 3K ohm, 102 W, 18 R1093 321-0251-01 4.02K ohm, 1/4 W, 108 3K ohm, 12 W, 12% R1103 316-0101-00 100 ohm, 1/4 W, 108 3K ohm, 12 W, 12% R1111 321-0251-01 4.02K ohm, 1/4 W, 108 3K ohm, 12 W, 12% R1109 </th <th></th> <th>Tektronix</th> <th>Serial/Model</th> <th>No.</th> <th></th> <th></th>		Tektronix	Serial/Model	No.		
RIO66 300-0421-00 3K ohm, 3 W, WW, 5% R1071 316-0103-00 10K ohm, 1/4 W, 10% R1072 321-0164-00 499 ohm, 1/8 W, 1% R1073 321-0228-00 2.32X ohm, 1/8 W, 1% R1073 321-0228-00 3.92X ohm, 1/8 W, 1% R1076 321-0195-00 1.05K ohm, 1/8 W, 1% R1081 321-0193-00 1K ohm, 1/8 W, 1% R1084 321-0193-00 1K ohm, 1/8 W, 1% R1085 316-0181-00 180 ohm, 1/4 W, 10% R1084 321-0256-00 4.53K ohm, 1/4 W, 10% R1093 316-0470-00 47 ohm, 1/4 W, 10% R1093 321-0256-00 4.53K ohm, 1/8 W, 1% R1093 321-0256-00 4.53K ohm, 1/4 W, 10% R1093 321-0251-01 4.02K ohm, 1/4 W, 10% R1093 321-0250-00 2.37K ohm, 1/4 W, 10% R1091 316-0402-00 562 ohm, 1/8 W, 1% R1101 311-1464-00 2K ohm, 1/4 W, 10% R1111 321-0251-00 2.49K ohm, 1/8 W, 1% R1112 321-0261-04 1/6 W, 1% <th>Ckt. No.</th> <th>Part No.</th> <th>Eff</th> <th>Disc</th> <th>Description</th> <th></th>	Ckt. No.	Part No.	Eff	Disc	Description	
No. Str. State State <thstate< th=""> State State <</thstate<>	RESISTORS	(cont)				
R1071 312-0103-00 10x ohm, 1/4 W, 10% R1072 321-0164-00 499 ohm, 1/8 W, 1% R1073 321-028-00 2.32K ohm, 1/8 W, 1% R1077 321-028-00 1.05K ohm, 1/8 W, 1% R1077 321-0250-00 3.92K ohm, 1/8 W, 1% R1081 321-0193-00 1K ohm, 1/8 W, 1% R1082 321-0193-00 1K ohm, 1/8 W, 1% R1084 321-0155-00 10 ohm, 1/4 W, 10% R1084 321-0165-00 10 ohm, 1/4 W, 10% R1084 316-0101-00 100 ohm, 1/4 W, 10% R1093 316-0101-00 100 ohm, 1/4 W, 10% R1093 321-0256-00 4.53K ohm, 1/8 W, 1% R1093 321-0251-01 4.02K ohm, 1/8 W, 1% R1093 321-0251-01 4.02K ohm, 1/8 W, 1% R1110 311-1464-00 2K ohm, Var R1111 321-0125-00 562 ohm, 1/8 W, 1% R1111 321-0254-01 100 ohm, 1/4 W, 10% R1113 321-0268-04 1.5M ohm, 1/2 W, 1/10% R1113 321-0268-04 1.5M ohm, 1/2 W, 1/10% R1111 321-0268-04 1.5M ohm, 1/2 W, 1/10% <td>R1066</td> <td>308-0421-00</td> <td>1</td> <td></td> <td>3K ohm. 3 W. WW. 5%</td> <td></td>	R1066	308-0421-00	1		3K ohm. 3 W. WW. 5%	
Ritoric 332-0164-00 499 cimi, 1/8 W, 1% Ritoria 321-0128-00 2.32K cim, 1/8 W, 1% Ritoria 321-0228-00 2.32K cim, 1/8 W, 1% Ritoria 321-0228-00 3.92K cim, 1/8 W, 1% Ritoria 321-0228-00 3.92K cim, 1/8 W, 1% Ritoria 321-0193-00 1K cim, 1/8 W, 1% Ritoria 321-0193-00 1K cim, 1/8 W, 1% Ritoria 316-0181-00 180 cim, 1/4 W, 10% Ritoria 316-0101-00 100 cim, 1/4 W, 10% Ritoria 316-0101-00 100 cim, 1/4 W, 10% Ritoria 321-0226-00 4.53K cim, 1/8 W, 1% Ritoria 316-0101-00 100 cim, 1/4 W, 10% Ritoria 316-0101-00 100 cim, 1/4 W, 10% Ritoria 316-0101-00 4.53K cim, 1/8 W, 1% Ritoria 316-0101-00 6.8K cim, 1/8 W, 1% Ritoria 316-0101-00 2.37K cim, 1/8 W, 1% Ritoria 316-0101-00 2.37K cim, 1/8 W, 1% Ritoria 316-0101-00 2.37K cim, 1/8 W, 1% Ritoria 321-0251-01 </td <td>R1071</td> <td>316-0103-00</td> <td></td> <td></td> <td>10K obm = 1/4 W = 108</td> <td></td>	R1071	316-0103-00			10K obm = 1/4 W = 108	
R1073 321-0228-00 2.32K ohm, 1/5 W, 1% R1075 321-0135-00 1.05K ohm, 1/6 W, 1% R1077 321-0236-00 3.92K ohm, 1/8 W, 1% R1081 321-0139-00 1K ohm, 1/8 W, 1% R1082 321-0139-00 1K ohm, 1/8 W, 1% R1082 321-0155-00 1K ohm, 1/8 W, 1% R1084 321-0155-00 180 ohm, 1/4 W, 10% R1085 316-0101-00 100 ohm, 1/4 W, 10% R1091 316-0470-00 47 ohm, 1/8 W, 1% R1093 321-0256-00 4.53K ohm, 1/8 W, 1% R1093 321-0256-00 4.53K ohm, 1/8 W, 1% R1095 316-010-00 100 ohm, 1/4 W, 10% R1097 321-0251-01 4.02K ohm, 1/8 W, 1% R1098 321-0229-00 2.37K ohm, 1/8 W, 1% R1110 311-1464-00 2K ohm, Var R1111 321-0125-00 196 ohm, 1/8 W, 1% R1112 321-0231-00 2.49K ohm, 1/2 W, 1/10% R1113 321-048-04 1.5M ohm, 1/2 W, 1/10% R1113 321-048-04 1.5M ohm, 1/2 W, 1/10% R1133 321-048-04 1.5M ohm, 1/2 W, 1/10% <	D1072	321-0164-00			100 obm 1/9 W 19	
R1075 321-0225-00 1.05K ohm, 1/8 W, 18 R1077 321-0250-00 3.92K ohm, 1/8 W, 18 R1081 321-0193-00 1K ohm, 1/8 W, 18 R1082 321-0193-00 1K ohm, 1/8 W, 18 R1084 321-0165-00 1K ohm, 1/4 W, 108 R1084 321-0165-00 180 ohm, 1/4 W, 108 R1084 321-0165-00 100 ohm, 1/4 W, 108 R1089 316-0101-00 100 ohm, 1/4 W, 108 R1091 316-0470-00 47 ohm, 1/4 W, 108 R1092 316-0101-00 100 ohm, 1/4 W, 108 R1093 321-0256-00 4.53K ohm, 1/8 W, 18 R1093 321-0229-00 2.37K ohm, Var R1093 321-0229-00 2.37K ohm, 1/8 W, 18 R1101 311-1464-00 2K ohm, Var R1111 321-0169-00 562 ohm, 1/8 W, 18 R1112 321-0068-00 49.9 ohm, 1/8 W, 18 R1113 321-0169-00 24.9K ohm, 1/8 W, 18 R1113 321-0169-00 24.9K ohm, 1/8 W, 18 R1113 321-0169-00 24.9K ohm, 1/8 W, 18 R1113 321-0169-00 150 ohm, 1/8 W, 18	R1072	321-0209-00			$\frac{1}{2} \frac{1}{2} \frac{1}$	
R1070 321-0250-00 3.92K ohm, 1/8 W, 18 R1081 321-0193-00 1K ohm, 1/8 W, 18 R1082 321-0193-00 1K ohm, 1/8 W, 18 R1084 321-0165-00 180 ohm, 1/4 W, 108 R1086 316-0181-00 180 ohm, 1/4 W, 108 R1089 316-0101-00 100 ohm, 1/4 W, 108 R1091 316-0470-00 47 ohm, 1/4 W, 108 R1092 316-0101-00 100 ohm, 1/4 W, 108 R1093 321-0256-00 4.53K ohm, 1/8 W, 18 R1095 316-0101-00 100 ohm, 1/4 W, 108 R1097 321-0251-01 4.02K ohm, 1/8 W, 18 R1098 321-0225-00 2.37K ohm, 1/8 W, 18 R1101 316-0682-00 6.8K ohm, 1/4 W, 108 R1111 321-0169-00 562 ohm, 1/8 W, 18 R1112 321-0125-00 196 ohm, 1/2 W, 1/108 R1113 321-0125-00 196 ohm, 1/2 W, 1/108 R1113 321-0125-00 196 ohm, 1/2 W, 1/108 R1113 321-0125-00 196 ohm, 1/2 W, 1/108 R1133 323-0488-04 1.5M ohm, 1/2 W, 1/108 R1131 321-01231-00 2.4K ohm, 1/8 W, 1	R1075	221-0228-00			2.52 CILL, $1/6$ W, 16	
R1007, 321-0230-00 15 321 Norm, 1/8 W, 18 R1081 321-0193-00 1K ohm, 1/8 W, 18 R1082 321-0193-00 1K ohm, 1/8 W, 18 R1084 321-0193-00 1K ohm, 1/8 W, 18 R1084 321-0165-00 511 ohm, 1/4 W, 108 R1089 316-0101-00 100 ohm, 1/4 W, 108 R1092 316-0101-00 100 ohm, 1/4 W, 108 R1093 321-0256-00 4.53K ohm, 1/8 W, 18 R1095 316-0101-00 100 ohm, 1/4 W, 108 R1093 321-0256-00 4.53K ohm, 1/8 W, 18 R1095 316-0101-00 100 ohm, 1/4 W, 108 R1096 321-0229-00 2.37K ohm, 1/8 W, 18 R1097 321-0229-00 2.37K ohm, Var R1101 311-1464-00 2K ohm, Var R1113 321-0169-00 562 ohm, 1/8 W, 18 R1113 321-0169-00 2.69 ohm, 1/8 W, 18 R1113 321-0169-00 2.69 ohm, 1/8 W, 18 R1113 321-025-00 196 ohm, 1/8 W, 18 R1113 321-0249-04 1.5M ohm, 1/2 W, 1/108 R1131 321-0648-04 500K ohm, 1/8 W, 14 <t< td=""><td>R1070</td><td>321-0195-00</td><td></td><td></td><td>1.05K OIIIII, 1/6 W, 16</td><td></td></t<>	R1070	321-0195-00			1.05K OIIIII, 1/6 W, 16	
R1081 321-0193-00 1K 01m, 1/8 W, 1% R1082 321-0165-00 1K 01m, 1/8 W, 1% R1084 321-0165-00 1K 01m, 1/8 W, 1% R1086 316-0101-00 180 0hm, 1/4 W, 10% R1081 316-0101-00 100 0hm, 1/4 W, 10% R1091 316-0470-00 47 ohm, 1/4 W, 10% R1092 316-0101-00 100 0hm, 1/4 W, 10% R1093 321-0256-00 4.53K 0hm, 1/8 W, 1% R1095 316-0101-00 100 0hm, 1/4 W, 10% R1097 321-0251-01 4.02K 0hm, 1/8 W, 1% R1098 321-0259-00 2.37K ohm, 1/8 W, 1% R1010 316-0682-00 6.8K 0hm, 1/4 W, 10% R1111 321-0169-00 2K ohm, Var R1111 321-0169-00 2K ohm, 1/8 W, 1% R1112 321-0668-00 49.9 ohm, 1/8 W, 1% R1113 321-0125-00 196 ohm, 1/8 W, 1% R1111 321-0125-00 196 ohm, 1/2 W, 1% R1113 321-048-04 1.5M ohm, 1/2 W, 1% R1131 323-0481-04 100 ohm, 1/2 W, 110% R1133 321-0648-04 50K ohm, 1/8 W, 1/10% <tr< td=""><td>R1077</td><td>321-0250-00</td><td></td><td></td><td>3.92 M OILIN, 1/0 W, 18</td><td></td></tr<>	R1077	321-0250-00			3.92 M OILIN, 1/0 W, 18	
R1082 321-0193-00 1K 0fm, 1/8 W, 1% R1084 321-0165-00 511 ohm, 1/4 W, 10% R1089 316-0101-00 100 ohm, 1/4 W, 10% R1091 316-0101-00 100 ohm, 1/4 W, 10% R1092 316-0101-00 100 ohm, 1/4 W, 10% R1093 321-0256-00 4.53K ohm, 1/8 W, 1% R1093 321-0229-00 2.37K ohm, 1/8 W, 1% R1097 321-0229-00 2.37K ohm, 1/8 W, 1% R1011 316-0682-00 6.8K ohm, 1/8 W, 1% R1101 311-1464-00 2K ohm, Var R1111 321-015-00 196 ohm, 1/8 W, 1% R1112 321-015-00 196 ohm, 1/8 W, 1% R1113 321-0231-00 2.49K ohm, 1/8 W, 1% R1113 321-0480-04 1.5M ohm, 1/2 W, 1/10% R1131 322-0490-04 1.5M ohm, 1/2 W, 1/10% R1133 321-0648-04 500K ohm, 1/8 W, 1/10% R1133 321-0648-04 500K ohm, 1/8 W, 1/10% R1133 321-0648-04 500K ohm, 1/8 W, 1/10% R1134 321-0648-04 500K ohm, 1/8 W, 1/10% R1135 321-0648-04 500K ohm, 1/8 W, 1/10	RIUBI	321-0193-00			$\frac{1}{10} \text{ Orm}, \frac{1}{8} \text{ W}, \frac{1}{8}$	
R1084 321-0165-00 511 Ohm, 1/4 W, 10% R1089 316-0101-00 180 ohm, 1/4 W, 10% R1091 316-0470-00 47 ohm, 1/4 W, 10% R1092 316-0101-00 100 ohm, 1/4 W, 10% R1093 321-0256-00 4.53K ohm, 1/8 W, 1% R1095 316-0101-00 100 ohm, 1/4 W, 10% R1097 321-0251-01 4.02K ohm, 1/8 W, 1% R1098 321-0259-00 2.37K ohm, 1/8 W, 1% R1011 311-1464-00 2K ohm, Var R1111 321-0159-00 562 ohm, 1/8 W, 1% R1112 321-0125-00 196 ohm, 1/8 W, 1% R1113 321-0215-00 196 ohm, 1/8 W, 1% R1113 321-0231-00 2.49K ohm, 1/8 W, 1% R1113 321-048-04 100 ohm, 1/2 W, 1/10% R1131 323-0481-04 1M ohm, 1/2 W, 1/10% R1133 323-0481-04 1M ohm, 1/8 W, 11% R1134 321-0648-04 500K ohm, 1/8 W, 1/10% R1135 321-0648-04 500K ohm, 1/8 W, 1/10% R1136 321-044-04 200K ohm, 1/8 W, 1/10% R1137 321-0385-04 100K ohm, 1/8 W, 1/10%	RIU82	321-0193-00			1K Onm, 1/8 W, 1%	
R1086 316-0181-00 180 ohm, 1/4 W, 10% R1089 316-0101-00 100 ohm, 1/4 W, 10% R1091 316-0101-00 100 ohm, 1/4 W, 10% R1093 321-0256-00 4.53K ohm, 1/8 W, 1% R1095 316-0101-00 100 ohm, 1/4 W, 10% R1095 321-0251-01 4.02K ohm, 1/8 W, 1% R1098 321-0229-00 2.37K ohm, 1/8 W, 1% R1101 311-1464-00 2K ohm, Var R1111 321-0125-00 562 ohm, 1/8 W, 1% R1112 321-0125-00 196 ohm, 1/8 W, 1% R1113 321-0125-00 196 ohm, 1/8 W, 1% R1113 321-0125-00 196 ohm, 1/8 W, 1% R1113 321-0231-00 2.49K ohm, 1/8 W, 1% R1113 321-0231-00 2.49K ohm, 1/2 W, 1/10% R1133 323-0481-04 1M ohm, 1/2 W, 1/10% R1133 323-0481-04 1M ohm, 1/2 W, 1/10% R1134 321-058-04 200K ohm, 1/8 W, 1/10% R1135 321-0618-04 200K ohm, 1/8 W, 1/10% R1136 321-0618-04 200K ohm, 1/8 W, 1/10% R1136 321-0756-04 50K ohm, 1/8 W, 1/10% </td <td>R1084</td> <td>321-0165-00</td> <td></td> <td></td> <td>511 Onm, 1/8 W, 1%</td> <td></td>	R1084	321-0165-00			511 Onm, 1/8 W, 1%	
R1089 316-0101-00 100 ohm, 1/4 W, 10% R1091 316-0470-00 47 ohm, 1/4 W, 10% R1092 316-0101-00 100 ohm, 1/4 W, 10% R1093 321-0256-00 4.53K ohm, 1/8 W, 1% R1095 316-0101-00 100 ohm, 1/4 W, 10% R1097 321-0251-01 4.02K ohm, 1/8 W, 1% R1098 321-0229-00 2.37K ohm, 1/8 W, 1% R1101 316-0682-00 6.8K ohm, 1/4 W, 10% R1111 321-0169-00 562 ohm, 1/8 W, 1% R1112 321-0169-00 562 ohm, 1/8 W, 1% R1113 321-0125-00 196 ohm, 1/8 W, 1% R1113 321-0125-00 196 ohm, 1/8 W, 1% R1117 321-0231-00 2.49K ohm, 1/8 W, 1% R1131 323-0498-04 1.5M ohm, 1/2 W, 1/10% R1133 321-0648-04 500K ohm, 1/8 W, 1/10% R1134 321-0648-04 500K ohm, 1/8 W, 1/10% R1135 321-0618-04 250K ohm, 1/8 W, 1/10% R1136 321-0648-04 500K ohm, 1/8 W, 1/10% R1138 321-056-04 50K ohm, 1/8 W, 1/10% R1145 311-1374-00 100K ohm, 1/8	R1086	316-0181-00	Ì		180 ohm, 1/4 W, 10%	
R1091 316-0470-00 47 ohm, 1/4 W, 10% R1092 316-0101-00 100 ohm, 1/4 W, 10% R1093 321-0256-00 4.53K ohm, 1/8 W, 1% R1095 316-0101-00 100 ohm, 1/4 W, 10% R1097 321-0251-01 4.02K ohm, 1/8 W, 1% R1098 321-0229-00 2.37K ohm, 1/8 W, 1% R1101 316-0602-00 6.68K ohm, 1/4 W, 10% R1111 321-0169-00 562 ohm, 1/8 W, 1% R1112 321-0169-00 562 ohm, 1/8 W, 1% R1113 321-0125-00 196 ohm, 1/8 W, 1% R1115 311-1244-00 100 ohm, 1/2 W, 1/10% R1115 311-1244-00 100 ohm, 1/2 W, 1/10% R1131 321-0231-00 2.49K ohm, 1/8 W, 1% R1131 321-0480-04 1.5M ohm, 1/2 W, 1/10% R1133 323-0481-04 1M ohm, 1/2 W, 1/10% R1134 321-0618-04 200K ohm, 1/8 W, 1/10% R1135 321-0618-04 200K ohm, 1/8 W, 1/10% R1136 321-0756-04 50K ohm, 1/8 W, 1/10% R1137 321-0385-04 100K ohm, 1/4 W, 10% R1146 316-0154-00 150K ohm,	R1089	316-0101-00			100 ohm, 1/4 W, 10%	
R1092 316-0101-00 100 ohm, 1/4 W, 10% R1093 321-0256-00 4.53K ohm, 1/8 W, 1% R1095 316-0101-00 100 ohm, 1/4 W, 10% R1097 321-0221-01 4.02K ohm, 1/8 W, 1% R1098 321-0229-00 2.37K ohm, 1/8 W, 1% R1101 316-0682-00 6.8K ohm, 1/4 W, 10% R1111 321-0169-00 562 ohm, 1/8 W, 1% R1112 321-0125-00 196 ohm, 1/8 W, 1% R1113 321-0125-00 196 ohm, 1/8 W, 1% R1113 321-0125-00 196 ohm, 1/8 W, 1% R1113 321-0231-00 2.49K ohm, 1/2 W, 1/10% R1131 323-0498-04 1.5M ohm, 1/2 W, 1/10% R1133 323-0481-04 100 ohm, 1/2 W, 1/10% R1134 321-0618-04 250K ohm, 1/8 W, 1/10% R1135 321-0618-04 200K ohm, 1/8 W, 1/10% R1136 321-0766-04 50K ohm, 1/8 W, 1/10% R1137 321-0385-04 100K ohm, 1/2 W, 1/10% R1146 316-0154-00 100K ohm, 1/4 W, 10% R1145 311-1374-00 50K ohm, 1/8 W, 1% R1145 311-1245-00 100K ohm,	R1091	316-0470-00	1		47 ohm, 1/4 W, 10%	
R1093 321-0256-00 4.53K ohm, 1/8 W, 18 R1095 316-0101-00 100 ohm, 1/4 W, 108 R1097 321-0251-01 4.02K ohm, 1/8 W, 1/2% R1098 321-0259-00 2.37K ohm, 1/8 W, 1% R1101 316-0682-00 6.8K ohm, 1/8 W, 1% R1101 311-1464-00 2K ohm, Var R1111 321-0169-00 562 ohm, 1/8 W, 1% R1112 321-0168-00 49.9 ohm, 1/8 W, 1% R1113 321-025-00 196 ohm, 1/8 W, 1% R1115 311-1244-00 100 ohm, Var R1115 311-1244-00 100 ohm, 1/8 W, 1% R1113 321-0231-00 2.49K ohm, 1/8 W, 1% R1131 323-048-04 1.5M ohm, 1/2 W, 1/10% R1133 323-048-04 1.5M ohm, 1/2 W, 1/10% R1134 321-0618-04 250K ohm, 1/8 W, 1/10% R1135 321-0618-04 250K ohm, 1/8 W, 1/10% R1136 321-0618-04 250K ohm, 1/8 W, 1/10% R1135 321-0618-04 200K ohm, 1/8 W, 1/10% R1136 321-0756-04 50K ohm, 1/8 W, 1/10% R1137 321-038-04 100K ohm, 1/8 W, 1/10% <td>R1092</td> <td>316-0101-00</td> <td>)</td> <td></td> <td>100 ohm, 1/4 W, 10%</td> <td></td>	R1092	316-0101-00)		100 ohm, 1/4 W, 10%	
R1095 $316-0101-00$ $100 \text{ ohm}, 1/4 \text{ W}, 108$ R1097 $321-0251-01$ $4.02 \text{ K} \text{ ohm}, 1/8 \text{ W}, 128$ R1098 $321-0229-00$ $2.37 \text{ K} \text{ ohm}, 1/8 \text{ W}, 18$ R1101 $316-0682-00$ $6.8 \text{ K} \text{ ohm}, 1/4 \text{ W}, 108$ R1110 $311-1464-00$ $2 \text{ K} \text{ ohm}, \text{ Var}$ R1111 $321-0125-00$ $562 \text{ ohm}, 1/8 \text{ W}, 18$ R1112 $321-0125-00$ $196 \text{ ohm}, 1/8 \text{ W}, 18$ R1113 $321-0125-00$ $196 \text{ ohm}, 1/8 \text{ W}, 18$ R1117 $321-0231-00$ $2.498 \text{ ohm}, 1/2 \text{ W}, 1/108$ R1131 $323-0498-04$ $1.5 \text{ M} \text{ ohm}, 1/2 \text{ W}, 1/108$ R1133 $323-0481-04$ $1 \text{ M} \text{ ohm}, 1/8 \text{ W}, 1/108$ R1134 $321-0618-04$ $250 \text{ K} \text{ ohm}, 1/8 \text{ W}, 1/108$ R1135 $321-0618-04$ $250 \text{ K} \text{ ohm}, 1/8 \text{ W}, 1/108$ R1136 $321-0414-04$ $200 \text{ K} \text{ ohm}, 1/8 \text{ W}, 1/108$ R1137 $321-0385-04$ $100 \text{ K} \text{ ohm}, 1/8 \text{ W}, 1/108$ R1140 $311-1374-00$ $50 \text{ K} \text{ ohm}, 1/4 \text{ W}, 108$ R1141 $316-0472-00$ $4.7 \text{ ohm}, 1/4 \text{ W}, 108$ R1145 $311-1245-00$ $100 \text{ K} \text{ ohm}, 1/4 \text{ W}, 108$ R1151 $321-0438-04$ $32.4 \text{ K} \text{ ohm}, 1/4 \text{ W}, 108$ R1146 $316-0472-00$ $4.7 \text{ ohm}, 1/4 \text{ W}, 108$ R1141 $316-0472-00$ $4.7 \text{ ohm}, 1/4 \text{ W}, 108$ R1146 $311-140-00$ $25 \text{ K} \text{ ohm}, 1/8 \text{ W}, 1/108$ R1151 $321-0438-04$ $300 \text{ K} \text{ ohm}, 1/2 \text{ W}, 1/108$ R1161 $323-0481-0$	R1093	321-0256-00			4.53K ohm, 1/8 W, 1%	
R1097 321-0251-01 4.02K ohm, 1/8 W, 1/2% R1098 321-0229-00 2.37K ohm, 1/8 W, 1% R1101 316-0682-00 6.8K ohm, 1/4 W, 10% R1101 311-1464-00 2K ohm, Var R1111 321-025-00 9.9 ohm, 1/8 W, 1% R1113 321-025-00 196 ohm, 1/8 W, 1% R1113 321-0231-00 2.49K ohm, 1/2 W, 1% R1131 323-0488-04 1.5M ohm, 1/2 W, 110% R1133 323-0481-04 1M ohm, 1/2 W, 1/10% R1134 321-0618-04 250K ohm, 1/8 W, 1/10% R1135 321-0618-04 250K ohm, 1/8 W, 1/10% R1136 321-0618-04 250K ohm, 1/8 W, 1/10% R1135 321-0618-04 200K ohm, 1/8 W, 1/10% R1136 321-0414-04 200K ohm, 1/8 W, 1/10% R1137 321-055-04 50K ohm, 1/8 W, 1/10% R1140 311-1374-00 50K ohm, 1/8 W, 1/10% R1141 316-0154-00 150K ohm, 1/4 W, 10% R1145 311-1245-00 10K ohm, Var R1145 311-1245-00 25K ohm, 1/8 W, 1% R1145 311-1245-00 25K ohm, 1/8 W, 1% <td>R1095</td> <td>316-0101-00</td> <td></td> <td></td> <td>100 ohm, 1/4 W, 10%</td> <td></td>	R1095	316-0101-00			100 ohm, 1/4 W, 10%	
R1098 321-0229-00 2.37K ohm, 1/8 W, 1% R1101 316-0682-00 6.8K ohm, 1/4 W, 10% R1101 311-1464-00 2K ohm, Var R1111 321-0169-00 562 ohm, 1/8 W, 1% R1112 321-0169-00 562 ohm, 1/8 W, 1% R1113 321-0125-00 196 ohm, 1/8 W, 1% R1113 321-0125-00 196 ohm, 1/8 W, 1% R1117 321-0231-00 2.49K ohm, Var R1131 323-0498-04 1.5M ohm, 1/2 W, 1/10% R1133 323-0498-04 1.5M ohm, 1/2 W, 1/10% R1134 321-0648-04 250K ohm, 1/8 W, 1/10% R1135 321-0648-04 200K ohm, 1/8 W, 1/10% R1136 321-0756-04 200K ohm, 1/8 W, 1/10% R1137 321-0385-04 100K ohm, 1/8 W, 1/10% R11401 311-1374-00 50K ohm, 1/8 W, 1/10% R11401 311-1245-00 100K ohm, Var R1141 316-0154-00 150K ohm, 1/8 W, 10% R1141 316-0154-00 150K ohm, 1/8 W, 10% R1141 316-0154-00 25K ohm, 1/8 W, 11% R1141 316-0154-00 25K ohm, 1/8 W, 11%	R1097	321-0251-01			4.02K ohm, 1/8 W, 1/2%	
R1101 316-0682-00 6.8K ohm, 1/4 W, 10% R1110 311-1464-00 2K ohm, Var R1111 321-0169-00 562 ohm, 1/8 W, 1% R1112 321-0068-00 49.9 ohm, 1/8 W, 1% R1113 321-0125-00 196 ohm, 1/8 W, 1% R1115 311-1244-00 100 ohm, Var R1117 321-0231-00 2.49K ohm, 1/2 W, 1/10% R1131 323-0480-04 1.5M ohm, 1/2 W, 1/10% R1133 323-0480-04 1.5M ohm, 1/8 W, 1/10% R1134 321-0648-04 500K ohm, 1/8 W, 1/10% R1135 321-0618-04 200K ohm, 1/8 W, 1/10% R1136 321-0414-04 200K ohm, 1/8 W, 1/10% R1137 321-0385-04 100K ohm, 1/8 W, 1/10% R1138 321-0756-04 50K ohm, 1/8 W, 1/10% R11401 311-1374-00 150K ohm, 1/4 W, 10% R1145 311-1245-00 10K ohm, Var R1141 316-0154-00 150K ohm, 1/4 W, 10% R1145 311-1245-00 26K ohm, 1/8 W, 1% R1151 321-0429-00 287K ohm, 1/8 W, 1% R1151 321-0429-00 287K ohm, 1/8 W, 1%	R1098	321-0229-00	-		2.37K ohm, 1/8 W, 1%	
R1110 311-1464-00 2K ohm, Var R1111 321-0169-00 562 ohm, 1/8 W, 1% R1112 321-0068-00 49.9 ohm, 1/8 W, 1% R1113 321-0125-00 196 ohm, 1/8 W, 1% R1115 311-1244-00 100 ohm, Var R1117 321-0231-00 2.49K ohm, 1/2 W, 1/10% R1131 323-0498-04 1.5M ohm, 1/2 W, 1/10% R1133 323-0481-04 1M ohm, 1/2 W, 1/10% R1134 321-0618-04 250K ohm, 1/8 W, 1/10% R1135 321-0618-04 250K ohm, 1/8 W, 1/10% R1136 321-0756-04 200K ohm, 1/8 W, 1/10% R1137 321-0385-04 100K ohm, 1/8 W, 1/10% R11401 311-1374-00 50K ohm, Var R1141 316-0154-00 150K ohm, 1/4 W, 10% R1145 311-1245-00 100K ohm, 1/4 W, 10% R1145 311-1245-00 100K ohm, 1/4 W, 10% R1145 311-1245-00 100K ohm, 1/4 W, 10% R1146 316-0472-00 4.7K ohm, 1/4 W, 10% R1151 321-0429-00 287K ohm, 1/4 W, 10% R1153 321-0428-04 1.5M ohm, 1/2 W, 1/10% <td>R1101</td> <td>316-0682-00</td> <td>)</td> <td></td> <td>6.8K ohm, 1/4 W, 10%</td> <td></td>	R1101	316-0682-00)		6.8K ohm, 1/4 W, 10%	
R1111 321-0169-00 562 ohm, 1/8 W, 1% R1112 321-0125-00 196 ohm, 1/8 W, 1% R1113 321-0125-00 196 ohm, 1/8 W, 1% R1115 311-1244-00 100 ohm, Var R1117 321-0231-00 2.49K ohm, 1/8 W, 1% R1131 323-0481-04 1.5M ohm, 1/2 W, 1/10% R1133 323-0481-04 1M ohm, 1/2 W, 1/10% R1134 321-0648-04 500K ohm, 1/8 W, 1/10% R1135 321-0648-04 250K ohm, 1/8 W, 1/10% R1136 321-0648-04 500K ohm, 1/8 W, 1/10% R1137 321-0648-04 500K ohm, 1/8 W, 1/10% R1138 321-0756-04 500K ohm, 1/8 W, 1/10% R1138 321-0756-04 50K ohm, 1/8 W, 1/10% R1140 311-1374-00 50K ohm, 1/8 W, 1/10% R1141 316-0154-00 150K ohm, 1/4 W, 10% R1141 316-0154-00 150K ohm, 1/4 W, 10% R1145 311-1245-00 10K ohm, 1/4 W, 10% R1145 311-1245-00 250K ohm, 1/8 W, 1% R1151 321-0338-00 32.4K ohm, 1/8 W, 1% R1153 321-0338-00 32.4K ohm, 1	B1110	311-1464-00	1		2K ohm, Var	
R1112 321-0108-00 49.9 ohm, 1/8 W, 1% R1113 321-0125-00 196 ohm, 1/8 W, 1% R1115 311-1244-00 100 ohm, Var R1117 321-023-00 2.49K ohm, 1/8 W, 1% R1131 322-048-04 1.5M ohm, 1/2 W, 1/10% R1131 323-048-04 1.5M ohm, 1/2 W, 1/10% R1133 321-0618-04 200K ohm, 1/8 W, 1/10% R1136 321-0648-04 200K ohm, 1/8 W, 1/10% R1137 321-0648-04 200K ohm, 1/8 W, 1/10% R1138 321-0756-04 200K ohm, 1/8 W, 1/10% R11401 311-1374-00 50K ohm, 1/8 W, 1/10% R11401 311-1245-00 150K ohm, 1/4 W, 10% R1145 311-1245-00 100K ohm, Var R1151 321-0429-00 287K ohm, 1/8 W, 1% R1151 321-0429-00 287K ohm, 1/8 W, 1% R1153 321-038-04 1.5M ohm, 1/2 W, 1/10% R1153 321-048-04 50K ohm, 1/8 W, 1% R1153 321-0429-00 25K ohm, 1/8 W, 1% R1151 321-0429-00 25K ohm, 1/8 W, 1% R1161 323-0481-04 1.5M ohm, 1/2 W, 1/10% </td <td>R1111</td> <td>321-0169-00</td> <td></td> <td></td> <td>562 obm, 1/8 W, 18</td> <td></td>	R1111	321-0169-00			562 obm, 1/8 W, 18	
R1113 321-0125-00 196 ohm, 1/8 W, 18 R1115 311-1244-00 100 ohm, Var R1117 321-0231-00 2.49K ohm, 1/2 W, 1/108 R1131 323-0498-04 1.5M ohm, 1/2 W, 1/108 R1133 323-0498-04 1.5M ohm, 1/2 W, 1/108 R1134 321-0648-04 500K ohm, 1/8 W, 1/108 R1135 321-0618-04 250K ohm, 1/8 W, 1/108 R1136 321-0414-04 200K ohm, 1/8 W, 1/108 R1137 321-0385-04 100K ohm, 1/8 W, 1/108 R1138 321-0756-04 50K ohm, 1/8 W, 1/108 R1140 311-1374-00 50K ohm, Var R1141 316-0154-00 150K ohm, 1/4 W, 108 R1145 311-1245-00 10K ohm, Var R1145 311-1245-00 10K ohm, 1/4 W, 108 R1151 321-0429-00 287K ohm, 1/8 W, 1% R1153 321-0338-00 32.4K ohm, 1/8 W, 1% R1153 321-0348-04 1.5M ohm, 1/2 W, 1/108 R1161 323-0498-04 1.5M ohm, 1/2 W, 1/108 R1163 321-0618-04 500K ohm, 1/8 W, 1/108 R1164 321-0618-04 250K ohm, 1/8 W,	R1112	321-0068-00			$49.9 \text{ obm} \cdot 1/8 \text{ W} \cdot 18$	
R1115 311-1244-00 100 ohm, Var R1117 321-0231-00 2.49K ohm, 1/8 W, 1% R1131 323-0498-04 1.5M ohm, 1/2 W, 1/10% R1133 323-0481-04 1M ohm, 1/2 W, 1/10% R1134 321-0648-04 500K ohm, 1/8 W, 1/10% R1135 321-0618-04 250K ohm, 1/8 W, 1/10% R1136 321-0414-04 200K ohm, 1/8 W, 1/10% R1137 321-0385-04 100K ohm, 1/8 W, 1/10% R1138 321-0756-04 50K ohm, 1/8 W, 1/10% R11401 311-1374-00 50K ohm, 1/4 W, 10% R1145 311-1245-00 10K ohm, 1/4 W, 10% R1146 316-0472-00 4.7K ohm, 1/4 W, 10% R1151 321-0429-00 287K ohm, 1/8 W, 1% R1153 321-0429-00 25K ohm, Var R1151 321-0429-00 25K ohm, 1/8 W, 1% R1153 321-0429-00 25K ohm, 1/8 W, 1% R1153 321-0429-00 25K ohm, 1/8 W, 1% R1161 323-0498-04 1.5M ohm, 1/2 W, 1/10% R1163 323-0498-04 1.5M ohm, 1/2 W, 1/10% R1164 321-0648-04 500K ohm, 1/8 W, 1/	R1113	321-0125-00			$196 \text{ obm}_{-} 1/8 \text{ W}_{-} 18$	
R1117 321-0231-00 2.49K ohm, 1/8 W, 1% R1131 323-0498-04 1.5M ohm, 1/2 W, 1/10% R1131 323-0481-04 1M ohm, 1/2 W, 1/10% R1133 323-0481-04 1M ohm, 1/2 W, 1/10% R1134 321-0648-04 500K ohm, 1/8 W, 1/10% R1135 321-0648-04 250K ohm, 1/8 W, 1/10% R1136 321-0414-04 200K ohm, 1/8 W, 1/10% R1137 321-0385-04 100K ohm, 1/8 W, 1/10% R1138 321-0756-04 50K ohm, 1/8 W, 1/10% R11401 311-1374-00 50K ohm, 1/8 W, 1/10% R1145 311-1245-00 10K ohm, 1/4 W, 10% R1146 316-0472-00 4.7K ohm, 1/4 W, 10% R1151 321-0429-00 287K ohm, 1/8 W, 1% R1153 321-0338-00 32.4K ohm, 1/8 W, 1% R1153 321-0429-00 287K ohm, 1/8 W, 1% R1153 321-0429-00 25K ohm, 1/8 W, 1% R1163 323-0481-04 1.5M ohm, 1/2 W, 1/10% R1163 323-0481-04 1.5M ohm, 1/2 W, 1/10% R1164 321-0648-04 500K ohm, 1/8 W, 1/10% R1164 321-0648-04	P1115	311-1244-00			100 ohm. Var	
R1131 323-0498-04 1.5M ohm, 1/2 W, 1/10% R1133 323-0481-04 1M ohm, 1/2 W, 1/10% R1134 321-0648-04 500K ohm, 1/8 W, 1/10% R1135 321-0648-04 250K ohm, 1/8 W, 1/10% R1136 321-0414-04 200K ohm, 1/8 W, 1/10% R1137 321-0385-04 100K ohm, 1/8 W, 1/10% R1138 321-0756-04 50K ohm, 1/8 W, 1/10% R11401 311-1374-00 50K ohm, Var R1145 311-1245-00 150K ohm, Var R1145 311-1245-00 10K ohm, 1/4 W, 10% R1151 321-0429-00 287K ohm, 1/8 W, 1% R1151 321-0388-00 32.4K ohm, 1/8 W, 1% R1161 323-0488-04 1.5M ohm, 1/2 W, 1/10% R1161 323-0488-04 1.5M ohm, 1/2 W, 1/10% R1163 321-0648-04 500K ohm, 1/8 W, 1/10% R1164 321-0648-04 500K ohm, 1/8 W, 1/10% R1165 321-0648-04 250K ohm, 1/8 W, 1/10% R1165 321-0648-04 250K ohm, 1/8 W, 1/10% R1165 321-0648-04 200K ohm, 1/8 W, 1/10% R1166 321-0414-04 2	D1117	321-0231-00			2.49 K obm. $1/8$ W 18	
R1131 323 0481 04 IM ohm, 1/2 W, 1/10% R1133 321-0648-04 IM ohm, 1/2 W, 1/10% R1134 321-0648-04 500K ohm, 1/8 W, 1/10% R1135 321-0648-04 250K ohm, 1/8 W, 1/10% R1136 321-0414-04 200K ohm, 1/8 W, 1/10% R1136 321-0414-04 200K ohm, 1/8 W, 1/10% R1137 321-0385-04 100K ohm, 1/8 W, 1/10% R1138 321-0756-04 50K ohm, 1/8 W, 1/10% R11401 311-1374-00 50K ohm, Var R1145 311-1245-00 10K ohm, Var R1146 316-0154-00 150K ohm, 1/4 W, 10% R1145 311-1245-00 10K ohm, Var R1146 316-0472-00 4.7K ohm, 1/4 W, 10% R1151 321-0338-00 32.4K ohm, 1/8 W, 1% R1153 321-0338-00 32.4K ohm, 1/8 W, 1% R1161 323-0498-04 1.5M ohm, 1/2 W, 1/10% R1163 323-0481-04 IM ohm, 1/2 W, 1/10% R1164 321-0648-04 500K ohm, 1/8 W, 1/10% R1165 321-0648-04 500K ohm, 1/8 W, 1/10% R1166 321-044-04 200K ohm, 1/8 W,	D1131	323-0498-04			1.5M obm $1/2 W 1/109$	
R1133 321-0648-04 In Olm, 1/2 W, 1/108 R1134 321-0648-04 500K ohm, 1/8 W, 1/108 R1135 321-0648-04 200K ohm, 1/8 W, 1/108 R1136 321-0414-04 200K ohm, 1/8 W, 1/108 R1136 321-0414-04 200K ohm, 1/8 W, 1/108 R1136 321-0414-04 200K ohm, 1/8 W, 1/108 R1137 321-0385-04 100K ohm, 1/8 W, 1/108 R1138 321-0756-04 50K ohm, 1/8 W, 1/108 R11401 311-1374-00 50K ohm, 1/4 W, 108 R1145 311-1245-00 150K ohm, 1/4 W, 108 R1145 311-1245-00 10K ohm, 1/4 W, 108 R1146 316-0472-00 4.7K ohm, 1/4 W, 108 R1151 321-0429-00 287K ohm, 1/8 W, 18 R1153 311-1410-00 25K ohm, Var R1161 323-0488-04 1.5M ohm, 1/2 W, 1/108 R1163 323-0481-04 1M ohm, 1/2 W, 1/108 R1163 321-0648-04 500K ohm, 1/8 W, 1/108 R1164 321-0648-04 500K ohm, 1/8 W, 1/108 R1165 321-0648-04 200K ohm, 1/8 W, 1/108 R1166 321-0414-04 <td< td=""><td>N1131</td><td>323-0481-04</td><td></td><td></td><td>1.51 Ohm 1/2 W 1/108</td><td></td></td<>	N1131	323-0481-04			1.51 Ohm 1/2 W 1/108	
R1134 321-0040-04 30000 01m, 1/8 W, 1/108 R1135 321-0040-04 25000 01m, 1/8 W, 1/108 R1136 321-0414-04 20000 01m, 1/8 W, 1/108 R1136 321-0385-04 10000 01m, 1/8 W, 1/108 R1137 321-0385-04 100000000 01m, 1/8 W, 1/108 R1138 321-0756-04 50000 01m, 1/8 W, 1/108 R11401 311-1374-00 50000 01m, 1/4 W, 108 R1141 316-0154-00 15000 01m, 1/4 W, 108 R1145 311-1245-00 10000 01m, 1/4 W, 108 R1146 316-0472-00 4.7K ohm, 1/4 W, 108 R1151 321-0429-00 287K ohm, 1/8 W, 18 R1153 321-0338-00 32.4K ohm, 1/8 W, 18 R1153 321-0338-00 32.4K ohm, 1/2 W, 1/108 R1161 323-0498-04 1.5M ohm, 1/2 W, 1/108 R1161 323-0498-04 1.5M ohm, 1/2 W, 1/108 R1163 323-0481-04 1M ohm, 1/2 W, 1/108 R1163 321-0618-04 250K ohm, 1/8 W, 1/108 R1165 321-0618-04 250K ohm, 1/8 W, 1/108 R1165 321-0618-04 250K ohm, 1/8 W, 1/108 R1166 <td< td=""><td>D113/</td><td>321-0648-04</td><td></td><td></td><td>500K obm 1/8 W 1/108</td><td></td></td<>	D113/	321-0648-04			500K obm 1/8 W 1/108	
Rl135321-0618-04250K ohm, 1/8 W, 1/10%Rl136321-0414-04200K ohm, 1/8 W, 1/10%Rl137321-0385-04100K ohm, 1/8 W, 1/10%Rl138321-0756-0450K ohm, 1/8 W, 1/10%Rl1401311-1374-0050K ohm, 1/8 W, 1/10%Rl141316-0154-00150K ohm, VarRl145311-1245-0010K ohm, 1/4 W, 10%Rl146316-0472-004.7K ohm, 1/4 W, 10%Rl151321-0429-00287K ohm, 1/8 W, 1%Rl153321-0338-0032.4K ohm, 1/8 W, 1%Rl161323-0498-041.5M ohm, 1/2 W, 1/10%Rl163323-0481-041M ohm, 1/2 W, 1/10%Rl164321-0648-04500K ohm, 1/8 W, 1/10%Rl165321-0618-04250K ohm, 1/8 W, 1/10%Rl166321-0414-04200K ohm, 1/8 W, 1/10%Rl167321-0385-04100K ohm, 1/8 W, 1/10%Rl168321-0756-0450K ohm, 1/8 W, 1/10%	RII 54	321-0040-04	1		500K 01m, 1/6 W, 1/108	
R1136 321-0414-04 200K ohm, 1/8 W, 1/10% R1137 321-0385-04 100K ohm, 1/8 W, 1/10% R1138 321-0756-04 50K ohm, 1/8 W, 1/10% R1140 311-1374-00 50K ohm, Var R1141 316-0154-00 150K ohm, 1/4 W, 10% R1145 311-1245-00 10K ohm, 1/4 W, 10% R1146 316-0472-00 4.7K ohm, 1/4 W, 10% R1151 321-0429-00 287K ohm, 1/8 W, 1% R1153 321-0338-00 32.4K ohm, 1/8 W, 1% R1161 323-0498-04 1.5M ohm, 1/2 W, 1/10% R1163 323-0481-04 1M ohm, 1/2 W, 1/10% R1164 321-0618-04 200K ohm, 1/8 W, 1/10% R1165 321-0618-04 200K ohm, 1/8 W, 1/10% R1166 321-0414-04 200K ohm, 1/8 W, 1/10% R1167 321-0385-04 100K ohm, 1/8 W, 1/10% R1168 321-0756-04 50K ohm, 1/8 W, 1/10%	R1135	321-0618-04			250K ohm, 1/8 W, 1/10%	
R1137 321-0385-04 100K chm, 1/8 W, 1/10% R1138 321-0756-04 50K chm, 1/8 W, 1/10% R11401 311-1374-00 50K chm, Var R1141 316-0154-00 150K ohm, 1/4 W, 10% R1145 311-1245-00 10K chm, 1/4 W, 10% R1146 316-0472-00 4.7K chm, 1/4 W, 10% R1151 321-0429-00 287K ohm, 1/8 W, 1% R1153 321-0338-00 32.4K ohm, 1/8 W, 1% R1155 311-1410-00 25K ohm, Var R1161 323-0498-04 1.5M ohm, 1/2 W, 1/10% R1163 323-0481-04 1M ohm, 1/2 W, 1/10% R1164 321-0648-04 500K ohm, 1/8 W, 1/10% R1165 321-0618-04 250K ohm, 1/8 W, 1/10% R1166 321-0414-04 200K ohm, 1/8 W, 1/10% R1167 321-0385-04 100K ohm, 1/8 W, 1/10% R1168 321-0756-04 50K ohm, 1/8 W, 1/10%	R1136	321-0414-04			200K Ohm, 1/8 W, 1/10%	
R1138 321-0756-04 50K ohm, 1/8 W, 1/10% R11401 311-1374-00 50K ohm, Var R1141 316-0154-00 150K ohm, 1/4 W, 10% R1145 311-1245-00 10K ohm, 1/4 W, 10% R1146 316-0472-00 4.7K ohm, 1/4 W, 10% R1151 321-0429-00 287K ohm, 1/8 W, 1% R1153 321-0338-00 32.4K ohm, 1/8 W, 1% R1155 311-1410-00 25K ohm, Var R1161 323-0498-04 1.5M ohm, 1/2 W, 1/10% R1163 323-0481-04 1M ohm, 1/2 W, 1/10% R1164 321-0648-04 500K ohm, 1/8 W, 1/10% R1165 321-0618-04 250K ohm, 1/8 W, 1/10% R1166 321-0414-04 200K ohm, 1/8 W, 1/10% R1167 321-0385-04 100K ohm, 1/8 W, 1/10% R1168 321-0756-04 50K ohm, 1/8 W, 1/10%	R1137	321-0385-04	2		100K ohm, 1/8 W, 1/10%	
R1140 ⁻¹ 311-1374-00 50K ohm, Var R1141 316-0154-00 150K ohm, 1/4 W, 10% R1145 311-1245-00 10K ohm, Var R1146 316-0472-00 4.7K ohm, 1/4 W, 10% R1151 321-0429-00 287K ohm, 1/8 W, 1% R1153 321-0338-00 32.4K ohm, 1/8 W, 1% R1155 311-1410-00 25K ohm, Var R1161 323-0498-04 1.5M ohm, 1/2 W, 1/10% R1163 323-0481-04 1M ohm, 1/2 W, 1/10% R1164 321-0648-04 500K ohm, 1/8 W, 1/10% R1165 321-0618-04 250K ohm, 1/8 W, 1/10% R1166 321-0414-04 200K ohm, 1/8 W, 1/10% R1167 321-0385-04 100K ohm, 1/8 W, 1/10% R1168 321-0756-04 50K ohm, 1/8 W, 1/10%	R1138,	321-0756-04	2		50K ohm, 1/8 W, 1/10%	
R1141 316-0154-00 150K ohm, 1/4 W, 10% R1145 311-1245-00 10K ohm, Var R1146 316-0472-00 4.7K ohm, 1/4 W, 10% R1151 321-0429-00 287K ohm, 1/8 W, 1% R1153 321-0338-00 32.4K ohm, 1/8 W, 1% R1155 311-1410-00 25K ohm, Var R1161 323-0498-04 1.5M ohm, 1/2 W, 1/10% R1163 323-0481-04 1M ohm, 1/2 W, 1/10% R1164 321-0648-04 500K ohm, 1/8 W, 1/10% R1165 321-0618-04 250K ohm, 1/8 W, 1/10% R1166 321-0414-04 200K ohm, 1/8 W, 1/10% R1167 321-0385-04 100K ohm, 1/8 W, 1/10% R1168 321-0756-04 50K ohm, 1/8 W, 1/10%	R1140-	311-1374-00			50K ohm, Var	
R1145 311-1245-00 10K ohm, Var R1146 316-0472-00 4.7K ohm, 1/4 W, 10% R1151 321-0429-00 287K ohm, 1/8 W, 1% R1153 321-0338-00 32.4K ohm, 1/8 W, 1% R1155 311-1410-00 25K ohm, Var R1161 323-0498-04 1.5M ohm, 1/2 W, 1/10% R1163 323-0481-04 1M ohm, 1/2 W, 1/10% R1164 321-0648-04 500K ohm, 1/8 W, 1/10% R1165 321-0618-04 250K ohm, 1/8 W, 1/10% R1166 321-0414-04 200K ohm, 1/8 W, 1/10% R1167 321-0385-04 100K ohm, 1/8 W, 1/10% R1168 321-0756-04 50K ohm, 1/8 W, 1/10%	R1141	316-0154-00)		150K ohm, 1/4 W, 10%	
R1146 316-0472-00 4.7K ohm, 1/4 W, 10% R1151 321-0429-00 287K ohm, 1/8 W, 1% R1153 321-0338-00 32.4K ohm, 1/8 W, 1% R1155 311-1410-00 25K ohm, Var R1161 323-0498-04 1.5M ohm, 1/2 W, 1/10% R1163 323-0481-04 1M ohm, 1/2 W, 1/10% R1164 321-0648-04 500K ohm, 1/8 W, 1/10% R1165 321-0618-04 250K ohm, 1/8 W, 1/10% R1166 321-0414-04 200K ohm, 1/8 W, 1/10% R1167 321-0385-04 100K ohm, 1/8 W, 1/10% R1168 321-0756-04 50K ohm, 1/8 W, 1/10%	R1145	311-1245-00)		10K ohm, Var	
R1151 321-0429-00 287K ohm, 1/8 W, 1% R1153 321-0338-00 32.4K ohm, 1/8 W, 1% R1155 311-1410-00 25K ohm, Var R1161 323-0498-04 1.5M ohm, 1/2 W, 1/10% R1163 323-0481-04 1M ohm, 1/2 W, 1/10% R1164 321-0648-04 500K ohm, 1/8 W, 1/10% R1165 321-0618-04 250K ohm, 1/8 W, 1/10% R1166 321-0414-04 200K ohm, 1/8 W, 1/10% R1167 321-0385-04 100K ohm, 1/8 W, 1/10% R1168 321-0756-04 50K ohm, 1/8 W, 1/10%	R1146	316-0472-00)		4.7K ohm, 1/4 W, 10%	
R1153321-0338-0032.4K ohm, 1/8 W, 1%R1155311-1410-0025K ohm, VarR1161323-0498-041.5M ohm, 1/2 W, 1/10%R1163323-0481-041M ohm, 1/2 W, 1/10%R1164321-0648-04500K ohm, 1/8 W, 1/10%R1165321-0618-04250K ohm, 1/8 W, 1/10%R1166321-0414-04200K ohm, 1/8 W, 1/10%R1167321-0385-04100K ohm, 1/8 W, 1/10%R1168321-0756-0450K ohm, 1/8 W, 1/10%	R1151	321-0429-00)		287K ohm, 1/8 W, 1%	
R1155311-1410-0025K ohm, VarR1161323-0498-041.5M ohm, 1/2 W, 1/10%R1163323-0481-041M ohm, 1/2 W, 1/10%R1164321-0648-04500K ohm, 1/8 W, 1/10%R1165321-0618-04250K ohm, 1/8 W, 1/10%R1166321-0414-04200K ohm, 1/8 W, 1/10%R1167321-0385-04100K ohm, 1/8 W, 1/10%R1168321-0756-0450K ohm, 1/8 W, 1/10%	R1153	321-0338-00)		32.4K ohm, 1/8 W, 1%	
R1161 323-0498-04 1.5M ohm, 1/2 W, 1/10% R1163 323-0481-04 1M ohm, 1/2 W, 1/10% R1164 321-0648-04 500K ohm, 1/8 W, 1/10% R1165 321-0618-04 250K ohm, 1/8 W, 1/10% R1166 321-0414-04 200K ohm, 1/8 W, 1/10% R1167 321-0385-04 100K ohm, 1/8 W, 1/10% R1168 321-0756-04 50K ohm, 1/8 W, 1/10%	R1155	311-1410-00)		25K ohm, Var	
R1163323-0481-04IM ohm, 1/2 W, 1/10%R1164321-0648-04500K ohm, 1/8 W, 1/10%R1165321-0618-04250K ohm, 1/8 W, 1/10%R1166321-0414-04200K ohm, 1/8 W, 1/10%R1167321-0385-04100K ohm, 1/8 W, 1/10%R1168321-0756-0450K ohm, 1/8 W, 1/10%	R1161	323-0498-04	ł		1.5M ohm, 1/2 W, 1/10%	
R1164321-0648-04500K ohm, 1/8 W, 1/10%R1165321-0618-04250K ohm, 1/8 W, 1/10%R1166321-0414-04200K ohm, 1/8 W, 1/10%R1167321-0385-04100K ohm, 1/8 W, 1/10%R1168321-0756-0450K ohm, 1/8 W, 1/10%	R1163	323-0481-04	ł		1M ohm, 1/2 W, 1/10%	
R1165321-0618-04250K ohm, 1/8 W, 1/10%R1166321-0414-04200K ohm, 1/8 W, 1/10%R1167321-0385-04100K ohm, 1/8 W, 1/10%R1168321-0756-0450K ohm, 1/8 W, 1/10%	R1164	321-0648-04	1		500K ohm, 1/8 W, 1/10%	
R1166321-0414-04200K ohm, 1/8 W, 1/10%R1167321-0385-04100K ohm, 1/8 W, 1/10%R1168321-0756-0450K ohm, 1/8 W, 1/10%	R1165	321-0618-04			250K ohm, 1/8 W, 1/10%	
R1167321-0385-04100K ohm, 1/8 W, 1/10%R1168321-0756-0450K ohm, 1/8 W, 1/10%	R1166	321-0414-04			200K ohm, 1/8 W, 1/10%	
R1168 321-0756-04 50K ohm, 1/8 W, 1/10%	R1167	321-0385-04			100K ohm, 1/8 W, 1/10%	
	R1168	321-0756-04	ł		50K ohm, 1/8 W, 1/10%	

 1 Furnished as a unit with S1140.

Cht. No	Tektronix	Serial/Model	No. Disc	Description
CRI. 140.	Full NO.		DISC	Description
RESISTORS (con	nt)			
R1170	316-0473-00			47K ohm, 1/4 W, 10%
R1175	311-1245-00			10K ohm, Var
R1201	316-0471-00			470 ohm, 1/4 W, 10%
R1202	321-0212-00			1.58K ohm, 1/8 W, 1%
R1205A,B	311-1430-00			5K ohm x 50K ohm, Var
R1206	315-0202-00			2K ohm, 1/4 W, 5%
R1207	315-0203-00			20K ohm, 1/4 W, 5%
R1208	315-0432-00			4.3K ohm, 1/4 W, 5%
R1209	315-0433-00			43K ohm, 1/4 W, 5%
R1211	321-0130-00			221 ohm, 1/8 W, 1%
R1212	316-0102-00			1K ohm, 1/4 W, 10%
R1214	321-0174-00			634 ohm, 1/8 W, 1%
R1215	311-1222-00			100 ohm, Var
R1216	321-0264-00			5.49K Ohm, 1/8 W, 1%
R1217	321-0147-00			332 Ohm, 1/8 W, 1%
R1219	321-0164-00			499 Onm, 1/8 W, 18
- R1220	321-0034-00			22.1 Onm, 1/8 W, 1%
R1221	321-01/3-00			619 ONM, 1/8 W, 1%
R1222	321-0173-00			619 ohm, 1/8 W, 1%
R1223	321-0184-00			806 ohm, 1/8 W, 1%
R1224	323-0248-00			3.74K ohm, 1/2 W, 18
R1225	311-1226-00			2.5K ohm, Var
R1226	323-0296-00			11.8K Ohm, 1/2 W, 1%
R1228	321-0210-00			1.5K Ohm, 1/8 W, 1%
R1229	316-0154-00			150K Onm, 1/4 W, 108
RT1230	307-0122-00			50 Onm, Thermal
R1231	321-0222-00			2K Onm, 1/8 W, 1%
R1232	315-0270-00			27 ohm, 1/4 W, 5%
R1233	321-0184-00			806 ohm, 1/8 W, 1%
R1234	323-0248-00			3.74K ohm, 1/2 W, 1%
R1235	323-0191-00			953 ohm, 1/2 W, 1%
R1236	323-0296-00			11.8K ohm, 1/2 W, 1%
R1237	311-1225-00			lK ohm, Var
R1238	311-1222-00			100 ohm, Var
R1239	321-0110-00			137 ohm, 1/8 W, 1%
R1241	321-0168-00			549 ohm, 1/8 W, 1%
R1242	321-0168-00			549 ohm, 1/8 W, 1%
R1244	321-0122-00			182 ohm, 1/8 W, 1%
R1246	321-0260-00			4.99K ohm, 1/8 W, 1%
R1247	315-0201-00			200 ohm, 1/4 W, 5%
R1248	321-0228-00			2.32K ohm, 1/8 W, 1%
R1249	315-0182-00			1.8K ohm, 1/4 W, 5%
R1253	321-0299-00			12.7K ohm, 1/8 W, 1%
R1254	321-0140-00			280 Onm, 1/8 W, 18
R1255	302-0181-00			180 ONM, 1/2 W, 108

1

August .

. (22.00

•

1 1 miles

Ckt. No.	Tektronix Part No.	Serial/Model Eff	No. Disc	Description
RESISTORS	(cont)		y = - 1 ,	
R1260	322-0289-00)		10K ohm, 1/4 W, 1%
R1261	322-0289-00)		10K ohm, 1/4 W, 1%
R1262	321-0189-00	ĥ		909 obm = 1/8 W = 18
D1262	316-0470-00			17 obm 1/4 W 109
D1264	303-0303-00			$\frac{1}{2}$ 0 mm, $\frac{1}{4}$ W, $\frac{1}{6}$
D1266	216-0101-00			100 obm 1/4 W 108
R1200	321-0222-00			100 0100, 1/4 W, 106
R1200	321-0222-00			$\frac{2K}{M} = \frac{1}{6} \frac$
R1269	321-0268-00			6.04K Onm, $1/8$ W, 18
R12/3	321-0299-00	J		12./K ONM, 1/8 W, 1%
R1274	323-0177-00)		681 ohm, 1/2 W, 1%
R1275	302-0221-00)		220 ohm, 1/2 W, 10%
R1280	322-0289-00)		10K ohm, 1/4 W, 1%
R1281	322-0289-00)		10K ohm, 1/4 W, 1%
R1282	321-0189-00)		909 ohm, 1/8 W, 1%
R1283	316-0470-00)		47 ohm, 1/4 W, 10%
R1284	302-0393-00)		39K ohm, 1/2 W, 10%
R1286	316-0101-00)		100 ohm, 1/4 W, 10%
R1288	316-0470-00	0		47 ohm, 1/4 W, 10%
R1289	302-0273-00)		27K ohm, 1/2 W, 10%
R1301	321-0160-00)		453 ohm, 1/8 W, 18
R1302	321-0160-00	5		453 ohm, 1/8 W, 1%
R1303	321-0209-00	5		1.47K ohm. 1/8 W. 18
R1304	315-0472-00	5		4.7K ohm. 1/4 W. 5%
R1306	315-0112-00	n n		1.1K ohm, 1/4 W, 58
R1307	321-0192-00	ĥ		976 ohm, $1/8 W$, 18
R1308	321-0171-00	- -		590 obm = 1/8 W = 18
D121/	315-0192-00		B010151	1.9K obm 1/4 W 59
KT214	515-0102-00	B010100	BUIUIJI	1.0K OIL(), 1/4 W, 5%
R1314	315-0911-00	D B010152		910 ohm, 1/4 W, 5%
R1317	301-0221-00	D B010100	B010151	220 ohm, 1/2 W, 5%
R1317	301-0471-00	O B010152		470 ohm, 1/2 W, 5%
R1321	321-0160-00	0		453 ohm, 1/8 W, 1%
R1322	321-0160-00	0		453 ohm, 1/8 W, 1%
R1323	321-0209-00	0		1.47K ohm, 1/8 W, 1%
R1324	315-0472-00	0		4.7K ohm, 1/4 W, 5%
R1326	315-0112-00	0		1.1K ohm, 1/4 W, 5%
R1327	321-0192-00	0		976 ohm, 1/8 W, 1%
R1328	321-0171-0	0		590 ohm, 1/8 W, 1%
R1334	315-0182-0	0 B010100	B010151	1.8K ohm, 1/4 W, 5%
R1334	315-0911-0	0 B010152		910 ohm, 1/4 W, 5%
R1337	301-0221-00	0 B010100	B010151	220 ohm, 1/2 W, 5%
R1337	301-0471-0	0 B010152		470 ohm, 1/2 W, 5%
R1339	316-0220-0	0		22 ohm, 1/4 W, 10%
R1345	315-0202-0	0		2K ohm, 1/4 W, 5%
R1348	316-0220-0	0		22 ohm, 1/4 W, 10%
R1349	316-0220-0	0		22 ohm, 1/4 W, 10%

Ckt. No.	Tektronix Part No.	Serial/Model Eff	No. Disc	Description
RESISTORS	(cont)			
R1400	311-1228-00			10K ohm, Var
R1401	322-0464-00			665K ohm, 1/4 W, 18
R1402	316-0224-00			$220K \text{ obm}_{2} 1/4 \text{ W}_{2} 10\%$
P1403	315-0273-00			27K obm = 1/4 W = 58
D1404	315-0103-00			10K obm 1/4 W 59
P1406	316-0683-00			68K obm 1/4 W 109
D1407	316-0102-00			$\frac{1}{4} \text{ w} = 108$
R1407	315-0242-00			$2 \Lambda K \text{ obm} 1/4 W 59$
R1400	216-0104-00			100K obm 1/4 W 109
R1409	516-0104-00			100K Onut, 1/4 W, 108
R1411	321-0327-00			24.9K ohm, 1/8 W, 1%
R1412	321-0329-00			26.1K ohm, 1/8 W, 1%
R1413	316-0103-00			10K ohm, 1/4 W, 10%
R1414	316-0392-00			3.9K ohm, 1/4 W, 10%
R1416	316-0472-00			4.7K ohm, 1/4 W, 10%
R1420	315-0394-00			390K ohm, 1/4 W, 5%
R1421	316-0103-00			10K ohm, 1/4 W, 10%
R1422	316-0103-00			10K ohm, 1/4 W, 10%
R1423	316-0103-00			10K ohm, 1/4 W, 10%
R1430	311-0075-00			5M ohm, Var
R1431A)				6.57M ohm,
R1431B				23.6M ohm,
R1431C	307-0290-04			550K ohm, Thick film
R1431D				24.5M ohm,
R1440	311-1313-00			2K ohm, Var
R1441	302-0562-00			5.6K ohm, 1/2 W, 10%
R1442	311-1235-00			100K ohm, Var
R1445	311-1372-00			100K ohm, Var
R1446	311-1227-00			5K ohm, Var
R1447	315-0223-00			22K ohm, 1/4 W, 5%
R1448	315-0243-00			24K ohm, 1/4 W, 5%
R1449	316-0101-00			100 ohm, 1/4 W, 10%
R1451	301-0243-00			24K ohm, 1/2 W, 5%
R1452	316-0221-00			220 ohm, 1/4 W, 10%
R1453	316-0470-00			47 ohm, 1/4 W, 10%
R1460	311-1373-00			5K ohm, Var
R1461	315-0302-00			3K ohm, 1/4 W, 5%
R1462	315-0242-00			2.4K ohm, 1/4 W, 5%
R1463	315-0122-00			1.2K ohm, 1/4 W, 5%
R1464	315-0153-00			15K ohm, 1/4 W, 5%
R1466	321-0220-00			1.91K ohm, 1/8 W, 1%
R1467	321-0168-00			549 ohm, 1/8 W, 1%
R1468	321-0249-00			3.83K ohm, 1/8 W, 1%
R1469	323-0322-00			22.1K ohm, 1/2 W, 1%
R1470	321-0307-00			15.4K ohm, 1/8 W, 1%
R1471	316-0101-00			100 ohm, 1/4 W, 10%

1.45 Martin

3

	Tektronix	Serial/Model	No.	
Ckt. No.	Part No.	Eff	Disc	Description
RESISTORS	(cont)			
R1472	316-0391-00)		390 ohm, 1/4 W, 10%
R1473	316-0102-00)		1K ohm, 1/4 W, 10%
R1474	316-0101-00)		100 ohm, 1/4 W, 10%
R1475	316-0102-00			1K ohm. 1/4 W. 10%
R1476	315-0911-00			910 obm, $1/4$ W, 5%
R1477	321-0201-00			1.21K ohm. $1/8$ W. 18
R1478	302-0393-00			39K ohm, 1/2 W, 10%
R1480	311-1231-00			25K ohm. Var
R1481	316-0103-00			10K ohm, 1/4 W, 10%
	510 0105 00			
R1482	316-0102-00)		1K ohm, 1/4 W, 10%
R1484	316-0471-00			470 ohm, 1/4 W, 10%
R1485	316-0221-00			220 ohm, 1/4 W, 10%
R1486	316-0226-00)		22M ohm, 1/4 W, 10%
R1488	316-0102-00)		1K ohm, 1/4 W, 10%
R1510	316-0103-00	XB010400		10K ohm, 1/4 W, 10%
R1511	315-0184-00) B010100 H	3010399	180K ohm, 1/4 W, 5%
R1511	316-0103-00	B010400		10K ohm, 1/4 W, 10%
R1512	316-0472-00) XB010400		4.7K ohm, 1/4 W, 10%
R1513	315-0222-00)		2.2K ohm, 1/4 W, 5%
R1515	315-0102-00)		1K ohm, 1/4 W, 5%
R1516	315-0102-00)		1K ohm, 1/4 W, 5%
R1521	323-0269-00)		6.19K ohm, 1/2 W, 1%
R1523	321-0292-00)		10.7K ohm, 1/8 W, 1%
R1524	315-0202-00)		2K ohm, 1/4 W, 5%
R1525	316-0102-00) XB011052		1K ohm, 1/4 W, 10%
R1527	315-0183-00)		18K ohm, 1/4 W, 5%
R1528	303-0223-00)		22K ohm, 1 W, 5%
R1532	315-0122-00)		1.2K ohm, 1/4 W, 5%
R1533	315-0563-00)		56K ohm, 1/4 W, 5%
R1534	307-0052-00)		3 ohm, 1/2 W, 5%
R1537	321-0366-00)		63.4K ohm, 1/8 W, 1%
R1538	311-1226-00)		2.5K ohm, Var
R1539	321-0296-00)		11.8K ohm, 1/8 W, 1%
R1543	321-0966-03	3		40K ohm, 1/8 W, 1/4%
R1544	321-0603-00)		15K ohm, 1/8 W, 1/4%
R1546	315-0102-00)		1K ohm, 1/4 W, 5%
R1547	315-0153-00)		15K ohm, 1/4 W, 5%
R1549	308-0459-00)		1.1 ohm, 3 W, WW, 5%
R1553	321-0775-03	3		45K ohm, 1/8 W, 1/4%
R1554	321-0774-03	3		4.5K ohm, 1/8 W, 1/4%
R1556	315-0102-00)		1K ohm, 1/4 W, 5%
R1557	315-0512-00)		5.1K ohm, 1/4 W, 5%
R1559	307-0093-00)		1.2 ohm, 1/2 W, 5%
R1563	321-0274-00)		6.98K ohm, 1/8 W, 1%
R1564	321-0967-03	3		55K ohm, $1/8$ W, $1/4$ %
		-		

Ckt. No.	Tektronix Part No.	Serial/Model Eff	No. Disc	Description
RESISTORS	(cont)			
R1565	321-0962-03			8K ohm, 1/8 W, 1/4%
R1566	315-0301-00			300 ohm, 1/4 W, 5%
R1567	315-0242-00			2.4K ohm, 1/4 W, 5%
P1569	308-0459-00			1.1 ohm. 3 W. WW. 5%
D1570	311-1373-00			5K ohm. Var
R1570	315-0303-00			3 QK obm 1/4 W 59
RIS/I	315-0392-00			15V obm 1/4 W 59
RISSI	315-0153-00			15K OILL, 1/4 W, 56 $52 GV obs 1/9 W 19$
R1584	321-0359-00			53.6K Ohm, $1/8$ W, 18
R1585	321-0280-00	•		8.06K Onm, 1/8 W, 1%
R1586	316-0104-00)		100K ohm, 1/4 W, 10%
R1587	316-0104-00)		100 K Onm, $1/4 W$, 108
R1589	315-0102-00			1K Onm, 1/4 W, 5%
R1591	315-0912-00			9.1K Ohm, 1/4 W, 5%
R1592	315-0473-00			47K Ohm, 1/4 W, 5%
R1593	315-0822-00			8.2K Ohm, 1/4 W, 5%
R1594	315-0513-00			51K ohm, 1/4 W, 5%
R1596	315-0512-00			5.1K ohm, 1/4 W, 5%
R1597	311-1221-00)		50 ohm, Var
R1598	321-0107-00)		127 ohm, 1/8 W, 1%
R1599	321-0001-00			10 ohm, 1/8 W, 1%
R1691	303-0150-00			15 ohm, 1 W, 5%
R1692	321-0062-00)		43.2 ohm, 1/8 W, 1%
R1693	323-0140-00)		280 ohm, 1/2 W, 1%
R1694	323-0140-00)		180 ohm, 1/2 W, 1%
R1695	321-0228-00)		2.32K ohm, 1/8 W, 1%
RT1696	307-0124-00)		5K ohm, Thermal
R1697	321-0201-00)		1.21K ohm, 1/8 W, 1%
R1698	315-0363-00)		36K ohm, 1/4 W, 5%
SWITCHES				
S51				Input Coupling CH 1
510	105-0342-00)		Actuator, Cam , VOLTS/DIV CH 1
5551				Input Coupling CH 2
560	105-0342-00)		Actuator, Cam, VOLTS/DIV CH 2
s112 ²	103 0312 00	·		······································
\$2123				
C225	260-1208-00)		Push-push, INVERT
C3387	105-0423-00			Actuator assy, Slide, BANDWIDTH LIMIT
S338B	105-0421-00)		Actuator assy, Slide, MOMENTARY
	0.00 1404 01			Duch VERM MODE
\$350				Push, VERI MODE
5400) \		Actuator accu Slido P (DLV'D) COUDCE
5510	105-0401-00	<i>)</i>		Actuator assy Silde P (DIVID) COURTING
S515	T02-0388-00)		ACTUATOL ASSA' STIME' P (DEL D) COOFFING
S530*				Actuation again A COUPOR
S610	105-0400-00)		Actuator assy, A SOURCE
S615	105-0399-00	J		ACTUATOR ASSY, A COUPLING
l 2See Me	chanical Parts	List for re	eplacem	ent parts.

²See Mechanical Parts List for replacement parts ²Furnished as a unit with R112. ³Furnished as a unit with R212. ⁴Furnished as a unit with R530.

1

100 m

2.

挫

100 C

他で

ž.

4,5

F

۲

		Tektr	onix	Serial/Model	No.	
<u>Ckt.</u>	No.	Part	No.	Eff	Disc	Description
SWI	TCHES (con	t)				
	S630 ¹					A TRIGGER SLOPE
	S1100	260-	1422-00)		Pushbutton, TRIG MODE
	S1120	260-	1423-00)		Pushbutton, HORIZ DISPLAY
	s1140 ²					
	S1150	105-	0366-00)		Actuator assy, Cam, TIME/CM
	S1155A,B ³					
	S1239	260-	-1208-00)		Push-push, X10 MAG
	S1501	260-	-0834-00)		Toggle, POWER
	S1502	260-	0638-00)		Thermostatic, open 75 deg. C, close 55 deg. (
	S1503	260-	-1300-01	L		Slide, LINE
TRA	NSFORMERS					
	Т354	120-	-0366-00)		Toroid, 2 windings
	T1420 ⁴	120-	-0800-00)		HV Power
	T1420 ⁴	120-	-0800-01	1		HV Power
	T1501	120-	-0798-00	0		LV Power
INT	TEGRATED CI	RCUIT	s			
	U440	155-	-0077-00) B010100	в039999х	Hybrid
	U540	155-	-0032-00	D C		Monolithic, input pre-amplifier
	U640	155-	-0032-00	0		Monolithic, input pre-amplifier
	U870	155-	-0049-00	D		Monolithic, sweep control
	U1524	156-	-0158-00	0		Dual operational amplifier, N5558V
	U1554	156-	-0158-00	0		Dual operational amplifier, N5558V
	U1690	156-	-0281-00	0		4 transistor array, MPQ2221
voi	TAGE MULTI	PLIE	λ			
	U1432	152-	-0552-00	0		Silicon, voltage multiplier
ELI	CTRON TUBE	s			•	
	V1440	154-	-0676-00	0 в010100	B010499	CRT
	V1440	154-	-0676-0	5 B010500		CRT

1 2Furnished as a unit with R630. 3Furnished as a unit with R1140. 4Furnished as a unit with R1155. 4 Either of these transformers may be used in the instrument.

Section 7-465

DIAGRAMS AND CIRCUIT BOARD ILLUSTRATIONS

Symbols and Reference Designators

Electrical components shown on the diagrams are in the following units unless noted otherwise:

Capacitors = Values one or greater are in picofarads (pF). Values less than one are in microfarads (μ F). Resistors = $Ohms(\Omega)$

Symbols used on the diagrams are based on USA Standard Y32.2-1967.

Logic symbology is based on MIL-STD-806B in terms of positive logic. Logic symbols depict the logic function performed and may differ from the manufacturer's data.

The following special symbols are used on the diagrams:



The following prefix letters are used as reference designators to identify components or assemblies on the diagrams.

- Assembly, separable or repairable (circuit board, etc.) А
- AT Attenuator, fixed or variable
- В Motor

13

- BT Battery
- Capacitor, fixed or variable С
- CR Diode, signal or rectifier
- DL Delay line
- DS Indicating device (lamp)
- F Fuse
- FL Filter
- Н Heat dissipating device (heat sink, heat radiator, etc.)
- HR Heater
- Connector, stationary portion
- K Relay
- L Inductor, fixed or variable

- LR Inductor/resistor combination
- M Meter
- Q Transistor or silicon-controlled rectifier
- Ρ Connector, movable portion
- R Resistor, fixed or variable
- RT Thermistor
- Switch S
- T Transformer
- TP Test point
- U Assembly, inseparable or non-repairable (integrated circuit, etc.)

7-1

- V Electron tube
- VR Voltage regulator (zener diode, etc.)
- Y Crystal













UCK DIAGHA







Fig. 7-4. P/O A4 Vertical Mode Switch circuit board.

Diagrams-465

A



A

Fig. 7-5. P/O A3 Vertical Preamp circuit board.





Fig. 7-7. A4 Vertical Mode Switch circuit board.

R218

 R249
 C-235
 R229
 R228
 O228
 R211
 R207
 C207

 R249
 C-235
 R237
 R238
 C
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0
 0</ R212 & C229 on underside Fig. 7-8. P/O A3 Vertical Preamp circuit board.

Diagrams—465

A

R 🛛 🖸 1200










Fig. 7-10. A5 Vertical Output Amplifier circuit board.









ENERATOR





R

<



Fig. 7-13. P/O A7 Timing circuit board.





















Fig. 7-18. P/O A9 Interface circuit board.



Fig. 7-19. A6 Fan Motor circuit board.



Fig. 7-20. A11 Trigger View Amplifier circuit board.



MOTOR







MECHANICAL PARTS LIST

Replacement parts should be ordered from the Tektronix Field Office or Representative in your area. Changes to Tektronix products give you the benefit of improved circuits and components. Please include the instrument type number and serial number with each order for parts or service.

ABBREVIATIONS

BHB	binding head brass	h	height or high	ОНВ	oval head brass
BHS	binding head steel	hex.	hexagonal	OHS	oval head steel
CRT	cathode-ray tube	ННВ	hex head brass	РНВ	pan head brass
csk	countersunk	HHS	hex head steel	PHS	pan head steel
DE	double end	HSB	hex socket brass	RHS	round head steel
FHB	flat head brass	HSS	hex socket steel	SE	single end
FHS	flat head steel	ID	inside diameter	тнв	truss head brass
Fil HB	fillister head brass	lg	length or long	THS	truss head steel
Fil HS	fillister head steel	ÕD	outside diameter	w	wide or width

FIGURE 1 FRONT & REAR

Fig. &			Q	
Index	Tektronix	Serial/Model	No. t	Description
No.	Part No.	Eff Disc	у	1 2 3 4 5
1-1	200-1411-00		1	BEZEL
		,	-	bezel includes:
-2	213-0313-00	1	4	THUMBSCREW, 4-40 x 0.45 inch, knurled
-3	337-1674-00	i i i i i i i i i i i i i i i i i i i	1	SHIELD, implosion, blue
-4	366-0494-00		3	KNOB, grayPOSITION, A TRIGGER HOLDOFF
			-	each knob includes:
	213-0153-00	e ¹	1	SETSCREW, 5-40 x 0.125 inch, HSS
-5	358-0378-01		14	BUSHING, sleeve
-6	358-0216-00		3	GROMMET, gray, plastic
-7	366-1031-02		2	KNOB, redVAR
			-	each knob includes:
	213-0153-00		1	SETSCREW, 5-40 x 0.125 inch, HSS
-8	366-1426-00		2	KNOB, grayVOLTS/DIVISION
			-	each knob includes:
	213-0153-00		2	SETSCREW, 5-40 x 0.125 inch, HSS
-9	366-0215-02		2	KNOB, lever switch
-10	366-1402-31		l	PUSHBUTTONINVERT
-11	366-1402-32		1	PUSHBUTTONBEAM FIND
-12	378-0803-01		2	LENS, indicator light
-13	366-1257-20		1	PUSHBUTTONCH 2
-14	366-1402-37		1	PUSHBUTTONCHOP
-15	366-1257-16		1	PUSHBUTTONADD
-16	366-1402-36		1	PUSHBUTTONALT
-17	366-1257-19		1	PUSHBUTTONCH 1
-18	426-0681-00		16	FRAME, pushbutton
-19	366-1023-01		3	KNOB, grayINTENSITY-FOCUS-SCALE ILLUM
			-	each knob includes:
	213-0153-00		1	SETSCREW, 5-40 x 0.125 inch, HSS
-20	366-1346-02		1	KNOB, redVAR
			-	knob includes:
	213-0153-00		1	SETSCREW, 5-40 x 0.125 inch, HSS

.

		FIGURE	1 F	RONT & REAR (cont)
Fia. &			Q	
Index	Tektronix	Serial/Model No.	t	Description
No.	Part No	Eff Disc	v	Description
1-21	366-1219-00)	1	KNOB, interlockingDELY'D SWEEP
		-	-	knob includes:
	213-0153-00)	2	SETSCREW, 5-40 x 0.125 inch, HSS
-22	354-0442-00)	1	RING, knob skirt
		-	-	ring includes:
• •	213-0153-00		1	SETSCREW, 5-40 x 0.125 inch, HSS
-23	401-0080-00)	1	BEARING, knob skirt
-24	366-1327-00)	1	KNOB, grayFINE
		- 	-	knob includes:
	213-0153-00		1	SETSCREW, 5-40 x 0.125 inch, HSS
-25	366-1280-00)	3	KNOB, grayHORIZ POSITION, LEVEL
		-	-	each knob includes:
	213-0153-00)	1	SETSCREW, 5-40 x 0.125 inch, HSS
-26	366-1402-33	3	1	PUSHBUTTONX10
-27	366-1402-35		1	PUSHBUTTONB DLY'D
-28	366-1402-44		1	PUSHBUTTONA INTEN
-29	366-1257-29)	1	PUSHBUTTONSINGLE SWP
-30	366-1402-34		1	PUSHBUTTONA
-31	366-1402-38		1	PUSHBUTTONAUTO
-32	366-1402-39		1	PUSHBUTTONNORM
-33	366-1402-29		1	PUSHBUTTONMIX
-34	378-0803-00		5	LENS, indicator light
-35	366-12/8-00)	2	KNOB, graySLOPE
			-	each knob includes:
26	213-0153-00	' 1	Ļ	SETSCREW, 5-40 x 0.125 inch, HSS
- 30	221-0220-00	-	Ļ	RESISTOR, Variable, W/nardware
-37	331-0328-00)	т	DIAL, CONTROL-DELAY TIME POSITION
	212-0049-00		-	CEECODEN 4 40 m 0 105 inch W00
_ 20	213-0048-00		Ţ	SETSCREW, 4-40 X U.125 INCN, HSS
-30	378-0035-00		4	DANEL front
-40	222-1022-00	1	1	PANEL, IFONT DESISTOD wariable
-40		-	4	ALSISTOR, VARIADIE
-41	210-0583-00	n an	٦	MIT boy 0 25-22 y 0 212 inch
-42	210-0940-00	,	1	NOI, $Mex.$, $0.25-52 \times 0.512$ Inch
72	210 0940-00		т.	WASHER, IIac, 0.25 ID x 0.375 Inch UD
-43	131-0955-00)	2	CONNECTOR, electrical, female BNC, w/bardware
-44	119-0373-00)	ĩ	CURRENT LOOP
			-	(ATTACHING PARTS)
-45	210-0586-00)	2	NUT, keps, $4-40 \ge 0.25$ inch
-46	210-0994-00)	2	WASHER, flat, 0.125 ID x 0.25 inch OD
-47	210-0849-00)	2	WASHER, fiber, shouldered. 0.11 ID x 0.187 inch OF
-48	361-0059-01		1	SPACER, current loop
-49	210-0593-00)	2	NUT, current loop
				*
-50	386-2330-00		1	SUBPANEL, front
_				(ATTACHING PARTS)
-51	213-0107-00		11	SCREW, thread forming, 4-40 x 0.25 inch, 100 deg.
		•		csk. FHS

2

₿

¹See Electrical Parts List for part number.

FIGURE 1 FRONT & REAR (cont)

Fig. &			Q	
Index No.	Tektronix Part No.	Serial/Model No. Eff Disc	t y	Description
1-52	352-0340-00		2	HOLDER, lamps
-53	211-0001-00		1	SCREW, 2-56 x 0.25 inch, PHS
-54	348-0276-00		ft	SHIELDING GASKET, electrical, 2.75 feet
-55	426-0926-01		1	FRAME, cabinet, front (ATTACHING PARTS)
-56	213-0183-00		4	SCREW, thread forming, 6-32 x 0.50 inch, PHS
-57	386-2340-00	1	4	SUPPORT, CRT, front
-58		-	Ŧ	CIRCUIT BOARD ASSEMBLYGRATICULE ILLUM AIO
FO			- 1	CIrcuit board assembly includes:
-59	3/8-0/28-00		1	HOLDER lamps
-60	175-0925-00		 	WIPE clostricel 2 wire ribbon 5 75 inches
-61	121-0707-00		2	CONNECTOR terminal
-62	252-0160-02		2	HOLDER torminal connector 2 wire (red)
-63	352-0109-02		1	CHASSIS main
-65	441-1004-00	1	1	COIL trace rotation
-66	344-0250-00		i	CLIP, electrical (ATTACHING PARTS)
-67	211-0008-00		1	SCREW, $4-40 \times 0.25$ inch. PHS
-68	210-0586-00		ī	NUT, keps, 4-40 x 0.25 inch
-69	348-0253-00		1	GROMMET, plastic, 1.145 inches ID
-70	348-0115-00		1	GROMMET, plastic, u-shape
-71	348-0063-00		3	GROMMET, plastic, 0.50 inch OD
-72	348-0056-00	1	4	GROMMET, plastic, 0.375 inch ID
-73		T	1	DELAY LINE
-74	407-1137-00		1	BRACKET, delay line (ATTACHING PARTS)
-75	210-0457-00		1	NUT, keps, 6-32 x 0.312 inch
-76		1	3	TRANSISTOR (ATTACHING PARTS FOR EACH)
-77	211-0012-00		1	SCREW, $4-40 \times 0.375$ inch, PHS
-78	210-0071-00		1	WASHER, spring tension
-79	342-0163-00	,	1	INSULATOR, transistor
-80		T	1	TRANSFORMER transformer includes:
-81	407-1066-00		1	BRACKET, transformer
-82	212-0522-00		4	SCREW, $10-32 \times 2.50$ inches, HHS
-83	210-0812-00		4	WASHER, fiber, #10
-84	166-0457-00		4	TUBE, insulating, 1.875 inches long
-85	200-1544-01		1	COVER, transformer
	210-0056-00		4	WASHER, lock, split, #10 (not shown)
-86	220-0561-00		4	NUT, hex., 10-32 x 0.25 inch (ATTACHING PARTS)
-87	211-0538-00		2	SCREW, 6-32 x 0.312 inch, 100 deg. csk, FHS
-88	210-0457-00		4	NUT, keps, $6-32 \times 0.312$ inch

¹See Electrical Parts List for part number.

₿

Fia. &			Q	
Index	Tektronix	Serial/Model No.	t	B
No.	Part No.	Eff Disc	y	
1-89	337-1763-00)	1	SHIELD, electrical, transformer
-90	348-0063-00		ī	GROMMET plastic 0 50 inch OD
-91	260-0638-00		ī	SWITCH thermostatic
71	200 0050 00		-	(ATTACHING PARTS)
-92	213-0044-00)	2	SCREW, thread forming, 5-32 x 0.188 inch, PHS
-93	210-0201-00)	1	LUG, solder, SE #4 (ATTACHING PARTS)
-94	211-0038-00	1	1	SCREW, $4-40 \times 0.312$ inch. 100 deg. csk. FHS
- 95	210-0586-00	, ,	ī	$MUT kens 4-40 \times 0.25 inch$
,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,	210 0300 00	•	-	$\frac{1}{2} = - \frac{1}{2} = - \frac{1}{2} = - \frac{1}{2}$
-96	129-0388-00)	2	POST, hex., 1.673 inches long
-97	337-1688-00)	1	SHIELD, electrical, high voltage
		-	-	(ATTACHING PARTS)
-98	211-0065-00)	3	SCREW, 4-40 x 0.188 inch, PHS
-99		_1	1	CTRCUTT BOARD ASSEMBLY FAN MOTOR AS
,,,		_	-	circuit board assembly includes.
-100	136-0269-00	n	1	SOCKET integrated circuit 14 nin
-101	131-0608-00	,	2	TERMINAL nin 0 265 inch long
-101	131-0008-00	1	2	COCUPE air connector
-102	130-0252-04	±	3	SOCKET, pin connector
-103	426-0781-00)	T	MOUNT, MOTOR
-104	212_0000_00	,	ſ	(ATTACHING PARTS)
-104	213-0088-00)	2	SCREW, thread forming, 4-40 X 0.25 inch, PHS
-105	337-1762-00	n	٦	SHIFLD, electrical, fan motor
-106	426-0781-00		1	MOUNT motor
100	420 0701 00	5	÷.	(ATTACHING PARTS)
-107	213-0088-00	ו	2	SCREW, thread forming, 4-40 x 0.25 inch. PHS
20,		-	-	
-108	407-1153-00	כ	1	BRACKET, transistor
				(ATTACHING PARTS)
-109	210-0586-00	0	2	NUT, keps, $4-40 \times 0.25$ inch
				· · · · · · · · · · · · · · · · · · ·
-110		-	1	TRANSISTOR
				(ATTACHING PARTS)
-111	211-0012-00	0	2	SCREW, 4-40 x 0.375 inch, PHS
-112	210-0205-00	0	1	LUG, solder, SE #8
-113	358-0214-00	0	2	BUSHING, insulator
-114	214-1610-00	0	1	HEATSINK, transistor
				*
-115	369-0031-00	0	1	IMPELLER, fan, w/setscrew
-116	348-0349-00	0	ft	SHIELDING GASKET, electrical, 2.75 feet
-117	426-0970-00	0	1	FRAME SECTION, cabinet rear
-118	348-0339-00	0	4	FOOT, cabinet, w/cord wrap
				(ATTACHING PARTS FOR EACH)
-119	212-0020-00	0	1	SCREW, 8-32 x 1.0 inch, PHS

FIGURE 1 FRONT & REAR (cont)

¹See Electrical Parts List for part number.

₿

FIGURE 1 FRONT & REAR (cont)

Fig. & Index No.	Tektronix Part No.	Serial/Mode Eff Dis	Q el No.t scy	Description
1-120	386-2332-00)	l	PANEL, rear (ATTACHING PARTS)
-121	211-0105-00)	1	SCREW, 4-40 x 0.188 inch, 100 deg. csk, FHS
-122	204-0549-01	L	1	BODY, line voltage selector (ATTACHING PARTS)
-123	210-0407-00)	2	NUT, hex., $6-32 \times 0.25$ inch
-124	210-0006-00)	2	WASHER, lock, split, 0.145 ID x 0.253 inch OD
-125	200-1445-01	-	1	COVER, line voltage selector
		•	-	cover includes:
	352-0102-00)	1	HOLDER, fuse, plastic (not shown) (ATTACHING PARTS)
	213-0034-00)	2	SCREW, thread cutting, 4-40 x 0.312 inch,
			-	PHS (not shown)
	161-0090-00) B010100 B	3010409 1	CABLE ASSEMBLY, power
-126	161-0033-07	B010410	1	CABLE ASSEMBLY, power
-127	358-0372-00)	ī	BUSHING, strain relief, bottom
-128	200-1004-00)	ī	CABLE NIPPLE
-129	358-0371-00)	1	BUSHING, strain relief, top
-130	200-1414-01	<u>_</u>	1	COVER, rear (ATTACHING PARTS)
-131	211-0101-00)	2	SCREW, 4-40 x 0.25 inch, 100 deg. csk, FHS
-132	211-0516-00)	2	SCREW, 6-32 x 0.875 inch, PHS
-133	386-2408-00)	l	PLATE, connector mounting
-134	131-0955-00)	4	CONNECTOR, electrical, female, BNC, w/hardware (ATTACHING PARTS FOR EACH)
-135	210-0255-00)	1	TERMINAL, lug, solder, 0.391 inch ID





FIGURE 2 CIRCUIT BOARDS

۲

No. Part No. Eff Disc y 1 = 2 3 4 5 2-1 337-1711-01 1 SHIELD, electrical, high voltage (ATTACHING PARTS) -2 211-0008-00 B040000 1 SCREW, 4-40 x 0.25 inch, PHS 211-0101-00 B040000 1 SCREW, 4-40 x 0.312 inch, PHS 211-0101-00 B040000 1 SCREW, 4-40 x 0.312 inch, PHS 210-1010-00 B040000 1 WASHER, flat, 0.119 inch ID 131-1428-00 X8040000 1 WASHER, flat, 0.119 inch ID -3 342-0175-00 1 INSULATOR, film, 3.65 x 4.70 inches -1 1212-0180-00 4 POST, hex, 0.62 inch long -6 2 TRANSISTOR (ATTACHING PARTS POR EACH) -7 211-0180-00 1 SCREW, (ATOH PARTS POR EACH) 1 -7 211-0180-00 1 INSULATOR, transistor - -10 1 CIRCUT BOARD ASEMELY-INTERFACE A9 - -11 <th>Fig. &</th> <th>- 1. •</th> <th>C</th> <th>1.1.NL</th> <th>Q</th> <th></th>	Fig. &	- 1. •	C	1.1.NL	Q	
No. Full PLAC Y 17343 2-1 337-7111-01 1 SHIELD, electrical, high voltage (ATTACHING PARTS) -2 211-0008-00 B040000 3 SCEEW, 4-40 x 0.25 inch, PHS 211-010-00 B040000 1 SCEEW, 4-40 x 0.25 inch, PHS 210-1010-00 XB040000 1 SCEEW, 4-40 x 0.32 inch, PHS 210-1010-00 XB040000 1 CLIP, ground	Index	lektronix	Serial/Mod	iel NO.	T M	Description
2-1 337-1711-01 1 SHIELD, electrical, high voltage (ATTACHING PARTS) -2 211-0008-00 B040000 3 SCREW, 4-40 x 0.25 inch, PHS 211-010-00 B040000 1 SCREW, 4-40 x 0.25 inch, PHS 211-010-00 B040000 1 SCREW, 4-40 x 0.312 inch, PHS 211-0101-00 SD040000 1 SCREW, 4-40 x 0.35 inch, PHS 211-0110-00 B040000 1 SCREW, 4-40 x 0.35 inch, PHS 342-0175-00 1 INSULATOR, film -3 342-0159-00 1 INSULATOR, film -5 129-0413-00 4 POST, hex., 0.62 inch PHB -7 211-0180-00 1 SCREW, sems, 2-56 x 0.25 inch, PHB -7 211-0180-00 1 SCREW, sems, 2-56 x 0.25 inch, PHB -7 211-0180-00 1 SCREW, sems, 10.26 inch, 70.01 inch sempth -7 211-0180-00 1 SCREW, sems, 10.26 inch, 70.01 inch sempth -7 211-0180-00 1 SCREW, sems, 2-56 x 0.25 inch, 70.10 inch sempth -7 11 36-0499-10 1 SCREW, sempth -10 inch des </th <th>INO.</th> <th>Parr INO.</th> <th></th> <th>ISC</th> <th>У</th> <th>1 2 3 4 5</th>	INO.	Parr INO.		ISC	У	1 2 3 4 5
-2 211-0008-00 B014000 33 SCREW, 4-40 x 0.25 inch, PHS 211-0008-00 B040000 1 SCREW, 4-40 x 0.25 inch, PHS 211-010-00 B040000 1 SCREW, 4-40 x 0.312 inch, PHS 211-0101-00 XB040000 1 CLIP, ground 311-1428-00 XB040000 1 CLIP, ground 342-0175-00 1 INSULATOR, film, 3.65 x 4.70 inches -4 342-0155-00 1 INSULATOR, film -5 129-0413-00 4 POST, hex., 0.62 inch long -6 2 TRANSISTOR -7 211-0180-00 1 SCREW, sems, 2-56 x 0.25 inch, PHB -8 210-1156-00 1 INSULATOR, transistor -0 inch, 0D -9 342-0166-00 1 INSULATOR, transistor -101 1 CIRCUIT BOARD ASEMBLY-INTERFACE A9 	2-1	337-1711-01			1	SHIELD, electrical, high voltage (ATTACHING PARTS)
211-0008-00 B040000 3 SCREW, 4-40 x 0.25 inch, PHS 210-1001-00 XB040000 1 WASHER, flat, 0.119 inch ID 131-1428-00 XB040000 1 CLIP, ground -3 342-0175-00 1 INSULATOR, film, 3.65 x 4.70 inches -4 342-0159-00 1 INSULATOR, film, 3.65 x 4.70 inches -5 129-0413-00 4 POST, hex, 0.62 inch long -6 2 TRANSISTOR -7 211-0180-00 1 SCREW, 4-60 x 0.25 inch, PHB -8 210-1156-00 1 SCREW, shouldered, plastic, 0.09 ID x 0.121 -7 211-0180-00 1 SCREW, shouldered, plastic, 0.09 ID x 0.121 -7 342-0166-00 1 INSULATOR, transistor -10 -10 1 CIRCUIT BOARD ASSEMELYINTERFACE A9 -11 136-0499-10 1 SOCKET, circuit board, 10 contact -12 136-0499-10 1 SOCKET, circuit board, 14 contact -13 136-0499-10 1 SOCKET, pin connector -14 214-0579-00 6 PIN, test point -15 136-0252-04 162 SOCKET, pin connector -16 131-1261-00 2 STRIP, ceramic, 3 notch -17 11-0566-00 1 STUP, plastic -20 355-0046-00 1 STUP, plastic -21 124-0192-00 2 STRIP, ceramic, 1 notch	-2	211-0008-00	B010100	B039999	4	SCREW, $4-40 \times 0.25$ inch, PHS
211-0110-00 B040000 1 SCREW, 4-40 x 0.312 inch, PHS 210-101-00 XB040000 1 WASHER, flat, 0.119 inch ID 131-1428-00 XB040000 1 CLIP, ground -3 342-0175-00 1 INSULATOR, film, 3.65 x 4.70 inches -4 342-0175-00 1 INSULATOR, film, 3.65 x 4.70 inches -5 129-0413-00 4 POST, hex., 0.62 inch long -6 2 TRANSISTOR -7 211-0180-00 1 SCREW, sems, 2-56 x 0.25 inch, PHB -8 210-1156-00 1 WASHER, shouldered, plastic, 0.09 ID x 0.121 inch, OD 1 CIRCUIT BOARD ASEMELVINTERFACE A9 circuit board assembly includes: -11 136-0499-10 1 SOCKET, circuit board, 14 contact -12 136-0499-10 1 SOCKET, circuit board, 14 contact -13 136-0499-10 1 SOCKET, circuit board, 14 contact -14 214-0579-00 6 PIN, test point -15 136-0252-04 162 SOCKET, pin connector -16 131-261-00 2 STRIP, ceramic, 1 notch -18 344-0154-00 2 CLIP, electrical, f-shape -1 <td></td> <td>211-0008-00</td> <td>B040000</td> <td></td> <td>3</td> <td>SCREW, $4-40 \times 0.25$ inch, PHS</td>		211-0008-00	B040000		3	SCREW, $4-40 \times 0.25$ inch, PHS
210-1001-00 XB040000 1 WASHER, flat, 0.119 inch ID 131-1428-00 XB040000 1 CLIP, ground -3 342-0175-00 1 INSULATOR, film, 3.65 x 4.70 inches -4 342-0159-00 1 INSULATOR, film, 3.65 x 4.70 inches -5 129-0413-00 4 POST, hex., 0.62 inch long -6 2 TRANSISTOR -7 211-0180-00 1 SCREW, sems, 2-56 x 0.25 inch, PHB -8 210-1156-00 1 SCREW, sems, 2-56 x 0.25 inch, PHB -9 342-0166-00 1 INSULATOR, film, 3.65 x 4.70 inches -10 - inch, OD -11 136-0499-14 1 SCCREY, sems, 2-56 x 0.25 inch, PHB -12 inch, OD 1 UNSULATOR, transistor -11 - inch, OD -12 inch.00 1 SCCKET, circuit board, 10 contact 13 136-0499-10 1 SCCKET, circuit board, 14 contact -13 136-0499-10 1 SCCKET, pin connector -14 214-0579-00 6 PIN, test point -15 131-261-00 2 STRIP, ceramic, 1 notch -17 131-0566-00 7 LINK, terminal connecting -18 344-0154-00 2 STRIP, ceramic, 1 notch strip includes: 355-0046-00 1 STUD, plastic -22 124-0118-00 </td <td></td> <td>211-0110-00</td> <td>B040000</td> <td></td> <td>1</td> <td>SCREW, $4-40 \times 0.312$ inch, PHS</td>		211-0110-00	B040000		1	SCREW, $4-40 \times 0.312$ inch, PHS
131-1428-00 XB040000 1 CLIP, ground -3 342-0175-00 1 INSULATOR, film, 3.65 x 4.70 inches -4 342-0159-00 1 INSULATOR, film, 3.65 x 4.70 inches -5 123-0413-00 4 POST, hex., 0.62 inch long -6 2 TRANSISTOR -7 211-0180-00 1 SCREW, sems, 2-56 x 0.25 inch, PHB -8 210-1156-00 1 WASHER, shouldered, plastic, 0.09 ID x 0.121 inch, 00 1 INSULATOR, transistor -10 -11 136-0499-10 1 SOCKET, circuit board, 10 contact -12 136-0499-10 1 SOCKET, circuit board, 10 contact -13 136-0499-10 1 SOCKET, circuit board, 14 contact -14 214-0579-00 6 PIN, test point -15 136-0499-14 1 SOCKET, eicruit board, 14 contact -14 124-0579-00 6 PIN, test point -15 136-0499-14 1 SOCKET, eicruit board, 16 contact -14 124-0579-00 2 STRIP, ceramic, 1 forch -14 124-0579-00 2 STRIP, ceramic, 2 notch -14 124-05		210-1001-00	XB040000		1	WASHER, flat, 0.119 inch ID
-3 342-0175-00 1 INSULATOR, film, 3.65 x 4.70 inches -4 342-0159-00 1 INSULATOR, film -5 129-0413-00 4 POST, hex., 0.62 inch long -6 2 TRANSISTOR (ATTACHING PARTS FOR EACH) 1 SCREW, sems, 2-56 x 0.25 inch, PHB -7 211-0180-00 1 SCREW, sems, 2-56 x 0.25 inch, PHB -8 210-1156-00 1 INSULATOR, fransistor inch, 0D 1 circuit board assembly includes: -11 136-0499-10 1 SOCKET, circuit board, 14 contact -13 136-0499-10 1 SOCKET, circuit board, 14 contact -13 136-0499-10 1 SOCKET, circuit board, 14 contact -13 136-0499-10 1 SOCKET, circuit board, 14 contact -14 214-0579-00 6 PIN, test point -15 136-0499-10 2 SCLET, circuit board, 14 contact -14 214-0159-00 2 CLIP, electrical, fishape -17 131-0566-00 1 <td< td=""><td></td><td>131-1428-00</td><td>XB040000</td><td></td><td>1</td><td>CLIP, ground</td></td<>		131-1428-00	XB040000		1	CLIP, ground
-4 342-0159-00 1 INSULATOR, film -5 129-0413-00 4 POST, hex., 0.62 inch long -6 IRANSISTOR (ATTACHING PARTS FOR EACH) -7 211-0180-00 1 SCREW, sens, 2-56 x 0.25 inch, PHB -8 210-1156-00 1 WASHER, shouldered, plastic, 0.09 ID x 0.121 -9 342-0166-00 1 INSULATOR, transistor -9 342-0166-00 1 INSULATOR, transistor -10 -10 -11 136-0499-10 1 SOCKET, circuit board, 4 contact -12 136-0499-14 1 SOCKET, circuit board, 10 contact -13 136-0499-14 1 SOCKET, circuit board, 14 contact -14 214-0579-00 6 PIN, test point -15 136-0499-14 1 SOCKET, circuit board, 14 contact -14 214-0579-00 2 STRIP, ceramic, 1 notch -17 131-0566-00 7 LINK, terminal connector -16 131-1261-00 2 STRIP, ceramic, 2 no	-3	342-0175-00			1	INSULATOR, film, 3.65×4.70 inches
-5 129-0413-00 4 POST, hex., 0.62 inch long -6 2 TRANSISTOR (ATTACHING PARTS FOR EACH) -7 211-0180-00 1 SCREW, sens, 2-56 x 0.25 inch, PHB -8 210-1156-00 1 WASHER, shouldered, plastic, 0.09 ID x 0.121 -9 342-0166-00 1 INSULATOR, transistor -10 - inch, OD -11 136-0499-10 1 SOCKET, circuit board, 4 contact -12 136-0499-10 1 SOCKET, circuit board, 10 contact -13 136-0499-10 1 SOCKET, circuit board, 14 contact -14 214-0579-00 6 FIN, test point -15 136-0499-10 1 SOCKET, circuit board, 14 contact -14 14 24-0579-00 6 FIN, test point -15 136-0499-10 1 SOCKET, circuit board, 14 contact -14 214-0579-00 6 FIN, test point -15 136-0252-04 162 SOCKET, pin connector -16 131-1261-00 2 STUD, plastic -20 <t< td=""><td>-4</td><td>342-0159-00</td><td></td><td></td><td>ī</td><td>INSULATOR, film</td></t<>	-4	342-0159-00			ī	INSULATOR, film
-6 2 TRANSISTOR -7 211-0180-00 1 SCREW, sems, 2-56 x 0.25 inch, PHB -8 210-1156-00 1 WASHER, shouldered, plastic, 0.09 ID x 0.121 -9 342-0166-00 1 INSULATOR, transistor -10 inch, OD 1 -11 136-0499-04 1 CIRCUIT BOARD ASSEMBLYINTERFACE A9 -12 136-0499-10 1 SOCKET, circuit board, 4 contact -13 136-0499-14 1 SOCKET, circuit board, 10 contact -13 136-0499-14 1 SOCKET, circuit board, 10 contact -14 214-0579-00 6 PIN, test point -15 136-0499-14 1 SOCKET, pin connector -16 131:0566-00 7 LINK, terminal connecting -17 131-0566-00 2 STRIP, ceramic, 3 notch each strip includes: -19 124-019-00 1 STRIP, ceramic, 1 notch strip includes: 1 STUD, plastic	-5	129-0413-00			4	POST, hex., 0.62 inch long
-7 211-0180-00 1 SCREW, sens, 2-56 x 0.25 inch, PHB -8 210-1156-00 1 WASER, shouldered, plastic, 0.09 ID x 0.121 inch, OD 1 -9 342-0166-00 1 INSULATOR, transistor -10 1 CIRCUIT BOARD ASSEMBLYINTERFACE A9 -11 136-0499-04 1 SOCKET, circuit board, 4 contact -12 136-0499-10 1 SOCKET, circuit board, 10 contact -13 136-0499-14 1 SOCKET, circuit board, 14 contact -14 214-0579-00 6 PIN, test point -15 136-0429-04 1 SOCKET, circuit board, 14 contact -14 214-0579-00 2 STRIP, ceramic, 1 notact -15 131-1261-00 2 CLIP, electrical, f-shape -17 131-0566-00 2 STRIP, ceramic, 1 notch strip includes: -20 355-0046-00 1 STUD, pl	-6				2	TRANSISTOR
-7 211-0180-00 1 SCREW, sens, 2-56 x 0.25 inch, PHB -8 210-1156-00 1 WASHER, shouldered, plastic, 0.09 ID x 0.121 inch, OD 1 INSULATOR, transistor -10 -11 136-0499-04 1 CIRCUIT BOARD ASSEMBLY-INTERFACE A9 -12 136-0499-10 1 SOCKET, circuit board, 4 contact -13 136-0499-14 1 SOCKET, circuit board, 10 contact -14 214-0579-00 6 PIN, test point 1 -15 136-0499-14 1 SOCKET, circuit board, 14 contact -14 214-0579-00 6 PIN, test point 1 -15 136-0492-00 2 SURE, clearmica, f-shape -17 131-0566-00 7 LINK, terminal connecting -18 344-0154-00 2 STRIP, ceramic, 2 notch - each strip includes: 3 -20 355-0046-00 1 STUD, plastic -21 124-0118-00 1 STRIP, ceramic, 1 notch <	•				-	(ATTACHING PARTS FOR EACH)
-8 210-1156-00 1 WASHER, shouldered, plastic, 0.09 ID x 0.121 -9 342-0166-00 1 INSULATOR, transistor -10 inch, OD 1 -11 136-0499-04 1 SOCKET, circuit board, 4 contact -12 136-0499-10 1 SOCKET, circuit board, 10 contact -13 136-0499-10 1 SOCKET, circuit board, 10 contact -14 214-0579-00 6 PIN, test point -15 136-0459-10 162 SOCKET, pin connector -16 131-1261-00 24 CONTACT, electrical, f-shape -17 131-0566-00 7 LINK, terminal connecting -18 344-0154-00 2 STRIP, ceramic, 2 notch each strip includes: -20 355-0046-00 1 STUD, plastic -21 124-0019-00 1 STUD, plastic -22 124-0018-00 1 STUD, plastic -23 358-0214-00 1 WASHER, insulating, rubber, 0.875 ID -23 358-0214-00 1 WASHER, incul	-7	211-0180-00			1	SCREW, sems, $2-56 \times 0.25$ inch. PHB
-9 342-0166-00 1 INSULATOR, transistor -10 1 1 INSULATOR, transistor -11 136-0499-04 1 SCKET, circuit board, 4 contact -12 136-0499-04 1 SCCKET, circuit board, 10 contact -13 136-0499-10 1 SCCKET, circuit board, 10 contact -14 214-0579-00 6 PIN, test point -15 136-0499-14 1 SCCKET, pin connector -16 131-2661-00 2 CLIP, electrical, f-shape -17 131-0566-00 7 LINK, terminal connecting -18 344-0154-00 2 CLIP, electrical, fuse -20 355-0046-00 1 STRIP, ceramic, 2 notch -21 124-0119-00 1 STRIP, ceramic, 1 notch -22 124-0118-00 1 STRIP, ceramic, 1 notch -23 355-0046-00 1 STUD, plastic -24 120-0966-00 1 MSTRIP, transistor -24 210-0968-00 1 BUSHING, insulator -25 131-0608-00 3 TERMINAL, pin, 0.365 inch	-8	210-1156-00			ī	WASHER, shouldered, plastic, 0.09 ID x 0.121
-9 342-0166-00 1 INSULATOR, transistor -10 1 1 CIRCUIT BOARD ASSEMBLYINTERFACE A9 -11 136-0499-04 1 SOCKET, circuit board, 4 contact -12 136-0499-10 1 SOCKET, circuit board, 10 contact -13 136-0499-10 1 SOCKET, circuit board, 10 contact -14 214-0579-00 6 PIN, test point -15 136-0252-04 162 SOCKET, pin connector -16 131-1261-00 2 CLIP, electrical, fuse -17 131-0566-00 7 LINK, transitor -18 344-0154-00 2 STRIP, ceramic, 3 notch -20 355-0046-00 1 STUD, plastic -21 124-0119-00 1 STRIP, ceramic, 1 notch - strip includes: 355-0046-00 -21 124-0118-00 1 STUD, plastic -22 124-0118-00 1 STUD, plastic -23 358-0214-00 10 BUSHING, insulator -24 210-0966-00 3 TERMINAL, pin, 0.365 inch long	Ũ				2	inch. OD
-10 1 -10 1 -11 136-0499-04 -12 136-0499-10 -13 136-0499-10 -14 214-0579-00 -15 136-0252-04 -16 131-1261-00 -17 131-0566-00 -17 131-0566-00 -17 131-0566-00 -17 131-0566-00 -17 131-0566-00 -17 131-0566-00 -17 131-0566-00 -17 131-0566-00 -17 131-0566-00 -18 344-0154-00 -20 355-0046-00 -21 124-019-00 -25 355-0046-00 -21 124-0119-00 -22 124-0119-00 -23 55-0046-00 -21 124-0119-00 -22 124-0118-00 -23 355-0046-00 -23 358-0214-00 -24 210-0966-00 -25 131-0608-00 -26 214-0973-00 -27 -28 210-0583-00 -29 210-0984-00 -30 3260-1208-00 -31 386-2433-00 -33 260-1208-00 -34 361-0384-00 -34 361-0384-00 -34 361-0384-00 -34 361-0384-00 -35 SPACER, pushbutton switch, 0.133 inch long -34 361-0384-00 -35 SPACER, pushbutton switch, 0.133 inch long -34 361-0384-00 -35 SPACER, pushbutton switch, 0.133 inch long -34 361-0384-00 -35 SPACER, pushbutton switch, 0.133 inch long	-9	342-0166-00			1	INSULATOR, transistor
	-10		L [.]		1	
-11 136-0499-04 1 SOCKET, circuit board, 4 contact -12 136-0499-10 1 SOCKET, circuit board, 10 contact -13 136-0499-14 1 SOCKET, circuit board, 10 contact -14 214-0579-00 6 PIN, test point -15 136-0252-04 162 SOCKET, pin connector -16 131-1261-00 24 CONTACT, electrical, f-shape -17 131-0566-00 7 LINK, terminal connecting -18 344-0154-00 2 STRIP, ceramic, 3 notch -19 124-0092-00 2 STRIP, ceramic, 2 notch -11 -14 -14 -14 -14 -20 355-0046-00 1 STRIP, ceramic, 2 notch -17 -12 124-0119-00 1 STRIP, ceramic, 1 notch -17 -12 124-0118-00 1 STRIP, ceramic, 1 notch -16 -17 -18 355-0046-00 1 STUD, plastic -23 358-0214-00 10 BUSHING, insulator 1 -24 210-0966-00 1 WASHER, insulating, rubber, 0.875 ID	-10				т -	circuit board accombly includes.
-12 136-0499-10 1 SOCKET, circuit board, 10 contact -13 136-0499-14 1 SOCKET, circuit board, 14 contact -14 214-0579-00 6 PIN, test point -15 136-0252-04 162 SOCKET, pin connector -16 131-1261-00 24 CONTACT, electrical, f-shape -17 131-0566-00 7 LINK, terminal connecting -18 344-0154-00 2 CLIP, electrical, fuse -19 124-0092-00 2 STRIP, ceramic, 3 notch -20 355-0046-00 1 STRIP, ceramic, 2 notch -21 124-0119-00 1 STRIP, ceramic, 1 notch -22 124-0118-00 1 STRIP, ceramic, 1 notch -23 358-0214-00 10 BUSHING, insulator -24 210-0966-00 1 STEMP, transistor -25 213-0608-00 33 TERMINAL, pin, 0.365 inch long -26 214-0973-00 1 HEATSINK, transistor -27 1 RESISTOR, variable -28 210-0940-00 1 WASHER, lock	11	126-0400-04			1	SOCKET airquit board 4 contact
13 130-0499-14 1 SOCKET, circuit board, 14 contact -14 214-0579-00 6 PIN, test point -15 136-0499-14 1 SOCKET, circuit board, 14 contact -14 214-0579-00 6 PIN, test point -15 136-0499-14 12 SOCKET, circuit board, 14 contact -14 214-0579-00 6 PIN, test point -15 136-0252-04 162 SOCKET, circuit board, 14 contact -16 131-1261-00 24 CONTACT, electrical, f-shape -17 131-0566-00 7 LINK, terminal connecting -18 344-0154-00 2 STRIP, ceramic, 3 notch each strip includes: -20 355-0046-00 1 STRIP, ceramic, 1 notch strip includes: strip includes: strip includes:	-12	126-0499-04			Ť	SOCKET, circuit board, 4 contact
-14 14-0579-00 6 FIN. test point -15 136-0252-04 162 SOCKET, pin connector -16 131-1261-00 24 CONTACT, electrical, f-shape -17 131-0566-00 7 LINK, terminal connecting -18 344-0154-00 2 CLIP, electrical, fuse -19 124-0092-00 2 STRIP, ceramic, 3 notch each strip includes: -20 355-0046-00 1 STRIP, ceramic, 2 notch strip includes: -21 124-0119-00 1 STRIP, ceramic, 2 notch strip includes: -22 124-0118-00 1 STRIP, ceramic, 1 notch strip includes: strip includes: -23 358-0214-00 10 BUSHING, insulator -24 210-0966-00 1 WASHER, insulating, rubber, 0.875 ID -25 131-0608-00 3 TERINAL, pin, 0.365 inch long -26 214-0973-00 <td>-12</td> <td>136-0499-10 126-0409-14</td> <td></td> <td></td> <td>1</td> <td>SOCKET, circuit board, 10 contact</td>	-12	136-0499-10 126-0409-14			1	SOCKET, circuit board, 10 contact
-15 136-0252-04 162 SOCKET, pin connector -16 131-1261-00 24 CONTACT, electrical, f-shape -17 131-0566-00 7 LINK, terminal connecting -18 344-0154-00 2 CLIP, electrical, fuse -19 124-0092-00 2 STRIP, ceramic, 3 notch -20 355-0046-00 1 STUD, plastic -21 124-0119-00 1 STUP, ceramic, 2 notch -21 124-0119-00 1 STUP, ceramic, 2 notch -22 124-0119-00 1 STUP, ceramic, 1 notch -22 124-0118-00 1 STUP, ceramic, 1 notch -23 355-0046-00 1 STUP, plastic -23 358-0214-00 10 BUSHING, insulator -24 210-0966-00 1 WASHER, insulating, rubber, 0.875 ID -25 131-0608-00 33 TERMINAL, pin, 0.365 inch long -26 214-0973-00 1 HEATSINK, transistor -27 1 RESISTOR, variable (ATTACHING PARTS) 1 NUT, hex, 0.25-32 x 0.312 inch 0D	-14				Ē	BIN test point
131-1261-00 102 SOCKET, plantometeon 16 131-1261-00 24 CONTACT, electrical, f-shape -17 131-0566-00 7 LINK, terminal connecting -18 344-0154-00 2 CLIP, electrical, fuse -19 124-0092-00 2 STRIP, ceramic, 3 notch each strip includes: -20 355-0046-00 1 STUD, plastic -21 124-0119-00 1 STRIP, ceramic, 2 notch strip includes: 355-0046-00 1 STUD, plastic -22 124-0118-00 1 STUD, plastic -23 358-0214-00 10 BUSHING, insulator -24 210-0966-00 1 WASHER, insulating, rubber, 0.875 ID -25 131-0608-00 33 TERMINAL, pin, 0.365 inch long -26 214-0973-00 1 HEXSINK, transistor -27 1 RESISTOR, variable (ATTACHING PARTS) 1 NUT, hex., 0.25-32 x 0.312 inch -29 210-0940-00 1 WASHER, lock,	-14	126-0252-04		16	2	SOCKET pin connector
131-121-1201-00 124 CONTRET, Flectifical, fistage 17 131-056-00 7 LINK, terminal connecting -18 344-0154-00 2 CLIP, electrical, fuse -19 124-0192-00 2 STRIP, ceramic, 3 notch each strip includes: -20 355-0046-00 1 STUD, plastic -21 124-0119-00 strip includes: -355-0046-00 1 STUD, plastic -22 124-0118-00 1 STRIP, ceramic, 1 notch strip includes: 355-0046-00 1 STUD, plastic -23 358-0214-00 10 BUSHING, insulator -24 210-0966-00 1 WASHER, insulating, rubber, 0.875 ID -25 131-0608-00 33 TERMINAL, pin, 0.365 inch long -26 214-0973-00 1 HEXISINK, transistor -27 1 RESISTOR, variable (ATTACHING PARTS) 1 NUT, hex., 0.25-32 x 0.312 inch -28 210-0940-00 1 WASHER, flock, 0.261 ID x	-15	121-1261-00		20	1	CONTACT electrical f-shape
-19 131-0306-00 2 CLIP, cleatrical conducting -19 124-0092-00 2 STRIP, ceramic, 3 notch -20 355-0046-00 1 STUD, plastic -21 124-0119-00 1 STRIP, ceramic, 2 notch -355-0046-00 1 STUD, plastic -22 124-0119-00 1 STRIP, ceramic, 1 notch - strip includes: 355-0046-00 1 STUD, plastic -22 124-0118-00 1 STUD, plastic -23 358-0214-00 10 BUSHING, insulator -24 210-0966-00 1 STUD, plastic -23 358-0214-00 10 BUSHING, insulator -24 210-0966-00 1 WASHER, insulating, rubber, 0.875 ID -25 131-0608-00 3 TERMINAL, pin, 0.365 inch long -26 214-0973-00 1 HEATSINK, transistor -27 1 RESISTOR, variable -28 210-0583-00 1 NUT, hex., 0.25-32 x 0.312 inch -29 210-0940-00 1 WAS	-17	131-0566-00		2	7	LINK terminal connecting
-10 344-0192-00 2 STRIP, Ceramic, 3 notch -20 355-0046-00 1 STUD, plastic -21 124-0119-00 1 STRIP, ceramic, 2 notch -21 124-0119-00 1 STRIP, ceramic, 2 notch -22 124-0119-00 1 STRIP, ceramic, 1 notch -22 124-0118-00 1 STRIP, ceramic, 1 notch -22 124-0118-00 1 STUD, plastic -23 355-0046-00 1 STUD, plastic -23 358-0214-00 10 BUSHING, insulator -24 210-0966-00 1 WASHER, insulating, rubber, 0.875 ID -25 131-0608-00 3 TERMINAL, pin, 0.365 inch long -26 214-0973-00 1 HEATSINK, transistor -27 1 RESISTOR, variable -28 210-0583-00 1 NUT, hex., 0.25-32 x 0.312 inch -29 210-0940-00 1 WASHER, flat, 0.25 ID x 0.375 inch OD -30 210-0046-00 1 WASHER, lock, 0.261 ID x 0.40 inch OD -31 386-2433-00 1	-1/ -10	244-0154-00			2	CLIP electrical fuse
- each strip includes: -20 355-0046-00 1 STUD, plastic -21 124-0119-00 1 STRIP, ceramic, 2 notch	-10	124-0092-00			2	STRIP ceramic 3 notch
-20 355-0046-00 1 STUD, plastic -21 124-0119-00 1 STRIP, ceramic, 2 notch -355-0046-00 1 STUD, plastic -22 124-0118-00 1 STRIP, ceramic, 1 notch -23 355-0046-00 1 STUD, plastic -24 124-0118-00 1 STRIP, ceramic, 1 notch -355-0046-00 1 STUD, plastic -23 358-0214-00 10 BUSHING, insulator -24 210-0966-00 1 WASHER, insulating, rubber, 0.875 ID -25 131-0608-00 33 TERMINAL, pin, 0.365 inch long -26 214-0973-00 1 HEATSINK, transistor -27 - - 1 RESISTOR, variable (ATTACHING PARTS) 1 NUT, hex., 0.25-32 x 0.312 inch 0 -28 210-0583-00 1 NUT, hex., 0.251 ID x 0.40 inch OD -30 210-0046-00 1 WASHER, lock, 0.261 ID x 0.40 inch OD -31 386-2433-00 1 SUPPORT, resistor -32 - - - - -3	-19	124-0092-00			-	each strin includes.
-21 124-0119-00 1 STRIP, ceramic, 2 notch	-20	355-0046-00			1	STUD, plastic
11 12 0110 01 1 STRIP, Ceramic, 1 1 355-0046-00 1 STRIP, ceramic, 1 notch -22 124-0118-00 1 STRIP, ceramic, 1 notch -355-0046-00 1 STRIP, ceramic, 1 notch -22 124-0118-00 1 STRIP, ceramic, 1 notch -23 355-0046-00 1 STUD, plastic -23 358-0214-00 10 BUSHING, insulator -24 210-0966-00 1 WASHER, insulating, rubber, 0.875 ID -25 131-0608-00 33 TERMINAL, pin, 0.365 inch long -26 214-0973-00 1 HEATSINK, transistor -27 -0 -0 1 RESISTOR, variable (ATTACHING PARTS) 1 NUT, hex., 0.25-32 x 0.312 inch 0.25 -28 210-0583-00 1 NUT, hex., 0.251 ID x 0.375 inch OD -29 210-0940-00 1 WASHER, lock, 0.261 ID x 0.40 inch OD -31 386-2433-00 1 SUPPORT, resistor -32 260-1208-00 1 SWITCH, pushX10 MAG	-21	124-0119-00			î	STRIP, ceramic, 2 notch
355-0046-00 1 STUD, plastic -22 124-0118-00 1 STRIP, ceramic, 1 notch -355-0046-00 1 STUD, plastic -23 358-0214-00 10 BUSHING, insulator -24 210-0966-00 1 WASHER, insulating, rubber, 0.875 ID -25 131-0608-00 33 TERMINAL, pin, 0.365 inch long -26 214-0973-00 1 HEATSINK, transistor -27 1 1 RESISTOR, variable (ATTACHING PARTS) 1 NUT, hex., 0.25-32 x 0.312 inch -29 210-0940-00 1 WASHER, flat, 0.251 ID x 0.375 inch OD -30 210-0046-00 1 SUPPORT, resistor -31 386-2433-00 1 SUPPORT, resistor -32 1 4 RESISTOR, variable -33 260-1208-00 1 SWITCH, pushX10 MAG (ATTACHING PARTS) -34 361-0384-00 2 SPACER, pushbutton switch, 0.133 inch long	21				<u> </u>	strip includes:
-22 124-0118-00 1 STRIP, ceramic, 1 notch -355-0046-00 1 STUD, plastic -23 358-0214-00 10 BUSHING, insulator -24 210-0966-00 1 WASHER, insulating, rubber, 0.875 ID -25 131-0608-00 33 TERMINAL, pin, 0.365 inch long -26 214-0973-00 1 HEATSINK, transistor -27 1 1 RESISTOR, variable (ATTACHING PARTS) (ATTACHING PARTS) -28 210-0583-00 1 NUT, hex., 0.25-32 x 0.312 inch -29 210-0940-00 1 WASHER, flat, 0.25 ID x 0.375 inch OD -30 210-0046-00 1 WASHER, lock, 0.261 ID x 0.40 inch OD -31 386-2433-00 1 SUPPORT, resistor -32		355-0046-00			1	STUD, plastic
22 includes: 355-0046-00 1 355-0046-00 1 23 358-0214-00 -24 210-0966-00 -25 131-0608-00 -26 214-0973-00 -27 - -26 214-0973-00 -27 - -28 210-0583-00 -29 210-0940-00 1 NUT, hex., 0.25-32 x 0.312 inch -29 210-0940-00 1 WASHER, flat, 0.25 ID x 0.375 inch OD -30 210-0046-00 1 WASHER, lock, 0.261 ID x 0.40 inch OD -31 386-2433-00 -32 - -33 260-1208-00 -34 361-0384-00	-22	124-0118-00			ī	STRIP, ceramic, 1 notch
355-0046-00 1 STUD, plastic -23 358-0214-00 10 BUSHING, insulator -24 210-0966-00 1 WASHER, insulating, rubber, 0.875 ID -25 131-0608-00 33 TERMINAL, pin, 0.365 inch long -26 214-0973-00 1 HEATSINK, transistor -27 1 1 RESISTOR, variable (ATTACHING PARTS) 1 NUT, hex., 0.25-32 x 0.312 inch -29 210-0583-00 1 NUT, hex., 0.25-32 x 0.312 inch -30 210-0046-00 1 WASHER, flat, 0.25 ID x 0.375 inch OD -31 386-2433-00 1 SUPPORT, resistor -32 1 4 RESISTOR, variable -33 260-1208-00 1 SWITCH, pushx10 MAG (ATTACHING PARTS) -34 361-0384-00 2	~~				_	strip includes:
-23 358-0214-00 10 BUSHING, insulator -24 210-0966-00 1 WASHER, insulating, rubber, 0.875 ID -25 131-0608-00 33 TERMINAL, pin, 0.365 inch long -26 214-0973-00 1 HEATSINK, transistor -27 - - - 1 -27 - - - 1 -28 210-0583-00 1 NUT, hex., 0.25-32 x 0.312 inch -29 210-0940-00 1 WASHER, flat, 0.25 ID x 0.375 inch OD -30 210-0046-00 1 WASHER, lock, 0.261 ID x 0.40 inch OD -31 386-2433-00 1 SUPPORT, resistor -32 - - - 4 -33 260-1208-00 1 SWITCH, pushX10 MAG (ATTACHING PARTS) - 3 361-0384-00 -34 361-0384-00 2 SPACER, pushbutton switch, 0.133 inch long		355-0046-00			1	STUD, plastic
-24 210-0966-00 1 WASHER, insulating, rubber, 0.875 ID -25 131-0608-00 33 TERMINAL, pin, 0.365 inch long -26 214-0973-00 1 HEATSINK, transistor -27 1 1 RESISTOR, variable (ATTACHING PARTS) -28 210-0583-00 1 NUT, hex., 0.25-32 x 0.312 inch -29 210-0940-00 1 WASHER, flat, 0.25 ID x 0.375 inch OD -30 210-0046-00 1 WASHER, lock, 0.261 ID x 0.40 inch OD -31 386-2433-00 1 SUPPORT, resistor -32 1 4 RESISTOR, variable -33 260-1208-00 1 SWITCH, pushX10 MAG (ATTACHING PARTS) -34 361-0384-00 2	-23	358-0214-00		1	0	BUSHING, insulator
-25 131-0608-00 33 TERMINAL, pin, 0.365 inch long -26 214-0973-00 1 HEATSINK, transistor -27 1 1 RESISTOR, variable (ATTACHING PARTS) (ATTACHING PARTS) -28 210-0583-00 1 NUT, hex., 0.25-32 x 0.312 inch -29 210-0940-00 1 WASHER, flat, 0.25 ID x 0.375 inch OD -30 210-0046-00 1 WASHER, lock, 0.261 ID x 0.40 inch OD -31 386-2433-00 1 SUPPORT, resistor -32 1 4 RESISTOR, variable -33 260-1208-00 1 SWITCH, pushX10 MAG -34 361-0384-00 2 SPACER, pushbutton switch, 0.133 inch long	-24	210-0966-00		_	1	WASHER, insulating, rubber, 0.875 ID
-26 214-0973-00 1 HEATSINK, transistor -27 1 1 RESISTOR, variable (ATTACHING PARTS) -28 210-0583-00 1 NUT, hex., 0.25-32 x 0.312 inch -29 210-0940-00 1 WASHER, flat, 0.25 ID x 0.375 inch OD -30 210-0046-00 1 WASHER, lock, 0.261 ID x 0.40 inch OD -31 386-2433-00 1 SUPPORT, resistor -32 1 4 RESISTOR, variable -33 260-1208-00 1 SWITCH, pushX10 MAG (ATTACHING PARTS) -34 361-0384-00 2 SPACER, pushbutton switch, 0.133 inch long	-25	131-0608-00		3	3	TERMINAL, pin, 0.365 inch long
-27 1 1 RESISTOR, variable (ATTACHING PARTS) -28 210-0583-00 1 NUT, hex., 0.25-32 x 0.312 inch -29 210-0940-00 1 WASHER, flat, 0.25 ID x 0.375 inch OD -30 210-0046-00 1 WASHER, lock, 0.261 ID x 0.40 inch OD -31 386-2433-00 1 SUPPORT, resistor -32 1 4 RESISTOR, variable -33 260-1208-00 1 SWITCH, pushX10 MAG (ATTACHING PARTS) -34 361-0384-00 2 SPACER, pushbutton switch, 0.133 inch long	-26	214-0973-00	_		1	HEATSINK, transistor
(ATTACHING PARTS) -28 210-0583-00 1 NUT, hex., 0.25-32 x 0.312 inch -29 210-0940-00 -30 210-0046-00 -31 386-2433-00 -32 -33 260-1208-00 -34 361-0384-00 2 SPACER, pushbutton switch, 0.133 inch long	-27		L		1	RESISTOR, variable
-28 210-0583-00 1 NUT, hex., 0.25-32 x 0.312 inch -29 210-0940-00 1 WASHER, flat, 0.25 ID x 0.375 inch OD -30 210-0046-00 1 WASHER, lock, 0.261 ID x 0.40 inch OD -31 386-2433-00 1 SUPPORT, resistor -32 1 4 RESISTOR, variable -33 260-1208-00 1 SWITCH, pushX10 MAG (ATTACHING PARTS) -34 361-0384-00 2 SPACER, pushbutton switch, 0.133 inch long						(ATTACHING PARTS)
-29 210-0940-00 1 WASHER, flat, 0.25 ID x 0.375 inch OD -30 210-0046-00 1 WASHER, lock, 0.261 ID x 0.40 inch OD -31 386-2433-00 1 SUPPORT, resistor -32 1 4 RESISTOR, variable -33 260-1208-00 1 SWITCH, pushX10 MAG (ATTACHING PARTS) -34 361-0384-00 2 SPACER, pushbutton switch, 0.133 inch long	-28	210-0583-00			1	NUT, hex., 0.25-32 x 0.312 inch
-30 210-0046-00 1 WASHER, lock, 0.261 ID x 0.40 inch OD -31 386-2433-00 1 SUPPORT, resistor -32 1 4 RESISTOR, variable -33 260-1208-00 1 SWITCH, pushX10 MAG (ATTACHING PARTS) -34 361-0384-00 2 SPACER, pushbutton switch, 0.133 inch long	-29	210-0940-00			1	WASHER, flat, 0.25 ID x 0.375 inch OD
-31 386-2433-00 -32 1 -33 260-1208-00 -34 361-0384-00 1 SUPPORT, resistor 4 RESISTOR, variable 1 SWITCH, pushX10 MAG (ATTACHING PARTS) 2 SPACER, pushbutton switch, 0.133 inch long	-30	210-0046-00			1	WASHER, lock, 0.261 ID x 0.40 inch OD
-32 4 RESISTOR, variable -33 260-1208-00 1 SWITCH, pushX10 MAG (ATTACHING PARTS) -34 361-0384-00 2 SPACER, pushbutton switch, 0.133 inch long	-31	386-2433-00			1	SUPPORT, resistor
-33 260-1208-00 1 SWITCH, pushX10 MAG (ATTACHING PARTS) -34 361-0384-00 2 SPACER, pushbutton switch, 0.133 inch long	-32		L		4	RESISTOR, variable
(ATTACHING PARTS) -34 361-0384-00 2 SPACER, pushbutton switch, 0.133 inch long	-33	260-1208-00			1	SWITCH, pushX10 MAG
	-34	361-0384-00			2	(ATTACHING PARTS) SPACER, pushbutton switch, 0.133 inch long

l See Electrical Parts List for part number.

		FIG	URE 2	CI	IRCUIT BOARDS (cont)
Fia. &				Q	
Index	Tektronix	Serial/Model	No.	t	Description
No.	Part No.	Eff Disc		у	
2-35	260-1421-00	na na far an ann an Annaichte ann ann an Annaichte an Annaichte		1	SWITCH, pushBEAM FIND
-36	361-0385-00			2	SPACER, pushbutton switch, 0.164 inch long
-37	337-1759-00	-		1	SHIELD, electrical
-38		T		1	MULTIPLIER (ATTACHING PARTS)
-39	220-0661-00			2	NUT, self-locking, hex., 8-32 x 0.344 inch (ATTACHING PARTS)
-40	211-0116-00			8	SCREW, sems, 4-40 x 0.312 inch, PHB
-41	384-1174-00			1	SHAFT, extension, 1.80 inches long
-42	384-1179-00			1	SHAFT, extension, 9.312 inches long
-43	384-1187-00			1	SHAFT, extension, 3.4 inches long
-44	384-1173-00			1	SHAFT, extension, 1.90 inches long
-45	384-1101-00			2	SHAFT, extension, 4.14 inches long
-46	384-1149-00			1	SHAFT, extension, 7 inches long
-47	376-0051-00			3	COUPLING, flexible
				_	each coupling includes:
	213-0022-00			4	SETSCREW, $4-40 \times 0.188$ inch. HSS
-48	376-0029-00			2	COUPLING, shaft, rigid
				-	each coupling includes:
	213-0022-00			2	SETSCREW, $4-40 \times 0.188$ inch. HSS
-49	407-1133-00			ī	BRACKET, power switch (ATTACHING PARTS)
-50	210-0406-00			2	NUT, hex., $4-40 \times 0.188$ inch
-51	210-0994-00			2	WASHER, flat, 0.125 ID x 0.25 inch OD
	200-1526-00	XB030000		1	COVER, switch hole (not shown)
-52	260-1300-01			1	SWITCH, slideLINE (ATTACHING PARTS)
-53	211-0007-00			2	SCREW, 4-40 x 0.188 inch, PHS
-54	260-0834-00			1	SWITCH, togglePOWER (ATTACHING PARTS)
-55	210-0562-00			1	NUT, hex., 0.25-40 x 0.312 inch
-56	210-0046-00			1	WASHER, lock, internal, 0.261 ID x 0.40 inch OD
-57		1		1	CIRCUIT BOARD ASSEMBLYTRIG VIEW All
_ = 0				-	Circuit Doard assembly includes:
-58	130-032/-01 214-0972-00			4	SOCKET, pin terminal, 0.06/ inch diameter
-60	126-0252-04		-	1.2	REATBING, TRANSISTOR
-00	211 0116 00		-	.2	(ATTACHING PARTS)
-0T	∠TT-0TT0-00			T	SCREW, sems, 4-40 x 0.312 inch, PHB

¹See Electrical Parts List for part number.

₿

Fig. &			Q	
Index	Tektronix	Serial/Model	No. t	Description
No.	Part No.	Eff Disc	у	
2-62	214-1756-00)	1	ACTUATOR, power switch
-63	384-1159-00		ī	SHAFT, extension
-64		1	ī	CTRCUIT BOARD ASSEMBLYTRIG GEN & SWP LOGIC AS
04			-	circuit board assembly includes:
-65	131-1003-00		6	RECEDENCLE coavial cable
-66	214-0579-00		1	TERMINAL test point
-67	131-0566-00		1	LINK terminal connecting
-69	121-0500-00		1	TERMINAL pip 0.71 inch long
-00	131-0608-00		12	TERMINAL, pin, 0.71 men jong
- 60	136-0252-04		1/9	SOCKET connector pin 0 181 inch long
-09	255-0175-00		140	Sources, connector pin, 0.101 inch long
-70	126-0400-14	,	2	SIOD, press mount, 4-40 x 0.55 men rong
-71	136-0499-14		1	SOCKET, circuit board, 14 contact
72	120-0411-00		÷	BOST have 0 215 inch long
-/3			1	POST, nex., 0.515 inch long
-/4	200-116/-00		2	UOLDED Jam
-/5	352-0331-00		3	HOLDER, IAMP
-/6	131-1031-00		23	CONTACT ASSEMBLY, COP
			,	(ATTACHING PARTS FOR EACH)
-//	210-0//9-00		T	RIVET, tubular
70	206 2276 00		-	
-/8	386-2376-00		Ţ	PLATE, lever mounting
-79	210-065/-01	•	2	EYELET
	105-0401-00		T	ACTUATOR ASSEMBLY, SIIde SWITCHB SOURCE
~ ~			-	actuator assembly includes:
-80	105-0417-00		1	ACTUATOR, Switch, Slide
-81	351-0355-00	2	1	GUIDE, Switch, slide
-82	214-1126-00	2	-	SPRING, flat, gold
	214-1126-01	2	-	SPRING, flat, green
	214-1126-02	-	_	SPRING, flat, red
-83	214-1127-00		2	ROLLER, detent
-84	376-0142-00		Ţ	COUPLER, slide to shaft
	213-0048-00		1	SETSCREW, $4-40 \times 0.125$ inch, HSS (not shown)
	105-0400-00		1	ACTUATOR ASSEMBLY, slide switchA SOURCE
		•	-	actuator assembly includes:
-85	105-0418-00		1	ACTUATOR, switch, slide
-86	351-0355-00	2	T	GUIDE, switch, slide
-87	214-1126-00	2	-	SPRING, flat, gold
	214-1126-01	2	-	SPRING, flat, green
	214-1126-02	-	-	SPRING, flat, red
-88	214-1127-00		2	ROLLER, detent
-89	376-0142-00		Ţ	COUPLER, slide to shaft
	213-0048-00		1 Q	SETSCREW, 4-40 X 0.125 inch, HSS
	105-0399-00		2	ACTUATOR ASSEMBLY, SIIde SWITCHCOUPLING
~~			-	each actuator assembly includes:
-90	105-0419-00		Ţ	AUTUATUK, SWITCH, SIIGE
-91	351-0355-00	2	T	GUIDE, SWITCH, SIIGE CDRING flat gold
-92	214-1126-00	2	-	SPRING, IIal, 9010 SPRING flat groop
	214-1126-01	2	-	SPRING, IIac, Green SDDING flat rod
0.2	214-1120-02		-	DOILED dotont
-93	214-112/-00	1	2	KOTTER' GECENC

¹See Electrical Parts List for part number.
²Replace only with part bearing the same color code as the original part in your instrument.

₿

		FIGURE	2 CI	RCUIT BOARDS (cont)
Fig. &			Q	
Indax	Taktronix	Serial/Model No	+	• • • •
No.	Part No.	Eff Disc	у У	Description
2-94	376-0142-00	0	1	COUPLER, slide to shaft
-95	213-0048-00	0	ī	SETSCREW, $4-40 \times 0.125$ inch. HSS
-96	384-1160-00	- -	4	SHAFT, extension, lever switch
-97	214-1770-00	- 0	4	LEVER, slide switch
21	214 1//0 00	5	*	(ATTACHING PARTS)
-98	354-0165-00	n	2	RING, retaining
20		6	-	(ATTACHING PARTS)
-99	211-0116-00	0	3	SCREW, sems, 4-40 x 0.312 inch, PHB
_100		_1	٦	
-100		_	Ŧ	circuit board accombly includes.
		-	-	ACTUATION ACCEMPTY ACCIDENTS:
	102-0300-00	U	T	ACTUATOR ASSEMBLY, Cam Switch-TIME/CM
1 ^ 1		-	-	actuator assembly includes:
-101	200-1419-00	U	T	COVER, Cam Switch
			~	(ATTACHING PARTS)
-102	211-0008-0	U	6	SCREW, $4-40 \times 0.25$ inch, PHS
-103	210-0004-0	0	6	WASHER, lock, internal, 0.12 ID x 0.26 inch OE
	210-0406-0	0	5	NUT, hex., 4-40 x 0.188 inch (not shown)
-104	131-0963-0	0	2	CONTACT, electrical, grounding
-105	354-0391-0	0	2	RING, retaining
-106	401-0081-02	2	1	BEARING, cam switch, front
-107	214-1139-0	02	_	SPRING, flat, gold
	214-1139-02	22	-	SPRING, flat, green
	214-1139-0	32	_	SPRING, flat, red
-108	214-1127-0	0	4	ROLLER, detent
-100	105 - 0365 - 01		1	ACTUATOR, cam switch, front
_110	401-0115-0	0	1	BEARING cam switch center
_111	105-0364-0	0	1	ACTUATOR can switch roar
-112	401-0091-0	4	1	PEADING cam switch front w/incort
112	401-0081-0	4 0	1	SEARING, Cam Switch, Hont, W/HISELL
-113		0		STOP ASSEMBLI, Call Switch
-114	210-0406-0	0	5	(ATTACHING PARTS)
-115	211-0116-0	0	6	SCREW, sems, 4-40 x 0.312 inch, PHB
-116	131-0604-0	0	29	CONTACT, electrical, spring
-117		_1	1	RESISTOR, variable (ATTACHING PARTS)
-118	361-0515-0	0	1	SPACER, switch, plastic
-119	376-0039-0	0	1	COUPLING, shaft
	212 0075 0	-	-	$CEMECREW = 4-40 \times 0.004 \text{ inch WSS}$
120	213-0075-0	0	2	SEISCREW, 4-40 X 0.094 INCH, DSS
-120	260-1422-0	U	Т	(ATTACHING PARTS)
-121	361-0411-0	0	4	SPACER, pushbutton switch
-122	384-1068-0	0	1	SHAFT, extension, 8 inches long
-123	352-0331-0	0	2	HOLDER, lamp
-124	260-1423-0	0	1	SWITCH, pushbuttonHORIZ DISPLAY (ATTACHING PARTS)
-125	361-0385-0	0	4	SPACER, pushbutton switch

1
2See Electrical Parts List for part number.
2Replace only with part bearing the same color code as the original part in
your instrument.

Fig. &			Q	
Index	Tektronix	Serial/Model	No. t	Description
No.	Part No.	Eff Disc	у	
2-126	126-0252-04		6	SOCKET nin connector 0 181 inch long
127	121-1261-00		20	CONTRACT clostrical fraction
-12/	131-1201-00		20	(AMMACITAL, I-Shape
1 0 0	211 0110 00		,	(ATTACHING PARIS)
-128	211-0116-00		Ţ	SCREW, Sems, 4-40 X 0.312 Inch, PHB
-129	129-0386-00		T	POST, hex., 1.613 inches long
120	204-1126-00		2	SUNFT ortonsion 0.95 inch long
-10	<u> </u>		כ ו	DRACKET CRT shield room
-131	407-1128-00		T	BRACKET, CRI SHIELQ, IEdi
_ 1 2 2	211-0507-00		2	(ATTACHING PARTS)
-132	211-0507-00		2	$\frac{1}{100} = \frac{1}{100} \times \frac{1}$
-133	210-0803-00		2	WASHER, HIAC, 0.15 ID X 0.375 INCH OD
-134	210-0202-00		2	LUG, Solder, SE #6
-135	220-0419-00		3	NUT, square, $6-32 \times 0.312$ inch
-136	211-0590-00		1	SCREW, $6-32 \times 0.25$ inch, PHS
1 2 7	200-1450-00		1	
-13/	200-1459-00		+	(AMTACHING DADTE)
1 2 0	211-0000-00		2	$COPEW A=A0 \times 0.25 \text{ inch } PUS$
-138	211-0008-00		2	SCREW, $4-40 \times 0.25$ inch, FHS
-139	386-2246-00		1	SUPPORT, CRT, rear
-140	348-0145-00		ī	GROMMET, u-shape
_141	337-1644-00		ī	SHIELD SECTION, CRT, neck
-142	557 1044 00	1	ī	COIL y avis
-142	242-0217-00		1	CLAMP coil plastic
-142	545-0217-00		-	(ATTACHING PARTS)
-144	211-0147-00		2	SCREW, $4-40 \times 0.25$ inch. PHS
-145	210-0994-00		2	WASHER, flat, 0.125 ID x 0.25 inch OD
110	210 0001 00	_	-	*
-146		1	1	CIRCUIT BOARD ASSEMBLYVERT OUTPUT A5
			-	circuit board assembly includes:
	129-0320-00	_XB040000	1	POST, press mount
-147		¹ B010100 B03	9999X 1	INTEGRATED CIRCUIT
-148	407-1149-00	B010100 B03	9999X 1	BRACKET, integrated circuit, grounding
-149	131-0608-00	B010100 B03	9999 5	TERMINAL, pin
147	131-0608-00	B040000	4	TERMINAL, pin
-150	136-0252-01	2010010	2	SOCKET, pin connector, 0.178 inch long
100	136-0252-04	B010100 B03	9999 17	SOCKET, pin connector, 0.181 inch long
	136-0252-04	B040000	31	SOCKET, pin connector, 0.181 inch long
	150 0252 04	2010000	02	(ATTACHING PARTS)
-151	211-0116-00	B010100 B03	9999 1	SCREW, sems, 4-40 x 0.312 inch, PHB
	211-0116-00	B040000	2	SCREW, sems, 4-40 x 0.312 inch, PHB
-152	220-0456-00	B010100 B03	9999X 1	NUT, hex., 6-32 x 0.25 inch
-153	210-1092-00	B010100 B03	9999X 1	WASHER, flat, 0.147 ID x 0.312 inch OD
-154	361-0008-00	B010100 B03	99999x 3	SPACER, plastic
	211-0130-00	XB040000	1	SCREW, $4-40 \times 0.25$ inch, HSS

¹See Electrical Parts List for part number.

₿

Fig. &				Q	
Index	Tektronix	Serial/M	odel No.	t	Description
No.	Part No.	Eff	Disc	У	
2-	644-0048-00	ХВ04000)	1	BRACKET ASSEMBLY, vertical output
		-		-	bracket assembly includes:
	214-1138-00	XB040000		2	HEATSINK, insulator
	352-0062-00) XB04000) -	2	HOLDER, transistor heatsink (ATTACHING PARTS FOR EACH)
	211-0033-00) XB040000)	2	SCREW, 4-40 x 0.312 inch, PHS, w/lock washer
	211-0012-00) XB040000)	2	SCREW, $4-40 \times 0.375$ inch, PHS
	210-0004-00) XB040000)	3	WASHER, lock, internal, #4
	210-0406-00) XB04000)	4	NUT, hex., 4-40 x 0.188 inch
	343-0097-00) XB040000)	2	CLAMP, transistor heatsink
	210-0717-00) XB040000)	2	RIVET
	210-0599-00) XB040000)	4	NUT, sleeve, 0.375-32 x 0.562 inch
	214-0368-00) XB040000)	2	SPRING, transistor heatsink holder
	131-0761-00) XB040000)	1	TERMINAL POST
	210-0205-00) XB040000)	1	LUG, solder, SE #8
	407-1389-00) XB040000)	1	BRACKET, heatsink
					(ATTACHING PARTS)
	211-0130-00	XB04000)	2	SCREW, $4-40 \times 0.25$ inch, HSS
-155		_1		1	CIRCUIT BOARD ASSEMBLYVERT MODE A4
		-		_	circuit board assembly includes:
-156	352-0331-00)		2	HOLDER, lamp
-157	260-1424-01			ī	SWITCH, pushbuttonVERT MODE
150		-		-	(ATTACHING PARTS)
-120	361-0411-00)		4	SPACER, pushbutton switch
-159	131-0608-00	1 I		<u>g</u>	TERMINAL Din
-160	136-0252-04	, I		12	SOCKET nin connector 0 181 inch long
-161	175-0828-00	1)	-	F+	WIRE electrical 5 wire ribbon 4 75 inches
101	1/5 0020 00	,			(ATTACHING PARTS)
-162	211-0116-00)		6	SCREW, sems, 4-40 x 0.312 inch. PHB
1.00		1		Ţ	
-103		-		T	CIRCUIT BOARD ASSEMBLYVERT PREAMP A3
	105-0421-00	-		-	CITCUIT DOARD ASSEMBLY INCLUDES:
	105-0421-00	, -		T _	ACTUATOR ASSEMBLY, SIIde SWITCHMOMENTARY
-164	105-0420-00	-		1	ACTUATOR clide switch
-165	214-1779-00			1	CDDING holigal
-166	351-0359-00			1	CUIDE switch slide
100	105-0423-00			1	ACTILATOR ASSEMBLY slide switchRANDWIDTH ITMIT
		-		-	actuator assembly includes.
-167	213-0048-00	า		٦	SETSCREW $A=40 \times 0.125$ inch HSS
-168	376-0146-00	, ,		î	COUDLER chaft
-169	105-0422-00	, 1		î	ACTUATOR, slide switch
-170	351-0355-00	ń		ī	GUIDE, switch slide
-171	214-1126-00	52		-	SPRING, flat, gold
- / -	214-1126-01	2		_	SPRING flat, green
	214-1126-01	52		_	SDRING, IIac, green SDRING flat rod
-170	214 1120-02	-		2	POLLEP detent
112		,		4	NOLLEN, GECENC

¹See Electrical Parts List for part number.
²Replace only with part bearing the same color code as the original part in your instrument.

1

9-2 9-2

1998

₿

Fig. &			G	
Index	Tektronix	Serial/Model	No. t	Description
No.	Part No.	Eff Disc	у	1 2 3 4 5
2-173	131-0344-00		2	CONNECTOR feed-thru
-174	358-0176-00		2	BUSHING, plastic
-175	131-1003-00		q	CONNECTOR, plug, electrical
-176	200-0945-01		6	COVER HALF, transistor, 2-56 thread
-177	200-0945-00		6	COVER HALF, transistor
			0	(ATTACHING PAPES FOR FACH)
-178	211-0062-00		1	SCREW 2-56 x 0 312 inch DUS
			*	
-179	136-0252-01		2	SOCKET, pin connector, 0.178 inch long
272	136-0252-04		153	SOCKET, pin connector, 0.181 inch long
-180	352-0134-00		100	HOLDER, coil
-181	214-0506-00		ī	TERMINAL, pip. 0.375 inch long
-182	214-0579-00		12	TERMINAL, test point
-183	131-0608-00		1	TERMINAL, pip. 0.365 inch long
-184	131-1030-00		Ā	CONTACT ASSEMBLY cam switch bottom
104	131-1031-00		5	CONTACT ASSEMBLY cam switch top
-185	210-0779-00		6	RIVET, tubular, 0.115 inch long
-186	260-1208-00		1	SWITCH, pushbuttonINVERT
200	200 2200 00		-	(ATTACHING PARTS)
-187	361-0411-00		2	SPACER, pushbutton switch
207	501 0411 00		~	
-188		1	2	RESISTOR, variable
-189		1	2	RESISTOR, variable, w/switch
105			-	(ATTACHING PARTS FOR FACH)
-190	361-0515-00		1	SPACER, switch, plastic
270			-	(ATTACHING PARTS)
-191	211-0116-00		2	SCREW, sems, $4-40 \times 0.312$ inch. PHB
	131-1428-00	XB040000	1	CLIP, ground
	129-0413-00	XB040000	ī	POST, stud. 0.62 inch long
	210-1002-00	XB040000	ī	WASHER, flat, 0.125 ID x 0.25 inch OD
			-	
-192	384-1059-00		4	SHAFT, extension, 6,581 inches long
-193	384-1162-00		1	SHAFT, extension, w/knob, 11.42 inches long
-194	384-1129-00		6	SHAFT, extension
-195	384-1149-00		2	SHAFT, extension, 7 inches long
-196	384-1180-00		2	SHAFT, extension, 6.40 inches long
-197	376-0029-00		2	COUPLING, shaft, rigid
			_	each coupling includes:
	213-0075-00		2	SETSCREW, 4-40 x 0.94 inch, HSS
-198	376-0051-00		2	COUPLING, flexible
			-	each coupling includes:
	213-0022-00		2	SETSCREW, 4-40 x 0.188 inch, HSS
-199	346-0102-00		1	STRAP, grounding
				(ATTACHING PARTS)
-200	211-0116-00		1	SCREW, sems, 4-40 x 0.312 inch, PHB
		1	_	
-201		-	2	CIRCUIT BOARD ASSEMBLYCH 1 & CH 2 ATTEN A1 &
			-	each circuit board assembly includes:
-202	105-0243-00		1	LEVER, Switch-AC DC
			-	(ATTACHING PARTS)
-203	213-0214-00		1	SCREW, $2-56 \times 0.375$, CAP SOC

¹See Electrical Parts List for part number.

		E	FIGURE	2 CII	RCUIT BOARDS (cont)
Fig. &				0	
Index	Tektronix	Serial/Mo	del No	+	
No	Part No	Eff C			Description
110.	Fall INO.			Y	1 2 3 4 5
2-204	131-0963-00			2	CONTACT, electrical, grounding
-205	354-0391-00	I.		2	RING, retaining
-206	210-0406-00	I		10	NUT, hex., $4-40 \times 0.188$ inch
-207	401-0081-02			1	BEARING, cam switch, front
					(ATTACHING PARTS)
-208	211-0097-00	I		2	SCREW, 4-40 x 0.312 inch, PHS
-209	210-0004-00	I		2	WASHER, lock, internal, 0.12 ID x 0.26 inch OD
					*
-210	214-1127-00	.		4	ROLLER, detent
-211	214-1139-00	1		-	SPRING, flat, gold
	214-1139-02	1		-	SPRING, flat, green
	214-1139-03	,T		-	SPRING, flat, red
-212	105-0282-00	ł		1	DRUM, cam switch
-213	401-0115-00)		1	BEARING, cam switch, center
-214	105-0342-00)		1	ACTUATOR, cam switch
-215	401-0081-02			1	BEARING, cam switch, front
	136-0333-00	1		. 1	SOCKET, pin connector
-216	136-0252-01			12	SOCKET, pin connector, 0.178 inch long
-217	131-1354-00)		2	LINK, terminal connecting
-218	337-1406-00	1		1	SHIELD, electrical, cam contact
-219	131-1030-00			6	CONTACT ASSEMBLY, cam switch, bottom
	131-1031-00			8	CONTACT ASSEMBLY, cam switch, top
-220	441-1095-00			1	CHASSIS, attenuator
					(ATTACHING PARTS)
-221	211-0001-00			2	SCREW, 2-56 x 0.25 inch, PHS
	210-0938-00			1	WASHER, flat, 0.109 ID x 0.25 inch OD
-222	210-0053-00			2	WASHER, lock, split, 0.092 ID x 0.175 inch OD
-223	210-1008-00)		2	WASHER, flat, 0.90 ID x 0.188 inch OD
-224	210-0405-00			2	NUT, hex., 2-56 x 0.188 inch
-225	129-0299-00			4	POST, hex., 0.333 inch long
-226	210-0004-00)		4	WASHER, LOCK, Internal, U.12 ID X U.26 INCh OD
	210 0261 00	DO10100	D01067		
-22/	210-0261-00	BOLOIOO	BOTOP/	91	LUG, SOIDER WRGWRD, flat, 0,125 TD w 0,25 imah OD
220	210-0994-00	BOTOPSO		, T	WASHER, FLAT, 0.125 ID X 0.25 INCH OD
-228	200-1438-00)		Ŧ	COVER, Chassis, attenuator
_ 220	212-0055-00	`		2	(ATTACHING PARTS) CODEW thread forming 2-22 x 0 199 inch DUG
-229	213-0035-00)		2	SCREW, United torming, $2-32 \times 0.100$ inch, Ph5 WASHER flat 0 100 TD \times 0 25 inch OD
-230	211-0008-00			1	WASHER, HIAC, 0.105 HD x 0.25 HeH OD SCREW $4-40 \times 0.25$ inch DUS
-231	211-0008-00	,		4	WASHER, flat, 0.125 Inch, rhs
252	210 0004 00	•		-	= *
-233	131-0679-00)		1	CONNECTOR, electrical, BNC, w/hardware
				-	(ATTACHING PARTS)
-234	220-0569-00)		1	NUT, knurled, 0.50×0.235 inch
-235	361-0424-00)		1	SPACER, ring
					(ATTACHING PARTS)
-236	211-0116-00)		3	SCREW, sems, 4-40 x 0.312 inch, PHB
-237	210-0586-00)		3	NUT, keps, 4-40 x 0.25 inch

¹Replace only with part bearing the same color code as the original part in your instrument.
Fig. & Index No.	Tektronix Part No.	Serial/M Eff	odel No. Disc	Q t y	Description
2-238	337-1804-00			2	SHIELD, electrical, attenuator
-239	175-0825-00			ft	WIRE, electrical, 2 wire ribbon, 29.5 inches
-240	175-0826-00			f+	WIRE, electrical, 3 wire ribbon, 3.5 inches
-241	175-0827-00			f+	WIRE, electrical, 4 wire ribbon, 4 inches
-242	175-0828-00	B010100	B039999	f+	WIRE, electrical 5 wire ribbon 13 inches
676	175-0828-00	B040000	0000000	£+	WIRE, electrical, 5 wire ribbon, 15 inches
-243	175-0831-00	B040000			WIRE, electrical, 5 wire ribbon, 10.5 inches
-245	210-0774-00			1 L 2	EVELET motollig 0 152 inches
-244	210-0774-00			2	EIELET, metallic, 0.152 inch OD
-245	210-07/5-00			3	EYELET, metallic, 0.126 inch OD
-246	131-0707-00			46	CONNECTOR, terminal
	131-0371-00			2	CONNECTOR, terminal (large)
-247	131-0472-01			4	CONNECTOR, pin, female
-248	352-0169-00			4	HOLDER, terminal connector, 2 wire
-249	352-0161-00			1	HOLDER, terminal connector, 3 wire
-250	352-0162-00	B010100	в039999	1	HOLDER, terminal connector, 4 wire
	352-0162-00	B040000		2	HOLDER, terminal connector, 4 wire
-251	352-0163-00	B010100	в039999	3	HOLDER, terminal connector, 5 wire
	352-0163-00	B040000		2	HOLDER, terminal connector, 5 wire
-252	352-0166-00	2010000		2	HOLDER terminal connector 8 wire
252	225 0100-00			2	nonder, cerminal connector, o wile

and the second

۲

FIGURE 2 CIRCUIT BOARDS (cont)

.

Fig. &				Q
Index	Tektronix	Serial/N	Nodel No.	t
No.	Part No.	Eff	Disc	У
3-1	437-0141-00			1
				-
-2	348-0080-01			4
-3	200-1412-00			1
-4	200-0602-01			2
-5	367-0140-03			1
				-
-6	211-0512-00			4
-7	214-0516-00			2
-8	214-0513-00			2
-9	214-0515-00			2
				-
-10	213-0182-00			1
-11	210-0805-00			1

∔⊗

y 1 2 3 4 5 Description

CABINET, oscilloscope cabinet includes: FOOT, cabinet COVER, front COVER, handle latch HANDLE, carrying mounting hardware: (not included w/handle) SCREW, 6-32 X 0.50 inch, 100° csk, FHS

SPRING, handle index INDEX, handle ring INDEX HANDLE, hub mounting hardware for each: (not included w/index handle) SCREW, 0.25-20 X 0.75 inch, Cap HS WASHER, flat, 0.204 ID X 0.438 inch OD



465 OSCILLOSCOPE



Fig. &				Q			
Index	Tektronix	Serial/M	lodel No.	t			
No.	Part No.	Eff	Disc	У	123	345	Description
				ST	ANDAR	D	
4-1	016-0535-02			1	POUCH	H, acces	ssory, w/hdwr
-2	016-0537-00			1	POUCH	H, acces	ssory, w/zipper
-3	010-6065-03			2	PROBE	EPACK	KAGE
-4	337-1674-01			1	SHIEL	D, imp	losion, clear
-5	134-0016-01			1	PLUG,	tip, w/	binding post
-6	003-0301-00			1	TOOL,	alignm	nent
-7	159-0016-00			2	FUSE,	1.5A, 1	fast-blo
	159-0042-00			2	FUSE,	0.75Å	, fast-blo
	070-1331-00			1	MANU	AL, ins	struction (not shown)
	070-1331-00			1	MANU	AL, op	erators (not shown)



ELECTRICAL PARTS LIST AND SCHEMATIC CORRECTIONS

CHANGE TO:

C18	281-0626-00	3.3 pF, Cer, 500 V
C33	281-0182-00	1.8–10 pF, Var
C47	281-0182-00	1.8–10 pF, Var
C48	281-0182-00	1.8-10 pF, Var
C68	281-0626-00	3.3 pF, Cer, 500 V
C83	281-0182-00	1.8–10 pF, Var
C97	281-0182-00	1.8-10 pF, Var
C98	281-0182-00	1.8-10 pF, Var
CR 31	152-0153-00	Silicon, FD7003 or CD5574
CR32	152-0153-00	Silicon, FD7003 or CD5574
CR 81	152-0153-00	Silicon, FD7003 or CD5574
CR8 2	152-0153-00	Silicon, FD7003 or CD5574
R18	315-0361-00	360 Ω, 1/4 W, 5%
R21	315-0470-00	47 Ω, 1/4 W, 5%
R51	315-0470-00	47 Ω, 1/4 W, 5%
R68	315-0361-00	360 Ω, 1/4 W, 5%
R 67 6	315 - 0510 -00	51 Ω, 1/4 W, 5%
REMOVE		
100		

C103	281-0604-00	2.2	pF,	Cer,	500	V,	±0.25	pF
C203	281-0604-00	2.2	pF,	Cer,	5 0 0	V,	±0.25	рF

465 EFF SN B090000-up

	ELECTRICAL PARTS L	IST AND SCHEMATIC	CORRECTION
CHANGE TO:			
C1307	281-0500-00	2.2 pF, Cer, 500	v
C1327	281-0500-00	2.2 pF, Cer, 500	v
R516	321-0481-00	1 MΩ, 1/8 W, 1%	
REMOVE :			
C1469	281-0661-00	0.8 pF, Cer, 500	V, ±0.1 pF
ADD:			
R1315	315-0221-00	220 Ω, 1/4 W, 5%	
R1335	315-0221-00	220 Ω, 1/4 W, 5%	



M19,957/573

	ELECTRICAL PA	RTS LIST AND SCHEMATIC CORRECTION
CHANGE TO:		
A 9	670-2233 - 03	INTERFACE Circuit Board Assembly
C1512	290 - 0670 - 00	550 μ F x 100, Elect.
C1549	290 - 0529 - 00	47 μ F, Elect. 20 V
CR1514	152-0107-00	Silicon, TI60 or 1N647
VR1515	152 -0 268 -00	Zener, 1N979B, 0.4 W, 56 V, 5%
Q1534	151 - 0436 - 00	Silicon, NPN MJ2801
R1516	308 - 0363 - 00	3 kΩ, 8 W
REMOVE :		
C1434	283 - 0005 - 00	0.01 µF, Cer, 250 V, +100%-0%
CR1216	152 - 0141 - 02	Silicon, 1N4152
CR1513	152 -0 066 -00	Silicon, diffused, selected from 1N3194
VR1434	152 - 0247-00	Zener, 1N989B, 0.4 W, 150 V, 5%
VR1441	152 - 0283-00	Zener, 1N976V, 0.4 W, 43 V, 5%
Q1514	151 - 0506 - 00	SCR, 200 V, 4A, C106B2
R1441	302 - 0562 - 00	5.6 kΩ, 1/2 W, 10%
R1460	311 - 1373-00	5 kΩ, Var
R1513 R1512 R1515 ADD:	315-0222-00 316-0472-00 315-0102-00	2.2 kΩ, 1/4 W, 5% 4.7 kΩ, 1/4 W, 10% 1 kΩ, 1/4 W, 5%
C1427	283 - 0002 - 00	0.01 μF , Cer, 500 V
CR1218	152-0141-02	Silicon, 1N4152
CR1427	152 - 0107 - 00	Silicon, TI60 or 1N647
CR1516	152 - 0107 - 00	Silicon, TI60 or 1N647
Q1516	151-0311-01	Silicon, NPN, MJE240
Q1518	151 - 0347 - 00	Silicon, NPN, 2N5551
R1218	315 - 0152 - 00	1.5 kΩ, 1/4 W, 5%

M20,032/473

Page 2 of 4

ADD:

R1427	316-0106-00	10 MΩ, 1/4 W, 10%
R1460A	311-1538-00	
R1460B	311-1538-00	5 kΩ x 2.5 MΩ, dual
R1517	315-0200-00	20 Ω, 1/4 W, 5%
R1518	303-0203-00	20 kΩ, 1 W, 5%
R1519	315-0101-00	100 Ω, 1/4 W, 5%



M20,032/473





Vertical Output Amplifier Circuit Description

The Vertical Output Amplifier is a three-stage paraphase amplifier. The first stage consists of transistors Q402, Q406, Q412 and Q416. The low-frequency compensation network, a portion of the high-frequency compensation network, and the Vert Out Center adjustment are in this stage. The next stage consists of transistors Q432, Q462, Q442 and Q472 with a thermal compensation network consisting of thermistor RT448, resistor R453 and varicap CR434 and capacitor C444 plus the remaining high-frequency compensation network. The final stage consists of transistors Q468, Q482, Q478 and Q492 with a gain adjustment R466. Capacitors C464 and C474 are built into the printed circuit board by lead and run capacitance.

BEAM FINDER

The BEAM FINDER switch, when pressed, limits the current to the emitters of transistors Q432 and Q442. This reduces the gain of the total stage, limiting the display to the display area without affecting the position of the display.

SECTION 5 PART II - SHORT-FORM CALIBRATION

VERTICAL SYSTEM CALIBRATION

- 7. Adjust Vertical Output Centering
 - a. Connect DC Voltmeter between TP322 and TP324.
 - b. Adjust CH 1 POSITION for 0 volt reading on the meter.
 - c. ADJUST Vertical Output Centering, R429, to position the trace to the center graticule line.
- 8. Check BEAM FIND Operation
- 9. Adjust CH 1 Step Attenuator Balance
 - ADJUST CH 1 Step Atten Bal, R25, for no more than 0.2 division trace shift when switching between 5 mV, 10 mV and 20 mV.
 - ADJUST CH | Variable Balance, R120, for no more than
 l division trace shift when rotating the CH | VAR control through its range.
 - c. Check CH 1 UNCAL light.
- 10. Adjust CH 2 Step Attenuator Balance
 - ADJUST CH 2 Step Atten Bal, R75, for no more than 0.2 division trace shift when switching between 5 mV, 10 mV, and 20 mV.
 - ADJUST CH 2 Variable Balance, R220, for no more than
 l division trace shift when rotating the CH 1 VAR control through its range.

M20,159/573

- c. Check CH 2 UNCAL light.
- 11. Check Probe Indicator Light
 - a. Connect a X10 probe to CH 1 input.
 - b. Check that the left light goes out and the right light comes on.
 - c. Repeat procedure for CH 2.
- 12. Check CH 1 and 2 INPUT COUPLING Switch
- 13. Adjust CH 1 and 2 Position Centering
 - a. VOLTS/DIV switches to 50 mV INPUT COUPLING to AC
 - b. Connect a 2.4 division, 50 kHz signal from the Type 191
 Medium-Frequency Constant-Amplitude Signal Generator.
 - c. VOLTS/DIV switch to 5 mV.
 - d. ADJUST CH 1 Position Centering, R115, so the top and bottom of the display can be positioned past the center horizontal line.
 - e. Re-adjust R115 and R120 for minimum trace shift.
 - f. Repeat the above procedure for CH 2 adjust R215.
 - g. Re-adjust R215 and R220 for minimum trace shift.
- 14. Check CH 2 Invert Balance and Operation
- Adjust CH 1 and Vertical Output Gains
 a. CH 1 VOLTS/DIV to 5 mV.

- b. Connect 20 mV signal from Standard Amplitude Calibrator to CH l input.
- c. ADJUST CH 1 Gain, R118, for 200 mV push-pull signal between TP322 and TP324.
- d. ADJUST Vertical Output Gain, R466, for 4 divisions deflection.
- e. Check all attenuator ranges for proper deflection, within 3%.
- f. Check Variable Range: CH 1 VAR control must reduce a 5 division signal to less than 2 divisions.

16. Adjust CH 2 Gain

- a. CH 2 VOLTS/DIV to 5 mV
- b. Connect 20 mV signal from Standard Amplitude Calibrator to CH 2 input.
- c. ADJUST CH 2 Gain, R218, for 4 divisions deflection.
- d. Check all attenuator ranges for proper deflection, within 3%.
- e. Check Variable Range: CH 2 VAR control must reduce a 5 division signal to less than 2 divisions.

17. Check ADD Operation

- a. Both VOLTS/DIV to 5 mV Both INPUT COUPLING switches to DC
- b. Connect 10 mV from Standard Amplitude Calibrator to both CH inputs.
- c. Set VERT MODE to ADD.

- d. Check for 4 divisions deflection, within $\pm 3\%$ unadjusted, or within $\pm 0.5\%$ adjusted.
- 18. Check Compression and Expansion
 - a. With 2 division signal, position to top and bottom of graticule.
 - b. Check for no more than 0.1 division of compression or expansion.
- 19. Check Vertical Alternate Operation on All Sweep Speeds
- 20. Check Vertical CHOP Operation
 - a. TIME/DIV to 1 μs
 VERT MODE to CHOP
 - b. Check for blanking of transients at normal INTENSITY level.
 - c. Check duration of each cycle is about 4 divisions.
- 21. Adjust Vertical Output Low-Frequency Compensation
 - a. Connect the fast-rise output of the Square-Wave Generator (Type 106) to CH 1 input.
 - ADJUST R425, R426 for best flat-top waveform using 100 KHz signal.
- 22. Adjust VOLTS/DIV Compensation
 - Adjust CH 1 VOLTS/DIV Compensation for no more than 2%
 aberrations. Use 20 picofarad Normalizer and a 5 division
 signal at 1 KHz.

5 mV	C1
10 mV	Check
20 mV	Check
50 mV	C12, C13
.1 V	Check
.2 V	Check
.5 V	C10, C11
1 V	Check
2 V	Check
5 V	Check

b. Repeat procedure for CH 2.

23. Adjust Vertical Output High-Frequency Compensation

- a. VOLTS/DIV to 5 mV
 A TIME/DIV to 0.05 μs
- Adjust for a 5 division display from the Fast-Rise High Amplitude Pulse Generator (Type 109) to CH 2 input.
- c. ADJUST C77, C83, C205, R205, C249, R249, R427, R422,
 C422, R438, C438, for no more than 3% aberrations and
 a 3.5 nanosecond, or less, risetime.
- d. Check negative step aberrations, within 5%.
- e. CH 2 VOLTS/DIV to 10 mV
- f. ADJUST R97, C97, for aberrations within 3% and 3.5 nanosecond, or less, risetime.
- g. Check negative step aberrations, within 5%.
- h. CH 2 VOLTS/DIV to 20 mV

- ADJUST R98, C98, for aberrations within 3% and 3.5 nanosecond, or less, risetime.
- j. Check negative step aberrations, within 5%.
- k. Check remaining settings of CH 2 VOLTS/DIV switch for:
 Positive step aberrations within 3%; risetime of 3.5 nanoseconds, or less; negative step aberrations within 5%.
- Check position effect: Positive step aberrations within 5%, negative step aberrations within 7%.
- 24. Adjust CH 1 High-Frequency Compensation
 - a. Repeat step 23-c with adjustments C27, C33, C105, R105,
 C122, R122, C149, and R149.
 - b. Adjust R47, C47 for step 23-f.
 - c. Adjust R48, C48 for step 23-i.
- 25. Check Vertical Amplifier Bandwidth
 - a. Use the High-Frequency Constant-Amplitude Signal Generator (067-0532-01): 5 division display of 3 MHz reference signal.
 - b. From 5 mV to 5 V settings of both VOLTS/DIV switches, check frequency is at least 100 MHz (0° C to + 40° C) when display is reduced to 3.5 division.
- 26. Check Cascaded Bandwidth and Sensitivity
 - a. Connect CH 1 OUT to CH 2 input through a terminated cable.
 - b. Check sensitivity is at least 1 mV/division.
 - c. Check Bandwidth is at least 50 MHz.

- 27. Check Vertical Channel Isolation and CMRR
 - a. Channel isolation: at least 100:1 at 25 MHz.
 - b. CMRR: at least 10:1 at 20 MHz for signals of 6 divisions or less.
- 28. Check Bandwidth Limit Operation
 - a. Connect 6 division display of a 50 kHz signal to CH 1 input.
 - b. Check frequency is 20 MHz, within 4 MHz, when display is reduced to 4.2 divisions.

SECTION 5 PART III - CALIBRATION

VERTICAL SYSTEM CALIBRATION

- 9. Adjust Vertical Output Centering and Check BEAM FIND
 - a. Connect the DC Voltmeter between TP322 and TP324 (see Fig. 5-8).
 - Adjust the CH 1 POSITION control for 0 volt reading on the meter.
 - c. ADJUST Vertical Output Centering adjustment, R429, to position the trace to the center graticule line.
 - d. Remove the DC Voltmeter lead connections.
 - e. Position the trace off-screen with the CH 1 POSITION and horizontal POSITION controls.
 - f. Push the BEAM FIND button and hold it in.
 - g. CHECK That the trace is brought into the CRT viewing area.
 - h. Release the BEAM FIND button.
- 10. Adjust CH 1 Step Attenuator Balance
 - a. Set the CH 1 VOLTS/DIV switch to 20 mV and the CH 1 INPUT COUPLING switch to GND.
 - Position the trace to the center horizontal graticule line.
 - c. CHECK CRT display for 0.2 division or less of trace shift between adjacent switch positions when rotating the CH 1 VOLTS /DIV switch from 20 mV to 5 mV.

- ADJUST CH 1 Step Atten Bal adjustment, R25, (see Fig. 5-10) for minimum trace shift when rotating the CH 1 VOLTS/ DIV switch from 20 mV to 5 mV.
- 11. Adjust CH 1 Variable Volts/Division Balance
 - Position the trace to the center horizontal graticule line.
 - b. CHECK That the CH 1 UNCAL light comes on when the VAR control is out of the detent position.
 - c. CHECK CRT display for 1 division or less of trace shift when rotating the CH 1 VAR control through its range.
 - ADJUST CH 1 Variable Balance adjustment, R120 (see
 Fig. 5-11) for minimum trace shift when rotating the
 CH 1 VAR control through its range.
 - e. Return the CH 1 VAR control to the detent position.

- 12. Adjust CH 1 Position Centering
 - a. Set the CH 1 VOLTS/DIV switch to 50 mV.
 - b. Connect the output of the Medium-Frequency Constant-Amplitude Signal Generator (Type 191) to the CH 1 input via a GR-to-BNC adapter, a 42-inch 50Ω BNC cable, and a 50Ω BNC termination.

- Adjust the Medium-Frequency signal generator for a 2.4 division, 50 kHz output signal.
- d. Switch the CH 1 VOLTS/DIV to the 5 mV setting.
- e. CHECK The top of the CRT display can be positioned below the center horizontal graticule line, and that the bottom of the display can be positioned above the center horizontal graticule line.
- f. ADJUST CH 1 Position Centering adjustment, R115, (See Fig. 5-11) so the top of the CRT display can be positioned below the center horizontal graticule line and the bottom of the display can be positioned above the center horizontal graticule line.
- g. INTERACTION Between CH 1 Position Centering and CH 1 Variable Volts/Division Balance adjustments. Readjust both until no interaction is visible.
- 13. Adjust CH 2 Step Attenuator Balance
 - a. Connect the output of the Standard Amplitude Calibrator to the CH 2 input via a 42-inch 50 Ω BNC cable.
 - b. Set the VERT MODE switch to CH 2; CH 2 VOLTS/DIV switch to 20 mV.
 - c. Position the trace to the center horizontal graticule line.
 - d. CHECK CRT display for 0.2 division or less of trace
 shift between adjacent switch positions when rotating the
 CH 2 VOLTS/DIV switch from 20 mV to 5 mV.

- ADJUST CH 2 Step Atten Bal adjustment, R75, (See
 Fig. 5-12) for minimum trace shift when rotating the
 CH 2 VOLTS/DIV switch from 20 mV to 5 mV.
- 14. Adjust CH 2 Variable Volts/Division Balance
 - a. CHECK That the CH 2 UNCAL light comes on when theCH 2 VAR control is out of the detent position.
 - b. CHECK CRT display for 1 division or less of trace shift when rotating the CH 2 VAR control through its range.
 - ADJUST CH 2 Variable Balance adjustment, R220, (see
 Fig. 5-13) for minimum trace shift when rotating the
 CH 2 VAR control through its range.
 - d. Return the VAR control to the detent position.
 - e. Disconnect the CH 2 test setup.
- 15. Adjust CH 2 Position Centering
 - a. Move the test signal from CH 1 to the CH 2 input.
 - b. Set the CH 2 VOLTS/DIV switch to 50 mV; and the VERT MODE switch to CH 2.
 - Adjust the Medium-Frequency signal generator for a 2.4
 division, 50 kHz output signal.
 - d. Set the CH 2 VOLTS/DIV switch to 5 mV.
 - e. CHECK Top of CRT display can be positioned below the center horizontal graticule line, and the bottom of the display can be positioned above the center horizontal graticule line.

- f. ADJUST CH 2 Position Centering adjustment, R215, (see Fig. 5-13) so that the top of the CRT display can be positioned below the center horizontal graticule line, and the bottom of the display can be positioned above the center horizontal graticule line.
- g. INTERACTION Between CH 2 Position Centering and CH 2 Variable Volts/Division Balance adjustments. Readjust both until no interaction occurs.
- 16. Check CH 2 INVERT Balance
 - a. Set the CH 2 INPUT COUPLING switch to GND.
 - b. Position the trace to the center horizontal graticule line.
 - c. Push the INVERT button.
 - d. CHECK For less than 2 divisions of trace shift when switching from normal to inverted.
- 17. Check Probe Indicator Lights
 - a. Set both VOLTS/DIV switches to 5 mV.
 - b. Connect the 465's X10 probe to the CH 1 input.
 - c. CHECK Light under 5 mV is extinguished and the light under 50 mV comes on.
 - d. Set VERT MODE switch to CH 2.
 - e. Move the probe to the CH 2 input.
 - f. CHECK Light under 5 mV is extinguished and the light under 50 mV comes on.
 - g. Remove the X10 probe.

- 18. Check INPUT COUPLING Switches
 - a. Set both INPUT COUPLING switches to DC.
 - b. Connect the Standard Amplitude Calibrator output to the CH 2 input via a 42-inch 50Ω BNC cable.
 - c. Adjust the Standard Amplitude Calibrator for 20 mV output.
 - d. Position the bottom of the display to the center horizontal graticule line.
 - e. Set CH 2 INPUT COUPLING switch to GND.
 - f. CHECK For no vertical deflection; trace is at center horizontal graticule line.
 - g. Set CH 2 INPUT COUPLING switch to AC.
 - h. CHECK That display is centered about the center horizontal graticule line.
 - i. Move the test signal to CH 1.
 - j. Position the bottom of the display to the center horizontal graticule line.
 - k. Set CH 1 INPUT COUPLING switch to GND.
 - 1. Repeat step 13-f.
 - m. Set CH 1 INPUT COUPLING switch to AC.
 - n. Repeat step 13-h.
 - o. Disconnect the test setup.
- 19. Adjust CH 1 and Vertical Output Gains
 - a. Set the VERT MODE switch to CH 1, the CH 1 VOLTS/DIV switch to 5 mV, and the CH 1 INPUT COUPLING switch to DC.
 - b. Connect the output of the Standard Amplitude Calibrator to the CH 1 input via a 42-inch 50 Ω BNC cable.
 - c. Adjust the Standard Amplitude Calibrator for a 20 mV output.
 - d. Set the Test Oscilloscope: Vertical Mode to ADD, Channel2 to INVERT, and both VOLTS/DIV switches to 5 mV.

- e. Connect two X10 probes from the Test Oscilloscope to TP322 and TP324 on the Preamp board of the 465 (see Fig. 5-8).
- f. CHECK The Test Oscilloscope for a 200 mV (peak-to-peak) signal between TP322 and TP324.
- g. ADJUST CH 1 Gain adjustment, R118, (see Fig. 5-14) for 200 mV (peak-to-peak) display on the Test Oscilloscope. (NOTE: This is a nominal value for this adjustment and may vary from instrument to instrument.)
- h. Remove the X10 probes from TP322 and TP324.
- CHECK CRT display for 4 divisions of deflection within 3% (0.12 division).
- j. ADJUST Vertical Output Gain adjustment, R466, for 4 divisions of deflection.
- k. CHECK Accuracy of CH 1 VOLTS/DIV switch using the settings given in Table 5-6 to see if the deflection factor accuracy for each position is within 3%.

20. Adjust CH 2 Gain

- a. Set the CH 2 VOLTS/DIV switch to 5 mV, the VERT MODE switch to CH 2, and the CH 2 INPUT COUPLING switch to DC.
- b. Move the test signal to CH 2 input connector.
- c. Adjust the Standard Amplitude Calibrator for a 20 mV output.
- d. CHECK CRT display for 4 divisions of deflection within 3%.
- e. ADJUST CH 2 Gain adjustment, R218, (see Fig. 5-16) for
 4 divisions of deflection.

- f. CHECK Accuracy of the CH 2 VOLTS/DIV switch using the settings given in Table 5-6. Deflection factor accuracy to be within 3% in all switch positions.
- 21. Check CH 2 and CH 1 Variable Volts/Division Ranges
 - Adjust the Standard Amplitude Calibrator for 5 divisions of deflection.
 - b. Rotate the CH 2 VAR control fully counterclockwise.
 - c. CHECK CRT display reduces to less than 2 divisions.
 - d. Move the test signal to the CH 1 input connector.
 - e. Set the VERT MODE switch to CH 1.
 - f. Adjust the Standard Amplitude Calibrator for 5 divisions of deflection.
 - g. Rotate the CH 1 VAR control fully counterclockwise.
 - h. CHECK CRT display reduces to less than 2 divisions.
 - i. Return the VAR controls to the detent positions.
- 22. Check Vertical ADD Mode Operation
 - a. Set both VOLTS/DIV switches to 5 mV and both INPUT COUPLING switches to DC.
 - b. Connect the Standard Amplitude Calibrator output to both channel inputs via a dual input coupler.
 - c. Adjust the Standard Amplitude Calibrator for a 10 mV output.
 - d. Set the VERT MODE switch to ADD.
 - e. CHECK For 4 divisions of deflection, within $\pm 3\%$ unadjusted, or $\pm 0.5\%$ adjusted.

- 23. Check Compression and Expansion
 - a. Set the CH 2 INPUT COUPLING switch to GND and the VERT MODE switch to CH 1.
 - Adjust the CH 1 VAR control for 2 divisions of deflection centered about the center horizontal graticule line.
 - c. Position the top of the display to the top graticule line.
 - d. CHECK CRT display for 0.1 division or less of compression or expansion.
 - Position the bottom of the display to the bottom graticule line.
 - f. CHECK CRT display for 0.1 division or less of compression or expansion.
 - g. Set the CH 1 VAR control to the detent position.
 - h. Disconnect the test setup.
- 24. Check Vertical ALT Mode Operation
 - a. Set the VERT MODE switch to ALT, and the A Trigger LEVEL control fully clockwise.
 - b. Position the two traces 2 divisions apart.
 - c. CHECK That the sweeps alternate at all settings of the A TIME/DIV switch except X-Y.
- 25. Check Vertical CHOP Mode Operation
 - a. Set the A TIME/DIV switch to 1 μ s, the A SOURCE switch to NORM, the A SLOPE switch to +, the VERT MODE switch to CHOP, and both INPUT COUPLING switches to GND.
 - b. Position the two traces about 4 divisions apart.

- c. Adjust the A LEVEL control for a stable display.
- d. CHECK For complete blanking of switching transients between chopped segments (see Fig. 5-17).
- e. CHECK Duration of each cycle is about four divisions.
- 26. Adjust Vertical Output Low-Frequency Compensation
 - a. Set the A TIME/DIV switch to 20 μs , the VERT MODE switch to CH 1, both INPUT COUPLING switches to DC, and both VOLTS/DIV switches to 5 mV.
 - b. Connect the fast-rise output of the Square-Wave Generator (Type 106) to the CH 1 input via a GR-to-BNC adapter, 42inch 50 α BNC cable, a X10 BNC attenuator, and a 50 α BNC termination.
 - c. Adjust the Square-Wave Generator for a 5 division 100 kHz output signal.
 - d. CHECK CRT display for flat-top waveform with no more than 3% overshoot or roll-off on the leading edge.
 - e. ADJUST R425, R426 for best flat-top waveform.
 - f. INTERACTION Between adjustments in this step. Readjust if necessary for total optimum response.
- 27. Adjust CH 1 VOLTS/DIV Compensation
 - a. Add a 20 pf Normalizer to the test setup between the 50 Ω BNC termination and the CH 1 input.
 - b. Move the test setup from the fast-rise output to the high-amplitude output of the Square-Wave Generator (Type 106).

- c. Adjust the Square-Wave Generator for a five division 1 kHz display. Add or remove attenuators as necessary to maintain a five division display throughout this step.
- d. CHECK CRT display for flat-top waveform with no more than 2% overshoot or roll-off on the leading edge.
- e. ADJUST Cl (see Fig. 5-19) with a low-capacitance screwdriver, for best flat-top waveform.
- f. Set the CH 1 VOLTS/DIV switch to 50 mV.
- g. CHECK CRT display for flat-top waveform with no more than 2% overshoot or roll-off on the leading edge.
- h. ADJUST Channel 1 Cl3 (see Fig. 5-19) for best flat-top waveform, and Channel 1 Cl2 for the best corner with a low-capacitance screwdriver.
- CAL AID Remove the 20 pf Normalizer when adjusting or checking the corner response.
- j. INTERACTION Between Channel 1's Cl3 and Cl2. Readjust both for total optimum response.
- k. Set the CH 1 VOLTS/DIV switch to 0.5V.
- CHECK CRT display for flat-top waveform with no more than 2% overshoot or roll-off on the leading edge.
- m. ADJUST Channel 1 Cl1 (see Fig. 5-19) for best flat-top waveform, and Channel 1 Cl0 for the best corner, with the low-capacitance screwdriver.
- n. Set the CH 1 VOLTS/DIV switch to 5 V.
- O. CHECK CRT display for flat-top waveform with no more than 2% overshoot or roll-off on the leading edge.

- 28. Adjust CH 2 VOLTS/DIV Compensation
 - a. Set the VERT MODE switch to CH 2 and move the test signal to the CH 2 input.
 - Adjust the Square-Wave Generator (Type 106) for a five division display. Remove or add attenuators as necessary to maintain a five division display.
 - c. CHECK CRT display for flat-top waveform with no more than 2% overshoot or roll-off on the leading edge.
 - d. ADJUST C51 (see Fig. 5-20) with the low-capacitance screwdriver, for best flat-top waveform.
 - e. Set the CH 2 VOLTS/DIV switch to 50 mV.
 - f. CHECK CRT display for flat-top waveform with no more than 2% overshoot or roll-off on the leading edge.
 - g. ADJUST Channel 2 Cl3 (see Fig. 5-20) for the best flattop waveform, and Channel 2 Cl2 for the best corner, with the low-capacitance screwdriver.
 - h. CAL AID Remove the 20 pf Normalizer when adjusting or checking the corner response.
 - INTERACTION Between Channel 2's Cl3 and Cl2. Readjust both for total optimum response.
 - j. Set the CH 2 VOLTS/DIV switch to 0.5 V.
 - k. CHECK CRT display for flat-top waveform with no more than 2% overshoot or roll-off on the leading edge.
 - ADJUST Channel 2 Cll (see Fig. 5-20) for best flat-top waveform, and Channel 2 ClO for the best corner, with the low-capacitance screwdriver.
 - m. INTERACTION Between Channel 2's Cll and ClO. Readjust both for optimum response.

- n. Set the CH 2 VOLTS/DIV switch to 5 V.
- O. CHECK CRT display for flat-top waveform with no more than 2% overshoot or roll-off on the leading edge.
- p. Disconnect the test setup.
- 29. Adjust Channel 2 and Vertical Output High-Frequency Compensation
 - a. Set both VOLTS/DIV switches to 5 mV, the VERT MODE switch to CH 2, the A TIME/DIV switch to 0.05 μs , and the A SLOPE TO +.
 - b. Connect the Fast-Rise High-Amplitude Pulse Generator (Type 109) to the CH 2 input via a GR-to-BNC adapter, 42-inch 50 Ω BNC cable, two X10 BNC attenuators, and a 50 Ω BNC termination.
 - c. Set the Pulse Generator polarity to + and the voltage range to 50 V.
 - Adjust the Pulse Generator for five divisions of deflection. Remove or add attenuators as necessary to maintain a five division display throughout this step.
 - e. CHECK CRT display for risetime of 3.5 nanoseconds or less.
 - f. CHECK CRT display for flat-top waveform with 3% or less of aberrations.
 - g. ADJUST C77, C83, C205, R205, C249, R249, R422, C422, R438, C438 and R427, with a low-capacitance screwdriver, for the best flat-top waveform (see Fig. 5-21).

- h. Set the Pulse Generator polarity to and the 465 A SLOPE switch to -.
- CHECK CRT display for flat-bottom waveform with 5% or less of aberrations.
- j. CAL AID The above adjustments also affect the negativestep aberrations. Adjust for optimum response and minimum aberrations on both the positive- and negative-going steps.
- k. Set the A SLOPE control to + and the Pulse Generator polarity to +.
- 1. Set the CH 2 VOLTS/DIV switch to 10 mV.
- m. CHECK CRT display for risetime of 3.5 nanoseconds or less.
- n. CHECK CRT display for flat-top waveform with 3% or less of aberrations.
- ADJUST R97 and C97 (see Fig. 5-21) for optimum risetime and aberrations.
- p. Set the Pulse Generator polarity to and the 465 A SLOPE switch to -.
- q. CHECK CRT display for best corner and flat-bottom waveform with 5% or less aberrations.
- r. Set the CH 2 VOLTS/DIV switch to 20 mV and the A SLOPE switch to +.
- s. Set the Pulse Generator to +.
- CHECK CRT display for risetime of 3.5 nanoseconds or less.

- u. CHECK CRT display for flat-top waveform with 3% or less of aberrations.
- v. ADJUST R98 and C98 (see Fig. 5-21) for optimum risetime and aberrations.
- w. Set the Pulse Generator polarity to and the 465 A SLOPE switch to -.
- x. CHECK CRT display for flat-bottom waveform with 5% or less of aberrations.
- y. Set the CH 2 VOLTS/DIV switch to 50 mV.
- z. Set the A SLOPE switch to + and the Pulse Generator polarity to +.
- aa. CHECK CRT display for risetime of 3.5 nanoseconds or less.
- ab. CHECK CRT display for flat-top waveform with 3% or less of aberrations.
- ac. Set the Pulse Generator polarity to and the **46**5 A SLOPE switch to -.
- ad. CHECK CRT display for best corner and flat-bottom waveform with 5% or less aberrations.
- ae. Repeat step 29-z through 29-ad for each setting of the CH 2 VOLTS/DIV switch from 0.1 V to 5 V.
- 30. Check CH 2 Position Effect
 - a. Set the CH 2 VOLTS/DIV switch to 5 mV.
 - Adjust the Pulse Generator (Type 109) for five divisions of display.

- c. Adjust the A LEVEL control for a stable display.
- d. Position the top of the display to the bottom graticule line.
- e. CHECK CRT display for less than 5% aberrations.
- f. Set the Pulse Generator polarity to and the 465 A SLOPE switch to -.
- g. Position the bottom of the display to the top graticule line.
- h. CHECK CRT display for less than 7% aberrations.
- 31. Adjust CH 1 High-Frequency Compensation
 - a. Move the test signal from CH 2 to the CH 1 input.
 - b. Set the A TIME/DIV switch to 0.05 μs , the A SLOPE switch to +, and the VERT MODE switch to CH 1.
 - c. Set the Fast-Rise High-Amplitude Pulse Generator (Type 109) to + and adjust the Pulse Generator for five divisions of deflection. Remove or add attenuators as necessary to maintain a five division display throughout this step.
 - d. CHECK CRT display for risetime of 3.5 nanoseconds or less.
 e. CHECK CRT display for flat-top waveform with 3% or less of aberrations.
 - f. ADJUST C27, C33, C105, R105, R122, C122, C149, and R149 (see Fig. 5-23) with a low-capacitance screwdriver, for the best flat-top waveform.
 - g. Set the Pulse Generator polarity to and the 465 A SLOPE switch to -.

- h. CHECK CRT display for flat-bottom waveform with 5% or less of aberrations.
- i. CAL AID The above adjustments also affect the negativestep aberrations. Adjust them for optimum response and minimum aberrations on both the positive-and negativegoing steps.
- j. Set the A SLOPE control to + and the Pulse Generator polarity to +.
- k. Set the CH 1 VOLTS/DIV switch to 10 mV.
- CHECK CRT display for risetime of 3.5 nanoseconds or less.
- m. CHECK CRT display for flat-top waveform with 3% or less of aberrations.
- n. ADJUST R47 and C47 (see Fig. 5-23) for optimum risetime and aberrations.
- Set the Pulse Generator polarity to and the 465 A SLOPE switch to -.
- p. CHECK CRT display for best corner and flat-bottom waveform with 5% or less aberrations.
- q. Set the CH 1 VOLTS/DIV switch to 20 mV and the A SLOPE switch to +.
- r. Set the Pulse Generator polarity to +.
- s. CHECK CRT display for risetime of 3.5 nanoseconds or less.
- t. CHECK CRT display for flat-top waveform with 3% or less of aberrations.
- ADJUST R48 and C48 (see Fig. 5-23) for optimum risetime and aberrations.
- v. Set the Pulse Generator polarity to and the 465 A SLOPE switch to -.
- w. CHECK CRT display for flat-bottom waveform with 5% or less of aberrations.
- x. Set the CH 1 VOLTS/DIV switch to 50 mV.
- y. Set the A SLOPE switch to + and the Pulse Generator polarity to +.
- z. CHECK CRT display for risetime of 3.5 nanoseconds or less.
- aa. CHECK CRT display for flat-top waveform with 3% or less of aberrations.
- ab. Set the Pulse Generator polarity to and the 465 A SLOPE switch to -.
- ac. CHECK CRT display for best corner and flat-bottom waveform with 5% or less aberrations.
- ad. Repeat step 31-y through 31-ac for each setting of the CH 1 VOLTS/DIV switch from 0.1 V to 5 V.
- 32. Check CH 1 Position Effect
 - a. Set the CH 1 VOLTS/DIV switch to 5 mV.
 - Adjust the Pulse Generator (Type 109) for five divisions of display.
 - c. Adjust the A LEVEL control for a stable display.
 - Position the top of the display to the bottom graticule line.

- e. CHECK CRT display for less than 5% aberrations.
- f. Set the Pulse Generator polarity to and the 465 A SLOPE switch to -.
- g. Position the bottom of the display to the top graticule line.
- h. CHECK CRT display for less than 7% aberrations.
- i. Disconnect the test setup.
- 33. Check Vertical Amplifier Bandwidth
 - a. Connect the output of the High-Frequency Constant-Amplitude Signal Generator (067-0532-01) to the CH 1 input via a GR-to-BNC adapter, X10 BNC attenuator, and a 50 Ω BNC termination.
 - b. Set the TRIG MODE switch to AUTO, A TIME/DIV switch to 0.2 ms, both VOLTS/DIV switches to 5 mV and the VERT MODE switch to CH 1.
 - c. Adjust the High-Frequency signal generator output amplitude for a five division display of a 3 megahertz reference signal.
 - d. Without changing the output amplitude, increase the output frequency of the signal generator until the display is reduced to 3.5 divisions.
 - e. CHECK Output frequency of the signal generator must
 be at least 100 megahertz (0°C to +40°C).
 - f. Repeat this bandwidth check procedure, steps 33-c through 33-e, for settings of the CH 1 VOLTS/DIV switch from 10 mV to 2 V.

- g. Move the test signal to CH 2 input, set the VERT MODE switch to CH 2, and the CH 2 INPUT COUPLING switch to DC.
- Repeat this bandwidth check, step 33-c through 33-e, for settings of the CH 2 VOLTS/DIV switch from 5 mV to 2 V.
- i. Disconnect the test setup.
- 34. Check Cascaded Gain and Bandwidth
 - a. Set both INPUT COUPLING switches to DC, the VERT MODE switch to CH 2, both VOLTS/DIV switches to 5 mV, and the A TIME/DIV switch to 1 ms.
 - b. Connect the CH 1 VERT SIGNAL OUT (on the rear panel) to the CH 2 input connector via a 42-inch 50 Ω BNC cable and a 50 Ω BNC termination.
 - c. Connect the Standard Amplitude Calibrator to the CH 1 input via a 42-inch 50 Ω BNC cable.
 - d. Adjust the Standard Amplitude Calibrator for a 5 mV output.
 - e. CHECK CRT display for at least five divisions of deflection.
 - f. Remove the test setup from the CH 1 input.
 - g. Connect the output of the Medium-Frequency Constant-Amplitude Signal Generator (Type 191) to the CH 1 input via a GR-to-BNC adapter, 42-inch 50 Ω BNC cable, X10 BNC attenuator, and a 50 Ω BNC termination.
 - h. Adjust the Medium-Frequency signal generator for a five division display of a 50 kilohertz reference signal.

- Without changing the output amplitude of the signal generator, increase the output frequency until the display is reduced to 3.5 divisions.
- j. CHECK Output frequency of the signal generator must be at least 50 megahertz.
- k. Disconnect the test setup.
- 35. Check Vertical Channel Isolation
 - Move the test signal to the CH 2 input after removing the X10 attenuator.
 - b. Set CH 2 VOLTS/DIV switch to 0.2 V, CH 1 INPUT COUPLING switch to GND, and VERT MODE switch to CH 2.
 - c. Adjust the Medium-Frequency signal generator for a 2 division display of a 25 megahertz signal.
 - d. Set both VOLTS/DIV switches to 20 mV and VERT MODE switch to CH 1.
 - e. CHECK CRT display for no more than 0.2 division of deflection.
 - f. Move the CH 2 input test setup to the CH 1 input.
 - g. Set the CH 1 INPUT COUPLING switch to DC, CH 2 INPUT COUPLING switch to GND, CH 1 VOLTS/DIV switch to 0.2 V.
 - h. Adjust the Medium-Frequency signal generator for a 2 division display of a 25 megahertz signal.
 - i. Set VERT MODE switch to CH 2.
 - j. CHECK CRT display for no more than 0.2 division of deflection.
 - k. Disconnect the test setup.

- 36. Check Common Mode Rejection Ratio
 - a. Set both VOLTS/DIV switches to 5 mV, both INPUT COUPLING switches to DC, the VERT MODE switch to CH 1, and push the CH 2 INVERT switch.
 - b. Connect the output of the Medium-Frequency Constant-Amplitude Signal Generator (Type 191) to the CH 1 and 2 inputs via a GR-to-BNC adapter, 42-inch 50 Ω BNC cable, X10 BNC attenuator, 50 Ω BNC termination, and a dual input coupler.
 - c. Adjust the Medium-Frequency signal generator for a six division display of a 50 kHz signal.
 - d. Set the VERT MODE switch to ADD.
 - e. Increase output frequency of the Medium-Frequency signal generator to 20 MHz.
 - f. Note the amount of vertical deflection for use in step 36-h.
 - g. Set the VERT MODE switch to CH 1.
 - h. CHECK That the amount of vertical deflection is at least 10 times that noted in step 36-f.
 - i. Release the CH 2 INVERT switch and disconnect the test setup.
- 37. Check Bandwidth Limit Operation
 - a. Pull the 20 MHz BW/TRIG VIEW button to BW and set the CH 1 INPUT COUPLING switch to DC.

- b. Connect the Medium-Frequency Constant-Amplitude Signal Generator (Type 191) to the CH 1 input via 42-inch 50 Ω BNC cable and a 50 Ω BNC termination.
- c. Adjust the Medium-Frequency signal generator for a six division display of a 50 kilohertz signal.
- Increase the output frequency of the signal generator until the display is reduced to 4.2 divisions.
- e. CHECK Output frequency of the signal generator is between 16 and 24 megahertz.
- f. Disconnect the test setup.

ELECTRICAL PARTS LIST

Replacement parts should be ordered from the Tektronix Field Office or Representative in your area. Changes to Tektronix products give you the benefit of improved circuits and components. Please include the instrument type number and serial number with each order for parts or service.

ABBREVIATIONS AND REFERENCE DESIGNATORS

Α	Assembly, separable or	FL	Filter	PTM	paper or plastic, tubular
	repairable	н	Heat dissipating device		molded
AT	Attenuator, fixed or variable		(heat sink, etc.)	R	Resistor, fixed or variable
В	Motor	HR	Heater	RT	Thermistor
BT	Battery	J	Connector, stationary portion	S	Switch
С	Capacitor, fixed or variable	K	Relay	Т	Transformer
Cer	Ceramic	L	Inductor, fixed or variable	TP	Test point
CR	Diode, signal or rectifier	LR	Inductor/resistor combination	U	Assembly, inseparable or
CRT	cathode-ray tube	M	Meter		non-repairable
DL	Delay line	Q	Transistor or silicon-	V	Electron tube
DS	Indicating device (lamp)		controlled rectifier	Var	Variable
Elect.	Electrolytic	Р	Connector, movable portion	VR	Voltage regulator (zener diode,
EMC	electrolytic, metal cased	PMC	Paper, metal cased		etc.)
EMT	electrolytic, metal tubular	PT	paper, tubular	WW	wire-wound
F	Fuse			Y	Crystal

Ckt. No.	Part No.	Eff	Disc	Description
ASSEMBLY				
	670-3023-00	хво40000		OUTPUT Circuit Board Assembly
CAPACITORS				
C402	283-0032-00			470 pF, Cer, 500 V, 5%
C412	283-0032-00			470 pF, Cer, 500 V, 5%
C422	281-0139-00			2.5-9 pF, Var, Cer, 100 V
C425	281-0638-00			240 pF, Cer, 500 V, 5%
C426	281-0580-00			470 pF, Cer, 500 V, 10%
C427	281-0524-00			150 pF, Cer, 500 V, 20%
C430	283-0000-00			0.001 μF, Cer, 500 V, +100%-0%
C432	283-0065-00			0.001 µF, Cer, 100 V, 5%
C437	281-0629-00			33 pF, Cer, 600 V, 5%
C438	281–0123– 00			5-25 pF, Var, Cer, 100 V
C439	281-0617-00			15 pF, Cer, 200 V, 10%
C442	283-0065-00			0.001 µF, Cer, 100 V, 5%
C444	281-0651- 00			47 pF, Cer, 200 V, 5%
C469	281-0500-00			2.2 pF, Cer, 500 V, ±0.5 pF
C481	283-0032-00			470 pF, Cer, 500 V, 5%
C482	283-0000-00			0.001 µF, Cer, 500 V, +100%-0%
C485	283-0003-00			0.01 µF, Cer, 150 V, +80%-20%
C491	283-0032-00			470 pF, Cer, 500 V, 5%
C492	283-0000-00			0.001 µF, Cer, 500 V, +100%-0%
C498	290-0523-00			2.2 µF, Elect., 20 V, 20%
C499	290-0523-00			2.2 µF, Elect., 20 V, 20%

M20,159/573

ELECTRICAL PARTS LIST (cont)

Ckt. No.	Tektronix Part No.	Serial/Model Eff	No. Disc	Description
DIODES				
CR434	152-0422-00			Silicon VVC PG1084
CR451	152-0141-02			Silicon. 1N4152
CR452	152-0141-02			Silicon $1N4152$
VR464	152-0195-00			Zener selected from $1N751A = 0.4 W = 5.1 V = 5\%$
VR481_VR491	152-0395-00	XB060000		Zener, $1N749A = 0.4 W = 4.3 V = 5\%$
INDUCTORS	132 0393 00			
L464	108-0570-00			75 nH
L474	108-0570-00			75 nH
L498	108-0440-00			8 μH
L499	108-0440-00			8 µН
LR483	108-0328-00			0.3 μ H (wound on a 220 Ω , 1/4 W, 5% resistor)
LR493 .	108-0328-00			0.3 μ H (wound on a 220 Ω , 1/4 W, 5% resistor)
RESISTORS				
R401	321-0068-00			49.9 Ω, 1/8 W, 1%
R402	315-0221-00			220 Ω, 1/4 W, 5%
R403	321-0097-00			100 Ω, 1/8 W, 1%
R404	321-0097-00			100 Ω, 1/8 W, 1%
R406	315-0242-00			2.4 k Ω , 1/4 W, 5%
R408	321-0121-00			178 Ω, 1/8 W, 1%
R409	321-0189-00			909 Ω, 1/8 W, 1%
R411	321-0068-00			49.9 Ω, 1/8 W, 1%
R412	315-0221-00			220 Ω, 1/4 W, 5%
R413	321-0097-00			100 Ω, 1/8 W, 1%
R414	321-0097- 00			100 Ω, 1/8 W, 1%
R416	315-0242-00			$2.4 \text{ k}\Omega, 1/4 \text{ W}, 5\%$
R418	311-1237-00			$1 k\Omega$, Var
R419	321-0189-00			909 û, 1/8 W, 1%
R421	321-0089-00			82.5 Ω, 1/8 W, 1%
R422	311-1278-00			250 Ω, Var
R423	315-0101-00			100 Ω, 1/4 W, 5%
R424	315-0101-00			100 Ω, 1/4 W, 5%
R425	311-1238-00			5 k Ω , Var
R426	311-1228-00			$10 \ k\Omega$, Var
R427	311-1225-00			l kΩ, Var
P /20				
R430	323-0159-00			442 M, 1/2 W, 1%
R431	317-0220-00			22 Ω, 1/8 W, 5%
R432	315-0131-00			$130 \ \Omega, 1/4 \ W, 5\%$
R433	323-0118-00			165 Ω , 1/2 W, 1%
R434	315-0100-00			$10 \ \Omega, \ 1/4 \ W, \ 5\%$
R435	321-0059-00			40.2 %, 1/8 W, 1%
R436	317-0100-00			10 Ω, 1/8 W, 5%
R437	317-0561-00			560 Ω, 1/8 W, 5%
R438	311-1260-00			250 Ω, Var
R440	323-0159-00			442 Ω, 1/2 W, 1%
R441	317-0220-00			22 Ω, 1/8 W, 5%
R442	315-0131-00			130 Ω, 1/4 W, 5%

M20,159/573

•

1

#

-

-

-

لتفع

-

ELECTRICAL PARTS LIST (cont)

Ckt. No.	Tektronix Part No.	Serial/Model Eff	No. Disc	Description	
RESISTORS (cont)				
R443	323-0118-00			165 Ω, 1/2 W, 1%	
R444	315-0100-00			10 Ω, 1/4 W, 5%	
R445	321-0059-00			40.2 Ω, 1/8 W, 1%	
R448	315-0622-00			$6.2 \text{ k}\Omega, 1/4 \text{ W}, 5\%$	
RT448	307-0181-00			100 kΩ, Thermal	
R449	321-0193-00			$1 k\Omega, 1/8 W, 1\%$	
R451	315-0820-00			82 Ω, 1/4 W, 5%	
R452	315-0301-00			300 Ω, 1/4 W, 5%	
R453	323-0157-00			422 Ω, 1/2 W, 1%	
R462	321-0205-00			1.33 kΩ, 1/8 W, 1%	
R463	321-0219-00			$1.87 \text{ k}\Omega, 1/8 \text{ W}, 1\%$	
R464	321-0093-00			90.9 Ω, 1/8 W, 1%	
R465	321-0126-00			200 Ω, 1/8 W, 1%	
R466	311-1226-00			2.5 kΩ, Var	
R468	321-0031-00			20.5 Ω, 1/8 W, 1%	
R469	323-0072-00			54.9 Ω, 1/2 W, 1%	
R474	321-0093-00			90.9 Ω, 1/8 W, 1%	
R475	321-0126-00			200 ଯ, 1/8 W, 1%	
R478	321-0031-00			20.5 Ω, 1/8 W, 1%	
R480	315-0100-00			10 Ω, 1/4 W, 5%	
R481	315-0820-00			82 Ω, 1/4 W, 5%	
R482	315-0820-00			82 Ω, 1/4 W, 5%	
R483	310-0700-00			430 Ω, 4 W, WW, 1%	
R485	301-0100-00			10 Ω, 1/2 W, 5%	
R491	315-0820-00			82 Ω, 1/4 W, 5%	
R492	315-0820-00			82 Ω, 1/4 W, 5%	
R493	310-0700-00			430 Ω, 4 W, WW, 1%	
R498	315-0100-00			10 Ω, 1/4 W, 5%	
R499	315-0100-00			10 Ω, 1/4 W, 5%	
TRANSISTORS					
Q402	151-0212-00			Silicon, NPN, selected from A485	
Q406	151-0212-00			Silicon, NPN, selected from A485	
Q412	151-0212-00			Silicon, NPN, selected from A485	
Q416	151-0212-00			Silicon, NPN, selected from A485	
Q432	151-0212-00			Silicon, NPN, selected from A485	
Q442	151-0212-00			Silicon, NPN, selected from A485	
Q462	151-0434-00			Silicon, PNP, 2N4261	
Q468	151-0222-00			Silicon, NPN, selected from 2N4251	
Q472	151-0434-00			Silicon, PNP, 2N4261	
Q478	151-0222-00			Silicon, NPN, sleected from 2N4251	
Q482	151-0446-00			Silicon, NPN, selected from 2N3866	
Q492	151-04 46 -00			Silicon, NPN, selected from 2N3866	

M20,159/573

MECHANICAL PARTS LIST

Replacement parts should be ordered from the Tektronix Field Office or Representative in your area. Changes to Tektronix products give you the benefit of improved circuits and components. Please include the instrument type number and serial number with each order for parts or service.

ABBREVIATIONS

BHB	binding head brass	h	height or high	ОНВ	oval head brass
BHS	binding head steel	hex.	hexagonal	OHS	oval head steel
CRT	cathode-ray tube	HHB	hex head brass	РНВ	pan head brass
csk	countersunk	HHS	hex head steel	PHS	pan head steel
DE	double end	HSB	hex socket brass	RHS	round head steel
FHB	flat head brass	HSS	hex socket steel	SE	single end
FHS	flat head steel	ID	inside diameter	ТНВ	truss head brass
Fil HB	fillister head brass	lg	length or long	THS	truss head steel
Fil HS	fillister head st ee l	ÓD	outside diameter	w	wide or width

rig. a			Q	
Index	Tektronix	Serial/Model No.	t	Description
No.	Part No.	Eff Disc	у	1 2 3 4 5
	1		1	CIRCUIT BOARD ASSEMBLYOUTPUT
				circuit board assembly includes:
	131-9608-00		4	TERMINAL, pin, 0,365 inch long
	136-0252-01		2	SOCKET, pin connector, 0,178 inch long
	136-0252-04		31	SOCKET, pin connector, 0.178 inch long
	129-0106-00		1	POST, metallic
	131-0761-00		1	TERMINAL POST
	214- 1138-00		2	HEATSINK
	214-0368-00		2	SPRING, heatsink
	343-0097-00		2	CLAMP, transistor, heatsink, plastic
	352-0062-00		2	HOLDER, transistor, heatsink, plastic
	407-1389-00		1	BRACKET, heatsink
	211-0130-00		2	SCREW, $4-40 \times 0.25$ inch. HSS
	211-0033-00		4	SCREW, 4-40 x 0.312 inch, PHS
	211-0012-00		4	SCREW, 4-40 x 0.375 inch, PHS
	210-0627-00		2	RIVET
	210-0004-00		6	WASHER, lock, internal, #4
	210-0599-00		4	NUT, sleeve
	210-0406-00		8	NUT, hex., 4-40 x 0.188 inch

¹Refer to Electrical Parts List for part number.

M20,159/573

أتتحد

199

and a

أكنت

1

-

in the second second





M20,159/573

-

نائیں

÷

أثري

زنن



AMPLIF M20159

ELECTRICAL PARTS LIST AND SCHEMATIC CORRECTION

CHANGE TO:

R428

C481	283-0077-00	3 30 pF, Cer, 500 V
C491	283-0077-00	330 pF, Cer, 500 V
C676	281-0549-00	68 pF, (nominal value) selected
VR481	152-0195-00	Zener, selected from 1N751A, 0.4 W, 5.1 V, 5%
VR491	152-0195-00	Zener, selected from 1N751A, 0.4 W, 5.1 V, 5%
R481	315 - 0101 - 00	100 Ω, 1/4 W, 5%
R491	315-0101-00	100 Ω, 1/4 W, 5%
ADD:		
C428	283-0220-00	0.01 µF, Cer, 50 V
C678		33 pF (nominal value) selected (Added when required)

Add C428 (.01 $\mu F)$ and R428 (12K) in series between junction of C426/C427

315-0123-00 12 kΩ, 1/4 W, 5%

and R426/R427 located on Vertical Output Amplifier B040000-up.

Add C678 (nominal value 33 pF) between emitters of Q678 and Q688. $\langle 11 \rangle$

أتبي

-

ant.

Contraction of the local division of the loc

ألات

أكرد

N

465 EFF All Serial Numbers

For some selected Serial Number instruments the following value may be used for R1585.

R1585 321-0278-00 7.68 kΩ, 1/8 W, 1%

فليتنا

. بروان

W

ELECTRICAL PARTS LIST AND SCHEMATIC CORRECTION

C225	283-0004-00	0.02 μ F, Cer, 150 V (Installed in all instruments)
C1339	283-0081-00	0.1 μ F, Cer, 25 V
VR1524	152 - 0508-00	Zener, 0.4 W, 12.6 V, 5%
Q804	151 - 0199 - 00	Silicon, PNP, MPS-3640
Q854	151 - 0199-00	Silicon, PNP, MPS-3640
R122	311-1224-00	500 Ω, Var
R1448	315-0183-00	18 kΩ, 1/4 W, 5%
R1566	315-0471-00	470 Ω, 1/4 W, 5%
R1585	321-0278-00	7.68 k Ω , 1/8 W, 1% (7.68 k Ω value was use in some selected earlier SN instruments.)
REMOVE :		
C345	283-0004-00	0.02 µF, Cer, 150 V
C354	290 - 0517 - 00	6.8 μF, Elect., 35 V, 20%
C375	283 -0004-0 0	0.02 μF, Cer, 150 V
R1524	315 - 0202 - 00	2 kΩ, 1/4 W, 5%
ADD:		
C165	283-0004-00	0.02 µF, Cer, 150 V
VR1523	152 - 0243 - 00	Zener, 1N965B, 0.4 W, 15 V, 5%
	315-0331-00	330 Ω, 1/4 W, 5%

MECHANICAL PARTS LIST CORRECTION

Page 8-4

Fig. 1-115	369-0031-00	B010100	B109999	1	IMPELLER, fan w/setscrew
	369-0031-01	B110000		1	IMPELLER, fan w/setscrew
	105-0507-00	XB110000		1	STOP, end play
					M20,515 M20,012, M20,129, C1/673 M20,261, M20,385, M20,393, M20,555,

يدر مند



MANUAL CHANGE INFORMATION

At Tektronix, we continually strive to keep up with latest electronic developments by adding circuit and component improvements to our instruments as soon as they are developed and tested.

Sometimes, due to printing and shipping requirements, we can't get these changes immediately into printed manuals. Hence, your manual may contain new change information on following pages.

A single change may affect several sections. Sections of the manual are often printed at different times, so some of the information on the change pages may already be in your manual. Since the change information sheets are carried in the manual until ALL changes are permanently entered, some duplication may occur. If no such change pages appear in this section, your manual is correct as printed.

M.G.K