


CHANGE

DESCRIPTION

1

- a. Title Page: Add "1945" to list of Serial Numbers covered.
- b. Pages 4-3/4-4: Revise R1 on schematics as follows:



Add the following footnotes to the schematics:

- *** Used only on PCA's with series no. 1819.
- † Resistor removed on series no. 1945. If PCA is used in Select Code 17 of the computer mainframe, reinstall 150 ohm resistor in R1 slot located next to U24.

Revise R1 on Assembly drawing as follows:



Add the following footnote to Assembly drawing:

- † Resistor removed on series no. 1945.
- If PCA is used in Select Code 17 of the computer mainframe, reinstall 150 ohm resistor in R1 slot located next to U24.

- c. Page 5-2: On Assembly parts list, add "****" to "R1" and list the following footnote:
 - *** Used only on series no. 1819.
 - R1 resistor deleted totally on series no. 1945